Contents

Product range

A2 Motor-vehicle sensors from Bosch for the aftermarket and workshops

A3 Important information

A4 Motor-vehicle sensors

Applications

B1 Notes for users

B2 Passenger vehicles, Transporters

Cross-reference

C1 Part numbers

C2 Non-Bosch → Bosch

The most comprehensive automotive aftermarket range:
Motor-vehicle sensors from Bosch for the aftermarket and workshops

The number of different sensors used in motor vehicles has increased dramatically in recent years. Bosch supplies replacement parts and diagnosis systems.

Even compact vehicle models are currently fitted with more than 50 individual sensors and sensor-based systems including the electronic stability program ESP for example.

The majority are not subject to wear, but accidents or other influences may cause damage. Of particular relevance to everyday workshop practice are hot-film air-mass meters, wheel-speed sensors, engine-speed sensors, pressure sensors and temperature sensors.

As the leading supplier of original-equipment automotive sensors, Bosch can also offer the most comprehensive aftermarket range in this sector. Suitable replacement parts can be found for nearly all repair applications. In addition, Bosch provides workshops with the essential electronic diagnosis techniques for the identification of defective sensors.

The Bosch sensor range comprises several hundred different types. The types of sensor based on ultra-modern micro electromechanical systems (MEMS) span a field of applications including pressure, acceleration and yaw-rate detection. The wide range of conventional measuring elements available extends from speed sensors and hot-film air-mass meters right through to sensors for automatic air-conditioning systems.

Counterfeit/imitation products:
Important information

Warning about air-mass meters
Only genuine Bosch air-mass meters ensure compliance with the legally prescribed emission values.
The vehicle homologation will be invalidated if use is made of air-mass meters from other manufacturers. In addition, this can result in a considerable loss of engine power and thus higher fuel consumption.

Bosch products guarantee Bosch quality

This means:
- Satisfaction of customer requirements and expectations
- Bosch engineers pursue ambitious quality targets
- Innovation thanks to constant technological progress
- Broad Bosch range → High degree of market coverage
- Top performance, optimum operation
- Long service life
- Maximum reliability
- Compliance with all legal requirements and safety standards
- Excellent workmanship
- Environmental compatibility

Motor-vehicle sensors

Engine-speed and reference-mark sensors

System:
Motronic

Operation:
A ferromagnetic gear wheel with reference mark (tooth gap) is attached to the crankshaft. The speed sensor scans the tooth sequence. The electronic control unit uses the signal to calculate the crankshaft position and speed. Some systems are equipped with 2 sensors. Crankshaft position and speed are then measured separately.

Part number: **0 261 210 ...**

Yaw-rate sensor with acceleration sensor employing micromechanical technology

System:
ESP

Operation:
The measuring element of the yaw-rate sensor is produced using surface micromechanical technology and operates on the Coriolis principle. It makes use of the force of inertia of an oscillating mass in a rotating system. Thanks to its high operating frequency, fully digital evaluation electronics and closed control loop, the yaw-rate sensor element is extremely resistant to mechanical interference and vibration.
The measuring element for the linear lateral and longitudinal acceleration determines vehicle acceleration on the basis of the capacitive change in the micromechanical structures. The high signal-detection and processing resolution in conjunction with the excellent noise characteristics of the sensor ensure a broad measuring range even with only slight lateral acceleration.

Part number:
0 265 005 2.., 0 265 005 6.., 0 265 005 7..

Active (Hall or AMR) speed sensor

System:
ABS/ASR/ESP

Operation:
The sensor ring of the active speed sensor takes the form of a multi-pole ring attached to the wheel hub. The alternately magnetized plastic elements are arranged in annular formation on a non-magnetic metallic carrier. These North and South poles assume the function of the sensor-ring teeth. A typical feature of the active speed sensor is the integration of the measuring element (“Hall” or magnetoresistive), the signal amplifier and the signal conditioning unit into one so-called IC (integrated circuit). There is a constant change in the magnetic flux through the IC as the multi-pole ring rotates. The speed information is transmitted as load-independent current in the form of square-wave pulses.
The frequency of the current pulses is proportional to the wheel speed. Detection is highly sensitive. So-called “intelligent” sensors are even capable of detecting whether the vehicle is moving forwards or backwards or is stationary.

Part number: **0 265 007 ..., 0 265 008 ...**

Passive (inductive) speed sensor

System:
ABS/ASR/ESP

Operation:
A constant magnetic field is generated in the sensor without a power supply.
The sensor is located directly above a sensor ring attached to the wheel hub.
As the sensor ring turns, the constantly alternating sequence of teeth and gaps causes interference in the magnetic field. This produces a change in the magnetic flux through the sensor components, thus inducing an AC voltage. Both the frequency and the amplitude of the AC voltage are proportional to the wheel speed, thus supplying the electronic control unit with information on the rate of rotation of the wheel.

Part number: **0 265 001 ..., 0 265 006 ...**

Camshaft speed sensor

System:
Motronic

Operation:
The camshaft position indicates whether an engine piston moving towards top dead center is in the compression or exhaust stroke. The speed sensor at the camshaft (also referred to as phase sensor) passes this information to the electronic control unit. Such sensors are used where high accuracy is required. Further advantages include a comparatively large air-gap range and good temperature compensation.

Part number: **0 232 10. ...**

Throttle-valve potentiometer, throttle-valve sensor

Systems:
Mono-Jetronic, Motronic, Mono-Motronic

Operation:
Throttle-valve sensors are attached to the throttle-valve assembly or to the central injection unit. These sensors detect the position of the throttle valve and the angular velocity on opening and closing. The angular velocity is an important signal for the electronic control unit to provide compensation for load-change jolts and to prevent part-load bucking.

Note:
Throttle-valve sensors at central injection units cannot be replaced. The entire bottom section of the injection unit has to be renewed. The appropriate bottom section can be found in the replacement-parts program.

Part number: **0 261 211 ..., 0 280 122 ...**

Motor-vehicle sensors

Air-mass meter

Systems:
LH-Jetronic, Motronic

Operation:
The air-mass meter is installed between the air cleaner and throttle valve and measures the intake-air mass. Use is made in practice of hot-wire and hot-film air-mass meters. Both sensors operate on the same principle: An electrically heated thin platinum wire or platinum film resistor is positioned in the intake-air flow together with a temperature sensor as temperature-sensitive resistor. The electronic control unit is supplied with a voltage signal proportional to the air-mass flow and uses this signal to calculate the quantity of fuel required.

Part number:
0 280 21. ..., BX: 0 986 280 1.. (HLM) and 0 986 280 2.. (HFM)

Air-flow sensor

Systems:
L-Jetronic, Motronic

Operation:
The air flowing into the engine deflects a sensor plate in opposition to the restoring force of a spring. A potentiometer converts the deflection of the sensor plate into a voltage. The electronic control unit uses this signal to calculate the quantity of fuel required.

Part number:
0 280 200 ..., 0 280 201 ..., 0 280 202 ..., 0 280 203 ..., BX: 0 986 280 0..

Air-flow sensor

Systems:
K- and KE-Jetronic, KE-Motronic

Operation:
The air-flow sensor and the fuel distributor together form the mixture-control unit. The two components are available separately and must be replaced separately. The air flowing through the air funnel moves the sensor plate by a certain amount. The sensor-plate deflection is transmitted by way of a lever system to the fuel distributor.

Part number:
0 438 120 ..., 0 438 121 ..., F 026 TX2 ..., BX: 0 986 439 ...

Pressure sensors (Motronic)

System:
Motronic

Operation:
Pressure sensors can be used for a variety of applications. Intake-manifold pressure sensors measure the absolute pressure in the intake manifold. These sensors are either integrated into the electronic control unit or fitted in the vicinity of the intake manifold in the form of externally mounted sensors. Modern systems featuring on-board diagnosis are additionally fitted with tank-pressure sensors. Modern DUO sensors combine pressure and temperature measurement.

Part number: **0 261 230 ...**

High-pressure sensor (DS-HD-KV)

Operation:
The sensor installed in the high-pressure fuel rail (KVS-HD) is designed to detect the fuel pressure level in the rail. The pressure measured is used as actual quantity for rail-pressure regulation.

Part number: **0 261 545 ...**

Knock sensors

System:
Motronic

Operation:
The knock sensor converts vibration into electric signals. This enables the electronic control unit to detect knocking combustion and to retard the ignition point to prevent engine damage. In some cases several sensors are attached to the engine block for knock-control purposes.

Part number: **0 261 231 ...**

Motor-vehicle sensors

Steering-angle sensor

System:
ESP/EHB

Operation:
The steering angle is output as an absolute value over the full angle range (turning range) of the steering column.
The steering column drives two measurement gears by way of a gear wheel. All the gear wheels are located in the housing. The measurement gears are fitted with magnets. The angular position of the magnets is detected by measuring elements, the resistance of which changes depending on the direction of the magnetic field. The measurement gears have different numbers of teeth and their rotational position thus changes at different rates. The total angle can be calculated from the sum of the two current angles by way of a mathematical function and also checked for plausibility. This measurement principle can thus cover a measuring range of several steering wheel turns without a revolution counter.

Part number: **0 265 005 4.., 0 265 005 5..**

Pedal-travel sensor/accelerator-pedal module

System:
Motronic with EGAS

Operation:
In contrast to conventional engine-management systems, in the case of the Motronic with EGAS the driver's acceleration input is no longer relayed to the throttle valve via a cable. Instead, the input is detected using a pedal-travel sensor (also referred to as "electronic throttle control" or ETC) and transmitted to the electronic control unit. The accelerator-pedal module is a pre-assembled unit containing a vehicle-specific foot plate alongside the pedal-travel sensor. The Motronic control unit evaluates the sensor signal and adjusts the electric motor-driven throttle valve (throttle device or EMS positioner) taking into account other vehicle and engine data.

Part number:
0 205 001 ..., 0 280 752 ..., 0 280 755 ...

Temperature sensor (engine)

Systems:
D-, L- and LH-Jetronic,
K-Jetronic (with Lambda sensor),
KE-Jetronic, KE-Motronic, Motronic

Operation:
The coolant-temperature sensor measures the temperature in the coolant circuit and provides the electronic control unit with an electric signal. The sensor consists of an NTC thermistor embedded in a threaded sleeve or a plastic casing. The "coolant temperature" signal is particularly important for the starting and warm-up phase.

Part number: **0 261 220 ..., 0 280 130 ...**



Thermo-time switch

Systems:
D-, L-, LH-, K- and KE-Jetronic, Motronic

Operation:
The thermo-time switch limits the injection period of the cold-start valve as a function of time and temperature. The switch consists of an electrically heated bimetallic element, which breaks or makes a contact. Triggering is by way of the ignition/starter switch.

Part number: **0 280 130 2..**

Lambda sensors

Further information can be found in the Lambda sensors catalog.

Catalog order number: **1 987 720 017**

How to use this catalogue



JAGUAR | **B181**

Product | **Product**

JAGUAR

Daimler

3.6			**3,6 l 136/165 kW ; AJ6.4 6 Zyl.**
Raddrehzahlfühler, vorn	10.86-08.89	LAB	**0 265 001 095**
		RAB	**0 265 001 094**
Raddrehzahlfühler, hinten	10.86-08.89		**0 265 001 096**

Sovereign

2.9			**2,9 l 104 kW AJ 6 6 Zyl.**
Geber, Drosselklappe	10.86-08.90		**0 280 120 301**
Luftmassenmesser, Benzineinspritzung	10.86-08.90		**0 280 213 001**
Impulsgeber, Zündung/Jetronic	10.86-08.90		**0 261 210 041**
Temperaturfühler, Kühlwasser Einspritzsystem	10.86-08.90		**0 280 130 032**
Raddrehzahlfühler, vorn	10.86-08.90	LAB	**0 265 001 095**
		RAB	**0 265 001 094**
Raddrehzahlfühler, hinten	10.86-08.90		**0 265 001 096**
2.9			**2,9 l 123 kW AJ 6 6 Zyl.**
Geber, Drosselklappe	10.86-08.90		**0 280 120 301**
Luftmassenmesser, Benzineinspritzung	10.86-08.90		**0 280 213 001**
Temperaturfühler, Kühlwasser Einspritzsystem	10.86-08.90		**0 280 130 032**
Raddrehzahlfühler, vorn	10.86-08.90	LAB	**0 265 001 095**
		RAB	**0 265 001 094**
Raddrehzahlfühler, hinten	10.86-08.90		**0 265 001 096**
3.6			**3,6 l 135/170 kW AJ6.4 6 Zyl.**
Raddrehzahlfühler, vorn	10.86-08.89	LAB	**0 265 001 095**
		RAB	**0 265 001 094**
Raddrehzahlfühler, hinten	10.86-08.89		**0 265 001 096**

XJ S Coupé

5.3			**5,3 l 183 kW 12 Zyl.**
Relais, Jetronic	07.81-12.89		**0 332 014 113**
		DID	**0 332 014 112**
5.3			**5,3 l 183 kW HE V12 12 Zyl.**
Relais, Jetronic	07.81-12.87		**0 332 014 411**
5.3 V12			**5,3 l 222-227 kW 12 Zyl.**
Relais, Jetronic	03.90-12.97		**0 332 014 113**
		DID	**0 332 014 112**

XJ 6

2.9			**2,9 l 110 kW AJ6 6 Zyl.**
Geber, Drosselklappe	10.86-12.88		**0 280 120 301**
Luftmassenmesser, Benzineinspritzung	10.86-12.88		**0 280 213 001**
Impulsgeber, Zündung/Jetronic	10.86-12.88		**0 261 210 041**
Temperaturfühler, Kühlwasser Einspritzsystem	10.86-12.88		**0 280 130 032**
Raddrehzahlfühler, vorn			
Fg.Nr. →594575	10.86-12.88	LAB	**0 265 001 095**
		RAB	**0 265 001 094**
Raddrehzahlfühler, hinten			
Fg.Nr. →594575	10.86-12.88		**0 265 001 096**
2.9			**2,9 l 123 kW AJ 6 6 Zyl.**
Geber, Drosselklappe	10.86-08.90		**0 280 120 301**
Luftmassenmesser, Benzineinspritzung	10.86-08.90		**0 280 213 001**
Temperaturfühler, Kühlwasser Einspritzsystem	10.86-08.90		**0 280 130 032**
Raddrehzahlfühler, vorn			
Fg.Nr. →594575	B 10.86-08.90	LAB	**0 265 001 095**
		RAB	**0 265 001 094**
Raddrehzahlfühler, hinten			
Fg.Nr. →594575	10.86-08.90		**0 265 001 096**
3.2 24V			**3,2 l 146-149 kW 9BPMNA 6 Zyl.**
Raddrehzahlfühler, vorn	10.90-09.94	LAB	**0 265 001 095**
		RAB	**0 265 001 094**
Raddrehzahlfühler, hinten	10.90-09.94		**0 265 001 096**
3.6			**3,6 l 136/170 kW AJ6.4 6 Zyl.**
Raddrehzahlfühler, vorn	10.86-08.89	LAB	**0 265 001 095**
		RAB	**0 265 001 094**
Raddrehzahlfühler, hinten	10.86-08.89		**0 265 001 096**
4.2			**4,2 l 147 kW 6 Zyl.**
Luftmengenmesser, Benzineinspritzung	S 03.79-10.86		**0 280 203 006**
			0 986 280 022
Luftmassenmesser, Benzineinspritzung	03.79-10.86		**0 280 203 005**
			0 986 280 047
Relais, Jetronic	03.79-10.86		**0 332 014 113**
4.2			**4,2 l 147-151 kW 6 Zyl.**
Luftmengenmesser, Benzineinspritzung	03.79-10.86		**0 280 203 006**
			0 986 280 022
Relais, Jetronic	03.79-10.86		**0 332 014 113**

XJ 12

5.3 HE			**5,3 l 183 kW 12 Zyl.**
Relais, Jetronic	07.81-09.94	DID	**0 332 014 112**
Raddrehzahlfühler, vorn	01.90-09.94	LAB	**0 265 001 270**
		RAB	**0 265 001 269**
Raddrehzahlfühler, hinten	01.90-09.94	LAB	**0 265 001 272**
		RAB	**0 265 001 271**
5.3 HE			**5,3 l 194 kW 12 Zyl.**
Relais, Jetronic	07.81-09.94		**0 332 014 411**
Raddrehzahlfühler, vorn	01.90-09.94	LAB	**0 265 001 270**
		RAB	**0 265 001 269**
Raddrehzahlfühler, hinten	01.90-09.94	LAB	**0 265 001 272**
		RAB	**0 265 001 271**
5.3 HE			**5,3 l 197-198 kW 12 Zyl.**
Raddrehzahlfühler, vorn	01.90-09.94	LAB	**0 265 001 270**
		RAB	**0 265 001 269**
Raddrehzahlfühler, hinten	01.90-09.94	LAB	**0 265 001 272**
		RAB	**0 265 001 271**

X-Type

2.0 [CF1]			**2,1 l 115 kW 2.1IV6 6 Zyl.**
Raddrehzahlfühler, vorn	03.02→		**0 265 007 879**
Raddrehzahlfühler, hinten	03.02→	AA	**0 265 007 879**
		LAB,NAA	**0 265 007 417**
		NAA,RAB	**0 265 007 404**
2.0 D [CF1]			**2,0 l 96 kW R4-X404 4 Zyl.**
Raddrehzahlfühler, vorn	09.03→		**0 265 007 879**
Raddrehzahlfühler, hinten	09.03→	AA	**0 265 007 879**
		LAB,NAA	**0 265 007 417**
		NAA,RAB	**0 265 007 404**
2.5 [CF1]			**2,5 l 145 kW 6 Zyl.**
Raddrehzahlfühler, vorn	03.01→		**0 265 007 879**
Raddrehzahlfühler, hinten	03.01→	AA	**0 265 007 879**
		LAB,NAA	**0 265 007 417**
		NAA,RAB	**0 265 007 404**

Bosch Automotive Aftermarket 2008 | 2009 X-Type ▶

J

① **Vehicle brand**
Manufacturer indicated

② **Vehicle models**
in alphabetical order

③ **Model specifics**
special vehicle information

④ **Production period**

⑤ **Export country**
Indicates the country for which the product is intended

⑥ **Icon explanations**
See end of catalogue

⑦ **Engine details**
Displacement in liters (Ltr.)
Power output in kW
Engine designation
Number of cylinders

⑧ **Order number**
10-digit aftermarket order number

⑨ **Special notes**
For explanations see end of catalogue

⑩ **Product name**

⑪ **Note**
Continues on next page

de
Verwendungsteil

en
Applications

fr
Affectations

it
Impiego

es
Aplicación

Benutzerhinweise

In diesem Katalog sind die Daten von Fahrzeugen, Motoren und Geräten für den europäischen Markt von Baujahr 1986 bis einschließlich 2007 erfasst. Diese wurden aus Hersteller- und Importeurangaben, aus Fahrzeuguntersuchungen sowie aus Unterlagen von Bosch nach bestem Wissen sorgfältig zusammengestellt und geben den Stand zum Zeitpunkt der Drucklegung wieder.

Zwangsläufige Abweichungen durch länderspezifische technische Änderungen können nie ganz ausgeschlossen werden. Bosch kann daher insoweit nicht für die Vollständigkeit und Fehlerfreiheit der Daten haften. Für Irrtümer und Druckfehler, die zu Schäden am Eigentum oder Vermögen führen, haftet Bosch nur bei grob fahrlässiger Pflichtverletzung und bei Vorsatz für unmittelbare Schäden. Bei Personenschäden haftet Bosch auch bei leichter Fahrlässigkeit.

Bitte beachten Sie: Durch die Umstellung auf die neueste Ausführung aus der Erstausrüstung können bei manchen Verwendungen zwischen den Bestellnummern für Neuware und Austausch unterschiedliche Leistungsangaben auftreten.

Notes for users

This catalog contains the data from the vehicles, engines, and equipment for the European market from year of manufacture 1986 up to and including the year 2007. This data has been assembled from information provided by manufacturers and importers, and taken from Bosch documentation, as well as from investigations made on vehicles. It has been compiled to the best of our knowledge and belief, and reflects the status at the date of going to print.

It is impossible to avoid deviations caused by technical changes resulting from the conditions and regulations applying in a particular country. Bosch can therefore accept no liability for the completeness and faultlessness of the data. In case of mistakes and misprints which result in damage to property or assets, Bosch is only liable for immediate damages insofar as a gross breach of duty or wrongful intent apply. If personal injury is involved, Bosch is liable also in case of ordinary negligence.

Please note:
For some applications, the performance data given with the part numbers for exchange and new products can differ due to the changeover to the latest OE version.

A l'attention de l'utilisateur

Le présent catalogue mentionne les données spécifiques de véhicules, moteurs et appareils pour le marché européen depuis l'année de fabrication 1986 jusqu'au millésime 2007 inclus. Ces informations ont été rassemblées soigneusement et en toute impartialité à partir des indications des constructeurs et importateurs, des contrôles techniques des véhicules et de la documentation Bosch, et matérialisent le stade des connaissances au moment de la mise sous presse.

Il n'est jamais possible d'exclure totalement les divergences éventuelles dues aux modifications techniques, spécifiques des différents pays considérés. En aucun cas, Bosch n'engage sa responsabilité en ce qui concerne l'intégralité et l'exactitude des données. En ce qui concerne les erreurs et les fautes d'impression, qui peuvent entraîner des dommages à la propriété ou à la fortune, Bosch n'engage sa responsabilité pour les dommages directs qu'en cas d'atteinte et de négligence graves et intentionnelles envers ses obligations. En cas de dommages causés aux personnes, Bosch engage sa responsabilité aussi en cas de légère négligence.

Veuillez faire attention, pour certaines applications, la puissance donnée pour l'échange standard peut être differente de celle du produit neuf car nous donnons la puissance de la dernierè version d'origine.

Avvertenze per la consultazione

Nella seguente parte di catalogo sono contemplati veicoli, motori ed apparecchi a partire dall'anno di costruzione 1986 fino all'anno 2007. Tali informazioni sono state rilevate dalle documentazioni di Case Auto, Importatori, da verifiche eseguite sui veicoli, così come da documentazione Bosch.

Eventuali discordanze dovute a specifiche esigenze del Paese e variazioni tecniche non possono essere previste. Per questo Bosch non si assume alcuna responsabilità per mancanze ed eventuali errori riferite ai dati. Per danni a cose o danni patrimoniali, dovuti ad errori o refusi di stampa, Bosch è responsabile solo in caso di dolo o colpa grave. Per danni alla persona, Bosch è responsabile anche in caso di colpa meno grave.

Prego prestare attenzione: dopo gli ultimi cambiamenti intervenuti potranno verificarsi delle differenze tra il numero d'ordine per prodotto nuovo ed il rigenerato del primo equipaggiamento.

Avertencia al usuario

Los datos recogidos en este catálogo para vehículos, motores y maquinaria del mercado europeo abarcan los años de fabricación entre 1986 y 2007, inclusive. Estos datos han sido recogidos del fondo documental de Bosch, así como de las inspecciones de vehículos, datos de fabricantes e importadores.

No obstante, y debido al cuantioso material de información, no se puede excluir la posibilidad de modificaciones, diferencias propias de aplicaciones específicas de los países, fallos, equivocaciones o errores. En caso de inexactitudes y errores de imprenta, la responsabilidad de Bosch se limita al daño inmediato, con posibles perjuicios patrimoniales, a no ser que el daño previsible y típico del contrato sea de mayor cuantía o se deba a dolo o culpa intencionada o a negligencia grave.

Atención:
Con la introducción de nuevas versiones en los primeros equipos algunas aplicaciones pueden contener tanto para las referencias de gama original como para las de intercambio distintas equivalencias.

Product			

ALFA ROMEO

Brera

2.2 JTS [939]			**2,2 l 136 kW 939A5000 4 Zyl.**
Air mass meter, gasoline injection	01.06→		**0 280 218 164**
Phase sensor	01.06→		**0 232 103 052**
Wheel speed sensor, front	01.06→		**0 265 008 055**
Wheel speed sensor, rear	01.06→		**0 265 008 056**
2.4 JTDM 20V [939]			**2,4 l 147 kW 939A3000 5 Zyl.**
Air mass meter, diesel	04.06→		**0 281 002 763**
Boost pressure sensor, Diesel	04.06→		**0 281 002 437**
Wheel speed sensor, front	04.06→		**0 265 008 055**
Wheel speed sensor, rear	04.06→		**0 265 008 056**
2.4 JTDM 20V [939]			**2,4 l 154 kW 939A9000 5 Zyl.**
Air mass meter, diesel	05.07→		**0 281 002 764**
Boost pressure sensor, Diesel	05.07→		**0 281 002 437**
Wheel speed sensor, front	05.07→		**0 265 008 055**
Wheel speed sensor, rear	05.07→		**0 265 008 056**
3.2 JTS 24V Q4 [939]			**3,2 l 191 kW 939A000 6 Zyl.**
Air mass meter, gasoline injection	01.06→		**0 280 218 182**
Wheel speed sensor, front	01.06→		**0 265 008 055**
Wheel speed sensor, rear	01.06→		**0 265 008 056**

Coupé SZ

3.0 V6 [139]			**3,0 l 154 kW AR 61501 6 Zyl.**
Air flow sensor, gasoline injection	03.89-12.91		**0 280 202 205**
Speed sensor, ignition/injection	03.89-12.91		**0 261 210 036**

GT

1.8 TS [937]			**1,8 l 106 kW AR32205 4 Zyl.**
Throttle valve assembly			
Mot.no. →3649574	10.03-04.04		**0 280 750 102**
Mot.no. 3649575→	05.04→		**1 287 213 612**
Air mass meter, gasoline injection	10.03-03.06		**0 281 002 309**
Phase sensor	10.03→		**0 232 101 035**
Speed sensor, ignition/injection	10.03→		**0 261 210 227**
Knock sensor	10.03→		**0 261 231 131**
Yaw rate sensor, brake system	10.03→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)			
Ricam.no →0045014	10.03-11.05		**0 265 005 303**
Wheel speed sensor, front	10.03→	LAB	**0 265 007 486**
		RAB	**0 265 007 487**
Wheel speed sensor, rear	10.03→		**0 265 007 488**
1.9 JTD 16V [937]			**1,9 l 103 kW 937A5000 4 Zyl.**
Air mass meter, diesel	10.03→		**0 280 218 120**
High-pressure sensor (CR system)	10.03→		**0 281 002 534**
Yaw rate sensor, brake system	10.03→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)			
Ricam.no →0045014	10.03-11.05		**0 265 005 303**
Wheel speed sensor, front	10.03→	LAB	**0 265 007 486**
		RAB	**0 265 007 487**
Wheel speed sensor, rear	10.03→		**0 265 007 488**
1.9 JTD 16V [937]			**1,9 l 110 kW 937A5000 4 Zyl.**
Air mass meter, diesel	01.04→		**0 281 002 792**
High-pressure sensor (CR system)	01.04→		**0 281 002 706**
Yaw rate sensor, brake system	01.04→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)			
Ricam.no →0045014	01.04-11.05		**0 265 005 303**
Wheel speed sensor, front	01.04→	LAB	**0 265 007 486**
		RAB	**0 265 007 487**
Wheel speed sensor, rear	01.04→		**0 265 007 488**
2.0 JTS [937]			**2,0 l 120/121 kW 932A2000; 937A1000 4 Zyl.**
Throttle valve assembly			
Mot.no. →3649574	10.03-04.04		**0 280 750 102**
Mot.no. 3649575→	05.04→		**1 287 213 612**
Air mass meter, gasoline injection	10.03→		**0 280 218 120**
Phase sensor	10.03→		**0 232 101 035**
Speed sensor, ignition/injection	10.03→		**0 261 210 227**
Knock sensor	10.03-12.05		**0 261 231 148**
	01.06→		**0 261 231 173**
Yaw rate sensor, brake system	10.03→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)			
Ricam.no →0045014	10.03-11.05		**0 265 005 303**
Wheel speed sensor, front	10.03→	LAB	**0 265 007 486**
		RAB	**0 265 007 487**
Wheel speed sensor, rear	10.03→		**0 265 007 488**
3.2 V6 [937]			**3,2 l 176 kW 936A000 6 Zyl.**
Throttle valve assembly	10.03→		**0 280 750 014**
Air mass meter, gasoline injection	10.03→		**0 281 002 533**
Phase sensor	10.03→		**0 232 103 024**
Speed sensor, ignition/injection	10.03→		**0 261 210 203**
Knock sensor	10.03→	LAB	**0 261 231 152**
		RAB	**0 261 231 153**
Yaw rate sensor, brake system	10.03→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)			
Ricam.no →0045014	10.03-11.05		**0 265 005 303**
Wheel speed sensor, front	10.03→	LAB	**0 265 007 486**
		RAB	**0 265 007 487**
Wheel speed sensor, rear	10.03→		**0 265 007 488**

GTV

1.8 T.S. 16V [916]			**1,8 l 106 kW AR 32201 4 Zyl.**
Throttle valve assembly	05.98-12.00		**3 437 010 460**
Air mass meter, gasoline injection	04.99-12.00		**0 280 218 019**
	05.98-03.99		**0 281 002 199**
Phase sensor	05.98-12.00		**0 232 101 035**
Speed sensor, ignition/injection	05.98-12.00		**0 261 210 160**
Knock sensor	05.98-12.00		**0 261 231 131**
Vacuum pickup, ignition/injection	05.98-12.00		**0 928 400 327**
Wheel speed sensor, front			
Ricam.no →6063041	05.98-12.00		**0 265 006 212**
Ricam.no 6063042→	05.98-12.00	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	05.98-11.99	LAB	**0 265 006 260**
	12.99-12.00	LAB	**0 265 007 098**
	05.98-11.99	RAB	**0 265 006 261**
	12.99-12.00	RAB	**0 265 007 099**
2.0 JTS [916]			**2,0 l 121 kW 937A1.000 4 Zyl.**
Throttle valve assembly	04.03-12.05		**0 280 750 102**
Air mass meter, gasoline injection	04.03-12.05		**0 280 218 113**
Phase sensor	04.03-12.05		**0 232 101 035**
Speed sensor, ignition/injection	04.03-12.05		**0 261 210 227**
Knock sensor	04.03-12.05		**0 261 231 148**
Wheel speed sensor, front	04.03-12.05	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	04.03-12.05	LAB	**0 265 007 098**
		RAB	**0 265 007 099**
2.0 T.S. 16V [916]			**2,0 l 110 kW AR 16201 4 Zyl.**
Throttle valve sensor	04.95-04.98		**0 280 122 001**
Air mass meter, gasoline injection	04.95-04.98		**0 280 217 111**

Product			
Phase sensor	04.95-04.98		**0 232 101 026**
Speed sensor, ignition/injection	04.95-04.98		**0 261 210 129**
Knock sensor	04.95-04.98		**0 261 231 007**
Temperature sensor, intake air, injection system	04.95-04.98		**0 280 130 073**
Temperature sensor, coolant, injection system	04.95-04.98		**0 280 130 026**
Wheel speed sensor, front	04.95-04.98		**0 265 006 212**
Wheel speed sensor, rear	04.95-04.98	LAB	**0 265 006 260**
		RAB	**0 265 006 261**
2.0 T.S. 16V [916]		**2,0 l 110 kW AR 32310 4 Zyl.**	
Throttle valve assembly			
Mot.no. →3649574	08.00-04.04		**0 280 750 102**
Mot.no. 3649575→	05.04-12.05		**1 287 213 612**
Throttle valve sensor	08.00-12.05		**0 280 122 001**
Air mass meter, gasoline injection	08.00-12.05		**0 281 002 309**
Phase sensor	08.00-12.05		**0 232 101 035**
Speed sensor, ignition/injection			
Mot.no. →3649574	08.00-12.05		**0 261 210 160**
Mot.no. 3649575→	08.00-12.05		**0 261 210 227**
Knock sensor	08.00-12.05		**0 261 231 131**
Vacuum pickup, ignition/injection	08.00-12.05		**0 928 400 327**
Temperature sensor, intake air, injection system	08.00-12.05		**0 280 130 073**
Temperature sensor, coolant, injection system	08.00-12.05		**0 280 130 026**
Wheel speed sensor, front	08.00-12.05	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	08.00-12.05	LAB	**0 265 007 098**
		RAB	**0 265 007 099**
2.0 T.S. 16V [916]		**2,0 l 114 kW AR 32301 4 Zyl.**	
Throttle valve sensor	05.98-07.00		**3 437 010 455**
Phase sensor	05.98-07.00		**0 232 101 035**
Speed sensor, ignition/injection	05.98-07.00		**0 261 210 160**
Knock sensor	05.98-07.00		**0 261 231 131**
Temperature sensor, intake air, injection system	05.98-07.00		**0 280 130 073**
Temperature sensor, coolant, injection system	05.98-07.00		**0 280 130 026**
Wheel speed sensor, front			
Ricam.no →6063041	05.98-07.00		**0 265 006 212**
Ricam.no 6063042→	05.98-07.00	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	05.98-11.99	LAB	**0 265 006 260**
		RAB	**0 265 006 261**
2.0 V6 Turbo [916]		**2,0 l 148 kW AR 16202 6 Zyl.**	
Throttle valve sensor	04.95-07.00		**0 280 120 435**
Air flow sensor, gasoline injection	04.95-07.00		**0 280 203 034**
Phase sensor	04.95-07.00		**0 356 914 224**
Pulse generator, ignition/Jetronic	04.95-07.00		**0 261 210 036**
Knock sensor	04.95-07.00		**0 261 231 007**
Pressure sensor, intake manifold, gasoline	04.95-07.00	HL	**0 280 101 001**
Wheel speed sensor, front	04.95-11.99		**0 265 006 162**
	12.99-07.00	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	04.95-11.99	LAB	**0 265 006 260**
	12.99-07.00	LAB	**0 265 007 098**
	04.95-11.99	RAB	**0 265 006 261**
	12.99-07.00	RAB	**0 265 007 099**
3.0 V6 24V [916]		**3,0 l 160 kW AR 16105 6 Zyl.**	
Throttle valve assembly	08.00-12.05		**0 280 750 014**
Throttle valve sensor	08.00-12.05		**0 280 122 001**
Air mass meter, gasoline injection	08.00-12.05		**0 280 218 054**
Phase sensor	08.00-12.05		**0 232 103 024**
Speed sensor, ignition/injection	08.00-12.05		**0 261 210 203**
Temperature sensor, intake air, injection system	08.00-12.05		**0 280 130 073**
Temperature sensor, coolant, injection system	08.00-12.05		**0 280 130 055**
Wheel speed sensor, front	08.00-12.05	LAB	**0 265 007 073**
		RAB	**0 265 007 074**

Product			
Wheel speed sensor, rear	08.00-12.05	LAB	**0 265 007 098**
		RAB	**0 265 007 099**
3.0 V6 24V [916]		**3,0 l 162 kW AR 16102 6 Zyl.**	
Throttle valve sensor	11.96-07.00		**0 280 122 001**
Air mass meter, gasoline injection	11.96-03.98		**0 280 217 514**
	04.98-07.00		**0 280 217 531**
Phase sensor	11.96-03.98		**0 232 103 009**
Speed sensor, ignition/injection	11.96-02.98		**0 261 210 113**
	03.98-07.00		**0 261 210 163**
Knock sensor	11.96-07.00		**0 261 231 007**
Temperature sensor, intake air, injection system	11.96-07.00		**0 280 130 073**
Temperature sensor, coolant, injection system	11.96-07.00		**0 280 130 055**
Wheel speed sensor, front	11.96-11.99		**0 265 006 162**
	12.99-07.00	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	11.96-11.99	LAB	**0 265 006 260**
	12.99-07.00	LAB	**0 265 007 098**
	11.96-11.99	RAB	**0 265 006 261**
	12.99-07.00	RAB	**0 265 007 099**
3.2 V6 24V [916]		**3,2 l 176 kW 936A6.000 6 Zyl.**	
Throttle valve assembly	04.03-12.05		**0 280 750 014**
Air mass meter, gasoline injection	04.03-12.05		**0 281 002 533**
Phase sensor	04.03-12.05		**0 232 103 009**
Speed sensor, ignition/injection	04.03-12.05		**0 261 210 203**
Wheel speed sensor, front	04.03-12.05	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	04.03-12.05	LAB	**0 265 007 098**
		RAB	**0 265 007 099**

GTV 6

2.5 i.e.		**2,5 l 110 kW 019.11 Kat. 6 Zyl.**	
Throttle valve sensor	09.82-02.87		**0 280 120 302**
Air flow sensor, gasoline injection	01.81-02.87		**0 280 202 010**
Pressure sensor, intake manifold, gasoline	09.84-02.87	HL	**0 280 101 001**
Temperature sensor, coolant, injection system	01.81-02.87		**0 280 130 023**
Relay, Jetronic	09.82-02.87	WEI	**0 332 514 127**
2.5 i.e.		**2,5 l 116-118 kW 016.46 6 Zyl.**	
Throttle valve sensor	11.80-02.87		**0 280 120 302**
Air flow sensor, gasoline injection	11.80-02.87		**0 280 202 013**
Temperature sensor, coolant, injection system	11.80-02.87		**0 280 130 023**
Relay, Jetronic	11.80-02.87	15A	**0 332 514 121**

Roadster RZ

3.0 V6 Zagato [139]		**3,0 l 154 kW AR 61501 6 Zyl.**	
Air flow sensor, gasoline injection	01.92-12.93		**0 280 202 205**
Speed sensor, ignition/injection	01.92-12.93		**0 261 210 036**

Spider

1.8 T.S. 16V [916]		**1,8 l 106 kW AR 32201 4 Zyl.**	
Throttle valve assembly	05.98-07.00		**3 437 010 460**
Phase sensor	05.98-07.00		**0 232 101 035**
Speed sensor, ignition/injection	05.98-07.00		**0 261 210 160**
Knock sensor	05.98-07.00		**0 261 231 131**
Wheel speed sensor, front	09.99-11.99		**0 265 006 212**
	12.99-07.00	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	05.98-11.99	LAB	**0 265 006 260**
	12.99-07.00	LAB	**0 265 007 098**
	05.98-11.99	RAB	**0 265 006 261**
	12.99-07.00	RAB	**0 265 007 099**

A

Product			
◀ Spider			
2.0 i.e. [105]			**2,0 l 86 kW 015.44 4 Zyl.**
Throttle valve sensor	10.81-12.89		**0 280 120 304**
Speed sensor, ignition/injection	03.86-12.89		**0 261 210 002**
Pulse generator, ignition/Jetronic	10.81-02.86		**0 261 210 001**
Pressure sensor, intake manifold, gasoline	09.84-12.89	HL	**0 280 101 001**
Temperature sensor, coolant, injection system	10.81-12.89		**0 280 130 023**
Relay, Jetronic	10.81-12.89		**0 280 230 001**
		LAH	**0 332 014 125**
2.0 i.e. [115]			**2,0 l 88/93 kW AR 01588; AR 01590 4 Zyl.**
Throttle valve sensor	01.90-12.94		**0 280 120 300**
Speed sensor, ignition/injection	01.90-12.94		**0 261 210 036**
Temperature sensor, coolant, injection system	01.90-12.94		**0 280 130 026**
2.0 JTS [916]			**2,0 l 121 kW 937A1.000 4 Zyl.**
Throttle valve assembly	04.03-04.04		**0 280 750 102**
	05.04-02.06		**1 287 213 612**
Air mass meter, gasoline injection	04.03-02.06		**0 280 218 113**
Phase sensor	04.03-02.06		**0 232 101 035**
Speed sensor, ignition/injection	04.03-02.06		**0 261 210 227**
Knock sensor	04.03-12.05		**0 261 231 148**
	01.06-02.06		**0 261 231 173**
Wheel speed sensor, front	04.03-02.06	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	04.03-02.06	LAB	**0 265 007 098**
		RAB	**0 265 007 099**
2.0 T.S. 16V [916]			**2,0 l 110 kW AR 16201 4 Zyl.**
Throttle valve assembly	04.95-04.98		**3 437 010 460**
Throttle valve sensor	04.95-04.98		**0 280 122 001**
Air mass meter, gasoline injection	04.95-02.98		**0 280 217 111**
Phase sensor	04.95-02.98		**0 232 101 026**
Speed sensor, ignition/injection	04.95-02.98		**0 261 210 129**
Knock sensor	04.95-02.98		**0 261 231 095**
Temperature sensor, intake air, injection system	04.95-04.98		**0 280 130 073**
Temperature sensor, coolant, injection system	04.95-04.98		**0 280 130 026**
Wheel speed sensor, front			
Ricam.no →6063041	04.95-04.98		**0 265 006 212**
Ricam.no 6063042→	04.95-04.98	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	04.95-02.98		**0 265 006 197**
2.0 T.S. 16V [916]			**2,0 l 110 kW AR 32310 CF3 4 Zyl.**
Throttle valve assembly			
Mot.no. →3649574	08.00-04.04		**0 280 750 102**
Mot.no. 3649575→	05.04-02.06		**1 287 213 612**
Throttle valve sensor	08.00-02.06		**0 280 122 001**
Air mass meter, gasoline injection	08.00-02.06		**0 281 002 309**
Phase sensor	08.00-02.06		**0 232 101 035**
Speed sensor, ignition/injection			
Mot.no. →3649574	08.00-02.06		**0 261 210 160**
Mot.no. 3649575→	08.00-02.06		**0 261 210 227**
Knock sensor	08.00-02.06		**0 261 231 131**
Vacuum pickup, ignition/injection	08.00-02.06		**0 928 400 327**
Temperature sensor, intake air, injection system	08.00-02.06		**0 280 130 073**
Temperature sensor, coolant, injection system	08.00-02.06		**0 280 130 026**
Wheel speed sensor, front	08.00-02.06	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	08.00-02.06	LAB	**0 265 007 098**
		RAB	**0 265 007 099**
2.0 T.S. 16V [916]			**2,0 l 114 kW AR 32301 4 Zyl.**
Throttle valve sensor	05.98-07.00		**3 437 010 455**
Air mass meter, gasoline injection	04.99-07.00		**0 280 218 019**
	05.98-03.99		**0 281 002 199**
Phase sensor	05.98-07.00		**0 232 101 035**
Speed sensor, ignition/injection	05.98-07.00		**0 261 210 160**
Knock sensor	05.98-07.00		**0 261 231 131**
Temperature sensor, intake air, injection system	05.98-07.00		**0 280 130 073**
Temperature sensor, coolant, injection system	05.98-07.00		**0 280 130 026**
Wheel speed sensor, front			
Ricam.no →6063041	05.98-07.00		**0 265 006 212**
Ricam.no 6063042→	05.98-07.00	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	05.98-11.99	LAB	**0 265 006 260**
		RAB	**0 265 006 261**
2.0 V6 Turbo [916]			**2,0 l 147 kW AR 16202 4 Zyl.**
Throttle valve sensor	04.98-12.00		**0 280 120 435**
Air flow sensor, gasoline injection	04.98-12.00		**0 280 203 034**
Phase sensor	04.98-12.00		**0 356 914 224**
Pulse generator, ignition/Jetronic	04.98-12.00		**0 261 210 036**
Knock sensor	04.98-12.00		**0 261 231 007**
Pressure sensor, intake manifold, gasoline	04.98-12.00	HL	**0 280 101 001**
Wheel speed sensor, front	04.98-11.99		**0 265 006 162**
	12.99-12.00	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	12.99-12.00	LAB	**0 265 007 098**
		RAB	**0 265 007 099**
2.2 JTS [939]			**2,2 l 140 kW 939A5000 4 Zyl.**
Air mass meter, gasoline injection	03.06→		**0 280 218 164**
Phase sensor	03.06→		**0 232 103 052**
Wheel speed sensor, front	03.06→		**0 265 008 055**
Wheel speed sensor, rear	03.06→		**0 265 008 056**
2.4 JTDM 20V [939]			**2,4 l 147 kW 939A3000 5 Zyl.**
Air mass meter, diesel	03.07→		**0 281 002 763**
Boost pressure sensor, Diesel	03.07→		**0 281 002 437**
Wheel speed sensor, front	03.07→		**0 265 008 055**
Wheel speed sensor, rear	03.07→		**0 265 008 056**
3.0 V6 12V [916]			**3,0 l 141 kW AR 16101; AR 16199 6 Zyl.**
Throttle valve sensor	04.95-02.06		**0 280 122 001**
Air mass meter, gasoline injection	04.95-02.06		**0 280 217 514**
Phase sensor	04.95-02.06		**0 232 103 009**
Pulse generator, ignition/Jetronic	04.95-02.06		**0 261 210 113**
Knock sensor	04.95-02.98		**0 261 231 007**
	03.98-02.06		**0 261 231 131**
Temperature sensor, intake air, injection system	04.95-02.06		**0 280 130 073**
Temperature sensor, coolant, injection system	04.95-02.06		**0 280 130 026**
Wheel speed sensor, front	04.95-11.99		**0 265 006 162**
	12.99-02.06	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	04.95-02.98		**0 265 006 197**
	03.98-11.99	LAB	**0 265 006 260**
	12.99-02.06	LAB	**0 265 007 098**
	03.98-11.99	RAB	**0 265 006 261**
	12.99-02.06	RAB	**0 265 007 099**
3.0 V6 24V [916]			**3,0 l 162 kW AR 16105 CF3 6 Zyl.**
Throttle valve assembly	08.00-03.03		**0 280 750 014**
Throttle valve sensor	08.00-03.03		**0 280 122 001**
Air mass meter, gasoline injection	08.00-03.03		**0 280 218 054**
Phase sensor	08.00-03.03		**0 232 103 024**
Speed sensor, ignition/injection	08.00-03.03		**0 261 210 203**
Temperature sensor, intake air, injection system	08.00-03.03		**0 280 130 073**
Temperature sensor, coolant, injection system	08.00-03.03		**0 280 130 055**
Wheel speed sensor, front	08.00-03.03	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	08.00-03.03	LAB	**0 265 007 098**
		RAB	**0 265 007 099**
3.2 JTS 24V Q4 [939]			**3,2 l 195 kW 939A000 6 Zyl.**
Air mass meter, gasoline injection	09.06→		**0 280 218 182**
Wheel speed sensor, front	09.06→		**0 265 008 055**
Wheel speed sensor, rear	09.06→		**0 265 008 056**

A

Product			
3.2 V6 24V [916]			**3,2 l 176 kW 936A6.000 6 Zyl.**
Throttle valve assembly	04.03-02.06		**0 280 750 014**
Air mass meter, gasoline injection	04.03-02.06		**0 281 002 533**
Phase sensor	04.03-02.06		**0 232 103 009**
Speed sensor, ignition/injection	04.03-02.06		**0 261 210 203**
Wheel speed sensor, front	04.03-02.06	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	04.03-02.06	LAB	**0 265 007 098**
		RAB	**0 265 007 099**

Sprint

1.7 i.e.			**1,7 l 77 kW 305.58 Kat. 4 Zyl.**
Throttle valve sensor	10.87-12.89		**0 280 120 315**
Air flow sensor, gasoline injection	10.87-12.89		**0 280 200 601**
Temperature sensor, coolant, injection system	10.87-12.89		**0 280 130 026**
Relay, Jetronic	10.87-12.89		**0 332 014 113**

6

2.5 i.e.			**2,5 l 110 kW 019.28 Kat. 6 Zyl.**
Throttle valve sensor	09.79-12.86		**0 280 120 302**
Air flow sensor, gasoline injection	09.79-12.86		**0 280 202 010**
Pressure sensor, intake manifold, gasoline	09.84-12.86	HL	**0 280 101 001**
Temperature sensor, coolant, injection system	09.79-12.86		**0 280 130 023**
Relay, Jetronic	09.82-12.86	WEI	**0 332 514 127**
2.5 i.e.			**2,5 l 117 kW 019.28 6 Zyl.**
Throttle valve sensor	09.83-12.86		**0 280 120 302**
Air flow sensor, gasoline injection	09.83-12.86		**0 280 202 013**
Temperature sensor, coolant, injection system	09.83-12.86		**0 280 130 023**
Relay, Jetronic	09.83-12.86	WEI	**0 332 514 127**
		15A	**0 332 514 121**

33 Berlina

1.3 I.E. [907]			**1,3 l 65 kW AR30753 MPI-Weber 4 Zyl.**
Wheel speed sensor, front	09.91-10.94		**0 265 003 061**
Wheel speed sensor, rear	09.91-10.94	LAB	**0 265 003 066**
		RAB	**0 265 003 062**
1.4 I.E. [907]			**1,4 l 64 kW AR30755 KAT 4 Zyl.**
Throttle valve sensor	09.91-09.94		**0 280 120 315**
Air flow sensor, gasoline injection	09.91-09.94		**0 280 200 601**
Temperature sensor, coolant, injection system	09.91-09.94		**0 280 130 026**
Wheel speed sensor, front	09.91-09.94		**0 265 003 061**
Wheel speed sensor, rear	09.91-09.94	LAB	**0 265 003 066**
		RAB	**0 265 003 062**
1.5 I.E. [907]			**1,5 l 70 kW AR30738; AR30751 4 Zyl.**
Throttle valve sensor	04.92-10.94		**0 280 122 001**
Speed sensor, ignition/injection	04.92-10.94		**0 261 210 036**
Temperature sensor, coolant, injection system	04.92-10.94		**0 280 130 026**
Wheel speed sensor, front	04.92-10.94		**0 265 003 061**
Wheel speed sensor, rear	04.92-10.94	LAB	**0 265 003 066**
		RAB	**0 265 003 062**
1.5 I.E. [907]			**1,5 l 70-72/74 kW AR30750; AR30751 KAT 4 Zyl.**
Throttle valve sensor	06.90-10.94		**0 280 120 315**
Air flow sensor, gasoline injection	06.90-10.94		**0 280 200 601**
Temperature sensor, coolant, injection system	06.90-10.94		**0 280 130 026**
Wheel speed sensor, front	06.90-10.94		**0 265 003 061**
Wheel speed sensor, rear	06.90-10.94	LAB	**0 265 003 066**
		RAB	**0 265 003 062**
1.5 I.E. 4x4 [907]			**1,5 l 70 kW AR30751 4 Zyl.**
Throttle valve sensor	04.92-10.94		**0 280 122 001**
Speed sensor, ignition/injection	04.92-10.94		**0 261 210 036**
Temperature sensor, coolant, injection system	04.92-10.94		**0 280 130 026**
Wheel speed sensor, front	04.92-10.94		**0 265 003 061**
Wheel speed sensor, rear	04.92-10.94	LAB	**0 265 001 267**
		RAB	**0 265 001 268**
1.7 I.E. [905]			**1,7 l 77 kW AR30558 4 Zyl.**
Throttle valve sensor	10.87-12.89		**0 280 120 315**
Air flow sensor, gasoline injection	10.87-12.89		**0 280 200 601**
Temperature sensor, coolant, injection system	10.87-12.89		**0 280 130 026**
Relay, Jetronic	10.87-12.89		**0 332 014 113**
1.7 I.E. [907]			**1,7 l 77 kW AR30740 4 Zyl.**
Throttle valve sensor	04.92-10.94		**0 280 122 001**
Speed sensor, ignition/injection	04.92-10.94		**0 261 210 036**
Temperature sensor, coolant, injection system	04.92-10.94		**0 280 130 039**
Wheel speed sensor, front	04.92-10.94		**0 265 003 061**
Wheel speed sensor, rear	04.92-10.94	LAB	**0 265 003 066**
		RAB	**0 265 003 062**
1.7 I.E. [907]			**1,7 l 79 kW AR30736; AR30737 4 Zyl.**
Throttle valve sensor	01.90-03.92		**0 280 120 315**
Air flow sensor, gasoline injection	01.90-03.92		**0 280 200 601**
Temperature sensor, coolant, injection system	01.90-03.92		**0 280 130 026**
Wheel speed sensor, front	01.90-03.92		**0 265 003 061**
Wheel speed sensor, rear	01.90-03.92	LAB	**0 265 003 066**
		RAB	**0 265 003 062**
1.7 I.E. 4x4 [907]			**1,7 l 77 kW AR30737 4 Zyl.**
Throttle valve sensor	04.92-10.94		**0 280 122 001**
Speed sensor, ignition/injection	04.92-10.94		**0 261 210 036**
Temperature sensor, coolant, injection system	04.92-10.94		**0 280 130 039**
Wheel speed sensor, front	04.92-10.94		**0 265 003 061**
Wheel speed sensor, rear	04.92-10.94	LAB	**0 265 001 267**
		RAB	**0 265 001 268**
1.7 I.E. 4x4 [907]			**1,7 l 79 kW AR30736; AR30737 KAT 4 Zyl.**
Throttle valve sensor	07.90-03.92		**0 280 120 315**
Air flow sensor, gasoline injection	07.90-03.92		**0 280 200 601**
Temperature sensor, coolant, injection system	07.90-03.92		**0 280 130 026**
Wheel speed sensor, front	07.90-03.92		**0 265 003 061**
Wheel speed sensor, rear	07.90-03.92	LAB	**0 265 001 267**
		RAB	**0 265 001 268**
1.7 I.E. 16V [907]			**1,7 l 95/98 kW AR30746; AR30747 4 Zyl.**
Throttle valve sensor	01.90-10.94		**0 280 120 304**
Air flow sensor, gasoline injection	01.90-10.94		**0 280 202 206**
			0 986 280 065
Speed sensor, ignition/injection	01.90-10.94		**0 261 210 036**
Temperature sensor, coolant, injection system	01.90-10.94		**0 280 130 026**
Wheel speed sensor, front	01.90-10.94		**0 265 003 061**
Wheel speed sensor, rear	01.90-10.94	LAB	**0 265 003 066**
		RAB	**0 265 003 062**
1.7 I.E. 16V 4x4 [907]			**1,7 l 95-97 kW AR30747 4 Zyl.**
Throttle valve sensor	01.90-10.94		**0 280 120 304**
Air flow sensor, gasoline injection	01.90-10.94		**0 280 202 206**
			0 986 280 065
Speed sensor, ignition/injection	01.90-10.94		**0 261 210 036**
Temperature sensor, coolant, injection system	01.90-10.94		**0 280 130 026**
Wheel speed sensor, front	01.90-10.94		**0 265 003 061**
Wheel speed sensor, rear	01.90-10.94	LAB	**0 265 001 267**
		RAB	**0 265 001 268**

33 Sport Wagon

1.5 I.E. [907]			**1,5 l 70-72 kW AR30751 4 Zyl.**
Throttle valve sensor	06.90-03.92		**0 280 120 315**
Air flow sensor, gasoline injection	06.90-03.92		**0 280 200 601**
Temperature sensor, coolant, injection system	06.90-03.92		**0 280 130 026**

A

Product			
◀ 33 Sport Wagon			
Wheel speed sensor, front	06.90-03.92		**0 265 003 061**
Wheel speed sensor, rear	06.90-03.92	LAB	**0 265 003 066**
		RAB	**0 265 003 062**
1.5 l.E. 4x4 [907]	**1,5 l 70-72 kW AR30751 4 Zyl.**		
Throttle valve sensor	06.90-03.92		**0 280 120 315**
Air flow sensor, gasoline injection	06.90-03.92		**0 280 200 601**
Temperature sensor, coolant, injection system	06.90-03.92		**0 280 130 026**
Wheel speed sensor, front	06.90-03.92		**0 265 003 061**
Wheel speed sensor, rear	06.90-03.92	LAB	**0 265 001 267**
		RAB	**0 265 001 268**
1.7 l.E. [905]	**1,7 l 77 kW AR30558; AR30558 KAT 4 Zyl.**		
Throttle valve sensor	09.88-12.89		**0 280 120 315**
Air flow sensor, gasoline injection	09.88-12.89		**0 280 200 601**
Temperature sensor, coolant, injection system	09.88-12.89		**0 280 130 026**
Relay, Jetronic	09.88-12.89		**0 332 014 113**
1.7 l.E. [907]	**1,7 l 79 kW AR30736; AR30737 4 Zyl.**		
Throttle valve sensor	07.90-03.92		**0 280 120 315**
Air flow sensor, gasoline injection	07.90-03.92		**0 280 200 601**
Temperature sensor, coolant, injection system	07.90-03.92		**0 280 130 026**
Wheel speed sensor, front	07.90-03.92		**0 265 003 061**
Wheel speed sensor, rear	07.90-03.92	LAB	**0 265 003 066**
		RAB	**0 265 003 062**
1.7 l.E. 4x4 [905]	**1,7 l 77 kW AR30558; AR30558 KAT 4 Zyl.**		
Throttle valve sensor	09.88-12.89		**0 280 120 315**
Air flow sensor, gasoline injection	09.88-12.89		**0 280 200 601**
Temperature sensor, coolant, injection system	09.88-12.89		**0 280 130 026**
Relay, Jetronic	09.88-12.89		**0 332 014 113**
1.7 l.E. 4x4 [907]	**1,7 l 77 kW AR30737 4 Zyl.**		
Throttle valve sensor	03.92-10.94		**0 280 122 001**
Speed sensor, ignition/injection	03.92-10.94		**0 261 210 036**
Temperature sensor, coolant, injection system	03.92-10.94		**0 280 130 039**
Wheel speed sensor, front	03.92-10.94		**0 265 003 061**
Wheel speed sensor, rear	03.92-10.94	LAB	**0 265 001 267**
		RAB	**0 265 001 268**
1.7 l.E. 4x4 [907]	**1,7 l 79 kW AR30736; AR30737 4 Zyl.**		
Throttle valve sensor	07.90-03.92		**0 280 120 315**
Air flow sensor, gasoline injection	07.90-03.92		**0 280 200 601**
Temperature sensor, coolant, injection system	07.90-03.92		**0 280 130 026**
Wheel speed sensor, front	07.90-03.92		**0 265 003 061**
Wheel speed sensor, rear	07.90-03.92	LAB	**0 265 001 267**
		RAB	**0 265 001 268**
1.7 l.E. 16V [907]	**1,7 l 95 kW AR30747 4 Zyl.**		
Throttle valve sensor	01.90-03.92		**0 280 120 304**
Air flow sensor, gasoline injection	01.90-03.92		**0 280 202 206**
			0 986 280 065
Speed sensor, ignition/injection	01.90-03.92		**0 261 210 036**
Temperature sensor, coolant, injection system	01.90-03.92		**0 280 130 026**
Wheel speed sensor, front	01.90-03.92		**0 265 003 061**
Wheel speed sensor, rear	01.90-03.92	LAB	**0 265 003 066**
		RAB	**0 265 003 062**
1.7 l.E. 16V 4x4 [907]	**1,7 l 95/98 kW AR30746; AR30747 4 Zyl.**		
Throttle valve sensor	01.90-10.94		**0 280 120 304**
Air flow sensor, gasoline injection	01.90-10.94		**0 280 202 206**
			0 986 280 065
Speed sensor, ignition/injection	01.90-10.94		**0 261 210 036**
Temperature sensor, coolant, injection system	01.90-10.94		**0 280 130 026**
Wheel speed sensor, front	01.90-10.94		**0 265 003 061**
Wheel speed sensor, rear	01.90-10.94	LAB	**0 265 001 267**
		RAB	**0 265 001 268**

Product			
75			
1.6	**1,6 l 81 kW AR 06100 4 Zyl.**		
Throttle valve sensor	05.85-09.89		**0 261 211 003**
1.6 l.E.	**1,6 l 77-79 kW AR 61101 4 Zyl.**		
Throttle valve sensor	08.89-02.92		**0 280 120 300**
Speed sensor, ignition/injection	08.89-02.92		**0 261 210 036**
Temperature sensor, coolant, injection system	08.89-02.92		**0 280 130 026**
1.8	**1,8 l 89 kW AR 06202 4 Zyl.**		
Throttle valve sensor	05.85-09.89		**0 261 211 003**
1.8 l.E.	**1,8 l 88 kW AR 06168 4 Zyl.**		
Throttle valve sensor	09.88-02.92		**0 280 120 300**
Air flow sensor, gasoline injection	09.88-02.92		**0 280 202 078**
Speed sensor, ignition/injection	09.88-02.92		**0 261 210 002**
Temperature sensor, coolant, injection system	09.88-02.92		**0 280 130 023**
Relay, Jetronic	09.88-02.92	DID	**0 332 014 112**
1.8 l.E.	**1,8 l 88 kW AR 61201 4 Zyl.**		
Throttle valve sensor	08.89-02.92		**0 280 120 300**
Speed sensor, ignition/injection	08.89-02.92		**0 261 210 036**
Temperature sensor, coolant, injection system	08.89-02.92		**0 280 130 026**
1.8 Turbo Essence	**1,8 l 121 kW AR 06158 4 Zyl.**		
Air flow sensor, gasoline injection	12.86-12.87		**0 280 202 113**
Temperature sensor, coolant, injection system	12.86-12.87		**0 280 130 032**
1.8 Turbo l.E.	**1,8 l 118 kW AR 06134 4 Zyl.**		
Air flow sensor, gasoline injection	02.86-01.90		**0 280 202 058**
Knock sensor	02.86-01.90		**0 261 231 006**
Temperature sensor, coolant, injection system	02.86-01.90		**0 280 130 032**
Relay, Jetronic	02.86-01.90		**0 280 230 009**
2.0 Twin Spark	**2,0 l 106 kW AR 06166 KAT 4 Zyl.**		
Throttle valve sensor	09.87-02.92		**0 280 120 315**
Speed sensor, ignition/injection	09.87-02.92		**0 261 210 036**
Temperature sensor, coolant, injection system	09.87-02.92		**0 280 130 026**
2.0 Twin Spark	**2,0 l 109 kW AR 06224 4 Zyl.**		
Throttle valve sensor	01.87-02.92		**0 280 120 315**
Speed sensor, ignition/injection	01.87-02.92		**0 261 210 036**
Temperature sensor, coolant, injection system	01.87-02.92		**0 280 130 026**
Relay, Jetronic	01.87-02.92		**0 332 014 113**
2.5 V6	**2,5 l 110-113 kW AR 01911 KAT 6 Zyl.**		
Throttle valve sensor	02.86-02.92		**0 280 120 304**
Air flow sensor, gasoline injection	02.86-02.92		**0 280 202 010**
Pressure sensor, intake manifold, gasoline	02.86-02.92	HL	**0 280 101 001**
Temperature sensor, coolant, injection system	02.86-02.92		**0 280 130 023**
Relay, Jetronic	02.86-02.92	WEI	**0 332 514 127**
2.5 V6	**2,5 l 115 kW AR 01646 6 Zyl.**		
Throttle valve sensor	09.85-02.87		**0 280 120 304**
Air flow sensor, gasoline injection	09.85-02.87		**0 280 202 013**
Pressure sensor, intake manifold, gasoline	02.86-02.87	HL	**0 280 101 001**
Temperature sensor, coolant, injection system	09.85-02.87		**0 280 130 023**
Relay, Jetronic	09.85-02.87	WEI	**0 332 514 127**
3.0 ES Coupé Zagato	**3,0 l 152 kW AR 61501 6 Zyl.**		
Throttle valve sensor	03.89-02.92		**0 280 120 300**
Air flow sensor, gasoline injection	03.89-02.92		**0 280 202 205**
Speed sensor, ignition/injection	03.89-02.92		**0 261 210 036**
Temperature sensor, coolant, injection system	03.89-02.92		**0 280 130 026**
3.0 V6	**3,0 l 133-136 kW AR 06120 6 Zyl.**		
Throttle valve sensor	01.87-02.92		**0 280 120 304**
Air flow sensor, gasoline injection	01.87-02.92		**0 280 202 105**
Pressure sensor, intake manifold, gasoline	01.87-02.92	HL	**0 280 101 001**
Temperature sensor, coolant, injection system	01.87-02.92		**0 280 130 023**
Relay, Jetronic	01.87-02.92	WEI	**0 332 514 127**

Product			
3.0 V6	**3,0 l 133-136 kW AR 06124 KAT 6 Zyl.**		
Throttle valve sensor	02.87-01.90		**0 280 120 304**
Air flow sensor, gasoline injection	02.87-01.90		**0 280 202 108**
			0 986 280 067
Pressure sensor, intake manifold, gasoline	02.87-01.90	HL	**0 280 101 001**
Temperature sensor, coolant, injection system	02.87-01.90		**0 280 130 023**
Relay, Jetronic	02.87-01.90	WEI	**0 332 514 127**
3.0 V6	**3,0 l 139-141 kW AR 61503 6 Zyl.**		
Throttle valve sensor	02.90-02.92		**0 280 120 300**
Air flow sensor, gasoline injection	02.90-02.92		**0 280 202 205**
Speed sensor, ignition/injection	02.90-02.92		**0 261 210 036**
Temperature sensor, coolant, injection system	02.90-02.92		**0 280 130 026**

90

2.0 i.e.	**2,0 l 94 kW AR 01713 MPI-Bosch 4 Zyl.**		
Throttle valve sensor	10.84-01.87		**0 280 120 300**
Air flow sensor, gasoline injection	04.85-01.87		**0 280 202 078**
Pulse generator, ignition/Jetronic	10.84-01.87		**0 261 210 001**
Temperature sensor, coolant, injection system	10.84-01.87		**0 280 130 023**
Relay, Jetronic	10.84-01.87		**0 332 014 113**
		DID	**0 332 014 112**
2.5 i.e. V6	**2,5 l 110-113 kW AR 01911 6 Zyl.**		
Throttle valve sensor	02.86-12.90		**0 280 120 304**
Air flow sensor, gasoline injection	02.86-12.90		**0 280 202 010**
Pressure sensor, intake manifold, gasoline	02.86-12.90	HL	**0 280 101 001**
Temperature sensor, coolant, injection system	02.86-12.90		**0 280 130 023**
Relay, Jetronic	02.86-12.90	WEI	**0 332 514 127**
2.5 i.e. V6	**2,5 l 115 kW AR 01646 MPI-Bosch 6 Zyl.**		
Throttle valve sensor	10.84-01.87		**0 280 120 304**
Air flow sensor, gasoline injection	10.84-01.87		**0 280 202 013**
Temperature sensor, coolant, injection system	10.84-01.87		**0 280 130 023**
Relay, Jetronic	09.85-01.87	WEI	**0 332 514 127**

145

1.3 i.e. [930 MY95]	**1,4 l 68 kW AR 33501 MPI-Weber 4 Zyl.**		
Wheel speed sensor, front	04.94-11.96		**0 265 006 162**
Wheel speed sensor, rear			
Ricam.no →3076158	04.94-11.96		**0 265 006 197**
Ricam.no 3076159→	04.94-11.96	LAB	**0 265 006 325**
		RAB	**0 265 006 326**
1.4 i.e. 16V T.S. [930 MY97]	**1,4 l 76 kW AR 33503 4 Zyl.**		
Throttle valve sensor	11.96-02.99		**0 280 122 001**
Air mass meter, gasoline injection	11.96-01.98		**0 280 217 102**
	02.98-02.99		**0 280 218 001**
Phase sensor	11.96-02.99		**0 232 101 026**
Speed sensor, ignition/injection	05.98-02.99		**0 261 210 160**
Pulse generator, ignition/Jetronic	11.96-04.98		**0 261 210 129**
Knock sensor	11.96-02.99		**0 261 231 095**
Temperature sensor, intake air, injection system	11.96-02.99		**0 280 130 073**
Temperature sensor, coolant, injection system	11.96-02.99		**0 280 130 026**
Wheel speed sensor, front	11.96-02.99		**0 265 006 162**
Wheel speed sensor, rear	11.96-02.99	LAB	**0 265 006 325**
		RAB	**0 265 006 326**
1.4 i.e. 16V T.S. [930 MY99]	**1,4 l 76 kW AR 33503 4 Zyl.**		
Air mass meter, gasoline injection	02.99-12.00		**0 280 218 001**
Phase sensor	02.99-12.00		**0 232 101 035**
Speed sensor, ignition/injection	02.99-12.00		**0 261 210 160**
Knock sensor	02.99-12.00		**0 261 231 131**
Wheel speed sensor, front	02.99-12.00	LAB	**0 265 007 063**
		RAB	**0 265 007 064**
Wheel speed sensor, rear	02.99-12.00	LAB	**0 265 007 065**
		RAB	**0 265 007 066**
1.6 i.e. [930 MY95]	**1,6 l 78 kW AR 33201 MPI-Bosch 4 Zyl.**		
Throttle valve sensor	04.94-12.94		**0 280 122 001**
Pulse generator, ignition/Jetronic	04.94-12.94		**0 261 210 036**
Temperature sensor, intake air, injection system	04.94-12.94		**0 280 130 073**
Temperature sensor, coolant, injection system	04.94-12.94		**0 280 130 026**
Wheel speed sensor, front	04.94-12.94		**0 265 006 162**
Wheel speed sensor, rear			
Ricam.no →3076158	04.94-12.94		**0 265 006 197**
Ricam.no 3076159→	04.94-12.94	LAB	**0 265 006 325**
		RAB	**0 265 006 326**
1.6 i.e. [930 MY95]	**1,6 l 78 kW AR 33201 MPI-Roch. 4 Zyl.**		
Wheel speed sensor, front	01.95-11.96		**0 265 006 162**
Wheel speed sensor, rear			
Ricam.no →3076158	01.95-11.96		**0 265 006 197**
Ricam.no 3076159→	01.95-11.96	LAB	**0 265 006 325**
		RAB	**0 265 006 326**
1.6 i.e. 16V T.S. [930 MY97]	**1,6 l 88 kW AR 67601 4 Zyl.**		
Throttle valve sensor	11.96-02.99		**0 280 122 001**
Air mass meter, gasoline injection	11.96-02.99		**0 280 217 111**
Phase sensor	11.96-02.99		**0 232 101 026**
Speed sensor, ignition/injection	05.98-02.99		**0 261 210 160**
Pulse generator, ignition/Jetronic	11.96-04.98		**0 261 210 129**
Knock sensor	11.96-02.99		**0 261 231 095**
Temperature sensor, intake air, injection system	11.96-02.99		**0 280 130 073**
Temperature sensor, coolant, injection system	11.96-02.99		**0 280 130 026**
Wheel speed sensor, front	11.96-02.99		**0 265 006 162**
Wheel speed sensor, rear	11.96-02.99	LAB	**0 265 006 325**
		RAB	**0 265 006 326**
1.6 i.e. 16V T.S. [930 MY99]	**1,6 l 88 kW AR 32102; AR 67601 4 Zyl.**		
Air mass meter, gasoline injection	02.99-12.00		**0 280 218 019**
Phase sensor	02.99-12.00		**0 232 101 035**
Speed sensor, ignition/injection	02.99-12.00		**0 261 210 160**
Knock sensor	02.99-12.00		**0 261 231 131**
Wheel speed sensor, front	02.99-12.00	LAB	**0 265 007 063**
		RAB	**0 265 007 064**
Wheel speed sensor, rear	02.99-12.00	LAB	**0 265 007 065**
		RAB	**0 265 007 066**
1.7 i.e. 16V [930 MY95]	**1,7 l 96 kW AR 33401 4 Zyl.**		
Throttle valve sensor	04.94-11.96		**0 280 122 001**
Air mass meter, gasoline injection	04.94-11.96		**0 280 217 111**
Phase sensor	04.94-11.96		**0 232 103 010**
Pulse generator, ignition/Jetronic	04.94-11.96		**0 261 210 113**
Temperature sensor, intake air, injection system	04.94-11.96		**0 280 130 073**
Temperature sensor, coolant, injection system	04.94-11.96		**0 280 130 026**
Wheel speed sensor, front	04.94-11.96		**0 265 006 162**
Wheel speed sensor, rear			
Ricam.no →3076158	04.94-11.96		**0 265 006 197**
Ricam.no 3076159→	04.94-11.96	LAB	**0 265 006 325**
		RAB	**0 265 006 326**
1.8 i.e. 16V T.S. [930 MY97]	**1,8 l 103 kW AR 32201 4 Zyl.**		
Throttle valve assembly	05.98-02.99		**3 437 010 460**
Air mass meter, gasoline injection	05.98-02.99		**0 280 217 111**
Phase sensor	05.98-02.99		**0 232 101 035**
Speed sensor, ignition/injection	05.98-02.99		**0 261 210 160**
Knock sensor	05.98-02.99		**0 261 231 131**
Wheel speed sensor, rear	05.98-02.99	LAB	**0 265 006 325**
		RAB	**0 265 006 326**
1.8 i.e. 16V T.S. [930 MY97]	**1,8 l 103 kW AR 67106; AR 67199 4 Zyl.**		
Throttle valve sensor	11.96-04.98		**0 280 122 001**
Air mass meter, gasoline injection	11.96-04.98		**0 280 217 111**
Phase sensor	11.96-04.98		**0 232 101 026**

A

Product			
◀ 145			
Pulse generator, ignition/Jetronic	11.96-04.98		**0 261 210 129**
Knock sensor	11.96-04.98		**0 261 231 095**
Temperature sensor, intake air, injection system	11.96-04.98		**0 280 130 073**
Temperature sensor, coolant, injection system	11.96-04.98		**0 280 130 026**
Wheel speed sensor, front	11.96-04.98		**0 265 006 162**
Wheel speed sensor, rear	11.96-04.98	LAB	**0 265 006 325**
		RAB	**0 265 006 326**
1.8 i.e. 16V T.S. [930 MY99]	**1,8 l 103 kW AR 32201 4 Zyl.**		
Throttle valve assembly	02.99-12.00		**3 437 010 460**
Air mass meter, gasoline injection	02.99-12.00		**0 280 218 019**
Phase sensor	02.99-12.00		**0 232 101 035**
Speed sensor, ignition/injection	02.99-12.00		**0 261 210 160**
Knock sensor	02.99-12.00		**0 261 231 131**
Vacuum pickup, ignition/injection	02.99-12.00		**0 928 400 327**
Wheel speed sensor, front	02.99-12.00	LAB	**0 265 007 063**
		RAB	**0 265 007 064**
Wheel speed sensor, rear	02.99-12.00	LAB	**0 265 007 065**
		RAB	**0 265 007 066**
1.9 JTD [930 MY97]	**1,9 l 76 kW AR 32302 4 Zyl.**		
Air mass meter, diesel	05.98-02.99		**0 280 218 019**
Speed sensor, diesel	05.98-02.99		**0 281 002 214**
Phase sensor	05.98-02.99		**0 281 002 213**
High-pressure sensor (CR system)	05.98-02.99		**0 281 002 210**
Boost pressure sensor, Diesel	05.98-02.99		**0 281 002 215**
Temperature sensor, fuel	05.98-02.99	2PO	**0 281 002 209**
Pedal position sensor, diesel	05.98-02.99		**0 281 002 203**
Wheel speed sensor, front	05.98-02.99	LAB	**0 265 007 063**
		RAB	**0 265 007 064**
Wheel speed sensor, rear	05.98-02.99	LAB	**0 265 007 065**
		RAB	**0 265 007 066**
1.9 JTD [930 MY99]	**1,9 l 76 kW AR 32302 4 Zyl.**		
Air mass meter, diesel	02.99-12.00		**0 280 218 019**
Speed sensor, diesel	02.99-12.00		**0 281 002 214**
Phase sensor	02.99-12.00		**0 281 002 213**
High-pressure sensor (CR system)	02.99-12.00		**0 281 002 210**
Boost pressure sensor, Diesel	02.99-12.00		**0 281 002 215**
Temperature sensor, fuel	02.99-12.00	2PO	**0 281 002 209**
Pedal position sensor, diesel	02.99-12.00		**0 281 002 203**
Wheel speed sensor, front	02.99-12.00	LAB	**0 265 007 063**
		RAB	**0 265 007 064**
Wheel speed sensor, rear	02.99-12.00	LAB	**0 265 007 065**
		RAB	**0 265 007 066**
1.9 TD [930 MY95]	**1,9 l 66 kW AR 33601; AR 67501 4 Zyl.**		
Wheel speed sensor, front	04.94-11.96		**0 265 006 162**
Wheel speed sensor, rear			
Ricam.no →3076158	04.94-11.96		**0 265 006 197**
Ricam.no 3076159→	04.94-11.96	LAB	**0 265 006 325**
		RAB	**0 265 006 326**
1.9 TD [930 MY97]	**1,9 l 66 kW AR 33601; AR 67501 4 Zyl.**		
Wheel speed sensor, front	11.96-05.98		**0 265 006 162**
Wheel speed sensor, rear	11.96-05.98	LAB	**0 265 006 325**
		RAB	**0 265 006 326**
2.0 i.e. 16V T.S. [930 MY95]	**2,0 l 110 kW AR 67204 4 Zyl.**		
Throttle valve sensor	10.95-11.96		**0 280 122 001**
Air mass meter, gasoline injection	10.95-11.96		**0 280 217 111**
Phase sensor	10.95-11.96		**0 232 101 026**
Pulse generator, ignition/Jetronic	10.95-11.96		**0 261 210 129**
Knock sensor	10.95-11.96		**0 261 231 095**
Temperature sensor, intake air, injection system	10.95-11.96		**0 280 130 073**
Temperature sensor, coolant, injection system	10.95-11.96		**0 280 130 055**
Wheel speed sensor, front	10.95-11.96		**0 265 006 162**

Product			
Wheel speed sensor, rear			
Ricam.no →3076158	10.95-11.96		**0 265 006 197**
Ricam.no 3076159→	10.95-11.96	LAB	**0 265 006 325**
		RAB	**0 265 006 326**
2.0 i.e. 16V T.S. [930 MY95]	**2,0 l 110 kW AR 67299 4 Zyl.**		
Throttle valve sensor	10.94-11.96		**0 280 122 001**
Air mass meter, gasoline injection	10.94-11.96		**0 280 217 111**
Phase sensor	10.94-11.96		**0 232 101 026**
Pulse generator, ignition/Jetronic	10.94-11.96		**0 261 210 129**
Knock sensor	10.94-11.96		**0 261 231 095**
Temperature sensor, intake air, injection system	10.94-11.96		**0 280 130 073**
Temperature sensor, coolant, injection system	10.94-11.96		**0 280 130 055**
2.0 i.e. 16V T.S. [930 MY97]	**2,0 l 110 kW AR 32301 Step A 4 Zyl.**		
Throttle valve assembly	05.98-02.99		**3 437 010 460**
Air mass meter, gasoline injection	05.98-02.99		**0 280 217 111**
Phase sensor	05.98-02.99		**0 232 101 035**
Speed sensor, ignition/injection	05.98-02.99		**0 261 210 160**
Knock sensor	05.98-02.99		**0 261 231 131**
Wheel speed sensor, rear	05.98-02.99	LAB	**0 265 006 325**
		RAB	**0 265 006 326**
2.0 i.e. 16V T.S. [930 MY97]	**2,0 l 110 kW AR 67204; AR 67299 4 Zyl.**		
Throttle valve sensor	11.96-02.99		**0 280 122 001**
Air mass meter, gasoline injection	11.96-02.99		**0 280 217 111**
Phase sensor	11.96-02.99		**0 232 101 026**
Pulse generator, ignition/Jetronic	11.96-02.99		**0 261 210 129**
Knock sensor	11.96-02.99		**0 261 231 095**
Temperature sensor, intake air, injection system	11.96-02.99		**0 280 130 073**
Temperature sensor, coolant, injection system	11.96-02.99		**0 280 130 055**
Wheel speed sensor, front	11.96-02.99		**0 265 006 212**
Wheel speed sensor, rear	11.96-02.99	LAB	**0 265 006 325**
		RAB	**0 265 006 326**
2.0 i.e. 16V T.S. [930 MY99]	**2,0 l 110 kW AR 32301 4 Zyl.**		
Throttle valve assembly	02.99-12.00		**3 437 010 460**
Air mass meter, gasoline injection	02.99-12.00		**0 280 218 019**
Phase sensor	02.99-12.00		**0 232 101 035**
Speed sensor, ignition/injection	02.99-12.00		**0 261 210 160**
Knock sensor	02.99-12.00		**0 261 231 131**
Vacuum pickup, ignition/injection	02.99-12.00		**0 928 400 327**
Wheel speed sensor, front	02.99-12.00	LAB	**0 265 007 063**
		RAB	**0 265 007 064**
Wheel speed sensor, rear	02.99-12.00	LAB	**0 265 007 065**
		RAB	**0 265 007 066**

146

1.3 i.e. [930 MY95]	**1,3 l 68 kW AR 33501 MPI-Weber 4 Zyl.**		
Wheel speed sensor, front	12.94-11.96		**0 265 006 212**
Wheel speed sensor, rear	12.94-11.96		**0 265 006 197**
1.4 i.e. 16V T.S. [930 MY97]	**1,4 l 76 kW AR 33503 4 Zyl.**		
Throttle valve sensor	11.96-02.99		**0 280 122 001**
Air mass meter, gasoline injection	11.96-02.99		**0 280 217 102**
Phase sensor	11.96-02.99		**0 232 101 026**
Pulse generator, ignition/Jetronic	11.96-02.99		**0 261 210 129**
Knock sensor	11.96-02.99		**0 261 231 095**
Temperature sensor, intake air, injection system	11.96-02.99		**0 280 130 073**
Temperature sensor, coolant, injection system	11.96-02.99		**0 280 130 026**
Wheel speed sensor, front	11.96-02.99		**0 265 006 162**
Wheel speed sensor, rear	11.96-02.99	LAB	**0 265 006 325**
		RAB	**0 265 006 326**
1.4 i.e. 16V T.S. [930MY99]	**1,4 l 76 kW AR 33503 4 Zyl.**		
Air mass meter, gasoline injection	02.99-12.00		**0 280 218 001**
Phase sensor	02.99-12.00		**0 232 101 035**
Speed sensor, ignition/injection	02.99-12.00		**0 261 210 160**

Product			
Knock sensor	02.99-12.00		**0 261 231 131**
Wheel speed sensor, front	02.99-12.00	LAB	**0 265 007 063**
		RAB	**0 265 007 064**
Wheel speed sensor, rear	02.99-12.00	LAB	**0 265 007 065**
		RAB	**0 265 007 066**
1.6 i.e. [930 MY95]	**1,6 l 78 kW AR 33201 MPI-Roch. 4 Zyl.**		
Wheel speed sensor, front	05.95-11.96		**0 265 006 212**
Wheel speed sensor, rear	05.95-11.96		**0 265 006 197**
1.6 i.e. 16V T.S. [930 MY97]	**1,6 l 88 kW AR 67601 4 Zyl.**		
Throttle valve sensor	11.96-02.99		**0 280 122 001**
Air mass meter, gasoline injection	11.96-02.99		**0 280 217 111**
Phase sensor	11.96-02.99		**0 232 101 026**
Pulse generator, ignition/Jetronic	11.96-02.99		**0 261 210 129**
Knock sensor	11.96-02.99		**0 261 231 095**
Temperature sensor, intake air, injection system	11.96-02.99		**0 280 130 073**
Temperature sensor, coolant, injection system	11.96-02.99		**0 280 130 026**
Wheel speed sensor, front	11.96-02.99		**0 265 006 162**
Wheel speed sensor, rear	11.96-02.99	LAB	**0 265 006 325**
		RAB	**0 265 006 326**
1.6 i.e. 16V T.S. [930MY99]	**1,6 l 88 kW AR 32102; AR 67601 4 Zyl.**		
Air mass meter, gasoline injection	02.99-12.00		**0 280 218 019**
Phase sensor	02.99-12.00		**0 232 101 035**
Speed sensor, ignition/injection	02.99-12.00		**0 261 210 160**
Knock sensor	02.99-12.00		**0 261 231 131**
Wheel speed sensor, front	02.99-12.00	LAB	**0 265 007 063**
		RAB	**0 265 007 064**
Wheel speed sensor, rear	02.99-12.00	LAB	**0 265 007 065**
		RAB	**0 265 007 066**
1.7 i.e. 16V [930 MY95]	**1,7 l 96 kW AR 33401 4 Zyl.**		
Throttle valve sensor	12.94-11.96		**0 280 122 001**
Air mass meter, gasoline injection	12.94-11.96		**0 280 217 111**
Phase sensor	12.94-11.96		**0 232 103 010**
Pulse generator, ignition/Jetronic	12.94-11.96		**0 261 210 113**
Temperature sensor, intake air, injection system	12.94-11.96		**0 280 130 073**
Temperature sensor, coolant, injection system	12.94-11.96		**0 280 130 026**
Wheel speed sensor, front	12.94-11.96		**0 265 006 212**
Wheel speed sensor, rear	12.94-11.96		**0 265 006 197**
1.8 i.e. 16V T.S. [930 MY97]	**1,8 l 103 kW AR 32201 4 Zyl.**		
Throttle valve assembly	05.98-02.99		**3 437 010 460**
Air mass meter, gasoline injection	05.98-02.99		**0 280 217 111**
Phase sensor	05.98-02.99		**0 232 101 035**
Speed sensor, ignition/injection	05.98-02.99		**0 261 210 160**
Knock sensor	05.98-02.99		**0 261 231 131**
Wheel speed sensor, front	05.98-02.99		**0 265 006 162**
Wheel speed sensor, rear	05.98-02.99	LAB	**0 265 006 325**
		RAB	**0 265 006 326**
1.8 i.e. 16V T.S. [930 MY97]	**1,8 l 103 kW AR 67106 4 Zyl.**		
Throttle valve sensor	11.96-04.98		**0 280 122 001**
Air mass meter, gasoline injection	11.96-04.98		**0 280 217 111**
Phase sensor	11.96-04.98		**0 232 101 026**
Pulse generator, ignition/Jetronic	11.96-04.98		**0 261 210 129**
Knock sensor	11.96-04.98		**0 261 231 095**
Temperature sensor, intake air, injection system	11.96-04.98		**0 280 130 073**
Temperature sensor, coolant, injection system	11.96-04.98		**0 280 130 026**
Wheel speed sensor, front	11.96-04.98		**0 265 006 162**
Wheel speed sensor, rear	11.96-04.98	LAB	**0 265 006 325**
		RAB	**0 265 006 326**
1.8 i.e. 16V T.S. [930MY99]	**1,8 l 103 kW AR 32201 4 Zyl.**		
Throttle valve assembly	02.99-12.00		**3 437 010 460**
Air mass meter, gasoline injection	02.99-12.00		**0 280 218 019**
Phase sensor	02.99-12.00		**0 232 101 035**
Speed sensor, ignition/injection	02.99-12.00		**0 261 210 160**
Knock sensor	02.99-12.00		**0 261 231 131**

Product			
Vacuum pickup, ignition/injection	02.99-12.00		**0 928 400 327**
Wheel speed sensor, front	02.99-12.00	LAB	**0 265 007 063**
		RAB	**0 265 007 064**
Wheel speed sensor, rear	02.99-12.00	LAB	**0 265 007 065**
		RAB	**0 265 007 066**
1.9 JTD [930 MY97]	**1,9 l 76 kW AR 32302 4 Zyl.**		
Air mass meter, diesel	05.98-02.99		**0 280 218 019**
Speed sensor, diesel	05.98-02.99		**0 281 002 214**
Phase sensor	05.98-02.99		**0 281 002 213**
High-pressure sensor (CR system)	05.98-02.99		**0 281 002 210**
Boost pressure sensor, Diesel	05.98-02.99		**0 281 002 215**
Temperature sensor, fuel	05.98-02.99	2PO	**0 281 002 209**
Pedal position sensor, diesel	05.98-02.99		**0 281 002 203**
Wheel speed sensor, front	05.98-02.99	LAB	**0 265 007 063**
		RAB	**0 265 007 064**
Wheel speed sensor, rear	05.98-02.99	LAB	**0 265 007 065**
		RAB	**0 265 007 066**
1.9 JTD [930MY99]	**1,9 l 76 kW AR 32302 4 Zyl.**		
Air mass meter, diesel	02.99-12.00		**0 280 218 019**
Speed sensor, diesel	02.99-12.00		**0 281 002 214**
Phase sensor	02.99-12.00		**0 281 002 213**
High-pressure sensor (CR system)	02.99-12.00		**0 281 002 210**
Boost pressure sensor, Diesel	02.99-12.00		**0 281 002 215**
Temperature sensor, fuel	02.99-12.00	2PO	**0 281 002 209**
Pedal position sensor, diesel	02.99-12.00		**0 281 002 203**
Wheel speed sensor, front	02.99-12.00	LAB	**0 265 007 063**
		RAB	**0 265 007 064**
Wheel speed sensor, rear	02.99-12.00	LAB	**0 265 007 065**
		RAB	**0 265 007 066**
1.9 TD [930 MY95]	**1,9 l 66 kW AR 33601; AR 67501 4 Zyl.**		
Wheel speed sensor, front	12.94-11.96		**0 265 006 212**
Wheel speed sensor, rear	12.94-11.96		**0 265 006 197**
1.9 TD [930 MY97]	**1,9 l 66 kW AR 33601; AR 67501 4 Zyl.**		
Wheel speed sensor, front	11.96-05.98		**0 265 006 162**
Wheel speed sensor, rear	11.96-05.98	LAB	**0 265 006 325**
		RAB	**0 265 006 326**
2.0 ti 16V T.S. [930 MY95]	**2,0 l 110 kW AR 67204 4 Zyl.**		
Throttle valve sensor	10.95-11.96		**0 280 122 001**
Air mass meter, gasoline injection	10.95-11.96		**0 280 217 111**
Phase sensor	10.95-11.96		**0 232 101 026**
Pulse generator, ignition/Jetronic	10.95-11.96		**0 261 210 129**
Knock sensor	10.95-11.96		**0 261 231 095**
Temperature sensor, intake air, injection system	10.95-11.96		**0 280 130 073**
Temperature sensor, coolant, injection system	10.95-11.96		**0 280 130 055**
Wheel speed sensor, front	10.95-11.96		**0 265 006 212**
Wheel speed sensor, rear	10.95-11.96	LAB	**0 265 006 325**
		RAB	**0 265 006 326**
2.0 ti 16V T.S. [930 MY97]	**2,0 l 110 kW AR 32301 4 Zyl.**		
Throttle valve assembly	05.98-02.99		**3 437 010 460**
Air mass meter, gasoline injection	05.98-02.99		**0 280 217 111**
Phase sensor	05.98-02.99		**0 232 101 035**
Speed sensor, ignition/injection	05.98-02.99		**0 261 210 160**
Knock sensor	05.98-02.99		**0 261 231 131**
Wheel speed sensor, front	05.98-02.99		**0 265 006 162**
Wheel speed sensor, rear	05.98-02.99	LAB	**0 265 006 325**
		RAB	**0 265 006 326**
2.0 ti 16V T.S. [930 MY97]	**2,0 l 110 kW AR 67204 4 Zyl.**		
Throttle valve sensor	11.96-04.98		**0 280 122 001**
Air mass meter, gasoline injection	11.96-04.98		**0 280 217 111**
Phase sensor	11.96-04.98		**0 232 101 026**
Pulse generator, ignition/Jetronic	11.96-04.98		**0 261 210 129**
Knock sensor	11.96-04.98		**0 261 231 095**
Temperature sensor, intake air, injection system	11.96-04.98		**0 280 130 073**

Product			
◀ 146			
Temperature sensor, coolant, injection system	11.96-04.98		**0 280 130 055**
Wheel speed sensor, front	11.96-04.98		**0 265 006 212**
Wheel speed sensor, rear	11.96-04.98	LAB	**0 265 006 325**
		RAB	**0 265 006 326**
2.0 ti 16V T.S. [930MY99]		**2,0 l 110 kW AR 32301 4 Zyl.**	
Throttle valve assembly	02.99-12.00		**3 437 010 460**
Air mass meter, gasoline injection	02.99-12.00		**0 280 218 019**
Phase sensor	02.99-12.00		**0 232 101 035**
Speed sensor, ignition/injection	02.99-12.00		**0 261 210 160**
Knock sensor	02.99-12.00		**0 261 231 131**
Vacuum pickup, ignition/injection	02.99-12.00		**0 928 400 327**
Wheel speed sensor, front	02.99-12.00	LAB	**0 265 007 063**
		RAB	**0 265 007 064**
Wheel speed sensor, rear	02.99-12.00	LAB	**0 265 007 065**
		RAB	**0 265 007 066**
147			
1.6 TS 16V [937]		**1,6 l 88 kW AR 32104 4 Zyl.**	
Air mass meter, gasoline injection	11.00→		**0 281 002 309**
Phase sensor	11.00→		**0 232 101 035**
Speed sensor, ignition/injection			
Mot.no. →3636739	11.00→		**0 261 210 160**
Mot.no. 3636740→	11.00→		**0 261 210 227**
Knock sensor	11.00→		**0 261 231 131**
Yaw rate sensor, brake system	11.00→		**0 265 005 241**
Wheel speed sensor, front			
Ricam.no →03222100	11.00-10.02	LAB	**0 265 007 086**
		RAB	**0 265 007 085**
Ricam.no 03222101→	11.02→	LAB	**0 265 007 542**
		RAB	**0 265 007 543**
Wheel speed sensor, rear			
Ricam.no →03222100	11.00-10.02		**0 265 007 089**
Ricam.no 03222101→	11.02→		**0 265 007 544**
1.6 TS 16V ECO [937]		**1,6 l 77 kW AR 37203 4 Zyl.**	
Air mass meter, gasoline injection	11.00→		**0 281 002 309**
Phase sensor	11.00→		**0 232 101 035**
Speed sensor, ignition/injection			
Mot.no. →3613607	11.00→		**0 261 210 160**
Mot.no. 3613608→	11.00→		**0 261 210 227**
Knock sensor	11.00→		**0 261 231 131**
Yaw rate sensor, brake system	11.00→		**0 265 005 241**
Wheel speed sensor, front			
Ricam.no →03222100	11.00-10.02	LAB	**0 265 007 086**
		RAB	**0 265 007 085**
Ricam.no 03222101→	11.02→	LAB	**0 265 007 542**
		RAB	**0 265 007 543**
Wheel speed sensor, rear			
Ricam.no →03222100	11.00-10.02		**0 265 007 089**
Ricam.no 03222101→	11.02→		**0 265 007 544**
1.9 JTD [937]		**1,9 l 74 kW 182B9000 4 Zyl.**	
Air mass meter, diesel	06.03-10.06		**0 280 218 120**
Speed sensor, diesel	06.03-09.03		**0 281 002 474**
	10.03-10.06		**0 281 002 603**
Phase sensor	06.03-10.06		**0 281 002 213**
High-pressure sensor (CR system)			
Ricam.no →03944567	06.03-10.06		**0 281 002 405**
Ricam.no 03944568→	06.03-10.06		**0 281 002 734**
Boost pressure sensor, Diesel	06.03-08.06		**0 281 002 510**
	09.06-10.06		**0 281 002 844**
Yaw rate sensor, brake system	06.03-10.06		**0 265 005 241**

Product			
Wheel speed sensor, front	06.03-10.06	LAB	**0 265 007 542**
		RAB	**0 265 007 543**
Wheel speed sensor, rear	06.03-10.06		**0 265 007 089**
1.9 JTD [937]		**1,9 l 81-85 kW 937A2000 4 Zyl.**	
Air mass meter, diesel	11.00-03.05		**0 280 218 120**
Speed sensor, diesel	11.00-09.03		**0 281 002 474**
	10.03-03.05		**0 281 002 603**
Phase sensor	11.00-03.05		**0 281 002 213**
High-pressure sensor (CR system)			
Ricam.no →03944567	11.00-03.05		**0 281 002 405**
Ricam.no 03944568→	11.00-03.05		**0 281 002 734**
Boost pressure sensor, Diesel			
Mot.no. →2705193	11.00-07.01		**0 281 002 215**
Mot.no. 2705194→	08.01-03.05		**0 281 002 510**
Yaw rate sensor, brake system	11.00-03.05		**0 265 005 241**
Wheel speed sensor, front			
Ricam.no →03222100	11.00-10.02	LAB	**0 265 007 086**
		RAB	**0 265 007 085**
Ricam.no 03222101→	11.02-03.05	LAB	**0 265 007 542**
		RAB	**0 265 007 543**
Wheel speed sensor, rear			
Ricam.no →03222100	11.00-10.02		**0 265 007 089**
Ricam.no 03222101→	11.02-03.05		**0 265 007 544**
1.9 JTDM [937]		**1,9 l 85/92 kW 937A3000; 939A7000 4 Zyl.**	
Air mass meter, diesel	04.05→		**0 281 002 792**
Speed sensor, diesel	04.05→		**0 281 002 603**
Phase sensor	04.05→		**0 281 002 213**
High-pressure sensor (CR system)	04.05→		**0 281 002 706**
Boost pressure sensor, Diesel	04.05-02.07		**0 281 002 437**
	03.07→		**0 281 002 845**
Yaw rate sensor, brake system	04.05→		**0 265 005 241**
Wheel speed sensor, front	04.05→	LAB	**0 265 007 542**
		RAB	**0 265 007 543**
Wheel speed sensor, rear	04.05→		**0 265 007 089**
1.9 JTDM 16V [937]		**1,9 l 93 kW 937A4000 4 Zyl.**	
Air mass meter, diesel	06.03-09.06		**0 280 218 120**
High-pressure sensor (CR system)	06.03-09.06		**0 281 002 534**
Boost pressure sensor, Diesel	06.03-09.06		**0 281 002 437**
Yaw rate sensor, brake system	06.03-09.06		**0 265 005 241**
Wheel speed sensor, front	06.03-09.06	LAB	**0 265 007 542**
		RAB	**0 265 007 543**
Wheel speed sensor, rear	06.03-09.06		**0 265 007 089**
1.9 JTDM 16V [937]		**1,9 l 100 kW 192B1000 4 Zyl.**	
Throttle valve assembly	01.06→		**0 280 750 102**
Air mass meter, diesel	02.04-12.05		**0 280 218 120**
	01.06→		**0 281 002 792**
High-pressure sensor (CR system)	02.04-12.05		**0 281 002 534**
	01.06→		**0 281 002 706**
Boost pressure sensor, Diesel	02.04→		**0 281 002 437**
Yaw rate sensor, brake system	02.04→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)			
Ricam.no →3489988	01.06-02.06		**0 265 005 303**
Wheel speed sensor, front	02.04→	LAB	**0 265 007 542**
		RAB	**0 265 007 543**
Wheel speed sensor, rear	02.04→		**0 265 007 089**
1.9 JTDM 16V [937]		**1,9 l 103 kW 192A5000 4 Zyl.**	
Air mass meter, diesel	10.02-09.03		**0 280 218 120**
High-pressure sensor (CR system)	10.02-09.03		**0 281 002 534**
Boost pressure sensor, Diesel	10.02-09.03		**0 281 002 437**
Yaw rate sensor, brake system	10.02-09.03		**0 265 005 241**
Wheel speed sensor, front	11.02-09.03	LAB	**0 265 007 542**
		RAB	**0 265 007 543**
Wheel speed sensor, rear	10.02-09.03		**0 265 007 089**

A

Product			
1.9 JTDM 16V [937]		**1,9 l 110 kW 937A5000 4 Zyl.**	
Throttle valve assembly	06.05→	NPF	**0 280 750 102**
Air mass meter, diesel	10.04-03.05		**0 280 218 120**
	06.05→		**0 281 002 792**
High-pressure sensor (CR system)	10.04-03.05		**0 281 002 534**
	06.05→		**0 281 002 706**
Boost pressure sensor, Diesel	10.04-03.05		**0 281 002 437**
	06.05→		**0 281 002 437**
Yaw rate sensor, brake system	06.05→		**0 265 005 241**
	10.04-03.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)			
Ricam.no →3489988	06.05-02.06		**0 265 005 303**
Wheel speed sensor, front	06.05→	LAB	**0 265 007 542**
	10.04-03.05	LAB	**0 265 007 542**
	06.05→	RAB	**0 265 007 543**
	10.04-03.05	RAB	**0 265 007 543**
Wheel speed sensor, rear	06.05→		**0 265 007 089**
	10.04-03.05		**0 265 007 089**
2.0 TS 16V [937]		**2,0 l 110 kW AR 32310 4 Zyl.**	
Throttle valve assembly			
Mot.no. →3649574	11.00-04.04		**0 280 750 102**
Mot.no. 3649575→	05.04→		**1 287 213 612**
Air mass meter, gasoline injection	11.00→		**0 281 002 309**
Phase sensor	11.00→		**0 232 101 035**
Speed sensor, ignition/injection			
Mot.no. →3649574	11.00→		**0 261 210 160**
Mot.no. 3649575→	11.00→		**0 261 210 227**
Knock sensor	11.00→		**0 261 231 131**
Yaw rate sensor, brake system	11.00→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)			
Ricam.no →3486881	11.00-01.06		**0 265 005 303**
Wheel speed sensor, front			
Ricam.no →03222100	11.00-10.02	LAB	**0 265 007 086**
		RAB	**0 265 007 085**
Ricam.no 03222101→	11.02→	LAB	**0 265 007 542**
		RAB	**0 265 007 543**
Wheel speed sensor, rear			
Ricam.no →03222100	11.00-10.02		**0 265 007 089**
Ricam.no 03222101→	11.02→		**0 265 007 544**
3.2 GTA [937]		**3,2 l 184 kW 932A000 6 Zyl.**	
Throttle valve assembly	01.03→		**0 280 750 014**
Air mass meter, gasoline injection	01.03→		**0 281 002 533**
Phase sensor	01.03→		**0 232 103 024**
Speed sensor, ignition/injection	01.03→		**0 261 210 203**
Yaw rate sensor, brake system	01.03→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)			
Ricam.no →3486881	01.03-01.06		**0 265 005 303**
Wheel speed sensor, front	01.03→	LAB	**0 265 007 486**
		RAB	**0 265 007 487**
Wheel speed sensor, rear	01.03→		**0 265 007 089**

155

Product			
1.6 i 16V T.S. [167 MY96]		**1,6 l 85 kW AR 67601 4 Zyl.**	
Throttle valve sensor	05.96-10.97		**0 280 122 001**
Air mass meter, gasoline injection	05.96-10.97		**0 280 217 111**
Phase sensor	05.96-10.97		**0 232 101 026**
Speed sensor, ignition/injection	05.96-10.97		**0 261 210 129**
Knock sensor	05.96-10.97		**0 261 231 095**
Temperature sensor, intake air, injection system	05.96-10.97		**0 280 130 073**
Temperature sensor, coolant, injection system	05.96-10.97		**0 280 130 026**
Wheel speed sensor, front	05.96-10.97		**0 265 006 212**
Wheel speed sensor, rear	05.96-10.97		**0 265 006 197**
1.7 T.S. [167 MY92]		**1,7 l 85/95 kW AR 67103; AR 67105 4 Zyl.**	
Throttle valve sensor	02.92-04.96		**0 280 122 001**
Speed sensor, ignition/injection	02.92-04.96		**0 261 210 090**
Temperature sensor, coolant, injection system	02.92-04.96		**0 280 130 026**
Wheel speed sensor, front			
Ricam.no →0159167	02.92-04.96		**0 265 006 212**
Ricam.no 0159168→	02.92-04.96		**0 265 006 162**
Wheel speed sensor, rear	02.92-04.96		**0 265 006 197**
1.8 i 16V T.S. [167 MY96]		**1,8 l 100 kW AR 67106 4 Zyl.**	
Throttle valve sensor	05.96-10.97		**0 280 122 001**
Air mass meter, gasoline injection	05.96-10.97		**0 280 217 111**
Phase sensor	05.96-10.97		**0 232 101 026**
Speed sensor, ignition/injection	05.96-10.97		**0 261 210 129**
Knock sensor	05.96-10.97		**0 261 231 095**
Temperature sensor, intake air, injection system	05.96-10.97		**0 280 130 073**
Temperature sensor, coolant, injection system	05.96-10.97		**0 280 130 026**
Wheel speed sensor, front	05.96-10.97		**0 265 006 212**
Wheel speed sensor, rear	05.96-10.97		**0 265 006 197**
1.8 T.S. [167 MY92]		**1,8 l 93 kW AR 67101/67102 4 Zyl.**	
Throttle valve sensor	02.92-04.96		**0 280 122 001**
Speed sensor, ignition/injection	02.92-04.96		**0 261 210 090**
Temperature sensor, coolant, injection system	02.92-04.96		**0 280 130 026**
Wheel speed sensor, front			
Ricam.no →0159167	02.92-04.96		**0 265 006 212**
Ricam.no 0159168→	02.92-04.96		**0 265 006 162**
Wheel speed sensor, rear	02.92-04.96		**0 265 006 197**
1.9 TD [167]		**1,9 l 66 kW AR 67501 4 Zyl.**	
Wheel speed sensor, front			
Ricam.no →0159167	04.93-04.96		**0 265 006 212**
Ricam.no 0159168→	04.93-04.96		**0 265 006 162**
Wheel speed sensor, rear			
Ricam.no →0159167	04.93-04.96		**0 265 006 197**
1.9 TD [167 MY96]		**1,9 l 66 kW AR 33601 4 Zyl.**	
Wheel speed sensor, front	05.96-10.97		**0 265 006 212**
Wheel speed sensor, rear	05.96-10.97		**0 265 006 197**
2.0 i 16V T.S. [167 MY96]		**2,0 l 110 kW AR 67204 4 Zyl.**	
Throttle valve sensor	05.96-10.97		**0 280 122 001**
Air mass meter, gasoline injection	05.96-10.97		**0 280 217 111**
Phase sensor	05.96-10.97		**0 232 101 026**
Speed sensor, ignition/injection	05.96-10.97		**0 261 210 129**
Knock sensor	05.96-10.97		**0 261 231 095**
Temperature sensor, intake air, injection system	05.96-10.97		**0 280 130 073**
Temperature sensor, coolant, injection system	05.96-10.97		**0 280 130 055**
Wheel speed sensor, front	05.96-10.97		**0 265 006 212**
Wheel speed sensor, rear	05.96-10.97		**0 265 006 197**
2.0 i 16V T.S. [167 MY96]		**2,0 l 110 kW AR 67299 4 Zyl.**	
Throttle valve sensor	05.96-10.97		**0 280 122 001**
Air mass meter, gasoline injection	05.96-10.97		**0 280 217 111**
Phase sensor	05.96-10.97		**0 232 101 026**
Speed sensor, ignition/injection	05.96-10.97		**0 261 210 129**
Knock sensor	05.96-10.97		**0 261 231 095**
Temperature sensor, intake air, injection system	05.96-10.97		**0 280 130 073**
Temperature sensor, coolant, injection system	05.96-10.97		**0 280 130 026**
Wheel speed sensor, front	05.96-10.97		**0 265 006 212**
Wheel speed sensor, rear	05.96-10.97		**0 265 006 197**
2.0 T.S. [167 MY92]		**2,0 l 104/106 kW AR 67201; AR 67202 4 Zyl.**	
Throttle valve sensor	02.92-02.95		**0 280 122 001**
Speed sensor, ignition/injection	02.92-02.95		**0 261 210 090**
Temperature sensor, coolant, injection system	02.92-02.95		**0 280 130 026**
Wheel speed sensor, front			
Ricam.no →0159167	02.92-02.95		**0 265 006 212**
Ricam.no 0159168→	02.92-02.95		**0 265 006 162**
Wheel speed sensor, rear	02.92-02.95		**0 265 006 197**

A

Product			
◀ 155			
2.0 T.S. 16V [167 MY92]	**2,0 l 110 kW AR 67204 4 Zyl.**		
Throttle valve sensor	03.95-04.96		**0 280 122 001**
Air mass meter, gasoline injection	03.95-04.96		**0 280 217 111**
Phase sensor	03.95-04.96		**0 232 101 026**
Speed sensor, ignition/injection	03.95-04.96		**0 261 210 129**
Knock sensor	03.95-04.96		**0 261 231 095**
Temperature sensor, intake air, injection system	03.95-04.96		**0 280 130 073**
Temperature sensor, coolant, injection system	03.95-04.96		**0 280 130 026**
Wheel speed sensor, front			
Ricam.no →0159167	03.95-04.96		**0 265 006 212**
Ricam.no 0159168→	03.95-04.96		**0 265 006 162**
Wheel speed sensor, rear	03.95-04.96		**0 265 006 197**
2.0 Turbo 4x4 [167 MY92]	**2,0 l 140 kW AR 67203 4 Zyl.**		
Acceleration sensor, ABS	02.92-04.96		**0 265 005 030**
Lateral acceleration sensor, brake system	02.92-04.96		**0 265 005 031**
Wheel speed sensor, front			
Fg.no. VET0160725→	02.92-04.96		**0 265 006 162**
Fg.no. →VET0160724	02.92-04.96		**0 265 001 355**
Wheel speed sensor, rear	02.92-04.96		**0 265 001 304**
2.5 i V6 [167 MY96]	**2,5 l 121 kW AR 67303 6 Zyl.**		
Throttle valve sensor	05.96-10.97		**0 280 122 001**
Air flow sensor, gasoline injection	05.96-10.97		**0 280 202 211**
			0 986 280 091
Speed sensor, ignition/injection	05.96-10.97		**0 261 210 090**
Temperature sensor, coolant, injection system	05.96-10.97		**0 280 130 026**
Wheel speed sensor, front	05.96-10.97		**0 265 006 212**
Wheel speed sensor, rear	05.96-10.97		**0 265 006 197**
2.5 TD [167]	**2,5 l 92 kW VM07B / VM31B 4 Zyl.**		
Air flow sensor, diesel	04.93-04.96		**0 280 202 205**
Pulse generator, diesel	04.93-04.96		**0 281 002 096**
Temperature sensor, coolant, diesel	04.93-04.96		**0 280 130 055**
Pedal position sensor, diesel	04.93-05.95		**0 205 001 009**
	06.95-04.96		**0 205 001 016**
Wheel speed sensor, front			
Ricam.no →0159167	04.93-04.96		**0 265 006 212**
Ricam.no 0159168→	04.93-04.96		**0 265 006 162**
Wheel speed sensor, rear			
Ricam.no →0159167	04.93-04.96		**0 265 006 197**
2.5 TD [167 MY96]	**2,5 l 92 kW VM31B EDC-Bosch 4 Zyl.**		
Air flow sensor, diesel	05.96-10.97		**0 280 202 205**
Pedal position sensor, diesel	05.96-10.97		**0 204 120 802**
Wheel speed sensor, front	05.96-10.97		**0 265 006 212**
Wheel speed sensor, rear	05.96-10.97		**0 265 006 197**
2.5 V6 [167 MY92]	**2,5 l 120 kW AR 67301 6 Zyl.**		
Throttle valve sensor	02.92-04.96		**0 280 122 001**
Air flow sensor, gasoline injection	02.92-04.96		**0 280 202 204**
			0 986 280 055
Speed sensor, ignition/injection	02.92-04.96		**0 261 210 090**
Temperature sensor, coolant, injection system	02.92-04.96		**0 280 130 026**
Wheel speed sensor, front			
Ricam.no →0159167	02.92-04.96		**0 265 006 212**
Ricam.no 0159168→	02.92-04.96		**0 265 006 162**
Wheel speed sensor, rear	02.92-04.96		**0 265 006 197**

156 Berlina

1.6 TS 16V [932]	**1,6 l 88 kW AR32102 4 Zyl.**		
Throttle valve assembly	04.98-09.00		**3 437 010 452**
Air mass meter, gasoline injection	04.98-06.98		**0 280 217 111**
	07.98-09.00		**0 280 218 019**
Phase sensor	04.98-09.00		**0 232 101 026**
Speed sensor, ignition/injection	04.98-09.00		**0 261 210 160**
Knock sensor	04.98-09.00		**0 261 231 131**
Temperature sensor, intake air, injection system	04.98-09.00		**0 280 130 073**
Temperature sensor, coolant, injection system	04.98-09.00		**0 280 130 026**
Wheel speed sensor, front			
Ricam.no →0062418	04.98-09.00	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no 0062419→	04.98-09.00	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear			
Ricam.no →0062418	04.98-09.00		**0 265 007 018**
Ricam.no 0062419→	04.98-09.00		**0 265 007 048**
1.6 TS 16V [932]	**1,6 l 88 kW AR32103 4 Zyl.**		
Throttle valve assembly	09.00-12.01		**0 280 750 073**
Mot.no. →3636739	01.02-10.05		**0 280 750 073**
Air mass meter, gasoline injection	09.00-10.05		**0 281 002 309**
Phase sensor	09.00-12.01		**0 232 101 026**
	01.02-10.05		**0 232 101 035**
Speed sensor, ignition/injection	09.00-12.01		**0 261 210 160**
Mot.no. →3636739	01.02-10.05		**0 261 210 160**
Mot.no. 3636740→	01.02-10.05		**0 261 210 227**
Knock sensor	09.00-10.05		**0 261 231 131**
Temperature sensor, intake air, injection system	09.00-12.01		**0 280 130 073**
Temperature sensor, coolant, injection system	09.00-12.01		**0 280 130 026**
Yaw rate sensor, brake system	01.02-10.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	01.02-10.05		**0 265 005 303**
Wheel speed sensor, front	10.02-10.05	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Ricam.no →0062418	09.00-12.01	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no →00526907	01.02-10.02	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Ricam.no 0062419→	09.00-12.01	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear	10.02-10.05	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
Ricam.no →0062418	09.00-12.01		**0 265 007 018**
Ricam.no →00526907	01.02-10.02		**0 265 007 048**
Ricam.no 0062419→	09.00-12.01		**0 265 007 048**
1.6 TS 16V [932]	**1,6 l 88 kW AR32104 4 Zyl.**		
Throttle valve assembly	09.00-12.01		**0 280 750 073**
Mot.no. →3636739	01.02-10.05		**0 280 750 073**
Air mass meter, gasoline injection	01.02-10.05		**0 281 002 309**
	09.00-12.01	LLE	**0 281 002 309**
Phase sensor	09.00-12.01		**0 232 101 026**
	01.02-10.05		**0 232 101 035**
Speed sensor, ignition/injection	09.00-12.01		**0 261 210 160**
Mot.no. →3636739	01.02-10.05		**0 261 210 160**
Mot.no. 3636740→	01.02-10.05		**0 261 210 227**
Knock sensor	09.00-10.05		**0 261 231 131**
Temperature sensor, intake air, injection system	09.00-12.01		**0 280 130 073**
Temperature sensor, coolant, injection system	09.00-12.01		**0 280 130 026**
Yaw rate sensor, brake system	01.02-10.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	01.02-10.05		**0 265 005 303**
Wheel speed sensor, front	10.02-10.05	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Ricam.no →0062418	09.00-12.01	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no →00526907	01.02-10.02	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Ricam.no 0062419→	09.00-12.01	LAB	**0 265 007 046**
		RAB	**0 265 007 047**

Product			
Wheel speed sensor, rear	10.02-10.05	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
Ricam.no →0062418	09.00-12.01		**0 265 007 018**
Ricam.no →00526907	01.02-10.02		**0 265 007 048**
Ricam.no 0062419→	09.00-12.01		**0 265 007 048**
1.6 TS 16V [932]		**1,6 l 88 kW**	**AR67601 4 Zyl.**
Throttle valve assembly			
Ricam.no 00084340→	10.97-09.00		**3 437 010 452**
Air mass meter, gasoline injection	10.97-06.98		**0 280 217 111**
	07.98-09.00		**0 280 218 019**
Phase sensor	10.97-09.00		**0 232 101 026**
Speed sensor, ignition/injection	10.97-09.00		**0 261 210 160**
Knock sensor	10.97-09.00		**0 261 231 131**
Temperature sensor, intake air, injection system	10.97-09.00		**0 280 130 073**
Temperature sensor, coolant, injection system	10.97-09.00		**0 280 130 026**
Wheel speed sensor, front	10.97-03.98	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no →0062418	10.97-09.00	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no 0062419→	10.97-09.00	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear	10.97-03.98		**0 265 007 018**
Ricam.no →0062418	10.97-09.00		**0 265 007 018**
Ricam.no 0062419→	10.97-09.00		**0 265 007 048**
1.8 TS 16V [932]		**1,8 l 106 kW**	**AR32201 4 Zyl.**
Throttle valve assembly	10.97-09.00		**3 437 010 460**
Air mass meter, gasoline injection	10.97-09.00		**0 280 218 019**
Phase sensor	10.97-09.00		**0 232 101 035**
Speed sensor, ignition/injection	10.97-09.00		**0 261 210 160**
Knock sensor	10.97-09.00		**0 261 231 131**
Temperature sensor, coolant, injection system	10.97-09.00	2PO	**0 281 002 209**
Wheel speed sensor, front	10.97-03.98	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no →0062418	10.97-09.00	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no 0062419→	10.97-09.00	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear	10.97-03.98		**0 265 007 018**
Ricam.no →0062418	10.97-09.00		**0 265 007 018**
Ricam.no 0062419→	10.97-09.00		**0 265 007 048**
1.8 TS 16V [932]		**1,8 l 106 kW**	**AR32205 4 Zyl.**
Throttle valve assembly	09.00-12.01		**0 280 750 102**
Mot.no. →3649574	01.02-04.04		**0 280 750 102**
Mot.no. 3649575→	05.04-10.05		**1 287 213 612**
Air mass meter, gasoline injection	01.02-10.05		**0 281 002 309**
	09.00-12.01	LLE	**0 281 002 309**
Phase sensor	09.00-10.05		**0 232 101 035**
Speed sensor, ignition/injection	09.00-12.01		**0 261 210 160**
Mot.no. →3649574	01.02-10.05		**0 261 210 160**
Mot.no. 3649575→	01.02-10.05		**0 261 210 227**
Knock sensor	09.00-10.05		**0 261 231 131**
Temperature sensor, coolant, injection system	09.00-12.01	2PO	**0 281 002 209**
Yaw rate sensor, brake system	01.02-10.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	01.02-10.05		**0 265 005 303**
Wheel speed sensor, front	10.02-10.05	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Ricam.no →0062418	09.00-12.01	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no →00526907	01.02-10.02	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Ricam.no 0062419→	09.00-12.01	LAB	**0 265 007 046**
		RAB	**0 265 007 047**

Product			
Wheel speed sensor, rear	10.02-10.05	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
Ricam.no →0062418	09.00-12.01		**0 265 007 018**
Ricam.no →00526907	01.02-10.02		**0 265 007 048**
Ricam.no 0062419→	09.00-12.01		**0 265 007 048**
1.9 JTD [932]		**1,9 l 74 kW**	**182B9.000 4 Zyl.**
Air mass meter, diesel	06.03-12.04		**0 281 002 309**
Speed sensor, diesel	06.03-12.04		**0 281 002 214**
Phase sensor	06.03-12.04		**0 281 002 213**
High-pressure sensor (CR system)	06.03-12.04		**0 281 002 260**
Yaw rate sensor, brake system	06.03-12.04		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	06.03-12.04		**0 265 005 303**
Wheel speed sensor, front	06.03-12.04	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Wheel speed sensor, rear	06.03-12.04	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
1.9 JTD [932]		**1,9 l 76 kW**	**AR32302 4 Zyl.**
Air mass meter, diesel	05.98-09.00		**0 280 218 019**
	10.97-04.98		**0 281 002 199**
Speed sensor, diesel	10.97-09.00		**0 281 002 214**
Phase sensor	10.97-09.00		**0 281 002 213**
High-pressure sensor (CR system)	10.97-09.00		**0 281 002 210**
Boost pressure sensor, Diesel	10.97-09.00		**0 281 002 215**
Temperature sensor, coolant, diesel	10.97-09.00	2PO	**0 281 002 209**
Temperature sensor, fuel	10.97-09.00	2PO	**0 281 002 209**
Pedal position sensor, diesel	10.97-09.00		**0 281 002 203**
Wheel speed sensor, front	10.97-03.98	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no →0062418	10.97-09.00	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no 0062419→	10.97-09.00	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear	10.97-03.98		**0 265 007 018**
Ricam.no →0062418	10.97-09.00		**0 265 007 018**
Ricam.no 0062419→	10.97-09.00		**0 265 007 048**
1.9 JTD [932]		**1,9 l 81-85 kW**	**AR37101 / 937A2.000 4 Zyl.**
Air mass meter, diesel	09.00-12.01		**0 281 002 309**
Speed sensor, diesel	09.00-12.01		**0 281 002 214**
Phase sensor	09.00-12.01		**0 281 002 213**
High-pressure sensor (CR system)	09.00-12.01		**0 281 002 260**
Boost pressure sensor, Diesel	09.00-12.01		**0 281 002 215**
Temperature sensor, coolant, diesel	09.00-12.01	2PO	**0 281 002 209**
Temperature sensor, fuel	09.00-12.01	2PO	**0 281 002 209**
Wheel speed sensor, front			
Ricam.no →0062418	09.00-12.01	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no 0062419→	09.00-12.01	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear			
Ricam.no →0062418	09.00-12.01		**0 265 007 018**
Ricam.no 0062419→	09.00-12.01		**0 265 007 048**
1.9 JTD [932]		**1,9 l 85 kW**	**937A2.000 4 Zyl.**
Air mass meter, diesel	01.02-10.05		**0 281 002 309**
Speed sensor, diesel	01.02-01.04		**0 281 002 474**
	02.04-10.05		**0 281 002 603**
Phase sensor	01.02-10.05		**0 281 002 213**
High-pressure sensor (CR system)			
Mot.no. →3928481	01.02-01.04	LLE	**0 281 002 405**
Mot.no. →3940874	01.02-01.04	RLE	**0 281 002 405**
Mot.no. 3928482→	02.04-10.05	LLE	**0 281 002 734**
Mot.no. 3940875→	02.04-10.05	RLE	**0 281 002 734**
Boost pressure sensor, Diesel	01.02-10.05		**0 281 002 844**
Yaw rate sensor, brake system	01.02-10.05		**0 265 005 241**

A

Product			
◀ 156 Berlina			
Pressure sensor, ESP, (electronic stability program)	01.02-10.05		**0 265 005 303**
Wheel speed sensor, front	10.02-10.05	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Ricam.no →00526907	01.02-10.02	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear	10.02-10.05	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
Ricam.no →00526907	01.02-10.02		**0 265 007 048**
1.9 JTD 16V [932]	**1,9 l 93/100/103 kW 192A5.000; 192B1000; 937A4.000 4 Zyl.**		
Throttle valve assembly	10.02-10.05		**0 280 750 102**
Air mass meter, diesel	10.02-10.05		**0 280 218 113**
High-pressure sensor (CR system)	10.02-10.05		**0 281 002 534**
Boost pressure sensor, Diesel	10.02-10.05		**0 281 002 437**
Yaw rate sensor, brake system	10.02-10.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	10.02-10.05		**0 265 005 303**
Wheel speed sensor, front	10.02-10.05	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Wheel speed sensor, rear	10.02-10.05	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
2.0 JTS 16V [932]	**2,0 l 119/121 kW 932A2.000; 937A1.000 4 Zyl.**		
Throttle valve assembly	01.02-12.05		**0 280 750 102**
Air mass meter, gasoline injection	01.02-12.05		**0 280 218 113**
Phase sensor	01.02-12.05		**0 232 101 035**
Speed sensor, ignition/injection	01.02-12.05		**0 261 210 227**
Knock sensor	01.02-12.05		**0 261 231 148**
Yaw rate sensor, brake system	01.02-12.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	01.02-12.05		**0 265 005 303**
Wheel speed sensor, front	10.02-12.05	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Ricam.no →00526907	01.02-10.02	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear	10.02-12.05	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
Ricam.no →00526907	01.02-10.02		**0 265 007 048**
2.0 TS 16V [932]	**2,0 l 114 kW AR32301 4 Zyl.**		
Throttle valve assembly	10.97-09.00	GS	**3 437 010 460**
Air mass meter, gasoline injection	10.97-09.00		**0 280 218 019**
Phase sensor	10.97-09.00		**0 232 101 035**
Speed sensor, ignition/injection	10.97-09.00		**0 261 210 160**
Knock sensor	10.97-09.00		**0 261 231 131**
Vacuum pickup, ignition/injection	10.97-09.00		**0 928 400 327**
Wheel speed sensor, front	10.97-03.98	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no →0062418	10.97-09.00	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no 0062419→	10.97-09.00	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear	10.97-03.98		**0 265 007 018**
Ricam.no →0062418	10.97-09.00		**0 265 007 018**
Ricam.no 0062419→	10.97-09.00		**0 265 007 048**
2.0 TS 16V [932]	**2,0 l 114 kW AR32303 4 Zyl.**		
Throttle valve assembly	10.97-12.01		**3 437 010 460**
Air mass meter, gasoline injection	10.97-12.01		**0 280 218 019**
Phase sensor	10.97-12.01		**0 232 101 035**
Speed sensor, ignition/injection	10.97-12.01		**0 261 210 160**
Knock sensor	10.97-12.01		**0 261 231 131**
Vacuum pickup, ignition/injection	10.97-12.01		**0 928 400 327**
Wheel speed sensor, front	10.97-03.98	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no →0062418	10.97-12.01	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no 0062419→	10.97-12.01	LAB	**0 265 007 046**
		RAB	**0 265 007 047**

Product			
Wheel speed sensor, rear	10.97-03.98		**0 265 007 018**
Ricam.no →0062418	10.97-12.01		**0 265 007 018**
Ricam.no 0062419→	10.97-12.01		**0 265 007 048**
2.0 TS 16V [932]	**2,0 l 114 kW AR32310 4 Zyl.**		
Throttle valve assembly	09.00-12.01		**0 280 750 102**
Air mass meter, gasoline injection	09.00-12.01	LLE	**0 281 002 309**
Phase sensor	09.00-12.01		**0 232 101 035**
Speed sensor, ignition/injection	09.00-12.01		**0 261 210 160**
Knock sensor	09.00-12.01		**0 261 231 131**
Vacuum pickup, ignition/injection	09.00-12.01		**0 928 400 327**
Wheel speed sensor, front			
Ricam.no →0062418	09.00-12.01	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no 0062419→	09.00-12.01	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear			
Ricam.no →0062418	09.00-12.01		**0 265 007 018**
Ricam.no 0062419→	09.00-12.01		**0 265 007 048**
2.0 TS 16V [932]	**2,0 l 121 kW AR32310 4 Zyl.**		
Throttle valve assembly	01.02-10.05		**0 280 750 102**
Air mass meter, gasoline injection	01.02-10.05		**0 281 002 309**
Phase sensor	01.02-10.05		**0 232 101 035**
Speed sensor, ignition/injection			
Mot.no. →3649574	01.02-10.05		**0 261 210 160**
Mot.no. 3649575→	01.02-10.05		**0 261 210 227**
Knock sensor	01.02-10.05		**0 261 231 131**
Vacuum pickup, ignition/injection	01.02-10.05		**0 928 400 327**
Yaw rate sensor, brake system	01.02-10.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	01.02-10.05		**0 265 005 303**
Wheel speed sensor, front	01.02-10.05	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Wheel speed sensor, rear	01.02-10.05	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
2.4 JTD [932]	**2,4 l 100 kW AR32501 5 Zyl.**		
Air mass meter, diesel	05.98-09.00		**0 280 218 019**
	10.97-04.98		**0 281 002 199**
Speed sensor, diesel	10.97-09.00		**0 281 002 474**
Phase sensor	10.97-09.00		**0 281 002 213**
High-pressure sensor (CR system)	10.97-09.00		**0 281 002 210**
Boost pressure sensor, Diesel	10.97-09.00		**0 281 002 215**
Temperature sensor, coolant, diesel	10.97-09.00	2PO	**0 281 002 209**
Temperature sensor, fuel	10.97-09.00	2PO	**0 281 002 209**
Pedal position sensor, diesel	10.97-09.00		**0 281 002 203**
Wheel speed sensor, front	10.97-03.98	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no →0062418	10.97-09.00	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no 0062419→	10.97-09.00	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear	10.97-03.98		**0 265 007 018**
Ricam.no →0062418	10.97-09.00		**0 265 007 018**
Ricam.no 0062419→	10.97-09.00		**0 265 007 048**
2.4 JTD [932]	**2,4 l 100 kW 839A6.000 5 Zyl.**		
Air mass meter, diesel	09.00-12.01		**0 281 002 309**
Speed sensor, diesel	09.00-12.01		**0 281 002 474**
Phase sensor	09.00-12.01		**0 281 002 213**
High-pressure sensor (CR system)	09.00-12.01		**0 281 002 405**
Boost pressure sensor, Diesel	09.00-12.01		**0 281 002 215**
Temperature sensor, coolant, diesel	09.00-12.01	2PO	**0 281 002 209**
Temperature sensor, fuel	09.00-12.01	2PO	**0 281 002 209**
Pedal position sensor, diesel	09.00-12.01		**0 281 002 203**

A

Product			
Wheel speed sensor, front			
Ricam.no →0062418	09.00-12.01	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no 0062419→	09.00-12.01	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear			
Ricam.no →0062418	09.00-12.01		**0 265 007 018**
Ricam.no 0062419→	09.00-12.01		**0 265 007 048**
2.4 JTD [932]	**2,4 l 110 kW 841C000 5 Zyl.**		
Air mass meter, diesel	01.02-10.05		**0 281 002 309**
Speed sensor, diesel	01.02-10.05		**0 281 002 474**
Phase sensor	01.02-10.05		**0 281 002 213**
High-pressure sensor (CR system)	01.02-10.05		**0 281 002 405**
Boost pressure sensor, Diesel	01.02-10.05		**0 281 002 844**
Yaw rate sensor, brake system	01.02-10.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	01.02-10.05		**0 265 005 303**
Wheel speed sensor, front	10.02-10.05	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Ricam.no →00526907	01.02-10.02	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear	10.02-10.05	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
Ricam.no →00526907	01.02-10.02		**0 265 007 048**
2.4 JTD [932]	**2,4 l 129 kW 841G.000 5 Zyl.**		
Throttle valve assembly	06.03-10.05		**0 280 750 102**
Air mass meter, diesel	06.03-10.05		**0 281 002 598**
Boost pressure sensor, Diesel	06.03-10.05		**0 281 002 437**
Yaw rate sensor, brake system	06.03-10.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	06.03-10.05		**0 265 005 303**
Wheel speed sensor, front	06.03-10.05	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Wheel speed sensor, rear	06.03-10.05	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
2.4 JTD 20V [932]	**2,4 l 120 kW 841M000 5 Zyl.**		
Throttle valve assembly	10.04-10.05		**0 280 750 102**
Air mass meter, diesel	10.04-10.05		**0 281 002 598**
Boost pressure sensor, Diesel	10.04-10.05		**0 281 002 437**
Yaw rate sensor, brake system	10.04-10.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	10.04-10.05		**0 265 005 303**
Wheel speed sensor, front	10.04-10.05	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Wheel speed sensor, rear	10.04-10.05	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
2.5 24V [932]	**2,5 l 140 kW AR32401; AR32402 6 Zyl.**		
Throttle valve assembly	10.97-12.01		**0 280 750 014**
Air mass meter, gasoline injection	10.97-12.01		**0 280 217 531**
Speed sensor, ignition/injection	10.97-12.01		**0 261 210 163**
Knock sensor	10.97-12.01	L43	**0 261 231 095**
Temperature sensor, coolant, injection system	10.97-12.01		**0 280 130 055**
Wheel speed sensor, front	10.97-03.98	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no →0062418	10.97-12.01	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no 0062419→	10.97-12.01	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear	10.97-03.98		**0 265 007 018**
Ricam.no →0062418	10.97-12.01		**0 265 007 018**
Ricam.no 0062419→	10.97-12.01		**0 265 007 048**
2.5 24V [932]	**2,5 l 140 kW AR32405 6 Zyl.**		
Throttle valve assembly	09.00-12.01		**0 280 750 014**
Air mass meter, gasoline injection	09.00-12.01		**0 280 218 054**
Speed sensor, ignition/injection	09.00-12.01		**0 261 210 163**
Knock sensor	09.00-12.01	L43	**0 261 231 095**

Product			
Temperature sensor, coolant, injection system	09.00-12.01		**0 280 130 055**
Wheel speed sensor, front			
Ricam.no →0062418	09.00-12.01	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no 0062419→	09.00-12.01	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear			
Ricam.no →0062418	09.00-12.01		**0 265 007 018**
Ricam.no 0062419→	09.00-12.01		**0 265 007 048**
2.5 24V [932]	**2,5 l 141 kW AR32405 6 Zyl.**		
Throttle valve assembly	01.02-10.05		**0 280 750 014**
Air mass meter, gasoline injection	01.02-10.05		**0 280 218 054**
Phase sensor	01.02-10.05		**0 232 103 024**
Speed sensor, ignition/injection	01.02-10.05		**0 261 210 203**
Yaw rate sensor, brake system	01.02-10.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	01.02-10.05		**0 265 005 303**
Wheel speed sensor, front	10.02-10.05	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Ricam.no →00526907	01.02-10.02	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear	10.02-10.05	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
Ricam.no →00526907	01.02-10.02		**0 265 007 048**
3.2 GTA [932]	**3,2 l 184 kW 932A000 6 Zyl.**		
Throttle valve assembly	03.02-10.05		**0 280 750 014**
Air mass meter, gasoline injection	03.02-10.05		**0 281 002 533**
Phase sensor	03.02-10.05		**0 232 103 024**
Speed sensor, ignition/injection	03.02-10.05		**0 261 210 203**
Yaw rate sensor, brake system	03.02-10.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	03.02-10.05		**0 265 005 303**
Wheel speed sensor, front	10.02-10.05	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Ricam.no →00526907	03.02-10.02	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear	10.02-10.05	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
Ricam.no →00526907	03.02-10.02		**0 265 007 048**

156 Cross Wagon Q4

1.9 JTD 4x4 [932]	**1,9 l 110 kW 937A5000 4 Zyl.**		
Throttle valve assembly	10.04→		**0 280 750 102**
Air mass meter, diesel	10.04-05.05	EU3	**0 280 218 113**
High-pressure sensor (CR system)	10.04-05.05		**0 281 002 534**
	06.05→		**0 281 002 706**
Boost pressure sensor, Diesel	10.04→		**0 281 002 437**
Yaw rate sensor, brake system	10.04→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	10.04→		**0 265 005 303**
Wheel speed sensor, rear	10.04→		**0 265 007 691**

156 Sport Wagon

1.6 TS 16V [932]	**1,6 l 88 kW AR32104 4 Zyl.**		
Throttle valve assembly			
Mot.no. →3636739	01.02-12.05		**0 280 750 073**
Air mass meter, gasoline injection	01.02-12.05		**0 281 002 309**
Phase sensor	01.02-12.05		**0 232 101 035**
Speed sensor, ignition/injection			
Mot.no. →3636739	01.02-12.05		**0 261 210 160**
Mot.no. 3636740→	01.02-12.05		**0 261 210 227**
Knock sensor	01.02-12.05		**0 261 231 131**
Yaw rate sensor, brake system	01.02-12.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	01.02-12.05		**0 265 005 303**

A

Product			
◀ 156 Sport Wagon			
Wheel speed sensor, front	10.02-12.05	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Ricam.no →00526907	01.02-10.02	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear	10.02-12.05	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
Ricam.no →00526907	01.02-10.02		**0 265 007 048**
1.6 TS 16V [932]	**1,6 l 88 kW AR32104 CF3 4 Zyl.**		
Throttle valve assembly	09.00-12.01		**0 280 750 073**
Air mass meter, gasoline injection	09.00-12.01	LLE	**0 281 002 309**
Phase sensor	09.00-12.01		**0 232 101 026**
Speed sensor, ignition/injection	09.00-12.01		**0 261 210 160**
Knock sensor	09.00-12.01		**0 261 231 131**
Temperature sensor, intake air, injection system	09.00-12.01		**0 280 130 073**
Temperature sensor, coolant, injection system	09.00-12.01		**0 280 130 026**
Wheel speed sensor, front			
Ricam.no →0062418	09.00-12.01	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no 0062419→	09.00-12.01	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear			
Ricam.no →0062418	09.00-12.01		**0 265 007 018**
Ricam.no 0062419→	09.00-12.01		**0 265 007 048**
1.6 TS 16V [932]	**1,6 l 88 kW AR67601 CF2 4 Zyl.**		
Throttle valve assembly	06.00-09.00		**3 437 010 452**
Air mass meter, gasoline injection	06.00-09.00		**0 280 218 019**
Phase sensor	06.00-09.00		**0 232 101 026**
Speed sensor, ignition/injection	06.00-09.00		**0 261 210 160**
Knock sensor	06.00-09.00		**0 261 231 131**
Temperature sensor, intake air, injection system	06.00-09.00		**0 280 130 073**
Temperature sensor, coolant, injection system	06.00-09.00		**0 280 130 026**
Wheel speed sensor, front			
Ricam.no →0062418	06.00-09.00	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no 0062419→	06.00-09.00	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear			
Ricam.no →0062418	06.00-09.00		**0 265 007 018**
Ricam.no 0062419→	06.00-09.00		**0 265 007 048**
1.8 TS 16V [932]	**1,8 l 106 kW AR32201 CF2 4 Zyl.**		
Throttle valve assembly	06.00-09.00		**3 437 010 460**
Air mass meter, gasoline injection	06.00-09.00		**0 280 218 019**
Phase sensor	06.00-09.00		**0 232 101 035**
Speed sensor, ignition/injection	06.00-09.00		**0 261 210 160**
Knock sensor	06.00-09.00		**0 261 231 131**
Temperature sensor, coolant, injection system	06.00-09.00	2PO	**0 281 002 209**
Wheel speed sensor, front			
Ricam.no →0062418	06.00-09.00	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no 0062419→	06.00-09.00	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear			
Ricam.no →0062418	06.00-09.00		**0 265 007 018**
Ricam.no 0062419→	06.00-09.00		**0 265 007 048**
1.8 TS 16V [932]	**1,8 l 106 kW AR32205 4 Zyl.**		
Throttle valve assembly			
Mot.no. →3649574	01.02-04.04		**0 280 750 102**
Mot.no. 3649575→	05.04-12.05		**1 287 213 612**
Air mass meter, gasoline injection	01.02-12.05		**0 281 002 309**
Phase sensor	01.02-12.05		**0 232 101 035**
Speed sensor, ignition/injection			
Mot.no. →3649574	01.02-12.05		**0 261 210 160**
Mot.no. 3649575→	01.02-12.05		**0 261 210 227**

Product			
Knock sensor	01.02-12.05		**0 261 231 131**
Yaw rate sensor, brake system	01.02-12.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	01.02-12.05		**0 265 005 303**
Wheel speed sensor, front	10.02-12.05	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Ricam.no →00526907	01.02-10.02	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear	10.02-12.05	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
Ricam.no →00526907	01.02-10.02		**0 265 007 048**
1.8 TS 16V [932]	**1,8 l 106 kW AR32205 CF3 4 Zyl.**		
Throttle valve assembly	09.00-12.01		**0 280 750 102**
Air mass meter, gasoline injection	09.00-12.01	LLE	**0 281 002 309**
Phase sensor	09.00-12.01		**0 232 101 035**
Speed sensor, ignition/injection	09.00-12.01		**0 261 210 160**
Knock sensor	09.00-12.01		**0 261 231 131**
Temperature sensor, coolant, injection system	09.00-12.01	2PO	**0 281 002 209**
Wheel speed sensor, front			
Ricam.no →0062418	09.00-12.01	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no 0062419→	09.00-12.01	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear			
Ricam.no →0062418	09.00-12.01		**0 265 007 018**
Ricam.no 0062419→	09.00-12.01		**0 265 007 048**
1.9 JTD [932]	**1,9 l 74 kW 182B9.000 4 Zyl.**		
Air mass meter, diesel	06.03-12.04		**0 281 002 309**
Speed sensor, diesel	06.03-12.04		**0 281 002 214**
Phase sensor	06.03-12.04		**0 281 002 213**
High-pressure sensor (CR system)	06.03-12.04		**0 281 002 260**
Yaw rate sensor, brake system	06.03-12.04		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	06.03-12.04		**0 265 005 303**
Wheel speed sensor, front	06.03-12.04	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Wheel speed sensor, rear	06.03-12.04	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
1.9 JTD [932]	**1,9 l 76 kW AR32302 CF2 4 Zyl.**		
Air mass meter, diesel	06.00-09.00		**0 280 218 019**
Speed sensor, diesel	06.00-09.00		**0 281 002 214**
Phase sensor	06.00-09.00		**0 281 002 213**
High-pressure sensor (CR system)	06.00-09.00		**0 281 002 210**
Boost pressure sensor, Diesel	06.00-09.00		**0 281 002 215**
Temperature sensor, coolant, diesel	06.00-09.00	2PO	**0 281 002 209**
Temperature sensor, fuel	06.00-09.00	2PO	**0 281 002 209**
Pedal position sensor, diesel	06.00-09.00		**0 281 002 203**
Wheel speed sensor, front			
Ricam.no →0062418	06.00-09.00	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no 0062419→	06.00-09.00	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear			
Ricam.no →0062418	06.00-09.00		**0 265 007 018**
Ricam.no 0062419→	06.00-09.00		**0 265 007 048**
1.9 JTD [932]	**1,9 l 80-85 kW AR37101 / 937A2.000 4 Zyl.**		
Air mass meter, diesel	09.00-12.01		**0 281 002 309**
Speed sensor, diesel	09.00-12.01		**0 281 002 214**
Phase sensor	09.00-12.01		**0 281 002 213**
High-pressure sensor (CR system)	09.00-12.01		**0 281 002 260**
Boost pressure sensor, Diesel	09.00-12.01		**0 281 002 215**
Temperature sensor, coolant, diesel	09.00-12.01	2PO	**0 281 002 209**
Temperature sensor, fuel	09.00-12.01	2PO	**0 281 002 209**

A

Product			
Wheel speed sensor, front			
Ricam.no →0062418	09.00-12.01	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no 0062419→	09.00-12.01	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear			
Ricam.no →0062418	09.00-12.01		**0 265 007 018**
Ricam.no 0062419→	09.00-12.01		**0 265 007 048**
1.9 JTD [932]	**1,9 l 85 kW 937A2.000 4 Zyl.**		
Air mass meter, diesel	01.02-12.05		**0 281 002 309**
Speed sensor, diesel	01.02-01.04		**0 281 002 474**
	02.04-12.05		**0 281 002 603**
Phase sensor	01.02-12.05		**0 281 002 213**
High-pressure sensor (CR system)			
Mot.no. →3928481	01.02-01.04	LLE	**0 281 002 405**
Mot.no. 3928482→	02.04-12.05	LLE	**0 281 002 734**
Yaw rate sensor, brake system	01.02-12.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	01.02-12.05		**0 265 005 303**
Wheel speed sensor, front	10.02-12.05	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Ricam.no →00526907	01.02-10.02	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear	10.02-12.05	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
Ricam.no →00526907	01.02-10.02		**0 265 007 048**
1.9 JTD 16V [932]	**1,9 l 93 kW 937A4.000 4 Zyl.**		
Throttle valve assembly	06.03-10.05		**0 280 750 102**
Air mass meter, diesel	06.03-10.05		**0 280 218 113**
High-pressure sensor (CR system)	06.03-10.05		**0 281 002 534**
Boost pressure sensor, Diesel	06.03-10.05		**0 281 002 437**
Yaw rate sensor, brake system	06.03-10.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	06.03-10.05		**0 265 005 303**
Wheel speed sensor, front	06.03-10.05	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Wheel speed sensor, rear	06.03-10.05	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
1.9 JTD 16V [932]	**1,9 l 93 kW 937A4000 4 Zyl.**		
Throttle valve assembly	10.03-12.05		**0 280 750 102**
Boost pressure sensor, Diesel	10.03-12.05		**0 281 002 437**
Yaw rate sensor, brake system	10.03-12.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	10.03-12.05		**0 265 005 303**
Wheel speed sensor, rear	10.03-12.05		**0 265 007 691**
1.9 JTD 16V [932]	**1,9 l 100/103 kW 192A5.000; 192B1000 4 Zyl.**		
Throttle valve assembly	10.02-12.05		**0 280 750 102**
Air mass meter, diesel	10.02-12.05		**0 280 218 113**
High-pressure sensor (CR system)	10.02-12.05		**0 281 002 534**
Boost pressure sensor, Diesel	10.02-12.05		**0 281 002 437**
Yaw rate sensor, brake system	10.02-12.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	10.02-12.05		**0 265 005 303**
Wheel speed sensor, front	10.02-12.05	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Wheel speed sensor, rear	10.02-12.05	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
1.9 JTD 16V [932]	**1,9 l 110 kW 937A5000 4 Zyl.**		
Throttle valve assembly	10.03-12.05		**0 280 750 102**
Boost pressure sensor, Diesel	10.03-12.05		**0 281 002 437**
Yaw rate sensor, brake system	10.03-12.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	10.03-12.05		**0 265 005 303**
Wheel speed sensor, rear	10.03-12.05		**0 265 007 691**
2.0 JTS 16V [932]	**2,0 l 119/121 kW 932A2.000; 937A1.000 4 Zyl.**		
Throttle valve assembly	01.02-12.05		**0 280 750 102**
Air mass meter, gasoline injection	01.02-12.05		**0 280 218 113**
Phase sensor	01.02-12.05		**0 232 101 035**

Product			
Speed sensor, ignition/injection	01.02-12.05		**0 261 210 227**
Knock sensor	01.02-12.05		**0 261 231 148**
Yaw rate sensor, brake system	01.02-12.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	01.02-12.05		**0 265 005 303**
Wheel speed sensor, front	10.02-12.05	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Ricam.no →00526907	01.02-10.02	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear	10.02-12.05	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
Ricam.no →00526907	01.02-10.02		**0 265 007 048**
2.0 TS 16V [932]	**2,0 l 114 kW AR32301 CF2 4 Zyl.**		
Throttle valve assembly	06.00-09.00	GS	**3 437 010 460**
Air mass meter, gasoline injection	06.00-09.00		**0 280 218 019**
Phase sensor	06.00-09.00		**0 232 101 035**
Speed sensor, ignition/injection	06.00-09.00		**0 261 210 160**
Knock sensor	06.00-09.00		**0 261 231 131**
Vacuum pickup, ignition/injection	06.00-09.00		**0 928 400 327**
Wheel speed sensor, front			
Ricam.no →0062418	06.00-09.00	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no 0062419→	06.00-09.00	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear			
Ricam.no →0062418	06.00-09.00		**0 265 007 018**
Ricam.no 0062419→	06.00-09.00		**0 265 007 048**
2.0 TS 16V [932]	**2,0 l 114 kW AR32310 CF3 4 Zyl.**		
Throttle valve assembly	09.00-12.01		**0 280 750 102**
Air mass meter, gasoline injection	09.00-12.01	LLE	**0 281 002 309**
Phase sensor	09.00-12.01		**0 232 101 035**
Speed sensor, ignition/injection	09.00-12.01		**0 261 210 160**
Knock sensor	09.00-12.01		**0 261 231 131**
Vacuum pickup, ignition/injection	09.00-12.01		**0 928 400 327**
Wheel speed sensor, front			
Ricam.no →0062418	09.00-12.01	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no 0062419→	09.00-12.01	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear			
Ricam.no →0062418	09.00-12.01		**0 265 007 018**
Ricam.no 0062419→	09.00-12.01		**0 265 007 048**
2.0 TS 16V [932]	**2,0 l 121 kW AR32310 CF3 4 Zyl.**		
Throttle valve assembly	01.02-10.05		**0 280 750 102**
Air mass meter, gasoline injection	01.02-10.05	LLE	**0 281 002 309**
Phase sensor	01.02-10.05		**0 232 101 035**
Speed sensor, ignition/injection			
Mot.no. →3649574	01.02-10.05		**0 261 210 160**
Mot.no. 3649575→	01.02-10.05		**0 261 210 227**
Knock sensor	01.02-10.05		**0 261 231 131**
Vacuum pickup, ignition/injection	01.02-10.05		**0 928 400 327**
Yaw rate sensor, brake system	01.02-10.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	01.02-10.05		**0 265 005 303**
Wheel speed sensor, front	01.02-10.05	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Wheel speed sensor, rear	01.02-10.05	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
2.4 JTD [932]	**2,4 l 100 kW AR32501 CF2 5 Zyl.**		
Air mass meter, diesel	06.00-09.00		**0 280 218 019**
Speed sensor, diesel	06.00-09.00		**0 281 002 474**
Phase sensor	06.00-09.00		**0 281 002 213**
High-pressure sensor (CR system)	06.00-09.00		**0 281 002 210**
Boost pressure sensor, Diesel	06.00-09.00		**0 281 002 215**
Temperature sensor, coolant, diesel	06.00-09.00	2PO	**0 281 002 209**

A

Product			
◀ 156 Sport Wagon			
Temperature sensor, fuel	06.00-09.00	2PO	**0 281 002 209**
Pedal position sensor, diesel	06.00-09.00		**0 281 002 203**
Wheel speed sensor, front			
Ricam.no →0062418	06.00-09.00	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no 0062419→	06.00-09.00	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear			
Ricam.no →0062418	06.00-09.00		**0 265 007 018**
Ricam.no 0062419→	06.00-09.00		**0 265 007 048**
2.4 JTD [932]	**2,4 l 100 kW 839A6.000 CF3 5 Zyl.**		
Air mass meter, diesel	09.00-12.01		**0 281 002 309**
Speed sensor, diesel	09.00-12.01		**0 281 002 474**
Phase sensor	09.00-12.01		**0 281 002 213**
High-pressure sensor (CR system)	09.00-12.01		**0 281 002 405**
Boost pressure sensor, Diesel	09.00-12.01		**0 281 002 215**
Temperature sensor, coolant, diesel	09.00-12.01	2PO	**0 281 002 209**
Temperature sensor, fuel	09.00-12.01	2PO	**0 281 002 209**
Pedal position sensor, diesel	09.00-12.01		**0 281 002 203**
Wheel speed sensor, front			
Ricam.no →0062418	09.00-12.01	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no 0062419→	09.00-12.01	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear			
Ricam.no →0062418	09.00-12.01		**0 265 007 018**
Ricam.no 0062419→	09.00-12.01		**0 265 007 048**
2.4 JTD [932]	**2,4 l 110 kW 841C000 5 Zyl.**		
Air mass meter, diesel	01.02-10.05		**0 281 002 309**
Speed sensor, diesel	01.02-10.05		**0 281 002 474**
Phase sensor	01.02-10.05		**0 281 002 213**
High-pressure sensor (CR system)	01.02-10.05		**0 281 002 405**
Boost pressure sensor, Diesel	01.02-10.05		**0 281 002 844**
Yaw rate sensor, brake system	01.02-10.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	01.02-10.05		**0 265 005 303**
Wheel speed sensor, front	10.02-10.05	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Ricam.no →00526907	01.02-10.02	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear	10.02-10.05	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
Ricam.no →00526907	01.02-10.02		**0 265 007 048**
2.4 JTD [932]	**2,4 l 129 kW 841G000 5 Zyl.**		
Throttle valve assembly	06.03-12.05		**0 280 750 102**
Air mass meter, diesel	06.03-12.05		**0 281 002 598**
Yaw rate sensor, brake system	06.03-12.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	06.03-12.05		**0 265 005 303**
Wheel speed sensor, front	06.03-12.05	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Wheel speed sensor, rear	06.03-12.05	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
2.4 JTD 20V [932]	**2,4 l 120 kW 841M000 5 Zyl.**		
Throttle valve assembly	10.04-10.05		**0 280 750 102**
Air mass meter, diesel	10.04-10.05		**0 281 002 598**
Yaw rate sensor, brake system	10.04-10.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	10.04-10.05		**0 265 005 303**
Wheel speed sensor, front	10.04-10.05	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Wheel speed sensor, rear	10.04-10.05	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
2.5 24V [932]	**2,5 l 140 kW AR32401 CF2 6 Zyl.**		
Throttle valve assembly	06.00-09.00		**0 280 750 014**
Air mass meter, gasoline injection	06.00-09.00		**0 280 217 531**
Speed sensor, ignition/injection	06.00-09.00		**0 261 210 163**
Knock sensor	06.00-09.00	L43	**0 261 231 095**
Temperature sensor, coolant, injection system	06.00-09.00		**0 280 130 055**
Wheel speed sensor, front			
Ricam.no →0062418	06.00-09.00	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no 0062419→	06.00-09.00	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear			
Ricam.no →0062418	06.00-09.00		**0 265 007 018**
Ricam.no 0062419→	06.00-09.00		**0 265 007 048**
2.5 24V [932]	**2,5 l 140 kW AR32405 CF3 6 Zyl.**		
Throttle valve assembly	09.00-12.01		**0 280 750 014**
Air mass meter, gasoline injection	09.00-12.01		**0 280 218 054**
Speed sensor, ignition/injection	09.00-12.01		**0 261 210 163**
Knock sensor	09.00-12.01	L43	**0 261 231 095**
Temperature sensor, coolant, injection system	09.00-12.01		**0 280 130 055**
Wheel speed sensor, front			
Ricam.no →0062418	09.00-12.01	LAB	**0 265 007 016**
		RAB	**0 265 007 017**
Ricam.no 0062419→	09.00-12.01	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear			
Ricam.no →0062418	09.00-12.01		**0 265 007 018**
Ricam.no 0062419→	09.00-12.01		**0 265 007 048**
2.5 24V [932]	**2,5 l 141 kW AR32405 6 Zyl.**		
Throttle valve assembly	01.02-10.05		**0 280 750 014**
Air mass meter, gasoline injection	01.02-10.05		**0 280 218 054**
Phase sensor	01.02-10.05		**0 232 103 024**
Speed sensor, ignition/injection	01.02-10.05		**0 261 210 203**
Yaw rate sensor, brake system	01.02-10.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	01.02-10.05		**0 265 005 303**
Wheel speed sensor, front	10.02-10.05	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Ricam.no →00526907	01.02-10.02	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear	10.02-10.05	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
Ricam.no →00526907	01.02-10.02		**0 265 007 048**
3.2 GTA [932]	**3,2 l 184 kW 932A000 6 Zyl.**		
Throttle valve assembly	03.02-10.05		**0 280 750 014**
Air mass meter, gasoline injection	03.02-10.05		**0 281 002 533**
Phase sensor	03.02-10.05		**0 232 103 024**
Speed sensor, ignition/injection	03.02-10.05		**0 261 210 203**
Yaw rate sensor, brake system	03.02-10.05		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	03.02-10.05		**0 265 005 303**
Wheel speed sensor, front	10.02-10.05	LAB,MFD	**0 265 007 486**
		MFD,RAB	**0 265 007 487**
Ricam.no →00526907	03.02-10.02	LAB	**0 265 007 046**
		RAB	**0 265 007 047**
Wheel speed sensor, rear	10.02-10.05	MFD	**0 265 007 488**
		OFD	**0 265 007 113**
Ricam.no →00526907	03.02-10.02		**0 265 007 048**

156 Sport Wagon Q4

1.9 JTD 16V 4x4 [932]	**1,9 l 110 kW 937A5000 4 Zyl.**		
Throttle valve assembly	10.04→		**0 280 750 102**
Air mass meter, diesel	10.04-05.05	EU3	**0 280 218 113**
High-pressure sensor (CR system)	10.04-05.05		**0 281 002 534**
	06.05→		**0 281 002 706**
Boost pressure sensor, Diesel	10.04→		**0 281 002 437**
Yaw rate sensor, brake system	10.04→		**0 265 005 241**

Product		
Pressure sensor, ESP, (electronic stability program)	10.04→	**0 265 005 303**
Wheel speed sensor, rear	10.04→	**0 265 007 691**

159 Berlina

1.8 i [939]	**1,8 l 96 kW 939A4000 4 Zyl.**	
Wheel speed sensor, front	03.06→	**0 265 008 055**
Wheel speed sensor, rear	03.06→	**0 265 008 056**
1.9 JTDM 8V [939]	**1,9 l 85/88 kW 937A7000; 939A1000 4 Zyl.**	
Speed sensor, diesel	06.05→	**0 281 002 603**
Phase sensor	06.05→	**0 281 002 213**
High-pressure sensor (CR system)	06.05→	**0 281 002 706**
Boost pressure sensor, Diesel	06.05-02.07	**0 281 002 437**
	03.07→	**0 281 002 845**
Wheel speed sensor, front	06.05→	**0 265 008 055**
Wheel speed sensor, rear	06.05→	**0 265 008 056**
1.9 JTDM 16V [939]	**1,9 l 100/110 kW 937A8000; 939A2000 4 Zyl.**	
High-pressure sensor (CR system)	06.05→	**0 281 002 706**
Boost pressure sensor, Diesel	06.05→	**0 281 002 845**
Wheel speed sensor, front	06.05→	**0 265 008 055**
Wheel speed sensor, rear	06.05→	**0 265 008 056**
1.9 JTS [939]	**1,9 l 118 kW 939A6000 4 Zyl.**	
Air mass meter, gasoline injection	06.05→	**0 280 218 164**
Phase sensor	06.05→	**0 232 103 052**
Wheel speed sensor, front	06.05→	**0 265 008 055**
Wheel speed sensor, rear	06.05→	**0 265 008 056**
2.2 JTS [939]	**2,2 l 136 kW 939A5000 4 Zyl.**	
Air mass meter, gasoline injection	06.05→	**0 280 218 164**
Phase sensor	06.05→	**0 232 103 052**
Wheel speed sensor, front	06.05→	**0 265 008 055**
Wheel speed sensor, rear	06.05→	**0 265 008 056**
2.4 JTD 20V [939]	**2,4 l 154 kW 939A9000 5 Zyl.**	
Air mass meter, diesel	02.07→	**0 281 002 764**
High-pressure sensor (CR system)	02.07→	**0 281 002 706**
Boost pressure sensor, Diesel	02.07-02.07	**0 281 002 437**
	03.07→	**0 281 002 845**
Wheel speed sensor, front	02.07→	**0 265 008 055**
Wheel speed sensor, rear	02.07→	**0 265 008 056**
2.4 JTDM 20V [939]	**2,4 l 147 kW 939A3000 5 Zyl.**	
Air mass meter, diesel	06.05→	**0 281 002 764**
High-pressure sensor (CR system)	06.05→	**0 281 002 706**
Boost pressure sensor, Diesel	06.05-02.07	**0 281 002 437**
	03.07→	**0 281 002 845**
Wheel speed sensor, front	06.05→	**0 265 008 055**
Wheel speed sensor, rear	06.05→	**0 265 008 056**

159 Berlina Q4

2.4 JTD 20V [939]	**2,4 l 154 kW 939A9000 5 Zyl.**	
Air mass meter, diesel	09.06→	**0 281 002 764**
High-pressure sensor (CR system)	09.06→	**0 281 002 706**
Boost pressure sensor, Diesel	09.06-02.07	**0 281 002 437**
	03.07→	**0 281 002 845**
Wheel speed sensor, front	09.06→	**0 265 008 055**
Wheel speed sensor, rear	09.06→	**0 265 008 056**
3.2 JTS [939]	**3,2 l 191 kW 939A000 6 Zyl.**	
Air mass meter, gasoline injection	01.06→	**0 280 218 182**
Wheel speed sensor, front	01.06→	**0 265 008 055**
Wheel speed sensor, rear	01.06→	**0 265 008 056**

159 Sport Wagon

1.8 i [939]	**1,8 l 96 kW 939A4000 4 Zyl.**	
Wheel speed sensor, front	03.06→	**0 265 008 055**
Wheel speed sensor, rear	03.06→	**0 265 008 056**
1.9 JTDM 8V [939]	**1,9 l 85/88 kW 937A7000; 939A1000 4 Zyl.**	
Speed sensor, diesel	03.06→	**0 281 002 603**
Phase sensor	03.06→	**0 281 002 213**
High-pressure sensor (CR system)	03.06→	**0 281 002 706**
Boost pressure sensor, Diesel	03.06-02.07	**0 281 002 437**
	03.07→	**0 281 002 845**
Wheel speed sensor, front	03.06→	**0 265 008 055**
Wheel speed sensor, rear	03.06→	**0 265 008 056**
1.9 JTDM 16V [939]	**1,9 l 100/110 kW 937A8000; 939A2000 4 Zyl.**	
High-pressure sensor (CR system)	03.06→	**0 281 002 706**
Boost pressure sensor, Diesel	03.06→	**0 281 002 845**
Wheel speed sensor, front	03.06→	**0 265 008 055**
Wheel speed sensor, rear	03.06→	**0 265 008 056**
1.9 JTS [939]	**1,9 l 118 kW 939A6000 4 Zyl.**	
Air mass meter, gasoline injection	03.06→	**0 280 218 164**
Phase sensor	03.06→	**0 232 103 052**
Wheel speed sensor, front	03.06→	**0 265 008 055**
Wheel speed sensor, rear	03.06→	**0 265 008 056**
2.2 JTS [939]	**2,2 l 136 kW 939A5000 4 Zyl.**	
Air mass meter, gasoline injection	03.06→	**0 280 218 164**
Phase sensor	03.06→	**0 232 103 052**
Wheel speed sensor, front	03.06→	**0 265 008 055**
Wheel speed sensor, rear	03.06→	**0 265 008 056**
2.4 JTD 20V [939]	**2,4 l 154 kW 939A9000 5 Zyl.**	
Air mass meter, diesel	02.07→	**0 281 002 764**
High-pressure sensor (CR system)	02.07→	**0 281 002 706**
Boost pressure sensor, Diesel	02.07-02.07	**0 281 002 437**
	03.07→	**0 281 002 845**
Wheel speed sensor, front	02.07→	**0 265 008 055**
Wheel speed sensor, rear	02.07→	**0 265 008 056**
2.4 JTDM 20V [939]	**2,4 l 147 kW 939A3000 5 Zyl.**	
Air mass meter, diesel	03.06→	**0 281 002 764**
High-pressure sensor (CR system)	03.06→	**0 281 002 706**
Boost pressure sensor, Diesel	03.06-02.07	**0 281 002 437**
	03.07→	**0 281 002 845**
Wheel speed sensor, front	03.06→	**0 265 008 055**
Wheel speed sensor, rear	03.06→	**0 265 008 056**

159 Sport Wagon Q4

2.4 JTD 20V [939]	**2,4 l 154 kW 939A9000 5 Zyl.**	
Air mass meter, diesel	09.06→	**0 281 002 764**
High-pressure sensor (CR system)	09.06→	**0 281 002 706**
Boost pressure sensor, Diesel	09.06-02.07	**0 281 002 437**
	03.07→	**0 281 002 845**
Wheel speed sensor, front	09.06→	**0 265 008 055**
Wheel speed sensor, rear	09.06→	**0 265 008 056**
3.2 JTS [939]	**3,2 l 191 kW 939A000 6 Zyl.**	
Air mass meter, gasoline injection	03.06→	**0 280 218 182**
Wheel speed sensor, front	03.06→	**0 265 008 055**
Wheel speed sensor, rear	03.06→	**0 265 008 056**

164

2.0 T.S. [164]	**2,0 l 106 kW AR 64103 4 Zyl.**	
Throttle valve sensor	09.92-10.98	**0 280 122 001**
Speed sensor, ignition/injection	09.92-10.98	**0 261 210 036**
Temperature sensor, coolant, injection system	09.92-10.98	**0 280 130 026**

A

Product			
◀ 164			
Wheel speed sensor, front	09.92-10.98	LAB	**0 265 006 118**
		RAB	**0 265 006 119**
Wheel speed sensor, rear			
Fg.no. →6302794	09.92-10.98		**0 265 003 075**
2.0 Turbo i.e. [164]	**2,0 l 126 kW AR 06476 4 Zyl.**		
Throttle valve sensor	01.88-09.92		**0 280 120 313**
Air flow sensor, gasoline injection	01.88-09.92		**0 280 202 060**
			0 986 280 046
Temperature sensor, coolant, injection system	01.88-09.92		**0 280 130 026**
Relay, Jetronic	01.88-09.92		**0 280 230 006**
Wheel speed sensor, front	01.88-02.89		**0 265 001 156**
	03.89-09.92	LAB	**0 265 001 251**
		RAB	**0 265 001 250**
Wheel speed sensor, rear	01.88-09.92	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.0 Twin Spark [164]	**2,0 l 102/107 kW AR 06416; AR 06420 4 Zyl.**		
Throttle valve sensor	06.87-09.92		**0 280 120 315**
Air flow sensor, gasoline injection	06.87-09.92		**0 280 202 210**
			0 986 280 063
Speed sensor, ignition/injection	06.87-09.92		**0 261 210 036**
Temperature sensor, coolant, injection system	06.87-09.92		**0 280 130 026**
Wheel speed sensor, front	06.87-02.89		**0 265 001 156**
	03.89-09.92	LAB	**0 265 001 251**
		RAB	**0 265 001 250**
Wheel speed sensor, rear	06.87-09.92	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.0 V6 Turbo [164]	**2,0 l 148 kW AR 64102 6 Zyl.**		
Throttle valve sensor	09.92-10.98		**0 280 120 435**
Air flow sensor, gasoline injection	09.92-10.98		**0 280 203 034**
Speed sensor, ignition/injection	09.92-10.98		**0 261 210 036**
Knock sensor	09.92-10.98		**0 261 231 007**
Pressure sensor, intake manifold, gasoline	09.92-10.98	HL	**0 280 101 001**
Temperature sensor, coolant, injection system	09.92-10.98		**0 280 130 032**
Wheel speed sensor, front	09.92-09.92	LAB	**0 265 001 251**
		RAB	**0 265 001 250**
Wheel speed sensor, rear	09.92-10.98	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.0 V6 Turbo i.e. [164]	**2,0 l 148 kW AR 64102 6 Zyl.**		
Throttle valve sensor	03.91-09.92		**0 280 120 435**
Air flow sensor, gasoline injection	03.91-09.92		**0 280 203 034**
Speed sensor, ignition/injection	03.91-09.92		**0 261 210 036**
Pulse generator, ignition/Jetronic	03.91-09.92		**0 356 914 224**
Knock sensor	03.91-09.92		**0 261 231 007**
Pressure sensor, intake manifold, gasoline	03.91-09.92	HL	**0 280 101 001**
Temperature sensor, coolant, injection system	03.91-09.92		**0 280 130 032**
Wheel speed sensor, front	03.91-09.92	LAB	**0 265 001 251**
		RAB	**0 265 001 250**
Wheel speed sensor, rear	03.91-09.92	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.5 D Turbo [164]	**2,5 l 85 kW VM84A 4 Zyl.**		
Wheel speed sensor, front	06.87-02.89		**0 265 001 156**
	03.89-09.92	LAB	**0 265 001 251**
		RAB	**0 265 001 250**
Wheel speed sensor, rear	06.87-09.92	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.5 D Turbo [164]	**2,5 l 92 kW VM08B / VM32B 4 Zyl.**		
Air flow sensor, diesel	09.92-10.98		**0 281 002 085**
Pulse generator, diesel	09.92-10.98		**0 281 002 096**
Temperature sensor, coolant, diesel	09.92-10.98		**0 280 130 055**
Pedal position sensor, diesel	09.92-10.98		**0 205 001 009**
Wheel speed sensor, front	09.92-10.98	LAB	**0 265 006 118**
		RAB	**0 265 006 119**

Product			
Wheel speed sensor, rear			
Fg.no. →6302794	09.92-10.98		**0 265 003 075**
3.0 i.e. [164]	**3,0 l 132/136-140 kW AR 06410; AR 06412; AR 64303 6 Zyl.**		
Throttle valve sensor	06.87-09.92		**0 280 120 300**
Air flow sensor, gasoline injection	06.87-09.92		**0 280 202 201**
Speed sensor, ignition/injection	06.87-09.92		**0 261 210 036**
Temperature sensor, coolant, injection system	06.87-09.92		**0 280 130 026**
Relay, Jetronic	06.87-09.92		**0 332 014 113**
Wheel speed sensor, front	06.87-02.89		**0 265 001 156**
	03.89-09.92	LAB	**0 265 001 251**
		RAB	**0 265 001 250**
Wheel speed sensor, rear	06.87-09.92	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
3.0 i.e.Q.V. [164]	**3,0 l 147 kW AR 64301 6 Zyl.**		
Throttle valve sensor	09.90-09.92		**0 280 120 300**
Air flow sensor, gasoline injection	09.90-09.92		**0 280 203 035**
Speed sensor, ignition/injection	09.90-09.92		**0 261 210 036**
Temperature sensor, coolant, injection system	09.90-09.92		**0 280 130 026**
Wheel speed sensor, front	09.90-09.92	LAB	**0 265 001 251**
		RAB	**0 265 001 250**
Wheel speed sensor, rear	09.90-09.92	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
3.0 Q4 4x4 [164]	**3,0 l 171 kW AR 64307 / 66304 6 Zyl.**		
Throttle valve sensor	12.93-10.98		**0 280 122 001**
Air mass meter, gasoline injection	12.93-10.98	OWE	**0 280 217 503**
Phase sensor	12.93-10.98		**0 232 103 009**
Speed sensor, ignition/injection	12.93-10.98		**0 261 210 113**
Knock sensor	12.93-10.98	L43	**0 261 231 095**
Temperature sensor, intake air, injection system	12.93-10.98		**0 280 130 073**
Temperature sensor, coolant, injection system	12.93-10.98		**0 280 130 026**
Wheel speed sensor, front	12.93-10.98	LAB	**0 265 006 118**
		RAB	**0 265 006 119**
Wheel speed sensor, rear	12.93-10.98		**0 265 006 120**
3.0 V6 12V [164]	**3,0 l 132 kW AR 64305; AR 64399 6 Zyl.**		
Throttle valve sensor	09.92-10.98		**0 280 122 001**
Speed sensor, ignition/injection	09.92-10.98		**0 261 210 036**
Knock sensor	09.92-10.98		**0 261 231 007**
Temperature sensor, coolant, injection system	09.92-10.98		**0 280 130 026**
Wheel speed sensor, front	09.92-10.98	LAB	**0 265 006 118**
		RAB	**0 265 006 119**
Wheel speed sensor, rear			
Fg.no. →6302794	09.92-10.98		**0 265 003 075**
3.0 V6 24V [164]	**3,0 l 155 kW AR 64306; AR 66301 / 66302 6 Zyl.**		
Throttle valve sensor	09.92-10.98		**0 280 122 001**
Air flow sensor, gasoline injection	09.92-10.98		**0 280 203 026**
			0 986 280 042
Phase sensor	09.92-10.98		**0 261 210 090**
Speed sensor, ignition/injection	09.92-10.98		**0 261 210 047**
Knock sensor	09.92-10.98		**0 261 231 007**
Temperature sensor, coolant, injection system	09.92-10.98		**0 280 130 026**
Wheel speed sensor, front	09.92-10.98	LAB	**0 265 006 118**
		RAB	**0 265 006 119**
Wheel speed sensor, rear			
Fg.no. →6299489	09.92-10.98		**0 265 003 075**
3.0 V6 24V Q.V. [164]	**3,0 l 169-171 kW AR 64304 6 Zyl.**		
Throttle valve sensor	09.92-10.98		**0 280 122 001**
Air flow sensor, gasoline injection	09.92-10.98		**0 280 203 026**
			0 986 280 042
Phase sensor	09.92-10.98		**0 232 103 009**
Speed sensor, ignition/injection	09.92-10.98		**0 261 210 047**
Knock sensor	09.92-10.98	L43	**0 261 231 095**
Wheel speed sensor, front	09.92-10.98	LAB	**0 265 006 118**
		RAB	**0 265 006 119**

A

Product			
Wheel speed sensor, rear			
Fg.no. →6302794	09.92-10.98		**0 265 003 075**
3.0 V6 24V Q.V. G.D. [164]	**3,0 l 170 kW AR 64308 6 Zyl.**		
Throttle valve sensor	09.92-10.98		**0 280 122 001**
Air flow sensor, gasoline injection	09.92-10.98		**0 280 203 026**
			0 986 280 042
Phase sensor	09.92-10.98		**0 232 103 009**
Speed sensor, ignition/injection	09.92-10.98		**0 261 210 047**
Knock sensor	09.92-10.98	L43	**0 261 231 095**
Wheel speed sensor, front	09.92-10.98	LAB	**0 265 006 118**
		RAB	**0 265 006 119**
Wheel speed sensor, rear			
Fg.no. →6302794	09.92-10.98		**0 265 003 075**

166

2.0 T.S. 16V [936]	**2,0 l 114 kW AR 34103 4 Zyl.**		
Throttle valve assembly	10.98-09.00		**3 437 010 457**
Air mass meter, gasoline injection	10.98-09.00		**0 280 218 019**
Phase sensor	10.98-09.00		**0 232 101 035**
Speed sensor, ignition/injection	10.98-09.00		**0 261 210 160**
Knock sensor	10.98-09.00		**0 261 231 131**
Vacuum pickup, ignition/injection	10.98-09.00		**0 928 400 327**
Pressure sensor, ESP, (electronic stability program)	10.98-09.00		**0 265 005 303**
Wheel speed sensor, front	10.98-09.00	LAB	**0 265 007 021**
		RAB	**0 265 007 020**
Wheel speed sensor, rear	10.98-09.00		**0 265 007 022**
2.0 T.S. 16V [936]	**2,0 l 114 kW AR 36301 4 Zyl.**		
Throttle valve assembly			
Mot.no. →3649574	09.00-04.04		**0 280 750 102**
Mot.no. 3649575→	05.04→		**1 287 213 612**
Air mass meter, gasoline injection	09.00→		**0 281 002 309**
Phase sensor	09.00→		**0 232 101 035**
Speed sensor, ignition/injection			
Mot.no. →3649574	09.00→		**0 261 210 160**
Mot.no. 3649575→	09.00→		**0 261 210 227**
Knock sensor	09.00→		**0 261 231 131**
Vacuum pickup, ignition/injection	09.00→		**0 928 400 327**
Yaw rate sensor, brake system			
Fg.no. →94869	09.00-08.04		**0 265 005 277**
Fg.no. 94870→	09.04→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	09.00→		**0 265 005 303**
Wheel speed sensor, front	09.00→	LAB	**0 265 007 021**
		RAB	**0 265 007 020**
Wheel speed sensor, rear	09.00→		**0 265 007 022**
2.0 Turbo V6 [936]	**2,0 l 151 kW AR 34102 6 Zyl.**		
Throttle valve assembly	10.98-12.04		**0 280 750 053**
Air mass meter, gasoline injection	10.98-05.03		**0 280 218 036**
	06.03-12.04		**0 280 218 054**
Phase sensor	10.98-12.04		**0 232 103 024**
Speed sensor, ignition/injection	10.98-12.04		**0 261 210 167**
Knock sensor	10.98-12.04	L37	**0 261 231 007**
		L43	**0 261 231 095**
Pressure sensor, intake manifold, gasoline	10.98-12.04	HL	**0 280 101 001**
Temperature sensor, coolant, injection system	10.98-12.04		**0 280 130 039**
Yaw rate sensor, brake system			
Fg.no. →94869	10.98-08.04		**0 265 005 277**
Fg.no. 94870→	09.04-12.04		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	10.98-12.04		**0 265 005 303**
Wheel speed sensor, front	10.98-12.04	LAB	**0 265 007 021**
		RAB	**0 265 007 020**
Wheel speed sensor, rear	10.98-12.04		**0 265 007 022**

Product			
2.4 JTD [936]	**2,4 l 100 kW AR 34202 5 Zyl.**		
Air mass meter, diesel	10.98-09.00		**0 280 218 019**
Speed sensor, diesel	10.98-09.00		**0 281 002 474**
Phase sensor	10.98-09.00		**0 281 002 213**
High-pressure sensor (CR system)	10.98-09.00		**0 281 002 210**
Boost pressure sensor, Diesel	10.98-09.00		**0 281 002 215**
Temperature sensor, fuel	10.98-09.00	2PO	**0 281 002 209**
Pedal position sensor, diesel	10.98-09.00		**0 281 002 202**
Pressure sensor, ESP, (electronic stability program)	10.98-09.00		**0 265 005 303**
Wheel speed sensor, front	10.98-09.00	LAB	**0 265 007 021**
		RAB	**0 265 007 020**
Wheel speed sensor, rear	10.98-09.00		**0 265 007 022**
2.4 JTD [936]	**2,4 l 100-110 kW 839A6000 / 841C000 5 Zyl.**		
Air mass meter, diesel	09.00→		**0 281 002 309**
Speed sensor, diesel			
Mot.no. →4036104	09.00→		**0 281 002 474**
Mot.no. 4036105→	09.00→		**0 281 002 603**
Phase sensor	09.00→		**0 281 002 213**
High-pressure sensor (CR system)	09.00→		**0 281 002 210**
Boost pressure sensor, Diesel	09.00→		**0 281 002 844**
Temperature sensor, fuel	09.00→	2PO	**0 281 002 209**
Pedal position sensor, diesel	09.00→		**0 281 002 202**
Yaw rate sensor, brake system			
Fg.no. →94869	09.00-08.04		**0 265 005 277**
Fg.no. 94870→	09.04→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	09.00→		**0 265 005 303**
Wheel speed sensor, front	09.00→	LAB	**0 265 007 021**
		RAB	**0 265 007 020**
Wheel speed sensor, rear	09.00→		**0 265 007 022**
2.4 JTD 20V [936]	**2,4 l 120/128 kW 841M000; 841N000 5 Zyl.**		
Throttle valve assembly	10.04→		**0 280 750 102**
Air mass meter, diesel	10.04→		**0 281 002 598**
Boost pressure sensor, Diesel	10.04→		**0 281 002 845**
Yaw rate sensor, brake system			
Fg.no. 94870→	10.04→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	10.04→		**0 265 005 303**
Wheel speed sensor, front	10.04→	LAB	**0 265 007 021**
		RAB	**0 265 007 020**
Wheel speed sensor, rear	10.04→		**0 265 007 022**
2.4 JTD 20V [936]	**2,4 l 129 kW 841G000 / 841H000 5 Zyl.**		
Throttle valve assembly	06.03→		**0 280 750 102**
Air mass meter, diesel	06.03→		**0 281 002 598**
Boost pressure sensor, Diesel	06.03→		**0 281 002 845**
Yaw rate sensor, brake system			
Fg.no. →94869	06.03-08.04		**0 265 005 277**
Fg.no. 94870→	09.04→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	06.03→		**0 265 005 303**
Wheel speed sensor, front	06.03→	LAB	**0 265 007 021**
		RAB	**0 265 007 020**
Wheel speed sensor, rear	06.03→		**0 265 007 022**
2.4 JTDM 20V [936]	**2,4 l 132-136 kW 936B000 5 Zyl.**		
Throttle valve assembly	10.05→		**0 280 750 102**
Air mass meter, diesel	10.05→		**0 281 002 763**
Boost pressure sensor, Diesel	10.05→		**0 281 002 845**
Yaw rate sensor, brake system			
Fg.no. 94870→	10.05→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	10.05→		**0 265 005 303**
Wheel speed sensor, front	10.05→	LAB	**0 265 007 021**
		RAB	**0 265 007 020**
Wheel speed sensor, rear	10.05→		**0 265 007 022**
2.5 V6 24V [936]	**2,5 l 140 kW AR 34201 6 Zyl.**		
Throttle valve assembly	10.98-09.00		**0 280 750 014**
Air mass meter, gasoline injection	10.98-09.00		**0 280 217 531**

A

Product			
◀ 166			
Phase sensor	10.98-09.00		**0 232 103 009**
Speed sensor, ignition/injection	10.98-09.00		**0 261 210 163**
Knock sensor	10.98-09.00	L37	**0 261 231 007**
		L43	**0 261 231 095**
Pressure sensor, ESP, (electronic stability program)	10.98-09.00		**0 265 005 303**
Wheel speed sensor, front	10.98-09.00	LAB	**0 265 007 021**
		RAB	**0 265 007 020**
Wheel speed sensor, rear	10.98-09.00		**0 265 007 022**
2.5 V6 24V [936]		**2,5 l 140 kW AR 36201 6 Zyl.**	
Throttle valve assembly	09.00→		**0 280 750 014**
Air mass meter, gasoline injection	09.00→		**0 280 218 054**
Phase sensor	09.00→		**0 232 103 024**
Speed sensor, ignition/injection	09.00→		**0 261 210 203**
Knock sensor	09.00→	L37	**0 261 231 007**
		L43	**0 261 231 095**
Yaw rate sensor, brake system			
Fg.no. →94869	09.00-08.04		**0 265 005 277**
Fg.no. 94870→	09.04→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	09.00→		**0 265 005 303**
Wheel speed sensor, front	09.00→	LAB	**0 265 007 021**
		RAB	**0 265 007 020**
Wheel speed sensor, rear	09.00→		**0 265 007 022**
3.0 V6 24V [936]		**3,0 l 166 kW AR 34301; AR 34302 6 Zyl.**	
Throttle valve assembly	10.98-09.00		**0 280 750 014**
Air mass meter, gasoline injection	10.98-09.00		**0 280 217 531**
Phase sensor	10.98-09.00		**0 232 103 009**
Speed sensor, ignition/injection	10.98-09.00		**0 261 210 163**
Knock sensor	10.98-09.00	L37	**0 261 231 007**
		L43	**0 261 231 095**
Pressure sensor, ESP, (electronic stability program)	10.98-09.00		**0 265 005 303**
Wheel speed sensor, front	10.98-09.00	LAB	**0 265 007 021**
		RAB	**0 265 007 020**
Wheel speed sensor, rear	10.98-09.00		**0 265 007 022**
3.0 V6 24V [936]		**3,0 l 166 kW AR 36101 6 Zyl.**	
Throttle valve assembly	09.00→		**0 280 750 014**
Air mass meter, gasoline injection	09.00→		**0 280 218 054**
Phase sensor	09.00→		**0 232 103 024**
Speed sensor, ignition/injection	09.00→		**0 261 210 203**
Knock sensor	09.00→	L37	**0 261 231 007**
		L43	**0 261 231 095**
Yaw rate sensor, brake system			
Fg.no. →94869	09.00-08.04		**0 265 005 277**
Fg.no. 94870→	09.04→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	09.00→		**0 265 005 303**
Wheel speed sensor, front	09.00→	LAB	**0 265 007 021**
		RAB	**0 265 007 020**
Wheel speed sensor, rear	09.00→		**0 265 007 022**
3.2 V6 24V [936]		**3,2 l 166 kW 936A000 6 Zyl.**	
Throttle valve assembly	06.03→		**0 280 750 014**
Air mass meter, gasoline injection	06.03→		**0 280 218 054**
Phase sensor	06.03→		**0 232 103 024**
Speed sensor, ignition/injection	06.03→		**0 261 210 203**
Yaw rate sensor, brake system			
Fg.no. →94869	06.03-08.04		**0 265 005 277**
Fg.no. 94870→	09.04→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	06.03→		**0 265 005 303**
Wheel speed sensor, front	06.03→	LAB	**0 265 007 021**
		RAB	**0 265 007 020**
Wheel speed sensor, rear	06.03→		**0 265 007 022**

A

Product			

ALPINA (B. BOVENSIEPEN KG)

B 7

4.4 [E 65/66]		**4,4 l 368 kW N62 B44A19 8 Zyl.**	
Knock sensor	03.04→		**0 261 231 200**
Duo sensor, acceleration and yaw rate, brake system	03.04→		**0 265 005 285**
Pressure sensor, ESP, (electronic stability program)	03.04→		**0 265 005 303**
Wheel speed sensor, front	03.04-09.05		**0 265 007 592**
Wheel speed sensor, rear	03.04-09.05		**0 265 007 593**
	10.05→		**0 265 007 845**

Roadster

V8 [Z8]		**4,8 l 280 kW F 5/1 8 Zyl.**	
Air mass meter, gasoline injection	06.02-10.03		**0 280 217 814**
Knock sensor	06.02-10.03		**0 261 231 200**
Yaw rate sensor, brake system	06.02-10.03		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	06.02-10.03		**0 265 005 303**

ASTON MARTIN

Vantage

5.3 Zagato		**5,3 l 318 kW V8 8 Zyl.**	
Wheel speed sensor, front	01.86-12.89		**0 265 006 216**
5.3 32V Kompressor		**5,3 l 410 kW V8 8 Zyl.**	
Wheel speed sensor, front	10.92-12.99		**0 265 006 216**

Virage Coupé

5.3 V8/32V		**5,3 l 246 kW 8 Zyl.**	
Wheel speed sensor, front	10.88-12.95	LAB	**0 265 001 323**
Wheel speed sensor, rear	10.88-12.95		**0 265 001 324**

AUDI

A2

1.2 TDI 3L [8Z0]		**1,2 l 45 kW ANY 3 Zyl.**	
Boost pressure sensor, Diesel			
Fg.no. →8Z..2..027 000	09.99-01.02		**0 281 002 177**
Fg.no. 8Z..2..027 001→	02.02-08.05		**0 281 002 399**
1.4 [8Z0]		**1,4 l 55 kW AUA; BBY 4 Zyl.**	
Knock sensor	09.99-08.05		**0 261 231 146**
1.4 TDI [8Z0]		**1,4 l 55 kW AMF 3 Zyl.**	
Boost pressure sensor, Diesel			
Fg.no. →8Z..2..027 000	09.99-01.02		**0 281 002 177**
Fg.no. 8Z..2..027 001→	02.02-08.03		**0 281 002 399**
1.4 TDI [8Z0]		**1,4 l 55 kW BHC 3 Zyl.**	
Air mass meter, diesel	05.03-08.05		**0 281 002 610**
Boost pressure sensor, Diesel	05.03-08.05		**0 281 002 399**
1.4 TDI [8Z0]		**1,4 l 66 kW ATL 3 Zyl.**	
Air mass meter, diesel	11.03-08.05		**0 281 002 610**
Boost pressure sensor, Diesel	11.03-08.05		**0 281 002 401**
1.6 FSI [8Z0]		**1,6 l 81 kW BAD 4 Zyl.**	
Throttle valve assembly	01.02-08.05		**0 280 750 059**
Knock sensor	01.02-08.05		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	01.02-08.05		**0 261 230 079**

Product			

A3

1.4 TFSI [8P1]			**1,4 l 92 kW CAXC 4 Zyl.**
Knock sensor	09.07→		**0 261 231 146**
Boost pressure sensor, gasoline	09.07→		**0 281 002 399**
1.6			**1,6 l 74 kW AKL 4 Zyl.**
Phase sensor	05.99-09.06	NOC	**0 232 101 031**
Speed sensor, ignition/injection	05.99-09.06	FKW	**0 261 210 147**
1.6			**1,6 l 74 kW BAH 4 Zyl.**
Speed sensor, ignition/injection	09.00-09.06	FKW	**0 261 210 147**
Knock sensor	09.00-09.06	OHL	**0 261 231 146**
1.6 [8L1]			**1,6 l 74 kW AEH 4 Zyl.**
Phase sensor	09.96-06.01	NOC	**0 232 101 031**
Speed sensor, ignition/injection	09.96-06.01	FKW	**0 261 210 147**
Temperature sensor, intake air, injection system	09.96-06.01		**0 280 130 085**
Accelerator pedal module			
Fg.no. 8L..X..001 072→	08.98-06.01	GS,LLE	**0 280 752 214**
Fg.no. 8L..Y..000 001→	05.99-06.01	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8L..X..090 000	09.96-04.99	GS,RLE	**0 280 752 016**
Fg.no. 8L..V..155 001→8L..X..001 071	07.97-08.98	GS,LLE	**0 281 002 269**
1.6 [8L1]			**1,6 l 74 kW AKL 4 Zyl.**
Phase sensor	08.97-06.01	NOC	**0 232 101 031**
Speed sensor, ignition/injection	08.97-06.01	FKW	**0 261 210 147**
Temperature sensor, intake air, injection system	08.97-06.01		**0 280 130 085**
Accelerator pedal module			
Fg.no. 8L..X..001 072→	08.98-06.01	GS,LLE	**0 280 752 214**
Fg.no. 8L..Y..000 001→	05.99-06.01	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8L..X..001 071	08.97-08.98	GS,LLE	**0 281 002 269**
Fg.no. →8L..X..090 000	08.97-04.99	GS,RLE	**0 280 752 016**
1.6 [8L1]			**1,6 l 74 kW APF 4 Zyl.**
Phase sensor	08.98-08.00	NOC	**0 232 101 031**
Speed sensor, ignition/injection	08.98-08.00	FKW	**0 261 210 199**
Accelerator pedal module	08.98-08.00	GS,LLE	**0 280 752 214**
Fg.no. 8L..Y..000 001→	05.99-08.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8L..X..090 000	08.98-04.99	GS,RLE	**0 280 752 016**
1.6 [8L1]			**1,6 l 75 kW AVU 4 Zyl.**
Phase sensor	05.00-04.02	NOC	**0 232 101 038**
Speed sensor, ignition/injection	05.00-04.02	FKW	**0 261 210 199**
Accelerator pedal module	05.00-04.02	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.6 [8L1]			**1,6 l 75 kW BFQ 4 Zyl.**
Speed sensor, ignition/injection	05.02-06.03		**0 261 210 199**
Accelerator pedal module	05.02-06.03	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.6 [8P1]			**1,6 l 75 kW BGU; BSE; BSF 4 Zyl.**
Speed sensor, ignition/injection	05.03→		**0 261 210 199**
Knock sensor	05.03→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.03→		**0 261 230 031**
1.6 FSI [8P1]			**1,6 l 85 kW BAG 4 Zyl.**
Speed sensor, ignition/injection			
Fg.no. 8P..4..103 001→	11.03-05.04		**0 261 210 250**
Knock sensor	08.03-05.04		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	08.03-05.04		**0 261 230 095**
1.6 FSI [8P1]			**1,6 l 85 kW BLF; BLP 4 Zyl.**
Knock sensor	06.04-09.07		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	06.04-09.07		**0 261 230 095**
1.8			**1,8 l 92 kW AGN 4 Zyl.**
Air mass meter, gasoline injection	05.99-09.06		**0 280 218 002**
			0 986 280 205
Phase sensor	05.99-09.06	NOC	**0 232 101 024**
Speed sensor, ignition/injection	05.99-09.06	FKW	**0 261 210 147**
Temperature sensor, intake air, injection system	05.99-09.06		**0 280 130 085**
1.8 [8L1]			**1,8 l 92 kW AGN 4 Zyl.**
Air mass meter, gasoline injection			
Fg.no. 8L..W..000 001→	08.97-06.01		**0 280 218 002**
			0 986 280 205
Phase sensor	09.96-06.01	NOC	**0 232 101 024**
Speed sensor, ignition/injection	09.96-06.01	FKW	**0 261 210 147**
Temperature sensor, intake air, injection system	09.96-06.01		**0 280 130 085**
Accelerator pedal module			
Fg.no. 8L..X..001 072→	08.98-06.01	GS,LLE	**0 280 752 214**
Fg.no. 8L..Y..000 001→	05.99-06.01	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8L..X..090 000	09.96-04.99	GS,RLE	**0 280 752 016**
Fg.no. 8L..V..155 001→8L..X..001 071	07.97-08.98	GS,LLE	**0 281 002 269**
1.8 [8L1]			**1,8 l 92 kW APG 4 Zyl.**
Throttle valve assembly	08.98-04.03		**0 280 750 026**
Air mass meter, gasoline injection	08.98-04.03		**0 280 218 060**
			0 986 280 216
Phase sensor	08.98-04.03	NOC	**0 232 101 024**
Speed sensor, ignition/injection	08.98-04.03	FKW	**0 261 210 147**
Accelerator pedal module	08.98-04.03	GS,LLE	**0 280 752 214**
Fg.no. 8L..Y..000 001→	05.99-04.03	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8L..X..090 000	08.98-04.99	GS,RLE	**0 280 752 016**
1.8 FSI [8P1]			**1,8 l 118 kW BYT 4 Zyl.**
Boost pressure sensor, gasoline	11.06-06.07		**0 261 230 073**
1.8 quattro [8L1]			**1,8 l 92 kW AGN 4 Zyl.**
Air mass meter, gasoline injection	08.98-06.99		**0 280 218 002**
			0 986 280 205
Phase sensor	08.98-06.99	NOC	**0 232 101 024**
Speed sensor, ignition/injection	08.98-06.99	FKW	**0 261 210 147**
Temperature sensor, intake air, injection system	08.98-06.99		**0 280 130 085**
Accelerator pedal module	08.98-06.99	GS,LLE	**0 280 752 214**
Fg.no. 8L..Y..000 001→	05.99-06.99	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8L..X..090 000	08.98-04.99	GS,RLE	**0 280 752 016**
1.8 T			**1,8 l 110 kW AGU 4 Zyl.**
Air mass meter, gasoline injection	05.99-09.06		**0 280 217 117**
			0 986 280 201
Phase sensor	05.99-09.06	NOC	**0 232 101 024**
Speed sensor, ignition/injection	05.99-09.06	FKW	**0 261 210 147**
Temperature sensor, intake air, injection system	05.99-09.06		**0 280 130 085**
1.8 T			**1,8 l 132 kW APP 4 Zyl.**
Throttle valve assembly	03.00-09.06		**0 280 750 036**
Air mass meter, gasoline injection	03.00-09.06		**0 280 218 032**
			0 986 280 210
Speed sensor, ignition/injection	03.00-09.06	FKW	**0 261 210 147**

A

Product			
◀ A3			
1.8 T			**1,8 l 132 kW AUQ 4 Zyl.**
Throttle valve assembly	10.00-09.06		**0 280 750 036**
Phase sensor	10.00-09.06	NOC	**0 232 101 024**
Knock sensor	10.00-09.06	OHL	**0 261 231 146**
1.8 T [8L1]			**1,8 l 110 kW AGU 4 Zyl.**
Air mass meter, gasoline injection			
Fg.no. →8L..V..200 000	12.96-07.97		**0 280 217 112**
Fg.no. 8L..W..000 001→	08.97-06.03		**0 280 217 117**
			0 986 280 201
Phase sensor	12.96-06.03	NOC	**0 232 101 024**
Speed sensor, ignition/injection	12.96-06.03	FKW	**0 261 210 199**
Boost pressure sensor, gasoline	12.96-06.03		**0 281 002 177**
Temperature sensor, intake air, injection system	12.96-06.03		**0 280 130 085**
Accelerator pedal module			
Fg.no. 8L..X..001 072→	08.98-06.03	GS,LLE	**0 280 752 214**
Fg.no. 8L..Y..000 001→	05.99-06.03	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8L..X..090 000	12.96-04.99	GS,RLE	**0 280 752 016**
Fg.no. 8L..V..155 001→8L..X..001 071	07.97-08.98	GS,LLE	**0 281 002 269**
1.8 T [8L1]			**1,8 l 110 kW AQA 4 Zyl.**
Throttle valve assembly	08.98-06.99		**0 280 750 036**
Air mass meter, gasoline injection	08.98-06.99		**0 280 218 023**
			0 986 280 209
Temperature sensor, intake air, injection system	08.98-06.99		**0 280 130 085**
Accelerator pedal module	08.98-06.99	GS,LLE	**0 280 752 214**
Fg.no. 8L..Y..000 001→	05.99-06.99	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8L..X..090 000	08.98-04.99	GS,RLE	**0 280 752 016**
1.8 T [8L1]			**1,8 l 110 kW ARZ 4 Zyl.**
Throttle valve assembly	07.99-04.00		**0 280 750 036**
Air mass meter, gasoline injection			
Fg.no. →8L..Y..050 000	07.99-10.99		**0 280 218 023**
			0 986 280 209
Fg.no. 8L..Y..050 001→	10.99-04.00		**0 280 218 032**
			0 986 280 210
Phase sensor	07.99-04.00	NOC	**0 232 101 024**
Speed sensor, ignition/injection	07.99-04.00	FKW	**0 261 210 147**
Temperature sensor, intake air, injection system	07.99-04.00		**0 280 130 085**
Accelerator pedal module	07.99-04.00	GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.8 T [8L1]			**1,8 l 110 kW AUM 4 Zyl.**
Throttle valve assembly	05.00-06.03		**0 280 750 036**
Air mass meter, gasoline injection	05.00-08.00		**0 280 218 032**
			0 986 280 210
	09.00-06.03		**0 280 218 063**
			0 986 280 217
Phase sensor	05.00-06.03	NOC	**0 232 101 024**
Speed sensor, ignition/injection	05.00-06.03	FKW	**0 261 210 147**
Knock sensor	05.00-06.03		**0 261 231 146**
Boost pressure sensor, gasoline	05.00-06.03		**0 281 002 177**
Temperature sensor, intake air, injection system	05.00-06.03		**0 280 130 085**
Accelerator pedal module	05.00-06.03	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.8 T [8L1]			**1,8 l 132 kW AJQ 4 Zyl.**
Throttle valve assembly	08.98-08.00		**0 280 750 036**
Air mass meter, gasoline injection			
Fg.no. →8L..Y..050 000	08.98-10.99		**0 280 218 023**
			0 986 280 209
Air mass meter, gasoline injection			
Fg.no. 8L..Y..050 001→	10.99-08.00		**0 280 218 032**
			0 986 280 210
Speed sensor, ignition/injection	08.98-08.00	FKW	**0 261 210 147**
Temperature sensor, intake air, injection system	08.98-08.00		**0 280 130 085**
Accelerator pedal module	08.98-08.00	GS,LLE	**0 280 752 214**
Fg.no. 8L..Y..000 001→	05.99-08.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8L..X..090 000	08.98-04.99	GS,RLE	**0 280 752 016**
1.8 T [8L1]			**1,8 l 132 kW APP 4 Zyl.**
Throttle valve assembly	08.98-05.00		**0 280 750 036**
Air mass meter, gasoline injection			
Fg.no. →8L..Y..050 000	08.98-10.99		**0 280 218 023**
			0 986 280 209
Fg.no. 8L..Y..050 001→	10.99-05.00		**0 280 218 032**
			0 986 280 210
Speed sensor, ignition/injection	08.98-05.00	FKW	**0 261 210 147**
Temperature sensor, intake air, injection system	08.98-05.00		**0 280 130 085**
Accelerator pedal module	08.98-05.00	GS,LLE	**0 280 752 214**
Fg.no. 8L..Y..000 001→	05.99-05.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.8 T [8L1]			**1,8 l 132 kW ARY 4 Zyl.**
Throttle valve assembly	09.00-06.01		**0 280 750 036**
Air mass meter, gasoline injection	09.00-06.01		**0 280 218 063**
			0 986 280 217
Phase sensor	09.00-06.01	NOC	**0 232 101 024**
Speed sensor, ignition/injection	09.00-06.01	FKW	**0 261 210 147**
Knock sensor	09.00-06.01		**0 261 231 146**
Boost pressure sensor, gasoline	09.00-06.01		**0 281 002 177**
Temperature sensor, intake air, injection system	09.00-06.01		**0 280 130 085**
Accelerator pedal module	09.00-06.01	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.8 T [8L1]			**1,8 l 132 kW AUQ 4 Zyl.**
Throttle valve assembly	05.00-06.03		**0 280 750 036**
Air mass meter, gasoline injection	05.00-08.00		**0 280 218 032**
			0 986 280 210
	09.00-06.03		**0 280 218 063**
			0 986 280 217
Phase sensor	05.00-06.03	NOC	**0 232 101 024**
Speed sensor, ignition/injection	05.00-06.03	FKW	**0 261 210 199**
Knock sensor	05.00-06.03		**0 261 231 146**
Boost pressure sensor, gasoline	05.00-06.03		**0 281 002 177**
Temperature sensor, intake air, injection system	05.00-06.03		**0 280 130 085**
Accelerator pedal module	05.00-06.03	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.8 T quattro [8L1]			**1,8 l 110 kW AGU 4 Zyl.**
Air mass meter, gasoline injection	08.97-08.00		**0 280 217 117**
			0 986 280 201
Phase sensor	08.97-08.00	NOC	**0 232 101 024**
Speed sensor, ignition/injection	08.97-08.00	NOC	**0 261 210 199**
Boost pressure sensor, gasoline	08.97-08.00		**0 281 002 177**
Temperature sensor, intake air, injection system	08.97-08.00		**0 280 130 085**
Accelerator pedal module			
Fg.no. 8L..X..001 072→	08.98-08.00	GS,LLE	**0 280 752 214**
Fg.no. 8L..Y..000 001→	05.99-08.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**

Product			
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8L..X..001 071	08.97-08.98	GS,LLE	**0 281 002 269**
Fg.no. →8L..X..090 000	08.97-04.99	GS,RLE	**0 280 752 016**
1.8 T quattro [8L1]			**1,8 l 110 kW AQA 4 Zyl.**
Throttle valve assembly	08.98-04.01		**0 280 750 036**
Air mass meter, gasoline injection			
Fg.no. →8L..Y..050 000	08.98-10.99		**0 280 218 023**
			0 986 280 209
Fg.no. 8L..Y..050 001→	10.99-04.01		**0 280 218 032**
			0 986 280 210
Speed sensor, ignition/injection	08.98-04.01	FKW	**0 261 210 147**
Temperature sensor, intake air, injection system	08.98-04.01		**0 280 130 085**
Accelerator pedal module	08.98-04.01	GS,LLE	**0 280 752 214**
Fg.no. 8L..Y..000 001→	05.99-04.01	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8L..X..090 000	08.98-04.99	GS,RLE	**0 280 752 016**
1.8 T quattro [8L1]			**1,8 l 110 kW ARX 4 Zyl.**
Throttle valve assembly	10.99-06.03		**0 280 750 036**
Air mass meter, gasoline injection	10.99-06.03		**0 280 218 063**
			0 986 280 217
Speed sensor, ignition/injection	10.99-06.03	FKW	**0 261 210 147**
Knock sensor	10.99-06.03		**0 261 231 146**
Boost pressure sensor, gasoline	10.99-06.03		**0 281 002 177**
Temperature sensor, intake air, injection system	10.99-06.03		**0 280 130 085**
Accelerator pedal module	10.99-06.03	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.8 T quattro [8L1]			**1,8 l 132 kW AJQ 4 Zyl.**
Throttle valve assembly	08.98-08.00		**0 280 750 036**
Air mass meter, gasoline injection			
Fg.no. →8L..Y..050 000	08.98-10.99		**0 280 218 023**
			0 986 280 209
Fg.no. 8L..Y..050 001→	10.99-08.00		**0 280 218 032**
			0 986 280 210
Speed sensor, ignition/injection	08.98-08.00	FKW	**0 261 210 147**
Temperature sensor, intake air, injection system	08.98-08.00		**0 280 130 085**
Accelerator pedal module	08.98-08.00	GS,LLE	**0 280 752 214**
Fg.no. 8L..Y..000 001→	05.99-08.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8L..X..090 000	08.98-04.99	GS,RLE	**0 280 752 016**
1.8 T quattro [8L1]			**1,8 l 132 kW ARY 4 Zyl.**
Throttle valve assembly	09.00-06.03		**0 280 750 036**
Air mass meter, gasoline injection	09.00-06.03		**0 280 218 063**
			0 986 280 217
Phase sensor	09.00-06.03	NOC	**0 232 101 024**
Speed sensor, ignition/injection	09.00-06.03	FKW	**0 261 210 147**
Knock sensor	09.00-06.03		**0 261 231 146**
Boost pressure sensor, gasoline	09.00-06.03		**0 281 002 177**
Temperature sensor, intake air, injection system	09.00-06.03		**0 280 130 085**
Accelerator pedal module	09.00-06.03	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.8 TFSI [8P1]			**1,8 l 118 kW BZB 4 Zyl.**
Boost pressure sensor, gasoline	06.07-05.08		**0 261 230 073**

Product			
1.9 TDI [8L1]			**1,9 l 66 kW AGR 4 Zyl.**
Air mass meter, diesel			
Fg.no. 8L..X..000 001→	08.98-08.00		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel	09.96-08.00		**0 281 002 177**
Accelerator pedal module			
Fg.no. 8L..Y..000 001→	05.99-08.00	AG,RLE	**0 281 002 347**
	04.99-08.00	GS,RLE	**0 281 002 345**
Pedal position sensor, diesel			
Fg.no. →8L..V..150 000	09.96-07.97	AG,LLE	**0 205 001 045**
Fg.no. 8L..V..155 001→8L..X..001 071	07.97-08.98	GS,LLE	**0 281 002 269**
1.9 TDI [8L1]			**1,9 l 66 kW ALH 4 Zyl.**
Air mass meter, diesel	08.97-06.01		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel	08.97-06.01		**0 281 002 177**
Accelerator pedal module			
Fg.no. 8L..Y..000 001→	04.99-08.00	GS,RLE	**0 281 002 345**
Fg.no. 8L..Y..000 001→8L..1..080 600	05.99-02.01	AG,RLE	**0 281 002 347**
Pedal position sensor, diesel			
Fg.no. →8L..X..001 071	08.97-08.98	GS,LLE	**0 281 002 269**
1.9 TDI [8L1]			**1,9 l 74 kW ATD 4 Zyl.**
Air mass meter, diesel			
Fg.no. →8L..2..040 000	09.00-10.01		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 8L..2..040 001→	10.01-06.03		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	09.00-06.03		**0 281 002 177**
Accelerator pedal module			
Fg.no. →8L..1..080 600	09.00-02.01	AG,RLE	**0 281 002 347**
1.9 TDI [8L1]			**1,9 l 74 kW AXR 4 Zyl.**
Air mass meter, diesel	11.01-06.03		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	11.01-06.03		**0 281 002 399**
1.9 TDI [8L1]			**1,9 l 81 kW AHF 4 Zyl.**
Air mass meter, diesel			
Fg.no. 8L..X..000 001→	08.98-08.00		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel	01.97-08.00		**0 281 002 177**
Accelerator pedal module			
Fg.no. 8L..Y..000 001→	05.99-08.00	AG,RLE	**0 281 002 347**
	04.99-08.00	GS,RLE	**0 281 002 345**
Pedal position sensor, diesel			
Fg.no. →8L..V..150 000	01.97-07.97	AG,LLE	**0 205 001 045**
Fg.no. 8L..V..155 001→8L..X..001 071	07.97-08.98	GS,LLE	**0 281 002 269**
1.9 TDI [8L1]			**1,9 l 81 kW ASV 4 Zyl.**
Air mass meter, diesel	09.99-06.01		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel	09.99-06.01		**0 281 002 177**
Accelerator pedal module	09.99-08.00	GS,RLE	**0 281 002 345**
Fg.no. →8L..1..080 600	09.99-02.01	AG,RLE	**0 281 002 347**
1.9 TDI [8L1]			**1,9 l 96 kW ASZ 4 Zyl.**
Air mass meter, diesel			
Fg.no. →8L..2..105 000	05.00-04.02		**0 280 217 529**
			0 986 280 204
Fg.no. 8L..2..105 001→	04.02-06.03		**0 281 002 461**
			0 986 284 007

A

Product			
◀ A3			
Boost pressure sensor, Diesel	05.00-06.03		0 281 002 401
Accelerator pedal module	05.00-08.00	GS,RLE	0 281 002 345
Fg.no. →8L..1..080 600	05.00-02.01	AG,RLE	0 281 002 347
1.9 TDI [8P1]			**1,9 l 77 kW BKC 4 Zyl.**
Air mass meter, diesel	06.03-05.06		0 281 002 531
			0 986 284 009
Speed sensor, diesel	06.03-05.06	FKW,TW	0 261 210 233
1.9 TDI [8P1]			**1,9 l 77 kW BLS; BXE 4 Zyl.**
Air mass meter, diesel	11.05→		0 281 002 531
			0 986 284 009
Speed sensor, diesel	11.05→	FKW,TW	0 261 210 233
Boost pressure sensor, Diesel	11.05→		0 281 002 399
1.9 TDI quattro [8L1]			**1,9 l 96 kW ASZ 4 Zyl.**
Air mass meter, diesel			
Fg.no. →8L..2..105 000	05.00-04.02		0 280 217 529
			0 986 280 204
Fg.no. 8L..2..105 001→	04.02-06.03		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	05.00-06.03		0 281 002 401
Accelerator pedal module	05.00-08.00	GS,RLE	0 281 002 345
Fg.no. →8L..1..080 600	05.00-02.01	AG,RLE	0 281 002 347
2.0 FSI [8P1]			**2,0 l 110 kW AXW 4 Zyl.**
Knock sensor	05.03-05.04	OHL	0 261 231 146
Pressure sensor, intake manifold, gasoline	05.03-05.04		0 261 230 031
Boost pressure sensor, gasoline	05.03-05.04		0 261 230 073
2.0 FSI [8P1]			**2,0 l 110 kW BHD 4 Zyl.**
Boost pressure sensor, gasoline	10.03-01.04		0 261 230 073
2.0 FSI [8P1]			**2,0 l 110 kW BLR; BLX; BLY; BMB 4 Zyl.**
Knock sensor	01.04-10.05	OHL	0 261 231 146
Pressure sensor, intake manifold, gasoline	01.04-10.05		0 261 230 031
Boost pressure sensor, gasoline	01.04-10.05		0 261 230 073
2.0 FSI [8P1]			**2,0 l 110 kW BVY; BVZ 4 Zyl.**
Knock sensor	11.05→	OHL	0 261 231 146
Pressure sensor, intake manifold, gasoline	11.05→		0 261 230 031
2.0 TDI [8P1]			**2,0 l 100/103/120/125 kW AZV; BKD; BMM; BMN; BUY 4 Zyl.**
Air mass meter, diesel	05.03→		0 281 002 461
			0 986 284 007
Speed sensor, diesel	05.03→	FKW,TW	0 261 210 233
Boost pressure sensor, Diesel	05.03→		0 281 002 401
2.0 TDI quattro [8P1]			**2,0 l 100/103/125 kW AZV; BKD; BMM; BMN 4 Zyl.**
Air mass meter, diesel	05.03→		0 281 002 461
			0 986 284 007
Speed sensor, diesel	05.03→	FKW,TW	0 261 210 233
Boost pressure sensor, Diesel	05.03→		0 281 002 401
2.0 TFSI [8P1]			**2,0 l 147 kW AXX; BWA 4 Zyl.**
Speed sensor, ignition/injection	09.04→		0 261 210 199
Boost pressure sensor, gasoline	09.04→		0 261 230 073
2.0 TFSI [8P1]			**2,0 l 147 kW CAWB 4 Zyl.**
Boost pressure sensor, gasoline	10.07→		0 261 230 073
2.0 TFSI quattro [8P1]			**2,0 l 147 kW AXX; BWA 4 Zyl.**
Speed sensor, ignition/injection	09.04→		0 261 210 199
Boost pressure sensor, gasoline	09.04→		0 261 230 073
3.2 quattro [8P1]			**3,2 l 184 kW BDB 6 Zyl.**
Air mass meter, gasoline injection	07.03-08.04		0 280 218 073
			0 986 280 222
Phase sensor	07.03-08.04		0 232 103 019
Knock sensor	07.03-08.04	OHL	0 261 231 146
3.2 quattro [8P1]			**3,2 l 184 kW BMJ 6 Zyl.**
Air mass meter, gasoline injection	09.04-10.05		0 280 218 073
			0 986 280 222
Phase sensor			
Fg.no. →8P..6A066 000,→8P..6B005 500	09.04-08.05		0 232 103 019
Knock sensor	09.04-10.05	OHL	0 261 231 146

Product			
3.2 quattro [8P1]			**3,2 l 184 kW BUB 6 Zyl.**
Air mass meter, gasoline injection	11.05→		0 280 218 073
			0 986 280 222
Knock sensor	11.05→	OHL	0 261 231 146

A3 Sportback

1.4 TFSI [8PA]			**1,4 l 92 kW CAXC 4 Zyl.**
Knock sensor	06.07→		0 261 231 146
Boost pressure sensor, gasoline	06.07→		0 281 002 399
1.6 [8PA]			**1,6 l 75 kW BGU 4 Zyl.**
Speed sensor, ignition/injection	09.04-05.05		0 261 210 199
Pressure sensor, intake manifold, gasoline	09.04-05.05		0 261 230 031
1.6 [8PA]			**1,6 l 75 kW BSE; BSF 4 Zyl.**
Speed sensor, ignition/injection	06.05→		0 261 210 199
Knock sensor	06.05→		0 261 231 146
Pressure sensor, intake manifold, gasoline	06.05→		0 261 230 031
1.6 FSI [8PA]			**1,6 l 85 kW BLF; BLP 4 Zyl.**
Knock sensor	09.04-05.07		0 261 231 146
Pressure sensor, intake manifold, gasoline	09.04-05.07		0 261 230 095
1.8 FSI [8PA]			**1,8 l 118 kW BYT 4 Zyl.**
Boost pressure sensor, gasoline	11.06-05.07		0 261 230 073
1.8 TFSI [8PA]			**1,8 l 118 kW BZB 4 Zyl.**
Boost pressure sensor, gasoline	06.07-05.08		0 261 230 073
1.9 TDI [8PA]			**1,9 l 77 kW BKC 4 Zyl.**
Air mass meter, diesel	09.04-05.06		0 281 002 531
			0 986 284 009
1.9 TDI [8PA]			**1,9 l 77 kW BLS; BXE 4 Zyl.**
Air mass meter, diesel	11.05→		0 281 002 531
			0 986 284 009
Speed sensor, diesel	11.05→	FKW,TW	0 261 210 233
Boost pressure sensor, Diesel	11.05→		0 281 002 399
2.0 FSI [8PA]			**2,0 l 110 kW BLR; BLX; BLY; BMB 4 Zyl.**
Knock sensor	09.04-10.05	OHL	0 261 231 146
Pressure sensor, intake manifold, gasoline	09.04-10.05		0 261 230 031
Boost pressure sensor, gasoline	09.04-10.05		0 261 230 073
2.0 FSI [8PA]			**2,0 l 110 kW BVY; BVZ 4 Zyl.**
Knock sensor	11.05→	OHL	0 261 231 146
Pressure sensor, intake manifold, gasoline	11.05→		0 261 230 031
2.0 TDI [8PA]			**2,0 l 100/103/120/125 kW AZV; BKD; BMM; BMN; BUY 4 Zyl.**
Air mass meter, diesel	09.04→		0 281 002 461
			0 986 284 007
Speed sensor, diesel	09.04→	FKW,TW	0 261 210 233
Boost pressure sensor, Diesel	09.04→		0 281 002 401
2.0 TDI quattro [8PA]			**2,0 l 103 kW BKD 4 Zyl.**
Boost pressure sensor, Diesel	09.04-05.07		0 281 002 401
2.0 TDI quattro [8PA]			**2,0 l 103/125 kW BMM; BMN 4 Zyl.**
Air mass meter, diesel	11.05→		0 281 002 461
			0 986 284 007
Speed sensor, diesel	11.05→	FKW,TW	0 261 210 233
Boost pressure sensor, Diesel	11.05→		0 281 002 401
2.0 TFSI [8PA]			**2,0 l 147 kW AXX; BWA 4 Zyl.**
Speed sensor, ignition/injection	09.04→		0 261 210 199
Boost pressure sensor, gasoline	09.04→		0 261 230 073
2.0 TFSI [8PA]			**2,0 l 147 kW CAWB 4 Zyl.**
Boost pressure sensor, gasoline	06.07→		0 261 230 073
2.0 TFSI quattro [8PA]			**2,0 l 147 kW AXX; BWA 4 Zyl.**
Speed sensor, ignition/injection	09.04→		0 261 210 199
Boost pressure sensor, gasoline	09.04→		0 261 230 073
3.2 quattro [8PA]			**3,2 l 184 kW BMJ 6 Zyl.**
Air mass meter, gasoline injection	09.04-10.05		0 280 218 073
			0 986 280 222

Product			
Phase sensor			
Fg.no. →8P..6A066 000,→8P..6B005 500	09.04-08.05		**0 232 103 019**
Knock sensor	09.04-10.05	OHL	**0 261 231 146**
3.2 quattro [8PA]			**3,2 l 184 kW BUB 6 Zyl.**
Air mass meter, gasoline injection	11.05-05.07		**0 280 218 073**
			0 986 280 222
Knock sensor	11.05-05.07	OHL	**0 261 231 146**

A4

1.6 [8D2; B5]			**1,6 l 74 kW ADP 4 Zyl.**
Knock sensor	11.94-10.96		**0 261 231 038**
Temperature sensor, intake air, injection system	11.94-10.96		**0 280 130 085**
Lateral acceleration sensor, brake system	11.94-10.96		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	11.94-10.96		**0 265 005 214**
Yaw rate sensor, brake system	11.94-10.96		**0 265 005 207**
1.6 [8D2; B5]			**1,6 l 74 kW AHL 4 Zyl.**
Phase sensor	10.96-07.99		**0 232 101 031**
Speed sensor, ignition/injection	10.96-07.99		**0 261 210 147**
Knock sensor	10.96-07.99		**0 261 231 038**
Temperature sensor, intake air, injection system	10.96-07.99		**0 280 130 085**
Lateral acceleration sensor, brake system	10.96-07.99		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	10.96-07.99		**0 265 005 214**
Yaw rate sensor, brake system	10.96-07.99		**0 265 005 207**
1.6 [8D2; B5]			**1,6 l 74 kW ANA; ARM 4 Zyl.**
Phase sensor	08.98-06.00		**0 232 101 031**
Speed sensor, ignition/injection	08.98-06.00		**0 261 210 147**
Knock sensor	08.98-06.00		**0 261 231 038**
Lateral acceleration sensor, brake system	08.98-06.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.98-06.00		**0 265 005 214**
Yaw rate sensor, brake system	08.98-06.00		**0 265 005 207**
1.6 [8D2; B5]			**1,6 l 75 kW ALZ 4 Zyl.**
Phase sensor	06.00-10.00		**0 232 101 038**
Lateral acceleration sensor, brake system	06.00-10.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	06.00-10.00		**0 265 005 214**
Yaw rate sensor, brake system	06.00-10.00		**0 265 005 207**
1.6 [8EC; B7]			**1,6 l 75 kW ALZ 4 Zyl.**
Speed sensor, ignition/injection	11.04→		**0 281 002 222**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05→		**0 265 005 621**
Wheel speed sensor, front	11.04→		**0 265 006 809**
Wheel speed sensor, rear	11.04→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
1.6 [8E2; B6]			**1,6 l 75 kW ALZ 4 Zyl.**
Speed sensor, ignition/injection	10.00-12.04		**0 281 002 222**
Duo sensor, acceleration and yaw rate, brake system	10.00-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	10.00-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	10.00-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	10.00-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**

Product			
Wheel speed sensor, rear			
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
1.8 [8D2; B5]			**1,8 l 85 kW AFY 4 Zyl.**
Phase sensor	04.95-06.00		**0 232 101 024**
Knock sensor	04.95-06.00	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	04.95-06.00		**0 280 130 085**
Lateral acceleration sensor, brake system	04.95-06.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	04.95-06.00		**0 265 005 214**
Yaw rate sensor, brake system	04.95-06.00		**0 265 005 207**
1.8 [8D2; B5]			**1,8 l 92 kW ADR 4 Zyl.**
Throttle valve assembly			
Fg.no. 8D-X 250 001→	03.99-04.99		**0 280 750 080**
Air mass meter, gasoline injection			
Fg.no. 8D..X..200 001→	02.99-04.99		**0 280 218 013**
			0 986 280 206
Phase sensor	11.94-04.99		**0 232 101 024**
Knock sensor	11.94-04.99	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	11.94-04.99		**0 280 130 085**
Lateral acceleration sensor, brake system	11.94-04.99		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	11.94-04.99		**0 265 005 214**
Yaw rate sensor, brake system	11.94-04.99		**0 265 005 207**
1.8 [8D2; B5]			**1,8 l 92 kW APT 4 Zyl.**
Throttle valve assembly	04.99-10.00		**0 280 750 080**
Air mass meter, gasoline injection	04.99-10.00		**0 280 218 013**
			0 986 280 206
Phase sensor	04.99-10.00		**0 232 101 024**
Knock sensor	04.99-10.00	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	04.99-10.00		**0 280 130 085**
Lateral acceleration sensor, brake system	04.99-10.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	04.99-10.00		**0 265 005 214**
Yaw rate sensor, brake system	04.99-10.00		**0 265 005 207**
1.8 [8D2; B5]			**1,8 l 92 kW ARG 4 Zyl.**
Throttle valve assembly			
Fg.no. 8D-X 250 001→	03.99-10.00		**0 280 750 080**
Air mass meter, gasoline injection	08.98-10.00		**0 280 218 013**
			0 986 280 206
Phase sensor	08.98-10.00		**0 232 101 024**
Knock sensor	08.98-10.00	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	08.98-10.00		**0 280 130 085**
Lateral acceleration sensor, brake system	08.98-10.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.98-10.00		**0 265 005 214**
Yaw rate sensor, brake system	08.98-10.00		**0 265 005 207**
1.8 [8D2; B5]			**1,8 l 92 kW AVV 4 Zyl.**
Throttle valve assembly	06.00-10.00		**0 280 750 080**
Air mass meter, gasoline injection	06.00-10.00		**0 280 218 013**
			0 986 280 206
Temperature sensor, intake air, injection system	06.00-10.00		**0 280 130 085**
Lateral acceleration sensor, brake system	06.00-10.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	06.00-10.00		**0 265 005 214**
Yaw rate sensor, brake system	06.00-10.00		**0 265 005 207**

A

Product			
◀ A4			
1.8 quattro [8D2; B5]			**1,8 l 85 kW AFY 4 Zyl.**
Phase sensor	07.95-10.01		**0 232 101 024**
Knock sensor	07.95-10.01	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	07.95-10.01		**0 280 130 085**
Lateral acceleration sensor, brake system	07.95-10.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	07.95-10.01		**0 265 005 214**
Yaw rate sensor, brake system	07.95-10.01		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-10.01	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.8 quattro [8D2; B5]			**1,8 l 92 kW ADR 4 Zyl.**
Throttle valve assembly			
Fg.no. 8D-X 250 001→	03.99-04.99		**0 280 750 080**
Air mass meter, gasoline injection			
Fg.no. 8D..X..200 001→	02.99-04.99		**0 280 218 013**
			0 986 280 206
Phase sensor	11.94-04.99		**0 232 101 024**
Knock sensor	11.94-04.99	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	11.94-04.99		**0 280 130 085**
Lateral acceleration sensor, brake system	11.94-04.99		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	11.94-04.99		**0 265 005 214**
Yaw rate sensor, brake system	11.94-04.99		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-04.99	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.8 quattro [8D2; B5]			**1,8 l 92 kW APT 4 Zyl.**
Throttle valve assembly	02.99-10.00		**0 280 750 080**
Air mass meter, gasoline injection	02.99-10.00		**0 280 218 013**
			0 986 280 206
Phase sensor	02.99-10.00		**0 232 101 024**
Knock sensor	02.99-10.00	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	02.99-10.00		**0 280 130 085**
Lateral acceleration sensor, brake system	02.99-10.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	02.99-10.00		**0 265 005 214**
Yaw rate sensor, brake system	02.99-10.00		**0 265 005 207**
Wheel speed sensor, rear	02.99-10.00	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.8 quattro [8D2; B5]			**1,8 l 92 kW ARG 4 Zyl.**
Throttle valve assembly			
Fg.no. 8D-X 250 001→	03.99-06.00		**0 280 750 080**
Air mass meter, gasoline injection	02.99-06.00		**0 280 218 013**
			0 986 280 206
Phase sensor	02.99-06.00		**0 232 101 024**
Knock sensor	02.99-06.00	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	02.99-06.00		**0 280 130 085**
Lateral acceleration sensor, brake system	02.99-06.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	02.99-06.00		**0 265 005 214**
Yaw rate sensor, brake system	02.99-06.00		**0 265 005 207**
Wheel speed sensor, rear	02.99-06.00	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**

Product			
1.8 T [8D2; B5]			**1,8 l 110 kW AEB 4 Zyl.**
Air mass meter, gasoline injection	11.94-07.98		**0 280 217 112**
Phase sensor	11.94-07.98		**0 232 101 024**
Knock sensor	11.94-07.98	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	11.94-07.98		**0 280 130 085**
Lateral acceleration sensor, brake system	11.94-07.98		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	11.94-07.98		**0 265 005 214**
Yaw rate sensor, brake system	11.94-07.98		**0 265 005 207**
1.8 T [8D2; B5]			**1,8 l 110 kW ANB; APU 4 Zyl.**
Air mass meter, gasoline injection	08.98-06.00		**0 280 218 032**
			0 986 280 210
Phase sensor	08.98-06.00		**0 232 101 024**
Knock sensor	08.98-06.00	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Boost pressure sensor, gasoline	08.98-06.00		**0 281 002 177**
Temperature sensor, intake air, injection system	08.98-06.00		**0 280 130 085**
Lateral acceleration sensor, brake system	08.98-06.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.98-06.00		**0 265 005 214**
Yaw rate sensor, brake system	08.98-06.00		**0 265 005 207**
1.8 T [8D2; B5]			**1,8 l 110 kW ARK 4 Zyl.**
Air mass meter, gasoline injection	08.98-07.99		**0 280 218 032**
			0 986 280 210
Phase sensor	08.98-07.99		**0 232 101 024**
Lateral acceleration sensor, brake system	08.98-07.99		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.98-07.99		**0 265 005 214**
Yaw rate sensor, brake system	08.98-07.99		**0 265 005 207**
1.8 T [8D2; B5]			**1,8 l 110 kW ATW 4 Zyl.**
Throttle valve assembly	08.99-05.00		**0 280 750 009**
Air mass meter, gasoline injection	08.99-05.00		**0 280 218 002**
			0 986 280 205
Knock sensor	08.99-05.00	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Boost pressure sensor, gasoline	08.99-05.00		**0 281 002 177**
Temperature sensor, intake air, injection system	08.99-05.00		**0 280 130 085**
1.8 T [8D2; B5]			**1,8 l 110 kW AWT 4 Zyl.**
Air mass meter, gasoline injection	06.00-10.00		**0 280 218 063**
			0 986 280 217
Phase sensor	06.00-10.00		**0 232 101 024**
Speed sensor, ignition/injection	06.00-10.00		**0 281 002 222**
Boost pressure sensor, gasoline	06.00-10.00		**0 281 002 177**
Temperature sensor, intake air, injection system	06.00-10.00		**0 280 130 085**
Lateral acceleration sensor, brake system	06.00-10.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	06.00-10.00		**0 265 005 214**
Yaw rate sensor, brake system	06.00-10.00		**0 265 005 207**
1.8 T [8D2; B5]			**1,8 l 125 kW AWM 4 Zyl.**
Throttle valve assembly	05.00-10.00		**0 280 750 009**
Air mass meter, gasoline injection	05.00-10.00		**0 280 218 063**
			0 986 280 217
Phase sensor	05.00-10.00		**0 232 101 024**
Speed sensor, ignition/injection	05.00-10.00		**0 281 002 222**
Boost pressure sensor, gasoline	05.00-10.00		**0 281 002 177**
Temperature sensor, intake air, injection system	05.00-10.00		**0 280 130 085**
1.8 T [8D2; B5]			**1,8 l 132 kW AJL 4 Zyl.**
Air mass meter, gasoline injection	08.97-12.98		**0 280 217 117**
			0 986 280 201
Phase sensor	08.97-12.98		**0 232 101 024**
Knock sensor	08.97-12.98	KZB	**0 261 231 036**
		KZG	**0 261 231 038**

Product			
Temperature sensor, intake air, injection system	08.97-12.98		**0 280 130 085**
Lateral acceleration sensor, brake system	08.97-12.98		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.97-12.98		**0 265 005 214**
Yaw rate sensor, brake system	08.97-12.98		**0 265 005 207**
1.8 T [8EC; B7]		**1,8 l 120 kW BFB 4 Zyl.**	
Throttle valve assembly	11.04→		**0 280 750 009**
Air mass meter, gasoline injection	11.04→		**0 280 218 063**
			0 986 280 217
Phase sensor	11.04→		**0 232 101 024**
Speed sensor, ignition/injection	11.04→		**0 281 002 222**
Boost pressure sensor, gasoline	11.04→		**0 261 230 073**
Temperature sensor, intake air, injection system	11.04→		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05→		**0 265 005 621**
Wheel speed sensor, front	11.04→		**0 265 006 809**
Wheel speed sensor, rear	11.04→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
1.8 T [8E2; B6]		**1,8 l 110 kW AVJ 4 Zyl.**	
Throttle valve assembly	12.00-06.02		**0 280 750 009**
Air mass meter, gasoline injection	12.00-06.02		**0 280 218 063**
			0 986 280 217
Phase sensor	12.00-06.02		**0 232 101 024**
Speed sensor, ignition/injection	12.00-06.02		**0 281 002 222**
Boost pressure sensor, gasoline	12.00-06.02		**0 261 230 073**
Temperature sensor, intake air, injection system			
Fg.no. →8E..1..080 000	12.00-04.01		**0 280 130 085**
Fg.no. 8E..2..000 001→	04.01-06.02		**0 280 130 116**
Duo sensor, acceleration and yaw rate, brake system	12.00-06.02		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	12.00-06.02		**0 265 005 303**
Wheel speed sensor, front	12.00-06.02		**0 265 006 683**
Wheel speed sensor, rear	12.00-06.02	ALR,LAB	**0 265 006 707**
		ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
1.8 T [8E2; B6]		**1,8 l 120 kW BFB 4 Zyl.**	
Throttle valve assembly	07.02-12.04		**0 280 750 009**
Air mass meter, gasoline injection	07.02-12.04		**0 280 218 063**
			0 986 280 217
Phase sensor	07.02-12.04		**0 232 101 024**
Speed sensor, ignition/injection	07.02-12.04		**0 281 002 222**
Boost pressure sensor, gasoline	07.02-12.04		**0 261 230 073**
Temperature sensor, intake air, injection system	07.02-12.04		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	07.02-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	07.02-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	07.02-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	07.02-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	07.02-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
1.8 T [8E2; B6]		**1,8 l 125 kW AMB 4 Zyl.**	
Throttle valve assembly	07.01-06.02		**0 280 750 009**
Air mass meter, gasoline injection	07.01-06.02		**0 280 218 063**
			0 986 280 217
Phase sensor	07.01-06.02		**0 232 101 024**

Product			
Speed sensor, ignition/injection	07.01-06.02		**0 281 002 222**
Boost pressure sensor, gasoline	07.01-06.02		**0 261 230 073**
Temperature sensor, intake air, injection system	07.01-06.02		**0 280 130 116**
Duo sensor, acceleration and yaw rate, brake system	07.01-06.02		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	07.01-06.02		**0 265 005 303**
Wheel speed sensor, front	07.01-06.02		**0 265 006 683**
Wheel speed sensor, rear	07.01-06.02	ALR,LAB	**0 265 006 707**
		ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
1.8 T [8E2; B6]		**1,8 l 140 kW BEX 4 Zyl.**	
Throttle valve assembly	11.02-12.04		**0 280 750 009**
Air mass meter, gasoline injection	11.02-12.04		**0 280 218 063**
			0 986 280 217
Phase sensor	11.02-12.04		**0 232 101 024**
Speed sensor, ignition/injection	11.02-12.04		**0 281 002 222**
Boost pressure sensor, gasoline	11.02-12.04		**0 261 230 073**
Temperature sensor, intake air, injection system	11.02-12.04		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	11.02-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	11.02-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	11.02-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	11.02-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	11.02-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
1.8 T quattro [8D2; B5]		**1,8 l 110 kW AEB 4 Zyl.**	
Air mass meter, gasoline injection	11.94-12.98		**0 280 217 112**
Phase sensor	11.94-12.98		**0 232 101 024**
Knock sensor	11.94-12.98	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	11.94-12.98		**0 280 130 085**
Lateral acceleration sensor, brake system	11.94-12.98		**0 265 005 127**
Yaw rate sensor, brake system	11.94-12.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-12.98	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.8 T quattro [8D2; B5]		**1,8 l 110 kW ANB; APU 4 Zyl.**	
Air mass meter, gasoline injection	02.99-10.00		**0 280 218 032**
			0 986 280 210
Phase sensor	02.99-10.00		**0 232 101 024**
Knock sensor	02.99-10.00	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Boost pressure sensor, gasoline	02.99-10.00		**0 281 002 177**
Temperature sensor, intake air, injection system	02.99-10.00		**0 280 130 085**
Lateral acceleration sensor, brake system	02.99-10.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	02.99-10.00		**0 265 005 214**
Yaw rate sensor, brake system	02.99-10.00		**0 265 005 207**
Wheel speed sensor, rear	02.99-10.00	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.8 T quattro [8D2; B5]		**1,8 l 110 kW ARK 4 Zyl.**	
Air mass meter, gasoline injection	07.98-07.99		**0 280 218 032**
			0 986 280 210
Phase sensor	07.98-07.99		**0 232 101 024**
Lateral acceleration sensor, brake system	07.98-07.99		**0 265 005 127**

A

Product			
◀ A4			
Duo sensor, acceleration and yaw rate, brake system	07.98-07.99		**0 265 005 214**
Yaw rate sensor, brake system	07.98-07.99		**0 265 005 207**
Wheel speed sensor, rear	07.98-07.99	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.8 T quattro [8D2; B5]		**1,8 l 110 kW AWT 4 Zyl.**	
Air mass meter, gasoline injection	06.00-10.00		**0 280 218 063**
			0 986 280 217
Phase sensor	06.00-10.00		**0 232 101 024**
Speed sensor, ignition/injection	06.00-10.00		**0 281 002 222**
Boost pressure sensor, gasoline	06.00-10.00		**0 281 002 177**
Temperature sensor, intake air, injection system	06.00-10.00		**0 280 130 085**
Lateral acceleration sensor, brake system	06.00-10.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	06.00-10.00		**0 265 005 214**
Yaw rate sensor, brake system	06.00-10.00		**0 265 005 207**
Wheel speed sensor, rear	06.00-10.00	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.8 T quattro [8D2; B5]		**1,8 l 132 kW AJL 4 Zyl.**	
Air mass meter, gasoline injection	08.97-10.00		**0 280 217 117**
			0 986 280 201
Phase sensor	08.97-10.00		**0 232 101 024**
Knock sensor	08.97-10.00	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	08.97-10.00		**0 280 130 085**
Lateral acceleration sensor, brake system	08.97-10.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.97-10.00		**0 265 005 214**
Yaw rate sensor, brake system	08.97-10.00		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-10.00	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.8 T quattro [8EC; B7]		**1,8 l 120 kW BFB 4 Zyl.**	
Throttle valve assembly	11.04→		**0 280 750 009**
Air mass meter, gasoline injection	11.04→		**0 280 218 063**
			0 986 280 217
Phase sensor	11.04→		**0 232 101 024**
Speed sensor, ignition/injection	11.04→		**0 281 002 222**
Boost pressure sensor, gasoline	11.04→		**0 261 230 073**
Temperature sensor, intake air, injection system	11.04→		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05→		**0 265 005 621**
Wheel speed sensor, front	11.04→		**0 265 006 809**
Wheel speed sensor, rear	11.04→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
1.8 T quattro [8E2; B6]		**1,8 l 110 kW AVJ 4 Zyl.**	
Throttle valve assembly	12.00-06.02		**0 280 750 009**
Air mass meter, gasoline injection	12.00-06.02		**0 280 218 063**
			0 986 280 217
Phase sensor	12.00-06.02		**0 232 101 024**
Speed sensor, ignition/injection	12.00-06.02		**0 281 002 222**
Boost pressure sensor, gasoline	12.00-06.02		**0 261 230 073**
Temperature sensor, intake air, injection system			
Fg.no. →8E..1..080 000	12.00-04.01		**0 280 130 085**
Fg.no. 8E..2..000 001→	04.01-06.02		**0 280 130 116**
Duo sensor, acceleration and yaw rate, brake system	12.00-06.02		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	12.00-06.02		**0 265 005 303**

Product			
Wheel speed sensor, front	12.00-06.02		**0 265 006 683**
Wheel speed sensor, rear	12.00-06.02	ALR,LAB	**0 265 006 707**
		ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
1.8 T quattro [8E2; B6]		**1,8 l 120 kW BFB 4 Zyl.**	
Throttle valve assembly	07.02-12.04		**0 280 750 009**
Air mass meter, gasoline injection	07.02-12.04		**0 280 218 063**
			0 986 280 217
Phase sensor	07.02-12.04		**0 232 101 024**
Speed sensor, ignition/injection	07.02-12.04		**0 281 002 222**
Boost pressure sensor, gasoline	07.02-12.04		**0 261 230 073**
Temperature sensor, intake air, injection system	07.02-12.04		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	07.02-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	07.02-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	07.02-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	07.02-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	07.02-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
1.8 T quattro [8E2; B6]		**1,8 l 125 kW AMB 4 Zyl.**	
Throttle valve assembly	07.01-06.02		**0 280 750 009**
Air mass meter, gasoline injection	07.01-06.02		**0 280 218 063**
			0 986 280 217
Phase sensor	07.01-06.02		**0 232 101 024**
Speed sensor, ignition/injection	07.01-06.02		**0 281 002 222**
Boost pressure sensor, gasoline	07.01-06.02		**0 261 230 073**
Temperature sensor, intake air, injection system	07.01-06.02		**0 280 130 116**
Duo sensor, acceleration and yaw rate, brake system	07.01-06.02		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	07.01-06.02		**0 265 005 303**
Wheel speed sensor, front	07.01-06.02		**0 265 006 683**
Wheel speed sensor, rear	07.01-06.02	ALR,LAB	**0 265 006 707**
		ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
1.8 T quattro [8E2; B6]		**1,8 l 140 kW BEX 4 Zyl.**	
Throttle valve assembly	11.02-12.04		**0 280 750 009**
Air mass meter, gasoline injection	11.02-12.04		**0 280 218 063**
			0 986 280 217
Phase sensor	11.02-12.04		**0 232 101 024**
Speed sensor, ignition/injection	11.02-12.04		**0 281 002 222**
Boost pressure sensor, gasoline	11.02-12.04		**0 261 230 073**
Temperature sensor, intake air, injection system	11.02-12.04		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	11.02-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	11.02-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	11.02-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	11.02-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	11.02-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**

Product			
1.8 Turbo			**1,8 l 120 kW BFB/BKB 4 Zyl.**
Throttle valve assembly	04.03-02.07		**0 280 750 009**
Air mass meter, gasoline injection	04.03-02.07		**0 280 218 063**
			0 986 280 217
Phase sensor	04.03-02.07		**0 232 101 091**
Speed sensor, ignition/injection	04.03-02.07		**0 281 002 222**
Boost pressure sensor, gasoline	04.03-02.07		**0 261 230 073**
Temperature sensor, intake air, injection system	04.03-02.07		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	04.03-02.07		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	04.03-02.07		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	04.03-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-02.07		**0 265 006 809**
Wheel speed sensor, rear	04.03-02.07		**0 265 006 681**
1.9 TDI [8D2; B5]			**1,9 l 55 kW AFF 4 Zyl.**
Air mass meter, diesel	08.97-06.00		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	08.97-06.00		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. →8D..W..028 000	03.96-09.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
Fg.no. 8D..W..028 001→	09.97-06.00	AG	**0 281 002 289**
Fg.no. 8D..W..028 001→8D..W..080 000	09.97-11.97	GS	**0 281 002 229**
Fg.no. 8D..W..080 001→	11.97-06.00	GS	**0 281 002 286**
Lateral acceleration sensor, brake system	03.96-06.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	03.96-06.00		**0 265 005 214**
Yaw rate sensor, brake system	03.96-06.00		**0 265 005 207**
1.9 TDI [8D2; B5]			**1,9 l 66 kW AHH 4 Zyl.**
Boost pressure sensor, Diesel	04.97-10.00		**0 281 002 177**
Pedal position sensor, diesel	04.97-10.00	AG	**0 205 001 031**
		GS	**0 205 001 032**
Lateral acceleration sensor, brake system	04.97-10.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	04.97-10.00		**0 265 005 214**
Yaw rate sensor, brake system	04.97-10.00		**0 265 005 207**
1.9 TDI [8D2; B5]			**1,9 l 66 kW AHU 4 Zyl.**
Air mass meter, diesel	08.97-07.98		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	08.97-07.98		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. →8D..W..028 000	08.96-09.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
Fg.no. 8D..W..028 001→	09.97-07.98	AG	**0 281 002 289**
Fg.no. 8D..W..028 001→8D..W..080 000	09.97-11.97	GS	**0 281 002 229**
Fg.no. 8D..W..080 001→	11.97-07.98	GS	**0 281 002 286**
Lateral acceleration sensor, brake system	08.96-07.98		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.96-07.98		**0 265 005 214**
Yaw rate sensor, brake system	08.96-07.98		**0 265 005 207**
1.9 TDI [8D2; B5]			**1,9 l 66 kW 1Z 4 Zyl.**
Pedal position sensor, diesel	11.94-07.96	AG	**0 205 001 031**
		GS	**0 205 001 032**
Lateral acceleration sensor, brake system	11.94-07.96		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	11.94-07.96		**0 265 005 214**
Yaw rate sensor, brake system	11.94-07.96		**0 265 005 207**
1.9 TDI [8D2; B5]			**1,9 l 81 kW AFN 4 Zyl.**
Air mass meter, diesel	08.97-07.99		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	08.97-07.99		**0 281 002 177**

Product			
Pedal position sensor, diesel			
Fg.no. →8D..W..028 000	02.96-09.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
Fg.no. 8D..W..028 001→	09.97-07.99	AG	**0 281 002 289**
Fg.no. 8D..W..028 001→8D..W..080 000	09.97-11.97	GS	**0 281 002 229**
Fg.no. 8D..W..080 001→	11.97-07.99	GS	**0 281 002 286**
Lateral acceleration sensor, brake system	02.96-07.99		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	02.96-07.99		**0 265 005 214**
Yaw rate sensor, brake system	02.96-07.99		**0 265 005 207**
1.9 TDI [8D2; B5]			**1,9 l 81/85 kW AJM; AVG 4 Zyl.**
Air mass meter, diesel	08.98-11.00		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	08.98-11.00		**0 281 002 177**
Pedal position sensor, diesel	08.98-11.00	AG	**0 281 002 289**
		GS	**0 281 002 286**
Lateral acceleration sensor, brake system	08.98-11.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.98-11.00		**0 265 005 214**
Yaw rate sensor, brake system	08.98-11.00		**0 265 005 207**
1.9 TDI [8EC; B7]			**1,9 l 85 kW BKE 4 Zyl.**
Air mass meter, diesel	11.04-11.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	11.04-11.05		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05-11.05		**0 265 005 621**
Wheel speed sensor, front	11.04-11.05		**0 265 006 809**
Wheel speed sensor, rear	11.04-11.05	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
1.9 TDI [8EC; B7]			**1,9 l 85 kW BRB 4 Zyl.**
Air mass meter, diesel	01.06→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	01.06→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	01.06→		**0 265 005 621**
Wheel speed sensor, front	01.06→		**0 265 006 809**
Wheel speed sensor, rear	01.06→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
1.9 TDI [8E2; B6]			**1,9 l 74 kW AVB 4 Zyl.**
Air mass meter, diesel			
Fg.no. →8E..2..120 000	04.01-09.01		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 8E..2..120 001→	09.01-05.04		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	04.01-05.04		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	04.01-05.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	04.01-05.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	04.01-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-05.04		**0 265 006 809**
Wheel speed sensor, rear	04.01-05.04	ALR,LAB	**0 265 006 707**
		ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
1.9 TDI [8E2; B6]			**1,9 l 85 kW BKE 4 Zyl.**
Air mass meter, diesel	06.04-12.04		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	06.04-12.04		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	06.04-12.04		**0 265 005 252**

A

Product			
◀ A4			
Pressure sensor, ESP, (electronic stability program)	06.04-12.04		**0 265 005 303**
Wheel speed sensor, front	06.04-12.04		**0 265 006 809**
Wheel speed sensor, rear	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
1.9 TDI [8E2; B6]		**1,9 l 96 kW AVF 4 Zyl.**	
Air mass meter, diesel	04.01-12.04		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	04.01-12.04		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	04.01-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	04.01-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	04.01-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	04.01-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	04.01-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
1.9 TDI [8E2; B6]		**1,9 l 96 kW AWX 4 Zyl.**	
Air mass meter, diesel			
Fg.no. →8E..1..080 000	12.00-04.01		**0 280 217 529**
			0 986 280 204
Fg.no. 8E..2..000 001→	04.01-06.03		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	12.00-06.03		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	12.00-06.03		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	12.00-06.03		**0 265 005 303**
Wheel speed sensor, front	12.00-06.03		**0 265 006 683**
Wheel speed sensor, rear	12.00-06.03	ALR,LAB	**0 265 006 707**
		ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
1.9 TDI quattro [8D2; B5]		**1,9 l 81 kW AFN 4 Zyl.**	
Air mass meter, diesel	08.97-12.98		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	08.97-12.98		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. →8D..W..028 000	07.96-09.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
Fg.no. 8D..W..028 001→	09.97-12.98	AG	**0 281 002 289**
Fg.no. 8D..W..028 001→8D..W..080 000	09.97-11.97	GS	**0 281 002 229**
Fg.no. 8D..W..080 001→	11.97-12.98	GS	**0 281 002 286**
Lateral acceleration sensor, brake system	07.96-12.98		**0 265 005 127**
Yaw rate sensor, brake system	07.96-12.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-12.98	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.9 TDI quattro [8D2; B5]		**1,9 l 81 kW AVG 4 Zyl.**	
Air mass meter, diesel	08.99-01.00		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	08.99-01.00		**0 281 002 177**
Lateral acceleration sensor, brake system	08.99-01.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.99-01.00		**0 265 005 214**
Yaw rate sensor, brake system	08.99-01.00		**0 265 005 207**
Wheel speed sensor, rear	08.99-01.00	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**

Product			
1.9 TDI quattro [8D2; B5]		**1,9 l 85 kW AJM 4 Zyl.**	
Air mass meter, diesel	12.98-12.98		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	12.98-12.98		**0 281 002 177**
Pedal position sensor, diesel	12.98-12.98	AG	**0 281 002 289**
		GS	**0 281 002 286**
Lateral acceleration sensor, brake system	12.98-12.98		**0 265 005 127**
Yaw rate sensor, brake system	12.98-12.98		**0 265 005 207**
Wheel speed sensor, rear	12.98-12.98	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.9 TDI quattro [8D2; B5]		**1,9 l 85 kW ATJ 4 Zyl.**	
Air mass meter, diesel	01.00-10.00		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	01.00-10.00		**0 281 002 177**
Lateral acceleration sensor, brake system	01.00-10.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	01.00-10.00		**0 265 005 214**
Yaw rate sensor, brake system	01.00-10.00		**0 265 005 207**
Wheel speed sensor, rear	01.00-10.00	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.9 TDI quattro [8E2; B6]		**1,9 l 96 kW AVF 4 Zyl.**	
Air mass meter, diesel	04.01-12.04		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	04.01-12.04		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	04.01-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	04.01-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	04.01-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	04.01-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	04.01-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 [8EC; B7]		**2,0 l 96 kW ALT 4 Zyl.**	
Throttle valve assembly	11.04→		**0 280 750 088**
Air mass meter, gasoline injection	11.04→		**0 280 218 058**
			0 986 280 215
Phase sensor	11.04→		**0 232 101 024**
Speed sensor, ignition/injection	11.04→		**0 281 002 222**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05→		**0 265 005 621**
Wheel speed sensor, front	11.04→		**0 265 006 809**
Wheel speed sensor, rear	11.04→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 [8E2; B6]		**2,0 l 96 kW ALT 4 Zyl.**	
Throttle valve assembly	12.00-12.04		**0 280 750 088**
Air mass meter, gasoline injection	12.00-12.04		**0 280 218 058**
			0 986 280 215
Phase sensor	12.00-12.04		**0 232 101 024**
Speed sensor, ignition/injection	12.00-12.04		**0 281 002 222**
Temperature sensor, intake air, injection system	12.00-12.04		**0 280 130 116**
Duo sensor, acceleration and yaw rate, brake system	12.00-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	12.00-12.04		**0 265 005 303**

A

Product			
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	12.00-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	12.00-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	12.00-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 FSI [8E2; B6]		**2,0 l 105 kW AWA 4 Zyl.**	
Throttle valve assembly	11.01-12.04		**0 280 750 134**
Air mass meter, gasoline injection	11.01-12.04		**0 280 218 058**
			0 986 280 215
Speed sensor, ignition/injection	11.01-12.04		**0 261 210 145**
Duo sensor, acceleration and yaw rate, brake system	11.01-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	11.01-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	11.01-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	11.01-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	11.01-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TDI [8EC; B7]		**2,0 l 89/93 kW BVF; BVG 4 Zyl.**	
Air mass meter, diesel	11.05-11.06		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	11.05-11.06		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	11.05-11.06		**0 265 005 621**
Wheel speed sensor, front	11.05-11.06		**0 265 006 809**
Wheel speed sensor, rear	11.05-11.06	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TDI [8EC; B7]		**2,0 l 100 kW BNA 4 Zyl.**	
Air mass meter, diesel	11.04-10.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	11.04-10.05		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05-10.05		**0 265 005 621**
Wheel speed sensor, front	11.04-10.05		**0 265 006 809**
Wheel speed sensor, rear	11.04-10.05	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TDI [8EC; B7]		**2,0 l 100 kW BRF 4 Zyl.**	
Air mass meter, diesel	11.05→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	11.05→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	11.05→		**0 265 005 621**
Wheel speed sensor, front	11.05→		**0 265 006 809**
Wheel speed sensor, rear	11.05→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TDI [8EC; B7]		**2,0 l 103 kW BLB 4 Zyl.**	
Air mass meter, diesel	11.04-05.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	11.04-05.05		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	11.04-05.05		**0 265 005 601**

Product			
Wheel speed sensor, front	11.04-05.05		**0 265 006 809**
Wheel speed sensor, rear	11.04-05.05	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TDI [8EC; B7]		**2,0 l 103 kW BPW 4 Zyl.**	
Air mass meter, diesel	11.04→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	11.04→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05→		**0 265 005 621**
Wheel speed sensor, front	11.04→		**0 265 006 809**
Wheel speed sensor, rear	11.04→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TDI [8EC; B7]		**2,0 l 103/120/125 kW BRD; BRE; BVA 4 Zyl.**	
Air mass meter, diesel	06.05→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	06.05→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	06.05→		**0 265 005 621**
Wheel speed sensor, front	06.05→		**0 265 006 809**
Wheel speed sensor, rear	06.05→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TDI quattro [8EC; B7]		**2,0 l 103/120/125 kW BPW; BRD; BVA 4 Zyl.**	
Air mass meter, diesel	01.06→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	01.06→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	01.06→		**0 265 005 621**
Wheel speed sensor, front	01.06→		**0 265 006 809**
Wheel speed sensor, rear	01.06→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TFSI [8EC; B7]		**2,0 l 125 kW BPJ; BYK 4 Zyl.**	
Speed sensor, ignition/injection	10.06→		**0 261 210 199**
Knock sensor	10.06→		**0 261 231 146**
Boost pressure sensor, gasoline	10.06→		**0 261 230 073**
Duo sensor, acceleration and yaw rate, brake system	10.06→		**0 265 005 621**
Wheel speed sensor, front	10.06→		**0 265 006 809**
Wheel speed sensor, rear	10.06→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TFSI [8EC; B7]		**2,0 l 147 kW BGB 4 Zyl.**	
Speed sensor, ignition/injection	11.04-08.05		**0 261 210 199**
Knock sensor	11.04-08.05		**0 261 231 146**
Boost pressure sensor, gasoline	11.04-08.05		**0 261 230 073**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05-08.05		**0 265 005 621**
Wheel speed sensor, front	11.04-08.05		**0 265 006 809**
Wheel speed sensor, rear	11.04-08.05	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TFSI [8EC; B7]		**2,0 l 147/162 kW BUL; BWE 4 Zyl.**	
Speed sensor, ignition/injection	06.05→		**0 261 210 199**
Knock sensor	06.05→		**0 261 231 146**
Boost pressure sensor, gasoline	06.05→		**0 261 230 073**
Duo sensor, acceleration and yaw rate, brake system	06.05→		**0 265 005 621**
Wheel speed sensor, front	06.05→		**0 265 006 809**
Wheel speed sensor, rear	06.05→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**

A

Product			
◀ A4			
2.0 TFSI quattro [8EC; B7]			**2,0 l 147 kW BGB 4 Zyl.**
Speed sensor, ignition/injection	11.04-08.05		**0 261 210 199**
Knock sensor	11.04-08.05		**0 261 231 146**
Boost pressure sensor, gasoline	11.04-08.05		**0 261 230 073**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05-08.05		**0 265 005 621**
Wheel speed sensor, front	11.04-08.05		**0 265 006 809**
Wheel speed sensor, rear	11.04-08.05	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TFSI quattro [8EC; B7]			**2,0 l 147/162 kW BUL; BWE; BWT 4 Zyl.**
Speed sensor, ignition/injection	06.05→		**0 261 210 199**
Knock sensor	06.05→		**0 261 231 146**
Boost pressure sensor, gasoline	06.05→		**0 261 230 073**
Duo sensor, acceleration and yaw rate, brake system	06.05→		**0 265 005 621**
Wheel speed sensor, front	06.05→		**0 265 006 809**
Wheel speed sensor, rear	06.05→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.4			**2,4 l 125 kW BDV 6 Zyl.**
Throttle valve assembly	04.03-02.07		**0 280 750 030**
Phase sensor	04.03-02.07		**0 232 101 024**
Speed sensor, ignition/injection	04.03-02.07		**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system	04.03-02.07		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	04.03-02.07		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	04.03-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-02.07		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	04.03-05.04	ALR,LAB	**0 265 006 707**
2.4 [8D2; B5]			**2,4 l 120 kW AJG 6 Zyl.**
Throttle valve assembly	08.97-07.98		**0 280 750 030**
Phase sensor	08.97-07.98		**0 232 101 024**
Speed sensor, ignition/injection	08.97-07.98		**0 261 210 147**
Knock sensor	08.97-07.98		**0 261 231 036**
Temperature sensor, intake air, injection system	08.97-07.98		**0 280 130 085**
Lateral acceleration sensor, brake system	08.97-07.98		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.97-07.98		**0 265 005 214**
Yaw rate sensor, brake system	08.97-07.98		**0 265 005 207**
2.4 [8D2; B5]			**2,4 l 120 kW AMM 6 Zyl.**
Temperature sensor, intake air, injection system	06.00-10.00		**0 280 130 085**
Lateral acceleration sensor, brake system	06.00-10.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	06.00-10.00		**0 265 005 214**
Yaw rate sensor, brake system	06.00-10.00		**0 265 005 207**
2.4 [8D2; B5]			**2,4 l 120 kW APZ 6 Zyl.**
Phase sensor	08.98-06.00		**0 232 101 024**
Speed sensor, ignition/injection	08.98-06.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →8D..X..260 000	08.98-04.99		**0 261 231 036**
Temperature sensor, intake air, injection system	08.98-06.00		**0 280 130 085**
Lateral acceleration sensor, brake system	08.98-06.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.98-06.00		**0 265 005 214**
Yaw rate sensor, brake system	08.98-06.00		**0 265 005 207**
2.4 [8D2; B5]			**2,4 l 121 kW AGA 6 Zyl.**
Phase sensor	08.97-07.98		**0 232 101 024**
Speed sensor, ignition/injection	08.97-07.98		**0 261 210 147**
Knock sensor	08.97-07.98		**0 261 231 036**
Temperature sensor, intake air, injection system	08.97-07.98		**0 280 130 085**
Lateral acceleration sensor, brake system	08.97-07.98		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.97-07.98		**0 265 005 214**
Yaw rate sensor, brake system	08.97-07.98		**0 265 005 207**
2.4 [8D2; B5]			**2,4 l 121 kW ALF 6 Zyl.**
Throttle valve assembly	08.97-07.98		**0 280 750 030**
Phase sensor	08.97-07.98		**0 232 101 024**
Speed sensor, ignition/injection	08.97-07.98		**0 261 210 147**
Knock sensor	08.97-07.98		**0 261 231 036**
Temperature sensor, intake air, injection system	08.97-07.98		**0 280 130 085**
Lateral acceleration sensor, brake system	08.97-07.98		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.97-07.98		**0 265 005 214**
Yaw rate sensor, brake system	08.97-07.98		**0 265 005 207**
2.4 [8D2; B5]			**2,4 l 121 kW AML 6 Zyl.**
Phase sensor	08.98-10.00		**0 232 101 024**
Temperature sensor, intake air, injection system	08.98-10.00		**0 280 130 085**
Lateral acceleration sensor, brake system	08.98-10.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.98-10.00		**0 265 005 214**
Yaw rate sensor, brake system	08.98-10.00		**0 265 005 207**
2.4 [8D2; B5]			**2,4 l 121 kW APS; ARJ 6 Zyl.**
Phase sensor	08.98-06.00		**0 232 101 024**
Speed sensor, ignition/injection	08.98-06.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →8D..X..260 000	08.98-04.99		**0 261 231 036**
Temperature sensor, intake air, injection system	08.98-06.00		**0 280 130 085**
Lateral acceleration sensor, brake system	08.98-06.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.98-06.00		**0 265 005 214**
Yaw rate sensor, brake system	08.98-06.00		**0 265 005 207**
2.4 [8E2; B6]			**2,4 l 120/125 kW AMM; BDV 6 Zyl.**
Throttle valve assembly	04.01-12.04		**0 280 750 030**
Phase sensor	04.01-12.04		**0 232 101 024**
Speed sensor, ignition/injection	04.01-12.04		**0 261 210 178**
Temperature sensor, intake air, injection system	04.01-12.04		**0 280 130 116**
Duo sensor, acceleration and yaw rate, brake system	04.01-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	04.01-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	04.01-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	04.01-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	04.01-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.4 quattro [8D2; B5]			**2,4 l 120 kW AJG 6 Zyl.**
Throttle valve assembly	08.97-07.98		**0 280 750 030**
Phase sensor	08.97-07.98		**0 232 101 024**
Speed sensor, ignition/injection	08.97-07.98		**0 261 210 147**
Knock sensor	08.97-07.98		**0 261 231 036**
Temperature sensor, intake air, injection system	08.97-07.98		**0 280 130 085**
Lateral acceleration sensor, brake system	08.97-07.98		**0 265 005 127**
Yaw rate sensor, brake system	08.97-07.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-07.98	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**

Product			
2.4 quattro [8D2; B5]		**2,4 l 120 kW APZ 6 Zyl.**	
Speed sensor, ignition/injection	02.99-06.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →8D..X..260 000	02.99-04.99		**0 261 231 036**
Temperature sensor, intake air, injection system	02.99-06.00		**0 280 130 085**
Lateral acceleration sensor, brake system	02.99-06.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	02.99-06.00		**0 265 005 214**
Yaw rate sensor, brake system	02.99-06.00		**0 265 005 207**
Wheel speed sensor, rear	02.99-06.00	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.4 quattro [8D2; B5]		**2,4 l 121 kW AGA 6 Zyl.**	
Phase sensor	08.97-07.98		**0 232 101 024**
Speed sensor, ignition/injection	08.97-07.98		**0 261 210 147**
Knock sensor	08.97-07.98		**0 261 231 036**
Temperature sensor, intake air, injection system	08.97-07.98		**0 280 130 085**
Lateral acceleration sensor, brake system	08.97-07.98		**0 265 005 127**
Yaw rate sensor, brake system	08.97-07.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-07.98	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.4 quattro [8D2; B5]		**2,4 l 121 kW AML 6 Zyl.**	
Phase sensor	08.98-12.98		**0 232 101 024**
Temperature sensor, intake air, injection system	08.98-12.98		**0 280 130 085**
Lateral acceleration sensor, brake system	08.98-12.98		**0 265 005 127**
Yaw rate sensor, brake system	08.98-12.98		**0 265 005 207**
Wheel speed sensor, rear	08.98-12.98	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.4 quattro [8D2; B5]		**2,4 l 121 kW APS 6 Zyl.**	
Speed sensor, ignition/injection	02.99-10.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →8D..X..260 000	02.99-04.99		**0 261 231 036**
Temperature sensor, intake air, injection system	02.99-10.00		**0 280 130 085**
Lateral acceleration sensor, brake system	02.99-10.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	02.99-10.00		**0 265 005 214**
Yaw rate sensor, brake system	02.99-10.00		**0 265 005 207**
Wheel speed sensor, rear	02.99-10.00	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.4 quattro [8D2; B5]		**2,4 l 121 kW ARJ 6 Zyl.**	
Phase sensor	02.99-06.00		**0 232 101 024**
Speed sensor, ignition/injection	02.99-06.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →8D..X..260 000	02.99-04.99		**0 261 231 036**
Temperature sensor, intake air, injection system	02.99-06.00		**0 280 130 085**
Lateral acceleration sensor, brake system	02.99-06.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	02.99-06.00		**0 265 005 214**
Yaw rate sensor, brake system	02.99-06.00		**0 265 005 207**
Wheel speed sensor, rear	02.99-06.00	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.5 TDI [8D2; B5]		**2,5 l 110 kW AFB 6 Zyl.**	
Air mass meter, diesel	08.97-06.00		**0 281 002 429**
			0 986 284 005
Speed sensor, diesel	08.97-06.00	KZU	**0 281 002 222**

Product			
Boost pressure sensor, Diesel	08.97-06.00		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. →8D..W..028 000	08.97-09.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
Fg.no. 8D..W..028 001→	09.97-06.00	AG	**0 281 002 289**
Fg.no. 8D..W..028 001→8D..W..080 000	09.97-11.97	GS	**0 281 002 229**
Fg.no. 8D..W..080 001→	11.97-06.00	GS	**0 281 002 286**
Lateral acceleration sensor, brake system	08.97-06.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.97-06.00		**0 265 005 214**
Yaw rate sensor, brake system	08.97-06.00		**0 265 005 207**
2.5 TDI [8D2; B5]		**2,5 l 110 kW AKN 6 Zyl.**	
Air mass meter, diesel			
Fg.no. →8D..X..400 000	07.98-06.99		**0 281 002 429**
			0 986 284 005
Fg.no. 8D..Y..000 001→	07.99-10.00		**0 281 002 403**
			0 986 284 004
Speed sensor, diesel	07.98-10.00	KZU	**0 281 002 222**
Boost pressure sensor, Diesel	07.98-10.00		**0 281 002 177**
Pedal position sensor, diesel	07.98-10.00	AG	**0 281 002 289**
		GS	**0 281 002 286**
Lateral acceleration sensor, brake system	07.98-10.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	07.98-10.00		**0 265 005 214**
Yaw rate sensor, brake system	07.98-10.00		**0 265 005 207**
2.5 TDI [8EC; B7]		**2,5 l 120 kW BDG 6 Zyl.**	
Speed sensor, diesel	11.04-05.06		**0 281 002 222**
Boost pressure sensor, Diesel	11.04-05.06		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05-05.06		**0 265 005 621**
Wheel speed sensor, front	11.04-05.06		**0 265 006 809**
Wheel speed sensor, rear	11.04-05.06	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.5 TDI [8E2; B6]		**2,5 l 114 kW AYM 6 Zyl.**	
Speed sensor, diesel	04.01-06.02		**0 281 002 222**
Boost pressure sensor, Diesel	04.01-06.02		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	04.01-06.02		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	04.01-06.02		**0 265 005 303**
Wheel speed sensor, front	04.01-06.02		**0 265 006 683**
Wheel speed sensor, rear	04.01-06.02	ALR,LAB	**0 265 006 707**
		ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
2.5 TDI [8E2; B6]		**2,5 l 120 kW BCZ; BDG 6 Zyl.**	
Speed sensor, diesel	06.03-12.04		**0 281 002 222**
Boost pressure sensor, Diesel	06.03-12.04		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	06.03-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.03-12.04		**0 265 005 303**
Wheel speed sensor, front	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	06.03-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	06.03-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.5 TDI [8E2; B6]		**2,5 l 120 kW BFC 6 Zyl.**	
Speed sensor, diesel	07.02-05.03		**0 281 002 222**
Boost pressure sensor, Diesel	07.02-05.03		**0 281 002 399**

A

Product			
◀ A4			
Duo sensor, acceleration and yaw rate, brake system	07.02-05.03		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	07.02-05.03		**0 265 005 303**
Wheel speed sensor, front	07.02-05.03		**0 265 006 683**
Wheel speed sensor, rear	07.02-05.03	ALR,LAB	**0 265 006 707**
		ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
2.5 TDI quattro [8D2; B5]			**2,5 l 110 kW AFB 6 Zyl.**
Air mass meter, diesel	11.97-06.00		**0 281 002 429**
			0 986 284 005
Speed sensor, diesel	11.97-06.00	KZU	**0 281 002 222**
Boost pressure sensor, Diesel	11.97-06.00		**0 281 002 177**
Pedal position sensor, diesel	11.97-06.00	AG	**0 281 002 289**
		GS	**0 281 002 286**
Lateral acceleration sensor, brake system	11.97-06.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	11.97-06.00		**0 265 005 214**
Yaw rate sensor, brake system	11.97-06.00		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-06.00	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.5 TDI quattro [8D2; B5]			**2,5 l 110 kW AKN 6 Zyl.**
Air mass meter, diesel			
Fg.no. →8D..X..400 000	02.99-06.99		**0 281 002 429**
			0 986 284 005
Fg.no. 8D..Y..000 001→	07.99-10.00		**0 281 002 403**
			0 986 284 004
Speed sensor, diesel	02.99-10.00	KZU	**0 281 002 222**
Boost pressure sensor, Diesel	02.99-10.00		**0 281 002 177**
Pedal position sensor, diesel	02.99-10.00	AG	**0 281 002 289**
		GS	**0 281 002 286**
Lateral acceleration sensor, brake system	02.99-10.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	02.99-10.00		**0 265 005 214**
Yaw rate sensor, brake system	02.99-10.00		**0 265 005 207**
Wheel speed sensor, rear	02.99-10.00	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.5 TDI quattro [8E2; B6]			**2,5 l 132 kW AKE 6 Zyl.**
Speed sensor, diesel	12.00-05.03		**0 281 002 222**
Boost pressure sensor, Diesel	12.00-05.03		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	12.00-05.03		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	12.00-05.03		**0 265 005 303**
Wheel speed sensor, front	12.00-05.03		**0 265 006 683**
Wheel speed sensor, rear	12.00-05.03	ALR,LAB	**0 265 006 707**
		ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
2.5 TDI quattro [8E2; B6]			**2,5 l 132 kW BAU; BDH 6 Zyl.**
Speed sensor, diesel	11.02-12.04		**0 281 002 222**
Boost pressure sensor, Diesel	11.02-12.04		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	11.02-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	11.02-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	11.02-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	11.02-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	11.02-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**

Product			
Wheel speed sensor, rear			
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.6 [8D2; B5]			**2,6 l 102/110 kW ABC; ACZ 6 Zyl.**
Throttle valve sensor	11.94-07.98		**0 280 120 431**
Phase sensor	11.94-07.98		**0 232 101 027**
Knock sensor	11.94-07.98		**0 261 231 036**
Lateral acceleration sensor, brake system	11.94-07.98		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	11.94-07.98		**0 265 005 214**
Yaw rate sensor, brake system	11.94-07.98		**0 265 005 207**
2.6 quattro [8D2; B5]			**2,6 l 102 kW ACZ 6 Zyl.**
Throttle valve sensor	04.95-07.97		**0 280 120 431**
Phase sensor	04.95-07.97		**0 232 101 027**
Knock sensor	04.95-07.97		**0 261 231 036**
Lateral acceleration sensor, brake system	04.95-07.97		**0 265 005 127**
Yaw rate sensor, brake system	04.95-07.97		**0 265 005 207**
2.6 quattro [8D2; B5]			**2,6 l 110 kW ABC 6 Zyl.**
Throttle valve sensor	11.94-07.98		**0 280 120 431**
Phase sensor	11.94-07.98		**0 232 101 027**
Knock sensor	11.94-07.98		**0 261 231 036**
Lateral acceleration sensor, brake system	11.94-07.98		**0 265 005 127**
Yaw rate sensor, brake system	11.94-07.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-07.98	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.7 T quattro [8D2; B5]			**2,7 l 195 kW AGB 6 Zyl.**
Throttle valve assembly	02.99-10.00		**0 280 750 003**
Air mass meter, gasoline injection			
Fg.no. →8D..Y..300 000	02.99-06.00		**0 280 218 038**
			0 986 280 212
Phase sensor	02.99-10.00		**0 232 101 024**
Speed sensor, ignition/injection	02.99-10.00		**0 261 210 147**
Knock sensor			
Fg.no. →8D..X..260 000	02.99-04.99		**0 261 231 036**
Pedal position sensor, EMS (electronic engine management)	02.99-10.00		**0 280 752 020**
Lateral acceleration sensor, brake system	02.99-10.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	02.99-10.00		**0 265 005 214**
Yaw rate sensor, brake system	02.99-10.00		**0 265 005 207**
Wheel speed sensor, rear	02.99-10.00	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.7 TDI [8EC; B7]			**2,7 l 120/132 kW BPP; BSG 6 Zyl.**
Speed sensor, diesel	11.05→	FKW	**0 261 210 145**
High-pressure sensor (CR system)			
Fg.no. →8E..6..111 000,→8E..6..802 000	11.05-08.06		**0 281 002 504**
Boost pressure sensor, Diesel	11.05→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	11.05→		**0 265 005 621**
Wheel speed sensor, front	11.05→		**0 265 006 809**
Wheel speed sensor, rear	11.05→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.8 [8D2; B5]			**2,8 l 120 kW AFC 6 Zyl.**
Phase sensor	11.94-06.95		**0 232 101 024**
Knock sensor	11.94-06.95		**0 261 231 036**
Lateral acceleration sensor, brake system	11.94-06.95		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	11.94-06.95		**0 265 005 214**
Yaw rate sensor, brake system	11.94-06.95		**0 265 005 207**

Product			
2.8 [8D2; B5]			**2,8 l 128 kW AAH 6 Zyl.**
Throttle valve sensor	11.94-07.97		**0 280 120 431**
Phase sensor	11.94-07.97		**0 232 101 027**
Knock sensor	11.94-07.97		**0 261 231 036**
Lateral acceleration sensor, brake system	11.94-07.97		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	11.94-07.97		**0 265 005 214**
Yaw rate sensor, brake system	11.94-07.97		**0 265 005 207**
2.8 [8D2; B5]			**2,8 l 140 kW ATX 6 Zyl.**
Temperature sensor, intake air, injection system	03.99-10.00		**0 280 130 085**
Lateral acceleration sensor, brake system	03.99-10.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	03.99-10.00		**0 265 005 214**
Yaw rate sensor, brake system	03.99-10.00		**0 265 005 207**
2.8 [8D2; B5]			**2,8 l 142 kW ACK 6 Zyl.**
Throttle valve assembly	03.96-12.98		**0 280 750 030**
Speed sensor, ignition/injection	03.96-07.97		**0 261 210 134**
	08.97-12.98		**0 261 210 147**
Knock sensor	03.96-12.98		**0 261 231 036**
Temperature sensor, intake air, injection system	03.96-12.98		**0 280 130 085**
Lateral acceleration sensor, brake system	03.96-12.98		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	03.96-12.98		**0 265 005 214**
Yaw rate sensor, brake system	03.96-12.98		**0 265 005 207**
2.8 [8D2; B5]			**2,8 l 142 kW AHA 6 Zyl.**
Phase sensor	10.96-08.99		**0 232 101 024**
Speed sensor, ignition/injection	10.96-08.99	AG	**0 261 210 147**
		GS	**0 261 210 134**
Knock sensor			
Fg.no. →8D..X..260 000	10.96-04.99		**0 261 231 036**
Temperature sensor, intake air, injection system	10.96-08.99		**0 280 130 085**
2.8 [8D2; B5]			**2,8 l 142 kW ALG 6 Zyl.**
Phase sensor	08.97-07.98		**0 232 101 024**
Speed sensor, ignition/injection	08.97-07.98		**0 261 210 147**
Knock sensor	08.97-07.98		**0 261 231 036**
Temperature sensor, intake air, injection system	08.97-07.98		**0 280 130 085**
Lateral acceleration sensor, brake system	08.97-07.98		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.97-07.98		**0 265 005 214**
Yaw rate sensor, brake system	08.97-07.98		**0 265 005 207**
2.8 [8D2; B5]			**2,8 l 142 kW AMX 6 Zyl.**
Phase sensor	08.98-12.98		**0 232 101 024**
Speed sensor, ignition/injection	08.98-12.98	AG	**0 261 210 147**
		GS	**0 261 210 178**
Lateral acceleration sensor, brake system	08.98-12.98		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.98-12.98		**0 265 005 214**
Yaw rate sensor, brake system	08.98-12.98		**0 265 005 207**
2.8 [8D2; B5]			**2,8 l 142 kW APR; AQD 6 Zyl.**
Phase sensor	08.98-06.00		**0 232 101 024**
Speed sensor, ignition/injection	08.98-06.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →8D..X..260 000	08.98-04.99		**0 261 231 036**
Temperature sensor, intake air, injection system	08.98-06.00		**0 280 130 085**
Lateral acceleration sensor, brake system	08.98-06.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.98-06.00		**0 265 005 214**
Yaw rate sensor, brake system	08.98-06.00		**0 265 005 207**
2.8 quattro [8D2; B5]			**2,8 l 128 kW AAH 6 Zyl.**
Throttle valve sensor	11.94-12.96		**0 280 120 431**
Phase sensor	11.94-12.96		**0 232 101 027**
Knock sensor	11.94-12.96		**0 261 231 036**

Product			
Lateral acceleration sensor, brake system	11.94-12.96		**0 265 005 127**
Yaw rate sensor, brake system	11.94-12.96		**0 265 005 207**
2.8 quattro [8D2; B5]			**2,8 l 128 kW AFC 6 Zyl.**
Phase sensor	08.95-04.97		**0 232 101 027**
Knock sensor	08.95-04.97		**0 261 231 036**
2.8 quattro [8D2; B5]			**2,8 l 140 kW ATX 6 Zyl.**
Temperature sensor, intake air, injection system	09.99-10.00		**0 280 130 085**
Lateral acceleration sensor, brake system	09.99-10.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	09.99-10.00		**0 265 005 214**
Yaw rate sensor, brake system	09.99-10.00		**0 265 005 207**
Wheel speed sensor, rear	09.99-10.00	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.8 quattro [8D2; B5]			**2,8 l 142 kW ACK 6 Zyl.**
Throttle valve assembly	03.96-07.98		**0 280 750 030**
Phase sensor	03.96-07.98		**0 232 101 024**
Speed sensor, ignition/injection	03.96-07.97		**0 261 210 134**
	08.97-07.98		**0 261 210 147**
Knock sensor	03.96-07.98		**0 261 231 036**
Temperature sensor, intake air, injection system	03.96-07.98		**0 280 130 085**
Lateral acceleration sensor, brake system	03.96-07.98		**0 265 005 127**
Yaw rate sensor, brake system	03.96-07.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-07.98	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.8 quattro [8D2; B5]			**2,8 l 142 kW ALG 6 Zyl.**
Phase sensor	05.97-07.98		**0 232 101 024**
Speed sensor, ignition/injection	05.97-07.98		**0 261 210 147**
Temperature sensor, intake air, injection system	05.97-07.98		**0 280 130 085**
Lateral acceleration sensor, brake system	05.97-07.98		**0 265 005 127**
Yaw rate sensor, brake system	05.97-07.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-07.98	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.8 quattro [8D2; B5]			**2,8 l 142 kW AMX 6 Zyl.**
Phase sensor	07.99-10.00		**0 232 101 024**
Speed sensor, ignition/injection	07.99-10.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Lateral acceleration sensor, brake system	07.99-10.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	07.99-10.00		**0 265 005 214**
Yaw rate sensor, brake system	07.99-10.00		**0 265 005 207**
Wheel speed sensor, rear	07.99-10.00	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.8 quattro [8D2; B5]			**2,8 l 142 kW APR; AQD 6 Zyl.**
Phase sensor	02.99-06.00		**0 232 101 024**
Speed sensor, ignition/injection	02.99-06.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →8D..X..260 000	02.99-04.99		**0 261 231 036**
Temperature sensor, intake air, injection system	02.99-06.00		**0 280 130 085**
Lateral acceleration sensor, brake system	02.99-06.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	02.99-06.00		**0 265 005 214**
Yaw rate sensor, brake system	02.99-06.00		**0 265 005 207**
Wheel speed sensor, rear	02.99-06.00	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**

A

Product			
◀ A4			
3.0 [8EC; B7]		**3,0 l 160 kW BBJ 6 Zyl.**	
Throttle valve assembly	11.04-05.06		**0 280 750 030**
Speed sensor, ignition/injection	11.04-05.06	AG	**0 261 210 147**
		GS	**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05-05.06		**0 265 005 621**
Wheel speed sensor, front	11.04-05.06		**0 265 006 809**
Wheel speed sensor, rear	11.04-05.06	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
3.0 [8E2; B6]		**3,0 l 160/162 kW ASN; BBJ 6 Zyl.**	
Throttle valve assembly	12.00-12.04		**0 280 750 030**
Speed sensor, ignition/injection	12.00-12.04	AG	**0 261 210 147**
		GS	**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system	12.00-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	12.00-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	12.00-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	12.00-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	12.00-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
3.0 [8E2; B6]		**3,0 l 162 kW AVK 6 Zyl.**	
Throttle valve assembly	09.01-06.02		**0 280 750 030**
Speed sensor, ignition/injection	09.01-06.02	AG	**0 261 210 147**
		GS	**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system	09.01-06.02		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	09.01-06.02		**0 265 005 303**
Wheel speed sensor, front	09.01-06.02		**0 265 006 683**
Wheel speed sensor, rear	09.01-06.02	ALR,LAB	**0 265 006 707**
		ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
3.0 quattro		**3,0 l 160 kW BBJ 6 Zyl.**	
Speed sensor, ignition/injection	04.03→		**0 261 210 147**
Duo sensor, acceleration and yaw rate, brake system	04.03→		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	04.03→		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	04.03-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03→		**0 265 006 809**
Wheel speed sensor, rear	04.03→		**0 265 006 681**
3.0 quattro [8EC; B7]		**3,0 l 160 kW BBJ 6 Zyl.**	
Throttle valve assembly	11.04-05.06		**0 280 750 030**
Speed sensor, ignition/injection	11.04-05.06	AG	**0 261 210 147**
		GS	**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05-05.06		**0 265 005 621**
Wheel speed sensor, front	11.04-05.06		**0 265 006 809**
Wheel speed sensor, rear	11.04-05.06	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
3.0 quattro [8E2; B6]		**3,0 l 160/162 kW ASN; BBJ 6 Zyl.**	
Throttle valve assembly	12.00-12.04		**0 280 750 030**
Speed sensor, ignition/injection	12.00-12.04	AG	**0 261 210 147**
		GS	**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system	12.00-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	12.00-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	12.00-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	12.00-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	12.00-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
3.0 quattro [8E2; B6]		**3,0 l 162 kW AVK 6 Zyl.**	
Throttle valve assembly	09.01-06.02		**0 280 750 030**
Speed sensor, ignition/injection	09.01-06.02	AG	**0 261 210 147**
		GS	**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system	09.01-06.02		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	09.01-06.02		**0 265 005 303**
Wheel speed sensor, front	09.01-06.02		**0 265 006 683**
Wheel speed sensor, rear	09.01-06.02	ALR,LAB	**0 265 006 707**
		ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
3.0 TDI quattro [8EC; B7]		**3,0 l 150 kW BKN 6 Zyl.**	
Speed sensor, diesel	01.05-05.06	FKW	**0 261 210 145**
High-pressure sensor (CR system)			
Fg.no. →8E..6..184 000,→8E..6..800 880	01.05-07.05		**0 281 002 504**
Boost pressure sensor, Diesel	01.05-05.06		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	01.05-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05-05.06		**0 265 005 621**
Wheel speed sensor, front	01.05-05.06		**0 265 006 809**
Wheel speed sensor, rear	01.05-05.06	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
3.0 TDI quattro [8EC; B7]		**3,0 l 171 kW ASB 6 Zyl.**	
Speed sensor, diesel	01.06→	FKW	**0 261 210 145**
Boost pressure sensor, Diesel	01.06→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	01.06→		**0 265 005 621**
Wheel speed sensor, front	01.06→		**0 265 006 809**
Wheel speed sensor, rear	01.06→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
3.2 FSI, FSI quattro [8EC; B7]		**3,2 l 188 kW AUK 6 Zyl.**	
Throttle valve assembly	01.05→		**0 280 750 003**
Pressure sensor, intake manifold, gasoline	01.05→		**0 261 230 095**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	01.05-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05→		**0 265 005 621**
Wheel speed sensor, front	01.05→		**0 265 006 809**
Wheel speed sensor, rear	01.05→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**

A4 Avant

1.6 [8D5; B5]		**1,6 l 74 kW ADP 4 Zyl.**	
Knock sensor	11.94-10.96		**0 261 231 038**
Temperature sensor, intake air, injection system	11.94-10.96		**0 280 130 085**
Lateral acceleration sensor, brake system	11.94-10.96		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	11.94-10.96		**0 265 005 214**
Yaw rate sensor, brake system	11.94-10.96		**0 265 005 207**

Product			
1.6 [8D5; B5]			**1,6 l 74 kW AHL 4 Zyl.**
Phase sensor	10.96-07.99		**0 232 101 031**
Speed sensor, ignition/injection	10.96-07.99		**0 261 210 147**
Knock sensor	10.96-07.99		**0 261 231 038**
Temperature sensor, intake air, injection system	10.96-07.99		**0 280 130 085**
Lateral acceleration sensor, brake system	10.96-07.99		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	10.96-07.99		**0 265 005 214**
Yaw rate sensor, brake system	10.96-07.99		**0 265 005 207**
1.6 [8D5; B5]			**1,6 l 74 kW ANA; ARM 4 Zyl.**
Phase sensor	08.98-10.00		**0 232 101 031**
Speed sensor, ignition/injection	08.98-10.00		**0 261 210 147**
Knock sensor	08.98-10.00		**0 261 231 038**
Lateral acceleration sensor, brake system	08.98-10.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.98-10.00		**0 265 005 214**
Yaw rate sensor, brake system	08.98-10.00		**0 265 005 207**
1.6 [8D5; B5]			**1,6 l 75 kW ALZ 4 Zyl.**
Phase sensor	06.00-09.01		**0 232 101 038**
Lateral acceleration sensor, brake system	06.00-09.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	06.00-09.01		**0 265 005 214**
Yaw rate sensor, brake system	06.00-09.01		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	06.00-09.01		**0 265 005 303**
1.6 [8ED; B7]			**1,6 l 75 kW ALZ 4 Zyl.**
Speed sensor, ignition/injection	11.04→		**0 281 002 222**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05→		**0 265 005 621**
Wheel speed sensor, front	11.04→		**0 265 006 809**
Wheel speed sensor, rear	11.04→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
1.6 [8E5; B6]			**1,6 l 75 kW ALZ 4 Zyl.**
Speed sensor, ignition/injection	09.01-12.04		**0 281 002 222**
Duo sensor, acceleration and yaw rate, brake system	09.01-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	09.01-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	09.01-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	09.01-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	09.01-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
1.8 [8D5; B5]			**1,8 l 85 kW AFY 4 Zyl.**
Phase sensor	07.95-12.98		**0 232 101 024**
Knock sensor	07.95-12.98	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	07.95-12.98		**0 280 130 085**
Lateral acceleration sensor, brake system	07.95-12.98		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	07.95-12.98		**0 265 005 214**
Yaw rate sensor, brake system	07.95-12.98		**0 265 005 207**
1.8 [8D5; B5]			**1,8 l 92 kW ADR 4 Zyl.**
Air mass meter, gasoline injection			
Fg.no. 8D-X 200 001→	01.99-04.99		**0 280 218 013**
			0 986 280 206
Phase sensor	11.94-04.99		**0 232 101 024**
Knock sensor	11.94-04.99	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	11.94-04.99		**0 280 130 085**
Lateral acceleration sensor, brake system	11.94-04.99		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	11.94-04.99		**0 265 005 214**
Yaw rate sensor, brake system	11.94-04.99		**0 265 005 207**
1.8 [8D5; B5]			**1,8 l 92 kW APT 4 Zyl.**
Throttle valve assembly	04.99-07.99		**0 280 750 080**
Air mass meter, gasoline injection	04.99-07.99		**0 280 218 013**
			0 986 280 206
Phase sensor	04.99-07.99		**0 232 101 024**
Knock sensor	04.99-07.99	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	04.99-07.99		**0 280 130 085**
Lateral acceleration sensor, brake system	04.99-07.99		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	04.99-07.99		**0 265 005 214**
Yaw rate sensor, brake system	04.99-07.99		**0 265 005 207**
1.8 [8D5; B5]			**1,8 l 92 kW ARG 4 Zyl.**
Throttle valve assembly			
Fg.no. 8D-X 250 001→	03.99-07.99		**0 280 750 080**
Air mass meter, gasoline injection	08.98-07.99		**0 280 218 013**
			0 986 280 206
Phase sensor	08.98-07.99		**0 232 101 024**
Knock sensor	08.98-07.99	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	08.98-07.99		**0 280 130 085**
Lateral acceleration sensor, brake system	08.98-07.99		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.98-07.99		**0 265 005 214**
Yaw rate sensor, brake system	08.98-07.99		**0 265 005 207**
1.8 [8D5; B5]			**1,8 l 92 kW AVV 4 Zyl.**
Throttle valve assembly	06.00-09.01		**0 280 750 080**
Air mass meter, gasoline injection	06.00-09.01		**0 280 218 013**
			0 986 280 206
Temperature sensor, intake air, injection system	06.00-09.01		**0 280 130 085**
Lateral acceleration sensor, brake system	06.00-09.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	06.00-09.01		**0 265 005 214**
Yaw rate sensor, brake system	06.00-09.01		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	06.00-09.01		**0 265 005 303**
1.8 quattro [8D5; B5]			**1,8 l 85 kW AFY 4 Zyl.**
Phase sensor	07.95-09.01		**0 232 101 024**
Knock sensor	07.95-09.01	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	07.95-09.01		**0 280 130 085**
Lateral acceleration sensor, brake system	07.95-09.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	07.95-09.01		**0 265 005 214**
Yaw rate sensor, brake system	07.95-09.01		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	07.95-09.01		**0 265 005 303**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-09.01	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.8 quattro [8D5; B5]			**1,8 l 92 kW ADR 4 Zyl.**
Air mass meter, gasoline injection			
Fg.no. 8D..X..200 001→	02.99-04.99		**0 280 218 013**
			0 986 280 206
Phase sensor	11.94-04.99		**0 232 101 024**
Knock sensor	11.94-04.99	KZB	**0 261 231 036**
		KZG	**0 261 231 038**

A

Product			
◀ A4 Avant			
Temperature sensor, intake air, injection system	11.94-04.99		**0 280 130 085**
Lateral acceleration sensor, brake system	11.94-04.99		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	11.94-04.99		**0 265 005 214**
Yaw rate sensor, brake system	11.94-04.99		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-04.99	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.8 quattro [8D5; B5]		**1,8 l 92 kW APT 4 Zyl.**	
Air mass meter, gasoline injection	04.99-09.01		**0 280 218 013**
			0 986 280 206
Phase sensor	04.99-09.01		**0 232 101 024**
Knock sensor	04.99-09.01	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	04.99-09.01		**0 280 130 085**
Lateral acceleration sensor, brake system	04.99-09.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	04.99-09.01		**0 265 005 214**
Yaw rate sensor, brake system	04.99-09.01		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	04.99-09.01		**0 265 005 303**
Wheel speed sensor, rear	04.99-09.01	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.8 quattro [8D5; B5]		**1,8 l 92 kW ARG 4 Zyl.**	
Air mass meter, gasoline injection	08.98-06.00		**0 280 218 013**
			0 986 280 206
Phase sensor	08.98-06.00		**0 232 101 024**
Knock sensor	08.98-06.00	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	08.98-06.00		**0 280 130 085**
Lateral acceleration sensor, brake system	08.98-06.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.98-06.00		**0 265 005 214**
Yaw rate sensor, brake system	08.98-06.00		**0 265 005 207**
Wheel speed sensor, rear	08.98-06.00	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.8 T [8D5; B5]		**1,8 l 110 kW AEB 4 Zyl.**	
Air mass meter, gasoline injection	10.95-07.98		**0 280 217 112**
Phase sensor	10.95-07.98		**0 232 101 024**
Knock sensor	10.95-07.98	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	10.95-07.98		**0 280 130 085**
Lateral acceleration sensor, brake system	10.95-07.98		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	10.95-07.98		**0 265 005 214**
Yaw rate sensor, brake system	10.95-07.98		**0 265 005 207**
1.8 T [8D5; B5]		**1,8 l 110 kW ANB 4 Zyl.**	
Air mass meter, gasoline injection	05.99-07.99		**0 280 218 032**
			0 986 280 210
Phase sensor	05.99-07.99		**0 232 101 024**
Knock sensor	05.99-07.99	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Boost pressure sensor, gasoline	05.99-07.99		**0 281 002 177**
Temperature sensor, intake air, injection system	05.99-07.99		**0 280 130 085**
Lateral acceleration sensor, brake system	05.99-07.99		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	05.99-07.99		**0 265 005 214**
Yaw rate sensor, brake system	05.99-07.99		**0 265 005 207**
1.8 T [8D5; B5]		**1,8 l 110 kW APU 4 Zyl.**	
Air mass meter, gasoline injection	08.98-09.01		**0 280 218 032**
			0 986 280 210

Product			
Phase sensor	08.98-09.01		**0 232 101 024**
Knock sensor	08.98-09.01	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Boost pressure sensor, gasoline	08.98-09.01		**0 281 002 177**
Temperature sensor, intake air, injection system	08.98-09.01		**0 280 130 085**
Lateral acceleration sensor, brake system	08.98-09.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.98-09.01		**0 265 005 214**
Yaw rate sensor, brake system	08.98-09.01		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	08.98-09.01		**0 265 005 303**
1.8 T [8D5; B5]		**1,8 l 110 kW ATW 4 Zyl.**	
Throttle valve assembly	08.99-05.00		**0 280 750 009**
Air mass meter, gasoline injection	08.99-05.00		**0 280 218 002**
			0 986 280 205
Knock sensor	08.99-05.00	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Boost pressure sensor, gasoline	08.99-05.00		**0 281 002 177**
Temperature sensor, intake air, injection system	08.99-05.00		**0 280 130 085**
1.8 T [8D5; B5]		**1,8 l 110 kW AWT 4 Zyl.**	
Air mass meter, gasoline injection	06.00-09.01		**0 280 218 063**
			0 986 280 217
Phase sensor	06.00-09.01		**0 232 101 024**
Speed sensor, ignition/injection	06.00-09.01		**0 281 002 222**
Boost pressure sensor, gasoline	06.00-09.01		**0 281 002 177**
Temperature sensor, intake air, injection system	06.00-09.01		**0 280 130 085**
Lateral acceleration sensor, brake system	06.00-09.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	06.00-09.01		**0 265 005 214**
Yaw rate sensor, brake system	06.00-09.01		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	06.00-09.01		**0 265 005 303**
1.8 T [8D5; B5]		**1,8 l 132 kW AJL 4 Zyl.**	
Air mass meter, gasoline injection	08.97-09.01		**0 280 217 117**
			0 986 280 201
Phase sensor	08.97-09.01		**0 232 101 024**
Knock sensor	08.97-09.01	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	08.97-09.01		**0 280 130 085**
Lateral acceleration sensor, brake system	08.97-09.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.97-09.01		**0 265 005 214**
Yaw rate sensor, brake system	08.97-09.01		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	08.97-09.01		**0 265 005 303**
1.8 T [8ED; B7]		**1,8 l 120 kW BFB 4 Zyl.**	
Throttle valve assembly	11.04→		**0 280 750 009**
Air mass meter, gasoline injection	11.04→		**0 280 218 063**
			0 986 280 217
Phase sensor	11.04→		**0 232 101 024**
Speed sensor, ignition/injection	11.04→		**0 281 002 222**
Boost pressure sensor, gasoline	11.04→		**0 261 230 073**
Temperature sensor, intake air, injection system	11.04→		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05→		**0 265 005 621**
Wheel speed sensor, front	11.04→		**0 265 006 809**
Wheel speed sensor, rear	11.04→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
1.8 T [8E5; B6]		**1,8 l 110 kW AVJ 4 Zyl.**	
Air mass meter, gasoline injection	09.01-06.02		**0 280 218 063**
			0 986 280 217
Phase sensor	09.01-06.02		**0 232 101 024**
Speed sensor, ignition/injection	09.01-06.02		**0 281 002 222**
Boost pressure sensor, gasoline	09.01-06.02		**0 261 230 073**

Product			
Temperature sensor, intake air, injection system	09.01-06.02		**0 280 130 116**
Duo sensor, acceleration and yaw rate, brake system	09.01-06.02		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	09.01-06.02		**0 265 005 303**
Wheel speed sensor, front	09.01-06.02		**0 265 006 683**
Wheel speed sensor, rear	09.01-06.02	ALR,LAB	**0 265 006 707**
		ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
1.8 T [8E5; B6]			**1,8 l 120/140 kW BEX; BFB 4 Zyl.**
Throttle valve assembly	07.02-12.04		**0 280 750 009**
Air mass meter, gasoline injection	07.02-12.04		**0 280 218 063**
			0 986 280 217
Phase sensor	07.02-12.04		**0 232 101 024**
Speed sensor, ignition/injection	07.02-12.04		**0 281 002 222**
Boost pressure sensor, gasoline	07.02-12.04		**0 261 230 073**
Temperature sensor, intake air, injection system	07.02-12.04		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	07.02-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	07.02-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	07.02-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	07.02-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	07.02-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
1.8 T quattro [8D5; B5]			**1,8 l 110 kW AEB 4 Zyl.**
Air mass meter, gasoline injection	02.96-12.98		**0 280 217 112**
Phase sensor	02.96-12.98		**0 232 101 024**
Knock sensor	02.96-12.98	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	02.96-12.98		**0 280 130 085**
Lateral acceleration sensor, brake system	02.96-12.98		**0 265 005 127**
Yaw rate sensor, brake system	02.96-12.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-12.98	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.8 T quattro [8D5; B5]			**1,8 l 110 kW ANB 4 Zyl.**
Air mass meter, gasoline injection	07.99-06.00		**0 280 218 032**
			0 986 280 210
Phase sensor	07.99-06.00		**0 232 101 024**
Knock sensor	07.99-06.00	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Boost pressure sensor, gasoline	07.99-06.00		**0 281 002 177**
Temperature sensor, intake air, injection system	07.99-06.00		**0 280 130 085**
Lateral acceleration sensor, brake system	07.99-06.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	07.99-06.00		**0 265 005 214**
Yaw rate sensor, brake system	07.99-06.00		**0 265 005 207**
Wheel speed sensor, rear	07.99-06.00	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.8 T quattro [8D5; B5]			**1,8 l 110 kW APU 4 Zyl.**
Air mass meter, gasoline injection	02.99-09.01		**0 280 218 032**
			0 986 280 210
Phase sensor	02.99-09.01		**0 232 101 024**
Knock sensor	02.99-09.01	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Boost pressure sensor, gasoline	02.99-09.01		**0 281 002 177**

Product			
Temperature sensor, intake air, injection system	02.99-09.01		**0 280 130 085**
Lateral acceleration sensor, brake system	02.99-09.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	02.99-09.01		**0 265 005 214**
Yaw rate sensor, brake system	02.99-09.01		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	02.99-09.01		**0 265 005 303**
Wheel speed sensor, rear	02.99-09.01	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.8 T quattro [8D5; B5]			**1,8 l 110 kW ARK 4 Zyl.**
Air mass meter, gasoline injection	08.98-12.98		**0 280 218 032**
			0 986 280 210
Lateral acceleration sensor, brake system	08.98-12.98		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.98-12.98		**0 265 005 214**
Yaw rate sensor, brake system	08.98-12.98		**0 265 005 207**
Wheel speed sensor, rear	08.98-12.98	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.8 T quattro [8D5; B5]			**1,8 l 110 kW AWT 4 Zyl.**
Air mass meter, gasoline injection	06.00-09.01		**0 280 218 063**
			0 986 280 217
Phase sensor	06.00-09.01		**0 232 101 024**
Speed sensor, ignition/injection	06.00-09.01		**0 281 002 222**
Boost pressure sensor, gasoline	06.00-09.01		**0 281 002 177**
Temperature sensor, intake air, injection system	06.00-09.01		**0 280 130 085**
Lateral acceleration sensor, brake system	06.00-09.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	06.00-09.01		**0 265 005 214**
Yaw rate sensor, brake system	06.00-09.01		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	06.00-09.01		**0 265 005 303**
Wheel speed sensor, rear	06.00-09.01	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.8 T quattro [8D5; B5]			**1,8 l 132 kW AJL 4 Zyl.**
Air mass meter, gasoline injection	08.97-09.01		**0 280 217 117**
			0 986 280 201
Phase sensor	08.97-09.01		**0 232 101 024**
Knock sensor	08.97-09.01	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	08.97-09.01		**0 280 130 085**
Lateral acceleration sensor, brake system	08.97-09.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.97-09.01		**0 265 005 214**
Yaw rate sensor, brake system	08.97-09.01		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	08.97-09.01		**0 265 005 303**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-09.01	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.8 T quattro [8ED; B7]			**1,8 l 120 kW BFB 4 Zyl.**
Throttle valve assembly	11.04→		**0 280 750 009**
Air mass meter, gasoline injection	11.04→		**0 280 218 063**
			0 986 280 217
Phase sensor	11.04→		**0 232 101 024**
Speed sensor, ignition/injection	11.04→		**0 281 002 222**
Boost pressure sensor, gasoline	11.04→		**0 261 230 073**
Temperature sensor, intake air, injection system	11.04→		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05→		**0 265 005 621**
Wheel speed sensor, front	11.04→		**0 265 006 809**

A

Product			
◀ A4 Avant			
Wheel speed sensor, rear	11.04→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
1.8 T quattro [8E5; B6]		**1,8 l 110 kW AVJ 4 Zyl.**	
Throttle valve assembly	09.01-06.02		**0 280 750 009**
Phase sensor	09.01-06.02		**0 232 101 024**
Speed sensor, ignition/injection	09.01-06.02		**0 281 002 222**
Boost pressure sensor, gasoline	09.01-06.02		**0 261 230 073**
Temperature sensor, intake air, injection system	09.01-06.02		**0 280 130 116**
Duo sensor, acceleration and yaw rate, brake system	09.01-06.02		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	09.01-06.02		**0 265 005 303**
Wheel speed sensor, front	09.01-06.02		**0 265 006 683**
Wheel speed sensor, rear	09.01-06.02	ALR,LAB	**0 265 006 707**
		ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
1.8 T quattro [8E5; B6]		**1,8 l 120 kW BFB 4 Zyl.**	
Throttle valve assembly	07.02-12.04		**0 280 750 009**
Air mass meter, gasoline injection	07.02-12.04		**0 280 218 063**
			0 986 280 217
Phase sensor	07.02-12.04		**0 232 101 024**
Speed sensor, ignition/injection	07.02-12.04		**0 281 002 222**
Boost pressure sensor, gasoline	07.02-12.04		**0 261 230 073**
Temperature sensor, intake air, injection system	07.02-12.04		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	07.02-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	07.02-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	07.02-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	07.02-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	07.02-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
1.8 T quattro [8E5; B6]		**1,8 l 125 kW AMB 4 Zyl.**	
Throttle valve assembly	09.01-06.02		**0 280 750 009**
Air mass meter, gasoline injection	09.01-06.02		**0 280 218 063**
			0 986 280 217
Phase sensor	09.01-06.02		**0 232 101 024**
Speed sensor, ignition/injection	09.01-06.02		**0 281 002 222**
Boost pressure sensor, gasoline	09.01-06.02		**0 261 230 073**
Temperature sensor, intake air, injection system	09.01-06.02		**0 280 130 116**
Duo sensor, acceleration and yaw rate, brake system	09.01-06.02		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	09.01-06.02		**0 265 005 303**
Wheel speed sensor, front	09.01-06.02		**0 265 006 683**
Wheel speed sensor, rear	09.01-06.02	ALR,LAB	**0 265 006 707**
		ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
1.8 T quattro [8E5; B6]		**1,8 l 140 kW BEX 4 Zyl.**	
Throttle valve assembly	11.02-12.04		**0 280 750 009**
Air mass meter, gasoline injection	11.02-12.04		**0 280 218 063**
			0 986 280 217
Phase sensor	11.02-12.04		**0 232 101 024**
Speed sensor, ignition/injection	11.02-12.04		**0 281 002 222**
Boost pressure sensor, gasoline	11.02-12.04		**0 261 230 073**
Temperature sensor, intake air, injection system	11.02-12.04		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	11.02-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	11.02-12.04		**0 265 005 303**

Product			
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	11.02-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	11.02-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	11.02-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
1.9 TDI [8D5; B5]		**1,9 l 66 kW AHH 4 Zyl.**	
Air mass meter, diesel	04.97-09.01		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	08.97-09.01		**0 281 002 177**
Pedal position sensor, diesel	04.97-09.01	AG	**0 205 001 031**
		GS	**0 205 001 032**
Lateral acceleration sensor, brake system	04.97-09.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	04.97-09.01		**0 265 005 214**
Yaw rate sensor, brake system	04.97-09.01		**0 265 005 207**
1.9 TDI [8D5; B5]		**1,9 l 66 kW AHU 4 Zyl.**	
Air mass meter, diesel	08.97-07.98		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	08.97-07.98		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. →8D..W..028 000	08.96-09.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
Fg.no. 8D..W..028 001→	09.97-07.98	AG	**0 281 002 289**
Fg.no. 8D..W..028 001→8D..W..080 000	09.97-11.97	GS	**0 281 002 229**
Fg.no. 8D..W..080 001→	11.97-07.98	GS	**0 281 002 286**
Lateral acceleration sensor, brake system	08.96-07.98		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.96-07.98		**0 265 005 214**
Yaw rate sensor, brake system	08.96-07.98		**0 265 005 207**
1.9 TDI [8D5; B5]		**1,9 l 66 kW 1Z 4 Zyl.**	
Pedal position sensor, diesel	01.95-07.96	AG	**0 205 001 031**
		GS	**0 205 001 032**
Lateral acceleration sensor, brake system	01.95-07.96		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	01.95-07.96		**0 265 005 214**
Yaw rate sensor, brake system	01.95-07.96		**0 265 005 207**
1.9 TDI [8D5; B5]		**1,9 l 81 kW AFN 4 Zyl.**	
Air mass meter, diesel	08.97-12.98		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	08.97-12.98		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. →8D..W..028 000	02.96-09.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
Fg.no. 8D..W..028 001→	09.97-12.98	AG	**0 281 002 289**
Fg.no. 8D..W..028 001→8D..W..080 000	09.97-11.97	GS	**0 281 002 229**
Fg.no. 8D..W..080 001→	11.97-12.98	GS	**0 281 002 286**
Lateral acceleration sensor, brake system	02.96-12.98		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	02.96-12.98		**0 265 005 214**
Yaw rate sensor, brake system	02.96-12.98		**0 265 005 207**
1.9 TDI [8D5; B5]		**1,9 l 81 kW AVG 4 Zyl.**	
Air mass meter, diesel	08.99-06.00		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	08.99-06.00		**0 281 002 177**
Pedal position sensor, diesel	08.99-06.00	AG	**0 281 002 289**
		GS	**0 281 002 286**
Lateral acceleration sensor, brake system	08.99-06.00		**0 265 005 127**

A

Product			
Duo sensor, acceleration and yaw rate, brake system	08.99-06.00		**0 265 005 214**
Yaw rate sensor, brake system	08.99-06.00		**0 265 005 207**
1.9 TDI [8D5; B5]			**1,9 l 85 kW AJM 4 Zyl.**
Air mass meter, diesel	08.98-09.01		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	08.98-09.01		**0 281 002 177**
Pedal position sensor, diesel	08.98-09.01	AG	**0 281 002 289**
		GS	**0 281 002 286**
Lateral acceleration sensor, brake system	08.98-09.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.98-09.01		**0 265 005 214**
Yaw rate sensor, brake system	08.98-09.01		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	08.98-09.01		**0 265 005 303**
1.9 TDI [8ED; B7]			**1,9 l 85 kW BKE 4 Zyl.**
Air mass meter, diesel	11.04-12.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	11.04-12.05		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05-12.05		**0 265 005 621**
Wheel speed sensor, front	11.04-12.05		**0 265 006 809**
Wheel speed sensor, rear	11.04-12.05	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
1.9 TDI [8ED; B7]			**1,9 l 85 kW BRB 4 Zyl.**
Air mass meter, diesel	01.06→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	01.06→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	01.06→		**0 265 005 621**
Wheel speed sensor, front	01.06→		**0 265 006 809**
Wheel speed sensor, rear	01.06→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
1.9 TDI [8E5; B6]			**1,9 l 74 kW AVB 4 Zyl.**
Air mass meter, diesel	09.01-05.04		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	09.01-05.04		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	09.01-05.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	09.01-05.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	09.01-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-05.04		**0 265 006 809**
Wheel speed sensor, rear	09.01-05.04	ALR,LAB	**0 265 006 707**
		ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
1.9 TDI [8E5; B6]			**1,9 l 85 kW BKE 4 Zyl.**
Air mass meter, diesel	06.04-12.04		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	06.04-12.04		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	06.04-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.04-12.04		**0 265 005 303**
Wheel speed sensor, front	06.04-12.04		**0 265 006 809**
Wheel speed sensor, rear	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
1.9 TDI [8E5; B6]			**1,9 l 96 kW AVF 4 Zyl.**
Air mass meter, diesel	09.01-12.04		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	09.01-12.04		**0 281 002 401**

Product			
Duo sensor, acceleration and yaw rate, brake system	09.01-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	09.01-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	09.01-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	09.01-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	09.01-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
1.9 TDI [8E5; B6]			**1,9 l 96 kW AWX 4 Zyl.**
Air mass meter, diesel	09.01-06.03		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	09.01-06.03		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	09.01-06.03		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	09.01-06.03		**0 265 005 303**
Wheel speed sensor, front	09.01-06.03		**0 265 006 683**
Wheel speed sensor, rear	09.01-06.03	ALR,LAB	**0 265 006 707**
		ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
1.9 TDI quattro [8D5; B5]			**1,9 l 81 kW AFN 4 Zyl.**
Air mass meter, diesel	08.97-07.99		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	08.97-07.99		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. →8D..W..028 000	07.96-09.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
Fg.no. 8D..W..028 001→	09.97-07.99	AG	**0 281 002 289**
Fg.no. 8D..W..028 001→8D..W..080 000	09.97-11.97	GS	**0 281 002 229**
Fg.no. 8D..W..080 001→	11.97-07.99	GS	**0 281 002 286**
Lateral acceleration sensor, brake system	07.96-07.99		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	07.96-07.99		**0 265 005 214**
Yaw rate sensor, brake system	07.96-07.99		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-07.99	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.9 TDI quattro [8D5; B5]			**1,9 l 81 kW AVG 4 Zyl.**
Air mass meter, diesel	08.99-01.00		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	08.99-01.00		**0 281 002 177**
Lateral acceleration sensor, brake system	08.99-01.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.99-01.00		**0 265 005 214**
Yaw rate sensor, brake system	08.99-01.00		**0 265 005 207**
Wheel speed sensor, rear	08.99-01.00	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.9 TDI quattro [8D5; B5]			**1,9 l 85 kW AJM 4 Zyl.**
Air mass meter, diesel	12.98-12.98		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	12.98-12.98		**0 281 002 177**
Pedal position sensor, diesel	12.98-12.98	AG	**0 281 002 289**
		GS	**0 281 002 286**
Lateral acceleration sensor, brake system	12.98-12.98		**0 265 005 127**
Yaw rate sensor, brake system	12.98-12.98		**0 265 005 207**

A

Product			
◀ A4 Avant			
Wheel speed sensor, rear	12.98-12.98	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.9 TDI quattro [8D5; B5]		**1,9 l 85 kW ATJ 4 Zyl.**	
Air mass meter, diesel	01.00-09.01		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	01.00-09.01		**0 281 002 177**
Lateral acceleration sensor, brake system	01.00-09.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	01.00-09.01		**0 265 005 214**
Yaw rate sensor, brake system	01.00-09.01		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	01.00-09.01		**0 265 005 303**
Wheel speed sensor, rear	01.00-09.01	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
1.9 TDI quattro [8E5; B6]		**1,9 l 96 kW AVF 4 Zyl.**	
Air mass meter, diesel	09.01-12.04		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	09.01-12.04		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	09.01-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	09.01-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	09.01-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	09.01-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	09.01-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 [8ED; B7]		**2,0 l 96 kW ALT 4 Zyl.**	
Throttle valve assembly	11.04→		**0 280 750 088**
Air mass meter, gasoline injection	11.04→		**0 280 218 058**
			0 986 280 215
Phase sensor	11.04→		**0 232 101 024**
Speed sensor, ignition/injection	11.04→		**0 281 002 222**
Temperature sensor, intake air, injection system	11.04→		**0 280 130 116**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05→		**0 265 005 621**
Wheel speed sensor, front	11.04→		**0 265 006 809**
Wheel speed sensor, rear	11.04→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 [8E5; B6]		**2,0 l 96 kW ALT 4 Zyl.**	
Throttle valve assembly	09.01-12.04		**0 280 750 088**
Air mass meter, gasoline injection	09.01-12.04		**0 280 218 058**
			0 986 280 215
Phase sensor	09.01-12.04		**0 232 101 024**
Speed sensor, ignition/injection	09.01-12.04		**0 281 002 222**
Temperature sensor, intake air, injection system	09.01-12.04		**0 280 130 116**
Duo sensor, acceleration and yaw rate, brake system	09.01-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	09.01-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	09.01-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	09.01-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	09.01-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**

Product			
Wheel speed sensor, rear			
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 FSI [8E5; B6]		**2,0 l 110 kW AWA 4 Zyl.**	
Throttle valve assembly	09.01-12.04		**0 280 750 134**
Air mass meter, gasoline injection	09.01-12.04		**0 280 218 058**
			0 986 280 215
Speed sensor, ignition/injection	09.01-12.04		**0 261 210 145**
Duo sensor, acceleration and yaw rate, brake system	09.01-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	09.01-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	09.01-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	09.01-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	09.01-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TDI [8ED; B7]		**2,0 l 89/93 kW BVF; BVG 4 Zyl.**	
Air mass meter, diesel	11.05-11.06		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	11.05-11.06		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	11.05-11.06		**0 265 005 621**
Wheel speed sensor, front	11.05-11.06		**0 265 006 809**
Wheel speed sensor, rear	11.05-11.06	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TDI [8ED; B7]		**2,0 l 100 kW BNA 4 Zyl.**	
Air mass meter, diesel	11.04-10.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	11.04-10.05		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05-10.05		**0 265 005 621**
Wheel speed sensor, front	11.04-10.05		**0 265 006 809**
Wheel speed sensor, rear	11.04-10.05	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TDI [8ED; B7]		**2,0 l 100 kW BRF 4 Zyl.**	
Air mass meter, diesel	11.05→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	11.05→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	11.05→		**0 265 005 621**
Wheel speed sensor, front	11.05→		**0 265 006 809**
Wheel speed sensor, rear	11.05→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TDI [8ED; B7]		**2,0 l 103 kW BLB 4 Zyl.**	
Air mass meter, diesel	11.04-11.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	11.04-11.05		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	11.04-11.05		**0 265 005 601**
Wheel speed sensor, front	11.04-11.05		**0 265 006 809**
Wheel speed sensor, rear	11.04-11.05	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TDI [8ED; B7]		**2,0 l 103 kW BPW 4 Zyl.**	
Air mass meter, diesel	11.04→		**0 281 002 461**
			0 986 284 007

Product			
Boost pressure sensor, Diesel	11.04→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05→		**0 265 005 621**
Wheel speed sensor, front	11.04→		**0 265 006 809**
Wheel speed sensor, rear	11.04→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TDI [8ED; B7]	**2,0 l 103/120/125 kW BRD; BRE; BVA 4 Zyl.**		
Air mass meter, diesel	06.05→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	06.05→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	06.05→		**0 265 005 621**
Wheel speed sensor, front	06.05→		**0 265 006 809**
Wheel speed sensor, rear	06.05→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TDI quattro [8ED; B7]	**2,0 l 103/120/125 kW BPW; BRD; BVA 4 Zyl.**		
Air mass meter, diesel	01.06→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	01.06→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	01.06→		**0 265 005 621**
Wheel speed sensor, front	01.06→		**0 265 006 809**
Wheel speed sensor, rear	01.06→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TFSI [8ED; B7]	**2,0 l 125 kW BPJ 4 Zyl.**		
Speed sensor, ignition/injection	03.07→		**0 261 210 199**
Knock sensor	03.07→		**0 261 231 146**
Boost pressure sensor, gasoline	03.07→		**0 261 230 073**
Duo sensor, acceleration and yaw rate, brake system	03.07→		**0 265 005 621**
Wheel speed sensor, front	03.07→		**0 265 006 809**
Wheel speed sensor, rear	03.07→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TFSI [8ED; B7]	**2,0 l 147 kW BGB; BPG 4 Zyl.**		
Speed sensor, ignition/injection	11.04→		**0 261 210 199**
Knock sensor	11.04→		**0 261 231 146**
Boost pressure sensor, gasoline	11.04→		**0 261 230 073**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05→		**0 265 005 621**
Wheel speed sensor, front	11.04→		**0 265 006 809**
Wheel speed sensor, rear	11.04→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TFSI [8ED; B7]	**2,0 l 147/162 kW BUL; BWE 4 Zyl.**		
Speed sensor, ignition/injection	06.05→		**0 261 210 199**
Knock sensor	06.05→		**0 261 231 146**
Boost pressure sensor, gasoline	06.05→		**0 261 230 073**
Duo sensor, acceleration and yaw rate, brake system	06.05→		**0 265 005 621**
Wheel speed sensor, front	06.05→		**0 265 006 809**
Wheel speed sensor, rear	06.05→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TFSI quattro [8ED; B7]	**2,0 l 147 kW BGB 4 Zyl.**		
Speed sensor, ignition/injection	11.04-08.05		**0 261 210 199**
Knock sensor	11.04-08.05		**0 261 231 146**
Boost pressure sensor, gasoline	11.04-08.05		**0 261 230 073**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05-08.05		**0 265 005 621**

Product			
Wheel speed sensor, front	11.04-08.05		**0 265 006 809**
Wheel speed sensor, rear	11.04-08.05	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TFSI quattro [8ED; B7]	**2,0 l 147/162 kW BUL; BWE 4 Zyl.**		
Speed sensor, ignition/injection	06.05→		**0 261 210 199**
Knock sensor	06.05→		**0 261 231 146**
Boost pressure sensor, gasoline	06.05→		**0 261 230 073**
Duo sensor, acceleration and yaw rate, brake system	06.05→		**0 265 005 621**
Wheel speed sensor, front	06.05→		**0 265 006 809**
Wheel speed sensor, rear	06.05→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.4 [8D5; B5]	**2,4 l 120 kW AMM 6 Zyl.**		
Temperature sensor, intake air, injection system	06.00-09.01		**0 280 130 085**
Lateral acceleration sensor, brake system	06.00-09.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	06.00-09.01		**0 265 005 214**
Yaw rate sensor, brake system	06.00-09.01		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	06.00-09.01		**0 265 005 303**
2.4 [8D5; B5]	**2,4 l 120 kW APZ 6 Zyl.**		
Phase sensor	08.98-06.00		**0 232 101 024**
Speed sensor, ignition/injection	08.98-06.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →8D..X..260 000	08.98-04.99		**0 261 231 036**
Temperature sensor, intake air, injection system	08.98-06.00		**0 280 130 085**
Lateral acceleration sensor, brake system	08.98-06.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.98-06.00		**0 265 005 214**
Yaw rate sensor, brake system	08.98-06.00		**0 265 005 207**
2.4 [8D5; B5]	**2,4 l 121 kW AGA 6 Zyl.**		
Phase sensor	08.97-07.98		**0 232 101 024**
Speed sensor, ignition/injection	08.97-07.98		**0 261 210 147**
Knock sensor	08.97-07.98		**0 261 231 036**
Temperature sensor, intake air, injection system	08.97-07.98		**0 280 130 085**
Lateral acceleration sensor, brake system	08.97-07.98		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.97-07.98		**0 265 005 214**
Yaw rate sensor, brake system	08.97-07.98		**0 265 005 207**
2.4 [8D5; B5]	**2,4 l 121 kW ALF 6 Zyl.**		
Throttle valve assembly	08.97-07.98		**0 280 750 030**
Phase sensor	08.97-07.98		**0 232 101 024**
Speed sensor, ignition/injection	08.97-07.98		**0 261 210 147**
Knock sensor	08.97-07.98		**0 261 231 036**
Temperature sensor, intake air, injection system	08.97-07.98		**0 280 130 085**
Lateral acceleration sensor, brake system	08.97-07.98		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.97-07.98		**0 265 005 214**
Yaw rate sensor, brake system	08.97-07.98		**0 265 005 207**
2.4 [8D5; B5]	**2,4 l 121 kW AML 6 Zyl.**		
Phase sensor	08.98-09.01		**0 232 101 024**
Temperature sensor, intake air, injection system	08.98-09.01		**0 280 130 085**
Lateral acceleration sensor, brake system	08.98-09.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.98-09.01		**0 265 005 214**
Yaw rate sensor, brake system	08.98-09.01		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	08.98-09.01		**0 265 005 303**
2.4 [8D5; B5]	**2,4 l 121 kW APS; ARJ 6 Zyl.**		
Phase sensor	08.98-06.00		**0 232 101 024**
Speed sensor, ignition/injection	08.98-06.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →8D..X..260 000	08.98-04.99		**0 261 231 036**

A

Product			
◀ A4 Avant			
Temperature sensor, intake air, injection system	08.98-06.00		**0 280 130 085**
Lateral acceleration sensor, brake system	08.98-06.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.98-06.00		**0 265 005 214**
Yaw rate sensor, brake system	08.98-06.00		**0 265 005 207**
2.4 [8E5; B6]		**2,4 l 120/125 kW AMM; BDV 6 Zyl.**	
Throttle valve assembly	09.01-12.04		**0 280 750 030**
Phase sensor	09.01-12.04		**0 232 101 024**
Speed sensor, ignition/injection	09.01-12.04		**0 261 210 178**
Temperature sensor, intake air, injection system	09.01-12.04		**0 280 130 116**
Duo sensor, acceleration and yaw rate, brake system	09.01-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	09.01-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	09.01-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	09.01-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	09.01-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.4 quattro [8D5; B5]		**2,4 l 120 kW AJG 6 Zyl.**	
Phase sensor	08.97-07.98		**0 232 101 024**
Speed sensor, ignition/injection	08.97-07.98		**0 261 210 147**
Knock sensor	08.97-07.98		**0 261 231 036**
Temperature sensor, intake air, injection system	08.97-07.98		**0 280 130 085**
Lateral acceleration sensor, brake system	08.97-07.98		**0 265 005 127**
Yaw rate sensor, brake system	08.97-07.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-07.98	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.4 quattro [8D5; B5]		**2,4 l 120 kW APZ 6 Zyl.**	
Phase sensor	08.98-06.00		**0 232 101 024**
Speed sensor, ignition/injection	08.98-06.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →8D..X..260 000	08.98-04.99		**0 261 231 036**
Temperature sensor, intake air, injection system	08.98-06.00		**0 280 130 085**
Lateral acceleration sensor, brake system	08.98-06.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.98-06.00		**0 265 005 214**
Yaw rate sensor, brake system	08.98-06.00		**0 265 005 207**
Wheel speed sensor, rear	08.98-06.00	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.4 quattro [8D5; B5]		**2,4 l 121 kW AGA; ALF 6 Zyl.**	
Phase sensor	08.97-07.98		**0 232 101 024**
Speed sensor, ignition/injection	08.97-07.98		**0 261 210 147**
Knock sensor	08.97-07.98		**0 261 231 036**
Temperature sensor, intake air, injection system	08.97-07.98		**0 280 130 085**
Lateral acceleration sensor, brake system	08.97-07.98		**0 265 005 127**
Yaw rate sensor, brake system	08.97-07.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-07.98	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.4 quattro [8D5; B5]		**2,4 l 121 kW AML 6 Zyl.**	
Phase sensor	08.98-12.98		**0 232 101 024**
Temperature sensor, intake air, injection system	08.98-12.98		**0 280 130 085**
Lateral acceleration sensor, brake system	08.98-12.98		**0 265 005 127**

Product			
Yaw rate sensor, brake system	08.98-12.98		**0 265 005 207**
Wheel speed sensor, rear	08.98-12.98	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.4 quattro [8D5; B5]		**2,4 l 121 kW APS 6 Zyl.**	
Phase sensor	08.98-09.01		**0 232 101 024**
Speed sensor, ignition/injection	08.98-09.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →8D..X..260 000	08.98-04.99		**0 261 231 036**
Temperature sensor, intake air, injection system	08.98-09.01		**0 280 130 085**
Lateral acceleration sensor, brake system	08.98-09.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.98-09.01		**0 265 005 214**
Yaw rate sensor, brake system	08.98-09.01		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	08.98-09.01		**0 265 005 303**
Wheel speed sensor, rear	08.98-09.01	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.4 quattro [8D5; B5]		**2,4 l 121 kW ARJ 6 Zyl.**	
Phase sensor	02.99-07.99		**0 232 101 024**
Speed sensor, ignition/injection	02.99-07.99	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →8D..X..260 000	02.99-04.99		**0 261 231 036**
Temperature sensor, intake air, injection system	02.99-07.99		**0 280 130 085**
Lateral acceleration sensor, brake system	02.99-07.99		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	02.99-07.99		**0 265 005 214**
Yaw rate sensor, brake system	02.99-07.99		**0 265 005 207**
Wheel speed sensor, rear	02.99-07.99	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.5 TDI [8D5; B5]		**2,5 l 110 kW AFB 6 Zyl.**	
Air mass meter, diesel	11.97-06.00		**0 281 002 429**
			0 986 284 005
Speed sensor, diesel	11.97-06.00	KZU	**0 281 002 222**
Boost pressure sensor, Diesel	11.97-06.00		**0 281 002 177**
Pedal position sensor, diesel	11.97-06.00	AG	**0 281 002 289**
		GS	**0 281 002 286**
Lateral acceleration sensor, brake system	11.97-06.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	11.97-06.00		**0 265 005 214**
Yaw rate sensor, brake system	11.97-06.00		**0 265 005 207**
2.5 TDI [8D5; B5]		**2,5 l 110 kW AKN 6 Zyl.**	
Air mass meter, diesel			
Fg.no. →8D..X..400 000	08.98-06.99		**0 281 002 429**
			0 986 284 005
Fg.no. 8D..Y..000 001→	07.99-09.01		**0 281 002 403**
			0 986 284 004
Speed sensor, diesel	08.98-09.01	KZU	**0 281 002 222**
Boost pressure sensor, Diesel	08.98-09.01		**0 281 002 177**
Pedal position sensor, diesel	08.98-09.01	AG	**0 281 002 289**
		GS	**0 281 002 286**
Lateral acceleration sensor, brake system	08.98-09.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.98-09.01		**0 265 005 214**
Yaw rate sensor, brake system	08.98-09.01		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	08.98-09.01		**0 265 005 303**
2.5 TDI [8ED; B7]		**2,5 l 120 kW BDG 6 Zyl.**	
Speed sensor, diesel	11.04-05.06		**0 281 002 222**
Boost pressure sensor, Diesel	11.04-05.06		**0 281 002 399**

Product			
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05-05.06		**0 265 005 621**
Wheel speed sensor, front	11.04-05.06		**0 265 006 809**
Wheel speed sensor, rear	11.04-05.06	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.5 TDI [8E5; B6]			**2,5 l 114 kW AYM 6 Zyl.**
Speed sensor, diesel	09.01-06.02		**0 281 002 222**
Boost pressure sensor, Diesel	09.01-06.02		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	09.01-06.02		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	09.01-06.02		**0 265 005 303**
Wheel speed sensor, front	09.01-06.02		**0 265 006 683**
Wheel speed sensor, rear	09.01-06.02	ALR,LAB	**0 265 006 707**
		ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
2.5 TDI [8E5; B6]			**2,5 l 120 kW BCZ; BDG 6 Zyl.**
Speed sensor, diesel	06.03-12.04		**0 281 002 222**
Boost pressure sensor, Diesel	06.03-12.04		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	06.03-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.03-12.04		**0 265 005 303**
Wheel speed sensor, front	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	06.03-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	06.03-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.5 TDI [8E5; B6]			**2,5 l 120 kW BFC 6 Zyl.**
Speed sensor, diesel	07.02-05.03		**0 281 002 222**
Boost pressure sensor, Diesel	07.02-05.03		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	07.02-05.03		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	07.02-05.03		**0 265 005 303**
Wheel speed sensor, front	07.02-05.03		**0 265 006 683**
Wheel speed sensor, rear	07.02-05.03	ALR,LAB	**0 265 006 707**
		ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
2.5 TDI quattro [8D5; B5]			**2,5 l 110 kW AFB 6 Zyl.**
Air mass meter, diesel	11.97-06.00		**0 281 002 429**
			0 986 284 005
Speed sensor, diesel	11.97-06.00	KZU	**0 281 002 222**
Boost pressure sensor, Diesel	11.97-06.00		**0 281 002 177**
Pedal position sensor, diesel	11.97-06.00	AG	**0 281 002 289**
		GS	**0 281 002 286**
Lateral acceleration sensor, brake system	11.97-06.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	11.97-06.00		**0 265 005 214**
Yaw rate sensor, brake system	11.97-06.00		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-06.00	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.5 TDI quattro [8D5; B5]			**2,5 l 110 kW AKN 6 Zyl.**
Air mass meter, diesel			
Fg.no. →8D..X..400 000	07.98-06.99		**0 281 002 429**
			0 986 284 005
Fg.no. 8D..Y..000 001→	07.99-07.99		**0 281 002 403**
			0 986 284 004
Speed sensor, diesel	07.98-07.99	KZU	**0 281 002 222**

Product			
Boost pressure sensor, Diesel	07.98-07.99		**0 281 002 177**
Pedal position sensor, diesel	07.98-07.99	AG	**0 281 002 289**
		GS	**0 281 002 286**
Lateral acceleration sensor, brake system	07.98-07.99		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	07.98-07.99		**0 265 005 214**
Yaw rate sensor, brake system	07.98-07.99		**0 265 005 207**
Wheel speed sensor, rear	07.98-07.99	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.5 TDI quattro [8E5; B6]			**2,5 l 132 kW AKE 6 Zyl.**
Speed sensor, diesel	09.01-05.03		**0 281 002 222**
Boost pressure sensor, Diesel	09.01-05.03		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	09.01-05.03		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	09.01-05.03		**0 265 005 303**
Wheel speed sensor, front	09.01-05.03		**0 265 006 683**
Wheel speed sensor, rear	09.01-05.03	ALR,LAB	**0 265 006 707**
		ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
2.5 TDI quattro [8E5; B6]			**2,5 l 132 kW BAU; BDH 6 Zyl.**
Speed sensor, diesel	11.02-12.04		**0 281 002 222**
Boost pressure sensor, Diesel	11.02-12.04		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	11.02-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	11.02-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	11.02-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	11.02-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	11.02-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.6 [8D2; B5]			**2,6 l 110 kW ABC 6 Zyl.**
Throttle valve sensor	11.94-07.98		**0 280 120 431**
Phase sensor	11.94-07.98		**0 232 101 027**
Knock sensor	11.94-07.98		**0 261 231 036**
Lateral acceleration sensor, brake system	11.94-07.98		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	11.94-07.98		**0 265 005 214**
Yaw rate sensor, brake system	11.94-07.98		**0 265 005 207**
2.6 [8D5; B5]			**2,6 l 102/110 kW ABC; ACZ 6 Zyl.**
Throttle valve sensor	11.94-07.98		**0 280 120 431**
Phase sensor	11.94-07.98		**0 232 101 027**
Knock sensor	11.94-07.98		**0 261 231 036**
Lateral acceleration sensor, brake system	11.94-07.98		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	11.94-07.98		**0 265 005 214**
Yaw rate sensor, brake system	11.94-07.98		**0 265 005 207**
2.6 quattro [8D5; B5]			**2,6 l 102 kW ACZ 6 Zyl.**
Throttle valve sensor	01.96-07.97		**0 280 120 431**
Phase sensor	01.96-07.97		**0 232 101 027**
Knock sensor	01.96-07.97		**0 261 231 036**
Lateral acceleration sensor, brake system	01.96-07.97		**0 265 005 127**
Yaw rate sensor, brake system	01.96-07.97		**0 265 005 207**
2.6 quattro [8D5; B5]			**2,6 l 110 kW ABC 6 Zyl.**
Throttle valve sensor	11.94-07.98		**0 280 120 431**
Phase sensor	11.94-07.98		**0 232 101 027**
Knock sensor	11.94-07.98		**0 261 231 036**
Lateral acceleration sensor, brake system	11.94-07.98		**0 265 005 127**

A

Product			
◀ A4 Avant			
Yaw rate sensor, brake system	11.94-07.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-07.98	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.7 TDI [8ED; B7]		**2,7 l 120/132 kW BPP; BSG 6 Zyl.**	
Speed sensor, diesel	11.05→	FKW	**0 261 210 145**
High-pressure sensor (CR system)			
Fg.no. →8E..6..111 000,→8E..6..802 000	11.05-08.06		**0 281 002 504**
Boost pressure sensor, Diesel	11.05→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	11.05→		**0 265 005 621**
Wheel speed sensor, front	11.05→		**0 265 006 809**
Wheel speed sensor, rear	11.05→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.8 [8D5; B5]		**2,8 l 140 kW ATX 6 Zyl.**	
Temperature sensor, intake air, injection system	03.99-09.01		**0 280 130 085**
Lateral acceleration sensor, brake system	03.99-09.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	03.99-09.01		**0 265 005 214**
Yaw rate sensor, brake system	03.99-09.01		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	03.99-09.01		**0 265 005 303**
2.8 [8D5; B5]		**2,8 l 142 kW ACK 6 Zyl.**	
Throttle valve assembly	03.96-07.98		**0 280 750 030**
Phase sensor	03.96-07.98		**0 232 101 024**
Speed sensor, ignition/injection	03.96-07.97		**0 261 210 134**
	08.97-07.98		**0 261 210 147**
Knock sensor	03.96-07.98		**0 261 231 036**
Temperature sensor, intake air, injection system	03.96-07.98		**0 280 130 085**
Lateral acceleration sensor, brake system	03.96-07.98		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	03.96-07.98		**0 265 005 214**
Yaw rate sensor, brake system	03.96-07.98		**0 265 005 207**
2.8 [8D5; B5]		**2,8 l 142 kW AHA 6 Zyl.**	
Phase sensor	08.97-08.99		**0 232 101 024**
Speed sensor, ignition/injection	08.97-08.99		**0 261 210 147**
		AG	**0 261 210 147**
		GS	**0 261 210 134**
Knock sensor			
Fg.no. →8D..X..260 000	08.97-04.99		**0 261 231 036**
Temperature sensor, intake air, injection system	08.97-08.99		**0 280 130 085**
2.8 [8D5; B5]		**2,8 l 142 kW ALG 6 Zyl.**	
Phase sensor	08.97-07.98		**0 232 101 024**
Speed sensor, ignition/injection	08.97-07.98		**0 261 210 147**
Knock sensor	08.97-07.98		**0 261 231 036**
Temperature sensor, intake air, injection system	08.97-07.98		**0 280 130 085**
Lateral acceleration sensor, brake system	08.97-07.98		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.97-07.98		**0 265 005 214**
Yaw rate sensor, brake system	08.97-07.98		**0 265 005 207**
2.8 [8D5; B5]		**2,8 l 142 kW APR; AQD 6 Zyl.**	
Phase sensor	08.98-07.99		**0 232 101 024**
Speed sensor, ignition/injection	08.98-07.99	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →8D..X..260 000	08.98-04.99		**0 261 231 036**
Temperature sensor, intake air, injection system	08.98-07.99		**0 280 130 085**
Lateral acceleration sensor, brake system	08.98-07.99		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.98-07.99		**0 265 005 214**
Yaw rate sensor, brake system	08.98-07.99		**0 265 005 207**

Product			
2.8 [8D5; B5]		**2,8 l 142 kW ATQ 6 Zyl.**	
Phase sensor	08.99-09.01		**0 232 101 024**
Speed sensor, ignition/injection	08.99-09.01	AG	**0 261 210 147**
		GS	**0 261 210 134**
Temperature sensor, intake air, injection system	08.99-09.01		**0 280 130 085**
2.8 quattro [8D5; B5]		**2,8 l 140 kW ATX 6 Zyl.**	
Temperature sensor, intake air, injection system	09.99-09.01		**0 280 130 085**
Lateral acceleration sensor, brake system	09.99-09.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	09.99-09.01		**0 265 005 214**
Yaw rate sensor, brake system	09.99-09.01		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	09.99-09.01		**0 265 005 303**
Wheel speed sensor, rear	09.99-09.01	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.8 quattro [8D5; B5]		**2,8 l 142 kW ACK 6 Zyl.**	
Phase sensor	03.96-07.98		**0 232 101 024**
Speed sensor, ignition/injection	03.96-07.97		**0 261 210 134**
	08.97-07.98		**0 261 210 147**
Knock sensor	03.96-07.98		**0 261 231 036**
Temperature sensor, intake air, injection system	03.96-07.98		**0 280 130 085**
Lateral acceleration sensor, brake system	03.96-07.98		**0 265 005 127**
Yaw rate sensor, brake system	03.96-07.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-07.98	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.8 quattro [8D5; B5]		**2,8 l 142 kW ALG 6 Zyl.**	
Phase sensor	08.97-07.98		**0 232 101 024**
Speed sensor, ignition/injection	08.97-07.98		**0 261 210 147**
Knock sensor	08.97-07.98		**0 261 231 036**
Temperature sensor, intake air, injection system	08.97-07.98		**0 280 130 085**
Lateral acceleration sensor, brake system	08.97-07.98		**0 265 005 127**
Yaw rate sensor, brake system	08.97-07.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-07.98	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.8 quattro [8D5; B5]		**2,8 l 142 kW AMX 6 Zyl.**	
Phase sensor	06.00-09.01		**0 232 101 024**
Speed sensor, ignition/injection	06.00-09.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Lateral acceleration sensor, brake system	06.00-09.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	06.00-09.01		**0 265 005 214**
Yaw rate sensor, brake system	06.00-09.01		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	06.00-09.01		**0 265 005 303**
Wheel speed sensor, rear	06.00-09.01	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.8 quattro [8D5; B5]		**2,8 l 142 kW APR; AQD 6 Zyl.**	
Phase sensor	08.98-06.00		**0 232 101 024**
Speed sensor, ignition/injection	08.98-06.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →8D..X..260 000	08.98-04.99		**0 261 231 036**
Temperature sensor, intake air, injection system	08.98-06.00		**0 280 130 085**
Lateral acceleration sensor, brake system	08.98-06.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	08.98-06.00		**0 265 005 214**
Yaw rate sensor, brake system	08.98-06.00		**0 265 005 207**

A

Product			
Wheel speed sensor, rear	08.98-06.00	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.8 quattro [8D5; B5]		**2,8 l 142 kW ATQ 6 Zyl.**	
Phase sensor	08.99-09.01		**0 232 101 024**
Speed sensor, ignition/injection	08.99-09.01	AG	**0 261 210 147**
		GS	**0 261 210 134**
Temperature sensor, intake air, injection system	08.99-09.01		**0 280 130 085**
3.0 [8ED; B7]		**3,0 l 160 kW BBJ 6 Zyl.**	
Throttle valve assembly	11.04-05.06		**0 280 750 030**
Speed sensor, ignition/injection	11.04-05.06	AG	**0 261 210 147**
		GS	**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05-05.06		**0 265 005 621**
Wheel speed sensor, front	11.04-05.06		**0 265 006 809**
Wheel speed sensor, rear	11.04-05.06	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
3.0 [8E5; B6]		**3,0 l 160/162 kW ASN; BBJ 6 Zyl.**	
Throttle valve assembly	09.01-12.04		**0 280 750 030**
Speed sensor, ignition/injection	09.01-12.04	AG	**0 261 210 147**
		GS	**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system	09.01-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	09.01-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	09.01-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	09.01-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	09.01-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
3.0 quattro [8ED; B7]		**3,0 l 160 kW BBJ 6 Zyl.**	
Throttle valve assembly	11.04-05.06		**0 280 750 030**
Speed sensor, ignition/injection	11.04-05.06	AG	**0 261 210 147**
		GS	**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05-05.06		**0 265 005 621**
Wheel speed sensor, front	11.04-05.06		**0 265 006 809**
Wheel speed sensor, rear	11.04-05.06	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
3.0 quattro [8E5; B6]		**3,0 l 160/162 kW ASN; BBJ 6 Zyl.**	
Throttle valve assembly	09.01-12.04		**0 280 750 030**
Speed sensor, ignition/injection	09.01-12.04	AG	**0 261 210 147**
		GS	**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system	09.01-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	09.01-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	09.01-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	09.01-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	09.01-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**

Product			
Wheel speed sensor, rear			
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
3.0 quattro [8E5; B6]		**3,0 l 162 kW AVK 6 Zyl.**	
Throttle valve assembly	09.01-06.02		**0 280 750 030**
Speed sensor, ignition/injection	09.01-06.02	AG	**0 261 210 147**
		GS	**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system	09.01-06.02		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	09.01-06.02		**0 265 005 303**
Wheel speed sensor, front	09.01-06.02		**0 265 006 683**
Wheel speed sensor, rear	09.01-06.02	ALR,LAB	**0 265 006 707**
		ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
3.0 TDI quattro [8ED; B7]		**3,0 l 150 kW BKN 6 Zyl.**	
Speed sensor, diesel	01.05-05.06	FKW	**0 261 210 145**
High-pressure sensor (CR system)			
Fg.no. →8E..6..184 000,→8E..6..800 880	01.05-07.05		**0 281 002 504**
Boost pressure sensor, Diesel	01.05-05.06		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	01.05-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05-05.06		**0 265 005 621**
Wheel speed sensor, front	01.05-05.06		**0 265 006 809**
Wheel speed sensor, rear	01.05-05.06	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
3.0 TDI quattro [8ED; B7]		**3,0 l 171 kW ASB 6 Zyl.**	
Speed sensor, diesel	01.06→	FKW	**0 261 210 145**
Boost pressure sensor, Diesel	01.06→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	01.06→		**0 265 005 621**
Wheel speed sensor, front	01.06→		**0 265 006 809**
Wheel speed sensor, rear	01.06→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
3.2 , FSI quattro [8ED; B7]		**3,2 l 188 kW AUK 6 Zyl.**	
Throttle valve assembly	01.05→		**0 280 750 003**
Pressure sensor, intake manifold, gasoline	01.05→		**0 261 230 095**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	01.05-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05→		**0 265 005 621**
Wheel speed sensor, front	01.05→		**0 265 006 809**
Wheel speed sensor, rear	01.05→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**

A4 Cabriolet

1.8 T [8HE; B7]		**1,8 l 120 kW BFB 4 Zyl.**	
Throttle valve assembly	01.06→		**0 280 750 009**
Air mass meter, gasoline injection	01.06→		**0 280 218 063**
			0 986 280 217
Phase sensor	01.06→		**0 232 101 024**
Speed sensor, ignition/injection	01.06→		**0 281 002 222**
Boost pressure sensor, gasoline	01.06→		**0 261 230 073**
Temperature sensor, intake air, injection system	01.06→		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.06→		**0 265 005 621**
Wheel speed sensor, front	01.06→		**0 265 006 809**
Wheel speed sensor, rear	01.06→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**

A

Product			
◀ A4 Cabriolet			
1.8 T [8H7; B6]			**1,8 l 120 kW BFB 4 Zyl.**
Throttle valve assembly	04.02-12.05		**0 280 750 009**
Air mass meter, gasoline injection	04.02-12.05		**0 280 218 063**
			0 986 280 217
Phase sensor	04.02-12.05		**0 232 101 024**
Speed sensor, ignition/injection	04.02-12.05		**0 281 002 222**
Boost pressure sensor, gasoline	04.02-12.05		**0 261 230 073**
Temperature sensor, intake air, injection system	04.02-12.05		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	04.02-12.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	04.02-12.05		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	04.02-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.05		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	04.02-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	04.02-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.05	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
1.8 T [8H7; B6]			**1,8 l 125 kW AMB 4 Zyl.**
Throttle valve assembly	10.02-06.06		**0 280 750 009**
Air mass meter, gasoline injection	10.02-06.06		**0 280 218 063**
			0 986 280 217
Phase sensor	10.02-06.06		**0 232 101 024**
Speed sensor, ignition/injection	10.02-06.06		**0 281 002 222**
Boost pressure sensor, gasoline	10.02-06.06		**0 261 230 073**
Temperature sensor, intake air, injection system	10.02-06.06		**0 280 130 085**
Wheel speed sensor, front			
Fg.no. →8H..3..050 000	10.02-05.03		**0 265 006 683**
Fg.no. 8H..4..000 001→	06.03-06.06		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8H..4..050 000,→8H..4..902 000, PR no. 8Q3	10.02-05.04	LAB	**0 265 006 707**
Fg.no. →8H..6..007 938,→8H..6..900 601, PR no. 8Q0,PR no. 8Q1	10.02-04.06	LAB,RAB	**0 265 006 681**
Fg.no. →8H..6..007 938,→8H..6..900 601, PR no. 8Q3	10.02-04.06	RAB	**0 265 006 681**
Fg.no. 8H..5..000 001→,8H..5..900 001→, PR no. 8Q3	06.04-06.06	LAB	**0 265 006 826**
Fg.no. 8H..6..007 939→,8H..6..900 602→, PR no. 8Q0,PR no. 8Q1	05.06-06.06	LAB,RAB	**0 265 006 824**
Fg.no. 8H..6..007 939→,8H..6..900 602→, PR no. 8Q3	05.06-06.06	RAB	**0 265 006 824**
1.8 T quattro [8H7; B6]			**1,8 l 120 kW BFB 4 Zyl.**
Throttle valve assembly	07.02-12.05		**0 280 750 009**
Air mass meter, gasoline injection	07.02-12.05		**0 280 218 063**
			0 986 280 217
Phase sensor	07.02-12.05		**0 232 101 024**
Speed sensor, ignition/injection	07.02-12.05		**0 281 002 222**
Boost pressure sensor, gasoline	07.02-12.05		**0 261 230 073**
Temperature sensor, intake air, injection system	07.02-12.05		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	07.02-12.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	07.02-12.05		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	07.02-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.05		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	07.02-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	07.02-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Wheel speed sensor, rear			
Fg.no. 8E..5..000 001→	06.04-12.05	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 [8H7; B6]			**2,0 l 96 kW ALT 4 Zyl.**
Throttle valve assembly	05.04-12.05		**0 280 750 088**
Air mass meter, gasoline injection	05.04-12.05		**0 280 218 058**
			0 986 280 215
Phase sensor	05.04-12.05		**0 232 101 024**
Speed sensor, ignition/injection	05.04-12.05		**0 281 002 222**
Temperature sensor, intake air, injection system	05.04-12.05		**0 280 130 116**
Duo sensor, acceleration and yaw rate, brake system	05.04-12.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	05.04-12.05		**0 265 005 303**
Wheel speed sensor, front	05.04-12.05		**0 265 006 809**
Wheel speed sensor, rear	05.04-12.05	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TDI [8HE; B7]			**2,0 l 100/103 kW BPW; BRC 4 Zyl.**
Air mass meter, diesel	01.06→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	01.06→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	01.06→		**0 265 005 621**
Wheel speed sensor, front	01.06→		**0 265 006 809**
Wheel speed sensor, rear	01.06→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.0 TFSI [8HE; B7]			**2,0 l 147 kW BWE 4 Zyl.**
Speed sensor, ignition/injection	01.06→		**0 261 210 199**
Knock sensor	01.06→		**0 261 231 146**
Boost pressure sensor, gasoline	01.06→		**0 261 230 073**
Duo sensor, acceleration and yaw rate, brake system	01.06→		**0 265 005 621**
Wheel speed sensor, front	01.06→		**0 265 006 809**
Wheel speed sensor, rear	01.06→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.4 [8H7; B6]			**2,4 l 120 kW AMM 6 Zyl.**
Throttle valve assembly	04.02-12.05		**0 280 750 030**
Phase sensor	04.02-12.05		**0 232 101 024**
Speed sensor, ignition/injection	04.02-12.05		**0 261 210 178**
Temperature sensor, intake air, injection system	04.02-12.05		**0 280 130 116**
Duo sensor, acceleration and yaw rate, brake system	04.02-12.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	04.02-12.05		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	04.02-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.05		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	04.02-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	04.02-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.05	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.4 [8H7; B6]			**2,4 l 125 kW BDV 6 Zyl.**
Phase sensor	04.02-12.05		**0 232 101 024**
Speed sensor, ignition/injection	04.02-12.05		**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system	04.02-12.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	04.02-12.05		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	04.02-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.05		**0 265 006 809**

Product			
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	04.02-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	04.02-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.05	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.5 TDI [8H7; B6]		**2,5 l 120 kW BCZ; BDG 6 Zyl.**	
Speed sensor, diesel	06.03-12.05		**0 281 002 222**
Boost pressure sensor, Diesel	06.03-12.05		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	06.03-12.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.03-12.05		**0 265 005 303**
Wheel speed sensor, front	06.03-12.05		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	06.03-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	06.03-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.05	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
2.5 TDI [8H7; B6]		**2,5 l 120 kW BFC 6 Zyl.**	
Speed sensor, diesel	08.02-05.03		**0 281 002 222**
Boost pressure sensor, Diesel	08.02-05.03		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	08.02-05.03		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	08.02-05.03		**0 265 005 303**
Wheel speed sensor, front	08.02-05.03		**0 265 006 683**
Wheel speed sensor, rear	08.02-05.03	ALR,LAB	**0 265 006 707**
		ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
2.7 TDI [8HE; B7]		**2,7 l 132 kW BPP 6 Zyl.**	
Speed sensor, diesel	11.05→	FKW	**0 261 210 145**
Boost pressure sensor, Diesel	11.05→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	11.05→		**0 265 005 621**
Wheel speed sensor, front	11.05→		**0 265 006 809**
Wheel speed sensor, rear	11.05→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
3.0 [8H7; B6]		**3,0 l 160/162 kW ASN; BBJ 6 Zyl.**	
Throttle valve assembly	04.02-12.05		**0 280 750 030**
Speed sensor, ignition/injection	04.02-12.05	AG	**0 261 210 147**
		GS	**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system	04.02-12.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	04.02-12.05		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	04.02-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.05		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	04.02-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	04.02-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.05	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
3.0 quattro [8H7; B6]		**3,0 l 162 kW ASN 6 Zyl.**	
Throttle valve assembly	06.03-12.05		**0 280 750 030**
Speed sensor, ignition/injection	06.03-12.05	AG	**0 261 210 147**
		GS	**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system	06.03-12.05		**0 265 005 252**

Product			
Pressure sensor, ESP, (electronic stability program)	06.03-12.05		**0 265 005 303**
Wheel speed sensor, front	06.03-12.05		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	06.03-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	06.03-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.05	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
3.0 quattro [8H7; B6]		**3,0 l 162 kW BGN 6 Zyl.**	
Throttle valve assembly	06.04-06.06		**0 280 750 030**
Speed sensor, ignition/injection	06.04-06.06	AG	**0 261 210 147**
		GS	**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system	06.04-06.06		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.04-06.06		**0 265 005 303**
Wheel speed sensor, front	06.04-06.06		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8H..6..007 938,→8H..6..900 601, PR no. 8Q3	06.04-04.06	RAB	**0 265 006 681**
Fg.no. 8H..6..007 939→,8H..6..900 602→, PR no. 8Q0,PR no. 8Q1	05.06-06.06	LAB,RAB	**0 265 006 824**
Fg.no. 8H..6..007 939→,8H..6..900 602→, PR no. 8Q3	05.06-06.06	RAB	**0 265 006 824**
PR no. 8Q3	06.04-06.06	LAB	**0 265 006 826**
3.0 TDI quattro [8HE; B7]		**3,0 l 150/171 kW ASB; BKN 6 Zyl.**	
Speed sensor, diesel	01.06→	FKW	**0 261 210 145**
Boost pressure sensor, Diesel	01.06→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	01.06→		**0 265 005 621**
Pressure sensor, ESP, (electronic stability program)	01.06→		**0 265 005 303**
Wheel speed sensor, front	01.06→		**0 265 006 809**
Wheel speed sensor, rear	01.06→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
3.2 FSI, FSI quattro [8HE; B7]		**3,2 l 188 kW AUK 6 Zyl.**	
Throttle valve assembly	01.06→		**0 280 750 003**
Pressure sensor, intake manifold, gasoline	01.06→		**0 261 230 095**
Duo sensor, acceleration and yaw rate, brake system	01.06→		**0 265 005 621**
Pressure sensor, ESP, (electronic stability program)	01.06→		**0 265 005 303**
Wheel speed sensor, front	01.06→		**0 265 006 809**
Wheel speed sensor, rear	01.06→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
4.2 quattro [8HE; B7]		**4,2 l 253 kW BHF 8 Zyl.**	
Throttle valve assembly	08.06→		**0 280 750 003**
Air mass meter, gasoline injection	08.06→		**0 280 218 067**
			0 986 280 219
Speed sensor, ignition/injection	08.06→		**0 261 210 190**
Duo sensor, acceleration and yaw rate, brake system	08.06→		**0 265 005 621**
Pressure sensor, ESP, (electronic stability program)	08.06→		**0 265 005 303**
Wheel speed sensor, front	08.06→		**0 265 006 809**
Wheel speed sensor, rear	08.06→	RAB	**0 265 006 824**
4.2 quattro [8H7; B6]		**4,2 l 253 kW BBK 8 Zyl.**	
Throttle valve assembly	02.04-12.05		**0 280 750 003**
Air mass meter, gasoline injection	02.04-12.05		**0 280 218 067**
			0 986 280 219
Speed sensor, ignition/injection	02.04-12.05		**0 261 210 190**
Pressure sensor, ESP, (electronic stability program)	02.04-12.05		**0 265 005 303**

A

Product			

A5 Coupé

1.8 TFSI [8T3]			**1,8 l 125 kW CABD 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.07→		**0 265 005 668**
Wheel speed sensor	10.07→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
2.7 TDI [8T3]			**2,7 l 140 kW CAMA 6 Zyl.**
Boost pressure sensor, Diesel	07.07→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	07.07→		**0 265 005 668**
Wheel speed sensor	07.07→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
3.0 TDI quattro [8T3]			**3,0 l 176 kW CAPA 6 Zyl.**
Boost pressure sensor, Diesel	06.07→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	06.07→		**0 265 005 668**
Wheel speed sensor	06.07→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
3.2 FSI [8T3]			**3,2 l 195 kW CALA 6 Zyl.**
Pressure sensor, intake manifold, gasoline	06.07→		**0 261 230 095**
Duo sensor, acceleration and yaw rate, brake system	06.07→		**0 265 005 668**
Wheel speed sensor	06.07→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
3.2 FSI quattro [8T3]			**3,2 l 195 kW CALA 6 Zyl.**
Pressure sensor, intake manifold, gasoline	11.07→		**0 261 230 095**
Duo sensor, acceleration and yaw rate, brake system	11.07→		**0 265 005 668**
Wheel speed sensor	11.07→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**

A6

1.8 [C5]			**1,8 l 92 kW ANQ 4 Zyl.**
Air mass meter, gasoline injection	09.99-10.05		**0 280 218 013**
			0 986 280 206
Phase sensor	09.99-10.05		**0 232 101 024**
Speed sensor, ignition/injection	09.99-10.05	FKW	**0 261 210 147**
Knock sensor	09.99-10.05	HI,KZB	**0 261 231 036**
		KZG,VO	**0 261 231 038**
1.8 [4A2; C4]			**1,8 l 92 kW ADR 4 Zyl.**
Phase sensor	06.94-10.97		**0 232 101 024**
Knock sensor	06.94-10.97	LLE	**0 261 231 038**
		RLE	**0 261 231 036**
Temperature sensor, intake air, injection system	06.94-10.97		**0 280 130 085**
1.8 [4B2; C5]			**1,8 l 85 kW AFY 4 Zyl.**
Phase sensor	05.97-05.00		**0 232 101 024**
Knock sensor	05.97-05.00	HI	**0 261 231 036**
		VO	**0 261 231 038**
Temperature sensor, intake air, injection system	05.97-05.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	05.97-05.00		**0 265 005 214**
1.8 [4B2; C5]			**1,8 l 92 kW AJP 4 Zyl.**
Phase sensor	12.97-07.99		**0 232 101 024**
Speed sensor, ignition/injection	12.97-07.99		**0 261 210 147**
Knock sensor	12.97-07.99	HI	**0 261 231 036**
		VO	**0 261 231 038**
Temperature sensor, intake air, injection system	12.97-07.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	12.97-07.99		**0 265 005 214**

Product			

1.8 [4B2; C5]			**1,8 l 92 kW AQE; ARH 4 Zyl.**
Throttle valve assembly			
Fg.no. 4B..X..124 001→	05.99-04.01		**0 280 750 080**
Air mass meter, gasoline injection	01.99-04.01		**0 280 218 013**
			0 986 280 206
Phase sensor	01.99-04.01		**0 232 101 024**
Speed sensor, ignition/injection	01.99-04.01		**0 261 210 147**
Knock sensor	01.99-04.01	HI	**0 261 231 036**
		VO	**0 261 231 038**
Temperature sensor, intake air, injection system	01.99-04.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.99-04.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	01.99-04.01		**0 265 005 303**
1.8 quattro [4A2; C4]			**1,8 l 92 kW ADR 4 Zyl.**
Phase sensor	10.95-10.97		**0 232 101 024**
Knock sensor	10.95-10.97	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
1.8 T [4B2; C5]			**1,8 l 110 kW AEB 4 Zyl.**
Air mass meter, gasoline injection			
Fg.no. →4B..W..080 000	04.97-11.97		**0 280 217 112**
Fg.no. 4B..W..080 000→	11.97-01.99		**0 280 217 117**
			0 986 280 201
Phase sensor	04.97-01.99		**0 232 101 024**
Knock sensor	04.97-01.99	HI	**0 261 231 036**
		VO	**0 261 231 038**
Pressure sensor, intake manifold, gasoline	04.97-01.99		**0 280 101 001**
Boost pressure sensor, gasoline	04.97-01.99		**0 281 002 177**
Temperature sensor, intake air, injection system	04.97-01.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	04.97-01.99		**0 265 005 214**
1.8 T [4B2; C5]			**1,8 l 110 kW ANB 4 Zyl.**
Throttle valve assembly	01.99-09.00		**0 280 750 009**
Air mass meter, gasoline injection	01.99-09.00		**0 280 218 032**
			0 986 280 210
Phase sensor	01.99-09.00		**0 232 101 024**
Knock sensor	01.99-09.00	HI	**0 261 231 036**
		VO	**0 261 231 038**
Boost pressure sensor, gasoline	01.99-09.00		**0 281 002 177**
Temperature sensor, intake air, injection system	01.99-09.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.99-09.00		**0 265 005 214**
1.8 T [4B2; C5]			**1,8 l 110 kW APU 4 Zyl.**
Throttle valve assembly	11.98-04.01		**0 280 750 009**
Air mass meter, gasoline injection	11.98-04.01		**0 280 218 032**
			0 986 280 210
Phase sensor	11.98-04.01		**0 232 101 024**
Knock sensor	11.98-04.01	HI	**0 261 231 036**
		VO	**0 261 231 038**
Boost pressure sensor, gasoline	11.98-04.01		**0 281 002 177**
Temperature sensor, intake air, injection system	11.98-04.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	11.98-04.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	11.98-04.01		**0 265 005 303**
1.8 T [4B2; C5]			**1,8 l 110 kW ARK 4 Zyl.**
Throttle valve assembly	01.99-05.99		**0 280 750 009**
Air mass meter, gasoline injection	01.99-05.99		**0 280 218 032**
			0 986 280 210
Phase sensor	01.99-05.99		**0 232 101 024**
Knock sensor	01.99-05.99	HI	**0 261 231 036**
		VO	**0 261 231 038**
Boost pressure sensor, gasoline	01.99-05.99		**0 281 002 177**
Temperature sensor, intake air, injection system	01.99-05.99		**0 280 130 085**

Product			
Duo sensor, acceleration and yaw rate, brake system	01.99-05.99		**0 265 005 214**
1.8 T [4B2; C5]			**1,8 l 110 kW AWT 4 Zyl.**
Throttle valve assembly	05.00-04.01		**0 280 750 009**
Air mass meter, gasoline injection	05.00-04.01		**0 280 218 063**
			0 986 280 217
Phase sensor	05.00-04.01		**0 232 101 024**
Speed sensor, ignition/injection	05.00-04.01		**0 281 002 222**
Knock sensor	05.00-04.01	HI	**0 261 231 036**
		VO	**0 261 231 038**
Boost pressure sensor, gasoline	05.00-04.01		**0 281 002 177**
Temperature sensor, intake air, injection system	05.00-04.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	05.00-04.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	05.00-04.01		**0 265 005 303**
1.8 T [4B2; C5]			**1,8 l 132 kW AJL 4 Zyl.**
Air mass meter, gasoline injection	11.97-10.00		**0 280 217 117**
			0 986 280 201
Phase sensor	11.97-10.00		**0 232 101 024**
Knock sensor	11.97-10.00	HI	**0 261 231 036**
		VO	**0 261 231 038**
Pressure sensor, intake manifold, gasoline	11.97-10.00		**0 280 101 001**
Boost pressure sensor, gasoline	11.97-10.00		**0 281 002 177**
Temperature sensor, intake air, injection system	11.97-10.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	11.97-10.00		**0 265 005 214**
1.8 T quattro [4B2; C5]			**1,8 l 110 kW AEB 4 Zyl.**
Air mass meter, gasoline injection			
Fg.no. →4B..W..080 000	04.97-11.97		**0 280 217 112**
Fg.no. 4B..W..080 000→	11.97-01.99		**0 280 217 117**
			0 986 280 201
Phase sensor	04.97-01.99		**0 232 101 024**
Knock sensor	04.97-01.99	HI	**0 261 231 036**
		VO	**0 261 231 038**
Pressure sensor, intake manifold, gasoline	04.97-01.99		**0 280 101 001**
Boost pressure sensor, gasoline	04.97-01.99		**0 281 002 177**
Temperature sensor, intake air, injection system	04.97-01.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-01.99		**0 265 005 214**
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	04.97-10.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-01.99	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
1.8 T quattro [4B2; C5]			**1,8 l 110 kW ANB 4 Zyl.**
Throttle valve assembly	01.99-09.00		**0 280 750 009**
Air mass meter, gasoline injection	01.99-09.00		**0 280 218 032**
			0 986 280 210
Phase sensor	01.99-09.00		**0 232 101 024**
Knock sensor	01.99-09.00	HI	**0 261 231 036**
		VO	**0 261 231 038**
Boost pressure sensor, gasoline	01.99-09.00		**0 281 002 177**
Temperature sensor, intake air, injection system	01.99-09.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.99-09.00		**0 265 005 214**
Wheel speed sensor, rear	01.99-09.00	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**

Product			
1.8 T quattro [4B2; C5]			**1,8 l 110 kW APU 4 Zyl.**
Throttle valve assembly	11.98-05.01		**0 280 750 009**
Air mass meter, gasoline injection	11.98-05.01		**0 280 218 032**
			0 986 280 210
Phase sensor	11.98-05.01		**0 232 101 024**
Knock sensor	11.98-05.01	HI	**0 261 231 036**
		VO	**0 261 231 038**
Boost pressure sensor, gasoline	11.98-05.01		**0 281 002 177**
Temperature sensor, intake air, injection system	11.98-05.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	11.98-05.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	11.98-05.01		**0 265 005 303**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-05.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
1.8 T quattro [4B2; C5]			**1,8 l 110 kW ARK 4 Zyl.**
Throttle valve assembly	01.99-05.99		**0 280 750 009**
Air mass meter, gasoline injection	01.99-05.99		**0 280 218 032**
			0 986 280 210
Phase sensor	01.99-05.99		**0 232 101 024**
Knock sensor	01.99-05.99	HI	**0 261 231 036**
		VO	**0 261 231 038**
Boost pressure sensor, gasoline	01.99-05.99		**0 281 002 177**
Temperature sensor, intake air, injection system	01.99-05.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.99-05.99		**0 265 005 214**
Wheel speed sensor, rear	01.99-05.99	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
1.8 T quattro [4B2; C5]			**1,8 l 110 kW AWT 4 Zyl.**
Throttle valve assembly	05.00-05.04		**0 280 750 009**
Air mass meter, gasoline injection	05.00-05.04		**0 280 218 063**
			0 986 280 217
Phase sensor	05.00-05.04		**0 232 101 024**
Speed sensor, ignition/injection	05.00-05.04		**0 281 002 222**
Knock sensor	05.00-05.04	HI	**0 261 231 036**
		VO	**0 261 231 038**
Boost pressure sensor, gasoline	05.00-05.04		**0 281 002 177**
Temperature sensor, intake air, injection system	05.00-05.04		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	05.00-05.01		**0 265 005 214**
	06.01-05.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	05.00-05.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-05.04		**0 265 006 765**
Wheel speed sensor, rear	05.00-05.04	OLW	**0 265 006 761**
Fg.no. →4B..2..079 500	05.00-12.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
Fg.no. 4B..2..079 501→	12.01-05.04	ALR,LAB	**0 265 006 763**
		ALR,RAB	**0 265 006 761**
		OLW	**0 265 006 761**
1.8 T quattro [4B2; C5]			**1,8 l 132 kW AJL 4 Zyl.**
Air mass meter, gasoline injection	06.97-10.00		**0 280 217 117**
			0 986 280 201
Phase sensor	06.97-10.00		**0 232 101 024**
Knock sensor	06.97-10.00	HI	**0 261 231 036**
		VO	**0 261 231 038**
Pressure sensor, intake manifold, gasoline	06.97-10.00		**0 280 101 001**
Boost pressure sensor, gasoline	06.97-10.00		**0 281 002 177**
Temperature sensor, intake air, injection system	06.97-10.00		**0 280 130 085**

A

Product			
◀ A6			
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-10.00		**0 265 005 214**
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	06.97-10.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-10.00	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
1.8 Turbo [C5]			**1,8 l 110 kW AWL 4 Zyl.**
Throttle valve assembly	07.00-09.06		**0 280 750 009**
Air mass meter, gasoline injection	07.00-09.06		**0 280 218 063**
			0 986 280 217
Phase sensor	07.00-09.06		**0 232 101 024**
Speed sensor, ignition/injection	07.00-09.06	FKW	**0 261 210 147**
Knock sensor	07.00-09.06	HI,KZB	**0 261 231 036**
		KZG,VO	**0 261 231 038**
Temperature sensor, intake air, injection system	07.00-09.06		**0 280 130 116**
1.9 TDI [4A2; C4]			**1,9 l 66 kW 1Z 4 Zyl.**
Pedal position sensor, diesel			
Fg.no. →4A..S..082 000	06.94-02.95	AG	**0 205 001 018**
		GS	**0 205 001 017**
Fg.no. 4A..S..082 001→	02.95-09.96	AG	**0 205 001 031**
		GS	**0 205 001 032**
1.9 TDI [4B2; C5]			**1,9 l 81 kW AFN 4 Zyl.**
Air mass meter, diesel	04.97-08.99		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	04.97-08.99		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. →4B..X..200 000	04.97-06.99	AG	**0 281 002 289**
		GS	**0 281 002 286**
Duo sensor, acceleration and yaw rate, brake system	04.97-08.99		**0 265 005 214**
1.9 TDI [4B2; C5]			**1,9 l 81 kW AVG 4 Zyl.**
Air mass meter, diesel	08.99-10.00		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	08.99-10.00		**0 281 002 177**
Duo sensor, acceleration and yaw rate, brake system	08.99-10.00		**0 265 005 214**
1.9 TDI [4B2; C5]			**1,9 l 85 kW AJM 4 Zyl.**
Air mass meter, diesel	05.99-04.01		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	05.99-04.01		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. →4B..X..200 000	05.99-06.99	AG	**0 281 002 289**
		GS	**0 281 002 286**
Duo sensor, acceleration and yaw rate, brake system	05.99-04.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	05.99-04.01		**0 265 005 303**
1.9 TDI [4B2; C5]			**1,9 l 96 kW AVF; AWX 4 Zyl.**
Air mass meter, diesel	06.01-05.04		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	06.01-05.04		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	06.01-05.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.01-05.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-05.04		**0 265 006 765**
2.0 [4A2; C4]			**2,0 l 85 kW ABK 4 Zyl.**
Knock sensor	06.94-08.96	LLE	**0 261 231 038**
		RLE	**0 261 231 036**

Product			
2.0 [4A2; C4]			**2,0 l 103 kW ACE 4 Zyl.**
Throttle valve sensor	06.94-10.97		**0 280 120 426**
Air flow sensor, gasoline injection	06.94-10.97		**0 986 439 389**
			F 026 TX2 059
			0 986 439 389
Knock sensor	06.94-10.97	LLE	**0 261 231 038**
		RLE	**0 261 231 036**
2.0 [4B2; C5]			**2,0 l 96 kW ALT 4 Zyl.**
Throttle valve assembly	06.01-05.04		**0 280 750 088**
Air mass meter, gasoline injection	06.01-05.04		**0 280 218 058**
			0 986 280 215
Phase sensor	06.01-05.04		**0 232 101 024**
Speed sensor, ignition/injection	06.01-05.04		**0 281 002 222**
Temperature sensor, intake air, injection system	06.01-05.04		**0 280 130 116**
Duo sensor, acceleration and yaw rate, brake system	06.01-05.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.01-05.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-05.04		**0 265 006 765**
2.0 quattro [4A2; C4]			**2,0 l 103 kW ACE 4 Zyl.**
Throttle valve sensor	06.94-10.97		**0 280 120 426**
Air flow sensor, gasoline injection	06.94-10.97		**0 986 439 389**
			F 026 TX2 059
			0 986 439 389
Phase sensor	06.94-10.97		**0 232 101 024**
Knock sensor	06.94-10.97	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
2.0 TDI [4F2; C6]			**2,0 l 89 kW BVG 4 Zyl.**
Air mass meter, diesel	09.05-06.06		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	09.05-06.06		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	09.05-06.06		**0 265 005 692**
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06-06.06	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
2.0 TDI [4F2; C6]			**2,0 l 100 kW BNA 4 Zyl.**
Air mass meter, diesel	07.04-11.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	07.04-11.05		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	07.04-11.05		**0 265 005 692**
Wheel speed sensor			
Fg.no. →4F..5..085 230	07.04-12.04	LAB	**0 265 007 728**
2.0 TDI [4F2; C6]			**2,0 l 100 kW BRF 4 Zyl.**
Air mass meter, diesel	06.05→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	06.05→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	06.05-05.06		**0 265 005 692**
Fg.no. 4F..7..000 001→	06.06→		**0 265 005 619**
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
2.0 TDI [4F2; C6]			**2,0 l 103 kW BLB 4 Zyl.**
Air mass meter, diesel	07.04-11.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	07.04-11.05		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	07.04-11.05		**0 265 005 692**

A

Product			
Wheel speed sensor			
Fg.no. →4F..5..085 230	07.04-12.04	LAB	**0 265 007 728**
2.0 TDI [4F2; C6]			**2,0 l 103 kW BRE 4 Zyl.**
Air mass meter, diesel	06.05→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	06.05→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	06.05-05.06		**0 265 005 692**
Fg.no. 4F..7..000 001→	06.06→		**0 265 005 619**
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
2.0 TFSI [4F2; C6]			**2,0 l 125 kW BPJ 4 Zyl.**
Speed sensor, ignition/injection	06.05→		**0 261 210 199**
Knock sensor	06.05→		**0 261 231 146**
Boost pressure sensor, gasoline	06.05→		**0 261 230 073**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	06.05-05.06		**0 265 005 692**
Fg.no. 4F..7..000 001→	06.06→		**0 265 005 619**
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
2.3 [4A2; C4]			**2,3 l 98 kW AAR 5 Zyl.**
Throttle valve sensor	06.94-10.97	AG	**0 280 120 433**
Air flow sensor, gasoline injection	06.94-10.97		**F 026 TX2 054**
			F 026 TX2 054
Knock sensor	06.94-10.97		**0 261 231 038**
2.3 quattro [4A2; C4]			**2,3 l 98 kW AAR 5 Zyl.**
Throttle valve sensor	08.94-07.95	AG	**0 280 120 433**
Air flow sensor, gasoline injection	08.94-07.95		**F 026 TX2 054**
			F 026 TX2 054
Knock sensor	08.94-07.95	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
2.4 [C5]			**2,4 l 121 kW APS 6 Zyl.**
Throttle valve assembly	09.99-09.05		**0 280 750 030**
Phase sensor	09.99-09.05		**0 232 101 024**
Speed sensor, ignition/injection	09.99-09.05	AG,FKW	**0 261 210 147**
		FKW,GS	**0 261 210 178**
Temperature sensor, intake air, injection system	09.99-09.05		**0 280 130 085**
2.4 [4A2; C4]			**2,4 l 110 kW AFM 6 Zyl.**
Throttle valve sensor	07.95-10.97		**0 280 120 431**
Knock sensor	07.95-10.97		**0 261 231 036**
2.4 [4B2; C5]			**2,4 l 100 kW ALW 6 Zyl.**
Phase sensor	08.97-01.99		**0 232 101 024**
Speed sensor, ignition/injection	08.97-01.99	AG	**0 261 210 147**
		GS	**0 261 210 178**
Temperature sensor, intake air, injection system	08.97-01.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	08.97-01.99		**0 265 005 214**
2.4 [4B2; C5]			**2,4 l 100 kW ARN 6 Zyl.**
Throttle valve assembly	02.99-05.00		**0 280 750 030**
Phase sensor	02.99-05.00		**0 232 101 024**
Speed sensor, ignition/injection	02.99-05.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →4B..X..200 000	02.99-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	02.99-05.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	02.99-05.00		**0 265 005 214**

Product			
2.4 [4B2; C5]			**2,4 l 100 kW ASM 6 Zyl.**
Throttle valve assembly	06.01-05.04		**0 280 750 030**
Phase sensor	06.01-05.04		**0 232 101 024**
Speed sensor, ignition/injection	06.01-05.04	AG	**0 261 210 147**
		GS	**0 261 210 178**
Temperature sensor, intake air, injection system	06.01-05.04		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	06.01-05.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.01-05.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-05.04		**0 265 006 765**
2.4 [4B2; C5]			**2,4 l 115 kW APC 6 Zyl.**
Phase sensor	04.98-04.01		**0 232 101 024**
Speed sensor, ignition/injection	04.98-04.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →4B..X..200 000	04.98-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	04.98-04.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	04.98-04.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	04.98-04.01		**0 265 005 303**
2.4 [4B2; C5]			**2,4 l 120 kW AJG; ALF 6 Zyl.**
Phase sensor	04.97-01.99		**0 232 101 024**
Speed sensor, ignition/injection	04.97-01.99	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	04.97-01.99		**0 261 231 036**
Temperature sensor, intake air, injection system	04.97-01.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	04.97-01.99		**0 265 005 214**
2.4 [4B2; C5]			**2,4 l 120 kW AMM 6 Zyl.**
Throttle valve assembly	06.01-05.04		**0 280 750 030**
Phase sensor	06.01-05.04		**0 232 101 024**
Speed sensor, ignition/injection	06.01-05.04	AG	**0 261 210 147**
		GS	**0 261 210 178**
Temperature sensor, intake air, injection system	06.01-05.04		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	06.01-05.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.01-05.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-05.04		**0 265 006 765**
2.4 [4B2; C5]			**2,4 l 120 kW APZ 6 Zyl.**
Throttle valve assembly	11.98-05.00		**0 280 750 030**
Phase sensor	11.98-05.00		**0 232 101 024**
Speed sensor, ignition/injection	11.98-05.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →4B..X..200 000	11.98-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	11.98-05.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	11.98-05.00		**0 265 005 214**
2.4 [4B2; C5]			**2,4 l 121 kW AGA 6 Zyl.**
Phase sensor	04.97-01.99		**0 232 101 024**
Speed sensor, ignition/injection	04.97-01.99	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	04.97-01.99		**0 261 231 036**
Temperature sensor, intake air, injection system	04.97-01.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	04.97-01.99		**0 265 005 214**
2.4 [4B2; C5]			**2,4 l 121 kW AML 6 Zyl.**
Throttle valve assembly	06.00-04.01		**0 280 750 030**
Phase sensor	06.00-04.01		**0 232 101 024**

A

Product			
◀ A6			
Speed sensor, ignition/injection	06.00-04.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Temperature sensor, intake air, injection system	06.00-04.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	06.00-04.01		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.00-04.01		**0 265 005 303**
2.4 [4B2; C5]		**2,4 l 121 kW APS; ARJ 6 Zyl.**	
Throttle valve assembly	11.98-04.01		**0 280 750 030**
Phase sensor	11.98-04.01		**0 232 101 024**
Speed sensor, ignition/injection	11.98-04.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →4B..X..200 000	11.98-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	11.98-04.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	11.98-04.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	11.98-04.01		**0 265 005 303**
2.4 [4B2; C5]		**2,4 l 125 kW BDV 6 Zyl.**	
Throttle valve assembly	06.01-05.04		**0 280 750 030**
Phase sensor	06.01-05.04		**0 232 101 024**
Speed sensor, ignition/injection	06.01-05.04	AG	**0 261 210 147**
		GS	**0 261 210 178**
Temperature sensor, intake air, injection system	06.01-05.04		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	06.01-05.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.01-05.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-05.04		**0 265 006 765**
2.4 [4F2; C6]		**2,4 l 130 kW BDW 6 Zyl.**	
Throttle valve assembly	04.04→		**0 280 750 003**
Pressure sensor, intake manifold, gasoline	04.04→		**0 261 230 095**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	04.04-05.06		**0 265 005 692**
Fg.no. 4F..7..000 001→	06.06→		**0 265 005 619**
Wheel speed sensor			
Fg.no. →4F..5..085 230	04.04-12.04	LAB	**0 265 007 728**
Fg.no. 4F..6..140 001→	02.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
2.4 quattro [4B2; C5]		**2,4 l 115 kW APC 6 Zyl.**	
Phase sensor	08.98-07.99		**0 232 101 024**
Speed sensor, ignition/injection	08.98-07.99	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →4B..X..200 000	08.98-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	08.98-07.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-07.99		**0 265 005 214**
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	08.98-10.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-07.99	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.4 quattro [4B2; C5]		**2,4 l 120 kW AJG 6 Zyl.**	
Phase sensor	06.97-01.99		**0 232 101 024**
Speed sensor, ignition/injection	06.97-01.99	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	06.97-01.99		**0 261 231 036**
Temperature sensor, intake air, injection system	06.97-01.99		**0 280 130 085**

Product			
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-01.99		**0 265 005 214**
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	06.97-10.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-01.99	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.4 quattro [4B2; C5]		**2,4 l 120 kW APZ 6 Zyl.**	
Throttle valve assembly	11.98-05.00		**0 280 750 030**
Phase sensor	11.98-05.00		**0 232 101 024**
Speed sensor, ignition/injection	11.98-05.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →4B..X..200 000	11.98-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	11.98-05.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	11.98-05.00		**0 265 005 214**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-05.00	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.4 quattro [4B2; C5]		**2,4 l 121 kW AGA; ALF 6 Zyl.**	
Phase sensor	04.97-01.99		**0 232 101 024**
Speed sensor, ignition/injection	04.97-01.99	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	04.97-01.99		**0 261 231 036**
Temperature sensor, intake air, injection system	04.97-01.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-01.99		**0 265 005 214**
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	04.97-10.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-01.99	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.4 quattro [4B2; C5]		**2,4 l 121 kW AML 6 Zyl.**	
Throttle valve assembly	06.00-05.01		**0 280 750 030**
Phase sensor	06.00-05.01		**0 232 101 024**
Speed sensor, ignition/injection	06.00-05.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Temperature sensor, intake air, injection system	06.00-05.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	06.00-05.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	06.00-05.01		**0 265 005 303**
Wheel speed sensor, rear	06.00-05.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.4 quattro [4B2; C5]		**2,4 l 121 kW APS 6 Zyl.**	
Phase sensor	11.98-06.99		**0 232 101 024**
Speed sensor, ignition/injection	11.98-06.99	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	11.98-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	11.98-06.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	11.98-06.99		**0 265 005 214**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-06.99	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**

A

Product			
2.4 quattro [4B2; C5]			**2,4 l 121 kW ARJ 6 Zyl.**
Throttle valve assembly	11.98-05.01		**0 280 750 030**
Phase sensor	11.98-05.01		**0 232 101 024**
Speed sensor, ignition/injection	11.98-05.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →4B..X..200 000	11.98-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	11.98-05.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	11.98-05.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	11.98-05.01		**0 265 005 303**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-05.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.4 quattro [4B2; C5]			**2,4 l 125 kW BDV 6 Zyl.**
Throttle valve assembly	06.01-05.04		**0 280 750 030**
Phase sensor	06.01-05.04		**0 232 101 024**
Speed sensor, ignition/injection	06.01-05.04	AG	**0 261 210 147**
		GS	**0 261 210 178**
Temperature sensor, intake air, injection system	06.01-05.04		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	06.01-05.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.01-05.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-05.04		**0 265 006 765**
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	06.01-12.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
Fg.no. 4B..2..079 501→	12.01-05.04	ALR,LAB	**0 265 006 763**
		ALR,RAB	**0 265 006 761**
		OLW	**0 265 006 761**
2.4 quattro [4F2; C6]			**2,4 l 130 kW BDW 6 Zyl.**
Throttle valve assembly	01.05→		**0 280 750 003**
Pressure sensor, intake manifold, gasoline	01.05→		**0 261 230 095**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	01.05-05.06		**0 265 005 692**
Fg.no. 4F..7..000 001→	06.06→		**0 265 005 619**
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
2.5 TDI [4A2; C4]			**2,5 l 85/103 kW AAT; AEL 5 Zyl.**
Air mass meter, diesel	06.94-10.97		**0 281 002 074**
Pedal position sensor, diesel			
Fg.no. →4A..S..082 000	06.94-02.95	AG	**0 205 001 018**
		GS	**0 205 001 017**
Fg.no. 4A..S..082 001→	02.95-10.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
2.5 TDI [4B2; C5]			**2,5 l 110 kW AFB 6 Zyl.**
Air mass meter, diesel	04.97-05.00		**0 281 002 429**
			0 986 284 005
Speed sensor, diesel	04.97-05.00		**0 281 002 222**
Pressure sensor, intake manifold, diesel	04.97-05.00		**0 281 002 326**
Pedal position sensor, diesel			
Fg.no. →4B..X..200 000	04.97-06.99	AG	**0 281 002 289**
		GS	**0 281 002 286**
Duo sensor, acceleration and yaw rate, brake system	04.97-05.00		**0 265 005 214**

Product			
2.5 TDI [4B2; C5]			**2,5 l 110 kW AKN 6 Zyl.**
Air mass meter, diesel	11.98-06.99		**0 281 002 429**
			0 986 284 005
Speed sensor, diesel	11.98-06.99		**0 281 002 222**
Pressure sensor, intake manifold, diesel	11.98-06.99		**0 281 002 326**
Pedal position sensor, diesel	11.98-06.99	AG	**0 281 002 289**
		GS	**0 281 002 286**
Duo sensor, acceleration and yaw rate, brake system	11.98-06.99		**0 265 005 214**
2.5 TDI [4B2; C5]			**2,5 l 114 kW AYM 6 Zyl.**
Speed sensor, diesel	06.01-06.02		**0 281 002 222**
Pressure sensor, intake manifold, diesel	06.01-06.02		**0 281 002 326**
Duo sensor, acceleration and yaw rate, brake system	06.01-06.02		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.01-06.02		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→	09.01-06.02		**0 265 006 578**
2.5 TDI [4B2; C5]			**2,5 l 120 kW BCZ; BDG; BFC 6 Zyl.**
Speed sensor, diesel	07.02-05.04		**0 281 002 222**
Pressure sensor, intake manifold, diesel	07.02-05.04		**0 281 002 326**
Duo sensor, acceleration and yaw rate, brake system	07.02-05.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	07.02-05.04		**0 265 005 303**
Wheel speed sensor, front	07.02-05.04		**0 265 006 765**
2.5 TDI [4B2; C5]			**2,5 l 132 kW AKE 6 Zyl.**
Speed sensor, diesel	10.99-08.03		**0 281 002 222**
Pressure sensor, intake manifold, diesel	10.99-08.03		**0 281 002 326**
Duo sensor, acceleration and yaw rate, brake system	10.99-05.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	10.99-08.03		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-08.03		**0 265 006 765**
2.5 TDI [4B2; C5]			**2,5 l 132 kW BAU; BDH 6 Zyl.**
Speed sensor, diesel	11.02-05.04		**0 281 002 222**
Pressure sensor, intake manifold, diesel	11.02-05.04		**0 281 002 326**
Duo sensor, acceleration and yaw rate, brake system	11.02-05.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	11.02-05.04		**0 265 005 303**
Wheel speed sensor, front	11.02-05.04		**0 265 006 765**
2.5 TDI quattro [4A2; C4]			**2,5 l 103 kW AEL 5 Zyl.**
Air mass meter, diesel	07.95-10.97		**0 281 002 074**
Pedal position sensor, diesel	07.95-10.97		**0 205 001 032**
2.5 TDI quattro [4B2; C5]			**2,5 l 110 kW AFB 6 Zyl.**
Air mass meter, diesel	07.97-05.00		**0 281 002 429**
			0 986 284 005
Speed sensor, diesel	07.97-05.00		**0 281 002 222**
Pressure sensor, intake manifold, diesel	07.97-05.00		**0 281 002 326**
Pedal position sensor, diesel			
Fg.no. →4B..X..200 000	07.97-06.99	AG	**0 281 002 289**
		GS	**0 281 002 286**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-05.00		**0 265 005 214**
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	07.97-10.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-05.00	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**

A

Product			
◀ A6			
2.5 TDI quattro [4B2; C5]		**2,5 l 110 kW AKN 6 Zyl.**	
Air mass meter, diesel	11.98-06.99		**0 281 002 429**
			0 986 284 005
Speed sensor, diesel	11.98-06.99		**0 281 002 222**
Pressure sensor, intake manifold, diesel	11.98-06.99		**0 281 002 326**
Pedal position sensor, diesel	11.98-06.99	AG	**0 281 002 289**
		GS	**0 281 002 286**
Duo sensor, acceleration and yaw rate, brake system	11.98-06.99		**0 265 005 214**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-06.99	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.5 TDI quattro [4B2; C5]		**2,5 l 132 kW AKE 6 Zyl.**	
Speed sensor, diesel	10.99-08.03		**0 281 002 222**
Pressure sensor, intake manifold, diesel	10.99-08.03		**0 281 002 326**
Duo sensor, acceleration and yaw rate, brake system	10.99-05.01		**0 265 005 214**
	06.01-08.03		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.99-08.03		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-08.03		**0 265 006 765**
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	10.99-12.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
Fg.no. 4B..2..079 501→	12.01-08.03	ALR,LAB	**0 265 006 763**
		ALR,RAB	**0 265 006 761**
		OLW	**0 265 006 761**
2.5 TDI quattro [4B2; C5]		**2,5 l 132 kW BAU; BDH 6 Zyl.**	
Speed sensor, diesel	02.03-05.04		**0 281 002 222**
Pressure sensor, intake manifold, diesel	02.03-05.04		**0 281 002 326**
Duo sensor, acceleration and yaw rate, brake system	02.03-05.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	02.03-05.04		**0 265 005 303**
Wheel speed sensor, front	02.03-05.04		**0 265 006 765**
Wheel speed sensor, rear	02.03-05.04	ALR,LAB	**0 265 006 763**
		ALR,RAB	**0 265 006 761**
		OLW	**0 265 006 761**
2.6 [4A2; C4]		**2,6 l 102 kW ACZ 6 Zyl.**	
Throttle valve sensor	06.94-10.97		**0 280 120 431**
Phase sensor	06.94-10.97		**0 232 101 027**
Temperature sensor, intake air, injection system	06.94-10.97	KZS	**0 280 130 060**
2.6 [4A2; C4]		**2,6 l 110 kW ABC 6 Zyl.**	
Throttle valve sensor	06.94-10.97		**0 280 120 431**
Phase sensor	06.94-10.97		**0 232 101 027**
Knock sensor	06.94-10.97		**0 261 231 036**
Temperature sensor, intake air, injection system	06.94-10.97	KZS	**0 280 130 060**
2.6 i [4A2; C4]		**2,6 l 110 kW ABC 6 Zyl.**	
Throttle valve sensor	06.94-12.97		**0 280 120 431**
Knock sensor	06.94-12.97		**0 261 231 036**
Temperature sensor, coolant, injection system	06.94-12.97	ABM	**0 280 130 040**
2.6 quattro [4A2; C4]		**2,6 l 102/110 kW ABC; ACZ 6 Zyl.**	
Throttle valve sensor	06.94-10.97		**0 280 120 431**
Phase sensor	06.94-10.97		**0 232 101 027**
Knock sensor	06.94-10.97		**0 261 231 036**
Temperature sensor, intake air, injection system	06.94-10.97	KZS	**0 280 130 060**
2.7 Biturbo [4B2; C5]		**2,7 l 169 kW AJK 6 Zyl.**	
Throttle valve assembly	02.99-05.01		**0 280 750 003**
Air mass meter, gasoline injection	02.99-05.01		**0 280 218 038**
			0 986 280 212
Phase sensor	02.99-05.01		**0 232 101 024**
Speed sensor, ignition/injection	02.99-05.01	GS	**0 261 210 147**
Fg.no. →4B..1..006 637	02.99-05.00	AG	**0 281 002 222**
Fg.no. 4B..1..006 638→	06.00-05.01	AG	**0 261 210 217**
Knock sensor			
Fg.no. →4B..X..200 000	02.99-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	02.99-05.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	02.99-05.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	02.99-05.01		**0 265 005 303**
2.7 Biturbo quattro [4B2; C5]		**2,7 l 169 kW AJK 6 Zyl.**	
Air mass meter, gasoline injection	10.97-08.00		**0 280 218 038**
			0 986 280 212
Phase sensor	10.97-08.00		**0 232 101 024**
Speed sensor, ignition/injection	10.97-08.00	GS	**0 261 210 147**
Fg.no. →4B..1..006 637	10.97-05.00	AG	**0 281 002 222**
Fg.no. 4B..1..006 638→	06.00-08.00	AG	**0 261 210 217**
Knock sensor			
Fg.no. →4B..X..200 000	10.97-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	10.97-08.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-08.00		**0 265 005 214**
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	10.97-10.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-08.00	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.7 Biturbo quattro [4B2; C5]		**2,7 l 169 kW AZA 6 Zyl.**	
Throttle valve assembly	09.00-05.01		**0 280 750 003**
Speed sensor, ignition/injection	09.00-05.01	AG	**0 261 210 217**
		GS	**0 261 210 147**
Temperature sensor, intake air, injection system	09.00-05.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	09.00-05.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	09.00-05.01		**0 265 005 303**
Wheel speed sensor, rear	09.00-05.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.7 Biturbo quattro [4B2; C5]		**2,7 l 184 kW ARE 6 Zyl.**	
Throttle valve assembly	06.01-06.02		**0 280 750 003**
Phase sensor	06.01-06.02		**0 232 101 024**
Speed sensor, ignition/injection	06.01-06.02	AG	**0 261 210 217**
		GS	**0 261 210 147**
Temperature sensor, intake air, injection system	06.01-06.02		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	06.01-06.02		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.01-06.02		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→	09.01-06.02		**0 265 006 578**
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	06.01-12.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
Fg.no. 4B..2..079 501→	12.01-06.02	ALR,LAB	**0 265 006 763**
		ALR,RAB	**0 265 006 761**
		OLW	**0 265 006 761**
2.7 Biturbo quattro [4B2; C5]		**2,7 l 184 kW BES 6 Zyl.**	
Throttle valve assembly	07.02-05.04		**0 280 750 003**
Phase sensor	07.02-05.04		**0 232 101 024**
Speed sensor, ignition/injection	07.02-05.04	AG	**0 261 210 217**
		GS	**0 261 210 147**
Temperature sensor, intake air, injection system	07.02-05.04		**0 280 130 085**

A

Product			
Duo sensor, acceleration and yaw rate, brake system	07.02-05.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	07.02-05.04		**0 265 005 303**
Wheel speed sensor, front	07.02-05.04		**0 265 006 765**
Wheel speed sensor, rear	07.02-05.04	ALR,LAB	**0 265 006 763**
		ALR,RAB	**0 265 006 761**
		OLW	**0 265 006 761**
2.7 Biturbo quattro [4B2; C5]			**2,7 l 187 kW BEL 6 Zyl.**
Throttle valve assembly	07.02-07.04		**0 280 750 003**
Phase sensor	07.02-07.04		**0 232 101 024**
Speed sensor, ignition/injection	07.02-07.04	AG	**0 261 210 217**
		GS	**0 261 210 147**
Temperature sensor, intake air, injection system	07.02-07.04		**0 280 130 116**
Duo sensor, acceleration and yaw rate, brake system	07.02-07.04		**0 265 005 252**
Wheel speed sensor, front	07.02-07.04		**0 265 006 765**
Wheel speed sensor, rear	07.02-07.04	ALR,LAB	**0 265 006 763**
		ALR,RAB	**0 265 006 761**
		OLW	**0 265 006 761**
2.7 quattro [4B2; C5]			**2,7 l 187 kW APB 6 Zyl.**
Throttle valve assembly	06.01-06.02		**0 280 750 003**
Phase sensor	06.01-06.02		**0 232 101 024**
Speed sensor, ignition/injection	06.01-06.02	AG	**0 261 210 217**
		GS	**0 261 210 147**
Temperature sensor, intake air, injection system	06.01-06.02		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	06.01-06.02		**0 265 005 252**
Wheel speed sensor, front	06.01-06.02	B17,B18	**0 265 006 578**
Wheel speed sensor, rear	06.01-06.02	OLW	**0 265 006 761**
Fg.no. →4B..2..079 500	06.01-12.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
Fg.no. 4B..2..079 501→	12.01-06.02	ALR,LAB	**0 265 006 763**
		ALR,RAB	**0 265 006 761**
		OLW	**0 265 006 761**
2.7 TDI [4F2; C6]			**2,7 l 120/132 kW BPP; BSG 6 Zyl.**
Speed sensor, diesel	11.04→	FKW	**0 261 210 145**
High-pressure sensor (CR system)			
Fg.no. →4F..6..132 000	11.04-12.05		**0 281 002 504**
Boost pressure sensor, Diesel	11.04→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	11.04-05.06		**0 265 005 692**
Fg.no. 4F..7..000 001→	06.06→		**0 265 005 619**
Wheel speed sensor			
Fg.no. →4F..5..085 230	11.04-12.04	LAB	**0 265 007 728**
Fg.no. 4F..6..140 001→	02.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
2.7 TDI quattro [4F2; C6]			**2,7 l 120/132 kW BPP; BSG 6 Zyl.**
Speed sensor, diesel	06.05→	FKW	**0 261 210 145**
High-pressure sensor (CR system)			
Fg.no. →4F..6..132 000	06.05-12.05		**0 281 002 504**
Boost pressure sensor, Diesel	06.05→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	06.05-05.06		**0 265 005 692**
Fg.no. 4F..7..000 001→	06.06→		**0 265 005 619**
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**

Product			
2.8 [C5]			**2,8 l 140 kW ATX 6 Zyl.**
Throttle valve assembly	09.99-09.05		**0 280 750 030**
Speed sensor, ignition/injection	09.99-09.05	AG,FKW	**0 261 210 147**
		FKW,GS	**0 261 210 178**
Temperature sensor, intake air, injection system	09.99-09.05		**0 280 130 085**
2.8 [4A2; C4]			**2,8 l 120 kW AEJ 6 Zyl.**
Throttle valve sensor	09.94-10.97		**0 280 120 431**
2.8 [4A2; C4]			**2,8 l 128 kW AAH 6 Zyl.**
Throttle valve sensor	06.94-10.97		**0 280 120 431**
Phase sensor	06.94-10.97		**0 232 101 027**
Knock sensor	06.94-10.97		**0 261 231 036**
2.8 [4A2; C4]			**2,8 l 142 kW ACK 6 Zyl.**
Throttle valve sensor	10.95-10.97		**0 280 120 431**
Phase sensor	10.95-10.97		**0 232 101 024**
Speed sensor, ignition/injection	10.95-10.97		**0 261 210 139**
Knock sensor	10.95-10.97		**0 261 231 036**
Temperature sensor, intake air, injection system	10.95-10.97	KZS	**0 280 130 060**
2.8 [4B2; C5]			**2,8 l 132 kW AGE 6 Zyl.**
Phase sensor	10.97-05.00		**0 232 101 024**
Speed sensor, ignition/injection	10.97-05.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →4B..X..200 000	10.97-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	10.97-05.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	10.97-05.00		**0 265 005 214**
2.8 [4B2; C5]			**2,8 l 140 kW ATX 6 Zyl.**
Throttle valve assembly	07.99-04.01		**0 280 750 030**
Phase sensor	07.99-04.01		**0 232 101 024**
Speed sensor, ignition/injection	07.99-04.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Temperature sensor, intake air, injection system	07.99-04.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	07.99-04.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	07.99-04.01		**0 265 005 303**
2.8 [4B2; C5]			**2,8 l 142 kW ACK 6 Zyl.**
Phase sensor	04.97-07.98		**0 232 101 024**
Speed sensor, ignition/injection	04.97-07.98	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	04.97-07.98		**0 261 231 036**
Temperature sensor, intake air, injection system	04.97-07.98		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	04.97-07.98		**0 265 005 214**
2.8 [4B2; C5]			**2,8 l 142 kW AHA 6 Zyl.**
Phase sensor	08.97-07.98		**0 232 101 024**
Speed sensor, ignition/injection	08.97-07.98	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	08.97-07.98		**0 261 231 036**
Duo sensor, acceleration and yaw rate, brake system	08.97-07.98		**0 265 005 214**
2.8 [4B2; C5]			**2,8 l 142 kW ALG 6 Zyl.**
Phase sensor	06.97-01.99		**0 232 101 024**
Speed sensor, ignition/injection	06.97-01.99	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	06.97-01.99		**0 261 231 036**
Temperature sensor, intake air, injection system	06.97-01.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	06.97-01.99		**0 265 005 214**
2.8 [4B2; C5]			**2,8 l 142 kW AMX 6 Zyl.**
Throttle valve assembly	06.00-04.01		**0 280 750 030**
Phase sensor	06.00-04.01		**0 232 101 024**
Speed sensor, ignition/injection	06.00-04.01	AG	**0 261 210 147**
		GS	**0 261 210 178**

A

Product			
◀ A6			
Temperature sensor, intake air, injection system	06.00-04.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	06.00-04.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	06.00-04.01		**0 265 005 303**
2.8 [4B2; C5]		**2,8 l 142 kW APR; AQD 6 Zyl.**	
Throttle valve assembly	11.98-04.01		**0 280 750 030**
Phase sensor	11.98-04.01		**0 232 101 024**
Speed sensor, ignition/injection	11.98-04.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →4B..X..200 000	11.98-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	11.98-04.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	11.98-04.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	11.98-04.01		**0 265 005 303**
2.8 [4B2; C5]		**2,8 l 142 kW ATQ 6 Zyl.**	
Phase sensor	08.99-04.01		**0 232 101 024**
Speed sensor, ignition/injection	08.99-04.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	08.99-04.01		**0 261 231 036**
Duo sensor, acceleration and yaw rate, brake system	08.99-04.01		**0 265 005 214**
2.8 FSI [4F2; C6]		**2,8 l 154 kW BDX 6 Zyl.**	
Pressure sensor, intake manifold, gasoline	11.06→		**0 261 230 095**
Duo sensor, acceleration and yaw rate, brake system	11.06→		**0 265 005 619**
Wheel speed sensor	11.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
2.8 FSI quattro [4F2, C6]		**2,8 l 154 kW BDX 6 Zyl.**	
Pressure sensor, intake manifold, gasoline	11.06→		**0 261 230 095**
Duo sensor, acceleration and yaw rate, brake system	11.06→		**0 265 005 619**
Wheel speed sensor	11.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
2.8 i [4A2; C4]		**2,8 l 128 kW AAH 6 Zyl.**	
Knock sensor	06.94-12.97		**0 261 231 036**
Temperature sensor, coolant, injection system	06.94-12.97	ABM	**0 280 130 040**
2.8 quattro [4A2; C4]		**2,8 l 120 kW AEJ 6 Zyl.**	
Throttle valve sensor	07.95-10.97		**0 280 120 431**
Knock sensor	07.95-10.97		**0 261 231 036**
2.8 quattro [4A2; C4]		**2,8 l 128 kW AAH 6 Zyl.**	
Throttle valve sensor	06.94-10.97		**0 280 120 431**
Phase sensor	06.94-10.97		**0 232 101 027**
Knock sensor	06.94-10.97		**0 261 231 036**
2.8 quattro [4A2; C4]		**2,8 l 142 kW ACK 6 Zyl.**	
Throttle valve sensor	10.95-10.97		**0 280 120 431**
Phase sensor	10.95-10.97		**0 232 101 024**
Speed sensor, ignition/injection	10.95-10.97		**0 261 210 139**
Knock sensor	10.95-10.97		**0 261 231 036**
Temperature sensor, intake air, injection system	10.95-10.97	KZS	**0 280 130 060**
2.8 quattro [4B2; C5]		**2,8 l 132 kW AGE 6 Zyl.**	
Phase sensor	04.98-05.00		**0 232 101 024**
Speed sensor, ignition/injection	04.98-05.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →4B..X..200 000	04.98-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	04.98-05.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-05.00		**0 265 005 214**
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	04.98-10.98		**0 265 005 207**

Product			
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-05.00	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.8 quattro [4B2; C5]		**2,8 l 140 kW ATX 6 Zyl.**	
Throttle valve assembly	07.99-05.01		**0 280 750 030**
Phase sensor	07.99-05.01		**0 232 101 024**
Speed sensor, ignition/injection	07.99-05.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Temperature sensor, intake air, injection system	07.99-05.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	07.99-05.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	07.99-05.01		**0 265 005 303**
Wheel speed sensor, rear	07.99-05.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.8 quattro [4B2; C5]		**2,8 l 142 kW ACK 6 Zyl.**	
Phase sensor	04.97-12.98		**0 232 101 024**
Speed sensor, ignition/injection	04.97-12.98	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	04.97-12.98		**0 261 231 036**
Temperature sensor, intake air, injection system	04.97-12.98		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-12.98		**0 265 005 214**
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	04.97-10.98		**0 265 005 207**
2.8 quattro [4B2; C5]		**2,8 l 142 kW ALG 6 Zyl.**	
Phase sensor	06.97-01.99		**0 232 101 024**
Speed sensor, ignition/injection	06.97-01.99	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	06.97-01.99		**0 261 231 036**
Temperature sensor, intake air, injection system	06.97-01.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-01.99		**0 265 005 214**
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	06.97-10.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-01.99	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.8 quattro [4B2; C5]		**2,8 l 142 kW AMX 6 Zyl.**	
Throttle valve assembly	06.00-05.01		**0 280 750 030**
Phase sensor	06.00-05.01		**0 232 101 024**
Speed sensor, ignition/injection	06.00-05.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	06.00-05.01		**0 261 231 036**
Temperature sensor, intake air, injection system	06.00-05.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	06.00-05.01		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.00-05.01		**0 265 005 303**
Wheel speed sensor, rear	06.00-05.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.8 quattro [4B2; C5]		**2,8 l 142 kW APR 6 Zyl.**	
Throttle valve assembly	01.99-05.01		**0 280 750 030**
Phase sensor	01.99-05.01		**0 232 101 024**
Speed sensor, ignition/injection	01.99-05.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →4B..X..200 000	01.99-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	01.99-05.01		**0 280 130 085**

Product			
Duo sensor, acceleration and yaw rate, brake system	01.99-05.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	01.99-05.01		**0 265 005 303**
Wheel speed sensor, rear	01.99-05.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.8 quattro [4B2; C5]		**2,8 l 142 kW AQD 6 Zyl.**	
Throttle valve assembly	11.98-05.01		**0 280 750 030**
Phase sensor	11.98-05.01		**0 232 101 024**
Speed sensor, ignition/injection	11.98-05.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →4B..X..200 000	11.98-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	11.98-05.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	11.98-05.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	11.98-05.01		**0 265 005 303**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-05.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
3.0 [4B2; C5]		**3,0 l 160 kW BBJ 6 Zyl.**	
Throttle valve assembly	06.01-05.04		**0 280 750 030**
Phase sensor	06.01-05.04		**0 232 101 024**
Speed sensor, ignition/injection	06.01-05.04	AG	**0 261 210 147**
		GS	**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system	06.01-05.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.01-05.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-05.04		**0 265 006 765**
3.0 [4B2; C5]		**3,0 l 162 kW ASN 6 Zyl.**	
Throttle valve assembly	06.01-05.04		**0 280 750 030**
Speed sensor, ignition/injection	06.01-05.04	AG	**0 261 210 147**
		GS	**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system	06.01-05.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.01-05.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-05.04		**0 265 006 765**
3.0 [4B2; C5]		**3,0 l 162 kW AVK 6 Zyl.**	
Throttle valve assembly	06.01-07.04		**0 280 750 030**
Speed sensor, ignition/injection	06.01-07.04		**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system	06.01-07.04		**0 265 005 252**
Wheel speed sensor, front			
Fg.no. →4B..2..031 500	06.01-06.02	B17,B18	**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-07.04		**0 265 006 765**
3.0 [4F2; C6]		**3,0 l 160 kW BBJ 6 Zyl.**	
Throttle valve assembly	04.04-05.06		**0 280 750 030**
Duo sensor, acceleration and yaw rate, brake system	04.04-05.06		**0 265 005 692**
Wheel speed sensor			
Fg.no. →4F..5..085 230	04.04-12.04	LAB	**0 265 007 728**
Fg.no. 4F..6..140 001→	02.06-05.06	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
3.0 quattro [4B2; C5]		**3,0 l 160 kW BBJ 6 Zyl.**	
Throttle valve assembly	06.01-05.04		**0 280 750 030**
Phase sensor	06.01-05.04		**0 232 101 024**
Speed sensor, ignition/injection	06.01-05.04	AG	**0 261 210 147**
		GS	**0 261 210 178**

Product			
Duo sensor, acceleration and yaw rate, brake system	06.01-05.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.01-05.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-05.04		**0 265 006 765**
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	06.01-12.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
Fg.no. 4B..2..079 501→	12.01-05.04	ALR,LAB	**0 265 006 763**
		ALR,RAB	**0 265 006 761**
		OLW	**0 265 006 761**
3.0 quattro [4B2; C5]		**3,0 l 162 kW ASN 6 Zyl.**	
Throttle valve assembly	06.01-05.04		**0 280 750 030**
Speed sensor, ignition/injection	06.01-05.04	AG	**0 261 210 147**
		GS	**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system	06.01-05.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.01-05.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-05.04		**0 265 006 765**
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	06.01-12.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
Fg.no. 4B..2..079 501→	12.01-05.04	ALR,LAB	**0 265 006 763**
		ALR,RAB	**0 265 006 761**
		OLW	**0 265 006 761**
3.0 quattro [4F2; C6]		**3,0 l 160 kW BBJ 6 Zyl.**	
Throttle valve assembly	04.04-05.06		**0 280 750 030**
Duo sensor, acceleration and yaw rate, brake system	04.04-05.06		**0 265 005 692**
Wheel speed sensor			
Fg.no. →4F..5..085 230	04.04-12.04	LAB	**0 265 007 728**
Fg.no. 4F..6..140 001→	02.06-05.06	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
3.0 TDI quattro [4F2; C6]		**3,0 l 155 kW BNG 6 Zyl.**	
Speed sensor, diesel	04.04→	FKW	**0 261 210 145**
High-pressure sensor (CR system)			
Fg.no. →4F..6..132 000	04.04-12.05		**0 281 002 504**
Boost pressure sensor, Diesel	04.04→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	04.04-05.06		**0 265 005 692**
Fg.no. 4F..7..000 001→	06.06→		**0 265 005 619**
Wheel speed sensor			
Fg.no. →4F..5..085 230	04.04-12.04	LAB	**0 265 007 728**
Fg.no. 4F..6..140 001→	02.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
3.0 TDI quattro [4F2; C6]		**3,0 l 165 kW BMK 6 Zyl.**	
Speed sensor, diesel	04.04-05.06	FKW	**0 261 210 145**
High-pressure sensor (CR system)			
Fg.no. →4F..6..132 000	04.04-12.05		**0 281 002 504**
Boost pressure sensor, Diesel	04.04-05.06		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	04.04-05.06		**0 265 005 692**
Wheel speed sensor			
Fg.no. →4F..5..085 230	04.04-12.04	LAB	**0 265 007 728**
Fg.no. 4F..6..140 001→	02.06-05.06	LAB	**0 265 007 930**
		RAB	**0 265 007 928**

A

Product			
◀ A6			
3.0 TDI quattro [4F2; C6]			**3,0 l 171 kW ASB 6 Zyl.**
Speed sensor, diesel	06.06→	FKW	**0 261 210 145**
Boost pressure sensor, Diesel	06.06→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	06.06→		**0 265 005 619**
Wheel speed sensor	06.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
3.2 FSI [4F2; C6]			**3,2 l 188 kW AUK 6 Zyl.**
Throttle valve assembly	04.04-05.07		**0 280 750 003**
Pressure sensor, intake manifold, gasoline	04.04-05.07		**0 261 230 095**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	04.04-05.06		**0 265 005 692**
Fg.no. 4F..7..000 001→	06.06-05.07		**0 265 005 619**
Wheel speed sensor			
Fg.no. →4F..5..085 230	04.04-12.04	LAB	**0 265 007 728**
Fg.no. 4F..6..140 001→	02.06-05.07	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
3.2 FSI quattro [4F2; C6]			**3,2 l 188 kW AUK 6 Zyl.**
Throttle valve assembly	04.04→		**0 280 750 003**
Pressure sensor, intake manifold, gasoline	04.04→		**0 261 230 095**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	04.04-05.06		**0 265 005 692**
Fg.no. 4F..7..000 001→	06.06→		**0 265 005 619**
Wheel speed sensor			
Fg.no. →4F..5..085 230	04.04-12.04	LAB	**0 265 007 728**
Fg.no. 4F..6..140 001→	02.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
3.2 FSI quattro [4F2; C6]			**3,2 l 188 kW BKH 6 Zyl.**
Throttle valve assembly	07.05→		**0 280 750 003**
Pressure sensor, intake manifold, gasoline	07.05→		**0 261 230 095**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	07.05-05.06		**0 265 005 692**
Fg.no. 4F..7..000 001→	06.06→		**0 265 005 619**
Wheel speed sensor	07.05→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
3.2 FSI quattro [4F2; C6]			**3,2 l 249 kW BYU 6 Zyl.**
Throttle valve assembly	09.06→		**0 280 750 003**
Pressure sensor, intake manifold, gasoline	09.06→		**0 261 230 095**
Duo sensor, acceleration and yaw rate, brake system	09.06→		**0 265 005 619**
Wheel speed sensor	09.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
4.2 FSI quattro [4F2; C6]			**4,2 l 257 kW BVJ 8 Zyl.**
Throttle valve assembly	06.06→		**0 280 750 003**
Air mass meter, gasoline injection	06.06→		**0 280 218 069**
			0 986 280 220
Duo sensor, acceleration and yaw rate, brake system	06.06→		**0 265 005 619**
Wheel speed sensor	06.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
4.2 quattro [4B4; C5]			**4,2 l 220 kW ARS 8 Zyl.**
Throttle valve assembly	04.99-05.01		**0 280 750 032**
Air mass meter, gasoline injection	04.99-05.01		**0 280 218 015**
			0 986 280 207
Phase sensor	04.99-05.01		**0 232 101 024**
Speed sensor, ignition/injection	04.99-05.01	AG	**0 261 210 190**
		GS	**0 261 210 192**
Knock sensor	04.99-05.01		**0 261 231 038**
Duo sensor, acceleration and yaw rate, brake system	04.99-05.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	04.99-05.01		**0 265 005 303**
Wheel speed sensor, front	04.99-05.01		**0 265 006 578**
Wheel speed sensor, rear	04.99-05.01	LAB	**0 265 006 567**
		RAB	**0 265 006 565**
4.2 quattro [4B4; C5]			**4,2 l 220 kW ASG 8 Zyl.**
Throttle valve assembly	06.00-05.04		**0 280 750 003**
Air mass meter, gasoline injection	06.00-05.04		**0 280 218 069**
			0 986 280 220
Phase sensor	06.00-05.04		**0 232 101 024**
Speed sensor, ignition/injection	06.00-05.04	AG	**0 261 210 190**
		GS	**0 261 210 192**
Knock sensor	06.00-05.04		**0 261 231 038**
Duo sensor, acceleration and yaw rate, brake system	06.00-05.01		**0 265 005 214**
	06.01-05.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.00-05.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →4B..2..200 000	06.00-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-05.04		**0 265 006 765**
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	06.00-12.01	LAB	**0 265 006 567**
		RAB	**0 265 006 565**
Fg.no. 4B..2..079 501→	12.01-05.04	LAB	**0 265 006 769**
	01.02-05.04	RAB	**0 265 006 767**
4.2 quattro [4B4; C5]			**4,2 l 220 kW AWN 8 Zyl.**
Throttle valve assembly	06.01-07.04		**0 280 750 003**
Air mass meter, gasoline injection	06.01-07.04		**0 280 218 069**
			0 986 280 220
Phase sensor	06.01-07.04		**0 232 101 024**
Speed sensor, ignition/injection	06.01-07.04		**0 261 210 190**
Knock sensor	06.01-07.04		**0 261 231 038**
Duo sensor, acceleration and yaw rate, brake system	06.01-07.04		**0 265 005 252**
Wheel speed sensor, front			
Fg.no. →4B..2..031 500	06.01-08.01		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-07.04		**0 265 006 765**
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	06.01-12.01	LAB	**0 265 006 567**
		RAB	**0 265 006 565**
Fg.no. 4B..2..079 501→	12.01-07.04	LAB	**0 265 006 769**
	01.02-07.04	RAB	**0 265 006 767**
4.2 quattro [4F2; C6]			**4,2 l 246 kW BAT 8 Zyl.**
Throttle valve assembly	04.04-05.06		**0 280 750 003**
Air mass meter, gasoline injection	04.04-05.06		**0 280 218 069**
			0 986 280 220
Speed sensor, ignition/injection	04.04-05.06		**0 261 210 190**
Duo sensor, acceleration and yaw rate, brake system	04.04-05.06		**0 265 005 692**
Wheel speed sensor			
Fg.no. →4F..5..085 230	04.04-12.04	LAB	**0 265 007 728**
Fg.no. 4F..6..140 001→	02.06-05.06	LAB	**0 265 007 930**
		RAB	**0 265 007 928**

A6 Avant

1.8 [4A5; C4]			**1,8 l 92 kW ADR 4 Zyl.**
Phase sensor	10.95-10.97		**0 232 101 024**
Knock sensor	10.95-10.97	LLE	**0 261 231 038**
		RLE	**0 261 231 036**
Temperature sensor, intake air, injection system	10.95-10.97		**0 280 130 085**
1.8 [4B5; C5]			**1,8 l 85 kW AFY 4 Zyl.**
Phase sensor	02.98-05.00		**0 232 101 024**
Knock sensor	02.98-05.00	HI	**0 261 231 036**
		VO	**0 261 231 038**

Product			
Temperature sensor, intake air, injection system	02.98-05.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	02.98-05.00		**0 265 005 214**
1.8 [4B5; C5]			**1,8 l 92 kW AJP 4 Zyl.**
Phase sensor	02.98-04.99		**0 232 101 024**
Speed sensor, ignition/injection	02.98-04.99		**0 261 210 147**
Knock sensor	02.98-04.99	HI	**0 261 231 036**
		VO	**0 261 231 038**
Temperature sensor, intake air, injection system	02.98-04.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	02.98-04.99		**0 265 005 214**
1.8 [4B5; C5]			**1,8 l 92 kW AQE; ARH 4 Zyl.**
Throttle valve assembly			
Fg.no. 4B..X..124 001→	05.99-04.01		**0 280 750 080**
Air mass meter, gasoline injection	01.99-04.01		**0 280 218 013**
			0 986 280 206
Phase sensor	01.99-04.01		**0 232 101 024**
Speed sensor, ignition/injection	01.99-04.01		**0 261 210 147**
Knock sensor	01.99-04.01	HI	**0 261 231 036**
		VO	**0 261 231 038**
Temperature sensor, intake air, injection system	01.99-04.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.99-04.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	01.99-04.01		**0 265 005 303**
1.8 quattro [4A5; C4]			**1,8 l 92 kW ADR 4 Zyl.**
Phase sensor	07.96-10.97		**0 232 101 024**
Knock sensor	07.96-10.97	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
1.8 T [4B5; C5]			**1,8 l 110 kW AEB 4 Zyl.**
Air mass meter, gasoline injection	02.98-01.99		**0 280 217 117**
			0 986 280 201
Phase sensor	02.98-01.99		**0 232 101 024**
Knock sensor	02.98-01.99	HI	**0 261 231 036**
		VO	**0 261 231 038**
Pressure sensor, intake manifold, gasoline	02.98-01.99		**0 280 101 001**
Boost pressure sensor, gasoline	02.98-01.99		**0 281 002 177**
Temperature sensor, intake air, injection system	02.98-01.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	02.98-01.99		**0 265 005 214**
1.8 T [4B5; C5]			**1,8 l 110 kW ANB 4 Zyl.**
Throttle valve assembly	01.99-09.00		**0 280 750 009**
Air mass meter, gasoline injection	01.99-09.00		**0 280 218 032**
			0 986 280 210
Phase sensor	01.99-09.00		**0 232 101 024**
Knock sensor	01.99-09.00	HI	**0 261 231 036**
		VO	**0 261 231 038**
Boost pressure sensor, gasoline	01.99-09.00		**0 281 002 177**
Temperature sensor, intake air, injection system	01.99-09.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.99-09.00		**0 265 005 214**
1.8 T [4B5; C5]			**1,8 l 110 kW APU 4 Zyl.**
Throttle valve assembly	11.98-04.01		**0 280 750 009**
Air mass meter, gasoline injection	11.98-04.01		**0 280 218 032**
			0 986 280 210
Phase sensor	11.98-04.01		**0 232 101 024**
Knock sensor	11.98-04.01	HI	**0 261 231 036**
		VO	**0 261 231 038**
Boost pressure sensor, gasoline	11.98-04.01		**0 281 002 177**
Temperature sensor, intake air, injection system	11.98-04.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	11.98-04.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	11.98-04.01		**0 265 005 303**

Product			
1.8 T [4B5; C5]			**1,8 l 110 kW ARK 4 Zyl.**
Throttle valve assembly	01.99-05.99		**0 280 750 009**
Air mass meter, gasoline injection	01.99-05.99		**0 280 218 032**
			0 986 280 210
Phase sensor	01.99-05.99		**0 232 101 024**
Knock sensor	01.99-05.99	HI	**0 261 231 036**
		VO	**0 261 231 038**
Boost pressure sensor, gasoline	01.99-05.99		**0 281 002 177**
Temperature sensor, intake air, injection system	01.99-05.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.99-05.99		**0 265 005 214**
1.8 T [4B5; C5]			**1,8 l 110 kW AWT 4 Zyl.**
Throttle valve assembly	05.00-04.01		**0 280 750 009**
Air mass meter, gasoline injection	05.00-04.01		**0 280 218 063**
			0 986 280 217
Phase sensor	05.00-04.01		**0 232 101 024**
Speed sensor, ignition/injection	05.00-04.01		**0 281 002 222**
Knock sensor	05.00-04.01	HI	**0 261 231 036**
		VO	**0 261 231 038**
Boost pressure sensor, gasoline	05.00-04.01		**0 281 002 177**
Temperature sensor, intake air, injection system	05.00-04.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	05.00-04.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	05.00-04.01		**0 265 005 303**
1.8 T [4B5; C5]			**1,8 l 132 kW AJL 4 Zyl.**
Air mass meter, gasoline injection	02.98-10.00		**0 280 217 117**
			0 986 280 201
Phase sensor	02.98-10.00		**0 232 101 024**
Knock sensor	02.98-10.00	HI	**0 261 231 036**
		VO	**0 261 231 038**
Pressure sensor, intake manifold, gasoline	02.98-10.00		**0 280 101 001**
Boost pressure sensor, gasoline	02.98-10.00		**0 281 002 177**
Temperature sensor, intake air, injection system	02.98-10.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	02.98-10.00		**0 265 005 214**
1.8 T quattro [4B5; C5]			**1,8 l 110 kW AEB 4 Zyl.**
Air mass meter, gasoline injection	02.98-01.99		**0 280 217 117**
			0 986 280 201
Phase sensor	02.98-01.99		**0 232 101 024**
Knock sensor	02.98-01.99	HI	**0 261 231 036**
		VO	**0 261 231 038**
Pressure sensor, intake manifold, gasoline	02.98-01.99		**0 280 101 001**
Boost pressure sensor, gasoline	02.98-01.99		**0 281 002 177**
Temperature sensor, intake air, injection system	02.98-01.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-01.99		**0 265 005 214**
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	02.98-10.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-01.99	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
1.8 T quattro [4B5; C5]			**1,8 l 110 kW ANB 4 Zyl.**
Throttle valve assembly	01.99-09.00		**0 280 750 009**
Air mass meter, gasoline injection	01.99-09.00		**0 280 218 032**
			0 986 280 210
Phase sensor	01.99-09.00		**0 232 101 024**
Knock sensor	01.99-09.00	HI	**0 261 231 036**
		VO	**0 261 231 038**
Boost pressure sensor, gasoline	01.99-09.00		**0 281 002 177**
Temperature sensor, intake air, injection system	01.99-09.00		**0 280 130 085**

A

Product			
◀ A6 Avant			
Duo sensor, acceleration and yaw rate, brake system	01.99-09.00		**0 265 005 214**
Wheel speed sensor, rear	01.99-09.00	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
1.8 T quattro [4B5; C5]		**1,8 l 110 kW APU 4 Zyl.**	
Throttle valve assembly	11.98-05.01		**0 280 750 009**
Air mass meter, gasoline injection	11.98-05.01		**0 280 218 032**
			0 986 280 210
Phase sensor	11.98-05.01		**0 232 101 024**
Knock sensor	11.98-05.01	HI	**0 261 231 036**
		VO	**0 261 231 038**
Boost pressure sensor, gasoline	11.98-05.01		**0 281 002 177**
Temperature sensor, intake air, injection system	11.98-05.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	11.98-05.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	11.98-05.01		**0 265 005 303**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-05.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
1.8 T quattro [4B5; C5]		**1,8 l 110 kW ARK 4 Zyl.**	
Throttle valve assembly	01.99-05.99		**0 280 750 009**
Air mass meter, gasoline injection	01.99-05.99		**0 280 218 032**
			0 986 280 210
Phase sensor	01.99-05.99		**0 232 101 024**
Knock sensor	01.99-05.99	HI	**0 261 231 036**
		VO	**0 261 231 038**
Boost pressure sensor, gasoline	01.99-05.99		**0 281 002 177**
Temperature sensor, intake air, injection system	01.99-05.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.99-05.99		**0 265 005 214**
Wheel speed sensor, rear	01.99-05.99	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
1.8 T quattro [4B5; C5]		**1,8 l 110 kW AWT 4 Zyl.**	
Throttle valve assembly	05.00-01.05		**0 280 750 009**
Air mass meter, gasoline injection	05.00-01.05		**0 280 218 063**
			0 986 280 217
Phase sensor	05.00-01.05		**0 232 101 024**
Speed sensor, ignition/injection	05.00-01.05		**0 281 002 222**
Knock sensor	05.00-01.05	HI	**0 261 231 036**
		VO	**0 261 231 038**
Boost pressure sensor, gasoline	05.00-01.05		**0 281 002 177**
Temperature sensor, intake air, injection system	05.00-01.05		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	05.00-05.01		**0 265 005 214**
	06.01-01.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	05.00-01.05		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-01.05		**0 265 006 765**
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	05.00-12.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
Fg.no. 4B..2..079 501→	12.01-01.05	ALR,LAB	**0 265 006 763**
		ALR,RAB	**0 265 006 761**
		OLW	**0 265 006 761**
1.8 T quattro [4B5; C5]		**1,8 l 132 kW AJL 4 Zyl.**	
Air mass meter, gasoline injection	02.98-10.00		**0 280 217 117**
			0 986 280 201
Phase sensor	02.98-10.00		**0 232 101 024**
Knock sensor	02.98-10.00	HI	**0 261 231 036**
		VO	**0 261 231 038**

Product			
Pressure sensor, intake manifold, gasoline	02.98-10.00		**0 280 101 001**
Boost pressure sensor, gasoline	02.98-10.00		**0 281 002 177**
Temperature sensor, intake air, injection system	02.98-10.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-10.00		**0 265 005 214**
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	02.98-10.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-10.00	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
1.9 TDI [4A5; C4]		**1,9 l 66 kW 1Z 4 Zyl.**	
Pedal position sensor, diesel			
Fg.no. →4A..S..082 000	07.94-02.95	AG	**0 205 001 018**
		GS	**0 205 001 017**
Fg.no. 4A..S..082 001→	02.95-06.96	AG	**0 205 001 031**
		GS	**0 205 001 032**
1.9 TDI [4B5; C5]		**1,9 l 81/85 kW AFN; AJM 4 Zyl.**	
Air mass meter, diesel	02.98-04.01		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	02.98-04.01		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. →4B..X..200 000	02.98-06.99	AG	**0 281 002 289**
		GS	**0 281 002 286**
Duo sensor, acceleration and yaw rate, brake system	02.98-04.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	02.98-04.01		**0 265 005 303**
1.9 TDI [4B5; C5]		**1,9 l 96 kW AVF; AWX 4 Zyl.**	
Air mass meter, diesel	06.01-01.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	06.01-01.05		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	06.01-01.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.01-01.05		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-01.05		**0 265 006 765**
2.0 [4A5; C4]		**2,0 l 85 kW ABK 4 Zyl.**	
Knock sensor	06.94-06.96	LLE	**0 261 231 038**
		RLE	**0 261 231 036**
2.0 [4A5; C4]		**2,0 l 103 kW ACE 4 Zyl.**	
Throttle valve sensor	07.96-10.97		**0 280 120 426**
Air flow sensor, gasoline injection	07.96-10.97		**0 986 439 389**
			F 026 TX2 059
			0 986 439 389
Phase sensor	07.96-10.97		**0 232 101 024**
Knock sensor	07.96-10.97	LLE	**0 261 231 038**
		RLE	**0 261 231 036**
2.0 [4B5; C5]		**2,0 l 96 kW ALT 4 Zyl.**	
Throttle valve assembly	06.01-01.05		**0 280 750 088**
Air mass meter, gasoline injection	06.01-01.05		**0 280 218 058**
			0 986 280 215
Phase sensor	06.01-01.05		**0 232 101 024**
Speed sensor, ignition/injection	06.01-01.05		**0 281 002 222**
Temperature sensor, intake air, injection system	06.01-01.05		**0 280 130 116**
Duo sensor, acceleration and yaw rate, brake system	06.01-01.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.01-01.05		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-01.05		**0 265 006 765**

A

Product			
2.0 quattro [4A5; C4]			**2,0 l 103 kW ACE 4 Zyl.**
Throttle valve sensor	06.94-10.97		**0 280 120 426**
Air flow sensor, gasoline injection	06.94-10.97		**0 986 439 389**
			F 026 TX2 059
			0 986 439 389
Phase sensor	06.94-10.97		**0 232 101 024**
Knock sensor	06.94-10.97	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
2.0 TDI [4F5; C6]			**2,0 l 89 kW BVG 4 Zyl.**
Air mass meter, diesel	09.05-06.06		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	09.05-06.06		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	09.05-06.06		**0 265 005 601**
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06-06.06	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
2.0 TDI [4F5; C6]			**2,0 l 100 kW BNA 4 Zyl.**
Air mass meter, diesel	06.05-11.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	06.05-11.05		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	06.05-11.05		**0 265 005 601**
2.0 TDI [4F5; C6]			**2,0 l 100 kW BRF 4 Zyl.**
Air mass meter, diesel	06.05→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	06.05→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	06.05-05.06		**0 265 005 601**
Fg.no. 4F..7..000 001→	06.06→		**0 265 005 619**
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
2.0 TDI [4F5; C6]			**2,0 l 103 kW BLB 4 Zyl.**
Air mass meter, diesel	06.05-11.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	06.05-11.05		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	06.05-11.05		**0 265 005 601**
2.0 TDI [4F5; C6]			**2,0 l 103 kW BRE 4 Zyl.**
Air mass meter, diesel	06.05→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	06.05→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	06.05-05.06		**0 265 005 601**
Fg.no. 4F..7..000 001→	06.06→		**0 265 005 619**
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
2.0 TFSI [4F5; C6]			**2,0 l 125 kW BPJ 4 Zyl.**
Speed sensor, ignition/injection	06.05→		**0 261 210 199**
Knock sensor	06.05→		**0 261 231 146**
Boost pressure sensor, gasoline	06.05→		**0 261 230 073**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	06.05-05.06		**0 265 005 601**
Fg.no. 4F..7..000 001→	06.06→		**0 265 005 619**
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**

Product			
2.3 [4A5; C4]			**2,3 l 98 kW AAR 5 Zyl.**
Throttle valve sensor	06.94-06.96	AG	**0 280 120 433**
Air flow sensor, gasoline injection	06.94-06.96		**F 026 TX2 054**
			F 026 TX2 054
Knock sensor	06.94-06.96		**0 261 231 038**
2.3 quattro [4A5; C4]			**2,3 l 98 kW AAR 4 Zyl.**
Throttle valve sensor	07.96-07.97	AG	**0 280 120 433**
Air flow sensor, gasoline injection	07.96-07.97		**F 026 TX2 054**
			F 026 TX2 054
Knock sensor	07.96-07.97	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
2.4 [4A5; C4]			**2,4 l 110 kW AFM 6 Zyl.**
Throttle valve sensor	07.96-10.97		**0 280 120 431**
Knock sensor	07.96-10.97		**0 261 231 036**
2.4 [4B5; C5]			**2,4 l 100 kW ALW 6 Zyl.**
Phase sensor	02.98-01.99		**0 232 101 024**
Speed sensor, ignition/injection	02.98-01.99	AG	**0 261 210 147**
		GS	**0 261 210 178**
Temperature sensor, intake air, injection system	02.98-01.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	02.98-01.99		**0 265 005 214**
2.4 [4B5; C5]			**2,4 l 100 kW ARN 6 Zyl.**
Throttle valve assembly	02.99-05.00		**0 280 750 030**
Phase sensor	02.99-05.00		**0 232 101 024**
Speed sensor, ignition/injection	02.99-05.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →4B..X..200 000	02.99-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	02.99-05.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	02.99-05.00		**0 265 005 214**
2.4 [4B5; C5]			**2,4 l 100 kW ASM 6 Zyl.**
Throttle valve assembly	06.01-01.05		**0 280 750 030**
Phase sensor	06.01-01.05		**0 232 101 024**
Speed sensor, ignition/injection	06.01-01.05	AG	**0 261 210 147**
		GS	**0 261 210 178**
Temperature sensor, intake air, injection system	06.01-01.05		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	06.01-01.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.01-01.05		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-01.05		**0 265 006 765**
2.4 [4B5; C5]			**2,4 l 115 kW APC 6 Zyl.**
Phase sensor	04.98-07.98		**0 232 101 024**
Speed sensor, ignition/injection	04.98-07.98	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	04.98-07.98		**0 261 231 036**
Temperature sensor, intake air, injection system	04.98-07.98		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	04.98-07.98		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	04.98-07.98		**0 265 005 303**
2.4 [4B5; C5]			**2,4 l 120 kW AJG 6 Zyl.**
Phase sensor	02.98-07.98		**0 232 101 024**
Speed sensor, ignition/injection	02.98-07.98	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	02.98-07.98		**0 261 231 036**
Temperature sensor, intake air, injection system	02.98-07.98		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	02.98-07.98		**0 265 005 214**
2.4 [4B5; C5]			**2,4 l 120 kW AMM 6 Zyl.**
Throttle valve assembly	06.00-04.01		**0 280 750 030**
Phase sensor	06.00-04.01		**0 232 101 024**

A

Product			
◀ A6 Avant			
Speed sensor, ignition/injection	06.00-04.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Temperature sensor, intake air, injection system	06.00-04.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	06.00-04.01		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.00-04.01		**0 265 005 303**
2.4 [4B5; C5]		**2,4 l 120 kW APZ 6 Zyl.**	
Throttle valve assembly	11.98-05.00		**0 280 750 030**
Phase sensor	11.98-05.00		**0 232 101 024**
Speed sensor, ignition/injection	11.98-05.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →4B..X..200 000	11.98-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	11.98-05.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	11.98-05.00		**0 265 005 214**
2.4 [4B5; C5]		**2,4 l 121 kW AGA; ALF 6 Zyl.**	
Phase sensor	04.97-01.99		**0 232 101 024**
Speed sensor, ignition/injection	04.97-01.99	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	04.97-01.99		**0 261 231 036**
Temperature sensor, intake air, injection system	04.97-01.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	04.97-01.99		**0 265 005 214**
2.4 [4B5; C5]		**2,4 l 121 kW APS; ARJ 6 Zyl.**	
Throttle valve assembly	11.98-04.01		**0 280 750 030**
Phase sensor	11.98-04.01		**0 232 101 024**
Speed sensor, ignition/injection	11.98-04.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →4B..X..200 000	11.98-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	11.98-04.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	11.98-04.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	11.98-04.01		**0 265 005 303**
2.4 [4B5; C5]		**2,4 l 125 kW BDV 6 Zyl.**	
Throttle valve assembly	06.01-01.05		**0 280 750 030**
Phase sensor	06.01-01.05		**0 232 101 024**
Speed sensor, ignition/injection	06.01-01.05	AG	**0 261 210 147**
		GS	**0 261 210 178**
Temperature sensor, intake air, injection system	06.01-01.05		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	06.01-01.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.01-01.05		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-01.05		**0 265 006 765**
2.4 [4F5; C6]		**2,4 l 130 kW BDW 6 Zyl.**	
Throttle valve assembly	03.05→		**0 280 750 003**
Pressure sensor, intake manifold, gasoline	03.05→		**0 261 230 095**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	03.05-05.06		**0 265 005 601**
Fg.no. 4F..7..000 001→	06.06→		**0 265 005 619**
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
2.4 quattro [4B5; C5]		**2,4 l 115 kW APC 6 Zyl.**	
Phase sensor	08.98-05.01		**0 232 101 024**
Speed sensor, ignition/injection	08.98-05.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →4B..X..200 000	08.98-06.99		**0 261 231 036**

Product			
Temperature sensor, intake air, injection system	08.98-05.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-05.01		**0 265 005 214**
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	08.98-10.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-05.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.4 quattro [4B5; C5]		**2,4 l 120 kW AJG 6 Zyl.**	
Phase sensor	02.98-01.99		**0 232 101 024**
Speed sensor, ignition/injection	02.98-01.99	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	02.98-01.99		**0 261 231 036**
Temperature sensor, intake air, injection system	02.98-01.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-01.99		**0 265 005 214**
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	02.98-10.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-01.99	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.4 quattro [4B5; C5]		**2,4 l 120 kW APZ 6 Zyl.**	
Throttle valve assembly	11.98-05.01		**0 280 750 030**
Phase sensor	11.98-05.01		**0 232 101 024**
Speed sensor, ignition/injection	11.98-05.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →4B..X..200 000	11.98-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	11.98-05.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	11.98-05.01		**0 265 005 214**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-05.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.4 quattro [4B5; C5]		**2,4 l 121 kW AGA; ALF 6 Zyl.**	
Phase sensor	04.97-01.99		**0 232 101 024**
Speed sensor, ignition/injection	04.97-01.99	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	04.97-01.99		**0 261 231 036**
Temperature sensor, intake air, injection system	04.97-01.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-01.99		**0 265 005 214**
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	04.97-10.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-01.99	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.4 quattro [4B5; C5]		**2,4 l 121 kW AML 6 Zyl.**	
Throttle valve assembly	06.00-05.01		**0 280 750 030**
Phase sensor	06.00-05.01		**0 232 101 024**
Speed sensor, ignition/injection	06.00-05.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Temperature sensor, intake air, injection system	06.00-05.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	06.00-05.01		**0 265 005 214**

A

Product			
Pressure sensor, ESP, (electronic stability program)	06.00-05.01		**0 265 005 303**
Wheel speed sensor, rear	06.00-05.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.4 quattro [4B5; C5]		**2,4 l 121 kW APS 6 Zyl.**	
Phase sensor	11.98-06.99		**0 232 101 024**
Speed sensor, ignition/injection	11.98-06.99	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	11.98-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	11.98-06.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	11.98-06.99		**0 265 005 214**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-06.99	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.4 quattro [4B5; C5]		**2,4 l 121 kW ARJ 6 Zyl.**	
Throttle valve assembly	11.98-05.01		**0 280 750 030**
Phase sensor	11.98-05.01		**0 232 101 024**
Speed sensor, ignition/injection	11.98-05.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →4B..X..200 000	11.98-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	11.98-05.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	11.98-05.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	11.98-05.01		**0 265 005 303**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-05.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.4 quattro [4B5; C5]		**2,4 l 125 kW BDV 6 Zyl.**	
Throttle valve assembly	06.01-01.05		**0 280 750 030**
Phase sensor	06.01-01.05		**0 232 101 024**
Speed sensor, ignition/injection	06.01-01.05	AG	**0 261 210 147**
		GS	**0 261 210 178**
Temperature sensor, intake air, injection system	06.01-01.05		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	06.01-01.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.01-01.05		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-01.05		**0 265 006 765**
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	06.01-12.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
Fg.no. 4B..2..079 501→	12.01-01.05	ALR,LAB	**0 265 006 763**
		ALR,RAB	**0 265 006 761**
		OLW	**0 265 006 761**
2.4 quattro [4F5; C6]		**2,4 l 130 kW BDW 6 Zyl.**	
Throttle valve assembly	03.05→		**0 280 750 003**
Pressure sensor, intake manifold, gasoline	03.05→		**0 261 230 095**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	03.05-05.06		**0 265 005 601**
Fg.no. 4F..7..000 001→	06.06→		**0 265 005 619**
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**

Product			
2.5 TDI [4A5; C4]		**2,5 l 85/103 kW AAT; AEL 5 Zyl.**	
Air mass meter, diesel	06.94-10.97		**0 281 002 074**
Pedal position sensor, diesel			
Fg.no. →4A..S..082 000	06.94-02.95	AG	**0 205 001 018**
		GS	**0 205 001 017**
Fg.no. 4A..S..082 001→	02.95-10.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
2.5 TDI [4B5; C5]		**2,5 l 110 kW AFB 6 Zyl.**	
Air mass meter, diesel	02.98-05.00		**0 281 002 429**
			0 986 284 005
Speed sensor, diesel	02.98-05.00		**0 281 002 222**
Pressure sensor, intake manifold, diesel	02.98-05.00		**0 281 002 326**
Pedal position sensor, diesel			
Fg.no. →4B..X..200 000	02.98-06.99	AG	**0 281 002 289**
		GS	**0 281 002 286**
Duo sensor, acceleration and yaw rate, brake system	02.98-05.00		**0 265 005 214**
2.5 TDI [4B5; C5]		**2,5 l 110 kW AKN 6 Zyl.**	
Air mass meter, diesel			
Fg.no. →8D..X..400 000	11.98-06.99		**0 281 002 429**
			0 986 284 005
Fg.no. 8D..Y..000 001→	07.99-04.01		**0 281 002 403**
			0 986 284 004
Speed sensor, diesel	11.98-04.01		**0 281 002 222**
Pressure sensor, intake manifold, diesel	11.98-04.01		**0 281 002 326**
Pedal position sensor, diesel	11.98-04.01	AG	**0 281 002 289**
		GS	**0 281 002 286**
Duo sensor, acceleration and yaw rate, brake system	11.98-04.01		**0 265 005 214**
2.5 TDI [4B5; C5]		**2,5 l 114 kW AYM 6 Zyl.**	
Speed sensor, diesel	06.01-06.02		**0 281 002 222**
Pressure sensor, intake manifold, diesel	06.01-06.02		**0 281 002 326**
Duo sensor, acceleration and yaw rate, brake system	06.01-06.02		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.01-06.02		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→	09.01-06.02		**0 265 006 578**
2.5 TDI [4B5; C5]		**2,5 l 120 kW BFC 6 Zyl.**	
Speed sensor, diesel	07.02-08.03		**0 281 002 222**
Pressure sensor, intake manifold, diesel	07.02-08.03		**0 281 002 326**
Duo sensor, acceleration and yaw rate, brake system	07.02-08.03		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	07.02-08.03		**0 265 005 303**
Wheel speed sensor, front	07.02-08.03		**0 265 006 765**
2.5 TDI [4B5; C5]		**2,5 l 132 kW AKE 6 Zyl.**	
Speed sensor, diesel	10.99-08.03		**0 281 002 222**
Pressure sensor, intake manifold, diesel	10.99-08.03		**0 281 002 326**
Duo sensor, acceleration and yaw rate, brake system	10.99-05.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	10.99-08.03		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-08.03		**0 265 006 765**
2.5 TDI [4B5; C5]		**2,5 l 132 kW BAU; BCZ; BDG; BDH 6 Zyl.**	
Speed sensor, diesel	11.02-01.05		**0 281 002 222**
Pressure sensor, intake manifold, diesel	11.02-01.05		**0 281 002 326**
Duo sensor, acceleration and yaw rate, brake system	11.02-01.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	11.02-01.05		**0 265 005 303**
Wheel speed sensor, front	11.02-01.05		**0 265 006 765**
2.5 TDI quattro [4A5; C4]		**2,5 l 103 kW AEL 5 Zyl.**	
Air mass meter, diesel	07.96-10.97		**0 281 002 074**
Pedal position sensor, diesel	07.96-10.97		**0 205 001 032**

A

Product			
◀ A6 Avant			
2.5 TDI quattro [4B5; C5]			**2,5 l 110 kW AFB 6 Zyl.**
Air mass meter, diesel	02.98-05.00		**0 281 002 429**
			0 986 284 005
Speed sensor, diesel	02.98-05.00		**0 281 002 222**
Pressure sensor, intake manifold, diesel	02.98-05.00		**0 281 002 326**
Pedal position sensor, diesel			
Fg.no. →4B..X..200 000	02.98-06.99	AG	**0 281 002 289**
		GS	**0 281 002 286**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-05.00		**0 265 005 214**
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	02.98-10.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-05.00	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.5 TDI quattro [4B5; C5]			**2,5 l 110 kW AKN 6 Zyl.**
Air mass meter, diesel	11.98-06.99		**0 281 002 429**
			0 986 284 005
Speed sensor, diesel	11.98-06.99		**0 281 002 222**
Pressure sensor, intake manifold, diesel	11.98-06.99		**0 281 002 326**
Pedal position sensor, diesel	11.98-06.99	AG	**0 281 002 289**
		GS	**0 281 002 286**
Duo sensor, acceleration and yaw rate, brake system	11.98-06.99		**0 265 005 214**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-06.99	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.5 TDI quattro [4B5; C5]			**2,5 l 132 kW AKE 6 Zyl.**
Speed sensor, diesel	10.99-08.03		**0 281 002 222**
Pressure sensor, intake manifold, diesel	10.99-08.03		**0 281 002 326**
Duo sensor, acceleration and yaw rate, brake system	10.99-05.01		**0 265 005 214**
	06.01-08.03		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.99-08.03		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-08.03		**0 265 006 765**
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	10.99-12.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
Fg.no. 4B..2..079 501→	12.01-08.03	ALR,LAB	**0 265 006 763**
		ALR,RAB	**0 265 006 761**
		OLW	**0 265 006 761**
2.5 TDI quattro [4B5; C5]			**2,5 l 132 kW BAU; BDH 6 Zyl.**
Speed sensor, diesel	02.03-01.05		**0 281 002 222**
Pressure sensor, intake manifold, diesel	02.03-01.05		**0 281 002 326**
Duo sensor, acceleration and yaw rate, brake system	02.03-01.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	02.03-01.05		**0 265 005 303**
Wheel speed sensor, front	02.03-01.05		**0 265 006 765**
Wheel speed sensor, rear	02.03-01.05	ALR,LAB	**0 265 006 763**
		ALR,RAB	**0 265 006 761**
		OLW	**0 265 006 761**
2.6 [4A5; C4]			**2,6 l 102 kW ACZ 6 Zyl.**
Throttle valve sensor	06.94-07.96		**0 280 120 431**
Phase sensor	06.94-07.96		**0 232 101 027**
Temperature sensor, intake air, injection system	06.94-07.96	KZS	**0 280 130 060**

Product			
2.6 [4A5; C4]			**2,6 l 110 kW ABC 6 Zyl.**
Throttle valve sensor	06.94-06.96		**0 280 120 431**
Phase sensor	06.94-06.96		**0 232 101 027**
Knock sensor	06.94-06.96		**0 261 231 036**
Temperature sensor, intake air, injection system	06.94-06.96	KZS	**0 280 130 060**
2.6 quattro [4A5; C4]			**2,6 l 102/110 kW ABC; ACZ 6 Zyl.**
Throttle valve sensor	06.94-10.97		**0 280 120 431**
Phase sensor	06.94-10.97		**0 232 101 027**
Knock sensor	06.94-10.97		**0 261 231 036**
Temperature sensor, intake air, injection system	06.94-10.97	KZS	**0 280 130 060**
2.7 Biturbo [4B5; C5]			**2,7 l 169 kW AJK 6 Zyl.**
Air mass meter, gasoline injection	02.99-05.01		**0 280 218 038**
			0 986 280 212
Phase sensor	02.99-05.01		**0 232 101 024**
Speed sensor, ignition/injection	02.99-05.01	GS	**0 261 210 147**
Fg.no. →4B..1..006 637	02.99-05.00	AG	**0 281 002 222**
Fg.no. 4B..1..006 638→	06.00-05.01	AG	**0 261 210 217**
Knock sensor			
Fg.no. →4B..X..200 000	02.99-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	02.99-05.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	02.99-05.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	02.99-05.01		**0 265 005 303**
2.7 Biturbo quattro [4B5; C5]			**2,7 l 169 kW AJK 6 Zyl.**
Air mass meter, gasoline injection	02.99-08.00		**0 280 218 038**
			0 986 280 212
Phase sensor	02.99-08.00		**0 232 101 024**
Speed sensor, ignition/injection	02.99-08.00	GS	**0 261 210 147**
Fg.no. →4B..1..006 637	02.99-05.00	AG	**0 281 002 222**
Fg.no. 4B..1..006 638→	06.00-08.00	AG	**0 261 210 217**
Knock sensor			
Fg.no. →4B..X..200 000	02.99-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	02.99-08.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	02.99-08.00		**0 265 005 214**
Wheel speed sensor, rear	02.99-08.00	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.7 Biturbo quattro [4B5; C5]			**2,7 l 169 kW AZA 6 Zyl.**
Throttle valve assembly	09.00-05.01		**0 280 750 003**
Speed sensor, ignition/injection	09.00-05.01	AG	**0 261 210 217**
		GS	**0 261 210 147**
Temperature sensor, intake air, injection system	09.00-05.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	09.00-05.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	09.00-05.01		**0 265 005 303**
Wheel speed sensor, rear	09.00-05.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.7 Biturbo quattro [4B5; C5]			**2,7 l 184 kW ARE 6 Zyl.**
Throttle valve assembly	06.01-06.02		**0 280 750 003**
Phase sensor	06.01-06.02		**0 232 101 024**
Speed sensor, ignition/injection	06.01-06.02	AG	**0 261 210 217**
		GS	**0 261 210 147**
Temperature sensor, intake air, injection system	06.01-06.02		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	06.01-06.02		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.01-06.02		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→	09.01-06.02		**0 265 006 578**

Product			
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	06.01-12.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
Fg.no. 4B..2..079 501→	12.01-06.02	ALR,LAB	**0 265 006 763**
		ALR,RAB	**0 265 006 761**
		OLW	**0 265 006 761**
2.7 Biturbo quattro [4B5; C5]		**2,7 l 184 kW BES 6 Zyl.**	
Throttle valve assembly	07.02-01.05		**0 280 750 003**
Phase sensor	07.02-01.05		**0 232 101 024**
Speed sensor, ignition/injection	07.02-01.05	AG	**0 261 210 217**
		GS	**0 261 210 147**
Temperature sensor, intake air, injection system	07.02-01.05		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	07.02-01.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	07.02-01.05		**0 265 005 303**
Wheel speed sensor, front	07.02-01.05		**0 265 006 765**
Wheel speed sensor, rear	07.02-01.05	ALR,LAB	**0 265 006 763**
		ALR,RAB	**0 265 006 761**
		OLW	**0 265 006 761**
2.7 TDI [4F5; C6]		**2,7 l 120/132 kW BPP; BSG 6 Zyl.**	
Speed sensor, diesel	03.05→	FKW	**0 261 210 145**
High-pressure sensor (CR system)			
Fg.no. →4F..6..132 000	03.05-12.05		**0 281 002 504**
Boost pressure sensor, Diesel	03.05→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	03.05-05.06		**0 265 005 601**
Fg.no. 4F..7..000 001→	06.06→		**0 265 005 619**
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
2.7 TDI quattro [4F5; C6]		**2,7 l 120/132 kW BPP; BSG 6 Zyl.**	
Speed sensor, diesel	06.05→	FKW	**0 261 210 145**
High-pressure sensor (CR system)			
Fg.no. →4F..6..132 000	06.05-12.05		**0 281 002 504**
Boost pressure sensor, Diesel	06.05→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	06.05-05.06		**0 265 005 601**
Fg.no. 4F..7..000 001→	06.06→		**0 265 005 619**
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
2.8 [4A5; C4]		**2,8 l 120 kW AEJ 6 Zyl.**	
Throttle valve sensor	06.94-07.96		**0 280 120 431**
2.8 [4A5; C4]		**2,8 l 128 kW AAH 6 Zyl.**	
Throttle valve sensor	09.94-07.96		**0 280 120 431**
Phase sensor	09.94-07.96		**0 232 101 027**
Knock sensor	09.94-07.96		**0 261 231 036**
2.8 [4A5; C4]		**2,8 l 142 kW ACK 6 Zyl.**	
Throttle valve sensor	10.95-10.97		**0 280 120 431**
Phase sensor	10.95-10.97		**0 232 101 024**
Speed sensor, ignition/injection	10.95-10.97		**0 261 210 139**
Knock sensor	10.95-10.97		**0 261 231 036**
Temperature sensor, intake air, injection system	10.95-10.97	KZS	**0 280 130 060**
2.8 [4B5; C5]		**2,8 l 132 kW AGE 6 Zyl.**	
Phase sensor	02.98-05.00		**0 232 101 024**
Speed sensor, ignition/injection	02.98-05.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →4B..X..200 000	02.98-06.99		**0 261 231 036**

Product			
Temperature sensor, intake air, injection system	02.98-05.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	02.98-05.00		**0 265 005 214**
2.8 [4B5; C5]		**2,8 l 140 kW ATX 6 Zyl.**	
Throttle valve assembly	07.99-04.01		**0 280 750 030**
Phase sensor	07.99-04.01		**0 232 101 024**
Speed sensor, ignition/injection	07.99-04.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Temperature sensor, intake air, injection system	07.99-04.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	07.99-04.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	07.99-04.01		**0 265 005 303**
2.8 [4B5; C5]		**2,8 l 142 kW ACK; ALG 6 Zyl.**	
Phase sensor	02.98-01.99		**0 232 101 024**
Speed sensor, ignition/injection	02.98-01.99	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	02.98-01.99		**0 261 231 036**
Temperature sensor, intake air, injection system	02.98-01.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	02.98-01.99		**0 265 005 214**
2.8 [4B5; C5]		**2,8 l 142 kW APR; AQD 6 Zyl.**	
Throttle valve assembly	11.98-04.01		**0 280 750 030**
Phase sensor	11.98-04.01		**0 232 101 024**
Speed sensor, ignition/injection	11.98-04.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →4B..X..200 000	11.98-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	11.98-04.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	11.98-04.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	11.98-04.01		**0 265 005 303**
2.8 FSI [4F5; C6]		**2,8 l 154 kW BDX 6 Zyl.**	
Pressure sensor, intake manifold, gasoline	11.06→		**0 261 230 095**
2.8 FSI quattro [4F5, C6]		**2,8 l 154 kW BDX 6 Zyl.**	
Pressure sensor, intake manifold, gasoline	11.06→		**0 261 230 095**
2.8 quattro [4A5; C4]		**2,8 l 120 kW AEJ 6 Zyl.**	
Throttle valve sensor	07.96-10.97		**0 280 120 431**
2.8 quattro [4A5; C4]		**2,8 l 128 kW AAH 6 Zyl.**	
Throttle valve sensor	06.94-10.97		**0 280 120 431**
Phase sensor	06.94-10.97		**0 232 101 027**
Knock sensor	06.94-10.97		**0 261 231 036**
2.8 quattro [4A5; C4]		**2,8 l 142 kW ACK 6 Zyl.**	
Throttle valve sensor	07.96-10.97		**0 280 120 431**
Phase sensor	07.96-10.97		**0 232 101 024**
Speed sensor, ignition/injection	07.96-10.97		**0 261 210 139**
Knock sensor	07.96-10.97		**0 261 231 036**
Temperature sensor, intake air, injection system	07.96-10.97	KZS	**0 280 130 060**
2.8 quattro [4B5; C5]		**2,8 l 132 kW AGE 6 Zyl.**	
Phase sensor	04.98-05.01		**0 232 101 024**
Speed sensor, ignition/injection	04.98-05.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →4B..X..200 000	04.98-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	04.98-05.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-05.01		**0 265 005 214**
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	04.98-10.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-05.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**

A

Product			
◀ A6 Avant			
2.8 quattro [4B5; C5]		**2,8 l 140 kW ATX 6 Zyl.**	
Throttle valve assembly	07.99-05.01		**0 280 750 030**
Phase sensor	07.99-05.01		**0 232 101 024**
Speed sensor, ignition/injection	07.99-05.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Temperature sensor, intake air, injection system	07.99-05.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	07.99-05.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	07.99-05.01		**0 265 005 303**
Wheel speed sensor, rear	07.99-05.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.8 quattro [4B5; C5]		**2,8 l 142 kW ACK 6 Zyl.**	
Phase sensor	02.98-12.98		**0 232 101 024**
Speed sensor, ignition/injection	02.98-12.98	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	02.98-12.98		**0 261 231 036**
Temperature sensor, intake air, injection system	02.98-12.98		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-12.98		**0 265 005 214**
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	02.98-10.98		**0 265 005 207**
2.8 quattro [4B5; C5]		**2,8 l 142 kW ALG 6 Zyl.**	
Phase sensor	02.98-01.99		**0 232 101 024**
Speed sensor, ignition/injection	02.98-01.99	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	02.98-01.99		**0 261 231 036**
Temperature sensor, intake air, injection system	02.98-01.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-01.99		**0 265 005 214**
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	02.98-10.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-01.99	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.8 quattro [4B5; C5]		**2,8 l 142 kW AMX 6 Zyl.**	
Throttle valve assembly	06.00-05.01		**0 280 750 030**
Phase sensor	06.00-05.01		**0 232 101 024**
Speed sensor, ignition/injection	06.00-05.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	06.00-05.01		**0 261 231 036**
Temperature sensor, intake air, injection system	06.00-05.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	06.00-05.01		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.00-05.01		**0 265 005 303**
Wheel speed sensor, rear	06.00-05.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.8 quattro [4B5; C5]		**2,8 l 142 kW APR 6 Zyl.**	
Throttle valve assembly	01.99-05.01		**0 280 750 030**
Phase sensor	01.99-05.01		**0 232 101 024**
Speed sensor, ignition/injection	01.99-05.01	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →4B..X..200 000	01.99-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	01.99-05.01		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.99-05.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	01.99-05.01		**0 265 005 303**
Wheel speed sensor, rear	01.99-05.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
2.8 quattro [4B5; C5]		**2,8 l 142 kW AQD 6 Zyl.**	
Throttle valve assembly	11.98-07.99		**0 280 750 030**
Phase sensor	11.98-07.99		**0 232 101 024**
Speed sensor, ignition/injection	11.98-07.99	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →4B..X..200 000	11.98-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	11.98-07.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	11.98-07.99		**0 265 005 214**
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-07.99	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
3.0 [4B5; C5]		**3,0 l 160/162 kW ASN; BBJ 6 Zyl.**	
Throttle valve assembly	06.01-01.05		**0 280 750 030**
Speed sensor, ignition/injection	06.01-01.05	AG	**0 261 210 147**
		GS	**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system	06.01-01.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.01-01.05		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-01.05		**0 265 006 765**
3.0 [4F5; C6]		**3,0 l 160 kW BBJ 6 Zyl.**	
Throttle valve assembly	03.05-05.06		**0 280 750 030**
Duo sensor, acceleration and yaw rate, brake system	03.05-05.06		**0 265 005 601**
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06-05.06	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
3.0 quattro [4B5; C5]		**3,0 l 160 kW BBJ 6 Zyl.**	
Throttle valve assembly	06.01-01.05		**0 280 750 030**
Phase sensor	06.01-01.05		**0 232 101 024**
Speed sensor, ignition/injection	06.01-01.05	AG	**0 261 210 147**
		GS	**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system	06.01-01.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.01-01.05		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-01.05		**0 265 006 765**
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	06.01-12.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
Fg.no. 4B..2..079 501→	12.01-01.05	ALR,LAB	**0 265 006 763**
		ALR,RAB	**0 265 006 761**
		OLW	**0 265 006 761**
3.0 quattro [4B5; C5]		**3,0 l 162 kW ASN 6 Zyl.**	
Throttle valve assembly	06.01-01.05		**0 280 750 030**
Speed sensor, ignition/injection	06.01-01.05	AG	**0 261 210 147**
		GS	**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system	06.01-01.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.01-01.05		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-01.05		**0 265 006 765**

A

Product			
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	06.01-12.01	ALR,LAB	**0 265 006 586**
		ALR,RAB	**0 265 006 584**
		OLW	**0 265 006 584**
Fg.no. 4B..2..079 501→	12.01-01.05	ALR,LAB	**0 265 006 763**
		ALR,RAB	**0 265 006 761**
		OLW	**0 265 006 761**
3.0 quattro [4F5; C6]		**3,0 l 160 kW BBJ 6 Zyl.**	
Throttle valve assembly	03.05-05.06		**0 280 750 030**
Duo sensor, acceleration and yaw rate, brake system	03.05-05.06		**0 265 005 601**
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06-05.06	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
3.0 TDI quattro [4F5; C6]		**3,0 l 155 kW BNG 6 Zyl.**	
Speed sensor, diesel	03.05→	FKW	**0 261 210 145**
Boost pressure sensor, Diesel	03.05→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	03.05-05.06		**0 265 005 601**
Fg.no. 4F..7..000 001→	06.06→		**0 265 005 619**
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
3.0 TDI quattro [4F5; C6]		**3,0 l 165 kW BMK 6 Zyl.**	
Speed sensor, diesel	03.05-05.06	FKW	**0 261 210 145**
High-pressure sensor (CR system)			
Fg.no. →4F..6..132 000	03.05-12.05		**0 281 002 504**
Boost pressure sensor, Diesel	03.05-05.06		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	03.05-05.06		**0 265 005 601**
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06-05.06	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
3.0 TDI quattro [4F5; C6]		**3,0 l 171 kW ASB 6 Zyl.**	
Speed sensor, diesel	06.06→	FKW	**0 261 210 145**
Boost pressure sensor, Diesel	06.06→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	06.06→		**0 265 005 619**
Wheel speed sensor	06.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
3.2 FSI [4F5; C6]		**3,2 l 188 kW AUK 6 Zyl.**	
Throttle valve assembly	03.05-05.07		**0 280 750 003**
Pressure sensor, intake manifold, gasoline	03.05-05.07		**0 261 230 095**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	03.05-05.06		**0 265 005 601**
Fg.no. 4F..7..000 001→	06.06-05.07		**0 265 005 619**
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06-05.07	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
3.2 FSI quattro [4F5; C6]		**3,2 l 188 kW AUK 6 Zyl.**	
Throttle valve assembly	03.05→		**0 280 750 003**
Pressure sensor, intake manifold, gasoline	03.05→		**0 261 230 095**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	03.05-05.06		**0 265 005 601**
Fg.no. 4F..7..000 001→	06.06→		**0 265 005 619**
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**

Product			
4.2 FSI quattro [4F5; C6]		**4,2 l 257 kW BVJ 8 Zyl.**	
Throttle valve assembly	06.06→		**0 280 750 003**
Air mass meter, gasoline injection	06.06→		**0 280 218 069**
			0 986 280 220
Duo sensor, acceleration and yaw rate, brake system	06.06→		**0 265 005 619**
Wheel speed sensor	06.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
4.2 quattro [4B6; C5]		**4,2 l 220 kW ARS 8 Zyl.**	
Throttle valve assembly	04.99-05.01		**0 280 750 032**
Air mass meter, gasoline injection	04.99-05.01		**0 280 218 015**
			0 986 280 207
Phase sensor	04.99-05.01		**0 232 101 024**
Speed sensor, ignition/injection	04.99-05.01	AG	**0 261 210 190**
		GS	**0 261 210 192**
Knock sensor	04.99-05.01		**0 261 231 038**
Duo sensor, acceleration and yaw rate, brake system	04.99-05.01		**0 265 005 214**
Pressure sensor, ESP, (electronic stability program)	04.99-05.01		**0 265 005 303**
Wheel speed sensor, front	04.99-05.01		**0 265 006 578**
Wheel speed sensor, rear	04.99-05.01	LAB	**0 265 006 567**
		RAB	**0 265 006 565**
4.2 quattro [4B6; C5]		**4,2 l 220 kW ASG 8 Zyl.**	
Throttle valve assembly	06.01-01.05		**0 280 750 003**
Air mass meter, gasoline injection	06.01-01.05		**0 280 218 069**
			0 986 280 220
Phase sensor	06.01-01.05		**0 232 101 024**
Speed sensor, ignition/injection	06.01-01.05	AG	**0 261 210 190**
		GS	**0 261 210 192**
Knock sensor	06.01-01.05		**0 261 231 038**
Duo sensor, acceleration and yaw rate, brake system	06.01-01.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.01-01.05		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →4B..2..200 000	06.01-06.02		**0 265 006 578**
Fg.no. 4B..3..000 001→	07.02-01.05		**0 265 006 765**
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	06.01-12.01	LAB	**0 265 006 567**
		RAB	**0 265 006 565**
Fg.no. 4B..2..079 501→	12.01-01.05	LAB	**0 265 006 769**
	01.02-01.05	RAB	**0 265 006 767**
4.2 quattro [4F5; C6]		**4,2 l 246 kW BAT 8 Zyl.**	
Throttle valve assembly	03.05-05.06		**0 280 750 003**
Air mass meter, gasoline injection	03.05-05.06		**0 280 218 069**
			0 986 280 220
Speed sensor, ignition/injection	03.05-05.06		**0 261 210 190**
Duo sensor, acceleration and yaw rate, brake system	03.05-05.06		**0 265 005 601**
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06-05.06	LAB	**0 265 007 930**
		RAB	**0 265 007 928**

A6 Avant Allroad

2.5 TDI [4BH; C5]		**2,5 l 120 kW BCZ 6 Zyl.**	
Speed sensor, diesel	06.03-08.05		**0 281 002 222**
Pressure sensor, intake manifold, diesel	06.03-08.05		**0 281 002 326**
Duo sensor, acceleration and yaw rate, brake system	06.03-08.05		**0 265 005 214**
Wheel speed sensor, rear	06.03-08.05	LAB	**0 265 006 781**
		RAB	**0 265 006 783**

A

Product

◀ A6 Avant Allroad

2.5 TDI [4BH; C5]			**2,5 l 132 kW AKE 6 Zyl.**
Speed sensor, diesel	05.00-05.03		**0 281 002 222**
Pressure sensor, intake manifold, diesel	05.00-05.03		**0 281 002 326**
Duo sensor, acceleration and yaw rate, brake system	05.00-05.03		**0 265 005 214**
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	05.00-11.01	LAB	**0 265 006 655**
		RAB	**0 265 006 657**
Fg.no. 4B..2..079 501→	12.01-05.03	LAB	**0 265 006 781**
		RAB	**0 265 006 783**
2.5 TDI [4BH; C5]			**2,5 l 132 kW BAU 6 Zyl.**
Speed sensor, diesel	06.03-08.05		**0 281 002 222**
Pressure sensor, intake manifold, diesel	06.03-08.05		**0 281 002 326**
Duo sensor, acceleration and yaw rate, brake system	06.03-08.05		**0 265 005 214**
Wheel speed sensor, rear	06.03-08.05	LAB	**0 265 006 781**
		RAB	**0 265 006 783**
2.7 T [4BH; C5]			**2,7 l 184 kW ARE 6 Zyl.**
Throttle valve assembly	05.00-06.02		**0 280 750 003**
Phase sensor	05.00-06.02		**0 232 101 024**
Speed sensor, ignition/injection	05.00-06.02	AG	**0 261 210 217**
		GS	**0 261 210 147**
Temperature sensor, intake air, injection system	05.00-06.02		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	05.00-06.02		**0 265 005 214**
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	05.00-11.01	LAB	**0 265 006 655**
		RAB	**0 265 006 657**
Fg.no. 4B..2..079 501→	12.01-06.02	LAB	**0 265 006 781**
		RAB	**0 265 006 783**
2.7 T [4BH; C5]			**2,7 l 184 kW BES 6 Zyl.**
Throttle valve assembly	07.02-08.05		**0 280 750 003**
Phase sensor	07.02-08.05		**0 232 101 024**
Speed sensor, ignition/injection	07.02-08.05	AG	**0 261 210 217**
		GS	**0 261 210 147**
Temperature sensor, intake air, injection system	07.02-08.05		**0 280 130 116**
Duo sensor, acceleration and yaw rate, brake system	07.02-08.05		**0 265 005 214**
Wheel speed sensor, rear	07.02-08.05	LAB	**0 265 006 781**
		RAB	**0 265 006 783**
2.7 T [4BH; C5]			**2,7 l 187 kW APB 6 Zyl.**
Throttle valve assembly	09.00-06.02		**0 280 750 003**
Phase sensor	09.00-06.02		**0 232 101 024**
Speed sensor, ignition/injection	09.00-06.02	AG	**0 261 210 217**
		GS	**0 261 210 147**
Temperature sensor, intake air, injection system	09.00-06.02		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	09.00-06.02		**0 265 005 214**
Wheel speed sensor, front	09.00-06.02	B17,B18	**0 265 006 578**
2.7 T [4BH; C5]			**2,7 l 187 kW BEL 6 Zyl.**
Throttle valve assembly	07.02-08.05		**0 280 750 003**
Phase sensor	07.02-08.05		**0 232 101 024**
Speed sensor, ignition/injection	07.02-08.05	AG	**0 261 210 217**
		GS	**0 261 210 147**
Temperature sensor, intake air, injection system	07.02-08.05		**0 280 130 116**
Duo sensor, acceleration and yaw rate, brake system	07.02-08.05		**0 265 005 214**
Wheel speed sensor, rear	07.02-08.05	LAB	**0 265 006 781**
		RAB	**0 265 006 783**

Product

2.7 TDI [4FH; C6]			**2,7 l 120/132 kW BPP; BSG 6 Zyl.**
Speed sensor, diesel	05.06→	FKW	**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..7..075 000	05.06-10.06		**0 265 005 601**
Fg.no. 4F..7..075 001→	11.06→		**0 265 005 692**
Wheel speed sensor	05.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
3.0 TDI [4FH; C6]			**3,0 l 155/171 kW ASB; BNG 6 Zyl.**
Speed sensor, diesel	05.06→	FKW	**0 261 210 178**
Boost pressure sensor, Diesel	05.06→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..7..075 000	05.06-10.06		**0 265 005 601**
Fg.no. 4F..7..075 001→	11.06→		**0 265 005 692**
Wheel speed sensor	05.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
3.2 FSI [4FH; C6]			**3,2 l 188 kW AUK 6 Zyl.**
Throttle valve assembly	05.06→		**0 280 750 003**
Pressure sensor, intake manifold, gasoline	05.06→		**0 261 230 095**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..7..075 000	05.06-10.06		**0 265 005 601**
Fg.no. 4F..7..075 001→	11.06→		**0 265 005 692**
Wheel speed sensor	05.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
4.2 [4BH; C5]			**4,2 l 220 kW BAS 8 Zyl.**
Throttle valve assembly	07.02-08.05		**0 280 750 003**
Air mass meter, gasoline injection	07.02-08.05		**0 280 218 069**
			0 986 280 220
Speed sensor, ignition/injection	07.02-08.05		**0 261 210 190**
Duo sensor, acceleration and yaw rate, brake system	07.02-08.05		**0 265 005 214**
Wheel speed sensor, rear	07.02-08.05	LAB	**0 265 006 781**
		RAB	**0 265 006 783**
4.2 FSI [4FH; C6]			**4,2 l 257 kW BVJ 8 Zyl.**
Throttle valve assembly	05.06→		**0 280 750 003**
Air mass meter, gasoline injection	05.06→		**0 280 218 069**
			0 986 280 220
Pressure sensor, intake manifold, gasoline	05.06→		**0 261 230 095**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..7..075 000	05.06-10.06		**0 265 005 601**
Fg.no. 4F..7..075 001→	11.06→		**0 265 005 692**
Wheel speed sensor	05.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**

A8

2.5 TDI [4D2; D2]			**2,5 l 110 kW AFB 6 Zyl.**
Air mass meter, diesel	06.97-04.00		**0 281 002 429**
			0 986 284 005
Speed sensor, diesel	06.97-04.00	KZU	**0 281 002 222**
Pressure sensor, intake manifold, diesel	06.97-04.00		**0 281 002 326**
Pedal position sensor, diesel	08.98-04.00		**0 281 002 331**
	06.97-07.98	AG	**0 281 002 253**
		GS	**0 281 002 229**
Lateral acceleration sensor, brake system	06.97-04.00		**0 265 005 127**
Yaw rate sensor, brake system	06.97-04.00		**0 265 005 207**
Wheel speed sensor, front			
Fg.no. 4D..X..005 001→	10.98-04.00	16R	**0 265 006 580**
		20R	**0 265 006 662**

Product			
Wheel speed sensor, rear			
Fg.no. 4D..X..005 001→	10.98-04.00		**0 265 006 588**
2.5 TDI [4D2; D2]			**2,5 l 110 kW AKN 6 Zyl.**
Air mass meter, diesel	11.97-09.02		**0 281 002 429**
			0 986 284 005
Speed sensor, diesel	11.97-09.02	KZU	**0 281 002 222**
Pressure sensor, intake manifold, diesel	11.97-09.02		**0 281 002 326**
Pedal position sensor, diesel	08.98-09.02		**0 281 002 331**
	11.97-07.98	AG	**0 281 002 253**
		GS	**0 281 002 229**
Lateral acceleration sensor, brake system	11.97-09.02		**0 265 005 127**
Yaw rate sensor, brake system	11.97-09.02		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	11.97-09.02		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. 4D..X..005 001→	10.98-09.02	16R	**0 265 006 580**
		20R	**0 265 006 662**
Wheel speed sensor, rear			
Fg.no. 4D..X..005 001→	10.98-09.02		**0 265 006 588**
2.5 TDI [4D2; D2]			**2,5 l 132 kW AKE 6 Zyl.**
Speed sensor, diesel	05.00-09.02	KZU	**0 281 002 222**
Pressure sensor, intake manifold, diesel	05.00-09.02		**0 281 002 326**
Pedal position sensor, diesel	05.00-09.02		**0 281 002 331**
Lateral acceleration sensor, brake system	05.00-09.02		**0 265 005 127**
Yaw rate sensor, brake system	05.00-09.02		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	05.00-09.02		**0 265 005 303**
Wheel speed sensor, front	05.00-09.02	16R	**0 265 006 580**
		20R	**0 265 006 662**
Wheel speed sensor, rear	05.00-09.02		**0 265 006 588**
2.5 TDI quattro [4D2; D2]			**2,5 l 110 kW AFB; AKN 6 Zyl.**
Air mass meter, diesel	06.97-06.00		**0 281 002 429**
			0 986 284 005
Speed sensor, diesel	06.97-06.00	KZU	**0 281 002 222**
Pressure sensor, intake manifold, diesel	06.97-06.00		**0 281 002 326**
Pedal position sensor, diesel	08.98-06.00		**0 281 002 331**
	06.97-07.98	AG	**0 281 002 253**
		GS	**0 281 002 229**
Lateral acceleration sensor, brake system	06.97-06.00		**0 265 005 127**
Yaw rate sensor, brake system	06.97-06.00		**0 265 005 207**
Wheel speed sensor, front			
Fg.no. 4D..X..005 001→	10.98-06.00	16R,FKR	**0 265 006 580**
		20R,FKR	**0 265 006 662**
Wheel speed sensor, rear	06.97-06.00	FKR	**0 265 006 588**
2.5 TDI quattro [4D2; D2]			**2,5 l 132 kW AKE 6 Zyl.**
Speed sensor, diesel	11.99-09.02	KZU	**0 281 002 222**
Pressure sensor, intake manifold, diesel	11.99-09.02		**0 281 002 326**
Pedal position sensor, diesel	11.99-09.02		**0 281 002 331**
Lateral acceleration sensor, brake system	11.99-09.02		**0 265 005 127**
Yaw rate sensor, brake system	11.99-09.02		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	11.99-09.02		**0 265 005 303**
Wheel speed sensor, front	11.99-09.02	16R,FKR	**0 265 006 580**
		20R,FKR	**0 265 006 662**
Wheel speed sensor, rear	11.99-09.02	FKR	**0 265 006 588**
2.8 [4D2; D2]			**2,8 l 120/128 kW AAH; AEJ 6 Zyl.**
Throttle valve sensor	06.94-03.96		**0 280 120 431**
Phase sensor	06.94-03.96		**0 232 101 027**
Knock sensor	06.94-03.96		**0 261 231 036**
Pedal position sensor, EMS (electronic engine management)	06.94-03.96		**0 280 752 022**
2.8 [4D2; D2]			**2,8 l 142 kW ACK 6 Zyl.**
Throttle valve sensor	03.96-12.98		**0 280 120 431**
Phase sensor	03.96-12.98		**0 232 101 024**

Product			
Speed sensor, ignition/injection			
Fg.no. →4D..V..010 965	03.96-04.97	AG	**0 261 210 139**
		GS	**0 261 210 134**
Fg.no. 4D..V..010 966→	04.97-12.98	AG	**0 281 002 222**
		GS	**0 261 210 147**
Knock sensor	03.96-12.98		**0 261 231 036**
Pedal position sensor, EMS (electronic engine management)	03.96-12.98		**0 280 752 022**
Lateral acceleration sensor, brake system	03.96-12.98		**0 265 005 127**
Yaw rate sensor, brake system	03.96-12.98		**0 265 005 207**
Wheel speed sensor, front			
Fg.no. 4D..X..005 001→	10.98-12.98	16R	**0 265 006 580**
		20R	**0 265 006 662**
Wheel speed sensor, rear			
Fg.no. 4D..X..005 001→	10.98-12.98		**0 265 006 588**
2.8 [4D2; D2]			**2,8 l 142 kW ALG 6 Zyl.**
Phase sensor	10.97-12.98		**0 232 101 024**
Speed sensor, ignition/injection	10.97-12.98	AG	**0 281 002 222**
		GS	**0 261 210 147**
Temperature sensor, intake air, injection system	10.97-12.98		**0 280 130 085**
Pedal position sensor, EMS (electronic engine management)	10.97-12.98		**0 280 752 022**
Lateral acceleration sensor, brake system	10.97-12.98		**0 265 005 127**
Yaw rate sensor, brake system	10.97-12.98		**0 265 005 207**
Wheel speed sensor, front			
Fg.no. 4D..X..005 001→	10.98-12.98	16R	**0 265 006 580**
		20R	**0 265 006 662**
Wheel speed sensor, rear			
Fg.no. 4D..X..005 001→	10.98-12.98		**0 265 006 588**
2.8 [4D2; D2]			**2,8 l 142 kW AMX 6 Zyl.**
Throttle valve assembly	05.00-09.02		**0 280 750 030**
Phase sensor	05.00-09.02		**0 232 101 024**
Speed sensor, ignition/injection	05.00-09.02	AG	**0 281 002 222**
		GS	**0 261 210 147**
Temperature sensor, intake air, injection system	05.00-09.02		**0 280 130 085**
Pedal position sensor, EMS (electronic engine management)	05.00-09.02		**0 280 752 022**
Lateral acceleration sensor, brake system	05.00-09.02		**0 265 005 127**
Yaw rate sensor, brake system	05.00-09.02		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	05.00-09.02		**0 265 005 303**
Wheel speed sensor, front	05.00-09.02	16R	**0 265 006 580**
		20R	**0 265 006 662**
Wheel speed sensor, rear	05.00-09.02		**0 265 006 588**
2.8 [4D2; D2]			**2,8 l 142 kW APR 6 Zyl.**
Throttle valve assembly	01.99-04.99		**0 280 750 030**
Phase sensor	01.99-04.99		**0 232 101 024**
Speed sensor, ignition/injection	01.99-04.99	AG	**0 281 002 222**
		GS	**0 261 210 147**
Temperature sensor, intake air, injection system	01.99-04.99		**0 280 130 085**
Pedal position sensor, EMS (electronic engine management)	01.99-04.99		**0 280 752 022**
Lateral acceleration sensor, brake system	01.99-04.99		**0 265 005 127**
Yaw rate sensor, brake system	01.99-04.99		**0 265 005 207**
Wheel speed sensor, front	01.99-04.99	16R	**0 265 006 580**
		20R	**0 265 006 662**
Wheel speed sensor, rear	01.99-04.99		**0 265 006 588**
2.8 [4D2; D2]			**2,8 l 142 kW AQD 6 Zyl.**
Throttle valve assembly	01.99-02.01		**0 280 750 030**
Phase sensor	01.99-02.01		**0 232 101 024**
Speed sensor, ignition/injection	01.99-02.01	AG	**0 281 002 222**
		GS	**0 261 210 147**
Temperature sensor, intake air, injection system	01.99-02.01		**0 280 130 085**

A

Product			
◀ A8			
Pedal position sensor, EMS (electronic engine management)	01.99-02.01		**0 280 752 022**
Lateral acceleration sensor, brake system	01.99-02.01		**0 265 005 127**
Yaw rate sensor, brake system	01.99-02.01		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	01.99-02.01		**0 265 005 303**
Wheel speed sensor, front	01.99-02.01	16R	**0 265 006 580**
		20R	**0 265 006 662**
Wheel speed sensor, rear	01.99-02.01		**0 265 006 588**
2.8 FSI [4E; D3]		**2,8 l 154 kW BDX 6 Zyl.**	
Pressure sensor, intake manifold, gasoline	09.07→		**0 261 230 095**
Duo sensor, acceleration and yaw rate, brake system	09.07→		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	09.07→		**0 265 005 303**
Wheel speed sensor	09.07→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
2.8 quattro [4D2; D2]		**2,8 l 120/128 kW AAH; AEJ 6 Zyl.**	
Throttle valve sensor	09.94-03.96		**0 280 120 431**
Phase sensor	09.94-03.96		**0 232 101 027**
Knock sensor	09.94-03.96		**0 261 231 036**
Pedal position sensor, EMS (electronic engine management)	09.94-03.96		**0 280 752 022**
2.8 quattro [4D2; D2]		**2,8 l 142 kW ACK 6 Zyl.**	
Throttle valve sensor	03.96-12.98		**0 280 120 431**
Phase sensor	03.96-12.98		**0 232 101 024**
Speed sensor, ignition/injection			
Fg.no. →4D..V..010 965	03.96-04.97	AG	**0 261 210 139**
		GS	**0 261 210 134**
Fg.no. 4D..V..010 966→	04.97-12.98	AG	**0 281 002 222**
		GS	**0 261 210 147**
Knock sensor	03.96-12.98		**0 261 231 036**
Pedal position sensor, EMS (electronic engine management)	03.96-12.98		**0 280 752 022**
Lateral acceleration sensor, brake system	03.96-12.98		**0 265 005 127**
Yaw rate sensor, brake system	03.96-12.98		**0 265 005 207**
Wheel speed sensor, front			
Fg.no. 4D..X..005 001→	10.98-12.98	16R,FKR	**0 265 006 580**
		20R,FKR	**0 265 006 662**
Wheel speed sensor, rear	03.96-12.98	FKR	**0 265 006 588**
2.8 quattro [4D2; D2]		**2,8 l 142 kW ALG 6 Zyl.**	
Phase sensor	10.97-12.98		**0 232 101 024**
Speed sensor, ignition/injection	10.97-12.98	AG	**0 281 002 222**
		GS	**0 261 210 147**
Knock sensor	10.97-12.98		**0 261 231 036**
Temperature sensor, intake air, injection system	10.97-12.98		**0 280 130 085**
Pedal position sensor, EMS (electronic engine management)	10.97-12.98		**0 280 752 022**
Lateral acceleration sensor, brake system	10.97-12.98		**0 265 005 127**
Yaw rate sensor, brake system	10.97-12.98		**0 265 005 207**
Wheel speed sensor, front			
Fg.no. 4D..X..005 001→	10.98-12.98	16R,FKR	**0 265 006 580**
		20R,FKR	**0 265 006 662**
Wheel speed sensor, rear	10.97-12.98	FKR	**0 265 006 588**
2.8 quattro [4D2; D2]		**2,8 l 142 kW AMX 6 Zyl.**	
Throttle valve assembly	05.00-09.02		**0 280 750 030**
Phase sensor	05.00-09.02		**0 232 101 024**
Speed sensor, ignition/injection	05.00-09.02	AG	**0 281 002 222**
		GS	**0 261 210 147**
Temperature sensor, intake air, injection system	05.00-09.02		**0 280 130 085**
Pedal position sensor, EMS (electronic engine management)	05.00-09.02		**0 280 752 022**
Lateral acceleration sensor, brake system	05.00-09.02		**0 265 005 127**
Yaw rate sensor, brake system	05.00-09.02		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	05.00-09.02		**0 265 005 303**

Product			
Wheel speed sensor, front	05.00-09.02	16R,FKR	**0 265 006 580**
		20R,FKR	**0 265 006 662**
Wheel speed sensor, rear	05.00-09.02	FKR	**0 265 006 588**
2.8 quattro [4D2; D2]		**2,8 l 142 kW APR; AQD 6 Zyl.**	
Throttle valve assembly	01.99-04.99		**0 280 750 030**
Phase sensor	01.99-04.99		**0 232 101 024**
Speed sensor, ignition/injection	01.99-04.99	AG	**0 281 002 222**
		GS	**0 261 210 147**
Temperature sensor, intake air, injection system	01.99-04.99		**0 280 130 085**
Pedal position sensor, EMS (electronic engine management)	01.99-04.99		**0 280 752 022**
Lateral acceleration sensor, brake system	01.99-04.99		**0 265 005 127**
Yaw rate sensor, brake system	01.99-04.99		**0 265 005 207**
Wheel speed sensor, front	01.99-04.99	16R,FKR	**0 265 006 580**
		20R,FKR	**0 265 006 662**
Wheel speed sensor, rear	01.99-04.99	FKR	**0 265 006 588**
3.0 [4E; D3]		**3,0 l 160/162 kW ASN; BBJ 6 Zyl.**	
Throttle valve assembly	07.03-05.06		**0 280 750 030**
Speed sensor, ignition/injection	07.03-05.06		**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system	07.03-05.06		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	07.03-05.06		**0 265 005 303**
Wheel speed sensor	07.03-05.06	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
3.0 quattro [4E; D3]		**3,0 l 160 kW BBJ 6 Zyl.**	
Throttle valve assembly	11.03-05.06		**0 280 750 030**
Speed sensor, ignition/injection	11.03-05.06		**0 261 210 178**
Duo sensor, acceleration and yaw rate, brake system	11.03-05.06		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	11.03-05.06		**0 265 005 303**
Wheel speed sensor	11.03-05.06	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
3.0 TDI quattro [4E; D3]		**3,0 l 155/171 kW ASB; BNG 6 Zyl.**	
Speed sensor, diesel	11.03→	FKW	**0 261 210 145**
High-pressure sensor (CR system)			
Fg.no. →4E..6..011 250	11.03-09.05		**0 281 002 504**
Boost pressure sensor, Diesel	11.03→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	11.03→		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	11.03→		**0 265 005 303**
Wheel speed sensor	11.03→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
3.2 FSI, FSI quattro [4E; D3]		**3,2 l 191 kW BPK 6 Zyl.**	
Throttle valve assembly	06.05→		**0 280 750 003**
Pressure sensor, intake manifold, gasoline	06.05→		**0 261 230 095**
Duo sensor, acceleration and yaw rate, brake system	06.05→		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.05→		**0 265 005 303**
Wheel speed sensor	06.05→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
3.3 TDI quattro [4D2; D2]		**3,3 l 165 kW AKF 8 Zyl.**	
Air mass meter, diesel	12.99-08.02		**0 281 002 435**
			0 986 284 006
Speed sensor, diesel	12.99-08.02		**0 261 210 192**
Pressure sensor, intake manifold, diesel	12.99-08.02		**0 281 002 326**
Pedal position sensor, diesel	12.99-08.02		**0 281 002 331**
Lateral acceleration sensor, brake system	12.99-08.02		**0 265 005 127**
Yaw rate sensor, brake system	12.99-08.02		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	12.99-08.02		**0 265 005 303**
Wheel speed sensor, front	12.99-08.02	FKR	**0 265 006 662**
Wheel speed sensor, rear	12.99-08.02	FKR	**0 265 006 588**

Product			
3.7 [4D2; D2]			**3,7 l 169 kW AEW; AKJ 8 Zyl.**
Throttle valve sensor	07.95-12.98		**0 280 120 431**
Air mass meter, gasoline injection	07.95-12.98		**0 280 217 804**
Phase sensor	07.95-12.98		**0 232 101 024**
Speed sensor, ignition/injection			
Fg.no. →4B..X..004 999	07.95-10.98		**0 261 210 143**
Fg.no. 4D..X..005 001→	11.98-12.98		**0 261 210 190**
Knock sensor	07.95-12.98	LAB	**0 261 231 040**
		RAB	**0 261 231 038**
Temperature sensor, intake air, injection system	07.95-12.98	KZS	**0 280 130 060**
Pedal position sensor, EMS (electronic engine management)	07.95-12.98		**0 280 752 022**
Lateral acceleration sensor, brake system	07.95-12.98		**0 265 005 127**
Yaw rate sensor, brake system	07.95-12.98		**0 265 005 207**
Wheel speed sensor, front			
Fg.no. 4D..X..005 001→	10.98-12.98	16R	**0 265 006 580**
		20R	**0 265 006 662**
Wheel speed sensor, rear			
Fg.no. 4D..X..005 001→	10.98-12.98		**0 265 006 588**
3.7 [4D2; D2]			**3,7 l 191 kW AKC 8 Zyl.**
Throttle valve assembly	05.00-09.02		**0 280 750 003**
Air mass meter, gasoline injection	05.00-09.02		**0 280 218 069**
			0 986 280 220
Phase sensor	05.00-09.02		**0 232 101 024**
Speed sensor, ignition/injection	05.00-09.02		**0 261 210 190**
Knock sensor	05.00-09.02		**0 261 231 038**
Pedal position sensor, EMS (electronic engine management)	05.00-09.02		**0 280 752 022**
Lateral acceleration sensor, brake system	05.00-09.02		**0 265 005 127**
Yaw rate sensor, brake system	05.00-09.02		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	05.00-09.02		**0 265 005 303**
Wheel speed sensor, front	05.00-09.02	16R	**0 265 006 580**
		20R	**0 265 006 662**
Wheel speed sensor, rear	05.00-09.02		**0 265 006 588**
3.7 [4D2; D2]			**3,7 l 191 kW AQG 8 Zyl.**
Throttle valve assembly	10.98-02.01		**0 280 750 032**
Air mass meter, gasoline injection	10.98-02.01		**0 280 218 015**
			0 986 280 207
Phase sensor	10.98-02.01		**0 232 101 024**
Speed sensor, ignition/injection	10.98-02.01		**0 261 210 190**
Knock sensor	10.98-02.01		**0 261 231 038**
Pedal position sensor, EMS (electronic engine management)	10.98-02.01		**0 280 752 022**
Lateral acceleration sensor, brake system	10.98-02.01		**0 265 005 127**
Yaw rate sensor, brake system	10.98-02.01		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	10.98-02.01		**0 265 005 303**
Wheel speed sensor, front	10.98-02.01	16R	**0 265 006 580**
		20R	**0 265 006 662**
Wheel speed sensor, rear	10.98-02.01		**0 265 006 588**
3.7 quattro [4D2; D2]			**3,7 l 169 kW AEW; AKJ 8 Zyl.**
Throttle valve sensor	10.95-12.98		**0 280 120 431**
Air mass meter, gasoline injection	10.95-12.98		**0 280 217 804**
Phase sensor	10.95-12.98		**0 232 101 024**
Speed sensor, ignition/injection			
Fg.no. →4B..X..004 999	10.95-10.98		**0 261 210 143**
Fg.no. 4D..X..005 001→	11.98-12.98	AG	**0 261 210 190**
		GS	**0 261 210 192**
Knock sensor			
Fg.no. →4D..X..004 999	10.95-10.98	LAB	**0 261 231 040**
		RAB	**0 261 231 038**
Fg.no. 4D..X..005 001→	10.98-12.98		**0 261 231 038**

Product			
Temperature sensor, intake air, injection system	10.95-12.98	KZS	**0 280 130 060**
Pedal position sensor, EMS (electronic engine management)	10.95-12.98		**0 280 752 022**
Lateral acceleration sensor, brake system	10.95-12.98		**0 265 005 127**
Yaw rate sensor, brake system	10.95-12.98		**0 265 005 207**
Wheel speed sensor, front			
Fg.no. 4D..X..005 001→	10.98-12.98	16R,FKR	**0 265 006 580**
		20R,FKR	**0 265 006 662**
Wheel speed sensor, rear	10.95-12.98	FKR	**0 265 006 588**
3.7 quattro [4D2; D2]			**3,7 l 191 kW AKC 8 Zyl.**
Throttle valve assembly	05.00-09.02		**0 280 750 003**
Air mass meter, gasoline injection	05.00-09.02		**0 280 218 069**
			0 986 280 220
Phase sensor	05.00-09.02		**0 232 101 024**
Speed sensor, ignition/injection	05.00-09.02	AG	**0 261 210 190**
		GS	**0 261 210 192**
Knock sensor	05.00-09.02		**0 261 231 038**
Pedal position sensor, EMS (electronic engine management)	05.00-09.02		**0 280 752 022**
Lateral acceleration sensor, brake system	05.00-09.02		**0 265 005 127**
Yaw rate sensor, brake system	05.00-09.02		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	05.00-09.02		**0 265 005 303**
Wheel speed sensor, front	05.00-09.02	16R,FKR	**0 265 006 580**
		20R,FKR	**0 265 006 662**
Wheel speed sensor, rear	05.00-09.02	FKR	**0 265 006 588**
3.7 quattro [4D2; D2]			**3,7 l 191 kW AQG 8 Zyl.**
Throttle valve assembly	10.98-02.01		**0 280 750 032**
Air mass meter, gasoline injection	10.98-02.01		**0 280 218 015**
			0 986 280 207
Phase sensor	10.98-02.01		**0 232 101 024**
Speed sensor, ignition/injection	10.98-02.01	AG	**0 261 210 190**
		GS	**0 261 210 192**
Knock sensor	10.98-02.01		**0 261 231 038**
Pedal position sensor, EMS (electronic engine management)	10.98-02.01		**0 280 752 022**
Lateral acceleration sensor, brake system	10.98-02.01		**0 265 005 127**
Yaw rate sensor, brake system	10.98-02.01		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	10.98-02.01		**0 265 005 303**
Wheel speed sensor, front	10.98-02.01	16R,FKR	**0 265 006 580**
		20R,FKR	**0 265 006 662**
Wheel speed sensor, rear	10.98-02.01	FKR	**0 265 006 588**
3.7 quattro [4E; D3]			**3,7 l 206 kW BFL 8 Zyl.**
Throttle valve assembly	11.02-05.06		**0 280 750 003**
Air mass meter, gasoline injection	11.02-05.06		**0 280 218 069**
			0 986 280 220
Phase sensor	11.02-05.06		**0 232 101 024**
Speed sensor, ignition/injection	11.02-05.06		**0 261 210 245**
Duo sensor, acceleration and yaw rate, brake system	11.02-05.06		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	11.02-05.06		**0 265 005 303**
Wheel speed sensor	11.02-05.06	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
4.0 TDI quattro [4E; D3]			**4,0 l 202 kW ASE 8 Zyl.**
Speed sensor, diesel	05.03-07.05	FKW	**0 261 210 192**
High-pressure sensor (CR system)	05.03-07.05		**0 281 002 606**
Boost pressure sensor, Diesel	05.03-07.05		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	05.03-07.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	05.03-07.05		**0 265 005 303**
Wheel speed sensor	05.03-07.05	LAB	**0 265 007 930**
		RAB	**0 265 007 928**

A

Product			
◀ A8			
4.2 FSI quattro [4E; D3]			**4,2 l 257 kW BVJ 8 Zyl.**
Throttle valve assembly	06.06→		**0 280 750 003**
Air mass meter, gasoline injection	06.06→		**0 280 218 069**
			0 986 280 220
Duo sensor, acceleration and yaw rate, brake system	06.06→		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.06→		**0 265 005 303**
Wheel speed sensor	06.06→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
4.2 quattro [4D2; D2]			**4,2 l 175 kW ARU 8 Zyl.**
Air mass meter, gasoline injection	02.99-04.00		**0 280 218 015**
			0 986 280 207
Speed sensor, ignition/injection	02.99-04.00	AG	**0 261 210 190**
		GS	**0 261 210 192**
Knock sensor	02.99-04.00		**0 261 231 038**
Pedal position sensor, EMS (electronic engine management)	02.99-04.00		**0 280 752 022**
Lateral acceleration sensor, brake system	02.99-04.00		**0 265 005 127**
Yaw rate sensor, brake system	02.99-04.00		**0 265 005 207**
Wheel speed sensor, front	02.99-04.00	16R,FKR	**0 265 006 580**
		20R,FKR	**0 265 006 662**
Wheel speed sensor, rear	02.99-04.00	FKR	**0 265 006 588**
4.2 quattro [4D2; D2]			**4,2 l 180 kW AEM 8 Zyl.**
Throttle valve sensor	06.94-07.96		**0 280 120 431**
Air mass meter, gasoline injection	06.94-07.96		**0 280 217 804**
Phase sensor	06.94-07.96		**0 232 101 024**
Speed sensor, ignition/injection	06.94-07.96		**0 261 210 111**
Knock sensor	06.94-07.96	LAB	**0 261 231 040**
		RAB	**0 261 231 038**
Temperature sensor, intake air, injection system	06.94-07.96	KZS	**0 280 130 060**
Pedal position sensor, EMS (electronic engine management)	06.94-07.96		**0 280 752 022**
4.2 quattro [4D2; D2]			**4,2 l 210/220 kW ABZ; AGH 8 Zyl.**
Throttle valve sensor	06.94-12.98		**0 280 120 431**
Air mass meter, gasoline injection	06.94-12.98		**0 280 217 804**
Phase sensor	06.94-12.98		**0 232 101 024**
Speed sensor, ignition/injection			
Fg.no. →4D..T..015 000	06.94-07.96		**0 261 210 111**
Fg.no. 4D..V..000 001→4D..X..004 999	07.96-10.98		**0 261 210 143**
Fg.no. 4D..X..005 001→	11.98-12.98	AG	**0 261 210 190**
		GS	**0 261 210 192**
Knock sensor			
Fg.no. →4D..X..004 999	06.94-10.98	LAB	**0 261 231 040**
		RAB	**0 261 231 038**
Fg.no. 4D..X..005 001→	10.98-12.98		**0 261 231 038**
Temperature sensor, intake air, injection system	06.94-12.98	KZS	**0 280 130 060**
Pedal position sensor, EMS (electronic engine management)	06.94-12.98		**0 280 752 022**
Lateral acceleration sensor, brake system	06.94-12.98		**0 265 005 127**
Yaw rate sensor, brake system	06.94-12.98		**0 265 005 207**
Wheel speed sensor, front			
Fg.no. 4D..X..005 001→	10.98-12.98	16R,FKR	**0 265 006 580**
		20R,FKR	**0 265 006 662**
Wheel speed sensor, rear	06.94-12.98	FKR	**0 265 006 588**
4.2 quattro [4D2; D2]			**4,2 l 220 kW AKG 8 Zyl.**
Throttle valve sensor	04.97-12.98		**0 280 120 431**
Air mass meter, gasoline injection	04.97-12.98		**0 280 217 804**
Phase sensor	04.97-12.98		**0 232 101 024**
Speed sensor, ignition/injection			
Fg.no. →4D..X..004 999	04.97-10.98		**0 261 210 143**
Fg.no. 4D..X..005 001→	11.98-12.98	AG	**0 261 210 190**
		GS	**0 261 210 192**

Product			
Knock sensor			
Fg.no. →4D..X..004 999	04.97-10.98	LAB	**0 261 231 040**
		RAB	**0 261 231 038**
Fg.no. 4D..X..005 001→	10.98-12.98		**0 261 231 038**
Temperature sensor, intake air, injection system	04.97-12.98	KZS	**0 280 130 060**
Pedal position sensor, EMS (electronic engine management)	04.97-12.98		**0 280 752 022**
Lateral acceleration sensor, brake system	04.97-12.98		**0 265 005 127**
Yaw rate sensor, brake system	04.97-12.98		**0 265 005 207**
Wheel speed sensor, front			
Fg.no. 4D..X..005 001→	10.98-12.98	16R,FKR	**0 265 006 580**
		20R,FKR	**0 265 006 662**
Wheel speed sensor, rear	04.97-12.98	FKR	**0 265 006 588**
4.2 quattro [4D2; D2]			**4,2 l 228 kW AKB 8 Zyl.**
Speed sensor, ignition/injection	05.99-05.00	AG	**0 261 210 190**
		GS	**0 261 210 192**
Pedal position sensor, EMS (electronic engine management)	05.99-05.00		**0 280 752 022**
4.2 quattro [4D2; D2]			**4,2 l 228 kW AQF 8 Zyl.**
Air mass meter, gasoline injection	10.98-02.01		**0 280 218 015**
			0 986 280 207
Speed sensor, ignition/injection	10.98-02.01	AG	**0 261 210 190**
		GS	**0 261 210 192**
Pedal position sensor, EMS (electronic engine management)	10.98-02.01		**0 280 752 022**
Lateral acceleration sensor, brake system	10.98-02.01		**0 265 005 127**
Yaw rate sensor, brake system	10.98-02.01		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	10.98-02.01		**0 265 005 303**
Wheel speed sensor, front	10.98-02.01	16R,FKR	**0 265 006 580**
		20R,FKR	**0 265 006 662**
Wheel speed sensor, rear	10.98-02.01	FKR	**0 265 006 588**
4.2 quattro [4D2; D2]			**4,2 l 228 kW AUW 8 Zyl.**
Air mass meter, gasoline injection	05.00-09.02		**0 280 218 069**
			0 986 280 220
Speed sensor, ignition/injection	05.00-09.02	AG	**0 261 210 190**
		GS	**0 261 210 192**
Knock sensor	05.00-09.02		**0 261 231 038**
Pedal position sensor, EMS (electronic engine management)	05.00-09.02		**0 280 752 022**
Lateral acceleration sensor, brake system	05.00-09.02		**0 265 005 127**
Yaw rate sensor, brake system	05.00-09.02		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	05.00-09.02		**0 265 005 303**
Wheel speed sensor, front	05.00-09.02	16R,FKR	**0 265 006 580**
		20R,FKR	**0 265 006 662**
Wheel speed sensor, rear	05.00-09.02	FKR	**0 265 006 588**
4.2 quattro [4E; D3]			**4,2 l 246 kW BFM 8 Zyl.**
Throttle valve assembly	11.02-05.06		**0 280 750 003**
Air mass meter, gasoline injection	11.02-05.06		**0 280 218 069**
			0 986 280 220
Phase sensor	11.02-05.06		**0 232 101 024**
Speed sensor, ignition/injection	11.02-05.06		**0 261 210 245**
Duo sensor, acceleration and yaw rate, brake system	11.02-05.06		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	11.02-05.06		**0 265 005 303**
Wheel speed sensor	11.02-05.06	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
4.2 TDI quattro [4E; D3]			**4,2 l 235/240 kW BMC; BVN 8 Zyl.**
Speed sensor, diesel	01.05→	FKW	**0 261 210 192**
Boost pressure sensor, Diesel	01.05→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	01.05→		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	01.05→		**0 265 005 303**

A

Product			
Wheel speed sensor	01.05→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
6.0 quattro [4D2; D2]			**6,0 l 309 kW AZC 12 Zyl.**
Air mass meter, gasoline injection	03.01-08.02		**0 280 218 071**
			0 986 280 221
Phase sensor	03.01-08.02		**0 232 103 019**
Pedal position sensor, EMS (electronic engine management)	03.01-08.02		**0 280 752 022**
Lateral acceleration sensor, brake system	03.01-08.02		**0 265 005 127**
Yaw rate sensor, brake system	03.01-08.02		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	03.01-08.02		**0 265 005 303**
Wheel speed sensor, front	03.01-08.02	FKR	**0 265 006 662**
Wheel speed sensor, rear	03.01-08.02	FKR	**0 265 006 588**
6.0 quattro [4E; D3]			**6,0 l 331 kW BHT 12 Zyl.**
Air mass meter, gasoline injection	02.04→		**0 280 218 143**
Phase sensor	02.04→		**0 232 103 019**
Duo sensor, acceleration and yaw rate, brake system	02.04→		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	02.04→		**0 265 005 303**
Wheel speed sensor	02.04→	LAB,OSS	**0 265 007 930**
		OSS,RAB	**0 265 007 928**
6.0 quattro [4E; D3]			**6,0 l 331 kW BSB 12 Zyl.**
Phase sensor	10.04→		**0 232 103 019**
Duo sensor, acceleration and yaw rate, brake system	10.04→		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.04→		**0 265 005 303**
Wheel speed sensor	10.04→	LAB,OSS	**0 265 007 930**
		OSS,RAB	**0 265 007 928**
6.0 quattro [4E; D3]			**6,0 l 331 kW BTE 12 Zyl.**
Air mass meter, gasoline injection	02.05→		**0 280 218 143**
Phase sensor	02.05→		**0 232 103 019**
Duo sensor, acceleration and yaw rate, brake system	02.05→		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	02.05→		**0 265 005 303**
Wheel speed sensor	02.05→	LAB,OSS	**0 265 007 930**
		OSS,RAB	**0 265 007 928**

Cabriolet

1.8 [8G7; B4]			**1,8 l 92 kW ADR 4 Zyl.**
Phase sensor	01.97-08.00		**0 232 101 024**
Knock sensor	01.97-08.00	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	01.97-08.00		**0 280 130 085**
1.9 TDI [8G7; B4]			**1,9 l 66 kW AHU 4 Zyl.**
Pedal position sensor, diesel	07.96-08.00		**0 205 001 032**
2.0 [8G7; B4]			**2,0 l 85 kW ABK 4 Zyl.**
Phase sensor	01.93-09.98		**0 232 101 027**
Knock sensor	01.93-09.98	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
2.0 [8G7; B4]			**2,0 l 103 kW ACE 4 Zyl.**
Throttle valve sensor	05.95-07.96		**0 280 120 426**
Air flow sensor, gasoline injection	05.95-07.96		**0 986 439 389**
			F 026 TX2 059
			0 986 439 389
2.3 [8G7; B4]			**2,3 l 98 kW NG 5 Zyl.**
Throttle valve sensor	06.91-07.94		**0 280 120 433**
Air flow sensor, gasoline injection	06.91-07.94		**F 026 TX2 054**
			F 026 TX2 054
Knock sensor	06.91-07.94	LLE	**0 261 231 036**
		RLE	**0 261 231 038**
Pressure sensor, intake manifold, gasoline	06.91-07.94		**0 280 101 001**
Temperature sensor, coolant, injection system	06.91-07.94		**0 280 130 053**

Product			
2.6 [8G7; B4]			**2,6 l 102 kW ACZ 6 Zyl.**
Throttle valve sensor	05.95-12.99		**0 280 120 431**
Phase sensor	05.95-12.99		**0 232 101 027**
Knock sensor	05.95-12.99		**0 261 231 038**
Temperature sensor, intake air, injection system	05.95-12.99	KZS	**0 280 130 060**
Temperature sensor, coolant, injection system	05.95-12.99	KZW	**0 280 130 040**
2.6 [8G7; B4]			**2,6 l 110 kW ABC 6 Zyl.**
Throttle valve sensor	01.94-08.00		**0 280 120 431**
Phase sensor	01.94-08.00		**0 232 101 027**
Knock sensor	01.94-08.00	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	01.94-08.00	KZS	**0 280 130 060**
Temperature sensor, coolant, injection system	01.94-08.00	KZW	**0 280 130 040**
2.8 [8G7; B4]			**2,8 l 128 kW AAH 6 Zyl.**
Throttle valve sensor	11.92-08.00		**0 280 120 431**
Phase sensor	11.92-08.00		**0 232 101 027**
Knock sensor	11.92-08.00	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, coolant, injection system	11.92-08.00	KZW	**0 280 130 040**

Coupé

1.8 [89; B3]			**1,8 l 82 kW DZ 4 Zyl.**
Air flow sensor, gasoline injection	08.89-07.91	FOB	**F 026 TX2 051**
			F 026 TX2 051
1.8 GT [85; B2]			**1,8 l 66 kW JN 4 Zyl.**
Air flow sensor, gasoline injection	01.85-07.88		**F 026 TX2 063**
			F 026 TX2 063
Temperature sensor, coolant, injection system	01.85-07.88		**0 280 130 040**
1.8 GT [85; B2]			**1,8 l 81 kW PV 4 Zyl.**
Air flow sensor, gasoline injection	08.86-07.88		**F 026 TX2 063**
			F 026 TX2 063
Knock sensor	08.86-07.88		**0 261 231 038**
Temperature sensor, coolant, injection system	08.86-07.88		**0 280 130 040**
1.8 GT [85; B2]			**1,8 l 82 kW DZ 4 Zyl.**
Air flow sensor, gasoline injection	08.86-07.88	FOB	**F 026 TX2 051**
			F 026 TX2 051
2.0 [89; B3]			**2,0 l 83 kW 3A 4 Zyl.**
Air flow sensor, gasoline injection	05.89-07.90		**0 438 121 087**
			0 986 439 387
Knock sensor	05.89-07.90	KZB,LLE	**0 261 231 036**
		KZG,RLE	**0 261 231 038**
Temperature sensor, coolant, injection system	05.89-07.90	KZW	**0 280 130 040**
2.0 [89; B3]			**2,0 l 85 kW AAD 4 Zyl.**
Throttle valve sensor	08.90-07.91		**0 280 120 426**
Air flow sensor, gasoline injection	08.90-07.91		**0 438 121 087**
			0 986 439 387
Knock sensor	08.90-07.91	KZB	**0 261 231 036**
Temperature sensor, coolant, injection system	08.90-07.91	KZW	**0 280 130 040**
2.0 [89; B3]			**2,0 l 85 kW ABK 4 Zyl.**
Knock sensor	09.91-12.95	KZB	**0 261 231 036**
2.0 [89; B3]			**2,0 l 101 kW 6A 4 Zyl.**
Air flow sensor, gasoline injection	01.92-07.92		**0 986 439 389**
			F 026 TX2 059
			0 986 439 389
Knock sensor	01.92-07.92	KZG	**0 261 231 038**
Temperature sensor, coolant, injection system	01.92-07.92	KZW	**0 280 130 040**
2.0 [89; B3]			**2,0 l 103 kW ACE 4 Zyl.**
Throttle valve sensor	08.92-12.95		**0 280 120 426**
Air flow sensor, gasoline injection	08.92-12.95		**0 986 439 389**
			F 026 TX2 059
			0 986 439 389

A

Product			
◀ Coupé			
Knock sensor	08.92-12.95	KZG	**0 261 231 038**
Temperature sensor, coolant, injection system	08.92-12.95	KZW	**0 280 130 040**
2.0 GT [85; B2]			**2,0 l 83 kW SK 5 Zyl.**
Knock sensor	02.86-07.86		**0 261 231 038**
Wheel speed sensor, rear	02.86-07.86		**0 265 001 099**
2.0 GT [85; B2]			**2,0 l 85 kW HP 5 Zyl.**
Air flow sensor, gasoline injection			
Fg.no. →85..G..140 638	08.83-02.86	FMB	**0 438 121 005**
Wheel speed sensor, rear	08.83-07.86		**0 265 001 099**
2.0 GT 5E [85; B2]			**2,0 l 81 kW JL 5 Zyl.**
Air flow sensor, gasoline injection	09.83-07.88		**0 438 120 181**
Wheel speed sensor, rear	09.83-07.88		**0 265 001 099**
2.0 GT 5E [85; B2]			**2,0 l 85 kW JS 5 Zyl.**
Air flow sensor, gasoline injection			
Fg.no. →85..G..140 638	09.83-02.86	FMB	**0 438 121 005**
Wheel speed sensor, rear	09.83-07.86		**0 265 001 099**
2.2 [89; B3]			**2,2 l 98 kW KV 5 Zyl.**
Air flow sensor, gasoline injection	11.88-07.91	FOB	**0 438 120 211**
2.2 GT [85; B2]			**2,2 l 88 kW KX 5 Zyl.**
Air flow sensor, gasoline injection	01.84-07.88		**F 026 TX2 064**
			F 026 TX2 064
Pressure sensor, intake manifold, gasoline	01.84-07.88		**0 280 101 001**
Temperature sensor, coolant, injection system	01.84-07.88		**0 280 130 037**
Wheel speed sensor, rear	01.84-07.88		**0 265 001 099**
2.2 GT [85; B2]			**2,2 l 98/100 kW HY; KV 5 Zyl.**
Air flow sensor, gasoline injection			
Fg.no. →85..G..140 638	09.84-02.86	FMB	**0 438 121 005**
Wheel speed sensor, rear	09.84-07.88		**0 265 001 099**
2.2 quattro [85; B2]			**2,2 l 89 kW JT 5 Zyl.**
Air flow sensor, gasoline injection	12.84-12.87	FOB	**F 026 TX2 064**
			F 026 TX2 064
Pressure sensor, intake manifold, gasoline	12.84-12.87		**0 280 101 001**
Temperature sensor, coolant, injection system	12.84-12.87		**0 280 130 037**
2.2 quattro [85; B2]			**2,2 l 98/100 kW HY; KV 5 Zyl.**
Air flow sensor, gasoline injection			
Fg.no. →85..G..140 638	12.84-02.86	FMB	**0 438 121 005**
2.2 quattro [89; B3]			**2,2 l 98 kW KV 5 Zyl.**
Air flow sensor, gasoline injection	11.88-07.91	FOB	**0 438 120 211**
2.2 S2 T quattro [89; B3]			**2,2 l 162 kW 3B 5 Zyl.**
Air mass meter, gasoline injection	09.90-09.92		**0 280 213 007**
			0 986 280 137
Knock sensor	09.90-09.92	KZA	**0 261 231 040**
		KZG	**0 261 231 038**
Pressure sensor, intake manifold, gasoline	09.90-09.92		**0 280 101 001**
Temperature sensor, coolant, injection system	09.90-09.92		**0 280 130 037**
2.2 S2 T quattro [89; B3]			**2,2 l 169 kW ABY 5 Zyl.**
Throttle valve sensor	10.92-12.95		**0 280 120 431**
Air mass meter, gasoline injection	10.92-12.95		**0 280 213 007**
			0 986 280 137
Knock sensor			
Fg.no. →8B..P..003 310	10.92-11.92	KZA	**0 261 231 040**
Fg.no. 8B..P..003 311→	11.92-12.95	KZB	**0 261 231 036**
Pressure sensor, intake manifold, gasoline	10.92-12.95		**0 280 101 001**
2.3 [89; B3]			**2,3 l 98 kW NG 5 Zyl.**
Air flow sensor, gasoline injection	11.88-07.94		**F 026 TX2 054**
			F 026 TX2 054
Knock sensor	11.88-07.94	KZB,LLE	**0 261 231 036**
		KZG,RLE	**0 261 231 038**
Pressure sensor, intake manifold, gasoline	11.88-07.94		**0 280 101 001**
Temperature sensor, coolant, injection system	11.88-07.94	2PO	**0 280 130 053**

Product			
2.3 [89; B3]			**2,3 l 125 kW 7A 5 Zyl.**
Throttle valve sensor			
Fg.no. 8B..L..008 001→	11.89-07.91		**0 280 120 422**
Temperature sensor, coolant, injection system	08.89-07.91		**0 280 130 037**
2.3 GT [85; B2]			**2,3 l 98 kW NG 5 Zyl.**
Air flow sensor, gasoline injection	08.86-07.88		**F 026 TX2 054**
			F 026 TX2 054
Knock sensor	08.86-07.88		**0 261 231 038**
Pressure sensor, intake manifold, gasoline	08.86-07.88		**0 280 101 001**
Temperature sensor, coolant, injection system	02.87-07.88		**0 280 130 053**
Wheel speed sensor, rear	08.86-07.88		**0 265 001 099**
2.3 quattro [85; B2]			**2,3 l 98 kW NG 5 Zyl.**
Air flow sensor, gasoline injection	01.87-12.87		**F 026 TX2 054**
			F 026 TX2 054
Knock sensor	01.87-12.87	KZG	**0 261 231 038**
Pressure sensor, intake manifold, gasoline	01.87-12.87		**0 280 101 001**
Temperature sensor, coolant, injection system	01.87-12.87	2PO	**0 280 130 053**
2.3 quattro [89; B3]			**2,3 l 98 kW NG 5 Zyl.**
Air flow sensor, gasoline injection	11.88-07.94		**F 026 TX2 054**
			F 026 TX2 054
Knock sensor	11.88-07.94	KZB,LLE	**0 261 231 036**
		KZG,RLE	**0 261 231 038**
Pressure sensor, intake manifold, gasoline	11.88-07.94		**0 280 101 001**
Temperature sensor, coolant, injection system	11.88-07.94	2PO	**0 280 130 053**
2.3 quattro [89; B3]			**2,3 l 125 kW 7A 5 Zyl.**
Throttle valve sensor			
Fg.no. 8B..L..008 001→	11.89-07.91		**0 280 120 422**
Temperature sensor, coolant, injection system	11.88-07.91		**0 280 130 037**
2.6 [89; B3]			**2,6 l 110 kW ABC 6 Zyl.**
Phase sensor	08.92-12.95		**0 232 101 027**
Knock sensor	08.92-12.95	KZB	**0 261 231 036**
Temperature sensor, intake air, injection system	08.92-12.95	KZS	**0 280 130 060**
Temperature sensor, coolant, injection system	08.92-12.95	KZW	**0 280 130 040**
2.6 quattro [89; B3]			**2,6 l 110 kW ABC 6 Zyl.**
Throttle valve sensor	08.92-12.95		**0 280 120 431**
Phase sensor	08.92-12.95		**0 232 101 027**
Knock sensor	08.92-12.95	KZB	**0 261 231 036**
Temperature sensor, intake air, injection system	08.92-12.95	KZS	**0 280 130 060**
Temperature sensor, coolant, injection system	08.92-12.95	KZW	**0 280 130 040**
2.8 [89; B3]			**2,8 l 128 kW AAH 6 Zyl.**
Throttle valve sensor	09.91-12.95		**0 280 120 431**
Phase sensor	09.91-12.95		**0 232 101 027**
Knock sensor	09.91-12.95	KZB	**0 261 231 036**
Temperature sensor, coolant, injection system	09.91-12.95	KZW	**0 280 130 040**
2.8 quattro [89; B3]			**2,8 l 128 kW AAH 6 Zyl.**
Throttle valve sensor	08.91-12.95		**0 280 120 431**
Phase sensor	08.91-12.95		**0 232 101 027**
Knock sensor	08.91-12.95	KZB	**0 261 231 036**
Temperature sensor, coolant, injection system	08.91-12.95	KZW	**0 280 130 040**

Quattro

2.2 Turbo [85; B2]			**2,2 l 162 kW RR 5 Zyl.**
Air mass meter, gasoline injection	08.89-07.91		**0 280 213 007**
			0 986 280 137
Knock sensor	08.89-07.91	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, coolant, injection system	08.89-07.91		**0 280 130 037**
2.2 Turbo Sport [85; B2]			**2,2 l 225 kW KW 5 Zyl.**
Air mass meter, gasoline injection	05.84-07.87		**0 280 214 001**
			0 986 280 124
Acceleration sensor, ABS	05.84-07.87		**0 265 005 002**

A

Product			

Q7

3.0 TDI [4LB]			**3,0 l 155/171 kW BUG; BUN 6 Zyl.**
Boost pressure sensor, Diesel	03.06-11.07		**0 281 002 401**
3.6 FSI [4LB]			**3,6 l 206 kW BHK 6 Zyl.**
Air mass meter, gasoline injection	03.07→		**0 280 218 175**
4.2 FSI [4LB]			**4,2 l 257 kW BAR 8 Zyl.**
Throttle valve assembly	03.06-05.08		**0 280 750 003**
Air mass meter, gasoline injection	03.06-05.08		**0 280 218 060**
			0 986 280 216

RS4

4.2 quattro [8EC; B7]			**4,2 l 309 kW BNS 8 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	11.05→		**0 265 005 621**
Wheel speed sensor, front	11.05→		**0 265 006 809**
Wheel speed sensor, rear	11.05→	RAB	**0 265 006 824**

RS4 Avant

2.7 quattro [8D5; B5]			**2,7 l 280 kW ASJ; AZR 6 Zyl.**
Air mass meter, gasoline injection	05.00-09.01		**0 280 218 067**
			0 986 280 219
Phase sensor	05.00-09.01		**0 232 101 024**
Speed sensor, ignition/injection	05.00-09.01		**0 261 210 147**
Boost pressure sensor, gasoline	05.00-09.01		**0 281 002 177**
Temperature sensor, intake air, injection system	05.00-09.01		**0 280 130 085**
Lateral acceleration sensor, brake system	05.00-09.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	05.00-09.01		**0 265 005 214**
Yaw rate sensor, brake system	05.00-09.01		**0 265 005 207**
Wheel speed sensor, front	05.00-09.01		**0 265 006 578**
Wheel speed sensor, rear	05.00-09.01	LAB	**0 265 006 695**
		RAB	**0 265 006 693**
4.2 quattro [8ED; B7]			**4,2 l 309 kW BNS 8 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	05.06→		**0 265 005 621**
Wheel speed sensor, front	05.06→		**0 265 006 809**
Wheel speed sensor, rear	05.06→	RAB	**0 265 006 824**

RS4 Cabriolet

4.2 quattro [8HE; B7]			**4,2 l 309 kW BNS 8 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	05.06→		**0 265 005 621**
Wheel speed sensor, front	05.06→		**0 265 006 809**
Wheel speed sensor, rear	05.06→	RAB	**0 265 006 824**

RS6

4.2 quattro [4B4]			**4,2 l 331 kW BCY 8 Zyl.**
Throttle valve assembly	07.02-04.04		**0 280 750 127**
Air mass meter, gasoline injection	07.02-04.04		**0 280 218 065**
			0 986 280 218
Phase sensor	07.02-04.04		**0 232 101 024**
Speed sensor, ignition/injection	07.02-04.04		**0 261 210 192**
Knock sensor	07.02-04.04		**0 261 231 038**
Boost pressure sensor, gasoline	07.02-04.04		**0 281 002 177**
Temperature sensor, intake air, injection system	07.02-04.04		**0 280 130 060**
Duo sensor, acceleration and yaw rate, brake system	07.02-04.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	07.02-04.04		**0 265 005 303**
Wheel speed sensor, front	07.02-04.04		**0 265 006 765**
Wheel speed sensor, rear	07.02-04.04	RAB	**0 265 006 767**
Fg.no. →4B..4..900 476	07.02-08.03	LAB	**0 265 006 771**
Fg.no. 4B..4..900 477→	09.03-04.04	LAB	**0 265 006 769**

RS6 Avant

4.2 quattro [4B6]			**4,2 l 331 kW BCY 8 Zyl.**
Throttle valve assembly	05.02-04.04		**0 280 750 127**
Air mass meter, gasoline injection	05.02-04.04		**0 280 218 065**
			0 986 280 218
Phase sensor	05.02-04.04		**0 232 101 024**
Speed sensor, ignition/injection	05.02-04.04		**0 261 210 192**
Knock sensor	05.02-04.04		**0 261 231 038**
Boost pressure sensor, gasoline	05.02-04.04		**0 281 002 177**
Temperature sensor, intake air, injection system	05.02-04.04		**0 280 130 060**
Duo sensor, acceleration and yaw rate, brake system	05.02-04.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	05.02-04.04		**0 265 005 303**
Wheel speed sensor, front	05.02-04.04		**0 265 006 765**
Wheel speed sensor, rear	05.02-04.04	RAB	**0 265 006 767**
Fg.no. →4B..4..900 476	05.02-08.03	LAB	**0 265 006 771**
Fg.no. 4B..4..900 477→	09.03-04.04	LAB	**0 265 006 769**
4.2 quattro [4B6]			**4,2 l 353 kW BRV 8 Zyl.**
Throttle valve assembly	04.04-09.04		**0 280 750 127**
Air mass meter, gasoline injection	04.04-09.04		**0 280 218 065**
			0 986 280 218
Phase sensor	04.04-09.04		**0 232 101 024**
Speed sensor, ignition/injection	04.04-09.04		**0 261 210 192**
Knock sensor	04.04-09.04		**0 261 231 038**
Boost pressure sensor, gasoline	04.04-09.04		**0 281 002 177**
Temperature sensor, intake air, injection system	04.04-09.04		**0 280 130 060**
Duo sensor, acceleration and yaw rate, brake system	04.04-09.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	04.04-09.04		**0 265 005 303**
Wheel speed sensor, front	04.04-09.04		**0 265 006 765**
Wheel speed sensor, rear	04.04-09.04	LAB	**0 265 006 769**
		RAB	**0 265 006 767**

R8

4.2 quattro [423]			**4,2 l 309 kW BYH 8 Zyl.**
Throttle valve assembly			
Fg.no. →42..8..000 500	04.07-05.07		**0 280 750 003**
Air mass meter, gasoline injection	04.07→		**0 280 218 143**
Duo sensor, acceleration and yaw rate, brake system	04.07→	MBH	**0 265 005 621**
		NBA	**0 265 005 619**
Wheel speed sensor	04.07→	LAB	**0 265 007 928**
		RAB	**0 265 007 930**

S3

1.8 quattro [8L1]			**1,8 l 154 kW AMK 4 Zyl.**
Throttle valve assembly	09.00-04.02		**0 280 750 036**
Air mass meter, gasoline injection	09.00-04.02		**0 280 218 065**
			0 986 280 218
Phase sensor	09.00-04.02	NOC	**0 232 101 024**
Speed sensor, ignition/injection	09.00-04.02	FKW	**0 261 210 199**
Knock sensor	09.00-04.02		**0 261 231 146**
Boost pressure sensor, gasoline			
Fg.no. →8L..1..080 000	09.00-02.01		**0 281 002 177**
Fg.no. 8L..1..080 001→	02.01-04.02		**0 261 230 073**
Temperature sensor, intake air, injection system	09.00-04.02		**0 280 130 085**

A

Product			
◀ S3			
Accelerator pedal module	09.00-04.02	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.8 quattro [8L1]		**1,8 l 154 kW APY 4 Zyl.**	
Throttle valve assembly	08.98-08.00		**0 280 750 036**
Air mass meter, gasoline injection	08.98-08.00		**0 280 218 034**
			0 986 280 211
Phase sensor	08.98-08.00	NOC	**0 232 101 024**
Speed sensor, ignition/injection	08.98-08.00	FKW	**0 261 210 147**
Boost pressure sensor, gasoline	08.98-08.00		**0 281 002 177**
Temperature sensor, intake air, injection system	08.98-08.00		**0 280 130 085**
Accelerator pedal module	08.98-08.00	GS,LLE	**0 280 752 214**
Fg.no. 8L..Y..000 001→	05.99-08.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8L..X..090 000	08.98-04.99	GS,RLE	**0 280 752 016**
1.8 quattro [8L1]		**1,8 l 154 kW AUL 4 Zyl.**	
Air mass meter, gasoline injection	09.99-04.01		**0 280 218 034**
			0 986 280 211
Phase sensor	09.99-04.01	NOC	**0 232 101 024**
Speed sensor, ignition/injection	09.99-04.01	FKW	**0 261 210 199**
Boost pressure sensor, gasoline	09.99-04.01		**0 281 002 177**
1.8 quattro [8L1]		**1,8 l 165 kW BAM 4 Zyl.**	
Throttle valve assembly	08.01-06.03		**0 280 750 036**
Air mass meter, gasoline injection	08.01-06.03		**0 280 218 065**
			0 986 280 218
Phase sensor	08.01-06.03	NOC	**0 232 101 024**
Speed sensor, ignition/injection	08.01-06.03	FKW	**0 261 210 199**
Knock sensor	08.01-06.03		**0 261 231 146**
Boost pressure sensor, gasoline	08.01-06.03		**0 261 230 073**
Temperature sensor, intake air, injection system	08.01-06.03		**0 280 130 085**
Accelerator pedal module	08.01-06.03	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
2.0 TFSI quattro [8P1]		**2,0 l 188/195 kW BHZ; BZC 4 Zyl.**	
Speed sensor, ignition/injection	11.06→		**0 261 210 199**
Boost pressure sensor, gasoline	11.06→		**0 281 002 401**
S4			
2.2 quattro [4A2; C4]		**2,2 l 169 kW AAN 5 Zyl.**	
Air mass meter, gasoline injection	07.92-07.94		**0 280 213 007**
			0 986 280 137
Knock sensor	07.92-07.94	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
2.7 Biturbo quattro [8D2; B5]		**2,7 l 187 kW APB 6 Zyl.**	
Pedal position sensor, EMS (electronic engine management)	10.97-12.98		**0 280 752 020**
Lateral acceleration sensor, brake system	10.97-12.98		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	10.97-12.98		**0 265 005 214**
Yaw rate sensor, brake system	10.97-12.98		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-12.98	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.7 Biturbo quattro [8D2; B5]		**2,7 l 195 kW AGB 6 Zyl.**	
Air mass meter, gasoline injection			
Fg.no. →8D..Y..300 000	10.97-06.00		**0 280 218 038**
			0 986 280 212
Phase sensor	10.97-10.00		**0 232 101 024**

Product			
Knock sensor			
Fg.no. →8D..X..260 000	10.97-04.99		**0 261 231 036**
Temperature sensor, intake air, injection system	10.97-10.00		**0 280 130 085**
Pedal position sensor, EMS (electronic engine management)	10.97-10.00		**0 280 752 020**
Lateral acceleration sensor, brake system	10.97-10.00		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	10.97-10.00		**0 265 005 214**
Yaw rate sensor, brake system	10.97-10.00		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-10.00	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.7 Biturbo quattro [8D2; B5]		**2,7 l 195 kW AZB 6 Zyl.**	
Phase sensor	11.00-09.01		**0 232 101 024**
Temperature sensor, intake air, injection system	11.00-09.01		**0 280 130 085**
Pedal position sensor, EMS (electronic engine management)	11.00-09.01		**0 280 752 020**
Lateral acceleration sensor, brake system	11.00-09.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	11.00-09.01		**0 265 005 214**
Yaw rate sensor, brake system	11.00-09.01		**0 265 005 207**
Wheel speed sensor, rear	11.00-09.01	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
4.2 quattro [4A2; C4]		**4,2 l 206 kW ABH 8 Zyl.**	
Air mass meter, gasoline injection	07.92-07.94		**0 280 216 001**
Knock sensor	07.92-07.94	KZA	**0 261 231 040**
		KZG	**0 261 231 038**
Temperature sensor, coolant, injection system	07.92-07.94		**0 280 130 037**
4.2 quattro [8EC; B7]		**4,2 l 253 kW BBK 8 Zyl.**	
Throttle valve assembly	11.04→		**0 280 750 003**
Air mass meter, gasoline injection	11.04→		**0 280 218 067**
			0 986 280 219
Speed sensor, ignition/injection	11.04→		**0 261 210 190**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05→		**0 265 005 621**
Wheel speed sensor, front	11.04→		**0 265 006 809**
Wheel speed sensor, rear	11.04→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
4.2 quattro [8E2; B6]		**4,2 l 253 kW BBK 8 Zyl.**	
Throttle valve assembly	03.03-12.04		**0 280 750 003**
Air mass meter, gasoline injection	03.03-12.04		**0 280 218 067**
			0 986 280 219
Speed sensor, ignition/injection	03.03-12.04		**0 261 210 190**
Duo sensor, acceleration and yaw rate, brake system	03.03-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	03.03-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	03.03-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	03.03-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	03.03-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**

A

Product

S4 Avant

2.7 Biturbo quattro [8D5; B5]			**2,7 l 195 kW AGB 6 Zyl.**
Air mass meter, gasoline injection			
Fg.no. →8D..Y..300 000	10.97-06.00		**0 280 218 038**
			0 986 280 212
Phase sensor	10.97-09.01		**0 232 101 024**
Knock sensor			
Fg.no. →8D..X..260 000	10.97-04.99		**0 261 231 036**
Temperature sensor, intake air, injection system	10.97-09.01		**0 280 130 085**
Pedal position sensor, EMS (electronic engine management)	10.97-09.01		**0 280 752 020**
Lateral acceleration sensor, brake system	10.97-09.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	10.97-09.01		**0 265 005 214**
Yaw rate sensor, brake system	10.97-09.01		**0 265 005 207**
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-09.01	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
		OLW	**0 265 006 569**
2.7 Biturbo quattro [8D5; B5]			**2,7 l 195 kW AZB 6 Zyl.**
Phase sensor	11.00-09.01		**0 232 101 024**
Temperature sensor, intake air, injection system	11.00-09.01		**0 280 130 085**
Pedal position sensor, EMS (electronic engine management)	11.00-09.01		**0 280 752 020**
Lateral acceleration sensor, brake system	11.00-09.01		**0 265 005 127**
Duo sensor, acceleration and yaw rate, brake system	11.00-09.01		**0 265 005 214**
Yaw rate sensor, brake system	11.00-09.01		**0 265 005 207**
Wheel speed sensor, rear	11.00-09.01	ALR,LAB	**0 265 006 571**
		ALR,RAB	**0 265 006 569**
4.2 quattro [8ED; B7]			**4,2 l 253 kW BBK; BHF 8 Zyl.**
Throttle valve assembly	11.04→		**0 280 750 003**
Air mass meter, gasoline injection	11.04→		**0 280 218 067**
			0 986 280 219
Speed sensor, ignition/injection	11.04→		**0 261 210 190**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		**0 265 005 601**
Fg.no. 8E..6..000 001→	06.05→		**0 265 005 621**
Wheel speed sensor, front	11.04→		**0 265 006 809**
Wheel speed sensor, rear	11.04→	ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**
4.2 quattro [8E5; B6]			**4,2 l 253 kW BBK 8 Zyl.**
Throttle valve assembly	03.03-12.04		**0 280 750 003**
Air mass meter, gasoline injection	03.03-12.04		**0 280 218 067**
			0 986 280 219
Speed sensor, ignition/injection	03.03-12.04		**0 261 210 190**
Duo sensor, acceleration and yaw rate, brake system	03.03-12.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	03.03-12.04		**0 265 005 303**
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	03.03-05.03		**0 265 006 683**
Fg.no. 8E..4..000 001→	06.03-12.04		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	03.03-05.04	ALR,LAB	**0 265 006 707**
Fg.no. →8E..4..400 000	03.03-05.04	ALR,RAB	**0 265 006 681**
		OLW	**0 265 006 681**
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	**0 265 006 826**
		ALR,RAB	**0 265 006 824**
		OLW	**0 265 006 824**

Product

S4 Cabriolet

4.2 quattro [8HE; B7]			**4,2 l 253 kW BBK 8 Zyl.**
Throttle valve assembly	01.06→		**0 280 750 003**
Air mass meter, gasoline injection	01.06→		**0 280 218 067**
			0 986 280 219
Speed sensor, ignition/injection	01.06→		**0 261 210 190**
Duo sensor, acceleration and yaw rate, brake system	01.06→		**0 265 005 621**
Pressure sensor, ESP, (electronic stability program)	01.06→		**0 265 005 303**
Wheel speed sensor, front	01.06→		**0 265 006 809**
Wheel speed sensor, rear	01.06→	RAB	**0 265 006 824**
4.2 quattro [8H7; B7]			**4,2 l 253 kW BBK; BHF 8 Zyl.**
Throttle valve assembly	02.04-06.06		**0 280 750 003**
Air mass meter, gasoline injection	02.04-06.06		**0 280 218 067**
			0 986 280 219
Speed sensor, ignition/injection	02.04-06.06		**0 261 210 190**
Duo sensor, acceleration and yaw rate, brake system	02.04-06.06		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	02.04-06.06		**0 265 005 303**
Wheel speed sensor, front	02.04-06.06		**0 265 006 809**
Wheel speed sensor, rear			
Fg.no. →8H..4..050 000,→8H..4..902 000, PR no. 8Q3	02.04-05.04	LAB	**0 265 006 707**
Fg.no. 8H..5..000 001→,8H..5..900 001→, PR no. 8Q3	06.04-06.06	LAB	**0 265 006 826**
PR no. 8Q0,PR no. 8Q1	02.04-06.06		**0 265 006 681**
PR no. 8Q3	02.04-06.06	RAB	**0 265 006 681**

S5 Coupé

4.2 quattro [8T3]			**4,2 l 260 kW CAUA 8 Zyl.**
Throttle valve assembly	06.07→		**0 280 750 003**
Air mass meter, gasoline injection	06.07→		**0 280 218 214**
Duo sensor, acceleration and yaw rate, brake system	06.07→		**0 265 005 668**
Wheel speed sensor	06.07→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**

S6

2.2 T quattro [4A2; C4]			**2,2 l 169 kW AAN 5 Zyl.**
Throttle valve sensor	06.94-07.97		**0 280 120 431**
Air mass meter, gasoline injection	06.94-07.97		**0 280 213 007**
			0 986 280 137
Phase sensor	06.94-07.97		**0 232 101 020**
Knock sensor	06.94-07.97	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
4.2 Plus quattro [4A2; C4]			**4,2 l 240 kW AHK 8 Zyl.**
Throttle valve sensor	06.96-10.97		**0 280 120 431**
Air mass meter, gasoline injection	06.96-10.97		**0 280 217 817**
Phase sensor	06.96-10.97	NOC	**0 232 101 024**
Speed sensor, ignition/injection	06.96-10.97		**0 261 210 111**
Knock sensor	06.96-10.97	KZA	**0 261 231 040**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	06.96-10.97	KZS	**0 280 130 060**
4.2 quattro [4A2; C4]			**4,2 l 213 kW AEC 8 Zyl.**
Air mass meter, gasoline injection	09.94-07.97		**0 280 216 001**
Knock sensor	09.94-07.97	KZA	**0 261 231 040**
		KZG	**0 261 231 038**
4.2 quattro [4B4; C5]			**4,2 l 250 kW ANK 8 Zyl.**
Air mass meter, gasoline injection	06.01-05.04		**0 280 218 069**
			0 986 280 220

A

Product			
◀ S6			
Phase sensor	06.01-05.04		0 232 101 024
Speed sensor, ignition/injection	06.01-05.04	AG	0 261 210 190
		GS	0 261 210 192
Knock sensor	06.01-05.04		0 261 231 038
Duo sensor, acceleration and yaw rate, brake system	06.01-05.04		0 265 005 252
Wheel speed sensor, front			
Fg.no. 4B..3..000 001→	07.02-05.04		0 265 006 765
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	06.01-12.01	RAB	0 265 006 565
Fg.no. 4B..2..079 501→	01.02-05.04	LAB	0 265 006 771
		RAB	0 265 006 767
4.2 quattro [4B4; C5]		**4,2 l 250 kW AQJ 8 Zyl.**	
Phase sensor	09.99-05.01		0 232 101 024
Speed sensor, ignition/injection	09.99-05.01	AG	0 261 210 190
		GS	0 261 210 192
Knock sensor	09.99-05.01		0 261 231 038
Duo sensor, acceleration and yaw rate, brake system	09.99-05.01		0 265 005 214
Wheel speed sensor, front	09.99-05.01		0 265 006 578
Wheel speed sensor, rear	09.99-05.01	RAB	0 265 006 565
5.2 FSI quattro [4F2; C6]		**5,2 l 320 kW BXA 10 Zyl.**	
Throttle valve assembly	06.06→		0 280 750 003
Air mass meter, gasoline injection	06.06→		0 280 218 143
Duo sensor, acceleration and yaw rate, brake system	06.06→		0 265 005 692
Wheel speed sensor	06.06→	LAB	0 265 007 930
		RAB	0 265 007 928

S6 Avant

2.2 T quattro [4A5; C4]		**2,2 l 169 kW AAN 5 Zyl.**	
Throttle valve sensor	06.94-07.97		0 280 120 431
Air mass meter, gasoline injection	06.94-07.97		0 280 213 007
			0 986 280 137
Phase sensor	06.94-07.97		0 232 101 020
Knock sensor	06.94-07.97	KZB	0 261 231 036
		KZG	0 261 231 038
4.2 Plus quattro [4A5; C4]		**4,2 l 240 kW AHK 8 Zyl.**	
Throttle valve sensor	06.96-10.97		0 280 120 431
Air mass meter, gasoline injection	06.96-10.97		0 280 217 817
Phase sensor	06.96-10.97	NOC	0 232 101 024
Speed sensor, ignition/injection	06.96-10.97		0 261 210 111
Knock sensor	06.96-10.97	KZA	0 261 231 040
		KZG	0 261 231 038
Temperature sensor, intake air, injection system	06.96-10.97	KZS	0 280 130 060
4.2 quattro [4A5; C4]		**4,2 l 213 kW AEC 8 Zyl.**	
Air mass meter, gasoline injection	09.94-07.97		0 280 216 001
Knock sensor	09.94-07.97	KZA	0 261 231 040
		KZG	0 261 231 038
4.2 quattro [4B6; C5]		**4,2 l 250 kW ANK 8 Zyl.**	
Air mass meter, gasoline injection	06.01-01.05		0 280 218 069
			0 986 280 220
Phase sensor	06.01-01.05		0 232 101 024
Speed sensor, ignition/injection	06.01-01.05	AG	0 261 210 190
		GS	0 261 210 192
Knock sensor	06.01-01.05		0 261 231 038
Duo sensor, acceleration and yaw rate, brake system	06.01-01.05		0 265 005 252
Wheel speed sensor, front			
Fg.no. 4B..3..000 001→	07.02-01.05		0 265 006 765
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	06.01-12.01	RAB	0 265 006 565
Fg.no. 4B..2..079 501→	01.02-05.04	LAB	0 265 006 771
		RAB	0 265 006 767
4.2 quattro [4B6; C5]		**4,2 l 250 kW AQJ 8 Zyl.**	
Phase sensor	09.99-05.01		0 232 101 024
Speed sensor, ignition/injection	09.99-05.01	AG	0 261 210 190
		GS	0 261 210 192
Knock sensor	09.99-05.01		0 261 231 038
Duo sensor, acceleration and yaw rate, brake system	09.99-05.01		0 265 005 214
Wheel speed sensor, front	09.99-05.01		0 265 006 578
Wheel speed sensor, rear	09.99-05.01	RAB	0 265 006 565
4.2 quattro [4B6; C5]		**4,2 l 250 kW BBD 8 Zyl.**	
Throttle valve assembly	06.01-07.04		0 280 750 003
Air mass meter, gasoline injection	06.01-07.04		0 280 218 067
			0 986 280 219
Phase sensor	06.01-07.04		0 232 101 024
Speed sensor, ignition/injection	06.01-07.04		0 261 210 190
Knock sensor	06.01-07.04		0 261 231 038
Duo sensor, acceleration and yaw rate, brake system	06.01-07.04		0 265 005 252
Wheel speed sensor, front			
Fg.no. →4B..2..031 500	06.01-08.01		0 265 006 578
Fg.no. 4B..3..000 001→	07.02-07.04		0 265 006 765
Wheel speed sensor, rear			
Fg.no. 4B..2..079 501→4B..4..027 600	01.02-08.03	LAB	0 265 006 771
Fg.no. 4B..4..900 477→	09.03-07.04	LAB	0 265 006 769
5.2 FSI quattro [4F5; C6]		**5,2 l 320 kW BXA 10 Zyl.**	
Throttle valve assembly	06.06→		0 280 750 003
Air mass meter, gasoline injection	06.06→		0 280 218 143
Duo sensor, acceleration and yaw rate, brake system	06.06→		0 265 005 601
Wheel speed sensor	06.06→	LAB	0 265 007 930
		RAB	0 265 007 928

S8

4.2 quattro [4D2]		**4,2 l 250 kW AHC; AKH 8 Zyl.**	
Throttle valve sensor	09.96-12.98		0 280 120 431
Air mass meter, gasoline injection	09.96-12.98		0 280 217 817
Phase sensor	09.96-12.98		0 232 101 024
Speed sensor, ignition/injection	09.96-12.98	AG	0 261 210 143
		GS	0 261 210 111
Knock sensor	09.96-12.98	LAB	0 261 231 040
		RAB	0 261 231 038
Temperature sensor, intake air, injection system	09.96-12.98	KZS	0 280 130 060
Pedal position sensor, EMS (electronic engine management)	09.96-12.98		0 280 752 022
Lateral acceleration sensor, brake system	09.96-12.98		0 265 005 127
Yaw rate sensor, brake system	09.96-12.98		0 265 005 207
Wheel speed sensor, front			
Fg.no. 4D..X..005 001→	10.98-12.98	16R,FKR	0 265 006 580
		20R,FKR	0 265 006 662
Wheel speed sensor, rear	09.96-12.98	FKR	0 265 006 588
4.2 quattro [4D2]		**4,2 l 265 kW AQH 8 Zyl.**	
Phase sensor	05.99-02.01		0 232 101 024
Speed sensor, ignition/injection	05.99-02.01	AG	0 261 210 190
		GS	0 261 210 192
Knock sensor	05.99-02.01	KZG	0 261 231 038
Pedal position sensor, EMS (electronic engine management)	05.99-02.01		0 280 752 022
Lateral acceleration sensor, brake system	05.99-02.01		0 265 005 127

Product			
Yaw rate sensor, brake system	05.99-02.01		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	05.99-02.01		**0 265 005 303**
Wheel speed sensor, front	05.99-02.01	16R,FKR	**0 265 006 580**
		20R,FKR	**0 265 006 662**
Wheel speed sensor, rear	05.99-02.01	FKR	**0 265 006 588**
4.2 quattro [4D2]		**4,2 l 265 kW AVP 8 Zyl.**	
Air mass meter, gasoline injection	09.00-09.02		**0 280 218 067**
			0 986 280 219
Phase sensor	09.00-09.02		**0 232 101 024**
Speed sensor, ignition/injection	09.00-09.02	AG	**0 261 210 190**
		GS	**0 261 210 192**
Knock sensor	09.00-09.02	KZG	**0 261 231 038**
Pedal position sensor, EMS (electronic engine management)	09.00-09.02		**0 280 752 022**
Lateral acceleration sensor, brake system	09.00-09.02		**0 265 005 127**
Yaw rate sensor, brake system	09.00-09.02		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	09.00-09.02		**0 265 005 303**
Wheel speed sensor, front	09.00-09.02	16R,FKR	**0 265 006 580**
		20R,FKR	**0 265 006 662**
Wheel speed sensor, rear	09.00-09.02	FKR	**0 265 006 588**
4.2 quattro [4D2]		**4,2 l 265 kW AYS; BCS 8 Zyl.**	
Air mass meter, gasoline injection	09.00-09.02		**0 280 218 067**
			0 986 280 219
Phase sensor	09.00-09.02		**0 232 101 024**
Speed sensor, ignition/injection	09.00-09.02	AG	**0 261 210 190**
		GS	**0 261 210 192**
Knock sensor	09.00-09.02	KZG	**0 261 231 038**
Lateral acceleration sensor, brake system	09.00-09.02		**0 265 005 127**
Yaw rate sensor, brake system	09.00-09.02		**0 265 005 207**
Pressure sensor, ESP, (electronic stability program)	09.00-09.02		**0 265 005 303**
Wheel speed sensor, front	09.00-09.02	16R,FKR	**0 265 006 580**
		20R,FKR	**0 265 006 662**
Wheel speed sensor, rear	09.00-09.02	FKR	**0 265 006 588**
5.2 FSI quattro [4E2]		**5,2 l 331 kW BSM 10 Zyl.**	
Throttle valve assembly	06.06→		**0 280 750 003**
Air mass meter, gasoline injection	06.06→		**0 280 218 143**
Duo sensor, acceleration and yaw rate, brake system	06.06→		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	06.06→		**0 265 005 303**
Wheel speed sensor	06.06→	LAB,OSS	**0 265 007 930**
		OSS,RAB	**0 265 007 928**

TT Coupé

Product			
1.8 T [8N3]		**1,8 l 110 kW AUM 4 Zyl.**	
Throttle valve assembly	01.01-06.06		**0 280 750 036**
Air mass meter, gasoline injection	01.01-06.06		**0 280 218 063**
			0 986 280 217
Phase sensor	01.01-06.06		**0 232 101 024**
Speed sensor, ignition/injection	01.01-06.06		**0 261 210 199**
Knock sensor	01.01-06.06		**0 261 231 146**
Boost pressure sensor, gasoline			
Fg.no. →8N..3..050 000	01.01-05.03		**0 281 002 177**
Fg.no. 8N..4..000 001→	06.03-06.06		**0 261 230 073**
Temperature sensor, intake air, injection system	01.01-06.06		**0 280 130 085**
Accelerator pedal module	01.01-06.06	GS,LLE	**0 280 752 214**
	01.01-08.02	RLE	**0 280 752 210**
1.8 T [8N3]		**1,8 l 120 kW BVP 4 Zyl.**	
Throttle valve assembly	09.05-06.06		**0 280 750 036**
Air mass meter, gasoline injection	09.05-06.06		**0 280 218 063**
			0 986 280 217
Phase sensor	09.05-06.06		**0 232 101 024**
Speed sensor, ignition/injection	09.05-06.06		**0 261 210 199**
Knock sensor	09.05-06.06		**0 261 231 146**
Boost pressure sensor, gasoline	09.05-06.06		**0 261 230 073**
Temperature sensor, intake air, injection system	09.05-06.06		**0 280 130 085**
Accelerator pedal module	09.05-06.06	GS,LLE	**0 280 752 214**
1.8 T [8N3]		**1,8 l 132 kW AJQ 4 Zyl.**	
Throttle valve assembly	07.98-08.00		**0 280 750 036**
Air mass meter, gasoline injection			
Fg.no. →8N..Y..050 000	07.98-11.99		**0 280 218 023**
			0 986 280 209
Fg.no. 8N..Y..050 001→	12.99-08.00		**0 280 218 032**
			0 986 280 210
Phase sensor	07.98-08.00		**0 232 101 024**
Speed sensor, ignition/injection	07.98-08.00		**0 261 210 147**
Pressure sensor, intake manifold, gasoline	07.98-08.00		**0 280 101 001**
Boost pressure sensor, gasoline	07.98-08.00		**0 281 002 177**
Temperature sensor, intake air, injection system	07.98-08.00		**0 280 130 085**
Accelerator pedal module	07.98-08.00	LLE	**0 280 752 214**
Fg.no. 8N..Y..080 001→	04.00-08.00	RLE	**0 280 752 210**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8N..Y..080 000	07.98-03.00	RLE	**0 280 752 016**
1.8 T [8N3]		**1,8 l 132 kW APP 4 Zyl.**	
Throttle valve assembly	11.99-09.00		**0 280 750 036**
Air mass meter, gasoline injection	11.99-09.00		**0 280 218 032**
			0 986 280 210
Phase sensor	11.99-09.00		**0 232 101 024**
Speed sensor, ignition/injection	11.99-09.00		**0 261 210 147**
Pressure sensor, intake manifold, gasoline	11.99-09.00		**0 280 101 001**
Boost pressure sensor, gasoline	11.99-09.00		**0 281 002 177**
Temperature sensor, intake air, injection system	11.99-09.00		**0 280 130 085**
Accelerator pedal module	11.99-09.00	LLE	**0 280 752 214**
Fg.no. 8N..Y..080 001→	04.00-09.00	RLE	**0 280 752 210**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8N..Y..080 000	11.99-03.00	RLE	**0 280 752 016**
1.8 T [8N3]		**1,8 l 132 kW ATC 4 Zyl.**	
Throttle valve assembly	03.99-08.00		**0 280 750 036**
Air mass meter, gasoline injection	03.99-08.00		**0 280 218 032**
			0 986 280 210
Phase sensor	03.99-08.00		**0 232 101 024**
Temperature sensor, intake air, injection system	03.99-08.00		**0 280 130 085**
Accelerator pedal module	03.99-08.00	GS	**0 280 752 214**
1.8 T [8N3]		**1,8 l 132 kW AUQ 4 Zyl.**	
Throttle valve assembly	09.00-06.06		**0 280 750 036**
Air mass meter, gasoline injection	09.00-06.06		**0 280 218 063**
			0 986 280 217
Phase sensor	09.00-06.06		**0 232 101 024**
Speed sensor, ignition/injection	09.00-06.06		**0 261 210 199**
Knock sensor	09.00-06.06		**0 261 231 146**
Boost pressure sensor, gasoline			
Fg.no. →8N..3..050 000	09.00-05.03		**0 281 002 177**
Fg.no. 8N..4..000 001→	06.03-06.06		**0 261 230 073**
Temperature sensor, intake air, injection system	09.00-06.06		**0 280 130 085**
Accelerator pedal module	09.00-06.06	GS,LLE	**0 280 752 214**
	09.00-08.02	RLE	**0 280 752 210**
1.8 T [8N3]		**1,8 l 132 kW AWP 4 Zyl.**	
Throttle valve assembly	09.02-06.06		**0 280 750 036**
Air mass meter, gasoline injection	09.00-06.06		**0 280 218 063**
			0 986 280 217
Phase sensor	09.00-06.06		**0 232 101 024**
Speed sensor, ignition/injection	09.00-06.06		**0 261 210 199**
Knock sensor	09.00-06.06		**0 261 231 146**

A

Product			
◀ TT Coupé			
Boost pressure sensor, gasoline			
Fg.no. →8N..3..050 000	09.00-05.03		**0 281 002 177**
Fg.no. 8N..4..000 001→	06.03-06.06		**0 261 230 073**
Temperature sensor, intake air, injection system	09.00-06.06		**0 280 130 085**
Accelerator pedal module	09.00-06.06	GS	**0 280 752 214**
1.8 T [8N3]			**1,8 l 140 kW BVR 4 Zyl.**
Throttle valve assembly	09.05-06.06		**0 280 750 036**
Air mass meter, gasoline injection	09.05-06.06		**0 280 218 063**
			0 986 280 217
Phase sensor	09.05-06.06		**0 232 101 024**
Speed sensor, ignition/injection	09.05-06.06		**0 261 210 199**
Knock sensor	09.05-06.06		**0 261 231 146**
Boost pressure sensor, gasoline	09.05-06.06		**0 261 230 073**
Temperature sensor, intake air, injection system	09.05-06.06		**0 280 130 085**
Accelerator pedal module	09.05-06.06	GS,LLE	**0 280 752 214**
1.8 T quattro [8N3]			**1,8 l 132 kW AJQ 4 Zyl.**
Throttle valve assembly	07.98-08.00		**0 280 750 036**
Air mass meter, gasoline injection			
Fg.no. →8N..Y..050 000	07.98-11.99		**0 280 218 023**
			0 986 280 209
Fg.no. 8N..Y..050 001→	12.99-08.00		**0 280 218 032**
			0 986 280 210
Phase sensor	07.98-08.00		**0 232 101 024**
Speed sensor, ignition/injection	07.98-08.00		**0 261 210 147**
Pressure sensor, intake manifold, gasoline	07.98-08.00		**0 280 101 001**
Boost pressure sensor, gasoline	07.98-08.00		**0 281 002 177**
Temperature sensor, intake air, injection system	07.98-08.00		**0 280 130 085**
Accelerator pedal module	07.98-08.00	LLE	**0 280 752 214**
Fg.no. 8N..Y..080 001→	04.00-08.00	RLE	**0 280 752 210**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8N..Y..080 000	07.98-03.00	RLE	**0 280 752 016**
1.8 T quattro [8N3]			**1,8 l 132 kW ARY 4 Zyl.**
Throttle valve assembly	09.00-05.05		**0 280 750 036**
Air mass meter, gasoline injection	09.00-05.05		**0 280 218 063**
			0 986 280 217
Phase sensor	09.00-05.05		**0 232 101 024**
Speed sensor, ignition/injection	09.00-05.05		**0 261 210 199**
Knock sensor	09.00-05.05		**0 261 231 146**
Boost pressure sensor, gasoline			
Fg.no. →8N..3..050 000	09.00-05.03		**0 281 002 177**
Fg.no. 8N..4..000 001→	06.03-05.05		**0 261 230 073**
Temperature sensor, intake air, injection system	09.00-05.05		**0 280 130 085**
Accelerator pedal module	09.00-05.05	GS,LLE	**0 280 752 214**
	09.00-08.02	RLE	**0 280 752 210**
1.8 T quattro [8N3]			**1,8 l 132 kW ATC 4 Zyl.**
Throttle valve assembly	11.99-08.00		**0 280 750 036**
Air mass meter, gasoline injection	11.99-08.00		**0 280 218 032**
			0 986 280 210
Phase sensor	11.99-08.00		**0 232 101 024**
Temperature sensor, intake air, injection system	11.99-08.00		**0 280 130 085**
Accelerator pedal module	11.99-08.00	GS	**0 280 752 214**
1.8 T quattro [8N3]			**1,8 l 132 kW AUQ 4 Zyl.**
Throttle valve assembly	06.05-06.06		**0 280 750 036**
Air mass meter, gasoline injection	06.05-06.06		**0 280 218 063**
			0 986 280 217
Phase sensor	06.05-06.06		**0 232 101 024**
Speed sensor, ignition/injection	06.05-06.06		**0 261 210 199**
Knock sensor	06.05-06.06		**0 261 231 146**
Boost pressure sensor, gasoline	06.05-06.06		**0 261 230 073**
Temperature sensor, intake air, injection system	06.05-06.06		**0 280 130 085**
Accelerator pedal module	06.05-06.06	GS,LLE	**0 280 752 214**

Product			
1.8 T quattro [8N3]			**1,8 l 132 kW AWP 4 Zyl.**
Air mass meter, gasoline injection	09.00-08.02		**0 280 218 063**
			0 986 280 217
Phase sensor	09.00-08.02		**0 232 101 024**
Speed sensor, ignition/injection	09.00-08.02		**0 261 210 199**
Knock sensor	09.00-08.02		**0 261 231 146**
Boost pressure sensor, gasoline	09.00-08.02		**0 281 002 177**
Temperature sensor, intake air, injection system	09.00-08.02		**0 280 130 085**
Accelerator pedal module	09.00-08.02	GS	**0 280 752 214**
1.8 T quattro [8N3]			**1,8 l 140 kW BVR 4 Zyl.**
Throttle valve assembly	09.05-06.06		**0 280 750 036**
Air mass meter, gasoline injection	09.05-06.06		**0 280 218 063**
			0 986 280 217
Phase sensor	09.05-06.06		**0 232 101 024**
Speed sensor, ignition/injection	09.05-06.06		**0 261 210 199**
Knock sensor	09.05-06.06		**0 261 231 146**
Boost pressure sensor, gasoline	09.05-06.06		**0 261 230 073**
Temperature sensor, intake air, injection system	09.05-06.06		**0 280 130 085**
Accelerator pedal module	09.05-06.06	GS,LLE	**0 280 752 214**
1.8 T quattro [8N3]			**1,8 l 165 kW AMU 4 Zyl.**
Throttle valve assembly	03.00-08.02		**0 280 750 036**
Air mass meter, gasoline injection	03.00-08.02		**0 280 218 034**
			0 986 280 211
Phase sensor	03.00-08.02		**0 232 101 024**
Temperature sensor, intake air, injection system	03.00-08.02		**0 280 130 085**
Accelerator pedal module	03.00-08.02	GS	**0 280 752 214**
1.8 T quattro [8N3]			**1,8 l 165 kW APX 4 Zyl.**
Throttle valve assembly	07.98-08.01		**0 280 750 036**
Air mass meter, gasoline injection	07.98-08.01		**0 280 218 034**
			0 986 280 211
Phase sensor	07.98-08.01		**0 232 101 024**
Speed sensor, ignition/injection	07.98-08.01		**0 261 210 147**
Boost pressure sensor, gasoline			
Fg.no. →8N..1..031 000	07.98-01.01		**0 281 002 177**
Fg.no. 8N..1..031 001→	02.01-08.01		**0 261 230 073**
Temperature sensor, intake air, injection system	07.98-08.01		**0 280 130 085**
Accelerator pedal module	07.98-08.01	LLE	**0 280 752 214**
Fg.no. 8N..Y..080 001→	04.00-08.01	RLE	**0 280 752 210**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8N..Y..080 000	07.98-03.00	RLE	**0 280 752 016**
1.8 T quattro [8N3]			**1,8 l 165 kW BAM 4 Zyl.**
Throttle valve assembly	09.00-06.06		**0 280 750 036**
Air mass meter, gasoline injection	09.00-06.06		**0 280 218 065**
			0 986 280 218
Phase sensor	09.00-06.06		**0 232 101 024**
Speed sensor, ignition/injection	09.02-06.06		**0 261 210 178**
	09.00-08.02		**0 261 210 199**
Knock sensor	09.00-06.06		**0 261 231 146**
Boost pressure sensor, gasoline			
Fg.no. →8N..1..031 000	09.00-01.01		**0 281 002 177**
Fg.no. 8N..1..031 001→	02.01-06.06		**0 261 230 073**
Temperature sensor, intake air, injection system	09.00-06.06		**0 280 130 085**
Accelerator pedal module	09.00-06.06	GS,LLE	**0 280 752 214**
	09.00-08.02	RLE	**0 280 752 210**
2.0 TFSI [8J3]			**2,0 l 147 kW BWA 4 Zyl.**
Speed sensor, ignition/injection	07.06→		**0 261 210 199**
Boost pressure sensor, gasoline	07.06→		**0 261 230 073**
3.2 quattro [8J3]			**3,2 l 184 kW BUB 6 Zyl.**
Air mass meter, gasoline injection	07.06→		**0 280 218 073**
			0 986 280 222
Phase sensor	07.06→		**0 232 103 019**
Knock sensor	07.06→	OHL	**0 261 231 146**

Product			
3.2 quattro [8N3]			**3,2 l 184 kW BHE 6 Zyl.**
Air mass meter, gasoline injection	07.03-06.06		**0 280 218 073**
			0 986 280 222
Phase sensor	07.03-06.06		**0 232 103 019**
Knock sensor	07.03-06.06	OHL	**0 261 231 146**
Accelerator pedal module	07.03-06.06	GS,LLE	**0 280 752 214**

TT Roadster

1.8 T [8N9]			**1,8 l 110 kW AUM 4 Zyl.**
Throttle valve assembly	01.01-06.06		**0 280 750 036**
Air mass meter, gasoline injection	01.01-06.06		**0 280 218 063**
			0 986 280 217
Phase sensor	01.01-06.06		**0 232 101 024**
Speed sensor, ignition/injection	01.01-06.06		**0 261 210 199**
Knock sensor	01.01-06.06		**0 261 231 146**
Boost pressure sensor, gasoline	01.01-06.06		**0 281 002 177**
Fg.no. →8N..3..050 000	01.01-05.03		**0 281 002 177**
Fg.no. 8N..4..000 001→	06.03-06.06		**0 261 230 073**
Temperature sensor, intake air, injection system	01.01-06.06		**0 280 130 085**
Accelerator pedal module	01.01-06.06	GS,LLE	**0 280 752 214**
	01.01-08.02	RLE	**0 280 752 210**
1.8 T [8N9]			**1,8 l 120 kW BVP 4 Zyl.**
Throttle valve assembly	09.05-06.06		**0 280 750 036**
Air mass meter, gasoline injection	09.05-06.06		**0 280 218 063**
			0 986 280 217
Phase sensor	09.05-06.06		**0 232 101 024**
Speed sensor, ignition/injection	09.05-06.06		**0 261 210 199**
Knock sensor	09.05-06.06		**0 261 231 146**
Boost pressure sensor, gasoline	09.05-06.06		**0 261 230 073**
Temperature sensor, intake air, injection system	09.05-06.06		**0 280 130 085**
Accelerator pedal module	09.05-06.06	GS,LLE	**0 280 752 214**
1.8 T [8N9]			**1,8 l 132 kW AJQ 4 Zyl.**
Throttle valve assembly	04.99-08.00		**0 280 750 036**
Air mass meter, gasoline injection			
Fg.no. →8N..Y..050 000	04.99-11.99		**0 280 218 023**
			0 986 280 209
Fg.no. 8N..Y..050 001→	12.99-08.00		**0 280 218 032**
			0 986 280 210
Phase sensor	04.99-08.00		**0 232 101 024**
Speed sensor, ignition/injection	04.99-08.00		**0 261 210 147**
Pressure sensor, intake manifold, gasoline	04.99-08.00		**0 280 101 001**
Boost pressure sensor, gasoline	04.99-08.00		**0 281 002 177**
Temperature sensor, intake air, injection system	04.99-08.00		**0 280 130 085**
Accelerator pedal module	04.99-08.00	LLE	**0 280 752 214**
Fg.no. 8N..Y..080 001→	04.00-08.00	RLE	**0 280 752 210**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8N..Y..080 000	04.99-03.00	RLE	**0 280 752 016**
1.8 T [8N9]			**1,8 l 132 kW APP 4 Zyl.**
Throttle valve assembly	09.99-10.01		**0 280 750 036**
Air mass meter, gasoline injection	09.99-10.01		**0 280 218 032**
			0 986 280 210
Phase sensor	09.99-10.01		**0 232 101 024**
Speed sensor, ignition/injection	09.99-10.01		**0 261 210 147**
Pressure sensor, intake manifold, gasoline	09.99-10.01		**0 280 101 001**
Boost pressure sensor, gasoline	09.99-10.01		**0 281 002 177**
Temperature sensor, intake air, injection system	09.99-10.01		**0 280 130 085**
Accelerator pedal module	09.99-10.01	LLE	**0 280 752 214**
Fg.no. 8N..Y..080 001→	04.00-10.01	RLE	**0 280 752 210**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8N..Y..080 000	09.99-03.00	RLE	**0 280 752 016**

Product			
1.8 T [8N9]			**1,8 l 132 kW ATC 4 Zyl.**
Throttle valve assembly	11.99-08.00		**0 280 750 036**
Air mass meter, gasoline injection	11.99-08.00		**0 280 218 032**
			0 986 280 210
Phase sensor	11.99-08.00		**0 232 101 024**
Temperature sensor, intake air, injection system	11.99-08.00		**0 280 130 085**
Accelerator pedal module	11.99-08.00	GS	**0 280 752 214**
1.8 T [8N9]			**1,8 l 132 kW AUQ 4 Zyl.**
Throttle valve assembly	08.00-06.06		**0 280 750 036**
Air mass meter, gasoline injection	08.00-06.06		**0 280 218 063**
			0 986 280 217
Phase sensor	08.00-06.06		**0 232 101 024**
Speed sensor, ignition/injection	08.00-06.06		**0 261 210 199**
Knock sensor	08.00-06.06		**0 261 231 146**
Boost pressure sensor, gasoline	08.00-06.06		**0 281 002 177**
Fg.no. →8N..3..050 000	08.00-05.03		**0 281 002 177**
Fg.no. 8N..4..000 001→	06.03-06.06		**0 261 230 073**
Temperature sensor, intake air, injection system	08.00-06.06		**0 280 130 085**
Accelerator pedal module	08.00-06.06	GS,LLE	**0 280 752 214**
	08.00-08.02	RLE	**0 280 752 210**
1.8 T [8N9]			**1,8 l 132 kW AWP 4 Zyl.**
Air mass meter, gasoline injection	09.00-08.02		**0 280 218 063**
			0 986 280 217
Phase sensor	09.00-08.02		**0 232 101 024**
Speed sensor, ignition/injection	09.00-08.02		**0 261 210 199**
Knock sensor	09.00-08.02		**0 261 231 146**
Boost pressure sensor, gasoline	09.00-08.02		**0 281 002 177**
Temperature sensor, intake air, injection system	09.00-08.02		**0 280 130 085**
Accelerator pedal module	09.00-08.02	GS	**0 280 752 214**
1.8 T [8N9]			**1,8 l 140 kW BVR 4 Zyl.**
Throttle valve assembly	09.05-06.06		**0 280 750 036**
Air mass meter, gasoline injection	09.05-06.06		**0 280 218 063**
			0 986 280 217
Phase sensor	09.05-06.06		**0 232 101 024**
Speed sensor, ignition/injection	09.05-06.06		**0 261 210 199**
Knock sensor	09.05-06.06		**0 261 231 146**
Boost pressure sensor, gasoline	09.05-06.06		**0 261 230 073**
Temperature sensor, intake air, injection system	09.05-06.06		**0 280 130 085**
Accelerator pedal module	09.05-06.06	GS,LLE	**0 280 752 214**
1.8 T quattro [8N9]			**1,8 l 132 kW AJQ 4 Zyl.**
Throttle valve assembly	07.99-08.00		**0 280 750 036**
Air mass meter, gasoline injection			
Fg.no. →8N..Y..050 000	07.99-11.99		**0 280 218 023**
			0 986 280 209
Fg.no. 8N..Y..050 001→	12.99-08.00		**0 280 218 032**
			0 986 280 210
Phase sensor	07.99-08.00		**0 232 101 024**
Speed sensor, ignition/injection	07.99-08.00		**0 261 210 147**
Pressure sensor, intake manifold, gasoline	07.99-08.00		**0 280 101 001**
Boost pressure sensor, gasoline	07.99-08.00		**0 281 002 177**
Temperature sensor, intake air, injection system	07.99-08.00		**0 280 130 085**
Accelerator pedal module	07.99-08.00	LLE	**0 280 752 214**
Fg.no. 8N..Y..080 001→	04.00-08.00	RLE	**0 280 752 210**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8N..Y..080 000	07.99-03.00	RLE	**0 280 752 016**
1.8 T quattro [8N9]			**1,8 l 132 kW ARY 4 Zyl.**
Throttle valve assembly	09.00-05.05		**0 280 750 036**
Air mass meter, gasoline injection	09.00-05.05		**0 280 218 063**
			0 986 280 217
Phase sensor	09.00-05.05		**0 232 101 024**
Speed sensor, ignition/injection	09.00-05.05		**0 261 210 199**
Knock sensor	09.00-05.05		**0 261 231 146**

A

Product			
◀ TT Roadster			
Boost pressure sensor, gasoline	09.00-05.05		**0 281 002 177**
Fg.no. →8N..3..050 000	09.00-05.03		**0 281 002 177**
Fg.no. 8N..4..000 001→	06.03-05.05		**0 261 230 073**
Temperature sensor, intake air, injection system	09.00-05.05		**0 280 130 085**
Accelerator pedal module	09.00-05.05	GS,LLE	**0 280 752 214**
	09.00-08.02	RLE	**0 280 752 210**
1.8 T quattro [8N9]			**1,8 l 132 kW ATC 4 Zyl.**
Throttle valve assembly	11.99-08.00		**0 280 750 036**
Air mass meter, gasoline injection	11.99-08.00		**0 280 218 032**
			0 986 280 210
Phase sensor	11.99-08.00		**0 232 101 024**
Temperature sensor, intake air, injection system	11.99-08.00		**0 280 130 085**
Accelerator pedal module	11.99-08.00	GS	**0 280 752 214**
1.8 T quattro [8N9]			**1,8 l 132 kW AUQ 4 Zyl.**
Throttle valve assembly	06.05-06.06		**0 280 750 036**
Air mass meter, gasoline injection	06.05-06.06		**0 280 218 063**
			0 986 280 217
Phase sensor	06.05-06.06		**0 232 101 024**
Speed sensor, ignition/injection	06.05-06.06		**0 261 210 199**
Knock sensor	06.05-06.06		**0 261 231 146**
Boost pressure sensor, gasoline	06.05-06.06		**0 261 230 073**
Temperature sensor, intake air, injection system	06.05-06.06		**0 280 130 085**
Accelerator pedal module	06.05-06.06	GS,LLE	**0 280 752 214**
1.8 T quattro [8N9]			**1,8 l 132 kW AWP 4 Zyl.**
Air mass meter, gasoline injection	09.00-08.02		**0 280 218 063**
			0 986 280 217
Phase sensor	09.00-08.02		**0 232 101 024**
Speed sensor, ignition/injection	09.00-08.02		**0 261 210 199**
Knock sensor	09.00-08.02		**0 261 231 146**
Boost pressure sensor, gasoline	09.00-08.02		**0 281 002 177**
Temperature sensor, intake air, injection system	09.00-08.02		**0 280 130 085**
Accelerator pedal module	09.00-08.02	GS	**0 280 752 214**
1.8 T quattro [8N9]			**1,8 l 140 kW BVR 4 Zyl.**
Throttle valve assembly	09.05-06.06		**0 280 750 036**
Air mass meter, gasoline injection	09.05-06.06		**0 280 218 063**
			0 986 280 217
Phase sensor	09.05-06.06		**0 232 101 024**
Speed sensor, ignition/injection	09.05-06.06		**0 261 210 199**
Knock sensor	09.05-06.06		**0 261 231 146**
Temperature sensor, intake air, injection system	09.05-06.06		**0 280 130 085**
Accelerator pedal module	09.05-06.06	GS,LLE	**0 280 752 214**
1.8 T quattro [8N9]			**1,8 l 165 kW AMU 4 Zyl.**
Throttle valve assembly	03.00-08.02		**0 280 750 036**
Air mass meter, gasoline injection	03.00-08.02		**0 280 218 034**
			0 986 280 211
Phase sensor	03.00-08.02		**0 232 101 024**
Temperature sensor, intake air, injection system	03.00-08.02		**0 280 130 085**
Accelerator pedal module	03.00-08.02	GS	**0 280 752 214**
1.8 T quattro [8N9]			**1,8 l 165 kW APX 4 Zyl.**
Throttle valve assembly	03.99-08.01		**0 280 750 036**
Air mass meter, gasoline injection	03.99-08.01		**0 280 218 034**
			0 986 280 211
Phase sensor	03.99-08.01		**0 232 101 024**
Speed sensor, ignition/injection	03.99-08.01		**0 261 210 147**
Boost pressure sensor, gasoline			
Fg.no. →8N..1..031 000	03.99-01.01		**0 281 002 177**
Fg.no. 8N..1..031 001→	02.01-08.01		**0 261 230 073**
Temperature sensor, intake air, injection system	03.99-08.01		**0 280 130 085**
Accelerator pedal module	03.99-08.01	LLE	**0 280 752 214**
Fg.no. 8N..Y..080 001→	04.00-08.01	RLE	**0 280 752 210**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8N..Y..080 000	03.99-03.00	RLE	**0 280 752 016**

Product			
1.8 T quattro [8N9]			**1,8 l 165 kW BAM 4 Zyl.**
Throttle valve assembly	09.00-06.06		**0 280 750 036**
Air mass meter, gasoline injection	09.00-06.06		**0 280 218 065**
			0 986 280 218
Phase sensor	09.00-06.06		**0 232 101 024**
Speed sensor, ignition/injection	09.02-06.06		**0 261 210 178**
	09.00-08.02		**0 261 210 199**
Knock sensor	09.00-06.06		**0 261 231 146**
Boost pressure sensor, gasoline			
Fg.no. →8N..1..031 000	09.00-01.01		**0 281 002 177**
Fg.no. 8N..1..031 001→	02.01-06.06		**0 261 230 073**
Temperature sensor, intake air, injection system	09.00-06.06		**0 280 130 085**
Accelerator pedal module	09.00-06.06	GS,LLE	**0 280 752 214**
	09.00-08.02	RLE	**0 280 752 210**
2.0 TFSI [8J9]			**2,0 l 147 kW BWA 4 Zyl.**
Speed sensor, ignition/injection	02.07→		**0 261 210 199**
Boost pressure sensor, gasoline	02.07→		**0 261 230 073**
3.2 quattro [8J9]			**3,2 l 184 kW BUB 6 Zyl.**
Air mass meter, gasoline injection	02.07→		**0 280 218 073**
			0 986 280 222
Phase sensor	02.07→		**0 232 103 019**
Knock sensor	02.07→	OHL	**0 261 231 146**
3.2 quattro [8N9]			**3,2 l 184 kW BHE 6 Zyl.**
Air mass meter, gasoline injection	07.03-06.06		**0 280 218 073**
			0 986 280 222
Phase sensor	07.03-06.06		**0 232 103 019**
Knock sensor	07.03-06.06	OHL	**0 261 231 146**
Accelerator pedal module	07.03-06.06	GS,LLE	**0 280 752 214**
V8			
3.6 quattro [44; 4C; D11]			**3,6 l 184 kW PT 8 Zyl.**
Throttle valve sensor			
Fg.no. →4C..M..020 000	10.88-07.91		**0 280 120 424**
Fg.no. 4C..N..000 001→	07.91-11.93		**0 280 120 428**
Air mass meter, gasoline injection	10.88-11.93		**0 280 216 001**
Knock sensor	10.88-11.93	KZA	**0 261 231 040**
		KZG	**0 261 231 038**
Temperature sensor, coolant, injection system	10.88-11.93		**0 280 130 037**
4.2 quattro [44; 4C; D11]			**4,2 l 206 kW ABH 8 Zyl.**
Throttle valve sensor	10.91-11.93		**0 280 120 428**
Air mass meter, gasoline injection	10.91-11.93		**0 280 216 001**
Knock sensor	10.91-11.93	KZA	**0 261 231 040**
		KZG	**0 261 231 038**
Temperature sensor, coolant, injection system	10.91-11.93		**0 280 130 037**
80			
1.4 [89; 8A2; B3]			**1,4 l 48 kW SE 4 Zyl.**
Wheel speed sensor, rear			
Fg.no. →89..J..373 598	08.86-04.88		**0 265 001 181**
1.6 [8C2; B4]			**1,6 l 74 kW ADA 4 Zyl.**
Throttle valve sensor	06.93-05.95		**0 280 120 431**
Knock sensor	06.93-05.95		**0 261 231 036**
1.6 [8C2; B4]			**1,6 l 75 kW ABB 4 Zyl.**
Air flow sensor, gasoline injection	03.92-08.93		**F 026 TX2 051**
			F 026 TX2 051
Pressure sensor, intake manifold, gasoline	03.92-08.93		**0 280 101 001**
1.6 [81; 85; B2]			**1,6 l 55 kW DT 4 Zyl.**
Temperature sensor, coolant, injection system	08.83-03.87		**0 280 130 040**

A

Product			
1.6 [89; 8A2; B3]			**1,6 l 51 kW PP 4 Zyl.**
Temperature sensor, coolant, injection system	03.87-12.91	KZW	**0 280 130 040**
Wheel speed sensor, rear			
Fg.no. →89..J..373 598	03.87-04.88		**0 265 001 181**
1.6 [89; 8A2; B3]			**1,6 l 55 kW RN 4 Zyl.**
Wheel speed sensor, rear			
Fg.no. →89..J..373 598	09.86-04.88		**0 265 001 181**
1.6 [89; 8A2; B3]			**1,6 l 75 kW ABB 4 Zyl.**
Air flow sensor, gasoline injection	08.90-12.91	FOB	**F 026 TX2 051**
			F 026 TX2 051
Temperature sensor, coolant, injection system	08.90-12.91	KAT	**0 280 130 040**
		KZW	**0 280 130 040**
1.6 D [89; 8A2; B3]			**1,6 l 40 kW JK 4 Zyl.**
Wheel speed sensor, rear			
Fg.no. →89..J..373 598	09.86-04.88		**0 265 001 181**
1.8 [81; 85; B2]			**1,8 l 64/66 kW DS; SF 4 Zyl.**
Temperature sensor, coolant, injection system	01.83-03.87		**0 280 130 040**
1.8 [81; 85; B2]			**1,8 l 66 kW JN 4 Zyl.**
Air flow sensor, gasoline injection	08.83-03.87		**F 026 TX2 063**
			F 026 TX2 063
Temperature sensor, coolant, injection system	08.83-03.87		**0 280 130 040**
1.8 [81; 85; B2]			**1,8 l 81 kW PV 4 Zyl.**
Air flow sensor, gasoline injection	08.85-03.87		**F 026 TX2 063**
			F 026 TX2 063
Knock sensor	08.85-03.87		**0 261 231 038**
1.8 [81; 85; B2]			**1,8 l 82 kW DZ; MU 4 Zyl.**
Air flow sensor, gasoline injection			
Fg.no. →81..G..140 000	01.83-02.86		**0 438 120 189**
Fg.no. 81..G..140 001→	02.86-03.87	FOB	**F 026 TX2 051**
			F 026 TX2 051
1.8 [89; 8A2; B3]			**1,8 l 55 kW RU 4 Zyl.**
Wheel speed sensor, rear			
Fg.no. →89..J..373 598	10.86-04.88		**0 265 001 181**
1.8 E [89; 8A2; B3]			**1,8 l 82 kW DZ 4 Zyl.**
Air flow sensor, gasoline injection	09.86-12.91	FOB	**F 026 TX2 051**
			F 026 TX2 051
Temperature sensor, coolant, injection system	09.86-12.91	KZW	**0 280 130 040**
Wheel speed sensor, rear			
Fg.no. →89..J..373 598	09.86-04.88		**0 265 001 181**
1.8 quattro [81; 85; B2]			**1,8 l 66 kW JN 4 Zyl.**
Air flow sensor, gasoline injection	08.85-08.86		**F 026 TX2 063**
			F 026 TX2 063
Temperature sensor, coolant, injection system	08.85-08.86		**0 280 130 040**
1.8 quattro [81; 85; B2]			**1,8 l 81 kW PV 4 Zyl.**
Air flow sensor, gasoline injection	03.85-08.86		**F 026 TX2 063**
			F 026 TX2 063
Knock sensor	03.85-08.86		**0 261 231 038**
Temperature sensor, coolant, injection system	03.85-08.86		**0 280 130 040**
1.8 quattro [81; 85; B2]			**1,8 l 82 kW DZ; MU 4 Zyl.**
Air flow sensor, gasoline injection	03.85-08.86	MZF	**0 438 121 027**
		NOR	**0 438 120 189**
1.8 quattro [89; 8A2; B3]			**1,8 l 64 kW SF 4 Zyl.**
Wheel speed sensor, rear			
Fg.no. →89..J..373 595	09.86-04.88		**0 265 001 183**
1.8 quattro [89; 8A2; B3]			**1,8 l 66 kW JN 4 Zyl.**
Air flow sensor, gasoline injection	09.86-07.90		**F 026 TX2 063**
			F 026 TX2 063
Temperature sensor, coolant, injection system	09.86-07.90		**0 280 130 040**
Wheel speed sensor, rear			
Fg.no. →89..J..373 595	09.86-04.88		**0 265 001 183**
1.8 quattro [89; 8A2; B3]			**1,8 l 82 kW DZ 4 Zyl.**
Air flow sensor, gasoline injection	09.86-09.91	FOB	**F 026 TX2 051**
			F 026 TX2 051

Product			
Wheel speed sensor, rear			
Fg.no. →89..J..373 595	09.86-04.88		**0 265 001 183**
1.8 S [89; 8A2; B3]			**1,8 l 64 kW SF 4 Zyl.**
Temperature sensor, coolant, injection system	09.86-01.90	KZW	**0 280 130 040**
Wheel speed sensor, rear			
Fg.no. →89..J..373 598	09.86-04.88		**0 265 001 181**
1.8 S [89; 8A2; B3]			**1,8 l 66 kW JN 4 Zyl.**
Air flow sensor, gasoline injection	09.86-12.91		**F 026 TX2 063**
			F 026 TX2 063
Temperature sensor, coolant, injection system	09.86-12.91	KZW	**0 280 130 040**
Wheel speed sensor, rear			
Fg.no. →89..J..373 598	09.86-04.88		**0 265 001 181**
1.8 S [89; 8A2; B3]			**1,8 l 66 kW JV; NE; PM 4 Zyl.**
Temperature sensor, coolant, injection system	08.86-12.91	KZW	**0 280 130 040**
Wheel speed sensor, rear			
Fg.no. →89..J..373 598	08.86-04.88		**0 265 001 181**
1.9 E [89; 8A2; B3]			**1,9 l 83 kW SD 4 Zyl.**
Air flow sensor, gasoline injection	09.87-07.88		**F 026 TX2 063**
			F 026 TX2 063
Knock sensor	09.87-07.88		**0 261 231 038**
Temperature sensor, coolant, injection system	09.87-07.88	KZW	**0 280 130 040**
Wheel speed sensor, rear			
Fg.no. →89..J..373 598	09.87-04.88		**0 265 001 181**
1.9 quattro [89; 8A2; B3]			**1,9 l 83 kW SD 4 Zyl.**
Air flow sensor, gasoline injection	09.86-07.88		**F 026 TX2 063**
			F 026 TX2 063
Knock sensor	09.86-07.88		**0 261 231 036**
Temperature sensor, coolant, injection system	09.86-07.88		**0 280 130 040**
Wheel speed sensor, rear			
Fg.no. →89..J..373 595	09.86-04.88		**0 265 001 183**
1.9 TDI [8C2; B4]			**1,9 l 66 kW 1Z 4 Zyl.**
Air flow sensor, diesel			
Fg.no. →8C..R..128 401	09.91-01.94	GS	**0 281 002 072**
Boost pressure sensor, Diesel	09.91-05.95		**0 281 002 018**
Pressure sensor, intake manifold, diesel	09.91-05.95		**0 261 230 037**
Pedal position sensor, diesel			
Fg.no. →8C..R..300 000	09.91-07.94		**0 205 001 001**
Fg.no. 8C..S..000 001→	08.94-05.95	AG	**0 205 001 018**
		GS	**0 205 001 017**
2.0 [8C2; B4]			**2,0 l 101 kW 6A 4 Zyl.**
Throttle valve sensor	09.91-07.92		**0 280 120 426**
Air flow sensor, gasoline injection	09.91-07.92		**0 986 439 389**
			F 026 TX2 059
			0 986 439 389
Temperature sensor, coolant, injection system	09.91-07.92	ABM	**0 280 130 040**
2.0 [8C2; B4]			**2,0 l 103 kW ACE 4 Zyl.**
Throttle valve sensor	08.92-05.95		**0 280 120 426**
Air flow sensor, gasoline injection	08.92-05.95		**0 986 439 389**
			F 026 TX2 059
			0 986 439 389
Knock sensor	08.92-05.95	LLE	**0 261 231 036**
		RLE	**0 261 231 038**
Temperature sensor, coolant, injection system	08.92-05.95	ABM	**0 280 130 040**
2.0 [89; 8A2; B3]			**2,0 l 85 kW AAD 4 Zyl.**
Throttle valve sensor	08.90-12.91		**0 280 120 426**
Air flow sensor, gasoline injection	08.90-12.91		**0 438 121 087**
			0 986 439 387
Knock sensor	08.90-12.91		**0 261 231 036**
Temperature sensor, coolant, injection system	08.90-12.91	KAT	**0 280 130 040**
		KZW	**0 280 130 040**

A

Product			
◀ 80			
2.0 [89; 8A2; B3]			**2,0 l 101 kW 6A 4 Zyl.**
Air flow sensor, gasoline injection	03.90-12.91		**0 986 439 389**
			F 026 TX2 059
			0 986 439 389
Knock sensor	03.90-12.91	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, coolant, injection system	03.90-12.91	KAT	**0 280 130 040**
2.0 E [8C2; B4]			**2,0 l 85 kW ABK 4 Zyl.**
Knock sensor	09.91-05.95		**0 261 231 036**
2.0 E [89; 8A2; B3]			**2,0 l 83 kW 3A 4 Zyl.**
Air flow sensor, gasoline injection	08.88-10.90		**0 438 121 087**
			0 986 439 387
Knock sensor	08.88-10.90		**0 261 231 038**
Temperature sensor, coolant, injection system	08.88-10.90	KAT	**0 280 130 040**
		KZW	**0 280 130 040**
2.0 quattro [8C2; B4]			**2,0 l 79/85 kW ABK; ADW 4 Zyl.**
Knock sensor	09.91-05.95	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
2.0 quattro [8C2; B4]			**2,0 l 101/103 kW ACE; 6A 4 Zyl.**
Throttle valve sensor	09.91-05.95		**0 280 120 426**
Air flow sensor, gasoline injection	09.91-05.95		**0 986 439 389**
			F 026 TX2 059
			0 986 439 389
Knock sensor	09.91-05.95	LLE	**0 261 231 036**
		RLE	**0 261 231 038**
Temperature sensor, coolant, injection system	09.91-05.95	ABM	**0 280 130 040**
2.0 quattro [89; 8A2; B3]			**2,0 l 83 kW 3A 4 Zyl.**
Air flow sensor, gasoline injection	08.88-09.90		**0 438 121 087**
			0 986 439 387
Knock sensor	08.88-09.90	LLE	**0 261 231 036**
		RLE	**0 261 231 038**
Temperature sensor, coolant, injection system	08.88-09.90		**0 280 130 040**
2.0 quattro [89; 8A2; B3]			**2,0 l 85 kW AAD 4 Zyl.**
Throttle valve sensor	09.90-09.91		**0 280 120 426**
Air flow sensor, gasoline injection	09.90-09.91		**0 438 121 087**
			0 986 439 387
Knock sensor	09.90-09.91	LLE	**0 261 231 036**
		RLE	**0 261 231 038**
Temperature sensor, coolant, injection system	09.90-09.91	KZW	**0 280 130 040**
2.0 16V quattro [89; 8A2; B3]			**2,0 l 101 kW 6A 4 Zyl.**
Air flow sensor, gasoline injection	03.90-08.91		**0 986 439 389**
			F 026 TX2 059
			0 986 439 389
Knock sensor	03.90-08.91	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, coolant, injection system	03.90-08.91	KZW	**0 280 130 040**
2.2 S2 quattro [8C2; B4]			**2,2 l 169 kW ABY 5 Zyl.**
Throttle valve sensor	02.93-05.95		**0 280 120 431**
Air mass meter, gasoline injection	02.93-05.95		**0 280 213 007**
			0 986 280 137
Phase sensor	02.93-05.95		**0 232 101 020**
Knock sensor	02.93-05.95	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Pressure sensor, intake manifold, gasoline	02.93-05.95		**0 280 101 001**
Temperature sensor, coolant, injection system	02.93-05.95	KZW	**0 280 130 037**
2.3 [8C2; B4]			**2,3 l 98 kW NG 5 Zyl.**
Throttle valve sensor	09.91-11.94		**0 280 120 433**
Air flow sensor, gasoline injection	09.91-11.94		**F 026 TX2 054**
			F 026 TX2 054
Knock sensor	09.91-11.94	LLE	**0 261 231 036**
		RLE	**0 261 231 038**
Pressure sensor, intake manifold, gasoline	09.91-11.94		**0 280 101 001**
Temperature sensor, coolant, injection system	09.91-11.94		**0 280 130 053**

Product			
2.3 quattro [8C2; B4]			**2,3 l 98 kW NG 5 Zyl.**
Air flow sensor, gasoline injection	09.91-11.94		**F 026 TX2 054**
			F 026 TX2 054
Knock sensor	09.91-11.94	LLE	**0 261 231 036**
		RLE	**0 261 231 038**
Pressure sensor, intake manifold, gasoline	09.91-11.94		**0 280 101 001**
Temperature sensor, coolant, injection system	09.91-11.94	ABM	**0 280 130 053**
2.3 quattro [89; 8A2; B3]			**2,3 l 98 kW NG 5 Zyl.**
Air flow sensor, gasoline injection	04.87-08.91		**F 026 TX2 054**
			F 026 TX2 054
Knock sensor	04.87-08.91	LLE	**0 261 231 036**
		RLE	**0 261 231 038**
Pressure sensor, intake manifold, gasoline	04.87-08.91		**0 280 101 001**
Temperature sensor, coolant, injection system	04.87-08.91	KZS	**0 280 130 053**
Wheel speed sensor, rear			
Fg.no. →89..J..373 595	04.87-04.88		**0 265 001 183**
2.6 E [8C2; B4]			**2,6 l 102 kW ACZ 6 Zyl.**
Temperature sensor, coolant, injection system	05.93-05.95	ABM	**0 280 130 040**
2.6 E [8C2; B4]			**2,6 l 110 kW ABC 6 Zyl.**
Throttle valve sensor	07.92-05.95		**0 280 120 431**
Knock sensor	07.92-05.95	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, coolant, injection system	07.92-05.95	ABM	**0 280 130 040**
2.6 quattro [8C2; B4]			**2,6 l 102/110 kW ABC; ACZ 6 Zyl.**
Throttle valve sensor	07.92-05.95		**0 280 120 431**
Knock sensor	07.92-05.95	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	07.92-05.95		**0 280 130 060**
Temperature sensor, coolant, injection system	07.92-05.95	ABM	**0 280 130 040**
2.8 E, quattro [8C2; B4]			**2,8 l 128 kW AAH 6 Zyl.**
Throttle valve sensor	09.91-05.95		**0 280 120 431**
Knock sensor	09.91-05.95	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, coolant, injection system	09.91-05.95	ABM	**0 280 130 040**

80 Avant

1.6 [8C5; B4]			**1,6 l 74 kW ADA 4 Zyl.**
Throttle valve sensor	06.93-07.95		**0 280 120 431**
Knock sensor	06.93-07.95		**0 261 231 036**
1.6 [8C5; B4]			**1,6 l 75 kW ABB 4 Zyl.**
Air flow sensor, gasoline injection	03.92-05.93		**F 026 TX2 051**
			F 026 TX2 051
Pressure sensor, intake manifold, gasoline	03.92-05.93		**0 280 101 001**
1.9 TDI [8C5; B4]			**1,9 l 66 kW 1Z 4 Zyl.**
Air flow sensor, diesel			
Fg.no. →8C..R..128 401	08.92-01.94	GS	**0 281 002 072**
Boost pressure sensor, Diesel	08.92-07.95		**0 281 002 018**
Pressure sensor, intake manifold, diesel	08.92-07.95		**0 261 230 037**
Pedal position sensor, diesel			
Fg.no. →8C..R..300 000	08.92-07.94		**0 205 001 001**
Fg.no. 8C..S..000 001→	08.94-07.95	AG	**0 205 001 018**
		GS	**0 205 001 017**
2.0 [8C5; B4]			**2,0 l 103 kW ACE 4 Zyl.**
Throttle valve sensor	08.92-07.95		**0 280 120 426**
Air flow sensor, gasoline injection	08.92-07.95		**0 986 439 389**
			F 026 TX2 059
			0 986 439 389
Knock sensor	08.92-07.95	LLE	**0 261 231 036**
		RLE	**0 261 231 038**
Temperature sensor, coolant, injection system	08.92-07.95	ABM	**0 280 130 040**

A

Product			
2.0 E [8C5; B4]			**2,0 l 85 kW ABK 4 Zyl.**
Knock sensor	08.92-07.95		**0 261 231 036**
2.0 quattro [8C5; B4]			**2,0 l 79 kW ADW 4 Zyl.**
Knock sensor	11.93-07.95	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
2.0 quattro [8C5; B4]			**2,0 l 103 kW ACE 4 Zyl.**
Throttle valve sensor	07.94-07.95		**0 280 120 426**
Air flow sensor, gasoline injection	07.94-07.95		**0 986 439 389**
			F 026 TX2 059
			0 986 439 389
Knock sensor	07.94-07.95	LLE	**0 261 231 036**
		RLE	**0 261 231 038**
Temperature sensor, coolant, injection system	07.94-07.95	ABM	**0 280 130 040**
2.2 RS2 quattro [8C5; B4]			**2,2 l 232 kW ADU 5 Zyl.**
Throttle valve sensor	03.94-07.95		**0 280 120 431**
Air mass meter, gasoline injection	03.94-07.95		**0 280 213 017**
			0 986 280 139
Knock sensor	03.94-07.95	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
2.2 S2 quattro [8C5; B4]			**2,2 l 169 kW ABY 5 Zyl.**
Throttle valve sensor	07.94-07.95		**0 280 120 431**
Air mass meter, gasoline injection	07.94-07.95		**0 280 213 007**
			0 986 280 137
Phase sensor	07.94-07.95		**0 232 101 020**
Knock sensor	07.94-07.95	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Pressure sensor, intake manifold, gasoline	07.94-07.95		**0 280 101 001**
Temperature sensor, coolant, injection system	07.94-07.95	KZW	**0 280 130 037**
2.3 E [8C5; B4]			**2,3 l 98 kW NG 5 Zyl.**
Throttle valve sensor	08.92-11.94		**0 280 120 433**
Air flow sensor, gasoline injection	08.92-11.94		**F 026 TX2 054**
			F 026 TX2 054
Knock sensor	08.92-11.94	LLE	**0 261 231 036**
		RLE	**0 261 231 038**
Pressure sensor, intake manifold, gasoline	08.92-11.94		**0 280 101 001**
Temperature sensor, coolant, injection system	08.92-11.94		**0 280 130 053**
2.3 quattro [8C5; B4]			**2,3 l 98 kW NG 5 Zyl.**
Air flow sensor, gasoline injection	08.92-11.94		**F 026 TX2 054**
			F 026 TX2 054
Knock sensor	08.92-11.94	LLE	**0 261 231 036**
		RLE	**0 261 231 038**
Pressure sensor, intake manifold, gasoline	08.92-11.94		**0 280 101 001**
Temperature sensor, coolant, injection system	08.92-11.94	ABM	**0 280 130 053**
2.6 E [8C5; B4]			**2,6 l 102 kW ACZ 6 Zyl.**
Temperature sensor, coolant, injection system	05.93-05.95	ABM	**0 280 130 040**
2.6 E [8C5; B4]			**2,6 l 110 kW ABC 6 Zyl.**
Throttle valve sensor	08.92-05.95		**0 280 120 431**
Knock sensor	08.92-05.95	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, coolant, injection system	08.92-05.95	ABM	**0 280 130 040**
2.6 quattro [8C5; B4]			**2,6 l 102/110 kW ABC; ACZ 6 Zyl.**
Throttle valve sensor	08.92-07.95		**0 280 120 431**
Knock sensor	08.92-07.95	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	08.92-07.95		**0 280 130 060**
Temperature sensor, coolant, injection system	08.92-07.95	ABM	**0 280 130 040**
2.8 E [8C5; B4]			**2,8 l 128 kW AAH 6 Zyl.**
Throttle valve sensor	08.92-05.95		**0 280 120 431**
Knock sensor	08.92-05.95	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, coolant, injection system	08.92-05.95	ABM	**0 280 130 040**

Product			
2.8 quattro [8C5; B4]			**2,8 l 128 kW AAH 6 Zyl.**
Throttle valve sensor	08.92-07.95		**0 280 120 431**
Knock sensor	08.92-07.95	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, coolant, injection system	08.92-07.95	ABM	**0 280 130 040**

90

1.6 TD [89; 8A2; B3]			**1,6 l 59 kW RA 4 Zyl.**
Wheel speed sensor, rear			
Fg.no. →89..J..373 598	07.87-04.88		**0 265 001 181**
1.8 [81; 85; B2]			**1,8 l 66 kW JN 4 Zyl.**
Air flow sensor, gasoline injection	06.84-03.87		**F 026 TX2 063**
			F 026 TX2 063
Temperature sensor, coolant, injection system	06.84-03.87		**0 280 130 040**
1.8 E [89; 8A2; B3]			**1,8 l 82 kW DZ 4 Zyl.**
Air flow sensor, gasoline injection	08.89-12.91	FOB	**F 026 TX2 051**
			F 026 TX2 051
Temperature sensor, coolant, injection system	08.89-12.91	FGK,KZW	**0 280 130 040**
2.0 [81; 85; B2]			**2,0 l 81 kW JL 5 Zyl.**
Air flow sensor, gasoline injection	10.84-03.87		**0 438 120 181**
Wheel speed sensor, rear	10.84-03.87		**0 265 001 099**
2.0 [81; 85; B2]			**2,0 l 83 kW SK 5 Zyl.**
Knock sensor	02.86-03.87		**0 261 231 038**
Wheel speed sensor, rear	02.86-03.87		**0 265 001 099**
2.0 [81; 85; B2]			**2,0 l 85 kW HP; JS 5 Zyl.**
Air flow sensor, gasoline injection			
Fg.no. 81..G..144 746→	02.86-03.87	FOB	**0 438 120 211**
Wheel speed sensor, rear	10.84-03.87		**0 265 001 099**
2.0 [89; 8A2; B3]			**2,0 l 83 kW 3A 4 Zyl.**
Air flow sensor, gasoline injection	09.87-10.90		**0 438 121 070**
			0 986 439 370
Knock sensor	09.87-10.90	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, coolant, injection system	09.87-10.90		**0 280 130 040**
2.0 [89; 8A2; B3]			**2,0 l 85 kW PS 5 Zyl.**
Throttle valve sensor	05.87-12.91		**0 280 120 433**
Air flow sensor, gasoline injection	05.87-12.91	FGK,FOB	**0 438 121 073**
		FOB,OKA	**0 438 120 211**
Knock sensor	05.87-12.91	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, coolant, injection system	05.87-12.91	KAT,KZS	**0 280 130 053**
		KZW,OKA	**0 280 130 040**
Wheel speed sensor, rear			
Fg.no. →89..J..373 598	05.87-04.88		**0 265 001 181**
2.0 quattro [89; 8A2; B3]			**2,0 l 118 kW NM 5 Zyl.**
Temperature sensor, coolant, injection system	01.88-09.91		**0 280 130 037**
Wheel speed sensor, rear			
Fg.no. →89..J..373 595	01.88-04.88		**0 265 001 183**
2.2 [81; 85; B2]			**2,2 l 85 kW KX 5 Zyl.**
Air flow sensor, gasoline injection	01.85-03.87		**F 026 TX2 064**
			F 026 TX2 064
Pressure sensor, intake manifold, gasoline	01.85-03.87		**0 280 101 001**
Wheel speed sensor, rear	01.85-03.87		**0 265 001 099**
2.2 [81; 85; B2]			**2,2 l 98/100 kW HY; KV 5 Zyl.**
Air flow sensor, gasoline injection			
Fg.no. 81..G..144 746→	02.86-03.87	FOB	**0 438 120 211**
Wheel speed sensor, rear	10.84-03.87		**0 265 001 099**
2.2 E [89; 8A2; B3]			**2,2 l 98 kW KV 5 Zyl.**
Air flow sensor, gasoline injection	04.87-12.91	FOB	**0 438 120 211**
Wheel speed sensor, rear			
Fg.no. →89..J..373 598	04.87-04.88		**0 265 001 181**

A

Product			
◀ 90			
2.2 quattro [81; 85; B2]			**2,2 l 89 kW JT 5 Zyl.**
Air flow sensor, gasoline injection	12.84-03.87		**F 026 TX2 064**
			F 026 TX2 064
Pressure sensor, intake manifold, gasoline	12.84-03.87		**0 280 101 001**
Temperature sensor, coolant, injection system	12.84-03.87		**0 280 130 037**
2.2 quattro [81; 85; B2]			**2,2 l 100 kW HY 5 Zyl.**
Air flow sensor, gasoline injection			
Fg.no. 85..G..144 746→	03.86-03.87	FOB	**0 438 120 211**
2.2 quattro [89; 8A2; B3]			**2,2 l 98 kW KV 5 Zyl.**
Air flow sensor, gasoline injection	04.87-09.91	FOB	**0 438 120 211**
Wheel speed sensor, rear			
Fg.no. →89..J..373 595	04.87-04.88		**0 265 001 183**
2.3 [89; 8A2; B3]			**2,3 l 125 kW 7A 5 Zyl.**
Throttle valve sensor			
Fg.no. 8A..L..070 001→	10.89-12.91		**0 280 120 422**
Temperature sensor, coolant, injection system	08.88-12.91		**0 280 130 037**
2.3 E [89; 8A2; B3]			**2,3 l 98 kW NG 5 Zyl.**
Throttle valve sensor	04.87-12.91		**0 280 120 433**
Air flow sensor, gasoline injection	04.87-12.91		**F 026 TX2 054**
			F 026 TX2 054
Knock sensor	04.87-12.91	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Pressure sensor, intake manifold, gasoline	04.87-12.91		**0 280 101 001**
Temperature sensor, coolant, injection system	04.87-12.91		**0 280 130 053**
Wheel speed sensor, rear			
Fg.no. →89..J..373 598	04.87-04.88		**0 265 001 181**
2.3 quattro [89; 8A2; B3]			**2,3 l 98 kW NG 5 Zyl.**
Throttle valve sensor	04.87-09.91		**0 280 120 426**
Air flow sensor, gasoline injection	04.87-09.91		**F 026 TX2 054**
			F 026 TX2 054
Knock sensor	04.87-09.91	LLE	**0 261 231 036**
		RLE	**0 261 231 004**
Pressure sensor, intake manifold, gasoline	04.87-09.91		**0 280 101 001**
Temperature sensor, coolant, injection system	04.87-09.91		**0 280 130 053**
Wheel speed sensor, rear			
Fg.no. →89..J..373 595	04.87-04.88		**0 265 001 183**
2.3 quattro [89; 8A2; B3]			**2,3 l 125 kW 7A 5 Zyl.**
Throttle valve sensor			
Fg.no. 8A..L..203 051→	03.90-09.91		**0 280 120 422**
Temperature sensor, coolant, injection system	07.88-09.91		**0 280 130 037**
2.8 quattro [89; 8A2; B3]			**2,8 l 128 kW AAH 6 Zyl.**
Knock sensor	03.92-06.95	LLE	**0 261 231 036**
100			
1.6 [4A2; C4]			**1,6 l 75 kW ABB 4 Zyl.**
Air flow sensor, gasoline injection	03.92-01.94		**F 026 TX2 051**
			F 026 TX2 051
1.8 [44; 44Q; C3]			**1,8 l 55 kW DR; RS 4 Zyl.**
Wheel speed sensor, rear	08.82-12.87		**0 265 001 060**
1.8 [44; 44Q; C3]			**1,8 l 65/66 kW DS; JW; SH 4 Zyl.**
Wheel speed sensor, rear			
Fg.no. →44..J..200 099	03.83-12.87		**0 265 001 060**
1.8 [44; 44Q; C3]			**1,8 l 66 kW PH 4 Zyl.**
Air flow sensor, gasoline injection	04.85-12.90		**F 026 TX2 063**
			F 026 TX2 063
Temperature sensor, coolant, injection system	04.85-12.90		**0 280 130 040**
Wheel speed sensor, rear			
Fg.no. →44..J..200 099	04.85-12.87		**0 265 001 060**
1.8 [44; 44Q; C3]			**1,8 l 66 kW 4B 4 Zyl.**
Temperature sensor, coolant, injection system	01.88-12.90		**0 280 130 040**

Product			
1.8 quattro [44; 44Q; C3]			**1,8 l 66 kW PH 4 Zyl.**
Air flow sensor, gasoline injection	08.85-07.88		**F 026 TX2 063**
			F 026 TX2 063
Temperature sensor, coolant, injection system	08.85-07.88		**0 280 130 040**
2.0 [4A2; C4]			**2,0 l 85 kW AAD 4 Zyl.**
Throttle valve sensor	01.91-12.92	AG	**0 280 120 433**
		GS	**0 280 120 426**
Air flow sensor, gasoline injection	08.91-12.92		**0 438 121 087**
			0 986 439 387
Knock sensor	01.91-12.92	LLE	**0 261 231 038**
		RLE	**0 261 231 036**
2.0 [4A2; C4]			**2,0 l 85 kW ABK 4 Zyl.**
Knock sensor	01.93-07.94	LLE	**0 261 231 038**
		RLE	**0 261 231 036**
2.0 [4A2; C4]			**2,0 l 103 kW ACE 4 Zyl.**
Air flow sensor, gasoline injection	01.92-07.94		**0 986 439 389**
			F 026 TX2 059
			0 986 439 389
Knock sensor	01.92-07.94		**0 261 231 038**
2.0 [44; 44Q; C3]			**2,0 l 83 kW SL 5 Zyl.**
Air flow sensor, gasoline injection	08.86-12.87	FOB	**0 438 120 211**
Knock sensor	08.86-12.87		**0 261 231 038**
Wheel speed sensor, rear	08.86-12.87		**0 265 001 060**
2.0 [44; 44Q; C3]			**2,0 l 85 kW KP 5 Zyl.**
Air flow sensor, gasoline injection			
Fg.no. →44..G..300000	08.84-07.86	FMB	**0 438 121 005**
Fg.no. 44..H..025439→	08.86-12.87	FOB	**0 438 120 211**
Wheel speed sensor, rear	08.84-12.87		**0 265 001 060**
2.0 [44; 44Q; C3]			**2,0 l 85 kW RT 5 Zyl.**
Air flow sensor, gasoline injection	01.88-12.90		**0 438 121 073**
		FOB	**0 438 120 211**
Knock sensor	01.88-12.90		**0 261 231 038**
2.0 D [44; 44Q; C3]			**2,0 l 51 kW CN 5 Zyl.**
Wheel speed sensor, rear			
Fg.no. →44..J..200 099	08.80-12.87		**0 265 001 060**
2.0 quattro [4A2; C4]			**2,0 l 85 kW AAD 4 Zyl.**
Throttle valve sensor	12.90-07.92		**0 280 120 426**
Air flow sensor, gasoline injection	08.91-07.92		**0 438 121 087**
			0 986 439 387
Knock sensor	12.90-07.92	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
2.0 quattro [4A2; C4]			**2,0 l 103 kW ACE 4 Zyl.**
Throttle valve sensor	01.92-07.94		**0 280 120 426**
Air flow sensor, gasoline injection	01.92-07.94		**0 986 439 389**
			F 026 TX2 059
			0 986 439 389
Knock sensor	01.92-07.94	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
2.0 TD [44; 44Q; C3]			**2,0 l 66 kW DE 5 Zyl.**
Wheel speed sensor, rear	08.82-12.87		**0 265 001 060**
2.0 TD [44; 44Q; C3]			**2,0 l 75 kW NC 5 Zyl.**
Wheel speed sensor, rear			
Fg.no. →44..J..200 099	08.87-12.87		**0 265 001 060**
2.2 [44; 44Q; C3]			**2,2 l 85 kW KZ 5 Zyl.**
Air flow sensor, gasoline injection	08.84-07.87		**F 026 TX2 064**
			F 026 TX2 064
Pressure sensor, intake manifold, gasoline	08.84-07.87		**0 280 101 001**
Wheel speed sensor, rear	08.84-07.87		**0 265 001 060**
2.2 [44; 44Q; C3]			**2,2 l 101 kW HX; KU 5 Zyl.**
Air flow sensor, gasoline injection			
Fg.no. →44..G..300000	08.84-07.86	FMB	**0 438 121 005**
Fg.no. 44..H..025439→	08.86-12.90	FOB	**0 438 120 211**

A

Product			
Wheel speed sensor, rear			
Fg.no. →44..J..200 099	08.84-12.87		**0 265 001 060**
2.2 E			**2,2 l 96 kW PR 5 Zyl.**
Air flow sensor, gasoline injection	01.92-12.98		**0 438 120 211**
Knock sensor	01.92-12.98		**0 261 231 004**
2.2 quattro [44; 44Q; C3]			**2,2 l 88 kW PX 5 Zyl.**
Air flow sensor, gasoline injection	08.85-07.86		**F 026 TX2 064**
			F 026 TX2 064
Pressure sensor, intake manifold, gasoline	08.85-07.86		**0 280 101 001**
2.2 quattro [44; 44Q; C3]			**2,2 l 101 kW HX; KU 5 Zyl.**
Air flow sensor, gasoline injection			
Fg.no. 44..H..000 001→	08.86-11.90	FOB	**0 438 120 211**
2.2 quattro Turbo [44; 44Q; C3]			**2,2 l 121 kW MC 5 Zyl.**
Air flow sensor, gasoline injection			
Fg.no. →44..K..038 261	03.86-10.88		**0 438 121 053**
2.2 turbo [44; 44Q; C3]			**2,2 l 121 kW MC 5 Zyl.**
Air flow sensor, gasoline injection			
Fg.no. →44..K..038 261	05.86-10.88		**0 438 121 053**
Wheel speed sensor, rear			
Fg.no. →44..J..200 099	05.86-12.87		**0 265 001 060**
2.3 [4A2; C4]			**2,3 l 98 kW AAR 5 Zyl.**
Throttle valve sensor	12.90-07.94		**0 280 120 433**
Air flow sensor, gasoline injection	12.90-07.94		**F 026 TX2 054**
			F 026 TX2 054
Knock sensor	12.90-07.94		**0 261 231 038**
Pressure sensor, intake manifold, gasoline	12.90-07.94		**0 280 101 001**
2.3 [44; 44Q; C3]			**2,3 l 100 kW NF 5 Zyl.**
Throttle valve sensor	10.86-12.90		**0 280 120 433**
Air flow sensor, gasoline injection	10.86-12.90		**F 026 TX2 054**
			F 026 TX2 054
Knock sensor	10.86-12.90		**0 261 231 038**
Pressure sensor, intake manifold, gasoline	10.86-12.90		**0 280 101 001**
Temperature sensor, coolant, injection system	10.86-12.90		**0 280 130 053**
Wheel speed sensor, rear			
Fg.no. →44..J..200 099	10.86-12.87		**0 265 001 060**
2.3 quattro [4A2; C4]			**2,3 l 98 kW AAR 5 Zyl.**
Air flow sensor, gasoline injection	12.90-07.94		**F 026 TX2 054**
			F 026 TX2 054
Knock sensor	12.90-07.94		**0 261 231 038**
Pressure sensor, intake manifold, gasoline	12.90-07.94		**0 280 101 001**
2.3 quattro [44; 44Q; C3]			**2,3 l 100 kW NF 5 Zyl.**
Air flow sensor, gasoline injection	08.86-11.90		**F 026 TX2 054**
			F 026 TX2 054
Knock sensor	08.86-11.90		**0 261 231 038**
Pressure sensor, intake manifold, gasoline	08.86-11.90		**0 280 101 001**
Temperature sensor, coolant, injection system	08.86-11.90	2PO	**0 280 130 053**
2.5 TDI [4A2; C4]			**2,5 l 85 kW AAT 5 Zyl.**
Air mass meter, diesel	08.91-07.94		**0 281 002 074**
Pressure sensor, intake manifold, diesel	08.91-07.94		**0 281 002 018**
Temperature sensor, coolant, diesel	08.91-07.94		**0 280 130 037**
Temperature sensor, charge air cooling, diesel	08.91-07.94		**0 280 130 039**
Pedal position sensor, diesel			
Fg.no. →4A..P..064 812	08.91-01.93		**0 205 001 001**
Fg.no. 4A..P..064 813→	02.93-07.94	AG	**0 205 001 013**
		GS	**0 205 001 007**
2.5 TDI [4A2; C4]			**2,5 l 85 kW ABP 5 Zyl.**
Pressure sensor, intake manifold, diesel	06.91-07.92		**0 281 002 018**
Temperature sensor, coolant, diesel	06.91-07.92		**0 280 130 037**
Temperature sensor, charge air cooling, diesel	06.91-07.92		**0 280 130 039**
Pedal position sensor, diesel	06.91-07.92		**0 205 001 001**
2.5 TDI [44; 44Q; C3]			**2,5 l 88 kW 1T 5 Zyl.**
Pressure sensor, intake manifold, diesel	01.90-12.90		**0 281 002 018**
Temperature sensor, coolant, diesel	01.90-12.90		**0 280 130 037**

Product			
Temperature sensor, intake air, diesel	01.90-12.90		**0 280 130 039**
Pedal position sensor, diesel	01.90-12.90		**0 205 001 001**
2.6 [4A2; C4]			**2,6 l 102 kW ACZ 6 Zyl.**
Throttle valve sensor	01.93-07.94		**0 280 120 431**
Temperature sensor, coolant, injection system	01.93-07.94		**0 280 130 040**
2.6 [4A2; C4]			**2,6 l 110 kW ABC 6 Zyl.**
Throttle valve sensor	04.92-07.94		**0 280 120 431**
Knock sensor	04.92-07.94		**0 261 231 036**
Temperature sensor, coolant, injection system	04.92-07.94		**0 280 130 040**
2.6 E			**2,6 l 102 kW ACZ 6 Zyl.**
Phase sensor	01.92-01.98		**0 232 101 024**
Knock sensor	01.92-01.98		**0 261 231 004**
2.6 quattro [4A2; C4]			**2,6 l 110 kW ABC 6 Zyl.**
Throttle valve sensor	03.92-07.94		**0 280 120 431**
Phase sensor	03.92-07.94		**0 232 101 027**
Knock sensor	03.92-07.94		**0 261 231 036**
Temperature sensor, coolant, injection system	03.92-07.94		**0 280 130 040**
2.8 [4A2; C4]			**2,8 l 128 kW AAH 6 Zyl.**
Throttle valve sensor	12.90-07.94		**0 280 120 431**
Knock sensor	12.90-07.94		**0 261 231 036**
Temperature sensor, coolant, injection system	12.90-07.94		**0 280 130 040**
2.8 quattro [4A2; C4]			**2,8 l 128 kW AAH 6 Zyl.**
Throttle valve sensor	12.90-07.94		**0 280 120 431**
Phase sensor	12.90-07.94		**0 232 101 027**
Knock sensor	12.90-07.94		**0 261 231 036**
Temperature sensor, coolant, injection system	12.90-07.94		**0 280 130 040**

100 Avant

1.6 [4A5; C4]			**1,6 l 75 kW ABB 4 Zyl.**
Air flow sensor, gasoline injection	03.92-07.93		**F 026 TX2 051**
			F 026 TX2 051
1.8 [44; 44Q; C3]			**1,8 l 55 kW DR; RS 4 Zyl.**
Wheel speed sensor, rear	05.83-12.87		**0 265 001 060**
1.8 [44; 44Q; C3]			**1,8 l 66 kW DS; JW 4 Zyl.**
Wheel speed sensor, rear			
Fg.no. →44..J..200 099	05.83-12.87		**0 265 001 060**
1.8 [44; 44Q; C3]			**1,8 l 66 kW PH 4 Zyl.**
Air flow sensor, gasoline injection	08.86-12.87		**F 026 TX2 063**
			F 026 TX2 063
Temperature sensor, coolant, injection system	08.86-12.87		**0 280 130 040**
Wheel speed sensor, rear	08.86-12.87		**0 265 001 060**
1.8 [44; 44Q; C3]			**1,8 l 66 kW 4B 4 Zyl.**
Temperature sensor, coolant, injection system	01.88-07.89		**0 280 130 040**
1.8 quattro [44; 44Q; C3]			**1,8 l 66 kW PH 4 Zyl.**
Air flow sensor, gasoline injection	08.85-07.88		**F 026 TX2 063**
			F 026 TX2 063
Temperature sensor, coolant, injection system	08.85-07.88		**0 280 130 040**
2.0 [4A5; C4]			**2,0 l 85 kW AAD 4 Zyl.**
Throttle valve sensor	08.91-12.92	AG	**0 280 120 433**
		GS	**0 280 120 426**
Air flow sensor, gasoline injection	08.91-12.92		**0 438 121 087**
			0 986 439 387
Knock sensor	08.91-12.92	LLE	**0 261 231 038**
		RLE	**0 261 231 036**
2.0 [4A5; C4]			**2,0 l 85 kW ABK 4 Zyl.**
Knock sensor	01.93-07.94	LLE	**0 261 231 038**
		RLE	**0 261 231 036**
2.0 [4A5; C4]			**2,0 l 103 kW ACE 4 Zyl.**
Air flow sensor, gasoline injection	07.92-07.94		**0 986 439 389**
			F 026 TX2 059
			0 986 439 389
Knock sensor	07.92-07.94		**0 261 231 038**

A

Product			
◀ 100 Avant			
2.0 [44; 44Q; C3]			**2,0 l 83 kW SL 5 Zyl.**
Air flow sensor, gasoline injection	08.86-12.87	FOB	**0 438 120 211**
Knock sensor	08.86-12.87		**0 261 231 038**
Wheel speed sensor, rear	08.86-12.87		**0 265 001 060**
2.0 [44; 44Q; C3]			**2,0 l 85 kW KP 5 Zyl.**
Air flow sensor, gasoline injection	08.86-12.87	FOB	**0 438 120 211**
Wheel speed sensor, rear	08.86-12.87		**0 265 001 060**
2.0 [44; 44Q; C3]			**2,0 l 85 kW RT 5 Zyl.**
Air flow sensor, gasoline injection	01.88-12.90	FOB,OKA	**0 438 120 211**
		KAT	**0 438 121 073**
Knock sensor	01.88-12.90		**0 261 231 038**
2.0 D [44; 44Q; C3]			**2,0 l 51 kW CN 5 Zyl.**
Wheel speed sensor, rear			
Fg.no. →44..J..200 099	05.83-12.87		**0 265 001 060**
2.0 quattro [4A5; C4]			**2,0 l 85 kW AAD 4 Zyl.**
Throttle valve sensor	12.90-07.92		**0 280 120 426**
Air flow sensor, gasoline injection	08.91-07.92		**0 438 121 087**
			0 986 439 387
Knock sensor	12.90-07.92	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
2.0 TD [44; 44Q; C3]			**2,0 l 66 kW DE 5 Zyl.**
Wheel speed sensor, rear	05.83-12.87		**0 265 001 060**
2.2 [44; 44Q; C3]			**2,2 l 85 kW KZ 5 Zyl.**
Air flow sensor, gasoline injection	08.86-07.87		**F 026 TX2 064**
			F 026 TX2 064
Pressure sensor, intake manifold, gasoline	08.86-07.87		**0 280 101 001**
Wheel speed sensor, rear	08.86-07.87		**0 265 001 060**
2.2 [44; 44Q; C3]			**2,2 l 101 kW HX 5 Zyl.**
Air flow sensor, gasoline injection	09.86-12.87	FOB	**0 438 120 211**
Wheel speed sensor, rear	09.86-12.87		**0 265 001 060**
2.2 [44; 44Q; C3]			**2,2 l 101 kW KU 5 Zyl.**
Air flow sensor, gasoline injection	01.88-07.89	FOB	**0 438 120 211**
2.2 quattro [44; 44Q; C3]			**2,2 l 88 kW PX 5 Zyl.**
Air flow sensor, gasoline injection	08.85-07.86		**F 026 TX2 064**
			F 026 TX2 064
Pressure sensor, intake manifold, gasoline	08.85-07.86		**0 280 101 001**
2.2 quattro [44; 44Q; C3]			**2,2 l 101 kW HX 5 Zyl.**
Air flow sensor, gasoline injection			
Fg.no. 44..H..000 001→	08.86-12.87	FOB	**0 438 120 211**
2.2 quattro [44; 44Q; C3]			**2,2 l 101 kW KU 5 Zyl.**
Air flow sensor, gasoline injection	08.86-11.90	FOB	**0 438 120 211**
2.2 quattro Turbo [44; 44Q; C3]			**2,2 l 121 kW MC 5 Zyl.**
Air flow sensor, gasoline injection			
Fg.no. →44..K..038 261	03.86-10.88		**0 438 121 053**
2.2 Turbo [44; 44Q; C3]			**2,2 l 121 kW MC 5 Zyl.**
Air flow sensor, gasoline injection			
Fg.no. →44..K..038 261	08.88-10.88		**0 438 121 053**
2.3 [4A5; C4]			**2,3 l 98 kW AAR 5 Zyl.**
Throttle valve sensor	08.91-07.94		**0 280 120 433**
Air flow sensor, gasoline injection	08.91-07.94		**F 026 TX2 054**
			F 026 TX2 054
Knock sensor	08.91-07.94		**0 261 231 038**
Pressure sensor, intake manifold, gasoline	08.91-07.94		**0 280 101 001**
2.3 [44; 44Q; C3]			**2,3 l 100 kW NF 5 Zyl.**
Throttle valve sensor	01.88-07.89		**0 280 120 433**
Air flow sensor, gasoline injection	01.88-07.89		**F 026 TX2 054**
			F 026 TX2 054
Knock sensor	01.88-07.89		**0 261 231 038**
Pressure sensor, intake manifold, gasoline	01.88-07.89		**0 280 101 001**
Temperature sensor, coolant, injection system	01.88-07.89		**0 280 130 053**
2.3 quattro [4A5; C4]			**2,3 l 98 kW AAR 5 Zyl.**
Air flow sensor, gasoline injection	12.90-07.94		**F 026 TX2 054**
			F 026 TX2 054

Product			
Knock sensor	12.90-07.94		**0 261 231 038**
Pressure sensor, intake manifold, gasoline	12.90-07.94		**0 280 101 001**
2.3 quattro [44; 44Q; C3]			**2,3 l 100 kW NF 5 Zyl.**
Air flow sensor, gasoline injection	08.86-11.90		**F 026 TX2 054**
			F 026 TX2 054
Knock sensor	08.86-11.90		**0 261 231 038**
Pressure sensor, intake manifold, gasoline	08.86-11.90		**0 280 101 001**
Temperature sensor, coolant, injection system	08.86-11.90	2PO	**0 280 130 053**
2.5 TDI [4A5; C4]			**2,5 l 85 kW AAT 5 Zyl.**
Air mass meter, diesel	08.91-07.94		**0 281 002 074**
Pressure sensor, intake manifold, diesel	08.91-07.94		**0 281 002 018**
Temperature sensor, coolant, diesel	08.91-07.94		**0 280 130 037**
Temperature sensor, charge air cooling, diesel	08.91-07.94		**0 280 130 039**
Pedal position sensor, diesel			
Fg.no. →4A..P..064 812	08.91-01.93		**0 205 001 001**
Fg.no. 4A..P..064 813→	02.93-07.94	AG	**0 205 001 013**
		GS	**0 205 001 007**
2.5 TDI [4A5; C4]			**2,5 l 85 kW ABP 5 Zyl.**
Pressure sensor, intake manifold, diesel	08.91-07.92		**0 281 002 018**
Temperature sensor, coolant, diesel	08.91-07.92		**0 280 130 037**
Temperature sensor, charge air cooling, diesel	08.91-07.92		**0 280 130 039**
Pedal position sensor, diesel	08.91-07.92		**0 205 001 001**
2.5 TDI [44; 44Q; C3]			**2,5 l 88 kW 1T 5 Zyl.**
Pressure sensor, intake manifold, diesel	01.90-12.90		**0 281 002 018**
Temperature sensor, coolant, diesel	01.90-12.90		**0 280 130 037**
Temperature sensor, intake air, diesel	01.90-12.90		**0 280 130 039**
Pedal position sensor, diesel	01.90-12.90		**0 205 001 001**
2.6 [4A5; C4]			**2,6 l 102 kW ACZ 6 Zyl.**
Throttle valve sensor	07.93-07.94		**0 280 120 431**
Temperature sensor, coolant, injection system	07.93-07.94		**0 280 130 040**
2.6 [4A5; C4]			**2,6 l 110 kW ABC 6 Zyl.**
Throttle valve sensor	07.92-07.94		**0 280 120 431**
Knock sensor	07.92-07.94		**0 261 231 036**
Temperature sensor, coolant, injection system	07.92-07.94		**0 280 130 040**
2.6 quattro [4A5; C4]			**2,6 l 110 kW ABC 6 Zyl.**
Throttle valve sensor	03.92-07.94		**0 280 120 431**
Phase sensor	03.92-07.94		**0 232 101 027**
Knock sensor	03.92-07.94		**0 261 231 036**
Temperature sensor, coolant, injection system	03.92-07.94		**0 280 130 040**
2.8 [4A5; C4]			**2,8 l 128 kW AAH 6 Zyl.**
Throttle valve sensor	08.91-07.94		**0 280 120 431**
Knock sensor	08.91-07.94		**0 261 231 036**
Temperature sensor, coolant, injection system	08.91-07.94		**0 280 130 040**
2.8 quattro [4A5; C4]			**2,8 l 128 kW AAH 6 Zyl.**
Throttle valve sensor	12.90-07.94		**0 280 120 431**
Phase sensor	12.90-07.94		**0 232 101 027**
Knock sensor	12.90-07.94		**0 261 231 036**
Temperature sensor, coolant, injection system	12.90-07.94		**0 280 130 040**

200

2.2 Turbo [44, C3]			**2,2 l 121 kW MC 5 Zyl.**
Air flow sensor, gasoline injection			
Fg.no. →44..K..038 261	08.85-10.88		**0 438 121 053**
Pressure sensor, intake manifold, gasoline	08.85-12.91		**0 280 101 001**
Wheel speed sensor, rear			
Fg.no. →44..J..200 099	08.85-01.88		**0 265 001 060**
2.2 Turbo [44, C3]			**2,2 l 134 kW JY; KG 5 Zyl.**
Pressure sensor, intake manifold, gasoline	08.83-01.88		**0 280 101 001**
Wheel speed sensor, rear	08.83-01.88		**0 265 001 060**
2.2 Turbo [44, C3]			**2,2 l 140/147 kW 1B; 2B 5 Zyl.**
Pressure sensor, intake manifold, gasoline	02.88-12.91		**0 280 101 001**

A

Product			
2.2 Turbo quattro [44, C3]			**2,2 l 121 kW MC 5 Zyl.**
Air flow sensor, gasoline injection			
Fg.no. →44..K..038 261	01.85-10.88		**0 438 121 053**
Pressure sensor, intake manifold, gasoline	01.85-12.90		**0 280 101 001**
2.2 Turbo quattro [44, C3]			**2,2 l 134 kW JY; KG 5 Zyl.**
Pressure sensor, intake manifold, gasoline	11.84-12.87		**0 280 101 001**
2.2 Turbo quattro [44, C3]			**2,2 l 147 kW 1B 5 Zyl.**
Pressure sensor, intake manifold, gasoline	02.88-11.90		**0 280 101 001**
2.2 Turbo quattro [44, C3]			**2,2 l 162 kW 3B 5 Zyl.**
Air mass meter, gasoline injection	03.89-12.90		**0 280 213 007**
			0 986 280 137
Knock sensor	03.89-12.90	KZA	**0 261 231 040**
		KZB	**0 261 231 036**
Pressure sensor, intake manifold, gasoline	03.89-12.90		**0 280 101 001**
Temperature sensor, coolant, injection system	03.89-12.90		**0 280 130 037**
2.6			**2,6 l 102 kW ACZ 6 Zyl.**
Phase sensor	11.95-09.99		**0 232 101 027**
Knock sensor	11.95-09.99	KZB	**0 261 231 036**
Temperature sensor, intake air, injection system	11.95-09.99	KZS	**0 280 130 060**
Temperature sensor, coolant, injection system	11.95-09.99	LAB	**0 280 130 040**

200 Avant

2.2 Turbo quattro [44, C3]			**2,2 l 121 kW MC 5 Zyl.**
Air flow sensor, gasoline injection			
Fg.no. →44..K..038 261	01.85-10.88		**0 438 121 053**
Pressure sensor, intake manifold, gasoline	01.85-11.90		**0 280 101 001**
2.2 Turbo quattro [44, C3]			**2,2 l 134 kW JY; KG 5 Zyl.**
Pressure sensor, intake manifold, gasoline	11.84-12.87		**0 280 101 001**
2.2 Turbo quattro [44, C3]			**2,2 l 147 kW 1B 5 Zyl.**
Pressure sensor, intake manifold, gasoline	02.88-11.90		**0 280 101 001**
2.2 Turbo quattro [44, C3]			**2,2 l 162 kW 3B 5 Zyl.**
Air mass meter, gasoline injection	03.89-11.90		**0 280 213 007**
			0 986 280 137
Knock sensor	03.89-11.90	KZA	**0 261 231 040**
		KZB	**0 261 231 036**
Pressure sensor, intake manifold, gasoline	03.89-11.90		**0 280 101 001**
Temperature sensor, coolant, injection system	03.89-11.90		**0 280 130 037**

4000

1.8 [81]			**1,8 l 79 kW MG 4 Zyl.**
Air flow sensor, gasoline injection	10.84-12.87		**F 026 TX2 063**
			F 026 TX2 063
Knock sensor	10.84-12.87		**0 261 231 002**
2.2 quattro [81]			**2,2 l 88 kW JT 5 Zyl.**
Air flow sensor, gasoline injection	12.83-03.87		**F 026 TX2 064**
			F 026 TX2 064
Pressure sensor, intake manifold, gasoline	12.83-03.87		**0 280 101 001**
Temperature sensor, coolant, injection system	12.83-03.87		**0 280 130 037**

5000

2.2 [44]			**2,2 l 85 kW KZ 5 Zyl.**
Air flow sensor, gasoline injection	08.84-09.86		**F 026 TX2 064**
			F 026 TX2 064
Pressure sensor, intake manifold, gasoline	08.84-09.86		**0 280 101 001**
Temperature sensor, coolant, injection system	08.84-09.86		**0 280 130 037**
2.2 Turbo [44]			**2,2 l 118 kW MC 5 Zyl.**
Air flow sensor, gasoline injection	08.85-05.88		**0 438 121 053**
Wheel speed sensor, rear	08.85-05.88		**0 265 001 060**

Product			
2.3 [44]			**2,3 l 100 kW NF 5 Zyl.**
Air flow sensor, gasoline injection	10.86-01.88		**F 026 TX2 054**
			F 026 TX2 054
Pressure sensor, intake manifold, gasoline	10.86-01.88		**0 280 101 010**
Temperature sensor, coolant, injection system	10.86-01.88		**0 280 130 053**

AUSTIN

Maestro

2.0 i			**2,0 l 83 kW EFI O Series 4 Zyl.**
Relay, Jetronic	10.84-08.88	DID	**0 332 014 112**

Montego

2.0 i			**2,0 l 83 kW O Series 4 Zyl.**
Relay, Jetronic	04.84-08.88	DID	**0 332 014 112**

Montego Estate

2.0 i			**2,0 l 83 kW O Series EFi 4 Zyl.**
Relay, Jetronic	10.84-08.88	DID	**0 332 014 112**

AUTOBIANCHI

Y 10

1.0 fire i.e.			**1,0 l 33 kW 156 A 2.146 KAT; 156 A 2.246; 156 A 2.256 KAT 4 Zyl.**
Temperature sensor, coolant, injection system	10.87-09.92		**0 280 130 026**
1.0 fire i.e. 4x4			**1,0 l 33 kW 156 A 2.146 KAT 4 Zyl.**
Temperature sensor, coolant, injection system	10.87-07.89		**0 280 130 026**
1.1 fire i.e.			**1,1 l 37/41 kW 156 C.000; 156 C.046 KAT 4 Zyl.**
Temperature sensor, coolant, injection system	01.89-09.92		**0 280 130 026**
1.1 fire i.e. 4x4			**1,1 l 41 kW 156 C.000 KAT 4 Zyl.**
Temperature sensor, coolant, injection system	01.89-09.92		**0 280 130 026**
1.1 i.e. [R.92]			**1,1 l 37 kW 156 C 046 4 Zyl.**
Speed sensor, ignition/injection	09.92-01.95		**0 261 210 098**
Temperature sensor, coolant, injection system	09.92-01.95		**0 280 130 026**
1.1 i.e. [R.92]			**1,1 l 43 kW 176 B 2.000 4 Zyl.**
Speed sensor, ignition/injection	02.95-12.95		**0 261 210 117**
Temperature sensor, coolant, injection system	02.95-12.95		**0 280 130 026**
1.1 i.e. ECVT [R.92]			**1,1 l 40 kW 176 B 2.000 4 Zyl.**
Speed sensor, ignition/injection	02.95-12.95		**0 261 210 117**
Temperature sensor, coolant, injection system	02.95-12.95		**0 280 130 026**
1.1 i.e. Selectronic, i.e. 4x4 [R.92]			**1,1 l 37 kW 156 C 046 4 Zyl.**
Speed sensor, ignition/injection	09.92-01.95		**0 261 210 098**
Temperature sensor, coolant, injection system	09.92-01.95		**0 280 130 026**
1.3 GT i.e.			**1,3 l 53/54/57 kW 146 A 5.046 KAT; 146 B.000 4 Zyl.**
Throttle valve sensor	11.87-09.92		**0 280 120 328**
Air flow sensor, gasoline injection	11.87-09.92		**0 280 200 602**
Temperature sensor, coolant, injection system	11.87-09.92		**0 280 130 026**
Relay, Jetronic	11.87-09.92		**0 332 014 113**
1.3 i.e. [R.92]			**1,3 l 53 kW 146 A 5.046 MPI 4 Zyl.**
Air flow sensor, gasoline injection	09.92-12.95		**0 280 200 602**
Temperature sensor, coolant, injection system	09.92-12.95		**0 280 130 026**
Relay, Jetronic	09.92-12.95		**0 332 014 113**

A

Product

BENTLEY

Brooklands

6.8 V8		**6,8 l 182 kW L 410 MN 1T 8 Zyl.**
Throttle valve sensor	07.93-07.98	**0 280 122 007**
Air mass meter, gasoline injection	07.93-07.98	**0 280 217 801**
Phase sensor	07.93-07.98	**0 232 103 010**
Pulse generator, ignition/Jetronic	07.93-07.98	**0 261 210 047**
Pressure sensor, intake manifold, gasoline	07.93-07.98	**0 261 230 004**
Temperature sensor, intake air, injection system	07.93-07.98	**0 280 130 039**
Temperature sensor, coolant, injection system	07.93-07.98	**0 280 130 026**

Continental Cabrio

R 6.8 V8 Turbo		**6,8 l 286 kW L 410 MT 1T 8 Zyl.**
Throttle valve sensor	08.95-12.95	**0 280 122 007**
Air mass meter, gasoline injection	08.95-12.95	**0 280 217 801**
Phase sensor	08.95-12.95	**0 232 103 010**
Pulse generator, ignition/Jetronic	08.95-12.95	**0 261 210 047**
Pressure sensor, intake manifold, gasoline	08.95-12.95	**0 261 230 004**
Temperature sensor, intake air, injection system	08.95-12.95	**0 280 130 039**
Temperature sensor, coolant, injection system	08.95-12.95	**0 280 130 026**

Mulsanne

6.8		**6,8 lV8 8 Zyl.**
Air flow sensor, gasoline injection	01.81-12.86	**0 438 120 157**
6.8 Turbo		**6,8 l 232 kW V8 8 Zyl.**
Throttle valve sensor	10.86-05.90	**0 280 120 300**
Air flow sensor, gasoline injection	10.86-05.90	**0 438 121 063**
Speed sensor, ignition/injection	10.86-05.90	**0 261 210 003**
Pressure sensor, intake manifold, gasoline	10.86-05.90	**0 281 002 018**
Temperature sensor, coolant, injection system	10.86-05.90	**0 280 130 032**

Turbo R, S

R 6.8		**6,8 l 232/240 kW V8 8 Zyl.**
Throttle valve sensor	11.91-03.93	**0 280 120 300**
Air flow sensor, gasoline injection	11.91-03.93	**F 026 TX2 056**
		F 026 TX2 056
Speed sensor, ignition/injection	11.91-03.93	**0 261 210 047**
Pressure sensor, intake manifold, gasoline	11.91-03.93	**0 281 002 018**
Temperature sensor, coolant, injection system	11.91-03.93	**0 280 130 026**
R 6.8 V8		**6,8 l 265 kW L 410 MT 8 Zyl.**
Throttle valve sensor	04.93-07.95	**0 280 122 007**
Air mass meter, gasoline injection	04.93-07.95	**0 280 217 801**
Temperature sensor, intake air, injection system	04.93-07.95	**0 280 130 039**
Temperature sensor, coolant, injection system	04.93-07.95	**0 280 130 026**
R 6.8 V8		**6,8 l 286 kW L 410 MT 1T 8 Zyl.**
Throttle valve sensor	07.95-07.99	**0 280 122 007**
Air mass meter, gasoline injection	07.95-07.99	**0 280 217 801**
Phase sensor	07.95-07.99	**0 232 103 010**
Speed sensor, ignition/injection	07.95-07.99	**0 261 210 047**
Pressure sensor, intake manifold, gasoline	07.95-07.99	**0 261 230 004**
Temperature sensor, intake air, injection system	07.95-07.99	**0 280 130 039**
Temperature sensor, coolant, injection system	07.95-07.99	**0 280 130 026**

Product

BERTONE

Freeclimber

1.6 i			**1,6 l 74 kW M 40 B 16 4 Zyl.**
Air flow sensor, gasoline injection	02.92→	KAT	**0 280 200 204**
			0 986 280 029
		OKA	**0 280 200 205**
			0 986 280 040
Temperature sensor, coolant, injection system	02.92→		**0 280 130 026**

BMW

Serie M

M 3 [E 30]			**2,3 l 143-158 kW 23 4E A/S 2 4 Zyl.**
Throttle valve sensor	07.86-12.90		**0 280 120 301**
Air flow sensor, gasoline injection	07.86-12.90		**0 280 203 028**
			0 986 280 049
Speed sensor, ignition/injection	07.86-12.90		**0 261 210 002**
Pressure sensor, intake manifold, gasoline	07.86-11.86		**0 280 101 001**
Temperature sensor, coolant, injection system	07.86-12.90		**0 280 130 026**
Wheel speed sensor	07.86-12.90	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
M 3 [E 36]			**3,0 l 210 kW 30 6S 1 6 Zyl.**
Air mass meter, gasoline injection	01.94-09.95		**0 280 217 806**
Knock sensor	01.94-09.95	MI	**0 261 231 092**
M 3 Evolution I [E 30]			**2,3 l 147 kW 23 4E A 4 Zyl.**
Throttle valve sensor	02.87-05.87		**0 280 120 301**
Air flow sensor, gasoline injection	02.87-05.87		**0 280 203 028**
			0 986 280 049
Speed sensor, ignition/injection	02.87-05.87		**0 261 210 002**
Pressure sensor, intake manifold, gasoline	02.87-05.87		**0 280 101 001**
Temperature sensor, coolant, injection system	02.87-05.87		**0 280 130 026**
Wheel speed sensor	02.87-05.87	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
M 3 Evolution II [E 30]			**2,3 l 162 kW 23 4S 1 4 Zyl.**
Throttle valve sensor	03.88-08.88		**0 280 120 301**
Air flow sensor, gasoline injection	03.88-08.88		**0 280 203 028**
			0 986 280 049
Speed sensor, ignition/injection	03.88-08.88		**0 261 210 002**
Pressure sensor, intake manifold, gasoline	03.88-08.88		**0 280 101 001**
Temperature sensor, coolant, injection system	03.88-08.88		**0 280 130 026**
Wheel speed sensor	03.88-08.88	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
M 3 Evolution III [E 30]			**2,5 l 175 kW 25 4S 1 4 Zyl.**
Throttle valve sensor	12.89-04.90		**0 280 120 301**
Air flow sensor, gasoline injection	12.89-04.90		**0 280 203 027**
			0 986 280 002
Speed sensor, ignition/injection	12.89-04.90		**0 261 210 002**
Pressure sensor, intake manifold, gasoline	12.89-04.90		**0 280 101 001**
Temperature sensor, coolant, injection system	12.89-04.90		**0 280 130 026**
Wheel speed sensor	12.89-04.90	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
M 3 3.2 [E 36]			**3,2 l 236 kW 32 6S 1 6 Zyl.**
Air mass meter, gasoline injection	10.95-12.97		**0 280 217 806**
Knock sensor	10.95-12.97	MI	**0 261 231 092**

Product			
Pedal position sensor, EMS (electronic engine management)	10.95-12.97		**0 280 752 001**
M 5 [E 28]	**3,5 l 191-210 kW 35 6E D 6 Zyl.**		
Throttle valve sensor	01.85-12.87		**0 280 120 301**
Air flow sensor, gasoline injection	01.85-12.87		**0 280 203 025**
			0 986 280 043
Speed sensor, ignition/injection	01.85-12.87		**0 261 210 002**
Pressure sensor, intake manifold, gasoline	09.86-12.87	KAT	**0 280 101 001**
Temperature sensor, coolant, injection system	01.85-12.87		**0 280 130 023**
Wheel speed sensor	01.85-08.86	HI	**0 265 001 027**
	09.86-12.87	HI,LAB	**0 265 001 168**
		HI,RAB	**0 265 001 167**
	01.85-12.87	VO	**0 265 001 029**
M 5 [E 39]	**5,0 l 294 kW 50 8S 1 8 Zyl.**		
Air mass meter, gasoline injection	10.98→		**0 280 217 533**
Knock sensor	10.98→		**0 261 231 200**
Pedal position sensor, EMS (electronic engine management)	10.98→		**0 280 752 023**
Duo sensor, acceleration and yaw rate, brake system	10.98→		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	10.98-07.03		**0 265 005 303**
M 5 3.6 [E 34]	**3,5 l 232 kW 36 6S 1 6 Zyl.**		
Throttle valve sensor	10.88-12.93	AG	**0 280 120 404**
		GS	**0 280 120 301**
Air mass meter, gasoline injection	10.88-12.94		**0 280 214 001**
			0 986 280 124
Temperature sensor, coolant, injection system	11.90-12.94		**0 280 130 026**
Wheel speed sensor, front	10.88-12.93		**0 265 001 339**
M 5 3.8 [E 34]	**3,8 l 240-250 kW 38 6S 1 6 Zyl.**		
Air mass meter, gasoline injection	03.92-12.95		**0 280 214 006**
Wheel speed sensor, front	03.92-12.95		**0 265 001 339**
M 6 [E 24]	**3,4 l 191 kW 35 6E E 6 Zyl.**		
Throttle valve sensor	09.86-12.88		**0 280 120 301**
Air flow sensor, gasoline injection	09.86-12.88		**0 280 203 025**
			0 986 280 043
Pressure sensor, intake manifold, gasoline	09.86-12.88		**0 280 101 001**
Temperature sensor, coolant, injection system	09.86-12.88		**0 280 130 026**
Wheel speed sensor, front	09.86-12.88		**0 265 001 038**
Wheel speed sensor, rear	10.86-12.88	LAB	**0 265 001 168**
		RAB	**0 265 001 167**
M 535 i [E 28]	**3,4 l 136-141/150-160 kW 34 6E A; 34 6K A 6 Zyl.**		
Throttle valve sensor	01.86-12.87		**0 280 120 320**
	09.86-12.87	AG	**0 280 120 406**
Air flow sensor, gasoline injection	09.84-12.87		**0 280 203 027**
			0 986 280 002
Speed sensor, ignition/injection	09.84-08.86		**0 261 210 002**
	09.86-12.87		**0 261 210 035**
Pulse generator, ignition/Jetronic	09.86-12.87		**0 356 914 212**
Temperature sensor, coolant, injection system	09.84-12.87		**0 280 130 026**
Wheel speed sensor	09.84-08.86	HI	**0 265 001 027**
	09.86-12.87	HI,LAB	**0 265 001 168**
		HI,RAB	**0 265 001 167**
	09.84-12.87	VO	**0 265 001 029**
M 635 CSi [E 24]	**3,5 l 191-210 kW 35 6E D 6 Zyl.**		
Throttle valve sensor	03.84-04.89		**0 280 120 301**
Air flow sensor, gasoline injection	03.84-04.89		**0 280 203 025**
			0 986 280 043
Speed sensor, ignition/injection	03.84-04.89		**0 261 210 002**
Pressure sensor, intake manifold, gasoline	09.86-04.89		**0 280 101 001**
Temperature sensor, coolant, injection system	03.84-04.89		**0 280 130 026**
Wheel speed sensor, front	03.84-04.89		**0 265 001 038**

Product			
Wheel speed sensor, rear	03.84-09.86		**0 265 001 027**
	10.86-04.89	LAB	**0 265 001 168**
		RAB	**0 265 001 167**

Serie M Cabrio

M 3 [E 30]	**2,3 l 143-158 kW 23 4E A/S 2 4 Zyl.**		
Throttle valve sensor	03.88-09.91		**0 280 120 301**
Air flow sensor, gasoline injection	03.88-09.91		**0 280 203 028**
			0 986 280 049
Speed sensor, ignition/injection	03.88-09.91		**0 261 210 002**
Temperature sensor, coolant, injection system	03.88-09.91		**0 280 130 026**
Wheel speed sensor	03.88-09.91	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
M 3 [E 36]	**3,0 l 210 kW 30 6S 1 6 Zyl.**		
Air mass meter, gasoline injection	01.94-12.95		**0 280 217 806**
Knock sensor	01.94-12.95	MI	**0 261 231 092**
M 3 3.2 [E 36]	**3,2 l 236 kW 32 6S 1 6 Zyl.**		
Air mass meter, gasoline injection	01.96-12.99		**0 280 217 806**
Knock sensor	01.96-12.99	MI	**0 261 231 092**
Pedal position sensor, EMS (electronic engine management)	01.96-12.99		**0 280 752 001**

Serie M Coupé

M 3 [E 36]	**3,0 l 179 kW 30 6S 2 6 Zyl.**		
Air mass meter, gasoline injection	09.93-12.96		**0 280 217 502**
Phase sensor	09.93-12.96	NOC	**0 232 103 003**
Temperature sensor, coolant, injection system	09.93-09.95		**0 280 130 026**
M 3 [E 36]	**3,0 l 210 kW 30 6S 1 6 Zyl.**		
Air mass meter, gasoline injection	09.92-09.95		**0 280 217 806**
Knock sensor	09.92-09.95	MI	**0 261 231 092**
Temperature sensor, intake air, injection system	09.92-09.95		**0 280 130 060**
M 3 3.2 [E 36]	**3,2 l 236 kW 32 6S 1/3 6 Zyl.**		
Air mass meter, gasoline injection	10.95-12.98		**0 280 217 806**
Knock sensor	10.95-12.98	MI	**0 261 231 092**

Serie M Touring

M 5 [E 34]	**3,8 l 240-250 kW 38 6S 1 6 Zyl.**		
Air mass meter, gasoline injection	04.92-12.95		**0 280 214 006**
Wheel speed sensor, front	04.92-12.95		**0 265 001 339**

Serie X

X 3 2.0 d [E 83]	**2,0 l 110 kW 20 4D 4 4 Zyl.**		
Air mass meter, diesel	10.04-09.07		**0 928 400 529**
Duo sensor, acceleration and yaw rate, brake system	10.04-09.06		**0 265 005 285**
Wheel speed sensor, front	10.04-09.05		**0 265 007 621**
Wheel speed sensor, rear	10.04-09.05		**0 265 007 622**
X 3 2.0i [E 83]	**2,0 l 110 kW N46 B20B 4 Zyl.**		
Air mass meter, gasoline injection	09.05→	BFK	**0 280 218 165**
		BHK	**0 280 218 159**
Duo sensor, acceleration and yaw rate, brake system	09.05-09.06		**0 265 005 285**
X 3 2.5i [E 83]	**2,5 l 141 kW 25 6S 5 6 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	03.04-09.06		**0 265 005 285**
Wheel speed sensor, front	03.04-09.05		**0 265 007 621**
Wheel speed sensor, rear	03.04-09.05		**0 265 007 622**

B

Product

◀ Serie X

X 3 3.0 d [E 83]			**3,0 l 150 kW 30 6D 2 6 Zyl.**
Air mass meter, diesel	01.04-09.05		**0 928 400 529**
Duo sensor, acceleration and yaw rate, brake system	01.04-09.05		**0 265 005 285**
Wheel speed sensor, front	01.04-09.05		**0 265 007 621**
Wheel speed sensor, rear	01.04-09.05		**0 265 007 622**
X 3 3.0 d [E 83]			**3,0 l 160 kW 30 6D 3 6 Zyl.**
Air mass meter, diesel	10.06-02.07		**0 281 002 849**
	09.05-09.06		**0 928 400 529**
Duo sensor, acceleration and yaw rate, brake system	09.05-09.06		**0 265 005 285**
X 3 3.0 sd [E 83]			**3,0 l 210 kW 30 6D 5 6 Zyl.**
Air mass meter, diesel	09.06-02.07		**0 281 002 849**
X 3 3.0i [E 83]			**3,0 l 170 kW 30 6S 3 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	01.04-09.06		**0 265 005 285**
Wheel speed sensor, front	01.04-09.05		**0 265 007 621**
Wheel speed sensor, rear	01.04-09.05		**0 265 007 622**
X 5 3.0 d [E 53]			**3,0 l 135 kW 30 6D 1 6 Zyl.**
Air mass meter, diesel	03.01-09.03	UPE	**0 928 400 527**
High-pressure sensor (CR system)	03.01-09.03		**0 281 002 475**
Duo sensor, acceleration and yaw rate, brake system	03.01-09.03		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	03.01-09.03		**0 265 005 303**
X 5 3.0 d [E 53]			**3,0 l 160 kW 30 6D 2 6 Zyl.**
Air mass meter, diesel	10.03-10.06		**0 928 400 529**
High-pressure sensor (CR system)	10.03-10.06		**0 281 002 497**
Duo sensor, acceleration and yaw rate, brake system	10.03-10.06		**0 265 005 285**
Wheel speed sensor, rear	10.03-10.06		**0 265 007 853**
X 5 3.0 d [E 70]			**3,0 l 173 kW 30 6D 3 6 Zyl.**
Air mass meter, diesel	03.07→		**0 928 400 529**
Duo sensor, acceleration and yaw rate, brake system	03.07→	EAO	**0 265 005 678**
X 5 3.0 si [E 70]			**3,0 l 200 kW N52 B30A 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	11.06→	EAO	**0 265 005 678**
X 5 3.0i [E 53]			**3,0 l 170 kW 30 6S 3 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.99-09.03		**0 265 005 248**
	10.03-10.06		**0 265 005 285**
Pressure sensor, ESP, (electronic stability program)	10.99-09.03		**0 265 005 303**
Wheel speed sensor, rear	10.03-10.06		**0 265 007 853**
X 5 4.4i [E 53]			**4,4 l 210 kW 44 8S 2 8 Zyl.**
Air mass meter, gasoline injection	03.99-09.03		**0 280 217 814**
Knock sensor	03.99-09.03		**0 261 231 200**
Duo sensor, acceleration and yaw rate, brake system	03.99-09.03		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	03.99-09.03		**0 265 005 303**
X 5 4.4i [E 53]			**4,4 l 235 kW N62 B44A 8 Zyl.**
Air mass meter, gasoline injection	10.03-10.06		**0 280 218 135**
Knock sensor	10.03-10.06		**0 261 231 200**
Duo sensor, acceleration and yaw rate, brake system	10.03-10.06		**0 265 005 285**
Wheel speed sensor, rear	10.03-10.06		**0 265 007 853**
X 5 4.6 is [E 53]			**4,6 l 255 kW 46 8S 1 8 Zyl.**
Air mass meter, gasoline injection	02.02-09.03		**0 280 217 814**
Knock sensor	02.02-09.03		**0 261 231 200**
Duo sensor, acceleration and yaw rate, brake system	02.02-09.03		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	02.02-09.03		**0 265 005 303**
X 5 4.8 is [E 53]			**4,8 l 265 kW N62 B48A 8 Zyl.**
Air mass meter, gasoline injection	03.04-10.06		**0 280 218 135**
Knock sensor	03.04-10.06		**0 261 231 200**

Product

Duo sensor, acceleration and yaw rate, brake system	03.04-10.06		**0 265 005 285**
Wheel speed sensor, rear	03.04-10.06		**0 265 007 853**
X 5 4.8i [E 70]			**4,8 l 261 kW N62 B48B 8 Zyl.**
Knock sensor	11.06→		**0 261 231 200**
Duo sensor, acceleration and yaw rate, brake system	11.06→	EAO	**0 265 005 678**

Serie Z

Z 1 [E30]			**2,5 l 125 kW 25 6K 1 6 Zyl.**
Throttle valve sensor	07.88-06.91		**0 280 120 310**
Air flow sensor, gasoline injection	07.88-06.91		**0 280 202 082**
			0 986 280 003
Pulse generator, ignition/Jetronic	07.88-06.91		**0 356 914 212**
Temperature sensor, coolant, injection system	07.88-06.91		**0 280 130 026**
Wheel speed sensor, front	07.88-06.91	LAB	**0 265 001 038**
		RAB	**0 265 001 057**
Wheel speed sensor, rear	07.88-09.90		**0 265 001 244**
Z 3 M 3.2 [E 36/7]			**3,2 l 236 kW 32 6S 1 6 Zyl.**
Air mass meter, gasoline injection	11.96-12.00		**0 280 217 806**
Knock sensor	11.96-12.00	MI	**0 261 231 092**
Z 3 M 3.2 [E 36/7]			**3,2 l 239 kW 32 6S 4 6 Zyl.**
Pedal position sensor, EMS (electronic engine management)	03.01-12.02		**0 280 752 023**
Z 3 1.8 [E 36/7]			**1,8 l 85 kW 18 4E 2 4 Zyl.**
Air flow sensor, gasoline injection	09.94-12.98	OKA	**0 280 202 135**
Z 3 1.9 [E 36/7]			**1,9 l 87 kW 19 4E 1 4 Zyl.**
Air mass meter, gasoline injection	09.98-12.02		**0 280 217 124**
Z 3 1.9 [E 36/7]			**1,9 l 103 kW 19 4S 1 4 Zyl.**
Air mass meter, gasoline injection	09.95-12.99		**0 280 217 110**
Z 3 2.2i [E 36/7]			**2,2 l 125 kW 22 6S 1 6 Zyl.**
Pedal position sensor, EMS (electronic engine management)	09.00-12.02		**0 281 002 291**
Z 3 2.5i [E 36/7]			**2,5 l 141 kW 25 6S 5 6 Zyl.**
Pedal position sensor, EMS (electronic engine management)	09.00-12.02		**0 281 002 291**
Z 3 3.0i [E 36/7]			**3,0 l 170 kW 30 6S 3 6 Zyl.**
Pedal position sensor, EMS (electronic engine management)	05.00-12.02		**0 281 002 291**
Z 4 2.0i [E 85]			**2,0 l 110 kW N46 B20... 4 Zyl.**
Air mass meter, gasoline injection	03.05→	BFK	**0 280 218 165**
		BHK	**0 280 218 159**
Z 8 [E 52]			**5,0 l 294 kW 50 8S 1 8 Zyl.**
Air mass meter, gasoline injection	03.00-07.03		**0 280 217 533**
Knock sensor	03.00-07.03		**0 261 231 200**
Duo sensor, acceleration and yaw rate, brake system	03.00-07.03		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	03.00-07.03		**0 265 005 303**

Serie Z Coupé

Z 3 M 3.2 [E 36/8]			**3,2 l 236 kW 32 6S 1/3 6 Zyl.**
Air mass meter, gasoline injection	09.97-12.00		**0 280 217 806**
Knock sensor	09.97-12.00	MI	**0 261 231 092**
Z 3 M 3.2 [E 36/8]			**3,2 l 239 kW 32 6S 4 6 Zyl.**
Pedal position sensor, EMS (electronic engine management)	03.01-12.02		**0 280 752 023**
Z 3 3.0i [E 36/8]			**3,0 l 170 kW 30 6S 3 6 Zyl.**
Pedal position sensor, EMS (electronic engine management)	05.00-12.02		**0 281 002 291**

Product			

Serie 1

116 i [E 87]			**1,6 l 85 kW N45 B16A 4 Zyl.**
Air mass meter, gasoline injection	09.04-03.07		**0 280 218 075**
118 d [E 81]			**2,0 l 100-105 kW N47 D20A 4 Zyl.**
Air mass meter, diesel	05.07→		**0 281 002 567**
118 d [E 87]			**2,0 l 90 kW 20 4D 4 4 Zyl.**
Air mass meter, diesel	09.04-03.07		**0 928 400 529**
High-pressure sensor (CR system)	09.04-03.07		**0 281 002 497**
118 d [E 87]			**2,0 l 100-105 kW N47 D20A 4 Zyl.**
Air mass meter, diesel	03.07→		**0 281 002 567**
118 i [E 81]			**2,0 l 105 kW N43 B20A 4 Zyl.**
Air mass meter, gasoline injection	05.07→		**0 280 218 159**
118 i [E 87]			**2,0 l 95 kW N46 B20B 4 Zyl.**
Air mass meter, gasoline injection	11.04-03.07	BFK	**0 280 218 165**
		BHK	**0 280 218 159**
118 i [E 87]			**2,0 l 105 kW N43 B20A 4 Zyl.**
Air mass meter, gasoline injection	03.07→		**0 280 218 159**
120 d [E 81]			**2,0 l 120-130 kW N47 D20A 4 Zyl.**
Air mass meter, diesel	05.07→		**0 281 002 567**
120 d [E 87]			**2,0 l 120 kW 20 4D 4 4 Zyl.**
Air mass meter, diesel	09.04-03.07		**0 928 400 529**
High-pressure sensor (CR system)	09.04-03.07		**0 281 002 497**
120 d [E 87]			**2,0 l 120-130 kW N47 D20A 4 Zyl.**
Air mass meter, diesel	03.07→		**0 281 002 567**
120 i [E 81]			**2,0 l 115 kW N46 B20... 4 Zyl.**
Air mass meter, gasoline injection	05.07→	BHK	**0 280 218 159**
120 i [E 81]			**2,0 l 120-125 kW N43 B20A 4 Zyl.**
Air mass meter, gasoline injection	05.07→		**0 280 218 159**
120 i [E 87]			**2,0 l 110 kW N46 B20... 4 Zyl.**
Air mass meter, gasoline injection	09.04-03.07	BFK	**0 280 218 165**
		BHK	**0 280 218 159**
120 i [E 87]			**2,0 l 115 kW N46 B20... 4 Zyl.**
Air mass meter, gasoline injection	03.07→	BHK	**0 280 218 159**
120 i [E 87]			**2,0 l 120-125 kW N43 B20A 4 Zyl.**
Air mass meter, gasoline injection	03.07→		**0 280 218 159**
123 d [E 81]			**2,0 l 150 kW N47 D20B 4 Zyl.**
Air mass meter, diesel	09.07→		**0 281 002 567**
123 d [E 87]			**2,0 l 150 kW N47 D20B 4 Zyl.**
Air mass meter, diesel	09.07→		**0 281 002 567**

Serie 1 Coupé

120 d [E 82]			**2,0 l 130 kW N47 D20A 4 Zyl.**
Air mass meter, diesel	10.07→		**0 281 002 567**
123 d [E 82]			**2,0 l 150 kW N47 D20B 4 Zyl.**
Air mass meter, diesel	10.07→		**0 281 002 567**

Serie 3

316 [E 30]			**1,8 l 66 kW 18 4V D 4 Zyl.**
Temperature sensor, coolant, injection system	09.83-12.88		**0 280 130 026**
Wheel speed sensor	09.82-12.88	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
316 i [E 30]			**1,6 l 73-75 kW 16 4E 1 4 Zyl.**
Throttle valve sensor	09.88-12.91		**0 280 120 316**
Air flow sensor, gasoline injection	09.88-12.91	KAT	**0 280 200 204**
			0 986 280 029
		LLP,OKA	**0 280 200 205**
			0 986 280 040
Speed sensor, ignition/injection	09.88-03.89		**0 261 210 035**
Pulse generator, ignition/Jetronic	09.88-08.90		**0 356 914 212**
	09.90-12.91		**0 356 914 220**
Temperature sensor, coolant, injection system	09.88-12.91		**0 280 130 026**
Wheel speed sensor	09.88-12.91	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
316 i [E 30]			**1,8 l 75 kW 18 4K A 4 Zyl.**
Throttle valve sensor	09.87-12.88		**0 280 120 320**
Air flow sensor, gasoline injection	09.87-12.88		**0 280 202 039**
			0 986 280 001
Pressure sensor, intake manifold, gasoline	09.87-12.88	AG	**0 280 101 001**
		VFA	**0 280 101 005**
Temperature sensor, coolant, injection system	09.87-12.88		**0 280 130 023**
Wheel speed sensor	09.87-12.88	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
316 i [E 36]			**1,6 l 73-75 kW 16 4E 1 4 Zyl.**
Air flow sensor, gasoline injection	09.90-02.94	KAT	**0 280 200 204**
			0 986 280 029
		LLP,OKA	**0 280 200 205**
			0 986 280 040
Temperature sensor, coolant, injection system	09.90-02.94		**0 280 130 026**
316 i [E 36]			**1,6 l 75 kW 16 4E 2 4 Zyl.**
Air flow sensor, gasoline injection	09.93-12.98	KAT	**0 280 200 204**
			0 986 280 029
		LLP,OKA	**0 280 200 205**
			0 986 280 040
Knock sensor	09.93-09.95		**0 261 231 097**
Temperature sensor, coolant, injection system	09.93-09.95		**0 280 130 026**
316 i [E 36]			**1,8 l 85 kW 18 4E 1 4 Zyl.**
Air flow sensor, gasoline injection	10.91-10.94	OKA	**0 280 202 135**
Temperature sensor, coolant, injection system	10.91-10.94		**0 280 130 026**
316 i [E 46]			**1,6 l 75 kW 16 4E 3 4 Zyl.**
Air mass meter, gasoline injection	04.98-09.02		**0 280 217 124**
316 i [E 46]			**1,6 l 85 kW N40 B16A; N45 B16A 4 Zyl.**
Air mass meter, gasoline injection	03.02-03.05		**0 280 218 075**
316 i [E 46]			**1,8 l 85 kW N42 B18A; N46 B18A 4 Zyl.**
Air mass meter, gasoline injection	02.02-03.05		**0 280 218 075**
316 i [E 46]			**1,9 l 77 kW 19 4E 1 4 Zyl.**
Air mass meter, gasoline injection	04.98-09.02		**0 280 217 124**
316 i [E 90]			**1,6 l 85 kW N45 B16A 4 Zyl.**
Air mass meter, gasoline injection	09.05→		**0 280 218 075**
318 d [E 46]			**2,0 l 85 kW 20 4D 1 4 Zyl.**
Air mass meter, diesel	09.01-03.03	UPE	**0 928 400 527**
318 d [E 46]			**2,0 l 85 kW 20 4D 4 4 Zyl.**
Air mass meter, diesel	03.03-03.05	EU3,UPE	**0 928 400 527**
		EU4	**0 928 400 529**
High-pressure sensor (CR system)	03.03-03.05		**0 281 002 497**
318 d [E 90]			**2,0 l 90 kW 20 4D 4 4 Zyl.**
Air mass meter, diesel	09.05→		**0 928 400 529**
High-pressure sensor (CR system)	09.05→		**0 281 002 497**
318 i [E 30]			**1,8 l 75-77 kW 18 4K A 4 Zyl.**
Throttle valve sensor	01.86-12.87		**0 280 120 320**
Air flow sensor, gasoline injection	10.84-12.87		**0 280 202 039**
			0 986 280 001
Pressure sensor, intake manifold, gasoline	10.84-12.87	AG	**0 280 101 001**
	12.84-12.87	VFA	**0 280 101 005**
Temperature sensor, coolant, injection system	10.84-12.87		**0 280 130 023**
Relay, pump	10.84-12.87	TW	**0 280 230 001**
Wheel speed sensor	10.84-12.87	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**

B

Product			
◀ Serie 3			
318 i [E 30]		**1,8 l 77 kW 18 4E B 4 Zyl.**	
Throttle valve sensor	07.82-12.87		**0 280 120 320**
	01.86-12.87		**0 280 120 320**
Air flow sensor, gasoline injection	07.82-12.87		**0 280 202 050**
			0 986 280 005
Temperature sensor, coolant, injection system	09.83-12.87		**0 280 130 023**
Relay, pump	07.82-12.87	TW	**0 280 230 001**
Wheel speed sensor	09.83-12.87	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
318 i [E 30]		**1,8 l 83-85 kW 18 4E 1 4 Zyl.**	
Throttle valve sensor	09.87-12.91		**0 280 120 316**
Air flow sensor, gasoline injection	09.87-12.91	OKA	**0 280 202 135**
Speed sensor, ignition/injection	09.87-03.89		**0 261 210 035**
Pulse generator, ignition/Jetronic	09.87-08.90		**0 356 914 212**
	09.90-12.91		**0 356 914 220**
Temperature sensor, coolant, injection system	09.87-12.91		**0 280 130 026**
Wheel speed sensor	09.87-12.91	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
318 i [E 36]		**1,8 l 83-85 kW 18 4E 1 4 Zyl.**	
Air flow sensor, gasoline injection	12.90-02.94	LLP,OKA	**0 280 202 135**
Temperature sensor, coolant, injection system	12.90-02.94		**0 280 130 026**
318 i [E 36]		**1,8 l 85 kW 18 4E 2 4 Zyl.**	
Air flow sensor, gasoline injection	09.93-12.98	LLP,OKA	**0 280 202 135**
	11.92-10.98	OKA	**0 280 202 135**
Knock sensor	11.92-09.95		**0 261 231 097**
Temperature sensor, coolant, injection system	09.93-09.95		**0 280 130 026**
Relay, Jetronic	11.92-10.98		**0 332 019 456**
318 i [E 36]		**1,8 l 103 kW 18 4S 1 4 Zyl.**	
Air flow sensor, gasoline injection	03.92-10.96	LLP,OKA	**0 280 202 135**
	11.92-10.96	OKA	**0 280 202 135**
Knock sensor	03.92-10.96		**0 261 231 072**
Temperature sensor, coolant, injection system	03.92-09.95		**0 280 130 026**
	11.92-10.96		**0 280 130 026**
318 i [E 36]		**1,9 l 103 kW 19 4S 1 4 Zyl.**	
Air mass meter, gasoline injection	09.95-12.98		**0 280 217 110**
318 i [E 46]		**1,9 l 87 kW 19 4E 1 4 Zyl.**	
Air mass meter, gasoline injection	04.98-09.01		**0 280 217 124**
318 i [E 46]		**2,0 l 105 kW N42 B20A; N46 B20... 4 Zyl.**	
Air mass meter, gasoline injection	09.01-03.05		**0 280 218 075**
318 i [E 90]		**2,0 l 95 kW N46 B20B 4 Zyl.**	
Air mass meter, gasoline injection	09.05→	BFK	**0 280 218 165**
		BHK	**0 280 218 159**
318 is [E 30]		**1,8 l 100 kW 18 4S 1 4 Zyl.**	
Air flow sensor, gasoline injection	09.89-12.91	OKA	**0 280 202 135**
Phase sensor	09.89-12.91	NOC	**0 261 210 058**
Speed sensor, ignition/injection	09.89-12.91	FKW	**0 261 210 057**
Temperature sensor, coolant, injection system	09.89-12.91		**0 280 130 026**
Wheel speed sensor	09.89-12.91	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
318 is [E 36]		**1,8 l 103 kW 18 4S 1 4 Zyl.**	
Air flow sensor, gasoline injection	03.93-12.96	LLP,OKA	**0 280 202 135**
Knock sensor	03.93-12.96		**0 261 231 072**
Temperature sensor, coolant, injection system	03.93-09.95		**0 280 130 026**
318 is [E 36]		**1,9 l 103 kW 19 4S 1 4 Zyl.**	
Air mass meter, gasoline injection	03.95-12.98		**0 280 217 110**
318 tds [E 36]		**1,7 l 66 kW 17 4T 1 4 Zyl.**	
Pedal position sensor, diesel	10.94-03.98		**0 205 001 040**
320 d [E 46]		**2,0 l 100 kW 20 4D 1 4 Zyl.**	
Air mass meter, diesel	11.00-09.01	UPE	**0 928 400 527**
Pedal position sensor, diesel	04.98-09.01		**0 205 001 040**

Product			
320 d [E 46]		**2,0 l 110 kW 20 4D 4 4 Zyl.**	
Air mass meter, diesel	09.01-03.05	EU3,UPE	**0 928 400 527**
		EU4	**0 928 400 529**
High-pressure sensor (CR system)	09.01-03.05		**0 281 002 497**
320 d [E 90]		**2,0 l 110/120 kW 20 4D 4 4 Zyl.**	
Air mass meter, diesel	03.05→		**0 928 400 529**
High-pressure sensor (CR system)	03.05→		**0 281 002 497**
320 i [E 30]		**2,0 l 90-95 kW 20 6E E/K A 6 Zyl.**	
Throttle valve sensor	12.85-12.91	AG	**0 280 120 402**
		GS	**0 280 120 321**
Air flow sensor, gasoline injection	09.86-12.91		**0 280 202 083**
			0 986 280 009
Speed sensor, ignition/injection	12.85-09.87		**0 261 210 028**
	12.86-03.89		**0 261 210 035**
Pulse generator, ignition/Jetronic	12.86-08.90		**0 356 914 212**
	09.90-12.91		**0 356 914 220**
Temperature sensor, coolant, injection system	12.85-12.91		**0 280 130 026**
Relay, pump	12.85-12.91	TW	**0 280 230 001**
Wheel speed sensor	12.85-12.91	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
320 i [E 30]		**2,0 l 92-95 kW 20 6E B/Z 6 Zyl.**	
Throttle valve sensor	01.86-09.87		**0 280 120 319**
Air flow sensor, gasoline injection	10.85-09.87		**0 280 202 090**
			0 986 280 068
Speed sensor, ignition/injection	09.82-09.87		**0 261 210 028**
Temperature sensor, coolant, injection system	10.84-09.87		**0 280 130 026**
Relay, pump	09.82-09.87	TW	**0 280 230 001**
Wheel speed sensor	09.82-09.87	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
320 i [E 36]		**2,0 l 95 kW 20 6S 1/2 6 Zyl.**	
Temperature sensor, coolant, injection system	10.91-01.93		**0 280 130 026**
320 i [E 36]		**2,0 l 110 kW 20 6S 1/2 6 Zyl.**	
Air mass meter, gasoline injection	09.90-09.92	BO	**0 280 212 025**
			0 986 280 111
			0 986 280 130
Phase sensor	09.90-09.92	BOM,NOC	**0 261 210 053**
Temperature sensor, intake air, injection system	09.90-12.95		**0 280 130 039**
Temperature sensor, coolant, injection system	09.90-09.92		**0 280 130 026**
320 i [E 90]		**2,0 l 110 kW N46 B20... 4 Zyl.**	
Air mass meter, gasoline injection	03.05-03.07	BFK	**0 280 218 165**
	03.05→	BHK	**0 280 218 159**
320 is [E 30]		**2,0 l 141 kW 20 4E A 4 Zyl.**	
Throttle valve sensor	01.88-12.90		**0 280 120 301**
Air flow sensor, gasoline injection	01.88-12.90		**0 280 203 028**
			0 986 280 049
Speed sensor, ignition/injection	01.88-12.90		**0 261 210 002**
Pressure sensor, intake manifold, gasoline	01.88-12.90		**0 280 101 001**
Temperature sensor, coolant, injection system	01.88-12.90		**0 280 130 026**
Wheel speed sensor	01.88-12.90	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
320 si [E 90]		**2,0 l 127 kW N45 B20A 4 Zyl.**	
Air mass meter, gasoline injection	03.06-09.06	BFK	**0 280 218 165**
		BHK	**0 280 218 159**
323 i [E 30]		**2,3 l 102-110 kW 23 6E B/C/W 6 Zyl.**	
Throttle valve sensor	09.82-12.86		**0 280 120 301**
Air flow sensor, gasoline injection	10.85-12.86		**0 280 202 090**
			0 986 280 068
Temperature sensor, coolant, injection system	09.84-12.86		**0 280 130 026**
Relay, pump	09.82-12.86	TW	**0 280 230 001**

Product			
Wheel speed sensor	09.82-12.86	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
324 d [E 30]		**2,4 l 63 kW 24 6D A/B 6 Zyl.**	
Pressure sensor, intake manifold, diesel	09.88-12.90		**0 281 002 018**
Temperature sensor, coolant, diesel	09.88-12.90		**0 280 130 055**
Temperature sensor, intake air, diesel	09.88-12.90		**0 280 130 039**
Pedal position sensor, diesel	09.88-12.90		**0 132 009 316**
Wheel speed sensor	09.85-12.90	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
324 td [E 30]		**2,4 l 85 kW 24 6T B 6 Zyl.**	
Pressure sensor, intake manifold, diesel	09.87-12.90		**0 281 002 018**
Temperature sensor, coolant, diesel	09.87-12.90		**0 280 130 055**
Temperature sensor, intake air, diesel	09.87-12.90		**0 280 130 039**
Pedal position sensor, diesel	09.87-12.90		**0 132 009 315**
Wheel speed sensor	09.87-12.90	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
325 d [E 90]		**3,0 l 145 kW 30 6D 3 6 Zyl.**	
Air mass meter, diesel	09.06→		**0 928 400 529**
325 e [E 30]		**2,7 l 90 kW 6 Zyl.**	
Throttle valve sensor	01.86-12.88		**0 280 120 319**
	12.86-12.88	AG	**0 280 120 404**
Air flow sensor, gasoline injection	12.86-12.88		**0 280 202 083**
			0 986 280 009
	09.84-11.86		**0 280 202 091**
			0 986 280 006
Speed sensor, ignition/injection	01.86-11.86		**0 261 210 002**
	12.86-12.88		**0 261 210 035**
Pulse generator, ignition/Jetronic	12.86-12.88		**0 356 914 212**
Pressure sensor, intake manifold, gasoline	10.83-12.88		**0 280 101 001**
Temperature sensor, coolant, injection system	09.84-12.88		**0 280 130 026**
Wheel speed sensor	10.83-12.88	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
325 e [E 30]		**2,7 l 90-95 kW 27 6K A/B 6 Zyl.**	
Throttle valve sensor	01.85-11.86		**0 280 120 301**
	12.86-12.87		**0 280 120 319**
		AG	**0 280 120 404**
Air flow sensor, gasoline injection	09.86-12.87		**0 280 202 083**
			0 986 280 009
	09.85-08.86		**0 280 202 091**
			0 986 280 006
Speed sensor, ignition/injection	01.85-11.86		**0 261 210 001**
Pulse generator, ignition/Jetronic	12.86-12.87		**0 356 914 212**
Pressure sensor, intake manifold, gasoline	01.85-11.86		**0 280 101 001**
Temperature sensor, coolant, injection system	01.85-12.87		**0 280 130 026**
Wheel speed sensor	01.85-12.87	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
325 i [E 30]		**2,5 l 125 kW 25 6K 1 6 Zyl.**	
Throttle valve sensor	12.86-12.91	AG	**0 280 120 402**
		GS	**0 280 120 321**
Air flow sensor, gasoline injection	12.86-12.91		**0 280 202 082**
			0 986 280 003
Speed sensor, ignition/injection	12.86-09.87		**0 261 210 028**
Pulse generator, ignition/Jetronic	12.86-12.91		**0 356 914 212**
Temperature sensor, coolant, injection system	12.86-12.91		**0 280 130 026**
Wheel speed sensor	12.86-12.91	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**

Product			
325 i [E 30]		**2,5 l 126 kW 25 6E 1/2 6 Zyl.**	
Throttle valve sensor	01.86-12.91		**0 280 120 321**
	09.85-12.91	AG	**0 280 120 402**
Air flow sensor, gasoline injection	09.85-12.91		**0 280 202 082**
			0 986 280 003
		TRO	**0 280 202 092**
Speed sensor, ignition/injection	09.85-09.87		**0 261 210 028**
Temperature sensor, coolant, injection system	09.85-12.91		**0 280 130 026**
Wheel speed sensor	09.85-12.91	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
325 i [E 36]		**2,5 l 138 kW 25 6S 1/2 6 Zyl.**	
Air mass meter, gasoline injection	04.91-02.93		**0 280 213 011**
			0 986 280 116
Phase sensor	07.93-08.95		**0 261 210 053**
Temperature sensor, coolant, injection system	04.91-08.95		**0 280 130 026**
325 i [E 36]		**2,5 l 141 kW 25 6S 1/2 6 Zyl.**	
Air mass meter, gasoline injection	09.90-09.92		**0 280 213 011**
			0 986 280 116
	10.92-12.95		**0 280 217 502**
Phase sensor	09.90-09.92	BOM,NOC	**0 261 210 053**
	10.92-12.95	NOC	**0 232 103 003**
Temperature sensor, intake air, injection system	09.90-12.95		**0 280 130 039**
Temperature sensor, coolant, injection system	09.90-09.95		**0 280 130 026**
325 iX [E 30]		**2,5 l 125 kW 25 6K 1 6 Zyl.**	
Throttle valve sensor	12.86-12.91	AG	**0 280 120 402**
		GS	**0 280 120 321**
Air flow sensor, gasoline injection	12.86-12.91		**0 280 202 082**
			0 986 280 003
Pulse generator, ignition/Jetronic	12.86-12.91		**0 356 914 212**
Temperature sensor, coolant, injection system	12.86-12.91		**0 280 130 026**
Acceleration sensor, ABS	12.86-12.91		**0 265 005 003**
Wheel speed sensor	12.86-12.91	HI	**0 265 001 059**
		VO	**0 265 001 113**
325 iX [E 30]		**2,5 l 126 kW 25 6E 1/2 6 Zyl.**	
Throttle valve sensor	03.86-12.91		**0 280 120 321**
		AG	**0 280 120 402**
Air flow sensor, gasoline injection	03.86-12.91		**0 280 202 082**
			0 986 280 003
		TRO	**0 280 202 092**
Speed sensor, ignition/injection	03.86-09.87		**0 261 210 028**
Temperature sensor, coolant, injection system	03.86-12.91		**0 280 130 026**
Acceleration sensor, ABS	03.86-12.91		**0 265 005 003**
Wheel speed sensor	03.86-12.91	HI	**0 265 001 059**
		VO	**0 265 001 113**
325 td [E 36]		**2,5 l 85 kW 25 6T 1 6 Zyl.**	
Pressure sensor, intake manifold, diesel	09.91-09.92		**0 281 002 063**
Temperature sensor, coolant, diesel	09.91-01.96		**0 280 130 055**
Pedal position sensor, diesel	09.91-12.98		**0 205 001 040**
325 tds [E 36]		**2,5 l 105 kW 25 6T 1 6 Zyl.**	
Temperature sensor, coolant, diesel	05.93-01.96		**0 280 130 055**
Pedal position sensor, diesel	05.93-12.98		**0 205 001 040**
325 xi [E 46]		**2,5 l 141 kW 25 6S 5 6 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	09.00-03.05		**0 265 005 248**
325 xi [E 90]		**2,5 l 160 kW N52 B25A 6 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	09.05→		**0 265 005 678**
Wheel speed sensor, front	09.05→		**0 265 007 669**
Wheel speed sensor, rear	09.05→		**0 265 007 670**
330 d [E 46]		**3,0 l 135 kW 30 6D 1 6 Zyl.**	
Air mass meter, diesel	02.01-03.03	UPE	**0 928 400 527**
High-pressure sensor (CR system)	10.99-03.03		**0 281 002 475**

B

Product			

◀ Serie 3

330 d [E 46]		**3,0 l 150 kW 30 6D 2 6 Zyl.**	
Air mass meter, diesel	03.03-03.05		**0 928 400 529**
High-pressure sensor (CR system)	03.03-03.05		**0 281 002 497**
330 d [E 90]		**3,0 l 170 kW 30 6D 3 6 Zyl.**	
Air mass meter, diesel	09.05→		**0 928 400 529**
High-pressure sensor (CR system)	09.05→		**0 281 002 497**
330 xd [E 46]		**3,0 l 135 kW 30 6D 1 6 Zyl.**	
Air mass meter, diesel	02.01-03.03	UPE	**0 928 400 527**
High-pressure sensor (CR system)	07.00-03.03		**0 281 002 475**
Duo sensor, acceleration and yaw rate, brake system	07.00-03.03		**0 265 005 248**
330 xd [E 46]		**3,0 l 150 kW 30 6D 2 6 Zyl.**	
Air mass meter, diesel	03.03-03.05		**0 928 400 529**
High-pressure sensor (CR system)	03.03-03.05		**0 281 002 497**
Duo sensor, acceleration and yaw rate, brake system	03.03-03.05		**0 265 005 248**
330 xd [E 90]		**3,0 l 170 kW 30 6D 3 6 Zyl.**	
Air mass meter, diesel	09.05→		**0 928 400 529**
High-pressure sensor (CR system)	09.05→		**0 281 002 497**
Duo sensor, acceleration and yaw rate, brake system	09.05→		**0 265 005 678**
Wheel speed sensor, front	09.05→		**0 265 007 669**
Wheel speed sensor, rear	09.05→		**0 265 007 670**
330 xi [E 46]		**3,0 l 170 kW 30 6S 3 6 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	07.00-03.05		**0 265 005 248**
330 xi [E 90]		**3,0 l 190 kW N52 B30A 6 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	09.05→		**0 265 005 678**
Wheel speed sensor, front	09.05→		**0 265 007 669**
Wheel speed sensor, rear	09.05→		**0 265 007 670**
335 d [E 90]		**3,0 l 210 kW 30 6D 5 6 Zyl.**	
Air mass meter, diesel	09.06-02.07		**0 281 002 849**
335 xi [E 90]		**3,0 l 225 kW N54 B30A 6 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	03.07→		**0 265 005 678**
Wheel speed sensor, front	03.07→		**0 265 007 669**
Wheel speed sensor, rear	03.07→		**0 265 007 670**

Serie 3 Cabrio

318 Ci [E 46]		**2,0 l 105-110 kW N42 B20A; N46 B20... 4 Zyl.**	
Air mass meter, gasoline injection	09.01-03.07		**0 280 218 075**
318 i [E 30]		**1,8 l 83 kW 18 4E 1 4 Zyl.**	
Throttle valve sensor	09.90-12.93		**0 280 120 316**
Air flow sensor, gasoline injection	09.90-12.93	OKA	**0 280 202 135**
Pulse generator, ignition/Jetronic	09.90-12.93		**0 356 914 220**
Temperature sensor, coolant, injection system	09.90-12.93		**0 280 130 026**
Wheel speed sensor	09.90-12.93	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
318 i [E 30]		**1,8 l 103 kW 18 4S 1 4 Zyl.**	
Phase sensor	07.90-12.92	NOC	**0 261 210 058**
Speed sensor, ignition/injection	07.90-12.92	FKW	**0 261 210 057**
Temperature sensor, coolant, injection system	07.90-12.92		**0 280 130 026**
Wheel speed sensor	07.90-12.92	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
318 i [E 36]		**1,8 l 83-85 kW 18 4E 2 4 Zyl.**	
Air flow sensor, gasoline injection	01.94-12.99	LLP,OKA	**0 280 202 135**
Knock sensor	01.94-09.95		**0 261 231 097**
Temperature sensor, coolant, injection system	01.94-09.95		**0 280 130 026**

Product			
318 i [E 36]		**1,8 l 103 kW 18 4S 1 4 Zyl.**	
Knock sensor	09.93-09.96		**0 261 231 072**
Temperature sensor, coolant, injection system	09.93-09.95		**0 280 130 026**
318 i [E 36]		**1,9 l 103 kW 19 4S 1 4 Zyl.**	
Air mass meter, gasoline injection	09.95-12.98		**0 280 217 110**
320 Cd [E 46]		**2,0 l 110 kW 20 4D 4 4 Zyl.**	
Air mass meter, diesel	01.05-03.07	EU3,UPE	**0 928 400 527**
		EU4	**0 928 400 529**
High-pressure sensor (CR system)	01.05-03.07		**0 281 002 497**
320 i [E 30]		**2,0 l 92-95 kW 20 6E B 6 Zyl.**	
Throttle valve sensor	04.86-09.87		**0 280 120 319**
Air flow sensor, gasoline injection	04.86-09.87		**0 280 202 090**
			0 986 280 068
Speed sensor, ignition/injection	04.86-09.87		**0 261 210 028**
Temperature sensor, coolant, injection system	04.86-09.87		**0 280 130 026**
Relay, pump	04.86-09.87	TW	**0 280 230 001**
Wheel speed sensor	04.86-09.87	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
320 i [E 30]		**2,0 l 95 kW 20 6E E/K A 6 Zyl.**	
Throttle valve sensor	04.86-12.93	AG	**0 280 120 402**
		GS	**0 280 120 321**
Air flow sensor, gasoline injection	09.86-12.93		**0 280 202 083**
			0 986 280 009
Speed sensor, ignition/injection	04.86-09.87		**0 261 210 028**
	12.86-03.89		**0 261 210 035**
Pulse generator, ignition/Jetronic	12.86-08.90		**0 356 914 212**
	09.90-12.93		**0 356 914 220**
Temperature sensor, coolant, injection system	04.86-12.93		**0 280 130 026**
Relay, pump	04.86-12.93	TW	**0 280 230 001**
Wheel speed sensor	04.86-12.93	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
320 i [E 93]		**2,0 l 115 kW N46 B20B 4 Zyl.**	
Air mass meter, gasoline injection	03.07→	BHK	**0 280 218 159**
320 i [E 93]		**2,0 l 120-125 kW N43 B20A 4 Zyl.**	
Air mass meter, gasoline injection	03.07→		**0 280 218 159**
325 i [E 30]		**2,5 l 125 kW 25 6K 1 6 Zyl.**	
Throttle valve sensor	12.86-12.92	AG	**0 280 120 402**
		GS	**0 280 120 321**
Air flow sensor, gasoline injection	12.86-12.92		**0 280 202 082**
			0 986 280 003
Speed sensor, ignition/injection	12.86-09.87		**0 261 210 028**
Pulse generator, ignition/Jetronic	12.86-12.92		**0 356 914 212**
Temperature sensor, coolant, injection system	12.86-12.92		**0 280 130 026**
Wheel speed sensor	12.86-12.92	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
325 i [E 30]		**2,5 l 126 kW 25 6E 1/2 6 Zyl.**	
Throttle valve sensor	01.86-12.92		**0 280 120 321**
	09.85-12.92	AG	**0 280 120 402**
Air flow sensor, gasoline injection	09.85-12.92		**0 280 202 082**
			0 986 280 003
		TRO	**0 280 202 092**
Speed sensor, ignition/injection	09.85-09.87		**0 261 210 028**
Temperature sensor, coolant, injection system	09.85-12.92		**0 280 130 026**
Wheel speed sensor	09.85-12.92	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
325 i [E 36]		**2,5 l 141 kW 25 6S 2 6 Zyl.**	
Air mass meter, gasoline injection	03.93-12.95		**0 280 217 502**
Phase sensor	03.93-12.95	NOC	**0 232 103 003**
Temperature sensor, coolant, injection system	03.93-09.95		**0 280 130 026**

Product			
330 Cd [E 46]			**3,0 l 150 kW 30 6D 2 6 Zyl.**
Air mass meter, diesel	04.05-03.07		**0 928 400 529**
High-pressure sensor (CR system)	04.05-03.07		**0 281 002 497**
330 d [E 93]			**3,0 l 170 kW 30 6D 3 6 Zyl.**
Air mass meter, diesel	03.07→		**0 928 400 529**
High-pressure sensor (CR system)	03.07→		**0 281 002 497**

Serie 3 Compact

316 g [E 36]			**1,6 l 64-75 kW 16 4E 2 4 Zyl.**
Air flow sensor, gasoline injection	11.95-09.00	KAT	**0 280 200 204**
			0 986 280 029
		LLP,OKA	**0 280 200 205**
			0 986 280 040
316 i [E 36]			**1,6 l 75 kW 16 4E 2 4 Zyl.**
Air flow sensor, gasoline injection	03.94-09.00	KAT	**0 280 200 204**
			0 986 280 029
		LLP,OKA	**0 280 200 205**
			0 986 280 040
Knock sensor	03.94-09.95		**0 261 231 097**
Temperature sensor, coolant, injection system	03.94-09.95		**0 280 130 026**
316 i [E 36]			**1,9 l 77 kW 19 4E 1 4 Zyl.**
Air mass meter, gasoline injection	12.98-09.00		**0 280 217 124**
316 ti [E 46]			**1,6 l 85 kW N40 B16A; N45 B16A 4 Zyl.**
Air mass meter, gasoline injection	03.02-12.04		**0 280 218 075**
316 ti [E 46]			**1,8 l 85 kW N42 B18A; N46 B18A 4 Zyl.**
Air mass meter, gasoline injection	06.01-12.04		**0 280 218 075**
318 td [E 46]			**2,0 l 85 kW 20 4D 4 4 Zyl.**
Air mass meter, diesel	03.03-12.04	EU3,UPE	**0 928 400 527**
		EU4	**0 928 400 529**
High-pressure sensor (CR system)	03.03-12.04		**0 281 002 497**
318 tds [E 36]			**1,7 l 66 kW 17 4T 1 4 Zyl.**
Pedal position sensor, diesel	01.95-09.00		**0 205 001 040**
318 ti [E 36]			**1,8 l 103 kW 18 4S 1 4 Zyl.**
Air flow sensor, gasoline injection	10.94-09.96	LLP,OKA	**0 280 202 135**
Knock sensor	10.94-09.96		**0 261 231 072**
Temperature sensor, coolant, injection system	10.94-09.95		**0 280 130 026**
318 ti [E 36]			**1,9 l 103 kW 19 4S 1 4 Zyl.**
Air mass meter, gasoline injection	12.95-09.00		**0 280 217 110**
Temperature sensor, intake air, injection system	12.95-09.00		**0 280 130 039**
318 ti [E 46]			**2,0 l 105 kW N42 B20A; N46 B20... 4 Zyl.**
Air mass meter, gasoline injection	09.01-12.04		**0 280 218 075**
320 td [E 46]			**2,0 l 110 kW 20 4D 4 4 Zyl.**
Air mass meter, diesel	09.01-12.04	EU3,UPE	**0 928 400 527**
		EU4	**0 928 400 529**
High-pressure sensor (CR system)	09.01-12.04		**0 281 002 497**

Serie 3 Coupé

316 Ci [E 46]			**1,6 l 75 kW 16 4E 3 4 Zyl.**
Air mass meter, gasoline injection	10.99-09.02		**0 280 217 124**
316 Ci [E 46]			**1,6 l 85 kW N40 B16A; N45 B16A 4 Zyl.**
Air mass meter, gasoline injection	03.02-09.06		**0 280 218 075**
316 i [E 36]			**1,6 l 75 kW 16 4E 2 4 Zyl.**
Air flow sensor, gasoline injection	09.93-12.99	KAT	**0 280 200 204**
			0 986 280 029
		LLP,OKA	**0 280 200 205**
			0 986 280 040
Knock sensor	09.93-09.95		**0 261 231 097**
Temperature sensor, coolant, injection system	09.93-09.95		**0 280 130 026**
318 Ci [E 46]			**1,9 l 87 kW 19 4E 1 4 Zyl.**
Air mass meter, gasoline injection	04.99-09.01		**0 280 217 124**

Product			
318 Ci [E 46]			**2,0 l 105-110 kW N42 B20A; N46 B20... 4 Zyl.**
Air mass meter, gasoline injection	09.01-09.06		**0 280 218 075**
318 is [E 36]			**1,8 l 103 kW 18 4S 1 4 Zyl.**
Air flow sensor, gasoline injection	03.92-09.96	LLP,OKA	**0 280 202 135**
Knock sensor	03.92-09.96		**0 261 231 072**
Temperature sensor, coolant, injection system	03.92-09.95		**0 280 130 026**
318 is [E 36]			**1,9 l 103 kW 19 4S 1 4 Zyl.**
Air mass meter, gasoline injection	12.95-12.99		**0 280 217 110**
320 Cd [E 46]			**2,0 l 110 kW 20 4D 4 4 Zyl.**
Air mass meter, diesel	09.03-09.06	EU3,UPE	**0 928 400 527**
		EU4	**0 928 400 529**
High-pressure sensor (CR system)	09.03-09.06		**0 281 002 497**
320 d [E 92]			**2,0 l 130 kW N47 D20A 4 Zyl.**
Air mass meter, diesel	03.07→		**0 281 002 567**
320 i [E 36]			**2,0 l 110 kW 20 6S 1/2 6 Zyl.**
Air mass meter, gasoline injection	03.92-09.92	BO	**0 280 212 025**
			0 986 280 111
			0 986 280 130
Phase sensor	03.92-09.92	BOM,NOC	**0 261 210 053**
Temperature sensor, intake air, injection system	03.92-12.95		**0 280 130 039**
320 i [E 92]			**2,0 l 115 kW N46 B20B 4 Zyl.**
Air mass meter, gasoline injection	03.07→	BHK	**0 280 218 159**
320 i [E 92]			**2,0 l 125 kW N43 B20A 4 Zyl.**
Air mass meter, gasoline injection	03.07→		**0 280 218 159**
325 d [E 92]			**3,0 l 145 kW 30 6D 3 6 Zyl.**
Air mass meter, diesel	03.07→		**0 928 400 529**
325 i [E 36]			**2,5 l 141 kW 25 6S 1/2 6 Zyl.**
Air mass meter, gasoline injection	03.92-09.92		**0 280 213 011**
			0 986 280 116
	10.92-12.95		**0 280 217 502**
Phase sensor	03.92-09.92	BOM,NOC	**0 261 210 053**
	10.92-12.95	NOC	**0 232 103 003**
Temperature sensor, intake air, injection system	03.92-12.95		**0 280 130 039**
Temperature sensor, coolant, injection system	03.92-09.95		**0 280 130 026**
325 is [E 36]			**2,5 l 141 kW 25 6S 1/2 6 Zyl.**
Air mass meter, gasoline injection	03.91-09.92		**0 280 213 011**
			0 986 280 116
	10.92-12.95		**0 280 217 502**
Phase sensor	03.91-09.92	BOM,NOC	**0 261 210 053**
	10.92-12.95	NOC	**0 232 103 003**
Temperature sensor, coolant, injection system	03.91-09.95		**0 280 130 026**
325 xi [E 92]			**2,5 l 160 kW N52 B25A 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.06→		**0 265 005 678**
Wheel speed sensor, front	09.06→		**0 265 007 669**
Wheel speed sensor, rear	09.06→		**0 265 007 670**
330 Cd [E 46]			**3,0 l 150 kW 30 6D 2 6 Zyl.**
Air mass meter, diesel	03.03-09.06		**0 928 400 529**
High-pressure sensor (CR system)	03.03-09.06		**0 281 002 497**
330 d [E 92]			**3,0 l 170 kW 30 6D 3 6 Zyl.**
Air mass meter, diesel	09.06→		**0 928 400 529**
330 xd [E 92]			**3,0 l 170 kW 30 6D 3 6 Zyl.**
Air mass meter, diesel	09.06→		**0 928 400 529**
Duo sensor, acceleration and yaw rate, brake system	09.06→		**0 265 005 678**
Wheel speed sensor, front	09.06→		**0 265 007 669**
Wheel speed sensor, rear	09.06→		**0 265 007 670**
330 xi [E 92]			**3,0 l 200 kW N52 B30A 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.06→		**0 265 005 678**
Wheel speed sensor, front	09.06→		**0 265 007 669**
Wheel speed sensor, rear	09.06→		**0 265 007 670**

B

Product			
◀ Serie 3 Coupé			
335 d [E 92]		**3,0 l 210 kW 30 6D 5 6 Zyl.**	
Air mass meter, diesel	09.06-02.07		**0 281 002 849**

Serie 3 Touring

316 i [E 30]		**1,6 l 73-75 kW 16 4E 1 4 Zyl.**	
Air flow sensor, gasoline injection	09.91-06.94	KAT	**0 280 200 204**
			0 986 280 029
		LLP,OKA	**0 280 200 205**
			0 986 280 040
Wheel speed sensor	09.91-06.94	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
316 i [E 36]		**1,6 l 75 kW 16 4E 2 4 Zyl.**	
Air flow sensor, gasoline injection	01.96-12.99	KAT	**0 280 200 204**
			0 986 280 029
		LLP,OKA	**0 280 200 205**
			0 986 280 040
316 i [E 46]		**1,8 l 85 kW N42 B18A; N46 B18A 4 Zyl.**	
Air mass meter, gasoline injection	03.02-09.05		**0 280 218 075**
318 d [E 46]		**2,0 l 85 kW 20 4D 1 4 Zyl.**	
Air mass meter, diesel	03.02-03.03	UPE	**0 928 400 527**
318 d [E 46]		**2,0 l 85 kW 20 4D 4 4 Zyl.**	
Air mass meter, diesel	03.03-09.05	EU3,UPE	**0 928 400 527**
		EU4	**0 928 400 529**
High-pressure sensor (CR system)	03.03-09.05		**0 281 002 497**
318 d [E 91]		**2,0 l 90 kW 20 4D 4 4 Zyl.**	
Air mass meter, diesel	03.06→		**0 928 400 529**
High-pressure sensor (CR system)	03.06→		**0 281 002 497**
318 i [E 30]		**1,8 l 83-85 kW 18 4E 1 4 Zyl.**	
Throttle valve sensor	04.89-06.94		**0 280 120 316**
Air flow sensor, gasoline injection	04.89-06.94	OKA	**0 280 202 135**
Pulse generator, ignition/Jetronic	04.89-08.90		**0 356 914 212**
	09.90-12.93		**0 356 914 220**
Temperature sensor, coolant, injection system	04.89-12.93		**0 280 130 026**
Wheel speed sensor	04.89-06.94	HI	**0 265 001 059**
		LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
318 i [E 36]		**1,8 l 85 kW 18 4E 2 4 Zyl.**	
Air flow sensor, gasoline injection	07.95-12.99	LLP,OKA	**0 280 202 135**
318 i [E 46]		**1,9 l 87 kW 19 4E 1 4 Zyl.**	
Air mass meter, gasoline injection	10.99-09.01		**0 280 217 124**
318 i [E 46]		**2,0 l 105 kW N42 B20A; N46 B20... 4 Zyl.**	
Air mass meter, gasoline injection	09.01-03.05		**0 280 218 075**
318 i [E 91]		**2,0 l 95 kW N46 B20B 4 Zyl.**	
Air mass meter, gasoline injection	03.06→	BFK	**0 280 218 165**
		BHK	**0 280 218 159**
318 tds [E 36]		**1,7 l 66 kW 17 4T 1 4 Zyl.**	
Pedal position sensor, diesel	03.95-12.99		**0 205 001 040**
320 d [E 46]		**2,0 l 100 kW 20 4D 1 4 Zyl.**	
Air mass meter, diesel	11.00-09.01	UPE	**0 928 400 527**
320 d [E 46]		**2,0 l 110 kW 20 4D 4 4 Zyl.**	
Air mass meter, diesel	09.01-09.05	EU3,UPE	**0 928 400 527**
		EU4	**0 928 400 529**
High-pressure sensor (CR system)	09.01-09.05		**0 281 002 497**
320 d [E 91]		**2,0 l 110/120 kW 20 4D 4 4 Zyl.**	
Air mass meter, diesel	09.05→		**0 928 400 529**
High-pressure sensor (CR system)	09.05→		**0 281 002 497**
320 i [E 30]		**2,0 l 90-95 kW 20 6E E/K A 6 Zyl.**	
Throttle valve sensor	01.88-12.91		**0 280 120 321**
		AG	**0 280 120 402**
Air flow sensor, gasoline injection	01.88-12.91		**0 280 202 083**
			0 986 280 009

Product			
Speed sensor, ignition/injection	01.88-03.89		**0 261 210 035**
Pulse generator, ignition/Jetronic	01.88-08.90		**0 356 914 212**
	09.90-12.91		**0 356 914 220**
Temperature sensor, coolant, injection system	01.88-12.91		**0 280 130 026**
Wheel speed sensor	04.89-12.91	HI	**0 265 001 059**
	01.88-03.89	HI	**0 265 001 199**
	01.88-12.91	LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
320 i [E 91]		**2,0 l 110 kW N46 B20... 4 Zyl.**	
Air mass meter, gasoline injection	09.05→	BFK	**0 280 218 165**
		BHK	**0 280 218 159**
324 td [E 30]		**2,4 l 85 kW 24 6T B 6 Zyl.**	
Pressure sensor, intake manifold, diesel	01.88-12.93		**0 281 002 018**
Temperature sensor, coolant, diesel	01.88-12.93		**0 280 130 055**
Temperature sensor, intake air, diesel	01.88-12.93		**0 280 130 039**
Pedal position sensor, diesel	01.88-12.93		**0 132 009 315**
Wheel speed sensor	04.89-12.93	HI	**0 265 001 059**
	01.88-03.89	HI	**0 265 001 199**
	01.88-12.93	LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
325 d [E 91]		**3,0 l 145 kW 30 6D 3 6 Zyl.**	
Air mass meter, diesel	09.06→		**0 928 400 529**
325 i [E 30]		**2,5 l 125 kW 25 6K 1 6 Zyl.**	
Throttle valve sensor	07.87-12.93	AG	**0 280 120 402**
		GS	**0 280 120 321**
Air flow sensor, gasoline injection	07.87-12.93		**0 280 202 082**
			0 986 280 003
Pulse generator, ignition/Jetronic	07.87-12.93		**0 356 914 212**
Temperature sensor, coolant, injection system	07.87-12.93		**0 280 130 026**
Wheel speed sensor	04.89-12.93	HI	**0 265 001 059**
	07.87-03.89	HI	**0 265 001 199**
	07.87-12.93	LAB,VO	**0 265 001 058**
		RAB,VO	**0 265 001 057**
325 iX [E 30]		**2,5 l 125 kW 25 6K 1 6 Zyl.**	
Throttle valve sensor	06.88-03.93		**0 280 120 321**
		AG	**0 280 120 402**
Air flow sensor, gasoline injection	06.88-03.93		**0 280 202 082**
			0 986 280 003
Pulse generator, ignition/Jetronic	06.88-03.93		**0 356 914 212**
Temperature sensor, coolant, injection system	06.88-03.93		**0 280 130 026**
Acceleration sensor, ABS	06.88-03.93		**0 265 005 003**
Wheel speed sensor	04.89-03.93	HI	**0 265 001 059**
	06.88-03.89	HI	**0 265 001 199**
	06.88-03.93	VO	**0 265 001 113**
325 tds [E 36]		**2,5 l 105 kW 25 6T 1 6 Zyl.**	
Temperature sensor, coolant, diesel	09.95-01.96		**0 280 130 055**
Pedal position sensor, diesel	09.95-12.99		**0 205 001 040**
325 xi [E 46]		**2,5 l 141 kW 25 6S 5 6 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	09.00-09.05		**0 265 005 248**
325 xi [E 91]		**2,5 l 160 kW N52 B25A 6 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	09.05→		**0 265 005 678**
Wheel speed sensor, front	09.05→		**0 265 007 669**
Wheel speed sensor, rear	09.05→		**0 265 007 670**
330 d [E 46]		**3,0 l 135 kW 30 6D 1 6 Zyl.**	
Air mass meter, diesel	02.01-03.03	UPE	**0 928 400 527**
High-pressure sensor (CR system)	10.99-03.03		**0 281 002 475**
330 d [E 46]		**3,0 l 150 kW 30 6D 2 6 Zyl.**	
Air mass meter, diesel	03.03-09.05		**0 928 400 529**
High-pressure sensor (CR system)	03.03-09.05		**0 281 002 497**
330 d [E 91]		**3,0 l 170 kW 30 6D 3 6 Zyl.**	
Air mass meter, diesel	09.05→		**0 928 400 529**

Product

330 xd [E 46]			**3,0 l 135 kW 30 6D 1 6 Zyl.**
Air mass meter, diesel	02.01-03.03	UPE	**0 928 400 527**
High-pressure sensor (CR system)	07.00-03.03		**0 281 002 475**
Duo sensor, acceleration and yaw rate, brake system	07.00-03.03		**0 265 005 248**
330 xd [E 46]			**3,0 l 150 kW 30 6D 2 6 Zyl.**
Air mass meter, diesel	03.03-09.05		**0 928 400 529**
High-pressure sensor (CR system)	03.03-09.05		**0 281 002 497**
Duo sensor, acceleration and yaw rate, brake system	03.03-09.05		**0 265 005 248**
330 xd [E 91]			**3,0 l 170 kW 30 6D 3 6 Zyl.**
Air mass meter, diesel	09.05→		**0 928 400 529**
Duo sensor, acceleration and yaw rate, brake system	09.05→		**0 265 005 678**
Wheel speed sensor, front	09.05→		**0 265 007 669**
Wheel speed sensor, rear	09.05→		**0 265 007 670**
330 xi [E 46]			**3,0 l 170 kW 30 6S 3 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	07.00-09.05		**0 265 005 248**
330 xi [E 91]			**3,0 l 190 kW N52 B30A 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.05→		**0 265 005 678**
Wheel speed sensor, front	09.05→		**0 265 007 669**
Wheel speed sensor, rear	09.05→		**0 265 007 670**
335 d [E 91]			**3,0 l 210 kW 30 6D 5 6 Zyl.**
Air mass meter, diesel	09.06-02.07		**0 281 002 849**
335 xi [E 91]			**3,0 l 225 kW N54 B30A 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.07→		**0 265 005 678**
Wheel speed sensor, front	03.07→		**0 265 007 669**
Wheel speed sensor, rear	03.07→		**0 265 007 670**

Serie 5

518 i [E 28]			**1,8 l 77 kW 18 4E B/Y 4 Zyl.**
Throttle valve sensor	01.86-12.87		**0 280 120 320**
Air flow sensor, gasoline injection	09.84-12.87		**0 280 202 050**
			0 986 280 005
Temperature sensor, coolant, injection system	09.84-12.87		**0 280 130 023**
Wheel speed sensor, front	09.84-12.87		**0 265 001 029**
Wheel speed sensor, rear	05.86-09.86		**0 265 001 027**
	10.86-12.87	LAB	**0 265 001 168**
		RAB	**0 265 001 167**
518 i [E 28]			**1,8 l 77 kW 18 4E W 4 Zyl.**
Throttle valve sensor	01.84-12.87		**0 280 120 302**
Air flow sensor, gasoline injection	01.84-12.87		**0 280 202 050**
			0 986 280 005
Temperature sensor, coolant, injection system	01.84-12.87		**0 280 130 023**
Wheel speed sensor, front	01.84-12.87		**0 265 001 029**
Wheel speed sensor, rear	05.86-09.86		**0 265 001 027**
	10.86-12.87	LAB	**0 265 001 168**
		RAB	**0 265 001 167**
518 i [E 34]			**1,8 l 83 kW 18 4E 1 4 Zyl.**
Throttle valve sensor	09.89-09.91		**0 280 120 316**
Air flow sensor, gasoline injection	09.89-12.94	OKA	**0 280 202 135**
Pulse generator, ignition/Jetronic	09.89-08.90		**0 356 914 212**
	09.90-08.91		**0 356 914 220**
Temperature sensor, coolant, injection system	09.89-12.94		**0 280 130 026**
Wheel speed sensor, front	09.89-12.94		**0 265 001 339**
518 i [E 34]			**1,8 l 85 kW 18 4E 2 4 Zyl.**
Air flow sensor, gasoline injection	09.90-12.95	OKA	**0 280 202 135**
Knock sensor	09.90-12.95		**0 261 231 097**

Product

Temperature sensor, coolant, injection system	09.90-12.95		**0 280 130 026**
Wheel speed sensor, front	09.90-12.95		**0 265 001 339**
520 d [E 39]			**2,0 l 100 kW 20 4D 1 4 Zyl.**
Air mass meter, diesel	11.00-07.03	UPE	**0 928 400 527**
520 d [E 60]			**2,0 l 110/120 kW 20 4D 4 4 Zyl.**
Air mass meter, diesel	09.05-09.07		**0 928 400 529**
High-pressure sensor (CR system)	09.05-09.07		**0 281 002 497**
Duo sensor, acceleration and yaw rate, brake system	09.05-09.07		**0 265 005 678**
520 d [E 60]			**2,0 l 130 kW N47 D20A 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.07→	EAO	**0 265 005 678**
520 i [E 28]			**2,0 l 90-95 kW 20 6K A 6 Zyl.**
Throttle valve sensor	12.86-12.87		**0 280 120 321**
		AG	**0 280 120 402**
Air flow sensor, gasoline injection	12.86-12.87		**0 280 202 083**
			0 986 280 009
Pulse generator, ignition/Jetronic	12.86-12.87		**0 356 914 212**
Temperature sensor, coolant, injection system	12.86-12.87		**0 280 130 026**
Wheel speed sensor	12.86-12.87	HI	**0 265 001 027**
		VO	**0 265 001 029**
520 i [E 28]			**2,0 l 92 kW 20 6E B 6 Zyl.**
Air flow sensor, gasoline injection	04.80-01.86		**0 280 202 031**
	02.86-12.88		**0 280 202 090**
			0 986 280 068
520 i [E 28]			**2,0 l 92-95 kW 20 6E B/C/Z 6 Zyl.**
Throttle valve sensor	01.86-12.87		**0 280 120 319**
Air flow sensor, gasoline injection	09.82-12.87		**0 280 202 031**
Temperature sensor, coolant, injection system	09.84-12.87		**0 280 130 026**
Wheel speed sensor	04.86-12.87	HI	**0 265 001 027**
	09.82-12.87	VO	**0 265 001 029**
520 i [E 34]			**2,0 l 95 kW 20 6E E/K A 6 Zyl.**
Throttle valve sensor	01.88-12.90	AG	**0 280 120 402**
		GS	**0 280 120 310**
Air flow sensor, gasoline injection	01.88-12.90		**0 280 202 083**
			0 986 280 009
Pulse generator, ignition/Jetronic	01.88-08.90		**0 356 914 212**
	09.90-12.90		**0 356 914 220**
Temperature sensor, coolant, injection system	01.88-12.90		**0 280 130 026**
Wheel speed sensor, front	01.88-12.90		**0 265 001 339**
520 i [E 34]			**2,0 l 100 kW 20 6S 1/2 6 Zyl.**
Air mass meter, gasoline injection	10.90-09.92	BO	**0 280 212 025**
			0 986 280 111
			0 986 280 130
Wheel speed sensor, front	10.90-12.94		**0 265 001 339**
520 i [E 34]			**2,0 l 110 kW 20 6S 1/2 6 Zyl.**
Air mass meter, gasoline injection	09.89-09.92	BO	**0 280 212 025**
			0 986 280 111
			0 986 280 130
Phase sensor	09.89-09.92	BOM,NOC	**0 261 210 053**
Wheel speed sensor, front	09.89-12.95		**0 265 001 339**
520 i [E 39]			**2,0 l 100-110 kW 20 6S 3/4 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.98-06.03		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	10.98-06.03		**0 265 005 303**
520 i [E 39]			**2,2 l 120-125 kW 22 6S 1 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.00-07.03		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	09.00-07.03		**0 265 005 303**
520 i [E 60]			**2,0 l 115 kW N46 B20B 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.07→		**0 265 005 678**

B

Product			
◀ Serie 5			
520 i [E 60]			**2,0 l 125 kW N43 B20A 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.07→	EAO	**0 265 005 678**
520 i [E 60]			**2,2 l 125 kW 22 6S 1 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	07.03-09.05		**0 265 005 266**
	07.03-03.05	AFP,EAL	**0 265 005 285**
523 i [E 39]			**2,4 l 135 kW 24 6S 3 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.99-12.02		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	03.99-12.02		**0 265 005 303**
523 i [E 39]			**2,5 l 125 kW 25 6S 3/4 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.98-09.00		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	10.98-09.00		**0 265 005 303**
523 i [E 60]			**2,5 l 130 kW N52 B25... 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.05-09.05		**0 265 005 266**
		AFP,EAL	**0 265 005 285**
	10.05→	EAO	**0 265 005 678**
523 i [E 60]			**2,5 l 140 kW N53 B25A 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.07→	EAO	**0 265 005 678**
523 Li [E 60]			**2,5 l 130 kW N52 B25... 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	11.06→	EAO	**0 265 005 678**
524 d [E 28]			**2,4 l 63 kW 24 6D A 6 Zyl.**
Wheel speed sensor	03.86-12.87	VO	**0 265 001 029**
524 td [E 28]			**2,4 l 85 kW 24 6T A 6 Zyl.**
Speed sensor, diesel	01.87-12.87		**0 261 210 001**
Pressure sensor, intake manifold, diesel	01.87-12.87		**0 281 002 018**
Temperature sensor, coolant, diesel	01.87-12.87		**0 280 130 037**
Temperature sensor, intake air, diesel	01.87-12.87		**0 280 130 039**
Pedal position sensor, diesel	01.87-12.87		**0 132 009 308**
Wheel speed sensor	04.86-12.87	HI	**0 265 001 027**
	09.83-12.87	VO	**0 265 001 029**
524 td [E 34]			**2,4 l 85 kW 24 6T B 6 Zyl.**
Pressure sensor, intake manifold, diesel	03.88-12.91		**0 281 002 018**
Temperature sensor, coolant, diesel	03.88-12.91		**0 280 130 055**
Temperature sensor, intake air, diesel	03.88-12.91		**0 280 130 039**
Pedal position sensor, diesel	03.88-12.91		**0 132 009 315**
Wheel speed sensor, front	03.88-12.91		**0 265 001 339**
525 d [E 39]			**2,5 l 120 kW 25 6D 1 6 Zyl.**
Air mass meter, diesel	02.01-07.03	UPE	**0 928 400 527**
High-pressure sensor (CR system)	04.00-07.03		**0 281 002 475**
Duo sensor, acceleration and yaw rate, brake system	04.00-07.03		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	04.00-07.03		**0 265 005 303**
525 d [E 60]			**2,5 l 120/130 kW 25 6D 2 6 Zyl.**
Air mass meter, diesel	05.04-03.07		**0 928 400 529**
High-pressure sensor (CR system)	05.04-03.07		**0 281 002 497**
Duo sensor, acceleration and yaw rate, brake system	05.04-09.05		**0 265 005 266**
		AFP,EAL	**0 265 005 285**
	10.05-03.07	EAO	**0 265 005 678**
525 d [E 60]			**3,0 l 145 kW 30 6D 3 6 Zyl.**
Air mass meter, diesel	03.07→		**0 928 400 529**
Duo sensor, acceleration and yaw rate, brake system	03.07→	EAO	**0 265 005 678**
525 e [E 28]			**2,7 l 90-95 kW 27 6K A/B 6 Zyl.**
Throttle valve sensor	12.84-11.86		**0 280 120 301**
	12.86-12.87		**0 280 120 319**
		AG	**0 280 120 404**

Product			
Air flow sensor, gasoline injection	12.86-12.87		**0 280 202 083**
			0 986 280 009
	12.84-11.86		**0 280 202 091**
			0 986 280 006
Speed sensor, ignition/injection	12.84-11.86		**0 261 210 001**
Pulse generator, ignition/Jetronic	12.86-12.87		**0 356 914 212**
Pressure sensor, intake manifold, gasoline	12.84-11.86		**0 280 101 001**
Temperature sensor, coolant, injection system	12.84-12.87		**0 280 130 026**
Wheel speed sensor	04.86-12.87	HI	**0 265 001 027**
	12.84-12.87	VO	**0 265 001 029**
525 e [E 28]			**2,7 l 92 kW 27 6E A/B 6 Zyl.**
Throttle valve sensor	01.86-12.87		**0 280 120 319**
	09.85-12.87	AG	**0 280 120 404**
Air flow sensor, gasoline injection	09.85-12.87		**0 280 202 083**
			0 986 280 009
		TRO	**0 280 202 093**
Speed sensor, ignition/injection	09.85-12.87		**0 261 210 028**
Temperature sensor, coolant, injection system	05.83-12.87		**0 280 130 026**
Wheel speed sensor	04.86-12.87	HI	**0 265 001 027**
	05.83-12.87	VO	**0 265 001 029**
525 i [E 28]			**2,5 l 110 kW 25 6E A 6 Zyl.**
Throttle valve sensor	01.86-12.87		**0 280 120 320**
Air flow sensor, gasoline injection	06.81-12.87		**0 280 202 025**
			0 986 280 018
Temperature sensor, coolant, injection system	06.81-12.87		**0 280 130 023**
Relay, Jetronic	06.81-12.87		**0 280 230 001**
Wheel speed sensor	04.86-12.87	HI	**0 265 001 027**
	10.81-12.87	VO	**0 265 001 029**
525 i [E 34]			**2,5 l 125 kW 25 6K 1 6 Zyl.**
Throttle valve sensor	01.88-12.90	AG	**0 280 120 402**
		GS	**0 280 120 310**
Air flow sensor, gasoline injection	01.88-12.90		**0 280 202 082**
			0 986 280 003
Temperature sensor, coolant, injection system	01.88-12.90		**0 280 130 026**
Wheel speed sensor, front	01.88-12.90		**0 265 001 339**
525 i [E 34]			**2,5 l 141 kW 25 6S 1 6 Zyl.**
Air mass meter, gasoline injection	10.90-09.92		**0 280 213 011**
			0 986 280 116
525 i [E 34]			**2,5 l 141 kW 25 6S 1/2 6 Zyl.**
Air mass meter, gasoline injection	09.89-09.92		**0 280 213 011**
			0 986 280 116
	10.92-12.95		**0 280 217 502**
Phase sensor	10.92-12.95	NOC	**0 232 103 003**
	09.89-09.92	NOC	**0 261 210 053**
Temperature sensor, intake air, injection system	09.89-12.95		**0 280 130 039**
Temperature sensor, coolant, injection system	09.89-12.95		**0 280 130 026**
Wheel speed sensor, front	09.89-12.95		**0 265 001 339**
525 i [E 34]			**2,5 l 141 kW 25 6S 2 6 Zyl.**
Air mass meter, gasoline injection	01.93-12.96		**0 280 217 502**
Phase sensor	07.93-12.96		**0 261 210 053**
	01.93-12.96	NOC	**0 232 103 003**
Temperature sensor, coolant, injection system	01.93-12.96		**0 280 130 026**
525 i [E 39]			**2,5 l 141 kW 25 6S 5 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.00-07.03		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	09.00-07.03		**0 265 005 303**
525 i [E 60]			**2,5 l 141 kW 25 6S 5 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.03-09.05		**0 265 005 266**
	09.03-03.05	AFP,EAL	**0 265 005 285**
525 i [E 60]			**2,5 l 160 kW N52 B25... 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.05-09.05		**0 265 005 266**
		AFP,EAL	**0 265 005 285**
	10.05→	EAO	**0 265 005 678**

Product			
525 i [E 60]			**3,0 l 160 kW N53 B30A 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.07→	EAO	**0 265 005 678**
525 ix [E 34]			**2,5 l 141 kW 25 6S 1/2 6 Zyl.**
Air mass meter, gasoline injection	09.91-09.92		**0 280 213 011**
			0 986 280 116
	10.92-12.95		**0 280 217 502**
Phase sensor	10.92-12.95	NOC	**0 232 103 003**
	09.91-09.92	NOC	**0 261 210 053**
Temperature sensor, intake air, injection system	09.91-12.95		**0 280 130 039**
Temperature sensor, coolant, injection system	09.91-12.95		**0 280 130 026**
525 td [E 34]			**2,5 l 85 kW 25 6T 1 6 Zyl.**
Temperature sensor, coolant, diesel	03.93-12.95		**0 280 130 055**
Pedal position sensor, diesel	03.93-12.95		**0 205 001 040**
Wheel speed sensor, front	03.93-12.95		**0 265 001 339**
525 td [E 39]			**2,5 l 85 kW 25 6T 1 6 Zyl.**
Pedal position sensor, diesel	01.97-09.00		**0 205 001 040**
525 tds [E 34]			**2,5 l 105 kW 25 6T 1 6 Zyl.**
Pressure sensor, intake manifold, diesel	09.91-09.92		**0 281 002 063**
Temperature sensor, coolant, diesel	09.91-12.95		**0 280 130 055**
Pedal position sensor, diesel	09.94-12.95		**0 205 001 040**
Wheel speed sensor, front	09.91-12.95		**0 265 001 339**
525 tds [E 39]			**2,5 l 105 kW 25 6T 1 6 Zyl.**
Pedal position sensor, diesel	01.96-09.00		**0 205 001 040**
525 xd [E 60]			**3,0 l 145 kW 30 6D 3 6 Zyl.**
Air mass meter, diesel	09.07→		**0 928 400 529**
Duo sensor, acceleration and yaw rate, brake system	09.07→		**0 265 005 678**
Wheel speed sensor, front	09.07→		**0 265 007 850**
525 xi [E 60]			**2,5 l 160 kW N52 B25A 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.05-09.05		**0 265 005 610**
	10.05-03.07		**0 265 005 678**
Wheel speed sensor, front	03.05-03.07		**0 265 007 850**
525 xi [E 60]			**3,0 l 160 kW N53 B30A 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.07→		**0 265 005 678**
Wheel speed sensor, front	03.07→		**0 265 007 850**
528 e [E 28]			**2,7 l 90 kW 27 6K A/B 6 Zyl.**
Throttle valve sensor	01.86-12.87		**0 280 120 319**
	12.86-12.87	AG	**0 280 120 404**
Air flow sensor, gasoline injection	12.86-12.87		**0 280 202 083**
			0 986 280 009
	09.84-11.86		**0 280 202 091**
			0 986 280 006
Speed sensor, ignition/injection	09.85-08.86		**0 261 210 002**
	09.86-12.87		**0 261 210 035**
Pulse generator, ignition/Jetronic	12.86-12.87		**0 356 914 212**
Pressure sensor, intake manifold, gasoline	10.84-12.87		**0 280 101 001**
Temperature sensor, coolant, injection system	09.84-12.87		**0 280 130 026**
Wheel speed sensor	04.86-12.87	HI	**0 265 001 027**
	01.85-12.87	VO	**0 265 001 029**
528 i [E 28]			**2,8 l 135 kW 6 Zyl.**
Throttle valve sensor	01.86-12.87		**0 280 120 320**
Air flow sensor, gasoline injection	06.81-12.87		**0 280 202 025**
			0 986 280 018
Temperature sensor, coolant, injection system	06.81-12.87		**0 280 130 023**
Relay, Jetronic	06.81-12.87		**0 280 230 001**
Wheel speed sensor	10.81-08.86	HI	**0 265 001 027**
	09.86-12.87	HI,LAB	**0 265 001 168**
		HI,RAB	**0 265 001 167**
	10.81-12.87	VO	**0 265 001 029**

Product			
528 i [E 39]			**2,8 l 142 kW 28 6S 1/2 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.98-09.00		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	10.98-09.00		**0 265 005 303**
530 d [E 39]			**3,0 l 135-142 kW 30 6D 1 6 Zyl.**
Air mass meter, diesel	02.01-07.03	UPE	**0 928 400 527**
High-pressure sensor (CR system)	08.98-07.03		**0 281 002 475**
Pedal position sensor, diesel	08.98-09.99		**0 281 002 291**
Duo sensor, acceleration and yaw rate, brake system	10.98-07.03		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	10.98-07.03		**0 265 005 303**
530 d [E 60]			**3,0 l 160 kW 30 6D 2 6 Zyl.**
Air mass meter, diesel	07.03-09.05		**0 928 400 529**
High-pressure sensor (CR system)	07.03-09.05		**0 281 002 497**
Duo sensor, acceleration and yaw rate, brake system	07.03-09.05		**0 265 005 266**
		AFP,EAL	**0 265 005 285**
530 d [E 60]			**3,0 l 170 kW 30 6D 3 6 Zyl.**
Air mass meter, diesel	09.05-03.07		**0 928 400 529**
High-pressure sensor (CR system)	09.05-03.07		**0 281 002 497**
Duo sensor, acceleration and yaw rate, brake system	09.05-03.07	EAO	**0 265 005 678**
530 d [E 60]			**3,0 l 173 kW 30 6D 3 6 Zyl.**
Air mass meter, diesel	03.07→		**0 928 400 529**
Duo sensor, acceleration and yaw rate, brake system	03.07→	EAO	**0 265 005 678**
530 i [E 34]			**3,0 l 138 kW 30 6K A 6 Zyl.**
Throttle valve sensor	01.88-12.90	AG	**0 280 120 406**
		GS	**0 280 120 320**
Air flow sensor, gasoline injection	01.88-12.90		**0 280 203 027**
			0 986 280 002
Temperature sensor, coolant, injection system	01.88-12.90		**0 280 130 026**
Wheel speed sensor, front	01.88-12.90		**0 265 001 339**
530 i [E 34]			**3,0 l 160 kW 30 8S 1 8 Zyl.**
Air mass meter, gasoline injection	09.92-12.96		**0 280 217 502**
Knock sensor	09.92-04.93		**0 261 231 074**
	05.93-12.96		**0 261 231 096**
Temperature sensor, coolant, injection system	09.92-09.95	XJD	**0 280 130 089**
Wheel speed sensor, front	09.92-09.95		**0 265 001 339**
530 i [E 39]			**3,0 l 170 kW 30 6S 3 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.00-07.03		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	09.00-07.03		**0 265 005 303**
530 i [E 60]			**3,0 l 170 kW 30 6S 3 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	07.03-09.05		**0 265 005 266**
	07.03-03.05	AFP,EAL	**0 265 005 285**
530 i [E 60]			**3,0 l 190 kW N52 B30... 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.05-09.05		**0 265 005 266**
		AFP,EAL	**0 265 005 285**
	10.05→	EAO	**0 265 005 678**
530 i [E 60]			**3,0 l 200 kW N53 B30A 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.07→	EAO	**0 265 005 678**
530 xd [E 60]			**3,0 l 170 kW 30 6D 3 6 Zyl.**
Air mass meter, diesel	09.05-03.07		**0 928 400 529**
High-pressure sensor (CR system)	09.05-03.07		**0 281 002 497**
Duo sensor, acceleration and yaw rate, brake system	09.05-03.07		**0 265 005 678**
	10.05-03.07		**0 265 005 678**
Wheel speed sensor, front	09.05-03.07		**0 265 007 850**
530 xd [E 60]			**3,0 l 173 kW 30 6D 3 6 Zyl.**
Air mass meter, diesel	03.07→		**0 928 400 529**
Duo sensor, acceleration and yaw rate, brake system	03.07→		**0 265 005 678**
Wheel speed sensor, front	03.07→		**0 265 007 850**

B

Product

◀ Serie 5

530 xi [E 60]			**3,0 l 190 kW N52 B30A 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.05-09.05		**0 265 005 610**
	10.05→		**0 265 005 678**
Wheel speed sensor, front	03.05→		**0 265 007 850**
530 xi [E 60]			**3,0 l 200 kW N53 B30A 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.07→		**0 265 005 678**
Wheel speed sensor, front	03.07→		**0 265 007 850**
535 d [E 60]			**3,0 l 200 kW 30 6D 4 6 Zyl.**
Air mass meter, diesel	09.04-03.07		**0 281 002 713**
High-pressure sensor (CR system)	09.04-03.07		**0 281 002 497**
Duo sensor, acceleration and yaw rate, brake system	09.04-09.05		**0 265 005 266**
		AFP,EAL	**0 265 005 285**
	10.05-03.07	EAO	**0 265 005 678**
535 d [E 60]			**3,0 l 210 kW 30 6D 5 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.07→	EAO	**0 265 005 678**
535 i [E 28]			**3,4 l 134 kW 34 6K A 6 Zyl.**
Throttle valve sensor	01.86-12.87		**0 280 120 320**
Air flow sensor, gasoline injection	09.84-12.87		**0 280 203 027**
			0 986 280 002
Speed sensor, ignition/injection	09.84-12.87		**0 261 210 002**
Temperature sensor, coolant, injection system	09.84-12.87		**0 280 130 026**
Wheel speed sensor	01.85-08.86	HI	**0 265 001 027**
	01.85-12.87	VO	**0 265 001 029**
535 i [E 28]			**3,4 l 136-141 kW 34 6K A 6 Zyl.**
Throttle valve sensor	01.86-12.87		**0 280 120 320**
	09.86-12.87	AG	**0 280 120 406**
Air flow sensor, gasoline injection	01.85-12.87		**0 280 203 027**
			0 986 280 002
Speed sensor, ignition/injection	01.85-08.86		**0 261 210 002**
	09.86-12.87		**0 261 210 035**
Pulse generator, ignition/Jetronic	09.86-12.87		**0 356 914 212**
Temperature sensor, coolant, injection system	01.85-12.87		**0 280 130 026**
Wheel speed sensor	01.85-08.86	HI	**0 265 001 027**
	09.86-12.87	HI,LAB	**0 265 001 168**
		HI,RAB	**0 265 001 167**
	01.85-12.87	VO	**0 265 001 029**
535 i [E 28]			**3,4 l 160 kW 34 6E C 6 Zyl.**
Throttle valve sensor	01.86-12.87		**0 280 120 320**
	09.86-12.87	AG	**0 280 120 406**
Air flow sensor, gasoline injection	09.84-12.87		**0 280 203 027**
			0 986 280 002
Speed sensor, ignition/injection	09.84-08.86		**0 261 210 002**
	09.86-12.87		**0 261 210 035**
Pulse generator, ignition/Jetronic	09.86-12.87		**0 356 914 212**
Temperature sensor, coolant, injection system	09.84-12.87		**0 280 130 026**
Wheel speed sensor	09.84-08.86	HI	**0 265 001 027**
	09.86-12.87	HI,LAB	**0 265 001 168**
		HI,RAB	**0 265 001 167**
	09.84-12.87	VO	**0 265 001 029**
535 i [E 34]			**3,5 l 155 kW 34 6K B 6 Zyl.**
Throttle valve assembly	01.88-12.93		**0 132 010 453**
Throttle valve sensor	01.88-12.93	AG	**0 280 120 406**
		GS	**0 280 120 320**
Air flow sensor, gasoline injection	01.88-12.94		**0 280 203 027**
			0 986 280 002
Temperature sensor, coolant, injection system	01.88-12.94		**0 280 130 026**
	01.89-12.94	XJD	**0 280 130 089**
Wheel speed sensor, front	01.88-12.93		**0 265 001 339**
535 i [E 39]			**3,5 l 173-180 kW 35 8S 1/2 8 Zyl.**
Air mass meter, gasoline injection	01.96-09.98		**0 280 217 502**
	10.98-07.03		**0 280 217 533**

Product

Knock sensor	01.96-09.97		**0 261 231 113**
	10.97-07.03		**0 261 231 200**
Pedal position sensor, EMS (electronic engine management)	09.98-09.99		**0 281 002 291**
Duo sensor, acceleration and yaw rate, brake system	10.98-07.03		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	10.98-07.03		**0 265 005 303**
540 i [E 34]			**4,0 l 210 kW 40 8S 1 8 Zyl.**
Air mass meter, gasoline injection	09.92-12.96		**0 280 217 800**
Knock sensor	09.92-05.93		**0 261 231 074**
	06.93-09.95		**0 261 231 096**
Temperature sensor, coolant, injection system	09.92-09.95	XJD	**0 280 130 089**
Wheel speed sensor, front	09.92-09.95		**0 265 001 339**
540 i [E 39]			**4,4 l 210 kW 44 8S 1/2 8 Zyl.**
Air mass meter, gasoline injection	01.96-09.98		**0 280 217 800**
	10.98-07.03		**0 280 217 814**
Knock sensor	01.96-09.97		**0 261 231 113**
	10.97-07.03		**0 261 231 200**
Pedal position sensor, EMS (electronic engine management)	09.98-09.99		**0 281 002 291**
Duo sensor, acceleration and yaw rate, brake system	10.98-07.03		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	10.98-07.03		**0 265 005 303**
540 i [E 60]			**4,0 l 225 kW N62 B40A 8 Zyl.**
Knock sensor	09.05→		**0 261 231 200**
Duo sensor, acceleration and yaw rate, brake system	09.05→	EAO	**0 265 005 678**
545 i [E 60]			**4,4 l 245 kW N62 B44A 8 Zyl.**
Air mass meter, gasoline injection	09.03-09.05		**0 280 218 135**
Knock sensor	09.03-09.05		**0 261 231 200**
Duo sensor, acceleration and yaw rate, brake system	09.03-09.05		**0 265 005 266**
		AFP,EAL	**0 265 005 285**
550 i [E 60]			**4,8 l 270 kW N62 B48B 8 Zyl.**
Knock sensor	09.05→		**0 261 231 200**
Duo sensor, acceleration and yaw rate, brake system	09.05→	EAO	**0 265 005 678**

Serie 5 Touring

518 g [E 34]			**1,8 l 75-85 kW 18 4E 2 4 Zyl.**
Air flow sensor, gasoline injection	11.95-06.96	OKA	**0 280 202 135**
Knock sensor	11.95-06.96		**0 261 231 097**
Wheel speed sensor, front	11.95-06.96		**0 265 001 339**
518 i [E 34]			**1,8 l 83-85 kW 18 4E 1 4 Zyl.**
Air flow sensor, gasoline injection	03.93-12.94	OKA	**0 280 202 135**
Temperature sensor, coolant, injection system	03.93-12.94		**0 280 130 026**
Wheel speed sensor, front	03.93-12.94		**0 265 001 339**
518 i [E 34]			**1,8 l 85 kW 18 4E 2 4 Zyl.**
Air flow sensor, gasoline injection	09.94-12.96	OKA	**0 280 202 135**
Knock sensor	09.94-12.96		**0 261 231 097**
Temperature sensor, coolant, injection system	09.94-12.96		**0 280 130 026**
Wheel speed sensor, front	09.94-12.96		**0 265 001 339**
520 d [E 39]			**2,0 l 100 kW 20 4D 1 4 Zyl.**
Air mass meter, diesel	11.00-07.03	UPE	**0 928 400 527**
520 d [E 61]			**2,0 l 110/120 kW 20 4D 4 4 Zyl.**
Air mass meter, diesel	09.05-09.07		**0 928 400 529**
High-pressure sensor (CR system)	09.05-09.07		**0 281 002 497**
Duo sensor, acceleration and yaw rate, brake system	09.05-09.07		**0 265 005 678**
520 d [E 61]			**2,0 l 130 kW N47 D20A 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.07→	EAO	**0 265 005 678**

Product			
520 i [E 34]			**2,0 l 110 kW 20 6S 1/2 6 Zyl.**
Air mass meter, gasoline injection	11.91-09.92	BO	**0 280 212 025**
			0 986 280 111
			0 986 280 130
Phase sensor	11.91-09.92	BOM,NOC	**0 261 210 053**
Wheel speed sensor, front	11.91-12.96		**0 265 001 339**
520 i [E 39]			**2,0 l 100-110 kW 20 6S 3/4 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.98-12.01		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	10.98-12.01		**0 265 005 303**
520 i [E 39]			**2,2 l 120-125 kW 22 6S 1 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.00-05.04		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	09.00-05.04		**0 265 005 303**
520 i [E 61]			**2,0 l 125 kW N43 B20A 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.07→	EAO	**0 265 005 678**
523 i [E 39]			**2,5 l 125 kW 25 6S 3/4 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.98-09.00		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	10.98-09.00		**0 265 005 303**
523 i [E 61]			**2,5 l 130 kW N52 B25... 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.05-09.05		**0 265 005 266**
		AFP,EAL	**0 265 005 285**
	10.05→	EAO	**0 265 005 678**
Wheel speed sensor, rear	03.05-09.05		**0 265 007 623**
523 i [E 61]			**2,5 l 140 kW N53 B25A 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.07→	EAO	**0 265 005 678**
525 d [E 39]			**2,5 l 120 kW 25 6D 1 6 Zyl.**
Air mass meter, diesel	02.01-05.04	UPE	**0 928 400 527**
High-pressure sensor (CR system)	04.00-05.04		**0 281 002 475**
Duo sensor, acceleration and yaw rate, brake system	04.00-05.04		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	04.00-05.04		**0 265 005 303**
525 d [E 61]			**2,5 l 120/130 kW 25 6D 2 6 Zyl.**
Air mass meter, diesel	05.04-03.07		**0 928 400 529**
High-pressure sensor (CR system)	05.04-03.07		**0 281 002 497**
Duo sensor, acceleration and yaw rate, brake system	05.04-09.05		**0 265 005 266**
		AFP,EAL	**0 265 005 285**
	10.05-03.07	EAO	**0 265 005 678**
Wheel speed sensor, rear	05.04-09.05		**0 265 007 623**
525 d [E 61]			**3,0 l 145 kW 30 6D 3 6 Zyl.**
Air mass meter, diesel	03.07→		**0 928 400 529**
Duo sensor, acceleration and yaw rate, brake system	03.07→	EAO	**0 265 005 678**
525 i [E 34]			**2,5 l 141 kW 25 6S 1/2 6 Zyl.**
Air mass meter, gasoline injection	11.91-09.92		**0 280 213 011**
			0 986 280 116
	10.92-12.96		**0 280 217 502**
Phase sensor	10.92-12.96	NOC	**0 232 103 003**
	11.91-09.92	NOC	**0 261 210 053**
Temperature sensor, intake air, injection system	11.91-12.96		**0 280 130 039**
Temperature sensor, coolant, injection system	11.91-12.96		**0 280 130 026**
Wheel speed sensor, front	11.91-12.96		**0 265 001 339**
525 i [E 39]			**2,5 l 141 kW 25 6S 5 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.00-05.04		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	09.00-05.04		**0 265 005 303**
525 i [E 61]			**2,5 l 141 kW 25 6S 5 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	05.04-03.05		**0 265 005 266**
		AFP,EAL	**0 265 005 285**
Wheel speed sensor, rear	05.04-03.05		**0 265 007 623**

Product			
525 i [E 61]			**2,5 l 160 kW N52 B25... 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.05-09.05		**0 265 005 266**
		AFP,EAL	**0 265 005 285**
	10.05→	EAO	**0 265 005 678**
Wheel speed sensor, rear	03.05-09.05		**0 265 007 623**
525 i [E 61]			**3,0 l 160 kW N53 B30A 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.07→	EAO	**0 265 005 678**
525 ix [E 34]			**2,5 l 141 kW 25 6S 1/2 6 Zyl.**
Air mass meter, gasoline injection	02.92-09.92		**0 280 213 011**
			0 986 280 116
	10.92-12.96		**0 280 217 502**
Phase sensor	10.92-12.96	NOC	**0 232 103 003**
	02.92-09.92	NOC	**0 261 210 053**
Temperature sensor, intake air, injection system	02.92-12.96		**0 280 130 039**
Temperature sensor, coolant, injection system	02.92-12.96		**0 280 130 026**
525 td [E 34]			**2,5 l 85 kW 25 6T 1 6 Zyl.**
Temperature sensor, coolant, diesel	03.93-12.96		**0 280 130 055**
Pedal position sensor, diesel	03.93-12.96		**0 205 001 040**
Wheel speed sensor, front	03.93-12.96		**0 265 001 339**
525 tds [E 34]			**2,5 l 105 kW 25 6T 1 6 Zyl.**
Pressure sensor, intake manifold, diesel	12.91-09.92		**0 281 002 063**
Temperature sensor, coolant, diesel	12.91-12.96		**0 280 130 055**
Pedal position sensor, diesel	09.94-12.96		**0 205 001 040**
Wheel speed sensor, front	12.91-12.96		**0 265 001 339**
525 tds [E 39]			**2,5 l 105 kW 25 6T 1 6 Zyl.**
Pedal position sensor, diesel	03.97-09.00		**0 205 001 040**
525 xd [E 61]			**3,0 l 145 kW 30 6D 3 6 Zyl.**
Air mass meter, diesel	09.07→		**0 928 400 529**
Duo sensor, acceleration and yaw rate, brake system	09.07→		**0 265 005 678**
Wheel speed sensor, front	09.07→		**0 265 007 850**
525 xi [E 61]			**2,5 l 160 kW N52 B25A 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.05-09.05		**0 265 005 610**
	10.05-03.07		**0 265 005 678**
Wheel speed sensor, front	03.05-03.07		**0 265 007 850**
Wheel speed sensor, rear	03.05-09.05		**0 265 007 623**
525 xi [E 61]			**3,0 l 160 kW N53 B30A 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.07→		**0 265 005 678**
Wheel speed sensor, front	03.07→		**0 265 007 850**
528 i [E 39]			**2,8 l 142 kW 28 6S 1/2 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.98-09.00		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	10.98-09.00		**0 265 005 303**
530 d [E 39]			**3,0 l 135-142 kW 30 6D 1 6 Zyl.**
Air mass meter, diesel	02.01-05.04	UPE	**0 928 400 527**
High-pressure sensor (CR system)	08.98-05.04		**0 281 002 475**
Pedal position sensor, diesel	08.98-09.99		**0 281 002 291**
Duo sensor, acceleration and yaw rate, brake system	10.98-05.04		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	10.98-05.04		**0 265 005 303**
530 d [E 61]			**3,0 l 160 kW 30 6D 2 6 Zyl.**
Air mass meter, diesel	05.04-09.05		**0 928 400 529**
High-pressure sensor (CR system)	05.04-09.05		**0 281 002 497**
Duo sensor, acceleration and yaw rate, brake system	05.04-09.05		**0 265 005 266**
		AFP,EAL	**0 265 005 285**
Wheel speed sensor, rear	05.04-09.05		**0 265 007 623**
530 d [E 61]			**3,0 l 170 kW 30 6D 3 6 Zyl.**
Air mass meter, diesel	09.05-03.07		**0 928 400 529**
High-pressure sensor (CR system)	09.05-03.07		**0 281 002 497**
Duo sensor, acceleration and yaw rate, brake system	09.05-03.07	EAO	**0 265 005 678**

B

Product			
◀ Serie 5 Touring			
530 d [E 61]			**3,0 l 173 kW 30 6D 3 6 Zyl.**
Air mass meter, diesel	03.07→		**0 928 400 529**
Duo sensor, acceleration and yaw rate, brake system	03.07→	EAO	**0 265 005 678**
530 i [E 34]			**3,0 l 160 kW 30 8S 1 8 Zyl.**
Air mass meter, gasoline injection	09.92-12.96		**0 280 217 502**
Knock sensor	09.92-04.93		**0 261 231 074**
	05.93-12.96		**0 261 231 096**
Temperature sensor, coolant, injection system	09.92-12.96	XJD	**0 280 130 089**
Wheel speed sensor, front	09.92-12.96		**0 265 001 339**
530 i [E 39]			**3,0 l 170 kW 30 6S 3 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.00-05.04		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	09.00-05.04		**0 265 005 303**
530 i [E 61]			**3,0 l 190 kW N52 B30... 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.05-09.05		**0 265 005 266**
		AFP,EAL	**0 265 005 285**
	10.05→	EAO	**0 265 005 678**
Wheel speed sensor, rear	03.05-09.05		**0 265 007 623**
530 i [E 61]			**3,0 l 200 kW N53 B30A 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.07→	EAO	**0 265 005 678**
530 xd [E 61]			**3,0 l 170 kW 30 6D 3 6 Zyl.**
Air mass meter, diesel	09.05-03.07		**0 928 400 529**
High-pressure sensor (CR system)	09.05-03.07		**0 281 002 497**
Duo sensor, acceleration and yaw rate, brake system	09.05-03.07		**0 265 005 678**
	10.05-03.07		**0 265 005 678**
Wheel speed sensor, front	09.05-03.07		**0 265 007 850**
530 xd [E 61]			**3,0 l 173 kW 30 6D 3 6 Zyl.**
Air mass meter, diesel	03.07→		**0 928 400 529**
Duo sensor, acceleration and yaw rate, brake system	03.07→		**0 265 005 678**
Wheel speed sensor, front	03.07→		**0 265 007 850**
530 xi [E 61]			**3,0 l 190 kW N52 B30A 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.05-09.05		**0 265 005 610**
	10.05→		**0 265 005 678**
Wheel speed sensor, front	03.05→		**0 265 007 850**
Wheel speed sensor, rear	03.05-09.05		**0 265 007 623**
530 xi [E 61]			**3,0 l 200 kW N53 B30A 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.07→		**0 265 005 678**
Wheel speed sensor, front	03.07→		**0 265 007 850**
535 d [E 61]			**3,0 l 200 kW 30 6D 4 6 Zyl.**
Air mass meter, diesel	09.04-03.07		**0 281 002 713**
High-pressure sensor (CR system)	09.04-03.07		**0 281 002 497**
Duo sensor, acceleration and yaw rate, brake system	09.04-09.05		**0 265 005 266**
		AFP,EAL	**0 265 005 285**
	10.05-03.07	EAO	**0 265 005 678**
Wheel speed sensor, rear	09.04-09.05		**0 265 007 623**
535 d [E 61]			**3,0 l 210 kW 30 6D 5 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.07→	EAO	**0 265 005 678**
540 i [E 34]			**4,0 l 210 kW 40 8S 1 8 Zyl.**
Air mass meter, gasoline injection	10.93-12.96		**0 280 217 800**
Knock sensor	10.93-12.96		**0 261 231 096**
Temperature sensor, coolant, injection system	10.93-12.96	XJD	**0 280 130 089**
Wheel speed sensor, front	10.93-12.96		**0 265 001 339**
540 i [E 39]			**4,4 l 210 kW 44 8S 1/2 8 Zyl.**
Air mass meter, gasoline injection	03.97-09.98		**0 280 217 800**
	10.98-05.04		**0 280 217 814**
Knock sensor	03.97-09.97		**0 261 231 113**
	10.97-05.04		**0 261 231 200**

Product			
Pedal position sensor, EMS (electronic engine management)	09.98-09.99		**0 281 002 291**
Duo sensor, acceleration and yaw rate, brake system	10.98-05.04		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	10.98-05.04		**0 265 005 303**
545 i [E 61]			**4,4 l 245 kW N62 B44A 8 Zyl.**
Air mass meter, gasoline injection	05.04-09.05		**0 280 218 135**
Knock sensor	05.04-09.05		**0 261 231 200**
Duo sensor, acceleration and yaw rate, brake system	05.04-09.05		**0 265 005 266**
		AFP,EAL	**0 265 005 285**
Wheel speed sensor, rear	05.04-09.05		**0 265 007 623**
550 i [E 61]			**4,8 l 270 kW N62 B48B 8 Zyl.**
Knock sensor	09.05→		**0 261 231 200**
Duo sensor, acceleration and yaw rate, brake system	09.05→	EAO	**0 265 005 678**

Serie 6

628 CSi [E 24]			**2,8 l 135 kW 28 6E A 6 Zyl.**
Throttle valve sensor	01.86-12.87		**0 280 120 320**
Air flow sensor, gasoline injection	09.84-12.87		**0 280 202 025**
			0 986 280 018
Temperature sensor, coolant, injection system	09.84-12.87		**0 280 130 023**
Relay, Jetronic	09.84-12.87		**0 280 230 001**
Wheel speed sensor, front	09.84-12.87		**0 265 001 038**
Wheel speed sensor, rear	09.84-09.86		**0 265 001 027**
	10.86-12.87	LAB	**0 265 001 168**
		RAB	**0 265 001 167**
630 i [E 63]			**3,0 l 190 kW N52 B30... 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.04-09.05		**0 265 005 266**
		AFP,EAL	**0 265 005 285**
	10.05→	EAO	**0 265 005 678**
630 i [E 63]			**3,0 l 200 kW N53 B30A 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.07→	EAO	**0 265 005 678**
635 CSi [E 24]			**3,4 l 135 kW 6 Zyl.**
Throttle valve sensor	01.86-04.89		**0 280 120 320**
Air flow sensor, gasoline injection	09.84-04.89		**0 280 203 027**
			0 986 280 002
Speed sensor, ignition/injection	09.84-08.86		**0 261 210 002**
Temperature sensor, coolant, injection system	09.84-04.89		**0 280 130 026**
Wheel speed sensor, front	09.84-04.89		**0 265 001 038**
Wheel speed sensor, rear	09.84-09.86		**0 265 001 027**
	10.86-04.89	LAB	**0 265 001 168**
		RAB	**0 265 001 167**
635 CSi [E 24]			**3,4 l 136-155 kW 6 Zyl.**
Throttle valve sensor	01.86-04.89		**0 280 120 320**
	09.86-04.89	AG	**0 280 120 406**
Air flow sensor, gasoline injection	01.85-04.89		**0 280 203 027**
			0 986 280 002
Speed sensor, ignition/injection	01.85-08.86		**0 261 210 002**
	09.86-03.89		**0 261 210 035**
Pulse generator, ignition/Jetronic	09.86-04.89		**0 356 914 212**
Temperature sensor, coolant, injection system	01.85-04.89		**0 280 130 026**
Wheel speed sensor, front	01.85-04.89		**0 265 001 038**
Wheel speed sensor, rear	01.85-09.86		**0 265 001 027**
	10.86-04.89	LAB	**0 265 001 168**
		RAB	**0 265 001 167**
635 CSi [E 24]			**3,4 l 150-162 kW 6 Zyl.**
Throttle valve sensor	05.82-06.87		**0 280 120 320**
	07.87-04.89	AG	**0 280 120 406**
		GS	**0 280 120 320**

Product				
Air flow sensor, gasoline injection		05.82-04.89	KAT	**0 280 203 027**
				0 986 280 002
	CH,S	12.82-04.89	OKA	**0 280 203 014**
	~~CH,S~~	10.84-06.87	OKA	**0 280 203 027**
				0 986 280 002
Speed sensor, ignition/injection		07.87-04.89	AG	**0 261 210 002**
			GS	**0 261 210 035**
Pulse generator, ignition/Jetronic		09.86-04.89		**0 356 914 212**
Temperature sensor, coolant, injection system		05.82-04.89		**0 280 130 026**
Wheel speed sensor, front		05.82-04.89		**0 265 001 038**
Wheel speed sensor, rear		05.82-09.86		**0 265 001 027**
		10.86-04.89	LAB	**0 265 001 168**
			RAB	**0 265 001 167**
635 d [E 63]			**3,0 l 210 kW 30 6D 5 6 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system		09.07→	EAO	**0 265 005 678**
645 Ci [E 63]			**4,4 l 245 kW N62 B44A 8 Zyl.**	
Air mass meter, gasoline injection		01.04-09.05		**0 280 218 135**
Knock sensor		01.04-09.05		**0 261 231 200**
Duo sensor, acceleration and yaw rate, brake system		01.04-09.05		**0 265 005 266**
			AFP,EAL	**0 265 005 285**
650 i [E 63]			**4,8 l 270 kW N62 B48B 8 Zyl.**	
Knock sensor		09.05→		**0 261 231 200**
Duo sensor, acceleration and yaw rate, brake system		09.05→	EAO	**0 265 005 678**

Serie 6 Cabrio

630 i [E 64]			**3,0 l 190 kW N52 B30... 6 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system		09.04-09.05		**0 265 005 266**
			AFP,EAL	**0 265 005 285**
		10.05→	EAO	**0 265 005 678**
630 i [E 64]			**3,0 l 200 kW N53 B30A 6 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system		09.07→	EAO	**0 265 005 678**
635 d [E 64]			**3,0 l 210 kW 30 6D 5 6 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system		09.07→	EAO	**0 265 005 678**
645 Ci [E 64]			**4,4 l 245 kW N62 B44A 8 Zyl.**	
Air mass meter, gasoline injection		04.04-09.05		**0 280 218 135**
Knock sensor		04.04-09.05		**0 261 231 200**
Duo sensor, acceleration and yaw rate, brake system		04.04-09.05		**0 265 005 266**
			AFP,EAL	**0 265 005 285**
650 i [E 64]			**4,8 l 270 kW N62 B48B 8 Zyl.**	
Knock sensor		09.05→		**0 261 231 200**
Duo sensor, acceleration and yaw rate, brake system		09.05→	EAO	**0 265 005 678**

Serie 7

725 tds [E 38]			**2,5 l 105 kW 25 6T 1 6 Zyl.**	
Pedal position sensor, diesel		01.96-12.00		**0 205 001 040**
728 i [E 23]			**2,8 l 135 kW 28 6E A 6 Zyl.**	
Throttle valve sensor		07.78-06.86		**0 280 120 206**
		01.86-06.86		**0 280 120 320**
Air flow sensor, gasoline injection		06.81-06.86		**0 280 202 025**
				0 986 280 018
	S	07.78-06.86		**0 280 203 008**
Temperature sensor, coolant, injection system		06.81-06.86		**0 280 130 023**
Speed relay	S	07.78-06.86		**0 335 530 018**
Relay, Jetronic		06.81-06.86		**0 280 230 001**
	S	07.78-06.86		**0 332 514 105**

Product				
Wheel speed sensor		09.81-06.86	HI	**0 265 001 023**
		01.79-06.86	VO	**0 265 001 005**
Wheel speed sensor, rear		10.81-06.86		**0 265 001 023**
728 i, iL [E 38]			**2,8 l 142 kW 28 6S 1/2 6 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system		10.98-12.01		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)		10.98-12.01		**0 265 005 303**
730 d [E 38]			**3,0 l 135-142 kW 30 6D 1 6 Zyl.**	
Air mass meter, diesel		02.01-12.01	UPE	**0 928 400 527**
High-pressure sensor (CR system)		08.98-12.01		**0 281 002 475**
Pedal position sensor, diesel		08.98-09.99		**0 281 002 291**
Duo sensor, acceleration and yaw rate, brake system		10.98-12.01		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)		10.98-12.01		**0 265 005 303**
730 d [E 65]			**3,0 l 160 kW 30 6D 2 6 Zyl.**	
Air mass meter, diesel		10.02-03.05		**0 928 400 529**
High-pressure sensor (CR system)		10.02-03.05		**0 281 002 497**
Duo sensor, acceleration and yaw rate, brake system		10.02-03.05		**0 265 005 285**
Pressure sensor, ESP, (electronic stability program)		10.02-03.05		**0 265 005 303**
Wheel speed sensor, front		10.02-03.03		**0 265 007 461**
		04.03-03.05		**0 265 007 592**
Wheel speed sensor, rear		10.02-03.03		**0 265 007 462**
		04.03-03.05		**0 265 007 593**
730 d [E 65]			**3,0 l 170 kW 30 6D 3 6 Zyl.**	
Air mass meter, diesel		04.05→		**0 928 400 529**
High-pressure sensor (CR system)		04.05→		**0 281 002 497**
Duo sensor, acceleration and yaw rate, brake system		04.05→		**0 265 005 285**
Pressure sensor, ESP, (electronic stability program)		04.05→		**0 265 005 303**
Wheel speed sensor, front		04.05-09.05		**0 265 007 592**
Wheel speed sensor, rear		04.05-09.05		**0 265 007 593**
		10.05→		**0 265 007 845**
730 i [E 65]			**3,0 l 170 kW 30 6S 3 6 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system		03.03-03.05		**0 265 005 285**
Pressure sensor, ESP, (electronic stability program)		03.03-03.05		**0 265 005 303**
Wheel speed sensor, front		03.03-03.05		**0 265 007 592**
Wheel speed sensor, rear		03.03-03.05		**0 265 007 593**
730 i [E 65]			**3,0 l 190 kW N52 B30... 6 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system		04.05→		**0 265 005 285**
Pressure sensor, ESP, (electronic stability program)		04.05→		**0 265 005 303**
Wheel speed sensor, front		04.05-09.05		**0 265 007 592**
Wheel speed sensor, rear		04.05-09.05		**0 265 007 593**
		10.05→		**0 265 007 845**
730 i, iL [E 32]			**3,0 l 136-145 kW 30 6K A 6 Zyl.**	
Throttle valve assembly		09.87-06.94		**0 132 010 453**
Throttle valve sensor		09.86-06.94	AG	**0 280 120 406**
			GS	**0 280 120 320**
Air flow sensor, gasoline injection		09.86-06.94		**0 280 203 027**
				0 986 280 002
Temperature sensor, coolant, injection system		09.86-06.94		**0 280 130 026**
Wheel speed sensor, front		09.86-06.94		**0 265 001 339**
730 i, iL [E 32]			**3,0 l 160 kW 30 8S 1 8 Zyl.**	
Air mass meter, gasoline injection		09.91-10.94		**0 280 217 502**
Knock sensor		09.91-04.93		**0 261 231 074**
		05.93-10.94		**0 261 231 096**
Temperature sensor, intake air, injection system		09.91-10.94		**0 280 130 039**
Temperature sensor, coolant, injection system		09.91-10.94		**0 280 130 026**
Wheel speed sensor, front		09.91-10.94		**0 265 001 339**

B

Product			
◀ Serie 7			
730 i, iL [E 38]		**3,0 l 155-160 kW 30 8S 1 8 Zyl.**	
Air mass meter, gasoline injection	06.94-12.96		**0 280 217 502**
Knock sensor	06.94-12.96		**0 261 231 096**
Temperature sensor, coolant, injection system	06.94-12.96	XJD	**0 280 130 089**
730 Ld [E 66]		**3,0 l 170 kW 30 6D 3 6 Zyl.**	
Air mass meter, diesel	09.05→		**0 928 400 529**
High-pressure sensor (CR system)	09.05→		**0 281 002 497**
Duo sensor, acceleration and yaw rate, brake system	09.05→		**0 265 005 285**
Pressure sensor, ESP, (electronic stability program)	09.05→		**0 265 005 303**
Wheel speed sensor, rear	09.05→		**0 265 007 845**
730 Li [E 66]		**3,0 l 170 kW 30 6S 3 6 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	03.03-03.05		**0 265 005 285**
Pressure sensor, ESP, (electronic stability program)	03.03-03.05		**0 265 005 303**
Wheel speed sensor, front	03.03-03.05		**0 265 007 592**
Wheel speed sensor, rear	03.03-03.05		**0 265 007 593**
730 Li [E 66]		**3,0 l 190 kW N52 B30... 6 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 285**
Pressure sensor, ESP, (electronic stability program)	04.05→		**0 265 005 303**
Wheel speed sensor, front	04.05-09.05		**0 265 007 592**
Wheel speed sensor, rear	04.05-09.05		**0 265 007 593**
	10.05→		**0 265 007 845**
732 i [E 23]		**3,2 l 145 kW 32 6E A 6 Zyl.**	
Throttle valve sensor	01.86-06.86		**0 280 120 320**
Air flow sensor, gasoline injection	09.82-06.86		**0 280 203 018**
			0 986 280 072
CH,S	09.80-06.86		**0 280 203 014**
Speed sensor, ignition/injection	09.80-06.86		**0 261 210 002**
Temperature sensor, coolant, injection system	09.83-06.86		**0 280 130 023**
Wheel speed sensor	09.81-06.86	HI	**0 265 001 023**
	09.79-06.86	VO	**0 265 001 005**
Wheel speed sensor, rear	10.81-06.86		**0 265 001 023**
735 i [E 23]		**3,4 l 135/136-141 kW ; 34 6K A 6 Zyl.**	
Throttle valve sensor	01.86-08.86		**0 280 120 320**
Air flow sensor, gasoline injection	09.84-08.86		**0 280 203 027**
			0 986 280 002
Speed sensor, ignition/injection	09.84-08.86		**0 261 210 002**
Temperature sensor, coolant, injection system	09.84-08.86		**0 280 130 026**
Wheel speed sensor	01.85-08.86	HI	**0 265 001 023**
		VO	**0 265 001 005**
Wheel speed sensor, rear	09.84-08.86		**0 265 001 023**
735 i [E 23]		**3,4 l 160 kW 34 6E A/C 6 Zyl.**	
Throttle valve sensor	01.86-06.86		**0 280 120 320**
Air flow sensor, gasoline injection CH	09.82-06.86		**0 280 203 014**
~~CH~~	10.84-06.86		**0 280 203 027**
			0 986 280 002
Speed sensor, ignition/injection	09.82-06.86		**0 261 210 002**
Temperature sensor, coolant, injection system	09.82-06.86		**0 280 130 026**
Wheel speed sensor	09.82-06.86	HI	**0 265 001 023**
		VO	**0 265 001 005**
Wheel speed sensor, rear	09.82-06.86		**0 265 001 023**
735 i [E 65]		**3,6 l 200 kW N62 B36A 8 Zyl.**	
Air mass meter, gasoline injection	11.01-09.03		**0 280 218 077**
	10.03-03.05		**0 280 218 135**
Knock sensor	11.01-03.05		**0 261 231 200**
Duo sensor, acceleration and yaw rate, brake system	11.01-03.05		**0 265 005 285**
Pressure sensor, ESP, (electronic stability program)	11.01-03.05		**0 265 005 303**
Wheel speed sensor, front	11.01-03.03		**0 265 007 461**
	04.03-03.05		**0 265 007 592**

Product			
Wheel speed sensor, rear	11.01-03.03		**0 265 007 462**
	04.03-03.05		**0 265 007 593**
735 i, iL [E 32]		**3,4 l 155-162 kW 34 6E C/K B 6 Zyl.**	
Throttle valve assembly	09.87-12.92		**0 132 010 453**
Throttle valve sensor	09.86-12.92	AG	**0 280 120 406**
		GS	**0 280 120 320**
Air flow sensor, gasoline injection	09.86-12.92		**0 280 203 027**
			0 986 280 002
Temperature sensor, coolant, injection system	09.86-12.92		**0 280 130 026**
Wheel speed sensor, front	09.86-12.92		**0 265 001 339**
735 i, iL [E 38]		**3,5 l 173-175 kW 35 8S 1/2 8 Zyl.**	
Air mass meter, gasoline injection	09.94-09.98		**0 280 217 502**
	10.98-12.01		**0 280 217 533**
Knock sensor	09.94-09.97		**0 261 231 113**
	10.97-12.01		**0 261 231 200**
Pedal position sensor, EMS (electronic engine management)	09.98-09.99		**0 281 002 291**
Duo sensor, acceleration and yaw rate, brake system	10.98-12.01		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	10.98-12.01		**0 265 005 303**
735 Li [E 66]		**3,6 l 200 kW N62 B36A 8 Zyl.**	
Air mass meter, gasoline injection	03.02-09.03		**0 280 218 077**
	10.03-03.05		**0 280 218 135**
Knock sensor	03.02-03.05		**0 261 231 200**
Duo sensor, acceleration and yaw rate, brake system	03.02-03.05		**0 265 005 285**
Pressure sensor, ESP, (electronic stability program)	03.02-03.05		**0 265 005 303**
Wheel speed sensor, front	03.02-03.03		**0 265 007 461**
	04.03-03.05		**0 265 007 592**
Wheel speed sensor, rear	03.02-03.03		**0 265 007 462**
	04.03-03.05		**0 265 007 593**
740 d [E 38]		**3,9 l 180 kW 39 8D 1 8 Zyl.**	
Air mass meter, diesel	10.98-12.01		**0 280 217 124**
High-pressure sensor (CR system)	10.98-12.01		**0 281 002 475**
Pedal position sensor, diesel	10.98-12.01		**0 281 002 291**
Duo sensor, acceleration and yaw rate, brake system	10.98-12.01		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	10.98-12.01		**0 265 005 303**
740 d [E 65]		**3,9 l 190 kW 39 8D 1 8 Zyl.**	
Air mass meter, diesel	10.02-03.05		**0 281 002 567**
High-pressure sensor (CR system)	10.02-03.05		**0 281 002 497**
Duo sensor, acceleration and yaw rate, brake system	10.02-03.05		**0 265 005 285**
Pressure sensor, ESP, (electronic stability program)	10.02-03.05		**0 265 005 303**
Wheel speed sensor, front	10.02-03.03		**0 265 007 461**
	04.03-03.05		**0 265 007 592**
Wheel speed sensor, rear	10.02-03.03		**0 265 007 462**
	04.03-03.05		**0 265 007 593**
740 i [E 65]		**4,0 l 225 kW N62 B40A 8 Zyl.**	
Knock sensor	04.05→		**0 261 231 200**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 285**
Pressure sensor, ESP, (electronic stability program)	04.05→		**0 265 005 303**
Wheel speed sensor, front	04.05-09.05		**0 265 007 592**
Wheel speed sensor, rear	04.05-09.05		**0 265 007 593**
	10.05→		**0 265 007 845**
740 i, iL [E 32]		**4,0 l 210 kW 40 8S 1 8 Zyl.**	
Air mass meter, gasoline injection	09.91-10.94		**0 280 217 800**
Knock sensor	09.91-05.93		**0 261 231 074**
	06.93-10.94		**0 261 231 096**
Temperature sensor, intake air, injection system	09.91-10.94		**0 280 130 039**
Temperature sensor, coolant, injection system	09.91-10.94		**0 280 130 026**
Wheel speed sensor, front	09.91-10.94		**0 265 001 339**

Product			
740 i, iL [E 38]			**4,0 l 210 kW 40 8S 1 8 Zyl.**
Air mass meter, gasoline injection	06.94-06.96		**0 280 217 800**
Knock sensor	06.94-06.96		**0 261 231 096**
Temperature sensor, coolant, injection system	06.94-06.96	XJD	**0 280 130 089**
740 i, iL [E 38]			**4,4 l 210 kW 44 8S 1/2 8 Zyl.**
Air mass meter, gasoline injection	01.96-09.98		**0 280 217 800**
	10.98-12.01		**0 280 217 814**
Knock sensor	01.96-09.97		**0 261 231 113**
	10.97-12.01		**0 261 231 200**
Pedal position sensor, EMS (electronic engine management)	09.98-09.99		**0 281 002 291**
Duo sensor, acceleration and yaw rate, brake system	10.98-12.01		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	10.98-12.01		**0 265 005 303**
740 Li [E 66]			**4,0 l 225 kW N62 B40A 8 Zyl.**
Knock sensor	04.05→		**0 261 231 200**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 285**
Pressure sensor, ESP, (electronic stability program)	04.05→		**0 265 005 303**
Wheel speed sensor, front	04.05-09.05		**0 265 007 592**
Wheel speed sensor, rear	04.05-09.05		**0 265 007 593**
	10.05→		**0 265 007 845**
745 d [E 65]			**4,4 l 220 kW 44 8D 1 8 Zyl.**
Air mass meter, diesel	03.05-08.05		**0 281 002 567**
Duo sensor, acceleration and yaw rate, brake system	03.05-08.05		**0 265 005 285**
Pressure sensor, ESP, (electronic stability program)	03.05-08.05		**0 265 005 303**
Wheel speed sensor, front	03.05-08.05		**0 265 007 592**
Wheel speed sensor, rear	03.05-08.05		**0 265 007 593**
745 d [E 65]			**4,4 l 242 kW 44 8D 1 8 Zyl.**
Air mass meter, diesel	09.05→		**0 281 002 567**
Duo sensor, acceleration and yaw rate, brake system	09.05→		**0 265 005 285**
Pressure sensor, ESP, (electronic stability program)	09.05→		**0 265 005 303**
Wheel speed sensor, rear	09.05→		**0 265 007 845**
745 i [E 23]			**3,4 l 185 kW 34 6T A 6 Zyl.**
Speed sensor, ignition/injection	05.83-06.86		**0 261 210 002**
Knock sensor	05.83-06.86		**0 261 231 001**
Pressure sensor, intake manifold, gasoline	05.83-06.86	AG	**0 280 101 001**
Temperature sensor, coolant, injection system	05.83-06.86		**0 280 130 026**
Wheel speed sensor	05.83-06.86	HI	**0 265 001 023**
		VO	**0 265 001 005**
Wheel speed sensor, rear	05.83-06.86		**0 265 001 023**
745 i [E 65]			**4,4 l 245 kW N62 B44A 8 Zyl.**
Air mass meter, gasoline injection	11.01-09.03		**0 280 218 077**
	10.03-03.05		**0 280 218 135**
Knock sensor	11.01-03.05		**0 261 231 200**
Duo sensor, acceleration and yaw rate, brake system	11.01-03.05		**0 265 005 285**
Pressure sensor, ESP, (electronic stability program)	11.01-03.05		**0 265 005 303**
Wheel speed sensor, front	11.01-03.03		**0 265 007 461**
	04.03-03.05		**0 265 007 592**
Wheel speed sensor, rear	11.01-03.03		**0 265 007 462**
	04.03-03.05		**0 265 007 593**
745 Li [E 66]			**4,4 l 245 kW N62 B44A 8 Zyl.**
Air mass meter, gasoline injection	03.02-09.03		**0 280 218 077**
	10.03-03.05		**0 280 218 135**
Knock sensor	03.02-03.05		**0 261 231 200**
Duo sensor, acceleration and yaw rate, brake system	03.02-03.05		**0 265 005 285**
Pressure sensor, ESP, (electronic stability program)	03.02-03.05		**0 265 005 303**
Wheel speed sensor, front	03.02-03.03		**0 265 007 461**
	04.03-03.05		**0 265 007 592**

Product			
Wheel speed sensor, rear	03.02-03.03		**0 265 007 462**
	04.03-03.05		**0 265 007 593**
750 i [E 65]			**4,8 l 270 kW N62 B48B 8 Zyl.**
Knock sensor	04.05→		**0 261 231 200**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 285**
Pressure sensor, ESP, (electronic stability program)	04.05→		**0 265 005 303**
Wheel speed sensor, front	04.05-09.05		**0 265 007 592**
Wheel speed sensor, rear	04.05-09.05		**0 265 007 593**
	10.05→		**0 265 007 845**
750 i, iL [E 32]			**5,0 l 220 kW 50 12 A 12 Zyl.**
Throttle valve assembly	09.87-10.94		**0 205 003 001**
Air mass meter, gasoline injection	09.87-10.94		**0 280 212 025**
			0 986 280 111
			0 986 280 130
Temperature sensor, intake air, injection system	09.87-10.94		**0 280 130 060**
Temperature sensor, coolant, injection system	09.87-10.94		**0 280 130 056**
Wheel speed sensor, front	09.87-10.94		**0 265 001 339**
750 i, iL [E 38]			**5,4 l 240 kW 54 12 1/2 12 Zyl.**
Air mass meter, gasoline injection	06.94-12.01		**0 280 217 110**
Knock sensor	06.94-09.97		**0 261 231 107**
Duo sensor, acceleration and yaw rate, brake system	10.98-12.01		**0 265 005 248**
Pressure sensor, ESP, (electronic stability program)	10.98-12.01		**0 265 005 303**
750 Li [E 66]			**4,8 l 270 kW N62 B48B 8 Zyl.**
Knock sensor	04.05→		**0 261 231 200**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 285**
Pressure sensor, ESP, (electronic stability program)	04.05→		**0 265 005 303**
Wheel speed sensor, front	04.05-09.05		**0 265 007 592**
Wheel speed sensor, rear	04.05-09.05		**0 265 007 593**
	10.05→		**0 265 007 845**
760 i [E 65]			**6,0 l 327 kW N73 B60... 12 Zyl.**
Air mass meter, gasoline injection	12.02→		**0 280 218 076**
Duo sensor, acceleration and yaw rate, brake system	12.02→		**0 265 005 285**
Pressure sensor, ESP, (electronic stability program)	12.02→		**0 265 005 303**
Wheel speed sensor, front	12.02-03.03		**0 265 007 461**
	04.03-09.05		**0 265 007 592**
Wheel speed sensor, rear	12.02-03.03		**0 265 007 462**
	04.03-09.05		**0 265 007 593**
	10.05→		**0 265 007 845**
760 Li [E 66]			**6,0 l 327 kW N73 B60... 12 Zyl.**
Air mass meter, gasoline injection	12.02→		**0 280 218 076**
Duo sensor, acceleration and yaw rate, brake system	12.02→		**0 265 005 285**
Pressure sensor, ESP, (electronic stability program)	12.02→		**0 265 005 303**
Wheel speed sensor, front	12.02-03.03		**0 265 007 461**
	04.03-09.05		**0 265 007 592**
Wheel speed sensor, rear	12.02-03.03		**0 265 007 462**
	04.03-09.05		**0 265 007 593**
	10.05→		**0 265 007 845**

Serie 8

840 Ci [E 31]			**4,4 l 210 kW 44 8S 1 8 Zyl.**
Air mass meter, gasoline injection	09.94-12.99		**0 280 217 800**
Knock sensor	09.94-12.99		**0 261 231 113**
840 i [E 31]			**4,0 l 210 kW 40 8S 1 8 Zyl.**
Air mass meter, gasoline injection	04.93-03.96		**0 280 217 800**
Knock sensor	04.93-03.96		**0 261 231 096**
Temperature sensor, coolant, injection system	04.93-03.96	XJD	**0 280 130 089**

B

Product

◀ Serie 8

850 Ci [E 31]			**5,4 l 240 kW 54 12 1 12 Zyl.**
Air mass meter, gasoline injection	03.94-12.99		**0 280 217 110**
Knock sensor	03.94-12.99		**0 261 231 107**
850 CSi [E 31]			**5,6 l 279-280 kW 56 12 1 12 Zyl.**
Throttle valve assembly	08.92-10.96		**0 205 003 001**
Air mass meter, gasoline injection	08.92-10.96		**0 280 212 026**
Temperature sensor, coolant, injection system	08.92-10.96	AS3	**0 280 130 056**
		XJD	**0 280 130 089**
850 i, Ci [E 31]			**5,0 l 220 kW 50 12 A 12 Zyl.**
Throttle valve assembly	07.89-12.94		**0 205 003 001**
Air mass meter, gasoline injection	07.89-12.94		**0 280 212 025**
			0 986 280 111
			0 986 280 130
Temperature sensor, coolant, injection system	07.89-12.94	AS3	**0 280 130 056**
		XJD	**0 280 130 089**
Wheel speed sensor, front	07.89-09.91	BO	**0 265 001 301**
Wheel speed sensor, rear	07.89-09.91	BO,LAB	**0 265 001 303**
		BO,RAB	**0 265 001 302**

B

BUICK

Regal

2.0 i			**2,0 l 91 kW L34 4 Zyl.**
Phase sensor	02.03→		**0 232 103 015**
Speed sensor, ignition/injection	02.03→		**0 261 210 150**
Knock sensor	02.03→		**0 261 231 163**
Pressure sensor, intake manifold, gasoline	02.03→		**0 261 230 116**
Temperature sensor, coolant, injection system	02.03→		**0 280 130 121**

CADILLAC

Allante Convertible

4.5 i			**4,5 l 147 kW 8 Zyl.**
Wheel speed sensor, front	09.89-12.92		**0 265 001 258**

Catera

3.0			**3,0 l 149 kW X30... 6 Zyl.**
Throttle valve sensor	10.96-12.01		**0 280 122 014**
Air mass meter, gasoline injection	10.96-12.01		**0 280 217 519**
Speed sensor, ignition/injection	10.96-12.01		**0 261 210 131**
Knock sensor	10.96-12.01		**0 261 231 116**
Pressure sensor, intake manifold, gasoline	10.96-12.01	FTA	**0 261 230 015**
Temperature sensor, intake air, injection system	10.96-12.01		**0 280 130 092**
Temperature sensor, coolant, injection system	10.96-12.01		**0 280 130 093**

CHERY

QQ

1.1 i [SQR7110]			**1,1 l 38 kW DA465Q-1A2 4 Zyl.**
Throttle valve sensor	05.04-08.06		**0 280 122 019**
Knock sensor	05.04-08.06		**0 261 231 036**
Pressure sensor, intake manifold, gasoline	05.04-08.06		**0 261 230 011**
Temperature sensor, coolant, injection system	05.04-08.06		**0 280 130 037**

Product

CHEVROLET

Blazer

2.4 MPFI			**2,4 l 94 kW C24NE 4 Zyl.**
Throttle valve assembly	05.00-01.07		**F 000 DV0 100**
Throttle valve sensor	05.00-01.07		**0 280 122 001**
Speed sensor, ignition/injection	05.00-01.07		**0 261 210 030**
Knock sensor	05.00-01.07		**0 261 231 046**
Pressure sensor, intake manifold, gasoline	05.00-01.07		**0 261 230 022**
Temperature sensor, coolant, injection system	05.00-01.07		**0 280 130 107**
4.3 V6 MPFI			**4,3 l 132 kW C43NE 6 Zyl.**
Pressure sensor, intake manifold, gasoline	10.01-10.03		**0 261 230 030**

C

20			**4,1 l 165 kW C41GE 6 Zyl.**
Throttle valve sensor	01.96-12.96		**0 280 122 001**
Air mass meter, gasoline injection	01.96-12.96		**0 280 217 525**
Phase sensor	01.96-12.96		**0 232 103 006**
Speed sensor, ignition/injection	01.96-12.96		**0 261 210 083**
Temperature sensor, intake air, injection system	01.96-12.96		**0 280 130 073**
Temperature sensor, coolant, injection system	01.96-12.96		**0 280 130 068**

Calibra

2.0 16V			**2,0 l 110,3 kW C20XE 4 Zyl.**
Throttle valve sensor	10.93-03.96		**0 280 122 001**
Air mass meter, gasoline injection			
Fg.no. →14002934	10.93-03.96		**0 280 212 015**
			0 986 280 113
Fg.no. 14002935→	10.93-03.96		**0 280 217 106**
Phase sensor			
Fg.no. →1035178	10.93-03.95		**0 232 103 002**
Speed sensor, ignition/injection	10.93-03.96		**0 261 210 030**
Knock sensor	10.93-03.96		**0 261 231 006**
Temperature sensor, intake air, injection system	10.93-03.96		**0 280 130 073**
Temperature sensor, coolant, injection system	10.93-03.96		**0 280 130 107**
Wheel speed sensor, rear	10.93-03.96	HLI	**0 265 003 094**
		HRE	**0 265 003 093**

Camaro Coupé

5.0 i			**5,0 l 164 kW 8 Zyl.**
Air mass meter, gasoline injection	09.87-07.89		**0 280 213 009**
			0 986 280 105

Captiva

2.0 CDRi, CDRi 4x4 [KL1C]			**2,0 l 110 kW Z20S 4 Zyl.**
Air flow sensor, diesel	10.06→		**0 281 002 683**

Corvette Cabrio

5.7			**5,7 l 225 kW PTPI 8 Zyl.**
Throttle valve assembly	09.91-09.01		**0 205 005 002**
Acceleration sensor, ABS	09.91-08.92		**0 265 005 004**
	09.92-09.01		**0 265 005 041**
Wheel speed sensor, rear	09.91-09.01	LAB	**0 265 001 166**
		RAB	**0 265 001 165**

Product

Corvette Coupé

5.7			**5,7 l 179-183 kW L98 8 Zyl.**
Air mass meter, gasoline injection	08.85-07.87		**0 280 213 004**
			0 986 280 103
	08.87-07.89		**0 280 213 009**
			0 986 280 105
Acceleration sensor, ABS	08.86-08.91		**0 265 005 004**
Wheel speed sensor, front	08.87-07.89	LAB	**0 265 001 164**
		RAB	**0 265 001 163**
Wheel speed sensor, rear	08.87-07.91	LAB	**0 265 001 166**
		RAB	**0 265 001 165**
5.7 ZR-1			**5,7 l 279 kW LT5 8 Zyl.**
Acceleration sensor, ABS	06.89-08.91		**0 265 005 004**
Wheel speed sensor, rear	06.89-07.91	LAB	**0 265 001 166**
		RAB	**0 265 001 165**
5.7 ZR-1			**5,7 l 279-302 kW LT5 8 Zyl.**
Throttle valve assembly	09.91-08.95		**0 205 005 002**
Acceleration sensor, ABS	09.91-08.92		**0 265 005 004**
	09.92-08.95		**0 265 005 041**
Wheel speed sensor, rear	09.91-08.95	LAB	**0 265 001 166**
		RAB	**0 265 001 165**

Lacetti

2.0 D [KL1N, J200]			**2,0 l 89 kW 4 Zyl.**
Air flow sensor, diesel	09.06→		**0 281 002 683**

Nubira

2.0 D [KL1N, J200]			**2,0 l 89 kW 4 Zyl.**
Air mass meter, diesel	09.06→		**0 281 002 683**

Nubira Station Wagon

2.0 D [KL1N, J200]			**2,0 l 89 kW 4 Zyl.**
Air mass meter, diesel	09.06→		**0 281 002 683**

Silverado

4.1 MPFI			**4,1 l 102 kW C41GE 6 Zyl.**
Throttle valve assembly	11.96-12.01		**9 280 082 000**
Air mass meter, gasoline injection	11.96-12.01		**0 280 217 525**
Phase sensor	11.96-12.01		**0 232 103 006**
Speed sensor, ignition/injection	11.96-09.97		**0 261 210 083**
Temperature sensor, intake air, injection system	11.96-12.01		**0 280 130 073**
Temperature sensor, coolant, injection system	11.96-12.01		**0 280 130 032**

S10

2.2 EFI			**2,2 l 83 kW B22NZ 4 Zyl.**
Temperature sensor, coolant, injection system	03.95-10.98		**0 280 130 026**
2.2 MPFI			**2,2 l 100 kW C22SE 4 Zyl.**
Throttle valve assembly	08.97-04.00		**F 000 DV0 100**
Speed sensor, ignition/injection	08.97-04.00		**0 261 210 030**
Knock sensor	08.97-04.00		**0 261 231 046**
Pressure sensor, intake manifold, gasoline	08.97-04.00		**0 261 230 022**
Temperature sensor, coolant, injection system	08.97-04.00		**0 280 130 107**
4.3 V6 MPFI			**4,3 l 132 kW 6 Zyl.**
Pressure sensor, intake manifold, gasoline	10.01-10.03		**0 261 230 030**

Product

CHRYSLER

New Yorker

2.2 i			**2,2 l 72 kW EDF 4 Zyl.**
Temperature sensor, coolant, injection system	10.86-09.87		**0 280 130 063**

Voyager

2.5 TD [ES]			**2,5 l 85-87 kW VM HR 425 CLIEE 4 Zyl.**
Air mass meter, diesel	04.95-12.95		**0 281 002 132**
2.5 TD [GS]			**2,5 l 85 kW VM HR 425 CLIEE 4 Zyl.**
Air mass meter, diesel	01.95-12.00		**0 281 002 132**
Pressure sensor, intake manifold, diesel	08.97-12.00		**0 281 002 205**

CITROEN

AX

1.0 i			**1,0 l 31-33/37 kW CDY Kat. <TU9M>; CDZ Kat. <TU9M> 4 Zyl.**
Temperature sensor, coolant, injection system	07.92-12.98	KLO	**0 280 130 026**
1.4 i			**1,4 l 55-58 kW KDX,KDY Kat.(Gußmot.) <TU3FM>; KDY,KDZ Kat. <TU3M> 4 Zyl.**
Temperature sensor, coolant, injection system	06.88-12.96		**0 280 130 026**
1.4 i			**1,4 l 66/69-74 kW KFY Kat. <TU3FJ>; KFZ Kat. <TU3FJ>; K6B <TU3FJ2> 4 Zyl.**
Throttle valve sensor	05.91-12.96		**0 280 122 001**

Berlingo

Electrique [M49]			**24 kW SA18 0 Zyl.**
Wheel speed sensor, front	10.98-11.02		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	10.98-05.01		**0 265 006 209**
Org.no. 8939→	06.01-11.02		**0 265 006 659**
Electrique [M59]			**28 kW SA18 0 Zyl.**
Wheel speed sensor, front			
Org.no. →10220	11.02-11.04		**0 265 006 200**
Org.no. 10221→	12.04→		**0 265 007 666**
Wheel speed sensor, rear			
Org.no. →9582	11.02-02.03		**0 265 006 659**
Org.no. 9583→10220	03.03-11.04		**0 265 006 793**
Org.no. 10221→	12.04→	LAB	**0 265 007 668**
Org.no. 10221→10478	12.04-07.05	RAB	**0 265 007 667**
Org.no. 10479→	08.05→	RAB	**0 265 007 883**
1.1 i [M49]			**1,1 l 44 kW HDY; HDZ 4 Zyl.**
Temperature sensor, coolant, injection system	07.96-11.02		**0 280 130 084**
Wheel speed sensor, front	07.96-11.02		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	07.96-05.01		**0 265 006 209**
Org.no. 8939→	06.01-11.02		**0 265 006 659**
1.1 i [M49]			**1,1 l 44 kW HFX 4 Zyl.**
Pressure sensor, intake manifold, gasoline	06.00-11.02		**0 261 230 043**
Wheel speed sensor, front	06.00-11.02		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	06.00-05.01		**0 265 006 209**
Org.no. 8939→	06.01-11.02		**0 265 006 659**
1.1 i [M59]			**1,1 l 44 kW HFX 4 Zyl.**
Knock sensor	11.02→		**0 261 231 128**
Pressure sensor, intake manifold, gasoline	11.02→		**0 261 230 043**
Wheel speed sensor, front			
Org.no. →10220	11.02-11.04		**0 265 006 200**
Org.no. 10221→	12.04→		**0 265 007 666**

C

Product			
◀ Berlingo			
Wheel speed sensor, rear			
Org.no. →9582	11.02-02.03		**0 265 006 659**
Org.no. 9583→10220	03.03-11.04		**0 265 006 793**
Org.no. 10221→	12.04→	LAB	**0 265 007 668**
Org.no. 10221→10478	12.04-07.05	RAB	**0 265 007 667**
Org.no. 10479→	08.05→	RAB	**0 265 007 883**
1.4 [M49]			**1,4 l 51 kW K5A 4 Zyl.**
Wheel speed sensor, front	10.96-11.02		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	10.96-05.01		**0 265 006 209**
Org.no. 8939→	06.01-11.02		**0 265 006 659**
1.4 i [M49]			**1,4 l 55 kW KFW 4 Zyl.**
Pressure sensor, intake manifold, gasoline	06.00-11.02		**0 261 230 043**
Wheel speed sensor, front	06.00-11.02		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	06.00-05.01		**0 265 006 209**
Org.no. 8939→	06.01-11.02		**0 265 006 659**
1.4 i [M49]			**1,4 l 55 kW KFX 4 Zyl.**
Knock sensor	07.96-11.02	N14	**0 261 231 128**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	07.96-12.98		**0 261 230 012**
Org.no. 8057→	01.99-11.02		**0 261 230 057**
Wheel speed sensor, front	07.96-11.02		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	07.96-05.01		**0 265 006 209**
Org.no. 8939→	06.01-11.02		**0 265 006 659**
1.4 i [M59]			**1,4 l 55 kW KFW 4 Zyl.**
Knock sensor	11.02→		**0 261 231 128**
Pressure sensor, intake manifold, gasoline	11.02→		**0 261 230 043**
Accelerator pedal module	11.02→	LLE	**0 280 752 251**
Wheel speed sensor, front			
Org.no. →10220	11.02-11.04		**0 265 006 200**
Org.no. 10221→	12.04→		**0 265 007 666**
Wheel speed sensor, rear			
Org.no. →9582	11.02-02.03		**0 265 006 659**
Org.no. 9583→10220	03.03-11.04		**0 265 006 793**
Org.no. 10221→	12.04→	LAB	**0 265 007 668**
Org.no. 10221→10478	12.04-07.05	RAB	**0 265 007 667**
Org.no. 10479→	08.05→	RAB	**0 265 007 883**
1.6 HDi [M59]			**1,6 l 55 kW 9HW 4 Zyl.**
Wheel speed sensor, front	09.05→		**0 265 007 666**
Wheel speed sensor, rear	09.05→	LAB	**0 265 007 668**
		RAB	**0 265 007 883**
1.6 HDi [M59]			**1,6 l 66 kW 9HX 4 Zyl.**
Yaw rate sensor, brake system	09.05→		**0 265 005 290**
Wheel speed sensor, front	09.05→		**0 265 007 666**
Wheel speed sensor, rear	09.05→	LAB	**0 265 007 668**
		RAB	**0 265 007 883**
1.6 i 16V [M49]			**1,6 l 80 kW NFU 4 Zyl.**
Throttle valve assembly	06.00-11.02		**0 280 750 085**
Knock sensor	06.00-11.02		**0 261 231 128**
Pressure sensor, intake manifold, gasoline	06.00-11.02		**0 261 230 043**
Wheel speed sensor, front	06.00-11.02		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	06.00-05.01		**0 265 006 209**
Org.no. 8939→	06.01-11.02		**0 265 006 659**
1.6 i 16V [M59]			**1,6 l 80 kW NFU 4 Zyl.**
Throttle valve assembly	11.02→		**0 280 750 085**
Knock sensor	11.02→		**0 261 231 128**
			0 261 231 168
Pressure sensor, intake manifold, gasoline	11.02→		**0 261 230 043**
Accelerator pedal module	11.02→	LLE	**0 280 752 251**
Yaw rate sensor, brake system	11.02→		**0 265 005 290**

Product			
Wheel speed sensor, front			
Org.no. →10220	11.02-11.04		**0 265 006 200**
Org.no. 10221→	12.04→		**0 265 007 666**
Wheel speed sensor, rear			
Org.no. →9582	11.02-02.03	TBR	**0 265 006 659**
Org.no. →10220	11.02-11.04	SBR	**0 265 006 732**
Org.no. 9583→10220	03.03-11.04	TBR	**0 265 006 793**
Org.no. 10221→	12.04→	LAB	**0 265 007 668**
Org.no. 10221→10478	12.04-07.05	RAB	**0 265 007 667**
Org.no. 10479→	08.05→	RAB	**0 265 007 883**
1.8 D [M49]			**1,8 l 43-44 kW A9A-161A 4 Zyl.**
Wheel speed sensor, front	07.96-11.02		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	07.96-05.01		**0 265 006 209**
Org.no. 8939→	06.01-11.02		**0 265 006 659**
1.8 i			**1,8 l 74 kW XU7JB 4 Zyl.**
Temperature sensor, coolant, injection system	10.99-12.03		**0 280 130 084**
1.8 i [M49]			**1,8 l 66 kW LFX 4 Zyl.**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	03.97-12.98		**0 261 230 012**
Org.no. 8057→	01.99-11.02		**0 261 230 057**
Wheel speed sensor, front	03.97-11.02		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	03.97-05.01		**0 265 006 209**
Org.no. 8939→	06.01-11.02		**0 265 006 659**
1.9 D [M49]			**1,9 l 50-51/52 kW DJY; D9B; WJC/WJZ; WJY 4 Zyl.**
Wheel speed sensor, front	07.96-11.02		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	07.96-05.01		**0 265 006 209**
Org.no. 8939→	06.01-11.02		**0 265 006 659**
1.9 D [M59]			**1,9 l 52 kW WJY 4 Zyl.**
Wheel speed sensor, front			
Org.no. →10220	11.02-11.04		**0 265 006 200**
Org.no. 10221→	12.04→		**0 265 007 666**
Wheel speed sensor, rear			
Org.no. →9582	11.02-02.03		**0 265 006 659**
Org.no. 9583→10220	03.03-11.04		**0 265 006 793**
Org.no. 10221→	12.04→	LAB	**0 265 007 668**
Org.no. 10221→10478	12.04-07.05	RAB	**0 265 007 667**
Org.no. 10479→	08.05→	RAB	**0 265 007 883**
2.0 HDi [M49]			**2,0 l 66 kW RHY 4 Zyl.**
High-pressure sensor (CR system)	12.99-11.02		**0 281 002 283**
Wheel speed sensor, front	12.99-11.02		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	12.99-05.01		**0 265 006 209**
Org.no. 8939→	06.01-11.02		**0 265 006 659**
2.0 HDi [M59]			**2,0 l 66 kW RHY 4 Zyl.**
Yaw rate sensor, brake system	11.02→		**0 265 005 290**
Wheel speed sensor, front			
Org.no. →10220	11.02-11.04		**0 265 006 200**
Org.no. 10221→	12.04→		**0 265 007 666**
Wheel speed sensor, rear			
Org.no. →9582	11.02-02.03	TBR	**0 265 006 659**
Org.no. →10220	11.02-11.04	SBR	**0 265 006 732**
Org.no. 9583→10220	03.03-11.04	TBR	**0 265 006 793**
Org.no. 10221→	12.04→	LAB	**0 265 007 668**
Org.no. 10221→10478	12.04-07.05	RAB	**0 265 007 667**
Org.no. 10479→	08.05→	RAB	**0 265 007 883**
2.0 HDI			**2,0 l 66 kW DW10TD 4 Zyl.**
High-pressure sensor (CR system)	10.00→		**0 281 002 283**

Product

BX

14 i [X56]	**1,4 l 55 kW KDY Kat. <TU3M/Z>; KDZ Kat. <TU3M/Z> 4 Zyl.**	
Temperature sensor, coolant, injection system	09.88-09.93	**0 280 130 026**
16 i [X56]	**1,6 l 76 kW 180Z <XU5J> 4 Zyl.**	
Throttle valve sensor		
Fg.no. 4132→	02.88-12.94	**0 280 120 327**
Org.no. →4131	03.86-02.88	**0 280 120 310**
Air flow sensor, gasoline injection	06.86-12.94	**0 280 202 056**
		0 986 280 028
Temperature sensor, coolant, injection system	03.86-12.94	**0 280 130 026**
Relay, Jetronic	03.86-12.94	**0 280 230 006**
16 i [X56]	**1,6 l 83-85 kW B6D,B6E 4 Zyl.**	
Throttle valve sensor		
Fg.no. 4132→	02.88-02.93	**0 280 120 327**
Org.no. →4131	09.87-02.88	**0 280 120 310**
Air flow sensor, gasoline injection	09.87-02.93	**0 280 202 056**
		0 986 280 028
Temperature sensor, coolant, injection system	09.87-02.93	**0 280 130 026**
19 i [X56]	**1,9 l 75-77 kW DFZ Kat. <XU9J1/Z> 4 Zyl.**	
Throttle valve sensor		
Fg.no. 4132→	02.88-12.94	**0 280 120 327**
Org.no. →4131	03.86-02.88	**0 280 120 310**
Air flow sensor, gasoline injection		
Org.no. →4227 A,CH,D,NL,S	06.86-05.88	**0 280 202 097**
		0 986 280 070
Temperature sensor, coolant, injection system	03.86-12.94	**0 280 130 026**
Relay, Jetronic	03.86-12.94	**0 280 230 006**
19 i [X56]	**1,9 l 80 kW DDZ Kat. <XU9M/Z> 4 Zyl.**	
Temperature sensor, coolant, injection system	06.88-12.94	**0 280 130 026**
19 i [X56]	**1,9 l 88 kW DKZ Kat. <XU9JAZ> 4 Zyl.**	
Throttle valve sensor	06.88-03.93	**0 280 120 327**
Speed sensor, ignition/injection	06.88-03.93	**0 261 210 043**
Temperature sensor, coolant, injection system	06.88-03.93	**0 280 130 026**
19 i [X56]	**1,9 l 90 kW D6A <XU9J2/K> 4 Zyl.**	
Throttle valve sensor		
Fg.no. 4132→4923	02.88-05.90	**0 280 120 327**
Org.no. →4131	07.86-02.88	**0 280 120 310**
Org.no. 4924→	05.90-07.90	**0 280 122 001**
Air flow sensor, gasoline injection		
Org.no. →4923	07.86-04.90	**0 280 202 602**
		0 986 280 019
Temperature sensor, coolant, injection system	07.86-07.90	**0 280 130 026**
Relay, Jetronic	07.86-07.90	**0 332 019 151**
19 i [X56]	**1,9 l 90 kW D6D <XU9J2/K> 4 Zyl.**	
Throttle valve sensor	07.90-09.93	**0 280 122 001**
Speed sensor, ignition/injection	07.90-09.93	**0 261 210 043**
Temperature sensor, coolant, injection system	07.90-09.93	**0 280 130 026**
19 i 16S [X56]	**1,9 l 108 kW DFW Kat. <XU9J4/Z> 4 Zyl.**	
Throttle valve sensor	03.88-03.93	**0 280 120 327**
Speed sensor, ignition/injection	03.88-03.93	**0 261 210 043**
Knock sensor	03.88-03.93	**0 261 231 006**
Temperature sensor, coolant, injection system	03.88-03.93	**0 280 130 026**
19 i 16S [X56]	**1,9 l 116 kW D6C <XU9J4/K> 4 Zyl.**	
Throttle valve sensor		
Fg.no. 4132→	02.88-12.92	**0 280 120 327**
Org.no. →4131	07.87-02.88	**0 280 120 310**
Speed sensor, ignition/injection	07.87-12.92	**0 261 210 043**
Knock sensor	03.88-12.92	**0 261 231 006**
Temperature sensor, coolant, injection system	07.87-12.92	**0 280 130 026**

Product

C 15

E 1.1 i	**1,1 l 44 kW HDZ Kat. 4 Zyl.**	
Temperature sensor, coolant, injection system	06.89-12.96	**0 280 130 026**
E 1.4 i	**1,4 l 55-58 kW KDY Kat.(Gußmot.) 4 Zyl.**	
Temperature sensor, coolant, injection system	01.92-12.96	**0 280 130 026**

CX

20	**2,0 l 74-78 kW 829 A5, J6RA500 4 Zyl.**	
Wheel speed sensor	07.82-03.86	**0 265 001 098**
Wheel speed sensor, front	04.86-12.92	**0 265 001 157**
Wheel speed sensor, rear	07.82-12.92	**0 265 001 158**
22	**2,2 l 83-85 kW J6T A500 4 Zyl.**	
Wheel speed sensor	07.85-03.86	**0 265 001 098**
Wheel speed sensor, front	04.86-12.92	**0 265 001 157**
Wheel speed sensor, rear	07.85-12.92	**0 265 001 158**
25 D	**2,5 l 54 kW M25-660 4 Zyl.**	
Wheel speed sensor	07.82-03.86	**0 265 001 098**
Wheel speed sensor, front	04.86-12.92	**0 265 001 157**
Wheel speed sensor, rear	07.82-12.92	**0 265 001 158**
25 D Turbo	**2,5 l 70 kW M25-648 <CRD93T> 4 Zyl.**	
Wheel speed sensor	04.83-03.86	**0 265 001 098**
Wheel speed sensor, front	04.86-12.86	**0 265 001 157**
Wheel speed sensor, rear	04.83-12.86	**0 265 001 158**
25 D Turbo 2	**2,5 l 78 kW M25-671 4 Zyl.**	
Air flow sensor, diesel	01.87-12.92	**0 281 002 037**
Pulse generator, diesel	01.87-12.92	**0 281 002 030**
Pressure sensor, intake manifold, diesel	01.87-12.92	**0 281 002 018**
Temperature sensor, coolant, diesel	01.87-12.92	**0 280 130 026**
Pedal position sensor, diesel	01.87-12.92	**0 132 009 305**
Wheel speed sensor, front	01.87-12.92	**0 265 001 157**
Wheel speed sensor, rear	01.87-12.92	**0 265 001 158**
25 D Turbo 2	**2,5 l 88 kW M25-669 4 Zyl.**	
Wheel speed sensor, front	01.87-12.92	**0 265 001 157**
Wheel speed sensor, rear	01.87-12.92	**0 265 001 158**
25 Injection	**2,5 l 89-98 kW M25-663 Kat. 4 Zyl.**	
Throttle valve sensor	02.84-05.86	**0 280 120 301**
Wheel speed sensor	02.84-03.86	**0 265 001 098**
Wheel speed sensor, front	04.86-05.86	**0 265 001 157**
Wheel speed sensor, rear	02.84-05.86	**0 265 001 158**
25 Injection	**2,5 l 89-98 kW M25-668 Kat. <EN5L> 4 Zyl.**	
Throttle valve sensor	05.86-12.92	**0 280 120 301**
Air flow sensor, gasoline injection	05.86-12.92	**0 280 202 100**
Temperature sensor, coolant, injection system	05.86-12.92	**0 280 130 026**
Relay, Jetronic	05.86-12.92	**0 280 230 009**
Wheel speed sensor, front	05.86-12.92	**0 265 001 157**
Wheel speed sensor, rear	05.86-12.92	**0 265 001 158**
25 Injection	**2,5 l 96-100 kW M25-659 <EN5L> 4 Zyl.**	
Throttle valve sensor	07.83-12.92	**0 280 120 301**
Air flow sensor, gasoline injection	07.83-12.92	**0 280 202 021**
Temperature sensor, coolant, injection system	07.83-12.92	**0 280 130 026**
Relay, Jetronic	07.83-12.92	**0 280 230 009**
Wheel speed sensor	07.83-03.86	**0 265 001 098**
Wheel speed sensor, front	04.86-12.92	**0 265 001 157**
Wheel speed sensor, rear	07.83-12.92	**0 265 001 158**
25 Injection Turbo	**2,5 l 122-125 kW M25-662 <EN5T> 4 Zyl.**	
Throttle valve sensor	06.84-06.86	**0 280 120 313**
Air flow sensor, gasoline injection	06.84-06.86	**0 280 202 061**
Temperature sensor, coolant, injection system	06.84-06.86	**0 280 130 026**
Relay, Jetronic	06.84-06.86	**0 332 019 151**
Relay, pump	06.84-06.86	**0 280 230 009**

C

Product			
◀ CX			
Wheel speed sensor	06.84-03.86		**0 265 001 098**
Wheel speed sensor, front	04.86-06.86		**0 265 001 157**
Wheel speed sensor, rear	06.84-06.86		**0 265 001 158**
25 Injection Turbo 2	**2,5 l 116 kW M25-667 Kat. <EN5TE> 4 Zyl.**		
Throttle valve sensor	09.86-12.92		**0 280 120 318**
Temperature sensor, coolant, injection system	09.86-12.92		**0 280 130 026**
Relay, Jetronic	09.86-12.92		**0 280 230 009**
Wheel speed sensor, front	09.86-12.92		**0 265 001 157**
Wheel speed sensor, rear	09.86-12.92		**0 265 001 158**
25 Injection Turbo 2	**2,5 l 122 kW M25-662 <EN5TE> 4 Zyl.**		
Wheel speed sensor, front	05.86-12.87		**0 265 001 157**
Wheel speed sensor, rear	05.86-12.87		**0 265 001 158**
25 Injection Turbo 2	**2,5 l 122 kW M25-666 <EN5TE> 4 Zyl.**		
Throttle valve sensor	05.86-12.92		**0 280 120 317**
Air flow sensor, gasoline injection	05.86-12.92		**0 280 202 099**
Temperature sensor, coolant, injection system	05.86-12.92		**0 280 130 026**
Relay, Jetronic	05.86-12.92		**0 280 230 009**
Wheel speed sensor, front	05.86-12.92		**0 265 001 157**
Wheel speed sensor, rear	05.86-12.92		**0 265 001 158**

C1

1.0 i [B0]			**1,0 l 50 kW CFA 3 Zyl.**
Wheel speed sensor, rear	06.05→		**0 265 007 688**
1.4 HDi [B0]			**1,4 l 40 kW 8HT 4 Zyl.**
Wheel speed sensor, rear	06.05→		**0 265 007 688**

C2

1.1 i [A6]			**1,1 l 44 kW HFX 4 Zyl.**
Knock sensor			
Org.no. →9820	09.03-10.03		**0 261 231 128**
Org.no. 9821→	11.03→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	09.03→		**0 261 230 043**
1.4 HDi [A6]			**1,4 l 50 kW 8HX / 8HZ 4 Zyl.**
High-pressure sensor (CR system)	09.03→		**0 281 002 283**
Accelerator pedal module	09.03→	LLE	**0 280 752 251**
1.4 i [A6]			**1,4 l 55 kW KFV 4 Zyl.**
Knock sensor			
Org.no. →9820	09.03-10.03		**0 261 231 128**
Org.no. 9821→	11.03→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	09.03→		**0 261 230 043**
Accelerator pedal module	09.03→	LLE	**0 280 752 251**
1.4 i 16V [A6]			**1,4 l 66 kW KFU 4 Zyl.**
Knock sensor	12.05→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	12.05→		**0 261 230 043**
1.6 i [A6]			**1,6 l 80 kW NFU 4 Zyl.**
Throttle valve assembly	09.03→		**0 280 750 085**
Knock sensor	09.03→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	09.03→		**0 261 230 043**
Accelerator pedal module	09.03→	LLE	**0 280 752 251**
1.6 i VTS [A6]			**1,6 l 90 kW NFS 4 Zyl.**
Throttle valve assembly	10.04→		**0 280 750 085**
Knock sensor	10.04→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	10.04→		**0 261 230 043**
Accelerator pedal module	10.04→	LLE	**0 280 752 251**

C3

1.1 i [A8]			**1,1 l 44 kW HFX 4 Zyl.**
Knock sensor	01.02-08.05		**0 261 231 128**
Pressure sensor, intake manifold, gasoline	01.02-08.05		**0 261 230 043**
1.1 i [A31]			**1,1 l 44 kW HFX 4 Zyl.**
Knock sensor	09.05→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	09.05→		**0 261 230 043**
1.4 HDi [A8]			**1,4 l 50 kW 8HX 4 Zyl.**
High-pressure sensor (CR system)	01.02-08.05		**0 281 002 283**
1.4 HDi 16V [A8]			**1,4 l 66 kW 8HY 4 Zyl.**
Accelerator pedal module	01.02-08.05	LLE	**0 280 752 251**
1.4 i [A8]			**1,4 l 55 kW KFV 4 Zyl.**
Knock sensor	01.02-08.05		**0 261 231 128**
Pressure sensor, intake manifold, gasoline	01.02-08.05		**0 261 230 043**
Accelerator pedal module	01.02-08.05	LLE	**0 280 752 251**
1.4 i [A31]			**1,4 l 54 kW KFV 4 Zyl.**
Knock sensor	09.05→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	09.05→		**0 261 230 043**
1.4 i 16V [A8]			**1,4 l 66 kW KFU 4 Zyl.**
Knock sensor	10.03-08.05		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	10.03-08.05		**0 261 230 043**
Accelerator pedal module	10.03-08.05	LLE	**0 280 752 251**
1.4 i 16V [A31]			**1,4 l 66 kW KFU 4 Zyl.**
Knock sensor	09.05→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	09.05→		**0 261 230 043**
1.6 i [A8]			**1,6 l 80 kW NFU 4 Zyl.**
Throttle valve assembly	01.02-08.05		**0 280 750 085**
Knock sensor			
Org.no. →9428	01.02-09.02		**0 261 231 128**
Org.no. 9429→	10.02-08.05		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	01.02-08.05		**0 261 230 043**
Accelerator pedal module	01.02-08.05	LLE	**0 280 752 251**
1.6 i [A31]			**1,6 l 80 kW NFU 4 Zyl.**
Knock sensor	09.05→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	09.05→		**0 261 230 043**
1.6 16V			**1,6 l 81 kW TU5JP4 4 Zyl.**
Throttle valve assembly	05.03-09.05		**0 280 750 085**
Pressure sensor, intake manifold, gasoline	05.03-09.05		**0 261 230 043**
Accelerator pedal module	05.03-09.05		**0 280 752 251**

C3-Pluriel

1.4 HDi [A42]			**1,4 l 50 kW 8HX / 8HZ 4 Zyl.**
High-pressure sensor (CR system)	10.03→		**0 281 002 283**
1.4 i [A42]			**1,4 l 55 kW KFV 4 Zyl.**
Knock sensor			
Org.no. →9820	05.03-10.03		**0 261 231 128**
Org.no. 9821→	11.03→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	05.03→		**0 261 230 043**
Accelerator pedal module	05.03→	LLE	**0 280 752 251**
1.6 i 16V [A42]			**1,6 l 80 kW NFU 4 Zyl.**
Throttle valve assembly	05.03→		**0 280 750 085**
Knock sensor	05.03→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	05.03→		**0 261 230 043**
Accelerator pedal module	05.03→	LLE	**0 280 752 251**

C4

1.4 i [B5]			**1,4 l 66 kW KFU 4 Zyl.**
Knock sensor	11.04→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	11.04→		**0 261 230 043**
Yaw rate sensor, brake system	11.04→		**0 265 005 606**
Steering angle sensor, ESP (electronic stability program)	11.04→		**0 265 005 486**
Wheel speed sensor, rear	11.04→		**0 265 007 779**

Product		
1.6 HDi [B5]		**1,6 l 66/80 kW 9HX; 9HY/ 9HZ 4 Zyl.**
Yaw rate sensor, brake system	11.04→	**0 265 005 606**
Steering angle sensor, ESP (electronic stability program)	11.04→	**0 265 005 486**
Wheel speed sensor, rear	11.04→	**0 265 007 779**
1.6 i [B5]		**1,6 l 80 kW NFU 4 Zyl.**
Knock sensor	11.04→	**0 261 231 168**
Pressure sensor, intake manifold, gasoline	11.04→	**0 261 230 043**
Yaw rate sensor, brake system	11.04→	**0 265 005 606**
Steering angle sensor, ESP (electronic stability program)	11.04→	**0 265 005 486**
Wheel speed sensor, rear	11.04→	**0 265 007 779**
2.0 HDi [B5]		**2,0 l 100 kW RHR 4 Zyl.**
Yaw rate sensor, brake system	11.04→	**0 265 005 606**
Steering angle sensor, ESP (electronic stability program)	11.04→	**0 265 005 486**
Wheel speed sensor, rear	11.04→	**0 265 007 779**
2.0 i [B5]		**2,0 l 100 kW RFN 4 Zyl.**
Pressure sensor, intake manifold, gasoline	11.04→	**0 261 230 058**
Yaw rate sensor, brake system	11.04→	**0 265 005 606**
Steering angle sensor, ESP (electronic stability program)	11.04→	**0 265 005 486**
Wheel speed sensor, rear	11.04→	**0 265 007 779**
2.0 i [B5]		**2,0 l 103 kW RFJ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	11.04→	**0 261 230 043**
Yaw rate sensor, brake system	11.04→	**0 265 005 606**
Steering angle sensor, ESP (electronic stability program)	11.04→	**0 265 005 486**
Wheel speed sensor, rear	11.04→	**0 265 007 779**

C4 Coupé

1.4 i [B5]		**1,4 l 66 kW KFU 4 Zyl.**
Knock sensor	11.04→	**0 261 231 168**
Pressure sensor, intake manifold, gasoline	11.04→	**0 261 230 043**
Yaw rate sensor, brake system	11.04→	**0 265 005 606**
Steering angle sensor, ESP (electronic stability program)	11.04→	**0 265 005 486**
Wheel speed sensor, rear	11.04→	**0 265 007 779**
1.6 HDi [B5]		**1,6 l 66/80 kW 9HX; 9HY/ 9HZ 4 Zyl.**
Yaw rate sensor, brake system	11.04→	**0 265 005 606**
Steering angle sensor, ESP (electronic stability program)	11.04→	**0 265 005 486**
Wheel speed sensor, rear	11.04→	**0 265 007 779**
1.6 i [B5]		**1,6 l 80 kW NFU 4 Zyl.**
Knock sensor	11.04→	**0 261 231 168**
Pressure sensor, intake manifold, gasoline	11.04→	**0 261 230 043**
Yaw rate sensor, brake system	11.04→	**0 265 005 606**
Steering angle sensor, ESP (electronic stability program)	11.04→	**0 265 005 486**
Wheel speed sensor, rear	11.04→	**0 265 007 779**
2.0 HDi [B5]		**2,0 l 100 kW RHR 4 Zyl.**
Yaw rate sensor, brake system	11.04→	**0 265 005 606**
Steering angle sensor, ESP (electronic stability program)	11.04→	**0 265 005 486**
Wheel speed sensor, rear	11.04→	**0 265 007 779**
2.0 i [B5]		**2,0 l 100 kW RFN 4 Zyl.**
Pressure sensor, intake manifold, gasoline	11.04→	**0 261 230 058**
Yaw rate sensor, brake system	11.04→	**0 265 005 606**
Steering angle sensor, ESP (electronic stability program)	11.04→	**0 265 005 486**
Wheel speed sensor, rear	11.04→	**0 265 007 779**

Product		
2.0 i [B5]		**2,0 l 103/130 kW RFJ; RFK 4 Zyl.**
Pressure sensor, intake manifold, gasoline	11.04→	**0 261 230 043**
Yaw rate sensor, brake system	11.04→	**0 265 005 606**
Steering angle sensor, ESP (electronic stability program)	11.04→	**0 265 005 486**
Wheel speed sensor, rear	11.04→	**0 265 007 779**

C4 Grand Picasso

1.6 HDi [B58]		**1,6 l 80 kW 9HZ 4 Zyl.**
Yaw rate sensor, brake system	10.06→	**0 265 005 715**
Steering angle sensor, ESP (electronic stability program)	10.06→	**0 265 005 486**
Wheel speed sensor, front	10.06→	**0 265 007 788**
Wheel speed sensor, rear	10.06→	**0 265 007 789**
1.8 i [B58]		**1,8 l 92 kW 6FY 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.06→	**0 261 230 043**
Yaw rate sensor, brake system	10.06→	**0 265 005 715**
Steering angle sensor, ESP (electronic stability program)	10.06→	**0 265 005 486**
Wheel speed sensor, front	10.06→	**0 265 007 788**
Wheel speed sensor, rear	10.06→	**0 265 007 789**
2.0 HDi [B58]		**2,0 l 100 kW RHR 4 Zyl.**
Yaw rate sensor, brake system	10.06→	**0 265 005 715**
Steering angle sensor, ESP (electronic stability program)	10.06→	**0 265 005 486**
Wheel speed sensor, front	10.06→	**0 265 007 788**
Wheel speed sensor, rear	10.06→	**0 265 007 789**
2.0 i [B58]		**2,0 l 103 kW RFJ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.06→	**0 261 230 043**
Yaw rate sensor, brake system	10.06→	**0 265 005 715**
Steering angle sensor, ESP (electronic stability program)	10.06→	**0 265 005 486**
Wheel speed sensor, front	10.06→	**0 265 007 788**
Wheel speed sensor, rear	10.06→	**0 265 007 789**

C4 Picasso

1.6 HDi [B58]		**1,6 l 80 kW 9HZ 4 Zyl.**
Yaw rate sensor, brake system	02.07→	**0 265 005 715**
Steering angle sensor, ESP (electronic stability program)	02.07→	**0 265 005 486**
Wheel speed sensor, front	02.07→	**0 265 007 788**
Wheel speed sensor, rear	02.07→	**0 265 007 789**
1.8 i [B58]		**1,8 l 92 kW 6FY 4 Zyl.**
Pressure sensor, intake manifold, gasoline	02.07→	**0 261 230 043**
Yaw rate sensor, brake system	02.07→	**0 265 005 715**
Steering angle sensor, ESP (electronic stability program)	02.07→	**0 265 005 486**
Wheel speed sensor, front	02.07→	**0 265 007 788**
Wheel speed sensor, rear	02.07→	**0 265 007 789**
2.0 HDi [B58]		**2,0 l 100 kW RHR 4 Zyl.**
Yaw rate sensor, brake system	02.07→	**0 265 005 715**
Steering angle sensor, ESP (electronic stability program)	02.07→	**0 265 005 486**
Wheel speed sensor, front	02.07→	**0 265 007 788**
Wheel speed sensor, rear	02.07→	**0 265 007 789**
2.0 i [B58]		**2,0 l 103 kW RFJ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	02.07→	**0 261 230 043**
Yaw rate sensor, brake system	02.07→	**0 265 005 715**
Steering angle sensor, ESP (electronic stability program)	02.07→	**0 265 005 486**

Product			

◀ C4 Picasso

Wheel speed sensor, front	02.07→		**0 265 007 788**
Wheel speed sensor, rear	02.07→		**0 265 007 789**

C5

1.6 HDi [X7]			**1,6 l 80 kW 9HY/9HZ 4 Zyl.**
Accelerator pedal module	10.04→	LLE,OTT	**0 280 752 241**
		OTT,RLE	**0 280 752 242**
1.8 i [X7]			**1,8 l 85/92 kW 6FY; 6FZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.04→		**0 261 230 043**
Accelerator pedal module	10.04→	LLE,OTT	**0 280 752 241**
		OTT,RLE	**0 280 752 242**
1.8 i 16V [X4]			**1,8 l 85 kW 6FZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.01-09.04		**0 261 230 057**
2.0 HDi [X4]			**2,0 l 66/79/80 kW RHS; RHY; RHZ 4 Zyl.**
High-pressure sensor (CR system)	03.01-09.04		**0 281 002 283**
2.0 HDi [X7]			**2,0 l 100 kW RHR / RHL 4 Zyl.**
Accelerator pedal module	10.04→	LLE,OTT	**0 280 752 241**
		OTT,RLE	**0 280 752 242**
2.0 HPi [X4]			**2,0 l 103 kW RLZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.01-09.04		**0 261 230 058**
2.0 i [X7]			**2,0 l 103 kW RFJ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.04→		**0 261 230 043**
Accelerator pedal module	10.04→	LLE,OTT	**0 280 752 241**
		OTT,RLE	**0 280 752 242**
2.0 i 16V [X4]			**2,0 l 100 kW RFN 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.01-09.04		**0 261 230 057**
2.2 HDi [X4]			**2,2 l 98 kW 4HX 4 Zyl.**
High-pressure sensor (CR system)	03.01-09.04		**0 281 002 283**
2.2 HDi [X7]			**2,2 l 98/125 kW 4H ...; 4HX 4 Zyl.**
Accelerator pedal module	10.04→	LLE,OTT	**0 280 752 241**
		OTT,RLE	**0 280 752 242**
3.0 i [X4]			**3,0 l 150 kW XFX 6 Zyl.**
Throttle valve assembly	03.01-09.04		**0 280 750 041**
Knock sensor	03.01-09.04	KZB	**0 261 231 130**
		KZG	**0 261 231 071**
Pressure sensor, intake manifold, gasoline	03.01-09.04		**0 261 230 058**
3.0 i [X7]			**3,0 l 155 kW XFU 6 Zyl.**
Throttle valve assembly	10.04→		**0 280 750 041**
Pressure sensor, intake manifold, gasoline	10.04→		**0 261 230 058**
Accelerator pedal module	10.04→	LLE,OTT	**0 280 752 241**
		OTT,RLE	**0 280 752 242**

C5 Break

1.6 HDi [X7]			**1,6 l 80 kW 9HY/9HZ 4 Zyl.**
Accelerator pedal module	10.04→	LLE,OTT	**0 280 752 241**
		OTT,RLE	**0 280 752 242**
1.8 i [X7]			**1,8 l 85/92 kW 6FY; 6FZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.04→		**0 261 230 043**
Accelerator pedal module	10.04→	LLE,OTT	**0 280 752 241**
		OTT,RLE	**0 280 752 242**
1.8 i 16V [X4]			**1,8 l 85 kW 6FZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	06.01-09.04		**0 261 230 057**
2.0 HDi [X4]			**2,0 l 66/79/80 kW RHS; RHY; RHZ 4 Zyl.**
High-pressure sensor (CR system)	06.01-09.04		**0 281 002 283**
2.0 HDi [X7]			**2,0 l 100 kW RHR / RHL 4 Zyl.**
Accelerator pedal module	10.04→	LLE,OTT	**0 280 752 241**
		OTT,RLE	**0 280 752 242**
2.0 HPi [X4]			**2,0 l 103 kW RLZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	06.01-09.04		**0 261 230 058**
2.0 i [X7]			**2,0 l 103 kW RFJ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.04→		**0 261 230 043**

Product			

Accelerator pedal module	10.04→	LLE,OTT	**0 280 752 241**
		OTT,RLE	**0 280 752 242**
2.0 i 16V [X4]			**2,0 l 100 kW RFN 4 Zyl.**
Pressure sensor, intake manifold, gasoline	06.01-09.04		**0 261 230 057**
2.2 HDi [X4]			**2,2 l 98 kW 4HX 4 Zyl.**
High-pressure sensor (CR system)	06.01-09.04		**0 281 002 283**
2.2 HDi [X7]			**2,2 l 98/125 kW 4H ...; 4HX 4 Zyl.**
Accelerator pedal module	10.04→	LLE,OTT	**0 280 752 241**
		OTT,RLE	**0 280 752 242**
3.0 i [X4]			**3,0 l 150 kW XFX 6 Zyl.**
Throttle valve assembly	06.01-09.04		**0 280 750 041**
Knock sensor	06.01-09.04	KZB	**0 261 231 130**
		KZG	**0 261 231 071**
Pressure sensor, intake manifold, gasoline	06.01-09.04		**0 261 230 058**
3.0 i [X7]			**3,0 l 155 kW XFU 6 Zyl.**
Throttle valve assembly	10.04→		**0 280 750 041**
Pressure sensor, intake manifold, gasoline	10.04→		**0 261 230 058**
Accelerator pedal module	10.04→	LLE,OTT	**0 280 752 241**
		OTT,RLE	**0 280 752 242**

C6

2.2 HDi [X6]			**2,2 l 125 kW 4HT 4 Zyl.**
Accelerator pedal module	06.06→	LLE,OTT	**0 280 752 241**
		OTT,RLE	**0 280 752 242**
2.7 HDi [X6]			**2,7 l 150 kW UHZ 6 Zyl.**
Accelerator pedal module	11.05→	LLE,OTT	**0 280 752 241**
		OTT,RLE	**0 280 752 242**
3.0 i [X6]			**3,0 l 155 kW XFV 6 Zyl.**
Throttle valve assembly	11.05→		**0 280 750 041**
Knock sensor	11.05→	KZB	**0 261 231 130**
		KZG	**0 261 231 071**
Pressure sensor, intake manifold, gasoline	11.05→		**0 261 230 058**
Accelerator pedal module	11.05→	LLE,OTT	**0 280 752 241**
		OTT,RLE	**0 280 752 242**

C8

2.0 HDi [V3]			**2,0 l 81 kW RHT/RHM; RHW 4 Zyl.**
High-pressure sensor (CR system)	06.02→		**0 281 002 283**
Yaw rate sensor, brake system	06.02→		**0 265 005 290**
Wheel speed sensor, front	06.02→	LAB	**0 265 007 083**
		RAB	**0 265 007 084**
2.0 HDi [V3]			**2,0 l 88/100 kW RHK; RHR 4 Zyl.**
Yaw rate sensor, brake system	03.06→		**0 265 005 606**
Wheel speed sensor, front	03.06→	LAB	**0 265 007 083**
		RAB	**0 265 007 084**
2.0 i 16V [V3]			**2,0 l 100 kW RFN 4 Zyl.**
Pressure sensor, intake manifold, gasoline	06.02→		**0 261 230 058**
Yaw rate sensor, brake system	06.02→		**0 265 005 290**
Wheel speed sensor, front	06.02→	LAB	**0 265 007 083**
		RAB	**0 265 007 084**
2.0 i 16V [V3]			**2,0 l 103 kW RFJ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.05→		**0 261 230 043**
Yaw rate sensor, brake system	10.05→		**0 265 005 606**
Wheel speed sensor, front	10.05→	LAB	**0 265 007 083**
		RAB	**0 265 007 084**
2.2 HDi [V3]			**2,2 l 94 kW 4HW 4 Zyl.**
High-pressure sensor (CR system)	06.02→		**0 281 002 283**
Yaw rate sensor, brake system	06.02→		**0 265 005 290**
Wheel speed sensor, front	06.02→	LAB	**0 265 007 083**
		RAB	**0 265 007 084**

Product

2.2 i 16V [V3]			**2,2 l 116 kW 3FZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	06.02→		**0 261 230 057**
Yaw rate sensor, brake system	06.02→		**0 265 005 290**
Wheel speed sensor, front	06.02→	LAB	**0 265 007 083**
		RAB	**0 265 007 084**
3.0 i [V3]			**2,9 l 150 kW XFW 6 Zyl.**
Throttle valve assembly	10.02→		**0 280 750 041**
Pressure sensor, intake manifold, gasoline	10.02→		**0 261 230 058**
Yaw rate sensor, brake system	10.02→		**0 265 005 290**
Wheel speed sensor, front	10.02→	LAB	**0 265 007 083**
		RAB	**0 265 007 084**

Evasion

1.8 i [U60]			**1,8 l 72-74 kW LFW 4 Zyl.**
Wheel speed sensor, front			
Org.no. 7481→	06.97-07.02		**0 265 006 388**
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97		**0 265 006 426**
Org.no. 7602→	10.97-07.02		**0 265 006 504**
1.9 D Turbo [U60]			**1,9 l 66/67-68 kW DHX; D8B 4 Zyl.**
Wheel speed sensor, front			
Org.no. 7481→	06.97-07.02		**0 265 006 388**
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97		**0 265 006 426**
Org.no. 7602→	10.97-07.02		**0 265 006 504**
2.0 HDi [U60]			**2,0 l 80/81 kW RHW; RHZ 4 Zyl.**
High-pressure sensor (CR system)	01.99-07.02		**0 281 002 283**
Wheel speed sensor, front	01.99-07.02		**0 265 006 388**
Wheel speed sensor, rear	01.99-07.02		**0 265 006 504**
2.0 i [U60]			**2,0 l 89-90 kW RFU 4 Zyl.**
Knock sensor			
Org.no. →8133	06.94-02.99		**0 261 231 071**
Org.no. 8134→	03.99-07.02		**0 261 231 130**
Wheel speed sensor, front			
Org.no. 7481→	06.97-07.02		**0 265 006 388**
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97		**0 265 006 426**
Org.no. 7602→	10.97-07.02		**0 265 006 504**
2.0 i Turbo [U60]			**2,0 l 108-110 kW RGX 4 Zyl.**
Throttle valve sensor			
Org.no. →6778	06.94-06.95		**0 280 122 001**
Org.no. 6779→	07.95-07.02		**0 280 122 003**
Knock sensor			
Org.no. →8133	06.94-02.99		**0 261 231 071**
Org.no. 8134→	03.99-07.02		**0 261 231 130**
Wheel speed sensor, front			
Org.no. 7481→	06.97-07.02		**0 265 006 388**
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97		**0 265 006 426**
Org.no. 7602→	10.97-07.02		**0 265 006 504**
2.0 i 16V [U60]			**2,0 l 97-99 kW RFV 4 Zyl.**
Throttle valve sensor	05.98-04.00		**0 280 122 003**
Knock sensor			
Org.no. →8133	05.98-02.99		**0 261 231 109**
Org.no. 8134→	03.99-04.00	EFV	**0 261 231 130**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	05.98-12.98		**0 261 230 012**
Org.no. 8057→	01.99-04.00		**0 261 230 034**
Wheel speed sensor, front	05.98-04.00		**0 265 006 388**
Wheel speed sensor, rear	05.98-04.00		**0 265 006 504**

Product

2.0 i 16V [U60]			**2,0 l 100 kW RFN 4 Zyl.**
Pressure sensor, intake manifold, gasoline	04.00-07.02		**0 261 230 057**
Wheel speed sensor, front	04.00-07.02		**0 265 006 388**
Wheel speed sensor, rear	04.00-07.02		**0 265 006 504**
2.1 D Turbo [U60]			**2,1 l 80-81 kW P8C 4 Zyl.**
Temperature sensor, intake air, diesel	04.96-07.02		**0 280 130 039**
Wheel speed sensor, front			
Org.no. 7481→	06.97-07.02		**0 265 006 388**
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97		**0 265 006 426**
Org.no. 7602→	10.97-07.02		**0 265 006 504**

Jumper

1.9 D [23]			**1,9 l 51 kW DJY; D9B 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 15445358→	02.94-04.00		**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 15445358→	02.94-02.02	LAB	**0 265 006 405**
		RAB	**0 265 006 406**
1.9 D Turbo [23]			**1,9 l 66-68 kW DHX; D8C 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 15445358→	02.94-04.00		**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 15445358→	02.94-02.02	LAB	**0 265 006 405**
		RAB	**0 265 006 406**
2.0 [23]			**2,0 l 79 kW R5B 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 15445358→	02.94-04.00		**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 15445358→	02.94-02.02	LAB	**0 265 006 405**
		RAB	**0 265 006 406**
2.0 HDi [U5]			**2,0 l 62 kW RHV 4 Zyl.**
High-pressure sensor (CR system)	02.02→		**0 281 002 283**
2.0 HDi [23]			**2,0 l 62 kW RHV 4 Zyl.**
High-pressure sensor (CR system)	03.01-02.02		**0 281 002 283**
Wheel speed sensor, rear			
Fg.no. 15445358→	03.01-02.02	LAB	**0 265 006 405**
		RAB	**0 265 006 406**
2.0 i [23]			**2,0 l 80 kW RFW 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 15445358→	02.94-04.00		**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 15445358→	02.94-02.02	LAB	**0 265 006 405**
		RAB	**0 265 006 406**
2.2 HDi [U5]			**2,2 l 77 kW 4HY 4 Zyl.**
High-pressure sensor (CR system)	02.02→		**0 281 002 283**
2.5 D [23]			**2,5 l 63 kW T9A 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 15445358→	02.94-04.00		**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 15445358→	02.94-02.02	LAB	**0 265 006 405**
		RAB	**0 265 006 406**
2.5 D Turbo [23]			**2,5 l 76 kW THZ; T8A 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 15445358→	02.94-04.00		**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 15445358→	02.94-02.02	LAB	**0 265 006 405**
		RAB	**0 265 006 406**
2.5 TDi [23]			**2,5 l 79 kW THX 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 15445358→	10.96-04.00		**0 265 006 427**

C

Product			
◀ Jumper			
Wheel speed sensor, rear			
Fg.no. 15445358→	10.96-02.02	LAB	**0 265 006 405**
		RAB	**0 265 006 406**
2.8 D [23]		**2,8 l 64 kW 8140 63 4 Zyl.**	
Wheel speed sensor, front			
Fg.no. 15445358→	01.99-04.00		**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 15445358→	01.99-02.02	LAB	**0 265 006 405**
		RAB	**0 265 006 406**
2.8 D Turbo [23]		**2,8 l 90 kW 8140 43 4 Zyl.**	
Wheel speed sensor, front			
Fg.no. 15445358→	10.99-04.00		**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 15445358→	10.99-02.02	LAB	**0 265 006 405**
		RAB	**0 265 006 406**
2.8 HDi [U5]		**2,8 l 94/107 kW 8140 43s 4 Zyl.**	
Air flow sensor, diesel	02.02→		**0 281 002 184**
2.8 HDi [23]		**2,8 l 94 kW 8140 43s 4 Zyl.**	
Air flow sensor, diesel	09.00-02.02		**0 281 002 184**
Wheel speed sensor, rear			
Fg.no. 15445358→	09.00-02.02	LAB	**0 265 006 405**
		RAB	**0 265 006 406**
2.8 HDI		**2,8 l 93 kW 8140 43s 4 Zyl.**	
Speed sensor, diesel	09.05→		**0 281 002 332**
Boost pressure sensor, Diesel	09.05→		**0 281 002 514**
Temperature sensor, coolant, diesel	09.05→		**0 281 002 170**

Jumpy

1.6 HDi [G9]		**1,6 l 66 kW 9HU 4 Zyl.**	
Yaw rate sensor, brake system	02.07→		**0 265 005 606**
Wheel speed sensor, front	02.07→		**0 265 007 790**
Wheel speed sensor, rear	02.07→		**0 265 007 791**
1.6 i [U64]		**1,6 l 58 kW 220 A2.000 4 Zyl.**	
Temperature sensor, coolant, injection system	10.95→		**0 280 130 026**
Wheel speed sensor, front			
Org.no. 7481→9050	06.97-08.01		**0 265 006 388**
Org.no. 9051→	09.01→		**0 265 006 730**
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97		**0 265 006 426**
Org.no. 7602→9050	10.97-08.01		**0 265 006 504**
Org.no. 9051→	09.01→		**0 265 006 731**
1.9 D [U64]		**1,9 l 50-52 kW D9B 4 Zyl.**	
Wheel speed sensor, front			
Org.no. 7481→9050	06.97-08.01		**0 265 006 388**
Org.no. 9051→	09.01→		**0 265 006 730**
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97		**0 265 006 426**
Org.no. 7602→9050	10.97-08.01		**0 265 006 504**
Org.no. 9051→	09.01→		**0 265 006 731**
1.9 D [U64]		**1,9 l 51 kW WJZ 4 Zyl.**	
Wheel speed sensor, front	10.98-08.01		**0 265 006 388**
Wheel speed sensor, rear	10.98-08.01		**0 265 006 504**
1.9 D [U64]		**1,9 l 52 kW WJY 4 Zyl.**	
Wheel speed sensor, front	09.01→		**0 265 006 730**
Wheel speed sensor, rear	09.01→		**0 265 006 731**
1.9 D Turbo [U64]		**1,9 l 66/67-68 kW DHX; D8B 4 Zyl.**	
Wheel speed sensor, front			
Org.no. 7481→9050	06.97-08.01		**0 265 006 388**
Org.no. 9051→	09.01→		**0 265 006 730**
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97		**0 265 006 426**
Org.no. 7602→9050	10.97-08.01		**0 265 006 504**
Org.no. 9051→	09.01→		**0 265 006 731**
2.0 HDi [G9]		**2,0 l 88/100 kW RHK; RHR 4 Zyl.**	
Yaw rate sensor, brake system	02.07→		**0 265 005 606**
Wheel speed sensor, front	02.07→		**0 265 007 790**
Wheel speed sensor, rear	02.07→		**0 265 007 791**
2.0 HDi [U64]		**2,0 l 70/80/81 kW RHW; RHX; RHZ 4 Zyl.**	
High-pressure sensor (CR system)	10.99→		**0 281 002 283**
Wheel speed sensor, front			
Org.no. →9050	10.99-08.01		**0 265 006 388**
Org.no. 9051→	09.01→		**0 265 006 730**
Wheel speed sensor, rear			
Org.no. →9050	10.99-08.01		**0 265 006 504**
Org.no. 9051→	09.01→		**0 265 006 731**
2.0 i [U64]		**2,0 l 100 kW RFN 4 Zyl.**	
Pressure sensor, intake manifold, gasoline	04.00→		**0 261 230 057**
Wheel speed sensor, front			
Org.no. →9050	04.00-08.01		**0 265 006 388**
Org.no. 9051→	09.01→		**0 265 006 730**
Wheel speed sensor, rear			
Org.no. →9050	04.00-08.01		**0 265 006 504**
Org.no. 9051→	09.01→		**0 265 006 731**
2.0 i 16V [G9]		**2,0 l 103 kW RFJ 4 Zyl.**	
Pressure sensor, intake manifold, gasoline	02.07→		**0 261 230 043**
Yaw rate sensor, brake system	02.07→		**0 265 005 606**
Wheel speed sensor, front	02.07→		**0 265 007 790**
Wheel speed sensor, rear	02.07→		**0 265 007 791**

Saxo

1.1 i [S8]		**1,1 l 44 kW HFX 4 Zyl.**	
Pressure sensor, intake manifold, gasoline	03.00-09.03		**0 261 230 043**
1.4 i [S8]		**1,4 l 55 kW KFW 4 Zyl.**	
Pressure sensor, intake manifold, gasoline	06.00-09.03		**0 261 230 043**
1.4 i [S8]		**1,4 l 55 kW KFX 4 Zyl.**	
Knock sensor			
Org.no. 7756→	02.98-09.03	GS,IF4	**0 261 231 128**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	02.96-12.98		**0 261 230 012**
Org.no. 8057→	01.99-09.03		**0 261 230 057**
1.6 i [S8]		**1,6 l 65-66 kW NFZ 4 Zyl.**	
Throttle valve sensor	02.96-09.03	AG	**0 280 122 011**
Org.no. →7874	02.96-06.98	GS	**0 280 122 003**
Knock sensor			
Org.no. 7875→	06.98-09.03	GS	**0 261 231 128**
Pressure sensor, intake manifold, gasoline	02.96-09.03	AG	**0 261 230 004**
Org.no. →7874	02.96-06.98	GS	**0 261 230 004**
Org.no. 7875→8056	07.98-12.98	GS	**0 261 230 012**
Org.no. 8057→	01.99-09.03	GS	**0 261 230 057**
Temperature sensor, intake air, injection system	02.96-09.03	AG	**0 280 130 039**
Org.no. →7874	02.96-06.98	GS	**0 280 130 039**
1.6 i [S8]		**1,6 l 74 kW NFT 4 Zyl.**	
Knock sensor			
Org.no. →9456	06.00-10.02		**0 261 231 128**
Org.no. 9457→	11.02-09.03		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	06.00-09.03		**0 261 230 043**
1.6 i 16V [S8]		**1,6 l 87-88 kW NFX 4 Zyl.**	
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	07.96-12.98		**0 261 230 012**
Org.no. 8057→	01.99-09.03		**0 261 230 057**

C

Product

Visa

1.6 i [VD]			**1,6 l 76/83 kW B6D; 180A 4 Zyl.**
Throttle valve sensor	01.85-03.91		**0 280 120 327**
Air flow sensor, gasoline injection	01.85-03.91		**0 280 202 056**
			0 986 280 028
Temperature sensor, coolant, injection system	01.85-03.91		**0 280 130 026**
Relay, Jetronic	01.85-03.91		**0 280 230 006**

Xantia

1.8 i [X1]			**1,8 l 66 kW LFX 4 Zyl.**
Pressure sensor, intake manifold, gasoline	04.97-01.98		**0 261 230 012**
1.8 i [X1]			**1,8 l 70-71/74-76 kW LFZ Kat.; L6A 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.93-01.98	BO	**0 261 230 004**
1.8 i [X2]			**1,8 l 66 kW LFX 4 Zyl.**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	10.97-12.98		**0 261 230 012**
Org.no. 8057→	01.99-12.01		**0 261 230 057**
1.8 i 16V [X1]			**1,8 l 81 kW LFY Kat. 4 Zyl.**
Knock sensor	05.95-01.98	BO	**0 261 231 109**
Pressure sensor, intake manifold, gasoline	05.95-01.98		**0 261 230 012**
1.8 i 16V [X2]			**1,8 l 81 kW LFY 4 Zyl.**
Throttle valve sensor	12.97-12.01		**0 280 122 003**
Knock sensor	12.97-12.01	BO	**0 261 231 109**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	12.97-12.98		**0 261 230 012**
Org.no. 8057→	01.99-12.01		**0 261 230 057**
2.0 HDi [X2]			**2,0 l 66 kW RHY 4 Zyl.**
High-pressure sensor (CR system)	03.99-12.01		**0 281 002 283**
2.0 i [X1]			**2,0 l 89-90/91-92 kW RFX Kat.; R6D 4 Zyl.**
Knock sensor	03.93-01.98		**0 261 231 071**
2.0 i [X2]			**2,0 l 89-90 kW RFX 4 Zyl.**
Knock sensor	12.97-12.01	KZG	**0 261 231 071**
2.0 i Turbo [X1]			**2,0 l 108-110 kW RGX 4 Zyl.**
Throttle valve sensor	05.95-01.98		**0 280 122 003**
Knock sensor	05.95-01.98		**0 261 231 071**
2.0 i Turbo [X2]			**2,0 l 108-110 kW RGX 4 Zyl.**
Throttle valve sensor	12.97-12.01		**0 280 122 003**
Knock sensor			
Org.no. →8133	12.97-02.99		**0 261 231 071**
Org.no. 8134→	03.99-12.01		**0 261 231 130**
2.0 i 16V [X1]			**2,0 l 97 kW RFV 4 Zyl.**
Throttle valve sensor	12.94-01.98		**0 280 122 003**
Knock sensor	12.94-01.98		**0 261 231 109**
2.0 i 16V [X1]			**2,0 l 110-114 kW RFY, RFT 4 Zyl.**
Throttle valve sensor	03.93-12.98		**0 280 122 001**
Knock sensor	03.93-12.98		**0 261 231 071**
2.0 i 16V [X2]			**2,0 l 97 kW RFV 4 Zyl.**
Throttle valve sensor	12.97-12.01	AG	**0 280 122 005**
		GS	**0 280 122 003**
Knock sensor	12.97-12.01		**0 261 231 045**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	12.97-12.98		**0 261 230 012**
Org.no. 8057→	01.99-12.01		**0 261 230 034**
2.1 D Turbo [X1]			**2,1 l 80-81 kW P8C 4 Zyl.**
Temperature sensor, intake air, diesel	05.95-01.98		**0 280 130 039**
Pedal position sensor, diesel			
Org.no. →6992	05.95-01.96		**0 205 001 015**
2.1 D Turbo [X2]			**2,1 l 80-81 kW P8C 4 Zyl.**
Temperature sensor, intake air, injection system	12.97-12.01		**0 280 130 039**

Product

3.0 i [X1]			**3,0 l 140 kW XFZ 6 Zyl.**
Throttle valve sensor	10.96-01.98		**0 280 122 009**
Knock sensor	10.96-01.98		**0 261 231 125**
Pressure sensor, intake manifold, gasoline	10.96-01.98		**0 261 230 012**
3.0 i [X2]			**3,0 l 140 kW XFZ 6 Zyl.**
Throttle valve sensor	12.97-12.01		**0 280 122 009**
Knock sensor	12.97-12.01		**0 261 231 125**
Pressure sensor, intake manifold, gasoline			
Org.no. →8077	12.97-01.99		**0 261 230 012**
Org.no. 8078→	02.99-12.01		**0 261 230 034**

Xantia Break

1.8 i [X1]			**1,8 l 66 kW LFX 4 Zyl.**
Pressure sensor, intake manifold, gasoline	04.97-01.98		**0 261 230 012**
1.8 i [X1]			**1,8 l 70-71/74-76 kW LFZ Kat.; L6A 4 Zyl.**
Pressure sensor, intake manifold, gasoline	09.95-01.98	BO	**0 261 230 004**
1.8 i [X2]			**1,8 l 66 kW LFX 4 Zyl.**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	12.97-12.98		**0 261 230 012**
Org.no. 8057→	01.99-12.01		**0 261 230 057**
1.8 i 16V [X1]			**1,8 l 81 kW LFY Kat. 4 Zyl.**
Knock sensor	04.97-01.98	BO	**0 261 231 109**
Pressure sensor, intake manifold, gasoline	04.97-01.98		**0 261 230 012**
1.8 i 16V [X2]			**1,8 l 81 kW LFY 4 Zyl.**
Throttle valve sensor	12.97-12.01		**0 280 122 003**
Knock sensor	12.97-12.01	BO	**0 261 231 109**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	12.97-12.98		**0 261 230 012**
Org.no. 8057→	01.99-12.01		**0 261 230 057**
2.0 HDi [X2]			**2,0 l 66 kW RHY 4 Zyl.**
High-pressure sensor (CR system)	03.99-12.01		**0 281 002 283**
2.0 i [X1]			**2,0 l 89-90/91-92 kW RFX Kat.; R6D 4 Zyl.**
Knock sensor	09.95-01.98		**0 261 231 071**
2.0 i Turbo [X1]			**2,0 l 108-110 kW RGX 4 Zyl.**
Throttle valve sensor	09.95-01.98		**0 280 122 003**
Knock sensor	09.95-01.98		**0 261 231 071**
2.0 i Turbo [X2]			**2,0 l 108-110 kW RGX 4 Zyl.**
Throttle valve sensor	12.97-12.01		**0 280 122 003**
Knock sensor			
Org.no. →8133	12.97-02.99		**0 261 231 071**
Org.no. 8134→	03.99-12.01		**0 261 231 130**
2.0 i 16V [X1]			**2,0 l 97 kW RFV 4 Zyl.**
Throttle valve sensor	09.95-01.98		**0 280 122 003**
Knock sensor	09.95-01.98		**0 261 231 109**
2.0 i 16V [X2]			**2,0 l 97 kW RFV 4 Zyl.**
Throttle valve sensor	12.97-12.01	AG	**0 280 122 005**
		GS	**0 280 122 003**
Knock sensor	12.97-12.01		**0 261 231 045**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	12.97-12.98		**0 261 230 012**
Org.no. 8057→	01.99-12.01		**0 261 230 034**
2.1 D Turbo [X1]			**2,1 l 80-81 kW P8C 4 Zyl.**
Temperature sensor, intake air, diesel	06.96-01.98		**0 280 130 039**
2.1 D Turbo [X2]			**2,1 l 80-81 kW P8C 4 Zyl.**
Temperature sensor, intake air, injection system	12.97-12.01		**0 280 130 039**
3.0 i [X2]			**3,0 l 140 kW XFZ 6 Zyl.**
Throttle valve sensor	01.98-12.01		**0 280 122 009**
Knock sensor	01.98-12.01		**0 261 231 125**
Pressure sensor, intake manifold, gasoline			
Org.no. →8077	01.98-01.99		**0 261 230 012**
Org.no. 8078→	02.99-12.01		**0 261 230 034**

C

Product			

XM

2.0 i [Y3]			**2,0 l 79-81 kW RDZ Kat. 4 Zyl.**
Temperature sensor, intake air, injection system	05.89-06.94		**0 280 130 039**
2.0 i [Y3]			**2,0 l 89-90 kW RFZ Kat. <XU10J2Z> 4 Zyl.**
Throttle valve sensor	05.89-06.94		**0 280 122 001**
Pressure sensor, intake manifold, gasoline			
Org.no. 6020→	04.93-06.94	BO	**0 261 230 004**
Temperature sensor, intake air, injection system	05.89-06.94		**0 280 130 039**
Temperature sensor, coolant, injection system			
Org.no. 5714→	07.92-06.94	BO	**0 280 130 026**
2.0 i [Y3]			**2,0 l 90-96 kW R6A <XU10J2K> 4 Zyl.**
Throttle valve sensor	05.89-06.94	AG	**0 280 120 323**
Org.no. →4935	05.89-05.90	GS	**0 280 120 323**
Air flow sensor, gasoline injection	05.89-06.94		**0 280 202 118**
			0 986 280 057
Pressure sensor, intake manifold, gasoline			
Org.no. 6020→	04.93-06.94	BO	**0 261 230 004**
Temperature sensor, intake air, injection system	05.89-06.94		**0 280 130 039**
Temperature sensor, coolant, injection system			
Org.no. 5714→	07.92-06.94	BO	**0 280 130 026**
2.0 i [Y4]			**2,0 l 90-96 kW R6A <XU10J2> 4 Zyl.**
Air flow sensor, gasoline injection	07.94-10.00		**0 280 202 118**
			0 986 280 057
Temperature sensor, intake air, injection system	07.94-10.00		**0 280 130 039**
2.0 i Turbo [Y3]			**2,0 l 104-107 kW RGY <XU10J2TE/Z> 4 Zyl.**
Throttle valve sensor	09.92-06.94		**0 280 122 001**
Knock sensor	09.92-06.94		**0 261 231 109**
2.0 i Turbo [Y4]			**2,0 l 108 kW RGX <XU10J2TE> 4 Zyl.**
Throttle valve sensor			
Org.no. →6778	04.95-11.97		**0 280 122 001**
Org.no. 6779→	12.97-10.00		**0 280 122 003**
Knock sensor			
Org.no. →8133	04.95-02.99		**0 261 231 109**
Org.no. 8134→	03.99-10.00		**0 261 231 130**
2.0 i Turbo [Y4]			**2,0 l 108-110 kW RGY <XU10J2TE> 4 Zyl.**
Throttle valve sensor	07.94-09.95		**0 280 122 001**
Knock sensor	07.94-09.95		**0 261 231 109**
2.0 i 16V [Y4]			**2,0 l 97-99 kW RFV <XU10J4R> 4 Zyl.**
Throttle valve sensor	07.94-10.00		**0 280 122 003**
Knock sensor			
Org.no. →8133	07.94-02.99		**0 261 231 109**
Org.no. 8134→	03.99-10.00	EFV	**0 261 231 130**
Pressure sensor, intake manifold, gasoline			
Org.no. 7329→8056	02.97-12.98		**0 261 230 012**
Org.no. 8057→	01.99-10.00		**0 261 230 057**
2.1 D Turbo [Y4]			**2,1 l 80-81 kW P8C <XUD11BTE> 4 Zyl.**
Temperature sensor, intake air, diesel	07.94-10.00		**0 280 130 039**
Pedal position sensor, diesel			
Org.no. →6992	07.94-12.95	GS	**0 205 001 015**
2.5 D Turbo [Y4]			**2,5 l 94-96 kW THY <DK5ATE> 4 Zyl.**
Air flow sensor, diesel	07.94-10.00	N05	**0 281 002 128**
Pressure sensor, intake manifold, diesel	07.94-10.00	N03,N07	**0 281 002 063**
		N05	**0 281 002 122**
Temperature sensor, intake air, injection system	07.94-10.00		**0 280 130 039**
Pedal position sensor, diesel	07.94-10.00		**0 205 001 015**
3.0 i [Y3]			**3,0 l 123-125 kW SFZ,S6A <ZPJ> 6 Zyl.**
Knock sensor			
Org.no. →5168	06.89-02.91	HI,KZB	**0 261 231 033**
		KZG,VO	**0 261 231 034**
Org.no. 5169→	02.91-06.93	HI,KZB	**0 261 231 070**
		KZG,VO	**0 261 231 071**
Temperature sensor, intake air, injection system	05.89-06.93		**0 280 130 039**

Product			

3.0 i [Y3]			**3,0 l 123-125 kW UFZ <ZPJ> 6 Zyl.**
Knock sensor			
Org.no. 5169→	06.93-06.94	HI,KZB	**0 261 231 070**
		KZG,VO	**0 261 231 071**
Temperature sensor, intake air, injection system	06.93-06.94		**0 280 130 039**
3.0 i [Y4]			**3,0 l 123-125 kW UFY <ZPJ>; UFZ <ZPJ> 6 Zyl.**
Throttle valve sensor	07.94-12.97		**0 280 122 003**
Knock sensor	07.94-12.97	KZG	**0 261 231 071**
Temperature sensor, intake air, injection system	07.94-12.97		**0 280 130 039**
3.0 i [Y4]			**3,0 l 140-143 kW XFZ <ES9J4> 6 Zyl.**
Throttle valve sensor	09.97-10.00		**0 280 122 009**
Knock sensor	09.97-10.00		**0 261 231 125**
Pressure sensor, intake manifold, gasoline			
Org.no. →8077	09.97-12.98		**0 261 230 012**
Org.no. 8078→	01.99-10.00		**0 261 230 057**
3.0 i 24V [Y3]			**3,0 l 147 kW SKZ <ZPJ4> 6 Zyl.**
Knock sensor			
Org.no. →5168	06.89-02.91	HI,KZB	**0 261 231 033**
		KZG,VO	**0 261 231 034**
Org.no. 5169→	02.91-06.93	HI,KZB	**0 261 231 070**
		KZG,VO	**0 261 231 071**
3.0 i 24V [Y3]			**3,0 l 147 kW UKZ <ZPJ4> 6 Zyl.**
Knock sensor			
Org.no. 5169→	06.93-06.94	HI,KZB	**0 261 231 070**
		KZG,VO	**0 261 231 071**
3.0 i 24V [Y4]			**3,0 l 147 kW UKZ <ZPJ4> 6 Zyl.**
Throttle valve sensor	07.94-12.97		**0 280 122 003**
Knock sensor	07.94-12.97	KZG	**0 261 231 071**
Temperature sensor, intake air, injection system	07.94-12.97		**0 280 130 039**

Xsara

1.4 HDi [N7]			**1,4 l 50 kW 8HZ 4 Zyl.**
Yaw rate sensor, brake system	01.03→		**0 265 005 290**
Wheel speed sensor, front	01.03→		**0 265 006 389**
Wheel speed sensor, rear	01.03→		**0 265 006 203**
1.4 i [N6]			**1,4 l 55 kW KFX 4 Zyl.**
Knock sensor	07.97-08.00	N14	**0 261 231 128**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	07.97-12.98		**0 261 230 012**
Org.no. 8057→	01.99-08.00		**0 261 230 057**
Wheel speed sensor, front	07.97-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	07.97-08.00	STB	**0 265 006 203**
1.4 i [N7]			**1,4 l 55 kW KFW 4 Zyl.**
Knock sensor	09.00→		**0 261 231 128**
Pressure sensor, intake manifold, gasoline	09.00→		**0 261 230 043**
Yaw rate sensor, brake system	09.00→		**0 265 005 290**
Wheel speed sensor, front	09.00→		**0 265 006 389**
Wheel speed sensor, rear	09.00→		**0 265 006 203**
1.5 D [N6]			**1,5 l 42 kW VJY; VJZ 4 Zyl.**
Wheel speed sensor, front	07.97-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	07.97-08.00	STB	**0 265 006 203**
1.6 i [N6]			**1,6 l 65-66 kW NFZ 4 Zyl.**
Throttle valve sensor			
Org.no. →7874	07.97-06.98		**0 280 122 003**
Knock sensor			
Org.no. 7875→	07.98-08.00		**0 261 231 128**
Pressure sensor, intake manifold, gasoline			
Org.no. →7874	07.97-06.98		**0 261 230 004**
Org.no. 7875→8056	07.98-12.98		**0 261 230 012**
Temperature sensor, intake air, injection system			
Org.no. →7874	07.97-06.98		**0 280 130 039**

Product			
Wheel speed sensor, front	07.97-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	07.97-08.00	STB	**0 265 006 203**
1.6 i 16V [N7]			**1,6 l 80 kW NFU 4 Zyl.**
Throttle valve assembly	09.00→		**0 280 750 085**
Knock sensor			
Org.no. →9456	09.00-10.02		**0 261 231 128**
Org.no. 9457→	11.02→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	09.00→		**0 261 230 043**
Accelerator pedal module	09.00→		**0 280 752 243**
Yaw rate sensor, brake system	09.00→		**0 265 005 290**
Wheel speed sensor, front	09.00→		**0 265 006 389**
Wheel speed sensor, rear	09.00→		**0 265 006 202**
1.8 D [N6]			**1,8 l 44 kW A9A,161A 4 Zyl.**
Wheel speed sensor, front	07.97-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	07.97-08.00	STB	**0 265 006 203**
1.8 i [N6]			**1,8 l 66 kW LFX 4 Zyl.**
Pressure sensor, intake manifold, gasoline	07.97-08.00		**0 261 230 012**
Wheel speed sensor, front	07.97-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	07.97-08.00	STB	**0 265 006 203**
1.8 i [N6]			**1,8 l 74-75 kW LFZ; L6A 4 Zyl.**
Wheel speed sensor, front	07.97-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	07.97-08.00	STB	**0 265 006 203**
1.8 i 16V [N6]			**1,8 l 81-82 kW LFY 4 Zyl.**
Throttle valve sensor	07.97-08.00		**0 280 122 003**
Pressure sensor, intake manifold, gasoline	07.97-08.00		**0 261 230 012**
Wheel speed sensor, front	07.97-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	07.97-08.00	SBR	**0 265 006 202**
1.9 D [N6]			**1,9 l 50/51 kW DJY; WJZ 4 Zyl.**
Wheel speed sensor, front	07.97-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	07.97-08.00	STB	**0 265 006 203**
1.9 D [N7]			**1,9 l 52 kW WJY 4 Zyl.**
Yaw rate sensor, brake system	09.00→		**0 265 005 290**
Wheel speed sensor, front	09.00→		**0 265 006 389**
Wheel speed sensor, rear	09.00→		**0 265 006 203**
1.9 D Turbo [N6]			**1,9 l 55/66 kW DHV; DHY; D8A 4 Zyl.**
Wheel speed sensor, front	07.97-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	07.97-08.00	STB	**0 265 006 203**
2.0 HDi [N6]			**2,0 l 66 kW RHY 4 Zyl.**
Wheel speed sensor, front	02.99-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	02.99-08.00	SBR	**0 265 006 202**
2.0 HDi [N7]			**2,0 l 66 kW RHY 4 Zyl.**
High-pressure sensor (CR system)	09.00→	BO	**0 281 002 283**
Accelerator pedal module	09.00→		**0 280 752 243**
Yaw rate sensor, brake system	09.00→		**0 265 005 290**
Wheel speed sensor, front	09.00→		**0 265 006 389**
Wheel speed sensor, rear	09.00→		**0 265 006 202**
2.0 HDi [N7]			**2,0 l 80 kW RHZ 4 Zyl.**
High-pressure sensor (CR system)	09.00→		**0 281 002 283**
Accelerator pedal module	09.00→		**0 280 752 243**
Yaw rate sensor, brake system	09.00→		**0 265 005 290**
Wheel speed sensor, front	09.00→		**0 265 006 389**
Wheel speed sensor, rear	09.00→		**0 265 006 202**
2.0 i 16V [N6]			**2,0 l 97 kW RFV 4 Zyl.**
Throttle valve sensor	07.97-08.00		**0 280 122 003**
Knock sensor	07.97-08.00		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	07.97-08.00		**0 261 230 012**
Wheel speed sensor, front	07.97-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	07.97-08.00	SBR	**0 265 006 202**
2.0 i 16V [N6]			**2,0 l 120-123 kW RFS 4 Zyl.**
Throttle valve sensor	07.97-08.00		**0 280 122 009**
Pressure sensor, intake manifold, gasoline	07.97-08.00		**0 261 230 012**
Wheel speed sensor, front	07.97-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	07.97-08.00	SBR	**0 265 006 202**

Product			
2.0 i 16V [N7]			**2,0 l 100 kW RFN 4 Zyl.**
Pressure sensor, intake manifold, gasoline	09.00→		**0 261 230 057**
Yaw rate sensor, brake system	09.00→		**0 265 005 290**
Wheel speed sensor, front	09.00→		**0 265 006 389**
Wheel speed sensor, rear	09.00→		**0 265 006 202**

Xsara Break

1.4 HDi [N7]			**1,4 l 50 kW 8HZ 4 Zyl.**
Yaw rate sensor, brake system	01.03→		**0 265 005 290**
Wheel speed sensor, front	01.03→		**0 265 006 389**
Wheel speed sensor, rear	01.03→		**0 265 006 441**
1.4 i [N6]			**1,4 l 55 kW KFX 4 Zyl.**
Knock sensor	04.98-08.00	N14	**0 261 231 128**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	04.98-12.98		**0 261 230 012**
Org.no. 8057→	01.99-08.00		**0 261 230 057**
Wheel speed sensor, front	04.98-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	04.98-08.00	STB	**0 265 006 441**
1.4 i [N7]			**1,4 l 55 kW KFW 4 Zyl.**
Knock sensor	09.00→		**0 261 231 128**
Pressure sensor, intake manifold, gasoline	09.00→		**0 261 230 043**
Yaw rate sensor, brake system	09.00→		**0 265 005 290**
Wheel speed sensor, front	09.00→		**0 265 006 389**
Wheel speed sensor, rear	09.00→		**0 265 006 441**
1.5 D [N6]			**1,5 l 42 kW VJY; VJZ 4 Zyl.**
Wheel speed sensor, front	10.97-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	10.97-08.00	STB	**0 265 006 441**
1.6 i [N6]			**1,6 l 65-66 kW NFZ 4 Zyl.**
Throttle valve sensor			
Org.no. →7874	10.97-06.98		**0 280 122 003**
Knock sensor			
Org.no. 7875→	07.98-08.00		**0 261 231 128**
Pressure sensor, intake manifold, gasoline			
Org.no. →7874	10.97-06.98		**0 261 230 004**
Org.no. 7875→8056	07.98-12.98		**0 261 230 012**
Temperature sensor, intake air, injection system			
Org.no. →7874	10.97-06.98		**0 280 130 039**
Wheel speed sensor, front	10.97-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	10.97-08.00	STB	**0 265 006 441**
1.6 i 16V [N7]			**1,6 l 80 kW NFU 4 Zyl.**
Throttle valve assembly	09.00→		**0 280 750 085**
Knock sensor			
Org.no. →9456	09.00-10.02		**0 261 231 128**
Org.no. 9457→	11.02→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	09.00→		**0 261 230 043**
Accelerator pedal module	09.00→		**0 280 752 243**
Yaw rate sensor, brake system	09.00→		**0 265 005 290**
Wheel speed sensor, front	09.00→		**0 265 006 389**
Wheel speed sensor, rear	09.00→		**0 265 006 202**
1.8 D [N6]			**1,8 l 44 kW A9A,161A 4 Zyl.**
Wheel speed sensor, front	04.98-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	04.98-08.00	STB	**0 265 006 441**
1.8 i [N6]			**1,8 l 66 kW LFX 4 Zyl.**
Pressure sensor, intake manifold, gasoline	04.98-08.00		**0 261 230 012**
Wheel speed sensor, front	04.98-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	04.98-08.00	STB	**0 265 006 441**
1.8 i [N6]			**1,8 l 74-75 kW LFZ; L6A 4 Zyl.**
Wheel speed sensor, front	04.98-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	04.98-08.00	SBR	**0 265 006 202**
		STB	**0 265 006 441**

C

Product			
◀ Xsara Break			
1.8 i 16V [N6]			**1,8 l 81-82 kW LFY 4 Zyl.**
Throttle valve sensor	04.98-08.00		**0 280 122 003**
Pressure sensor, intake manifold, gasoline	04.98-08.00		**0 261 230 012**
Wheel speed sensor, front	04.98-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	04.98-08.00	SBR	**0 265 006 202**
1.9 D [N6]			**1,9 l 50/51 kW DJY; WJZ 4 Zyl.**
Wheel speed sensor, front	04.98-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	04.98-08.00	STB	**0 265 006 441**
1.9 D [N7]			**1,9 l 52 kW WJY 4 Zyl.**
Yaw rate sensor, brake system	09.00→		**0 265 005 290**
Wheel speed sensor, front	09.00→		**0 265 006 389**
Wheel speed sensor, rear	09.00→		**0 265 006 441**
1.9 D Turbo [N6]			**1,9 l 55/66 kW DHV; DHY 4 Zyl.**
Wheel speed sensor, front	04.98-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	04.98-08.00	STB	**0 265 006 441**
2.0 HDi [N6]			**2,0 l 66 kW RHY 4 Zyl.**
Wheel speed sensor, front	02.99-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	02.99-08.00	SBR	**0 265 006 202**
2.0 HDi [N7]			**2,0 l 66 kW RHY 4 Zyl.**
High-pressure sensor (CR system)	09.00→	BO	**0 281 002 283**
Accelerator pedal module	09.00→		**0 280 752 243**
Yaw rate sensor, brake system	09.00→		**0 265 005 290**
Wheel speed sensor, front	09.00→		**0 265 006 389**
Wheel speed sensor, rear	09.00→		**0 265 006 202**
2.0 HDi [N7]			**2,0 l 80 kW RHZ 4 Zyl.**
High-pressure sensor (CR system)	09.00→		**0 281 002 283**
Accelerator pedal module	09.00→		**0 280 752 243**
Yaw rate sensor, brake system	09.00→		**0 265 005 290**
Wheel speed sensor, front	09.00→		**0 265 006 389**
Wheel speed sensor, rear	09.00→		**0 265 006 202**
2.0 i 16V [N6]			**2,0 l 97 kW RFV 4 Zyl.**
Throttle valve sensor	07.98-08.00		**0 280 122 003**
Knock sensor	07.98-08.00		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	07.98-08.00		**0 261 230 012**
Wheel speed sensor, front	07.98-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	07.98-08.00	SBR	**0 265 006 202**
2.0 i 16V [N7]			**2,0 l 100 kW RFN 4 Zyl.**
Pressure sensor, intake manifold, gasoline	09.00→		**0 261 230 057**
Yaw rate sensor, brake system	09.00→		**0 265 005 290**
Wheel speed sensor, front	09.00→		**0 265 006 389**
Wheel speed sensor, rear	09.00→		**0 265 006 202**

Xsara Coupé

Product			
1.4 i [N6]			**1,4 l 55 kW KFX 4 Zyl.**
Knock sensor	07.97-08.00	N14	**0 261 231 128**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	07.97-12.98		**0 261 230 012**
Org.no. 8057→	01.99-08.00		**0 261 230 057**
Wheel speed sensor, front	07.97-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	07.97-08.00	STB	**0 265 006 203**
1.4 i [N7]			**1,4 l 55 kW KFW 4 Zyl.**
Knock sensor	09.00→		**0 261 231 128**
Pressure sensor, intake manifold, gasoline	09.00→		**0 261 230 043**
Yaw rate sensor, brake system	09.00→		**0 265 005 290**
Wheel speed sensor, front	09.00→		**0 265 006 389**
Wheel speed sensor, rear	09.00→		**0 265 006 203**
1.6 i 16V [N7]			**1,6 l 80 kW NFU 4 Zyl.**
Throttle valve assembly	09.00→		**0 280 750 085**
Knock sensor			
Org.no. →9456	09.00-10.02		**0 261 231 128**
Org.no. 9457→	11.02→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	09.00→		**0 261 230 043**
Accelerator pedal module	09.00→		**0 280 752 243**
Yaw rate sensor, brake system	09.00→		**0 265 005 290**
Wheel speed sensor, front	09.00→		**0 265 006 389**
Wheel speed sensor, rear	09.00→		**0 265 006 202**
1.8 D [N6]			**1,8 l 44 kW A9A,161A 4 Zyl.**
Wheel speed sensor, front	07.97-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	07.97-08.00	STB	**0 265 006 203**
1.8 i [N6]			**1,8 l 66 kW LFX 4 Zyl.**
Pressure sensor, intake manifold, gasoline	07.97-08.00		**0 261 230 012**
Wheel speed sensor, front	07.97-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	07.97-08.00	STB	**0 265 006 203**
1.8 i [N6]			**1,8 l 74 kW LFZ 4 Zyl.**
Wheel speed sensor, front	07.97-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	07.97-08.00	STB	**0 265 006 203**
1.8 i 16V [N6]			**1,8 l 81-82 kW LFY 4 Zyl.**
Throttle valve sensor	07.97-08.00		**0 280 122 003**
Pressure sensor, intake manifold, gasoline	07.97-08.00		**0 261 230 012**
Wheel speed sensor, front	07.97-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	07.97-08.00	SBR	**0 265 006 202**
1.9 D [N6]			**1,9 l 50/51 kW DJY; WJZ 4 Zyl.**
Wheel speed sensor, front	07.97-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	07.97-08.00	STB	**0 265 006 203**
1.9 D [N7]			**1,9 l 52 kW WJY 4 Zyl.**
Yaw rate sensor, brake system	09.00→		**0 265 005 290**
Wheel speed sensor, front	09.00→		**0 265 006 389**
Wheel speed sensor, rear	09.00→		**0 265 006 203**
1.9 D Turbo [N6]			**1,9 l 55/66 kW DHV; DHY 4 Zyl.**
Wheel speed sensor, front	07.97-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	07.97-08.00	STB	**0 265 006 203**
2.0 HDi [N6]			**2,0 l 66 kW RHY 4 Zyl.**
Wheel speed sensor, front	02.99-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	02.99-08.00	SBR	**0 265 006 202**
2.0 HDi [N7]			**2,0 l 66 kW RHY 4 Zyl.**
High-pressure sensor (CR system)	09.00→	BO	**0 281 002 283**
Accelerator pedal module	09.00→		**0 280 752 243**
Yaw rate sensor, brake system	09.00→		**0 265 005 290**
Wheel speed sensor, front	09.00→		**0 265 006 389**
Wheel speed sensor, rear	09.00→		**0 265 006 202**
2.0 HDi [N7]			**2,0 l 80 kW RHZ 4 Zyl.**
High-pressure sensor (CR system)	09.00→		**0 281 002 283**
Accelerator pedal module	09.00→		**0 280 752 243**
Yaw rate sensor, brake system	09.00→		**0 265 005 290**
Wheel speed sensor, front	09.00→		**0 265 006 389**
Wheel speed sensor, rear	09.00→		**0 265 006 202**
2.0 i 16V [N6]			**2,0 l 97 kW RFV 4 Zyl.**
Throttle valve sensor	07.97-08.00		**0 280 122 003**
Knock sensor	07.97-08.00		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	07.97-08.00		**0 261 230 012**
Wheel speed sensor, front	07.97-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	07.97-08.00	SBR	**0 265 006 202**
2.0 i 16V [N6]			**2,0 l 120-123 kW RFS 4 Zyl.**
Throttle valve sensor	07.97-08.00		**0 280 122 009**
Pressure sensor, intake manifold, gasoline	07.97-08.00		**0 261 230 012**
Wheel speed sensor, front	07.97-08.00	SBR	**0 265 006 389**
Wheel speed sensor, rear	07.97-08.00	SBR	**0 265 006 202**
2.0 i 16V [N7]			**2,0 l 100 kW RFN 4 Zyl.**
Pressure sensor, intake manifold, gasoline	09.00→		**0 261 230 057**
Yaw rate sensor, brake system	09.00→		**0 265 005 290**
Wheel speed sensor, front	09.00→		**0 265 006 389**
Wheel speed sensor, rear	09.00→		**0 265 006 202**
2.0 i 16V [N7]			**2,0 l 120 kW RFS 4 Zyl.**
Throttle valve sensor	09.00→		**0 280 122 009**
Pressure sensor, intake manifold, gasoline	09.00→		**0 261 230 057**

Product			
Yaw rate sensor, brake system	09.00→		**0 265 005 290**
Wheel speed sensor, front	09.00→		**0 265 006 389**
Wheel speed sensor, rear	09.00→		**0 265 006 202**

Xsara Picasso

1.6 HDi [N68]			**1,6 l 66 kW 9HX 4 Zyl.**
Yaw rate sensor, brake system	09.05→		**0 265 005 290**
Wheel speed sensor, front	09.05→		**0 265 007 665**
1.6 HDi [N68]			**1,6 l 80 kW 9HY/ 9HZ 4 Zyl.**
Yaw rate sensor, brake system	05.04→		**0 265 005 290**
Wheel speed sensor, front			
Org.no. →10220FV,→10312UW,→1031278	05.04→		**0 265 006 389**
Org.no. 10221FV→,10313UW→,1031378→	05.04→		**0 265 007 665**
1.6 i			**1,6 l 67 kW 4 Zyl.**
Knock sensor	06.02-02.07		**0 261 231 128**
Pressure sensor, intake manifold, gasoline	06.02-02.07		**0 261 230 043**
Wheel speed sensor, front	06.02-02.07		**0 265 006 389**
Wheel speed sensor, rear	06.02-02.07		**0 265 006 659**
1.6 i [N68]			**1,6 l 66 kW NFZ 4 Zyl.**
Knock sensor	01.00→		**0 261 231 128**
Pressure sensor, intake manifold, gasoline	01.00→		**0 261 230 057**
Wheel speed sensor, front			
Org.no. →10220FV,→10312UW,→1031278	01.00→		**0 265 006 389**
Org.no. 10221FV→,10313UW→,1031378→	01.00→		**0 265 007 665**
Wheel speed sensor, rear	01.00→		**0 265 006 659**
1.6 i [N68]			**1,6 l 74 kW NFV 4 Zyl.**
Knock sensor			
Org.no. →9491	01.00-11.02		**0 261 231 128**
Org.no. 9492→	12.02→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	01.00→		**0 261 230 043**
Wheel speed sensor, front			
Org.no. →10220FV,→10312UW,→1031278	01.00→		**0 265 006 389**
Org.no. 10221FV→,10313UW→,1031378→	01.00→		**0 265 007 665**
Wheel speed sensor, rear	01.00→		**0 265 006 659**
1.6 i 16V [N68]			**1,6 l 80 kW NFU; N6A 4 Zyl.**
Knock sensor	03.05→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	03.05→		**0 261 230 043**
Yaw rate sensor, brake system	03.05→		**0 265 005 290**
Wheel speed sensor, front	03.05→		**0 265 007 665**
1.6 i 16V Flex			**1,6 l 81-83 kW TU5JP4 4 Zyl.**
Throttle valve assembly	10.06→		**0 280 750 085**
Pressure sensor, intake manifold, gasoline	10.06→		**0 261 230 043**
Accelerator pedal module	10.06→		**0 280 752 251**
1.8 i [N68]			**1,8 l 85 kW 6FZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	01.00→		**0 261 230 057**
Yaw rate sensor, brake system	01.00→		**0 265 005 290**
Wheel speed sensor, front			
Org.no. →10220FV,→10312UW,→1031278	01.00→		**0 265 006 389**
Org.no. 10221FV→,10313UW→,1031378→	01.00→		**0 265 007 665**
Wheel speed sensor, rear	01.00→		**0 265 006 659**
2.0 HDi [N68]			**2,0 l 66 kW RHY 4 Zyl.**
High-pressure sensor (CR system)	01.00→		**0 281 002 283**
Yaw rate sensor, brake system	01.00→		**0 265 005 290**
Wheel speed sensor, front			
Org.no. →10220FV,→10312UW,→1031278	01.00→		**0 265 006 389**
Org.no. 10221FV→,10313UW→,1031378→	01.00→		**0 265 007 665**
Wheel speed sensor, rear	01.00→		**0 265 006 659**
2.0 i			**2,0 l 97 kW 4 Zyl.**
Pressure sensor, intake manifold, gasoline	06.02-02.07	EML	**0 261 230 058**
		MGS	**0 261 230 057**
Wheel speed sensor, front	06.02-02.07		**0 265 006 389**
Wheel speed sensor, rear	06.02-02.07		**0 265 006 659**

Product			
2.0 i 16V			**2,0 l 100 kW 4 Zyl.**
Wheel speed sensor, front	10.00→		**0 265 006 389**
Wheel speed sensor, rear	10.00→		**0 265 006 659**
2.0 i 16V [N68]			**2,0 l 100 kW RFM/ RFN 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.01→	EML	**0 261 230 058**
		MGS	**0 261 230 057**
Yaw rate sensor, brake system	03.01→		**0 265 005 290**
Wheel speed sensor, front			
Org.no. →10220FV,→10312UW,→1031278	03.01→		**0 265 006 389**
Org.no. 10221FV→,10313UW→,1031378→	03.01→		**0 265 007 665**
Wheel speed sensor, rear	03.01→		**0 265 006 659**

ZX

1.1 [N20/N21]			**1,1 l 40-44 kW H1A,H1B 4 Zyl.**
Wheel speed sensor, front	03.91-08.96		**0 265 006 199**
Wheel speed sensor, rear	03.91-08.96	KOB	**0 265 006 204**
Org.no. →6748	03.91-04.95	LIM,SBR	**0 265 006 204**
Org.no. 6749→	05.95-08.96	LIM,TBR	**0 265 006 203**
1.1 i [N20/N21]			**1,1 l 44 kW HDY 4 Zyl.**
Wheel speed sensor, front	09.96-06.97		**0 265 006 199**
Wheel speed sensor, rear	09.96-06.97	KOB	**0 265 006 204**
Org.no. 6749→	09.96-06.97	LIM,TBR	**0 265 006 203**
1.1 i [N20/N21]			**1,1 l 44 kW HDY Kat. 4 Zyl.**
Temperature sensor, coolant, injection system	04.94-08.96		**0 280 130 026**
Wheel speed sensor, front	04.94-08.96		**0 265 006 199**
Wheel speed sensor, rear	04.94-08.96	KOB	**0 265 006 204**
Org.no. →6748	04.94-04.95	LIM,SBR	**0 265 006 204**
Org.no. 6749→	05.95-08.96	LIM,TBR	**0 265 006 203**
1.1 i [N20/N21]			**1,1 l 44 kW HDZ 4 Zyl.**
Wheel speed sensor, front	09.96-06.97		**0 265 006 199**
Wheel speed sensor, rear	09.96-06.97	KOB	**0 265 006 204**
Org.no. 6749→	09.96-06.97	LIM,TBR	**0 265 006 203**
1.1 i [N20/N21]			**1,1 l 44 kW HDZ Kat. 4 Zyl.**
Wheel speed sensor, front	10.91-03.94		**0 265 006 199**
Wheel speed sensor, rear	10.91-03.94		**0 265 006 204**
1.4			**1,4 l 49 kW K5A 4 Zyl.**
Wheel speed sensor, front	02.92-12.99		**0 265 006 199**
Wheel speed sensor, rear	02.92-12.99		**0 265 006 203**
1.4 [N20/N21]			**1,4 l 55 kW K2D 4 Zyl.**
Wheel speed sensor, front	03.91-08.93		**0 265 006 199**
Wheel speed sensor, rear	03.91-08.93		**0 265 006 204**
1.4 [N20/N21]			**1,4 l 55 kW K5A 4 Zyl.**
Wheel speed sensor, front	09.93-12.95		**0 265 006 199**
Wheel speed sensor, rear	09.93-12.95	KOB	**0 265 006 204**
Org.no. →6748	09.93-04.95	LIM,SBR	**0 265 006 204**
Org.no. 6749→	05.95-12.95	LIM,TBR	**0 265 006 203**
1.4 D [N20/N21]			**1,4 l 37-39 kW K9Y 4 Zyl.**
Wheel speed sensor, front	06.94-06.97		**0 265 006 199**
Wheel speed sensor, rear	06.94-06.97	KOB	**0 265 006 204**
Org.no. →6748	06.94-04.95	LIM,SBR	**0 265 006 204**
Org.no. 6749→	05.95-06.97	LIM,TBR	**0 265 006 203**
1.4 i [N20/N21]			**1,4 l 55 kW KDX Kat. 4 Zyl.**
Temperature sensor, coolant, injection system			
Org.no. 5783→	08.92-08.96	BO	**0 280 130 026**
Wheel speed sensor, front	08.92-08.96		**0 265 006 199**
Wheel speed sensor, rear	08.92-08.96	KOB	**0 265 006 204**
Org.no. →6748	08.92-04.95	LIM,SBR	**0 265 006 204**
Org.no. 6749→	05.95-08.96	LIM,TBR	**0 265 006 203**
1.4 i [N20/N21]			**1,4 l 55 kW KDY,HDY Kat. 4 Zyl.**
Wheel speed sensor, front	03.91-08.92		**0 265 006 199**
Wheel speed sensor, rear	03.91-08.92		**0 265 006 204**

C

Product			
◀ ZX			
1.4 i [N20/N21]			**1,4 l 55 kW KFX 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.96-10.97		**0 261 230 012**
Wheel speed sensor, front	05.96-10.97		**0 265 006 199**
Wheel speed sensor, rear	05.96-10.97	KOB	**0 265 006 204**
Org.no. 6749→	05.96-10.97	LIM,TBR	**0 265 006 203**
1.4 i 8V			**1,4 l 55 kW KFX 4 Zyl.**
Throttle valve sensor	01.97→		**0 280 122 003**
Pressure sensor, intake manifold, gasoline	01.97→		**0 261 230 004**
			0 261 230 024
Temperature sensor, intake air, injection system	01.97→		**0 280 130 039**
Temperature sensor, coolant, injection system	01.97→		**0 280 130 026**
Wheel speed sensor, front	01.97→		**0 265 006 199**
Wheel speed sensor, rear	01.97→		**0 265 006 203**
1.5 D [N20/N21]			**1,5 l 42 kW VJY; VJZ 4 Zyl.**
Wheel speed sensor, front	09.96-10.97		**0 265 006 199**
Wheel speed sensor, rear	09.96-10.97	KOB	**0 265 006 204**
Org.no. 6749→	09.96-10.97	LIM,TBR	**0 265 006 203**
1.6 i [N20/N21]			**1,6 l 65 kW BFZ Kat. 4 Zyl.**
Wheel speed sensor, front	07.93-10.97		**0 265 006 199**
Wheel speed sensor, rear	07.93-10.97	KOB	**0 265 006 204**
Org.no. →6748	07.93-04.95	LIM,SBR	**0 265 006 204**
Org.no. 6749→	05.95-10.97	LIM,TBR	**0 265 006 203**
1.6 i [N20/N21]			**1,6 l 65-66 kW BDY Kat.; B4A 4 Zyl.**
Temperature sensor, intake air, injection system	03.91-12.94		**0 280 130 039**
Wheel speed sensor, front	03.91-12.94		**0 265 006 199**
Wheel speed sensor, rear	03.91-12.94		**0 265 006 204**
1.6 i [N20/N21]			**1,6 l 65-66 kW NFZ 4 Zyl.**
Throttle valve sensor	02.96-10.97		**0 280 122 003**
Pressure sensor, intake manifold, gasoline	02.96-10.97	BO	**0 261 230 004**
Temperature sensor, intake air, injection system	02.96-10.97		**0 280 130 039**
Wheel speed sensor, front	02.96-10.97		**0 265 006 199**
Wheel speed sensor, rear	02.96-10.97	KOB	**0 265 006 204**
Org.no. 6749→	02.96-10.97	LIM,TBR	**0 265 006 203**
1.6 i 8V			**1,6 l 65 kW NFZ 4 Zyl.**
Throttle valve sensor	10.96→	AG	**0 280 122 011**
		GS	**0 280 122 003**
Pressure sensor, intake manifold, gasoline	10.96→		**0 261 230 024**
Temperature sensor, intake air, injection system	10.96→		**0 280 130 039**
Temperature sensor, coolant, injection system	10.96→		**0 280 130 026**
Wheel speed sensor, front	10.96→		**0 265 006 199**
Wheel speed sensor, rear	10.96→		**0 265 006 203**
1.6 8V			**1,6 l 55 kW K2D 4 Zyl.**
Wheel speed sensor, front	04.92-12.99		**0 265 006 199**
Wheel speed sensor, rear	04.92-12.99		**0 265 006 203**
1.8 D [N20/N21]			**1,8 l 44 kW A9A,161A 4 Zyl.**
Wheel speed sensor, front	03.91-10.97		**0 265 006 199**
Wheel speed sensor, rear	03.91-10.97	KOB	**0 265 006 204**
Org.no. →6748	03.91-04.95	LIM,SBR	**0 265 006 204**
Org.no. 6749→	05.95-10.97	LIM,TBR	**0 265 006 203**
1.8 i [N20/N21]			**1,8 l 74-76 kW LFZ Kat.; L6A 4 Zyl.**
Pressure sensor, intake manifold, gasoline	07.92-10.97	BO	**0 261 230 004**
Wheel speed sensor, front	07.92-10.97		**0 265 006 199**
Wheel speed sensor, rear	07.92-10.97	KOB	**0 265 006 204**
Org.no. →6748	07.92-04.95	LIM,SBR	**0 265 006 204**
Org.no. 6749→	05.95-10.97	LIM,TBR	**0 265 006 203**
1.8 i 16V [N20/N21]			**1,8 l 81 kW LFY 4 Zyl.**
Throttle valve sensor	01.96-02.98		**0 280 122 003**
Knock sensor	01.96-02.98		**0 261 231 109**
Pressure sensor, intake manifold, gasoline	01.96-02.98		**0 261 230 012**
Wheel speed sensor, front	01.96-02.98		**0 265 006 199**
Wheel speed sensor, rear	01.96-02.98	KOB	**0 265 006 204**
		LIM,SBR	**0 265 006 202**
Org.no. 6749→	01.96-02.98	LIM,TBR	**0 265 006 203**

Product			
1.9 D [N20/N21]			**1,9 l 47-48 kW DJZ 4 Zyl.**
Wheel speed sensor, front	03.91-04.94		**0 265 006 199**
Wheel speed sensor, rear	03.91-04.94		**0 265 006 204**
1.9 D [N20/N21]			**1,9 l 50/51-52 kW DJY; D9B 4 Zyl.**
Wheel speed sensor, front	03.91-10.97		**0 265 006 199**
Wheel speed sensor, rear	03.91-10.97	KOB	**0 265 006 204**
Org.no. →6748	03.91-04.95	LIM,SBR	**0 265 006 204**
Org.no. 6749→	05.95-10.97	LIM,TBR	**0 265 006 203**
1.9 D Turbo [N20/N21]			**1,9 l 66/68 kW DHY; D8A 4 Zyl.**
Wheel speed sensor, front	07.92-10.97		**0 265 006 199**
Wheel speed sensor, rear	07.92-10.97	KOB	**0 265 006 204**
		LIM,SBR	**0 265 006 202**
Org.no. 6749→	05.95-10.97	LIM,TBR	**0 265 006 203**
1.9 i [N20/N21]			**1,9 l 88-90 kW DKZ,DFY Kat. 4 Zyl.**
Throttle valve sensor	03.91-10.97		**0 280 120 327**
Speed sensor, ignition/injection	03.91-10.97		**0 261 210 043**
Temperature sensor, coolant, injection system	03.91-10.97		**0 280 130 026**
Wheel speed sensor, front	03.91-10.97		**0 265 006 199**
Wheel speed sensor, rear	03.91-10.97	KOB	**0 265 006 204**
		LIM	**0 265 006 202**
1.9 i [N20/N21]			**1,9 l 93-96 kW D6E 4 Zyl.**
Speed sensor, ignition/injection	03.91-10.97		**0 261 210 043**
Temperature sensor, intake air, injection system	03.91-10.97		**0 280 130 039**
Temperature sensor, coolant, injection system	03.91-10.97		**0 280 130 026**
Wheel speed sensor, front	03.91-10.97		**0 265 006 199**
Wheel speed sensor, rear	03.91-10.97	KOB	**0 265 006 204**
		LIM	**0 265 006 202**
2.0 i [N20/N21]			**2,0 l 89-90 kW RFX Kat.; R6D 4 Zyl.**
Knock sensor	07.92-10.97	KZG	**0 261 231 071**
Wheel speed sensor, front	07.92-10.97		**0 265 006 199**
Wheel speed sensor, rear	07.92-10.97	KOB	**0 265 006 204**
		LIM	**0 265 006 202**
2.0 i 16V [N20/N21]			**2,0 l 110-114 kW RFY,RFT Kat. 4 Zyl.**
Throttle valve sensor			
Org.no. →6778	07.92-05.95		**0 280 122 001**
Knock sensor	07.92-10.97	KZG	**0 261 231 071**
Wheel speed sensor, front	07.92-10.97		**0 265 006 199**
Wheel speed sensor, rear	07.92-10.97	KOB	**0 265 006 204**
		LIM	**0 265 006 202**
2.0 i 16V [N20/N21]			**2,0 l 120-122 kW RFS 4 Zyl.**
Throttle valve sensor	09.96-10.97		**0 280 122 009**
Pressure sensor, intake manifold, gasoline	09.96-10.97		**0 261 230 012**
Wheel speed sensor, front	09.96-10.97		**0 265 006 199**
Wheel speed sensor, rear	09.96-10.97	KOB	**0 265 006 204**

DACIA

Logan

1.4 MPI [KS./LS.]			**1,4 l 55 kW K7J 710 4 Zyl.**
Wheel speed sensor, front	07.04→		**0 265 007 596**
Wheel speed sensor, rear	07.04→	LAB	**0 265 007 583**
		RAB	**0 265 007 582**
1.5 dCi [KS./LS.]			**1,5 l 48/50 kW K9K 790; K9K 792 4 Zyl.**
Boost pressure sensor, Diesel	06.05→		**0 281 002 593**
Wheel speed sensor, front	06.05→		**0 265 007 596**
Wheel speed sensor, rear	06.05→	LAB	**0 265 007 583**
		RAB	**0 265 007 582**
1.6 MPI [KS./LS.]			**1,6 l 64 kW K7M 710 4 Zyl.**
Wheel speed sensor, front	07.04→		**0 265 007 596**
Wheel speed sensor, rear	07.04→	LAB	**0 265 007 583**
		RAB	**0 265 007 582**

C

Product

1.6 16V [KS./LS.]			**1,6 l 77 kW K4M 690 4 Zyl.**
Wheel speed sensor, front	12.05→		**0 265 007 596**
Wheel speed sensor, rear	12.05→	LAB	**0 265 007 583**
		RAB	**0 265 007 582**

DAEWOO

Korando

2.0 i 16V [KJ]			**2,0 l 100 kW M161 E20 4 Zyl.**
Wheel speed sensor, front	07.96-12.00		**0 265 006 134**
Wheel speed sensor, rear	07.96-12.00		**0 265 006 343**
2.3 D [KJ]			**2,3 l 57 kW OM661 D23 4 Zyl.**
Wheel speed sensor, front	07.96-12.00		**0 265 006 134**
Wheel speed sensor, rear	07.96-12.00		**0 265 006 343**
2.3 i 16V [KJ]			**2,3 l 103 kW M161 E23 4 Zyl.**
Wheel speed sensor, front	07.96-12.00		**0 265 006 134**
Wheel speed sensor, rear	07.96-12.00		**0 265 006 343**
2.9 D [KJ]			**2,9 l 70-73 kW OM662 D29 5 Zyl.**
Wheel speed sensor, front	07.96-12.00		**0 265 006 134**
Wheel speed sensor, rear	07.96-12.00		**0 265 006 343**
2.9 TD Intercooler [KJ]			**2,9 l 95 kW OM662 D29 5 Zyl.**
Wheel speed sensor, front	07.96-12.00		**0 265 006 134**
Wheel speed sensor, rear	07.96-12.00		**0 265 006 343**
3.2 i 24V [KJ]			**3,2 l 162 kW M162 E32 6 Zyl.**
Wheel speed sensor, front	07.96-12.00		**0 265 006 134**
Wheel speed sensor, rear	07.96-12.00		**0 265 006 343**

Leganza

1.8 i [KLAV, V100]			**1,8 l 66-70/100 kW D-TEC; E-TEC 4 Zyl.**
Wheel speed sensor, front	03.97-12.02		**0 265 006 414**
Wheel speed sensor, rear	03.97-12.02		**0 265 006 415**
2.0 i [KLAV, V100]			**2,0 l 93/98-107 kW T20SED; X20SED 4 Zyl.**
Wheel speed sensor, front	03.97-12.02		**0 265 006 414**
Wheel speed sensor, rear	03.97-12.02		**0 265 006 415**
2.2 i [KLAV, V100]			**2,2 l 100 kW T22SED 4 Zyl.**
Wheel speed sensor, front	09.98-12.02		**0 265 006 414**
Wheel speed sensor, rear	09.98-12.02		**0 265 006 415**

Musso

2.0 i 16V [MJ]			**2,0 l 100 kW M161 E20 4 Zyl.**
Wheel speed sensor, front	05.96-12.00		**0 265 006 134**
Wheel speed sensor, rear	05.96-12.00		**0 265 006 135**
2.3 D [MJ]			**2,3 l 57 kW OM661 D23 4 Zyl.**
Wheel speed sensor, front	07.93-12.00		**0 265 006 134**
Wheel speed sensor, rear	07.93-12.00		**0 265 006 135**
2.3 i 16V [MJ]			**2,3 l 103 kW M161 E23 4 Zyl.**
Wheel speed sensor, front	05.96-12.00		**0 265 006 134**
Wheel speed sensor, rear	05.96-12.00		**0 265 006 135**
2.9 D [MJ]			**2,9 l 72 kW OM 662 D29 5 Zyl.**
Wheel speed sensor, front	07.93-12.00		**0 265 006 134**
Wheel speed sensor, rear	07.93-12.00		**0 265 006 135**
2.9 TD Intercooler [MJ]			**2,9 l 88 kW OM662 D29 5 Zyl.**
Wheel speed sensor, front	05.97-12.00		**0 265 006 134**
Wheel speed sensor, rear	05.97-12.00		**0 265 006 135**
3.2 i 24V [MJ]			**3,2 l 162 kW M162 E32 6 Zyl.**
Speed sensor, ignition/injection	01.96-12.00		**0 281 002 123**
Wheel speed sensor, front	01.96-12.00		**0 265 006 134**
Wheel speed sensor, rear	01.96-12.00		**0 265 006 135**

Product

Nubira

1.6 i [KALJ, J100]			**1,6 l 78 kW A16DMS 4 Zyl.**
Wheel speed sensor, front	09.97-09.99	LAB	**0 265 006 593**
		RAB	**0 265 006 594**
1.6 i [KALJ, 150, 190]			**1,6 l 78 kW 4 Zyl.**
Wheel speed sensor, front	10.99-06.03	LAB	**0 265 006 593**
		RAB	**0 265 006 594**
Wheel speed sensor, rear	10.99-06.03	LAB	**0 265 006 595**
		RAB	**0 265 006 596**
2.0 i [KALJ, J100]			**2,0 l 98 kW X20SED 4 Zyl.**
Wheel speed sensor, front	09.97-09.99	LAB	**0 265 006 593**
		RAB	**0 265 006 594**
2.0 i [KALJ, 150, 190]			**2,0 l 79/98 kW ; X20SED 4 Zyl.**
Wheel speed sensor, front	10.99-06.03	LAB	**0 265 006 593**
		RAB	**0 265 006 594**
Wheel speed sensor, rear	10.99-06.03	LAB	**0 265 006 595**
		RAB	**0 265 006 596**

Nubira Hatchback

1.6 i [KALJ, J100]			**1,6 l 78 kW A16DMS 4 Zyl.**
Wheel speed sensor, front	09.97-09.99	LAB	**0 265 006 593**
		RAB	**0 265 006 594**
2.0 i [KALJ, J100]			**2,0 l 98 kW X20SED 4 Zyl.**
Wheel speed sensor, front	09.97-09.99	LAB	**0 265 006 593**
		RAB	**0 265 006 594**

Nubira Station Wagon

1.6 i [KALJ, J100]			**1,6 l 78 kW A16DMS 4 Zyl.**
Wheel speed sensor, front	09.97-09.99	LAB	**0 265 006 593**
		RAB	**0 265 006 594**
1.6 i [KALJ, 150, 190]			**1,6 l 78 kW 4 Zyl.**
Wheel speed sensor, front	10.99-06.03	LAB	**0 265 006 593**
		RAB	**0 265 006 594**
Wheel speed sensor, rear	10.99-06.03	LAB	**0 265 006 595**
		RAB	**0 265 006 596**
2.0 i [KALJ, J100]			**2,0 l 98 kW X20SED 4 Zyl.**
Wheel speed sensor, front	09.97-09.99	LAB	**0 265 006 593**
		RAB	**0 265 006 594**
2.0 i [KALJ, 150, 190]			**2,0 l 98 kW X20SED 4 Zyl.**
Wheel speed sensor, front	10.99-06.03	LAB	**0 265 006 593**
		RAB	**0 265 006 594**
Wheel speed sensor, rear	10.99-06.03	LAB	**0 265 006 595**
		RAB	**0 265 006 596**

Prince

2.0 LPG			**2,0 l 83-85 kW Holden-C 20 LE 4 Zyl.**
Wheel speed sensor, front	01.91-03.96		**0 265 006 136**
Wheel speed sensor, rear	01.91-03.96		**0 265 006 137**

DAIMLER LTD.

Sovereign

4.2			**4,2 l 150 kW 6 Zyl.**
Air flow sensor, gasoline injection	03.79-12.89		**0 280 203 006**
			0 986 280 022

D

Product

DODGE

Caravan

2.5 TD [NS]		**2,5 l 85 kW VM HR 425 CLIEE 4 Zyl.**
Air mass meter, diesel	01.95-08.03	**0 281 002 132**
Pressure sensor, intake manifold, diesel	08.97-08.03	**0 281 002 205**

Dakota

3.9 [AN]		**3,9 l 131-134 kW EHC 6 Zyl.**
Speed sensor, ignition/injection	01.97-12.03 GS	**0 258 005 704**
5.2 [AN]		**5,2 l 164-172 kW ELF, ELG 8 Zyl.**
Speed sensor, ignition/injection	01.97-12.00 GS	**0 258 005 704**

Shadow

2.2		**2,2 l 69 kW EDF 4 Zyl.**
Temperature sensor, intake air, injection system	01.87-12.94	**0 280 130 046**

Spirit

2.5 i LE		**2,5 l 74 kW 4 TBI 4 Zyl.**
Temperature sensor, intake air, injection system	10.88-08.93	**0 280 130 046**
		0 280 130 063

600

2.2 i		**2,2 l 72 kW EDF 4 Zyl.**
Temperature sensor, coolant, injection system	09.85-08.88	**0 280 130 046**
		0 280 130 063

FERRARI

F50

V12		**4,7 l 383 kW 12 Zyl.**
Throttle valve sensor	07.95→	**0 280 122 011**
Air mass meter, gasoline injection	07.95→	**0 280 213 012**
		0 986 280 110
Phase sensor	07.95→	**0 232 103 006**
Pulse generator, ignition/Jetronic	07.95→	**0 261 210 104**
Temperature sensor, coolant, injection system	07.95→	**0 280 130 026**

F355

3.5		**3,5 l 280 kW F129B/40 8 Zyl.**
Throttle valve sensor	05.94-10.95	**0 280 122 001**
Air mass meter, gasoline injection	05.94-10.95	**0 280 213 023**
Phase sensor	05.94-10.95	**0 232 103 006**
Pulse generator, ignition/Jetronic	05.94-10.95	**0 261 210 126**
Temperature sensor, coolant, injection system	05.94-10.95	**0 280 130 026**
Spider		**3,5 l 280 kW F129C/40 8 Zyl.**
Throttle valve sensor	10.95→	**0 280 122 004**
Air mass meter, gasoline injection	10.95→	**0 280 217 800**
Phase sensor	10.95→	**0 232 103 006**
Pulse generator, ignition/Jetronic	10.95→	**0 261 210 126**
Knock sensor	10.95→	**0 261 231 007**
Temperature sensor, intake air, injection system	10.95→	**0 280 130 039**
Temperature sensor, coolant, injection system	10.95→	**0 280 130 026**

Product

F360

Modena		**3,5 l 298 kW F131 8 Zyl.**
Throttle valve assembly	03.99-12.04	**0 280 750 038**
Air mass meter, gasoline injection	03.99-12.04	**0 280 218 012**
Phase sensor	03.99-12.04	**0 232 103 026**
Speed sensor, ignition/injection	03.99-12.04	**0 261 210 198**
Knock sensor	03.99-12.04	**0 261 231 145**
Pressure sensor, intake manifold, gasoline	03.99-12.04	**0 261 230 015**
Temperature sensor, coolant, injection system	03.99-12.04	**0 281 002 170**
Spider		**3,5 l 294 kW F131B 8 Zyl.**
Throttle valve assembly	06.00→	**0 280 750 038**
Air mass meter, gasoline injection	06.00→	**0 280 218 012**
Phase sensor	06.00→	**0 232 103 026**
Speed sensor, ignition/injection	06.00→	**0 261 210 198**
Knock sensor	06.00→	**0 261 231 145**
Pressure sensor, intake manifold, gasoline	06.00→	**0 261 230 015**
Temperature sensor, coolant, injection system	06.00→	**0 281 002 170**

Mondial

T		**3,4 l 221 kW F 119 D 8 Zyl.**
Air mass meter, gasoline injection	10.89-02.94	**0 280 212 018**
Speed sensor, ignition/injection	10.89-02.94	**0 261 210 029**
Temperature sensor, coolant, injection system	10.89-02.94	**0 280 130 026**
T		**3,4 l 221 kW F 119 DL 8 Zyl.**
Throttle valve sensor	11.88-02.94	**0 280 120 311**
Air mass meter, gasoline injection	11.88-02.94	**0 280 212 018**
Speed sensor, ignition/injection	11.88-02.94	**0 261 210 029**
Temperature sensor, coolant, injection system	11.88-02.94	**0 280 130 026**
Relay, pump	11.88-02.94	**0 332 014 140**
8		**3,2 l 199 kW F 105 NS.. 8 Zyl.**
Throttle valve sensor	01.88-12.88	**0 280 120 310**
Air flow sensor, gasoline injection	01.88-12.88	**0 438 120 207**
Relay, Jetronic	01.88-12.88	**0 332 204 001**
8		**3,2 l 199 kW F 105 P..Kat. 4 Zyl.**
Air flow sensor, gasoline injection	01.88-12.88	**0 438 121 066**
Pressure sensor, intake manifold, gasoline	01.88-12.88	**0 280 101 003**
Relay, Jetronic	01.88-12.88	**0 280 230 009**
8 Quattrovalvole		**2,9 l 169 kW F 105 E..Kat. 8 Zyl.**
Throttle valve sensor	10.83-07.87	**0 280 120 310**
Air flow sensor, gasoline injection	10.83-07.87	**0 438 120 164**
Pressure sensor, intake manifold, gasoline	10.83-07.87	**0 280 101 003**
Relay, Jetronic	10.83-07.87 12S	**0 332 204 101**
8 Quattrovalvole		**3,2 l 191 kW F 105 C..Kat. 8 Zyl.**
Throttle valve sensor	01.86-12.87	**0 280 120 310**
Air flow sensor, gasoline injection	01.86-12.87	**0 438 120 164**
Pressure sensor, intake manifold, gasoline	01.86-12.87	**0 280 101 003**
8 Quattrovalvole		**3,2 l 195/199 kW F 105 C.. 8 Zyl.**
Throttle valve sensor	09.85-12.87	**0 280 120 310**
Air flow sensor, gasoline injection	09.85-12.87	**0 438 120 207**
Relay, Jetronic	09.85-12.87	**0 332 204 001**

Testarossa

4.9		**4,9 l 272 kW F 113 B..Kat. 12 Zyl.**
Throttle valve sensor	08.86-10.91	**0 280 120 310**
Air flow sensor, gasoline injection	08.86-10.91	**F 026 TX2 065**
		F 026 TX2 065
Pressure sensor, intake manifold, gasoline	08.86-10.91	**0 280 101 001**
Temperature sensor, coolant, injection system	08.86-10.91	**0 280 130 032**

D

Product			
4.9			**4,9 l 287 kW F 113 A../B.. 12 Zyl.**
Throttle valve sensor	01.86-10.91		**0 280 120 310**
Air flow sensor, gasoline injection	01.86-10.91		**F 026 TX2 065**
			F 026 TX2 065
Pressure sensor, intake manifold, gasoline	01.86-10.91		**0 280 101 001**
Temperature sensor, coolant, injection system	01.86-10.91		**0 280 130 032**
Relay, Jetronic	01.86-10.91		**0 280 230 012**

208

GTB Turbo			**2,0 l 162 kW F 106 D.. 8 Zyl.**
Air flow sensor, gasoline injection	06.82-10.89		**0 438 120 191**
Speed relay	06.82-10.89		**0 280 230 008**
Relay, pump	06.82-10.89		**0 280 230 007**
GTB Turbo			**2,0 l 187 kW F 106 N.. 8 Zyl.**
Throttle valve sensor	04.86-10.90		**0 280 120 314**
Air flow sensor, gasoline injection	04.86-10.90		**0 438 120 212**
GTS Turbo			**2,0 l 187 kW F 106 N.. 8 Zyl.**
Throttle valve sensor	04.86-10.90		**0 280 120 314**
Air flow sensor, gasoline injection	04.86-10.90		**0 438 120 212**

328

GTB			**3,2 l 188 kW F 105 C.. 8 Zyl.**
Throttle valve sensor	09.85-09.89		**0 280 120 310**
Air flow sensor, gasoline injection	09.85-09.89		**0 438 120 164**
Relay, Jetronic	09.85-09.89		**0 332 204 001**
GTB			**3,2 l 195/199 kW F 105 C.. 8 Zyl.**
Throttle valve sensor	09.85-12.88		**0 280 120 310**
Air flow sensor, gasoline injection	09.85-12.88		**0 438 120 207**
Relay, Jetronic	09.85-12.88		**0 332 204 001**
GTB			**3,2 l 199 kW F 105 CB.. 8 Zyl.**
Throttle valve sensor	01.88-09.89		**0 280 120 310**
Air flow sensor, gasoline injection	01.88-09.89		**0 438 120 207**
Relay, Jetronic	01.88-09.89		**0 332 204 001**
GTS			**3,2 l 195/199 kW F 105 C..; F 105 CB.. 8 Zyl.**
Throttle valve sensor	09.85-09.89		**0 280 120 310**
Air flow sensor, gasoline injection	09.85-09.89		**0 438 120 207**
Relay, Jetronic	09.85-09.89		**0 332 204 001**

348

TB			**3,4 l 217-221 kW F 119 F 000 8 Zyl.**
Air mass meter, gasoline injection	02.90-04.94		**0 280 212 018**
Temperature sensor, coolant, injection system	02.90-04.94		**0 280 130 026**
TS			**3,4 l 217-221 kW F 119 F 000 8 Zyl.**
Air mass meter, gasoline injection	08.90-04.94		**0 280 212 018**
Temperature sensor, coolant, injection system	08.90-04.94		**0 280 130 026**

412

4.9 i			**4,9 l 245/250 kW F 101 E.. 12 Zyl.**
Throttle valve sensor	06.85-12.88		**0 280 120 314**
Air flow sensor, gasoline injection	06.85-12.88		**0 438 120 206**
Relay, Jetronic	06.85-12.88		**0 332 014 113**
		12S	**0 332 204 101**
Wheel speed sensor, front	06.85-12.88	LAB	**0 265 001 091**
		RAB	**0 265 001 090**
Wheel speed sensor, rear	06.85-12.88	LAB	**0 265 001 093**
		RAB	**0 265 001 092**
4.9 i			**4,9 l 250 kW F 101 C.. 12 Zyl.**
Relay, Jetronic	07.86-12.88		**0 332 014 113**
		12S	**0 332 204 101**
Wheel speed sensor, front	07.86-12.88	LAB	**0 265 001 091**
		RAB	**0 265 001 090**
Wheel speed sensor, rear	07.86-12.88	LAB	**0 265 001 093**
		RAB	**0 265 001 092**

456

GT 2+2			**5,5 l 325 kW F 116 B 00 12 Zyl.**
Throttle valve sensor	01.93-03.96		**0 280 122 001**
Air mass meter, gasoline injection	01.93-03.96		**0 280 213 012**
			0 986 280 110
Phase sensor	01.93-03.96		**0 232 103 006**
Temperature sensor, coolant, injection system	01.93-03.96		**0 280 130 026**
GT/GTR 48V			**5,5 l 325 kW F 116 V12 12 Zyl.**
Throttle valve sensor	03.96-12.04		**0 280 122 004**
Air mass meter, gasoline injection	03.96-12.04		**0 280 217 521**
Phase sensor	03.96-12.04		**0 232 103 006**
Speed sensor, ignition/injection	03.96-12.04		**0 261 210 152**
Temperature sensor, intake air, injection system	03.96-12.04		**0 280 130 039**
Temperature sensor, coolant, injection system	03.96-12.04		**0 280 130 026**
Wheel speed sensor, front	03.96-12.04		**0 265 006 252**
Wheel speed sensor, rear	03.96-12.04		**0 265 006 253**

512

TR			**5,0 l 315 kW F 113 D 00/40 12 Zyl.**
Throttle valve sensor	01.92-10.94		**0 280 122 001**
Air mass meter, gasoline injection	01.92-10.94		**0 280 213 023**
Phase sensor	01.92-10.94		**0 232 101 016**
Speed sensor, ignition/injection	01.92-10.94		**0 261 210 029**
Temperature sensor, coolant, injection system	01.92-10.94		**0 280 130 026**
Wheel speed sensor, front	01.92-10.92		**0 265 001 361**
	11.92-10.94		**0 265 006 116**
Wheel speed sensor, rear	01.92-10.92		**0 265 001 363**
	11.92-10.94		**0 265 006 117**

550

Maranello			**5,5 l 357 kW F 133 12 Zyl.**
Throttle valve sensor	10.96→		**0 280 122 004**
Air mass meter, gasoline injection	10.96→		**0 280 217 521**
Temperature sensor, intake air, injection system	10.96→		**0 280 130 039**
Temperature sensor, coolant, injection system	10.96→		**0 280 130 026**

FIAT

Albea

1.2 i.e. 8V [172..]			**1,2 l 44 kW 188 A 4.000 4 Zyl.**
Speed sensor, ignition/injection	01.02→		**0 261 210 114**
1.2 i.e. 16V [172..]			**1,2 l 59 kW 188 A 5.000 4 Zyl.**
Throttle valve assembly	01.02→		**F 01C 600 023**
Speed sensor, ignition/injection	01.02→		**0 261 210 219**
Knock sensor	01.02→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	01.02→		**0 261 230 030**
Accelerator pedal module	01.02→		**0 281 002 379**
Wheel speed sensor, front	01.02→	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	01.02→		**0 265 007 126**
1.2 i.e. 16V LPG [172..]			**1,2 l 57-59 kW 188 A 5.000 4 Zyl.**
Throttle valve assembly	07.05→		**F 01C 600 023**
Speed sensor, ignition/injection	07.05→		**0 261 210 219**

F

Product			
◀ Albea			
Knock sensor	07.05→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	07.05→		**0 261 230 030**
Accelerator pedal module	07.05→		**0 281 002 379**
Wheel speed sensor, front	07.05→	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	07.05→		**0 265 007 126**
1.3 JTD 16V [172..]	**1,2 l 52 kW 188 A 9.000 4 Zyl.**		
Air mass meter, diesel	07.03→		**0 281 002 613**
High-pressure sensor (CR system)	07.03→		**0 281 002 534**
Boost pressure sensor, Diesel	07.03-05.06		**0 281 002 510**
	06.06→		**0 281 002 844**
Accelerator pedal module	07.03→		**0 281 002 379**
Wheel speed sensor, front	07.03→	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	07.03→		**0 265 007 126**
1.4 i.e. 8V [172..]	**1,4 l 57 kW 350 A 1.000 4 Zyl.**		
Phase sensor	07.06→		**0 232 103 048**
Pressure sensor, intake manifold, gasoline	07.06→		**0 261 230 030**
Accelerator pedal module	07.06→		**0 281 002 379**
Wheel speed sensor, front	07.06→	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	07.06→		**0 265 007 126**
1.6 i.e. 16V [172..]	**1,6 l 76 kW 182 B 6.000 4 Zyl.**		
Wheel speed sensor, front	01.02→	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	01.02→		**0 265 007 126**

Barchetta

1.8 i.e. 16V [183..]	**1,8 l 96 kW 183 A 1.000 4 Zyl.**		
Phase sensor			
Ricam.no →0037640	01.95-05.98		**0 232 101 026**
Ricam.no 0037641→	06.98-09.00		**0 232 101 037**
Temperature sensor, coolant, injection system			
Ricam.no →37640	01.95-05.98		**0 280 130 026**
Wheel speed sensor, front			
Ricam.no →43319	01.95-05.99		**0 265 006 138**
Ricam.no 43320→	06.99-09.00	LAB	**0 265 007 024**
		RAB	**0 265 007 025**
Wheel speed sensor, rear			
Ricam.no →43319	01.95-05.99	LAB	**0 265 006 210**
Ricam.no →0043319	01.95-05.99	RAB	**0 265 006 211**
Ricam.no 43320→	06.99-09.00	LAB	**0 265 007 026**
		RAB	**0 265 007 027**
1.8 i.e. 16V [183..]	**1,8 l 96 kW 188 A 6.000 4 Zyl.**		
Phase sensor	10.00-02.05		**0 232 101 037**
Wheel speed sensor, front	10.00-02.05	LAB	**0 265 007 024**
		RAB	**0 265 007 025**
Wheel speed sensor, rear	10.00-02.05	LAB	**0 265 007 026**
		RAB	**0 265 007 027**

Brava

1.2 16V [182..]	**1,2 l 60 kW 182 B 2.000 4 Zyl.**		
Throttle valve assembly	11.98-09.01		**0 280 750 013**
Speed sensor, ignition/injection	11.98-09.01		**0 261 210 124**
Knock sensor	11.98-09.01		**0 261 231 007**
Pressure sensor, intake manifold, gasoline	11.98-09.01		**0 261 230 035**
1.2 16V [182..]	**1,2 l 60 kW 188 A 5.000 4 Zyl.**		
Throttle valve assembly	08.00-09.01		**F 01C 600 023**
Speed sensor, ignition/injection	08.00-09.01		**0 261 210 220**
Knock sensor	08.00-09.01		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	08.00-09.01		**0 261 230 030**
1.4 12V [182..]	**1,4 l 55/59 kW 182 A 3.000; 182 A 5.000 4 Zyl.**		
Speed sensor, ignition/injection	10.95-10.98		**0 281 002 102**
Knock sensor	10.95-10.98		**0 261 231 007**
Temperature sensor, coolant, injection system	10.95-10.98		**0 280 130 026**
1.6 MPI 16V	**1,6 l 78 kW 178 A 8.011; 182 B 6.000 4 Zyl.**		
Wheel speed sensor, front	08.99-06.03	VLI	**0 265 007 034**
		VRE	**0 265 007 035**
Wheel speed sensor, rear	08.99-06.03	HLI	**0 265 007 032**
		HRE	**0 265 007 033**
1.8 MPI 16V	**1,8 l 97 kW 183 A 1.000 4 Zyl.**		
Phase sensor	02.00-06.03		**0 232 101 037**
Wheel speed sensor, front	02.00-06.03	VLI	**0 265 007 034**
		VRE	**0 265 007 035**
Wheel speed sensor, rear	02.00-06.03	HLI	**0 265 007 032**
		HRE	**0 265 007 033**
1.8 16V [182..]	**1,8 l 83 kW 182 A 2.000 4 Zyl.**		
Phase sensor			
Ricam.no →4873621	11.98-07.99		**0 232 101 026**
Ricam.no 4873622→	08.99-09.01		**0 232 101 037**
Temperature sensor, coolant, injection system	10.95-07.99		**0 280 130 055**
1.9 JTD [182..]	**1,9 l 76 kW 182 B 4.000 4 Zyl.**		
Air mass meter, diesel	11.98-09.01		**0 280 218 019**
Speed sensor, diesel	11.98-09.01		**0 281 002 214**
Phase sensor	11.98-09.01		**0 281 002 213**
High-pressure sensor (CR system)	11.98-09.01		**0 281 002 210**
Boost pressure sensor, Diesel	11.98-09.01		**0 281 002 215**
Temperature sensor, fuel	11.98-09.01		**0 281 002 209**
1.9 JTD [182..]	**1,9 l 76 kW 182 B 9.000 4 Zyl.**		
Air mass meter, diesel	08.00-09.01		**0 281 002 309**
Speed sensor, diesel	08.00-09.01		**0 281 002 214**
Phase sensor	08.00-09.01		**0 281 002 213**
High-pressure sensor (CR system)	08.00-09.01		**0 281 002 260**
Boost pressure sensor, Diesel	08.00-09.01		**0 281 002 215**
Temperature sensor, fuel	08.00-09.01		**0 281 002 209**
1.9 TD [182..]	**1,9 l 55 kW 182 A 8.000 4 Zyl.**		
Speed sensor, diesel	03.96-09.01		**0 281 002 102**
1.9 TD [182..]	**1,9 l 73/73,6 kW 182 A 7.000 4 Zyl.**		
Air mass meter, diesel	03.96-09.01		**0 281 002 144**
Speed sensor, diesel	03.96-09.01		**0 281 002 102**
Temperature sensor, intake air, diesel	03.96-09.01		**0 280 130 073**

Bravo

1.2 16V [182..]	**1,2 l 60 kW 182 B 2.000 4 Zyl.**		
Throttle valve assembly	11.98-09.01		**0 280 750 013**
Speed sensor, ignition/injection	11.98-09.01		**0 261 210 124**
Knock sensor	11.98-09.01		**0 261 231 007**
Pressure sensor, intake manifold, gasoline	11.98-09.01		**0 261 230 035**
1.2 16V [182..]	**1,2 l 60 kW 188 A 5.000 4 Zyl.**		
Throttle valve assembly	08.00-09.01		**F 01C 600 023**
Speed sensor, ignition/injection	08.00-09.01		**0 261 210 220**
Knock sensor	08.00-09.01		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	08.00-09.01		**0 261 230 030**
1.4 Turbo 16V [198]	**1,4 l 110 kW 198 A 1.000 4 Zyl.**		
Speed sensor, ignition/injection	07.07→		**0 261 210 238**
Knock sensor	07.07→		**0 261 231 173**
Pressure sensor, ESP, (electronic stability program)	07.07→		**0 265 005 303**
Wheel speed sensor, front	07.07→		**0 265 008 002**
Wheel speed sensor, rear	07.07→		**0 265 008 003**
1.4 12V [182..]	**1,4 l 55/59 kW 182 A 3.000; 182 A 5.000 4 Zyl.**		
Speed sensor, ignition/injection	10.95-10.98		**0 281 002 102**
Knock sensor	10.95-10.98		**0 261 231 007**
Temperature sensor, coolant, injection system	10.95-10.98		**0 280 130 026**

Product		
1.4 16V [198]	**1,4 l 66 kW 192 B 2.000 4 Zyl.**	
Throttle valve assembly	03.07→	**F 01C 600 027**
Phase sensor	03.07→	**0 232 103 048**
Speed sensor, ignition/injection	03.07→	**0 261 210 238**
Knock sensor	03.07→	**0 261 231 173**
Pressure sensor, intake manifold, gasoline	03.07→	**F 01C 600 070**
Pressure sensor, ESP, (electronic stability program)	03.07→	**0 265 005 303**
Wheel speed sensor, front	03.07→	**0 265 008 002**
Wheel speed sensor, rear	03.07→	**0 265 008 003**
1.8 16V [182..]	**1,8 l 83 kW 182 A 2.000 4 Zyl.**	
Phase sensor	10.95-10.98	**0 232 101 026**
Ricam.no →4873621	11.98-07.99	**0 232 101 026**
Ricam.no 4873622→	08.99-09.01	**0 232 101 037**
Temperature sensor, coolant, injection system	11.98-07.99	**0 280 130 055**
Relay, Jetronic	10.95-10.98 DID	**0 332 014 112**
1.9 JTD [182..]	**1,9 l 76 kW 182 B 4.000 4 Zyl.**	
Air mass meter, diesel	11.98-09.01	**0 280 218 019**
Speed sensor, diesel	11.98-09.01	**0 281 002 214**
Phase sensor	11.98-09.01	**0 281 002 213**
High-pressure sensor (CR system)	11.98-09.01	**0 281 002 210**
Boost pressure sensor, Diesel	11.98-09.01	**0 281 002 215**
Temperature sensor, fuel	11.98-09.01	**0 281 002 209**
1.9 JTD [182..]	**1,9 l 76 kW 182 B 9.000 4 Zyl.**	
Air mass meter, diesel	08.00-09.01	**0 281 002 309**
Speed sensor, diesel	08.00-09.01	**0 281 002 214**
Phase sensor	08.00-09.01	**0 281 002 213**
High-pressure sensor (CR system)	08.00-09.01	**0 281 002 260**
Boost pressure sensor, Diesel	08.00-09.01	**0 281 002 215**
Temperature sensor, fuel	08.00-09.01	**0 281 002 209**
1.9 JTD 8V [198]	**1,9 l 66 kW 192 B 5.000 4 Zyl.**	
Air mass meter, diesel	03.07-06.07	**0 281 002 792**
Speed sensor, diesel	03.07→	**0 281 002 603**
Phase sensor	03.07→	**0 281 002 213**
Boost pressure sensor, Diesel	03.07→	**0 281 002 845**
Pressure sensor, ESP, (electronic stability program)	03.07→	**0 265 005 303**
Wheel speed sensor, front	03.07→	**0 265 008 002**
Wheel speed sensor, rear	03.07→	**0 265 008 003**
1.9 JTD 8V [198]	**1,9 l 66 kW 198 A 1.000 4 Zyl.**	
Boost pressure sensor, Diesel	10.07→	**0 281 002 845**
Pressure sensor, ESP, (electronic stability program)	10.07→	**0 265 005 303**
Wheel speed sensor, front	10.07→	**0 265 008 002**
Wheel speed sensor, rear	10.07→	**0 265 008 003**
1.9 JTD 8V [198]	**1,9 l 85/88 kW 192 A 1.000; 192 A 8.000 4 Zyl.**	
Air mass meter, diesel	03.07-06.07	**0 281 002 792**
Speed sensor, diesel	03.07→	**0 281 002 603**
Phase sensor	03.07→	**0 281 002 213**
Boost pressure sensor, Diesel	03.07→	**0 281 002 845**
Pressure sensor, ESP, (electronic stability program)	03.07→	**0 265 005 303**
Wheel speed sensor, front	03.07→	**0 265 008 002**
Wheel speed sensor, rear	03.07→	**0 265 008 003**
1.9 JTD 16V [198]	**1,9 l 110 kW 937 A 5.000 4 Zyl.**	
Boost pressure sensor, Diesel	07.07→	**0 281 002 845**
Pressure sensor, ESP, (electronic stability program)	07.07→	**0 265 005 303**
Wheel speed sensor, front	07.07→	**0 265 008 002**
Wheel speed sensor, rear	07.07→	**0 265 008 003**
1.9 TD [182..]	**1,9 l 55 kW 182 A 8.000 4 Zyl.**	
Speed sensor, diesel	03.96-09.01	**0 281 002 102**
1.9 TD [182..]	**1,9 l 73/73,6 kW 182 A 7.000 4 Zyl.**	
Air mass meter, diesel	03.96-09.01	**0 281 002 144**
Speed sensor, diesel	03.96-09.01	**0 281 002 102**
Temperature sensor, intake air, diesel	03.96-09.01	**0 280 130 073**

Product		
2.0 20V [182..]	**2,0 l 108 kW 182 A 1.000 5 Zyl.**	
Throttle valve sensor	10.95-10.98	**0 280 122 001**
Air mass meter, gasoline injection	10.95-10.98	**0 280 217 111**
Phase sensor	10.95-10.98	**0 232 101 026**
Speed sensor, ignition/injection	10.95-10.98	**0 281 002 102**
Knock sensor	10.95-10.98	**0 261 231 095**
Temperature sensor, intake air, injection system	10.95-10.98	**0 280 130 073**
Temperature sensor, coolant, injection system	10.95-10.98	**0 280 130 026**
Relay, Jetronic	10.95-10.98	**0 332 014 140**
2.0 20V [182..]	**2,0 l 113 kW 182 B 7.000 5 Zyl.**	
Throttle valve assembly	11.98-09.01	**0 205 003 052**
Air mass meter, gasoline injection	11.98-09.01	**0 280 218 019**
Phase sensor	11.98-09.01	**0 232 101 036**
Speed sensor, ignition/injection	11.98-09.01	**0 261 210 160**
Knock sensor	11.98-09.01	**0 261 231 144**

Coupé

1.8 i 16V [175..]	**1,8 l 96 kW 183 A 1.000 4 Zyl.**	
Air mass meter, gasoline injection	03.96-09.96	**0 280 217 514**
Phase sensor	03.96-09.96	**0 232 101 026**
Temperature sensor, coolant, injection system	03.96-09.96	**0 280 130 026**
Wheel speed sensor, front	03.96-09.96	**0 265 006 212**
Wheel speed sensor, rear	03.96-09.96	**0 265 006 197**
1.8 16V [175..]	**1,8 l 96 kW 183 A 1.000 4 Zyl.**	
Phase sensor		
Mot.no. →1070426	10.96-04.98	**0 232 101 026**
Mot.no. 1070427→	05.98-09.00	**0 232 101 037**
Temperature sensor, coolant, injection system	10.96-05.98	**0 280 130 026**
Wheel speed sensor, front	10.96-09.00	**0 265 006 124**
Wheel speed sensor, rear	10.96-09.00	**0 265 006 197**
2.0 i 16V [175..]	**2,0 l 104 kW 836 A 3.000; 836 A 3.011 4 Zyl.**	
Wheel speed sensor, front	04.94-09.96	**0 265 006 212**
Wheel speed sensor, rear	04.94-09.96	**0 265 006 197**
2.0 i 16V Turbo [175..]	**2,0 l 143 kW 175 A 1.000 4 Zyl.**	
Knock sensor	04.94-09.96	**0 261 231 095**
Wheel speed sensor, front	02.94-09.96	**0 265 006 162**
Wheel speed sensor, rear	02.94-09.96	**0 265 006 197**
2.0 20V [175..]	**2,0 l 108 kW 182 A 1.000 5 Zyl.**	
Throttle valve sensor	10.96-03.98	**0 280 122 001**
Air mass meter, gasoline injection	10.96-03.98	**0 280 217 111**
Phase sensor	10.96-03.98	**0 232 101 026**
Speed sensor, ignition/injection	10.96-03.98	**0 281 002 102**
Knock sensor	10.96-03.98	**0 261 231 095**
Temperature sensor, intake air, injection system	10.96-03.98	**0 280 130 073**
Temperature sensor, coolant, injection system	10.96-03.98	**0 280 130 055**
Relay, Jetronic	10.96-03.98	**0 332 014 140**
Wheel speed sensor, front	10.96-03.98	**0 265 006 124**
Wheel speed sensor, rear	10.96-03.98	**0 265 006 197**
2.0 20V [175..]	**2,0 l 113 kW 182 B 3.000 5 Zyl.**	
Throttle valve assembly	04.98-09.00	**0 205 003 052**
Air mass meter, gasoline injection	04.98-09.00	**0 280 218 019**
Phase sensor	04.98-09.00	**0 232 101 036**
Speed sensor, ignition/injection	04.98-09.00	**0 261 210 160**
Knock sensor	04.98-09.00	**0 261 231 144**
Temperature sensor, intake air, injection system	04.98-09.00	**0 280 130 073**
Wheel speed sensor, front	04.98-09.00	**0 265 006 124**
Wheel speed sensor, rear	04.98-09.00	**0 265 006 197**
2.0 20V Turbo [175..]	**2,0 l 162 kW 175 A 3.000 5 Zyl.**	
Throttle valve sensor	10.96-09.00	**0 280 122 001**
Air mass meter, gasoline injection	10.96-09.00	**0 280 217 514**
Phase sensor	10.96-09.00	**0 232 101 026**

F

Product

◀ Coupé

Speed sensor, ignition/injection	10.96-09.00		**0 281 002 102**
Knock sensor	10.96-09.00		**0 261 231 007**
Pressure sensor, intake manifold, gasoline	10.96-09.00		**0 280 101 001**
Temperature sensor, intake air, injection system	10.96-09.00		**0 280 130 060**
Temperature sensor, coolant, injection system			
Mot.no. →1368080	10.96-09.00	LLE	**0 280 130 055**
Mot.no. →1373288	10.96-09.00	RLE	**0 280 130 055**
Relay, Jetronic	10.96-09.00		**0 332 014 140**
Relay, pump	10.96-09.00		**0 332 014 140**
Wheel speed sensor, front	10.96-09.00		**0 265 006 124**
Wheel speed sensor, rear	10.96-09.00		**0 265 006 197**

Croma

1.9 TD i.d. [154..]		**1,9 l 69 kW 154 C 6.000 4 Zyl.**	
Wheel speed sensor, front	07.90-10.92		**0 265 006 262**
Wheel speed sensor, rear			
Ricam.no →0001448	07.90-10.92		**0 265 003 075**
1.9 TD i.d. [154..]		**1,9 l 69 kW 154 D 1.000 4 Zyl.**	
Wheel speed sensor, front	11.92-12.96		**0 265 006 262**
Wheel speed sensor, rear			
Ricam.no →0001448	11.92-01.94		**0 265 003 075**
Ricam.no 0001449→	02.94-12.96		**0 265 006 238**
2.0 [154..]		**2,0 l 66 kW 154 A 1.000 4 Zyl.**	
Wheel speed sensor, front	12.85-02.89		**0 265 001 072**
Wheel speed sensor, rear	12.85-02.89	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.0 [154..]		**2,0 l 72 kW 154 C 2.000 CHT 4 Zyl.**	
Wheel speed sensor, front	03.89-06.90		**0 265 006 262**
Wheel speed sensor, rear	03.89-06.90		**0 265 003 075**
2.0 [154..]		**2,0 l 74 kW 154 C 5.000 CHT 4 Zyl.**	
Wheel speed sensor, front	07.90-11.92		**0 265 006 262**
Wheel speed sensor, rear	07.90-11.92		**0 265 003 075**
Ricam.no →0001448	07.90-11.92		**0 265 003 075**
2.0 i.e. [154..]		**2,0 l 83 kW 834 B.048 4 Zyl.**	
Throttle valve sensor	03.86-09.90		**0 280 120 311**
Air flow sensor, gasoline injection	03.86-09.90		**0 280 202 102**
			0 986 280 054
Temperature sensor, coolant, injection system	03.86-09.90		**0 280 130 026**
Relay, Jetronic	03.86-09.90		**0 280 230 006**
Wheel speed sensor, front	03.86-09.90		**0 265 001 072**
Wheel speed sensor, rear	03.86-09.90	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.0 i.e. [154..]		**2,0 l 85 kW 154 C 3.046 4 Zyl.**	
Throttle valve sensor	10.90-12.96		**0 280 120 311**
Air flow sensor, gasoline injection	10.90-12.96		**0 280 202 102**
			0 986 280 054
Temperature sensor, coolant, injection system	10.90-12.96		**0 280 130 026**
Relay, Jetronic	10.90-12.96		**0 280 230 006**
Wheel speed sensor, front	10.90-12.96		**0 265 006 262**
Wheel speed sensor, rear			
Ricam.no →0001448	10.90-01.94		**0 265 003 075**
Ricam.no 0001449→	02.94-12.96		**0 265 006 238**
2.0 i.e. [154..]		**2,0 l 85 kW 834 B.146 4 Zyl.**	
Air flow sensor, gasoline injection	11.92-12.96		**0 280 202 102**
			0 986 280 054
Temperature sensor, coolant, injection system	11.92-12.96		**0 280 130 026**
Relay, Jetronic	11.92-12.96		**0 280 230 006**
Wheel speed sensor, front	11.92-12.96		**0 265 006 262**
Wheel speed sensor, rear			
Ricam.no →0001448	11.92-01.94		**0 265 003 075**
Ricam.no 0001449→	02.94-12.96		**0 265 006 238**

Product

2.0 i.e. [154..]		**2,0 l 86 kW 154 C 3.000 4 Zyl.**	
Air flow sensor, gasoline injection	05.91-12.96		**0 280 202 059**
			0 986 280 044
Temperature sensor, coolant, injection system	05.91-12.96		**0 280 130 026**
Wheel speed sensor, front	07.90-12.96		**0 265 006 262**
Wheel speed sensor, rear			
Ricam.no →0001448	07.90-01.94		**0 265 003 075**
Ricam.no 0001449→	02.94-12.96		**0 265 006 238**
2.0 i.e. [154..]		**2,0 l 86 kW 834 B.146 4 Zyl.**	
Air flow sensor, gasoline injection	11.92-12.96		**0 280 202 102**
			0 986 280 054
Temperature sensor, coolant, injection system	11.92-12.96		**0 280 130 026**
Wheel speed sensor, front	11.92-12.96		**0 265 006 262**
Wheel speed sensor, rear			
Ricam.no →0001448	11.92-01.94		**0 265 003 075**
Ricam.no 0001449→	02.94-12.96		**0 265 006 238**
2.0 i.e. [154..]		**2,0 l 89 kW 834 AB 000 MPI-Bosch 4 Zyl.**	
Throttle valve sensor	12.85-06.90		**0 280 120 311**
Air flow sensor, gasoline injection	12.85-06.90		**0 280 202 059**
			0 986 280 044
Temperature sensor, coolant, injection system	12.85-06.90		**0 280 130 026**
Relay, Jetronic	12.85-06.90		**0 280 230 006**
Wheel speed sensor, front	12.85-06.90		**0 265 001 072**
Wheel speed sensor, rear	12.85-06.90	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.0 i.e. Turbo [154..]		**2,0 l 110 kW 154 C 4.046 4 Zyl.**	
Air flow sensor, gasoline injection	10.90-12.96		**0 280 202 103**
Temperature sensor, coolant, injection system	10.90-12.96		**0 280 130 026**
Relay, Jetronic	10.90-11.92		**0 280 230 009**
Wheel speed sensor, front	10.90-12.96		**0 265 006 262**
Wheel speed sensor, rear			
Ricam.no →0001448	10.90-01.94		**0 265 003 075**
Ricam.no 0001449→	02.94-12.96		**0 265 006 238**
2.0 i.e. Turbo [154..]		**2,0 l 110 kW 834 C.146 MPI-Bosch 4 Zyl.**	
Throttle valve sensor	07.86-09.90		**0 280 120 323**
Air flow sensor, gasoline injection	07.86-09.90		**0 280 202 103**
Temperature sensor, coolant, injection system	07.86-09.90		**0 280 130 026**
Relay, Jetronic			
Ricam.no →0281951	07.86-09.90		**0 280 230 006**
Ricam.no 0281952→	07.86-09.90		**0 280 230 009**
Wheel speed sensor, front	07.86-09.90		**0 265 001 072**
Wheel speed sensor, rear	07.86-09.90	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.0 i.e. Turbo [154..]		**2,0 l 114 kW 154 A 2.000 4 Zyl.**	
Throttle valve sensor	12.85-06.90		**0 280 120 312**
Air flow sensor, gasoline injection	12.85-04.90		**0 280 202 060**
			0 986 280 046
	05.90-06.90		**0 280 202 128**
Temperature sensor, coolant, injection system	12.85-06.90		**0 280 130 026**
Relay, Jetronic			
Ricam.no →0281951	12.85-06.90		**0 280 230 006**
Ricam.no 0281952→	12.85-06.90		**0 280 230 009**
Wheel speed sensor, front	12.85-06.90		**0 265 001 072**
Wheel speed sensor, rear	12.85-06.90	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.0 i.e. Turbo [154..]		**2,0 l 116 kW 154 C 4.000 4 Zyl.**	
Throttle valve sensor	07.90-11.92		**0 280 120 312**
Air flow sensor, gasoline injection	07.90-11.92		**0 280 202 128**
Temperature sensor, coolant, injection system	07.90-11.92		**0 280 130 026**
Relay, Jetronic	07.90-11.92		**0 280 230 009**
Wheel speed sensor, front	07.90-11.92		**0 265 006 262**
Wheel speed sensor, rear			
Ricam.no →0001448	07.90-11.92		**0 265 003 075**

F

Product			
2.0 i.e. 16V [154..]			**2,0 l 101 kW 154 E 1.000 4 Zyl.**
Throttle valve sensor	11.92-12.96		**0 280 122 001**
Air flow sensor, gasoline injection	11.92-12.96		**0 280 202 211**
			0 986 280 091
Speed sensor, ignition/injection	11.92-12.96		**0 261 210 093**
Knock sensor	11.92-12.96		**0 261 231 095**
Temperature sensor, coolant, injection system	11.92-12.96		**0 280 130 026**
Relay, Jetronic	11.92-12.96		**0 280 230 018**
		DID	**0 332 014 112**
Wheel speed sensor, front	11.92-12.96		**0 265 006 262**
Wheel speed sensor, rear			
Ricam.no →0001448	11.92-01.94		**0 265 003 075**
Ricam.no 0001449→	02.94-12.96		**0 265 006 238**
2.0 i.e. 16V [154..]			**2,0 l 101 kW 154 E 1.027 4 Zyl.**
Throttle valve sensor	03.95-12.96		**0 280 122 001**
Air flow sensor, gasoline injection	03.95-12.96		**0 280 202 211**
			0 986 280 091
Speed sensor, ignition/injection	03.95-12.96		**0 261 210 093**
Knock sensor	03.95-12.96		**0 261 231 095**
Temperature sensor, coolant, injection system	03.95-12.96		**0 280 130 026**
Wheel speed sensor, front	03.95-12.96		**0 265 006 262**
Wheel speed sensor, rear			
Ricam.no 0001449→	03.95-12.96		**0 265 006 238**
2.5 D [154..]			**2,5 l 55 kW 8144.67 4 Zyl.**
Wheel speed sensor, front	12.85-12.89		**0 265 001 072**
Wheel speed sensor, rear	12.85-12.89	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.5 i.e. [154..]			**2,5 l 117 kW 834 G.000 6 Zyl.**
Air flow sensor, gasoline injection	06.93-12.96		**0 280 202 211**
			0 986 280 091
Speed sensor, ignition/injection	06.93-12.96		**0 261 210 090**
Temperature sensor, coolant, injection system	06.93-12.96		**0 280 130 026**
Wheel speed sensor, front	06.93-12.96		**0 265 006 262**
Wheel speed sensor, rear			
Ricam.no →0001448	06.93-01.94		**0 265 003 075**
Ricam.no 0001449→	02.94-12.96		**0 265 006 238**
2.5 TD [154..]			**2,5 l 74 kW 8144.91.2200 4 Zyl.**
Wheel speed sensor, front	12.85-02.89		**0 265 001 072**
Wheel speed sensor, rear	12.85-02.89	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.5 TD [154..]			**2,5 l 77 kW 8144.97 S 4 Zyl.**
Wheel speed sensor, front	12.91-11.92		**0 265 006 262**
Wheel speed sensor, rear			
Ricam.no →0001448	12.91-11.92		**0 265 003 075**
2.5 TD [154..]			**2,5 l 85 kW 8144.97Y (EM.04) 4 Zyl.**
Wheel speed sensor, front	11.92-12.96		**0 265 006 262**
Wheel speed sensor, rear			
Ricam.no →0001448	11.92-01.94		**0 265 003 075**
Ricam.no 0001449→	02.94-12.96		**0 265 006 238**
2.5 TD [154..]			**2,5 l 85 kW 8144.97.2200 4 Zyl.**
Wheel speed sensor, front	03.89-06.90		**0 265 006 262**
Wheel speed sensor, rear	03.89-06.90		**0 265 003 075**
2.5 TD [154..]			**2,5 l 86 kW 8144.97 4 Zyl.**
Wheel speed sensor, front	07.90-10.92		**0 265 006 262**
Wheel speed sensor, rear			
Ricam.no →0001448	07.90-10.92		**0 265 003 075**
2.5 TDI [154..]			**2,5 l 85 kW 8144.97Y (US87) 4 Zyl.**
Air flow sensor, diesel	09.93-11.96		**0 281 002 088**
Speed sensor, ignition/injection	09.93-11.96		**0 261 210 093**
Temperature sensor, coolant, diesel	09.93-11.96		**0 280 130 026**
Pedal position sensor, diesel	09.93-11.96		**0 205 001 010**
Wheel speed sensor, front	09.93-11.96		**0 265 006 262**

Product			
Wheel speed sensor, rear			
Ricam.no →0001448	09.93-01.94		**0 265 003 075**
Ricam.no 0001449→	02.94-11.96		**0 265 006 238**

Doblo

1.2 i.e. 8V [119..]			**1,2 l 48 kW 223 A 5.000 4 Zyl.**
Phase sensor	07.00-09.05		**0 232 103 039**
Speed sensor, ignition/injection			
Mot.no. →2533528	07.00-09.05	OLH	**0 261 210 114**
1.3 JTD [119..]			**1,2 l 54 kW 199 A 2.000 4 Zyl.**
Air mass meter, diesel	10.05→		**0 281 002 792**
High-pressure sensor (CR system)	10.05→		**0 281 002 534**
Boost pressure sensor, Diesel			
Mot.no. →1376014	10.05→		**0 281 002 510**
Mot.no. 1376015→	10.05→		**0 281 002 844**
Accelerator pedal module	10.05→	LLE	**0 281 002 415**
1.3 JTD [119..]			**1,2 l 62 kW 223 A 9.000 4 Zyl.**
Air mass meter, diesel	10.05→		**0 281 002 792**
High-pressure sensor (CR system)	10.05→		**0 281 002 534**
Boost pressure sensor, Diesel	10.05-11.06		**0 281 002 437**
	12.06→		**0 281 002 845**
Accelerator pedal module	10.05→	LLE	**0 281 002 415**
1.3 JTD 16V [119..]			**1,2 l 51 kW 188 A 9.000 4 Zyl.**
Air mass meter, diesel	02.04-09.05		**0 281 002 613**
High-pressure sensor (CR system)	02.04-09.05		**0 281 002 534**
Boost pressure sensor, Diesel	02.04-09.05		**0 281 002 510**
Accelerator pedal module	02.04-09.05	LLE	**0 281 002 415**
1.3 MPI 16V			**1,3 l 59 kW 178 D 6.011 4 Zyl.**
Throttle valve assembly	11.01-01.06		**F 01C 600 023**
Speed sensor, ignition/injection	11.01-01.06		**0 261 210 161**
Knock sensor	11.01-01.06		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	11.01-01.06		**0 261 230 030**
Accelerator pedal module	11.01-01.06	LLE	**0 281 002 415**
1.4 i.e. [119..]			**1,4 l 55 kW 350 A 1.000 4 Zyl.**
Phase sensor	10.05→		**0 232 103 048**
Pressure sensor, intake manifold, gasoline	10.05→		**0 261 230 030**
Accelerator pedal module	10.05→	LLE	**0 281 002 415**
1.6 i.e. 16V [119..]			**1,6 l 76 kW 182 B 6.000 4 Zyl.**
Accelerator pedal module	10.01-09.05	LLE	**0 281 002 415**
1.9 D			**1,9 l 46 kW 4 Zyl.**
Speed sensor, diesel	11.03-01.06		**0 281 002 474**
1.9 D [119..]			**1,9 l 46 kW 223 A 6.000 4 Zyl.**
Speed sensor, diesel	07.00-09.05		**0 281 002 474**
Accelerator pedal module	07.00-09.05	LLE	**0 281 002 415**
1.9 JTD [119..]			**1,9 l 74 kW 182 B 9.000 4 Zyl.**
Air mass meter, diesel	10.01-01.04		**0 280 218 113**
Speed sensor, diesel	10.01-01.04		**0 281 002 474**
Phase sensor	10.01-01.04		**0 281 002 213**
High-pressure sensor (CR system)	10.01-01.04		**0 281 002 260**
Boost pressure sensor, Diesel	10.01-01.04		**0 281 002 510**
Accelerator pedal module	10.01-01.04	LLE	**0 281 002 415**
1.9 JTD [119..]			**1,9 l 74 kW 223 B 2.000 4 Zyl.**
Speed sensor, diesel	10.05→	KW	**0 281 002 603**
Phase sensor	10.05→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	10.05→		**0 281 002 534**
Boost pressure sensor, Diesel	10.05-03.07		**0 281 002 437**
	04.07→		**0 281 002 845**
Accelerator pedal module	10.05→	LLE	**0 281 002 415**
1.9 JTD [119..]			**1,9 l 77 kW 223 A 7.000 4 Zyl.**
Air mass meter, diesel	11.02-09.05		**0 280 218 113**
Speed sensor, diesel	11.02-01.04		**0 281 002 474**
	02.04-09.05		**0 281 002 603**

F

Product

◀ Doblo

Phase sensor	11.02-09.05		**0 281 002 213**
High-pressure sensor (CR system)			
Mot.no. →3920857	11.02-09.05	LLE	**0 281 002 260**
Mot.no. →3963472	11.02-09.05	RLE	**0 281 002 260**
Boost pressure sensor, Diesel	11.02-09.05		**0 281 002 510**
Accelerator pedal module	11.02-09.05	LLE	**0 281 002 415**
1.9 JTD [119..]	**1,9 l 77/88 kW 186 A 9.000; 223 B 1.000 4 Zyl.**		
Speed sensor, diesel	10.05→	KW	**0 281 002 603**
Phase sensor	10.05→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	10.05→		**0 281 002 534**
Boost pressure sensor, Diesel	10.05-03.07		**0 281 002 437**
	04.07→		**0 281 002 845**
Accelerator pedal module	10.05→	LLE	**0 281 002 415**

Doblo Cargo

1.2 i.e. 8V [223..]	**1,2 l 47 kW 223 A 5.000 4 Zyl.**		
Phase sensor	07.00-09.05		**0 232 103 039**
Speed sensor, ignition/injection			
Mot.no. →2533528	07.00-09.05	OLH	**0 261 210 114**
1.3 JTD [223..]	**1,2 l 55 kW 199 A 2.000 4 Zyl.**		
Air mass meter, diesel	10.05→		**0 281 002 792**
High-pressure sensor (CR system)	10.05→		**0 281 002 534**
Boost pressure sensor, Diesel			
Mot.no. →1376014	10.05→		**0 281 002 510**
Mot.no. 1376015→	10.05→		**0 281 002 844**
Accelerator pedal module	10.05→	LLE	**0 281 002 415**
1.3 JTD [223..]	**1,2 l 62 kW 223 A 9.000 4 Zyl.**		
Air mass meter, diesel	10.05→		**0 281 002 792**
High-pressure sensor (CR system)	10.05→		**0 281 002 534**
Boost pressure sensor, Diesel	10.05-11.06		**0 281 002 437**
	12.06→		**0 281 002 845**
Accelerator pedal module	10.05→	LLE	**0 281 002 415**
1.3 JTD 16V [223..]	**1,2 l 51 kW 188 A 9.000 4 Zyl.**		
Air mass meter, diesel	02.04-09.05		**0 281 002 613**
High-pressure sensor (CR system)	02.04-09.05		**0 281 002 534**
Boost pressure sensor, Diesel	02.04-09.05		**0 281 002 510**
Accelerator pedal module	02.04-09.05	LLE	**0 281 002 415**
1.4 i.e. [223..]	**1,4 l 57 kW 350 A 1.000 4 Zyl.**		
Phase sensor	10.05→		**0 232 103 048**
Pressure sensor, intake manifold, gasoline	10.05→		**0 261 230 030**
Accelerator pedal module	10.05→	LLE	**0 281 002 415**
1.6 i.e. 16V [223..]	**1,6 l 76 kW 182 B 6.000 4 Zyl.**		
Accelerator pedal module	10.01-09.05	LLE	**0 281 002 415**
1.9 D [223..]	**1,9 l 46 kW 223 A 6.000 4 Zyl.**		
Speed sensor, diesel	07.00-09.05		**0 281 002 474**
Accelerator pedal module	07.00-09.05	LLE	**0 281 002 415**
1.9 JTD [223..]	**1,9 l 74 kW 182 B 9.000 4 Zyl.**		
Air mass meter, diesel	10.01-01.04		**0 280 218 113**
Speed sensor, diesel	10.01-01.04		**0 281 002 474**
Phase sensor	10.01-01.04		**0 281 002 213**
High-pressure sensor (CR system)	10.01-01.04		**0 281 002 260**
Boost pressure sensor, Diesel	10.01-01.04		**0 281 002 510**
Accelerator pedal module	10.01-01.04	LLE	**0 281 002 415**
1.9 JTD [223..]	**1,9 l 74 kW 223 B 2.000 4 Zyl.**		
Speed sensor, diesel	10.05→	KW	**0 281 002 603**
Phase sensor	10.05→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	10.05→		**0 281 002 534**
Boost pressure sensor, Diesel	10.05-03.07		**0 281 002 437**
	04.07→		**0 281 002 845**
Accelerator pedal module	10.05→	LLE	**0 281 002 415**

Product

1.9 JTD [223..]	**1,9 l 77 kW 223 A 7.000 4 Zyl.**		
Air mass meter, diesel	11.02-09.05		**0 280 218 113**
Speed sensor, diesel	11.02-01.04		**0 281 002 474**
	02.04-09.05		**0 281 002 603**
Phase sensor	11.02-09.05		**0 281 002 213**
High-pressure sensor (CR system)			
Mot.no. →3920857	11.02-09.05	LLE	**0 281 002 260**
Mot.no. →3963472	11.02-09.05	RLE	**0 281 002 260**
Boost pressure sensor, Diesel	11.02-09.05		**0 281 002 510**
Accelerator pedal module	11.02-09.05	LLE	**0 281 002 415**
1.9 JTD [223..]	**1,9 l 77/88 kW 186 A 9.000; 223 B 1000 4 Zyl.**		
Speed sensor, diesel	10.05→	KW	**0 281 002 603**
Phase sensor	10.05→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	10.05→		**0 281 002 534**
Boost pressure sensor, Diesel	10.05-03.07		**0 281 002 437**
	04.07→		**0 281 002 845**
Accelerator pedal module	10.05→	LLE	**0 281 002 415**

Ducato

2.8 JTD Combinato, Maxi Cargo, Minibus, Multi T.A./T.B.	**2,8 l 93 kW 8140.43S 4 Zyl.**		
Pulse generator, diesel	06.05→		**0 281 002 667**
Speed sensor, diesel	06.05→		**0 281 002 332**
High-pressure sensor (CR system)	06.05→		**0 281 002 405**
Boost pressure sensor, Diesel	06.05→		**0 281 002 514**
Temperature sensor, coolant, diesel	06.05→		**0 281 002 170**
Wheel speed sensor, front	06.05→		**0 265 006 673**
Wheel speed sensor, rear	06.05→	LAB	**0 265 006 688**
		RAB	**0 265 006 689**

Ducato Cargo

2.8 D	**2,8 l 63 kW 8140.63.22.60 4 Zyl.**		
Wheel speed sensor, front	01.04-05.05		**0 265 006 673**
Wheel speed sensor, rear	01.04-05.05	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
2.8 D Turbo	**2,8 l 90 kW 8140.43.22.00 4 Zyl.**		
Wheel speed sensor, front	01.04-05.05		**0 265 006 673**
Wheel speed sensor, rear	01.04-05.05	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
2.8 JTD	**2,8 l 93 kW 8140.43S 4 Zyl.**		
Pulse generator, diesel	06.05→		**0 281 002 667**
Speed sensor, diesel	06.05→		**0 281 002 332**
High-pressure sensor (CR system)	06.05→		**0 281 002 405**
Boost pressure sensor, Diesel	06.05→		**0 281 002 514**
Temperature sensor, coolant, diesel	06.05→		**0 281 002 170**
Wheel speed sensor, front	06.05→		**0 265 006 673**
Wheel speed sensor, rear	06.05→	LAB	**0 265 006 688**
		RAB	**0 265 006 689**

Ducato Maxi 17

2.3 JTD [251..]	**2,3 l 88 kW F1AE0481D 4 Zyl.**		
Air mass meter, diesel	06.06→		**0 281 002 763**
Boost pressure sensor, Diesel	06.06-05.07		**0 281 002 437**
	06.07→		**0 281 002 845**
Wheel speed sensor, rear	06.06→	FKR,FMR	**0 265 007 686**
		FLR	**0 265 007 833**
3.0 JTD [251..]	**3,0 l 116 kW F1CE0481D 4 Zyl.**		
Air mass meter, diesel	06.06→		**0 281 002 763**
Phase sensor	06.06→		**0 281 002 667**
Boost pressure sensor, Diesel	06.06→		**0 281 002 437**

F

Product			
Wheel speed sensor, rear	06.06→	FKR,FMR	**0 265 007 686**
		FLR	**0 265 007 833**

Ducato Maxi 20

2.3 JTD [251..]		**2,3 l 88 kW F1AE0481D 4 Zyl.**	
Air mass meter, diesel	06.06→		**0 281 002 763**
Boost pressure sensor, Diesel	06.06-05.07		**0 281 002 437**
	06.07→		**0 281 002 845**
Wheel speed sensor, rear	06.06→	FKR,FMR	**0 265 007 686**
		FLR	**0 265 007 833**
3.0 JTD [251..]		**3,0 l 116 kW F1CE0481D 4 Zyl.**	
Air mass meter, diesel	06.06→		**0 281 002 763**
Phase sensor	06.06→		**0 281 002 667**
Boost pressure sensor, Diesel	06.06→		**0 281 002 437**
Wheel speed sensor, rear	06.06→	FKR,FMR	**0 265 007 686**
		FLR	**0 265 007 833**

Ducato 10

1.9 D [230..]		**1,9 l 50 kW DJY 4 Zyl.**	
Wheel speed sensor, front			
Fg.no. 5445359→5946342	04.98-10.01	BO	**0 265 006 427**
Fg.no. 5946343→	04.98-10.01	BSY	**0 265 006 673**
Wheel speed sensor, rear			
Fg.no. 5445359→	04.98-10.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
1.9 D [230..]		**1,9 l 51 kW 230 A 2.000 4 Zyl.**	
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.97-03.98	BO	**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 5445359→	08.97-03.98	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
1.9 TD [230..]		**1,9 l 60 kW 230 A 3.000 4 Zyl.**	
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.97-03.98	BO	**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 5445359→	08.97-03.98	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
1.9 TD [230..]		**1,9 l 66 kW DHX 4 Zyl.**	
Altitude sensor	04.98-10.01		**9 456 160 006**
Wheel speed sensor, front			
Fg.no. 5445359→5946342	04.98-10.01	BO	**0 265 006 427**
Fg.no. 5946343→	04.98-10.01	BSY	**0 265 006 673**
Wheel speed sensor, rear			
Fg.no. 5445359→	04.98-10.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
1.9 TD CAT [230..]		**1,9 l 59 kW 230 A 4.000 4 Zyl.**	
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.97-03.98	BO	**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 5445359→	08.97-03.98	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.0 [230..]		**2,0 l 79 kW R5B 4 Zyl.**	
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.97-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	03.94-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	08.97-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**

Product			
2.0 i.e. [230..]		**2,0 l 80 kW RFW 4 Zyl.**	
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.97-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	03.94-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	08.97-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.0 i.e. 4x4 [234..]		**2,0 l 80 kW RFW 4 Zyl.**	
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.97-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	03.94-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	08.97-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.0 JTD [230..]		**2,0 l 63 kW RHV 4 Zyl.**	
High-pressure sensor (CR system)	10.01-03.02		**0 281 002 283**
Wheel speed sensor, front			
Fg.no. 5946343→	10.01-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	10.01-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.5 D [230..]		**2,5 l 62 kW 8140.67 4 Zyl.**	
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.97-03.98	BO	**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 5445359→	08.97-03.98	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.5 TD ECO [230..]		**2,5 l 80 kW 8140.47R 4 Zyl.**	
Air flow sensor, diesel	03.94-03.98		**0 281 002 087**
Speed sensor, diesel	03.94-03.98	MDR	**0 281 002 108**
Temperature sensor, coolant, diesel	03.94-03.98		**0 280 130 026**
Pedal position sensor, diesel	03.94-03.98		**0 205 001 010**
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.97-03.98	BO	**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 5445359→	08.97-03.98	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.5 TD EGR [230..]		**2,5 l 85 kW 8140.47 4 Zyl.**	
Speed sensor, diesel	03.94-03.98	MDR	**0 281 002 108**
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.97-03.98	BO	**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 5445359→	08.97-03.98	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.5 TD EGR 4x4 [234..]		**2,5 l 85 kW 8140.47 4 Zyl.**	
Speed sensor, diesel	03.94-03.98	MDR	**0 281 002 108**
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.97-03.98	BO	**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 5445359→	08.97-03.98	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.8 D [230..]		**2,8 l 64 kW 8140.63 4 Zyl.**	
Wheel speed sensor, front			
Fg.no. 5445359→5946342	04.98-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	04.98-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	04.98-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**

F

Product

◀ Ducato 10

2.8 JTD [230..]			**2,8 l 94 kW 8140.43S 4 Zyl.**
Speed sensor, diesel	08.00-03.02		**0 281 002 332**
High-pressure sensor (CR system)	08.00-03.02		**0 281 002 405**
Wheel speed sensor, front			
Fg.no. 5946343→	08.00-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	08.00-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.8 JTD EGR [230..]			**2,8 l 94 kW 8140.43S 4 Zyl.**
Air mass meter, diesel	08.00-03.02		**0 281 002 184**
Speed sensor, diesel	08.00-03.02		**0 281 002 332**
High-pressure sensor (CR system)	08.00-03.02		**0 281 002 405**
Wheel speed sensor, front			
Fg.no. 5946343→	08.00-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	08.00-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.8 JTD EGR 4x4 [234..]			**2,8 l 94 kW 8140.43S 4 Zyl.**
Air mass meter, diesel	08.00-03.02		**0 281 002 184**
Speed sensor, diesel	08.00-03.02		**0 281 002 332**
High-pressure sensor (CR system)	08.00-03.02		**0 281 002 405**
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.00-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	08.00-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	08.00-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.8 JTD 4x4 [234..]			**2,8 l 94 kW 8140.43S 4 Zyl.**
Speed sensor, diesel	08.00-03.02		**0 281 002 332**
High-pressure sensor (CR system)	08.00-03.02		**0 281 002 405**
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.00-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	08.00-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	08.00-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.8 TD EGR [230..]			**2,8 l 90 kW 8140.43 4 Zyl.**
Speed sensor, diesel	10.97-03.02	MDR	**0 281 002 108**
Wheel speed sensor, front			
Fg.no. 5445359→5946342	10.97-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	10.97-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	10.97-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.8 TD EGR 4x4, TD 4x4 [234..]			**2,8 l 90 kW 8140.43 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 5445359→5946342	10.97-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	10.97-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	10.97-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**

Product

Ducato 11

2.0 i.e. [243..]			**2,0 l 81 kW RFL 4 Zyl.**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
Wheel speed sensor, rear	04.02-08.06	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
2.0 i.e. Bipower [243..]			**2,0 l 71-81 kW RFL 4 Zyl.**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
Wheel speed sensor, rear	04.02-08.06	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
2.0 i.e. Bipower 4x4 [247..]			**2,0 l 71-81 kW RFL 4 Zyl.**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
2.0 i.e. 4x4 [247..]			**2,0 l 81 kW RFL 4 Zyl.**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
2.0 JTD [243..]			**2,0 l 62 kW RHV 4 Zyl.**
High-pressure sensor (CR system)	04.02-08.06		**0 281 002 283**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
Wheel speed sensor, rear	04.02-08.06	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
2.2 JTD [250..]			**2,2 l 74 kW 4HV 4 Zyl.**
Wheel speed sensor, rear	06.06→	FKR,FMR	**0 265 007 686**
		FLR	**0 265 007 833**
2.3 JTD [243..]			**2,3 l 81 kW F1AE0481C 4 Zyl.**
Boost pressure sensor, Diesel	04.02-08.06		**0 281 002 514**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
Wheel speed sensor, rear	04.02-08.06	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
2.3 JTD [250..]			**2,3 l 88 kW F1AE0481D 4 Zyl.**
Air mass meter, diesel	06.06→		**0 281 002 763**
Boost pressure sensor, Diesel	06.06-05.07		**0 281 002 437**
	06.07→		**0 281 002 845**
Wheel speed sensor, rear	06.06→	FKR,FMR	**0 265 007 686**
		FLR	**0 265 007 833**
2.3 JTD EGR [243..]			**2,3 l 81 kW F1AE0481C 4 Zyl.**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
Wheel speed sensor, rear	04.02-08.06	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
2.8 JTD [243..]			**2,8 l 94 kW 8140.43S 4 Zyl.**
Boost pressure sensor, Diesel	04.02-08.06		**0 281 002 514**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
Wheel speed sensor, rear	04.02-08.06	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
2.8 JTD EGR [243..]			**2,8 l 94 kW 8140.43S 4 Zyl.**
Air mass meter, diesel	04.02-08.06		**0 281 002 184**
Boost pressure sensor, Diesel	04.02-08.06		**0 281 002 514**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
Wheel speed sensor, rear	04.02-08.06	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
2.8 JTD EGR 4x4 [247..]			**2,8 l 94 kW 8140.43S 4 Zyl.**
Air mass meter, diesel	04.02-08.06		**0 281 002 184**
Boost pressure sensor, Diesel	04.02-08.06		**0 281 002 514**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
2.8 TD EGR 4x4 [247..]			**2,8 l 90 kW 8140.43 4 Zyl.**
Wheel speed sensor, front	10.02-08.06		**0 265 006 673**
2.8 TD, TD EGR [243..]			**2,8 l 90 kW 8140.43 4 Zyl.**
Wheel speed sensor, front	10.02-08.06		**0 265 006 673**
Wheel speed sensor, rear	10.02-08.06	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
3.0 JTD [250..]			**3,0 l 116 kW F1CE0481D 4 Zyl.**
Air mass meter, diesel	06.06→		**0 281 002 763**
Phase sensor	06.06→		**0 281 002 667**
Boost pressure sensor, Diesel	06.06→		**0 281 002 437**

F

Product			
Wheel speed sensor, rear	06.06→	FKR,FMR	**0 265 007 686**
		FLR	**0 265 007 833**

Ducato 14

1.9 TD [231..]		**1,9 l 60 kW 230 A 3.000 4 Zyl.**	
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.97-03.98	BO	**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 5445359→	08.97-03.98	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
1.9 TD [231..]		**1,9 l 66 kW DHX 4 Zyl.**	
Altitude sensor	04.98-10.01		**9 456 160 006**
Wheel speed sensor, front			
Fg.no. 5445359→5946342	04.98-10.01	BO	**0 265 006 427**
Fg.no. 5946343→	04.98-10.01	BSY	**0 265 006 673**
Wheel speed sensor, rear			
Fg.no. 5445359→	04.98-10.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
1.9 TD CAT [231..]		**1,9 l 59 kW 230 A 4.000 4 Zyl.**	
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.97-03.98	BO	**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 5445359→	08.97-03.98	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.0 [231..]		**2,0 l 79 kW R5B 4 Zyl.**	
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.97-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	03.94-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	08.97-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.0 i.e. [231..]		**2,0 l 80 kW RFW 4 Zyl.**	
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.97-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	03.94-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	08.97-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.0 i.e. 4x4 [234..]		**2,0 l 80 kW RFW 4 Zyl.**	
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.97-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	03.94-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	08.97-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.0 JTD [231..]		**2,0 l 63 kW RHV 4 Zyl.**	
High-pressure sensor (CR system)	10.01-03.02		**0 281 002 283**
Wheel speed sensor, front			
Fg.no. 5946343→	10.01-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	10.01-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.5 D [231..]		**2,5 l 62 kW 8140.67 4 Zyl.**	
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.97-03.98	BO	**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 5445359→	08.97-03.98	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**

Product			
2.5 TD [231..]		**2,5 l 85 kW 8140.47 4 Zyl.**	
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.97-03.98	BO	**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 5445359→	08.97-03.98	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.5 TD ECO [231..]		**2,5 l 80 kW 8140.47R 4 Zyl.**	
Air flow sensor, diesel	03.94-03.98		**0 281 002 087**
Speed sensor, diesel	03.94-03.98	MDR	**0 281 002 108**
Temperature sensor, coolant, diesel	03.94-03.98		**0 280 130 026**
Pedal position sensor, diesel	03.94-03.98		**0 205 001 010**
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.97-03.98	BO	**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 5445359→	08.97-03.98	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.5 TD ECO 4x4 [234..]		**2,5 l 80 kW 8140.47R 4 Zyl.**	
Air flow sensor, diesel	03.94-03.98		**0 281 002 087**
Speed sensor, diesel	03.94-03.98	MDR	**0 281 002 108**
Temperature sensor, coolant, diesel	03.94-03.98		**0 280 130 026**
Pedal position sensor, diesel	03.94-03.98		**0 205 001 010**
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.97-03.98	BO	**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 5445359→	08.97-03.98	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.5 TD EGR [231..]		**2,5 l 85 kW 8140.47 4 Zyl.**	
Speed sensor, diesel	03.94-03.98	MDR	**0 281 002 108**
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.97-03.98	BO	**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 5445359→	08.97-03.98	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.5 TD EGR 4x4 [234..]		**2,5 l 85 kW 8140.47 4 Zyl.**	
Speed sensor, diesel	03.94-03.98	MDR	**0 281 002 108**
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.97-03.98	BO	**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 5445359→	08.97-03.98	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.8 D [231..]		**2,8 l 64 kW 8140.63 4 Zyl.**	
Wheel speed sensor, front			
Fg.no. 5445359→5946342	04.98-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	04.98-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	04.98-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.8 JTD [231..]		**2,8 l 94 kW 8140.43S 4 Zyl.**	
Speed sensor, diesel	08.00-03.02		**0 281 002 332**
High-pressure sensor (CR system)	08.00-03.02		**0 281 002 405**
Wheel speed sensor, front			
Fg.no. 5946343→	08.00-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	08.00-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.8 JTD EGR [231..]		**2,8 l 94 kW 8140.43S 4 Zyl.**	
Air mass meter, diesel	08.00-03.02		**0 281 002 184**
Speed sensor, diesel	08.00-03.02		**0 281 002 332**
High-pressure sensor (CR system)	08.00-03.02		**0 281 002 405**
Wheel speed sensor, front			
Fg.no. 5946343→	08.00-03.02	BSY	**0 265 006 673**

F

Product

◀ Ducato 14

Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	08.00-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.8 JTD EGR 4x4 [234..]		**2,8 l 94 kW 8140.43S 4 Zyl.**	
Air mass meter, diesel	08.00-03.02		**0 281 002 184**
Speed sensor, diesel	08.00-03.02		**0 281 002 332**
High-pressure sensor (CR system)	08.00-03.02		**0 281 002 405**
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.00-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	08.00-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	08.00-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.8 JTD 4x4 [234..]		**2,8 l 94 kW 8140.43S 4 Zyl.**	
Speed sensor, diesel	08.00-03.02		**0 281 002 332**
High-pressure sensor (CR system)	08.00-03.02		**0 281 002 405**
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.00-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	08.00-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	08.00-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.8 TD [231..]		**2,8 l 90 kW 8140.43 4 Zyl.**	
Wheel speed sensor, front			
Fg.no. 5445359→5946342	10.97-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	10.97-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	10.97-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.8 TD EGR [231..]		**2,8 l 90 kW 8140.43 4 Zyl.**	
Speed sensor, diesel	10.97-03.02	MDR	**0 281 002 108**
Wheel speed sensor, front			
Fg.no. 5445359→5946342	10.97-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	10.97-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	10.97-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.8 TD EGR 4x4, TD 4x4 [234..]		**2,8 l 90 kW 8140.43 4 Zyl.**	
Wheel speed sensor, front			
Fg.no. 5445359→5946342	10.97-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	10.97-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	10.97-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**

Ducato 15

2.0 i.e. [244..]		**2,0 l 81 kW RFL 4 Zyl.**	
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
Wheel speed sensor, rear	04.02-08.06	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
2.0 i.e. Bipower [244..]		**2,0 l 71-81 kW RFL 4 Zyl.**	
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
Wheel speed sensor, rear	04.02-08.06	LAB	**0 265 006 688**
		RAB	**0 265 006 689**

Product

2.0 i.e. Bipower 4x4 [247..]		**2,0 l 71-81 kW RFL 4 Zyl.**	
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
2.0 i.e. 4x4 [247..]		**2,0 l 81 kW RFL 4 Zyl.**	
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
2.0 JTD [244..]		**2,0 l 62 kW RHV 4 Zyl.**	
High-pressure sensor (CR system)	04.02-08.06		**0 281 002 283**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
Wheel speed sensor, rear	04.02-08.06	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
2.2 JTD [250..]		**2,2 l 74 kW 4HV 4 Zyl.**	
Air mass meter, diesel	06.06→		**0 281 002 763**
Wheel speed sensor, rear	06.06→	FKR,FMR	**0 265 007 686**
		FLR	**0 265 007 833**
2.3 JTD [244..]		**2,3 l 81 kW F1AE0481C 4 Zyl.**	
Boost pressure sensor, Diesel	04.02-08.06		**0 281 002 514**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
Wheel speed sensor, rear	04.02-08.06	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
2.3 JTD [250..]		**2,3 l 88 kW F1AE0481D 4 Zyl.**	
Air mass meter, diesel	06.06→		**0 281 002 763**
Boost pressure sensor, Diesel	06.06-05.07		**0 281 002 437**
	06.07→		**0 281 002 845**
Wheel speed sensor, rear	06.06→	FKR,FMR	**0 265 007 686**
		FLR	**0 265 007 833**
2.3 JTD EGR [244..]		**2,3 l 81 kW F1AE0481C 4 Zyl.**	
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
Wheel speed sensor, rear	04.02-08.06	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
2.8 JTD [244..]		**2,8 l 94 kW 8140.43S 4 Zyl.**	
Boost pressure sensor, Diesel	04.02-08.06		**0 281 002 514**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
Wheel speed sensor, rear	04.02-08.06	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
2.8 JTD CGV [244..]		**2,8 l 107 kW 8140.43S 4 Zyl.**	
Boost pressure sensor, Diesel	04.04-08.06		**0 281 002 514**
Wheel speed sensor, front	04.04-08.06		**0 265 006 673**
Wheel speed sensor, rear	04.04-08.06	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
2.8 JTD EGR [244..]		**2,8 l 94 kW 8140.43S 4 Zyl.**	
Air mass meter, diesel	04.02-08.06		**0 281 002 184**
Boost pressure sensor, Diesel	04.02-08.06		**0 281 002 514**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
Wheel speed sensor, rear	04.02-08.06	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
2.8 JTD EGR 4x4 [247..]		**2,8 l 94 kW 8140.43S 4 Zyl.**	
Air mass meter, diesel	04.02-08.06		**0 281 002 184**
Boost pressure sensor, Diesel	04.02-08.06		**0 281 002 514**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
2.8 JTD 4x4 [247..]		**2,8 l 94 kW 8140.43S 4 Zyl.**	
Boost pressure sensor, Diesel	04.02-08.06		**0 281 002 514**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
2.8 TD EGR 4x4, TD 4x4 [247..]		**2,8 l 90 kW 8140.43 4 Zyl.**	
Wheel speed sensor, front	10.02-08.06		**0 265 006 673**
2.8 TD, TD EGR [244..]		**2,8 l 90 kW 8140.43 4 Zyl.**	
Wheel speed sensor, front	10.02-08.06		**0 265 006 673**
Wheel speed sensor, rear	10.02-08.06	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
3.0 JTD [250..]		**3,0 l 116 kW F1CE0481D 4 Zyl.**	
Air mass meter, diesel	06.06→		**0 281 002 763**
Phase sensor	06.06→		**0 281 002 667**
Boost pressure sensor, Diesel	06.06→		**0 281 002 437**
Wheel speed sensor, rear	06.06→	FKR,FMR	**0 265 007 686**
		FLR	**0 265 007 833**

F

Product			

Ducato 17

2.2 JTD [250..]			**2,2 l 74 kW 4HV 4 Zyl.**
Air mass meter, diesel	06.06→		**0 281 002 763**
Wheel speed sensor, rear	06.06→	FKR,FMR	**0 265 007 686**
		FLR	**0 265 007 833**
2.3 JTD [250..]			**2,3 l 88 kW F1AE0481D 4 Zyl.**
Air mass meter, diesel	06.06→		**0 281 002 763**
Boost pressure sensor, Diesel	06.06-05.07		**0 281 002 437**
	06.07→		**0 281 002 845**
Wheel speed sensor, rear	06.06→	FKR,FMR	**0 265 007 686**
		FLR	**0 265 007 833**
3.0 JTD [250..]			**3,0 l 116 kW F1CE0481D 4 Zyl.**
Air mass meter, diesel	06.06→		**0 281 002 763**
Phase sensor	06.06→		**0 281 002 667**
Boost pressure sensor, Diesel	06.06→		**0 281 002 437**
Wheel speed sensor, rear	06.06→	FKR,FMR	**0 265 007 686**
		FLR	**0 265 007 833**

Ducato 18

2.0 i.e. [232..]			**2,0 l 80 kW RFW 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.97-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	03.94-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	08.97-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.0 i.e. [245..]			**2,0 l 81 kW RFL 4 Zyl.**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
Wheel speed sensor, rear	04.02-08.06	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
2.0 i.e. Bipower [245..]			**2,0 l 71-81 kW RFL 4 Zyl.**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
Wheel speed sensor, rear	04.02-08.06	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
2.0 i.e. Bipower 4x4 [247..]			**2,0 l 71-81 kW RFL 4 Zyl.**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
2.0 i.e. 4x4 [247..]			**2,0 l 81 kW RFL 4 Zyl.**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
2.3 JTD [245..]			**2,3 l 81 kW F1AE0481C 4 Zyl.**
Boost pressure sensor, Diesel	04.02-08.06		**0 281 002 514**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
Wheel speed sensor, rear	04.02-08.06	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
2.5 D [232..]			**2,5 l 62 kW 8140.67 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 5445359→	08.97-03.98	BO	**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 5445359→	08.97-03.98	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.5 D 4x4 [234..]			**2,5 l 62 kW 8140.67 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.97-03.98	BO	**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 5445359→	08.97-03.98	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.5 TD [232..]			**2,5 l 85 kW 8140.47 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 5445359→	08.97-03.98	BO	**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 5445359→	08.97-03.98	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.5 TD ECO [232..]			**2,5 l 80 kW 8140.47R 4 Zyl.**
Air flow sensor, diesel	03.94-03.98		**0 281 002 087**
Speed sensor, diesel	03.94-03.98	MDR	**0 281 002 108**
Temperature sensor, coolant, diesel	03.94-03.98		**0 280 130 026**
Pedal position sensor, diesel	03.94-03.98		**0 205 001 010**
Wheel speed sensor, front			
Fg.no. 5445359→	08.97-03.98	BO	**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 5445359→	08.97-03.98	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.5 TD 4x4 [234..]			**2,5 l 85 kW 8140.47 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.97-03.98	BO	**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 5445359→	08.97-03.98	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.8 D [232..]			**2,8 l 64 kW 8140.63 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 5445359→5946342	04.98-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	04.98-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	04.98-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.8 D 4x4 [234..]			**2,8 l 64 kW 8140.63 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 5445359→5946342	04.98-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	04.98-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	04.98-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.8 JTD [232..]			**2,8 l 94 kW 8140.43S 4 Zyl.**
Speed sensor, diesel	08.00-03.02		**0 281 002 332**
High-pressure sensor (CR system)	08.00-03.02		**0 281 002 405**
Wheel speed sensor, front			
Fg.no. 5946343→	08.00-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	08.00-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.8 JTD [245..]			**2,8 l 94 kW 8140.43S 4 Zyl.**
Boost pressure sensor, Diesel	04.02-08.06		**0 281 002 514**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
Wheel speed sensor, rear	04.02-08.06	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
2.8 JTD CGV [245..]			**2,8 l 107 kW 8140.43S 4 Zyl.**
Boost pressure sensor, Diesel	04.04-08.06		**0 281 002 514**
Wheel speed sensor, front	04.04-08.06		**0 265 006 673**
Wheel speed sensor, rear	04.04-08.06	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
2.8 JTD EGR [232..]			**2,8 l 94 kW 8140.43S 4 Zyl.**
Air mass meter, diesel	08.00-03.02		**0 281 002 184**
Speed sensor, diesel	08.00-03.02		**0 281 002 332**
High-pressure sensor (CR system)	08.00-03.02		**0 281 002 405**
Wheel speed sensor, front			
Fg.no. 5946343→	08.00-03.02	BSY	**0 265 006 673**

F

Product			
◀ Ducato 18			
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	08.00-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.8 JTD EGR [245..]		**2,8 l 94 kW 8140.43S 4 Zyl.**	
Air mass meter, diesel	04.02-08.06		**0 281 002 184**
Boost pressure sensor, Diesel	04.02-08.06		**0 281 002 514**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
Wheel speed sensor, rear	04.02-08.06	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
2.8 JTD EGR 4x4 [234..]		**2,8 l 94 kW 8140.43S 4 Zyl.**	
Air mass meter, diesel	08.00-03.02		**0 281 002 184**
Speed sensor, diesel	08.00-03.02		**0 281 002 332**
High-pressure sensor (CR system)	08.00-03.02		**0 281 002 405**
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.00-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	08.00-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	08.00-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.8 JTD EGR 4x4 [247..]		**2,8 l 94 kW 8140.43S 4 Zyl.**	
Air mass meter, diesel	04.02-08.06		**0 281 002 184**
Boost pressure sensor, Diesel	04.02-08.06		**0 281 002 514**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
2.8 JTD 4x4 [234..]		**2,8 l 94 kW 8140.43S 4 Zyl.**	
Speed sensor, diesel	08.00-03.02		**0 281 002 332**
High-pressure sensor (CR system)	08.00-03.02		**0 281 002 405**
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.00-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	08.00-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	08.00-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.8 JTD 4x4 [247..]		**2,8 l 94 kW 8140.43S 4 Zyl.**	
Boost pressure sensor, Diesel	04.02-08.06		**0 281 002 514**
Wheel speed sensor, front	04.02-08.06		**0 265 006 673**
2.8 TD [232..]		**2,8 l 90 kW 8140.43 4 Zyl.**	
Wheel speed sensor, front			
Fg.no. 5445359→5946342	10.97-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	10.97-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	10.97-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.8 TD [245..]		**2,8 l 90 kW 8140.43 4 Zyl.**	
Wheel speed sensor, front	10.02-08.06		**0 265 006 673**
Wheel speed sensor, rear	10.02-08.06	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
2.8 TD EGR [232..]		**2,8 l 90 kW 8140.43 4 Zyl.**	
Speed sensor, diesel	10.97-03.02	MDR	**0 281 002 108**
Wheel speed sensor, front			
Fg.no. 5445359→5946342	10.97-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	10.97-03.02	BSY	**0 265 006 673**
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	10.97-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.8 TD EGR 4x4, TD 4x4 [234..]		**2,8 l 90 kW 8140.43 4 Zyl.**	
Wheel speed sensor, front			
Fg.no. 5445359→5946342	10.97-03.02	BO	**0 265 006 427**
Fg.no. 5946343→	10.97-03.02	BSY	**0 265 006 673**

Product			
Wheel speed sensor, rear	12.01-03.02	LAB	**0 265 006 688**
		RAB	**0 265 006 689**
Fg.no. 5445359→	10.97-11.01	BO,LAB	**0 265 006 405**
		BO,RAB	**0 265 006 406**
2.8 TD 4x4 [247..]		**2,8 l 90 kW 8140.43 4 Zyl.**	
Wheel speed sensor, front	10.02-08.06		**0 265 006 673**

Fiorino

1.3 [255..]		**1,3 l 49 kW 146 A 5.000 4 Zyl.**	
Wheel speed sensor, front	09.93-12.01	LAB	**0 265 006 538**
		RAB	**0 265 006 537**
Wheel speed sensor, rear	09.93-12.01	LAB	**0 265 006 539**
		RAB	**0 265 006 540**
1.4 i.e. [255..]		**1,4 l 49 kW 146 D 5.000 4 Zyl.**	
Speed sensor, ignition/injection	06.95-12.01		**0 261 210 127**
Temperature sensor, coolant, injection system	06.95-12.01		**0 280 130 026**
Wheel speed sensor, front	06.95-12.01	LAB	**0 265 006 538**
		RAB	**0 265 006 537**
Wheel speed sensor, rear	06.95-12.01	LAB	**0 265 006 539**
		RAB	**0 265 006 540**
1.4 i.e. [255..]		**1,4 l 52 kW 146 C 5.000 4 Zyl.**	
Temperature sensor, coolant, injection system	09.93-06.95		**0 280 130 026**
Wheel speed sensor, front	09.93-06.95	LAB	**0 265 006 538**
		RAB	**0 265 006 537**
Wheel speed sensor, rear	09.93-06.95	LAB	**0 265 006 539**
		RAB	**0 265 006 540**
1.5 i.e. [255..]		**1,5 l 55 kW 149 C 1.000 4 Zyl.**	
Temperature sensor, coolant, injection system	01.88-08.93		**0 280 130 026**
1.6 i.e. [255..]		**1,6 l 59 kW 146 C 6.000 4 Zyl.**	
Temperature sensor, coolant, injection system	09.93-06.95		**0 280 130 026**
Wheel speed sensor, front	09.93-06.95	LAB	**0 265 006 538**
		RAB	**0 265 006 537**
Wheel speed sensor, rear	09.93-06.95	LAB	**0 265 006 539**
		RAB	**0 265 006 540**
1.6 i.e. [255..]		**1,6 l 59 kW 146 D 6.000 4 Zyl.**	
Speed sensor, ignition/injection	06.95-12.01		**0 261 210 127**
Temperature sensor, coolant, injection system	06.95-12.01		**0 280 130 026**
Wheel speed sensor, front	06.95-12.01	LAB	**0 265 006 538**
		RAB	**0 265 006 537**
Wheel speed sensor, rear	06.95-12.01	LAB	**0 265 006 539**
		RAB	**0 265 006 540**
1.7 D [255..]		**1,7 l 43 kW 146 B 2.000 4 Zyl.**	
Wheel speed sensor, front	09.93-12.01	LAB	**0 265 006 538**
		RAB	**0 265 006 537**
Wheel speed sensor, rear	09.93-12.01	LAB	**0 265 006 539**
		RAB	**0 265 006 540**
1.7 TDS [255..]		**1,7 l 46 kW 146 D 7.000 4 Zyl.**	
Wheel speed sensor, front	02.97-12.01	LAB	**0 265 006 538**
		RAB	**0 265 006 537**
Wheel speed sensor, rear	02.97-12.01	LAB	**0 265 006 539**
		RAB	**0 265 006 540**

Fiorino Furgao

1.5 MPI		**1,5 l 56 kW 160 E 1.011 4 Zyl.**	
Wheel speed sensor, front	09.97-06.02	LAB	**0 265 006 538**
		RAB	**0 265 006 537**
Wheel speed sensor, rear	09.97-06.02	LAB	**0 265 006 539**
		RAB	**0 265 006 540**

F

Product

Fiorino Pick-up

1.5 MPI	**1,5 l 56 kW 160 E 1.011 4 Zyl.**		
Wheel speed sensor, front	09.97-06.02	LAB	**0 265 006 538**
		RAB	**0 265 006 537**
Wheel speed sensor, rear	09.97-06.02	LAB	**0 265 006 539**
		RAB	**0 265 006 540**
1.6 MPI	**1,6 l 66 kW 146 B 7.011 4 Zyl.**		
Throttle valve sensor	10.95-10.96		**0 280 122 001**
Speed sensor, ignition/injection	10.95-10.96		**0 261 210 118**
Knock sensor	10.95-10.96		**0 261 231 007**
Pressure sensor, intake manifold, gasoline	10.95-10.96		**0 261 230 004**
Temperature sensor, intake air, injection system	10.95-10.96		**0 280 130 060**

Idea

1.3 JTD 16V [135..]	**1,3 l 52 kW 188 A 9.000 4 Zyl.**		
Air mass meter, diesel	01.04→		**0 281 002 613**
High-pressure sensor (CR system)	01.04→		**0 281 002 534**
Boost pressure sensor, Diesel			
Mot.no. →1376014	01.04→		**0 281 002 510**
Mot.no. 1376015→	01.04→		**0 281 002 844**
Accelerator pedal module	01.04→	RLE	**0 281 002 369**
Acceleration sensor, ABS	01.04-04.06		**0 265 005 127**
Yaw rate sensor, brake system	01.04-04.06		**0 265 005 241**
Wheel speed sensor, rear	01.04-03.07		**0 265 007 503**
1.3 JTD 16V [135..]	**1,3 l 66 kW 199 A 3.000 4 Zyl.**		
Air mass meter, diesel	11.04→		**0 281 002 792**
Boost pressure sensor, Diesel	11.04-11.06		**0 281 002 437**
	12.06→		**0 281 002 845**
Accelerator pedal module	11.04→	RLE	**0 281 002 369**
Acceleration sensor, ABS	11.04-04.06		**0 265 005 127**
Yaw rate sensor, brake system	11.04-04.06		**0 265 005 241**
Wheel speed sensor, rear	11.04-03.07		**0 265 007 503**
1.4 i.e. 8V [135..]	**1,4 l 55 kW 350 A 1.000 4 Zyl.**		
Phase sensor	11.04→		**0 232 103 048**
Pressure sensor, intake manifold, gasoline	11.04→		**0 261 230 030**
Accelerator pedal module	11.04→	RLE	**0 281 002 369**
Acceleration sensor, ABS	11.04-04.06		**0 265 005 127**
Yaw rate sensor, brake system	11.04-04.06		**0 265 005 241**
Wheel speed sensor, rear	11.04-03.07		**0 265 007 503**
1.4 i.e. 8V [135..]	**1,4 l 59 kW 188 A 5.000 4 Zyl.**		
Throttle valve assembly			
Mot.no. →992720	01.04→		**F 01C 600 023**
Mot.no. 992721→	01.04→		**0 280 750 042**
Speed sensor, ignition/injection	01.04→		**0 261 210 238**
Knock sensor	01.04→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	01.04→		**0 261 230 030**
Temperature sensor, coolant, injection system	01.04→		**F 01C 050 016**
Accelerator pedal module	01.04→	RLE	**0 281 002 369**
Acceleration sensor, ABS	01.04-04.06		**0 265 005 127**
Yaw rate sensor, brake system	01.04-04.06		**0 265 005 241**
Wheel speed sensor, rear	01.04-03.07		**0 265 007 503**
1.4 i.e. 16V [135..]	**1,4 l 66/70 kW 192 B 2.000; 843 A 1.000 4 Zyl.**		
Throttle valve assembly	01.04→		**F 01C 600 027**
Speed sensor, ignition/injection	01.04→		**0 261 210 238**
Knock sensor	01.04→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	01.04→		**0 261 230 030**
Accelerator pedal module	01.04→	RLE	**0 281 002 369**
Acceleration sensor, ABS	01.04-04.06		**0 265 005 127**
Yaw rate sensor, brake system	01.04-04.06		**0 265 005 241**
Wheel speed sensor, rear	01.04-03.07		**0 265 007 503**

Product

1.9 JTD 8V [135..]	**1,9 l 74 kW 188 B 2.000 4 Zyl.**		
Speed sensor, diesel	01.04→	KW	**0 281 002 603**
Phase sensor	01.04→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	01.04-10.04		**0 281 002 534**
Boost pressure sensor, Diesel	01.04-03.07		**0 281 002 437**
	04.07→		**0 281 002 845**
Accelerator pedal module	01.04→	RLE	**0 281 002 369**
Acceleration sensor, ABS	01.04-04.06		**0 265 005 127**
Yaw rate sensor, brake system	01.04-04.06		**0 265 005 241**
Wheel speed sensor, rear	01.04-03.07		**0 265 007 503**

Linea

1.3 JTD [110]	**1,3 l 66 kW 199 A 3.000 4 Zyl.**		
Air mass meter, diesel	03.07→		**0 281 002 792**
Boost pressure sensor, Diesel	03.07→		**0 281 002 845**
1.4 Turbo 16V [110]	**1,4 l 88 kW 198 A 4.000 4 Zyl.**		
Phase sensor	03.07→		**0 232 103 048**
Speed sensor, ignition/injection	03.07→		**0 261 210 238**
Knock sensor	03.07→		**0 261 231 173**
Boost pressure sensor, gasoline	03.07→		**0 281 002 844**
1.4 8V [110]	**1,4 l 57 kW 350 A 1.000 4 Zyl.**		
Phase sensor	03.07→		**0 232 103 048**
Pressure sensor, intake manifold, gasoline	03.07→		**0 261 230 030**

Marea

1.2 i 16V [185..]	**1,2 l 60 kW 182 B 2.000 4 Zyl.**		
Throttle valve assembly	03.99-09.02		**0 280 750 013**
Speed sensor, ignition/injection	03.99-09.02		**0 261 210 124**
Knock sensor	03.99-09.02		**0 261 231 007**
Pressure sensor, intake manifold, gasoline	03.99-09.02		**0 261 230 035**
Wheel speed sensor, front	03.99-09.02	LAB	**0 265 007 073**
	03.99-03.01	RAB	**0 265 007 035**
	04.01-09.02	RAB	**0 265 007 074**
Wheel speed sensor, rear	03.99-09.02	LAB	**0 265 007 032**
		RAB	**0 265 007 033**
1.4 i 12V [185..]	**1,4 l 59 kW 182 A 3.000 4 Zyl.**		
Speed sensor, ignition/injection	10.96-02.99		**0 281 002 102**
Knock sensor	10.96-02.99		**0 261 231 007**
Temperature sensor, coolant, injection system	10.96-02.99		**0 280 130 026**
Wheel speed sensor, front			
Ricam.no 0172273→,5054835→	10.96-02.99	LAB,LLE	**0 265 007 034**
Ricam.no 0176273→,5054835→	10.96-02.99	LLE,RAB	**0 265 007 035**
Wheel speed sensor, rear			
Ricam.no 0176273→,5054835→	10.96-02.99	LAB,LLE	**0 265 007 032**
		LLE,RAB	**0 265 007 033**
1.6 i 16V [185..]	**1,6 l 76 kW 182 A 4.000 4 Zyl.**		
Wheel speed sensor, front	03.99→	LAB	**0 265 007 073**
	03.99-03.01	RAB	**0 265 007 035**
	04.01→	RAB	**0 265 007 074**
Ricam.no 0172273→,5054835→	10.96-02.99	LAB,LLE	**0 265 007 034**
Ricam.no 0176273→,5054835→	10.96-02.99	LLE,RAB	**0 265 007 035**
Ricam.no 0180748→	10.96-02.99	LAB,RLE	**0 265 007 034**
		RAB,RLE	**0 265 007 035**
Wheel speed sensor, rear	03.99→	LAB	**0 265 007 032**
		RAB	**0 265 007 033**
Ricam.no 0176273→,5054835→	10.96-02.99	LAB,LLE	**0 265 007 032**
		LLE,RAB	**0 265 007 033**
Ricam.no 0180748→	10.96-02.99	LAB,RLE	**0 265 007 032**
		RAB,RLE	**0 265 007 033**

F

Product			
◀ Marea			
1.6 i 16V [185..]	**1,6 l 76 kW 182 B 5.098 4 Zyl.**		
Wheel speed sensor, front	03.99-09.02	LAB	**0 265 007 073**
	03.99-03.01	RAB	**0 265 007 035**
	04.01-09.02	RAB	**0 265 007 074**
Ricam.no 0172273→,5054835→	10.98-02.99	LAB,LLE	**0 265 007 034**
Ricam.no 0176273→,5054835→	10.98-02.99	LLE,RAB	**0 265 007 035**
Wheel speed sensor, rear	03.99-09.02	LAB	**0 265 007 032**
		RAB	**0 265 007 033**
Ricam.no 0176273→,5054835→	10.98-02.99	LAB,LLE	**0 265 007 032**
		LLE,RAB	**0 265 007 033**
1.6 i 16V [185..]	**1,6 l 76 kW 182 B 6.000 4 Zyl.**		
Wheel speed sensor, front	08.00→	LAB	**0 265 007 073**
	08.00-03.01	RAB	**0 265 007 035**
	04.01→	RAB	**0 265 007 074**
Wheel speed sensor, rear	08.00→	LAB	**0 265 007 032**
		RAB	**0 265 007 033**
1.6 i 16V BI-Power [185..]	**1,6 l 68-76 kW 185 A 3.000 4 Zyl.**		
Wheel speed sensor, front	03.99-09.02	LAB	**0 265 007 073**
	03.99-03.01	RAB	**0 265 007 035**
	04.01-09.02	RAB	**0 265 007 074**
Ricam.no 0172273→,5054835→	10.97-02.99	LAB,LLE	**0 265 007 034**
Ricam.no 0176273→,5054835→	10.97-02.99	LLE,RAB	**0 265 007 035**
Wheel speed sensor, rear	03.99-09.02	LAB	**0 265 007 032**
		RAB	**0 265 007 033**
Ricam.no 0176273→,5054835→	10.97-02.99	LAB,LLE	**0 265 007 032**
		LLE,RAB	**0 265 007 033**
1.8 i 16V [185..]	**1,8 l 83 kW 182 A 2.000 4 Zyl.**		
Phase sensor			
Ricam.no →2018321,→0270958	10.96-09.02		**0 232 101 026**
Ricam.no 2018322→,0270958→	03.99-09.02		**0 232 101 037**
Temperature sensor, coolant, injection system	10.96-02.99		**0 280 130 055**
Ricam.no →2018321,→0270957	03.99-09.02		**0 280 130 055**
Wheel speed sensor, front	03.99-09.02	LAB	**0 265 007 073**
	03.99-03.01	RAB	**0 265 007 035**
	04.01-09.02	RAB	**0 265 007 074**
Ricam.no 0172273→,5054835→	10.96-02.99	LAB,LLE	**0 265 007 034**
Ricam.no 0176273→,5054835→	10.96-02.99	LLE,RAB	**0 265 007 035**
Ricam.no 0180748→	10.96-02.99	LAB,RLE	**0 265 007 034**
		RAB,RLE	**0 265 007 035**
Wheel speed sensor, rear	03.99-09.02	LAB	**0 265 007 032**
		RAB	**0 265 007 033**
Ricam.no 0176273→,5054835→	10.96-02.99	LAB,LLE	**0 265 007 032**
		LLE,RAB	**0 265 007 033**
Ricam.no 0180748→	10.96-02.99	LAB,RLE	**0 265 007 032**
		RAB,RLE	**0 265 007 033**
1.8 MPI 16V	**1,8 l 97 kW 183 A 1.000 4 Zyl.**		
Phase sensor	08.99→		**0 232 101 037**
Wheel speed sensor, front	08.99→	VLI	**0 265 007 034**
		VRE	**0 265 007 035**
Wheel speed sensor, rear	08.99→	HLI	**0 265 007 032**
		HRE	**0 265 007 033**
1.9 JTD [185..]	**1,9 l 74 kW 182 B 9.000 4 Zyl.**		
Air mass meter, diesel	10.01-09.02		**0 281 002 309**
Speed sensor, diesel			
Mot.no. →2151823	10.01-09.02		**0 281 002 214**
Mot.no. 2151824→	10.01-09.02		**0 281 002 474**
Phase sensor	10.01-09.02		**0 281 002 213**
High-pressure sensor (CR system)	10.01-09.02		**0 281 002 260**
		EFV	**0 281 002 405**
Boost pressure sensor, Diesel	10.01-09.02		**0 281 002 510**
Wheel speed sensor, front	10.01-09.02	LAB	**0 265 007 073**
		RAB	**0 265 007 074**

Product			
Wheel speed sensor, rear	10.01-09.02	LAB	**0 265 007 032**
		RAB	**0 265 007 033**
1.9 JTD [185..]	**1,9 l 77 kW 182 B 4.000 4 Zyl.**		
Air mass meter, diesel	03.99-09.02		**0 280 218 019**
Speed sensor, diesel			
Mot.no. →2151823	03.99-09.02		**0 281 002 214**
Mot.no. 2151824→	03.99-09.02		**0 281 002 474**
Phase sensor	03.99-09.02		**0 281 002 213**
High-pressure sensor (CR system)	03.99-09.02		**0 281 002 210**
		EFV	**0 281 002 405**
Boost pressure sensor, Diesel	03.99-09.02		**0 281 002 215**
Temperature sensor, fuel	03.99-09.02		**0 281 002 209**
Wheel speed sensor, front	03.99-09.02	LAB	**0 265 007 073**
	03.99-03.01	RAB	**0 265 007 035**
	04.01-09.02	RAB	**0 265 007 074**
Wheel speed sensor, rear	03.99-09.02	LAB	**0 265 007 032**
		RAB	**0 265 007 033**
1.9 JTD [185..]	**1,9 l 81 kW 186 A 6.000 4 Zyl.**		
Air mass meter, diesel	08.00-09.02		**0 281 002 308**
Speed sensor, diesel			
Mot.no. →2151823	08.00-09.02		**0 281 002 214**
Mot.no. 2151824→	08.00-09.02		**0 281 002 474**
Phase sensor	08.00-09.02		**0 281 002 213**
High-pressure sensor (CR system)	08.00-09.02		**0 281 002 260**
		EFV	**0 281 002 405**
Boost pressure sensor, Diesel			
Mot.no. →2705194	08.00-07.01		**0 281 002 215**
Mot.no. 2705195→	08.01-09.02		**0 281 002 510**
Wheel speed sensor, front	08.00-09.02	LAB	**0 265 007 073**
	08.00-03.01	RAB	**0 265 007 035**
	04.01-09.02	RAB	**0 265 007 074**
Wheel speed sensor, rear	08.00-09.02	LAB	**0 265 007 032**
		RAB	**0 265 007 033**
1.9 TD [185..]	**1,9 l 55,1 kW 182 A 8.000 4 Zyl.**		
Speed sensor, diesel	10.96-09.02		**0 281 002 102**
Wheel speed sensor, front	03.99-09.02	LAB	**0 265 007 073**
	03.99-03.01	RAB	**0 265 007 035**
	04.01-09.02	RAB	**0 265 007 074**
Ricam.no 0172273→,5054835→	10.96-02.99	LAB,LLE	**0 265 007 034**
Ricam.no 0176273→,5054835→	10.96-02.99	LLE,RAB	**0 265 007 035**
Ricam.no 0180748→	10.96-02.99	LAB,RLE	**0 265 007 034**
		RAB,RLE	**0 265 007 035**
Wheel speed sensor, rear	03.99-09.02	LAB	**0 265 007 032**
		RAB	**0 265 007 033**
1.9 TD [185..]	**1,9 l 73,6 kW 182 A 7.000 4 Zyl.**		
Air mass meter, diesel	10.96-02.99		**0 281 002 144**
Speed sensor, diesel	10.96-02.99		**0 281 002 102**
Temperature sensor, coolant, diesel	10.96-02.99		**0 280 130 055**
Temperature sensor, intake air, diesel	10.96-02.99		**0 280 130 073**
Wheel speed sensor, front			
Ricam.no 0172273→,5054835→	10.96-02.99	LAB,LLE	**0 265 007 034**
Ricam.no 0176273→,5054835→	10.96-02.99	LLE,RAB	**0 265 007 035**
Ricam.no 0180748→	10.96-02.99	LAB,RLE	**0 265 007 034**
		RAB,RLE	**0 265 007 035**
2.0 i 20V [185..]	**2,0 l 108 kW 182 A 1.000 5 Zyl.**		
Throttle valve sensor	10.96-02.99		**0 280 122 001**
Air mass meter, gasoline injection	10.96-02.99		**0 280 217 111**
Phase sensor			
Ricam.no →2018321,→0270958	10.96-02.99		**0 232 101 026**
Speed sensor, ignition/injection	10.96-02.99		**0 281 002 102**
Knock sensor	10.96-02.99		**0 261 231 095**
Temperature sensor, intake air, injection system	10.96-02.99		**0 280 130 073**
Temperature sensor, coolant, injection system	10.96-02.99		**0 280 130 026**

F

Product			
Relay, Jetronic	10.96-02.99		**0 332 014 140**
Wheel speed sensor, front			
Ricam.no 0172273→,5054835→	10.96-02.99	LAB,LLE	**0 265 007 034**
Ricam.no 0176273→,5054835→	10.96-02.99	LLE,RAB	**0 265 007 035**
Wheel speed sensor, rear			
Ricam.no 0176273→,5054835→	10.96-02.99	LAB,LLE	**0 265 007 032**
		LLE,RAB	**0 265 007 033**
2.0 i 20V [185..]	**2,0 l 110 kW 185 A 8.000 5 Zyl.**		
Throttle valve assembly	08.00→		**0 205 003 052**
Air mass meter, gasoline injection	08.00→		**0 281 002 309**
Phase sensor	08.00→		**0 232 101 036**
Speed sensor, ignition/injection	08.00→		**0 261 210 160**
Knock sensor	08.00→		**0 261 231 144**
Temperature sensor, intake air, injection system	08.00-09.02		**0 280 130 073**
Wheel speed sensor, front	08.00→	LAB	**0 265 007 073**
	08.00-03.01	RAB	**0 265 007 035**
	04.01→	RAB	**0 265 007 074**
Wheel speed sensor, rear	08.00→	LAB	**0 265 007 032**
		RAB	**0 265 007 033**
2.0 i 20V [185..]	**2,0 l 113 kW 182 B 7.000 5 Zyl.**		
Throttle valve assembly	03.99→		**0 205 003 052**
Air mass meter, gasoline injection	03.99→		**0 280 218 019**
Phase sensor	03.99→		**0 232 101 036**
Speed sensor, ignition/injection	03.99→		**0 261 210 160**
Knock sensor	03.99→		**0 261 231 144**
Temperature sensor, intake air, injection system	03.99→		**0 280 130 073**
Wheel speed sensor, front	03.99→	LAB	**0 265 007 073**
	03.99-03.01	RAB	**0 265 007 035**
	04.01→	RAB	**0 265 007 074**
Wheel speed sensor, rear	03.99→	LAB	**0 265 007 032**
		RAB	**0 265 007 033**
2.4 JTD [185..]	**2,4 l 100 kW 185 A 6.000 5 Zyl.**		
Air mass meter, diesel	03.99-09.02		**0 280 218 004**
Speed sensor, diesel			
Mot.no. →2151823	03.99-09.02		**0 281 002 214**
Mot.no. 2151824→	03.99-09.02		**0 281 002 474**
Phase sensor	03.99-09.02		**0 281 002 213**
High-pressure sensor (CR system)	03.99-09.02		**0 281 002 210**
		EFV	**0 281 002 405**
Boost pressure sensor, Diesel	03.99-09.02		**0 281 002 215**
Temperature sensor, intake air, diesel	03.99-09.02		**0 280 130 073**
Temperature sensor, fuel	03.99-09.02		**0 281 002 209**
Wheel speed sensor, front	03.99-09.02	LAB	**0 265 007 073**
	03.99-03.01	RAB	**0 265 007 035**
	04.01-09.02	RAB	**0 265 007 074**
Wheel speed sensor, rear	03.99-09.02	LAB	**0 265 007 032**
		RAB	**0 265 007 033**
2.4 MPI 20V	**2,4 l 118 kW 185 A 7.011 5 Zyl.**		
Throttle valve assembly	08.00→		**1 287 213 608**
Air mass meter, gasoline injection	08.00→		**0 280 218 019**
Phase sensor	08.00→		**0 232 101 036**
Speed sensor, ignition/injection	08.00→		**0 261 210 160**
Knock sensor	08.00→		**0 261 231 144**
Wheel speed sensor, front	08.00→	VLI	**0 265 007 034**
		VRE	**0 265 007 035**
Wheel speed sensor, rear	08.00→	HLI	**0 265 007 032**
		HRE	**0 265 007 033**
2.4 TD [185..]	**2,4 l 91 kW 185 A 2.000 5 Zyl.**		
Air flow sensor, diesel			
Mot.no. →0918279	10.96-02.99		**0 281 002 185**
Air mass meter, diesel			
Mot.no. 0918280→	10.96-02.99		**0 281 002 144**

Product			
Speed sensor, diesel	10.96-02.99		**0 281 002 102**
Temperature sensor, coolant, diesel	10.96-02.99		**0 280 130 055**
Temperature sensor, intake air, diesel	10.96-02.99		**0 280 130 073**
Wheel speed sensor, front			
Ricam.no 0172273→,5054835→	10.96-02.99	LAB,LLE	**0 265 007 034**
Ricam.no 0176273→,5054835→	10.96-02.99	LLE,RAB	**0 265 007 035**
Ricam.no 0180748→	10.96-02.99	LAB,RLE	**0 265 007 034**
		RAB,RLE	**0 265 007 035**

Marea Weekend

1.8 MPI 16V	**1,8 l 97 kW 183 A 1.000 4 Zyl.**		
Phase sensor	08.99→		**0 232 101 037**
Wheel speed sensor, front	08.99→	VLI	**0 265 007 034**
		VRE	**0 265 007 035**
Wheel speed sensor, rear	08.99→	HLI	**0 265 007 032**
		HRE	**0 265 007 033**

Marengo

1.9 D [259..]	**1,9 l 48 kW 160 A 7.000 4 Zyl.**		
Wheel speed sensor, front	04.93-12.96	WW	**0 265 001 215**
Wheel speed sensor, rear	04.93-12.96	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.9 D Turbo [259..]	**1,9 l 66 kW 160 A 6.000 4 Zyl.**		
Wheel speed sensor, front	02.90-03.93		**0 265 001 215**
Wheel speed sensor, rear	02.90-12.96	LAB	**0 265 001 216**
	04.93-12.96	RAB	**0 265 001 217**
	02.90-03.93	RAB	**0 265 006 197**
1.9 JTD [285..]	**1,9 l 77 kW 182 B 4.000 4 Zyl.**		
Air mass meter, diesel	03.99-09.02		**0 280 218 019**
Speed sensor, diesel			
Mot.no. →2151823	03.99-09.02		**0 281 002 214**
Mot.no. 2151824→	03.99-09.02		**0 281 002 474**
Phase sensor	03.99-09.02		**0 281 002 213**
High-pressure sensor (CR system)	03.99-09.02		**0 281 002 210**
		EFV	**0 281 002 405**
Boost pressure sensor, Diesel	03.99-09.02		**0 281 002 215**
Temperature sensor, fuel	03.99-09.02		**0 281 002 209**
Wheel speed sensor, front	03.99-09.02	LAB	**0 265 007 073**
	03.99-03.01	RAB	**0 265 007 035**
	04.01-09.02	RAB	**0 265 007 074**
Wheel speed sensor, rear	03.99-09.02	LAB	**0 265 007 032**
		RAB	**0 265 007 033**
1.9 JTD [285..]	**1,9 l 81 kW 186 A 6.000 4 Zyl.**		
Air mass meter, diesel	08.00-09.02		**0 281 002 308**
Speed sensor, diesel			
Mot.no. →2151823	08.00-09.02		**0 281 002 214**
Mot.no. 2151824→	08.00-09.02		**0 281 002 474**
Phase sensor	08.00-09.02		**0 281 002 213**
High-pressure sensor (CR system)	08.00-09.02		**0 281 002 260**
		EFV	**0 281 002 405**
Boost pressure sensor, Diesel			
Mot.no. →2705194	08.00-07.01		**0 281 002 215**
Mot.no. 2705195→	08.01-09.02		**0 281 002 510**
Wheel speed sensor, front	08.00-09.02	LAB	**0 265 007 073**
	08.00-03.01	RAB	**0 265 007 035**
	04.01-09.02	RAB	**0 265 007 074**
Wheel speed sensor, rear	08.00-09.02	LAB	**0 265 007 032**
		RAB	**0 265 007 033**

F

Product

◀ Marengo

1.9 TD [285..]	**1,9 l 55 kW 182 A 8.000 4 Zyl.**		
Speed sensor, diesel	03.99-09.02		**0 281 002 102**
Wheel speed sensor, front	03.99-09.02	LAB	**0 265 007 073**
	03.99-03.01	RAB	**0 265 007 035**
	04.01-09.02	RAB	**0 265 007 074**
Wheel speed sensor, rear	03.99-09.02	LAB	**0 265 007 032**
		RAB	**0 265 007 033**
1.9 TD [285..]	**1,9 l 55,1 kW 182 A 8.000 4 Zyl.**		
Speed sensor, diesel	01.97-09.02		**0 281 002 102**
Wheel speed sensor, front	03.99-09.02	LAB,LLE	**0 265 007 073**
Ricam.no 0172273→,5054835→	01.97-02.99	LAB,LLE	**0 265 007 034**
Ricam.no 0176273→,5054835→	01.97-09.02	LLE,RAB	**0 265 007 035**
Wheel speed sensor, rear			
Ricam.no 0176273→,5054835→	01.97-09.02	LAB,LLE	**0 265 007 032**
		LLE,RAB	**0 265 007 033**
1.9 TD [285..]	**1,9 l 73,6 kW 182 A 7.000 4 Zyl.**		
Air mass meter, diesel	01.97-02.99		**0 281 002 144**
Speed sensor, diesel	01.97-02.99		**0 281 002 102**
Temperature sensor, coolant, diesel	01.97-02.99		**0 280 130 055**
Temperature sensor, intake air, diesel	01.97-02.99		**0 280 130 073**
Wheel speed sensor, front			
Ricam.no 0172273→,5054835→	01.97-02.99	LAB,LLE	**0 265 007 034**
Ricam.no 0176273→,5054835→	01.97-02.99	LLE,RAB	**0 265 007 035**
Wheel speed sensor, rear			
Ricam.no 0176273→,5054835→	01.97-02.99	LAB,LLE	**0 265 007 032**
		LLE,RAB	**0 265 007 033**

Multipla

1.6 Blupower [186..]	**1,6 l 70 kW 186 A 3.000 4 Zyl.**		
Wheel speed sensor, front	01.99-03.02	LAB	**0 265 007 038**
		RAB	**0 265 007 039**
Ricam.no →2152664	04.02→	LAB	**0 265 007 038**
		RAB	**0 265 007 039**
Ricam.no 2152665→	04.02→	LAB	**0 265 007 561**
		RAB	**0 265 007 560**
Wheel speed sensor, rear	01.99-03.02	LAB	**0 265 007 036**
		RAB	**0 265 007 037**
Ricam.no →2152664	04.02→	LAB	**0 265 007 551**
		RAB	**0 265 007 550**
Ricam.no 2152665→	04.02→	LAB	**0 265 007 563**
		RAB	**0 265 007 562**
1.6 16V [186..]	**1,6 l 76 kW 182 A 4.000 4 Zyl.**		
Wheel speed sensor, front	01.99-03.02	LAB	**0 265 007 038**
		RAB	**0 265 007 039**
Wheel speed sensor, rear	01.99-03.02	LAB	**0 265 007 036**
		RAB	**0 265 007 037**
1.6 16V [186..]	**1,6 l 76 kW 182 B 6.000 4 Zyl.**		
Yaw rate sensor, brake system	04.02→		**0 265 005 241**
Wheel speed sensor, front			
Ricam.no →2152664	09.00→	LAB	**0 265 007 038**
		RAB	**0 265 007 039**
Ricam.no 2152665→	09.00→	LAB	**0 265 007 561**
		RAB	**0 265 007 560**
Wheel speed sensor, rear	09.00-03.02	LAB	**0 265 007 036**
		RAB	**0 265 007 037**
Ricam.no →2152664	04.02→	LAB	**0 265 007 551**
		RAB	**0 265 007 550**
Ricam.no 2152665→	09.00→	LAB	**0 265 007 563**
		RAB	**0 265 007 562**

Product

1.6 16V Bipower [186..]	**1,6 l 68-76 kW 182 B 6.000 4 Zyl.**		
Yaw rate sensor, brake system	04.02→		**0 265 005 241**
Wheel speed sensor, front			
Ricam.no →2152664	01.01→	LAB	**0 265 007 038**
		RAB	**0 265 007 039**
Ricam.no 2152665→	01.01→	LAB	**0 265 007 561**
		RAB	**0 265 007 560**
Wheel speed sensor, rear	01.01-03.02	LAB	**0 265 007 036**
		RAB	**0 265 007 037**
Ricam.no →2152664	04.02→	LAB	**0 265 007 551**
		RAB	**0 265 007 550**
Ricam.no 2152665→	01.01→	LAB	**0 265 007 563**
		RAB	**0 265 007 562**
1.6 16V Bipower [186..]	**1,6 l 68-76 kW 186 A 4.000 4 Zyl.**		
Wheel speed sensor, front	01.99-03.02	LAB	**0 265 007 038**
		RAB	**0 265 007 039**
Wheel speed sensor, rear	01.99-03.02	LAB	**0 265 007 036**
		RAB	**0 265 007 037**
1.6 16V GPL [186..]	**1,6 l 68-76 kW 182 B 6.000 4 Zyl.**		
Wheel speed sensor, front			
Ricam.no →2152664	01.01→	LAB	**0 265 007 038**
		RAB	**0 265 007 039**
Ricam.no 2152665→	01.01→	LAB	**0 265 007 561**
		RAB	**0 265 007 560**
Wheel speed sensor, rear	01.01-03.02	LAB	**0 265 007 036**
		RAB	**0 265 007 037**
Ricam.no →2152664	04.02→	LAB	**0 265 007 551**
		RAB	**0 265 007 550**
Ricam.no 2152665→	01.01→	LAB	**0 265 007 563**
		RAB	**0 265 007 562**
1.9 JTD [186..]	**1,9 l 77 kW 182 B 4.000 4 Zyl.**		
Air mass meter, diesel	01.99-12.00		**0 280 218 004**
Speed sensor, diesel			
Mot.no. →2151823	01.99-12.00		**0 281 002 214**
Mot.no. 2151824→	01.99-12.00		**0 281 002 474**
Phase sensor	01.99-12.00		**0 281 002 213**
High-pressure sensor (CR system)	01.99-07.99		**0 281 002 210**
	08.99-12.00		**0 281 002 405**
Boost pressure sensor, Diesel	01.99-12.00		**0 281 002 510**
Temperature sensor, fuel	01.99-12.00		**0 281 002 209**
Wheel speed sensor, front	01.99-12.00	LAB	**0 265 007 038**
		RAB	**0 265 007 039**
Wheel speed sensor, rear	01.99-12.00	LAB	**0 265 007 036**
		RAB	**0 265 007 037**
1.9 JTD [186..]	**1,9 l 81 kW 186 A 6.000 4 Zyl.**		
Air mass meter, diesel	08.00-03.02		**0 281 002 308**
Speed sensor, diesel			
Mot.no. →2151823	08.00-03.02		**0 281 002 214**
Mot.no. 2151824→	08.00-03.02		**0 281 002 474**
Phase sensor	08.00-03.02		**0 281 002 213**
High-pressure sensor (CR system)	08.00-03.02		**0 281 002 405**
Boost pressure sensor, Diesel			
Mot.no. →2705194	08.00-07.01		**0 281 002 215**
Mot.no. 2705195→	08.01-03.02		**0 281 002 510**
Wheel speed sensor, front	08.00-03.02	LAB	**0 265 007 038**
		RAB	**0 265 007 039**
Wheel speed sensor, rear	08.00-03.02	LAB	**0 265 007 036**
		RAB	**0 265 007 037**
1.9 JTD [186..]	**1,9 l 85 kW 186 A 8.000 4 Zyl.**		
Air mass meter, diesel	11.03→		**0 280 218 120**
	04.02-10.03		**0 281 002 308**
	10.03→		**0 281 002 792**

F

Product			
Speed sensor, diesel	10.03→	KW	**0 281 002 603**
Mot.no. →3927658	04.02→		**0 281 002 474**
Mot.no. 3927659→	04.02→		**0 281 002 603**
Phase sensor	04.02→		**0 281 002 213**
	10.03→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	04.02-02.04		**0 281 002 405**
	10.03→		**0 281 002 534**
Boost pressure sensor, Diesel	10.03-03.07		**0 281 002 437**
	04.02-08.06		**0 281 002 510**
	09.06→		**0 281 002 844**
	04.07→		**0 281 002 845**
Pedal position sensor, diesel	04.02→	RLE	**0 281 002 386**
Yaw rate sensor, brake system	04.02→		**0 265 005 241**
Wheel speed sensor, front			
Ricam.no →2152664	04.02→	LAB	**0 265 007 038**
		RAB	**0 265 007 039**
Ricam.no 2152665→	04.02→	LAB	**0 265 007 561**
		RAB	**0 265 007 560**
Wheel speed sensor, rear			
Ricam.no →2152664	04.02→	LAB	**0 265 007 551**
		RAB	**0 265 007 550**
Ricam.no 2152665→	04.02→	LAB	**0 265 007 563**
		RAB	**0 265 007 562**
1.9 JTD [186..]	**1,9 l 88 kW 186 A 9.000 4 Zyl.**		
Air mass meter, diesel	10.05→		**0 281 002 792**
Speed sensor, diesel	10.05→	KW	**0 281 002 603**
Phase sensor	10.05→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	10.05→		**0 281 002 534**
Boost pressure sensor, Diesel	10.05-03.07		**0 281 002 437**
	04.07→		**0 281 002 845**
Pedal position sensor, diesel	10.05→	RLE	**0 281 002 386**
Yaw rate sensor, brake system	10.05→		**0 265 005 241**
Wheel speed sensor, front			
Ricam.no →2152664	10.05→	LAB	**0 265 007 038**
		RAB	**0 265 007 039**
Ricam.no 2152665→	10.05→	LAB	**0 265 007 561**
		RAB	**0 265 007 560**
Wheel speed sensor, rear			
Ricam.no →2152664	10.05→	LAB	**0 265 007 551**
		RAB	**0 265 007 550**
Ricam.no 2152665→	10.05→	LAB	**0 265 007 563**
		RAB	**0 265 007 562**

Nuova Croma

1.9 JTD 8V [194..]	**1,9 l 85/88 kW 939 A 1.000 4 Zyl.**		
Speed sensor, diesel	06.05→	KW	**0 281 002 603**
Phase sensor	06.05→		**0 281 002 213**
High-pressure sensor (CR system)	06.05→		**0 281 002 534**
Boost pressure sensor, Diesel	06.05→		**0 281 002 437**
1.9 JTD 16V [194..]	**1,9 l 100/110 kW 939 A 1.000; 939 A 2.000 4 Zyl.**		
High-pressure sensor (CR system)	06.05→		**0 281 002 534**
Boost pressure sensor, Diesel	06.05→		**0 281 002 437**
2.4 JTD [194..]	**2,4 l 147 kW 939 A 3.000 5 Zyl.**		
Air mass meter, diesel	06.05→		**0 281 002 763**
High-pressure sensor (CR system)	06.05→		**0 281 002 534**
Boost pressure sensor, Diesel	06.05→		**0 281 002 437**

Nuova 500

1.2 8V [150..]	**1,2 l 51 kW 169 A 4.000 4 Zyl.**		
Phase sensor	07.07→		**0 232 103 048**
Pressure sensor, intake manifold, gasoline	07.07→		**0 261 230 030**
Yaw rate sensor, brake system	07.07→		**0 265 005 607**
1.3 MJTD [150..]	**1,3 l 55 kW 169 A 1.000 4 Zyl.**		
Boost pressure sensor, Diesel	07.07→		**0 281 002 844**
Yaw rate sensor, brake system	07.07→		**0 265 005 607**
1.4 16V [150..]	**1,4 l 74 kW 169 A 3.000 4 Zyl.**		
Throttle valve assembly	07.07→		**F 01C 600 027**
Phase sensor	07.07→		**0 232 103 048**
Speed sensor, ignition/injection	07.07→		**0 261 210 238**
Knock sensor	07.07→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	07.07→		**F 01C 600 070**
Yaw rate sensor, brake system	07.07→		**0 265 005 607**

Palio

1.0 MPI 8V	**1,0 l 45 kW 178 A 3.011 4 Zyl.**		
Wheel speed sensor, front	06.96-08.01	LAB	**0 265 006 163**
		RAB	**0 265 006 164**
Wheel speed sensor, rear	06.96-08.01		**0 265 006 249**
1.0 MPI 8V 6 Marchas	**1,0 l 45 kW 178 A 3.011 4 Zyl.**		
Wheel speed sensor, front	01.99-10.00	LAB	**0 265 006 163**
		RAB	**0 265 006 164**
Wheel speed sensor, rear	01.99-10.00		**0 265 006 249**
1.0 MPI 16V	**1,0 l 51,5 kW 178 D 8.011 4 Zyl.**		
Throttle valve assembly	08.00-02.03		**F 01C 600 023**
Speed sensor, ignition/injection	08.00-02.03		**0 261 210 161**
Knock sensor	08.00-02.03		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	08.00-02.03		**0 261 230 030**
Wheel speed sensor, front	08.00-02.03	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	08.00-02.03		**0 265 007 051**
1.1 [178..]	**1,1 l 40 kW 178 B 9.033 4 Zyl.**		
Wheel speed sensor, front	03.01-07.01	LAB	**0 265 006 163**
	03.98-07.01	RAB	**0 265 006 164**
Wheel speed sensor, rear	03.01-07.01		**0 265 006 249**
1.2 i.e. 8V [171..]	**1,2 l 44 kW 188 A 4.000 4 Zyl.**		
Speed sensor, ignition/injection	10.01→		**0 261 210 114**
1.2 i.e. 8V [171..]	**1,2 l 46 kW 178 C 4.066 4 Zyl.**		
Phase sensor	07.01→		**0 232 103 039**
Speed sensor, ignition/injection	07.01-10.03	OLH	**0 261 210 114**
	11.03→	OLH	**0 261 210 114**
Wheel speed sensor, front	07.01→	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	07.01→		**0 265 007 051**
1.2 i.e. 8V [171..]	**1,2 l 54 kW 178 B 7.045 4 Zyl.**		
Phase sensor			
Mot.no. 2935744→	10.01→		**0 232 103 048**
Speed sensor, ignition/injection	10.01-10.03	OLH	**0 261 210 114**
	11.03→	OLH	**0 261 210 114**
1.2 i.e. 8V [178..]	**1,2 l 44 kW 178 B 5.000 4 Zyl.**		
Phase sensor	01.01-09.01		**0 232 103 039**
Speed sensor, ignition/injection	09.00-08.02		**0 261 210 114**
Wheel speed sensor, front	01.01-09.01	LAB	**0 265 006 163**
	03.01-08.02	LAB	**0 265 006 163**
	09.00-08.02	RAB	**0 265 006 164**
Wheel speed sensor, rear	01.01-09.01		**0 265 006 249**
	03.01-08.02		**0 265 006 249**

F

Product

◀ Palio

1.2 i.e. 8V [178..]	**1,2 l 44/54 kW 178 B 7.045; 188 A 4.000 4 Zyl.**		
Speed sensor, ignition/injection	03.00-09.01		**0 261 210 114**
Wheel speed sensor, front	03.00-09.01	LAB	**0 265 006 163**
		RAB	**0 265 006 164**
Wheel speed sensor, rear	03.00-09.01		**0 265 006 249**
1.2 i.e. 8V [178..]	**1,2 l 54 kW 178 E 2.000 4 Zyl.**		
Speed sensor, ignition/injection	11.99-09.01	OLH	**0 261 210 114**
Wheel speed sensor, front	11.99-09.01	LAB	**0 265 006 163**
		RAB	**0 265 006 164**
Wheel speed sensor, rear	11.99-09.01		**0 265 006 249**
1.2 i.e. 16V [171..]	**1,2 l 59 kW 188 A 5.000 4 Zyl.**		
Throttle valve assembly	10.01→		**0 280 750 042**
Speed sensor, ignition/injection	10.01→		**0 261 210 219**
Knock sensor	10.01→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	10.01→		**0 261 230 030**
Temperature sensor, coolant, injection system	10.01→		**F 01C 050 016**
Accelerator pedal module	10.01→		**0 281 002 379**
Wheel speed sensor, front	10.01→	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	10.01→		**0 265 007 051**
1.3 JTD 16V [171..]	**1,2 l 52 kW 188 A 9.000 4 Zyl.**		
Air mass meter, diesel	07.03→		**0 281 002 613**
High-pressure sensor (CR system)	07.03→		**0 281 002 534**
Boost pressure sensor, Diesel			
Mot.no. →1376014	07.03→		**0 281 002 510**
Mot.no. 1376015→	07.03→		**0 281 002 844**
Accelerator pedal module	07.03→		**0 281 002 379**
		RLE	**0 281 002 369**
Wheel speed sensor, front	07.03→	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	07.03→		**0 265 007 051**
1.3 MPI 16V	**1,3 l 59 kW 178 D 6.011 4 Zyl.**		
Throttle valve assembly	03.00→		**F 01C 600 023**
Speed sensor, ignition/injection	03.00→		**0 261 210 161**
Knock sensor	03.00→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	03.00→		**0 261 230 030**
Accelerator pedal module	03.00-02.03		**0 281 002 379**
Wheel speed sensor, front	03.00-09.00	LAB	**0 265 006 163**
	10.00→	LAB	**0 265 007 103**
	03.00-09.00	RAB	**0 265 006 164**
	10.00→	RAB	**0 265 007 102**
Wheel speed sensor, rear	03.00-09.00		**0 265 006 249**
	10.00→		**0 265 007 051**
1.4 i.e. [171..]	**1,4 l 57 kW 350 A 1.000 4 Zyl.**		
Phase sensor	07.03→		**0 232 103 048**
Pressure sensor, intake manifold, gasoline	07.03→		**0 261 230 030**
Accelerator pedal module	07.03→		**0 281 002 379**
Wheel speed sensor, front	07.03→	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	07.03→		**0 265 007 051**
1.4 i.e. [178..]	**1,4 l 51 kW 178 B 2.000; 178 B 2.016 4 Zyl.**		
Speed sensor, ignition/injection	03.98-09.01		**0 261 210 104**
Wheel speed sensor, front	03.98-09.01	LAB	**0 265 006 163**
		RAB	**0 265 006 164**
Wheel speed sensor, rear	03.98-09.01		**0 265 006 249**
1.5 MPI 8V	**1,5 l 60 kW 178 A 5.011 4 Zyl.**		
Wheel speed sensor, front	04.96-11.99	LAB	**0 265 006 163**
		RAB	**0 265 006 164**
Wheel speed sensor, rear	04.96-11.99		**0 265 006 249**
1.6 i.e. 16V [171..]	**1,6 l 74/76 kW 182 B 6.000 4 Zyl.**		
Wheel speed sensor, front	07.01→	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	07.01→		**0 265 007 051**

Product

1.6 i.e. 16V [178..]	**1,6 l 74/76 kW 178 B 3.000; 178 D 2.011; 182 B 6.000 4 Zyl.**		
Wheel speed sensor, front	03.98-09.01	LAB	**0 265 006 163**
		RAB	**0 265 006 164**
Wheel speed sensor, rear	03.98-09.01		**0 265 006 249**
1.6 i.e. 16V Sport [171..]	**1,6 l 76 kW 178 E 7.000 4 Zyl.**		
Wheel speed sensor, front	10.01→	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	10.01→		**0 265 007 051**
1.7 D Turbo	**1,7 l 52 kW 4 Zyl.**		
Wheel speed sensor, front	01.04→	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	01.04→		**0 265 007 051**
1.7 D Turbo [Fase II]	**1,7 l 52 kW 4 Zyl.**		
Wheel speed sensor, front	01.04→	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	01.04→		**0 265 007 051**
1.9 D [171..]	**1,9 l 48 kW 223 A 6.000 4 Zyl.**		
Speed sensor, diesel	01.03-06.05		**0 281 002 474**
Wheel speed sensor, front	01.03-06.05	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	01.03-06.05		**0 265 007 051**

Palio Weekend

1.0 MPI 16V	**1,0 l 51 kW 178 D 8.011 4 Zyl.**		
Throttle valve assembly	09.00-08.01		**F 01C 600 023**
	08.02-02.03		**F 01C 600 023**
Speed sensor, ignition/injection	09.00-02.03		**0 261 210 161**
Knock sensor	09.00-02.03		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	09.00-02.03		**0 261 230 030**
Wheel speed sensor, front	09.00-02.03	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	09.00-02.03	LAB	**0 265 007 052**
		RAB	**0 265 007 053**
1.2 i.e. [178..]	**1,2 l 44 kW 178 C 4.066 4 Zyl.**		
Speed sensor, ignition/injection	08.00-02.02		**0 261 210 114**
Wheel speed sensor, front	08.00-02.02	LAB	**0 265 006 163**
		RAB	**0 265 006 164**
Wheel speed sensor, rear	08.00-02.02	LAB	**0 265 006 364**
		RAB	**0 265 006 365**
1.2 i.e. 8V [173..]	**1,2 l 44 kW 188 A 4.000 4 Zyl.**		
Speed sensor, ignition/injection	10.01-10.03		**0 261 210 114**
	11.03→		**0 261 210 114**
Wheel speed sensor, front	10.01→	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	10.01→	LAB	**0 265 007 052**
		RAB	**0 265 007 053**
1.2 i.e. 8V [178..]	**1,2 l 44 kW 178 B 5.000 4 Zyl.**		
Phase sensor	01.01-09.01		**0 232 103 039**
Speed sensor, ignition/injection	03.99-09.01		**0 261 210 114**
Wheel speed sensor, front	03.99-09.01	LAB	**0 265 006 163**
		RAB	**0 265 006 164**
Wheel speed sensor, rear	03.99-09.01	LAB	**0 265 006 364**
		RAB	**0 265 006 365**
1.2 i.e. 16V [173..]	**1,2 l 59 kW 188 A 5.000 4 Zyl.**		
Throttle valve assembly	10.01-01.06		**F 01C 600 023**
	02.06→		**0 280 750 042**
Phase sensor	10.01→		**0 232 103 048**
Speed sensor, ignition/injection	10.01→		**0 261 210 219**
Knock sensor	10.01→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	10.01→		**0 261 230 030**
Temperature sensor, coolant, injection system	10.01→		**F 01C 050 016**
Accelerator pedal module	10.01→		**0 281 002 379**

F

Product			
Wheel speed sensor, front	10.01→	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	10.01→	LAB	**0 265 007 052**
		RAB	**0 265 007 053**
1.3 i MPI 16V [173..]		**1,2 l 59 kW 188 A 5.000 4 Zyl.**	
Throttle valve assembly	06.03-01.06		**F 01C 600 023**
	02.06-02.07		**0 280 750 042**
Speed sensor, ignition/injection	06.03-02.07		**0 261 210 219**
Knock sensor	06.03-02.07		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	06.03-02.07		**0 261 230 030**
Temperature sensor, coolant, injection system	06.03-02.07		**F 01C 050 016**
Accelerator pedal module	06.03-02.07		**0 281 002 379**
Wheel speed sensor, front	06.03-02.07	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	06.03-02.07	LAB	**0 265 007 052**
		RAB	**0 265 007 053**
1.3 MPI 16V		**1,3 l 59 kW 178 D 6.011 4 Zyl.**	
Throttle valve assembly	03.00-02.03		**F 01C 600 023**
Speed sensor, ignition/injection	03.00-02.03		**0 261 210 161**
Knock sensor	03.00-02.03		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	03.00-02.03		**0 261 230 030**
Accelerator pedal module	03.00-02.03		**0 281 002 379**
Wheel speed sensor, front	03.00-09.00	LAB	**0 265 006 163**
	10.00-02.03	LAB	**0 265 007 103**
	03.00-09.00	RAB	**0 265 006 164**
	10.00-02.03	RAB	**0 265 007 102**
Wheel speed sensor, rear	03.00-09.00	LAB	**0 265 006 364**
	10.00-02.03	LAB	**0 265 007 052**
	03.00-09.00	RAB	**0 265 006 365**
	10.00-02.03	RAB	**0 265 007 053**
1.4 i.e. [178..]		**1,4 l 51 kW 178 B 2.000; 178 B 2.016 4 Zyl.**	
Speed sensor, ignition/injection	11.97-06.01		**0 261 210 104**
Wheel speed sensor, front	11.97-06.01	LAB	**0 265 006 163**
		RAB	**0 265 006 164**
Wheel speed sensor, rear	11.97-06.01	LAB	**0 265 006 364**
		RAB	**0 265 006 365**
1.6 i.e. 8V [178..]		**1,6 l 69 kW 178 C 8.098 4 Zyl.**	
Speed sensor, ignition/injection	06.01-09.02		**0 261 210 104**
Wheel speed sensor, front	06.01-09.02	LAB	**0 265 006 163**
		RAB	**0 265 006 164**
Wheel speed sensor, rear	06.01-09.02	LAB	**0 265 006 364**
		RAB	**0 265 006 365**
1.6 i.e. 16V [173..]		**1,6 l 76 kW 182 B 6.000 4 Zyl.**	
Wheel speed sensor, front	10.01→	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	10.01→	LAB	**0 265 007 052**
		RAB	**0 265 007 053**
1.6 i.e. 16V [178..]		**1,6 l 74/76 kW 176 D 2.011; 178 B 3.000; 178 C 7.098; 182 B 6.000 4 Zyl.**	
Wheel speed sensor, front	11.97→	LAB	**0 265 006 163**
		RAB	**0 265 006 164**
Wheel speed sensor, rear	11.97→	LAB	**0 265 006 364**
		RAB	**0 265 006 365**
1.6 MPI 16V		**1,6 l 78 kW 178 D 2.011 4 Zyl.**	
Wheel speed sensor, front	05.97-09.00	LAB	**0 265 006 163**
	10.00-02.03	LAB	**0 265 007 103**
	05.97-09.00	RAB	**0 265 006 164**
	10.00-02.03	RAB	**0 265 007 102**
Wheel speed sensor, rear	05.97-09.00	LAB	**0 265 006 364**
	10.00-02.03	LAB	**0 265 007 052**
	05.97-09.00	RAB	**0 265 006 365**
	10.00-02.03	RAB	**0 265 007 053**

Product			
1.7 D Turbo		**1,7 l 52 kW 4 Zyl.**	
Wheel speed sensor, front	01.04→	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	01.04→		**0 265 007 051**
1.7 TD [178..]	**1,7 l 46/51 kW 176 A 3.000; 176 B 7.000; 178 C 9.066 4 Zyl.**		
Wheel speed sensor, front	09.97-02.02	LAB	**0 265 006 163**
		RAB	**0 265 006 164**
Wheel speed sensor, rear	09.97-02.02	LAB	**0 265 006 364**
		RAB	**0 265 006 365**
1.9 D [173..]		**1,9 l 48 kW 223 A 6.000 4 Zyl.**	
Speed sensor, diesel	01.03-02.04		**0 281 002 474**
Wheel speed sensor, front	01.03-02.04	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	01.03-02.04	LAB	**0 265 007 052**
		RAB	**0 265 007 053**
1.9 D [173..]		**1,9 l 51 kW 188 A 2.000 4 Zyl.**	
Speed sensor, diesel	04.03-09.04		**0 281 002 474**
Accelerator pedal module	04.03-09.04		**0 281 002 379**
Wheel speed sensor, front	04.03-09.04	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	04.03-09.04	LAB	**0 265 007 052**
		RAB	**0 265 007 053**
1.9 D [178..]		**1,9 l 46 kW 223 A 6.000 4 Zyl.**	
Speed sensor, diesel	11.00-09.01		**0 281 002 474**
Accelerator pedal module	11.00-09.01		**0 281 002 379**
Wheel speed sensor, front	11.00-09.01	LAB	**0 265 006 163**
		RAB	**0 265 006 164**
Wheel speed sensor, rear	11.00-09.01		**0 265 006 249**
1.9 JTD [173..]		**1,9 l 57/80 kW 188 A 2.000 4 Zyl.**	
Air mass meter, diesel	10.01→		**0 281 002 308**
Speed sensor, diesel	10.01-01.04		**0 281 002 474**
	02.04→		**0 281 002 603**
Phase sensor	10.01→		**0 281 002 213**
High-pressure sensor (CR system)	10.01-02.04		**0 281 002 405**
Boost pressure sensor, Diesel	10.01-09.04		**0 281 002 510**
Accelerator pedal module	10.01-09.04		**0 281 002 379**
Wheel speed sensor, front	10.01-09.04	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	10.01-09.04	LAB	**0 265 007 052**
		RAB	**0 265 007 053**
1.9 JTD [173..]		**1,9 l 80 kW 188 A 2.000 4 Zyl.**	
High-pressure sensor (CR system)	06.02-01.04		**0 281 002 405**
Boost pressure sensor, Diesel	06.02→		**0 281 002 510**
Accelerator pedal module	06.02→		**0 281 002 379**
Wheel speed sensor, front	06.02→	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	06.02→	LAB	**0 265 007 052**
		RAB	**0 265 007 053**
75 1.2 i.e. [178..]		**1,2 l 54 kW 178 B 5.000 4 Zyl.**	
Speed sensor, ignition/injection	09.97-09.01		**0 261 210 114**
Wheel speed sensor, front	09.97-09.01	LAB	**0 265 006 163**
		RAB	**0 265 006 164**
Wheel speed sensor, rear	09.97-09.01	LAB	**0 265 006 364**
		RAB	**0 265 006 365**
75 1.2 i.e. [178..]		**1,2 l 54 kW 188 A 4.000 4 Zyl.**	
Wheel speed sensor, front	08.00-09.01	LAB	**0 265 006 163**
		RAB	**0 265 006 164**
Wheel speed sensor, rear	08.00-09.01	LAB	**0 265 006 364**
		RAB	**0 265 006 365**
75 1.2 i.e. 8V [173..]		**1,2 l 54 kW 188 A 4.000 4 Zyl.**	
Phase sensor	10.01-09.04		**0 232 103 039**
Speed sensor, ignition/injection	10.01-10.03		**0 261 210 114**
	11.03-09.04		**0 261 210 114**

F

Product

◀ Palio Weekend

Wheel speed sensor, front	10.01-09.04	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	10.01-09.04	LAB	**0 265 007 052**
		RAB	**0 265 007 053**
85 1.2 i.e. 16V [173..]	**1,2 l 63 kW 188 A 5.000 4 Zyl.**		
Throttle valve assembly	10.01-09.04		**F 01C 600 023**
Phase sensor	10.01-09.04		**0 232 103 048**
Speed sensor, ignition/injection	10.01-09.04		**0 261 210 219**
Knock sensor	10.01-09.04		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	10.01-09.04		**0 261 230 030**
Accelerator pedal module	10.01-09.04		**0 281 002 379**
Wheel speed sensor, front	10.01-09.04	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	10.01-09.04	LAB	**0 265 007 052**
		RAB	**0 265 007 053**
100 1.6 i.e. 16V [173..]	**1,6 l 76 kW 182 B 6.000 4 Zyl.**		
Wheel speed sensor, front	10.01-09.04	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	10.01-09.04	LAB	**0 265 007 052**
		RAB	**0 265 007 053**
100 1.6 i.e. 16V [178..]	**1,6 l 76 kW 178 B 3.000; 182 B 6.000 4 Zyl.**		
Wheel speed sensor, front	09.97-09.01	LAB	**0 265 006 163**
		RAB	**0 265 006 164**
Wheel speed sensor, rear	09.97-09.01	LAB	**0 265 006 364**
		RAB	**0 265 006 365**

Panda

1.1 i.e. [169..]	**1,1 l 40 kW 187 A 1.000 4 Zyl.**		
Phase sensor	10.03→	NOC	**0 232 103 048**
Pressure sensor, intake manifold, gasoline	10.03→		**0 261 230 030**
Wheel speed sensor, front	10.03→		**0 265 007 448**
Wheel speed sensor, rear	10.03→		**0 265 007 449**
1.2 i.e. [169..]	**1,2 l 44 kW 188 A 4.000 4 Zyl.**		
Pressure sensor, intake manifold, gasoline	10.03→		**0 261 230 030**
Acceleration sensor, ABS	10.03→		**0 265 005 127**
Yaw rate sensor, brake system	10.03→		**0 265 005 241**
Wheel speed sensor, front	10.03→		**0 265 007 448**
Wheel speed sensor, rear	10.03→		**0 265 007 449**
1.2 i.e. Natural Power [169..]	**1,2 l 38-44 kW 188 A 4.000 4 Zyl.**		
Phase sensor	12.06→	NOC	**0 232 103 048**
Acceleration sensor, ABS	12.06→		**0 265 005 127**
Yaw rate sensor, brake system	12.06→		**0 265 005 241**
Wheel speed sensor, front	12.06→		**0 265 007 639**
1.2 i.e. 4x4 [169..]	**1,2 l 44 kW 188 A 4.000 4 Zyl.**		
Pressure sensor, intake manifold, gasoline	10.04→		**0 261 230 030**
Wheel speed sensor, front	10.04→		**0 265 007 639**
Wheel speed sensor, rear	10.04→		**0 265 007 640**
1.3 JTD [169..]	**1,3 l 52 kW 188 A 9.000 4 Zyl.**		
Air mass meter, diesel	01.04→		**0 281 002 613**
High-pressure sensor (CR system)	01.04→		**0 281 002 534**
Boost pressure sensor, Diesel	01.04-08.06		**0 281 002 510**
	09.06→		**0 281 002 844**
Acceleration sensor, ABS	01.04→		**0 265 005 127**
Yaw rate sensor, brake system	01.04→		**0 265 005 241**
Wheel speed sensor, front	01.04→		**0 265 007 448**
Wheel speed sensor, rear	01.04→		**0 265 007 449**
1.3 JTD [169..]	**1,3 l 55 kW 169 A 1.000 4 Zyl.**		
Air mass meter, diesel	05.06→		**0 281 002 792**
Boost pressure sensor, Diesel			
Mot.no. →1376014	05.06→		**0 281 002 510**
Mot.no. 1376015→	05.06→		**0 281 002 844**
Acceleration sensor, ABS	05.06→		**0 265 005 127**
Yaw rate sensor, brake system	05.06→		**0 265 005 241**
Wheel speed sensor, front	05.06→		**0 265 007 448**
Wheel speed sensor, rear	05.06→		**0 265 007 449**
1.3 JTD 4x4 [169..]	**1,3 l 52 kW 188 A 9.000 4 Zyl.**		
Air mass meter, diesel	09.05→		**0 281 002 613**
High-pressure sensor (CR system)	09.05→		**0 281 002 534**
Boost pressure sensor, Diesel	09.05-08.06		**0 281 002 510**
	09.06→		**0 281 002 844**
Wheel speed sensor, front	09.05→		**0 265 007 639**
Wheel speed sensor, rear	09.05→		**0 265 007 640**
1.4 i.e. 16V [169..]	**1,4 l 74 kW 169 A 3.000 4 Zyl.**		
Throttle valve assembly	10.06→		**F 01C 600 066**
Speed sensor, ignition/injection	10.06→		**0 261 210 238**
Knock sensor	10.06→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	10.06→		**F 01C 600 070**
Acceleration sensor, ABS	10.06→		**0 265 005 127**
Yaw rate sensor, brake system	10.06→		**0 265 005 241**
Wheel speed sensor, front	10.06→		**0 265 007 448**
Wheel speed sensor, rear	10.06→		**0 265 007 449**
1000 i.e. [141..]	**1,0 l 33 kW 141 C 2.000 4 Zyl.**		
Speed sensor, ignition/injection			
Mot.no. 4599750→	01.95-09.03		**0 261 210 117**
1000 i.e. [141..]	**1,0 l 33 kW 156 A 2.246 4 Zyl.**		
Temperature sensor, coolant, injection system	01.86-03.97	MEB	**0 280 130 026**
1000 i.e. 4x4 [153..]	**1,0 l 33 kW 156 A 2.246 4 Zyl.**		
Speed sensor, ignition/injection	07.90-04.92		**0 261 210 117**
Temperature sensor, coolant, injection system	01.86-06.90	MEB	**0 280 130 026**
1100 i.e. [141..]	**1,1 l 37 kW 156 C.046 4 Zyl.**		
Speed sensor, ignition/injection			
Mot.no. 4599750→	01.93-03.97		**0 261 210 117**
Temperature sensor, coolant, injection system	04.92-12.92	MEB	**0 280 130 026**
1100 i.e. [141..]	**1,1 l 37 kW 187 A 1.000 4 Zyl.**		
Phase sensor	12.00-09.03		**0 232 103 039**
1100 i.e. [141..]	**1,1 l 40 kW 176 B 2.000 4 Zyl.**		
Speed sensor, ignition/injection			
Mot.no. 4599750→	01.95-09.03		**0 261 210 117**
1100 i.e. Selecta [141..]	**1,1 l 37 kW 156 C.046 4 Zyl.**		
Speed sensor, ignition/injection			
Mot.no. 4599750→	01.93-03.97		**0 261 210 117**
Temperature sensor, coolant, injection system	01.86-12.92	MEB	**0 280 130 026**
1100 i.e. Selecta [141..]	**1,1 l 40 kW 176 B 2.000 4 Zyl.**		
Speed sensor, ignition/injection			
Mot.no. 4599750→	01.95-09.03		**0 261 210 117**
1100 i.e. 4x4 [153..]	**1,1 l 37 kW 156 C.046 4 Zyl.**		
Speed sensor, ignition/injection			
Mot.no. 4599750→	01.93-12.94		**0 261 210 117**
Temperature sensor, coolant, injection system	03.92-12.92	MEB	**0 280 130 026**
1100 i.e. 4x4 [153..]	**1,1 l 40 kW 176 B 2.000 4 Zyl.**		
Speed sensor, ignition/injection			
Mot.no. 4599750→	01.95-09.03		**0 261 210 117**

Petra

1.2 i.e. 16V [172..]	**1,2 l 59 kW 188 A 5.000 4 Zyl.**		
Throttle valve assembly	03.03→		**F 01C 600 023**
Speed sensor, ignition/injection	03.03→		**0 261 210 219**
Knock sensor	03.03→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	03.03→		**0 261 230 030**
Accelerator pedal module	03.03→		**0 281 002 379**
Wheel speed sensor, front	03.03→	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	03.03→		**0 265 007 126**

Product			

Punto

1.2 i 8V [188..]		**1,2 l 44 kW 188 A 4.000 4 Zyl.**	
Phase sensor	07.99-06.03		**0 232 103 039**
Speed sensor, ignition/injection	07.99-06.03		**0 261 210 114**
Wheel speed sensor, front			
Ricam.no →284749,→4546420,→5171879	07.99-05.02	LAB	**0 265 007 069**
		RAB	**0 265 007 070**
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	**0 265 007 510**
		RAB	**0 265 007 511**
Wheel speed sensor, rear			
Ricam.no →284749,→4546420,→5171879	07.99-05.02	LAB	**0 265 007 072**
		RAB	**0 265 007 071**
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	**0 265 007 512**
		RAB	**0 265 007 513**
1.2 i 8V Bipower [188..]		**1,2 l 59 kW 188 A 4.000 4 Zyl.**	
Speed sensor, ignition/injection	11.02-06.03		**0 261 210 114**
Wheel speed sensor, front	11.02-06.03	LAB	**0 265 007 510**
		RAB	**0 265 007 511**
Wheel speed sensor, rear	11.02-06.03	LAB	**0 265 007 512**
		RAB	**0 265 007 513**
1.2 i 16V [188..]		**1,2 l 59 kW 188 A 5.000 4 Zyl.**	
Throttle valve assembly	07.99-06.03		**F 01C 600 023**
Phase sensor	10.00-11.01		**0 232 103 035**
	12.01-06.03		**0 232 103 048**
Speed sensor, ignition/injection	07.99-09.00		**0 261 210 161**
	10.00-06.03		**0 261 210 219**
Knock sensor	07.99-06.03		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	07.99-06.03		**0 261 230 030**
Accelerator pedal module	07.99-06.03	RLE	**0 281 002 369**
Wheel speed sensor, front			
Ricam.no →284749,→4546420,→5171879	07.99-05.02	LAB	**0 265 007 069**
		RAB	**0 265 007 070**
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	**0 265 007 510**
		RAB	**0 265 007 511**
Wheel speed sensor, rear			
Ricam.no →284749,→4546420,→5171879	07.99-05.02	LAB	**0 265 007 072**
		RAB	**0 265 007 071**
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	**0 265 007 512**
		RAB	**0 265 007 513**
1.2 i.e. 8V [188..]		**1,2 l 44 kW 188 A 4.000 4 Zyl.**	
Phase sensor	07.03→	NOC	**0 232 103 048**
Speed sensor, ignition/injection			
Mot.no. →2192182	07.03→		**0 261 210 114**
Pressure sensor, intake manifold, gasoline	07.03→		**0 261 230 030**
Wheel speed sensor, front	07.03→	LAB	**0 265 007 610**
		RAB	**0 265 007 518**
Wheel speed sensor, rear	07.03→	RAB	**0 265 007 519**
1.2 i.e. 8V Bipower [188..]		**1,2 l 44 kW 188 A 4.000 4 Zyl.**	
Phase sensor	07.03→	NOC	**0 232 103 048**
Speed sensor, ignition/injection			
Mot.no. →2192182	07.03→		**0 261 210 114**
Wheel speed sensor, front	07.03→	LAB	**0 265 007 610**
		RAB	**0 265 007 518**
Wheel speed sensor, rear	07.03→	RAB	**0 265 007 519**
1.2 i.e. 16V [188..]		**1,2 l 59 kW 188 A 5.000 4 Zyl.**	
Throttle valve assembly	07.03→		**F 01C 600 023**
Phase sensor	07.03→		**0 232 103 048**
Speed sensor, ignition/injection	07.03→		**0 261 210 238**
Knock sensor	07.03→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	07.03→		**0 261 230 030**
Temperature sensor, coolant, injection system	07.03→		**F 01C 050 016**
Accelerator pedal module	07.03→	RLE	**0 281 002 369**

Product			
Wheel speed sensor, front	07.03→	LAB	**0 265 007 610**
		RAB	**0 265 007 518**
Wheel speed sensor, rear	07.03→	RAB	**0 265 007 519**
1.3 MJTD 16V [188..]		**1,3 l 52 kW 188 A 9.000 4 Zyl.**	
Air mass meter, diesel	07.03→		**0 281 002 613**
High-pressure sensor (CR system)	07.03-10.04		**0 281 002 534**
Boost pressure sensor, Diesel			
Mot.no. →1376014	07.03→		**0 281 002 510**
Mot.no. 1376015→	07.03→		**0 281 002 844**
Accelerator pedal module	07.03→	RLE	**0 281 002 369**
Acceleration sensor, ABS	07.03→		**0 265 005 127**
Yaw rate sensor, brake system	07.03→		**0 265 005 241**
Wheel speed sensor, front	07.03→	LAB	**0 265 007 610**
		RAB	**0 265 007 518**
Wheel speed sensor, rear	07.03→	LAB,OFD	**0 265 007 831**
		RAB	**0 265 007 519**
Ricam.no 0568434→,4972621→	07.03→	LAB,MFD	**0 265 007 831**
1.4 i.e. 16V [188..]		**1,4 l 70 kW 834 A 1.000 4 Zyl.**	
Throttle valve assembly	07.03→		**F 01C 600 027**
Speed sensor, ignition/injection	07.03→		**0 261 210 238**
Knock sensor	07.03→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	07.03→		**0 261 230 030**
Accelerator pedal module	07.03→	RLE	**0 281 002 369**
Acceleration sensor, ABS	07.03→		**0 265 005 127**
Yaw rate sensor, brake system	07.03→		**0 265 005 241**
Wheel speed sensor, front	07.03→	LAB	**0 265 007 610**
		RAB	**0 265 007 518**
Wheel speed sensor, rear	07.03→	LAB,OFD	**0 265 007 831**
		RAB	**0 265 007 519**
Ricam.no 0568434→,4972621→	07.03→	LAB,MFD	**0 265 007 831**
1.7 D [176..]		**1,7 l 42 kW 176 B 3.000 4 Zyl.**	
Wheel speed sensor, front	08.93-04.97	ZE	**0 265 001 387**
Wheel speed sensor, rear	08.93-04.97	LAB	**0 265 006 139**
		RAB	**0 265 006 140**
1.7 TD [176..]		**1,7 l 46/51-53 kW 176 A 3.000; 176 A 5.000; 176 B 7.000 4 Zyl.**	
Wheel speed sensor, front	08.93-08.99	ZE	**0 265 001 387**
Wheel speed sensor, rear	08.93-08.99	LAB	**0 265 006 139**
		RAB	**0 265 006 140**
1.8 i 16V [188..]		**1,7 l 96 kW 183 A 1.000 4 Zyl.**	
Phase sensor	07.99-06.03		**0 232 101 037**
Wheel speed sensor, front	07.99-06.03	LAB	**0 265 007 069**
		RAB	**0 265 007 070**
Wheel speed sensor, rear			
Ricam.no →0134146	07.99-06.00	LAB	**0 265 007 072**
		RAB	**0 265 007 071**
Ricam.no 0134147→	07.00-06.03	LAB	**0 265 007 100**
		RAB	**0 265 007 101**
1.8 i 16V [188..]		**1,7 l 96 kW 188 A 6.000 4 Zyl.**	
Phase sensor	09.00-06.03		**0 232 101 037**
Wheel speed sensor, front	09.00-06.03	LAB	**0 265 007 069**
		RAB	**0 265 007 070**
Wheel speed sensor, rear			
Ricam.no 0134147→	09.00-06.03	LAB	**0 265 007 100**
		RAB	**0 265 007 101**
1.8 i.e. 16V [188..]		**1,7 l 96 kW 188 A 6.000 4 Zyl.**	
Phase sensor	07.03→		**0 232 101 037**
Acceleration sensor, ABS	07.03→		**0 265 005 127**
Yaw rate sensor, brake system	07.03→		**0 265 005 241**
Wheel speed sensor, front	07.03→	LAB	**0 265 007 610**
		RAB	**0 265 007 518**
Wheel speed sensor, rear	07.03→	RAB	**0 265 007 520**
Ricam.no →0568433,→4972620	07.03-11.04	LAB	**0 265 007 521**

F

Product			
◀ Punto			
1.9 D [188..]		**1,9 l 44 kW 188 A 3.000 4 Zyl.**	
Speed sensor, diesel			
Mot.no. →2151823	07.99-06.03		**0 281 002 214**
Mot.no. 2151824→	07.99-06.03		**0 281 002 474**
Accelerator pedal module	07.99-06.03	RLE	**0 281 002 369**
Wheel speed sensor, front			
Ricam.no →284749,→4546420,→5171879	07.99-05.02	LAB	**0 265 007 069**
		RAB	**0 265 007 070**
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	**0 265 007 510**
		RAB	**0 265 007 511**
Wheel speed sensor, rear			
Ricam.no →284749,→4546420,→5171879	07.99-05.02	LAB	**0 265 007 072**
		RAB	**0 265 007 071**
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	**0 265 007 512**
		RAB	**0 265 007 513**
1.9 JTD [188..]		**1,9 l 59 kW 188 A 2.000 4 Zyl.**	
Air mass meter, diesel	07.99-06.03		**0 281 002 309**
Speed sensor, diesel			
Mot.no. →2151823	07.99-06.03		**0 281 002 214**
Mot.no. 2151824→	07.99-06.03		**0 281 002 474**
Phase sensor	07.99-06.03		**0 281 002 213**
High-pressure sensor (CR system)	07.99-06.03		**0 281 002 260**
		EFV	**0 281 002 405**
Boost pressure sensor, Diesel	07.99-06.03		**0 281 002 215**
		EFV	**0 281 002 510**
Accelerator pedal module	07.99-06.03	RLE	**0 281 002 369**
Wheel speed sensor, front			
Ricam.no →284749,→4546420,→5171879	07.99-05.02	LAB	**0 265 007 069**
		RAB	**0 265 007 070**
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	**0 265 007 510**
		RAB	**0 265 007 511**
Wheel speed sensor, rear			
Ricam.no →284749,→4546420,→5171879	07.99-05.02	LAB	**0 265 007 072**
		RAB	**0 265 007 071**
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	**0 265 007 512**
		RAB	**0 265 007 513**
1.9 JTD [188..]		**1,9 l 62,5 kW 188 A 7.000 4 Zyl.**	
Air mass meter, diesel	06.01-06.03		**0 281 002 309**
Speed sensor, diesel	06.01-06.03		**0 281 002 214**
		EFV	**0 281 002 474**
Phase sensor	06.01-06.03		**0 281 002 213**
High-pressure sensor (CR system)	06.01-06.03		**0 281 002 260**
		EFV	**0 281 002 405**
Boost pressure sensor, Diesel	06.01-06.03		**0 281 002 215**
		EFV	**0 281 002 510**
Accelerator pedal module	06.01-06.03	RLE	**0 281 002 369**
Wheel speed sensor, front			
Ricam.no →284749,→4546420,→5171879	06.01-05.02	LAB	**0 265 007 069**
		RAB	**0 265 007 070**
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	**0 265 007 510**
		RAB	**0 265 007 511**
Wheel speed sensor, rear			
Ricam.no →284749,→4546420,→5171879	06.01-05.02	LAB	**0 265 007 072**
		RAB	**0 265 007 071**
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	**0 265 007 512**
		RAB	**0 265 007 513**
1.9 JTD 8V [188..]		**1,9 l 63 kW 188 A 7.000 4 Zyl.**	
Air mass meter, diesel	07.03→		**0 280 218 113**
Speed sensor, diesel			
Mot.no. →3619164	07.03→		**0 281 002 474**
Mot.no. 3619165→	07.03→		**0 281 002 603**
Phase sensor	07.03→		**0 281 002 213**
High-pressure sensor (CR system)	07.03-02.04		**0 281 002 405**
Boost pressure sensor, Diesel	07.03→		**0 281 002 510**
Accelerator pedal module	07.03→	RLE	**0 281 002 369**
Acceleration sensor, ABS	07.03→		**0 265 005 127**
Yaw rate sensor, brake system	07.03→		**0 265 005 241**
Wheel speed sensor, front	07.03→	LAB	**0 265 007 610**
		RAB	**0 265 007 518**
Wheel speed sensor, rear	07.03→	LAB,OFD	**0 265 007 831**
		RAB	**0 265 007 519**
Ricam.no 0568434→,4972621→	07.03→	LAB,MFD	**0 265 007 831**
1.9 JTD 8V [188..]		**1,9 l 74 kW 188 B 2.000 4 Zyl.**	
Air mass meter, diesel	07.03→		**0 280 218 113**
Speed sensor, diesel	07.03→	KW	**0 281 002 603**
Phase sensor	07.03→		**0 281 002 213**
High-pressure sensor (CR system)	07.03→		**0 281 002 534**
Boost pressure sensor, Diesel	07.03→		**0 281 002 437**
Accelerator pedal module	07.03→	NSP,RLE	**0 281 002 369**
Acceleration sensor, ABS	07.03→		**0 265 005 127**
Yaw rate sensor, brake system	07.03→		**0 265 005 241**
Wheel speed sensor, front	07.03→	LAB	**0 265 007 610**
		RAB	**0 265 007 518**
Wheel speed sensor, rear	07.03→	RAB,SBR	**0 265 007 520**
		RAB,TBR	**0 265 007 519**
Ricam.no →0568433,→4972620	07.03→	LAB,SBR	**0 265 007 521**
Ricam.no 0568434→,4972621→	07.03→	LAB,TBR	**0 265 007 831**
55 1.1 i.e. [176..]		**1,1 l 40 kW 176 A 6.000; 176 B 2.000 4 Zyl.**	
Speed sensor, ignition/injection	08.93-08.99		**0 261 210 114**
Wheel speed sensor, front	08.93-08.99	ZE	**0 265 001 387**
Wheel speed sensor, rear	08.93-08.99	LAB	**0 265 006 139**
		RAB	**0 265 006 140**
60 1.2 i.e. [176..]		**1,2 l 43 kW 176 A 7.000 4 Zyl.**	
Speed sensor, ignition/injection	08.93-05.94		**0 261 210 114**
Wheel speed sensor, front	08.93-05.94	ZE	**0 265 001 387**
Wheel speed sensor, rear	08.93-05.94	LAB	**0 265 006 139**
		RAB	**0 265 006 140**
60 1.2 i.e. [176..]		**1,2 l 43 kW 176 B 4.000 4 Zyl.**	
Speed sensor, ignition/injection	06.95-08.99		**0 261 210 114**
Wheel speed sensor, front	06.95-08.99	ZE	**0 265 001 387**
Wheel speed sensor, rear	06.95-08.99	LAB	**0 265 006 139**
		RAB	**0 265 006 140**
60 1.2 i.e. Selecta [176..]		**1,2 l 43 kW 176 B 1.000 4 Zyl.**	
Speed sensor, ignition/injection	06.94-04.97		**0 261 210 114**
75 1.2 i.e. [176..]		**1,2 l 54 kW 176 A 8.000 4 Zyl.**	
Speed sensor, ignition/injection	08.93-08.99		**0 261 210 114**
Wheel speed sensor, front	08.93-08.99	ZE	**0 265 001 387**
Wheel speed sensor, rear	08.93-08.99	LAB	**0 265 006 139**
		RAB	**0 265 006 140**
85 1.2 i.e. 16V [176..]		**1,2 l 63 kW 176 B 9.000 4 Zyl.**	
Speed sensor, ignition/injection	05.97-08.99		**0 261 210 124**
Wheel speed sensor, front	05.97-08.99	ZE	**0 265 001 387**
Wheel speed sensor, rear	05.97-08.99	LAB	**0 265 006 139**
		RAB	**0 265 006 140**
90 1.6 i.e. [176..]		**1,6 l 65 kW 176 A 9.000 4 Zyl.**	
Wheel speed sensor, front	01.94-04.97	ZE	**0 265 001 387**
Wheel speed sensor, rear	01.94-04.97	LAB	**0 265 006 139**
		RAB	**0 265 006 140**

Punto Cabrio

60 1.2 i.e. [176..]		**1,2 l 43/44 kW 176 A 7.000; 176 B 4.000 4 Zyl.**	
Speed sensor, ignition/injection	04.94-08.99		**0 261 210 114**
Wheel speed sensor, front	04.94-08.99	ZE	**0 265 001 387**
Wheel speed sensor, rear	04.94-08.99	LAB	**0 265 006 139**
		RAB	**0 265 006 140**

F

Product

85 1.2 i.e. 16V [176..]	**1,2 l 63 kW 176 B 9.000 4 Zyl.**		
Speed sensor, ignition/injection	05.97-08.99		**0 261 210 124**
Wheel speed sensor, front	05.97-08.99	ZE	**0 265 001 387**
Wheel speed sensor, rear	05.97-08.99	LAB	**0 265 006 139**
		RAB	**0 265 006 140**
90 1.6 i.e. [176..]	**1,6 l 65 kW 176 A 9.000 4 Zyl.**		
Wheel speed sensor, front	04.94-04.97	ZE	**0 265 001 387**
Wheel speed sensor, rear	04.94-04.97	LAB	**0 265 006 139**
		RAB	**0 265 006 140**

Punto Grande

1.2 i.e. [199..]	**1,2 l 48 kW 199 A 4.000 4 Zyl.**		
Phase sensor	10.05→		**0 232 103 048**
Pressure sensor, intake manifold, gasoline	10.05→		**0 261 230 030**
Yaw rate sensor, brake system	10.05→		**0 265 005 607**
Wheel speed sensor, front	10.05→		**0 265 007 671**
Wheel speed sensor, rear	10.05→		**0 265 007 768**
1.3 MJTD [199..]	**1,3 l 55 kW 199 A 2.000 4 Zyl.**		
Air mass meter, diesel	10.05→		**0 281 002 792**
Boost pressure sensor, Diesel	10.05-05.06		**0 281 002 510**
	06.06→		**0 281 002 844**
Yaw rate sensor, brake system	10.05→		**0 265 005 607**
Wheel speed sensor, front	10.05→		**0 265 007 671**
Wheel speed sensor, rear	10.05→		**0 265 007 768**
1.3 MJTD [199..]	**1,3 l 66 kW 199 A 3.000 4 Zyl.**		
Air mass meter, diesel	10.05→		**0 281 002 792**
Boost pressure sensor, Diesel	10.05-11.06		**0 281 002 437**
	12.06→		**0 281 002 845**
Yaw rate sensor, brake system	10.05→		**0 265 005 607**
Wheel speed sensor, front	10.05→		**0 265 007 671**
Wheel speed sensor, rear	10.05→		**0 265 007 768**
1.4 i.e. Turbo 16V [199..]	**1,4 l 88 kW 198 A 4.000 4 Zyl.**		
Phase sensor	06.07→		**0 232 103 048**
Speed sensor, ignition/injection	06.07→		**0 261 210 238**
Knock sensor	06.07→		**0 261 231 173**
Boost pressure sensor, gasoline	06.07→		**0 281 002 844**
Yaw rate sensor, brake system	06.07→		**0 265 005 607**
Wheel speed sensor, front	06.07→		**0 265 007 671**
Wheel speed sensor, rear	06.07→		**0 265 007 769**
1.4 i.e. 8V [199..]	**1,4 l 57 kW 350 A 1.000 4 Zyl.**		
Phase sensor	10.05→		**0 232 103 048**
Pressure sensor, intake manifold, gasoline	10.05→		**0 261 230 030**
Yaw rate sensor, brake system	10.05→		**0 265 005 607**
Wheel speed sensor, front	10.05→		**0 265 007 671**
Wheel speed sensor, rear	10.05→		**0 265 007 768**
1.4 i.e. 16V [199..]	**1,4 l 70 kW 199 A 6.000 4 Zyl.**		
Throttle valve assembly	03.06→		**F 01C 600 066**
Speed sensor, ignition/injection	03.06→		**0 261 210 238**
Knock sensor	03.06→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	03.06→		**F 01C 600 070**
Temperature sensor, intake air, injection system	03.06→		**F 01C 600 071**
Yaw rate sensor, brake system	03.06→		**0 265 005 607**
Wheel speed sensor, front	03.06→		**0 265 007 671**
Wheel speed sensor, rear	03.06→	NSP	**0 265 007 768**
		VSP	**0 265 007 769**
1.9 JTD [199..]	**1,9 l 88/96 kW 199 A 5.000; 939 A 1.000 4 Zyl.**		
Speed sensor, diesel	10.05→	KW	**0 281 002 603**
Phase sensor	10.05→	NOC	**0 281 002 213**
Boost pressure sensor, Diesel	10.05-03.07		**0 281 002 437**
	04.07→		**0 281 002 845**
Yaw rate sensor, brake system	10.05→		**0 265 005 607**

Product

Wheel speed sensor, front	10.05→		**0 265 007 671**
Wheel speed sensor, rear	10.05→		**0 265 007 769**

Punto GT

1.4 i.e. Turbo [176..]	**1,4 l 96/98 kW 176 A 4.000; 176 B 6.000 4 Zyl.**		
Throttle valve sensor	08.93-08.99		**0 280 122 001**
Air mass meter, gasoline injection	08.93-08.99		**0 280 212 024**
			0 986 280 123
Phase sensor	08.93-08.99		**0 232 102 004**
Speed sensor, ignition/injection	08.93-08.99		**0 261 210 104**
Knock sensor	08.93-08.99		**0 261 231 007**
Pressure sensor, intake manifold, gasoline	08.93-08.99		**0 280 101 001**
Temperature sensor, intake air, injection system	08.93-08.99		**0 280 130 060**
Temperature sensor, coolant, injection system	08.93-08.99		**0 280 130 026**
Relay, Jetronic	04.94-04.97		**0 332 014 140**
Wheel speed sensor, front	08.93-08.99	ZE	**0 265 001 387**
Wheel speed sensor, rear	08.93-08.99	LAB	**0 265 006 139**
		RAB	**0 265 006 140**

Punto VAN

1.1 i.e. [276..]	**1,1 l 40 kW 176 B 2.000 4 Zyl.**		
Speed sensor, ignition/injection	05.97-08.99		**0 261 210 114**
Wheel speed sensor, front	05.97-08.99	ZE	**0 265 001 387**
Wheel speed sensor, rear	05.97-08.99	LAB	**0 265 006 139**
		RAB	**0 265 006 140**
1.2 i 8V [288..]	**1,2 l 44 kW 188 A 4.000 4 Zyl.**		
Phase sensor	07.03→	NOC	**0 232 103 048**
Speed sensor, ignition/injection	07.99-06.03		**0 261 210 114**
Mot.no. →2192182	07.03→		**0 261 210 114**
Pressure sensor, intake manifold, gasoline	07.03→		**0 261 230 030**
Wheel speed sensor, front	07.03→	LAB	**0 265 007 610**
		RAB	**0 265 007 518**
Ricam.no →284749,→4546420,→5171879	07.99-05.02	LAB	**0 265 007 069**
		RAB	**0 265 007 070**
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	**0 265 007 510**
		RAB	**0 265 007 511**
Wheel speed sensor, rear	07.03→	RAB	**0 265 007 519**
Ricam.no →284749,→4546420,→5171879	07.99-05.02	LAB	**0 265 007 072**
		RAB	**0 265 007 071**
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	**0 265 007 512**
		RAB	**0 265 007 513**
1.2 i 8V Bipower [288..]	**1,2 l 44 kW 188 A 4.000 4 Zyl.**		
Phase sensor	07.03→	NOC	**0 232 103 048**
Speed sensor, ignition/injection			
Mot.no. →2192182	07.03→		**0 261 210 114**
Wheel speed sensor, front	07.03→	LAB	**0 265 007 610**
		RAB	**0 265 007 518**
Wheel speed sensor, rear	07.03→	RAB	**0 265 007 519**
1.3 MJTD 16V [288..]	**1,3 l 52 kW 188 A 9.000 4 Zyl.**		
Air mass meter, diesel	07.03→		**0 281 002 613**
High-pressure sensor (CR system)	07.03-10.04		**0 281 002 534**
Boost pressure sensor, Diesel			
Mot.no. →1376014	07.03→		**0 281 002 510**
Mot.no. 1376015→	07.03→		**0 281 002 844**
Accelerator pedal module	07.03→	RLE	**0 281 002 369**
Acceleration sensor, ABS	07.03→		**0 265 005 127**
Yaw rate sensor, brake system	07.03→		**0 265 005 241**
Wheel speed sensor, front	07.03→	LAB	**0 265 007 610**
		RAB	**0 265 007 518**

F

Product			
◀ Punto VAN			
Wheel speed sensor, rear	07.03→	LAB,OFD	**0 265 007 831**
		RAB	**0 265 007 519**
Ricam.no 0568434→,4972621→	07.03→	LAB,MFD	**0 265 007 831**
1.7 D [276..]		**1,7 l 42 kW 176 B 3.000 4 Zyl.**	
Wheel speed sensor, front	05.97-08.99	ZE	**0 265 001 387**
Wheel speed sensor, rear	05.97-08.99	LAB	**0 265 006 139**
		RAB	**0 265 006 140**
1.7 TD [276..]		**1,7 l 51/53 kW 176 A 3.000; 176 A 5.000 4 Zyl.**	
Wheel speed sensor, front	05.97-08.99	ZE	**0 265 001 387**
Wheel speed sensor, rear	05.97-08.99	LAB	**0 265 006 139**
		RAB	**0 265 006 140**
1.7 TD SOFT [276..]		**1,7 l 46 kW 176 B7.000 4 Zyl.**	
Wheel speed sensor, front	05.97-08.99	ZE	**0 265 001 387**
Wheel speed sensor, rear	05.97-08.99	LAB	**0 265 006 139**
		RAB	**0 265 006 140**
1.9 D [288..]		**1,9 l 44 kW 188 A 3.000 4 Zyl.**	
Speed sensor, diesel			
Mot.no. →2151823	05.99-06.03		**0 281 002 214**
Mot.no. 2151824→	05.99-06.03		**0 281 002 474**
Accelerator pedal module	05.99-06.03	RLE	**0 281 002 369**
Wheel speed sensor, front			
Ricam.no →284749,→4546420,→5171879	05.99-05.02	LAB	**0 265 007 069**
		RAB	**0 265 007 070**
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	**0 265 007 510**
		RAB	**0 265 007 511**
Wheel speed sensor, rear			
Ricam.no →284749,→4546420,→5171879	05.99-05.02	LAB	**0 265 007 072**
		RAB	**0 265 007 071**
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	**0 265 007 512**
		RAB	**0 265 007 513**
1.9 JTD [288..]		**1,9 l 85 kW 188 A 7.000 4 Zyl.**	
Air mass meter, diesel	05.99-06.03		**0 281 002 309**
Speed sensor, diesel	05.99-06.03	EFV	**0 281 002 474**
Phase sensor	05.99-06.03		**0 281 002 213**
High-pressure sensor (CR system)	05.99-06.03		**0 281 002 260**
		EFV	**0 281 002 405**
Boost pressure sensor, Diesel	05.99-06.03		**0 281 002 215**
		EFV	**0 281 002 510**
Accelerator pedal module	05.99-06.03	RLE	**0 281 002 369**
Wheel speed sensor, front			
Ricam.no →284749,→4546420,→5171879	05.99-05.02	LAB	**0 265 007 069**
		RAB	**0 265 007 070**
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	**0 265 007 510**
		RAB	**0 265 007 511**
Wheel speed sensor, rear			
Ricam.no →284749,→4546420,→5171879	05.99-05.02	LAB	**0 265 007 072**
		RAB	**0 265 007 071**
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	**0 265 007 512**
		RAB	**0 265 007 513**
1.9 JTD 8V [288..]		**1,9 l 63 kW 188 A 7.000 4 Zyl.**	
Air mass meter, diesel	07.03→		**0 280 218 113**
Speed sensor, diesel			
Mot.no. →3619164	07.03→		**0 281 002 474**
Mot.no. 3619165→	07.03→		**0 281 002 603**
Phase sensor	07.03→		**0 281 002 213**
High-pressure sensor (CR system)	07.03-02.04		**0 281 002 405**
Boost pressure sensor, Diesel	07.03→		**0 281 002 510**
Accelerator pedal module	07.03→	RLE	**0 281 002 369**
Acceleration sensor, ABS	07.03→		**0 265 005 127**
Yaw rate sensor, brake system	07.03→		**0 265 005 241**
Wheel speed sensor, front	07.03→	LAB	**0 265 007 610**
		RAB	**0 265 007 518**

Product			
Wheel speed sensor, rear	07.03→	LAB,OFD	**0 265 007 831**
		RAB	**0 265 007 519**
Ricam.no 0568434→,4972621→	07.03→	LAB,MFD	**0 265 007 831**

Regata

75 i.e. [138..]		**1,5 l 55 kW 138 C 2.. 4 Zyl.**	
Throttle valve sensor	10.85-04.87		**0 280 120 300**
Air flow sensor, gasoline injection	10.85-04.87		**0 280 200 024**
			0 986 280 075
Pressure sensor, intake manifold, gasoline	10.85-04.87		**0 280 101 001**
Temperature sensor, coolant, injection system	10.85-04.87		**0 280 130 023**
Relay, Jetronic	10.85-04.87	WEI	**0 332 514 127**
75 i.e. [138..]		**1,5 l 55 kW 149 C 1.000 4 Zyl.**	
Temperature sensor, coolant, injection system	05.87-06.90		**0 280 130 026**

Ritmo

75 i.e. [138A..]		**1,5 l 55 kW 138 C 2.. 4 Zyl.**	
Throttle valve sensor	10.85-10.87		**0 280 120 300**
Air flow sensor, gasoline injection	10.85-10.87		**0 280 200 024**
			0 986 280 075
Pressure sensor, intake manifold, gasoline	10.85-10.87		**0 280 101 001**
Temperature sensor, coolant, injection system	10.85-10.87		**0 280 130 023**
Relay, Jetronic	10.85-10.87	WEI	**0 332 514 127**
75 i.e. [138A..]		**1,5 l 55 kW 149 C 1.. 4 Zyl.**	
Temperature sensor, coolant, injection system	05.87-12.88		**0 280 130 026**
90 i.e. [138A..]		**1,6 l 66 kW 149 C 2.000 4 Zyl.**	
Temperature sensor, coolant, injection system	05.87-12.87		**0 280 130 026**

Scudo

1.6 i [222..]		**1,6 l 58 kW 220 A 2.000 4 Zyl.**	
Pulse generator, ignition/Jetronic	10.95-05.00		**0 261 210 127**
Temperature sensor, coolant, injection system	10.95-05.00		**0 280 130 084**
Wheel speed sensor, front			
Ricam.no 7480→9050	06.97-05.00		**0 265 006 388**
Wheel speed sensor, rear			
Ricam.no 7480→7608	05.97-09.97		**0 265 006 426**
Ricam.no 7609→9050	09.97-05.00		**0 265 006 504**
1.9 D [222..]		**1,9 l 51 kW D9B 4 Zyl.**	
Wheel speed sensor, front			
Ricam.no 7480→9050	06.97-05.00		**0 265 006 388**
Wheel speed sensor, rear			
Ricam.no 7480→7608	05.97-09.97		**0 265 006 426**
Ricam.no 7609→9050	09.97-05.00		**0 265 006 504**
1.9 D [222..]		**1,9 l 51 kW WJZ 4 Zyl.**	
Wheel speed sensor, front			
Ricam.no 7480→9050	06.98-08.01		**0 265 006 388**
Wheel speed sensor, rear			
Ricam.no 7609→9050	06.98-08.01		**0 265 006 504**
1.9 TD [222..]		**1,9 l 66/68 kW DHX; D8B 4 Zyl.**	
Wheel speed sensor, front			
Ricam.no 7480→9050	06.97-05.00		**0 265 006 388**
Wheel speed sensor, rear			
Ricam.no 7480→7608	05.97-09.97		**0 265 006 426**
Ricam.no 7609→9050	09.97-05.00		**0 265 006 504**
2.0 8V JTD [222..]		**2,0 l 70/81 kW RHX; RHZ 4 Zyl.**	
High-pressure sensor (CR system)	10.99-01.07		**0 281 002 283**
Wheel speed sensor, front			
Ricam.no 7480→9050	10.99-08.01		**0 265 006 388**
Wheel speed sensor, rear			
Ricam.no 7609→9050	10.99-08.01		**0 265 006 504**

Product			
2.0 16V [222..]			**2,0 l 100 kW RFN 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.00-01.07		**0 261 230 057**
Wheel speed sensor, front			
Ricam.no 7480→9050	05.00-08.01		**0 265 006 388**
Wheel speed sensor, rear			
Ricam.no 7609→9050	05.00-08.01		**0 265 006 504**
2.0 16V JTD [222..]			**2,0 l 81 kW RHM 4 Zyl.**
High-pressure sensor (CR system)	06.04-01.07		**0 281 002 283**
2.0 16V JTD [222..]			**2,0 l 81 kW RHW 4 Zyl.**
High-pressure sensor (CR system)	09.00-05.04		**0 281 002 283**
Wheel speed sensor, front			
Ricam.no 7480→9050	09.00-08.01		**0 265 006 388**
Wheel speed sensor, rear			
Ricam.no 7609→9050	09.00-08.01		**0 265 006 504**

Sedici

1.9 JTD 4x4 [189..]			**1,9 l 88 kW D19AA 4 Zyl.**
Speed sensor, diesel	05.06→	KW	**0 281 002 603**
Phase sensor	05.06→		**0 281 002 213**
Boost pressure sensor, Diesel	05.06-03.07		**0 281 002 437**
	04.07→		**0 281 002 845**

Seicento

Elettra [187..]0 Zyl.			
Pedal position sensor, EMS (electronic engine management)	10.98-12.03		**0 281 002 202**
900 [187..]			**0,9 l 29 kW 1170 A 1.046 4 Zyl.**
Wheel speed sensor, front	03.98-12.03	LAB	**0 265 007 043**
		RAB	**0 265 007 044**
Wheel speed sensor, rear	03.98-12.03		**0 265 007 045**
1100 [187..]			**1,1 l 40 kW 176 B 2.000 4 Zyl.**
Wheel speed sensor, front	03.98-12.03	LAB	**0 265 007 043**
		RAB	**0 265 007 044**
Wheel speed sensor, rear	03.98-12.03		**0 265 007 045**
1100 [187..]			**1,1 l 40 kW 187 A 1.000 4 Zyl.**
Phase sensor			
Fg.no. →1219710	09.00→	NOC	**0 232 103 039**
Fg.no. 1219711→	09.00→	NOC	**0 232 103 048**
Wheel speed sensor, front	09.00→	LAB	**0 265 007 043**
		RAB	**0 265 007 044**
Wheel speed sensor, rear	09.00→		**0 265 007 045**

Siena

1.0 MPI 16V			**1,0 l 51 kW 178 D 8.011 4 Zyl.**
Throttle valve assembly	03.00-08.01		**F 01C 600 023**
	10.02-02.03		**F 01C 600 023**
Speed sensor, ignition/injection	03.00-02.03		**0 261 210 161**
Knock sensor	03.00-02.03		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	03.00-02.03		**0 261 230 030**
Wheel speed sensor, front	03.00-02.03	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	03.00-02.03		**0 265 007 051**
1.2 i.e. 8V [172..]			**1,2 l 44 kW 178 C 4.066 4 Zyl.**
Speed sensor, ignition/injection			
Mot.no. →2935743	01.02-03.04	OLH	**0 261 210 114**
Wheel speed sensor, front	01.02-03.04	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	01.02-03.04		**0 265 007 051**

Product			
1.2 i.e. 8V [178..]			**1,2 l 44/54 kW 178 B 5.000; 178 B 7.045 4 Zyl.**
Speed sensor, ignition/injection	01.98-12.01		**0 261 210 114**
Wheel speed sensor, front	03.99-12.01	LAB	**0 265 006 163**
		RAB	**0 265 006 164**
Wheel speed sensor, rear	03.99-12.01		**0 265 006 249**
1.3 MPI 16V			**1,3 l 59 kW 178 D 6.011 4 Zyl.**
Throttle valve assembly	03.00-02.03		**F 01C 600 023**
Speed sensor, ignition/injection	03.00-02.03		**0 261 210 161**
Knock sensor	03.00-02.03		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	03.00-02.03		**0 261 230 030**
Accelerator pedal module	03.00-02.03		**0 281 002 379**
Wheel speed sensor, front	03.00-09.00	LAB	**0 265 006 163**
	10.00-02.03	LAB	**0 265 007 103**
	03.00-09.00	RAB	**0 265 006 164**
	10.00-02.03	RAB	**0 265 007 102**
Wheel speed sensor, rear	03.00-09.00		**0 265 006 249**
	10.00-02.03		**0 265 007 051**
1.4 i.e. [178..]			**1,4 l 51 kW 178 B 2.000; 178 B 2.016 4 Zyl.**
Speed sensor, ignition/injection	04.97-06.01		**0 261 210 104**
Wheel speed sensor, front	04.97-06.01	LAB	**0 265 006 163**
	07.97-06.01	RAB	**0 265 006 164**
Wheel speed sensor, rear	04.97-06.01		**0 265 006 249**
1.4 i.e. 8V [178..]			**1,4 l 51 kW 178 B 2.000 4 Zyl.**
Speed sensor, ignition/injection	02.00-06.02		**0 261 210 104**
Wheel speed sensor, front	03.01-06.02	LAB	**0 265 006 163**
		RAB	**0 265 006 164**
Wheel speed sensor, rear	03.01-06.02		**0 265 006 249**
1.6 i.e. 16V [178..]			**1,6 l 76 kW 178 B 3.000; 182 B 6.000 4 Zyl.**
Wheel speed sensor, front	04.97-12.01	LAB	**0 265 006 163**
	07.97-12.01	RAB	**0 265 006 164**
Wheel speed sensor, rear	04.97-12.01		**0 265 006 249**

Stilo

1.2 16V [192..]			**1,2 l 59 kW 188 A 5.000 4 Zyl.**
Throttle valve assembly	10.01-12.03		**F 01C 600 023**
Phase sensor			
Fg.no. →819153	10.01-12.03		**0 232 103 035**
Fg.no. 819154→	10.01-12.03		**0 232 103 048**
Speed sensor, ignition/injection	10.01-12.03		**0 261 210 219**
Knock sensor	10.01-12.03		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	10.01-12.03		**0 261 230 030**
Accelerator pedal module	10.01-12.03	LLE,XBN	**0 280 752 227**
Wheel speed sensor, front	10.01-12.03		**0 265 007 401**
Wheel speed sensor, rear			
Fg.no. 312323→	10.01-12.03		**0 265 007 636**
Ricam.no →312322	10.01-12.03		**0 265 007 400**
1.4 16V [192..]			**1,4 l 66/70 kW 192 B 2.000; 843 A 1.000 4 Zyl.**
Throttle valve assembly	01.04→		**F 01C 600 027**
Phase sensor	01.04→	NOC	**0 232 103 048**
Speed sensor, ignition/injection	01.04→		**0 261 210 238**
Knock sensor	01.04→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	01.04→		**0 261 230 030**
Wheel speed sensor, front	01.04→		**0 265 007 401**
Wheel speed sensor, rear	01.04→		**0 265 007 636**
1.6 16V [192..]			**1,6 l 76 kW 182 B 6.000 4 Zyl.**
Accelerator pedal module	10.01-12.03	LLE,XBN	**0 280 752 227**
Yaw rate sensor, brake system	10.01→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	10.01→		**0 265 005 303**
Wheel speed sensor, front	10.01→		**0 265 007 401**
Wheel speed sensor, rear	01.04→		**0 265 007 636**
Fg.no. 312323→	10.01-12.03		**0 265 007 636**
Ricam.no →312322	10.01-12.03		**0 265 007 400**

F

Product			
◀ Stilo			
1.6 16V [192..]			**1,6 l 100 kW 192 B 3.000 4 Zyl.**
Accelerator pedal module	07.05→	LLE,XBN	**0 280 752 227**
Yaw rate sensor, brake system	07.05→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	07.05→		**0 265 005 303**
Wheel speed sensor, front	07.05→		**0 265 007 401**
Wheel speed sensor, rear	07.05→		**0 265 007 636**
1.8 MPI 8V			**1,8 l 76 kW 7D 4 Zyl.**
Wheel speed sensor, front	06.02-09.05		**0 265 007 401**
Wheel speed sensor, rear	06.02-09.05		**0 265 007 400**
1.8 MPI 16V			**1,8 l 97 kW 4 Zyl.**
Phase sensor	01.04→		**0 232 101 037**
Wheel speed sensor, front	01.04→		**0 265 007 401**
Wheel speed sensor, rear	01.04→		**0 265 007 400**
1.8 16V [192..]			**1,8 l 98 kW 192 A 4.000 4 Zyl.**
Phase sensor	10.01→		**0 232 101 037**
Yaw rate sensor, brake system	10.01→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	10.01→		**0 265 005 303**
Wheel speed sensor, front	10.01→		**0 265 007 401**
Wheel speed sensor, rear	01.04→		**0 265 007 636**
Fg.no. 312323→	10.01-12.03		**0 265 007 636**
Ricam.no →312322	10.01-12.03		**0 265 007 400**
1.9 JTD			**1,9 l 85 kW 4 Zyl.**
Air mass meter, diesel	06.02→		**0 281 002 308**
Pulse generator, diesel	06.02→		**0 281 002 213**
Speed sensor, diesel	06.02→		**0 281 002 474**
Accelerator pedal module	06.02→		**0 280 752 227**
Wheel speed sensor, front	06.02→		**0 265 007 401**
Wheel speed sensor, rear	06.02→		**0 265 007 400**
1.9 JTD 8V [192..]			**1,9 l 59 kW 192 A 3.000 4 Zyl.**
Air mass meter, diesel	10.01→		**0 281 002 308**
Speed sensor, diesel	10.01-12.03		**0 281 002 474**
	01.04→		**0 281 002 603**
Phase sensor	10.01→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	10.01-06.02		**0 281 002 260**
	07.02-12.03		**0 281 002 405**
Boost pressure sensor, Diesel	10.01-01.06		**0 281 002 510**
	02.06→		**0 281 002 844**
Accelerator pedal module	10.01→	LLE,XBN	**0 280 752 227**
Pressure sensor, ESP, (electronic stability program)	01.04→		**0 265 005 303**
Wheel speed sensor, front	10.01→		**0 265 007 401**
Wheel speed sensor, rear	01.04→		**0 265 007 636**
Fg.no. 312323→	10.01-12.03		**0 265 007 636**
Ricam.no →312322	10.01-12.03		**0 265 007 400**
1.9 JTD 8V [192..]			**1,9 l 66 kW 192 B 5.000 4 Zyl.**
Air mass meter, diesel	10.05-06.07		**0 281 002 792**
Speed sensor, diesel	10.05→	KW	**0 281 002 603**
Phase sensor	10.05→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	10.05→		**0 281 002 534**
Boost pressure sensor, Diesel	10.05-03.07		**0 281 002 437**
	04.07→		**0 281 002 845**
Yaw rate sensor, brake system	10.05→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	10.05→		**0 265 005 303**
Wheel speed sensor, front	10.05→		**0 265 007 401**
Wheel speed sensor, rear	10.05→		**0 265 007 636**
1.9 JTD 8V [192..]			**1,9 l 74 kW 192 A 9.000 4 Zyl.**
Air mass meter, diesel	01.04→		**0 281 002 308**
Speed sensor, diesel	01.04→		**0 281 002 603**
Phase sensor	01.04→	NOC	**0 281 002 213**
Boost pressure sensor, Diesel	01.04-01.06		**0 281 002 510**
	02.06→		**0 281 002 844**
Accelerator pedal module	01.04→	LLE,XBN	**0 280 752 227**
Yaw rate sensor, brake system	01.04→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	01.04→		**0 265 005 303**
Wheel speed sensor, front	01.04→		**0 265 007 401**
Wheel speed sensor, rear	01.04→		**0 265 007 636**
1.9 JTD 8V [192..]			**1,9 l 85 kW 192 A 1.000 4 Zyl.**
Air mass meter, diesel	10.01→		**0 281 002 308**
Speed sensor, diesel	10.01-12.03		**0 281 002 474**
	01.04→		**0 281 002 603**
Phase sensor	10.01→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	10.01-06.02		**0 281 002 260**
	07.02-12.03		**0 281 002 405**
Boost pressure sensor, Diesel	10.01-01.06		**0 281 002 510**
	02.06→		**0 281 002 844**
Accelerator pedal module	10.01→	LLE,XBN	**0 280 752 227**
Yaw rate sensor, brake system	10.01→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	10.01→		**0 265 005 303**
Wheel speed sensor, front	10.01→		**0 265 007 401**
Wheel speed sensor, rear	01.04→		**0 265 007 636**
Fg.no. 312323→	10.01-12.03		**0 265 007 636**
Ricam.no →312322	10.01-12.03		**0 265 007 400**
1.9 JTD 8V [192..]			**1,9 l 85/88 kW 192 A 8.000; 937 A 7.000 4 Zyl.**
Air mass meter, diesel	07.05-06.07		**0 281 002 792**
Speed sensor, diesel	07.05→	KW	**0 281 002 603**
Phase sensor	07.05→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	07.05→		**0 281 002 534**
Boost pressure sensor, Diesel	07.05-03.07		**0 281 002 437**
	04.07→		**0 281 002 845**
Yaw rate sensor, brake system	07.05→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	07.05→		**0 265 005 303**
Wheel speed sensor, front	07.05→		**0 265 007 401**
Wheel speed sensor, rear	07.05→		**0 265 007 636**
1.9 JTD 16V [192..]			**1,9 l 93/100/103 kW 192 A 5.000; 192 B 1.000; 937 A 4.000 4 Zyl.**
Air mass meter, diesel	01.04→		**0 280 218 120**
High-pressure sensor (CR system)	01.04→		**0 281 002 534**
Boost pressure sensor, Diesel	01.04-03.07		**0 281 002 437**
	04.07→		**0 281 002 845**
Accelerator pedal module	01.04→	LLE,XBN	**0 280 752 227**
Yaw rate sensor, brake system	01.04→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	01.04→		**0 265 005 303**
Wheel speed sensor, front	01.04→		**0 265 007 401**
Wheel speed sensor, rear	01.04→		**0 265 007 636**
1.9 JTD 16V [192..]			**1,9 l 110 kW 937 A 5.000 4 Zyl.**
Air mass meter, diesel	07.05-06.07		**0 281 002 792**
High-pressure sensor (CR system)	07.05→		**0 281 002 534**
Boost pressure sensor, Diesel	07.05-03.07		**0 281 002 437**
	04.07→		**0 281 002 845**
Yaw rate sensor, brake system	07.05→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	07.05→		**0 265 005 303**
Wheel speed sensor, front	07.05→		**0 265 007 401**
Wheel speed sensor, rear	07.05→		**0 265 007 636**
2.4 MPI 20V			**2,4 l 123 kW 192 A 7.011 5 Zyl.**
Throttle valve assembly	06.02→		**0 205 003 052**
Air mass meter, gasoline injection	06.02→		**0 281 002 308**
Phase sensor	06.02→		**0 232 101 036**
Speed sensor, ignition/injection	06.02→		**0 261 210 160**
Knock sensor	06.02→		**0 261 231 144**
Accelerator pedal module	06.02→	LLE,XBN	**0 280 752 227**
Yaw rate sensor, brake system	06.02→		**0 265 005 241**
Wheel speed sensor, front	06.02→		**0 265 007 401**
Wheel speed sensor, rear	06.02→		**0 265 007 400**
2.4 20V [192..]			**2,4 l 125 kW 192 A 2.000 5 Zyl.**
Throttle valve assembly	10.01→		**0 205 003 052**
Air mass meter, gasoline injection	10.01→		**0 281 002 308**
Phase sensor	10.01→		**0 232 101 036**

F

Product			
Speed sensor, ignition/injection	10.01→		**0 261 210 160**
Knock sensor	10.01→		**0 261 231 144**
Accelerator pedal module	10.01-12.03	LLE,XBN	**0 280 752 227**
Yaw rate sensor, brake system	10.01→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	10.01→		**0 265 005 303**
Wheel speed sensor, front	10.01→		**0 265 007 401**
Wheel speed sensor, rear	01.04→		**0 265 007 636**
Fg.no. 312323→	10.01-12.03		**0 265 007 636**
Ricam.no →312322	10.01-12.03		**0 265 007 400**

Stilo Multi Wagon

1.4 16V [192..] 1,4 l 66/70 kW 192 B 2.000; 843 A 1.000 4 Zyl.			
Throttle valve assembly	01.04→		**F 01C 600 027**
Phase sensor	01.04→	NOC	**0 232 103 048**
Speed sensor, ignition/injection	01.04→		**0 261 210 238**
Knock sensor	01.04→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	01.04→		**0 261 230 030**
Wheel speed sensor, front	01.04→		**0 265 007 401**
Wheel speed sensor, rear	01.04→		**0 265 007 636**
1.6 16V [192..] 1,6 l 76 kW 182 B 6.000 4 Zyl.			
Yaw rate sensor, brake system	10.02→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	10.02→		**0 265 005 303**
Wheel speed sensor, front	10.02→		**0 265 007 401**
Wheel speed sensor, rear	10.02→		**0 265 007 636**
1.6 16V [192..] 1,6 l 100 kW 192 B 3.000 4 Zyl.			
Accelerator pedal module	07.05→	LLE,XBN	**0 280 752 227**
Yaw rate sensor, brake system	07.05→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	07.05→		**0 265 005 303**
Wheel speed sensor, front	07.05→		**0 265 007 401**
Wheel speed sensor, rear	07.05→		**0 265 007 636**
1.8 16V [192..] 1,8 l 98 kW 192 A 4.000 4 Zyl.			
Phase sensor	10.02→		**0 232 101 037**
Yaw rate sensor, brake system	10.02→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	10.02→		**0 265 005 303**
Wheel speed sensor, front	10.02→		**0 265 007 401**
Wheel speed sensor, rear	10.02→		**0 265 007 636**
1.9 JTD 8V [192..] 1,9 l 59 kW 192 A 3.000 4 Zyl.			
Air mass meter, diesel	10.02→		**0 281 002 308**
Speed sensor, diesel	10.02-07.03		**0 281 002 474**
	08.03→		**0 281 002 603**
Phase sensor	10.02→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	10.02-12.03		**0 281 002 405**
Boost pressure sensor, Diesel	10.02-01.06		**0 281 002 510**
	02.06→		**0 281 002 844**
Accelerator pedal module	10.02→	LLE,XBN	**0 280 752 227**
Yaw rate sensor, brake system	10.02→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	10.02→		**0 265 005 303**
Wheel speed sensor, front	10.02→		**0 265 007 401**
Wheel speed sensor, rear	10.02→		**0 265 007 636**
1.9 JTD 8V [192..] 1,9 l 66 kW 192 B 5.000 4 Zyl.			
Air mass meter, diesel	10.05-06.07		**0 281 002 792**
Speed sensor, diesel	10.05→	KW	**0 281 002 603**
Phase sensor	10.05→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	10.05→		**0 281 002 534**
Boost pressure sensor, Diesel	10.05-03.07		**0 281 002 437**
	04.07→		**0 281 002 845**
Yaw rate sensor, brake system	10.05→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	10.05→		**0 265 005 303**
Wheel speed sensor, front	10.05→		**0 265 007 401**
Wheel speed sensor, rear	10.05→		**0 265 007 636**

Product			
1.9 JTD 8V [192..] 1,9 l 74 kW 192 A 9.000 4 Zyl.			
Air mass meter, diesel	09.04→		**0 281 002 308**
Speed sensor, diesel	09.04→		**0 281 002 603**
Phase sensor	09.04→	NOC	**0 281 002 213**
Boost pressure sensor, Diesel	09.04-01.06		**0 281 002 510**
	02.06→		**0 281 002 844**
Accelerator pedal module	09.04→	LLE,XBN	**0 280 752 227**
Yaw rate sensor, brake system	09.04→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	09.04→		**0 265 005 303**
Wheel speed sensor, front	09.04→		**0 265 007 401**
Wheel speed sensor, rear	09.04→		**0 265 007 636**
1.9 JTD 8V [192..] 1,9 l 85 kW 192 A 1.000 4 Zyl.			
Air mass meter, diesel	10.02→		**0 281 002 308**
Speed sensor, diesel	10.02-07.03		**0 281 002 474**
	08.03→		**0 281 002 603**
Phase sensor	10.02→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	10.02-12.03		**0 281 002 405**
Boost pressure sensor, Diesel	10.02-01.06		**0 281 002 510**
	02.06→		**0 281 002 844**
Accelerator pedal module	10.02→	LLE,XBN	**0 280 752 227**
Yaw rate sensor, brake system	10.02→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	10.02→		**0 265 005 303**
Wheel speed sensor, front	10.02→		**0 265 007 401**
Wheel speed sensor, rear	10.02→		**0 265 007 636**
1.9 JTD 8V [192..] 1,9 l 85/88 kW 192 A 8.000; 937 A 7.000 4 Zyl.			
Air mass meter, diesel	07.05-06.07		**0 281 002 792**
Speed sensor, diesel	07.05→	KW	**0 281 002 603**
Phase sensor	07.05→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	07.05→		**0 281 002 534**
Boost pressure sensor, Diesel	07.05-03.07		**0 281 002 437**
	04.07→		**0 281 002 845**
Yaw rate sensor, brake system	07.05→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	07.05→		**0 265 005 303**
Wheel speed sensor, front	07.05→		**0 265 007 401**
Wheel speed sensor, rear	07.05→		**0 265 007 636**
1.9 JTD 16V [192..] 1,9 l 93/100/103 kW 192 A 5.000; 192 B 1.000; 937 A 4.000 4 Zyl.			
Air mass meter, diesel	01.04→		**0 280 218 120**
High-pressure sensor (CR system)	01.04→		**0 281 002 534**
Boost pressure sensor, Diesel	01.04-03.07		**0 281 002 437**
	04.07→		**0 281 002 845**
Accelerator pedal module	01.04→	LLE,XBN	**0 280 752 227**
Yaw rate sensor, brake system	01.04→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	01.04→		**0 265 005 303**
Wheel speed sensor, front	01.04→		**0 265 007 401**
Wheel speed sensor, rear	01.04→		**0 265 007 636**
1.9 JTD 16V [192..] 1,9 l 110 kW 937 A 5.000 4 Zyl.			
Air mass meter, diesel	07.05-06.07		**0 281 002 792**
High-pressure sensor (CR system)	07.05→		**0 281 002 534**
Boost pressure sensor, Diesel	07.05-03.07		**0 281 002 437**
	04.07→		**0 281 002 845**
Yaw rate sensor, brake system	07.05→		**0 265 005 241**
Pressure sensor, ESP, (electronic stability program)	07.05→		**0 265 005 303**
Wheel speed sensor, front	07.05→		**0 265 007 401**
Wheel speed sensor, rear	07.05→		**0 265 007 636**
2.4 20V [192..] 2,4 l 125 kW 192 A 2.000 4 Zyl.			
Throttle valve assembly	01.04→		**0 205 003 052**
Air mass meter, gasoline injection	01.04→		**0 281 002 308**
Phase sensor	01.04→		**0 232 101 036**
Speed sensor, ignition/injection	01.04→		**0 261 210 160**
Knock sensor	01.04→		**0 261 231 144**
Yaw rate sensor, brake system	01.04→		**0 265 005 241**

F

Product

◀ Stilo Multi Wagon

Pressure sensor, ESP, (electronic stability program)	01.04→		**0 265 005 303**
Wheel speed sensor, front	01.04→		**0 265 007 401**
Wheel speed sensor, rear	01.04→		**0 265 007 636**

Strada

1.2 MPI 8V [278]	**1,2 l 44 kW 178 B 5.000 4 Zyl.**		
Speed sensor, ignition/injection	03.99-03.03		**0 261 210 114**
Wheel speed sensor, front	03.99-03.03	LAB	**0 265 007 049**
		RAB	**0 265 007 050**
Wheel speed sensor, rear	03.99-03.03	LAB	**0 265 007 054**
		RAB	**0 265 007 055**
1.2 MPI 8V [278]	**1,2 l 54 kW 188 A 4.000 4 Zyl.**		
Speed sensor, ignition/injection	05.01-06.05		**0 261 210 114**
Wheel speed sensor, front	04.03-06.05	ATJ,LAB	**0 265 007 103**
		ATJ,RAB	**0 265 007 102**
		ATN,LAB	**0 265 007 049**
		ATN,RAB	**0 265 007 050**
	05.01-03.03	LAB	**0 265 007 049**
		RAB	**0 265 007 050**
Wheel speed sensor, rear	05.01-06.05	LAB	**0 265 007 054**
		RAB	**0 265 007 055**
1.3 JTD [278]	**1,3 l 63 kW 223 A 9.000 4 Zyl.**		
Air mass meter, diesel	07.05→		**0 281 002 792**
Boost pressure sensor, Diesel	07.05-11.06		**0 281 002 437**
	12.06→		**0 281 002 845**
Accelerator pedal module	07.05→		**0 281 002 379**
Wheel speed sensor, front	07.05→	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	07.05→	LAB	**0 265 007 054**
		RAB	**0 265 007 055**
1.5 MPI 8V	**1,5 l 56 kW 178 A 5.011 4 Zyl.**		
Wheel speed sensor, front	10.98-02.03	LAB	**0 265 007 049**
		RAB	**0 265 007 050**
Wheel speed sensor, rear	10.98-02.03	LAB	**0 265 007 054**
		RAB	**0 265 007 055**
1.6 MPI 16V	**1,6 l 78 kW 178 D 2.011 4 Zyl.**		
Wheel speed sensor, front	02.98-02.03	LAB	**0 265 007 049**
		RAB	**0 265 007 050**
Wheel speed sensor, rear	02.98-02.03	LAB	**0 265 007 054**
		RAB	**0 265 007 055**
1.7 TDS [278]	**1,7 l 51 kW 176 A 3.000 4 Zyl.**		
Wheel speed sensor, front	03.99-03.03	LAB	**0 265 007 049**
		RAB	**0 265 007 050**
Wheel speed sensor, rear	03.99-03.03	LAB	**0 265 007 054**
		RAB	**0 265 007 055**
1.9 D [278]	**1,9 l 46 kW 223 A 6.000 4 Zyl.**		
Speed sensor, diesel	11.00-03.03		**0 281 002 214**
	04.03-06.05		**0 281 002 474**
Accelerator pedal module	11.00-06.05		**0 281 002 379**
Wheel speed sensor, front	11.00-06.05	LAB	**0 265 007 049**
		RAB	**0 265 007 050**
Wheel speed sensor, rear	11.00-06.05	LAB	**0 265 007 054**
		RAB	**0 265 007 055**
1.9 JTD [278]	**1,9 l 59 kW 188 A 2.000 4 Zyl.**		
Air mass meter, diesel	04.03-06.05		**0 281 002 308**
Speed sensor, diesel	04.03-02.04		**0 281 002 474**
	03.04-06.05		**0 281 002 603**
Phase sensor	04.03-06.05		**0 281 002 213**
High-pressure sensor (CR system)	04.03-02.04		**0 281 002 405**
Boost pressure sensor, Diesel	04.03-06.05		**0 281 002 844**
Accelerator pedal module	04.03-06.05		**0 281 002 379**

Product

Wheel speed sensor, front	04.03-06.05	LAB	**0 265 007 049**
		RAB	**0 265 007 050**
Wheel speed sensor, rear	04.03-06.05	LAB	**0 265 007 054**
		RAB	**0 265 007 055**

Strada Adventure

1.7 TD [Fase II]	**1,7 l 52 kW 4 Zyl.**		
Wheel speed sensor, front	10.06→	LAB	**0 265 007 103**
		RAB	**0 265 007 102**
Wheel speed sensor, rear	10.06→	LAB	**0 265 007 054**
		RAB	**0 265 007 055**

Tempra

1.4 [159]	**1,4 l 56 kW 159 A 2.000 4 Zyl.**		
Wheel speed sensor, front	04.93-03.96		**0 265 001 215**
	04.96-12.96		**0 265 006 212**
Wheel speed sensor, rear	04.96-12.96		**0 265 006 197**
	04.93-03.96	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.4 i.e. [159]	**1,4 l 51 kW 160 A 1.046 4 Zyl.**		
Temperature sensor, coolant, injection system	03.92-03.93		**0 280 130 026**
Wheel speed sensor, front	04.93-03.96		**0 265 001 215**
	04.96-12.96		**0 265 006 212**
Wheel speed sensor, rear	04.96-12.96		**0 265 006 197**
	04.93-03.96	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.4 i.e. [159]	**1,4 l 51 kW 836 A 4.000 4 Zyl.**		
Speed sensor, ignition/injection	03.95-12.96	KL	**0 261 210 118**
		KLO	**0 261 210 115**
Temperature sensor, coolant, injection system	03.95-12.96		**0 280 130 026**
Wheel speed sensor, front	03.95-03.96		**0 265 001 215**
	04.96-12.96		**0 265 006 212**
Wheel speed sensor, rear	04.96-12.96		**0 265 006 197**
	03.95-03.96	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.6 [159]	**1,6 l 62 kW 159 A 3.000 4 Zyl.**		
Speed sensor, ignition/injection	04.93-12.96	KL	**0 261 210 118**
Wheel speed sensor, front	04.93-03.96		**0 265 001 215**
	04.96-12.96		**0 265 006 212**
Wheel speed sensor, rear	04.96-12.96		**0 265 006 197**
	04.93-03.96	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.6 [159]	**1,6 l 62 kW 159 A 3.098 4 Zyl.**		
Wheel speed sensor, front	04.93-03.96		**0 265 001 215**
	04.96-12.96		**0 265 006 212**
Wheel speed sensor, rear	04.96-12.96		**0 265 006 197**
	04.93-03.96	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.6 i.e. [159]	**1,6 l 55 kW 159 A 3.048 4 Zyl.**		
Temperature sensor, coolant, injection system	06.92-03.93		**0 280 130 026**
1.6 i.e. [159]	**1,6 l 55 kW 835 C 1.000 4 Zyl.**		
Speed sensor, ignition/injection	04.93-12.96	KL	**0 261 210 118**
		KLO	**0 261 210 102**
Temperature sensor, coolant, injection system	04.93-12.96		**0 280 130 026**
Wheel speed sensor, front	04.93-03.96		**0 265 001 215**
	04.96-12.96		**0 265 006 212**
Wheel speed sensor, rear	04.96-12.96		**0 265 006 197**
	04.93-03.96	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.6 i.e. [159]	**1,6 l 57 kW 159 A 3.046 4 Zyl.**		
Temperature sensor, coolant, injection system	06.90-07.92		**0 280 130 026**

F

Product			
1.6 i.e. [159]			**1,6 l 66 kW 159 B 9.000 4 Zyl.**
Wheel speed sensor, front	05.94-03.96		**0 265 001 215**
	04.96-12.96		**0 265 006 212**
Wheel speed sensor, rear	04.96-12.96		**0 265 006 197**
	05.94-03.96	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.6 i.e. Selecta [159]			**1,6 l 55 kW 159 A 3.048 4 Zyl.**
Wheel speed sensor, front	04.93-03.96		**0 265 001 215**
	04.96-12.96		**0 265 006 212**
Wheel speed sensor, rear	04.96-12.96		**0 265 006 197**
	04.93-03.96	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.8 i.e. [159]			**1,8 l 66/71/76 kW 159 A 4.046; 835 C 2.000; 835 C 4.000; 836 A 5.000 4 Zyl.**
Wheel speed sensor, front	04.93-03.96		**0 265 001 215**
	04.96-12.96		**0 265 006 212**
Wheel speed sensor, rear	04.96-12.96		**0 265 006 197**
	04.93-03.96	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.8 i.e. [159] 1,8 l 77 kW 159 A 4.046; 835 C 2.000; 835 C 4.000; 836 A 5.000 4 Zyl.			
Wheel speed sensor, front	04.93-03.96		**0 265 001 215**
	04.96-12.96		**0 265 006 212**
Wheel speed sensor, rear	04.96-12.96		**0 265 006 197**
1.8 i.e. [159]			**1,8 l 77 kW 835 C 2.000 4 Zyl.**
Wheel speed sensor, rear	04.93-12.96	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.9 D [159]			**1,9 l 48 kW 160 A 7.000 4 Zyl.**
Wheel speed sensor, front	04.93-12.96		**0 265 001 215**
Wheel speed sensor, rear	04.93-12.96	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.9 TD [159]			**1,9 l 60/66/68 kW 160 A 6.000; 160 A 6.046; 160 B 6.046; 160 D 1.000 4 Zyl.**
Wheel speed sensor, front	02.90-12.96		**0 265 001 215**
Wheel speed sensor, rear	02.90-12.96	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
2.0 i.e. [159]			**2,0 l 83-85 kW 159 A 6.046 4 Zyl.**
Wheel speed sensor, front	02.90-03.96		**0 265 001 215**
	04.96-12.96		**0 265 006 212**
Wheel speed sensor, rear	04.96-12.96		**0 265 006 197**
	02.90-03.96	LAB	**0 265 001 216**
	04.93-03.96	RAB	**0 265 001 217**
	02.90-03.93	RAB	**0 265 006 197**
2.0 SPI 8V			**2,0 l 76 kW 159 B 1.011 4 Zyl.**
Wheel speed sensor, front	05.94-12.98		**0 265 006 402**
Wheel speed sensor, rear	05.94-12.98		**0 265 006 403**

Tempra SW

1.4 [159]			**1,4 l 56 kW 159 A 2.000 4 Zyl.**
Wheel speed sensor, front	04.93-03.96		**0 265 001 215**
	04.96-12.96		**0 265 006 212**
Wheel speed sensor, rear	04.96-12.96		**0 265 006 197**
	04.93-03.96	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.4 i.e. [159]			**1,4 l 51 kW 160 A 1.046 4 Zyl.**
Temperature sensor, coolant, injection system	03.92-03.93		**0 280 130 026**
Wheel speed sensor, front	04.94-03.96		**0 265 001 215**
	04.96-12.96		**0 265 006 212**
Wheel speed sensor, rear	04.96-12.96		**0 265 006 197**
	04.94-03.96	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.4 i.e. [159]			**1,4 l 51 kW 836 A 4.000 4 Zyl.**
Speed sensor, ignition/injection	03.95-12.96	KL	**0 261 210 118**
		KLO	**0 261 210 115**
Temperature sensor, coolant, injection system	03.95-12.96		**0 280 130 026**
Wheel speed sensor, front	03.95-03.96		**0 265 001 215**
	04.96-12.96		**0 265 006 212**
Wheel speed sensor, rear	04.96-12.96		**0 265 006 197**
	03.95-03.96	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.6 [159]			**1,6 l 62 kW 159 A 3.000 4 Zyl.**
Speed sensor, ignition/injection	04.93-12.96	KL	**0 261 210 118**
Wheel speed sensor, front	04.93-03.96		**0 265 001 215**
	04.96-12.96		**0 265 006 212**
Wheel speed sensor, rear	04.96-12.96		**0 265 006 197**
	04.93-03.96	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.6 i.e. [159]			**1,6 l 55 kW 159 A 3.048 4 Zyl.**
Temperature sensor, coolant, injection system	06.92-03.93		**0 280 130 026**
1.6 i.e. [159]			**1,6 l 55 kW 835 C 1.000 4 Zyl.**
Speed sensor, ignition/injection	04.93-12.96	KL	**0 261 210 118**
		KLO	**0 261 210 102**
Temperature sensor, coolant, injection system	04.93-12.96		**0 280 130 026**
Wheel speed sensor, front	04.93-03.96		**0 265 001 215**
	04.96-12.96		**0 265 006 212**
Wheel speed sensor, rear	04.96-12.96		**0 265 006 197**
	04.93-03.96	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.6 i.e. [159]			**1,6 l 57 kW 159 A 3.046 4 Zyl.**
Temperature sensor, coolant, injection system	01.91-07.92		**0 280 130 026**
1.6 i.e. [159]			**1,6 l 66 kW 159 B 9.000 4 Zyl.**
Wheel speed sensor, front	05.94-03.96		**0 265 001 215**
	04.96-12.96		**0 265 006 212**
Wheel speed sensor, rear	04.96-12.96		**0 265 006 197**
	05.94-03.96	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.6 i.e. Selecta [159]			**1,6 l 55 kW 159 A 3.048 4 Zyl.**
Wheel speed sensor, front	04.93-03.96		**0 265 001 215**
	04.96-12.96		**0 265 006 212**
Wheel speed sensor, rear	04.96-12.96		**0 265 006 197**
	04.93-03.96	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.8 i.e. [159]			**1,8 l 66/71/76/77 kW 159 A 4.046;835 C 2.000/4.000; 836 A 5.000 4 Zyl.**
Wheel speed sensor, front	04.93-03.96		**0 265 001 215**
	04.96-12.96		**0 265 006 212**
Wheel speed sensor, rear	04.96-12.96		**0 265 006 197**
	04.93-03.96	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.9 D [159]			**1,9 l 48 kW 160 A 7.000 4 Zyl.**
Wheel speed sensor, front	04.93-12.96		**0 265 001 215**
Wheel speed sensor, rear	04.93-12.96	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.9 TD [159]			**1,9 l 60/66/68 kW 160 A 6.000; 160 A 6.046; 160 B 6.046; 160 D 1.000 4 Zyl.**
Wheel speed sensor, front	02.90-12.96		**0 265 001 215**
Wheel speed sensor, rear	02.90-12.96	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
2.0 i.e. [159]			**2,0 l 83-85 kW 159 A 6.046 4 Zyl.**
Wheel speed sensor, front	03.92-03.96		**0 265 001 215**
	04.96-12.96		**0 265 006 212**

F

Product			
◀ Tempra SW			
Wheel speed sensor, rear	04.96-12.96		**0 265 006 197**
	03.92-03.96	LAB	**0 265 001 216**
	04.93-03.96	RAB	**0 265 001 217**
	03.92-03.93	RAB	**0 265 006 197**
2.0 i.e. 4x4 [159]	**2,0 l 83-85 kW 159 A 6.046 4 Zyl.**		
Lateral acceleration sensor, brake system	03.92-12.96	LAB	**0 265 005 031**
		RAB	**0 265 005 030**
Wheel speed sensor, front	03.92-12.96		**0 265 001 215**
Wheel speed sensor, rear	03.92-12.96		**0 265 001 304**
2.0 MPI 8V	**2,0 l 80 kW 159 B 8.011 4 Zyl.**		
Wheel speed sensor, front	05.94-10.97		**0 265 001 355**
		WW	**0 265 001 215**
Wheel speed sensor, rear	05.94-10.97		**0 265 006 197**

Tipo

1.1 i.e. [160..]	**1,1 l 37 kW 156 C.046 4 Zyl.**		
Speed sensor, ignition/injection	10.94-05.95		**0 261 210 098**
	06.95-10.95		**0 261 210 117**
Temperature sensor, coolant, injection system	10.94-10.95		**0 280 130 026**
Wheel speed sensor, front	10.94-10.95		**0 265 001 215**
Wheel speed sensor, rear	10.94-10.95	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.4 [160..]	**1,4 l 52 kW 159 A 2.000 4 Zyl.**		
Temperature sensor, coolant, injection system	03.93-10.95		**0 280 130 066**
Wheel speed sensor, front	03.93-10.95		**0 265 001 215**
Wheel speed sensor, rear	03.93-10.95	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.4 i.e. [160..]	**1,4 l 51 kW 836 A 4.000 4 Zyl.**		
Speed sensor, ignition/injection	10.93-10.95	KL	**0 261 210 118**
		KLO	**0 261 210 115**
Temperature sensor, coolant, injection system	10.93-10.95		**0 280 130 066**
Wheel speed sensor, front	10.93-10.95		**0 265 001 215**
Wheel speed sensor, rear	10.93-10.95	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.4 i.e. [160..]	**1,4 l 52 kW 160 A 1.046 4 Zyl.**		
Temperature sensor, coolant, injection system	03.93-10.95		**0 280 130 066**
Wheel speed sensor, front	03.93-10.95		**0 265 001 215**
Wheel speed sensor, rear	03.93-10.95	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.6 [160..]	**1,6 l 58 kW 159 A 3.000 4 Zyl.**		
Speed sensor, ignition/injection	03.93-09.93	KL	**0 261 210 103**
		KLO	**0 261 210 102**
Temperature sensor, coolant, injection system	03.93-10.95		**0 280 130 066**
Wheel speed sensor, front	03.93-10.95		**0 265 001 215**
Wheel speed sensor, rear	03.93-10.95	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.6 i.e. [160..]	**1,6 l 55 kW 159 A 3.048 4 Zyl.**		
Temperature sensor, coolant, injection system	01.92-03.93		**0 280 130 066**
1.6 i.e. [160..]	**1,6 l 56 kW 160 E 2.011; 835 C 1.000 4 Zyl.**		
Speed sensor, ignition/injection	03.93-09.93	KL	**0 261 210 103**
	10.93-10.95	KL	**0 261 210 118**
	03.93-09.93	KLO	**0 261 210 102**
	10.93-10.95	KLO	**0 261 210 115**
Temperature sensor, coolant, injection system	03.93-10.95		**0 280 130 066**
Wheel speed sensor, front	03.93-10.95		**0 265 001 215**
Wheel speed sensor, rear	03.93-10.95	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.6 i.e. [160..]	**1,6 l 57 kW 159 A 3.046 4 Zyl.**		
Temperature sensor, coolant, injection system	03.90-03.93		**0 280 130 066**
1.6 i.e. Selecta [160..]	**1,6 l 56 kW 159 A 3.048 4 Zyl.**		
Temperature sensor, coolant, injection system	03.93-10.95		**0 280 130 066**
Wheel speed sensor, front	03.93-10.95		**0 265 001 215**
Wheel speed sensor, rear	03.93-10.95	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.6 MPI 8V	**1,6 l 66 kW 160 E 1.011 4 Zyl.**		
Throttle valve sensor	12.95-05.97		**0 280 122 001**
Speed sensor, ignition/injection	12.95-05.97		**0 261 210 118**
Knock sensor	12.95-05.97		**0 261 231 007**
Pressure sensor, intake manifold, gasoline	12.95-05.97		**0 261 230 004**
Temperature sensor, intake air, injection system	12.95-05.97		**0 280 130 060**
Temperature sensor, coolant, injection system	12.95-05.97		**0 280 130 068**
1.7 D [160..]	**1,7 l 42 kW 149 B 4.000 4 Zyl.**		
Wheel speed sensor, front	03.93-10.95		**0 265 001 215**
Wheel speed sensor, rear	03.93-10.95	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.8 i.e. [160..]	**1,8 l 66/71/77 kW 835 C 2.000/4.000; 836 A 5.000/6.000 4 Zyl.**		
Wheel speed sensor, front	03.93-10.95		**0 265 001 215**
Wheel speed sensor, rear	03.93-10.95	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.8 i.e. 16V [160..]	**1,8 l 101 kW 160 A 5.000 4 Zyl.**		
Wheel speed sensor, front	06.89-09.91		**0 265 001 215**
Wheel speed sensor, rear	06.89-09.91	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.9 D [160..]	**1,9 l 48 kW 160 A 7.000 4 Zyl.**		
Wheel speed sensor, front	03.93-10.95		**0 265 001 215**
Wheel speed sensor, rear	03.93-10.95	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.9 D Turbo [160..]	**1,9 l 65/68 kW 160 A 6.000; 160 D 1.000 4 Zyl.**		
Wheel speed sensor, front	03.93-10.95		**0 265 001 215**
Wheel speed sensor, rear	03.93-10.95	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.9 TD [160..]	**1,9 l 59/67,6/68 kW 160 A 6.000; 160 A 6.046; 160 B 6.046 4 Zyl.**		
Wheel speed sensor, front	07.87-03.93		**0 265 001 215**
Wheel speed sensor, rear	07.87-03.93	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
2.0 i.e. [160..]	**2,0 l 85 kW 159 A 6.011; 159 A 6.046 4 Zyl.**		
Wheel speed sensor, front	03.93-10.95		**0 265 001 215**
Wheel speed sensor, rear	03.93-10.95	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
2.0 i.e. 16V [160..]	**2,0 l 104/107 kW 160 A 8.046; 836 A 3.000; 836 A 3.011 4 Zyl.**		
Wheel speed sensor, front	12.90-10.95		**0 265 001 215**
Wheel speed sensor, rear	12.90-10.95	LAB	**0 265 001 216**
		RAB	**0 265 001 217**

Ulysse

1.8 i.e. [121..]	**1,8 l 75 kW LFW 4 Zyl.**		
Wheel speed sensor, front			
Ricam.no 7480→9050	06.97-05.00		**0 265 006 388**
Wheel speed sensor, rear			
Ricam.no 7480→7609	06.97-09.97	BO	**0 265 006 426**
Ricam.no 7610→	10.97-05.00	BO	**0 265 006 504**
1.9 TD [121..]	**1,9 l 66 kW DHX; D8B 4 Zyl.**		
Wheel speed sensor, front			
Ricam.no 7480→9050	06.97-12.99		**0 265 006 388**
Wheel speed sensor, rear			
Ricam.no 7480→7609	06.97-09.97	BO	**0 265 006 426**
Ricam.no 7610→	10.97-12.99	BO	**0 265 006 504**
2.0 i.e. [121..]	**2,0 l 90 kW RFU 4 Zyl.**		
Knock sensor			
Ricam.no 8135→	03.99-05.00		**0 261 231 130**
Wheel speed sensor, front			
Ricam.no 7480→9050	06.97-05.00		**0 265 006 388**

F

Product			
Wheel speed sensor, rear			
Ricam.no 7480→7609	06.97-09.97	BO	**0 265 006 426**
Ricam.no 7610→	10.97-05.00	BO	**0 265 006 504**
2.0 i.e. Turbo [121..]			**2,0 l 110 kW RGX 4 Zyl.**
Throttle valve sensor			
Ricam.no →6778	09.94-06.95		**0 280 122 001**
Ricam.no 6779→	07.95-05.00		**0 280 122 003**
Knock sensor			
Ricam.no 8135→	03.99-05.00		**0 261 231 130**
Wheel speed sensor, front			
Ricam.no 7480→9050	06.97-05.00		**0 265 006 388**
Wheel speed sensor, rear			
Ricam.no 7480→7609	06.97-09.97	BO	**0 265 006 426**
Ricam.no 7610→	10.97-05.00	BO	**0 265 006 504**
2.0 i.e. 16V [121..]			**2,0 l 97 kW RFV 4 Zyl.**
Knock sensor			
Ricam.no →8134	05.98-02.99		**0 261 231 109**
Ricam.no 8135→	03.99-05.00		**0 261 231 130**
Pressure sensor, intake manifold, gasoline			
Ricam.no →8057	05.98-12.98		**0 261 230 012**
Ricam.no 8058→	01.99-05.00		**0 261 230 034**
Wheel speed sensor, front			
Ricam.no 7480→9050	05.98-05.00		**0 265 006 388**
Wheel speed sensor, rear			
Ricam.no 7610→	05.98-05.00	BO	**0 265 006 504**
2.0 i.e. 16V [121..]			**2,0 l 100 kW RFN 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.00-09.02		**0 261 230 057**
Wheel speed sensor, front			
Ricam.no 7480→9050	03.00-08.01		**0 265 006 388**
Wheel speed sensor, rear			
Ricam.no 7610→	03.00-09.02	BO	**0 265 006 504**
2.0 JTD 8V [121..]			**2,0 l 80 kW RHZ 4 Zyl.**
High-pressure sensor (CR system)	07.99-09.02		**0 281 002 283**
Wheel speed sensor, front			
Ricam.no 7480→9050	07.99-08.01		**0 265 006 388**
Wheel speed sensor, rear			
Ricam.no 7610→	07.99-09.02	BO	**0 265 006 504**
2.0 JTD 16V [121..]			**2,0 l 80 kW RHW 4 Zyl.**
High-pressure sensor (CR system)	11.00-09.02		**0 281 002 283**
Wheel speed sensor, front			
Ricam.no 7480→9050	11.00-08.01		**0 265 006 388**
Wheel speed sensor, rear			
Ricam.no 7610→	11.00-09.02	BO	**0 265 006 504**
2.0 16V [179..]			**2,0 l 100 kW RFN 4 Zyl.**
Yaw rate sensor, brake system			
Ricam.no →10570	10.02-10.05		**0 265 005 290**
Wheel speed sensor, front	10.02-10.05	LAB	**0 265 007 083**
		RAB	**0 265 007 084**
2.0 16V JTD [179..]			**2,0 l 79/80 kW RHM; RHW 4 Zyl.**
High-pressure sensor (CR system)	10.02→		**0 281 002 283**
Yaw rate sensor, brake system			
Ricam.no →10570	10.02-10.05		**0 265 005 290**
Wheel speed sensor, front	10.02→	LAB	**0 265 007 083**
		RAB	**0 265 007 084**
2.0 16V JTD [179..]			**2,0 l 88/100 kW RHK; RHR 4 Zyl.**
Wheel speed sensor, front	02.06→	LAB	**0 265 007 083**
		RAB	**0 265 007 084**
2.1 TD [121..]			**2,1 l 80 kW P8C 4 Zyl.**
Wheel speed sensor, front			
Ricam.no 7480→9050	06.97-10.99		**0 265 006 388**
Wheel speed sensor, rear			
Ricam.no 7480→7609	06.97-09.97	BO	**0 265 006 426**
Ricam.no 7610→	10.97-10.99	BO	**0 265 006 504**

Product			
2.2 16V JTD [179..]			**2,2 l 94 kW 4HW 4 Zyl.**
High-pressure sensor (CR system)	10.02→		**0 281 002 283**
Yaw rate sensor, brake system			
Ricam.no →10570	10.02-10.05		**0 265 005 290**
Wheel speed sensor, front	10.02→	LAB	**0 265 007 083**
		RAB	**0 265 007 084**
3.0 V6 24V [179..]			**3,0 l 150 kW XFW 6 Zyl.**
Knock sensor	01.03-10.05	KZB	**0 261 231 130**
Yaw rate sensor, brake system			
Ricam.no →10570	01.03-10.05		**0 265 005 290**
Wheel speed sensor, front	01.03-10.05	LAB	**0 265 007 083**
		RAB	**0 265 007 084**

Uno

1.0 i.e. [158..]			**1,0 l 33 kW 146 D 8.000 4 Zyl.**
Speed sensor, ignition/injection	01.96-12.02		**0 261 210 114**
1.0 i.e. [158..]			**1,0 l 33 kW 156 A 2.246 4 Zyl.**
Temperature sensor, coolant, injection system	01.96-12.02		**0 280 130 026**
1.3 Turbo i.e. [146..]			**1,3 l 73,5 kW 146 A 2.246 4 Zyl.**
Throttle valve sensor	10.87-08.89		**0 280 120 314**
Air flow sensor, gasoline injection	10.87-08.89		**0 280 200 051**
Temperature sensor, coolant, injection system	10.87-08.89		**0 280 130 026**
Relay, Jetronic	10.87-08.89		**0 280 230 009**
1.3 Turbo i.e. [146..]			**1,3 l 74 kW 146 A 2.246 4 Zyl.**
Throttle valve sensor	09.89-03.91		**0 280 120 314**
Air flow sensor, gasoline injection	09.89-03.91		**0 280 200 051**
Temperature sensor, coolant, injection system	09.89-03.91		**0 280 130 066**
Relay, Jetronic	09.89-03.91		**0 280 230 009**
Wheel speed sensor, front	09.89-03.91	LAB	**0 265 001 337**
		RAB	**0 265 001 336**
Wheel speed sensor, rear	09.89-03.91		**0 265 001 338**
1.3 Turbo i.e. [146..]			**1,3 l 77 kW 146 A 2.000 4 Zyl.**
Throttle valve sensor	04.85-08.89		**0 280 120 314**
Air flow sensor, gasoline injection	04.85-08.89		**0 280 200 046**
Temperature sensor, coolant, injection system	04.85-08.89		**0 280 130 026**
Relay, Jetronic	04.85-08.89		**0 280 230 006**
1.4 i [146..]			**1,4 l 52 kW 146 A 4.045; 146 C 1.000 4 Zyl.**
Temperature sensor, coolant, injection system	05.90-12.98		**0 280 130 066**
1.4 MPI Turbo			**1,4 l 85 kW 146 A 8.011 4 Zyl.**
Throttle valve sensor	03.94-12.95		**0 280 120 314**
Temperature sensor, coolant, injection system	03.94-12.95		**0 280 130 026**
1.4 Turbo i.e. [146..]			**1,4 l 84 kW 146 A 8.046 4 Zyl.**
Throttle valve sensor	10.90-12.93		**0 280 120 314**
Temperature sensor, coolant, injection system	10.90-12.93		**0 280 130 066**
Relay, Jetronic	10.90-12.93		**0 332 014 113**
Wheel speed sensor, front	10.90-12.93	LAB	**0 265 001 337**
		RAB	**0 265 001 336**
Wheel speed sensor, rear	10.90-12.93		**0 265 001 338**
1.4 Turbo i.e. [146..]			**1,4 l 85 kW 146 A 8.000 4 Zyl.**
Throttle valve sensor	05.90-12.98		**0 280 120 314**
Temperature sensor, intake air, injection system	05.90-12.98		**0 280 130 026**
Relay, Jetronic	05.90-12.98		**0 332 014 107**
1.4 Turbo i.e. [146..]			**1,4 l 87 kW 146 A 8.000 4 Zyl.**
Throttle valve sensor	09.89-09.92		**0 280 120 314**
Temperature sensor, coolant, injection system	09.89-09.92		**0 280 130 066**
Relay, Jetronic	09.89-09.92		**0 332 014 113**
Wheel speed sensor, front	09.89-09.92	LAB	**0 265 001 337**
		RAB	**0 265 001 336**
Wheel speed sensor, rear	09.89-09.92		**0 265 001 338**

F

Product			

◀ Uno

1.6 R MPI		**1,6 l 66 kW 146 B 7.011 4 Zyl.**
Throttle valve sensor	05.93-09.94	**0 280 120 300**
Air flow sensor, gasoline injection	05.93-09.94	**0 280 200 055**
Knock sensor	05.93-09.94	**0 261 231 007**
Temperature sensor, intake air, injection system	05.93-09.94	**0 280 130 060**
Temperature sensor, coolant, injection system	05.93-09.94	**0 280 130 069**
45 fire i.e. [146..]		**1,0 l 33 kW 156 A 2.246 4 Zyl.**
Temperature sensor, coolant, injection system	10.87-08.89	**0 280 130 026**
45 i.e. [146..]		**1,0 l 33 kW 156 A 2.246 4 Zyl.**
Temperature sensor, coolant, injection system	09.89-03.94	**0 280 130 066**
70 i.e. [146..]		**1,4 l 51/52 kW 146 C 1.000; 160 A 1.046 4 Zyl.**
Temperature sensor, coolant, injection system	09.89-03.94	**0 280 130 066**
75 i.e. [146..]		**1,5 l 55 kW 138 C 2.048 4 Zyl.**
Throttle valve sensor	10.85-08.87	**0 280 120 300**
Air flow sensor, gasoline injection	10.85-08.87	**0 280 200 024**
		0 986 280 075
Pressure sensor, intake manifold, gasoline	10.85-08.87	**0 280 101 001**
Temperature sensor, coolant, injection system	10.85-08.87	**0 280 130 023**
Relay, Jetronic	10.85-08.87 WEI	**0 332 514 127**
75 i.e. [146..]		**1,5 l 55 kW 149 C 1.000 4 Zyl.**
Temperature sensor, coolant, injection system	09.87-08.89	**0 280 130 026**
	09.89-03.94	**0 280 130 066**
75 i.e. Selecta [146..]		**1,5 l 55 kW 149 C 1.000 4 Zyl.**
Temperature sensor, coolant, injection system	05.92-03.94	**0 280 130 066**

Uno Mille

1.0 MPI		**1,0 l 40 kW 178 D 9.011 4 Zyl.**
Speed sensor, ignition/injection	06.01-06.06	**0 261 210 114**

Uno Van

45 i.e. [246..]		**1,0 l 33 kW 156 A 2.246 4 Zyl.**
Temperature sensor, coolant, injection system	09.89-03.94	**0 280 130 066**

X 1/9

1500 i.e.		**1,5 l 56 kW 138 AE.. 4 Zyl.**
Throttle valve sensor	06.80-12.88	**0 280 120 300**
Air flow sensor, gasoline injection	09.80-12.88	**0 280 200 024**
		0 986 280 075
Pressure sensor, intake manifold, gasoline	09.83-12.88	**0 280 101 001**
Temperature sensor, coolant, injection system	06.80-12.88	**0 280 130 023**
Relay, Jetronic	09.80-12.88 WEI	**0 332 514 127**

FISSORE

Magnum 4x4

2.5 VIP V6 i.e.		**2,5 l 118 kW Alfa Romeo 019.11 6 Zyl.**
Throttle valve sensor	03.86-03.88	**0 280 120 302**
Air flow sensor, gasoline injection	03.86-03.88	**0 280 202 013**
Temperature sensor, intake air, injection system	03.86-03.88	**0 280 130 023**
Relay, Jetronic	03.86-03.88 WEI	**0 332 514 127**

Product			

FORD

Capri II

2.8 i [78]		**2,8 l 118 kW RRN 6 Zyl.**
Air flow sensor, gasoline injection	01.81-04.87	**0 438 120 069**

C-MAX

1.8 , FFV		**1,8 l 92 kW 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.07→	**0 261 230 044**
1.8 TDCi		**1,8 l 85 kW 4 Zyl.**
Pressure sensor, intake manifold, diesel	03.07→	**0 261 230 119**
2.0 , CNG		**2,0 l 107 kW 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.07→	**0 261 230 044**

Escort

1.6 i		**1,6 l 70 kW L1R 4 Zyl.**
Pressure sensor, intake manifold, gasoline	02.00-10.02	**0 261 230 027**
1.9 i		**1,9 l 82 kW J 4 Zyl.**
Air flow sensor, gasoline injection	08.89-02.92	**0 280 202 121**
		0 986 280 039

Escort IV

1.4 [86]		**1,4 l 51/54/55 kW FUA; FUAA; FUC 4 Zyl.**
Knock sensor	01.86-07.90	**0 261 231 006**
1.4 i [86]		**1,4 l 54 kW F6B; F6D 4 Zyl.**
Knock sensor	01.87-07.90	**0 261 231 006**
1.6 [86]		**1,6 l 58/65/66 kW LP2; LUC; LUG 4 Zyl.**
Knock sensor	01.86-07.90	**0 261 231 006**
1.6 i [86]		**1,6 l 66 kW L4B 4 Zyl.**
Air flow sensor, gasoline injection	01.86-07.90	**F 026 TX2 066**
		F 026 TX2 066
Knock sensor	01.86-07.90	**0 261 231 006**
Temperature sensor, coolant, injection system	01.86-07.90	**0 280 130 050**
1.6 RS Turbo [86]		**1,6 l 97 kW LNB 4 Zyl.**
Throttle valve sensor	01.86-07.90	**0 280 120 302**
Air flow sensor, gasoline injection	01.86-07.90	**0 438 121 056**
Knock sensor	01.86-07.90	**0 261 231 006**
Temperature sensor, coolant, injection system	01.86-07.90	**0 280 130 049**
1.6 XR3i [86]		**1,6 l 66/75 kW LJB; L4B 4 Zyl.**
Air flow sensor, gasoline injection	01.86-07.90	**F 026 TX2 066**
		F 026 TX2 066
Knock sensor	01.86-07.90	**0 261 231 006**
Temperature sensor, coolant, injection system	01.86-07.90	**0 280 130 050**
1.6 XR3i [86]		**1,6 l 77 kW LRB; LR2 4 Zyl.**
Air flow sensor, gasoline injection	01.86-08.89	**0 438 120 199**
Knock sensor	01.86-08.89	**0 261 231 006**
Relay, Jetronic	01.86-08.89	**0 280 230 113**
		0 280 230 116
1.6 XR3i [86]		**1,6 l 79 kW LJA 4 Zyl.**
Air flow sensor, gasoline injection	08.89-07.90	**0 438 120 199**
Knock sensor	08.89-07.90	**0 261 231 006**
Relay, Jetronic	08.89-07.90	**0 280 230 116**

F

Product		

Escort IV Cabrio

1.4 [86]		**1,4 l 51-55 kW FUA...; FUC 4 Zyl.**
Knock sensor	01.86-07.90	**0 261 231 006**
1.4 i [86]		**1,4 l 54 kW F6... 4 Zyl.**
Knock sensor	01.87-07.90	**0 261 231 006**
1.6 [86]		**1,6 l 58/65-66 kW LP2; LU... 4 Zyl.**
Knock sensor	01.86-07.90	**0 261 231 006**
1.6 i [86]		**1,6 l 66 kW L4B 4 Zyl.**
Air flow sensor, gasoline injection	01.86-07.90	**F 026 TX2 066**
		F 026 TX2 066
Knock sensor	01.86-07.90	**0 261 231 006**
Temperature sensor, coolant, injection system	01.86-07.90	**0 280 130 050**
1.6 XR3i [86]		**1,6 l 75 kW LJB 4 Zyl.**
Air flow sensor, gasoline injection	08.89-07.90	**F 026 TX2 066**
		F 026 TX2 066
Knock sensor	08.89-07.90	**0 261 231 006**
Temperature sensor, coolant, injection system	08.89-07.90	**0 280 130 050**
1.6 XR3i [86]		**1,6 l 77 kW LRB; LR2 4 Zyl.**
Air flow sensor, gasoline injection	01.86-08.89	**0 438 120 199**
Knock sensor	01.86-08.89	**0 261 231 006**
Relay, Jetronic	01.86-08.89	**0 280 230 113**
		0 280 230 116

Escort IV Express

1.4 [86]		**1,4 l 54 kW FUC 4 Zyl.**
Knock sensor	01.86-07.90	**0 261 231 006**
1.4 i [86]		**1,4 l 54 kW F6... 4 Zyl.**
Knock sensor	01.86-07.90	**0 261 231 006**
1.6 [86]		**1,6 l 65-66 kW LU... 4 Zyl.**
Knock sensor	01.86-07.90	**0 261 231 006**

Escort IV Turnier

1.4 [86]		**1,4 l 51-55 kW FUA...; FUC 4 Zyl.**
Knock sensor	01.86-07.90	**0 261 231 006**
1.4 i [86]		**1,4 l 54 kW F6... 4 Zyl.**
Knock sensor	01.87-07.90	**0 261 231 006**
1.6 [86]		**1,6 l 58/65-66 kW LP2; LU... 4 Zyl.**
Knock sensor	01.86-07.90	**0 261 231 006**
1.6 i [86]		**1,6 l 66 kW L4B 4 Zyl.**
Air flow sensor, gasoline injection	01.86-07.90	**F 026 TX2 066**
		F 026 TX2 066
Knock sensor	01.86-07.90	**0 261 231 006**
Temperature sensor, coolant, injection system	01.86-07.90	**0 280 130 050**

Escort SW

1.6 i		**1,6 l 70 kW L1R 4 Zyl.**
Pressure sensor, intake manifold, gasoline	02.00-10.02	**0 261 230 027**

Explorer

4.0 i		**4,0 l 153-157 kW EFI 6 Zyl.**
Knock sensor	09.96-08.98	**0 261 231 119**
	09.98-08.00	**0 261 231 138**

F

250		**3,9 l 149 kW 4 Zyl.**
Pulse generator, diesel	04.06→	**0 281 002 411**
Speed sensor, diesel	04.06→	**0 281 002 410**
Boost pressure sensor, Diesel	04.06→	**0 281 002 316**
Temperature sensor, coolant, diesel	04.06→	**0 281 002 471**

Fairlane

4.0 i [AU]		**4,0 l 168 kW Y 6 Zyl.**
Speed sensor, ignition/injection	02.99-06.00	**0 261 210 168**
Pressure sensor, intake manifold, gasoline	02.99-06.00	**0 261 230 029**
4.0 i [AU II]		**4,0 l 168 kW Y 6 Zyl.**
Speed sensor, ignition/injection	07.00-02.03	**0 261 210 168**
Pressure sensor, intake manifold, gasoline	07.00-02.03	**0 261 230 029**
4.0 i [BA]		**4,0 l 182 kW H 6 Zyl.**
Knock sensor	07.03-02.05	**0 261 231 045**
Pressure sensor, intake manifold, gasoline	07.03-02.05	**0 261 230 027**
		0 261 230 029
4.0 i [NL]		**4,0 l 162 kW X 6 Zyl.**
Wheel speed sensor, front	09.96-02.99	**0 265 006 230**
4.1 i [ZL]		**4,1 l 120 kW T 6 Zyl.**
Air flow sensor, gasoline injection	09.84-05.88	**0 280 202 077**
		0 986 280 023
5.0 i [NL]		**5,0 l 165 kW Z 8 Zyl.**
Wheel speed sensor, front	09.96-02.99	**0 265 006 230**
5.4 i [BA II]		**5,4 l 220 kW Z 8 Zyl.**
Yaw rate sensor, brake system	03.05-09.05	**0 265 005 236**

Falcon

4.1 i [XF]		**4,1 l 120 kW T 6 Zyl.**
Air flow sensor, gasoline injection	09.84-10.87	**0 280 202 077**
		0 986 280 023

Fiesta

1.0 i		**1,0 l 48 kW C4E 4 Zyl.**
Pressure sensor, intake manifold, gasoline	09.99-06.06	**0 261 230 027**
1.3 i		**1,3 l 51 kW JL474QA 4 Zyl.**
Knock sensor	05.03-02.07	**0 261 231 162**
Pressure sensor, intake manifold, gasoline	05.03-02.07	**0 261 230 027**
1.3 i		**1,3 l 55 kW 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.03-12.04	**0 261 230 027**
1.6 i		**1,6 l 68/70 kW ; JL482QA 4 Zyl.**
Knock sensor	03.02→	**0 261 231 162**
Pressure sensor, intake manifold, gasoline	03.00→	**0 261 230 027**
1.6 i		**1,6 l 70 kW L1M 4 Zyl.**
Pressure sensor, intake manifold, gasoline	09.99-04.05	**0 261 230 027**
1.6 i [New]		**1,6 l 72 kW CCJA 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.02→	**0 261 230 027**

Fiesta II

1.4 [84/87]		**1,4 l 51/54/55 kW FUB; FUBA; FUD 4 Zyl.**
Knock sensor	08.83-02.89	**0 261 231 006**
1.4 i [84/87]		**1,4 l 52 kW F6... 4 Zyl.**
Knock sensor	10.86-02.89	**0 261 231 006**
1.6 [84/87]		**1,6 l 58 kW LP3 4 Zyl.**
Knock sensor	08.83-02.89	**0 261 231 006**
1.6 XR2 [84/87]		**1,6 l 70-71 kW LU... 4 Zyl.**
Knock sensor	03.84-02.89	**0 261 231 006**

Fiesta III

1.6 Turbo [89]		**1,6 l 96-98 kW LHA 4 Zyl.**
Temperature sensor, coolant, injection system	07.90-12.96	**0 280 130 049**

F

Product			

Fiesta IV

1.25 i 16V [96]			**1,2 l 55 kW DH... 4 Zyl.**
Pressure sensor, intake manifold, gasoline	08.98-12.99		**0 261 230 027**
1.3 i [96]			**1,3 l 37/44 kW JJ...; J4... 4 Zyl.**
Pressure sensor, intake manifold, gasoline	08.98-12.02		**0 261 230 027**

Fiesta IV Courier

1.3 i [96]			**1,3 l 44 kW J4... 4 Zyl.**
Pressure sensor, intake manifold, gasoline	08.98-12.02		**0 261 230 027**

Fiesta Sedan

1.6 i			**1,6 l 70 kW L1M 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.01-08.04		**0 261 230 027**

Fiesta V

2.0 i ST150 [02]			**2,0 l 110 kW N4JB 4 Zyl.**
Pressure sensor, intake manifold, gasoline	11.04→		**0 261 230 044**

Focus

1.8 i			**1,8 l 91 kW CAF483Q0 4 Zyl.**
Pressure sensor, intake manifold, gasoline	09.05→		**0 261 230 044**

Focus C-MAX

1.6 Ti-VCT			**1,6 l 85 kW HXDA 4 Zyl.**
Phase sensor	07.04-03.07	NOC	**0 232 103 052**
1.8			**1,8 l 88/90-92 kW CSDA; CSDB; Q... 4 Zyl.**
Pressure sensor, intake manifold, gasoline	06.03-03.07		**0 261 230 044**
1.8 FFV			**1,8 l 92 kW Q7DA 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.05-03.07		**0 261 230 044**
1.8 TDCi			**1,8 l 85 kW KKDA 4 Zyl.**
Pressure sensor, intake manifold, diesel	04.05-03.07		**0 261 230 119**
2.0			**2,0 l 107 kW AOD... 4 Zyl.**
Pressure sensor, intake manifold, gasoline	04.04-03.07		**0 261 230 044**
2.0 CNG			**2,0 l 93-107 kW 4 Zyl.**
Pressure sensor, intake manifold, gasoline	11.05-03.07		**0 261 230 044**

Focus II

1.6 Ti-VCT			**1,6 l 85 kW HXDA 4 Zyl.**
Phase sensor	11.04→	NOC	**0 232 103 052**
1.8 FFV			**1,8 l 92 kW Q... 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.05→		**0 261 230 044**
1.8 TDCi			**1,8 l 85 kW KKDA 4 Zyl.**
Pressure sensor, intake manifold, diesel	04.05→		**0 261 230 119**
2.0 i			**2,0 l 107 kW AOD... 4 Zyl.**
Pressure sensor, intake manifold, gasoline	11.04→		**0 261 230 044**
2.5 i ST			**2,5 l 166 kW HYDA 5 Zyl.**
Air mass meter, gasoline injection	10.05→		**0 280 218 134**
Boost pressure sensor, gasoline	10.05→		**0 261 230 090**

Focus II Cabriolet

2.0 i			**2,0 l 107 kW AOD... 4 Zyl.**
Pressure sensor, intake manifold, gasoline	07.06→		**0 261 230 044**

Focus II Turnier

1.6 Ti-VCT			**1,6 l 85 kW HXDA 4 Zyl.**
Phase sensor	11.04→	NOC	**0 232 103 052**
1.8 FFV			**1,8 l 92 kW Q... 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.05→		**0 261 230 044**
1.8 TDCi			**1,8 l 85 kW KKDA 4 Zyl.**
Pressure sensor, intake manifold, diesel	04.05→		**0 261 230 119**
2.0 i			**2,0 l 107 kW AOD... 4 Zyl.**
Pressure sensor, intake manifold, gasoline	11.04→		**0 261 230 044**

Galaxy

1.8 TDCi [06]			**1,8 l 74/92 kW FFWA; QYWA 4 Zyl.**
Pressure sensor, intake manifold, diesel	03.06→		**0 261 230 119**
1.9 TDI [00]			**1,9 l 66/85 kW ANU; AUY 4 Zyl.**
Air mass meter, diesel	04.00-08.06		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
1.9 TDI [00]			**1,9 l 96/110 kW ASZ; BTB 4 Zyl.**
Air mass meter, diesel	01.03-08.06		**0 281 002 461**
			0 986 284 007
1.9 TDI [95]			**1,9 l 66 kW AHU 4 Zyl.**
Air mass meter, diesel	09.97-03.00		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Pedal position sensor, diesel	09.96-08.97		**0 205 001 044**
1.9 TDI [95]			**1,9 l 66 kW ANU 4 Zyl.**
Air mass meter, diesel	09.99-03.00		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
1.9 TDI [95]			**1,9 l 66 kW 1Z 4 Zyl.**
Pedal position sensor, diesel	02.95-09.96		**0 205 001 044**
1.9 TDI [95]			**1,9 l 81 kW AFN; AVG 4 Zyl.**
Air mass meter, diesel	11.97-03.00		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
2.0 [06]			**2,0 l 107 kW AOWA 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.06→		**0 261 230 044**
2.8 i [00]			**2,8 l 150 kW AYL 6 Zyl.**
Phase sensor	04.00-08.06	NOC	**0 232 103 019**
2.8 i [95]			**2,8 l 128 kW AAA; AMY 6 Zyl.**
Air mass meter, gasoline injection	02.95-03.00		**0 280 217 512**
			0 986 280 203
Phase sensor	12.97-03.00		**0 232 103 019**
2.8 i 4x4 [95]			**2,8 l 128 kW AAA; AMY 6 Zyl.**
Air mass meter, gasoline injection	07.96-03.00		**0 280 217 512**
			0 986 280 203
Phase sensor	12.97-03.00		**0 232 103 019**

Granada III

2.0 i [85]			**2,0 l 85 kW NR... 4 Zyl.**
Air flow sensor, gasoline injection	05.85-01.92		**0 280 202 063**
2.4 i [85]			**2,4 l 96 kW ARC 6 Zyl.**
Air flow sensor, gasoline injection	09.86-08.89		**0 280 200 047**
			0 986 280 056
2.4 i [92]			**2,4 l 92 kW ARD 6 Zyl.**
Air flow sensor, gasoline injection	02.92-09.94		**0 280 200 047**
			0 986 280 056
2.8 i [85]			**2,8 l 110 kW PRE 6 Zyl.**
Air flow sensor, gasoline injection	05.85-08.87		**0 280 200 044**

F

Product		
2.8 i 4x4 [85]		**2,8 l 110 kW PRE 6 Zyl.**
Air flow sensor, gasoline injection	08.86-08.87	**0 280 200 047**
		0 986 280 056
Knock sensor	10.85-08.87	**0 261 231 006**
2.9 i [85]		**2,9 l 110 kW BRC 6 Zyl.**
Air flow sensor, gasoline injection	09.86-01.92	**0 280 200 047**
		0 986 280 056
2.9 i [92]		**2,9 l 107 kW BRF 6 Zyl.**
Air flow sensor, gasoline injection	02.92-09.94	**0 280 200 047**
		0 986 280 056
2.9 i 4x4 [92]		**2,9 l 107 kW BR... 6 Zyl.**
Air flow sensor, gasoline injection	02.92-09.94	**0 280 200 047**
		0 986 280 056

Granada III Estate

2.4 i [92]		**2,4 l 92 kW ARD 6 Zyl.**
Air flow sensor, gasoline injection	02.92-09.94	**0 280 200 047**
		0 986 280 056
2.9 i [92]		**2,9 l 107 kW BRF 6 Zyl.**
Air flow sensor, gasoline injection	02.92-09.94	**0 280 200 047**
		0 986 280 056
2.9 i 4x4 [92]		**2,9 l 107 kW BR... 6 Zyl.**
Air flow sensor, gasoline injection	02.92-09.94	**0 280 200 047**
		0 986 280 056

Ka

1.0 i		**1,0 l 48 kW C4C 4 Zyl.**
Pressure sensor, intake manifold, gasoline	08.99-12.07	**0 261 230 027**
1.3 i		**1,3 l 36/37 kW JJB; JJD; JJF; JJG; JJH 4 Zyl.**
Pressure sensor, intake manifold, gasoline	09.00-10.02	**0 261 230 027**
1.3 i		**1,3 l 36/44 kW JJL; J4D; J4K; J4M; J4N 4 Zyl.**
Pressure sensor, intake manifold, gasoline	09.00-10.02	**0 261 230 027**
1.3 i		**1,3 l 44 kW J4P; J4S 4 Zyl.**
Pressure sensor, intake manifold, gasoline	09.00-10.02	**0 261 230 027**
1.3 i		**1,3 l 51 kW 4 Zyl.**
Knock sensor	10.05→	**0 261 231 162**
1.6 i		**1,6 l 70 kW CCA 4 Zyl.**
Pressure sensor, intake manifold, gasoline	02.01-12.07	**0 261 230 027**

LTD

4.1 i [FE]		**4,1 l 120 kW T 6 Zyl.**
Air flow sensor, gasoline injection	09.84-05.88	**0 280 202 077**
		0 986 280 023
5.0 i [DL]		**5,0 l 165 kW Z 8 Zyl.**
Wheel speed sensor, front	09.96-05.99	**0 265 006 230**

Maverick

2.0 i, i 4x4 [01]		**2,0 l 91-95 kW YF 4 Zyl.**
Knock sensor	10.00→	**0 261 231 124**
2.3 i, i 4x4 [01]		**2,3 l 112-116 kW GZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	12.03→	**0 261 230 180**

Merkur

2.9 i		**2,9 l 107 kW 6 Zyl.**
Air flow sensor, gasoline injection	11.86-02.92	**0 280 200 047**
		0 986 280 056

Mondeo

2.0 i		**2,0 l 105 kW J 4 Zyl.**
Pressure sensor, intake manifold, gasoline	02.04→	**0 261 230 068**
Yaw rate sensor, brake system	02.04→	**0 265 005 236**
Wheel speed sensor, front	02.04→	**0 265 007 879**
Wheel speed sensor, rear	02.04→	**0 265 007 879**
2.0 i		**2,0 l 107 kW CJBB Duratec-HE 4 Zyl.**
Pressure sensor, intake manifold, gasoline	08.01→	**0 261 230 044**
2.5 i		**2,5 l 127 kW Duratec-V6 6 Zyl.**
Yaw rate sensor, brake system	06.04→	**0 265 005 236**
Wheel speed sensor, front	06.04→	**0 265 007 879**
Wheel speed sensor, rear	06.04→	**0 265 007 879**

Mondeo III

1.8 i [01]		**1,8 l 81/92 kW CGB...; CGBA; CGBB; CHB... 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.00→	**0 261 230 044**
Duo sensor, acceleration and yaw rate, brake system	10.00-08.04	**0 265 005 236**
	09.04→	**0 265 005 639**
Steering angle sensor, ESP (electronic stability program)	10.00→	**0 265 005 414**
Pressure sensor, ESP, (electronic stability program)	10.00→	**0 265 005 303**
Wheel speed sensor	10.00→	**0 265 007 879**
1.8 i [01]		**1,8 l 96 kW CFBA 4 Zyl.**
Throttle valve assembly	06.03→	**0 280 750 110**
Air mass meter, gasoline injection	06.03→	**0 280 218 104**
Phase sensor	06.03→ NOC	**0 232 103 040**
Knock sensor	06.03→	**0 261 231 160**
Pressure sensor, intake manifold, gasoline	06.03→	**0 261 230 068**
Duo sensor, acceleration and yaw rate, brake system	06.03-08.04	**0 265 005 236**
	09.04→	**0 265 005 639**
Steering angle sensor, ESP (electronic stability program)	06.03→	**0 265 005 414**
Pressure sensor, ESP, (electronic stability program)	06.03→	**0 265 005 303**
Wheel speed sensor	06.03→	**0 265 007 879**
2.0 i [01]		**2,0 l 107 kW CJB... 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.00→	**0 261 230 044**
Duo sensor, acceleration and yaw rate, brake system	10.00-08.04	**0 265 005 236**
	09.04→	**0 265 005 639**
Steering angle sensor, ESP (electronic stability program)	10.00→	**0 265 005 414**
Pressure sensor, ESP, (electronic stability program)	10.00→	**0 265 005 303**
Wheel speed sensor	10.00→	**0 265 007 879**
2.0 TDCi [01]		**2,0 l 66 kW SDBA 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	04.06→	**0 265 005 639**
Steering angle sensor, ESP (electronic stability program)	04.06→	**0 265 005 414**
Pressure sensor, ESP, (electronic stability program)	04.06→	**0 265 005 303**
Wheel speed sensor	04.06→	**0 265 007 879**
2.0 TDCi [01]		**2,0 l 85/96 kW FMBA; HJB...; HJBA; HJBB; HJBC 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.01-08.04	**0 265 005 236**
	09.04→	**0 265 005 639**
Steering angle sensor, ESP (electronic stability program)	10.01→	**0 265 005 414**
Pressure sensor, ESP, (electronic stability program)	10.01→	**0 265 005 303**
Wheel speed sensor	10.01→	**0 265 007 879**
2.0 TDCi [01]		**2,0 l 96 kW N7B... 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.01-08.04	**0 265 005 236**
	09.04→	**0 265 005 639**
Steering angle sensor, ESP (electronic stability program)	10.01→	**0 265 005 414**

F

Product

◀ Mondeo III

Pressure sensor, ESP, (electronic stability program)	10.01→		**0 265 005 303**
Wheel speed sensor	10.01→		**0 265 007 879**
2.0 TDDi [01]			**2,0 l 66 kW D5BA 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.00-08.04		**0 265 005 236**
	09.04→		**0 265 005 639**
Steering angle sensor, ESP (electronic stability program)	10.00→		**0 265 005 414**
Pressure sensor, ESP, (electronic stability program)	10.00→		**0 265 005 303**
Wheel speed sensor	10.00→		**0 265 007 879**
2.0 TDDi [01]			**2,0 l 85 kW D6BA 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.00-08.02		**0 265 005 236**
Steering angle sensor, ESP (electronic stability program)	10.00-08.02		**0 265 005 414**
Pressure sensor, ESP, (electronic stability program)	10.00-08.02		**0 265 005 303**
Wheel speed sensor	10.00-08.02		**0 265 007 879**
2.2 TDCi [01]			**2,2 l 114 kW QJB... 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	08.04-08.04		**0 265 005 236**
	09.04→		**0 265 005 639**
Steering angle sensor, ESP (electronic stability program)	08.04→		**0 265 005 414**
Pressure sensor, ESP, (electronic stability program)	08.04→		**0 265 005 303**
Wheel speed sensor	08.04→		**0 265 007 879**
2.5 i [01]			**2,5 l 125 kW LCBD 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.00-08.04		**0 265 005 236**
	09.04→		**0 265 005 639**
Steering angle sensor, ESP (electronic stability program)	10.00→		**0 265 005 414**
Pressure sensor, ESP, (electronic stability program)	10.00→		**0 265 005 303**
Wheel speed sensor	10.00→		**0 265 007 879**
3.0 i [01]			**3,0 l 150 kW REBA 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	08.04-08.04		**0 265 005 236**
	09.04→		**0 265 005 639**
Pressure sensor, ESP, (electronic stability program)	08.04→		**0 265 005 303**
Wheel speed sensor	08.04→		**0 265 007 879**
3.0 i ST220 [01]			**3,0 l 166 kW MEBA 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	02.02-08.04		**0 265 005 236**
	09.04→		**0 265 005 639**
Steering angle sensor, ESP (electronic stability program)	02.02→		**0 265 005 414**
Pressure sensor, ESP, (electronic stability program)	02.02→		**0 265 005 303**
Wheel speed sensor	02.02→		**0 265 007 879**

Mondeo III Turnier

1.8 i [01]			**1,8 l 81/92 kW CGBA; CGBB; CHBA; CHBB 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.00→		**0 261 230 044**
Duo sensor, acceleration and yaw rate, brake system	10.00-08.04		**0 265 005 236**
	09.04→		**0 265 005 639**
Steering angle sensor, ESP (electronic stability program)	10.00→		**0 265 005 414**
Pressure sensor, ESP, (electronic stability program)	10.00→		**0 265 005 303**
Wheel speed sensor	10.00→		**0 265 007 879**
1.8 i [01]			**1,8 l 96 kW CFBA 4 Zyl.**
Throttle valve assembly	06.03→		**0 280 750 110**
Air mass meter, gasoline injection	06.03→		**0 280 218 104**
Phase sensor	06.03→	NOC	**0 232 103 040**
Knock sensor	06.03→		**0 261 231 160**
Pressure sensor, intake manifold, gasoline	06.03→		**0 261 230 068**
Duo sensor, acceleration and yaw rate, brake system	06.03-08.04		**0 265 005 236**
	09.04→		**0 265 005 639**
Steering angle sensor, ESP (electronic stability program)	06.03→		**0 265 005 414**

Product

Pressure sensor, ESP, (electronic stability program)	06.03→		**0 265 005 303**
Wheel speed sensor	06.03→		**0 265 007 879**
2.0 i [01]			**2,0 l 107 kW CJBA; CJBB 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.00→		**0 261 230 044**
Duo sensor, acceleration and yaw rate, brake system	10.00-08.04		**0 265 005 236**
	09.04→		**0 265 005 639**
Steering angle sensor, ESP (electronic stability program)	10.00→		**0 265 005 414**
Pressure sensor, ESP, (electronic stability program)	10.00→		**0 265 005 303**
Wheel speed sensor	10.00→		**0 265 007 879**
2.0 TDCi [01]			**2,0 l 66 kW SDBA 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 639**
Steering angle sensor, ESP (electronic stability program)	04.06→		**0 265 005 414**
Pressure sensor, ESP, (electronic stability program)	04.06→		**0 265 005 303**
Wheel speed sensor	04.06→		**0 265 007 879**
2.0 TDCi [01]			**2,0 l 85/96 kW FMBA; HJBA; HJBB; HJBC; N7B... 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.01-08.04		**0 265 005 236**
	09.04→		**0 265 005 639**
Steering angle sensor, ESP (electronic stability program)	10.01→		**0 265 005 414**
Pressure sensor, ESP, (electronic stability program)	10.01→		**0 265 005 303**
Wheel speed sensor	10.01→		**0 265 007 879**
2.0 TDDi [01]			**2,0 l 66 kW D5BA 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.00-08.04		**0 265 005 236**
	09.04→		**0 265 005 639**
Steering angle sensor, ESP (electronic stability program)	10.00→		**0 265 005 414**
Pressure sensor, ESP, (electronic stability program)	10.00→		**0 265 005 303**
Wheel speed sensor	10.00→		**0 265 007 879**
2.0 TDDi [01]			**2,0 l 85 kW D6BA 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.00-08.02		**0 265 005 236**
Steering angle sensor, ESP (electronic stability program)	10.00-08.02		**0 265 005 414**
Pressure sensor, ESP, (electronic stability program)	10.00-08.02		**0 265 005 303**
Wheel speed sensor	10.00-08.02		**0 265 007 879**
2.2 TDCi [01]			**2,2 l 114 kW QJB... 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	08.04-08.04		**0 265 005 236**
	09.04→		**0 265 005 639**
Steering angle sensor, ESP (electronic stability program)	08.04→		**0 265 005 414**
Pressure sensor, ESP, (electronic stability program)	08.04→		**0 265 005 303**
Wheel speed sensor	08.04→		**0 265 007 879**
2.5 i [01]			**2,5 l 125 kW LCBD 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.00-08.04		**0 265 005 236**
	09.04→		**0 265 005 639**
Steering angle sensor, ESP (electronic stability program)	10.00→		**0 265 005 414**
Pressure sensor, ESP, (electronic stability program)	10.00→		**0 265 005 303**
Wheel speed sensor	10.00→		**0 265 007 879**
3.0 i [01]			**3,0 l 150 kW REBA 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	08.04-08.04		**0 265 005 236**
	09.04→		**0 265 005 639**
Pressure sensor, ESP, (electronic stability program)	08.04→		**0 265 005 303**
Wheel speed sensor	08.04→		**0 265 007 879**
3.0 i ST220 [01]			**3,0 l 166 kW MEBA 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	02.02-08.04		**0 265 005 236**
	09.04→		**0 265 005 639**
Steering angle sensor, ESP (electronic stability program)	02.02→		**0 265 005 414**

F

Product			
Pressure sensor, ESP, (electronic stability program)	02.02→		**0 265 005 303**
Wheel speed sensor	02.02→		**0 265 007 879**

Mondeo IV

1.6 Ti-VCT [07]			**1,6 l 81/92 kW 4 Zyl.**
Phase sensor	02.07→	NOC	**0 232 103 052**
1.8 TDCi [07]			**1,8 l 74 kW 4 Zyl.**
Pressure sensor, intake manifold, diesel	02.07→		**0 261 230 119**
2.0 [07]			**2,0 l 107 kW 4 Zyl.**
Pressure sensor, intake manifold, gasoline	02.07→		**0 261 230 044**
2.5 [07]			**2,5 l 162 kW 5 Zyl.**
Air mass meter, gasoline injection	02.07→		**0 280 218 134**
Temperature sensor, intake air, injection system	02.07→		**0 261 230 105**

Mondeo IV Turnier

1.6 Ti-VCT [07]			**1,6 l 81/92 kW 4 Zyl.**
Phase sensor	02.07→	NOC	**0 232 103 052**
1.8 TDCi [07]			**1,8 l 74 kW 4 Zyl.**
Pressure sensor, intake manifold, diesel	02.07→		**0 261 230 119**
2.0 [07]			**2,0 l 107 kW 4 Zyl.**
Pressure sensor, intake manifold, gasoline	02.07→		**0 261 230 044**
2.5 [07]			**2,5 l 162 kW 5 Zyl.**
Air mass meter, gasoline injection	02.07→		**0 280 218 134**
Temperature sensor, intake air, injection system	02.07→		**0 261 230 105**

Orion II

1.4 i [86]			**1,4 l 54 kW F6... 4 Zyl.**
Knock sensor	10.87-07.90		**0 261 231 006**
1.6 i [86]			**1,6 l 66 kW L4B 4 Zyl.**
Air flow sensor, gasoline injection	04.86-07.90		**F 026 TX2 066**
			F 026 TX2 066
Knock sensor	04.86-07.90		**0 261 231 006**
Temperature sensor, coolant, injection system	04.86-07.90		**0 280 130 050**
1.6 i [86]			**1,6 l 75 kW LJB 4 Zyl.**
Knock sensor	08.89-07.90		**0 261 231 006**
1.6 i [86]			**1,6 l 77 kW LRB 4 Zyl.**
Air flow sensor, gasoline injection	04.86-07.90		**0 438 120 199**
Knock sensor	04.86-07.90		**0 261 231 006**
Relay, Jetronic	04.86-07.90		**0 280 230 116**
1.6 i [86]			**1,6 l 79 kW LJA 4 Zyl.**
Knock sensor	08.89-07.90		**0 261 231 006**

Scorpio I

1.8 [85]			**1,8 l 66 kW REC 4 Zyl.**
Speed relay	09.87-01.92		**0 280 230 117**
Relay, Jetronic	02.88-01.92		**0 280 230 117**
2.0 i [85]			**2,0 l 74 kW NRC 4 Zyl.**
Air flow sensor, gasoline injection	10.85-12.90		**0 280 202 063**
	CH,S 10.85-12.90		**0 280 202 094**
Knock sensor	10.85-12.90		**0 261 231 006**
2.0 i [85]			**2,0 l 85 kW NRA 4 Zyl.**
Air flow sensor, gasoline injection	05.85-01.92		**0 280 202 063**
	CH,S 05.85-01.92		**0 280 202 094**
2.0 i [85]			**2,0 l 85 kW NRI 4 Zyl.**
Air flow sensor, gasoline injection	10.85-01.92		**0 280 202 063**
	CH,S 10.85-01.92		**0 280 202 094**
Knock sensor	10.85-01.92		**0 261 231 006**

2.4 i [85]			**2,4 l 92/96 kW ARC; ARD 6 Zyl.**
Air flow sensor, gasoline injection	09.86-01.92	ZE	**0 280 200 047**
			0 986 280 056
2.4 i [92]			**2,4 l 92 kW ARD 6 Zyl.**
Air flow sensor, gasoline injection	02.92-09.94		**0 280 200 047**
			0 986 280 056
2.8 i [85]			**2,8 l 105-107 kW PR... 6 Zyl.**
Air flow sensor, gasoline injection	10.85-12.88		**0 280 200 047**
			0 986 280 056
2.8 i [85]			**2,8 l 110 kW PRE 6 Zyl.**
Air flow sensor, gasoline injection	05.85-11.86		**0 280 200 044**
2.8 i 4x4 [85]			**2,8 l 105-107 kW PR... 6 Zyl.**
Air flow sensor, gasoline injection	10.85-12.88		**0 280 200 047**
			0 986 280 056
2.8 i 4x4 [85]			**2,8 l 110 kW PRE 6 Zyl.**
Air flow sensor, gasoline injection	10.85-11.86		**0 280 200 044**
2.9 i [85]			**2,9 l 107/110 kW BR...; BRC 6 Zyl.**
Air flow sensor, gasoline injection	09.86-01.92	ZE	**0 280 200 047**
			0 986 280 056
2.9 i [92]			**2,9 l 107 kW BRF 6 Zyl.**
Air flow sensor, gasoline injection	02.92-09.94		**0 280 200 047**
			0 986 280 056
2.9 i 4x4 [85]			**2,9 l 107/110 kW BRC; BRE 6 Zyl.**
Air flow sensor, gasoline injection	09.86-01.92	ZE	**0 280 200 047**
			0 986 280 056
2.9 i 4x4 [92]			**2,9 l 107 kW BRF 6 Zyl.**
Air flow sensor, gasoline injection	02.92-09.94		**0 280 200 047**
			0 986 280 056

Scorpio I Turnier

2.4 i [92]			**2,4 l 92 kW ARD 6 Zyl.**
Air flow sensor, gasoline injection	02.92-09.94		**0 280 200 047**
			0 986 280 056
2.9 i [92]			**2,9 l 107 kW BRF 6 Zyl.**
Air flow sensor, gasoline injection	02.92-09.94		**0 280 200 047**
			0 986 280 056

Scorpio II

2.5 TD [95]			**2,5 l 85 kW SCC 4 Zyl.**
Speed sensor, diesel	01.95-12.98		**0 281 002 096**
2.9 i [95]			**2,9 l 110 kW BRG 6 Zyl.**
Air flow sensor, gasoline injection	10.94-08.96		**0 280 200 047**
			0 986 280 056

Scorpio II Turnier

2.5 TD [95]			**2,5 l 85 kW SCC 4 Zyl.**
Speed sensor, diesel	01.95-12.98		**0 281 002 096**
2.9 i [95]			**2,9 l 110 kW BRG 6 Zyl.**
Air flow sensor, gasoline injection	10.94-08.96		**0 280 200 047**
			0 986 280 056

Sierra

1.6 [87]			**1,6 l 53/55 kW LSE; LSF 4 Zyl.**
Speed relay	01.87-02.93		**0 280 230 118**
1.8 [87]			**1,8 l 59-66 kW RE... 4 Zyl.**
Speed relay	10.87-05.88		**0 280 230 117**
Relay, Jetronic	02.88-05.88		**0 280 230 117**

F

Product			
◀ Sierra			
2.0 i [82]			**2,0 l 74 kW NRD 4 Zyl.**
Air flow sensor, gasoline injection	CH,S	10.85-12.86	**0 280 202 094**
	~~CH,S~~	10.85-12.86	**0 280 202 063**
Knock sensor		10.85-12.86	**0 261 231 006**
2.0 i [82]			**2,0 l 85 kW NRB 4 Zyl.**
Air flow sensor, gasoline injection	CH,S	03.85-12.86	**0 280 202 094**
	~~CH,S~~	03.85-12.86	**0 280 202 063**
2.0 i [82]			**2,0 l 85 kW NR2 4 Zyl.**
Air flow sensor, gasoline injection	CH,S	10.85-12.86	**0 280 202 094**
	~~CH,S~~	10.85-12.86	**0 280 202 063**
Knock sensor		10.85-12.86	**0 261 231 001**
2.0 i [87]			**2,0 l 74 kW N4B 4 Zyl.**
Air flow sensor, gasoline injection		01.87-02.93	**0 280 202 063**
	S	01.87-05.92	**0 280 202 094**
Knock sensor		01.87-02.93	**0 261 231 001**
2.0 i [87]			**2,0 l 85 kW N4A; N4I 4 Zyl.**
Air flow sensor, gasoline injection		01.87-02.93	**0 280 202 063**
	S	01.87-05.92	**0 280 202 094**
2.8 i [87]			**2,8 l 105 kW PR8 6 Zyl.**
Air flow sensor, gasoline injection	CH,S	01.87-12.88	**0 280 200 047**
			0 986 280 056
	~~CH,S~~	01.87-12.88	**0 280 200 044**
2.8 i XR 4x4 [87]			**2,8 l 105-107 kW PR... 6 Zyl.**
Air flow sensor, gasoline injection	CH,S	01.87-12.88	**0 280 200 047**
			0 986 280 056
	~~CH,S~~	01.87-12.88	**0 280 200 044**
2.8 i XR 4x4 [87]			**2,8 l 110 kW PRG 6 Zyl.**
Air flow sensor, gasoline injection		01.87-12.88	**0 438 120 069**
Relay, Jetronic		01.87-12.88	**0 280 230 109**
2.8 i XR4, i XR4 4x4 [82]			**2,8 l 105-107/109-111 kW PR, PRI; PR5, PR6 6 Zyl.**
Air flow sensor, gasoline injection	CH,S	08.82-12.86	**0 280 200 047**
			0 986 280 056
	~~CH,S~~	08.82-12.86	**0 280 200 044**
2.8 i XR4 4x4 [82]			**2,8 l 110 kW PRT 6 Zyl.**
Air flow sensor, gasoline injection		02.85-12.86	**0 438 120 069**
Relay, Jetronic		02.85-12.86	**0 280 230 109**
2.9 i [87]			**2,9 l 107 kW B4... 6 Zyl.**
Air flow sensor, gasoline injection		08.88-02.93	**0 280 200 047**
			0 986 280 056
2.9 i XR 4x4 [87]			**2,9 l 107/110 kW B4...; B4A 6 Zyl.**
Air flow sensor, gasoline injection		08.88-02.93	**0 280 200 047**
			0 986 280 056

Sierra Turnier

1.6 [87]			**1,6 l 53/55 kW LSE; LSF 4 Zyl.**
Speed relay		01.87-02.93	**0 280 230 118**
1.8 [87]			**1,8 l 59 kW REF 4 Zyl.**
Speed relay		10.87-05.88	**0 280 230 117**
2.0 i [82]			**2,0 l 74/85 kW NRB; NRD 4 Zyl.**
Air flow sensor, gasoline injection	CH,S	03.85-12.86	**0 280 202 094**
	~~CH,S~~	03.85-12.86	**0 280 202 063**
2.0 i [82]			**2,0 l 85 kW NR2 4 Zyl.**
Air flow sensor, gasoline injection	CH,S	10.85-12.86	**0 280 202 094**
	~~CH,S~~	10.85-12.86	**0 280 202 063**
Knock sensor		10.85-12.86	**0 261 231 001**
2.0 i [87]			**2,0 l 74 kW N4B 4 Zyl.**
Air flow sensor, gasoline injection		01.87-02.93	**0 280 202 063**
	S	01.87-02.92	**0 280 202 094**
Knock sensor		01.87-02.93	**0 261 231 001**
2.0 i [87]			**2,0 l 85 kW N4A; N4I 4 Zyl.**
Air flow sensor, gasoline injection		01.87-02.93	**0 280 202 063**
	S	01.87-02.92	**0 280 202 094**

Product			
2.8 i XR4 [82]			**2,8 l 105-107/109-111 kW PR, PRI; PR5, PR6 6 Zyl.**
Air flow sensor, gasoline injection	CH,S	08.82-12.86	**0 280 200 047**
			0 986 280 056
	~~CH,S~~	08.82-12.86	**0 280 200 044**
2.8 i XR4 4x4 [82]			**2,8 l 110 kW PRT 6 Zyl.**
Air flow sensor, gasoline injection		03.85-12.86	**0 438 120 069**
Relay, Jetronic		03.85-12.86	**0 280 230 109**
2.8 i 4x4 [87]			**2,8 l 105-107 kW PR7 6 Zyl.**
Air flow sensor, gasoline injection	CH,S	01.87-12.88	**0 280 200 047**
			0 986 280 056
	~~CH,S~~	01.87-12.88	**0 280 200 044**
2.8 i 4x4 [87]			**2,8 l 110 kW PRG 6 Zyl.**
Air flow sensor, gasoline injection		01.87-12.88	**0 438 120 069**
Relay, Jetronic		01.87-12.88	**0 280 230 109**
2.9 i [87]			**2,9 l 107 kW B4... 6 Zyl.**
Air flow sensor, gasoline injection		08.88-02.93	**0 280 200 047**
			0 986 280 056
2.9 i 4x4 [87]			**2,9 l 107/110 kW B4...; B4A 6 Zyl.**
Air flow sensor, gasoline injection		08.88-02.93	**0 280 200 047**
			0 986 280 056

S-MAX

1.8 TDCi			**1,8 l 92 kW QYWA 4 Zyl.**
Pressure sensor, intake manifold, diesel		03.06→	**0 261 230 119**
2.0			**2,0 l 107 kW AOWA 4 Zyl.**
Pressure sensor, intake manifold, gasoline		03.06→	**0 261 230 044**
2.5			**2,5 l 162 kW HUWA 5 Zyl.**
Air mass meter, gasoline injection		03.06→	**0 280 218 134**
Temperature sensor, intake air, injection system		03.06→	**0 261 230 105**

Transit

FT 240 K/S 2.0 TD [F__]			**2,0 l 55 kW D3FA 4 Zyl.**
Wheel speed sensor, front		08.00-07.06	TW **0 265 006 458**
		07.03-07.06	TW **0 265 006 784**
Wheel speed sensor, rear		08.00-05.04	LAB,TW **0 265 006 542**
		07.03-07.06	LAB,TW **0 265 006 784**
		05.04-07.06	LAB,TW **0 265 006 816**
		08.00-05.04	LAB,TW **0 265 006 818**
		11.03-05.04	RAB,TW **0 265 006 460**
		05.04-07.06	RAB,TW **0 265 006 811**
		08.00-07.06	RAB,TW **0 265 006 815**
			0 265 006 817
FT 240 K/S 2.0 TDE [F__]			**2,0 l 63 kW F3FA 4 Zyl.**
Wheel speed sensor, front		08.00-07.06	TW **0 265 006 458**
		07.03-07.06	TW **0 265 006 784**
Wheel speed sensor, rear		08.00-05.04	LAB,TW **0 265 006 542**
		07.03-07.06	LAB,TW **0 265 006 784**
		05.04-07.06	LAB,TW **0 265 006 816**
		08.00-05.04	LAB,TW **0 265 006 818**
		11.03-05.04	RAB,TW **0 265 006 460**
		05.04-07.06	RAB,TW **0 265 006 811**
		08.00-07.06	RAB,TW **0 265 006 815**
			0 265 006 817
FT 260 K/S 2.0 TD [F__]			**2,0 l 55 kW D3FA 4 Zyl.**
Wheel speed sensor, front		08.00-07.06	TW **0 265 006 458**
		07.03-07.06	TW **0 265 006 784**
Wheel speed sensor, rear		08.00-05.04	LAB,TW **0 265 006 542**
		07.03-07.06	LAB,TW **0 265 006 784**
		05.04-07.06	LAB,TW **0 265 006 816**
		08.00-05.04	LAB,TW **0 265 006 818**
		11.03-05.04	RAB,TW **0 265 006 460**

F

Product			
Wheel speed sensor, rear	05.04-07.06	RAB,TW	**0 265 006 811**
	08.00-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 260 K/S 2.0 TDCi [F__]		**2,0 l 92 kW F1FA 4 Zyl.**	
Wheel speed sensor, front	05.02-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	05.02-05.04	LAB,TW	**0 265 006 542**
	07.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	05.02-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	05.02-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 260 K/S 2.0 TDE [F__]		**2,0 l 63/74 kW ABFA; F3FA 4 Zyl.**	
Wheel speed sensor, front	08.00-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	08.00-05.04	LAB,TW	**0 265 006 542**
	07.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	08.00-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	08.00-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 260 K/S 2.3i [F__]		**2,3 l 103-107 kW E5FC 4 Zyl.**	
Wheel speed sensor, front	08.01-07.06		**0 265 006 458**
Wheel speed sensor, rear	08.01-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	08.01-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	08.01-07.06	RAB,TW	**0 265 006 813**
FT 260 K/S 2.4 TDE [F__]		**2,4 l 66 kW D2F... 4 Zyl.**	
Wheel speed sensor, front	04.01-07.06		**0 265 006 458**
Wheel speed sensor, rear	04.01-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	04.01-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	04.01-07.06	RAB,TW	**0 265 006 813**
FT 280 K/S 2.0 TD [F__]		**2,0 l 55 kW D3FA 4 Zyl.**	
Wheel speed sensor, front	08.00-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	08.00-05.04	LAB,TW	**0 265 006 542**
	07.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	08.00-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	08.00-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 280 K/S 2.0 TDCi [F__]		**2,0 l 92 kW FIFA 4 Zyl.**	
Wheel speed sensor, front	05.02-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	05.02-05.04	LAB,TW	**0 265 006 542**
	07.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	05.02-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	05.02-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817

Product			
FT 280 K/S 2.0 TDE [F__]		**2,0 l 63/74 kW ABFA; F3FA 4 Zyl.**	
Wheel speed sensor, front	08.00-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	08.00-05.04	LAB,TW	**0 265 006 542**
	07.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	08.00-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	08.00-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 280 K/S 2.3i [F__]		**2,3 l 103-107 kW E5FC 4 Zyl.**	
Wheel speed sensor, front	08.01-07.06		**0 265 006 458**
Wheel speed sensor, rear	08.01-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	08.01-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	08.01-07.06	RAB,TW	**0 265 006 813**
FT 280 K/S 2.4 TDE [F__]		**2,4 l 66 kW D2F... 4 Zyl.**	
Wheel speed sensor, front	04.01-07.06		**0 265 006 458**
Wheel speed sensor, rear	04.01-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	04.01-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	04.01-07.06	RAB,TW	**0 265 006 813**
FT 280 L 2.3i [F__]		**2,3 l 103-107 kW E5FC 4 Zyl.**	
Wheel speed sensor, front	08.01-07.06		**0 265 006 458**
Wheel speed sensor, rear	08.01-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	08.01-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	08.01-07.06	RAB,TW	**0 265 006 813**
FT 280 L 2.4 TDE [F__]		**2,4 l 55 kW F4FA 4 Zyl.**	
Wheel speed sensor, front	01.00-09.03		**0 265 006 458**
Wheel speed sensor, rear	01.00-09.03	LAB,TW	**0 265 006 461**
	12.02-09.03	LAB,TW	**0 265 006 812**
	01.00-09.03	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
			0 265 006 813
FT 280 L 2.4 TDE [F__]		**2,4 l 66/85/92 kW DOFA; D2F...; FXFA 4 Zyl.**	
Wheel speed sensor, front	01.00-07.06		**0 265 006 458**
Wheel speed sensor, rear	01.00-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	01.00-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	01.00-07.06	RAB,TW	**0 265 006 813**
FT 280 M 2.0 TD [F__]		**2,0 l 55 kW D3FA 4 Zyl.**	
Wheel speed sensor, front	08.00-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	08.00-05.04	LAB,TW	**0 265 006 542**
	07.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	08.00-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	08.00-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817

F

Product			
◀ Transit			
FT 280 M 2.0 TDCi [F__]			**2,0 l 92 kW FIFA 4 Zyl.**
Wheel speed sensor, front	05.02-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	05.02-05.04	LAB,TW	**0 265 006 542**
	07.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	05.02-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	05.02-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 280 M 2.0 TDE [F__]			**2,0 l 63/74 kW ABFA; F3FA 4 Zyl.**
Wheel speed sensor, front	08.00-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	08.00-05.04	LAB,TW	**0 265 006 542**
	07.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	08.00-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	08.00-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 280 M 2.3i [F__]			**2,3 l 103-107 kW E5FC 4 Zyl.**
Wheel speed sensor, front	08.01-07.06		**0 265 006 458**
Wheel speed sensor, rear	08.01-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	08.01-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	08.01-07.06	RAB,TW	**0 265 006 813**
FT 280 M 2.4 TDE [F__]			**2,4 l 66 kW D2F... 4 Zyl.**
Wheel speed sensor, front	04.01-07.06		**0 265 006 458**
Wheel speed sensor, rear	04.01-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	04.01-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	04.01-07.06	RAB,TW	**0 265 006 813**
FT 280 S 2.4 TDI			**2,4 l 66 kW 4 Zyl.**
Wheel speed sensor, front	01.01-05.06		**0 265 006 458**
Wheel speed sensor, rear	01.01-09.03	LAB,OZB	**0 265 006 461**
	10.03-05.06	LAB,OZB	**0 265 006 812**
	01.01-05.06	LAB,ZWB	**0 265 006 814**
	01.01-09.03	OZB,RAB	**0 265 006 460**
	10.03-05.06	OZB,RAB	**0 265 006 811**
	01.01-05.06	RAB,ZWB	**0 265 006 813**
FT 300 K/S 2.0 TD [F__]			**2,0 l 55 kW D3FA 4 Zyl.**
Wheel speed sensor, front	08.00-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	08.00-05.04	LAB,TW	**0 265 006 542**
	07.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	08.00-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	08.00-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817

Product			
FT 300 K/S 2.0 TDCi [F__]			**2,0 l 92 kW FIFA 4 Zyl.**
Wheel speed sensor, front	05.02-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	05.02-05.04	LAB,TW	**0 265 006 542**
	07.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	05.02-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	05.02-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 300 K/S 2.0 TDE [F__]			**2,0 l 63/74 kW ABFA; F3FA 4 Zyl.**
Wheel speed sensor, front	08.00-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	08.00-05.04	LAB,TW	**0 265 006 542**
	07.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	08.00-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	08.00-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 300 K/S 2.3i [F__]			**2,3 l 107 kW E5FA 4 Zyl.**
Wheel speed sensor, front	08.00-07.06		**0 265 006 458**
Wheel speed sensor, rear	08.00-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	08.00-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	08.00-07.06	RAB,TW	**0 265 006 813**
FT 300 L 2.0 TD [F__]			**2,0 l 55 kW D3FA 4 Zyl.**
Wheel speed sensor, front	08.00-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	08.00-05.04	LAB,TW	**0 265 006 542**
	07.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	08.00-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	08.00-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 300 L 2.0 TDCi [F__]			**2,0 l 92 kW FIFA 4 Zyl.**
Wheel speed sensor, front	05.02-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	05.02-05.04	LAB,TW	**0 265 006 542**
	07.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	05.02-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	05.02-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 300 L 2.0 TDE [F__]			**2,0 l 63/74 kW ABFA; F3FA 4 Zyl.**
Wheel speed sensor, front	08.00-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	08.00-05.04	LAB,TW	**0 265 006 542**
	07.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	08.00-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	08.00-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817

F

Product			
FT 300 L 2.3i [F___]			**2,3 l 107 kW E5FA 4 Zyl.**
Wheel speed sensor, front	08.00-07.06		**0 265 006 458**
Wheel speed sensor, rear	08.00-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	08.00-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	08.00-07.06	RAB,TW	**0 265 006 813**
FT 300 M 2.0 TD [F___]			**2,0 l 55 kW D3FA 4 Zyl.**
Wheel speed sensor, front	08.00-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	08.00-05.04	LAB,TW	**0 265 006 542**
	07.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	08.00-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	08.00-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 300 M 2.0 TDCi [F___]			**2,0 l 92 kW FIFA 4 Zyl.**
Wheel speed sensor, front	05.02-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	05.02-05.04	LAB,TW	**0 265 006 542**
	07.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	05.02-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	05.02-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 300 M 2.0 TDE [F___]			**2,0 l 63/74 kW ABFA; F3FA 4 Zyl.**
Wheel speed sensor, front	08.00-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	08.00-05.04	LAB,TW	**0 265 006 542**
	07.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	08.00-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	08.00-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 300 M 2.3i [F___]			**2,3 l 107 kW E5FA 4 Zyl.**
Wheel speed sensor, front	08.00-07.06		**0 265 006 458**
Wheel speed sensor, rear	08.00-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	08.00-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	08.00-07.06	RAB,TW	**0 265 006 813**
FT 300 S 2.0 TDCi			**2,0 l 92 kW FIFA 4 Zyl.**
Wheel speed sensor, front	05.02-05.06	TW	**0 265 006 458**
			0 265 006 784
Wheel speed sensor, rear	05.02-05.04	LAB,TW	**0 265 006 542**
	07.03-05.06	LAB,TW	**0 265 006 784**
	05.04-05.06	LAB,TW	**0 265 006 816**
	05.02-05.04	LAB,TW	**0 265 006 818**
	05.02-05.06	RAB,TW	**0 265 006 815**
			0 265 006 817

Product			
FT 300 S 2.4 TDI			**2,4 l 66/74 kW 4 Zyl.**
Wheel speed sensor, front	01.01-05.06		**0 265 006 458**
Wheel speed sensor, rear	01.01-09.03	LAB,OZB	**0 265 006 461**
	10.03-05.06	LAB,OZB	**0 265 006 812**
	01.01-05.06	LAB,ZWB	**0 265 006 814**
	01.01-09.03	OZB,RAB	**0 265 006 460**
	10.03-05.06	OZB,RAB	**0 265 006 811**
	01.01-05.06	RAB,ZWB	**0 265 006 813**
FT 310 S 2.4 TDI			**2,4 l 88 kW 4 Zyl.**
Wheel speed sensor, front	01.01-05.06		**0 265 006 458**
Wheel speed sensor, rear	01.01-09.03	LAB,OZB	**0 265 006 461**
	10.03-05.06	LAB,OZB	**0 265 006 812**
	01.01-05.06	LAB,ZWB	**0 265 006 814**
	01.01-09.03	OZB,RAB	**0 265 006 460**
	10.03-05.06	OZB,RAB	**0 265 006 811**
	01.01-05.06	RAB,ZWB	**0 265 006 813**
FT 330 K/S 2.0 TDCi [F___]			**2,0 l 92 kW FIFA 4 Zyl.**
Wheel speed sensor, front	05.02-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	05.02-05.04	LAB,TW	**0 265 006 542**
	07.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	05.02-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	05.02-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 330 K/S 2.0 TDE [F___]			**2,0 l 74 kW ABFA 4 Zyl.**
Wheel speed sensor, front	08.03-07.06	TW	**0 265 006 458**
			0 265 006 784
Wheel speed sensor, rear	08.03-05.04	LAB,TW	**0 265 006 542**
	08.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	08.03-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	08.03-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 330 K/S 2.3i [F___]			**2,3 l 103-107 kW E5FA; E5FC 4 Zyl.**
Wheel speed sensor, front	12.00-07.06		**0 265 006 458**
Wheel speed sensor, rear	12.00-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	12.00-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	12.00-07.06	RAB,TW	**0 265 006 813**
FT 330 K/S 2.4 TD [F___]			**2,4 l 55 kW F4FA 4 Zyl.**
Wheel speed sensor, front	01.00-09.03		**0 265 006 458**
Wheel speed sensor, rear	01.00-09.03	LAB,TW	**0 265 006 461**
	12.02-09.03	LAB,TW	**0 265 006 812**
	01.00-09.03	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
			0 265 006 813
FT 330 K/S 2.4 TDCi [F___]			**2,4 l 101 kW H9FA 4 Zyl.**
Wheel speed sensor, front	03.04-07.06		**0 265 006 458**
Wheel speed sensor, rear	03.04-07.06	LAB,TW	**0 265 006 461**
			0 265 006 812
			0 265 006 814
		RAB,TW	**0 265 006 460**
			0 265 006 811
			0 265 006 813

F

Product			
◀ Transit			
FT 330 K/S 2.4 TDE [F__]	**2,4 l 66/85/88/92 kW DOFA; D2F...; D4FA; FXFA 4 Zyl.**		
Wheel speed sensor, front	01.00-07.06		**0 265 006 458**
Wheel speed sensor, rear	01.00-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	01.00-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	01.00-07.06	RAB,TW	**0 265 006 813**
FT 330 L 2.0 TDCi [F__]	**2,0 l 92 kW FIFA 4 Zyl.**		
Wheel speed sensor, front	05.02-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	05.02-05.04	LAB,TW	**0 265 006 542**
	07.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	05.02-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	05.02-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 330 L 2.0 TDE [F__]	**2,0 l 74 kW ABFA 4 Zyl.**		
Wheel speed sensor, front	08.03-07.06	TW	**0 265 006 458**
			0 265 006 784
Wheel speed sensor, rear	08.03-05.04	LAB,TW	**0 265 006 542**
	08.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	08.03-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	08.03-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 330 L 2.3i [F__]	**2,3 l 103-107 kW E5FA; E5FC 4 Zyl.**		
Wheel speed sensor, front	12.00-07.06		**0 265 006 458**
Wheel speed sensor, rear	12.00-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	12.00-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	12.00-07.06	RAB,TW	**0 265 006 813**
FT 330 L 2.4 TD [F__]	**2,4 l 55 kW F4FA 4 Zyl.**		
Wheel speed sensor, front	01.00-09.03		**0 265 006 458**
Wheel speed sensor, rear	01.00-09.03	LAB,TW	**0 265 006 461**
	12.02-09.03	LAB,TW	**0 265 006 812**
	01.00-09.03	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
			0 265 006 813
FT 330 L 2.4 TDCi [F__]	**2,4 l 101 kW H9FA 4 Zyl.**		
Wheel speed sensor, front	03.04-07.06		**0 265 006 458**
Wheel speed sensor, rear	03.04-07.06	LAB,TW	**0 265 006 461**
			0 265 006 812
			0 265 006 814
		RAB,TW	**0 265 006 460**
			0 265 006 811
			0 265 006 813
FT 330 L 2.4 TDE [F__]	**2,4 l 66/85/88/92 kW DOFA; D2F...; D4FA; FXFA 4 Zyl.**		
Wheel speed sensor, front	01.00-07.06		**0 265 006 458**
Wheel speed sensor, rear	01.00-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	01.00-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	01.00-07.06	RAB,TW	**0 265 006 813**

Product			
FT 330 L 2.4 TDI	**2,4 l 66/88 kW 4 Zyl.**		
Wheel speed sensor, front	01.01-05.06		**0 265 006 458**
Wheel speed sensor, rear	01.01-09.03	LAB,OZB	**0 265 006 461**
	10.03-05.06	LAB,OZB	**0 265 006 812**
	01.01-05.06	LAB,ZWB	**0 265 006 814**
	01.01-09.03	OZB,RAB	**0 265 006 460**
	10.03-05.06	OZB,RAB	**0 265 006 811**
	01.01-05.06	RAB,ZWB	**0 265 006 813**
FT 330 M 2.0 TDCi [F__]	**2,0 l 92 kW FIFA 4 Zyl.**		
Wheel speed sensor, front	05.02-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	05.02-05.04	LAB,TW	**0 265 006 542**
	07.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	05.02-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	05.02-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 330 M 2.0 TDE [F__]	**2,0 l 74 kW ABFA 4 Zyl.**		
Wheel speed sensor, front	08.03-07.06	TW	**0 265 006 458**
			0 265 006 784
Wheel speed sensor, rear	08.03-05.04	LAB,TW	**0 265 006 542**
	08.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	08.03-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	08.03-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 330 M 2.3i [F__]	**2,3 l 103-107 kW E5FA; E5FC 4 Zyl.**		
Wheel speed sensor, front	12.00-07.06		**0 265 006 458**
Wheel speed sensor, rear	12.00-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	12.00-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	12.00-07.06	RAB,TW	**0 265 006 813**
FT 330 M 2.4 TD [F__]	**2,4 l 55 kW F4FA 4 Zyl.**		
Wheel speed sensor, front	01.00-09.03		**0 265 006 458**
Wheel speed sensor, rear	01.00-09.03	LAB,TW	**0 265 006 461**
	12.02-09.03	LAB,TW	**0 265 006 812**
	01.00-09.03	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
			0 265 006 813
FT 330 M 2.4 TDCi [F__]	**2,4 l 101 kW H9FA 4 Zyl.**		
Wheel speed sensor, front	03.04-07.06		**0 265 006 458**
Wheel speed sensor, rear	03.04-07.06	LAB,TW	**0 265 006 461**
			0 265 006 812
			0 265 006 814
		RAB,TW	**0 265 006 460**
			0 265 006 811
			0 265 006 813
FT 330 M 2.4 TDE [F__]	**2,4 l 66/85/88/92 kW DOFA; D2F...; D4FA; FXFA 4 Zyl.**		
Wheel speed sensor, front	01.00-07.06		**0 265 006 458**
Wheel speed sensor, rear	01.00-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	01.00-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	01.00-07.06	RAB,TW	**0 265 006 813**

F

Product			
FT 330 M 2.4 TDI			**2,4 l 66/88 kW 4 Zyl.**
Wheel speed sensor, front	01.01-05.06		**0 265 006 458**
Wheel speed sensor, rear	01.01-09.03	LAB,OZB	**0 265 006 461**
	10.03-05.06	LAB,OZB	**0 265 006 812**
	01.01-05.06	LAB,ZWB	**0 265 006 814**
	01.01-09.03	OZB,RAB	**0 265 006 460**
	10.03-05.06	OZB,RAB	**0 265 006 811**
	01.01-05.06	RAB,ZWB	**0 265 006 813**
FT 330 S 2.4 TDI			**2,4 l 66/74/88 kW 4 Zyl.**
Wheel speed sensor, front	01.01-05.06		**0 265 006 458**
Wheel speed sensor, rear	01.01-09.03	LAB,OZB	**0 265 006 461**
	10.03-05.06	LAB,OZB	**0 265 006 812**
	01.01-05.06	LAB,ZWB	**0 265 006 814**
	01.01-09.03	OZB,RAB	**0 265 006 460**
	10.03-05.06	OZB,RAB	**0 265 006 811**
	01.01-05.06	RAB,ZWB	**0 265 006 813**
FT 350 E 2.4 TDI			**2,4 l 66/88 kW 4 Zyl.**
Wheel speed sensor, front	01.01-05.06		**0 265 006 458**
Wheel speed sensor, rear	01.01-09.03	LAB,OZB	**0 265 006 461**
	10.03-05.06	LAB,OZB	**0 265 006 812**
	01.01-05.06	LAB,ZWB	**0 265 006 814**
	01.01-09.03	OZB,RAB	**0 265 006 460**
	10.03-05.06	OZB,RAB	**0 265 006 811**
	01.01-05.06	RAB,ZWB	**0 265 006 813**
FT 350 E 2.4 TDI			**2,4 l 96 kW 4 Zyl.**
Wheel speed sensor, front	06.04-05.06		**0 265 006 458**
Wheel speed sensor, rear	06.04-05.06	LAB,OZB	**0 265 006 812**
		LAB,ZWB	**0 265 006 814**
		OZB,RAB	**0 265 006 811**
		RAB,ZWB	**0 265 006 813**
FT 350 EL 2.0 TDCi [F___]			**2,0 l 92 kW FIFA 4 Zyl.**
Wheel speed sensor, front	05.02-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	05.02-05.04	LAB,TW	**0 265 006 542**
	07.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	05.02-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	05.02-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 350 EL 2.0 TDE [F___]			**2,0 l 74 kW ABFA 4 Zyl.**
Wheel speed sensor, front	08.03-07.06	TW	**0 265 006 458**
			0 265 006 784
Wheel speed sensor, rear	08.03-05.04	LAB,TW	**0 265 006 542**
	08.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	08.03-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	08.03-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 350 EL 2.3i [F___]			**2,3 l 103-107 kW E5FA; E5FC 4 Zyl.**
Wheel speed sensor, front	12.00-07.06		**0 265 006 458**
Wheel speed sensor, rear	12.00-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	12.00-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	12.00-07.06	RAB,TW	**0 265 006 813**

Product			
FT 350 EL 2.4 TD [F___]			**2,4 l 55 kW F4FA 4 Zyl.**
Wheel speed sensor, front	01.00-09.03		**0 265 006 458**
Wheel speed sensor, rear	01.00-09.03	LAB,TW	**0 265 006 461**
	12.02-09.03	LAB,TW	**0 265 006 812**
	01.00-09.03	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
			0 265 006 813
FT 350 EL 2.4 TDCi [F___]			**2,4 l 101 kW H9FA 4 Zyl.**
Wheel speed sensor, front	03.04-07.06		**0 265 006 458**
Wheel speed sensor, rear	03.04-07.06	LAB,TW	**0 265 006 461**
			0 265 006 812
			0 265 006 814
		RAB,TW	**0 265 006 460**
			0 265 006 811
			0 265 006 813
FT 350 EL 2.4 TDE [F___]			**2,4 l 66/85/92 kW DOFA; D2F...; FXFA 4 Zyl.**
Wheel speed sensor, front	01.00-07.06		**0 265 006 458**
Wheel speed sensor, rear	01.00-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	01.00-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	01.00-07.06	RAB,TW	**0 265 006 813**
FT 350 L 2.0 TDCi [F___]			**2,0 l 92 kW FIFA 4 Zyl.**
Wheel speed sensor, front	05.02-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	05.02-05.04	LAB,TW	**0 265 006 542**
	07.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	05.02-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	05.02-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 350 L 2.0 TDE [F___]			**2,0 l 74 kW ABFA 4 Zyl.**
Wheel speed sensor, front	08.03-07.06	TW	**0 265 006 458**
			0 265 006 784
Wheel speed sensor, rear	08.03-05.04	LAB,TW	**0 265 006 542**
	08.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	08.03-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	08.03-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 350 L 2.3i [F___]			**2,3 l 103-107 kW E5FA; E5FC 4 Zyl.**
Wheel speed sensor, front	12.00-07.06		**0 265 006 458**
Wheel speed sensor, rear	12.00-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	12.00-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	12.00-07.06	RAB,TW	**0 265 006 813**
FT 350 L 2.4 TD [F___]			**2,4 l 55 kW F4FA 4 Zyl.**
Wheel speed sensor, front	01.00-09.03		**0 265 006 458**
Wheel speed sensor, rear	01.00-09.03	LAB,TW	**0 265 006 461**
	12.02-09.03	LAB,TW	**0 265 006 812**
	01.00-09.03	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
			0 265 006 813

F

Product			
◀ Transit			
FT 350 L 2.4 TDCi [F__]			**2,4 l 101 kW H9FA 4 Zyl.**
Wheel speed sensor, front	03.04-07.06		**0 265 006 458**
Wheel speed sensor, rear	03.04-07.06	LAB,TW	**0 265 006 461**
			0 265 006 812
			0 265 006 814
		RAB,TW	**0 265 006 460**
			0 265 006 811
			0 265 006 813
FT 350 L 2.4 TDE [F__]			**2,4 l 66/85/88/92 kW DOFA; D2F...; D4FA; FXFA 4 Zyl.**
Wheel speed sensor, front	01.00-07.06		**0 265 006 458**
Wheel speed sensor, rear	01.00-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	01.00-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	01.00-07.06	RAB,TW	**0 265 006 813**
FT 350 L 2.4 TDI			**2,4 l 66/88 kW 4 Zyl.**
Wheel speed sensor, front	01.01-05.06		**0 265 006 458**
Wheel speed sensor, rear	01.01-09.03	LAB,OZB	**0 265 006 461**
	10.03-05.06	LAB,OZB	**0 265 006 812**
	01.01-05.06	LAB,ZWB	**0 265 006 814**
	01.01-09.03	OZB,RAB	**0 265 006 460**
	10.03-05.06	OZB,RAB	**0 265 006 811**
	01.01-05.06	RAB,ZWB	**0 265 006 813**
FT 350 L 2.4 TDI			**2,4 l 96 kW 4 Zyl.**
Wheel speed sensor, front	06.04-05.06		**0 265 006 458**
Wheel speed sensor, rear	06.04-05.06	LAB,OZB	**0 265 006 812**
		LAB,ZWB	**0 265 006 814**
		OZB,RAB	**0 265 006 811**
		RAB,ZWB	**0 265 006 813**
FT 350 M 2.0 TDCi [F__]			**2,0 l 92 kW FIFA 4 Zyl.**
Wheel speed sensor, front	05.02-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	05.02-05.04	LAB,TW	**0 265 006 542**
	07.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	05.02-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	05.02-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 350 M 2.0 TDE [F__]			**2,0 l 74 kW ABFA 4 Zyl.**
Wheel speed sensor, front	08.03-07.06	TW	**0 265 006 458**
			0 265 006 784
Wheel speed sensor, rear	08.03-05.04	LAB,TW	**0 265 006 542**
	08.03-07.06	LAB,TW	**0 265 006 784**
	05.04-07.06	LAB,TW	**0 265 006 816**
	08.03-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	08.03-07.06	RAB,TW	**0 265 006 815**
			0 265 006 817
FT 350 M 2.3i [F__]			**2,3 l 103-107 kW E5FA; E5FC 4 Zyl.**
Wheel speed sensor, front	12.00-07.06		**0 265 006 458**
Wheel speed sensor, rear	12.00-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	12.00-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	12.00-07.06	RAB,TW	**0 265 006 813**

Product			
FT 350 M 2.4 TD [F__]			**2,4 l 55 kW F4FA 4 Zyl.**
Wheel speed sensor, front	01.00-09.03		**0 265 006 458**
Wheel speed sensor, rear	01.00-09.03	LAB,TW	**0 265 006 461**
	12.02-09.03	LAB,TW	**0 265 006 812**
	01.00-09.03	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
			0 265 006 813
FT 350 M 2.4 TDCi [F__]			**2,4 l 101 kW H9FA 4 Zyl.**
Wheel speed sensor, front	03.04-07.06		**0 265 006 458**
Wheel speed sensor, rear	03.04-07.06	LAB,TW	**0 265 006 461**
			0 265 006 812
			0 265 006 814
		RAB,TW	**0 265 006 460**
			0 265 006 811
			0 265 006 813
FT 350 M 2.4 TDE [F__]			**2,4 l 66/85/88/92 kW DOFA; D2F...; D4FA; FXFA 4 Zyl.**
Wheel speed sensor, front	01.00-07.06		**0 265 006 458**
Wheel speed sensor, rear	01.00-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	01.00-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	01.00-07.06	RAB,TW	**0 265 006 813**
FT 350 M 2.4 TDI			**2,4 l 66/88 kW 4 Zyl.**
Wheel speed sensor, front	01.01-05.06		**0 265 006 458**
Wheel speed sensor, rear	01.01-09.03	LAB,OZB	**0 265 006 461**
	10.03-05.06	LAB,OZB	**0 265 006 812**
	01.01-05.06	LAB,ZWB	**0 265 006 814**
	01.01-09.03	OZB,RAB	**0 265 006 460**
	10.03-05.06	OZB,RAB	**0 265 006 811**
	01.01-05.06	RAB,ZWB	**0 265 006 813**
FT 350 M 2.4 TDI			**2,4 l 96 kW 4 Zyl.**
Wheel speed sensor, front	06.04-05.06		**0 265 006 458**
Wheel speed sensor, rear	06.04-05.06	LAB,OZB	**0 265 006 812**
		LAB,ZWB	**0 265 006 814**
		OZB,RAB	**0 265 006 811**
		RAB,ZWB	**0 265 006 813**
FT 430 E 2.4 TDI			**2,4 l 96 kW 4 Zyl.**
Wheel speed sensor, front	06.04-05.06		**0 265 006 458**
Wheel speed sensor, rear	06.04-05.06	LAB,OZB	**0 265 006 812**
		LAB,ZWB	**0 265 006 814**
		OZB,RAB	**0 265 006 811**
		RAB,ZWB	**0 265 006 813**
FT 430 EL 2.4 TD [F__]			**2,4 l 55 kW F4FA 4 Zyl.**
Wheel speed sensor, front	08.02-09.03		**0 265 006 458**
Wheel speed sensor, rear	08.02-09.03	LAB,TW	**0 265 006 461**
	12.02-09.03	LAB,TW	**0 265 006 812**
	08.02-09.03	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
			0 265 006 813
FT 430 EL 2.4 TDCi [F__]			**2,4 l 101 kW H9FA 4 Zyl.**
Wheel speed sensor, front	03.04-07.06		**0 265 006 458**
Wheel speed sensor, rear	03.04-07.06	LAB,TW	**0 265 006 461**
			0 265 006 812
			0 265 006 814
		RAB,TW	**0 265 006 460**
			0 265 006 811
			0 265 006 813

F

Product			
FT 430 EL 2.4 TDE [F__]	**2,4 l 66/85/92 kW DOFA; D2F...; FXFA 4 Zyl.**		
Wheel speed sensor, front	08.02-07.06		**0 265 006 458**
Wheel speed sensor, rear	08.02-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	08.02-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	08.02-07.06	RAB,TW	**0 265 006 813**
FT 430 M 2.4 TD [F__]	**2,4 l 55 kW F4FA 4 Zyl.**		
Wheel speed sensor, front	08.02-09.03		**0 265 006 458**
Wheel speed sensor, rear	08.02-09.03	LAB,TW	**0 265 006 461**
	12.02-09.03	LAB,TW	**0 265 006 812**
	08.02-09.03	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
			0 265 006 813
FT 430 M 2.4 TDCi [F__]	**2,4 l 101 kW H9FA 4 Zyl.**		
Wheel speed sensor, front	03.04-07.06		**0 265 006 458**
Wheel speed sensor, rear	03.04-07.06	LAB,TW	**0 265 006 461**
			0 265 006 812
			0 265 006 814
		RAB,TW	**0 265 006 460**
			0 265 006 811
			0 265 006 813
FT 430 M 2.4 TDE [F__]	**2,4 l 85/92 kW DOFA; FXFA 4 Zyl.**		
Wheel speed sensor, front	08.02-07.06		**0 265 006 458**
Wheel speed sensor, rear	08.02-07.06	LAB,TW	**0 265 006 461**
	12.02-07.06	LAB,TW	**0 265 006 812**
	08.02-07.06	LAB,TW	**0 265 006 814**
		RAB,TW	**0 265 006 460**
	03.04-07.06	RAB,TW	**0 265 006 811**
	08.02-07.06	RAB,TW	**0 265 006 813**
2.0 i LWB 100-190, i SWB 80-150 [E_]	**2,0 l 72 kW NCA 4 Zyl.**		
Air flow sensor, gasoline injection	08.91-07.94		**0 280 202 063**
2.0 i 80-120, i 100 L, i 130-190 [T_]	**2,0 l 57 kW N6T 4 Zyl.**		
Air flow sensor, gasoline injection	10.88-07.91		**0 280 202 063**
2.2 TDCi	**2,2 l 63/81/96 kW P8FA; QVFA; QWF... 4 Zyl.**		
Boost pressure sensor, Diesel	04.06→		**0 261 230 131**
Duo sensor, acceleration and yaw rate, brake system	04.06→	TW	**0 265 005 690**
2.3 i	**2,3 l 107 kW GZF... 4 Zyl.**		
Pressure sensor, intake manifold, gasoline	04.06→		**0 261 230 044**
Duo sensor, acceleration and yaw rate, brake system	04.06→	TW	**0 265 005 690**
2.4 TDCi	**2,4 l 74/85/103 kW HPFB; JXFA; PHF... 4 Zyl.**		
Boost pressure sensor, Diesel	07.06→		**0 261 230 131**
Duo sensor, acceleration and yaw rate, brake system	07.06→	TW	**0 265 005 690**

Transit Euroline

2.0 TDCi [F__]	**2,0 l 92 kW F1FA 4 Zyl.**		
Wheel speed sensor, front	05.02-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	07.03-07.06	LAB,TW	**0 265 006 784**
	05.02-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	05.02-07.06	RAB,TW	**0 265 006 817**
2.0 TDE [F__]	**2,0 l 74 kW ABFA 4 Zyl.**		
Wheel speed sensor, front	08.00-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	07.03-07.06	LAB,TW	**0 265 006 784**
	08.00-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	08.00-07.06	RAB,TW	**0 265 006 817**
2.2 TDCi	**2,2 l 81/96 kW QVFA; QWF... 4 Zyl.**		
Boost pressure sensor, Diesel	04.06→		**0 261 230 131**
Duo sensor, acceleration and yaw rate, brake system	04.06→	TW	**0 265 005 690**

Transit Nugget

2.0 TDCi [F__]	**2,0 l 92 kW FIFA 4 Zyl.**		
Wheel speed sensor, front	05.02-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	07.03-07.06	LAB,TW	**0 265 006 784**
	05.02-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	05.02-07.06	RAB,TW	**0 265 006 817**
2.0 TDE [F__]	**2,0 l 74 kW ABFA 4 Zyl.**		
Wheel speed sensor, front	08.00-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	07.03-07.06	LAB,TW	**0 265 006 784**
	08.00-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	08.00-07.06	RAB,TW	**0 265 006 817**
2.2 TDCi	**2,2 l 81/96 kW QVFA; QWF... 4 Zyl.**		
Boost pressure sensor, Diesel	04.06→		**0 261 230 131**
Duo sensor, acceleration and yaw rate, brake system	04.06→	TW	**0 265 005 690**

Transit Tourneo

2.0 TDCi [F__]	**2,0 l 92 kW F1FA 4 Zyl.**		
Wheel speed sensor, front	05.02-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	07.03-07.06	LAB,TW	**0 265 006 784**
	05.02-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	05.02-07.06	RAB,TW	**0 265 006 817**
2.0 TDE [F__]	**2,0 l 74 kW ABFA 4 Zyl.**		
Wheel speed sensor, front	08.00-07.06	TW	**0 265 006 458**
	07.03-07.06	TW	**0 265 006 784**
Wheel speed sensor, rear	07.03-07.06	LAB,TW	**0 265 006 784**
	08.00-05.04	LAB,TW	**0 265 006 818**
	11.03-05.04	RAB,TW	**0 265 006 460**
	05.04-07.06	RAB,TW	**0 265 006 811**
	08.00-07.06	RAB,TW	**0 265 006 817**
2.2 TDCi	**2,2 l 81/96 kW QVFA; QWF... 4 Zyl.**		
Boost pressure sensor, Diesel	04.06→		**0 261 230 131**
Duo sensor, acceleration and yaw rate, brake system	04.06→	TW	**0 265 005 690**

Versailles

2.0 i	**2,0 l 82 kW UQC 4 Zyl.**		
Wheel speed sensor, front	02.95-10.96		**0 265 006 218**
Wheel speed sensor, rear	02.95-10.96	LAB	**0 265 006 220**
		RAB	**0 265 006 219**

F

Product

GAZ

Gazel

2.3			**2,3 l 80,9 kW 4063.10 4 Zyl.**
Throttle valve sensor	11.97→		**0 280 122 001**
Air mass meter, gasoline injection	11.97→	TW	**0 280 212 014**
			0 986 280 108
			0 280 218 037
			0 986 280 108
			0 986 280 108
Phase sensor	11.97→		**0 232 103 006**
Speed sensor, ignition/injection	11.97→		**0 261 210 113**
Knock sensor	11.97→		**0 261 231 046**
Pressure sensor, intake manifold, gasoline	11.97→	TW	**0 261 230 004**
			0 261 230 037
2.5 i			**2,5 l 111,8 kW 40522.10 4 Zyl.**
Throttle valve sensor	09.01→		**0 280 122 001**
Air mass meter, gasoline injection	09.01→	TW	**0 280 212 014**
			0 986 280 108
			0 280 218 037
			0 986 280 108
			0 986 280 108
Phase sensor	09.01→		**0 232 103 006**
Speed sensor, ignition/injection	09.01→		**0 261 210 113**
Knock sensor	09.01→		**0 261 231 046**
Pressure sensor, intake manifold, gasoline	09.01→	TW	**0 261 230 004**
			0 261 230 037
2.7 TD			**2,7 l 80 kW ADCR110 4 Zyl.**
Speed sensor, diesel	01.07→	FKW	**0 281 002 315**
Phase sensor	01.07→	NOC	**0 281 002 667**
Temperature sensor, coolant, diesel	01.07→		**0 281 002 209**
Temperature sensor, intake air, diesel	01.07→		**0 280 130 039**
Temperature sensor, fuel	01.07→		**0 281 002 209**
Accelerator pedal module	01.07→		**0 281 002 687**

Sobol

2.3			**2,3 l 80,9 kW 4063.10 4 Zyl.**
Throttle valve sensor	09.97→		**0 280 122 001**
Air mass meter, gasoline injection	09.97→	TW	**0 280 212 014**
			0 986 280 108
			0 280 218 037
			0 986 280 108
			0 986 280 108
Phase sensor	09.97→		**0 232 103 006**
Speed sensor, ignition/injection	09.97→		**0 261 210 113**
Knock sensor	09.97→		**0 261 231 046**
Pressure sensor, intake manifold, gasoline	09.97→	TW	**0 261 230 004**
			0 261 230 037
2.5 i			**2,5 l 111,8 kW 40522 4 Zyl.**
Throttle valve sensor	09.01→		**0 280 122 001**
Air mass meter, gasoline injection	09.01→	TW	**0 280 212 014**
			0 986 280 108
			0 280 218 037
			0 986 280 108
			0 986 280 108
Phase sensor	09.01→		**0 232 103 006**
Speed sensor, ignition/injection	09.01→		**0 261 210 113**
Knock sensor	09.01→		**0 261 231 046**
Pressure sensor, intake manifold, gasoline	09.01→	TW	**0 261 230 004**
			0 261 230 037

Product

Volga

2.1 TD			**2,1 l 70 kW 560 4 Zyl.**
Phase sensor	09.97→		**0 232 103 006**
2.3			**2,3 l 73,5 kW 4061.10 4 Zyl.**
Throttle valve sensor	11.02-12.05		**0 280 122 001**
Air mass meter, gasoline injection	11.02-12.05	TW	**0 280 212 014**
			0 986 280 108
			0 280 218 037
			0 986 280 108
			0 986 280 108
Phase sensor	11.02-12.05		**0 232 103 006**
Speed sensor, ignition/injection	11.02-12.05		**0 261 210 113**
Knock sensor	11.02-12.05		**0 261 231 046**
Pressure sensor, intake manifold, gasoline	11.02-12.05	TW	**0 261 230 004**
			0 261 230 037
2.3 i			**2,3 l 106,6/110 kW 4062.10 4 Zyl.**
Throttle valve sensor	01.97→		**0 280 122 001**
Air mass meter, gasoline injection	01.97→	TW	**0 280 212 014**
			0 986 280 108
			0 280 218 037
			0 986 280 108
			0 986 280 108
Speed sensor, ignition/injection	01.97→		**0 261 210 113**
Knock sensor	01.97→		**0 261 231 046**
Pressure sensor, intake manifold, gasoline	01.97→	TW	**0 261 230 004**
			0 261 230 037
2.3 i			**2,3 l 110 kW 4062 4 Zyl.**
Throttle valve sensor	01.89-12.99		**0 280 122 001**
Air mass meter, gasoline injection	01.89-12.99	TW	**0 280 212 014**
			0 986 280 108
			0 280 218 037
			0 986 280 108
			0 986 280 108
Phase sensor	01.89-12.99		**0 232 103 006**
Speed sensor, ignition/injection	01.89-12.99		**0 261 210 113**
Knock sensor	01.89-12.99		**0 261 231 046**
Pressure sensor, intake manifold, gasoline	01.89-12.99	TW	**0 261 230 004**
			0 261 230 037
2.3 i 16V			**2,3 l 106 kW 4062.10 4 Zyl.**
Throttle valve sensor	01.04→		**0 280 122 001**
Air mass meter, gasoline injection	01.04→	TW	**0 280 212 014**
			0 986 280 108
			0 280 218 037
			0 986 280 108
			0 986 280 108
Speed sensor, ignition/injection	01.04→		**0 261 210 113**
Knock sensor	01.04→		**0 261 231 046**
Pressure sensor, intake manifold, gasoline	01.04→	TW	**0 261 230 004**
			0 261 230 037
2.3 16V			**2,3 l 73,5 kW 4061.10 4 Zyl.**
Throttle valve sensor	01.97-12.04		**0 280 122 001**
Air mass meter, gasoline injection	01.97-12.04	TW	**0 280 212 014**
			0 986 280 108
			0 280 218 037
			0 986 280 108
			0 986 280 108
Phase sensor	01.97-12.04		**0 232 103 006**
Speed sensor, ignition/injection	01.97-12.04		**0 261 210 113**
Knock sensor	01.97-12.04		**0 261 231 046**
Pressure sensor, intake manifold, gasoline	01.97-12.04	TW	**0 261 230 004**
			0 261 230 037

G

Product			
2.4	**2,4 l 66/66,2/73,5 kW 402; 402.10; 4021; 4021.10 4 Zyl.**		
Phase sensor	01.86→		**0 232 103 006**

Volga Kombi

2.3	**2,3 l 73,5 kW 4061.10 4 Zyl.**		
Throttle valve sensor	11.02→		**0 280 122 001**
Air mass meter, gasoline injection	11.02→	TW	**0 280 212 014**
			0 986 280 108
			0 280 218 037
			0 986 280 108
			0 986 280 108
Speed sensor, ignition/injection	11.02→		**0 261 210 113**
Knock sensor	11.02→		**0 261 231 046**
Pressure sensor, intake manifold, gasoline	11.02→	TW	**0 261 230 004**
			0 261 230 037
2.3 i	**2,3 l 106,6 kW 4062.10 4 Zyl.**		
Throttle valve sensor	10.97→		**0 280 122 001**
Air mass meter, gasoline injection	10.97→	TW	**0 280 212 014**
			0 986 280 108
			0 280 218 037
			0 986 280 108
			0 986 280 108
Speed sensor, ignition/injection	10.97→		**0 261 210 113**
Knock sensor	10.97→		**0 261 231 046**
Pressure sensor, intake manifold, gasoline	10.97→	TW	**0 261 230 004**
			0 261 230 037
2.3 i 16V	**2,3 l 96/106 kW 4062.10 4 Zyl.**		
Throttle valve sensor	01.97→		**0 280 122 001**
Air mass meter, gasoline injection	01.97→	TW	**0 280 212 014**
			0 986 280 108
			0 280 218 037
			0 986 280 108
			0 986 280 108
Speed sensor, ignition/injection	01.97→		**0 261 210 113**
Knock sensor	01.97→		**0 261 231 046**
Pressure sensor, intake manifold, gasoline	01.97→	TW	**0 261 230 004**
			0 261 230 037
2.3 16V	**2,3 l 106 kW 4062.10 4 Zyl.**		
Throttle valve sensor	01.97-12.00		**0 280 122 001**
Air mass meter, gasoline injection	01.97-12.00	TW	**0 280 212 014**
			0 986 280 108
			0 280 218 037
			0 986 280 108
			0 986 280 108
Speed sensor, ignition/injection	01.97-12.00		**0 261 210 113**
Knock sensor	01.97-12.00		**0 261 231 046**
Pressure sensor, intake manifold, gasoline	01.97-12.00	TW	**0 261 230 004**
			0 261 230 037

GREATWALL

Deer

2.2 i 4WD	**2,2 l 78 kW GW491QE 4 Zyl.**		
Throttle valve sensor	06.96→		**0 280 122 019**
Phase sensor	06.96→		**0 232 101 024**
Speed sensor, ignition/injection	06.96→		**0 261 210 127**
Knock sensor	06.96→		**0 261 231 163**
Pressure sensor, intake manifold, gasoline	06.96→		**0 261 230 011**
Temperature sensor, coolant, injection system	06.96→		**0 280 130 113**

HOLDEN

Barina Hatchback

1.4 i [SB]	**1,4 l 44 kW C14NZ 4 Zyl.**		
Temperature sensor, coolant, injection system			
Fg.no. W3000001→,W4000001→	04.94-07.97		**0 280 130 093**
Fg.no. →V3999999,→V4999999	04.94-07.97		**0 280 130 107**

HONDA

Accord Hatchback

2.0 TDi [CG/CH/CL]	**2,0 l 77 kW 20T2N 4 Zyl.**		
Air mass meter, diesel	01.99-10.00		**0 280 218 012**
	01.99-12.99	GS,TW	**0 281 002 120**
Boost pressure sensor, Diesel	01.99-10.00		**0 281 002 389**
Temperature sensor, coolant, diesel	01.99-10.00		**0 280 130 026**
Temperature sensor, intake air, diesel	01.99-10.00		**0 280 130 039**

Accord Sedan

1.6 i [CG/CH/CL]	**1,6 l 85 kW D16B6 4 Zyl.**		
Temperature sensor, intake air, injection system	10.98-12.99		**0 280 130 073**
	01.00-02.03	GS	**0 280 130 092**
Temperature sensor, coolant, injection system	10.98-02.03		**0 280 130 107**
1.8 i [CG/CH/CL]	**1,8 l 100 kW F18B2 4 Zyl.**		
Temperature sensor, intake air, injection system	10.98-02.03	GS	**0 280 130 092**
2.0 D Turbo [CE/CF]	**2,0 l 77 kW 20T2N 4 Zyl.**		
Air mass meter, diesel	09.95-10.98		**0 281 002 120**
Speed sensor, diesel	09.95-10.98		**0 281 002 121**
Temperature sensor, coolant, diesel	09.95-10.98		**0 280 130 026**
Temperature sensor, intake air, diesel	09.95-10.98		**0 280 130 039**
2.0 i [CG/CH/CL]	**2,0 l 108 kW F20B6 4 Zyl.**		
Temperature sensor, intake air, injection system	10.98-02.03	GS	**0 280 130 092**
2.0 TDi [CG/CH/CL]	**2,0 l 77 kW 20T2N 4 Zyl.**		
Air mass meter, diesel	01.99-02.03		**0 280 218 012**
	01.99-12.99	GS,TW	**0 281 002 120**
Boost pressure sensor, Diesel	01.99-02.03		**0 281 002 389**
Temperature sensor, coolant, diesel	01.99-02.03		**0 280 130 026**
Temperature sensor, intake air, diesel	01.99-02.03		**0 280 130 039**
2.2 i Typ R [CG/CH/CL]	**2,2 l 156 kW H22A7 4 Zyl.**		
Temperature sensor, intake air, injection system	01.99-02.03	GS	**0 280 130 092**

Civic Aerodeck

2.0 D Turbo [MB/MC]	**2,0 l 77 kW 20T2N 4 Zyl.**		
Air mass meter, diesel	04.98-12.99		**0 281 002 120**
Temperature sensor, coolant, diesel	04.98-02.01		**0 280 130 026**
Temperature sensor, intake air, diesel	04.98-02.01		**0 280 130 039**
Wheel speed sensor, front	04.98-02.01	LAB	**0 265 006 258**
		RAB	**0 265 006 259**
Wheel speed sensor, rear	04.98-02.01	LAB	**0 265 006 267**
		RAB	**0 265 006 268**

Civic Fastback

2.0 D [MB/MC]	**2,0 l 63 kW 20T2N 4 Zyl.**		
Air mass meter, diesel	03.97-02.01		**0 281 002 120**
Temperature sensor, coolant, diesel	03.97-02.01		**0 280 130 026**

H

Product			

◀ Civic Fastback

Wheel speed sensor, front	03.97-02.01	LAB	**0 265 006 258**
		RAB	**0 265 006 259**
Wheel speed sensor, rear	03.97-02.01	LAB	**0 265 006 267**
		RAB	**0 265 006 268**

Civic Hatchback

1.7 CTDi [EU/EP]			**1,7 l 74 kW 4EE2 4 Zyl.**
Air mass meter, diesel	01.02-12.05		**0 281 002 482**

Jazz

1.2 [GD]			**1,2 l 57 kW L12A1 4 Zyl.**
Knock sensor	03.02→		**0 261 231 120**
Pressure sensor, intake manifold, gasoline	03.02→		**0 261 230 099**
1.4 [GD]			**1,3 l 61 kW L13A1 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.02→	GS	**0 261 230 099**

HYUNDAI

Accent

1.3 i [LC]			**1,3 l 55/61-63 kW G4E-A 4 Zyl.**
Throttle valve sensor	08.99-03.06		**0 280 122 014**
1.3 i [X3]			**1,3 l 44/55/62 kW G4EH 4 Zyl.**
Throttle valve sensor	07.94-07.99		**0 280 122 001**
Air mass meter, gasoline injection	07.94-07.99		**0 280 217 102**
1.3 i [X3]			**1,3 l 67 kW G4EH 4 Zyl.**
Throttle valve sensor	04.94-05.99		**0 280 122 001**
1.5 CRDi [LC]			**1,5 l 57-60 kW D3-EA 3 Zyl.**
Air mass meter, diesel	01.02-03.06		**0 281 002 528**
Accelerator pedal module	01.02-06.03	LLE	**0 281 002 545**
	01.02-02.04	RLE	**0 281 002 547**
1.5 i [LC]			**1,5 l 66/75 kW G4EB; G4EC-G 4 Zyl.**
Throttle valve sensor	08.99-03.06		**0 280 122 014**
1.5 i [X3]			**1,5 l 63/65-68 kW G4EK 4 Zyl.**
Throttle valve sensor	07.94-07.99		**0 280 122 001**
Air mass meter, gasoline injection	07.94-07.99		**0 280 217 102**
1.5 i [X3]			**1,5 l 71 kW 4 Zyl.**
Throttle valve sensor	04.94-05.99		**0 280 122 001**
1.5 i 12V			**1,5 l 69 kW Alpha 4 Zyl.**
Throttle valve sensor	11.99→		**0 280 122 014**
1.5 i 16V [X3]			**1,5 l 73 kW G4FK 4 Zyl.**
Throttle valve sensor	11.95-07.99		**0 280 122 001**
Air mass meter, gasoline injection	11.95-07.99		**0 280 217 102**
Pressure sensor, intake manifold, gasoline	08.97-05.98		**0 261 230 013**
1.6 i [LC]			**1,6 l 77 kW G4ED-G 4 Zyl.**
Throttle valve sensor	08.02-03.06		**0 280 122 014**

Accent Hatchback

1.3 [LC]			**1,3 l 53 kW G4E-A 4 Zyl.**
Throttle valve sensor	08.99-03.06		**0 280 122 014**
1.3 i [LC]			**1,3 l 55/61-63 kW G4E-A 4 Zyl.**
Throttle valve sensor	08.99-03.06		**0 280 122 014**
1.3 i [X3]			**1,3 l 44/55/62 kW G4EH 4 Zyl.**
Throttle valve sensor	07.94-07.99		**0 280 122 001**
Air mass meter, gasoline injection	07.94-07.99		**0 280 217 102**
1.5 CRDi [LC]			**1,5 l 57-60 kW D3-EA 3 Zyl.**
Air mass meter, diesel	01.02-03.06		**0 281 002 528**
Accelerator pedal module	01.02-06.03	LLE	**0 281 002 545**
	01.02-02.04	RLE	**0 281 002 547**
1.5 i [LC]			**1,5 l 66/75 kW G4EB; G4EC-G 4 Zyl.**
Throttle valve sensor	08.99-03.06		**0 280 122 014**
1.5 i [X3]			**1,5 l 63/65-68 kW G4EK 4 Zyl.**
Throttle valve sensor	07.94-07.99		**0 280 122 001**
Air mass meter, gasoline injection	07.94-07.99		**0 280 217 102**
1.5 i [X3]			**1,5 l 73 kW G4FK 4 Zyl.**
Throttle valve sensor	11.95-07.99		**0 280 122 001**
Air mass meter, gasoline injection	11.95-07.99		**0 280 217 102**
Pressure sensor, intake manifold, gasoline	08.97-05.98		**0 261 230 013**
1.6 i [LC]			**1,6 l 77 kW G4ED-G 4 Zyl.**
Throttle valve sensor	08.02-03.06		**0 280 122 014**

Coupé

1.6 i 16V [RD]			**1,6 l 84-85 kW Beta 4 Zyl.**
Throttle valve sensor	05.96-09.01		**0 280 122 001**
Air mass meter, gasoline injection	05.96-09.01		**0 280 217 116**
1.6 16V [GK]			**1,6 l 76-79 kW G4ED-G 4 Zyl.**
Throttle valve sensor	03.02→		**0 280 122 014**
1.8 i 16V [RD]			**1,8 l 94 kW G4GM 4 Zyl.**
Air mass meter, gasoline injection	07.97-09.01		**0 280 217 116**
2.0 i 16V [RD]			**2,0 l 100-102 kW G4GF 4 Zyl.**
Throttle valve sensor	05.96-09.01		**0 280 122 001**
Air mass meter, gasoline injection	05.96-09.01		**0 280 217 116**
2.0 16V [GK]			**2,0 l 101-105 kW G4GC-G 4 Zyl.**
Throttle valve sensor	10.01→		**0 280 122 014**

Elantra

1.5 i [J2]			**1,5 l 65-68 kW G4EK 4 Zyl.**
Throttle valve sensor	07.96-09.00		**0 280 122 001**
1.6 i			**1,6 l 82 kW G4GA 4 Zyl.**
Throttle valve sensor	04.04→		**0 280 122 014**
1.6 i 16V [J2]			**1,6 l 84 kW 4G61 4 Zyl.**
Throttle valve sensor	05.95-09.00		**0 280 122 001**
1.6 i 16V [XD]			**1,6 l 77-79 kW G4ED-G 4 Zyl.**
Throttle valve sensor	06.00→		**0 280 122 014**
1.8 i			**1,8 l 96 kW G4GB 4 Zyl.**
Throttle valve sensor	12.03→		**0 280 122 014**
1.8 i 16V [J2]			**1,8 l 101 kW G4GM 4 Zyl.**
Throttle valve sensor	05.95-09.00		**0 280 122 001**
Air mass meter, gasoline injection	05.95-01.96		**0 280 217 116**
1.8 i 16V [XD]			**1,8 l 97 kW G4GB 4 Zyl.**
Throttle valve sensor	06.00→		**0 280 122 014**
2.0 i 16V [XD]			**2,0 l 102-105 kW G4... 4 Zyl.**
Throttle valve sensor	06.00→		**0 280 122 014**

Elantra Hatchback

1.6 i 16V [XD]			**1,6 l 77-79 kW G4ED 4 Zyl.**
Throttle valve sensor	06.00→		**0 280 122 014**
1.8 i 16V [XD]			**1,8 l 97 kW G4GB 4 Zyl.**
Throttle valve sensor	06.00→		**0 280 122 014**
2.0 i 16V [XD]			**2,0 l 102-105 kW G4... 4 Zyl.**
Throttle valve sensor	06.00→		**0 280 122 014**

Excel

1.3 i [X3]			**1,3 l 55 kW G4EH 4 Zyl.**
Throttle valve sensor	07.94-07.99		**0 280 122 001**
Air mass meter, gasoline injection	07.94-07.99		**0 280 217 102**

Product			
1.5 i [X3]			**1,5 l 65-68 kW G4EK 4 Zyl.**
Throttle valve sensor	07.94-07.99		**0 280 122 001**
Air mass meter, gasoline injection	07.94-07.99		**0 280 217 102**
1.5 i 16V [X3]			**1,5 l 73 kW G4FK 4 Zyl.**
Throttle valve sensor	11.95-07.99		**0 280 122 001**
Air mass meter, gasoline injection	11.95-07.99		**0 280 217 102**
Pressure sensor, intake manifold, gasoline	08.97-05.98		**0 261 230 013**

Excel Hatchback

1.5 i [X3]			**1,5 l 73 kW G4FK 4 Zyl.**
Throttle valve sensor	11.95-07.99		**0 280 122 001**
Air mass meter, gasoline injection	11.95-07.99		**0 280 217 102**
Pressure sensor, intake manifold, gasoline	08.97-05.98		**0 261 230 013**

Getz

1.1 i [TB]			**1,1 l 46-49 kW G4HD 4 Zyl.**
Throttle valve sensor	09.02→		**0 280 122 014**
1.3 i [TB]			**1,3 l 60-63 kW G4E-A 4 Zyl.**
Throttle valve sensor	09.02-09.05		**0 280 122 014**
1.5 CRDi [TB]			**1,5 l 60 kW D3-EA 3 Zyl.**
Air mass meter, diesel	05.03-08.05		**0 281 002 528**
1.6 i [TB]			**1,6 l 77 kW G4ED-G 4 Zyl.**
Throttle valve sensor	09.02→		**0 280 122 014**

H 100

2.5 D			**2,5 l 55 kW D4BX 4 Zyl.**
Wheel speed sensor, front	02.93-12.94	LAB	**0 265 006 133**
		RAB	**0 265 006 121**
Wheel speed sensor, rear	02.93-12.94	LAB	**0 265 006 123**
		RAB	**0 265 006 122**

H-1

2.5 CRDi			**2,5 l 103 kW D4CB 4 Zyl.**
Air flow sensor, diesel	08.03→		**0 281 002 554**

Lantra

1.5 i [J2]			**1,5 l 65-68 kW G4EK 4 Zyl.**
Throttle valve sensor	07.96-09.00		**0 280 122 001**
1.6 i 16V [J2]			**1,6 l 66/84 kW G4DJ; G4GR 4 Zyl.**
Throttle valve sensor	05.95-09.00		**0 280 122 001**
1.8 i 16V [J2]			**1,8 l 94 kW G4GM 4 Zyl.**
Throttle valve sensor	05.95-09.00		**0 280 122 001**
Air mass meter, gasoline injection	05.95-01.96		**0 280 217 116**
2.0 i 16V [J2]			**2,0 l 102 kW G4GF 4 Zyl.**
Throttle valve sensor	08.96-09.00		**0 280 122 001**

Lantra Station Wagon

1.5 i [J2]			**1,5 l 65 kW G4EK 4 Zyl.**
Throttle valve sensor	07.96-09.00		**0 280 122 001**
1.6 i [J2]			**1,6 l 66/84 kW G4GR 4 Zyl.**
Throttle valve sensor	05.95-09.00		**0 280 122 001**
1.8 i [J2]			**1,8 l 94 kW G4GM 4 Zyl.**
Throttle valve sensor	05.95-09.00		**0 280 122 001**
Air mass meter, gasoline injection	05.95-01.96		**0 280 217 116**
2.0 i [J2]			**2,0 l 102 kW G4GF 4 Zyl.**
Throttle valve sensor	08.96-09.00		**0 280 122 001**

Product			

Matrix

1.5 CRDi [FC]			**1,5 l 60 kW D3-EA 3 Zyl.**
Air mass meter, diesel	08.01-01.06		**0 281 002 528**
Accelerator pedal module	08.01-01.06		**0 281 002 543**
		RLE	**0 281 002 547**
1.5 CRDi [FC]			**1,5 l 75 kW D4FA 4 Zyl.**
Accelerator pedal module	02.05→	LLE	**0 281 002 543**
		RLE	**0 281 002 547**
1.5 CRDi [FC]			**1,5 l 81 kW 4 Zyl.**
Accelerator pedal module	09.06→	LLE	**0 281 002 543**
1.6 i [FC]			**1,6 l 76 kW G4ED 4 Zyl.**
Throttle valve sensor	08.01→		**0 280 122 014**
1.8 i [FC]			**1,8 l 90 kW G4GB 4 Zyl.**
Throttle valve sensor	08.01→		**0 280 122 014**

Pony

1.3 i [X3]			**1,3 l 62 kW G4EH 4 Zyl.**
Throttle valve sensor	07.94-07.99		**0 280 122 001**
Air mass meter, gasoline injection	07.94-07.99		**0 280 217 102**

Santa Fe

2.0 CRDi [SM]			**2,0 l 83 kW D4EA 4 Zyl.**
Accelerator pedal module	04.01-07.02	LLE	**0 281 002 446**
	08.02-12.05	LLE	**0 281 002 556**
2.0 CRDI			**2,0 l 83 kW 4 Zyl.**
Air mass meter, diesel	06.00→		**0 281 002 447**
Accelerator pedal module	06.00-03.01		**0 281 002 446**
	06.00→		**0 281 002 556**
2.0 CRDi 4x4 [SM]			**2,0 l 83 kW D4EA 4 Zyl.**
Accelerator pedal module	07.01-07.02	LLE	**0 281 002 446**
	08.02-12.05	LLE	**0 281 002 556**
2.0 CRDi-VGT			**2,0 l 83 kW 4 Zyl.**
Accelerator pedal module	08.03→		**0 281 002 556**
2.0 CRDi-VGT 4x4 [SM]			**2,0 l 92 kW D4EA-V 4 Zyl.**
Accelerator pedal module	08.03-12.05	LLE	**0 281 002 556**
2.4 i [SM]			**2,4 l 100/107 kW G4JS-G; G4JSX 4 Zyl.**
Air mass meter, gasoline injection	02.00-07.01		**0 280 218 020**
2.4 i 4x4 [SM]			**2,4 l 100/107 kW G4JS-G; G4JSX 4 Zyl.**
Air mass meter, gasoline injection	12.00-07.01		**0 280 218 020**

Scoupe

1.5 i			**1,5 l 65-68 kW G4EK 4 Zyl.**
Throttle valve sensor	07.92-04.95		**0 280 122 001**
Air mass meter, gasoline injection	07.92-04.95		**0 280 217 102**
Speed sensor, ignition/injection	07.92-04.95		**0 261 210 083**
Knock sensor	07.92-04.94		**0 261 231 091**
1.5 i			**1,5 l 75 kW G4EK 4 Zyl.**
Throttle valve sensor	10.90-04.95		**0 280 122 001**
Speed sensor, ignition/injection	10.90-04.95		**0 261 210 083**
Temperature sensor, coolant, injection system	10.90-04.95		**0 280 130 026**
1.5 i Turbo GT			**1,5 l 84-85 kW Alpha; G4EK-TC 4 Zyl.**
Throttle valve sensor	04.91-04.95		**0 280 122 001**
Air mass meter, gasoline injection	04.91-04.95		**0 280 212 024**
			0 986 280 123
Speed sensor, ignition/injection	04.91-04.95		**0 261 210 083**
Knock sensor	04.91-04.94		**0 261 231 091**

H

Product		

Starex

2.5 CRDi		**2,5 l 103 kW D4CB 4 Zyl.**
Air flow sensor, diesel	10.02→	**0 281 002 554**
2.5 CRDi		**2,5 l 107 kW 4 Zyl.**
Air mass meter, diesel	12.02→	**0 281 002 554**

Terracan

2.9 CRDi [HP]		**2,9 l 110/120 kW J3 4 Zyl.**
Air mass meter, diesel	11.01→	**0 281 002 554**

Tiburon

1.5 i [RD]		**1,5 l 74-76 kW G4EK 4 Zyl.**
Throttle valve sensor	04.96→	**0 280 122 001**
Air mass meter, gasoline injection	04.96→	**0 280 217 102**
2.0 i [RD]		**2,0 l 102-103 kW G4GF 4 Zyl.**
Throttle valve sensor	05.96→	**0 280 122 001**
Air mass meter, gasoline injection	05.96→	**0 280 217 116**

Trajet

2.0 [FO]		**2,0 l 100-103 kW G4JP 4 Zyl.**
Throttle valve sensor	03.04→	**0 280 122 014**

Trajet XG

2.0 CRDi		**2,0 l 83 kW D 4 Zyl.**
Air mass meter, diesel	10.99→	**0 281 002 447**
Accelerator pedal module	10.99-03.01	**0 281 002 446**
	10.99→	**0 281 002 556**
2.0 i		**2,0 l 104 kW 4 Zyl.**
Throttle valve sensor	03.04→	**0 280 122 014**

Tucson

2.0 i, i 4x4 [JM]		**2,0 l 104 kW G4GC 4 Zyl.**
Throttle valve sensor	08.04→	**0 280 122 014**

XG

30 3.0i [F]		**3,0 l 138 kW G6CT 6 Zyl.**
Air mass meter, gasoline injection	12.98-11.02	**0 280 218 029**
	12.02-12.05	**0 280 218 090**
35 3.5i [F]		**3,5 l 145 kW G6CU 6 Zyl.**
Air mass meter, gasoline injection	03.03-12.05	**0 280 218 090**

INNOCENTI (NUOVA INNOCENTI)

Elba

1.4 i.e.		**1,4 l 49 kW 146 C 5.000 SPI-RB 4 Zyl.**
Temperature sensor, coolant, injection system	09.93-06.95	**0 280 130 026**
1.4 i.e.		**1,4 l 49 kW 146 D 5.000 SPI-RB 4 Zyl.**
Pulse generator, ignition/Jetronic	06.95-12.96	**0 261 210 115**
Temperature sensor, coolant, injection system	06.95-12.96	**0 280 130 026**
1.5 i.e.		**1,5 l 55 kW 149 C 1.000 4 Zyl.**
Temperature sensor, coolant, injection system	03.92-08.93	**0 280 130 026**
1.6 i.e.		**1,6 l 55 kW 146 C 6.000 SPI-RB 4 Zyl.**
Temperature sensor, coolant, injection system	09.93-03.96	**0 280 130 026**
1.6 i.e.		**1,6 l 55 kW 146 D 6.000 SPI-RB 4 Zyl.**
Pulse generator, ignition/Jetronic	03.95-12.96	**0 261 210 115**
Temperature sensor, coolant, injection system	03.95-12.96	**0 280 130 026**

IVECO

Daily

C 35 C 9			**2,8 l 66 kW 8140.43R... 4 Zyl.**
Speed sensor, diesel	08.01-09.04		**0 281 002 332**
High-pressure sensor (CR system)	08.01-09.04		**0 281 002 405**
Boost pressure sensor, Diesel			
Mot.no. →3487098	08.01-09.04		**0 281 002 205**
Mot.no. 3487099→	08.01-09.04		**0 281 002 514**
C 35 C 10			**2,3 l 70 kW F1AE0481A*A... 4 Zyl.**
Phase sensor	09.02-03.06	NOC	**0 281 002 512**
Boost pressure sensor, Diesel	09.02-03.06		**0 281 002 514**
Temperature sensor, coolant, diesel	09.02-03.06		**0 281 002 209**
C 35 C 11			**2,8 l 78 kW 8140.43B.43... 4 Zyl.**
Speed sensor, diesel	05.01-09.02		**0 281 002 332**
High-pressure sensor (CR system)	05.01-09.02		**0 281 002 405**
Boost pressure sensor, Diesel			
Mot.no. →3487098	05.01-09.02		**0 281 002 205**
Mot.no. 3487099→	05.01-09.02		**0 281 002 514**
C 35 C 12			**2,3 l 85 kW F1AE0481B... 4 Zyl.**
Phase sensor	09.02-03.06	NOC	**0 281 002 512**
Boost pressure sensor, Diesel	09.02-03.06		**0 281 002 514**
Temperature sensor, coolant, diesel	09.02-03.06		**0 281 002 209**
C 35 C 13			**2,8 l 92 kW 8140.43S... 4 Zyl.**
Speed sensor, diesel	05.99-09.04		**0 281 002 332**
High-pressure sensor (CR system)	05.99-09.04		**0 281 002 405**
Boost pressure sensor, Diesel			
Mot.no. →3487098	05.99-09.04		**0 281 002 205**
Mot.no. 3487099→	05.99-09.04		**0 281 002 514**
C 35 C 14			**3,0 l 100 kW F1CE0481A... 4 Zyl.**
Phase sensor	09.04-03.06	NOC	**0 281 002 667**
Boost pressure sensor, Diesel	09.04-03.06		**0 281 002 437**
Temperature sensor, coolant, diesel	09.04-03.06		**0 281 002 209**
C 35 C 15			**2,8 l 108 kW 8140.43N.43... 4 Zyl.**
Speed sensor, diesel	05.01-09.04		**0 281 002 332**
High-pressure sensor (CR system)	05.01-09.04		**0 281 002 405**
Boost pressure sensor, Diesel			
Mot.no. →3487098	05.01-09.04		**0 281 002 205**
Mot.no. 3487099→	05.01-09.04		**0 281 002 514**
C 35 C 17			**3,0 l 122 kW F1CE0481B... 4 Zyl.**
Phase sensor	09.04-03.06	NOC	**0 281 002 667**
Boost pressure sensor, Diesel	09.04-03.06		**0 281 002 437**
Temperature sensor, coolant, diesel	09.04-03.06		**0 281 002 209**
C 40 C 13			**2,8 l 92 kW 8140.43S... 4 Zyl.**
Speed sensor, diesel	01.01-09.04		**0 281 002 332**
High-pressure sensor (CR system)	01.01-09.04		**0 281 002 405**
Boost pressure sensor, Diesel			
Mot.no. →3487098	01.01-09.04		**0 281 002 205**
Mot.no. 3487099→	01.01-09.04		**0 281 002 514**
C 40 C 14			**3,0 l 100 kW F1CE0481A... 4 Zyl.**
Phase sensor	09.04-03.06	NOC	**0 281 002 667**
Boost pressure sensor, Diesel	09.04-03.06		**0 281 002 437**
Temperature sensor, coolant, diesel	09.04-03.06		**0 281 002 209**
C 40 C 15			**2,8 l 108 kW 8140.43N.43... 4 Zyl.**
Speed sensor, diesel	04.03-09.04		**0 281 002 332**
High-pressure sensor (CR system)	04.03-09.04		**0 281 002 405**

Product			
Boost pressure sensor, Diesel			
Mot.no. →3487098	04.03-09.04		**0 281 002 205**
Mot.no. 3487099→	04.03-09.04		**0 281 002 514**
C 40 C 17		**3,0 l 122 kW F1CE0481B... 4 Zyl.**	
Phase sensor	09.04-03.06	NOC	**0 281 002 667**
Boost pressure sensor, Diesel	09.04-03.06		**0 281 002 437**
Temperature sensor, coolant, diesel	09.04-03.06		**0 281 002 209**
C 45 C 13		**2,8 l 92 kW 8140.43S... 4 Zyl.**	
Speed sensor, diesel	01.01-09.04		**0 281 002 332**
High-pressure sensor (CR system)	01.01-09.04		**0 281 002 405**
Boost pressure sensor, Diesel			
Mot.no. →3487098	01.01-09.04		**0 281 002 205**
Mot.no. 3487099→	01.01-09.04		**0 281 002 514**
C 50 C 11		**2,8 l 78 kW 8140.43B.43... 4 Zyl.**	
Speed sensor, diesel	05.01-09.04		**0 281 002 332**
High-pressure sensor (CR system)	05.01-09.04		**0 281 002 405**
Boost pressure sensor, Diesel			
Mot.no. →3487098	05.01-09.04		**0 281 002 205**
Mot.no. 3487099→	05.01-09.04		**0 281 002 514**
C 50 C 13		**2,8 l 92 kW 8140.43S... 4 Zyl.**	
Speed sensor, diesel	05.99-09.04		**0 281 002 332**
High-pressure sensor (CR system)	05.99-09.04		**0 281 002 405**
Boost pressure sensor, Diesel			
Mot.no. →3487098	05.99-09.04		**0 281 002 205**
Mot.no. 3487099→	05.99-09.04		**0 281 002 514**
C 50 C 14		**3,0 l 100 kW F1CE0481A... 4 Zyl.**	
Phase sensor	09.04-03.06	NOC	**0 281 002 667**
Boost pressure sensor, Diesel	09.04-03.06		**0 281 002 437**
Temperature sensor, coolant, diesel	09.04-03.06		**0 281 002 209**
C 50 C 15		**2,8 l 108 kW 8140.43N.43... 4 Zyl.**	
Speed sensor, diesel	05.01-09.04		**0 281 002 332**
High-pressure sensor (CR system)	05.01-09.04		**0 281 002 405**
Boost pressure sensor, Diesel			
Mot.no. →3487098	05.01-09.04		**0 281 002 205**
Mot.no. 3487099→	05.01-09.04		**0 281 002 514**
C 50 C 17		**3,0 l 122 kW F1CE0481B... 4 Zyl.**	
Phase sensor	09.04-03.06	NOC	**0 281 002 667**
Boost pressure sensor, Diesel	09.04-03.06		**0 281 002 437**
Temperature sensor, coolant, diesel	09.04-03.06		**0 281 002 209**
C 65 C 14		**3,0 l 100 kW F1CE0481A... 4 Zyl.**	
Phase sensor	09.04-03.06	NOC	**0 281 002 667**
Boost pressure sensor, Diesel	09.04-03.06		**0 281 002 437**
Temperature sensor, coolant, diesel	09.04-03.06		**0 281 002 209**
C 65 C 15		**2,8 l 108 kW 8140.43N.43... 4 Zyl.**	
Speed sensor, diesel	05.00-09.04		**0 281 002 332**
High-pressure sensor (CR system)	05.00-09.04		**0 281 002 405**
Boost pressure sensor, Diesel			
Mot.no. →3487098	05.00-09.04		**0 281 002 205**
Mot.no. 3487099→	05.00-09.04		**0 281 002 514**
C 65 C 17		**3,0 l 122 kW F1CE0481B... 4 Zyl.**	
Phase sensor	09.04-03.06	NOC	**0 281 002 667**
Boost pressure sensor, Diesel	09.04-03.06		**0 281 002 437**
Temperature sensor, coolant, diesel	09.04-03.06		**0 281 002 209**
L 29 L 9		**2,8 l 66 kW 8140.43R... 4 Zyl.**	
Speed sensor, diesel	08.01-09.02		**0 281 002 332**
High-pressure sensor (CR system)	08.01-09.02		**0 281 002 405**
Boost pressure sensor, Diesel			
Mot.no. →3487098	08.01-09.02		**0 281 002 205**
Mot.no. 3487099→	08.01-09.02		**0 281 002 514**
L 29 L 10		**2,3 l 70 kW F1AE0481A... 4 Zyl.**	
Phase sensor	09.02-03.06	NOC	**0 281 002 512**
Boost pressure sensor, Diesel	09.02-03.06		**0 281 002 514**
Temperature sensor, coolant, diesel	09.02-03.06		**0 281 002 209**

Product			
L 29 L 12		**2,3 l 85 kW F1AE0481B... 4 Zyl.**	
Phase sensor	09.02-03.06	NOC	**0 281 002 512**
Boost pressure sensor, Diesel	09.02-03.06		**0 281 002 514**
Temperature sensor, coolant, diesel	09.02-03.06		**0 281 002 209**
L 29 L 13		**2,8 l 92 kW 8140.43S... 4 Zyl.**	
Speed sensor, diesel	10.00-03.06		**0 281 002 332**
High-pressure sensor (CR system)	10.00-03.06		**0 281 002 405**
Boost pressure sensor, Diesel			
Mot.no. →3487098	10.00-03.06		**0 281 002 205**
Mot.no. 3487099→	10.00-03.06		**0 281 002 514**
L 29 L 14		**2,3 l 100 kW F1AE0481M... 4 Zyl.**	
Phase sensor	09.04-03.06	NOC	**0 281 002 512**
Boost pressure sensor, Diesel	09.04-03.06		**0 281 002 514**
Temperature sensor, coolant, diesel	09.04-03.06		**0 281 002 209**
S 35 S 9		**2,8 l 66 kW 8140.43R... 4 Zyl.**	
Speed sensor, diesel	08.01-03.06		**0 281 002 332**
High-pressure sensor (CR system)	08.01-03.06		**0 281 002 405**
Boost pressure sensor, Diesel			
Mot.no. →3487098	08.01-03.06		**0 281 002 205**
Mot.no. 3487099→	08.01-03.06		**0 281 002 514**
S 35 S 10		**2,3 l 70 kW F1AE0481A... 4 Zyl.**	
Phase sensor	09.02-03.06	NOC	**0 281 002 512**
Boost pressure sensor, Diesel	09.02-03.06		**0 281 002 514**
Temperature sensor, coolant, diesel	09.02-03.06		**0 281 002 209**
S 35 S 11		**2,8 l 78 kW 8140.43B.43... 4 Zyl.**	
Speed sensor, diesel	05.01-03.06		**0 281 002 332**
High-pressure sensor (CR system)	05.01-03.06		**0 281 002 405**
Boost pressure sensor, Diesel			
Mot.no. →3487098	05.01-03.06		**0 281 002 205**
Mot.no. 3487099→	05.01-03.06		**0 281 002 514**
S 35 S 12		**2,3 l 85 kW F1AE0481B... 4 Zyl.**	
Phase sensor	09.02-03.06	NOC	**0 281 002 512**
Boost pressure sensor, Diesel	09.02-03.06		**0 281 002 514**
Temperature sensor, coolant, diesel	09.02-03.06		**0 281 002 209**
S 35 S 13		**2,8 l 92 kW 8140.43S... 4 Zyl.**	
Speed sensor, diesel	05.99-03.06		**0 281 002 332**
High-pressure sensor (CR system)	05.99-03.06		**0 281 002 405**
Boost pressure sensor, Diesel			
Mot.no. →3487098	05.99-03.06		**0 281 002 205**
Mot.no. 3487099→	05.99-03.06		**0 281 002 514**
S 35 S 14		**2,3 l 100 kW F1AE0481M... 4 Zyl.**	
Phase sensor	09.04-03.06	NOC	**0 281 002 512**
Boost pressure sensor, Diesel	09.04-03.06		**0 281 002 514**
Temperature sensor, coolant, diesel	09.04-03.06		**0 281 002 209**
S 35 S 15		**2,8 l 108 kW 8140.43N.43... 4 Zyl.**	
Speed sensor, diesel	05.01-03.06		**0 281 002 332**
High-pressure sensor (CR system)	05.01-03.06		**0 281 002 405**
Boost pressure sensor, Diesel			
Mot.no. →3487098	05.01-03.06		**0 281 002 205**
Mot.no. 3487099→	05.01-03.06		**0 281 002 514**
S 35 S 17		**3,0 l 122 kW F1CE0481B... 4 Zyl.**	
Phase sensor	09.04-03.06	NOC	**0 281 002 667**
Boost pressure sensor, Diesel	09.04-03.06		**0 281 002 437**
Temperature sensor, coolant, diesel	09.04-03.06		**0 281 002 209**

Daily Chassi

35 .13		**2,8 l 92 kW 8140.43S 4 Zyl.**	
Speed sensor, diesel	10.05→		**0 281 002 332**
High-pressure sensor (CR system)	10.05→		**0 281 002 405**
Boost pressure sensor, Diesel	10.05→		**0 281 002 514**
Temperature sensor, coolant, diesel	10.05→		**0 281 002 170**

Product

◀ Daily Chassi

50 .13			**2,8 l 92 kW 8140.43S 4 Zyl.**
Speed sensor, diesel	10.05→		**0 281 002 332**
High-pressure sensor (CR system)	10.05→		**0 281 002 405**
Boost pressure sensor, Diesel	10.05→		**0 281 002 514**
Temperature sensor, coolant, diesel	10.05→		**0 281 002 170**

Daily, Grinta

New Daily A45-10 Turbo			**2,5 l 76 kW 8140.27S.27... 4 Zyl.**
Wheel speed sensor, front	07.89-04.96		**0 265 050 012**
Wheel speed sensor, rear	02.90-02.96		**0 265 050 029**
New Daily 30-8, 35-8			**2,5 l 55 kW 8140.07.27... 4 Zyl.**
Wheel speed sensor, front	02.91-04.96		**0 265 050 012**
Wheel speed sensor, rear	02.91-02.96		**0 265 050 029**
New Daily 35-10 Turbo			**2,5 l 66,1-68,9 kW 8140.97.27... 4 Zyl.**
Wheel speed sensor, front	07.91-04.96		**0 265 050 012**
Wheel speed sensor, rear	07.91-02.96		**0 265 050 029**
New Daily 35-10 Turbo I.D.			**2,5 l 80 kW 8140.47R.2790 4 Zyl.**
Air flow sensor, diesel	07.92-04.97		**0 281 002 087**
Pulse generator, diesel	07.92-04.97		**0 281 002 089**
Temperature sensor, coolant, diesel	07.92-04.97		**0 280 130 026**
Pedal position sensor, diesel	07.92-04.97		**0 205 001 201**
Wheel speed sensor, front	07.92-04.97		**0 265 050 012**
Wheel speed sensor, rear	07.92-02.96		**0 265 050 029**
New Daily 40-8			**2,5 l 55 kW 8140.07.27... 4 Zyl.**
Wheel speed sensor, front	07.89-04.96		**0 265 050 012**
Wheel speed sensor, rear	02.90-02.96		**0 265 050 029**
New Daily 40-10 Turbo 4x4			**2,5 l 76 kW 8140.27S.28... 4 Zyl.**
Wheel speed sensor, front	09.89-04.96		**0 265 050 012**
Wheel speed sensor, rear	02.90-02.96		**0 265 050 029**
Turbo Daily A45-12 Turbo			**2,5 l 85 kW 8140.47.27... 4 Zyl.**
Wheel speed sensor, front	06.90-04.96		**0 265 050 012**
Wheel speed sensor, rear	06.90-02.96		**0 265 050 029**
Turbo Daily 35-10 Turbo			**2,5 l 80 kW 8140.47R... 4 Zyl.**
Wheel speed sensor, rear			
Fg.no. →5115972	07.92-04.97		**0 265 050 026**
Turbo Daily 35-10 Turbo			**2,8 l 76 kW 8140.23.37...; 8140.23.3713 4 Zyl.**
Wheel speed sensor, rear			
Fg.no. →5115972	05.96-05.99		**0 265 050 026**
Turbo Daily 35-12 Turbo			**2,5 l 85 kW 8140.47.27... 4 Zyl.**
Wheel speed sensor, front	10.90-04.96		**0 265 050 012**
Wheel speed sensor, rear	10.90-02.96		**0 265 050 029**
Turbo Daily 49-12 Turbo			**2,5 l 85 kW 8140.47.27... 4 Zyl.**
Wheel speed sensor, front	06.90-04.96		**0 265 050 012**
Wheel speed sensor, rear	06.90-02.96		**0 265 050 029**
Turbo Daily 59-12 Turbo			**2,5 l 85 kW 8140.47.27... 4 Zyl.**
Wheel speed sensor, front	05.91-04.96		**0 265 050 012**
Wheel speed sensor, rear	05.91-02.96		**0 265 050 029**

Scudato

60 .13			**2,8 l 92 kW 8140.43S 4 Zyl.**
Speed sensor, diesel	10.05→		**0 281 002 332**
High-pressure sensor (CR system)	10.05→		**0 281 002 405**
Boost pressure sensor, Diesel	10.05→		**0 281 002 514**
Temperature sensor, coolant, diesel	10.05→		**0 281 002 170**

Product

JAGUAR

Daimler

3.6			**3,6 l 136/165 kW ; AJ6.4 6 Zyl.**
Wheel speed sensor, front	10.86-08.89	LAB	**0 265 001 095**
		RAB	**0 265 001 094**
Wheel speed sensor, rear	10.86-08.89		**0 265 001 096**

Sovereign

2.9			**2,9 l 104 kW AJ 6 6 Zyl.**
Throttle valve sensor	10.86-08.90		**0 280 120 301**
Air mass meter, gasoline injection	10.86-08.90		**0 280 213 001**
Pulse generator, ignition/Jetronic	10.86-08.90		**0 261 210 041**
Temperature sensor, coolant, injection system	10.86-08.90		**0 280 130 032**
Wheel speed sensor, front	10.86-08.90	LAB	**0 265 001 095**
		RAB	**0 265 001 094**
Wheel speed sensor, rear	10.86-08.90		**0 265 001 096**
2.9			**2,9 l 123 kW AJ 6 6 Zyl.**
Throttle valve sensor	10.86-08.90		**0 280 120 301**
Air mass meter, gasoline injection	10.86-08.90		**0 280 213 001**
Temperature sensor, coolant, injection system	10.86-08.90		**0 280 130 032**
Wheel speed sensor, front	10.86-08.90	LAB	**0 265 001 095**
		RAB	**0 265 001 094**
Wheel speed sensor, rear	10.86-08.90		**0 265 001 096**
3.6			**3,6 l 135/170 kW AJ6.4 6 Zyl.**
Wheel speed sensor, front	10.86-08.89	LAB	**0 265 001 095**
		RAB	**0 265 001 094**
Wheel speed sensor, rear	10.86-08.89		**0 265 001 096**

XJ S Coupé

5.3			**5,3 l 183 kW 12 Zyl.**
Relay, Jetronic	07.81-12.89		**0 332 014 113**
		DID	**0 332 014 112**
5.3			**5,3 l 183 kW HE V12 12 Zyl.**
Relay, Jetronic	07.81-12.87		**0 332 014 411**
5.3 V12			**5,3 l 222-227 kW 12 Zyl.**
Relay, Jetronic	03.90-12.97		**0 332 014 113**
		DID	**0 332 014 112**

XJ 6

2.9			**2,9 l 110 kW AJ6 6 Zyl.**
Throttle valve sensor	10.86-12.88		**0 280 120 301**
Air mass meter, gasoline injection	10.86-12.88		**0 280 213 001**
Pulse generator, ignition/Jetronic	10.86-12.88		**0 261 210 041**
Temperature sensor, coolant, injection system	10.86-12.88		**0 280 130 032**
Wheel speed sensor, front			
Fg.no. →594575	10.86-12.88	LAB	**0 265 001 095**
		RAB	**0 265 001 094**
Wheel speed sensor, rear			
Fg.no. →594575	10.86-12.88		**0 265 001 096**
2.9			**2,9 l 123 kW AJ 6 6 Zyl.**
Throttle valve sensor	10.86-08.90		**0 280 120 301**
Air mass meter, gasoline injection	10.86-08.90		**0 280 213 001**
Temperature sensor, coolant, injection system	10.86-08.90		**0 280 130 032**
Wheel speed sensor, front			
Fg.no. →594575	10.86-08.90	LAB	**0 265 001 095**
		RAB	**0 265 001 094**

Product				
Wheel speed sensor, rear				
Fg.no. →594575		10.86-08.90		**0 265 001 096**
3.2 24V				**3,2 l 146-149 kW 9BPMNA 6 Zyl.**
Wheel speed sensor, front		10.90-09.94	LAB	**0 265 001 095**
			RAB	**0 265 001 094**
Wheel speed sensor, rear		10.90-09.94		**0 265 001 096**
3.6				**3,6 l 136/170 kW AJ6.4 6 Zyl.**
Wheel speed sensor, front		10.86-08.89	LAB	**0 265 001 095**
			RAB	**0 265 001 094**
Wheel speed sensor, rear		10.86-08.89		**0 265 001 096**
4.2				**4,2 l 147 kW 6 Zyl.**
Air flow sensor, gasoline injection	S	03.79-10.86		**0 280 203 006**
				0 986 280 022
Air mass meter, gasoline injection		03.79-10.86		**0 280 203 005**
				0 986 280 047
Relay, Jetronic		03.79-10.86		**0 332 014 113**
4.2				**4,2 l 147-151 kW 6 Zyl.**
Air flow sensor, gasoline injection		03.79-10.86		**0 280 203 006**
				0 986 280 022
Relay, Jetronic		03.79-10.86		**0 332 014 113**

XJ 12

5.3 HE				**5,3 l 183 kW 12 Zyl.**
Relay, Jetronic		07.81-09.94	DID	**0 332 014 112**
Wheel speed sensor, front		01.90-09.94	LAB	**0 265 001 270**
			RAB	**0 265 001 269**
Wheel speed sensor, rear		01.90-09.94	LAB	**0 265 001 272**
			RAB	**0 265 001 271**
5.3 HE				**5,3 l 194 kW 12 Zyl.**
Relay, Jetronic		07.81-09.94		**0 332 014 411**
Wheel speed sensor, front		01.90-09.94	LAB	**0 265 001 270**
			RAB	**0 265 001 269**
Wheel speed sensor, rear		01.90-09.94	LAB	**0 265 001 272**
			RAB	**0 265 001 271**
5.3 HE				**5,3 l 197-198 kW 12 Zyl.**
Wheel speed sensor, front		01.90-09.94	LAB	**0 265 001 270**
			RAB	**0 265 001 269**
Wheel speed sensor, rear		01.90-09.94	LAB	**0 265 001 272**
			RAB	**0 265 001 271**

X-Type

2.0 [CF1]				**2,1 l 115 kW 2.1lV6 6 Zyl.**
Wheel speed sensor, front		03.02→		**0 265 007 879**
Wheel speed sensor, rear		03.02→	AA	**0 265 007 879**
			LAB,NAA	**0 265 007 417**
			NAA,RAB	**0 265 007 404**
2.0 D [CF1]				**2,0 l 96 kW R4-X404 4 Zyl.**
Wheel speed sensor, front		09.03→		**0 265 007 879**
Wheel speed sensor, rear		09.03→	AA	**0 265 007 879**
			LAB,NAA	**0 265 007 417**
			NAA,RAB	**0 265 007 404**
2.5 [CF1]				**2,5 l 145 kW 6 Zyl.**
Wheel speed sensor, front		03.01→		**0 265 007 879**
Wheel speed sensor, rear		03.01→	AA	**0 265 007 879**
			LAB,NAA	**0 265 007 417**
			NAA,RAB	**0 265 007 404**
3.0 [CF1]				**3,0 l 169-172 kW AJ-V6 6 Zyl.**
Wheel speed sensor, front		03.01→		**0 265 007 879**
Wheel speed sensor, rear		03.01→	AA	**0 265 007 879**
			LAB,NAA	**0 265 007 417**
			NAA,RAB	**0 265 007 404**

X-Type Estate

2.0 [CF1]				**2,1 l 115 kW 2.1lV6 6 Zyl.**
Wheel speed sensor, front		03.03→		**0 265 007 879**
Wheel speed sensor, rear		03.03→	AA	**0 265 007 879**
			LAB,NAA	**0 265 007 417**
			NAA,RAB	**0 265 007 404**
2.0 D [CF1]				**2,0 l 96 kW R4-X404 4 Zyl.**
Wheel speed sensor, front		09.03→		**0 265 007 879**
Wheel speed sensor, rear		09.03→	AA	**0 265 007 879**
			LAB,NAA	**0 265 007 417**
			NAA,RAB	**0 265 007 404**
2.5 [CF1]				**2,5 l 145 kW 6 Zyl.**
Wheel speed sensor, front		09.03→		**0 265 007 879**
Wheel speed sensor, rear		09.03→	AA	**0 265 007 879**
			LAB,NAA	**0 265 007 417**
			NAA,RAB	**0 265 007 404**
3.0 [CF1]				**3,0 l 169-172 kW AJ-V6 6 Zyl.**
Wheel speed sensor, front		09.03→		**0 265 007 879**
Wheel speed sensor, rear		09.03→	AA	**0 265 007 879**
			LAB,NAA	**0 265 007 417**
			NAA,RAB	**0 265 007 404**

JEEP

Cherokee

2.5 D Turbo [XJ]				**2,5 l 85-89 kW ENC,ENO 4 Zyl.**
Temperature sensor, coolant, diesel		10.95-12.01		**0 280 130 055**

KIA

Avella

1.3 i				**1,3 l 54 kW B3 4 Zyl.**
Throttle valve sensor		03.94→		**0 280 122 001**

Capital

1.5 i				**1,5 l 85 kW B5D 4 Zyl.**
Throttle valve sensor		05.90-06.95		**0 280 120 316**
Air flow sensor, gasoline injection		05.90-06.95		**0 280 202 125**
Position sensor for TDC		05.90-06.95		**0 356 914 224**
Speed sensor, ignition/injection		05.90-06.95		**0 261 210 065**
Temperature sensor, coolant, injection system		05.90-06.95		**0 280 130 026**
Relay, Jetronic		05.90-05.93		**0 332 019 150**
Relay, pump		05.90-04.93		**0 332 019 453**

Carens II

2.0 CRDi				**2,0 l 85 kW 4 Zyl.**
Air mass meter, diesel		02.02-04.06		**0 281 002 447**

Carnival II

2.9 CRDi				**2,9 l 107 kW J3 4 Zyl.**
Air mass meter, diesel		01.02-03.06		**0 281 002 554**

K

Product		

Clarus I

1.8 16V [GC]		**1,8 l 85 kW T8D 4 Zyl.**
Air mass meter, gasoline injection	05.96-05.98	**0 280 217 116**
Speed sensor, ignition/injection	05.96-05.98	**0 261 210 104**
1.8 16V [GC]		**1,8 l 92 kW T8D 4 Zyl.**
Air mass meter, gasoline injection	05.96-05.98	**0 280 217 116**
2.0 16V [GC]		**2,0 l 98/109 kW FE 4 Zyl.**
Air mass meter, gasoline injection	05.96-05.98	**0 280 217 116**

Opirus

3.5 V6 [LD]		**3,5 l 149 kW G6CU 6 Zyl.**
Air mass meter, gasoline injection	09.03→	**0 280 218 090**

Sephia I

1.5 i 16V [FA]		**1,5 l 74 kW B5D 4 Zyl.**
Air mass meter, gasoline injection	10.97-12.00	**0 280 217 105**
1.6 i [FA]		**1,6 l 59 kW B6 4 Zyl.**
Position sensor for TDC	07.93-06.95	**0 356 914 213**
1.8 i 16V [FA]		**1,8 l 82 kW T8D 4 Zyl.**
Air mass meter, gasoline injection	09.96-12.97	**0 280 217 116**

Sephia I Hatchback

1.8 i 16V [FA]		**1,8 l 82 kW T8D 4 Zyl.**
Air mass meter, gasoline injection	09.96-12.00	**0 280 217 116**

Sephia I Leo

1.8 i 16V [FA]		**1,8 l 104 kW T8D 4 Zyl.**
Throttle valve sensor	09.96-09.97	**0 280 122 001**
Air mass meter, gasoline injection	09.96-09.97	**0 280 217 116**
Speed sensor, ignition/injection	09.96-09.97	**0 261 210 104**

Sorento

2.5 CRDi		**2,5 l 107 kW 4 Zyl.**
Air mass meter, diesel	05.00→	**0 281 002 554**
2.5 CRDi [JC]		**2,5 l 103 kW D4CB 4 Zyl.**
Air mass meter, diesel	07.02→	**0 281 002 554**
3.5 i V6 [JC]		**3,5 l 144 kW G6CU 6 Zyl.**
Air mass meter, gasoline injection	03.03→	**0 280 218 090**

Sportage

2.0 i 4WD [JA]		**2,0 l 70 kW FED 4 Zyl.**
Throttle valve sensor	07.93-09.98	**0 280 122 001**
Air mass meter, gasoline injection	07.93-09.98	**0 280 217 105**
Relay, pump	07.93-09.98	**0 332 019 151**
2.0 i 4WD [JA]		**2,0 l 73 kW FED 4 Zyl.**
Throttle valve sensor	07.93-08.04	**0 280 122 001**
Air mass meter, gasoline injection	07.93-08.04	**0 280 217 105**
Speed sensor, ignition/injection	07.93-08.04	**0 261 210 065**
Relay, pump	07.93-08.04	**0 332 019 151**
2.0 i 4WD [JA]		**2,0 l 94 kW FED 4 Zyl.**
Throttle valve sensor	04.94-10.98	**0 280 122 001**
Air mass meter, gasoline injection	04.94-10.98	**0 280 217 105**
Relay, pump	04.94-10.98	**0 332 019 151**
2.0 TD 4WD		**2,0 l 61 kW RF 4 Zyl.**
Speed sensor, diesel	11.96-10.98	**0 261 210 104**

Product		

LADA

Kalina

1.4		**1,4 l 65,5 kW 11194 4 Zyl.**
Air mass meter, gasoline injection	07.07→	**0 280 218 116**
1.6		**1,6 l 59,5/65,5 kW 21114-50; 21114-90; 21124 4 Zyl.**
Air mass meter, gasoline injection	11.04→	**0 280 218 116**

Kalina Hatchback

1.4		**1,4 l 65,5 kW 11194 4 Zyl.**
Air mass meter, gasoline injection	07.07→	**0 280 218 116**
1.6		**1,6 l 59,5 kW 21114-50 4 Zyl.**
Air mass meter, gasoline injection	07.06→	**0 280 218 116**

Kalina Kombi

1.4		**1,4 l 65,5 kW 11194 4 Zyl.**
Air mass meter, gasoline injection	07.07→	**0 280 218 116**
1.6		**1,6 l 59,5 kW 21114-50 4 Zyl.**
Air mass meter, gasoline injection	07.07→	**0 280 218 116**

Niva

1.7 i		**1,7 l 59-62 kW VAZ 2121.4 4 Zyl.**
Air mass meter, gasoline injection	07.96-12.99 BO,WW	**0 280 218 004**
1.7 i		**1,7 l 60/62 kW VAZ; VAZ 2121.3 4 Zyl.**
Air mass meter, gasoline injection	07.99-12.00	**0 280 218 004**

Priora

1.6		**1,6 l 72 kW 21126 4 Zyl.**
Air mass meter, gasoline injection	11.06→	**0 280 218 116**

Samara

1.3 i		**1,3 l 50 kW 2108 4 Zyl.**
Air mass meter, gasoline injection	02.96→	**0 280 218 004**
1.5 i		**1,5 l 50/52/60 kW 2111 4 Zyl.**
Air mass meter, gasoline injection	09.91→ BO,WW	**0 280 218 004**

Samara Hatchback

1.5 i		**1,5 l 57 kW 2111 4 Zyl.**
Air mass meter, gasoline injection	01.84→ BO,WW	**0 280 218 004**

Serie 110

1.5		**1,5 l 54 kW 2110 4 Zyl.**
Air mass meter, gasoline injection	01.96-12.00	**0 280 218 004**
1.5 i 8V		**1,5 l 56/57 kW 2111-14/16; 2111/2111-12 4 Zyl.**
Air mass meter, gasoline injection	01.96→ BO,WW	**0 280 218 004**
1.5 i 16V		**1,5 l 67/69 kW 2112/-10; 2112/-10,-14; 2112-70/76 4 Zyl.**
Air mass meter, gasoline injection	01.96→ BO,WW	**0 280 218 004**
1.5 16V Premier		**1,5 l 68 kW 2112 4 Zyl.**
Air mass meter, gasoline injection	06.99-12.00 BO,WW	**0 280 218 004**
2.0 GTI		**2,0 l 110 kW C20XE 4 Zyl.**
Wheel speed sensor, front	01.97-12.00	**0 265 006 330**
Wheel speed sensor, rear	01.97-12.00	**0 265 002 276**

K

Product			
2.0 16V			**2,0 l 110 kW C20XE 4 Zyl.**
Wheel speed sensor, front	01.96-12.00		**0 265 006 330**
Wheel speed sensor, rear	01.96-12.00		**0 265 002 276**

Serie 111

1.5 i			**1,5 l 57-58 kW 2111 4 Zyl.**
Air mass meter, gasoline injection	01.96→	BO,WW	**0 280 218 004**
1.5 i 8V			**1,5 l 57 kW 2111-14 4 Zyl.**
Air mass meter, gasoline injection	01.96→	BO,WW	**0 280 218 004**
1.5 i 16V			**1,5 l 67/69/70 kW 2112; 2112-10; 2112-10/16 4 Zyl.**
Air mass meter, gasoline injection	01.96→	BO,WW	**0 280 218 004**

Serie 112

1.5 i			**1,5 l 54 kW 4 Zyl.**
Air mass meter, gasoline injection	01.96→	BO,WW	**0 280 218 004**
1.5 i 8V			**1,5 l 56/57 kW 2111-14; 2111/2111-12 4 Zyl.**
Air mass meter, gasoline injection	01.96→	BO,WW	**0 280 218 004**
1.5 i 16V			**1,5 l 66/67/69 kW 2112; 2112-10 4 Zyl.**
Air mass meter, gasoline injection	01.96→	BO,WW	**0 280 218 004**

Serie 115

1.3 i			**1,3 l 47 kW 2114 4 Zyl.**
Air mass meter, gasoline injection	01.00→		**0 280 218 004**
1.5 i			**1,5 l 57 kW 2114 4 Zyl.**
Air mass meter, gasoline injection	01.00→		**0 280 218 004**

LAMBORGHINI (S+L+H)

Countach

Quattrovalvole			**5,2 l 309 kW L 507 V4 l 12 Zyl.**
Air flow sensor, gasoline injection	09.85-07.90		**0 438 120 098**

LANCIA

Dedra Berlina

1.6 i [835]			**1,6 l 55 kW 835C1.000 Kat 4 Zyl.**
Speed sensor, ignition/injection	04.93-10.94		**0 261 210 103**
	04.93-09.93	KL	**0 261 210 102**
	10.93-10.94	KL	**0 261 210 115**
Temperature sensor, coolant, injection system	04.93-10.94		**0 280 130 026**
Wheel speed sensor, rear	04.93-10.94	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.6 i [835]			**1,6 l 57 kW 835A1.046 Kat 4 Zyl.**
Temperature sensor, coolant, injection system	08.89-03.93		**0 280 130 026**
1.6 i [835]			**1,6 l 66 kW 159B9.000 MPI-GM 4 Zyl.**
Wheel speed sensor, front	10.94-08.95		**0 265 001 215**
	09.95-04.98		**0 265 006 212**
Wheel speed sensor, rear	09.95-04.98		**0 265 006 197**
	10.94-08.95	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.6 i 16V [835]			**1,6 l 76 kW 182A4.000 MPI-Weber 4 Zyl.**
Wheel speed sensor, front	04.98-10.99		**0 265 006 212**
Wheel speed sensor, rear	04.98-10.99		**0 265 006 197**
1.8 i [835]			**1,8 l 74 kW 836A5.000 MPI-Weber 4 Zyl.**
Wheel speed sensor, front	10.94-08.95		**0 265 001 215**
	09.95-12.95		**0 265 006 212**
Wheel speed sensor, rear	09.95-12.95		**0 265 006 197**
	10.94-08.95	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.8 i [835]			**1,8 l 77 kW 835A2.046 Kat 4 Zyl.**
Wheel speed sensor, front	04.93-10.94		**0 265 001 215**
Wheel speed sensor, rear	04.93-10.94	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.8 i 16V [835]			**1,8 l 97 kW 183A1.000 MPI-Hit. 4 Zyl.**
Wheel speed sensor, front	01.96-10.99		**0 265 006 212**
Wheel speed sensor, rear	01.96-10.99		**0 265 006 197**
1.9 TD [835]			**1,9 l 66 kW 835A4.000 4 Zyl.**
Wheel speed sensor, front	01.89-10.94		**0 265 001 215**
Wheel speed sensor, rear	01.89-10.94	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.9 TD [835]			**1,9 l 66 kW 835A4.000/160D1.000 4 Zyl.**
Wheel speed sensor, front	09.95-10.99		**0 265 006 212**
Wheel speed sensor, rear	10.94-10.99		**0 265 006 197**
2.0 i [835]			**2,0 l 83/86 kW 835A5.000 MPI-Weber; 835A5.046 Kat 4 Zyl.**
Wheel speed sensor, front	01.89-10.94		**0 265 001 215**
Wheel speed sensor, rear	01.89-10.94	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
2.0 i [835]			**2,0 l 119/132 kW 835A8.000 MPI-Weber; 835A8.046 Kat 4 Zyl.**
Acceleration sensor, ABS	06.90-07.92		**0 265 005 030**
Lateral acceleration sensor, brake system	06.90-10.94		**0 265 005 031**
Wheel speed sensor, front	06.90-10.94		**0 265 006 212**
Wheel speed sensor, rear	06.90-10.94		**0 265 006 197**
2.0 i Automatic [835]			**2,0 l 83 kW 835A5.046 Kat 4 Zyl.**
Wheel speed sensor, front	10.94-08.95		**0 265 001 215**
Wheel speed sensor, rear	10.94-08.95	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
2.0 i 4x4 Integrale [835]			**2,0 l 121/124 kW 835A7.000; 835A7.046 Kat 4 Zyl.**
Wheel speed sensor, front	06.90-10.94		**0 265 001 215**
Wheel speed sensor, rear	06.90-10.94		**0 265 001 304**
2.0 i 16V [835]			**2,0 l 102 kW 836A3.000 MPI-Weber 4 Zyl.**
Wheel speed sensor, front	09.95-10.99		**0 265 006 212**
Wheel speed sensor, rear	10.94-10.99		**0 265 006 197**

Dedra Station Wagon

1.6 i [835]			**1,6 l 66 kW 159B9.000 MPI-GM 4 Zyl.**
Wheel speed sensor, front	10.94-08.95		**0 265 001 215**
	09.95-04.98		**0 265 006 212**
Wheel speed sensor, rear	09.95-04.98		**0 265 006 197**
	10.94-08.95	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.6 i 16V [835]			**1,6 l 76 kW 182A4.000 MPI-Weber 4 Zyl.**
Wheel speed sensor, front	04.98-10.99		**0 265 006 212**
Wheel speed sensor, rear	04.98-10.99		**0 265 006 197**
1.8 i [835]			**1,8 l 74 kW 836A5.000 MPI-Weber 4 Zyl.**
Wheel speed sensor, front	10.94-08.95		**0 265 001 215**
	09.95-12.95		**0 265 006 212**
Wheel speed sensor, rear	09.95-12.95		**0 265 006 197**
	10.94-08.95	LAB	**0 265 001 216**
		RAB	**0 265 001 217**
1.8 i 16V [835]			**1,8 l 83/97 kW 182A2.000 MPI-Hit.; 183A1.000 MPI-Hit. 4 Zyl.**
Wheel speed sensor, front	01.96-10.99		**0 265 006 212**
Wheel speed sensor, rear	01.96-10.99		**0 265 006 197**
1.9 TD [835]			**1,9 l 66 kW 835A4.000/160D1.000 4 Zyl.**
Wheel speed sensor, front	09.95-10.99		**0 265 006 212**
Wheel speed sensor, rear	10.94-10.99		**0 265 006 197**
2.0 i 16V, i 16V 4x4 [835]			**2,0 l 102 kW 836A3.000 MPI-Weber 4 Zyl.**
Wheel speed sensor, front	09.95-10.99		**0 265 006 212**
Wheel speed sensor, rear	10.94-10.99		**0 265 006 197**

Product

Delta

1.4 i [836 Nuova D.]	**1,4 l 51 kW 160A1.046 SPI-Bosch 4 Zyl.**		
Speed sensor, ignition/injection	01.93-04.94		**0 261 210 115**
Temperature sensor, coolant, injection system	01.93-04.94		**0 280 130 026**
Wheel speed sensor, front	01.93-04.94		**0 265 006 212**
Wheel speed sensor, rear	01.93-04.94		**0 265 006 197**
1.4 i [836 Nuova D.]	**1,4 l 51 kW 836A4.000 SPI-Bosch 4 Zyl.**		
Speed sensor, ignition/injection	04.94-12.99		**0 261 210 115**
		KL	**0 261 210 118**
Temperature sensor, coolant, injection system	04.94-12.99		**0 280 130 026**
Wheel speed sensor, front	09.95-12.99		**0 265 006 162**
	04.94-08.95		**0 265 006 212**
Wheel speed sensor, rear	04.94-12.99		**0 265 006 197**
1.6 i [836 Nuova D.]	**1,6 l 55 kW 835C1.000 SPI-Bosch 4 Zyl.**		
Speed sensor, ignition/injection	01.93-09.93		**0 261 210 103**
	10.93-12.99		**0 261 210 118**
	01.93-09.93	KL	**0 261 210 102**
	10.93-12.99	KL	**0 261 210 115**
Temperature sensor, coolant, injection system	01.93-12.99		**0 280 130 026**
Wheel speed sensor, front	09.95-12.99		**0 265 006 162**
	01.93-08.95		**0 265 006 212**
Wheel speed sensor, rear	01.93-12.99		**0 265 006 197**
1.6 i 16V HPE [836 Nuova D.]	**1,6 l 66/76 kW 182A4.000, 182A6.000 MPI-Weber 4 Zyl.**		
Wheel speed sensor, front	01.96-12.99		**0 265 006 212**
Wheel speed sensor, rear	01.96-12.99		**0 265 006 197**
1.8 i [836 Nuova D.]	**1,8 l 66/74/76 kW 835C2.000, 835/836C4.000, 836A5.000, 836A6.000 MPI-Weber 4 Zyl.**		
Wheel speed sensor, front	09.95-12.99		**0 265 006 162**
	01.93-08.95		**0 265 006 212**
Wheel speed sensor, rear	01.93-12.99		**0 265 006 197**
1.8 i GT 16V [836 Nuova D.]	**1,8 l 97 kW 183A1.000 MPI-Hit. 4 Zyl.**		
Wheel speed sensor, front	01.96-12.99		**0 265 006 212**
Wheel speed sensor, rear	01.96-12.99		**0 265 006 197**
1.8 i 16V [836 Nuova D.]	**1,8 l 83 kW 182A2.000 MPI-Hit. 4 Zyl.**		
Wheel speed sensor, front	01.96-12.99		**0 265 006 212**
Wheel speed sensor, rear	01.96-12.99		**0 265 006 197**
1.9 TD [836 Nuova D.]	**1,9 l 66 kW 160D1.000 4 Zyl.**		
Wheel speed sensor, front	10.95-12.99		**0 265 006 162**
Wheel speed sensor, rear	10.95-12.99		**0 265 006 197**
1.9 TD [836 Nuova D.]	**1,9 l 66 kW 835A4.000 4 Zyl.**		
Wheel speed sensor, front	09.95-10.95		**0 265 006 162**
	07.94-08.95		**0 265 006 212**
Wheel speed sensor, rear	07.94-10.95		**0 265 006 197**
2.0 i HF Turbo Int. 4x4 [831]	**2,0 l 122/126/136 kW 831B5.000/C5.000 MPI-Weber; 831C5.046 Kat 4 Zyl.**		
Wheel speed sensor, front	05.86-02.89	LAB	**0 265 001 246**
		RAB	**0 265 001 247**
Wheel speed sensor, rear	05.86-02.89	LAB	**0 265 001 248**
		RAB	**0 265 001 249**
2.0 i Turbo 8V Int. 4x4 [831]	**2,0 l 126 kW 831C5.046 Kat 4 Zyl.**		
Wheel speed sensor, front	03.89-12.94	LAB	**0 265 001 246**
		RAB	**0 265 001 247**
Wheel speed sensor, rear	03.89-12.94	LAB	**0 265 001 248**
		RAB	**0 265 001 249**
2.0 i Turbo 16V Int. 4x4 [831]	**2,0 l 136 kW 831E5.046 Kat 4 Zyl.**		
Knock sensor	06.91-12.94		**0 261 231 095**
Wheel speed sensor, front	06.91-12.94	LAB	**0 265 001 246**
		RAB	**0 265 001 247**
Wheel speed sensor, rear	06.91-12.94	LAB	**0 265 001 248**
		RAB	**0 265 001 249**
2.0 i Turbo 16V Int. 4x4 [831]	**2,0 l 144-147 kW 831E5.000 MPI-Weber 4 Zyl.**		
Wheel speed sensor, front	06.91-12.94	LAB	**0 265 001 246**
		RAB	**0 265 001 247**
Wheel speed sensor, rear	06.91-12.94	LAB	**0 265 001 248**
		RAB	**0 265 001 249**
2.0 i Turbo 16V Int. 4x4 [831]	**2,0 l 147 kW 831D5.000 MPI-Weber 4 Zyl.**		
Acceleration sensor, ABS	03.89-09.91		**0 265 005 030**
Lateral acceleration sensor, brake system	03.89-09.91		**0 265 005 031**
Wheel speed sensor, front	03.89-09.91	LAB	**0 265 001 246**
		RAB	**0 265 001 247**
Wheel speed sensor, rear	03.89-09.91	LAB	**0 265 001 248**
		RAB	**0 265 001 249**
2.0 i 16V [836 Nuova D.]	**2,0 l 102 kW 836A3.000 MPI-Weber 4 Zyl.**		
Knock sensor	01.93-12.95		**0 261 231 102**
Wheel speed sensor, front	09.95-12.95		**0 265 006 162**
	01.93-08.95		**0 265 006 212**
Wheel speed sensor, rear	01.93-12.95		**0 265 006 197**
2.0 i 16V Turbo HPE [836 Nuova D.]	**2,0 l 137 kW 175A4.000 MPI-Weber 4 Zyl.**		
Wheel speed sensor, front	09.96-12.99		**0 265 006 162**
Wheel speed sensor, rear	09.96-12.99		**0 265 006 197**
2.0 i 16V Turbo HPE [836 Nuova D.]	**2,0 l 137 kW 836A2.000 MPI-Weber 4 Zyl.**		
Wheel speed sensor, front	09.95-09.96		**0 265 006 162**
	01.93-08.95		**0 265 006 212**
Wheel speed sensor, rear	01.93-09.96		**0 265 006 197**

Kappa Berlina

2.0 i Turbo 16V [838]	**2,0 l 151 kW 838A4.000 4 Zyl.**		
Throttle valve sensor	11.94-06.98		**0 280 122 001**
Air mass meter, gasoline injection	11.94-06.98		**0 280 213 025**
			0 986 280 114
Phase sensor	11.94-06.98		**0 232 101 018**
Pulse generator, ignition/Jetronic	11.94-06.98		**0 261 210 130**
Knock sensor	11.94-06.98		**0 261 231 007**
Pressure sensor, intake manifold, gasoline	11.94-06.98		**0 280 101 001**
Temperature sensor, intake air, injection system	11.94-06.98		**0 280 130 060**
Temperature sensor, coolant, injection system	11.94-06.98		**0 280 130 026**
Relay, Jetronic	11.94-06.98		**0 332 014 140**
Wheel speed sensor, front	11.94-06.98		**0 265 006 160**
Wheel speed sensor, rear			
Fg.no. 2059704→	11.94-06.98		**0 265 007 040**
Ricam.no →2059703	11.94-06.98		**0 265 006 300**
2.0 i Turbo 20V [838]	**2,0 l 162 kW 175A3.000 5 Zyl.**		
Throttle valve sensor	06.98-12.00		**0 280 122 001**
Air mass meter, gasoline injection	06.98-12.00		**0 280 217 514**
Phase sensor	06.98-12.00		**0 232 101 026**
Pulse generator, ignition/Jetronic	06.98-12.00		**0 261 210 119**
Knock sensor	06.98-12.00		**0 261 231 095**
Pressure sensor, intake manifold, gasoline	06.98-12.00		**0 280 101 001**
Temperature sensor, intake air, injection system	06.98-12.00		**0 280 130 060**
Temperature sensor, coolant, injection system	06.98-12.00		**0 280 130 026**
Relay, Jetronic	06.98-12.00		**0 332 014 140**
Wheel speed sensor, front	06.98-12.00		**0 265 006 160**
Wheel speed sensor, rear	06.98-12.00		**0 265 007 040**
2.0 i 20V [838]	**2,0 l 110 kW 838A1.000 5 Zyl.**		
Throttle valve sensor	11.94-06.96		**0 280 122 001**
		AG	**0 280 122 005**
Air mass meter, gasoline injection	11.94-06.96		**0 280 217 111**
Phase sensor	11.94-06.96		**0 232 101 026**
Pulse generator, ignition/Jetronic	11.94-06.96		**0 261 210 119**
Knock sensor	11.94-06.96		**0 261 231 095**
Temperature sensor, intake air, injection system	11.94-06.96		**0 280 130 073**

L

Product			
Temperature sensor, coolant, injection system	11.94-06.96		**0 280 130 026**
		AG	**0 280 130 032**
Relay, Jetronic	11.94-06.96		**0 332 014 140**
Wheel speed sensor, front	11.94-06.96		**0 265 006 160**
Wheel speed sensor, rear			
Fg.no. 2059704→	11.94-06.96		**0 265 007 040**
Ricam.no →2059703	11.94-06.96		**0 265 006 300**
2.0 i 20V [838]	**2,0 l 114 kW 838A6.000 5 Zyl.**		
Throttle valve sensor	06.96-12.00		**0 280 122 001**
Air mass meter, gasoline injection	06.96-06.98		**0 280 217 111**
	06.98-12.00		**0 280 218 019**
Phase sensor	06.96-06.98		**0 232 101 026**
	06.98-12.00		**0 232 101 036**
Speed sensor, ignition/injection	06.98-12.00		**0 261 210 160**
Pulse generator, ignition/Jetronic	06.96-06.98		**0 261 210 119**
Knock sensor	06.96-06.98		**0 261 231 095**
	06.98-12.00		**0 261 231 144**
Temperature sensor, intake air, injection system	06.96-12.00		**0 280 130 073**
Temperature sensor, coolant, injection system	06.96-12.00		**0 280 130 026**
Pedal position sensor, EMS (electronic engine management)	06.98-12.00		**0 281 002 202**
Relay, Jetronic	06.96-12.00		**0 332 014 140**
Wheel speed sensor, front	06.96-06.98		**0 265 006 160**
	06.98-12.00	LAB	**0 265 007 041**
		RAB	**0 265 007 042**
Wheel speed sensor, rear	06.96-12.00		**0 265 007 040**
2.4 i 20V [838]	**2,4 l 129 kW 838A2.000 5 Zyl.**		
Throttle valve sensor	11.94-06.98		**0 280 122 001**
Air mass meter, gasoline injection	11.94-06.98		**0 280 217 111**
Phase sensor	11.94-06.98		**0 232 101 026**
Pulse generator, ignition/Jetronic	11.94-06.98		**0 261 210 119**
Knock sensor	11.94-06.98		**0 261 231 095**
Temperature sensor, intake air, injection system	11.94-06.98		**0 280 130 073**
Temperature sensor, coolant, injection system	11.94-06.98		**0 280 130 026**
Relay, Jetronic	11.94-06.98		**0 332 014 140**
Wheel speed sensor, front	11.94-06.98		**0 265 006 160**
Wheel speed sensor, rear			
Fg.no. 2059704→	11.94-06.98		**0 265 007 040**
Ricam.no →2059703	11.94-06.98		**0 265 006 300**
2.4 i 20V [838]	**2,4 l 129 kW 838B2.000 5 Zyl.**		
Throttle valve sensor	06.98-12.00		**0 280 122 001**
Air mass meter, gasoline injection	06.98-12.00		**0 280 218 019**
Phase sensor	06.98-12.00		**0 232 101 036**
Speed sensor, ignition/injection	06.98-12.00		**0 261 210 160**
Knock sensor	06.98-12.00		**0 261 231 144**
Temperature sensor, intake air, injection system	06.98-12.00		**0 280 130 073**
Temperature sensor, coolant, injection system	06.98-12.00		**0 280 130 026**
Pedal position sensor, EMS (electronic engine management)	06.98-12.00		**0 281 002 202**
Relay, Jetronic	06.98-12.00		**0 332 014 140**
Wheel speed sensor, front	06.98-12.00	LAB	**0 265 007 041**
		RAB	**0 265 007 042**
Wheel speed sensor, rear	06.98-12.00		**0 265 007 040**
2.4 JTD [838]	**2,4 l 100 kW 838A8.000 5 Zyl.**		
Air mass meter, diesel	03.98-12.00		**0 280 218 019**
Speed sensor, diesel	03.98-12.00		**0 281 002 214**
Phase sensor	03.98-12.00		**0 281 002 213**
High-pressure sensor (CR system)	03.98-12.00		**0 281 002 210**
Boost pressure sensor, Diesel	03.98-12.00		**0 281 002 215**
Temperature sensor, fuel	03.98-12.00	2PO	**0 281 002 209**
Pedal position sensor, diesel	03.98-12.00		**0 281 002 202**

Product			
Wheel speed sensor, front	03.98-12.00	LAB	**0 265 007 041**
		RAB	**0 265 007 042**
Wheel speed sensor, rear	03.98-12.00		**0 265 007 040**
2.4 TD [838]	**2,4 l 91 kW 838A3.000; 838A7.000 5 Zyl.**		
Air flow sensor, diesel	11.94-03.98		**0 281 002 085**
Pulse generator, diesel	11.94-03.98		**0 261 210 119**
Temperature sensor, coolant, diesel	11.94-03.98		**0 280 130 026**
Pedal position sensor, diesel	11.94-03.98		**0 205 001 010**
Wheel speed sensor, front	11.94-03.98		**0 265 006 160**
Wheel speed sensor, rear			
Fg.no. 2059704→	11.94-03.98		**0 265 007 040**
Ricam.no →2059703	11.94-03.98		**0 265 006 300**
3.0 i 24V [838]	**3,0 l 150 kW 838B.000 6 Zyl.**		
Throttle valve sensor	11.94-12.00		**0 280 122 001**
Air mass meter, gasoline injection	11.94-06.98		**0 280 217 514**
Fg.no. →2088054	06.98-12.99		**0 280 217 514**
Fg.no. 2088054→	12.99-12.00		**0 280 217 531**
Phase sensor	11.94-12.00		**0 232 103 009**
Pulse generator, ignition/Jetronic	11.94-12.00		**0 261 210 113**
Knock sensor	11.94-12.00		**0 261 231 007**
Temperature sensor, intake air, injection system	11.94-12.00		**0 280 130 073**
Temperature sensor, coolant, injection system	11.94-12.00		**0 280 130 026**
Wheel speed sensor, front	11.94-06.98		**0 265 006 160**
	06.98-12.00	LAB	**0 265 007 041**
		RAB	**0 265 007 042**
Wheel speed sensor, rear			
Fg.no. →2059704	11.94-12.00		**0 265 006 300**
Fg.no. 2059704→	11.94-12.00		**0 265 007 040**
3.0 i 24V [838]	**3,0 l 150 kW 838.000 6 Zyl.**		
Throttle valve sensor	06.98-12.00		**0 280 122 001**
Air mass meter, gasoline injection			
Fg.no. →2092370	06.98-12.00		**0 280 217 514**
Fg.no. 2092371→	06.98-12.00		**0 280 217 531**
Pulse generator, ignition/Jetronic	06.98-12.00		**0 261 210 113**
Knock sensor	06.98-12.00		**0 261 231 007**
Temperature sensor, intake air, injection system	06.98-12.00		**0 280 130 073**
Temperature sensor, coolant, injection system	06.98-12.00		**0 280 130 026**
Wheel speed sensor, front	06.98-12.00		**0 265 006 160**
Wheel speed sensor, rear			
Fg.no. →2059704	06.98-12.00		**0 265 006 300**
Fg.no. 2059704→	06.98-12.00		**0 265 007 040**

Kappa Coupé

2.0 i Turbo 16V [838]	**2,0 l 151 kW 834A4.000 MPI-Bosch 4 Zyl.**		
Throttle valve sensor	04.97-06.98		**0 280 122 001**
Air mass meter, gasoline injection	04.97-06.98		**0 280 213 025**
			0 986 280 114
Phase sensor	04.97-06.98		**0 261 210 093**
Knock sensor	04.97-06.98		**0 261 231 095**
Temperature sensor, coolant, injection system	04.97-06.98		**0 280 130 026**
Relay, Jetronic	04.97-06.98		**0 332 014 140**
Wheel speed sensor, front	04.97-06.98		**0 265 006 160**
Wheel speed sensor, rear	04.97-06.98		**0 265 006 300**
2.0 i Turbo 20V [838]	**2,0 l 162 kW 175A3.000 MPI-Bosch 5 Zyl.**		
Throttle valve sensor	06.98-06.00		**0 280 122 001**
Air mass meter, gasoline injection	06.98-06.00		**0 280 217 514**
Phase sensor	06.98-06.00		**0 232 101 026**
Pulse generator, ignition/Jetronic	06.98-06.00		**0 261 210 119**
Knock sensor	06.98-06.00		**0 261 231 095**
Pressure sensor, intake manifold, gasoline	06.98-06.00		**0 280 101 001**
Temperature sensor, intake air, injection system	06.98-06.00		**0 280 130 060**
Temperature sensor, coolant, injection system	06.98-06.00		**0 280 130 026**

Product			
◀ Kappa Coupé			
Relay, Jetronic	06.98-06.00		**0 332 014 140**
Wheel speed sensor, front	06.98-06.00	LAB	**0 265 007 041**
		RAB	**0 265 007 042**
Wheel speed sensor, rear	06.98-06.00		**0 265 007 040**
2.4 i 20V [838]	**2,4 l 129 kW 838A2.000 MPI-RB 5 Zyl.**		
Throttle valve sensor	04.97-06.98		**0 280 122 001**
Air mass meter, gasoline injection	04.97-06.98		**0 280 217 111**
Phase sensor	04.97-06.98		**0 232 101 026**
Pulse generator, ignition/Jetronic	04.97-06.98		**0 261 210 119**
Knock sensor	04.97-06.98		**0 261 231 095**
Temperature sensor, intake air, injection system	04.97-06.98		**0 280 130 073**
Temperature sensor, coolant, injection system	04.97-06.98		**0 280 130 026**
Relay, Jetronic	04.97-06.98		**0 332 014 140**
Wheel speed sensor, front	04.97-06.98		**0 265 006 160**
Wheel speed sensor, rear	04.97-06.98		**0 265 007 040**
2.4 i 20V [838]	**2,4 l 129 kW 838B2.000 MPI-RB 5 Zyl.**		
Throttle valve assembly	06.98-06.00		**0 205 003 052**
Throttle valve sensor	06.98-06.00		**0 280 122 001**
Air mass meter, gasoline injection	06.98-06.00		**0 280 218 019**
Phase sensor	06.98-06.00		**0 232 101 026**
Pulse generator, ignition/Jetronic	06.98-06.00		**0 261 210 119**
Knock sensor	06.98-06.00		**0 261 231 095**
Temperature sensor, intake air, injection system	06.98-06.00		**0 280 130 073**
Temperature sensor, coolant, injection system	06.98-06.00		**0 280 130 026**
Relay, Jetronic	06.98-06.00		**0 332 014 140**
Wheel speed sensor, front	06.98-06.00	LAB	**0 265 007 041**
		RAB	**0 265 007 042**
Wheel speed sensor, rear	06.98-06.00		**0 265 007 040**
3.0 i 24V V6 [838]	**3,0 l 150 kW 838B.000 MPI-RB 6 Zyl.**		
Throttle valve sensor	04.97-06.00		**0 280 122 001**
Air mass meter, gasoline injection	04.97-06.00		**0 280 217 514**
Phase sensor	04.97-06.00		**0 232 103 009**
Pulse generator, ignition/Jetronic	04.97-06.00		**0 261 210 113**
Knock sensor	04.97-06.00		**0 261 231 007**
Temperature sensor, intake air, injection system	04.97-06.00		**0 280 130 073**
Temperature sensor, coolant, injection system	04.97-06.00		**0 280 130 026**
Wheel speed sensor, front	04.97-06.98		**0 265 006 160**
	06.98-06.00	LAB	**0 265 007 041**
		RAB	**0 265 007 042**
Wheel speed sensor, rear	04.97-06.98		**0 265 006 300**
	07.98-06.00		**0 265 007 040**

Kappa Station Wagon

Product			
2.0 i Turbo 16V [838]	**2,0 l 151 kW 838A4.000 4 Zyl.**		
Throttle valve sensor	11.94-06.98		**0 280 122 001**
Air mass meter, gasoline injection	11.94-06.98		**0 280 213 025**
			0 986 280 114
Phase sensor	11.94-06.98		**0 232 101 018**
Pulse generator, ignition/Jetronic	11.94-06.98		**0 261 210 130**
Knock sensor	11.94-06.98		**0 261 231 007**
Pressure sensor, intake manifold, gasoline	11.94-06.98		**0 280 101 001**
Temperature sensor, intake air, injection system	11.94-06.98		**0 280 130 060**
Temperature sensor, coolant, injection system	11.94-06.98		**0 280 130 026**
Relay, Jetronic	11.94-06.98		**0 332 014 140**
Wheel speed sensor, front	11.94-06.98		**0 265 006 160**
Wheel speed sensor, rear			
Fg.no. 2059704→	11.94-06.98		**0 265 007 040**
Ricam.no →2059703	11.94-06.98		**0 265 006 300**
2.0 i Turbo 20V [838]	**2,0 l 162 kW 175A3.000 5 Zyl.**		
Throttle valve sensor	06.98-12.00		**0 280 122 001**
Air mass meter, gasoline injection	06.98-12.00		**0 280 217 514**
Phase sensor	06.98-12.00		**0 232 101 026**
Pulse generator, ignition/Jetronic	06.98-12.00		**0 261 210 119**
Knock sensor	06.98-12.00		**0 261 231 095**
Pressure sensor, intake manifold, gasoline	06.98-12.00		**0 280 101 001**
Temperature sensor, intake air, injection system	06.98-12.00		**0 280 130 060**
Temperature sensor, coolant, injection system	06.98-12.00		**0 280 130 026**
Relay, Jetronic	06.98-12.00		**0 332 014 140**
Wheel speed sensor, front	06.98-12.00		**0 265 006 160**
Wheel speed sensor, rear	06.98-12.00		**0 265 007 040**
2.0 i 20V [838]	**2,0 l 114 kW 838A6.000 5 Zyl.**		
Throttle valve sensor	06.96-12.00		**0 280 122 001**
Air mass meter, gasoline injection	06.96-06.98		**0 280 217 111**
	06.98-12.00		**0 280 218 019**
Phase sensor	06.96-06.98		**0 232 101 026**
	06.98-12.00		**0 232 101 036**
Speed sensor, ignition/injection	06.98-12.00		**0 261 210 160**
Pulse generator, ignition/Jetronic	06.96-06.98		**0 261 210 119**
Knock sensor	06.96-06.98		**0 261 231 095**
	06.98-12.00		**0 261 231 144**
Temperature sensor, intake air, injection system	06.96-12.00		**0 280 130 073**
Temperature sensor, coolant, injection system	06.96-12.00		**0 280 130 026**
Pedal position sensor, EMS (electronic engine management)	06.98-12.00		**0 281 002 202**
Relay, Jetronic	06.96-12.00		**0 332 014 140**
Wheel speed sensor, front	06.96-06.98		**0 265 006 160**
	06.98-12.00	LAB	**0 265 007 041**
		RAB	**0 265 007 042**
Wheel speed sensor, rear	06.98-12.00		**0 265 007 040**
Fg.no. 2059704→	06.96-06.98		**0 265 007 040**
Ricam.no →2059703	06.96-06.98		**0 265 006 300**
2.4 D Turbo [838]	**2,4 l 91 kW 838A7.000 5 Zyl.**		
Air flow sensor, diesel	06.96-03.98		**0 281 002 085**
Pulse generator, diesel	06.96-03.98		**0 261 210 119**
Temperature sensor, coolant, diesel	06.96-03.98		**0 280 130 026**
Pedal position sensor, diesel	06.96-03.98		**0 205 001 010**
Wheel speed sensor, front	06.96-03.98		**0 265 006 160**
Wheel speed sensor, rear			
Fg.no. 2059704→	06.96-03.98		**0 265 007 040**
Ricam.no →2059703	06.96-03.98		**0 265 006 300**
2.4 i 20V [838]	**2,4 l 129 kW 838A2.000 5 Zyl.**		
Throttle valve sensor	11.94-06.98		**0 280 122 001**
Air mass meter, gasoline injection	11.94-06.98		**0 280 217 111**
Phase sensor	11.94-06.98		**0 232 101 026**
Pulse generator, ignition/Jetronic	11.94-06.98		**0 261 210 119**
Knock sensor	11.94-06.98		**0 261 231 095**
Temperature sensor, intake air, injection system	11.94-06.98		**0 280 130 073**
Temperature sensor, coolant, injection system	11.94-06.98		**0 280 130 026**
Relay, Jetronic	11.94-06.98		**0 332 014 140**
Wheel speed sensor, front	11.94-06.98		**0 265 006 160**
Wheel speed sensor, rear			
Fg.no. 2059704→	11.94-06.98		**0 265 007 040**
Ricam.no →2059703	11.94-06.98		**0 265 006 300**
2.4 i 20V [838]	**2,4 l 129 kW 838B2.000 5 Zyl.**		
Throttle valve sensor	06.98-12.00		**0 280 122 001**
Air mass meter, gasoline injection	06.98-12.00		**0 280 218 019**
Phase sensor	06.98-12.00		**0 232 101 036**
Speed sensor, ignition/injection	06.98-12.00		**0 261 210 160**
Knock sensor	06.98-12.00		**0 261 231 144**
Temperature sensor, intake air, injection system	06.98-12.00		**0 280 130 073**
Temperature sensor, coolant, injection system	06.98-12.00		**0 280 130 026**
Pedal position sensor, EMS (electronic engine management)	06.98-12.00		**0 281 002 202**
Relay, Jetronic	06.98-12.00		**0 332 014 140**

Product			
Wheel speed sensor, front	06.98-12.00	LAB	**0 265 007 041**
		RAB	**0 265 007 042**
Wheel speed sensor, rear	06.98-12.00		**0 265 007 040**
2.4 JTD [838]	**2,4 l 100 kW 838A8.000 5 Zyl.**		
Air mass meter, diesel	03.98-12.00		**0 280 218 019**
Speed sensor, diesel	03.98-12.00		**0 281 002 214**
Phase sensor	03.98-12.00		**0 281 002 213**
High-pressure sensor (CR system)	03.98-12.00		**0 281 002 210**
Boost pressure sensor, Diesel	03.98-12.00		**0 281 002 215**
Temperature sensor, fuel	03.98-12.00	2PO	**0 281 002 209**
Pedal position sensor, diesel	03.98-12.00		**0 281 002 202**
Wheel speed sensor, front	03.98-12.00	LAB	**0 265 007 041**
		RAB	**0 265 007 042**
Wheel speed sensor, rear	03.98-12.00		**0 265 007 040**
3.0 i 24V [838]	**3,0 l 150 kW 838B.000 6 Zyl.**		
Throttle valve sensor	11.94-12.00		**0 280 122 001**
Air mass meter, gasoline injection	11.94-06.98		**0 280 217 514**
Fg.no. →2088054	06.98-12.99		**0 280 217 514**
Fg.no. 2088054→	12.99-12.00		**0 280 217 531**
Phase sensor	11.94-12.00		**0 232 103 009**
Pulse generator, ignition/Jetronic	11.94-12.00		**0 261 210 113**
Knock sensor	11.94-12.00		**0 261 231 007**
Temperature sensor, intake air, injection system	11.94-12.00		**0 280 130 073**
Temperature sensor, coolant, injection system	11.94-12.00		**0 280 130 026**
Wheel speed sensor, front	11.94-06.98		**0 265 006 160**
	06.98-12.00	LAB	**0 265 007 041**
		RAB	**0 265 007 042**
Wheel speed sensor, rear			
Fg.no. →2059704	11.94-12.00		**0 265 006 300**
Fg.no. 2059704→	11.94-12.00		**0 265 007 040**

Lybra Berlina

1.6 i 16V [839]	**1,6 l 76 kW 182A4.000 4 Zyl.**		
Wheel speed sensor, front	10.99-09.00	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	10.99-09.00	LAB	**0 265 007 076**
		RAB	**0 265 007 075**
1.6 i 16V [839]	**1,6 l 76 kW 182B6.000 4 Zyl.**		
Wheel speed sensor, front	10.00-08.02	LAB	**0 265 007 073**
	09.02-09.05	LAB	**0 265 007 564**
	10.00-08.02	RAB	**0 265 007 074**
	09.02-09.05	RAB	**0 265 007 565**
Wheel speed sensor, rear	10.00-08.02	LAB	**0 265 007 076**
	09.02-09.05	LAB	**0 265 007 567**
	10.00-08.02	RAB	**0 265 007 075**
	09.02-09.05	RAB	**0 265 007 566**
1.8 i 16V [839]	**1,8 l 96 kW 839A4.000; 839A7.000 4 Zyl.**		
Air mass meter, gasoline injection	10.99-02.02		**0 280 218 019**
Phase sensor	10.99-02.02		**0 232 101 037**
Wheel speed sensor, front	10.99-02.02	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	10.99-02.02	LAB	**0 265 007 076**
		RAB	**0 265 007 075**
1.8 i 16V [839]	**1,8 l 96 kW 839A9.000 4 Zyl.**		
Air mass meter, gasoline injection	03.02-09.05		**0 280 218 019**
Phase sensor	03.02-09.05		**0 232 101 037**
Wheel speed sensor, front	03.02-08.02	LAB	**0 265 007 073**
	09.02-09.05	LAB	**0 265 007 564**
	03.02-08.02	RAB	**0 265 007 074**
	09.02-09.05	RAB	**0 265 007 565**

Product			
Wheel speed sensor, rear	03.02-08.02	LAB	**0 265 007 076**
	09.02-09.05	LAB	**0 265 007 567**
	03.02-08.02	RAB	**0 265 007 075**
	09.02-09.05	RAB	**0 265 007 566**
1.9 JTD [839]	**1,9 l 77 kW AR32302 4 Zyl.**		
Air mass meter, diesel	10.99-09.00		**0 280 218 019**
Speed sensor, diesel	10.99-09.00		**0 281 002 214**
Phase sensor	10.99-09.00		**0 281 002 213**
High-pressure sensor (CR system)	10.99-09.00		**0 281 002 210**
Boost pressure sensor, Diesel	10.99-09.00		**0 281 002 215**
Temperature sensor, fuel	10.99-09.00	2PO	**0 281 002 209**
Pedal position sensor, EMS (electronic engine management)	10.99-09.00		**0 281 002 202**
Wheel speed sensor, front	10.99-09.00	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	10.99-09.00	LAB	**0 265 007 076**
		RAB	**0 265 007 075**
1.9 JTD [839]	**1,9 l 80 kW AR37101 4 Zyl.**		
Air mass meter, diesel	09.00-06.01		**0 281 002 309**
Speed sensor, diesel	09.00-06.01		**0 281 002 474**
Phase sensor	09.00-06.01		**0 281 002 213**
High-pressure sensor (CR system)	09.00-06.01		**0 281 002 405**
Boost pressure sensor, Diesel	09.00-06.01		**0 281 002 215**
Temperature sensor, fuel	09.00-06.01	2PO	**0 281 002 209**
Pedal position sensor, EMS (electronic engine management)	09.00-06.01		**0 281 002 202**
Wheel speed sensor, front	09.00-06.01	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	09.00-06.01	LAB	**0 265 007 076**
		RAB	**0 265 007 075**
1.9 JTD [839]	**1,9 l 85 kW 937A2.000 4 Zyl.**		
Air mass meter, diesel	06.01-09.05		**0 281 002 309**
Speed sensor, diesel	06.01-06.03		**0 281 002 474**
	07.03-09.05		**0 281 002 603**
Phase sensor	06.01-09.05		**0 281 002 213**
High-pressure sensor (CR system)	06.01-02.04		**0 281 002 405**
Boost pressure sensor, Diesel	06.01-09.05		**0 281 002 215**
Temperature sensor, fuel	06.01-09.05	2PO	**0 281 002 209**
Pedal position sensor, EMS (electronic engine management)	06.01-09.05		**0 281 002 202**
Wheel speed sensor, front	06.01-08.02	LAB	**0 265 007 073**
	09.02-09.05	LAB	**0 265 007 564**
	06.01-08.02	RAB	**0 265 007 074**
	09.02-09.05	RAB	**0 265 007 565**
Wheel speed sensor, rear	06.01-08.02	LAB	**0 265 007 076**
	09.02-09.05	LAB	**0 265 007 567**
	06.01-08.02	RAB	**0 265 007 075**
	09.02-09.05	RAB	**0 265 007 566**
2.0 i 20V [839]	**2,0 l 110 kW 185A8.000 5 Zyl.**		
Throttle valve assembly	10.00-09.05		**0 205 003 052**
Air mass meter, gasoline injection	10.00-09.05		**0 281 002 309**
Phase sensor	10.00-09.05		**0 232 101 036**
Speed sensor, ignition/injection	10.00-09.05		**0 261 210 160**
Knock sensor	10.00-09.05		**0 261 231 144**
Pedal position sensor, EMS (electronic engine management)	10.00-09.05		**0 281 002 202**
Wheel speed sensor, front	10.00-08.02	LAB	**0 265 007 073**
	09.02-09.05	LAB	**0 265 007 564**
	10.00-08.02	RAB	**0 265 007 074**
	09.02-09.05	RAB	**0 265 007 565**

Product			

◀ Lybra Berlina

Wheel speed sensor, rear	10.00-08.02	LAB	**0 265 007 076**
	09.02-09.05	LAB	**0 265 007 567**
	10.00-08.02	RAB	**0 265 007 075**
	09.02-09.05	RAB	**0 265 007 566**
2.0 i 20V [839]	**2,0 l 113 kW 182B7.000 5 Zyl.**		
Throttle valve assembly	10.99-09.00		**0 205 003 052**
Air mass meter, gasoline injection	10.99-09.00		**0 280 218 019**
Phase sensor	10.99-09.00		**0 232 101 036**
Speed sensor, ignition/injection	10.99-09.00		**0 261 210 160**
Knock sensor	10.99-09.00		**0 261 231 144**
Pedal position sensor, EMS (electronic engine management)	10.99-09.00		**0 281 002 202**
Wheel speed sensor, front	10.99-09.00	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	10.99-09.00	LAB	**0 265 007 076**
		RAB	**0 265 007 075**
2.4 i 20V [839]	**2,4 l 129 kW 192A2.000 5 Zyl.**		
Throttle valve assembly	10.99-05.02		**0 205 003 052**
Air mass meter, gasoline injection	10.99-05.02		**0 281 002 309**
Phase sensor	10.99-05.02		**0 232 101 036**
Speed sensor, ignition/injection	10.99-05.02		**0 261 210 160**
Knock sensor	10.99-05.02		**0 261 231 144**
Pedal position sensor, EMS (electronic engine management)	10.99-05.02		**0 281 002 202**
Wheel speed sensor, front	10.99-05.02	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	10.99-05.02	LAB	**0 265 007 076**
		RAB	**0 265 007 075**
2.4 JTD [839]	**2,4 l 98 kW 839A5.000/AR32501 5 Zyl.**		
Air mass meter, diesel	10.99-09.00		**0 280 218 019**
Speed sensor, diesel	10.99-09.00		**0 281 002 214**
Phase sensor	10.99-09.00		**0 281 002 213**
High-pressure sensor (CR system)	10.99-09.00		**0 281 002 210**
Boost pressure sensor, Diesel	10.99-09.00		**0 281 002 215**
Temperature sensor, fuel	10.99-09.00	2PO	**0 281 002 209**
Pedal position sensor, EMS (electronic engine management)	10.99-09.00		**0 281 002 202**
Wheel speed sensor, front	10.99-09.00	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	10.99-09.00	LAB	**0 265 007 076**
		RAB	**0 265 007 075**
2.4 JTD [839]	**2,4 l 103 kW 839A6.000 5 Zyl.**		
Air mass meter, diesel	09.00-05.02		**0 281 002 309**
Speed sensor, diesel	09.00-05.02		**0 281 002 474**
Phase sensor	09.00-05.02		**0 281 002 213**
High-pressure sensor (CR system)	09.00-05.02		**0 281 002 405**
Boost pressure sensor, Diesel	09.00-05.02		**0 281 002 215**
Temperature sensor, fuel	09.00-05.02	2PO	**0 281 002 209**
Pedal position sensor, EMS (electronic engine management)	09.00-05.02		**0 281 002 202**
Wheel speed sensor, front	09.00-05.02	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	09.00-05.02	LAB	**0 265 007 076**
		RAB	**0 265 007 075**
2.4 JTD [839]	**2,4 l 110 kW 841C000 5 Zyl.**		
Air mass meter, diesel	10.03-09.05		**0 280 218 113**
	06.02-09.03		**0 281 002 309**
Speed sensor, diesel	06.02-06.03		**0 281 002 474**
	07.03-09.05		**0 281 002 603**
Phase sensor	06.02-09.05		**0 281 002 213**
High-pressure sensor (CR system)	06.02-09.05		**0 281 002 405**
Boost pressure sensor, Diesel	06.02-09.05		**0 281 002 215**
Temperature sensor, fuel	06.02-09.05	2PO	**0 281 002 209**

Product			

Pedal position sensor, EMS (electronic engine management)	06.02-09.05		**0 281 002 202**
Wheel speed sensor, front	06.02-08.02	LAB	**0 265 007 073**
	09.02-09.05	LAB	**0 265 007 564**
	06.02-08.02	RAB	**0 265 007 074**
	09.02-09.05	RAB	**0 265 007 565**
Wheel speed sensor, rear	06.02-08.02	LAB	**0 265 007 076**
	09.02-09.05	LAB	**0 265 007 567**
	06.02-08.02	RAB	**0 265 007 075**
	09.02-09.05	RAB	**0 265 007 566**

Lybra Station Wagon

1.6 i 16V [839]	**1,6 l 76 kW 182A4.000 4 Zyl.**		
Air mass meter, gasoline injection	10.99-09.00		**0 280 218 019**
Wheel speed sensor, front	10.99-09.00	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	10.99-09.00	LAB	**0 265 007 076**
		RAB	**0 265 007 075**
1.6 i 16V [839]	**1,6 l 76 kW 182B6.000 4 Zyl.**		
Air mass meter, gasoline injection	10.00-09.05		**0 280 218 019**
Wheel speed sensor, front	10.00-08.02	LAB	**0 265 007 073**
	09.02-09.05	LAB	**0 265 007 564**
	10.00-08.02	RAB	**0 265 007 074**
	09.02-09.05	RAB	**0 265 007 565**
Wheel speed sensor, rear	10.00-08.02	LAB	**0 265 007 076**
	09.02-09.05	LAB	**0 265 007 567**
	10.00-08.02	RAB	**0 265 007 075**
	09.02-09.05	RAB	**0 265 007 566**
1.8 i 16V [839]	**1,8 l 96 kW 839A4.000; 839A7.000 4 Zyl.**		
Air mass meter, gasoline injection	10.99-02.02		**0 280 218 019**
Phase sensor	10.99-02.02		**0 232 101 037**
Wheel speed sensor, front	10.99-02.02	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	10.99-02.02	LAB	**0 265 007 076**
		RAB	**0 265 007 075**
1.8 i 16V [839]	**1,8 l 96 kW 839A9.000 4 Zyl.**		
Air mass meter, gasoline injection	03.02-09.05		**0 280 218 019**
Phase sensor	03.02-09.05		**0 232 101 037**
Wheel speed sensor, front	03.02-08.02	LAB	**0 265 007 073**
	09.02-09.05	LAB	**0 265 007 564**
	03.02-08.02	RAB	**0 265 007 074**
	09.02-09.05	RAB	**0 265 007 565**
Wheel speed sensor, rear	03.02-08.02	LAB	**0 265 007 076**
	09.02-09.05	LAB	**0 265 007 567**
	03.02-08.02	RAB	**0 265 007 075**
	09.02-09.05	RAB	**0 265 007 566**
1.9 JTD [839]	**1,9 l 77 kW AR32302 4 Zyl.**		
Air mass meter, diesel	10.99-09.00		**0 280 218 019**
Speed sensor, diesel	10.99-09.00		**0 281 002 214**
Phase sensor	10.99-09.00		**0 281 002 213**
High-pressure sensor (CR system)	10.99-09.00		**0 281 002 210**
Boost pressure sensor, Diesel	10.99-09.00		**0 281 002 215**
Temperature sensor, fuel	10.99-09.00	2PO	**0 281 002 209**
Pedal position sensor, EMS (electronic engine management)	10.99-09.00		**0 281 002 202**
Wheel speed sensor, front	10.99-09.00	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	10.99-09.00	LAB	**0 265 007 076**
		RAB	**0 265 007 075**
1.9 JTD [839]	**1,9 l 80 kW AR37101 4 Zyl.**		
Air mass meter, diesel	09.00-06.01		**0 281 002 309**
Speed sensor, diesel	09.00-06.01		**0 281 002 474**

Product			
Phase sensor	09.00-06.01		**0 281 002 213**
High-pressure sensor (CR system)	09.00-06.01		**0 281 002 405**
Boost pressure sensor, Diesel	09.00-06.01		**0 281 002 215**
Temperature sensor, fuel	09.00-06.01	2PO	**0 281 002 209**
Pedal position sensor, EMS (electronic engine management)	09.00-06.01		**0 281 002 202**
Wheel speed sensor, front	09.00-06.01	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	09.00-06.01	LAB	**0 265 007 076**
		RAB	**0 265 007 075**
1.9 JTD [839]	**1,9 l 85 kW 937A2.000 4 Zyl.**		
Air mass meter, diesel	06.01-09.05		**0 281 002 309**
Speed sensor, diesel	06.01-06.03		**0 281 002 474**
	07.03-09.05		**0 281 002 603**
Phase sensor	06.01-09.05		**0 281 002 213**
High-pressure sensor (CR system)	06.01-02.04		**0 281 002 405**
Boost pressure sensor, Diesel	06.01-09.05		**0 281 002 215**
Temperature sensor, fuel	06.01-09.05	2PO	**0 281 002 209**
Pedal position sensor, EMS (electronic engine management)	06.01-09.05		**0 281 002 202**
Wheel speed sensor, front	06.01-08.02	LAB	**0 265 007 073**
	09.02-09.05	LAB	**0 265 007 564**
	06.01-08.02	RAB	**0 265 007 074**
	09.02-09.05	RAB	**0 265 007 565**
Wheel speed sensor, rear	06.01-08.02	LAB	**0 265 007 076**
	09.02-09.05	LAB	**0 265 007 567**
	06.01-08.02	RAB	**0 265 007 075**
	09.02-09.05	RAB	**0 265 007 566**
2.0 i 20V [839]	**2,0 l 113 kW 182B7.000 4 Zyl.**		
Throttle valve assembly	10.99-09.00		**0 205 003 052**
Air mass meter, gasoline injection	10.99-09.00		**0 280 218 019**
Phase sensor	10.99-09.00		**0 232 101 036**
Speed sensor, ignition/injection	10.99-09.00		**0 261 210 160**
Knock sensor	10.99-09.00		**0 261 231 144**
Pedal position sensor, EMS (electronic engine management)	10.99-09.00		**0 281 002 202**
Wheel speed sensor, front	10.99-09.00	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	10.99-09.00	LAB	**0 265 007 076**
		RAB	**0 265 007 075**
2.0 i 20V [839]	**2,0 l 113 kW 185A8.000 4 Zyl.**		
Throttle valve assembly	10.00-09.05		**0 205 003 052**
Air mass meter, gasoline injection	10.00-09.05		**0 281 002 309**
Phase sensor	10.00-09.05		**0 232 101 036**
Speed sensor, ignition/injection	10.00-09.05		**0 261 210 160**
Knock sensor	10.00-09.05		**0 261 231 144**
Pedal position sensor, EMS (electronic engine management)	10.00-09.05		**0 281 002 202**
Wheel speed sensor, front	10.00-08.02	LAB	**0 265 007 073**
	09.02-09.05	LAB	**0 265 007 564**
	10.00-08.02	RAB	**0 265 007 074**
	09.02-09.05	RAB	**0 265 007 565**
Wheel speed sensor, rear	10.00-08.02	LAB	**0 265 007 076**
	09.02-09.05	LAB	**0 265 007 567**
	10.00-08.02	RAB	**0 265 007 075**
	09.02-09.05	RAB	**0 265 007 566**
2.4 JTD [839]	**2,4 l 98 kW 839A5.000/AR32501 5 Zyl.**		
Air mass meter, diesel	10.99-09.00		**0 280 218 019**
Speed sensor, diesel	10.99-09.00		**0 281 002 214**
Phase sensor	10.99-09.00		**0 281 002 213**
High-pressure sensor (CR system)	10.99-09.00		**0 281 002 210**
Boost pressure sensor, Diesel	10.99-09.00		**0 281 002 215**
Temperature sensor, fuel	10.99-09.00	2PO	**0 281 002 209**

Product			
Pedal position sensor, EMS (electronic engine management)	10.99-09.00		**0 281 002 202**
Wheel speed sensor, front	10.99-09.00	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	10.99-09.00	LAB	**0 265 007 076**
		RAB	**0 265 007 075**
2.4 JTD [839]	**2,4 l 103 kW 839A6.000 5 Zyl.**		
Air mass meter, diesel	09.00-05.02		**0 281 002 309**
Speed sensor, diesel	09.00-05.02		**0 281 002 474**
Phase sensor	09.00-05.02		**0 281 002 213**
High-pressure sensor (CR system)	09.00-05.02		**0 281 002 405**
Boost pressure sensor, Diesel	09.00-05.02		**0 281 002 215**
Temperature sensor, fuel	09.00-05.02	2PO	**0 281 002 209**
Pedal position sensor, EMS (electronic engine management)	09.00-05.02		**0 281 002 202**
Wheel speed sensor, front	09.00-05.02	LAB	**0 265 007 073**
		RAB	**0 265 007 074**
Wheel speed sensor, rear	09.00-05.02	LAB	**0 265 007 076**
		RAB	**0 265 007 075**
2.4 JTD [839]	**2,4 l 110 kW 841C000 5 Zyl.**		
Air mass meter, diesel	10.03-09.05		**0 280 218 113**
	06.02-09.03		**0 281 002 309**
Speed sensor, diesel	06.02-06.03		**0 281 002 474**
	07.03-09.05		**0 281 002 603**
Phase sensor	06.02-09.05		**0 281 002 213**
High-pressure sensor (CR system)	06.02-09.05		**0 281 002 405**
Boost pressure sensor, Diesel	06.02-09.05		**0 281 002 215**
Temperature sensor, fuel	06.02-09.05	2PO	**0 281 002 209**
Pedal position sensor, EMS (electronic engine management)	06.02-09.05		**0 281 002 202**
Wheel speed sensor, front	06.02-08.02	LAB	**0 265 007 073**
	09.02-09.05	LAB	**0 265 007 564**
	06.02-08.02	RAB	**0 265 007 074**
	09.02-09.05	RAB	**0 265 007 565**
Wheel speed sensor, rear	06.02-08.02	LAB	**0 265 007 076**
	09.02-09.05	LAB	**0 265 007 567**
	06.02-08.02	RAB	**0 265 007 075**
	09.02-09.05	RAB	**0 265 007 566**

Musa

1.3 MJTD [184]	**1,3 l 51 kW 188A9000 4 Zyl.**		
Air mass meter, diesel	10.04→		**0 281 002 613**
Boost pressure sensor, Diesel			
Mot.no. →1376014	10.04→		**0 281 002 510**
Mot.no. 1376015→	10.04→		**0 281 002 844**
Acceleration sensor, ABS	10.04→		**0 265 005 127**
Yaw rate sensor, brake system	10.04-12.05		**0 265 005 241**
Wheel speed sensor, front	10.04-03.07		**0 265 007 830**
Wheel speed sensor, rear	10.04-03.07		**0 265 007 503**
1.3 MJTD 16V [184]	**1,3 l 66 kW 199A3000 4 Zyl.**		
Air mass meter, diesel	01.06→		**0 281 002 792**
Acceleration sensor, ABS	01.06→		**0 265 005 127**
Wheel speed sensor, front	01.06-03.07		**0 265 007 830**
Wheel speed sensor, rear	01.06-03.07		**0 265 007 503**
1.4 [184]	**1,4 l 55 kW 350A1000 4 Zyl.**		
Air mass meter, gasoline injection	03.05→		**0 281 002 613**
Pressure sensor, intake manifold, gasoline	03.05→		**0 261 230 030**
Acceleration sensor, ABS	03.05→		**0 265 005 127**
Yaw rate sensor, brake system	03.05-12.05		**0 265 005 241**
Wheel speed sensor, front	03.05-03.07		**0 265 007 830**
Wheel speed sensor, rear	03.05-03.07		**0 265 007 503**

Product

◀ Musa

1.4 16V [184]	**1,4 l 66/70 kW 192B2000; 843A1000 4 Zyl.**		
Air mass meter, gasoline injection	10.04→		**0 281 002 613**
Speed sensor, ignition/injection	10.04→		**0 261 210 238**
Knock sensor	10.04→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	10.04→		**0 261 230 030**
Acceleration sensor, ABS	10.04→		**0 265 005 127**
Yaw rate sensor, brake system	10.04-12.05		**0 265 005 241**
Wheel speed sensor, front	10.04-03.07		**0 265 007 830**
Wheel speed sensor, rear	10.04-03.07		**0 265 007 503**
1.9 JTD [184]	**1,9 l 74 kW 188B2000 4 Zyl.**		
Speed sensor, diesel	10.04→		**0 281 002 603**
Phase sensor	10.04→		**0 281 002 213**
High-pressure sensor (CR system)	10.04→		**0 281 002 534**
Boost pressure sensor, Diesel	10.04→		**0 281 002 845**
Acceleration sensor, ABS	10.04→		**0 265 005 127**
Yaw rate sensor, brake system	10.04-12.05		**0 265 005 241**
Wheel speed sensor, front	10.04-03.07		**0 265 007 830**
Wheel speed sensor, rear	10.04-03.07		**0 265 007 503**

L

Phedra

2.0 JTD 16V [180]	**2,0 l 80 kW RHM; RHW 4 Zyl.**		
High-pressure sensor (CR system)	09.02→		**0 281 002 283**
Duo sensor, acceleration and yaw rate, brake system			
Ricam.no →10569	09.02→		**0 265 005 290**
Ricam.no 10570→	09.02→		**0 265 005 606**
Wheel speed sensor, front	09.02→	LAB	**0 265 007 083**
		RAB	**0 265 007 084**
2.0 JTD 16V [180]	**2,0 l 88/100 kW RHK; RHR 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system			
Ricam.no 10570→	03.06→		**0 265 005 606**
Wheel speed sensor, front	03.06→	LAB	**0 265 007 083**
		RAB	**0 265 007 084**
2.0 16V [180]	**2,0 l 100 kW RFN 4 Zyl.**		
Temperature sensor, intake air, injection system	09.02-09.06		**0 261 230 058**
Duo sensor, acceleration and yaw rate, brake system			
Ricam.no →10569	09.02-09.06		**0 265 005 290**
Ricam.no 10570→	09.02-09.06		**0 265 005 606**
Wheel speed sensor, front	09.02-09.06	LAB	**0 265 007 083**
		RAB	**0 265 007 084**
2.2 JTD 16V [180]	**2,2 l 95 kW 4HW 4 Zyl.**		
High-pressure sensor (CR system)	09.02→		**0 281 002 283**
Duo sensor, acceleration and yaw rate, brake system			
Ricam.no →10569	09.02→		**0 265 005 290**
Ricam.no 10570→	09.02→		**0 265 005 606**
Wheel speed sensor, front	09.02→	LAB	**0 265 007 083**
		RAB	**0 265 007 084**
3.0 24V [180]	**3,0 l 150 kW XFW 6 Zyl.**		
Knock sensor	09.02-10.05	KZB	**0 261 231 130**
Temperature sensor, intake air, injection system	09.02-10.05		**0 261 230 058**
Duo sensor, acceleration and yaw rate, brake system			
Ricam.no →10569	09.02-10.05		**0 265 005 290**
Wheel speed sensor, front	09.02-10.05	LAB	**0 265 007 083**
		RAB	**0 265 007 084**

Product

Thema Berlina

2.0 i.e. [104]	**2,0 l 83-85 kW 834 B 0.. Kat. 4 Zyl.**		
Throttle valve sensor	03.86-09.88		**0 280 120 311**
Air flow sensor, gasoline injection	03.86-09.88		**0 280 202 102**
			0 986 280 054
Temperature sensor, coolant, injection system	03.86-09.88		**0 280 130 026**
Relay, Jetronic	03.86-06.88		**0 280 230 006**
Wheel speed sensor, front	03.86-09.88		**0 265 001 072**
Wheel speed sensor, rear	03.86-09.88	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.0 i.e. [104]	**2,0 l 84 kW 834 B 146 4 Zyl.**		
Air flow sensor, gasoline injection	05.92-11.94		**0 280 202 102**
			0 986 280 054
Temperature sensor, coolant, injection system	05.92-11.94		**0 280 130 026**
Relay, Jetronic	05.92-11.94		**0 280 230 006**
Wheel speed sensor, front	05.92-11.94		**0 265 006 262**
Wheel speed sensor, rear	05.92-09.93		**0 265 003 075**
	10.93-11.94		**0 265 006 238**
2.0 i.e. [104]	**2,0 l 86 kW 834 B 1.000 4 Zyl.**		
Throttle valve sensor	06.88-05.92		**0 280 120 311**
Air flow sensor, gasoline injection CH,S	06.88-05.92		**0 280 202 081**
~~CH,S~~	06.88-05.92		**0 280 202 059**
			0 986 280 044
Temperature sensor, coolant, injection system	06.88-05.92		**0 280 130 026**
Relay, Jetronic	06.88-06.88		**0 280 230 006**
Wheel speed sensor, front	06.88-05.92	LAB	**0 265 001 209**
	06.89-05.92	RAB	**0 265 001 210**
Wheel speed sensor, rear	06.88-05.92	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.0 i.e. [104]	**2,0 l 88 kW 834 B.000 4 Zyl.**		
Throttle valve sensor	11.84-09.88		**0 280 120 311**
Air flow sensor, gasoline injection CH,S	11.84-09.88		**0 280 202 081**
~~CH,S~~	11.84-09.88		**0 280 202 059**
			0 986 280 044
Temperature sensor, coolant, injection system	11.84-09.88		**0 280 130 026**
Relay, Jetronic	11.84-06.88		**0 280 230 006**
Wheel speed sensor, front	11.84-09.88		**0 265 001 072**
Wheel speed sensor, rear	11.84-09.88	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.0 i.e. Turbo [104]	**2,0 l 110 kW 834 C 146 4 Zyl.**		
Throttle valve sensor	06.88-05.90		**0 280 120 312**
Air flow sensor, gasoline injection	06.88-05.90		**0 280 202 060**
			0 986 280 046
Temperature sensor, coolant, injection system	06.88-05.90		**0 280 130 026**
Relay, Jetronic	06.88-05.90		**0 280 230 009**
Wheel speed sensor, front	06.88-05.90	LAB	**0 265 001 209**
	06.89-05.90	RAB	**0 265 001 210**
Wheel speed sensor, rear	06.88-05.90	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.0 i.e. Turbo [104]	**2,0 l 110 kW 834 C 146 Kat. 4 Zyl.**		
Throttle valve sensor	07.86-05.90		**0 280 120 323**
Air flow sensor, gasoline injection	07.86-05.90		**0 280 202 103**
Temperature sensor, coolant, injection system	07.86-05.90		**0 280 130 026**
Relay, Jetronic	07.86-06.88		**0 280 230 006**
	07.86-05.90		**0 280 230 009**
Wheel speed sensor, front	07.86-05.90	LAB	**0 265 001 209**
	06.89-05.90	RAB	**0 265 001 210**
Wheel speed sensor, rear	07.86-05.90	LAB	**0 265 001 074**
		RAB	**0 265 001 073**

Product			
2.0 i.e. Turbo [104]	**2,0 l 122 kW 834 C 000 4 Zyl.**		
Throttle valve sensor	11.84-09.88		**0 280 120 312**
Air flow sensor, gasoline injection	11.84-09.88		**0 280 202 060**
			0 986 280 046
Temperature sensor, coolant, injection system	11.84-09.88		**0 280 130 026**
Relay, Jetronic	11.84-06.88		**0 280 230 006**
	11.84-09.88		**0 280 230 009**
Wheel speed sensor, front	11.84-09.88		**0 265 001 072**
Wheel speed sensor, rear	11.84-09.88	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.0 i.e. Turbo 16V [104]	**2,0 l 132 kW 834 C 1.246 Kat 4 Zyl.**		
Throttle valve sensor	04.89-05.92		**0 280 120 331**
Air mass meter, gasoline injection	04.89-05.92		**0 280 202 115**
Temperature sensor, coolant, injection system	04.89-05.92		**0 280 130 026**
Relay, Jetronic	04.89-05.92		**0 280 230 009**
Wheel speed sensor, front	04.89-05.92	LAB	**0 265 001 209**
	06.89-05.92	RAB	**0 265 001 210**
Wheel speed sensor, rear	04.89-05.92	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.0 i.e. Turbo 16V [104]	**2,0 l 136 kW 834 C 1.000 4 Zyl.**		
Throttle valve sensor	06.88-05.92		**0 280 120 307**
Air mass meter, gasoline injection	06.88-05.92		**0 280 202 114**
			0 986 280 080
Temperature sensor, coolant, injection system	06.88-05.92		**0 280 130 026**
Relay, Jetronic	06.88-05.92		**0 280 230 009**
Wheel speed sensor, front	06.88-05.92	LAB	**0 265 001 209**
	06.89-05.92	RAB	**0 265 001 210**
Wheel speed sensor, rear	06.88-05.92	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.0 i.e. 16V [104]	**2,0 l 107 kW 834 B 2.246 Kat 4 Zyl.**		
Throttle valve sensor	02.89-05.92		**0 280 120 300**
Air flow sensor, gasoline injection	02.89-05.92		**0 280 202 602**
			0 986 280 019
Pressure sensor, intake manifold, gasoline	02.89-05.92		**0 280 101 001**
Temperature sensor, coolant, injection system	02.89-05.92		**0 280 130 026**
Wheel speed sensor, front	02.89-05.92	LAB	**0 265 001 209**
	06.89-05.92	RAB	**0 265 001 210**
Wheel speed sensor, rear	02.89-05.92	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.0 i.e. 16V [104]	**2,0 l 108 kW 834 B 2.000 4 Zyl.**		
Throttle valve sensor	06.88-05.92		**0 280 120 300**
Air flow sensor, gasoline injection	06.88-05.92		**0 280 202 602**
			0 986 280 019
Temperature sensor, coolant, injection system	06.88-05.92		**0 280 130 026**
Relay, Jetronic	06.88-05.92		**0 332 014 113**
Wheel speed sensor, front	06.88-05.92	LAB	**0 265 001 209**
	06.89-05.92	RAB	**0 265 001 210**
Wheel speed sensor, rear	06.88-05.92	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.0 i.e. 16V [104]	**2,0 l 112 kW 834 F 1.000 4 Zyl.**		
Throttle valve sensor	05.92-11.94		**0 280 122 001**
Air flow sensor, gasoline injection	05.92-11.94		**0 280 202 204**
			0 986 280 055
Speed sensor, ignition/injection	05.92-11.94		**0 261 210 093**
Knock sensor	05.92-11.94		**0 261 231 007**
Temperature sensor, coolant, injection system	05.92-11.94		**0 280 130 026**
Relay, Jetronic	05.92-11.94		**0 332 014 140**
		DID	**0 332 014 112**
Wheel speed sensor, front	05.92-11.94		**0 265 006 262**
Wheel speed sensor, rear	05.92-09.93		**0 265 003 075**
	10.93-11.94		**0 265 006 238**

Product			
2.0 i.e. 16V Turbo [104]	**2,0 l 148 kW 834 F 2.000 4 Zyl.**		
Throttle valve sensor	05.92-11.94		**0 280 122 001**
Air mass meter, gasoline injection	05.92-11.94		**0 280 213 025**
			0 986 280 114
Phase sensor	05.92-11.94		**0 232 101 018**
Speed sensor, ignition/injection	05.92-11.94		**0 261 210 093**
Knock sensor	05.92-11.94		**0 261 231 007**
Pressure sensor, intake manifold, gasoline	05.92-11.94		**0 280 101 001**
Temperature sensor, coolant, injection system	05.92-11.94		**0 280 130 026**
Relay, Jetronic	05.92-11.94		**0 332 014 140**
Wheel speed sensor, front	05.92-11.94		**0 265 006 262**
Wheel speed sensor, rear	05.92-09.93		**0 265 003 075**
	10.93-11.94		**0 265 006 238**
2.5 TD [104]	**2,5 l 74 kW 8144.91.2200 4 Zyl.**		
Wheel speed sensor, front	11.84-09.88		**0 265 001 072**
Wheel speed sensor, rear	11.84-09.88	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.5 TD [104]	**2,5 l 85 kW 8144.97S.2200 4 Zyl.**		
Wheel speed sensor, front	06.88-05.92	LAB	**0 265 001 209**
	06.89-05.92	RAB	**0 265 001 210**
Wheel speed sensor, rear	06.88-05.92	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.5 TD [104]	**2,5 l 85 kW 8144.97Y 4 Zyl.**		
Air flow sensor, diesel	01.93-11.94		**0 281 002 088**
Temperature sensor, coolant, diesel	01.93-11.94		**0 280 130 026**
Pedal position sensor, diesel	01.93-11.94		**0 205 001 010**
Wheel speed sensor, front	05.92-11.94		**0 265 006 262**
Wheel speed sensor, rear	05.92-09.93		**0 265 003 075**
	01.93-11.94		**0 265 003 075**
	10.93-11.94		**0 265 006 238**
2.5 TD [104]	**2,5 l 85 kW 8144.97.2200 4 Zyl.**		
Wheel speed sensor, front	06.88-05.92	LAB	**0 265 001 209**
	06.89-05.92	RAB	**0 265 001 210**
Wheel speed sensor, rear	06.88-05.92	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.8 6 V PRV [104]	**2,8 l 110 kW 834 E 000 6 Zyl.**		
Air flow sensor, gasoline injection	11.84-09.88		**0 438 120 200**
Relay, Jetronic	11.84-06.88		**0 280 230 006**
Wheel speed sensor, front	11.84-09.88		**0 265 001 072**
Wheel speed sensor, rear	11.84-09.88	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.9 6 V PRV [104]	**2,9 l 108 kW 834 E 146 6 Zyl.**		
Throttle valve sensor	06.88-09.91		**0 280 120 301**
Air mass meter, gasoline injection	06.88-09.91		**0 280 213 006**
			0 986 280 115
Speed sensor, ignition/injection	06.88-09.91		**0 261 210 029**
Knock sensor	06.88-09.91		**0 261 231 007**
Temperature sensor, coolant, injection system	06.88-09.91		**0 280 130 032**
Relay, Jetronic	06.88-09.91		**0 332 014 140**
Wheel speed sensor, rear	06.88-09.91	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
3.0 i.e. [104]	**3,0 l 126 kW 834 F.000 6 Zyl.**		
Throttle valve sensor	05.92-11.94		**0 280 122 001**
Speed sensor, ignition/injection	05.92-11.94		**0 261 210 096**
Knock sensor	05.92-11.94		**0 261 231 095**
Temperature sensor, coolant, injection system	05.92-11.94		**0 280 130 026**
Wheel speed sensor, front	05.92-11.94		**0 265 006 262**
Wheel speed sensor, rear	05.92-09.93		**0 265 003 075**
	10.93-11.94		**0 265 006 238**
8.32 [104]	**2,9 l 150 kW F 105 L.046 Kat 8 Zyl.**		
Throttle valve sensor	12.87-12.90		**0 280 120 302**
Air flow sensor, gasoline injection	12.87-12.90		**0 438 121 066**
Pressure sensor, intake manifold, gasoline	12.87-12.90		**0 280 101 003**

L

Product			

◀ Thema Berlina

Temperature sensor, coolant, injection system	12.87-12.90		**0 280 130 026**
Relay, Jetronic	12.87-12.90		**0 280 230 009**
Wheel speed sensor, front	12.87-06.89		**0 265 001 072**
Wheel speed sensor, rear	12.87-12.90	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
8.32 [104]		**2,9 l 158 kW F 105 L 8 Zyl.**	
Throttle valve sensor	06.86-12.89		**0 280 120 302**
Air flow sensor, gasoline injection	06.86-12.89		**0 438 121 066**
Temperature sensor, coolant, injection system	06.86-12.89		**0 280 130 026**
Relay, Jetronic	06.86-06.88		**0 280 230 006**
Wheel speed sensor, front	06.86-06.89		**0 265 001 072**
Wheel speed sensor, rear	06.86-12.89	LAB	**0 265 001 074**
		RAB	**0 265 001 073**

Thema Station Wagon

2.0 i.e. Turbo [104]		**2,0 l 110 kW 834 C 146 4 Zyl.**	
Throttle valve sensor	06.88-05.90		**0 280 120 312**
Air flow sensor, gasoline injection	06.88-05.90		**0 280 202 060**
			0 986 280 046
Temperature sensor, coolant, injection system	06.88-05.90		**0 280 130 026**
Relay, Jetronic	06.88-05.90		**0 280 230 009**
Wheel speed sensor, front	06.88-05.90	LAB	**0 265 001 209**
	06.89-05.90	RAB	**0 265 001 210**
Wheel speed sensor, rear	06.88-05.90	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.0 i.e. Turbo [104]		**2,0 l 110 kW 834 C 146 Kat. 4 Zyl.**	
Throttle valve sensor	07.86-05.90		**0 280 120 323**
Air flow sensor, gasoline injection	07.86-05.90		**0 280 202 103**
Temperature sensor, coolant, injection system	07.86-05.90		**0 280 130 026**
Relay, Jetronic	07.86-06.88		**0 280 230 006**
	07.86-05.90		**0 280 230 009**
Wheel speed sensor, front	07.86-05.90	LAB	**0 265 001 209**
	06.89-05.90	RAB	**0 265 001 210**
Wheel speed sensor, rear	07.86-05.90	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.0 i.e. Turbo [104]		**2,0 l 122 kW 834 C 000 4 Zyl.**	
Throttle valve sensor	11.84-09.88		**0 280 120 312**
Air flow sensor, gasoline injection	11.84-09.88		**0 280 202 060**
			0 986 280 046
Temperature sensor, coolant, injection system	11.84-09.88		**0 280 130 026**
Relay, Jetronic	11.84-06.88		**0 280 230 006**
	11.84-09.88		**0 280 230 009**
Wheel speed sensor, front	11.84-09.88		**0 265 001 072**
Wheel speed sensor, rear	11.84-09.88	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.0 i.e. Turbo 16V [104]		**2,0 l 132 kW 834 C 1.246 Kat 4 Zyl.**	
Throttle valve sensor	04.89-05.92		**0 280 120 331**
Air mass meter, gasoline injection	04.89-05.92		**0 280 202 115**
Temperature sensor, coolant, injection system	04.89-05.92		**0 280 130 026**
Relay, Jetronic	04.89-05.92		**0 280 230 009**
Wheel speed sensor, front	04.89-05.92	LAB	**0 265 001 209**
	06.89-05.92	RAB	**0 265 001 210**
Wheel speed sensor, rear	04.89-05.92	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.0 i.e. Turbo 16V [104]		**2,0 l 136 kW 834 C 1.000 4 Zyl.**	
Throttle valve sensor	06.88-05.92		**0 280 120 307**
Air mass meter, gasoline injection	06.88-05.92		**0 280 202 114**
			0 986 280 080
Temperature sensor, coolant, injection system	06.88-05.92		**0 280 130 026**
Relay, Jetronic	06.88-05.92		**0 280 230 009**
Wheel speed sensor, front	06.88-05.92	LAB	**0 265 001 209**
	06.89-05.92	RAB	**0 265 001 210**

Product			

Wheel speed sensor, rear	06.88-05.92	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.0 i.e. 16V [104]		**2,0 l 107 kW 834 B 2.246 Kat 4 Zyl.**	
Throttle valve sensor	02.89-05.92		**0 280 120 300**
Air flow sensor, gasoline injection	02.89-05.92		**0 280 202 602**
			0 986 280 019
Pressure sensor, intake manifold, gasoline	02.89-05.92		**0 280 101 001**
Temperature sensor, coolant, injection system	02.89-05.92		**0 280 130 026**
Wheel speed sensor, front	02.89-05.92	LAB	**0 265 001 209**
	06.89-05.92	RAB	**0 265 001 210**
Wheel speed sensor, rear	02.89-05.92	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.0 i.e. 16V [104]		**2,0 l 108 kW 834 B 2.000 4 Zyl.**	
Throttle valve sensor	06.88-05.92		**0 280 120 300**
Air flow sensor, gasoline injection	06.88-05.92		**0 280 202 602**
			0 986 280 019
Temperature sensor, coolant, injection system	06.88-05.92		**0 280 130 026**
Relay, Jetronic	06.88-05.92		**0 332 014 113**
Wheel speed sensor, front	06.88-05.92	LAB	**0 265 001 209**
	06.89-05.92	RAB	**0 265 001 210**
Wheel speed sensor, rear	06.88-05.92	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.0 i.e. 16V [104]		**2,0 l 112 kW 834 F 1.000 4 Zyl.**	
Throttle valve sensor	05.92-11.94		**0 280 122 001**
Air flow sensor, gasoline injection	05.92-11.94		**0 280 202 204**
			0 986 280 055
Speed sensor, ignition/injection	05.92-11.94		**0 261 210 093**
Knock sensor	05.92-11.94		**0 261 231 007**
Temperature sensor, coolant, injection system	05.92-11.94		**0 280 130 026**
Relay, Jetronic	05.92-11.94		**0 332 014 140**
		DID	**0 332 014 112**
Wheel speed sensor, front	05.92-11.94		**0 265 006 262**
Wheel speed sensor, rear	05.92-09.93		**0 265 003 075**
	10.93-11.94		**0 265 006 238**
2.0 i.e. 16V Turbo [104]		**2,0 l 148 kW 834 F 2.000 4 Zyl.**	
Throttle valve sensor	05.92-11.94		**0 280 122 001**
Air mass meter, gasoline injection	05.92-11.94		**0 280 213 025**
			0 986 280 114
Phase sensor	05.92-11.94		**0 232 101 018**
Speed sensor, ignition/injection	05.92-11.94		**0 261 210 093**
Knock sensor	05.92-11.94		**0 261 231 007**
Pressure sensor, intake manifold, gasoline	05.92-11.94		**0 280 101 001**
Temperature sensor, coolant, injection system	05.92-11.94		**0 280 130 026**
Relay, Jetronic	05.92-11.94		**0 332 014 140**
Wheel speed sensor, front	05.92-11.94		**0 265 006 262**
Wheel speed sensor, rear	05.92-09.93		**0 265 003 075**
	10.93-11.94		**0 265 006 238**
2.5 TD [104]		**2,5 l 74 kW 8144.91.2200 4 Zyl.**	
Wheel speed sensor, front	11.84-09.88		**0 265 001 072**
Wheel speed sensor, rear	11.84-09.88	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.5 TD [104]		**2,5 l 85 kW 8144.97S.2200 4 Zyl.**	
Wheel speed sensor, front	06.88-05.92	LAB	**0 265 001 209**
	06.89-05.92	RAB	**0 265 001 210**
Wheel speed sensor, rear	06.88-05.92	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
2.5 TD [104]		**2,5 l 85 kW 8144.97Y 4 Zyl.**	
Wheel speed sensor, front	05.92-11.94		**0 265 006 262**
Wheel speed sensor, rear	05.92-09.93		**0 265 003 075**
	10.93-11.94		**0 265 006 238**
2.5 TD [104]		**2,5 l 85 kW 8144.97Y EDC-Bosch 4 Zyl.**	
Air flow sensor, diesel	01.93-11.94		**0 281 002 088**
Temperature sensor, coolant, diesel	01.93-11.94		**0 280 130 026**

Product

Pedal position sensor, diesel	01.93-11.94		**0 205 001 010**
Wheel speed sensor, front	01.93-11.94		**0 265 006 262**
Wheel speed sensor, rear	01.93-11.94		**0 265 003 075**
2.5 TD [104]	**2,5 l 85 kW 8144.97.2200 4 Zyl.**		
Wheel speed sensor, front	06.88-05.92	LAB	**0 265 001 209**
	06.89-05.92	RAB	**0 265 001 210**
Wheel speed sensor, rear	06.88-05.92	LAB	**0 265 001 074**
		RAB	**0 265 001 073**
3.0 i.e. [104]	**3,0 l 126 kW 834 F.000 6 Zyl.**		
Throttle valve sensor	05.92-11.94		**0 280 122 001**
Speed sensor, ignition/injection	05.92-11.94		**0 261 210 096**
Knock sensor	05.92-11.94		**0 261 231 095**
Temperature sensor, coolant, injection system	05.92-11.94		**0 280 130 026**
Wheel speed sensor, front	05.92-11.94		**0 265 006 262**
Wheel speed sensor, rear	05.92-09.93		**0 265 003 075**
	10.93-11.94		**0 265 006 238**

Thesis

2.0 Turbo 20V [841]	**2,0 l 136 kW 841E.000 5 Zyl.**		
Throttle valve assembly	04.02→		**0 205 003 052**
Air mass meter, gasoline injection	04.02→		**0 280 218 054**
Phase sensor	04.02→		**0 232 101 036**
Speed sensor, ignition/injection	04.02→		**0 261 210 160**
Knock sensor	04.02→		**0 261 231 173**
2.4 JTD 10V [841]	**2,4 l 110 kW 841C.000 5 Zyl.**		
Air mass meter, diesel			
Ricam.no →8957	04.02-09.03		**0 281 002 309**
Ricam.no 8958→	10.03-02.05		**0 280 218 113**
Speed sensor, diesel	04.02-06.03		**0 281 002 474**
	07.03-02.05		**0 281 002 603**
Phase sensor	04.02-02.05		**0 281 002 213**
High-pressure sensor (CR system)	04.02-02.05		**0 281 002 405**
Boost pressure sensor, Diesel	04.02-02.05		**0 281 002 844**
2.4 JTD 20V [841]	**2,4 l 120/129 kW 841G.000; 841M.000; 841N.000 5 Zyl.**		
Air mass meter, diesel	06.03-02.06		**0 281 002 598**
Boost pressure sensor, Diesel	06.03-02.06		**0 281 002 845**
2.4 JTD 20V [841]	**2,4 l 129 kW 841H.000 5 Zyl.**		
Air mass meter, diesel	06.03-02.06		**0 281 002 598**
Boost pressure sensor, Diesel	06.03-02.06		**0 281 002 845**
2.4 JTD 20V [841]	**2,4 l 136 kW 841H.000 5 Zyl.**		
Air mass meter, diesel	03.06→		**0 281 002 763**
High-pressure sensor (CR system)	03.06→		**0 281 002 706**
Boost pressure sensor, Diesel	03.06→		**0 281 002 845**
2.4 20V [841]	**2,4 l 125 kW 841D.000 5 Zyl.**		
Throttle valve assembly	04.02→		**1 287 213 608**
Air mass meter, gasoline injection	04.02→		**0 281 002 309**
Phase sensor	04.02→		**0 232 101 036**
Speed sensor, ignition/injection	04.02→		**0 261 210 160**
Knock sensor	04.02→		**0 261 231 144**
3.0 V6 24V [841]	**3,0 l 158 kW 841A.000 6 Zyl.**		
Throttle valve assembly	04.02-07.03		**0 280 750 014**
Air mass meter, gasoline injection	04.02-07.03		**0 280 218 054**
Phase sensor	04.02-07.03		**0 232 103 024**
Speed sensor, ignition/injection	04.02-07.03		**0 261 210 203**
3.2 V6 24V [841]	**3,2 l 169 kW 841A.000 6 Zyl.**		
Throttle valve assembly	08.03→		**0 280 750 014**
Air mass meter, gasoline injection	08.03→		**0 280 218 054**
Phase sensor	08.03→		**0 232 103 024**
Speed sensor, ignition/injection	08.03→		**0 261 210 203**

Product

Y

1.1 i.e. [840]	**1,1 l 40 kW 176B2.000 SPI-Weber 4 Zyl.**		
Wheel speed sensor, front	04.97-06.00		**0 265 006 138**
Wheel speed sensor, rear	04.97-06.00	LAB	**0 265 006 139**
		RAB	**0 265 006 140**
1.2 i 8V [840]	**1,2 l 44 kW 188A4.000 4 Zyl.**		
Wheel speed sensor, front	06.00-06.03	LAB	**0 265 007 024**
		RAB	**0 265 007 025**
Wheel speed sensor, rear	06.00-06.03	LAB	**0 265 007 026**
		RAB	**0 265 007 027**
1.2 i 16V [840]	**1,2 l 63 kW 188A5.000 4 Zyl.**		
Throttle valve assembly	06.00-06.03		**0 280 750 042**
Speed sensor, ignition/injection	06.00-06.03		**0 261 210 220**
Knock sensor	06.00-06.03		**0 261 231 173**
Wheel speed sensor, front	06.00-06.03	LAB	**0 265 007 024**
		RAB	**0 265 007 025**
Wheel speed sensor, rear	06.00-06.03	LAB	**0 265 007 026**
		RAB	**0 265 007 027**
1.2 i.e. 8V [840]	**1,2 l 44 kW 840A3.000 SPI-Weber 4 Zyl.**		
Pulse generator, ignition/Jetronic	01.96-06.00		**0 281 002 102**
Wheel speed sensor, front	01.96-06.00		**0 265 006 138**
Wheel speed sensor, rear	01.96-06.00	LAB	**0 265 006 139**
		RAB	**0 265 006 140**
1.2 i.e. 16V [840]	**1,2 l 63 kW 176B9.000 MPI-Weber 4 Zyl.**		
Wheel speed sensor, front	04.97-06.00		**0 265 006 138**
Wheel speed sensor, rear	04.97-06.00	LAB	**0 265 006 139**
		RAB	**0 265 006 140**
1.4 i.e. 12V [840]	**1,4 l 55-59 kW 840A2.000 SPI-Bosch 4 Zyl.**		
Pulse generator, ignition/Jetronic	01.96-06.00		**0 281 002 102**
Knock sensor	01.96-06.00		**0 261 231 007**
Temperature sensor, coolant, injection system	01.96-06.00		**0 280 130 026**
Wheel speed sensor, front	01.96-06.00		**0 265 006 138**
Wheel speed sensor, rear	01.96-06.00	LAB	**0 265 006 139**
		RAB	**0 265 006 140**

Y 10

1.0 i fire [156]	**1,0 l 33 kW 156A2.246 SPI-Bosch 4 Zyl.**		
Temperature sensor, coolant, injection system	01.89-02.92		**0 280 130 026**
1.0 i fire 4x4 [156]	**1,0 l 33 kW 156A2.246 4 Zyl.**		
Temperature sensor, coolant, injection system	10.87-07.89		**0 280 130 026**
1.1 i [156]	**1,1 l 37 kW 156C.046 SPI-Bosch 4 Zyl.**		
Speed sensor, ignition/injection	09.92-12.95		**0 261 210 098**
Temperature sensor, coolant, injection system	09.92-12.95		**0 280 130 026**
1.1 i fire LX [156]	**1,1 l 37/41 kW 156C.000 SPI-Bosch; 156C.046 Kat 4 Zyl.**		
Temperature sensor, coolant, injection system	03.89-09.92		**0 280 130 026**
1.1 i fire 4x4 [156]	**1,1 l 41 kW 156C.000 SPI-Bosch 4 Zyl.**		
Temperature sensor, coolant, injection system	01.89-09.92		**0 280 130 026**
1.1 i Selectronic, i 4x4 [156]	**1,1 l 37 kW 156C.046 SPI-Bosch 4 Zyl.**		
Temperature sensor, coolant, injection system	09.92-12.95		**0 280 130 026**
1.3 i [156]	**1,3 l 53 kW 146A5.046 MPI-Bosch 4 Zyl.**		
Air flow sensor, gasoline injection	09.92-12.95		**0 280 200 602**
Temperature sensor, coolant, injection system	09.92-12.95		**0 280 130 026**
Relay, Jetronic	09.92-12.95		**0 332 014 113**
1.3 i GT [156]	**1,3 l 53/54/56/57 kW 146A5.046 Kat/MPI-Bosch; 156B.000 4 Zyl.**		
Throttle valve sensor	11.87-09.92		**0 280 120 328**
Air flow sensor, gasoline injection	11.87-09.92		**0 280 200 602**
Temperature sensor, coolant, injection system	11.87-09.92		**0 280 130 026**
Relay, Jetronic	11.87-09.92		**0 332 014 113**

L

Product		

Ypsilon

1.2 8V [843]		**1,2 l 44 kW 188A4.000 4 Zyl.**
Phase sensor	06.03→	**0 232 103 048**
Speed sensor, ignition/injection	11.03-03.04	**0 261 210 114**
Pressure sensor, intake manifold, gasoline	06.03→	**0 261 230 030**
Wheel speed sensor, front	06.03→	**0 265 007 830**
Wheel speed sensor, rear	06.03→	**0 265 008 049**
		0 265 008 188
1.2 16V [843]		**1,2 l 59 kW 188A5.000 4 Zyl.**
Speed sensor, ignition/injection	06.03-09.06	**0 261 210 238**
Knock sensor	06.03-09.06	**0 261 231 173**
Wheel speed sensor, front	06.03-09.06	**0 265 007 830**
Wheel speed sensor, rear	06.03-09.06	**0 265 008 049**
		0 265 008 188
1.3 JTD 16V [843]		**1,3 l 51 kW 188A4.000 4 Zyl.**
Air mass meter, diesel	06.03-09.06	**0 281 002 613**
Wheel speed sensor, front	06.03-09.06	**0 265 007 830**
Wheel speed sensor, rear	06.03-09.06	**0 265 008 049**
		0 265 008 188
1.3 Multijet 16V [843]		**1,3 l 55 kW 199A2000 4 Zyl.**
Air mass meter, diesel	10.06→	**0 281 002 792**
Wheel speed sensor, front	10.06→	**0 265 007 830**
Wheel speed sensor, rear	10.06→	**0 265 008 049**
		0 265 008 188
1.3 Multijet 16V [843]		**1,3 l 66 kW 199A3000 4 Zyl.**
Air mass meter, diesel	10.06→	**0 281 002 792**
Boost pressure sensor, Diesel	10.06-11.06	**0 281 002 437**
	12.06→	**0 281 002 845**
Wheel speed sensor, front	10.06→	**0 265 007 830**
Wheel speed sensor, rear	10.06→	**0 265 008 049**
		0 265 008 188
1.4 8V [843]		**1,4 l 57 kW 843A1.000 4 Zyl.**
Phase sensor	10.06→	**0 232 103 048**
Pressure sensor, intake manifold, gasoline	10.06→	**0 261 230 030**
Wheel speed sensor, front	10.06→	**0 265 007 830**
Wheel speed sensor, rear	10.06→	**0 265 008 049**
1.4 16V [843]		**1,4 l 70 kW 843A1.000 4 Zyl.**
Throttle valve assembly	06.03-03.04	**0 280 750 137**
Speed sensor, ignition/injection	06.03→	**0 261 210 238**
Knock sensor	06.03→	**0 261 231 173**
Wheel speed sensor, front	06.03→	**0 265 007 830**
Wheel speed sensor, rear	06.03→	**0 265 008 049**
		0 265 008 188

ZETA

2.0 i.e. Turbo [122]		**2,0 l 110 kW RGX 4 Zyl.**
Throttle valve sensor		
Ricam.no →6779	09.94-06.95	**0 280 122 001**
Ricam.no 6780→	07.95-06.99	**0 280 122 003**
Knock sensor		
Ricam.no 0008135→	03.99-06.99	**0 261 231 130**
Wheel speed sensor, front	09.94-06.99	**0 265 006 388**
Wheel speed sensor, rear	09.97-06.99	**0 265 006 406**
	09.94-08.97	**0 265 006 426**
2.0 JTD [122]		**2,0 l 80 kW RHW; RHZ 4 Zyl.**
High-pressure sensor (CR system)	06.99-06.02	**0 281 002 283**
Wheel speed sensor, front	06.99-06.02	**0 265 006 388**
Wheel speed sensor, rear	06.99-06.02	**0 265 006 406**
2.0 16V [122]		**2,0 l 97 kW RFN 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.00-06.02	**0 261 230 057**
Wheel speed sensor, front	10.00-06.02	**0 265 006 388**
Wheel speed sensor, rear	10.00-06.02	**0 265 006 504**
2.0 16V [122]		**2,0 l 97 kW RFV 4 Zyl.**
Throttle valve sensor	06.99-10.00	**0 280 122 009**
Knock sensor	06.99-10.00	**0 261 231 130**
Pressure sensor, intake manifold, gasoline	06.99-10.00	**0 261 230 012**
Wheel speed sensor, front	06.99-10.00	**0 265 006 388**
Wheel speed sensor, rear	06.99-10.00	**0 265 006 406**
2.1 TD [122]		**2,1 l 80 kW P8C 4 Zyl.**
Wheel speed sensor, front	05.96-06.99	**0 265 006 388**
Wheel speed sensor, rear	09.97-06.99	**0 265 006 406**
	05.96-08.97	**0 265 006 426**

LAND ROVER GROUP

Defender 90

2.5 Td5		**2,5 l 90 kW Td5 5 Zyl.**
Boost pressure sensor, Diesel	06.98-07.07	**0 281 002 205**
Temperature sensor, coolant, diesel	06.98-07.07	**0 280 130 026**

Defender 110

2.5 Td5		**2,5 l 90 kW Td5 5 Zyl.**
Boost pressure sensor, Diesel	06.98-07.07	**0 281 002 205**
Temperature sensor, coolant, diesel	06.98-07.07	**0 280 130 026**

Defender 130

2.5 Td5		**2,5 l 90 kW Td5 5 Zyl.**
Boost pressure sensor, Diesel	06.98-07.07	**0 281 002 205**
Temperature sensor, coolant, diesel	06.98-07.07	**0 280 130 026**

Discovery

2.5 TDi		**2,5 l 82-83 kW 19L 21L 4 Zyl.**
Air flow sensor, diesel	10.93-12.98	**0 281 002 092**
Pulse generator, diesel	10.93-12.98 AG	**0 281 002 104**
	CH 10.93-12.98	**0 281 002 107**
Speed sensor, diesel	10.93-12.98	**0 261 210 028**
Pressure sensor, intake manifold, diesel	10.93-12.98	**0 281 002 063**
Temperature sensor, coolant, diesel	10.93-12.98	**0 280 130 026**
Temperature sensor, intake air, diesel	10.93-12.98	**0 280 130 039**
Pedal position sensor, diesel	10.93-12.98	**0 205 001 021**
2.5 Td5		**2,5 l 100-102 kW 5ROHC 5 Zyl.**
Boost pressure sensor, Diesel	10.98-10.04	**0 281 002 205**
Temperature sensor, coolant, diesel	10.98-10.04	**0 280 130 026**
2.7 TDV6		**2,7 l 140 kW TDV6 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.04→	**0 265 005 639**
Wheel speed sensor, front		
Fg.no. 6A351057→	10.04→	**0 265 007 923**
Wheel speed sensor, rear	10.04→	**0 265 007 922**
4.0		**4,0 l 161 kW 4.0-V6 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.04→	**0 265 005 639**
Wheel speed sensor, front		
Fg.no. 6A351057→	10.04→	**0 265 007 923**
Wheel speed sensor, rear	10.04→	**0 265 007 922**

Product			
4.0 i			**4,0 l 136 kW V8 - EFi 8 Zyl.**
Throttle valve sensor	10.98-10.04		**0 280 122 016**
Air mass meter, gasoline injection	10.98-10.04		**0 280 217 532**
Speed sensor, ignition/injection	10.98-10.04	AG	**0 261 210 158**
		GS	**0 261 210 155**
Knock sensor	10.98-10.04	ZE	**0 261 231 140**
4.4			**4,4 l 220 kW AJ-V8 4.4 EFI 8 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.04→		**0 265 005 639**
Wheel speed sensor, front			
Fg.no. 6A351057→	10.04→		**0 265 007 923**
Wheel speed sensor, rear	10.04→		**0 265 007 922**

Freelander I

2.0 D			**2,0 l 70-72 kW TCie 17N,18N 4 Zyl.**
Air mass meter, diesel	09.97-09.03	EDC	**0 281 002 182**
Temperature sensor, coolant, diesel	09.97-09.03		**0 280 130 026**
Temperature sensor, intake air, diesel	09.97-09.03		**0 280 130 039**

Range Rover I

2.5 TDi			**2,5 l 81-83 kW 300 TDi 4 Zyl.**
Temperature sensor, coolant, diesel	01.95-04.96		**0 280 130 026**
2.5 TDi Classic			**2,5 l 83 kW 14L 4 Zyl.**
Air flow sensor, diesel	10.92-09.94		**0 281 002 092**
Pulse generator, diesel	10.92-09.94	AG	**0 281 002 104**
CH	10.92-09.94		**0 281 002 107**
Pressure sensor, intake manifold, diesel	10.92-09.94		**0 281 002 063**
Temperature sensor, coolant, diesel	10.92-09.94		**0 280 130 026**
Temperature sensor, intake air, diesel	10.92-09.94		**0 280 130 039**
Pedal position sensor, diesel	10.92-09.94		**0 205 001 021**
3.5 i			**3,5 l 110 kW V8F-EFI 8 Zyl.**
Relay, Jetronic	01.87-09.90		**0 332 014 113**
3.5 i			**3,5 l 112 kW 22D 8 Zyl.**
Air flow sensor, gasoline injection	06.70-06.86		**0 280 202 008**
Relay, Jetronic	06.70-06.86		**0 332 014 113**
3.5 i			**3,5 l 120 kW 24D,25D 8 Zyl.**
Air flow sensor, gasoline injection	10.85-09.89		**0 280 202 046**
			0 986 280 027
Relay, Jetronic	10.85-09.90		**0 332 014 113**

Range Rover II

2.5 D			**2,5 l 100-102 kW 25 6T 6 Zyl.**
Pedal position sensor, diesel			
Fg.no. WA 376580→	09.94-09.02		**0 205 001 040**
Fg.no. →WA 376579	09.94-09.02		**0 205 001 006**
4.0 i V8			**4,0 l 136-140 kW 42D 8 Zyl.**
Air mass meter, gasoline injection			
Fg.no. XA 410482→	09.94-09.02		**0 280 218 010**
Speed sensor, ignition/injection			
Fg.no. XA 410482→	09.94-09.02	AG	**0 261 210 158**
Knock sensor			
Fg.no. XA 410482→	09.94-09.02		**0 261 231 140**
4.6 i V8			**4,6 l 158-166 kW 46D 8 Zyl.**
Air mass meter, gasoline injection			
Fg.no. XA 410482→	09.94-09.02		**0 280 218 010**
Speed sensor, ignition/injection			
Fg.no. XA 410482→	09.94-09.02	AG	**0 261 210 158**
Knock sensor			
Fg.no. XA 410482→	09.94-09.02		**0 261 231 140**

Range Rover III

3.0 Td6			**2,9 l 130 kW M57 D30 6 Zyl.**
Pressure sensor, ESP, (electronic stability program)	03.02-09.06		**0 265 005 303**
3.6 TDV8			**3,6 l 200 kW 3.6 32V Lion 8 Zyl.**
Phase sensor	09.06→		**0 232 103 052**
Duo sensor, acceleration and yaw rate, brake system	09.06→		**0 265 005 655**
4.2 V8 Supercharged			**4,2 l 291 kW AJ-V8 8 Zyl.**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 5A000001→6A999999	03.05→		**0 265 005 639**
Fg.no. 7A000001→	03.05→		**0 265 005 655**
4.4 V8			**4,4 l 210 kW M62B44 V8 8 Zyl.**
Air mass meter, gasoline injection	03.02→		**0 280 217 814**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4A999999	03.02→		**0 265 005 248**
Fg.no. 5A000001→6A999999	03.02→		**0 265 005 639**
4.4 V8			**4,4 l 225 kW AJ 4.4 8 Zyl.**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 5A000001→6A999999	05.05→		**0 265 005 639**
Fg.no. 7A000001→	05.05→		**0 265 005 655**

Range Rover IV Sport

2.7 TDV6			**2,7 l 140 kW Lion 2.7-Liter-V6 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.05→		**0 265 005 639**
Wheel speed sensor, front	03.05→		**0 265 007 924**
Wheel speed sensor, rear	03.05→		**0 265 007 922**
3.6 TDV8			**3,6 l 200 kW 3.6 32V Lion 8 Zyl.**
Phase sensor	01.07→		**0 232 103 052**
Duo sensor, acceleration and yaw rate, brake system	01.07→		**0 265 005 639**
Wheel speed sensor, front	01.07→		**0 265 007 924**
Wheel speed sensor, rear	01.07→		**0 265 007 922**
4.2 V8 Supercharged			**4,2 l 286-287 kW AJ-V8 4.2 Kompr. 8 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.05→		**0 265 005 639**
Wheel speed sensor, front	03.05→		**0 265 007 924**
Wheel speed sensor, rear	03.05→		**0 265 007 922**
4.4 V8			**4,4 l 220 kW AJ-V8 4.4 EFI-V8 8 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.05→		**0 265 005 639**
Wheel speed sensor, front	03.05→		**0 265 007 924**
Wheel speed sensor, rear	03.05→		**0 265 007 922**

MAZDA

MPV

2.3 i [LW]			**2,3 l 104 kW L3 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.02-06.04	FAR	**0 261 230 180**

MX-5

1.8 [NC]			**1,8 l 93 kW 4 Zyl.**
Pressure sensor, intake manifold, gasoline			
Fg.no. →115161	07.05→		**0 261 230 180**

M

Product				
◀ MX-5				
2.0 [NC]				**2,0 l 118 kW 4 Zyl.**
Pressure sensor, intake manifold, gasoline				
Fg.no. →115161	07.05→			**0 261 230 180**
Tribute				
2.3 i, i 4x4 [EP]				**2,3 l 110 kW GZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	12.03-05.04			**0 261 230 180**
3 Hatchback				
2.0 [BK]				**2,0 l 110 kW LF 4 Zyl.**
Pressure sensor, intake manifold, gasoline				
Fg.no. 138361→381360	07.03→	FAR		**0 261 230 180**
3 Sedan				
2.0 [BK]				**2,0 l 110 kW LF 4 Zyl.**
Pressure sensor, intake manifold, gasoline				
Fg.no. 138361→381360	07.03→	FAR		**0 261 230 180**
5				
1.8 [CR]				**1,8 l 85 kW L8 4 Zyl.**
Pressure sensor, intake manifold, gasoline	02.05→			**0 261 230 180**
2.0 [CR]				**2,0 l 107 kW LF 4 Zyl.**
Pressure sensor, intake manifold, gasoline	02.05→			**0 261 230 180**
6 Fastback				
1.8 [GG/GY]				**1,8 l 88 kW L8 4 Zyl.**
Pressure sensor, intake manifold, gasoline				
Fg.no. →654518	03.05→			**0 261 230 180**
2.0 [GG/GY]				**2,0 l 104-108 kW LF 4 Zyl.**
Pressure sensor, intake manifold, gasoline				
Fg.no. →654518	03.05→			**0 261 230 180**
2.3 [GG/GY]				**2,3 l 122 kW L3 4 Zyl.**
Pressure sensor, intake manifold, gasoline				
Fg.no. →654518	03.05→			**0 261 230 180**
6 Sedan				
1.8 [GG/GY]				**1,8 l 88 kW L8 4 Zyl.**
Pressure sensor, intake manifold, gasoline				
Fg.no. →654518	03.05→			**0 261 230 180**
2.0 [GG/GY]				**2,0 l 104-108 kW LF 4 Zyl.**
Pressure sensor, intake manifold, gasoline				
Fg.no. →654518	03.05→			**0 261 230 180**
2.3 [GG/GY]				**2,3 l 122 kW L3 4 Zyl.**
Pressure sensor, intake manifold, gasoline				
Fg.no. →654518	03.05→			**0 261 230 180**
2.3 MPS 4x4 [GG/GY]				**2,3 l 191 kW 4 Zyl.**
Boost pressure sensor, gasoline				
Fg.no. →655119	07.05→			**0 261 230 128**
6 Wagon				
1.8 [GG/GY]				**1,8 l 88 kW L8 4 Zyl.**
Pressure sensor, intake manifold, gasoline				
Fg.no. →427967	03.05→			**0 261 230 180**
2.0 [GG/GY]				**2,0 l 104-108 kW LF 4 Zyl.**
Pressure sensor, intake manifold, gasoline				
Fg.no. →427967	03.05→			**0 261 230 180**
2.3 [GG/GY]				**2,3 l 122 kW L3 4 Zyl.**
Pressure sensor, intake manifold, gasoline				
Fg.no. →427967	03.05→			**0 261 230 180**
2.3 4x4 [GG/GY]				**2,3 l 119 kW L3 4 Zyl.**
Pressure sensor, intake manifold, gasoline				
Fg.no. →427967	03.05→			**0 261 230 180**

MERCEDES-BENZ

Classe A			
160 [168]			**1,6 l 75 kW M 166.960 4 Zyl.**
Speed sensor, ignition/injection	05.99-08.05		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	05.99-08.05		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	05.99-08.05		**0 265 005 303**
Fg.no. A029701→	05.99-08.05		**0 265 005 307**
Wheel speed sensor, front	05.99-08.05	LAB	**0 265 006 370**
		RAB	**0 265 006 368**
Wheel speed sensor, rear	05.99-08.05		**0 265 006 372**
190 [168]			**1,9 l 92 kW M 166.990 4 Zyl.**
Speed sensor, ignition/injection	09.00-08.05		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	09.00-08.05		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	09.00-08.05		**0 265 005 303**
Wheel speed sensor, front	09.00-08.05	LAB	**0 265 006 370**
		RAB	**0 265 006 368**
Wheel speed sensor, rear	09.00-08.05		**0 265 006 372**
MB			
100			**2,3 l 110 kW M 161.971 4 Zyl.**
Air mass meter, gasoline injection	11.96→		**0 280 217 100**
Speed sensor, ignition/injection	11.96→		**0 281 002 123**
Serie A			
140 [168]			**1,4 l 60 kW M 166.940 4 Zyl.**
Speed sensor, ignition/injection	01.98-08.04		**0 261 210 170**
	10.97-12.97		**0 281 002 123**
Duo sensor, acceleration and yaw rate, brake system	10.97-05.99		**0 265 005 201**
	06.99-08.04		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	10.97-08.04		**0 265 005 303**
Wheel speed sensor, front	10.97-08.04	LAB	**0 265 006 370**
		RAB	**0 265 006 368**
Wheel speed sensor, rear	10.97-08.04		**0 265 006 372**
150 [169]			**1,5 l 70 kW M 266.920 4 Zyl.**
Phase sensor	09.04→		**0 232 103 050**
Speed sensor, ignition/injection	09.04→		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	09.04→		**0 265 005 298**
Wheel speed sensor, front	09.04→		**0 265 007 478**
Wheel speed sensor, rear	09.04→		**0 265 007 480**
160 [168]			**1,6 l 75 kW M 166.960 4 Zyl.**
Speed sensor, ignition/injection	01.98-08.04		**0 261 210 170**
	10.97-12.97		**0 281 002 123**
Duo sensor, acceleration and yaw rate, brake system	10.97-05.99		**0 265 005 201**
	06.99-08.04		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	10.97-08.04		**0 265 005 303**
Wheel speed sensor, front	10.97-08.04	LAB	**0 265 006 370**
		RAB	**0 265 006 368**
Wheel speed sensor, rear	10.97-08.04		**0 265 006 372**

Product			
160 CDI [168]			**1,7 l 44 kW OM 668.941 4 Zyl.**
Air mass meter, diesel			
Mot.no. →30210110	09.98-02.01		**0 281 002 281**
Speed sensor, diesel	09.98-02.01		**0 261 210 170**
High-pressure sensor (CR system)	09.98-02.01		**0 281 002 498**
Duo sensor, acceleration and yaw rate, brake system	09.98-05.99		**0 265 005 201**
	06.99-02.01		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	09.98-02.01		**0 265 005 303**
Wheel speed sensor, front	09.98-02.01	LAB	**0 265 006 370**
		RAB	**0 265 006 368**
Wheel speed sensor, rear	09.98-02.01		**0 265 006 372**
160 CDI [168]			**1,7 l 55 kW OM 668.940 4 Zyl.**
Air mass meter, diesel			
Mot.no. →30210110	03.01-08.04		**0 281 002 281**
Speed sensor, diesel	03.01-08.04		**0 261 210 170**
High-pressure sensor (CR system)	03.01-08.04		**0 281 002 498**
Duo sensor, acceleration and yaw rate, brake system	03.01-08.04		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	03.01-08.04		**0 265 005 303**
Wheel speed sensor, front	03.01-08.04	LAB	**0 265 006 370**
		RAB	**0 265 006 368**
Wheel speed sensor, rear	03.01-08.04		**0 265 006 372**
160 CDI [169]			**2,0 l 60 kW OM 640.942 4 Zyl.**
Speed sensor, diesel	09.04→		**0 261 210 170**
High-pressure sensor (CR system)	09.04→		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	09.04→		**0 265 005 298**
Wheel speed sensor, front	09.04→		**0 265 007 478**
Wheel speed sensor, rear	09.04→		**0 265 007 480**
170 [169]			**1,7 l 85 kW M 266.940 4 Zyl.**
Phase sensor	09.04→		**0 232 103 050**
Speed sensor, ignition/injection	09.04→		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	09.04→		**0 265 005 298**
Wheel speed sensor, front	09.04→		**0 265 007 478**
Wheel speed sensor, rear	09.04→		**0 265 007 480**
170 CDI [168]			**1,7 l 66 kW OM 668.940 4 Zyl.**
Air mass meter, diesel			
Mot.no. →30210110	07.98-02.01		**0 281 002 281**
Speed sensor, diesel	07.98-02.01		**0 261 210 170**
High-pressure sensor (CR system)	07.98-02.01		**0 281 002 498**
Duo sensor, acceleration and yaw rate, brake system	07.98-05.99		**0 265 005 201**
	06.99-02.01		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	07.98-02.01		**0 265 005 303**
Wheel speed sensor, front	07.98-02.01	LAB	**0 265 006 370**
		RAB	**0 265 006 368**
Wheel speed sensor, rear	07.98-02.01		**0 265 006 372**
170 CDI [168]			**1,7 l 66/70 kW OM 668.942 4 Zyl.**
Air mass meter, diesel			
Mot.no. →30210110	03.01-08.04		**0 281 002 281**
Speed sensor, diesel	03.01-08.04		**0 261 210 170**
High-pressure sensor (CR system)	03.01-08.04		**0 281 002 498**
Duo sensor, acceleration and yaw rate, brake system	03.01-08.04		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	03.01-08.04		**0 265 005 303**
Wheel speed sensor, front	03.01-08.04	LAB	**0 265 006 370**
		RAB	**0 265 006 368**
Wheel speed sensor, rear	03.01-08.04		**0 265 006 372**
180 CDI [169]			**2,0 l 80 kW OM 640.940 4 Zyl.**
Speed sensor, diesel	09.04→		**0 261 210 170**
High-pressure sensor (CR system)	09.04→		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	09.04→		**0 265 005 298**

Product			
Wheel speed sensor, front	09.04→		**0 265 007 478**
Wheel speed sensor, rear	09.04→		**0 265 007 480**
190 [168]			**1,9 l 92 kW M 166.990 4 Zyl.**
Speed sensor, ignition/injection	03.99-08.04		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	03.99-05.99		**0 265 005 201**
	06.99-08.04		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	03.99-08.04		**0 265 005 303**
Wheel speed sensor, front	03.99-08.04	LAB	**0 265 006 370**
		RAB	**0 265 006 368**
Wheel speed sensor, rear	03.99-08.04		**0 265 006 372**
200 [169]			**2,0 l 100 kW M 266.960 4 Zyl.**
Phase sensor	09.04→		**0 232 103 050**
Speed sensor, ignition/injection	09.04→		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	09.04→		**0 265 005 298**
Wheel speed sensor, front	09.04→		**0 265 007 478**
Wheel speed sensor, rear	09.04→		**0 265 007 480**
200 CDI [169]			**2,0 l 103 kW OM 640.941 4 Zyl.**
Speed sensor, diesel	09.04→		**0 261 210 170**
High-pressure sensor (CR system)	09.04→		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	09.04→		**0 265 005 298**
Wheel speed sensor, front	09.04→		**0 265 007 478**
Wheel speed sensor, rear	09.04→		**0 265 007 480**
200 Turbo [169]			**2,0 l 142 kW M 266.980 4 Zyl.**
Phase sensor	06.05→		**0 232 103 050**
Speed sensor, ignition/injection	06.05→		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	06.05→		**0 265 005 298**
Wheel speed sensor, front	06.05→		**0 265 007 478**
Wheel speed sensor, rear	06.05→		**0 265 007 480**
210 Evolution [168]			**2,1 l 103 kW M 166.995 4 Zyl.**
Speed sensor, ignition/injection	03.02-08.04		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	03.02-08.04		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	03.02-08.04		**0 265 005 303**
Wheel speed sensor, front	03.02-08.04	LAB	**0 265 006 370**
		RAB	**0 265 006 368**
Wheel speed sensor, rear	03.02-08.04		**0 265 006 372**

Serie B

150 [245]			**1,5 l 70 kW M 266.920 4 Zyl.**
Phase sensor	04.05→		**0 232 103 050**
Speed sensor, ignition/injection	04.05→		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 298**
Wheel speed sensor, front	04.05→		**0 265 007 478**
Wheel speed sensor, rear	04.05→		**0 265 007 480**
170 [245]			**1,7 l 85 kW M 266.940 4 Zyl.**
Phase sensor	04.05→		**0 232 103 050**
Speed sensor, ignition/injection	04.05→		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 298**
Wheel speed sensor, front	04.05→		**0 265 007 478**
Wheel speed sensor, rear	04.05→		**0 265 007 480**
180 CDI [245]			**2,0 l 80 kW OM 640.940 4 Zyl.**
Speed sensor, diesel	04.05→	FKW	**0 261 210 170**
Phase sensor	04.05→		**0 232 103 050**
High-pressure sensor (CR system)	04.05→		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 298**

M

Product

◀ Serie B

Wheel speed sensor, front	04.05→		**0 265 007 478**
Wheel speed sensor, rear	04.05→		**0 265 007 480**
200 [245]	**2,0 l 100 kW M 266.960 4 Zyl.**		
Phase sensor	04.05→		**0 232 103 050**
Speed sensor, ignition/injection	04.05→		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 298**
Wheel speed sensor, front	04.05→		**0 265 007 478**
Wheel speed sensor, rear	04.05→		**0 265 007 480**
200 CDI [245]	**2,0 l 103 kW OM 640.941 4 Zyl.**		
Speed sensor, diesel	04.05→	FKW	**0 261 210 170**
Phase sensor	04.05→		**0 232 103 050**
High-pressure sensor (CR system)	04.05→		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 298**
Wheel speed sensor, front	04.05→		**0 265 007 478**
Wheel speed sensor, rear	04.05→		**0 265 007 480**
200 Turbo [245]	**2,0 l 142 kW M 266.980 4 Zyl.**		
Phase sensor	04.05→		**0 232 103 050**
Speed sensor, ignition/injection	04.05→		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 298**
Wheel speed sensor, front	04.05→		**0 265 007 478**
Wheel speed sensor, rear	04.05→		**0 265 007 480**

Serie C

30 AMG CDI [203]	**3,0 l 170 kW OM 612.990 5 Zyl.**		
Air mass meter, diesel	01.03-08.04		**0 281 002 535**
Speed sensor, diesel	01.03-08.04		**0 261 210 170**
High-pressure sensor (CR system)			
Mot.no. →30 287865,→40 176145, →50 846433,→60 001942	01.03-08.04		**0 281 002 498**
Mot.no. 30 287866→,40 176146→, 50 846434→,60 001943→	01.03-08.04		**0 281 002 700**
30 AMG CDI Coupé [203]	**3,0 l 170 kW OM 612.990 5 Zyl.**		
Air mass meter, diesel	09.02-08.04		**0 281 002 535**
Speed sensor, diesel	09.02-08.04		**0 261 210 170**
High-pressure sensor (CR system)			
Mot.no. →30 287865,→40 176145, →50 846433,→60 001942	09.02-08.04		**0 281 002 498**
Mot.no. 30 287866→,40 176146→, 50 846434→,60 001943→	09.02-08.04		**0 281 002 700**
32 AMG KOMPRESSOR [203]	**3,2 l 260 kW M 112.961 6 Zyl.**		
Throttle valve assembly	01.01-01.04		**0 280 750 017**
Phase sensor	01.01-01.04		**0 232 103 050**
Speed sensor, ignition/injection	01.01-01.04		**0 261 210 170**
Knock sensor	01.01-01.04		**0 261 231 110**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	01.01-01.04		**0 265 005 307**
36 AMG [202]	**3,6 l 206 kW M 104.941 6 Zyl.**		
Throttle valve assembly			
Mot.no. 006909→,Comp. no. Code 807	01.94-05.97	ASR,GS, OTT	**0 205 003 042**
Mot.no. 084643→,Comp. no. Code 807	01.94-05.97	AG,ASR, OTT	**0 205 003 042**
Air mass meter, gasoline injection			
Mot.no. →12/52 084642,~~Comp. no. Code 807~~	01.94-05.97		**0 280 217 500**
Mot.no. 006909→,Comp. no. Code 807	01.94-05.97	GS	**0 280 217 517**
Mot.no. 084643→,~~Comp. no. Code 807~~	08.96-05.97		**0 280 218 080**
Mot.no. 084643→,Comp. no. Code 807	01.94-05.97	AG	**0 280 217 517**

Product

Speed sensor, ignition/injection			
Mot.no. →004555	01.94-05.97	GS	**0 261 210 085**
Mot.no. →042151	01.94-05.97	AG	**0 261 210 085**
Mot.no. 004556→006908	01.94-05.97	GS	**0 261 210 122**
Mot.no. 006909→	01.94-05.97	GS	**0 261 210 141**
Mot.no. 042152→084642	01.94-05.97	AG	**0 261 210 122**
Mot.no. 084643→	01.94-05.97	AG	**0 261 210 141**
Pedal position sensor, EMS (electronic engine management)	09.96-05.97		**0 205 001 302**
Wheel speed sensor, front			
Fg.no. A334661→A809594, F331441→F894083,202...A/B/C/D/E, Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	01.94-05.97	BO,LAB	**0 265 006 266**
Fg.no. A344661→A809594, F331441→F894083,202...A/B/C/D/E, Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	01.94-05.97	BO,RAB	**0 265 006 264**
Fg.no. →A344660,→F331440, Comp. no. Code 805,~~Comp. no. Code 806~~	01.94-05.97	BO,LAB	**0 265 006 248**
		BO,RAB	**0 265 006 242**
Wheel speed sensor, rear	01.94-05.97	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
		BO,OEA	**0 265 002 212**
43 AMG [202]	**4,3 l 225 kW M 113.944 8 Zyl.**		
Throttle valve assembly	11.97-04.00		**0 205 003 048**
Air mass meter, gasoline injection	11.97-04.00		**0 280 217 810**
Phase sensor	11.97-04.00	NOC	**0 232 103 050**
Speed sensor, ignition/injection	11.97-04.00	FKW	**0 261 210 170**
Knock sensor	11.97-04.00		**0 261 231 110**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A653728,→F758207, Comp. no. Code 808,~~Comp. no. Code 809~~	11.97-04.00		**0 205 001 302**
Duo sensor, acceleration and yaw rate, brake system	11.97-04.00		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. A 809595→,F 894084→	11.97-04.00		**0 265 005 307**
Wheel speed sensor, front			
Fg.no. 202...A/B/C/D/E	11.97-04.00	BO,LAB	**0 265 006 266**
		BO,RAB	**0 265 006 264**
Wheel speed sensor, rear	11.97-04.00	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
		BO,OEA	**0 265 002 212**
55 AMG [203]	**5,4 l 270 kW M 113.988 8 Zyl.**		
Throttle valve assembly	02.04-08.07		**0 280 750 017**
Air mass meter, gasoline injection	02.04-08.07		**0 280 217 810**
Phase sensor	02.04-08.07		**0 232 103 050**
Speed sensor, ignition/injection	02.04-08.07		**0 261 210 170**
Knock sensor	02.04-08.07		**0 261 231 110**
160 KOMPRESSOR Coupé [203]	**1,8 l 90 kW M 271.921 4 Zyl.**		
Throttle valve assembly	06.05→		**0 280 750 076**
Phase sensor	06.05→		**0 232 103 050**
Speed sensor, ignition/injection	06.05→		**0 261 210 170**
180 [202]	**1,8 l 90 kW M 111.920 4 Zyl.**		
Air mass meter, gasoline injection	03.93-08.95		**0 280 217 100**
Speed sensor, ignition/injection	03.93-08.95		**0 261 210 085**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. A 809595→,F 894084→	03.93-08.95		**0 265 005 307**

Product			
Wheel speed sensor, front			
Fg.no. A334661→,F331441→, 202...A/B/D/E,Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	03.93-08.95	BO,LAB	**0 265 006 266**
Fg.no. A344661→,F331441→, 202...A/B/C/D/E,Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	03.93-08.95	BO,RAB	**0 265 006 264**
Fg.no. →A344660,→F331440,	03.93-08.95	BO,LAB	**0 265 006 248**
Comp. no. Code 805,~~Comp. no. Code 806~~		BO,RAB	**0 265 006 242**
Wheel speed sensor, rear	03.93-08.95	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
		BO,OEA	**0 265 002 212**
180 [202]		**1,8 l 90 kW M 111.921 4 Zyl.**	
Throttle valve assembly			
Mot.no. 060039→,Comp. no. Code 809, ~~Comp. no. Code 808~~	09.95-04.00	AG,OTT	**0 280 750 074**
Mot.no. 106154→,Comp. no. Code 809, ~~Comp. no. Code 808~~	09.95-04.00	GS,OTT	**0 280 750 074**
Air mass meter, gasoline injection	09.95-04.00	FGK	**0 280 217 114**
		KUT	**0 280 218 081**
Speed sensor, ignition/injection			
Mot.no. →060038	09.95-04.00	AG	**0 281 002 123**
Mot.no. →106153	09.95-04.00	GS	**0 281 002 123**
Mot.no. 060039→	09.95-04.00	AG	**0 261 210 170**
Mot.no. 106154→	09.95-04.00	GS	**0 261 210 170**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. A 809595→,F 894084→	09.95-04.00		**0 265 005 307**
Wheel speed sensor, front			
Fg.no. A334661→,F331441→, 202...A/B/D/E,Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	09.95-04.00	BO,LAB	**0 265 006 266**
Fg.no. A344661→,F331441→, 202...A/B/C/D/E,Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	09.95-04.00	BO,RAB	**0 265 006 264**
Fg.no. →A344660,→F331440,	09.95-04.00	BO,LAB	**0 265 006 248**
Comp. no. Code 805,~~Comp. no. Code 806~~		BO,RAB	**0 265 006 242**
Wheel speed sensor, rear	09.95-04.00	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
		BO,OEA	**0 265 002 212**
180 [203]		**2,0 l 95 kW M 111.951 4 Zyl.**	
Throttle valve assembly	10.00-08.02		**0 280 750 067**
Speed sensor, ignition/injection	10.00-08.02		**0 261 210 170**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	10.00-08.02		**0 265 005 307**
180 Coupé [203]		**2,0 l 95 kW M 111.951 4 Zyl.**	
Throttle valve assembly	01.01-08.02		**0 280 750 067**
Speed sensor, ignition/injection	01.01-08.02		**0 261 210 170**
180 KOMPRESSOR [203]		**1,8 l 105 kW M 271.946 4 Zyl.**	
Throttle valve assembly	09.02-07.07		**0 280 750 076**
Phase sensor	09.02-07.07		**0 232 103 050**
Speed sensor, ignition/injection	09.02-07.07		**0 261 210 170**
180 KOMPRESSOR [204]		**1,8 l 115 kW M 271.952 4 Zyl.**	
Throttle valve assembly	08.07→		**0 280 750 076**
Phase sensor	08.07→		**0 232 103 050**
Speed sensor, ignition/injection	08.07→		**0 261 210 170**
180 KOMPRESSOR Coupé [203]		**1,8 l 105 kW M 271.946 4 Zyl.**	
Throttle valve assembly	09.02→		**0 280 750 076**
Phase sensor	09.02→		**0 232 103 050**
Speed sensor, ignition/injection	09.02→		**0 261 210 170**

Product			
200 [202]		**2,0 l 100 kW M 111.941 4 Zyl.**	
Air mass meter, gasoline injection	01.94-04.00		**0 280 217 100**
Speed sensor, ignition/injection	01.94-04.00		**0 261 210 085**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. A 809595→,F 894084→	01.94-04.00		**0 265 005 307**
Wheel speed sensor, front			
Fg.no. A334661→,F331441→, 202...A/B/D/E,Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	01.94-04.00	BO,LAB	**0 265 006 266**
Fg.no. A344661→,F331441→, 202...A/B/C/D/E,Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	01.94-04.00	BO,RAB	**0 265 006 264**
Fg.no. →A344660,→F331440,	01.94-04.00	BO,LAB	**0 265 006 248**
Comp. no. Code 805,~~Comp. no. Code 806~~		BO,RAB	**0 265 006 242**
Wheel speed sensor, rear	01.94-04.00	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
		BO,OEA	**0 265 002 212**
200 [202]		**2,0 l 100 kW M 111.945 4 Zyl.**	
Throttle valve assembly			
Mot.no. 060039→,Comp. no. Code 809, ~~Comp. no. Code 808~~	01.94-04.00	AG,OTT	**0 280 750 074**
Mot.no. 106154→,Comp. no. Code 809, ~~Comp. no. Code 808~~	01.94-04.00	GS,OTT	**0 280 750 074**
Air mass meter, gasoline injection	01.94-04.00	FGK	**0 280 217 114**
		KUT	**0 280 218 081**
Speed sensor, ignition/injection			
Mot.no. →060038	01.94-04.00	AG	**0 281 002 123**
Mot.no. →106153	01.94-04.00	GS	**0 281 002 123**
Mot.no. 060039→	01.94-04.00	AG	**0 261 210 170**
Mot.no. 106154→	01.94-04.00	GS	**0 261 210 170**
Wheel speed sensor, front			
Fg.no. A334661→,F331441→, 202...A/B/D/E,Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	01.94-04.00	BO,LAB	**0 265 006 266**
Fg.no. A344661→,F331441→, 202...A/B/C/D/E,Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	01.94-04.00	BO,RAB	**0 265 006 264**
Wheel speed sensor, rear	01.94-04.00	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
		BO,OEA	**0 265 002 212**
200 CDI [202]		**2,2 l 75 kW OM 611.960 4 Zyl.**	
Air mass meter, diesel			
Mot.no. →30 055905	03.98-04.00		**0 280 217 114**
Mot.no. 30 055906→	03.98-04.00		**0 281 002 384**
Pulse generator, diesel	03.98-04.00		**0 281 002 123**
High-pressure sensor (CR system)	03.98-04.00		**0 281 002 498**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. A 809595→,F 894084→	03.98-04.00		**0 265 005 307**
Wheel speed sensor, front			
Fg.no. A334661→A809594, F331441→F894083,202...A/B/C/D/E, Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	03.98-04.00	BO,LAB	**0 265 006 266**
Fg.no. A344661→A809594, F331441→F894083,202...A/B/C/D/E, Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	03.98-04.00	BO,RAB	**0 265 006 264**
Fg.no. →A344660,→F331440,	03.98-04.00	BO,LAB	**0 265 006 248**
Comp. no. Code 805,~~Comp. no. Code 806~~		BO,RAB	**0 265 006 242**

M

◀ Serie C

Product			
Wheel speed sensor, rear	03.98-04.00	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
		BO,OEA	**0 265 002 212**
200 CDI [203]	**2,2 l 75/90 kW OM 646.962 4 Zyl.**		
Air mass meter, diesel	03.03-07.07		**0 281 002 535**
Speed sensor, diesel	03.03-07.07		**0 261 210 170**
High-pressure sensor (CR system)	03.03-07.07		**0 281 002 504**
200 CDI [203]	**2,2 l 85 kW OM 611.962 4 Zyl.**		
Speed sensor, diesel	10.00-02.03		**0 261 210 170**
High-pressure sensor (CR system)	10.00-02.03		**0 281 002 498**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	10.00-02.03		**0 265 005 307**
200 CDI [204]	**2,2 l 100 kW OM 646.811 4 Zyl.**		
Air mass meter, diesel	08.07→		**0 281 002 535**
Speed sensor, diesel	08.07→		**0 261 210 170**
200 CDI Coupé [203]	**2,2 l 90 kW OM 646.962 4 Zyl.**		
Air mass meter, diesel	03.03→		**0 281 002 535**
Speed sensor, diesel	03.03→		**0 261 210 170**
High-pressure sensor (CR system)	03.03→		**0 281 002 504**
200 CGI KOMPRESSOR, Coupé [203]	**1,8 l 125 kW M 271.942 4 Zyl.**		
Throttle valve assembly	04.03-08.04		**0 280 750 076**
Phase sensor	04.03-08.04		**0 232 103 050**
Speed sensor, ignition/injection	04.03-08.04		**0 261 210 170**
200 D [202]	**2,0 l 55 kW OM 601.913 4 Zyl.**		
Temperature sensor, coolant, diesel	03.93-08.95	KLO	**0 280 130 035**
Wheel speed sensor, front	03.93-08.95	LAB	**0 265 006 248**
		RAB	**0 265 006 242**
Wheel speed sensor, rear	03.93-08.95	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
		BO,OEA	**0 265 002 212**
200 D [202]	**2,0 l 55-65 kW OM 604.915 4 Zyl.**		
Speed sensor, diesel	09.96-06.99		**0 281 002 123**
Pedal position sensor, diesel			
Fg.no. →A436535,→F483848, Comp. no. Code 806,~~Comp. no. Code 807~~	09.96-06.99		**0 205 001 029**
Wheel speed sensor, front			
Fg.no. A334661→,F331441→, 202...A/B/D/E,Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	09.96-06.99	BO,LAB	**0 265 006 266**
Fg.no. A344661→,F331441→, 202...A/B/C/D/E,Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	09.96-06.99	BO,RAB	**0 265 006 264**
Fg.no. →A344660,→F331440, Comp. no. Code 805,~~Comp. no. Code 806~~	09.96-06.99	BO,LAB	**0 265 006 248**
		BO,RAB	**0 265 006 242**
Wheel speed sensor, rear	09.96-06.99	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
		BO,OEA	**0 265 002 212**
200 KOMPRESSOR [202]	**2,0 l 132-141 kW M 111.944 4 Zyl.**		
Throttle valve assembly			
Mot.no. 002224→,Comp. no. Code 809, ~~Comp. no. Code 808~~	09.95-04.00	AG	**0 280 750 074**
Mot.no. 015671→,Comp. no. Code 809, ~~Comp. no. Code 808~~	09.95-04.00	GS	**0 280 750 074**
Air mass meter, gasoline injection	09.95-04.00	FGK	**0 280 217 114**
		KUT	**0 280 218 081**

Product			
Speed sensor, ignition/injection			
Mot.no. →060038	09.95-04.00	AG	**0 281 002 123**
Mot.no. →106153	09.95-04.00	GS	**0 281 002 123**
Mot.no. 060039→	09.95-04.00	AG	**0 261 210 170**
Mot.no. 106154→	09.95-04.00	GS	**0 261 210 170**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. A 809595→,F 894084→	09.95-04.00		**0 265 005 307**
Wheel speed sensor, front			
Fg.no. →A809594,→F894083, 202...A/B/C/D/E, Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	09.95-04.00	BO,LAB	**0 265 006 266**
		BO,RAB	**0 265 006 264**
Wheel speed sensor, rear	09.95-04.00	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
		BO,OEA	**0 265 002 212**
200 KOMPRESSOR [203]	**1,8 l 120 kW M 271.940 4 Zyl.**		
Throttle valve assembly	09.02-02.07		**0 280 750 076**
Phase sensor	09.02-02.07		**0 232 103 050**
Speed sensor, ignition/injection	09.02-02.07		**0 261 210 170**
200 KOMPRESSOR [203]	**2,0 l 120 kW M 111.955 4 Zyl.**		
Throttle valve assembly	05.00-08.02		**0 280 750 074**
Speed sensor, ignition/injection	05.00-08.02		**0 261 210 170**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	05.00-08.02		**0 265 005 307**
200 KOMPRESSOR [204]	**1,8 l 135 kW M 271.950 4 Zyl.**		
Throttle valve assembly	03.07→		**0 280 750 076**
Phase sensor	03.07→		**0 232 103 050**
Speed sensor, ignition/injection	03.07→		**0 261 210 170**
200 KOMPRESSOR Coupé [203]	**1,8 l 120 kW M 271.940 4 Zyl.**		
Throttle valve assembly	09.02→		**0 280 750 076**
Phase sensor	09.02→		**0 232 103 050**
Speed sensor, ignition/injection	09.02→		**0 261 210 170**
200 KOMPRESSOR Coupé [203]	**2,0 l 120 kW M 111.955 4 Zyl.**		
Throttle valve assembly	01.01-08.02		**0 280 750 074**
Speed sensor, ignition/injection	01.01-08.02		**0 261 210 170**
220 [202]	**2,2 l 110 kW M 111.961 4 Zyl.**		
Air mass meter, gasoline injection	03.93-09.96		**0 280 217 100**
Speed sensor, ignition/injection	03.93-09.96	OWE	**0 261 210 085**
		WEG	**0 261 210 122**
Knock sensor	03.93-09.96	OWE	**0 261 231 098**
Wheel speed sensor, front	03.93-09.95	BO,LAB, OAS	**0 265 006 248**
		BO,OAS, RAB	**0 265 006 242**
Fg.no. A334661→,F331441→, 202...A/B/D/E,Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	03.93-09.96	BO,LAB	**0 265 006 266**
Fg.no. A344661→,F331441→, 202...A/B/C/D/E,Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	03.93-09.96	BO,RAB	**0 265 006 264**
Fg.no. →A344660,→F331440, Comp. no. Code 805,~~Comp. no. Code 806~~	03.93-09.96	BO,LAB	**0 265 006 248**
		BO,RAB	**0 265 006 242**
Wheel speed sensor, rear	03.93-09.96	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
		BO,OEA	**0 265 002 212**
220 CDI [202]	**2,2 l 92 kW OM 611.960 4 Zyl.**		
Air mass meter, diesel			
Mot.no. →30 055905	12.97-04.00		**0 280 217 114**
Mot.no. 30 055906→	12.97-04.00		**0 281 002 384**

Product			
Pulse generator, diesel	12.97-04.00		**0 281 002 123**
High-pressure sensor (CR system)	12.97-04.00		**0 281 002 498**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. A 809595→,F 894084→	12.97-04.00		**0 265 005 307**
Wheel speed sensor, front			
Fg.no. A334661→A809594, F331441→F894083,202...A/B/C/D/E, Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	12.97-04.00	BO,LAB	**0 265 006 266**
Fg.no. A344661→A809594, F331441→F894083,202...A/B/C/D/E, Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	12.97-04.00	BO,RAB	**0 265 006 264**
Fg.no. →A344660,→F331440, Comp. no. Code 805,~~Comp. no. Code 806~~	12.97-04.00	BO,LAB	**0 265 006 248**
		BO,RAB	**0 265 006 242**
Wheel speed sensor, rear	12.97-04.00	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
		BO,OEA	**0 265 002 212**
220 CDI [203]	**2,2 l 105 kW OM 611.962 4 Zyl.**		
Speed sensor, diesel	05.00-02.03		**0 261 210 170**
High-pressure sensor (CR system)	05.00-02.03		**0 281 002 498**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	05.00-02.03		**0 265 005 307**
220 CDI [203]	**2,2 l 110 kW OM 646.963 4 Zyl.**		
Air mass meter, diesel	03.03-02.07		**0 281 002 535**
Speed sensor, diesel	03.03-02.07		**0 261 210 170**
High-pressure sensor (CR system)	03.03-02.07		**0 281 002 504**
220 CDI [204]	**2,2 l 125 kW OM 646.811 4 Zyl.**		
Air mass meter, diesel	03.07→		**0 281 002 535**
Speed sensor, diesel	03.07→		**0 261 210 170**
220 CDI Coupé [203]	**2,2 l 105 kW OM 611.962 4 Zyl.**		
Speed sensor, diesel	01.01-02.03		**0 261 210 170**
High-pressure sensor (CR system)	01.01-02.03		**0 281 002 498**
220 CDI Coupé [203]	**2,2 l 110 kW OM 646.963 4 Zyl.**		
Air mass meter, diesel	03.03→		**0 281 002 535**
Speed sensor, diesel	03.03→		**0 261 210 170**
High-pressure sensor (CR system)	03.03→		**0 281 002 504**
220 D [202]	**2,2 l 55-70 kW OM 604.910 4 Zyl.**		
Speed sensor, diesel			
Mot.no. →018030	08.93-06.99	AG	**0 281 002 100**
Mot.no. →086383	08.93-06.99	GS	**0 281 002 100**
Mot.no. 018031→	08.93-06.99	AG	**0 281 002 123**
Mot.no. 086384→	08.93-06.99	GS	**0 281 002 123**
Pedal position sensor, diesel			
Fg.no. A 218853→,F 159752→	08.93-06.99		**0 205 001 029**
Fg.no. →A 218852,→F 159751	08.93-06.99		**0 205 001 008**
Wheel speed sensor, front			
Fg.no. A334661→,F331441→, 202...A/B/D/E,Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	08.93-06.99	BO,LAB	**0 265 006 266**
Fg.no. A344661→,F331441→, 202...A/B/C/D/E,Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	08.93-06.99	BO,RAB	**0 265 006 264**
Fg.no. →A344660,→F331440, Comp. no. Code 805,~~Comp. no. Code 806~~	08.93-06.99	BO,LAB	**0 265 006 248**
		BO,RAB	**0 265 006 242**
Wheel speed sensor, rear	08.93-06.99	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
		BO,OEA	**0 265 002 212**

Product			
230 [202]	**2,3 l 110 kW M 111.974 4 Zyl.**		
Air mass meter, gasoline injection	09.96-04.00	FGK	**0 280 217 114**
		KUT	**0 280 218 081**
Speed sensor, ignition/injection	09.96-04.00		**0 281 002 123**
Wheel speed sensor, front	09.96-04.00	BO,LAB	**0 265 006 266**
		BO,RAB	**0 265 006 264**
Wheel speed sensor, rear	09.96-04.00	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
		BO,OEA	**0 265 002 212**
230 [203]	**2,5 l 150 kW M 272.920 6 Zyl.**		
Throttle valve assembly	06.05-07.07		**0 280 750 017**
Air mass meter, gasoline injection	06.05-07.07		**0 280 218 190**
Phase sensor	06.05-07.07		**0 232 103 050**
Speed sensor, ignition/injection	06.05-07.07		**0 261 210 170**
Knock sensor	06.05-07.07		**0 261 231 188**
230 [204]	**2,5 l 150 kW M 272.921 6 Zyl.**		
Throttle valve assembly	08.07→		**0 280 750 017**
Air mass meter, gasoline injection	08.07→		**0 280 218 190**
Phase sensor	08.07→	LAB	**0 232 103 050**
Knock sensor	08.07→		**0 261 231 188**
230 Coupé [203]	**2,5 l 150 kW M 272.920 6 Zyl.**		
Throttle valve assembly	06.05→		**0 280 750 017**
Air mass meter, gasoline injection	06.05→		**0 280 218 190**
Phase sensor	06.05→		**0 232 103 050**
Speed sensor, ignition/injection	06.05→		**0 261 210 170**
Knock sensor	06.05→		**0 261 231 188**
230 KOMPRESSOR [202]	**2,3 l 142 kW M 111.975 4 Zyl.**		
Throttle valve assembly			
Mot.no. 000268→015300, Comp. no. Code 807/808,~~Comp. no. Code 809~~	09.95-04.00	AG	**0 205 003 044**
Mot.no. 005591→012652, Comp. no. Code 807/808,~~Comp. no. Code 809~~	09.95-04.00	GS	**0 205 003 044**
Mot.no. 012653→,Comp. no. Code 809, ~~Comp. no. Code 808~~	09.95-04.00	GS	**0 280 750 074**
Mot.no. 015301→,Comp. no. Code 809, ~~Comp. no. Code 808~~	09.95-04.00	AG	**0 280 750 074**
Air mass meter, gasoline injection	09.95-04.00	FGK	**0 280 217 114**
		KUT	**0 280 218 081**
Speed sensor, ignition/injection			
Mot.no. →012652	09.95-04.00	GS	**0 281 002 123**
Mot.no. →015300	09.95-04.00	AG	**0 281 002 123**
Mot.no. 012653→	09.95-04.00	GS	**0 261 210 170**
Mot.no. 015301→	09.95-04.00	AG	**0 261 210 170**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. A 809595→,F 894084→	09.95-04.00		**0 265 005 307**
Wheel speed sensor, front			
Fg.no. →A809594,→F894083, 202...A/B/C/D/E,Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	09.95-04.00	BO,LAB	**0 265 006 266**
		BO,RAB	**0 265 006 264**
Wheel speed sensor, rear	09.95-04.00	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
		BO,OEA	**0 265 002 212**
230 KOMPRESSOR, Coupé [203]	**1,8 l 141 kW M 271.948 4 Zyl.**		
Throttle valve assembly	02.04-05.05		**0 280 750 076**
Phase sensor	02.04-05.05		**0 232 103 050**
Speed sensor, ignition/injection	02.04-05.05		**0 261 210 170**
230 KOMPRESSOR Coupé [203]	**2,3 l 145 kW M 111.981 4 Zyl.**		
Throttle valve assembly	01.01-01.04		**0 280 750 074**

M

Product			
◀ Serie C			
230 4MATIC [204]			**2,5 l 150 kW M 272.911 6 Zyl.**
Throttle valve assembly	08.07→		**0 280 750 017**
Air mass meter, gasoline injection	08.07→		**0 280 218 190**
Phase sensor	08.07→	LAB	**0 232 103 050**
Knock sensor	08.07→		**0 261 231 188**
240 [202]			**2,4 l 125 kW M 112.910 6 Zyl.**
Throttle valve assembly	06.97-04.00		**0 205 003 046**
Air mass meter, gasoline injection	06.97-04.00		**0 280 217 515**
Phase sensor	06.97-04.00		**0 232 103 050**
Speed sensor, ignition/injection			
Mot.no. →370998	06.97-04.00		**0 261 210 141**
Mot.no. 370999→	06.97-04.00		**0 261 210 170**
Knock sensor	06.97-04.00		**0 261 231 110**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A653728,→F758207, Comp. no. Code 808,~~Comp. no. Code 809~~	06.97-04.00		**0 205 001 302**
Duo sensor, acceleration and yaw rate, brake system	06.97-04.00		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. A 809595→,F 894084→	06.97-04.00		**0 265 005 307**
Wheel speed sensor, front			
Fg.no. 202...A/B/C/D/E	06.97-04.00	BO,LAB	**0 265 006 266**
		BO,RAB	**0 265 006 264**
Wheel speed sensor, rear	06.97-04.00	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
		BO,OEA	**0 265 002 212**
240 [203]			**2,6 l 125 kW M 112.912 6 Zyl.**
Throttle valve assembly	05.00-05.05		**0 280 750 019**
Air mass meter, gasoline injection	05.00-05.05		**0 280 217 515**
Phase sensor	05.00-05.05		**0 232 103 050**
Speed sensor, ignition/injection	05.00-05.05		**0 261 210 170**
Knock sensor	05.00-05.05		**0 261 231 110**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	05.00-05.05		**0 265 005 307**
240 4MATIC [203]			**2,6 l 125 kW M 112.916 6 Zyl.**
Throttle valve assembly	09.02-06.05		**0 280 750 019**
Air mass meter, gasoline injection	09.02-06.05		**0 280 217 515**
Phase sensor	09.02-06.05		**0 232 103 050**
Speed sensor, ignition/injection	09.02-06.05		**0 261 210 170**
Knock sensor	09.02-06.05		**0 261 231 110**
250 D [202]			**2,5 l 83 kW OM 605.910 5 Zyl.**
Pulse generator, diesel	05.93-08.95		**0 281 002 100**
Speed sensor, diesel	05.93-08.95		**0 281 002 100**
Pedal position sensor, diesel			
Fg.no. A 218853→,F 159752→	05.93-08.95		**0 205 001 029**
Fg.no. →A 218852,→F 159751	05.93-08.95		**0 205 001 008**
Wheel speed sensor, front			
Fg.no. →A344660,→F331440, Comp. no. Code 805,~~Comp. no. Code 806~~	05.93-08.95	BO,LAB	**0 265 006 248**
		BO,RAB	**0 265 006 242**
Wheel speed sensor, rear	05.93-08.95	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
		BO,OEA	**0 265 002 212**
250 D Turbo [202]			**2,5 l 110 kW OM 605.960 5 Zyl.**
Air mass meter, diesel	09.95-04.00		**0 280 217 114**
Pulse generator, diesel			
Mot.no. →007447,~~Comp. no. Code 807~~	09.95-04.00	AG	**0 281 002 100**
Mot.no. →014999,~~Comp. no. Code 807~~	09.95-04.00	GS	**0 281 002 100**
Mot.no. 007448→,Comp. no. Code 807	09.95-04.00	AG	**0 281 002 123**
Mot.no. 015000→,Comp. no. Code 807	09.95-04.00	GS	**0 281 002 123**

Product			
Pedal position sensor, diesel	09.95-04.00		**0 205 001 029**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. A 809595→,F 894084→	09.95-04.00		**0 265 005 307**
Wheel speed sensor, front			
Fg.no. A334661→A809594, F331441→F894083,202...A/B/C/D/E, Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	09.95-04.00	BO,LAB	**0 265 006 266**
Fg.no. A344661→A809594, F331441→F894083,202...A/B/C/D/E, Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	09.95-04.00	BO,RAB	**0 265 006 264**
Fg.no. →A344660,→F331440, Comp. no. Code 805,~~Comp. no. Code 806~~	09.95-04.00	BO,LAB	**0 265 006 248**
		BO,RAB	**0 265 006 242**
Wheel speed sensor, rear	09.95-04.00	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
		BO,OEA	**0 265 002 212**
270 CDI [203]			**2,7 l 125 kW OM 612.962 5 Zyl.**
Speed sensor, diesel	12.00-08.04		**0 261 210 170**
High-pressure sensor (CR system)	12.00-08.04		**0 281 002 498**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	12.00-08.04		**0 265 005 307**
280 [202]			**2,8 l 142 kW M 104.941 6 Zyl.**
Throttle valve assembly			
Mot.no. 006909→,Comp. no. Code 807	05.93-05.97	ASR,GS, OTT	**0 205 003 042**
Mot.no. 084643→,Comp. no. Code 807	05.93-05.97	AG,ASR, OTT	**0 205 003 042**
Air mass meter, gasoline injection			
Mot.no. →12/52 084642,~~Comp. no. Code 807~~	05.93-05.97		**0 280 217 500**
Mot.no. 006909→,Comp. no. Code 807	05.93-05.97	GS	**0 280 217 517**
Mot.no. 084643→,~~Comp. no. Code 807~~	08.96-05.97		**0 280 218 080**
Mot.no. 084643→,Comp. no. Code 807	05.93-05.97	AG	**0 280 217 517**
Speed sensor, ignition/injection			
Mot.no. →004555	05.93-05.97	GS	**0 261 210 085**
Mot.no. →042151	05.93-05.97	AG	**0 261 210 085**
Mot.no. 004556→006908	05.93-05.97	GS	**0 261 210 122**
Mot.no. 006909→	05.93-05.97	GS	**0 261 210 141**
Mot.no. 042152→084642	05.93-05.97	AG	**0 261 210 122**
Mot.no. 084643→	05.93-05.97	AG	**0 261 210 141**
Pedal position sensor, EMS (electronic engine management)	09.96-05.97		**0 205 001 302**
Wheel speed sensor, front			
Fg.no. A334661→A809594, F331441→F894083,202...A/B/C/D/E, Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	05.93-05.97	BO,LAB	**0 265 006 266**
Fg.no. A344661→A809594, F331441→F894083,202...A/B/C/D/E, Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	05.93-05.97	BO,RAB	**0 265 006 264**
Fg.no. →A344660,→F331440, Comp. no. Code 805,~~Comp. no. Code 806~~	05.93-05.97	BO,LAB	**0 265 006 248**
		BO,RAB	**0 265 006 242**
Wheel speed sensor, rear	05.93-05.97	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
		BO,OEA	**0 265 002 212**

Product			
280 [202]			**2,8 l 145 kW M 112.920 6 Zyl.**
Throttle valve assembly			
Comp. no. Code 800	06.97-04.00		**0 205 003 046**
Comp. no. Code 801	06.97-04.00		**0 280 750 019**
Air mass meter, gasoline injection	06.97-04.00		**0 280 217 515**
Phase sensor	06.97-04.00		**0 232 103 050**
Speed sensor, ignition/injection			
Mot.no. →370998	06.97-04.00		**0 261 210 141**
Mot.no. 370999→	06.97-04.00		**0 261 210 170**
Knock sensor	06.97-04.00		**0 261 231 110**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A653728,→F758207, Comp. no. Code 808,~~Comp. no. Code 809~~	06.97-04.00		**0 205 001 302**
Duo sensor, acceleration and yaw rate, brake system	06.97-04.00		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. A 809595→,F 894084→	06.97-04.00		**0 265 005 307**
Wheel speed sensor, front			
Fg.no. 202...A/B/C/D/E	06.97-04.00	BO,LAB	**0 265 006 266**
		BO,RAB	**0 265 006 264**
Wheel speed sensor, rear	06.97-04.00	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
		BO,OEA	**0 265 002 212**
280 [203]			**3,0 l 170 kW M 272.940 6 Zyl.**
Throttle valve assembly	06.05-02.07		**0 280 750 017**
Air mass meter, gasoline injection	06.05-02.07		**0 280 218 190**
Phase sensor	06.05-02.07		**0 232 103 050**
Speed sensor, ignition/injection	06.05-02.07		**0 261 210 170**
Knock sensor	06.05-02.07		**0 261 231 188**
280 [204]			**3,0 l 170 kW M 272.947 6 Zyl.**
Throttle valve assembly	03.07→		**0 280 750 017**
Air mass meter, gasoline injection	03.07→		**0 280 218 190**
Phase sensor	03.07→	LAB	**0 232 103 050**
Knock sensor	03.07→		**0 261 231 188**
280 4MATIC [203]			**3,0 l 170 kW M 272.941 6 Zyl.**
Throttle valve assembly	07.05-08.07		**0 280 750 017**
Air mass meter, gasoline injection	07.05-08.07		**0 280 218 190**
Phase sensor	07.05-08.07		**0 232 103 050**
Speed sensor, ignition/injection	07.05-08.07		**0 261 210 170**
Knock sensor	07.05-08.07		**0 261 231 188**
280 4MATIC [204]			**3,0 l 170 kW M 272.948 6 Zyl.**
Throttle valve assembly	07.07→		**0 280 750 017**
Air mass meter, gasoline injection	07.07→		**0 280 218 190**
Phase sensor	07.07→	LAB	**0 232 103 050**
Knock sensor	07.07→		**0 261 231 188**
320 [203]			**3,2 l 160 kW M 112.946 6 Zyl.**
Throttle valve assembly	05.00-05.05		**0 280 750 019**
Air mass meter, gasoline injection	05.00-05.05		**0 280 217 515**
Phase sensor	05.00-05.05		**0 232 103 050**
Speed sensor, ignition/injection	05.00-05.05		**0 261 210 170**
Knock sensor	05.00-05.05		**0 261 231 110**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	05.00-05.05		**0 265 005 307**
320 CDI [203]			**3,0 l 165 kW OM 642.910 6 Zyl.**
Speed sensor, diesel	09.04-05.07		**0 261 210 170**
320 Coupé [203]			**3,2 l 160 kW M 112.946 6 Zyl.**
Throttle valve assembly	09.02-05.05		**0 280 750 019**
Air mass meter, gasoline injection	09.02-05.05		**0 280 217 515**
Phase sensor	09.02-05.05		**0 232 103 050**
Speed sensor, ignition/injection	09.02-05.05		**0 261 210 170**
Knock sensor	09.02-05.05		**0 261 231 110**
320 4MATIC [203]			**3,2 l 160 kW M 112.953 6 Zyl.**
Throttle valve assembly	09.02-06.05		**0 280 750 019**
Air mass meter, gasoline injection	09.02-06.05		**0 280 217 515**
Phase sensor	09.02-06.05		**0 232 103 050**
Speed sensor, ignition/injection	09.02-06.05		**0 261 210 170**
Knock sensor	09.02-06.05		**0 261 231 110**
350 [203]			**3,5 l 200 kW M 272.960 6 Zyl.**
Throttle valve assembly	06.05-02.07		**0 280 750 017**
Air mass meter, gasoline injection	06.05-02.07		**0 280 218 190**
Phase sensor	06.05-02.07		**0 232 103 050**
Speed sensor, ignition/injection	06.05-02.07		**0 261 210 170**
Knock sensor	06.05-02.07		**0 261 231 110**
350 [204]			**3,5 l 200 kW M 272.961 6 Zyl.**
Throttle valve assembly	03.07→		**0 280 750 017**
Air mass meter, gasoline injection	03.07→		**0 280 218 190**
Phase sensor	03.07→	LAB	**0 232 103 050**
Knock sensor	03.07→		**0 261 231 188**
350 Coupé [203]			**3,5 l 200 kW M 272.960 6 Zyl.**
Throttle valve assembly	06.05→		**0 280 750 017**
Air mass meter, gasoline injection	06.05→		**0 280 218 190**
Phase sensor	06.05→		**0 232 103 050**
Speed sensor, ignition/injection	06.05→		**0 261 210 170**
Knock sensor	06.05→		**0 261 231 110**
350 4MATIC [203]			**3,5 l 200 kW M 272.970 6 Zyl.**
Throttle valve assembly	07.05-08.07		**0 280 750 017**
Air mass meter, gasoline injection	07.05-08.07		**0 280 218 190**
Phase sensor	07.05-08.07		**0 232 103 050**
Speed sensor, ignition/injection	07.05-08.07		**0 261 210 170**
Knock sensor	07.05-08.07		**0 261 231 110**
350 4MATIC [204]			**3,5 l 200 kW M 272.971 6 Zyl.**
Throttle valve assembly	07.07→		**0 280 750 017**
Air mass meter, gasoline injection	07.07→		**0 280 218 190**
Phase sensor	07.07→	LAB	**0 232 103 050**
Knock sensor	07.07→		**0 261 231 188**

Serie C (T-Modell)

30 AMG CDI T [203]			**3,0 l 170 kW OM 612.990 5 Zyl.**
Air mass meter, diesel	01.03-08.04		**0 281 002 535**
Speed sensor, diesel	01.03-08.04		**0 261 210 170**
High-pressure sensor (CR system)			
Mot.no. →30 287865,→40 176145, →50 846433,→60 001942	01.03-08.04		**0 281 002 498**
Mot.no. 30 287866→,40 176146→, 50 846434→,60 001943→	01.03-08.04		**0 281 002 700**
32 AMG KOMPRESSOR T [203]			**3,2 l 260 kW M 112.961 6 Zyl.**
Throttle valve assembly	01.01-01.04		**0 280 750 017**
Phase sensor	01.01-01.04		**0 232 103 050**
Speed sensor, ignition/injection	01.01-01.04		**0 261 210 170**
Knock sensor	01.01-01.04		**0 261 231 110**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	01.01-01.04		**0 265 005 307**
43 AMG T [202]			**4,3 l 225 kW M 113.944 8 Zyl.**
Throttle valve assembly	10.97-02.01		**0 205 003 048**
Air mass meter, gasoline injection	10.97-02.01		**0 280 217 810**
Phase sensor	10.97-02.01	NOC	**0 232 103 050**
Speed sensor, ignition/injection	10.97-02.01	FKW	**0 261 210 170**
Knock sensor	10.97-02.01		**0 261 231 110**
Pedal position sensor, EMS (electronic engine management)	10.97-02.01		**0 205 001 302**

M

Product			
◀ Serie C (T-Modell)			
Duo sensor, acceleration and yaw rate, brake system	10.97-02.01		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. F 984084→	10.97-02.01		**0 265 005 307**
Wheel speed sensor, front	10.97-02.01	BO,LAB	**0 265 006 266**
		BO,RAB	**0 265 006 264**
Wheel speed sensor, rear			
Fg.no. →F894083,Comp. no. Code 808/809, ~~Comp. no. Code 800/807~~	10.97-02.01	LAB	**0 265 006 192**
		RAB	**0 265 006 172**
55 AMG T [203]	**5,4 l 270 kW M 113.988 8 Zyl.**		
Throttle valve assembly	02.04-08.07		**0 280 750 017**
Air mass meter, gasoline injection	02.04-08.07		**0 280 217 810**
Phase sensor	02.04-08.07		**0 232 103 050**
Speed sensor, ignition/injection	02.04-08.07		**0 261 210 170**
Knock sensor	02.04-08.07		**0 261 231 110**
180 KOMPRESSOR T [203]	**1,8 l 105 kW M 271.946 4 Zyl.**		
Throttle valve assembly	09.02-08.07		**0 280 750 076**
Phase sensor	09.02-08.07		**0 232 103 050**
Speed sensor, ignition/injection	09.02-08.07		**0 261 210 170**
180 KOMPRESSOR T [204]	**1,8 l 115 kW M 271.952 4 Zyl.**		
Throttle valve assembly	09.07→		**0 280 750 076**
Phase sensor	09.07→		**0 232 103 050**
Speed sensor, ignition/injection	09.07→		**0 261 210 170**
180 T [202]	**1,8 l 90 kW M 111.920 4 Zyl.**		
Air mass meter, gasoline injection	05.96-02.01		**0 280 217 100**
Speed sensor, ignition/injection	05.96-02.01		**0 261 210 085**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. F 984084→	05.96-02.01		**0 265 005 307**
Wheel speed sensor, rear			
Fg.no. →F894083,Comp. no. Code 808/809, ~~Comp. no. Code 800/807~~	05.96-02.01	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
180 T [202]	**1,8 l 90 kW M 111.921 4 Zyl.**		
Throttle valve assembly			
Mot.no. 060039→,Comp. no. Code 809, ~~Comp. no. Code 808~~	05.96-02.01	AG,OTT	**0 280 750 074**
Mot.no. 106154→,Comp. no. Code 809, ~~Comp. no. Code 808~~	05.96-02.01	GS,OTT	**0 280 750 074**
Air mass meter, gasoline injection	05.96-02.01	FGK	**0 280 217 114**
		KUT	**0 280 218 081**
Speed sensor, ignition/injection			
Mot.no. →060038	05.96-02.01	AG	**0 281 002 123**
Mot.no. →106153	05.96-02.01	GS	**0 281 002 123**
Mot.no. 060039→	05.96-02.01	AG	**0 261 210 170**
Mot.no. 106154→	05.96-02.01	GS	**0 261 210 170**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. F 984084→	05.96-02.01		**0 265 005 307**
Wheel speed sensor, rear			
Fg.no. →F894083,Comp. no. Code 808/809, ~~Comp. no. Code 800/807~~	05.96-02.01	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
180 T [202]	**2,0 l 95 kW M 111.952 4 Zyl.**		
Throttle valve assembly	09.00-02.01		**0 280 750 074**
Speed sensor, ignition/injection	09.00-02.01		**0 261 210 170**
180 T [203]	**2,0 l 95 kW M 111.951 4 Zyl.**		
Throttle valve assembly	01.01-08.02		**0 280 750 067**
Speed sensor, ignition/injection	01.01-08.02		**0 261 210 170**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	01.01-08.02		**0 265 005 307**

Product			
200 CDI T [202]	**2,2 l 75 kW OM 611.960 4 Zyl.**		
Air mass meter, diesel			
Mot.no. →30 055905	03.98-02.01		**0 280 217 114**
Mot.no. 30 055906→	03.98-02.01		**0 281 002 384**
Pulse generator, diesel	03.98-02.01		**0 281 002 123**
High-pressure sensor (CR system)	03.98-02.01		**0 281 002 498**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. F 984084→	03.98-02.01		**0 265 005 307**
Wheel speed sensor, rear			
Fg.no. →F894083,Comp. no. Code 808/809, ~~Comp. no. Code 800/807~~	03.98-02.01	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
200 CDI T [203]	**2,2 l 75/90 kW OM 646.962 4 Zyl.**		
Air mass meter, diesel	03.03-08.07		**0 281 002 535**
Speed sensor, diesel	03.03-08.07		**0 261 210 170**
High-pressure sensor (CR system)	03.03-08.07		**0 281 002 504**
200 CDI T [203]	**2,2 l 85 kW OM 611.962 4 Zyl.**		
Speed sensor, diesel	10.01-02.03		**0 261 210 170**
High-pressure sensor (CR system)	10.01-02.03		**0 281 002 498**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	10.01-02.03		**0 265 005 307**
200 CDI T [204]	**2,2 l 100 kW OM 646.811 4 Zyl.**		
Air mass meter, diesel	09.07→		**0 281 002 535**
Speed sensor, diesel	09.07→		**0 261 210 170**
200 CGI KOMPRESSOR T [203]	**1,8 l 125 kW M 271.942 4 Zyl.**		
Throttle valve assembly	04.03-08.04		**0 280 750 076**
Phase sensor	04.03-08.04		**0 232 103 050**
Speed sensor, ignition/injection	04.03-08.04		**0 261 210 170**
200 D T [202]	**2,0 l 65 kW OM 604.915 4 Zyl.**		
Speed sensor, diesel	09.96-06.99		**0 281 002 123**
Wheel speed sensor, rear			
Fg.no. →F873443,Comp. no. Code 808/809, ~~Comp. no. Code 800/807~~	09.96-06.99	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
200 KOMPRESSOR T [202]	**2,0 l 120 kW M 111.956 4 Zyl.**		
Throttle valve assembly	04.00-02.01		**0 280 750 074**
Speed sensor, ignition/injection	04.00-02.01		**0 261 210 170**
200 KOMPRESSOR T [202]	**2,0 l 132/141 kW M 111.944 4 Zyl.**		
Throttle valve assembly			
Mot.no. 002224→,Comp. no. Code 809, ~~Comp. no. Code 808~~	05.96-03.00	AG	**0 280 750 074**
Mot.no. 015671→,Comp. no. Code 809, ~~Comp. no. Code 808~~	05.96-03.00	GS	**0 280 750 074**
Air mass meter, gasoline injection	05.96-03.00	FGK	**0 280 217 114**
		KUT	**0 280 218 081**
Speed sensor, ignition/injection			
Mot.no. →060038	05.96-03.00	AG	**0 281 002 123**
Mot.no. →106153	05.96-03.00	GS	**0 281 002 123**
Mot.no. 060039→	05.96-03.00	AG	**0 261 210 170**
Mot.no. 106154→	05.96-03.00	GS	**0 261 210 170**
Wheel speed sensor, rear			
Fg.no. →F894083,Comp. no. Code 808/809, ~~Comp. no. Code 800/807~~	05.96-03.00	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
200 KOMPRESSOR T [203]	**1,8 l 120 kW M 271.940 4 Zyl.**		
Throttle valve assembly	09.02-08.07		**0 280 750 076**
Phase sensor	09.02-08.07		**0 232 103 050**
Speed sensor, ignition/injection	09.02-08.07		**0 261 210 170**

Product			
200 KOMPRESSOR T [203]			**2,0 l 120 kW M 111.955 4 Zyl.**
Throttle valve assembly	01.01-08.02		**0 280 750 074**
Speed sensor, ignition/injection	01.01-08.02		**0 261 210 170**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	01.01-08.02		**0 265 005 307**
200 KOMPRESSOR T [204]			**1,8 l 135 kW M 271.950 4 Zyl.**
Throttle valve assembly	09.07→		**0 280 750 076**
Phase sensor	09.07→		**0 232 103 050**
Speed sensor, ignition/injection	09.07→		**0 261 210 170**
200 T [202]			**2,0 l 100 kW M 111.941 4 Zyl.**
Air mass meter, gasoline injection	05.96-02.01		**0 280 217 100**
Speed sensor, ignition/injection	05.96-02.01		**0 261 210 085**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. F 984084→	05.96-02.01		**0 265 005 307**
Wheel speed sensor, rear			
Fg.no. →F894083,Comp. no. Code 808/809, ~~Comp. no. Code 800/807~~	05.96-02.01	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
200 T [202]			**2,0 l 100 kW M 111.945 4 Zyl.**
Throttle valve assembly			
Mot.no. 060039→,Comp. no. Code 809, ~~Comp. no. Code 808~~	05.96-02.01	AG,OTT	**0 280 750 074**
Mot.no. 106154→,Comp. no. Code 809, ~~Comp. no. Code 808~~	05.96-02.01	GS,OTT	**0 280 750 074**
Air mass meter, gasoline injection	05.96-02.01	FGK	**0 280 217 114**
		KUT	**0 280 218 081**
Speed sensor, ignition/injection			
Mot.no. →026604	05.96-02.01	GS	**0 281 002 123**
Mot.no. →056855	05.96-02.01	AG	**0 281 002 123**
Mot.no. 026605→	05.96-02.01	GS	**0 261 210 170**
Mot.no. 056856→	05.96-02.01	AG	**0 261 210 170**
Wheel speed sensor, rear			
Fg.no. →F894083,Comp. no. Code 808/809, ~~Comp. no. Code 800/807~~	05.96-02.01	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
220 CDI T [202]			**2,2 l 92 kW OM 611.960 4 Zyl.**
Air mass meter, diesel			
Mot.no. →30 055905	12.97-02.01		**0 280 217 114**
Mot.no. 30 055906→	12.97-02.01		**0 281 002 384**
Pulse generator, diesel	12.97-02.01		**0 281 002 123**
High-pressure sensor (CR system)	12.97-02.01		**0 281 002 498**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. F 984084→	12.97-02.01		**0 265 005 307**
Wheel speed sensor, rear			
Fg.no. →F894083,Comp. no. Code 808/809, ~~Comp. no. Code 800/807~~	12.97-02.01	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
220 CDI T [203]			**2,2 l 105 kW OM 611.962 4 Zyl.**
Speed sensor, diesel	01.01-02.03		**0 261 210 170**
High-pressure sensor (CR system)	01.01-02.03		**0 281 002 498**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	01.01-02.03		**0 265 005 307**
220 CDI T [203]			**2,2 l 110 kW OM 646.963 4 Zyl.**
Air mass meter, diesel	03.03-08.07		**0 281 002 535**
Speed sensor, diesel	03.03-08.07		**0 261 210 170**
High-pressure sensor (CR system)	03.03-08.07		**0 281 002 504**
220 CDI T [204]			**2,2 l 125 kW OM 646.811 4 Zyl.**
Air mass meter, diesel	09.07→		**0 281 002 535**
Speed sensor, diesel	09.07→		**0 261 210 170**

Product			
220 D T [202]			**2,2 l 55-70 kW OM 604.910 4 Zyl.**
Speed sensor, diesel			
Mot.no. →018030	05.96-06.99	AG	**0 281 002 100**
Mot.no. →086383	05.96-06.99	GS	**0 281 002 100**
Mot.no. 018031→	05.96-06.99	AG	**0 281 002 123**
Mot.no. 086384→	05.96-06.99	GS	**0 281 002 123**
Pedal position sensor, diesel	05.96-09.96		**0 205 001 029**
Wheel speed sensor, rear			
Fg.no. →F873443,Comp. no. Code 808/809, ~~Comp. no. Code 800/807~~	05.96-06.99	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
230 KOMPRESSOR T [202]			**2,3 l 142 kW M 111.975 4 Zyl.**
Throttle valve assembly			
Mot.no. 000268→015300, Comp. no. Code 807/808,~~Comp. no. Code 809~~	06.97-02.01	AG	**0 205 003 044**
Mot.no. 005591→012652, Comp. no. Code 807/808,~~Comp. no. Code 809~~	06.97-02.01	GS	**0 205 003 044**
Mot.no. 012653→,Comp. no. Code 809, ~~Comp. no. Code 808~~	06.97-02.01	GS	**0 280 750 074**
Mot.no. 015301→,Comp. no. Code 809, ~~Comp. no. Code 808~~	06.97-02.01	AG	**0 280 750 074**
Air mass meter, gasoline injection	06.97-02.01	FGK	**0 280 217 114**
		KUT	**0 280 218 081**
Speed sensor, ignition/injection			
Mot.no. →012652	06.97-02.01	GS	**0 281 002 123**
Mot.no. →015300	06.97-02.01	AG	**0 281 002 123**
Mot.no. 012653→	06.97-02.01	GS	**0 261 210 170**
Mot.no. 015301→	06.97-02.01	AG	**0 261 210 170**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. F 984084→	06.97-02.01		**0 265 005 307**
Wheel speed sensor, rear			
Fg.no. →F894083,Comp. no. Code 808/809, ~~Comp. no. Code 800/807~~	06.97-02.01	BO,LAB	**0 265 006 192**
		BO,RAB	**0 265 006 172**
230 KOMPRESSOR T [203]			**1,8 l 141 kW M 271.948 4 Zyl.**
Throttle valve assembly	02.04-05.05		**0 280 750 076**
Phase sensor	02.04-05.05		**0 232 103 050**
Speed sensor, ignition/injection	02.04-05.05		**0 261 210 170**
230 T [202]			**2,3 l 110 kW M 111.974 4 Zyl.**
Air mass meter, gasoline injection	05.96-05.97	FGK	**0 280 217 114**
		KUT	**0 280 218 081**
Speed sensor, ignition/injection	05.96-05.97		**0 281 002 123**
Wheel speed sensor, rear			
Fg.no. →F873443,Comp. no. Code 808/809, ~~Comp. no. Code 800/807~~	05.96-05.97	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
230 T [203]			**2,5 l 150 kW M 272.920 6 Zyl.**
Throttle valve assembly	06.05-08.07		**0 280 750 017**
Air mass meter, gasoline injection	06.05-08.07		**0 280 218 190**
Phase sensor	06.05-08.07		**0 232 103 050**
Speed sensor, ignition/injection	06.05-08.07		**0 261 210 170**
Knock sensor	06.05-08.07		**0 261 231 188**
230 T [204]			**2,5 l 150 kW M 272.921 6 Zyl.**
Throttle valve assembly	09.07→		**0 280 750 017**
Air mass meter, gasoline injection	09.07→		**0 280 218 190**
Phase sensor	09.07→	LAB	**0 232 103 050**
Knock sensor	09.07→		**0 261 231 188**
240 T [202]			**2,4 l 125 kW M 112.910 6 Zyl.**
Throttle valve assembly	06.97-02.01		**0 205 003 046**
Air mass meter, gasoline injection	06.97-02.01		**0 280 217 515**
Phase sensor	06.97-02.01		**0 232 103 050**

M

Product			
◀ Serie C (T-Modell)			
Speed sensor, ignition/injection			
Mot.no. →370998	06.97-02.01		**0 261 210 141**
Mot.no. 370999→	06.97-02.01		**0 261 210 170**
Knock sensor	06.97-02.01		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	06.97-02.01		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. F 984084→	06.97-02.01		**0 265 005 307**
Wheel speed sensor, front	06.97-02.01	BO,LAB	**0 265 006 266**
		BO,RAB	**0 265 006 264**
Wheel speed sensor, rear			
Fg.no. →F894083,Comp. no. Code 808/809, ~~Comp. no. Code 800/807~~	06.97-02.01	BO,LAB	**0 265 006 192**
		BO,RAB	**0 265 006 172**
240 T [202]	**2,6 l 125 kW M 112.915 6 Zyl.**		
Throttle valve assembly	08.00-02.01		**0 280 750 019**
Phase sensor	08.00-02.01	NOC	**0 232 103 050**
Speed sensor, ignition/injection	08.00-02.01		**0 261 210 170**
Knock sensor	08.00-02.01		**0 261 231 110**
Wheel speed sensor, front	08.00-02.01	BO,LAB	**0 265 006 266**
		BO,RAB	**0 265 006 264**
240 T [203]	**2,6 l 125 kW M 112.912 6 Zyl.**		
Throttle valve assembly	01.01-05.05		**0 280 750 019**
Air mass meter, gasoline injection	01.01-05.05		**0 280 217 515**
Phase sensor	01.01-05.05		**0 232 103 050**
Speed sensor, ignition/injection	01.01-05.05		**0 261 210 170**
Knock sensor	01.01-05.05		**0 261 231 110**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	01.01-05.05		**0 265 005 307**
240 4MATIC T [203]	**2,6 l 125 kW M 112.916 6 Zyl.**		
Throttle valve assembly	09.02-06.05		**0 280 750 019**
Air mass meter, gasoline injection	09.02-06.05		**0 280 217 515**
Phase sensor	09.02-06.05		**0 232 103 050**
Speed sensor, ignition/injection	09.02-06.05		**0 261 210 170**
Knock sensor	09.02-06.05		**0 261 231 110**
250 D Turbo T [202]	**2,5 l 110 kW OM 605.960 5 Zyl.**		
Air mass meter, diesel	05.96-02.01		**0 280 217 114**
Pulse generator, diesel			
Mot.no. →007447,~~Comp. no. Code 807~~	05.96-02.01	AG	**0 281 002 100**
Mot.no. →014999,~~Comp. no. Code 807~~	05.96-02.01	GS	**0 281 002 100**
Mot.no. 007448→,Comp. no. Code 807	05.96-02.01	AG	**0 281 002 123**
Mot.no. 015000→,Comp. no. Code 807	05.96-02.01	GS	**0 281 002 123**
Pedal position sensor, diesel	05.96-02.01		**0 205 001 029**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. F 984084→	05.96-02.01		**0 265 005 307**
Wheel speed sensor, rear			
Fg.no. →F894083,Comp. no. Code 808/809, ~~Comp. no. Code 800/807~~	05.96-02.01	BO,LAB, MET	**0 265 006 192**
		BO,MET, RAB	**0 265 006 172**
270 CDI T [203]	**2,7 l 125 kW OM 612.962 5 Zyl.**		
Speed sensor, diesel	01.01-08.04		**0 261 210 170**
High-pressure sensor (CR system)	01.01-08.04		**0 281 002 498**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	01.01-08.04		**0 265 005 307**
280 T [202]	**2,8 l 145 kW M 112.920 6 Zyl.**		
Throttle valve assembly			
Comp. no. Code 800	06.97-02.01		**0 205 003 046**
Comp. no. Code 801	06.97-02.01		**0 280 750 019**
Air mass meter, gasoline injection	06.97-02.01		**0 280 217 515**
Phase sensor	06.97-02.01		**0 232 103 050**
Speed sensor, ignition/injection			
Mot.no. →370998	06.97-02.01		**0 261 210 141**
Mot.no. 370999→	06.97-02.01		**0 261 210 170**

Product			
Knock sensor	06.97-02.01		**0 261 231 110**
Pedal position sensor, EMS (electronic engine management)	06.97-02.01		**0 205 001 302**
Duo sensor, acceleration and yaw rate, brake system	06.97-02.01		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. F 984084→	06.97-02.01		**0 265 005 307**
Wheel speed sensor, front	06.97-02.01	BO,LAB	**0 265 006 266**
		BO,RAB	**0 265 006 264**
Wheel speed sensor, rear			
Fg.no. →F894083,Comp. no. Code 808/809, ~~Comp. no. Code 800/807~~	06.97-02.01	LAB	**0 265 006 192**
		RAB	**0 265 006 172**
280 T [203]	**3,0 l 170 kW M 272.940 6 Zyl.**		
Throttle valve assembly	06.05-08.07		**0 280 750 017**
Air mass meter, gasoline injection	06.05-08.07		**0 280 218 190**
Phase sensor	06.05-08.07		**0 232 103 050**
Speed sensor, ignition/injection	06.05-08.07		**0 261 210 170**
Knock sensor	06.05-08.07		**0 261 231 188**
280 T [204]	**3,0 l 170 kW M 272.947 6 Zyl.**		
Throttle valve assembly	09.07→		**0 280 750 017**
Air mass meter, gasoline injection	09.07→		**0 280 218 190**
Phase sensor	09.07→	LAB	**0 232 103 050**
Knock sensor	09.07→		**0 261 231 188**
280 4MATIC T [203]	**3,0 l 170 kW M 272.941 6 Zyl.**		
Throttle valve assembly	07.05-08.07		**0 280 750 017**
Air mass meter, gasoline injection	07.05-08.07		**0 280 218 190**
Phase sensor	07.05-08.07		**0 232 103 050**
Speed sensor, ignition/injection	07.05-08.07		**0 261 210 170**
Knock sensor	07.05-08.07		**0 261 231 188**
320 CDI T [203]	**3,0 l 165 kW OM 642.910 6 Zyl.**		
Speed sensor, diesel	09.04-08.07		**0 261 210 170**
320 T [203]	**3,2 l 160 kW M 112.946 6 Zyl.**		
Throttle valve assembly	01.01-05.05		**0 280 750 019**
Air mass meter, gasoline injection	01.01-05.05		**0 280 217 515**
Phase sensor	01.01-05.05		**0 232 103 050**
Speed sensor, ignition/injection	01.01-05.05		**0 261 210 170**
Knock sensor	01.01-05.05		**0 261 231 110**
320 4MATIC T [203]	**3,2 l 160 kW M 112.953 6 Zyl.**		
Throttle valve assembly	09.02-06.05		**0 280 750 019**
Air mass meter, gasoline injection	09.02-06.05		**0 280 217 515**
Phase sensor	09.02-06.05		**0 232 103 050**
Speed sensor, ignition/injection	09.02-06.05		**0 261 210 170**
Knock sensor	09.02-06.05		**0 261 231 110**
350 T [203]	**3,5 l 200 kW M 272.960 6 Zyl.**		
Throttle valve assembly	06.05-08.07		**0 280 750 017**
Air mass meter, gasoline injection	06.05-08.07		**0 280 218 190**
Phase sensor	06.05-08.07		**0 232 103 050**
Speed sensor, ignition/injection	06.05-08.07		**0 261 210 170**
Knock sensor	06.05-08.07		**0 261 231 110**
350 T [204]	**3,5 l 200 kW M 272.961 6 Zyl.**		
Throttle valve assembly	09.07→		**0 280 750 017**
Air mass meter, gasoline injection	09.07→		**0 280 218 190**
Phase sensor	09.07→	LAB	**0 232 103 050**
Knock sensor	09.07→		**0 261 231 188**
350 4MATIC T [203]	**3,5 l 200 kW M 272.970 6 Zyl.**		
Throttle valve assembly	07.05-08.07		**0 280 750 017**
Air mass meter, gasoline injection	07.05-08.07		**0 280 218 190**
Phase sensor	07.05-08.07		**0 232 103 050**
Speed sensor, ignition/injection	07.05-08.07		**0 261 210 170**
Knock sensor	07.05-08.07		**0 261 231 110**

M

Product			

Serie CL

55 AMG Coupé [215]			**5,4 l 265 kW M 113.986 8 Zyl.**
Throttle valve assembly	09.99-08.00		**0 205 003 048**
	09.00-08.02		**0 280 750 017**
Air mass meter, gasoline injection	09.99-08.02		**0 280 217 810**
Phase sensor	09.99-08.02		**0 232 103 050**
Speed sensor, ignition/injection	09.99-08.02		**0 261 210 170**
Knock sensor	09.99-08.02		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	09.99-08.02		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	09.99-08.02		**0 265 005 303**
Wheel speed sensor, front	09.99-08.02		**0 265 007 002**
Wheel speed sensor, rear	09.99-08.02	LAB	**0 265 007 008**
		RAB	**0 265 007 006**
55 AMG KOMPRESSOR Coupé [215]			**5,4 l 368 kW M 113.991 8 Zyl.**
Throttle valve assembly	09.02-08.06		**0 280 750 045**
Phase sensor	09.02-08.06		**0 232 103 050**
Speed sensor, ignition/injection	09.02-08.06		**0 261 210 170**
Knock sensor	09.02-08.06		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	09.02-08.06		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	09.02-08.06		**0 265 005 303**
Wheel speed sensor, front	09.02-08.06		**0 265 007 002**
Wheel speed sensor, rear	09.02-08.06	LAB	**0 265 007 121**
		RAB	**0 265 007 123**
63 AMG Coupé [216]			**6,2 l 386 kW M 156.984 8 Zyl.**
Knock sensor	01.07→		**0 261 231 188**
65 AMG Coupé [215]			**6,0 l 450 kW M 275.980 12 Zyl.**
Speed sensor, ignition/injection	09.03-08.06		**0 261 210 170**
Knock sensor	09.03-08.06		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	09.03-08.06		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	09.03-08.06		**0 265 005 303**
Wheel speed sensor, front	09.03-08.06		**0 265 007 128**
Wheel speed sensor, rear	09.03-08.06	LAB	**0 265 007 121**
		RAB	**0 265 007 123**
65 AMG Coupé [216]			**6,0 l 450 kW M 275.982 12 Zyl.**
Speed sensor, ignition/injection	07.07→		**0 261 210 170**
Knock sensor	07.07→		**0 261 231 110**
500 Coupé [215]			**5,0 l 225 kW M 113.960 8 Zyl.**
Throttle valve assembly	09.99-08.00		**0 205 003 048**
	09.00-05.06		**0 280 750 017**
Air mass meter, gasoline injection	09.99-05.06		**0 280 217 810**
Phase sensor	09.99-05.06		**0 232 103 050**
Speed sensor, ignition/injection	09.99-05.06		**0 261 210 170**
Knock sensor	09.99-05.06		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	09.99-05.06		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	09.99-05.06		**0 265 005 303**
Wheel speed sensor, front	09.99-05.06		**0 265 007 002**
Wheel speed sensor, rear	09.99-05.06	LAB	**0 265 007 008**
		RAB	**0 265 007 006**
500 Coupé [216]			**5,5 l 285 kW M 273.961 8 Zyl.**
Throttle valve assembly	06.06→		**0 280 750 184**
Air mass meter, gasoline injection	06.06→		**0 280 218 190**
Phase sensor	06.06→	LAB	**0 232 103 050**
Knock sensor	06.06→		**0 261 231 188**
600 Coupé [215]			**5,5 l 368 kW M 275.950 12 Zyl.**
Throttle valve assembly	09.02-08.06		**0 280 750 125**
Speed sensor, ignition/injection	09.02-08.06		**0 261 210 170**
Knock sensor	09.02-08.06		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	09.02-08.06		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	09.02-08.06		**0 265 005 303**
Wheel speed sensor, front	09.02-08.06		**0 265 007 128**
Wheel speed sensor, rear	09.02-08.06	LAB	**0 265 007 121**
		RAB	**0 265 007 123**
600 Coupé [215]			**5,8 l 270 kW M 137.970 12 Zyl.**
Throttle valve assembly	09.99-08.02		**0 280 750 015**
Air mass meter, gasoline injection	09.99-08.02		**0 280 217 810**
Speed sensor, ignition/injection	09.99-08.02		**0 261 210 170**
Knock sensor	09.99-08.02		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	09.99-08.02		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	09.99-08.02		**0 265 005 303**
Wheel speed sensor, front	09.99-08.02		**0 265 007 002**
Wheel speed sensor, rear	09.99-08.02	LAB	**0 265 007 008**
		RAB	**0 265 007 006**
600 Coupé [216]			**5,5 l 380 kW M 275.953 12 Zyl.**
Throttle valve assembly	09.06→		**0 280 750 125**
Speed sensor, ignition/injection	09.06→		**0 261 210 170**
Knock sensor	09.06→		**0 261 231 110**

Serie CLK

55 AMG Cabrio [208]			**5,4 l 255 kW M 113.984 8 Zyl.**
Throttle valve assembly	09.00-04.02		**0 280 750 019**
Phase sensor	09.00-04.02	NOC	**0 232 103 050**
Speed sensor, ignition/injection	09.00-04.02	FKW	**0 261 210 170**
Knock sensor	09.00-04.02		**0 261 231 110**
Lateral acceleration sensor, brake system	09.00-04.02		**0 265 005 231**
Duo sensor, acceleration and yaw rate, brake system	09.00-04.02		**0 265 005 201**
Wheel speed sensor, front	09.00-04.02	LAB	**0 265 006 266**
Fg.no. 202...A/B/C/D/E	09.00-04.02	BO,RAB	**0 265 006 264**
Wheel speed sensor, rear	09.00-04.02	LAB	**0 265 006 192**
		RAB	**0 265 006 172**
55 AMG Cabrio [209]			**5,4 l 270 kW M 113.987 8 Zyl.**
Throttle valve assembly	02.03→		**0 280 750 017**
Air mass meter, gasoline injection	02.03→		**0 280 217 810**
Phase sensor	02.03→		**0 232 103 050**
Speed sensor, ignition/injection	02.03→		**0 261 210 170**
Knock sensor	02.03→		**0 261 231 110**
55 AMG Coupé [208]			**5,4 l 255 kW M 113.984 8 Zyl.**
Throttle valve assembly	05.99-08.00		**0 205 003 046**
	09.00-04.02		**0 280 750 019**
Phase sensor	05.99-04.02	NOC	**0 232 103 050**
Speed sensor, ignition/injection	05.99-04.02	FKW	**0 261 210 170**
Knock sensor	05.99-04.02		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	05.99-04.02		**0 265 005 201**
Wheel speed sensor, front	05.99-04.02	LAB	**0 265 006 266**
Fg.no. 202...A/B/C/D/E	05.99-04.02	BO,RAB	**0 265 006 264**
Wheel speed sensor, rear	05.99-04.02	LAB	**0 265 006 192**
		RAB	**0 265 006 172**
55 AMG Coupé [209]			**5,4 l 270 kW M 113.987 8 Zyl.**
Throttle valve assembly	09.02→		**0 280 750 017**
Air mass meter, gasoline injection	09.02→		**0 280 217 810**
Phase sensor	09.02→		**0 232 103 050**
Speed sensor, ignition/injection	09.02→		**0 261 210 170**
Knock sensor	09.02→		**0 261 231 110**
63 AMG Cabrio, Coupé [209]			**6,2 l 354 kW M 156.982 8 Zyl.**
Knock sensor	09.06→		**0 261 231 188**

M

Product			
◀ Serie CLK			
200 Cabrio [208]	**2,0 l 100 kW M 111.945 4 Zyl.**		
Air mass meter, gasoline injection	06.98-06.00	FGK	**0 280 217 114**
		KUT	**0 280 218 081**
Speed sensor, ignition/injection			
Mot.no. →026604	06.98-06.00	GS	**0 281 002 123**
Mot.no. →056855	06.98-06.00	AG	**0 281 002 123**
Mot.no. 026605→	06.98-06.00	GS	**0 261 210 170**
Mot.no. 056856→	06.98-06.00	AG	**0 261 210 170**
Pressure sensor, ESP, (electronic stability program)	06.98-06.00		**0 265 005 307**
200 CGI KOMPRESSOR Cabrio [209]	**1,8 l 125 kW M 271.942 4 Zyl.**		
Throttle valve assembly	06.03-08.04		**0 280 750 076**
Phase sensor	06.03-08.04		**0 232 103 050**
Speed sensor, ignition/injection	06.03-08.04		**0 261 210 170**
200 CGI KOMPRESSOR Coupé [209]	**1,8 l 125 kW M 271.942 4 Zyl.**		
Throttle valve assembly	05.02-08.04		**0 280 750 076**
Phase sensor	05.02-08.04		**0 232 103 050**
Speed sensor, ignition/injection	05.02-08.04		**0 261 210 170**
200 Coupé [208]	**2,0 l 100 kW M 111.945 4 Zyl.**		
Air mass meter, gasoline injection	06.97-06.00	FGK	**0 280 217 114**
		KUT	**0 280 218 081**
Speed sensor, ignition/injection			
Mot.no. →026604	06.97-06.00	GS	**0 281 002 123**
Mot.no. →056855	06.97-06.00	AG	**0 281 002 123**
Mot.no. 026605→	06.97-06.00	GS	**0 261 210 170**
Mot.no. 056856→	06.97-06.00	AG	**0 261 210 170**
Pressure sensor, ESP, (electronic stability program)	06.97-06.00		**0 265 005 307**
200 KOMPRESSOR Cabrio [208]	**2,0 l 120 kW M 111.956 4 Zyl.**		
Throttle valve assembly	06.00-01.03		**0 280 750 045**
Air mass meter, gasoline injection	06.00-01.03		**0 280 217 114**
Speed sensor, ignition/injection	06.00-01.03		**0 261 210 170**
Pressure sensor, ESP, (electronic stability program)	06.00-01.03		**0 265 005 307**
200 KOMPRESSOR Cabrio [208]	**2,0 l 142 kW M 111.944 4 Zyl.**		
Air mass meter, gasoline injection	09.96-05.00	FGK	**0 280 217 114**
		KUT	**0 280 218 081**
Speed sensor, ignition/injection			
Mot.no. →002223	09.96-05.00	AG	**0 281 002 123**
Mot.no. →015670	09.96-05.00	GS	**0 281 002 123**
Mot.no. 002224→	09.96-05.00	AG	**0 261 210 170**
Mot.no. 015671→	09.96-05.00	GS	**0 261 210 170**
Pressure sensor, ESP, (electronic stability program)	09.96-05.00		**0 265 005 307**
200 KOMPRESSOR Cabrio [209]	**1,8 l 120/135 kW M 271.940; M 271.955 4 Zyl.**		
Throttle valve assembly	02.03→		**0 280 750 076**
Phase sensor	02.03→		**0 232 103 050**
Speed sensor, ignition/injection	02.03→		**0 261 210 170**
200 KOMPRESSOR Coupé [208]	**2,0 l 120 kW M 111.956 4 Zyl.**		
Throttle valve assembly	06.00-04.02		**0 280 750 045**
Speed sensor, ignition/injection	06.00-04.02		**0 261 210 170**
Pressure sensor, ESP, (electronic stability program)	06.00-04.02		**0 265 005 307**
200 KOMPRESSOR Coupé [208]	**2,0 l 142 kW M 111.944 4 Zyl.**		
Throttle valve assembly	06.97-06.00		**0 205 003 044**
Air mass meter, gasoline injection	06.97-06.00	FGK	**0 280 217 114**
		KUT	**0 280 218 081**
Speed sensor, ignition/injection			
Mot.no. →002223	06.97-06.00	AG	**0 281 002 123**
Mot.no. →015670	06.97-06.00	GS	**0 281 002 123**
Mot.no. 002224→	06.97-06.00	AG	**0 261 210 170**
Mot.no. 015671→	06.97-06.00	GS	**0 261 210 170**
Pressure sensor, ESP, (electronic stability program)	06.97-06.00		**0 265 005 307**
200 KOMPRESSOR Coupé [209]	**1,8 l 120/135 kW M 271.940; M 271.955 4 Zyl.**		
Throttle valve assembly	09.02→		**0 280 750 076**
Phase sensor	09.02→		**0 232 103 050**
Speed sensor, ignition/injection	09.02→		**0 261 210 170**

Product			
220 CDI Coupé [209]	**2,1 l 110 kW OM 646.966 4 Zyl.**		
Air mass meter, diesel	04.05→		**0 281 002 535**
Speed sensor, diesel	04.05→		**0 261 210 170**
High-pressure sensor (CR system)	04.05→		**0 281 002 504**
230 KOMPRESSOR Cabrio [208]	**2,3 l 142 kW M 111.975 4 Zyl.**		
Throttle valve assembly	06.98-05.00		**0 205 003 044**
Air mass meter, gasoline injection	06.98-05.00	FGK	**0 280 217 114**
		KUT	**0 280 218 081**
Speed sensor, ignition/injection			
Mot.no. →012652	06.98-05.00	GS	**0 281 002 123**
Mot.no. →015300	06.98-05.00	AG	**0 281 002 123**
Mot.no. 012653→	06.98-05.00	GS	**0 261 210 170**
Mot.no. 015301→	06.98-05.00	AG	**0 261 210 170**
Pressure sensor, ESP, (electronic stability program)	06.98-05.00		**0 265 005 307**
230 KOMPRESSOR Cabrio [208]	**2,3 l 145 kW M 111.982 4 Zyl.**		
Throttle valve assembly	06.00-01.03		**0 280 750 045**
Speed sensor, ignition/injection	06.00-01.03		**0 261 210 170**
Pressure sensor, ESP, (electronic stability program)	06.00-01.03		**0 265 005 307**
230 KOMPRESSOR Coupé [208]	**2,3 l 142 kW M 111.975 4 Zyl.**		
Throttle valve assembly	06.97-06.00		**0 205 003 044**
Air mass meter, gasoline injection	06.97-06.00	FGK	**0 280 217 114**
		KUT	**0 280 218 081**
Speed sensor, ignition/injection			
Mot.no. →012652	06.97-06.00	GS	**0 281 002 123**
Mot.no. →015300	06.97-06.00	AG	**0 281 002 123**
Mot.no. 012653→	06.97-06.00	GS	**0 261 210 170**
Mot.no. 015301→	06.97-06.00	AG	**0 261 210 170**
Pressure sensor, ESP, (electronic stability program)	06.97-06.00		**0 265 005 307**
230 KOMPRESSOR Coupé [208]	**2,3 l 145 kW M 111.982 4 Zyl.**		
Throttle valve assembly	06.00-04.02		**0 280 750 045**
Speed sensor, ignition/injection	06.00-04.02		**0 261 210 170**
Pressure sensor, ESP, (electronic stability program)	06.00-04.02		**0 265 005 307**
240 Cabrio [209]	**2,6 l 125 kW M 112.912 6 Zyl.**		
Throttle valve assembly	02.03→		**0 280 750 019**
Air mass meter, gasoline injection	02.03→		**0 280 217 515**
Phase sensor	02.03→		**0 232 103 050**
Speed sensor, ignition/injection	02.03→		**0 261 210 170**
Knock sensor	02.03→		**0 261 231 110**
240 Coupé [209]	**2,6 l 125 kW M 112.912 6 Zyl.**		
Throttle valve assembly	05.02→		**0 280 750 019**
Air mass meter, gasoline injection	05.02→		**0 280 217 515**
Phase sensor	05.02→		**0 232 103 050**
Speed sensor, ignition/injection	05.02→		**0 261 210 170**
Knock sensor	05.02→		**0 261 231 110**
270 CDI Coupé [209]	**2,7 l 125 kW OM 612.962; 967 5 Zyl.**		
Speed sensor, diesel	09.02→		**0 261 210 170**
High-pressure sensor (CR system)	09.02→		**0 281 002 498**
280 Cabrio, Coupé [209]	**3,0 l 170 kW M 272.940 6 Zyl.**		
Throttle valve assembly	04.05→		**0 280 750 017**
Air mass meter, gasoline injection	04.05→		**0 280 218 190**
Phase sensor	04.05→	LAB	**0 232 103 050**
Knock sensor	04.05→		**0 261 231 188**
320 Cabrio [208]	**3,2 l 160 kW M 112.940 6 Zyl.**		
Throttle valve assembly	06.98-08.00		**0 205 003 046**
	09.00-01.03		**0 280 750 019**
Air mass meter, gasoline injection	06.98-01.03		**0 280 217 515**
Phase sensor	06.98-01.03		**0 232 103 037**
Speed sensor, ignition/injection			
Mot.no. →370998	06.98-01.03		**0 261 210 141**
Mot.no. 370999→	06.98-01.03	FKW	**0 261 210 170**
Knock sensor	06.98-01.03		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	06.98-01.03		**0 265 005 201**

M

Product			
Wheel speed sensor, front	06.98-01.03	LAB,MFD	**0 265 006 266**
		MFD,RAB	**0 265 006 264**
Wheel speed sensor, rear	06.98-01.03	LAB,MFD	**0 265 006 192**
		MFD,RAB	**0 265 006 172**
320 Cabrio [209]	**3,2 l 160 kW M 112.955 6 Zyl.**		
Throttle valve assembly	02.03→		**0 280 750 019**
Air mass meter, gasoline injection	02.03→		**0 280 217 515**
Phase sensor	02.03→		**0 232 103 050**
Speed sensor, ignition/injection	02.03→		**0 261 210 170**
Knock sensor	02.03→		**0 261 231 110**
320 CDI Cabrio, Coupé [209]	**3,0 l 165 kW OM 642.910 6 Zyl.**		
Speed sensor, diesel	04.05→		**0 261 210 170**
High-pressure sensor (CR system)	04.05→		**0 281 002 504**
320 Coupé [208]	**3,2 l 160 kW M 112.940 6 Zyl.**		
Throttle valve assembly	01.97-08.00		**0 205 003 046**
	09.00-06.02		**0 280 750 019**
Air mass meter, gasoline injection	01.97-06.02		**0 280 217 515**
Phase sensor	01.97-06.02		**0 232 103 037**
Speed sensor, ignition/injection			
Mot.no. →370998	01.97-06.02		**0 261 210 141**
Mot.no. 370999→	01.97-06.02	FKW	**0 261 210 170**
Knock sensor	01.97-06.02		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	01.97-06.02		**0 265 005 201**
Wheel speed sensor, front	01.97-06.02	LAB,MFD	**0 265 006 266**
		MFD,RAB	**0 265 006 264**
Wheel speed sensor, rear	01.97-06.02	LAB,MFD	**0 265 006 192**
		MFD,RAB	**0 265 006 172**
320 Coupé [209]	**3,2 l 160 kW M 112.955 6 Zyl.**		
Throttle valve assembly	05.02→		**0 280 750 019**
Air mass meter, gasoline injection	05.02→		**0 280 217 515**
Phase sensor	05.02→		**0 232 103 050**
Speed sensor, ignition/injection	05.02→		**0 261 210 170**
Knock sensor	05.02→		**0 261 231 110**
350 Cabrio, Coupé [209]	**3,5 l 200 kW M 272.960 6 Zyl.**		
Throttle valve assembly	04.05→		**0 280 750 017**
Air mass meter, gasoline injection	04.05→		**0 280 218 190**
Phase sensor	04.05→	LAB	**0 232 103 050**
Knock sensor	04.05→		**0 261 231 188**
430 Cabrio [208]	**4,3 l 205 kW M 113.943 8 Zyl.**		
Phase sensor	09.98-01.03	NOC	**0 232 103 050**
Speed sensor, ignition/injection	09.98-01.03	FKW	**0 261 210 170**
Knock sensor	09.98-01.03		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	09.98-01.03		**0 265 005 201**
Wheel speed sensor, front	09.98-01.03	LAB,MFD	**0 265 006 266**
		MFD,RAB	**0 265 006 264**
Wheel speed sensor, rear	09.98-01.03	LAB,MFD	**0 265 006 192**
		MFD,RAB	**0 265 006 172**
430 Coupé [208]	**4,3 l 205 kW M 113.943 8 Zyl.**		
Throttle valve assembly	08.98-04.02		**0 205 003 048**
Air mass meter, gasoline injection	08.98-04.02		**0 280 217 810**
Phase sensor	08.98-04.02	NOC	**0 232 103 050**
Speed sensor, ignition/injection	08.98-04.02	FKW	**0 261 210 170**
Knock sensor	08.98-04.02		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	08.98-04.02		**0 265 005 201**
Wheel speed sensor, front	08.98-04.02	LAB,MFD	**0 265 006 266**
		MFD,RAB	**0 265 006 264**
Wheel speed sensor, rear	08.98-04.02	LAB,MFD	**0 265 006 192**
		MFD,RAB	**0 265 006 172**

Product			
500 Cabrio [209]	**5,0 l 225 kW M 113.968 8 Zyl.**		
Throttle valve assembly	02.03-07.06		**0 280 750 017**
Air mass meter, gasoline injection	02.03-07.06		**0 280 217 810**
Phase sensor	02.03-07.06		**0 232 103 050**
Speed sensor, ignition/injection	02.03-07.06		**0 261 210 170**
Knock sensor	02.03-07.06		**0 261 231 110**
500 Cabrio [209]	**5,0 l 285 kW M 273.967 8 Zyl.**		
Throttle valve assembly	08.06→		**0 280 750 184**
Air mass meter, gasoline injection	08.06→		**0 280 218 190**
Phase sensor	08.06→	LAB	**0 232 103 050**
Knock sensor	08.06→		**0 261 231 188**
500 Coupé [209]	**5,0 l 225 kW M 113.968 8 Zyl.**		
Throttle valve assembly	05.02-07.06		**0 280 750 017**
Air mass meter, gasoline injection	05.02-07.06		**0 280 217 810**
Phase sensor	05.02-07.06		**0 232 103 050**
Speed sensor, ignition/injection	05.02-07.06		**0 261 210 170**
Knock sensor	05.02-07.06		**0 261 231 110**
500 Coupé [209]	**5,0 l 285 kW M 273.967 8 Zyl.**		
Throttle valve assembly	08.06→		**0 280 750 184**
Air mass meter, gasoline injection	08.06→		**0 280 218 190**
Phase sensor	08.06→	LAB	**0 232 103 050**
Knock sensor	08.06→		**0 261 231 188**

Serie CLS

55 AMG Coupé [219]	**5,4 l 350 kW M 113.990 8 Zyl.**		
Throttle valve assembly	01.05-05.06		**0 280 750 045**
Air mass meter, gasoline injection	01.05-05.06		**0 280 217 810**
Phase sensor	01.05-05.06		**0 232 103 050**
Speed sensor, ignition/injection	01.05-05.06		**0 261 210 170**
Knock sensor	01.05-05.06		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	01.05-05.06		**0 265 005 298**
Wheel speed sensor, front	01.05-05.06		**0 265 007 499**
Wheel speed sensor, rear	01.05-05.06		**0 265 007 500**
63 AMG Coupé [219]	**6,2 l 378 kW M 156.983 8 Zyl.**		
Knock sensor	06.06→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	06.06→		**0 265 005 298**
Wheel speed sensor, front	06.06→		**0 265 007 499**
Wheel speed sensor, rear	06.06→		**0 265 007 500**
320 CDI Coupé [219]	**3,0 l 165 kW OM 642.920 6 Zyl.**		
High-pressure sensor (CR system)	05.05→		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	05.05→		**0 265 005 298**
Wheel speed sensor, front	05.05→		**0 265 007 499**
Wheel speed sensor, rear	05.05→		**0 265 007 500**
350 CGI Coupé [219]	**3,5 l 215 kW M 272.985 6 Zyl.**		
Throttle valve assembly	07.06→		**0 280 750 017**
Air mass meter, gasoline injection	07.06→		**0 280 218 190**
Phase sensor	07.06→	LAB	**0 232 103 050**
Knock sensor	07.06→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	07.06→		**0 265 005 298**
Wheel speed sensor, front	07.06→		**0 265 007 499**
Wheel speed sensor, rear	07.06→		**0 265 007 500**
350 Coupé [219]	**3,5 l 200 kW M 272.964 6 Zyl.**		
Throttle valve assembly	06.04-06.06		**0 280 750 017**
Air mass meter, gasoline injection	06.04-06.06		**0 280 218 190**
Phase sensor	06.04-06.06	LAB	**0 232 103 050**
Knock sensor	06.04-06.06		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	06.04-06.06		**0 265 005 298**

M

Product

◀ Serie CLS

Wheel speed sensor, front	06.04-06.06		**0 265 007 499**
Wheel speed sensor, rear	06.04-06.06		**0 265 007 500**
500 Coupé [219]	**5,0 l 225 kW M 113.967 8 Zyl.**		
Throttle valve assembly	06.04-03.06		**0 280 750 017**
Air mass meter, gasoline injection	06.04-03.06		**0 280 217 810**
Phase sensor	06.04-03.06		**0 232 103 050**
Speed sensor, ignition/injection	06.04-03.06		**0 261 210 170**
Knock sensor	06.04-03.06		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	06.04-03.06		**0 265 005 298**
Wheel speed sensor, front	06.04-03.06		**0 265 007 499**
Wheel speed sensor, rear	06.04-03.06		**0 265 007 500**
500 Coupé [219]	**5,5 l 285 kW M 273.960 8 Zyl.**		
Throttle valve assembly	04.06→		**0 280 750 184**
Air mass meter, gasoline injection	04.06→		**0 280 218 190**
Phase sensor	04.06→	LAB	**0 232 103 050**
Knock sensor	04.06→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 298**
Wheel speed sensor, front	04.06→		**0 265 007 499**
Wheel speed sensor, rear	04.06→		**0 265 007 500**

Serie E

36 AMG Cabrio [124]	**3,6 l 195 kW M 104.992 6 Zyl.**		
Air mass meter, gasoline injection	03.93-02.94		**0 280 217 500**
Speed sensor, ignition/injection	03.93-02.94	RLE	**0 261 210 066**
Mot.no. →004356	03.93-02.94	GS,LLE	**0 261 210 055**
Mot.no. →072236	03.93-02.94	AG,LLE	**0 261 210 055**
Mot.no. 004357→	03.93-02.94	GS,LLE	**0 261 210 122**
Mot.no. 072237→	03.93-02.94	AG,LLE	**0 261 210 122**
Wheel speed sensor, front	03.93-02.94	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Wheel speed sensor, rear	03.93-02.94	AOS	**0 265 002 244**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
36 AMG Cabrio [124]	**3,6 l 200 kW M 104.992 6 Zyl.**		
Air mass meter, gasoline injection	03.94-06.98		**0 280 217 500**
Speed sensor, ignition/injection	03.94-06.98	LLE	**0 261 210 055**
		RLE	**0 261 210 066**
Wheel speed sensor, front	03.94-06.98	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Wheel speed sensor, rear	03.94-06.98	AOS	**0 265 002 244**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
36 AMG Coupé [124]	**3,6 l 195/200 kW M 104.992 6 Zyl.**		
Air mass meter, gasoline injection	03.93-06.96		**0 280 217 500**
Speed sensor, ignition/injection	03.93-06.96	RLE	**0 261 210 066**
Mot.no. →004356	03.93-06.96	GS,LLE	**0 261 210 055**
Mot.no. →072236	03.93-06.96	AG,LLE	**0 261 210 055**
Mot.no. 004357→	03.93-06.96	GS,LLE	**0 261 210 122**
Mot.no. 072237→	03.93-06.96	AG,LLE	**0 261 210 122**
Wheel speed sensor, front	03.93-06.96	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	03.93-06.96	AOS	**0 265 002 210**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
50 AMG [210]	**5,0 l 205-235 kW M 119.980,985 8 Zyl.**		
Throttle valve assembly	01.96-08.97		**0 205 003 037**
Air mass meter, gasoline injection	01.96-08.97		**0 280 217 807**
Phase sensor	01.96-08.97		**0 232 103 037**
Speed sensor, ignition/injection	01.96-08.97		**0 281 002 123**
Knock sensor	01.96-08.97		**0 261 231 110**

Product

Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A962231	01.96-08.97		**0 205 001 302**
Duo sensor, acceleration and yaw rate, brake system	01.96-08.97		**0 265 005 201**
Wheel speed sensor, front	01.96-08.97	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	01.96-08.97	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
55 AMG KOMPRESSOR [211]	**5,4 l 350 kW M 113.990 8 Zyl.**		
Throttle valve assembly	10.02-05.06		**0 280 750 045**
Air mass meter, gasoline injection	10.02-05.06		**0 280 217 810**
Phase sensor	10.02-05.06		**0 232 103 050**
Speed sensor, ignition/injection	10.02-05.06		**0 261 210 170**
Knock sensor	10.02-05.06		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	10.02-05.06		**0 265 005 258**
Wheel speed sensor, front	10.02-05.06		**0 265 007 499**
Wheel speed sensor, rear	10.02-05.06		**0 265 007 500**
60 AMG [124]	**6,0 l 280 kW M 119.974 8 Zyl.**		
Air mass meter, gasoline injection	07.93-06.95		**0 280 214 004**
			0 986 280 121
Speed sensor, ignition/injection	07.93-06.95		**0 261 210 085**
Knock sensor	07.93-06.95		**0 261 231 062**
Temperature sensor, intake air, injection system	07.93-06.95		**0 280 130 047**
Wheel speed sensor, front			
Fg.no. C013141→	07.93-06.95	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Fg.no. →C013142	07.93-06.95	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Wheel speed sensor, rear	07.93-06.95	LAB	**0 265 002 238**
		RAB	**0 265 002 108**
63 AMG [211]	**6,2 l 378 kW M 156.983 8 Zyl.**		
Knock sensor	06.06→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	06.06→		**0 265 005 298**
Wheel speed sensor, front	06.06→		**0 265 007 745**
Wheel speed sensor, rear	06.06→		**0 265 007 700**
200 [124]	**2,0 l 100 kW M 111.940 4 Zyl.**		
Speed sensor, ignition/injection	07.93-07.95		**0 261 210 055**
Wheel speed sensor, front			
Fg.no. C009356→,B891779→C009354, Comp. no. Code 859	07.93-07.95	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Fg.no. →C009355,B891779→C009354, ~~Comp. no. Code 859~~	07.93-07.95	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	07.93-07.95		**0 265 002 208**
200 [210]	**2,0 l 100 kW M 111.942 4 Zyl.**		
Air mass meter, gasoline injection	06.95-02.01	FGK	**0 280 217 114**
		KUT	**0 280 218 081**
Speed sensor, ignition/injection			
Mot.no. 055850 →	06.95-02.01	AG	**0 261 210 170**
Mot.no. 057355 →	06.95-02.01	GS	**0 261 210 170**
Mot.no. →055849	06.95-02.01	AG	**0 281 002 123**
Mot.no. →057354	06.95-02.01	GS	**0 281 002 123**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. B174000→,~~Comp. no. Code 800~~, Fg.no. X037894→	06.95-02.01		**0 265 005 258**
Fg.no. →B173999,~~Comp. no. Code 801~~, Fg.no. →X044900	06.95-02.01		**0 265 005 201**
Wheel speed sensor, front	06.95-02.01	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	06.95-02.01	LAB	**0 265 006 178**
		RAB	**0 265 006 194**

Product			
200 Cabrio [124]	**2,0 l 100 kW M 111.940 4 Zyl.**		
Speed sensor, ignition/injection	07.93-06.98		**0 261 210 055**
Wheel speed sensor, front	07.93-06.98	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Wheel speed sensor, rear	07.93-06.98		**0 265 002 254**
200 CDI [210]	**2,1 l 85 kW OM 611.961 4 Zyl.**		
Air mass meter, diesel	07.99-08.99		**0 281 002 152**
Pulse generator, diesel	07.99-08.99		**0 281 002 123**
Speed sensor, diesel	09.99-03.02		**0 261 210 170**
High-pressure sensor (CR system)	07.99-03.02		**0 281 002 498**
Duo sensor, acceleration and yaw rate, brake system	07.99-03.02		**0 265 005 258**
Wheel speed sensor, front	07.99-03.02	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	07.99-03.02	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
200 CDI [210]	**2,2 l 75 kW OM 611.961 4 Zyl.**		
Air mass meter, diesel	07.98-08.99		**0 281 002 152**
Pulse generator, diesel	07.98-08.99		**0 281 002 123**
Speed sensor, diesel	09.99-03.02		**0 261 210 170**
High-pressure sensor (CR system)	07.98-03.02		**0 281 002 498**
Duo sensor, acceleration and yaw rate, brake system	07.98-03.02		**0 265 005 258**
Wheel speed sensor, front	07.98-03.02	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	07.98-03.02	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
200 CDI [211]	**2,1 l 75/90 kW OM 646.951 4 Zyl.**		
Air mass meter, diesel	07.02→		**0 281 002 535**
Speed sensor, diesel	07.02→		**0 261 210 170**
High-pressure sensor (CR system)	07.02→		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	07.02→		**0 265 005 258**
Wheel speed sensor, front	07.02→		**0 265 007 499**
Wheel speed sensor, rear	07.02→		**0 265 007 500**
200 CDI [211]	**2,1 l 100 kW OM 646.821 4 Zyl.**		
Air mass meter, diesel	04.06→		**0 281 002 535**
Speed sensor, diesel	04.06→		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 298**
Wheel speed sensor, front	04.06→		**0 265 007 745**
Wheel speed sensor, rear	04.06→		**0 265 007 700**
200 Coupé [124]	**2,0 l 100 kW M 111.940 4 Zyl.**		
Speed sensor, ignition/injection	07.93-06.97		**0 261 210 055**
Wheel speed sensor, front			
Fg.no. C009356→,B891779→C009354, Comp. no. Code 859	07.93-06.97	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Fg.no. →C009355,B891779→C009354, ~~Comp. no. Code 859~~	07.93-06.97	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	07.93-06.97		**0 265 002 208**
200 D [124]	**2,0 l 55 kW OM 601.912 4 Zyl.**		
Wheel speed sensor, front			
Fg.no. A060862→	07.93-06.95	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Fg.no. →A060861	07.93-06.95	LAB	**0 265 001 128**
		RAB	**0 265 001 126**
Wheel speed sensor, rear			
Fg.no. A203047→	07.93-06.95		**0 265 002 208**
200 D [210]	**2,0 l 65 kW OM 604.917 4 Zyl.**		
Pulse generator, diesel	03.97-06.99		**0 281 002 123**
Pedal position sensor, diesel			
Fg.no. A 117064→,J 024802→	03.97-06.99		**0 205 001 302**
Fg.no. →A 177063,→J 024801	03.97-06.99		**0 205 001 029**

Product			
Wheel speed sensor, front	03.97-06.99	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	03.97-06.99	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
200 KOMPRESSOR [210]	**2,0 l 120 kW M 111.957 4 Zyl.**		
Throttle valve assembly	09.00-03.02		**0 280 750 074**
Speed sensor, ignition/injection	09.00-03.02		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	09.00-03.02		**0 265 005 258**
Wheel speed sensor, front	09.00-03.02	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	09.00-03.02	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
200 KOMPRESSOR [210]	**2,0 l 137 kW M 111.947 4 Zyl.**		
Throttle valve assembly	09.97-08.00		**0 205 003 044**
Air mass meter, gasoline injection	09.97-08.00	FGK	**0 280 217 114**
		KUT	**0 280 218 081**
Speed sensor, ignition/injection			
Mot.no. →001935	09.97-08.00	AG	**0 281 002 123**
Mot.no. →001936	09.97-08.00	AG	**0 261 210 170**
Mot.no. →005503	09.97-08.00	GS	**0 281 002 123**
Mot.no. →005504	09.97-08.00	GS	**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. B174000→,~~Comp. no. Code 800~~, Fg.no. X037894→	09.97-08.00		**0 265 005 258**
Fg.no. →B173999,~~Comp. no. Code 801~~, Fg.no. →X044900	09.97-08.00		**0 265 005 201**
Wheel speed sensor, front	09.97-08.00	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	09.97-08.00	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
200 KOMPRESSOR [211]	**1,8 l 120 kW M 271.941 4 Zyl.**		
Throttle valve assembly	03.02-03.06		**0 280 750 076**
Phase sensor	03.02-03.06	AUS,NOC	**0 232 103 037**
		EIN,NOC	**0 232 103 050**
Speed sensor, ignition/injection	03.02-03.06		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	03.02-03.06		**0 265 005 258**
Wheel speed sensor, front	03.02-03.06		**0 265 007 499**
Wheel speed sensor, rear	03.02-03.06		**0 265 007 500**
200 KOMPRESSOR [211]	**1,8 l 135 kW M 271.956 4 Zyl.**		
Throttle valve assembly	04.06→		**0 280 750 076**
Phase sensor	04.06→		**0 232 103 037**
Speed sensor, ignition/injection	04.06→		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 298**
Wheel speed sensor, front	04.06→		**0 265 007 745**
Wheel speed sensor, rear	04.06→		**0 265 007 700**
200 KOMPRESSOR NGT [211]	**1,8 l 120 kW M 271.941 4 Zyl.**		
Throttle valve assembly	04.04→		**0 280 750 076**
Phase sensor	04.04→	AUS,NOC	**0 232 103 037**
		EIN,NOC	**0 232 103 050**
Speed sensor, ignition/injection	04.04→		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	04.04→		**0 265 005 258**
Wheel speed sensor, front	04.04→		**0 265 007 499**
Wheel speed sensor, rear	04.04→		**0 265 007 500**
220 [124]	**2,2 l 110 kW M 111.960 4 Zyl.**		
Air mass meter, gasoline injection	07.93-06.95		**0 280 217 100**
Speed sensor, ignition/injection			
Mot.no. →079783	07.93-06.95	AG,LLE	**0 261 210 055**
Mot.no. →080036	07.93-06.95	GS,LLE	**0 261 210 055**

M

Product			
◀ Serie E			
Speed sensor, ignition/injection			
Mot.no. 079784→	07.93-06.95	GS,LLE	**0 261 210 122**
Mot.no. 080037→	07.93-06.95	AG,LLE	**0 261 210 122**
Knock sensor			
Mot.no. →079783	07.93-06.95	AG	**0 261 231 098**
Mot.no. →080036	07.93-06.95	GS	**0 261 231 098**
Wheel speed sensor, front			
Fg.no. C009356→,B891779→C009354, Comp. no. Code 859	07.93-06.95	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Fg.no. →C009355,B891779→C009354, ~~Comp. no. Code 859~~	07.93-06.95	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	07.93-06.95		**0 265 002 208**
220 Cabrio [124]	**2,2 l 110 kW M 111.960 4 Zyl.**		
Air mass meter, gasoline injection	07.93-06.98		**0 280 217 100**
Speed sensor, ignition/injection			
Mot.no. →079783	07.93-06.98	AG,LLE	**0 261 210 055**
Mot.no. →080036	07.93-06.98	GS,LLE	**0 261 210 055**
Mot.no. 079784→	07.93-06.98	GS,LLE	**0 261 210 122**
Mot.no. 080037→	07.93-06.98	AG,LLE	**0 261 210 122**
Knock sensor			
Mot.no. →079783	07.93-06.98	AG	**0 261 231 098**
Mot.no. →080036	07.93-06.98	GS	**0 261 231 098**
Wheel speed sensor, front	07.93-06.98	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Wheel speed sensor, rear	07.93-06.98		**0 265 002 254**
220 CDI [210]	**2,1 l 105 kW OM 611.961 4 Zyl.**		
Air mass meter, diesel	07.99-08.99		**0 281 002 152**
Pulse generator, diesel	07.99-08.99		**0 281 002 123**
Speed sensor, diesel	09.99-03.02		**0 261 210 170**
High-pressure sensor (CR system)	07.99-03.02		**0 281 002 498**
Duo sensor, acceleration and yaw rate, brake system	07.99-03.02		**0 265 005 258**
Wheel speed sensor, front	07.99-03.02	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	07.99-03.02	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
220 CDI [210]	**2,2 l 92 kW OM 611.961 4 Zyl.**		
Air mass meter, diesel	07.98-06.99		**0 281 002 152**
Pulse generator, diesel	07.98-06.99		**0 281 002 123**
High-pressure sensor (CR system)	07.98-06.99		**0 281 002 498**
Duo sensor, acceleration and yaw rate, brake system	07.98-06.99		**0 265 005 258**
Wheel speed sensor, front	07.98-06.99	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	07.98-06.99	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
220 CDI [211]	**2,1 l 100/110 kW OM 646.961 4 Zyl.**		
Air mass meter, diesel	03.02→		**0 281 002 535**
Speed sensor, diesel	03.02→		**0 261 210 170**
High-pressure sensor (CR system)	03.02→		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	03.02→		**0 265 005 258**
Wheel speed sensor, front	03.02→		**0 265 007 499**
Wheel speed sensor, rear	03.02→		**0 265 007 500**
220 CDI [211]	**2,1 l 125 kW OM 646.821 4 Zyl.**		
Air mass meter, diesel	04.06→		**0 281 002 535**
Speed sensor, diesel	04.06→		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 298**
Wheel speed sensor, front	04.06→		**0 265 007 745**
Wheel speed sensor, rear	04.06→		**0 265 007 700**

Product			
220 Coupé [124]	**2,2 l 110 kW M 111.960 4 Zyl.**		
Air mass meter, gasoline injection	07.93-06.97		**0 280 217 100**
Speed sensor, ignition/injection			
Mot.no. →079783	07.93-06.97	AG,LLE	**0 261 210 055**
Mot.no. →080036	07.93-06.97	GS,LLE	**0 261 210 055**
Mot.no. 079784→	07.93-06.97	GS,LLE	**0 261 210 122**
Mot.no. 080037→	07.93-06.97	AG,LLE	**0 261 210 122**
Knock sensor			
Mot.no. →079783	07.93-06.97	AG	**0 261 231 098**
Mot.no. →080036	07.93-06.97	GS	**0 261 231 098**
Wheel speed sensor, front			
Fg.no. C009356→,B891779→C009354, Comp. no. Code 859	07.93-06.97	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Fg.no. →C009355,B891779→C009354, ~~Comp. no. Code 859~~	07.93-06.97	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	07.93-06.97		**0 265 002 208**
220 D [210]	**2,2 l 55-70 kW OM 604.912 4 Zyl.**		
Pulse generator, diesel	06.95-06.99		**0 281 002 123**
Pedal position sensor, diesel			
Fg.no. A 117064→,J 024802→	06.95-06.99		**0 205 001 302**
Fg.no. →A 177063,→J 024801	06.95-06.99		**0 205 001 029**
Wheel speed sensor, front	06.95-06.99	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	06.95-06.99	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
230 [210]	**2,3 l 110 kW M 111.970 4 Zyl.**		
Air mass meter, gasoline injection			
Mot.no. →013233	06.95-08.97	GS	**0 280 217 100**
Mot.no. →042470	06.95-08.97	AG	**0 280 217 100**
Mot.no. 013234→	06.95-08.97	GS,KAT	**0 280 217 114**
		GS,KUT	**0 280 218 081**
Mot.no. 042471→	06.95-08.97	AG,KAT	**0 280 217 114**
		AG,KUT	**0 280 218 081**
Speed sensor, ignition/injection	06.95-08.97		**0 281 002 123**
Duo sensor, acceleration and yaw rate, brake system	06.95-08.97		**0 265 005 258**
Wheel speed sensor, front	06.95-08.97	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	06.95-08.97	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
230 [211]	**2,5 l 150 kW M 272.922 6 Zyl.**		
Air mass meter, gasoline injection	09.07→		**0 280 218 190**
Phase sensor	09.07→	LAB	**0 232 103 050**
Knock sensor	09.07→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	09.07→		**0 265 005 298**
Wheel speed sensor, front	09.07→		**0 265 007 745**
Wheel speed sensor, rear	09.07→		**0 265 007 700**
240 [210]	**2,4 l 125 kW M 112.911 6 Zyl.**		
Throttle valve assembly	09.97-06.99		**0 205 003 046**
Air mass meter, gasoline injection	09.97-06.99		**0 280 217 515**
Phase sensor	09.97-06.99		**0 232 103 037**
Speed sensor, ignition/injection			
Mot.no. →370998	09.97-06.99		**0 261 210 141**
Mot.no. 370999→	09.97-06.99		**0 261 210 170**
Knock sensor	09.97-06.99		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. B174000→,~~Comp. no. Code 800~~, Fg.no. X037894→	09.97-06.99		**0 265 005 258**
Fg.no. →B173999,~~Comp. no. Code 801~~, Fg.no. →X044900	09.97-06.99		**0 265 005 201**

Product			
Wheel speed sensor, front	09.97-06.99	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	09.97-06.99	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
240 [210]		**2,6 l 125 kW M 112.914 6 Zyl.**	
Throttle valve assembly	09.00-03.02		**0 280 750 019**
Air mass meter, gasoline injection	09.00-03.02		**0 280 217 515**
Phase sensor	09.00-03.02		**0 232 103 050**
Speed sensor, ignition/injection	09.00-03.02		**0 261 210 170**
Knock sensor	09.00-03.02		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	09.00-03.02		**0 265 005 258**
Wheel speed sensor, front	09.00-03.02	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	09.00-03.02	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
240 [211]		**2,6 l 130 kW M 112.913 6 Zyl.**	
Throttle valve assembly	03.02-03.05		**0 280 750 019**
Air mass meter, gasoline injection	03.02-03.05		**0 280 217 515**
Phase sensor	03.02-03.05		**0 232 103 050**
Speed sensor, ignition/injection	03.02-03.05		**0 261 210 170**
Knock sensor	03.02-03.05		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	03.02-03.05		**0 265 005 258**
Wheel speed sensor, front	03.02-03.05		**0 265 007 499**
Wheel speed sensor, rear	03.02-03.05		**0 265 007 500**
240 4MATIC [211]		**2,6 l 130 kW M 112.917 6 Zyl.**	
Throttle valve assembly	09.03→		**0 280 750 019**
Air mass meter, gasoline injection	09.03→		**0 280 217 515**
Phase sensor	09.03→		**0 232 103 050**
Speed sensor, ignition/injection	09.03→		**0 261 210 170**
Knock sensor	09.03→		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	09.03→		**0 265 005 258**
Wheel speed sensor, rear	09.03→		**0 265 007 500**
250 D [124]		**2,5 l 83 kW OM 605.911 5 Zyl.**	
Wheel speed sensor, front	07.93-06.95	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Wheel speed sensor, rear	07.93-06.95		**0 265 002 208**
250 D [210]		**2,5 l 83 kW OM 605.912 5 Zyl.**	
Pulse generator, diesel	06.95-06.99		**0 281 002 123**
Pedal position sensor, diesel	06.95-06.99		**0 205 001 029**
Wheel speed sensor, front	06.95-06.99	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	06.95-06.99	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
250 D Turbo [124]		**2,5 l 93 kW OM 602.962 5 Zyl.**	
Wheel speed sensor, front	07.93-06.95	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear			
Fg.no. A203047→	07.93-06.95		**0 265 002 208**
250 D Turbo [210]		**2,5 l 110 kW OM 605.962 5 Zyl.**	
Pulse generator, diesel	09.97-06.99		**0 281 002 123**
Pedal position sensor, diesel	09.97-06.99		**0 205 001 029**
Wheel speed sensor, front	09.97-06.99	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	09.97-06.99	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
270 CDI [210]		**2,7 l 125 kW OM 612.961 5 Zyl.**	
Speed sensor, diesel	06.99-03.02		**0 261 210 170**
High-pressure sensor (CR system)			
Mot.no. →287865	06.99-03.02		**0 281 002 498**
Mot.no. 287866→	06.99-03.02		**0 281 002 700**

Product			
Duo sensor, acceleration and yaw rate, brake system	06.99-03.02		**0 265 005 258**
Wheel speed sensor, front	06.99-03.02	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	06.99-03.02	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
270 CDI [211]		**2,7 l 130 kW OM 647.961 5 Zyl.**	
Air mass meter, diesel	03.02-03.05		**0 281 002 535**
Speed sensor, diesel	03.02-03.05		**0 261 210 170**
High-pressure sensor (CR system)	03.02-03.05		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	03.02-03.05		**0 265 005 258**
Wheel speed sensor, front	03.02-03.05		**0 265 007 499**
Wheel speed sensor, rear	03.02-03.05		**0 265 007 500**
280 [124]		**2,8 l 142 kW M 104.942 6 Zyl.**	
Air mass meter, gasoline injection	07.93-06.95		**0 280 217 500**
Speed sensor, ignition/injection			
Mot.no. →005789	07.93-06.95	GS,LLE	**0 261 210 055**
		GS,RLE	**0 261 210 066**
Mot.no. →048696	07.93-06.95	AG,LLE	**0 261 210 055**
		AG,RLE	**0 261 210 066**
Mot.no. 005790→	07.93-06.95	GS	**0 261 210 122**
Mot.no. 048697→	07.93-06.95	AG	**0 261 210 122**
Wheel speed sensor, front			
Fg.no. C009356→,B891779→C009354, Comp. no. Code 859	07.93-06.95	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Fg.no. →C009355,B891779→C009354, ~~Comp. no. Code 859~~	07.93-06.95	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	07.93-06.95	AOS	**0 265 002 210**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
280 [210]		**2,8 l 142 kW M 104.945 6 Zyl.**	
Air mass meter, gasoline injection	01.96-02.97		**0 280 217 500**
Speed sensor, ignition/injection	01.96-02.97		**0 261 210 122**
Wheel speed sensor, front	01.96-02.97	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	01.96-02.97	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
280 [210]		**2,8 l 150 kW M 112.921 6 Zyl.**	
Throttle valve assembly	06.95-08.00		**0 205 003 046**
	09.00-01.03		**0 280 750 019**
Air mass meter, gasoline injection	06.95-01.03		**0 280 217 515**
Phase sensor	06.95-01.03		**0 232 103 037**
Speed sensor, ignition/injection			
Mot.no. →370998	06.95-01.03		**0 261 210 141**
Mot.no. 370999→	06.95-01.03		**0 261 210 170**
Knock sensor	06.95-01.03		**0 261 231 110**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A962231	06.95-01.03		**0 205 001 302**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. B174000→,~~Comp. no. Code 800~~, Fg.no. X037894→	06.95-01.03		**0 265 005 258**
Fg.no. →B173999,~~Comp. no. Code 801~~, Fg.no. →X044900	06.95-01.03		**0 265 005 201**
Wheel speed sensor, front	06.95-01.03	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	06.95-01.03	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
280 [211]		**3,0 l 170 kW M 272.943 6 Zyl.**	
Throttle valve assembly	04.05→		**0 280 750 017**
Air mass meter, gasoline injection	04.05→		**0 280 218 190**

M

Product			
◀ Serie E			
Phase sensor	04.05→	LAB	**0 232 103 050**
Knock sensor	04.05→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 298**
Wheel speed sensor, front	04.05→		**0 265 007 745**
Wheel speed sensor, rear	04.05→		**0 265 007 700**
280 CDI [211]	**3,0 l 140 kW OM 642.920 6 Zyl.**		
High-pressure sensor (CR system)	04.05→		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 298**
Wheel speed sensor, front	04.05→		**0 265 007 745**
Wheel speed sensor, rear	04.05→		**0 265 007 700**
280 CDI [211]	**3,2 l 130 kW OM 648.961 6 Zyl.**		
Air mass meter, diesel	04.04-03.05		**0 281 002 535**
Speed sensor, diesel	04.04-03.05		**0 261 210 170**
High-pressure sensor (CR system)	04.04-03.05		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	04.04-03.05		**0 265 005 258**
Wheel speed sensor, front	04.04-03.05		**0 265 007 499**
Wheel speed sensor, rear	04.04-03.05		**0 265 007 700**
280 CDI 4MATIC [211]	**3,0 l 140 kW OM 642.921 6 Zyl.**		
High-pressure sensor (CR system)	04.05→		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 298**
Wheel speed sensor, front	04.05→		**0 265 007 745**
Wheel speed sensor, rear	04.05→		**0 265 007 700**
280 4MATIC [210]	**2,8 l 150 kW M 112.921 6 Zyl.**		
Throttle valve assembly	03.97-08.00		**0 205 003 046**
	09.00-01.03		**0 280 750 019**
Air mass meter, gasoline injection	03.97-01.03		**0 280 217 515**
Phase sensor	03.97-01.03		**0 232 103 037**
Speed sensor, ignition/injection			
Mot.no. →370998	03.97-01.03		**0 261 210 141**
Mot.no. 370999→	03.97-01.03		**0 261 210 170**
Knock sensor	03.97-01.03		**0 261 231 110**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A962231	03.97-01.03		**0 205 001 302**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. B174000→,~~Comp. no. Code 800~~, Fg.no. X037894→	03.97-01.03		**0 265 005 258**
Fg.no. →B173999,~~Comp. no. Code 801~~, Fg.no. →X044900	03.97-01.03		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)	07.99-01.03		**0 265 005 303**
Fg.no. →B 173367	07.99-01.03		**0 265 005 307**
Wheel speed sensor, front	03.97-01.03	LAB	**0 265 006 358**
		RAB	**0 265 006 356**
Wheel speed sensor, rear	03.97-01.03	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
280 4MATIC [211]	**3,0 l 170 kW M 272.944 6 Zyl.**		
Throttle valve assembly	04.05→		**0 280 750 017**
Air mass meter, gasoline injection	04.05→		**0 280 218 190**
Phase sensor	04.05→	LAB	**0 232 103 050**
Knock sensor	04.05→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 298**
Wheel speed sensor, front	04.05→		**0 265 007 745**
Wheel speed sensor, rear	04.05→		**0 265 007 700**
290 D Turbo [210]	**2,9 l 95 kW OM 602.982 5 Zyl.**		
Air mass meter, diesel	01.96-06.99		**0 280 217 509**
Pulse generator, diesel	01.96-06.99		**0 281 002 123**
Pedal position sensor, diesel	01.96-06.99		**0 205 001 029**

Product			
Wheel speed sensor, front	01.96-06.99	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	01.96-06.99	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
300 Bluetec [211]	**3,0 l 155 kW OM 642.920 6 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	12.07→		**0 265 005 298**
Wheel speed sensor, front	12.07→		**0 265 007 745**
Wheel speed sensor, rear	12.07→		**0 265 007 700**
300 D [124]	**3,0 l 100 kW OM 606.910 6 Zyl.**		
Wheel speed sensor, front	07.93-06.95	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Wheel speed sensor, rear	07.93-06.95		**0 265 002 208**
300 D [210]	**3,0 l 100 kW OM 606.912 6 Zyl.**		
Pulse generator, diesel	06.95-08.97		**0 281 002 123**
Pedal position sensor, diesel	06.95-08.97	LLE	**0 205 001 029**
		RLE	**0 205 001 302**
Wheel speed sensor, front	06.95-08.97	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	06.95-08.97	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
300 D Turbo [124]	**3,0 l 108 kW OM 603.960 6 Zyl.**		
Wheel speed sensor, front	07.93-06.95	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear			
Fg.no. A203047→	07.93-06.95		**0 265 002 208**
300 D Turbo [210]	**3,0 l 130 kW OM 606.962 6 Zyl.**		
Air mass meter, diesel	03.97-06.99		**0 281 002 152**
Pulse generator, diesel	03.97-06.99		**0 281 002 123**
Pedal position sensor, diesel	03.97-06.99		**0 205 001 029**
Duo sensor, acceleration and yaw rate, brake system	03.97-06.99		**0 265 005 201**
Wheel speed sensor, front	03.97-06.99	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	03.97-06.99	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
300 D Turbo 4MATIC [124]	**3,0 l 108 kW OM 603.963 6 Zyl.**		
Air flow sensor, diesel	07.93-06.95		**0 281 002 024**
			0 281 002 028
Temperature sensor, coolant, diesel	07.93-06.95		**0 280 130 035**
Wheel speed sensor, front	07.93-06.95	LAB	**0 265 001 300**
		RAB	**0 265 001 298**
Wheel speed sensor, rear			
Fg.no. A203047→	07.93-06.95		**0 265 002 208**
300 4MATIC [124]	**3,0 l 132 kW M 103.985 6 Zyl.**		
Air flow sensor, gasoline injection	07.93-06.95		**0 438 121 033**
			0 986 439 333
Speed sensor, ignition/injection	07.93-06.95		**0 261 210 051**
Temperature sensor, intake air, injection system	07.93-06.95		**0 280 130 047**
Temperature sensor, coolant, injection system			
Mot.no. →002187	07.93-06.95	2PO,GS	**0 280 130 044**
Mot.no. →008267	07.93-06.95	2PO,AG	**0 280 130 044**
Wheel speed sensor, front	07.93-06.95	LAB	**0 265 001 300**
		RAB	**0 265 001 298**
Wheel speed sensor, rear			
Fg.no. A203047→	07.93-06.95		**0 265 002 208**
320 [124]	**3,2 l 162 kW M 104.992 6 Zyl.**		
Air mass meter, gasoline injection	07.93-06.95		**0 280 217 500**
Speed sensor, ignition/injection			
Mot.no. →004356	07.93-06.95	GS,LLE	**0 261 210 055**
Mot.no. →072236	07.93-06.95	AG,LLE	**0 261 210 055**
Mot.no. 004357→	07.93-06.95	GS,LLE	**0 261 210 122**
Mot.no. 072237→	07.93-06.95	AG,LLE	**0 261 210 122**

Product			
Wheel speed sensor, front			
Fg.no. C009356→,B891779→C009354,	07.93-06.95	LAB	**0 265 006 111**
Comp. no. Code 859		RAB	**0 265 006 109**
Fg.no. →C009355,B891779→C009354,	07.93-06.95	LAB	**0 265 001 284**
~~Comp. no. Code 859~~		RAB	**0 265 001 282**
Wheel speed sensor, rear	07.93-06.95		**0 265 002 210**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
320 [210]	**3,2 l 162/170 kW M 104.995 6 Zyl.**		
Air mass meter, gasoline injection			
Mot.no. →12/52 050146,~~Comp. no. Code 807~~	06.95-08.97		**0 280 217 500**
Mot.no. 050174→,~~Comp. no. Code 807~~	06.95-08.97		**0 280 218 080**
Speed sensor, ignition/injection	06.95-08.97		**0 261 210 122**
Wheel speed sensor, front	06.95-08.97	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	06.95-08.97	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
320 [210]	**3,2 l 165 kW M 112.941 6 Zyl.**		
Throttle valve assembly	03.97-03.02		**0 205 003 046**
Air mass meter, gasoline injection	03.97-03.02		**0 280 217 515**
Phase sensor	03.97-03.02		**0 232 103 050**
Speed sensor, ignition/injection			
Mot.no. →370998	03.97-03.02		**0 261 210 141**
Mot.no. 370999→	03.97-03.02		**0 261 210 170**
Knock sensor	03.97-03.02		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. B174000→,~~Comp. no. Code 800~~, Fg.no. X037894→	03.97-03.02		**0 265 005 258**
Fg.no. →B173999,~~Comp. no. Code 801~~, Fg.no. →X044900	03.97-03.02		**0 265 005 201**
Wheel speed sensor, front	03.97-03.02	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	03.97-03.02	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
320 [211]	**3,2 l 165 kW M 112.949 6 Zyl.**		
Throttle valve assembly	03.02-03.05		**0 280 750 019**
Air mass meter, gasoline injection	03.02-03.05		**0 280 217 515**
Phase sensor	03.02-03.05		**0 232 103 050**
Speed sensor, ignition/injection	03.02-03.05		**0 261 210 170**
Knock sensor	03.02-03.05		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	03.02-03.05		**0 265 005 258**
Wheel speed sensor, front	03.02-03.05		**0 265 007 499**
Wheel speed sensor, rear	03.02-03.05		**0 265 007 500**
320 Cabrio [124]	**3,2 l 162-170 kW M 104.992 6 Zyl.**		
Air mass meter, gasoline injection	05.93-06.98		**0 280 217 500**
Speed sensor, ignition/injection			
Mot.no. →004356	05.93-06.98	GS,LLE	**0 261 210 055**
Mot.no. →072236	05.93-06.98	AG,LLE	**0 261 210 055**
Mot.no. 004357→	05.93-06.98	GS,LLE	**0 261 210 122**
Mot.no. 072237→	05.93-06.98	AG,LLE	**0 261 210 122**
Wheel speed sensor, front	05.93-06.98	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Wheel speed sensor, rear	05.93-06.98	AOS	**0 265 002 244**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
320 CDI [210]	**3,2 l 145 kW OM 613.961 6 Zyl.**		
Speed sensor, diesel	06.99-03.02		**0 261 210 170**
High-pressure sensor (CR system)	06.99-03.02		**0 281 002 498**
Duo sensor, acceleration and yaw rate, brake system	06.99-03.02		**0 265 005 258**

Product			
Wheel speed sensor, front	06.99-03.02	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	06.99-03.02	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
320 CDI [211]	**3,0 l 165 kW OM 642.920 6 Zyl.**		
High-pressure sensor (CR system)	04.05→		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 298**
Wheel speed sensor, front	04.05→		**0 265 007 745**
Wheel speed sensor, rear	04.05→		**0 265 007 700**
320 CDI [211]	**3,2 l 150 kW OM 648.961 6 Zyl.**		
Air mass meter, diesel	11.02-03.05		**0 281 002 535**
Speed sensor, diesel	11.02-03.05		**0 261 210 170**
High-pressure sensor (CR system)	11.02-03.05		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	11.02-03.05		**0 265 005 258**
Wheel speed sensor, front	11.02-03.05		**0 265 007 499**
Wheel speed sensor, rear	11.02-03.05		**0 265 007 500**
320 CDI 4MATIC [211]	**3,0 l 165 kW OM 642.921 6 Zyl.**		
High-pressure sensor (CR system)	04.05→		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 298**
Wheel speed sensor, front	04.05→		**0 265 007 745**
Wheel speed sensor, rear	04.05→		**0 265 007 700**
320 Coupé [124]	**3,2 l 162 kW M 104.992 6 Zyl.**		
Air mass meter, gasoline injection	07.93-06.98		**0 280 217 500**
Speed sensor, ignition/injection			
Mot.no. →004356	07.93-06.98	GS,LLE	**0 261 210 055**
Mot.no. →072236	07.93-06.98	AG,LLE	**0 261 210 055**
Mot.no. 004357→	07.93-06.98	GS,LLE	**0 261 210 122**
Mot.no. 072237→	07.93-06.98	AG,LLE	**0 261 210 122**
Wheel speed sensor, front	07.93-06.98	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	07.93-06.98	AOS	**0 265 002 210**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
320 4MATIC [210]	**3,2 l 165 kW M 112.941 6 Zyl.**		
Throttle valve assembly	09.97-03.02		**0 205 003 046**
Air mass meter, gasoline injection	09.97-03.02		**0 280 217 515**
Phase sensor	09.97-03.02		**0 232 103 050**
Speed sensor, ignition/injection			
Mot.no. →370998	09.97-03.02		**0 261 210 141**
Mot.no. 370999→	09.97-03.02		**0 261 210 170**
Knock sensor	09.97-03.02		**0 261 231 110**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A962231	09.97-03.02		**0 205 001 302**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. B174000→,~~Comp. no. Code 800~~, Fg.no. X037894→	09.97-03.02		**0 265 005 258**
Fg.no. →B173999,~~Comp. no. Code 801~~, Fg.no. →X044900	09.97-03.02		**0 265 005 201**
Wheel speed sensor, front	09.97-03.02	LAB	**0 265 006 358**
		RAB	**0 265 006 356**
Wheel speed sensor, rear	09.97-03.02	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
320 4MATIC [211]	**3,2 l 165 kW M 112.954 6 Zyl.**		
Throttle valve assembly	09.03-03.05		**0 280 750 019**
Air mass meter, gasoline injection	09.03-03.05		**0 280 217 515**
Phase sensor	09.03-03.05		**0 232 103 050**
Speed sensor, ignition/injection	09.03-03.05		**0 261 210 170**
Knock sensor	09.03-03.05		**0 261 231 110**

M

Product			
◀ Serie E			
Duo sensor, acceleration and yaw rate, brake system	09.03-03.05		**0 265 005 258**
Wheel speed sensor, rear	09.03-03.05		**0 265 007 500**
350 [211]	**3,5 l 200 kW M 272.964 6 Zyl.**		
Throttle valve assembly	04.05→		**0 280 750 017**
Air mass meter, gasoline injection	04.05→		**0 280 218 190**
Phase sensor	04.05→	LAB	**0 232 103 050**
Knock sensor	04.05→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 298**
Wheel speed sensor, front	04.05→		**0 265 007 745**
Wheel speed sensor, rear	04.05→		**0 265 007 700**
350 CGI [211]	**3,5 l 215 kW M 272.985 6 Zyl.**		
Throttle valve assembly	12.07→		**0 280 750 017**
Air mass meter, gasoline injection	12.07→		**0 280 218 190**
Phase sensor	12.07→		**0 232 103 050**
Knock sensor	12.07→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	12.07→		**0 265 005 298**
Wheel speed sensor, front	12.07→		**0 265 007 745**
Wheel speed sensor, rear	12.07→		**0 265 007 700**
350 4MATIC [211]	**3,5 l 200 kW M 272.972 6 Zyl.**		
Throttle valve assembly	04.05→		**0 280 750 017**
Air mass meter, gasoline injection	04.05→		**0 280 218 190**
Phase sensor	04.05→	LAB	**0 232 103 050**
Knock sensor	04.05→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 298**
Wheel speed sensor, front	04.05→		**0 265 007 745**
Wheel speed sensor, rear	04.05→		**0 265 007 700**
400 CDI [211]	**4,0 l 191 kW OM 628.961 8 Zyl.**		
Speed sensor, diesel	02.03-04.05		**0 261 210 170**
High-pressure sensor (CR system)			
Mot.no. →40035995	02.03-04.05		**0 281 002 498**
Mot.no. 40035996→	02.03-04.05		**0 281 002 700**
Duo sensor, acceleration and yaw rate, brake system	02.03-04.05		**0 265 005 258**
Wheel speed sensor, front	02.03-04.05		**0 265 007 499**
Wheel speed sensor, rear	02.03-04.05		**0 265 007 500**
420 [124]	**4,2 l 205/210 kW M 119.975 8 Zyl.**		
Air mass meter, gasoline injection	07.93-06.95		**0 280 214 004**
			0 986 280 121
Speed sensor, ignition/injection	07.93-06.95		**0 261 210 085**
Knock sensor	07.93-06.95		**0 261 231 062**
Temperature sensor, intake air, injection system	07.93-06.95		**0 280 130 047**
Wheel speed sensor, front			
Fg.no. C013141→	07.93-06.95	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Fg.no. →C013142	07.93-06.95	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Wheel speed sensor, rear	07.93-06.95	AOS	**0 265 002 210**
		ASR,LAB	**0 265 002 238**
		ASR,RAB	**0 265 002 108**
420 [210]	**4,2 l 205 kW M 119.985 8 Zyl.**		
Throttle valve assembly	01.96-08.97		**0 205 003 037**
Air mass meter, gasoline injection	01.96-08.97		**0 280 217 807**
Phase sensor	01.96-08.97		**0 232 103 037**
Speed sensor, ignition/injection	01.96-08.97		**0 281 002 123**
Knock sensor	01.96-08.97		**0 261 231 110**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A962231	01.96-08.97		**0 205 001 302**

Product			
Duo sensor, acceleration and yaw rate, brake system	01.96-08.97		**0 265 005 201**
Wheel speed sensor, front	01.96-08.97	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	01.96-08.97	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
420 CDI [211]	**4,0 l 231 kW OM 629.910 8 Zyl.**		
Phase sensor	09.05→		**0 232 103 050**
High-pressure sensor (CR system)	09.05→		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	09.05→		**0 265 005 298**
Wheel speed sensor, front	09.05→		**0 265 007 745**
Wheel speed sensor, rear	09.05→		**0 265 007 700**
430 [210]	**4,3 l 205 kW M 113.940 8 Zyl.**		
Throttle valve assembly	09.97-08.00		**0 205 003 048**
	09.00-03.02		**0 280 750 017**
Air mass meter, gasoline injection	09.97-03.02		**0 280 217 810**
Phase sensor	09.97-03.02		**0 232 103 050**
Speed sensor, ignition/injection	09.97-03.02		**0 261 210 170**
Knock sensor	09.97-03.02		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. B174000→,~~Comp. no. Code 800~~, Fg.no. X037894→	09.97-03.02		**0 265 005 258**
Fg.no. →B173999,~~Comp. no. Code 801~~, Fg.no. →X044900	09.97-03.02		**0 265 005 201**
Wheel speed sensor, front	09.97-03.02	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	09.97-03.02	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
430 4MATIC [210]	**4,3 l 205 kW M 113.940 8 Zyl.**		
Throttle valve assembly	06.99-08.00		**0 205 003 048**
	09.00-03.02		**0 280 750 017**
Air mass meter, gasoline injection	06.99-03.02		**0 280 217 810**
Phase sensor	06.99-03.02		**0 232 103 050**
Speed sensor, ignition/injection	06.99-03.02		**0 261 210 170**
Knock sensor	06.99-03.02		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. B174000→,~~Comp. no. Code 800~~, Fg.no. X037894→	06.99-03.02		**0 265 005 258**
Fg.no. →B173999,~~Comp. no. Code 801~~, Fg.no. →X044900	06.99-03.02		**0 265 005 201**
Wheel speed sensor, front	06.99-03.02	LAB	**0 265 006 358**
		RAB	**0 265 006 356**
Wheel speed sensor, rear	06.99-03.02	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
500 [124]	**5,0 l 235 kW M 119.974 8 Zyl.**		
Air mass meter, gasoline injection	07.93-06.95		**0 280 214 004**
			0 986 280 121
Speed sensor, ignition/injection	07.93-06.95		**0 261 210 085**
Knock sensor	07.93-06.95		**0 261 231 062**
Temperature sensor, intake air, injection system	07.93-06.95		**0 280 130 047**
Wheel speed sensor, front			
Fg.no. C013141→	07.93-06.95	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Fg.no. →C013142	07.93-06.95	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Wheel speed sensor, rear	07.93-06.95	LAB	**0 265 002 238**
		RAB	**0 265 002 108**

Product			
500 [124]	**5,0 l 235-240 kW M 119.974 8 Zyl.**		
Air mass meter, gasoline injection	07.93-06.95		**0 280 214 004**
			0 986 280 121
Speed sensor, ignition/injection	07.93-06.95		**0 261 210 085**
Knock sensor	07.93-06.95		**0 261 231 062**
Temperature sensor, intake air, injection system	07.93-06.95		**0 280 130 047**
Acceleration sensor, ABS	07.93-05.94		**0 265 005 107**
	06.94-06.95		**0 265 005 107**
	07.93-05.94		**0 265 005 107**
Wheel speed sensor, front			
Fg.no. C013141→	07.93-06.95	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Fg.no. →C013142	07.93-06.95	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Wheel speed sensor, rear	07.93-06.95	LAB	**0 265 002 238**
		RAB	**0 265 002 108**
500 [211]	**5,0 l 225 kW M 113.967 8 Zyl.**		
Throttle valve assembly	03.02-03.06		**0 280 750 017**
Air mass meter, gasoline injection	03.02-03.06		**0 280 217 810**
Phase sensor	03.02-03.06		**0 232 103 050**
Speed sensor, ignition/injection	03.02-03.06		**0 261 210 170**
Knock sensor	03.02-03.06		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	03.02-03.06		**0 265 005 258**
Wheel speed sensor, front	03.02-03.06		**0 265 007 499**
Wheel speed sensor, rear	03.02-03.06		**0 265 007 500**
500 [211]	**5,5 l 285 kW M 273.960 8 Zyl.**		
Throttle valve assembly	04.06→		**0 280 750 184**
Air mass meter, gasoline injection	04.06→		**0 280 218 190**
Phase sensor	04.06→	LAB	**0 232 103 050**
Knock sensor	04.06→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 298**
Wheel speed sensor, front	04.06→		**0 265 007 745**
Wheel speed sensor, rear	04.06→		**0 265 007 700**
500 4MATIC [211]	**5,0 l 225 kW M 113.969 8 Zyl.**		
Throttle valve assembly	09.03-08.06		**0 280 750 017**
Air mass meter, gasoline injection	09.03-08.06		**0 280 217 810**
Phase sensor	09.03-08.06		**0 232 103 050**
Speed sensor, ignition/injection	09.03-08.06		**0 261 210 170**
Knock sensor	09.03-08.06		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	09.03-08.06		**0 265 005 258**
Wheel speed sensor, rear	09.03-08.06		**0 265 007 500**
500 4MATIC [211]	**5,5 l 285 kW M 273.962 8 Zyl.**		
Throttle valve assembly	09.06→		**0 280 750 184**
Air mass meter, gasoline injection	09.06→		**0 280 218 190**
Phase sensor	09.06→	LAB	**0 232 103 050**
Knock sensor	09.06→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	09.06→		**0 265 005 298**
Wheel speed sensor, front	09.06→		**0 265 007 745**
Wheel speed sensor, rear	09.06→		**0 265 007 700**

Serie E (T-Modell)

Product			
36 AMG T [124]	**3,6 l 195-200 kW M 104.992 6 Zyl.**		
Air mass meter, gasoline injection	03.94-05.96		**0 280 217 500**
Speed sensor, ignition/injection			
Mot.no. →004356	03.94-05.96	GS,LLE	**0 261 210 055**
Mot.no. →072236	03.94-05.96	AG,LLE	**0 261 210 055**
Mot.no. 004357→	03.94-05.96	GS,LLE	**0 261 210 122**
Mot.no. 072237→	03.94-05.96	AG,LLE	**0 261 210 122**
Wheel speed sensor, front			
Fg.no. F264121→	03.94-05.96	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Fg.no. →F264120	03.94-05.96	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	03.94-05.96	AOS	**0 265 002 210**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
55 AMG KOMPRESSOR T [211]	**5,4 l 350 kW M 113.990 8 Zyl.**		
Throttle valve assembly	09.03-05.06		**0 280 750 045**
Air mass meter, gasoline injection	09.03-05.06		**0 280 217 810**
Phase sensor	09.03-05.06		**0 232 103 050**
Speed sensor, ignition/injection	09.03-05.06		**0 261 210 170**
Knock sensor	09.03-05.06		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	09.03-05.06		**0 265 005 258**
Wheel speed sensor, front	09.03-05.06		**0 265 007 499**
Wheel speed sensor, rear	09.03-05.06		**0 265 007 500**
55 AMG T [210]	**5,5 l 260 kW M 113.980 8 Zyl.**		
Throttle valve assembly	03.98-08.00		**0 205 003 048**
	09.00-01.03		**0 280 750 017**
Air mass meter, gasoline injection	03.98-01.03		**0 280 217 810**
Phase sensor	03.98-01.03		**0 232 103 050**
Speed sensor, ignition/injection			
Mot.no. →002692	03.98-01.03		**0 261 210 141**
Mot.no. 002693→	03.98-01.03		**0 261 210 170**
Knock sensor	03.98-01.03		**0 261 231 110**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A962231	03.98-01.03		**0 205 001 302**
Duo sensor, acceleration and yaw rate, brake system	03.98-01.03		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)	06.00-01.03		**0 265 005 303**
	07.99-05.00		**0 265 005 307**
Wheel speed sensor, front	03.98-01.03	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	03.98-01.03	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
63 AMG T [211]	**6,2 l 378 kW M 156.983 8 Zyl.**		
Knock sensor	06.06→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	06.06→		**0 265 005 298**
Wheel speed sensor, front	06.06→		**0 265 007 745**
Wheel speed sensor, rear	06.06→		**0 265 007 700**
200 CDI [211]	**2,1 l 100 kW OM 646.821 4 Zyl.**		
Air mass meter, diesel	04.07→		**0 281 002 535**
Speed sensor, diesel	04.07→		**0 261 210 170**
Wheel speed sensor, front	04.07→		**0 265 007 745**
Wheel speed sensor, rear	04.07→		**0 265 007 700**
200 KOMPRESSOR T [210]	**2,0 l 120 kW M 111.957 4 Zyl.**		
Throttle valve assembly	09.00-01.03		**0 280 750 074**
Speed sensor, ignition/injection	09.00-01.03		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	09.00-01.03		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	09.00-01.03		**0 265 005 303**
Fg.no. →B 173367	09.00-01.03		**0 265 005 307**
Wheel speed sensor, front	09.00-01.03	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	09.00-01.03	LAB	**0 265 006 178**
		RAB	**0 265 006 194**

M

Product			
◀ Serie E (T-Modell)			
200 KOMPRESSOR T [210]			**2,0 l 137 kW M 111.947 4 Zyl.**
Throttle valve assembly	09.97-01.03		**0 205 003 044**
Air mass meter, gasoline injection	09.97-01.03	FGK	**0 280 217 114**
		KUT	**0 280 218 081**
Speed sensor, ignition/injection			
Mot.no. →001935	09.97-01.03	AG	**0 281 002 123**
Mot.no. →001936	09.97-01.03	AG	**0 261 210 170**
Mot.no. →005503	09.97-01.03	GS	**0 281 002 123**
Mot.no. →005504	09.97-01.03	GS	**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	09.97-01.03		**0 265 005 201**
Wheel speed sensor, front	09.97-01.03	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	09.97-01.03	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
200 KOMPRESSOR T [211]			**1,8 l 120 kW M 271.941 4 Zyl.**
Throttle valve assembly	02.03-03.06		**0 280 750 076**
Phase sensor	02.03-03.06	AUS,NOC	**0 232 103 037**
		EIN,NOC	**0 232 103 050**
Speed sensor, ignition/injection	02.03-03.06		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	02.03-03.06		**0 265 005 258**
Wheel speed sensor, front	02.03-03.06		**0 265 007 499**
Wheel speed sensor, rear	02.03-03.06		**0 265 007 500**
200 KOMPRESSOR T [211]			**1,8 l 135 kW M 271.956 4 Zyl.**
Throttle valve assembly	04.06→		**0 280 750 076**
Phase sensor	04.06→		**0 232 103 037**
Speed sensor, ignition/injection	04.06→		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 298**
Wheel speed sensor, front	04.06→		**0 265 007 745**
Wheel speed sensor, rear	04.06→		**0 265 007 700**
200 T [124]			**2,0 l 100 kW M 111.940 4 Zyl.**
Speed sensor, ignition/injection	07.93-05.96		**0 261 210 055**
Wheel speed sensor, front			
Fg.no. F264121→	07.93-05.96	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Fg.no. →F264120	07.93-05.96	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear			
Fg.no. F005650→	07.93-05.96		**0 265 002 208**
200 T [210]			**2,0 l 100 kW M 111.942 4 Zyl.**
Air mass meter, gasoline injection	05.96-01.03	FGK	**0 280 217 114**
		KUT	**0 280 218 081**
Speed sensor, ignition/injection			
Mot.no. 055850 →	05.96-06.99	AG	**0 261 210 170**
Mot.no. 057355 →	05.96-06.99	GS	**0 261 210 170**
Mot.no. →055849	05.96-06.99	AG	**0 281 002 123**
Mot.no. →057354	05.96-06.99	GS	**0 281 002 123**
Duo sensor, acceleration and yaw rate, brake system	05.96-01.03		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)	07.99-01.03		**0 265 005 303**
Fg.no. →B 173367	07.99-01.03		**0 265 005 307**
Wheel speed sensor, front	05.96-01.03	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	05.96-01.03	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
220 CDI T [210]			**2,1 l 105 kW OM 611.961 4 Zyl.**
Air mass meter, diesel	07.99-08.99		**0 281 002 152**
Pulse generator, diesel	07.99-08.99		**0 281 002 123**
Speed sensor, diesel	09.99-01.03		**0 261 210 170**
High-pressure sensor (CR system)	07.99-01.03		**0 281 002 498**
Duo sensor, acceleration and yaw rate, brake system	07.99-01.03		**0 265 005 258**

Product			
Pressure sensor, ESP, (electronic stability program)	07.99-01.03		**0 265 005 303**
Wheel speed sensor, front	07.99-01.03	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	07.99-01.03	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
220 CDI T [210]			**2,2 l 92 kW OM 611.961 4 Zyl.**
Air mass meter, diesel	07.98-06.99		**0 281 002 152**
Pulse generator, diesel	07.98-06.99		**0 281 002 123**
High-pressure sensor (CR system)	07.98-06.99		**0 281 002 498**
Duo sensor, acceleration and yaw rate, brake system	07.98-06.99		**0 265 005 258**
Wheel speed sensor, front	07.98-06.99	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	07.98-06.99	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
220 CDI T [211]			**2,1 l 100/110 kW OM 646.961 4 Zyl.**
Air mass meter, diesel	02.03→		**0 281 002 535**
Speed sensor, diesel	02.03→		**0 261 210 170**
High-pressure sensor (CR system)	02.03→		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	02.03→		**0 265 005 258**
Wheel speed sensor, front	02.03→		**0 265 007 499**
Wheel speed sensor, rear	02.03→		**0 265 007 500**
220 CDI T [211]			**2,1 l 125 kW OM 646.821 4 Zyl.**
Air mass meter, diesel	04.06→		**0 281 002 535**
Speed sensor, diesel	04.06→		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 298**
Wheel speed sensor, front	04.06→		**0 265 007 745**
Wheel speed sensor, rear	04.06→		**0 265 007 700**
220 T [124]			**2,2 l 110 kW M 111.960 4 Zyl.**
Air mass meter, gasoline injection	07.93-05.96		**0 280 217 100**
Speed sensor, ignition/injection			
Mot.no. →079783	07.93-05.96	AG,LLE	**0 261 210 055**
Mot.no. →080036	07.93-05.96	GS,LLE	**0 261 210 055**
Mot.no. 079784→	07.93-05.96	GS,LLE	**0 261 210 122**
Mot.no. 080037→	07.93-05.96	AG,LLE	**0 261 210 122**
Knock sensor			
Mot.no. →079783	07.93-05.96	AG	**0 261 231 098**
Mot.no. →080036	07.93-05.96	GS	**0 261 231 098**
Wheel speed sensor, front			
Fg.no. F264121→	07.93-05.96	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Fg.no. →F264120	07.93-05.96	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear			
Fg.no. F005650→	07.93-05.96		**0 265 002 208**
230 [211]			**2,5 l 150 kW M 272.922 6 Zyl.**
Air mass meter, gasoline injection	09.07→		**0 280 218 190**
Phase sensor	09.07→	LAB	**0 232 103 050**
Knock sensor	09.07→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	09.07→		**0 265 005 298**
Wheel speed sensor, front	09.07→		**0 265 007 745**
Wheel speed sensor, rear	09.07→		**0 265 007 700**
230 T [210]			**2,3 l 110 kW M 111.970 4 Zyl.**
Air mass meter, gasoline injection			
Mot.no. →013233	05.96-08.97	GS	**0 280 217 100**
Mot.no. →042470	05.96-08.97	AG	**0 280 217 100**
Mot.no. 013234→	05.96-08.97	GS,KAT	**0 280 217 114**
		GS,KUT	**0 280 218 081**
Mot.no. 042471→	05.96-08.97	AG,KAT	**0 280 217 114**
		AG,KUT	**0 280 218 081**

Product			
Speed sensor, ignition/injection	05.96-08.97		**0 281 002 123**
Duo sensor, acceleration and yaw rate, brake system	05.96-08.97		**0 265 005 258**
Wheel speed sensor, front	05.96-08.97	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	05.96-08.97	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
240 T [210]	**2,4 l 125 kW M 112.911 6 Zyl.**		
Throttle valve assembly	09.97-01.03		**0 205 003 046**
Air mass meter, gasoline injection	09.97-01.03		**0 280 217 515**
Phase sensor	09.97-01.03		**0 232 103 037**
Speed sensor, ignition/injection			
Mot.no. →370998	09.97-01.03		**0 261 210 141**
Mot.no. 370999→	09.97-01.03		**0 261 210 170**
Knock sensor	09.97-01.03		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	09.97-01.03		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)	07.99-01.03		**0 265 005 303**
Fg.no. →B 173367	07.99-01.03		**0 265 005 307**
Wheel speed sensor, front	09.97-01.03	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	09.97-01.03	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
240 T [210]	**2,6 l 125 kW M 112.914 6 Zyl.**		
Throttle valve assembly	06.99-01.03		**0 280 750 019**
Air mass meter, gasoline injection	06.99-01.03		**0 280 217 515**
Phase sensor	06.99-01.03		**0 232 103 050**
Speed sensor, ignition/injection	06.99-01.03		**0 261 210 170**
Knock sensor	06.99-01.03		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	06.99-01.03		**0 265 005 258**
Wheel speed sensor, front	06.99-01.03	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	06.99-01.03	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
240 T [211]	**2,6 l 130 kW M 112.913 6 Zyl.**		
Throttle valve assembly	02.03-03.05		**0 280 750 019**
Air mass meter, gasoline injection	02.03-03.05		**0 280 217 515**
Phase sensor	02.03-03.05		**0 232 103 050**
Speed sensor, ignition/injection	02.03-03.05		**0 261 210 170**
Knock sensor	02.03-03.05		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	02.03-03.05		**0 265 005 258**
Wheel speed sensor, front	02.03-03.05		**0 265 007 499**
Wheel speed sensor, rear	02.03-03.05		**0 265 007 500**
240 4MATIC T [211]	**2,6 l 130 kW M 112.917 6 Zyl.**		
Throttle valve assembly	09.03→		**0 280 750 019**
Air mass meter, gasoline injection	09.03→		**0 280 217 515**
Phase sensor	09.03→		**0 232 103 050**
Speed sensor, ignition/injection	09.03→		**0 261 210 170**
Knock sensor	09.03→		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	09.03→		**0 265 005 258**
Wheel speed sensor, rear	09.03→		**0 265 007 500**
250 D T [124]	**2,5 l 83 kW OM 605.911 5 Zyl.**		
Wheel speed sensor, front	07.93-05.96	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Wheel speed sensor, rear			
Fg.no. F005650→	07.93-05.96		**0 265 002 208**
250 D T [210]	**2,5 l 83 kW OM 605.912 5 Zyl.**		
Pulse generator, diesel	05.96-06.98		**0 281 002 123**
Pedal position sensor, diesel	05.96-06.98		**0 205 001 029**

Product			
Wheel speed sensor, front	05.96-06.98	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	05.96-06.98	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
250 D Turbo T [124]	**2,5 l 93 kW OM 602.962 5 Zyl.**		
Wheel speed sensor, front	07.93-06.95	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Wheel speed sensor, rear			
Fg.no. F005650→	07.93-06.95		**0 265 002 208**
250 D Turbo T [210]	**2,5 l 110 kW OM 605.962 5 Zyl.**		
Pulse generator, diesel	09.97-08.99		**0 281 002 123**
Pedal position sensor, diesel	09.97-08.99		**0 205 001 029**
Wheel speed sensor, front	09.97-08.99	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	09.97-08.99	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
270 CDI T [210]	**2,7 l 125 kW OM 612.961 5 Zyl.**		
Speed sensor, diesel	06.99-01.03		**0 261 210 170**
High-pressure sensor (CR system)			
Mot.no. →287865	06.99-01.03		**0 281 002 498**
Mot.no. 287866→	06.99-01.03		**0 281 002 700**
Duo sensor, acceleration and yaw rate, brake system	06.99-01.03		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	06.99-01.03		**0 265 005 303**
Wheel speed sensor, front	06.99-01.03	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	06.99-01.03	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
270 CDI T [211]	**2,7 l 130 kW OM 647.961 5 Zyl.**		
Air mass meter, diesel	02.03-03.05		**0 281 002 535**
Speed sensor, diesel	02.03-03.05		**0 261 210 170**
High-pressure sensor (CR system)	02.03-03.05		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	02.03-03.05		**0 265 005 258**
Wheel speed sensor, front	02.03-03.05		**0 265 007 499**
Wheel speed sensor, rear	02.03-03.05		**0 265 007 500**
280 CDI T [211]	**3,0 l 140 kW OM 642.920 6 Zyl.**		
High-pressure sensor (CR system)	04.05→		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 298**
Wheel speed sensor, front	04.05→		**0 265 007 745**
Wheel speed sensor, rear	04.05→		**0 265 007 700**
280 CDI T [211]	**3,2 l 130 kW OM 648.961 6 Zyl.**		
Air mass meter, diesel	04.04-03.05		**0 281 002 535**
Speed sensor, diesel	04.04-03.05		**0 261 210 170**
High-pressure sensor (CR system)	04.04-03.05		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	04.04-03.05		**0 265 005 258**
Wheel speed sensor, front	04.04-03.05		**0 265 007 499**
Wheel speed sensor, rear	04.04-03.05		**0 265 007 700**
280 CDI 4MATIC T [211]	**3,0 l 140 kW OM 642.921 6 Zyl.**		
High-pressure sensor (CR system)	04.05→		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 298**
Wheel speed sensor, front	04.05→		**0 265 007 745**
Wheel speed sensor, rear	04.05→		**0 265 007 700**
280 T [124]	**2,8 l 142-145 kW M 104.942 6 Zyl.**		
Air mass meter, gasoline injection	07.93-05.96		**0 280 217 500**
Speed sensor, ignition/injection			
Mot.no. →005789	07.93-05.96	GS,LLE	**0 261 210 055**
		GS,RLE	**0 261 210 066**
Mot.no. →048696	07.93-05.96	AG,LLE	**0 261 210 055**
		AG,RLE	**0 261 210 066**

M

Product			
◀ Serie E (T-Modell)			
Speed sensor, ignition/injection			
Mot.no. 005790→	07.93-05.96	GS	**0 261 210 122**
Mot.no. 048697→	07.93-05.96	AG	**0 261 210 122**
Wheel speed sensor, front			
Fg.no. F264121→	07.93-05.96	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Fg.no. →F264120	07.93-05.96	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	07.93-05.96	AOS	**0 265 002 210**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
280 T [210]	**2,8 l 150 kW M 112.921 6 Zyl.**		
Throttle valve assembly	07.96-08.00		**0 205 003 046**
	09.00-01.03		**0 280 750 019**
Air mass meter, gasoline injection	07.96-01.03		**0 280 217 515**
Phase sensor	07.96-01.03		**0 232 103 037**
Speed sensor, ignition/injection			
Mot.no. →370998	07.96-01.03		**0 261 210 141**
Mot.no. 370999→	07.96-01.03		**0 261 210 170**
Knock sensor	07.96-01.03		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	07.96-01.03		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)	07.96-01.03		**0 265 005 307**
Wheel speed sensor, front	07.96-01.03	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	07.96-01.03	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
280 T [211]	**3,0 l 170 kW M 272.943 6 Zyl.**		
Throttle valve assembly	04.05→		**0 280 750 017**
Air mass meter, gasoline injection	04.05→		**0 280 218 190**
Phase sensor	04.05→	LAB	**0 232 103 050**
Knock sensor	04.05→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 298**
Wheel speed sensor, front	04.05→		**0 265 007 745**
Wheel speed sensor, rear	04.05→		**0 265 007 700**
280 4MATIC T [210]	**2,8 l 150 kW M 112.921 6 Zyl.**		
Throttle valve assembly	03.97-08.00		**0 205 003 046**
	09.00-01.03		**0 280 750 019**
Air mass meter, gasoline injection	03.97-01.03		**0 280 217 515**
Phase sensor	03.97-01.03		**0 232 103 037**
Speed sensor, ignition/injection			
Mot.no. →370998	03.97-01.03		**0 261 210 141**
Mot.no. 370999→	03.97-01.03		**0 261 210 170**
Knock sensor	03.97-01.03		**0 261 231 110**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A962231	03.97-01.03		**0 205 001 302**
Duo sensor, acceleration and yaw rate, brake system	03.97-01.03		**0 265 005 201**
Wheel speed sensor, front	03.97-01.03	LAB	**0 265 006 358**
		RAB	**0 265 006 356**
Wheel speed sensor, rear	03.97-01.03	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
280 4MATIC T [211]	**3,0 l 170 kW M 272.944 6 Zyl.**		
Throttle valve assembly	04.05→		**0 280 750 017**
Air mass meter, gasoline injection	04.05→		**0 280 218 190**
Phase sensor	04.05→	LAB	**0 232 103 050**
Knock sensor	04.05→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 298**
Wheel speed sensor, front	04.05→		**0 265 007 745**
Wheel speed sensor, rear	04.05→		**0 265 007 700**

Product			
290 D Turbo T [210]	**2,9 l 95 kW OM 602.982 5 Zyl.**		
Air mass meter, diesel	05.96-06.99		**0 280 217 509**
Pulse generator, diesel	05.96-06.99		**0 281 002 123**
Pedal position sensor, diesel	05.96-06.99		**0 205 001 029**
Wheel speed sensor, front	05.96-06.99	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	05.96-06.99	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
300 D T [124]	**3,0 l 100 kW OM 606.910 6 Zyl.**		
Wheel speed sensor, front	07.93-05.96	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Wheel speed sensor, rear			
Fg.no. F005650→	07.93-05.96		**0 265 002 208**
300 D Turbo T [124]	**3,0 l 105-108 kW OM 603.960 6 Zyl.**		
Wheel speed sensor, front	07.93-05.96	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Wheel speed sensor, rear			
Fg.no. F005650→	07.93-05.96		**0 265 002 208**
300 D Turbo T [210]	**3,0 l 130 kW OM 606.962 6 Zyl.**		
Air mass meter, diesel	03.97-06.99		**0 281 002 152**
Pulse generator, diesel	03.97-06.99		**0 281 002 123**
Pedal position sensor, diesel	03.97-06.99		**0 205 001 029**
Duo sensor, acceleration and yaw rate, brake system	03.97-06.99		**0 265 005 201**
Wheel speed sensor, front	03.97-06.99	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	03.97-06.99	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
300 D Turbo 4MATIC T [124]	**3,0 l 105-108 kW OM 603.963 6 Zyl.**		
Air flow sensor, diesel	07.93-05.96		**0 281 002 024**
			0 281 002 028
Temperature sensor, coolant, diesel	07.93-05.96		**0 280 130 035**
Wheel speed sensor, front			
Fg.no. F128718→	07.93-05.96	LAB	**0 265 001 300**
		RAB	**0 265 001 298**
Fg.no. →F128717	07.93-05.96	LAB	**0 265 001 400**
		RAB	**0 265 001 398**
Wheel speed sensor, rear			
Fg.no. F005650→	07.93-05.96		**0 265 002 208**
300 4MATIC T [124]	**3,0 l 132 kW M 103.985 6 Zyl.**		
Air flow sensor, gasoline injection	07.93-06.95		**0 438 121 033**
			0 986 439 333
Speed sensor, ignition/injection	07.93-06.95		**0 261 210 051**
Temperature sensor, intake air, injection system	07.93-06.95		**0 280 130 047**
Temperature sensor, coolant, injection system			
Mot.no. →002187	07.93-06.95	2PO,GS	**0 280 130 044**
Mot.no. →008267	07.93-06.95	2PO,AG	**0 280 130 044**
Wheel speed sensor, front			
Fg.no. F128718→	07.93-06.95	LAB	**0 265 001 300**
		RAB	**0 265 001 298**
Fg.no. →F128717	07.93-06.95	LAB	**0 265 001 400**
		RAB	**0 265 001 398**
Wheel speed sensor, rear			
Fg.no. F005650→	07.93-06.95		**0 265 002 208**
320 CDI T [210]	**3,2 l 145 kW OM 613.961 6 Zyl.**		
Speed sensor, diesel	07.99-01.03		**0 261 210 170**
High-pressure sensor (CR system)	07.99-01.03		**0 281 002 498**
Duo sensor, acceleration and yaw rate, brake system	07.99-01.03		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	07.99-01.03		**0 265 005 303**
Wheel speed sensor, front	07.99-01.03	LAB	**0 265 006 190**
		RAB	**0 265 006 188**

M

Product			
Wheel speed sensor, rear	07.99-01.03	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
320 CDI T [211]	**3,0 l 165 kW OM 642.920 6 Zyl.**		
High-pressure sensor (CR system)	04.05→		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 298**
Wheel speed sensor, front	04.05→		**0 265 007 745**
Wheel speed sensor, rear	04.05→		**0 265 007 700**
320 CDI T [211]	**3,2 l 150 kW OM 648.961 6 Zyl.**		
Air mass meter, diesel	02.03-03.05		**0 281 002 535**
Speed sensor, diesel	02.03-03.05		**0 261 210 170**
High-pressure sensor (CR system)	02.03-03.05		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	02.03-03.05		**0 265 005 258**
Wheel speed sensor, front	02.03-03.05		**0 265 007 499**
Wheel speed sensor, rear	02.03-03.05		**0 265 007 500**
320 CDI 4MATIC T [211]	**3,0 l 165 kW OM 642.921 6 Zyl.**		
High-pressure sensor (CR system)	04.05→		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 298**
Wheel speed sensor, front	04.05→		**0 265 007 745**
Wheel speed sensor, rear	04.05→		**0 265 007 700**
320 T [124]	**3,2 l 162 kW M 104.992 6 Zyl.**		
Air mass meter, gasoline injection	07.93-05.96		**0 280 217 500**
Speed sensor, ignition/injection			
Mot.no. →004356	07.93-05.96	GS,LLE	**0 261 210 055**
Mot.no. →072236	07.93-05.96	AG,LLE	**0 261 210 055**
Mot.no. 004357→	07.93-05.96	GS,LLE	**0 261 210 122**
Mot.no. 072237→	07.93-05.96	AG,LLE	**0 261 210 122**
Wheel speed sensor, front			
Fg.no. F264121→	07.93-05.96	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Fg.no. →F264120	07.93-05.96	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	07.93-05.96	AOS	**0 265 002 210**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
320 T [210]	**3,2 l 165 kW M 112.941 6 Zyl.**		
Throttle valve assembly	03.97-01.03		**0 205 003 046**
Air mass meter, gasoline injection	03.97-01.03		**0 280 217 515**
Phase sensor	03.97-01.03		**0 232 103 050**
Speed sensor, ignition/injection			
Mot.no. →370998	03.97-01.03		**0 261 210 141**
Mot.no. 370999→	03.97-01.03		**0 261 210 170**
Knock sensor	03.97-01.03		**0 261 231 110**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A962231	03.97-01.03		**0 205 001 302**
Duo sensor, acceleration and yaw rate, brake system	03.97-01.03		**0 265 005 201**
Wheel speed sensor, front	03.97-01.03	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	03.97-01.03	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
320 T [211]	**3,2 l 165 kW M 112.949 6 Zyl.**		
Throttle valve assembly	02.03-03.05		**0 280 750 019**
Air mass meter, gasoline injection	02.03-03.05		**0 280 217 515**
Phase sensor	02.03-03.05		**0 232 103 050**
Speed sensor, ignition/injection	02.03-03.05		**0 261 210 170**
Knock sensor	02.03-03.05		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	02.03-03.05		**0 265 005 258**

Product			
Wheel speed sensor, front	02.03-03.05		**0 265 007 499**
Wheel speed sensor, rear	02.03-03.05		**0 265 007 500**
320 4MATIC T [210]	**3,2 l 165 kW M 112.941 6 Zyl.**		
Throttle valve assembly	06.97-02.01		**0 205 003 046**
Air mass meter, gasoline injection	06.97-02.01		**0 280 217 515**
Phase sensor	06.97-02.01		**0 232 103 050**
Speed sensor, ignition/injection			
Mot.no. →370998	06.97-02.01		**0 261 210 141**
Mot.no. 370999→	06.97-02.01		**0 261 210 170**
Knock sensor	06.97-02.01		**0 261 231 110**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A962231	06.97-02.01		**0 205 001 302**
Duo sensor, acceleration and yaw rate, brake system	06.97-02.01		**0 265 005 201**
Wheel speed sensor, front	06.97-02.01	LAB	**0 265 006 358**
		RAB	**0 265 006 356**
Wheel speed sensor, rear	06.97-02.01	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
320 4MATIC T [211]	**3,2 l 165 kW M 112.954 6 Zyl.**		
Throttle valve assembly	09.03-03.05		**0 280 750 019**
Air mass meter, gasoline injection	09.03-03.05		**0 280 217 515**
Phase sensor	09.03-03.05		**0 232 103 050**
Speed sensor, ignition/injection	09.03-03.05		**0 261 210 170**
Knock sensor	09.03-03.05		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	09.03-03.05		**0 265 005 258**
Wheel speed sensor, rear	09.03-03.05		**0 265 007 500**
350 CGI [211]	**3,5 l 215 kW M 272.985 6 Zyl.**		
Throttle valve assembly	12.07→		**0 280 750 017**
Air mass meter, gasoline injection	12.07→		**0 280 218 190**
Phase sensor	12.07→		**0 232 103 050**
Knock sensor	12.07→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	12.07→		**0 265 005 298**
Wheel speed sensor, front	12.07→		**0 265 007 745**
Wheel speed sensor, rear	12.07→		**0 265 007 700**
350 T [211]	**3,5 l 200 kW M 272.964 6 Zyl.**		
Throttle valve assembly	04.05→		**0 280 750 017**
Air mass meter, gasoline injection	04.05→		**0 280 218 190**
Phase sensor	04.05→	LAB	**0 232 103 050**
Knock sensor	04.05→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 298**
Wheel speed sensor, front	04.05→		**0 265 007 745**
Wheel speed sensor, rear	04.05→		**0 265 007 700**
350 4MATIC T [211]	**3,5 l 200 kW M 272.972 6 Zyl.**		
Throttle valve assembly	04.05→		**0 280 750 017**
Air mass meter, gasoline injection	04.05→		**0 280 218 190**
Phase sensor	04.05→	LAB	**0 232 103 050**
Knock sensor	04.05→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 298**
Wheel speed sensor, front	04.05→		**0 265 007 745**
Wheel speed sensor, rear	04.05→		**0 265 007 700**
420 T [210]	**4,2 l 205 kW M 119.985 8 Zyl.**		
Throttle valve assembly	05.96-08.97		**0 205 003 037**
Air mass meter, gasoline injection	05.96-08.97		**0 280 217 807**
Phase sensor	05.96-08.97		**0 232 103 037**
Speed sensor, ignition/injection	05.96-08.97		**0 281 002 123**
Knock sensor	05.96-08.97		**0 261 231 110**

M

Product

◀ Serie E (T-Modell)

Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A962231	05.96-08.97		**0 205 001 302**
Duo sensor, acceleration and yaw rate, brake system	05.96-08.97		**0 265 005 201**
Wheel speed sensor, front	05.96-08.97	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	05.96-08.97	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
430 T [210]	**4,3 l 205 kW M 113.940 8 Zyl.**		
Throttle valve assembly	09.97-08.00		**0 205 003 048**
	09.00-01.03		**0 280 750 017**
Air mass meter, gasoline injection	09.97-01.03		**0 280 217 810**
Phase sensor	09.97-01.03		**0 232 103 050**
Speed sensor, ignition/injection	09.97-01.03		**0 261 210 170**
Knock sensor	09.97-01.03		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	09.97-01.03		**0 265 005 201**
Wheel speed sensor, front	09.97-01.03	LAB	**0 265 006 190**
		RAB	**0 265 006 188**
Wheel speed sensor, rear	09.97-01.03	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
430 4MATIC T [210]	**4,3 l 205 kW M 113.940 8 Zyl.**		
Throttle valve assembly	06.97-08.00		**0 205 003 048**
	09.00-01.03		**0 280 750 017**
Air mass meter, gasoline injection	06.97-01.03		**0 280 217 810**
Phase sensor	06.97-01.03		**0 232 103 050**
Speed sensor, ignition/injection	06.97-01.03		**0 261 210 170**
Knock sensor	06.97-01.03		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	06.97-01.03		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)	06.97-01.03		**0 265 005 303**
Fg.no. →B 173367	06.97-01.03		**0 265 005 307**
Wheel speed sensor, front	06.97-01.03	LAB	**0 265 006 358**
		RAB	**0 265 006 356**
Wheel speed sensor, rear	06.97-01.03	LAB	**0 265 006 178**
		RAB	**0 265 006 194**
500 T [211]	**5,0 l 225 kW M 113.967 8 Zyl.**		
Throttle valve assembly	09.03-03.06		**0 280 750 017**
Air mass meter, gasoline injection	09.03-03.06		**0 280 217 810**
Phase sensor	09.03-03.06		**0 232 103 050**
Speed sensor, ignition/injection	09.03-03.06		**0 261 210 170**
Knock sensor	09.03-03.06		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	09.03-03.06		**0 265 005 258**
Wheel speed sensor, front	09.03-03.06		**0 265 007 499**
Wheel speed sensor, rear	09.03-03.06		**0 265 007 500**
500 T [211]	**5,5 l 285 kW M 273.960 8 Zyl.**		
Throttle valve assembly	04.06→		**0 280 750 184**
Air mass meter, gasoline injection	04.06→		**0 280 218 190**
Phase sensor	04.06→	LAB	**0 232 103 050**
Knock sensor	04.06→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 298**
Wheel speed sensor, front	04.06→		**0 265 007 745**
Wheel speed sensor, rear	04.06→		**0 265 007 700**
500 4MATIC T [211]	**5,0 l 225 kW M 113.969 8 Zyl.**		
Throttle valve assembly	09.03-08.06		**0 280 750 017**
Air mass meter, gasoline injection	09.03-08.06		**0 280 217 810**
Phase sensor	09.03-08.06		**0 232 103 050**
Speed sensor, ignition/injection	09.03-08.06		**0 261 210 170**
Knock sensor	09.03-08.06		**0 261 231 110**

Product

Duo sensor, acceleration and yaw rate, brake system	09.03-08.06		**0 265 005 258**
Wheel speed sensor, rear	09.03-08.06		**0 265 007 500**
500 4MATIC T [211]	**5,5 l 285 kW M 273.962 8 Zyl.**		
Throttle valve assembly	09.06→		**0 280 750 184**
Air mass meter, gasoline injection	09.06→		**0 280 218 190**
Phase sensor	09.06→	LAB	**0 232 103 050**
Knock sensor	09.06→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	09.06→		**0 265 005 298**
Wheel speed sensor, front	09.06→		**0 265 007 745**
Wheel speed sensor, rear	09.06→		**0 265 007 700**

Serie G

55 AMG [463]	**5,4 l 260 kW M 113.982 8 Zyl.**		
Throttle valve assembly	04.99-03.04		**0 280 750 017**
Phase sensor	04.99-03.04	NOC	**0 232 103 050**
Speed sensor, ignition/injection	04.99-03.04	FKW	**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	04.99-03.04		**0 265 005 258**
Wheel speed sensor, front	04.99-03.04		**0 265 002 262**
55 AMG KOMPRESSOR [463]	**5,4 l 350-368 kW M 113.993 8 Zyl.**		
Air mass meter, gasoline injection	04.04→		**0 280 217 810**
Phase sensor	04.04→	NOC	**0 232 103 050**
Speed sensor, ignition/injection	04.04→	FKW	**0 261 210 170**
Knock sensor	04.04→		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	04.04→		**0 265 005 258**
200 GE [463]	**2,0 l 80 kW M 102.965 4 Zyl.**		
Air flow sensor, gasoline injection	01.90-07.93	KAT	**0 438 121 043**
			0 986 439 343
Speed sensor, ignition/injection	01.90-07.93		**0 261 210 066**
Temperature sensor, intake air, injection system	01.90-07.93		**0 280 130 047**
Acceleration sensor, ABS	01.90-07.93		**0 265 002 230**
Wheel speed sensor, rear			
Fg.no. →082464	01.90-07.93	LAB	**0 265 001 292**
		RAB	**0 265 001 290**
230 [463]	**2,3 l 93 kW M 102.989 4 Zyl.**		
Air flow sensor, gasoline injection	08.90-10.94	KAT	**0 438 121 043**
			0 986 439 343
Speed sensor, ignition/injection	08.90-10.94		**0 261 210 066**
Temperature sensor, intake air, injection system	08.90-10.94		**0 280 130 047**
Acceleration sensor, ABS	08.90-10.93		**0 265 002 230**
	11.93-10.94	4-K	**0 265 002 230**
			0 265 005 040
Wheel speed sensor, front	07.94-10.94		**0 265 002 262**
Wheel speed sensor, rear			
Fg.no. →082464	08.90-10.94	LAB	**0 265 001 292**
		RAB	**0 265 001 290**
230 G [461]	**2,3 l 66 kW M 115.974 4 Zyl.**		
Air flow sensor, gasoline injection	04.92-09.93	KAT	**0 438 121 043**
			0 986 439 343
Speed sensor, ignition/injection	04.92-09.93		**0 261 210 055**
Pulse generator, ignition/Jetronic	04.92-09.93	WW	**0 261 210 066**
230 GE [460]	**2,3 l 90-92 kW M 102.987 4 Zyl.**		
Air flow sensor, gasoline injection	03.86-08.92	KAT	**0 438 121 043**
			0 986 439 343
Speed sensor, ignition/injection	03.86-08.89		**0 261 210 014**
Temperature sensor, intake air, injection system	03.86-08.92		**0 280 130 047**
Temperature sensor, coolant, injection system	03.86-08.89		**0 280 130 044**

M

Product			
230 GE [460]			**2,3 l 92 kW M 102.987 4 Zyl.**
Air flow sensor, gasoline injection	09.85-08.89		**0 986 439 301**
			F 026 TX2 060
Temperature sensor, intake air, injection system	09.85-08.89		**0 280 130 047**
Temperature sensor, coolant, injection system	09.85-08.89		**0 280 130 042**
230 GE [461]			**2,3 l 90/92 kW M 102.979; M 102.979;996; M 102.996 4 Zyl.**
Air flow sensor, gasoline injection	04.92-09.95	KAT	**0 438 121 043**
			0 986 439 343
Speed sensor, ignition/injection	04.92-09.95		**0 261 210 066**
230 GE [461]			**2,3 l 92 kW M 102.997 4 Zyl.**
Air flow sensor, gasoline injection	04.92-09.95	KAT	**0 438 121 043**
			0 986 439 343
230 GE [463]			**2,3 l 92-95 kW M 102.989 4 Zyl.**
Air flow sensor, gasoline injection	09.89-07.93	KAT	**0 438 121 043**
			0 986 439 343
Speed sensor, ignition/injection	09.89-07.93		**0 261 210 066**
Temperature sensor, intake air, injection system	09.89-07.93		**0 280 130 047**
Acceleration sensor, ABS	09.89-07.93		**0 265 002 230**
Wheel speed sensor, rear			
Fg.no. →082464	09.89-07.93	LAB	**0 265 001 292**
		RAB	**0 265 001 290**
250 GD [463]			**2,5 l 69 kW OM 602.931 5 Zyl.**
Acceleration sensor, ABS	09.89-07.93		**0 265 002 230**
Wheel speed sensor, rear			
Fg.no. →082464	09.89-07.93	LAB	**0 265 001 292**
		RAB	**0 265 001 290**
270 CDI [463]			**2,7 l 115 kW OM 612.965 5 Zyl.**
Speed sensor, diesel	10.01→		**0 261 210 170**
High-pressure sensor (CR system)			
Mot.no. →30 287865,→40 176145, →50 846433,→60 001942	10.01→		**0 281 002 498**
Mot.no. 30 287866→,40 176146→, 50 846434→,60 001943→	10.01→		**0 281 002 700**
Duo sensor, acceleration and yaw rate, brake system	10.01→		**0 265 005 258**
280 GE [460]			**2,8 l 110-115 kW M 110.994 6 Zyl.**
Air flow sensor, gasoline injection	06.80-08.89		**0 438 120 115**
300 [463]			**3,0 l 125 kW M 103.987 6 Zyl.**
Temperature sensor, intake air, injection system	09.93-10.94		**0 280 130 047**
Acceleration sensor, ABS	09.93-10.93		**0 265 002 230**
	11.93-10.94	4-K	**0 265 002 230**
			0 265 005 040
Wheel speed sensor, front	07.94-10.94		**0 265 002 262**
Wheel speed sensor, rear			
Fg.no. →082464	09.93-10.94	LAB	**0 265 001 292**
		RAB	**0 265 001 290**
300 [463]			**3,0 l 126 kW M 103.987 6 Zyl.**
Air flow sensor, gasoline injection	08.93-10.94		**0 438 121 033**
			0 986 439 333
Temperature sensor, intake air, injection system	08.93-10.94		**0 280 130 047**
Acceleration sensor, ABS	08.93-10.93		**0 265 002 230**
	11.93-10.94	4-K	**0 265 002 230**
			0 265 005 040
Wheel speed sensor, front	07.94-10.94		**0 265 002 262**
300 D [463]			**3,0 l 83 kW OM 603.931 6 Zyl.**
Acceleration sensor, ABS	04.90-10.93		**0 265 002 230**
	11.93-10.94	4-K	**0 265 002 230**
			0 265 005 040
Wheel speed sensor, front	07.94-10.94		**0 265 002 262**
300 D Turbo [463]			**3,0 l 130 kW OM 606.964 6 Zyl.**
Pedal position sensor, diesel	09.96-11.00		**0 205 001 029**

Product			
300 GD [463]			**3,0 l 83 kW OM 603.931 6 Zyl.**
Acceleration sensor, ABS	09.89-10.93		**0 265 002 230**
Wheel speed sensor, front	07.94-07.97		**0 265 002 262**
300 GE [463]			**3,0 l 125 kW M 103.987 6 Zyl.**
Temperature sensor, intake air, injection system	08.90-08.93		**0 280 130 047**
Acceleration sensor, ABS	08.90-08.93		**0 265 002 230**
		4-K	**0 265 002 230**
Wheel speed sensor, rear			
Fg.no. →082464	08.90-08.93	LAB	**0 265 001 292**
		RAB	**0 265 001 290**
300 GE [463]			**3,0 l 126 kW M 103.987 6 Zyl.**
Air flow sensor, gasoline injection	09.89-07.93		**0 438 121 033**
			0 986 439 333
Temperature sensor, intake air, injection system	09.89-07.93		**0 280 130 047**
Acceleration sensor, ABS	09.89-07.93		**0 265 002 230**
320 [463]			**3,2 l 154 kW M 112.945 6 Zyl.**
Throttle valve assembly	06.97-11.97		**0 205 003 046**
Air mass meter, gasoline injection	06.97-11.97	FGK	**0 280 217 810**
		KUT	**0 280 218 083**
Phase sensor	06.97-11.97	NOC	**0 232 103 050**
Knock sensor	06.97-11.97		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	06.97-11.97		**0 265 005 258**
Wheel speed sensor, front	06.97-11.97		**0 265 002 262**
320 [463]			**3,2 l 155 kW M 104.996 6 Zyl.**
Air mass meter, gasoline injection	08.93-11.97		**0 280 217 500**
Speed sensor, ignition/injection	08.93-11.97		**0 261 210 122**
Wheel speed sensor, front	07.94-11.97		**0 265 002 262**
320 [463]			**3,2 l 158 kW M 112.945 6 Zyl.**
Throttle valve assembly			
Comp. no. Code 800	12.97-08.00		**0 205 003 046**
Comp. no. Code 801	09.00→		**0 280 750 019**
Air mass meter, gasoline injection	12.97→	FGK	**0 280 217 515**
		KUT	**0 280 218 082**
Phase sensor	12.97→	NOC	**0 232 103 050**
Knock sensor	12.97→		**0 261 231 110**
350 D Turbo [463]			**3,5 l 100 kW OM 603.972 6 Zyl.**
Wheel speed sensor, front	07.94-06.96		**0 265 002 262**
350 GD Turbo [463]			**3,5 l 100 kW OM 603.972 6 Zyl.**
Wheel speed sensor, front	09.91-08.93		**0 265 002 262**
400 CDI [463]			**4,0 l 184 kW OM 628.962 8 Zyl.**
Speed sensor, diesel	12.00→		**0 261 210 170**
High-pressure sensor (CR system)			
Mot.no. →40035995	12.00→		**0 281 002 498**
Mot.no. 40035996→	12.00→		**0 281 002 700**
Duo sensor, acceleration and yaw rate, brake system	12.00→		**0 265 005 258**
500 [463]			**5,0 l 218 kW M 113.962 8 Zyl.**
Throttle valve assembly			
Mot.no. →205217	04.98-09.05		**0 205 003 048**
Mot.no. 205218→	04.98-09.05		**0 280 750 017**
Air mass meter, gasoline injection	04.98-09.05	FGK	**0 280 217 810**
		KUT	**0 280 218 083**
Phase sensor	04.98-09.05	NOC	**0 232 103 050**
Speed sensor, ignition/injection	04.98-09.05	FKW	**0 261 210 170**
Knock sensor	04.98-09.05		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	06.98-09.05		**0 265 005 258**
Wheel speed sensor, front	06.99-09.05		**0 265 002 262**
500 AMG GE [463]			**5,0 l 195 kW M 117.965 8 Zyl.**
Temperature sensor, intake air, injection system	03.93-09.01		**0 280 130 047**
Acceleration sensor, ABS	03.93-10.93		**0 265 002 230**
Wheel speed sensor, front	07.94-09.01		**0 265 002 262**

M

Product			
◀ Serie G			
Wheel speed sensor, rear			
Fg.no. →082464	03.93-09.01	LAB	**0 265 001 292**
		RAB	**0 265 001 290**

Serie GL

420 CDI [164]	**4,0 l 225 kW OM 629.912 8 Zyl.**		
Phase sensor	02.06→		**0 232 103 050**
450 [164]	**4,7 l 250 kW M 273.923 8 Zyl.**		
Throttle valve assembly	02.06→		**0 280 750 184**
Air mass meter, gasoline injection	02.06→		**0 280 218 190**
Phase sensor	02.06→	LAB	**0 232 103 050**
Knock sensor	02.06→		**0 261 231 188**
500 [164]	**5,5 l 285 kW M 273.963 8 Zyl.**		
Throttle valve assembly	02.06→		**0 280 750 184**
Air mass meter, gasoline injection	02.06→		**0 280 218 190**
Phase sensor	02.06→	LAB	**0 232 103 050**
Knock sensor	02.06→		**0 261 231 188**

Serie ML

55 AMG [163]	**5,4 l 255 kW M 113.981 8 Zyl.**		
Air mass meter, gasoline injection	03.00-06.05	FGK	**0 280 217 810**
		KUT	**0 280 218 083**
Phase sensor	03.00-06.05	NOC	**0 232 103 050**
Speed sensor, ignition/injection	03.00-06.05	FKW	**0 261 210 170**
Knock sensor	03.00-06.05		**0 261 231 110**
63 AMG [164]	**6,2 l 375 kW M 156.980 8 Zyl.**		
Knock sensor	02.06→		**0 261 231 188**
230 [163]	**2,3 l 110 kW M 111.977 4 Zyl.**		
Air mass meter, gasoline injection	03.98-06.00	FGK	**0 280 217 114**
		KUT	**0 280 218 081**
Speed sensor, ignition/injection	03.98-06.00		**0 261 210 170**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A 012282	03.98-06.00		**0 205 001 302**
270 CDI [163]	**2,7 l 120 kW OM 612.963 5 Zyl.**		
Speed sensor, diesel	11.99-06.05		**0 261 210 170**
High-pressure sensor (CR system)			
Mot.no. →30 287865,→40 176145, →50 846433,→60 001942	11.99-06.05		**0 281 002 498**
Mot.no. 30 287866→,40 176146→, 50 846434→,60 001943→	11.99-06.05		**0 281 002 700**
280 CDI [164]	**3,0 l 140 kW OM 642.940 6 Zyl.**		
High-pressure sensor (CR system)	07.05→		**0 281 002 504**
320 [163]	**3,2 l 160 kW M 112.942 6 Zyl.**		
Throttle valve assembly	03.98-07.02		**0 205 003 046**
Air mass meter, gasoline injection	03.98-07.02	FGK	**0 280 217 515**
		KUT	**0 280 218 082**
Phase sensor	03.98-07.02	NOC	**0 232 103 037**
Speed sensor, ignition/injection			
Mot.no. →358406	03.98-07.02		**0 261 210 141**
Mot.no. 358407→	03.98-07.02		**0 261 210 170**
Knock sensor	03.98-07.02		**0 261 231 110**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A 012282	03.98-07.02		**0 205 001 302**
320 CDI [164]	**3,0 l 165 kW OM 642.940 6 Zyl.**		
High-pressure sensor (CR system)	07.05→		**0 281 002 504**
350 [163]	**3,7 l 173/180 kW M 112.970 6 Zyl.**		
Phase sensor	08.02-06.05		**0 232 103 050**
Speed sensor, ignition/injection	08.02-06.05		**0 261 210 170**
Knock sensor	08.02-06.05		**0 261 231 110**

Product			
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A 012282	08.02-06.05		**0 205 001 302**
350 [164]	**3,5 l 200 kW M 272.967 6 Zyl.**		
Throttle valve assembly	07.05→		**0 280 750 017**
Air mass meter, gasoline injection	07.05→		**0 280 218 190**
Phase sensor	07.05→	LAB	**0 232 103 050**
Knock sensor	07.05→		**0 261 231 188**
400 CDI [163]	**4,0 l 184 kW OM 628.963 8 Zyl.**		
Speed sensor, diesel	09.01-06.05		**0 261 210 170**
High-pressure sensor (CR system)			
Mot.no. →40035995	09.01-06.05		**0 281 002 498**
Mot.no. 40035996→	09.01-06.05		**0 281 002 700**
420 CDI [164]	**4,0 l 225 kW OM 629.912 8 Zyl.**		
Phase sensor	02.06→		**0 232 103 050**
430 [163]	**4,3 l 200 kW M 113.942 8 Zyl.**		
Air mass meter, gasoline injection	06.98-07.02	FGK	**0 280 217 810**
		KUT	**0 280 218 083**
Phase sensor	06.98-07.02	NOC	**0 232 103 050**
Speed sensor, ignition/injection	06.98-07.02	FKW	**0 261 210 170**
Knock sensor	06.98-07.02		**0 261 231 110**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A 012282	06.98-07.02		**0 205 001 302**
500 [163]	**5,0 l 215 kW M 113.965 8 Zyl.**		
Throttle valve assembly	09.01-06.05		**0 280 750 017**
Phase sensor	09.01-06.05	NOC	**0 232 103 050**
Speed sensor, ignition/injection	09.01-06.05	FKW	**0 261 210 170**
Knock sensor	09.01-06.05		**0 261 231 110**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A 012282	09.01-06.05		**0 205 001 302**
500 [164]	**5,0 l 225 kW M 113.964 8 Zyl.**		
Throttle valve assembly	07.05→		**0 280 750 017**
Air mass meter, gasoline injection	07.05→		**0 280 217 810**
Phase sensor	07.05→		**0 232 103 050**
Speed sensor, ignition/injection	07.05→		**0 261 210 170**
Knock sensor	07.05→		**0 261 231 110**

Serie R

63 AMG 4MATIC [251]	**6,2 l 375 kW M 156.980 8 Zyl.**		
Knock sensor	04.06→		**0 261 231 188**
280 [251]	**3,0 l 170 kW M 272.945 6 Zyl.**		
Throttle valve assembly	05.07→		**0 280 750 017**
Air mass meter, gasoline injection	05.07→		**0 280 218 190**
Phase sensor	05.07→	LAB	**0 232 103 050**
Knock sensor	05.07→		**0 261 231 188**
280 CDI [251]	**3,0 l 140 kW OM 642.950 6 Zyl.**		
Boost pressure sensor, Diesel	05.07→		**0 261 230 143**
280 CDI 4MATIC [251]	**3,0 l 140 kW OM 642.950 6 Zyl.**		
High-pressure sensor (CR system)	04.06→		**0 281 002 504**
Boost pressure sensor, Diesel	04.06→		**0 261 230 143**
320 CDI 4MATIC [251]	**3,0 l 165 kW OM 642.950 6 Zyl.**		
High-pressure sensor (CR system)	02.06→		**0 281 002 504**
Boost pressure sensor, Diesel	02.06→		**0 261 230 143**
350 [251]	**3,5 l 200 kW M 272.967 6 Zyl.**		
Throttle valve assembly	05.07→		**0 280 750 017**
Air mass meter, gasoline injection	05.07→		**0 280 218 190**
Phase sensor	05.07→	LAB	**0 232 103 050**
Knock sensor	05.07→		**0 261 231 188**

Product			
350 4MATIC [251]	**3,5 l 200 kW M 272.967 6 Zyl.**		
Throttle valve assembly	02.06→		**0 280 750 017**
Air mass meter, gasoline injection	02.06→		**0 280 218 190**
Phase sensor	02.06→	LAB	**0 232 103 050**
Knock sensor	02.06→		**0 261 231 188**
500 4MATIC [251]	**5,0 l 225 kW M 113.971 8 Zyl.**		
Throttle valve assembly	02.06-04.07		**0 280 750 017**
Air mass meter, gasoline injection	02.06-04.07		**0 280 217 810**
Phase sensor	02.06-04.07		**0 232 103 050**
Speed sensor, ignition/injection	02.06-04.07		**0 261 210 170**
Knock sensor	02.06-04.07		**0 261 231 110**
500 4MATIC [251]	**5,0 l 285 kW M 273.963 8 Zyl.**		
Throttle valve assembly	05.07→		**0 280 750 184**
Air mass meter, gasoline injection	05.07→		**0 280 218 190**
Phase sensor	05.07→	LAB	**0 232 103 050**
Knock sensor	05.07→		**0 261 231 188**

Serie S

CL 420 Coupé [140]	**4,2 l 205 kW M 119.971,981 8 Zyl.**		
Throttle valve assembly			
Engine type M119.981	06.96-08.99		**0 205 003 037**
Air mass meter, gasoline injection			
Mot.no. M119.981	06.96-08.99		**0 280 217 807**
Engine type M119.971	06.96-08.99		**0 280 214 004**
			0 986 280 121
Phase sensor			
Engine type M 119.981	06.96-08.99		**0 232 103 037**
Speed sensor, ignition/injection			
Engine type M 119.971	06.96-08.99		**0 261 210 055**
Engine type M 119.981	06.96-08.99		**0 281 002 123**
Knock sensor			
Engine type M 119.971	06.96-08.99		**0 261 231 054**
Engine type M 119.981	06.96-08.99		**0 261 231 110**
Temperature sensor, intake air, injection system			
Engine type M119.971	06.96-08.99		**0 280 130 047**
Pedal position sensor, EMS (electronic engine management)	06.96-08.99		**0 205 001 302**
Duo sensor, acceleration and yaw rate, brake system	06.96-08.99		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)	06.96-08.99		**0 265 005 300**
Wheel speed sensor, front	06.96-08.99	LAB	**0 265 001 410**
		RAB	**0 265 001 408**
Wheel speed sensor, rear			
Fg.no. →A212244	06.96-08.99	LAB	**0 265 002 218**
		RAB	**0 265 002 216**
CL 500 Coupé [140]	**5,0 l 235 kW M 119.970,980 8 Zyl.**		
Throttle valve assembly			
Engine type M119.980	09.96-08.99		**0 205 003 037**
Air mass meter, gasoline injection			
Mot.no. M119.980	09.96-08.99		**0 280 217 807**
Engine type M119.970	09.96-08.99		**0 280 214 004**
			0 986 280 121
Phase sensor			
Engine type M 119.980	09.96-08.99		**0 232 103 037**
Speed sensor, ignition/injection			
Engine type M 119.970	09.96-08.99		**0 261 210 055**
Engine type M 119.980	09.96-08.99		**0 281 002 123**
Knock sensor	09.96-08.99		**0 261 231 054**
Temperature sensor, intake air, injection system			
Engine type M119.970	09.96-08.99		**0 280 130 047**
Pedal position sensor, EMS (electronic engine management)	09.96-08.99		**0 205 001 302**
Duo sensor, acceleration and yaw rate, brake system	09.96-08.99		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)	09.96-08.99		**0 265 005 300**
Wheel speed sensor, front	09.96-08.99	LAB	**0 265 001 410**
		RAB	**0 265 001 408**
Wheel speed sensor, rear	09.96-08.99	OAS	**0 265 002 220**
Fg.no. →A212244	09.96-08.99	ASR,LAB	**0 265 002 218**
		ASR,RAB	**0 265 002 216**
CL 600 Coupé [140]	**6,0 l 290 kW M 120.982 12 Zyl.**		
Throttle valve assembly	06.96-08.99		**0 205 003 039**
Air mass meter, gasoline injection	06.96-08.99		**0 280 217 509**
Phase sensor	06.96-08.99	FKW	**0 281 002 123**
		NOC	**0 232 103 050**
Knock sensor	06.96-08.99		**0 261 231 110**
Pedal position sensor, EMS (electronic engine management)	06.96-08.99		**0 205 001 302**
Duo sensor, acceleration and yaw rate, brake system	06.96-08.99		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)	06.96-08.99		**0 265 005 300**
Wheel speed sensor, front	06.96-08.99	LAB	**0 265 001 410**
		RAB	**0 265 001 408**
Wheel speed sensor, rear			
Fg.no. →A212244	06.96-08.99	LAB	**0 265 002 218**
		RAB	**0 265 002 216**
55 AMG [220]	**5,4 l 265 kW 113.986 8 Zyl.**		
Air mass meter, gasoline injection	08.00-08.02		**0 280 217 810**
Phase sensor	08.00-08.02	NOC	**0 232 103 050**
Speed sensor, ignition/injection	08.00-08.02		**0 261 210 170**
Knock sensor	08.00-08.02		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. A 322444→	08.00-08.02		**0 265 005 258**
Fg.no. →A 322443	08.00-08.02		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	08.00-08.02		**0 265 005 303**
Wheel speed sensor, front	08.00-08.02		**0 265 007 002**
Wheel speed sensor, rear	08.00-08.02	FMS,LAB	**0 265 007 121**
		FMS,RAB	**0 265 007 123**
		LAB	**0 265 007 008**
		LAB,OSS	**0 265 007 008**
		OSS,RAB	**0 265 007 006**
		RAB	**0 265 007 006**
55 AMG KOMPRESSOR [220]	**5,4 l 368 kW 113.991 8 Zyl.**		
Phase sensor	09.02-08.05	NOC	**0 232 103 050**
Speed sensor, ignition/injection	09.02-08.05		**0 261 210 170**
Knock sensor	09.02-08.05		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	09.02-08.05		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	09.02-08.05		**0 265 005 303**
Wheel speed sensor, front	09.02-08.05		**0 265 007 002**
Wheel speed sensor, rear	09.02-08.05	LAB	**0 265 007 121**
		RAB	**0 265 007 123**
63 AMG [221]	**6,2 l 386 kW M 156.984 8 Zyl.**		
Knock sensor	12.06→		**0 261 231 188**
65 AMG [220]	**6,0 l 450 kW M 275.980 12 Zyl.**		
Speed sensor, ignition/injection	02.04-08.05		**0 261 210 170**
Knock sensor	02.04-08.05		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	02.04-08.05		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	02.04-08.05		**0 265 005 303**
Wheel speed sensor, front	02.04-08.05		**0 265 007 128**

M

Product			
◀ Serie S			
Wheel speed sensor, rear	02.04-08.05	FMS,LAB	**0 265 007 121**
		FMS,RAB	**0 265 007 123**
		LAB,OSS	**0 265 007 008**
		OSS,RAB	**0 265 007 006**
65 AMG [221]	**6,0 l 450 kW M 275.982 12 Zyl.**		
Speed sensor, ignition/injection	07.06→		**0 261 210 170**
Knock sensor	07.06→		**0 261 231 110**
260 SE [126]	**2,6 l 118-122 kW M 103.941 6 Zyl.**		
Air flow sensor, gasoline injection	09.85-06.91		**0 438 121 033**
			0 986 439 333
Temperature sensor, intake air, injection system	09.85-06.91		**0 280 130 047**
Temperature sensor, coolant, injection system			
Mot.no. →004196	09.85-06.91	2PO,GS	**0 280 130 044**
Mot.no. →013693	09.85-06.91	2PO,AG	**0 280 130 044**
Wheel speed sensor, front	09.85-08.89	ABS,LAB	**0 265 001 021**
		ABS,RAB	**0 265 001 020**
	09.89-06.91	LAB	**0 265 001 280**
		RAB	**0 265 001 278**
Wheel speed sensor, rear	09.85-06.91		**0 265 002 258**
		ASR	**0 265 002 260**
280 [140]	**2,8 l 142-145 kW M 104.944 6 Zyl.**		
Throttle valve assembly			
Mot.no. 001152→,Comp. no. Code 807	06.93-09.98	ASR,HMG	**0 205 003 042**
Mot.no. 017173→,Comp. no. Code 807	06.93-09.98	ASR,GMG	**0 205 003 042**
Air mass meter, gasoline injection			
Mot.no. →001151,~~Comp. no. Code 807~~	06.93-09.98	GS	**0 280 217 500**
Mot.no. →017172,~~Comp. no. Code 807~~	06.93-09.98	AG	**0 280 217 500**
Mot.no. 001152→,Comp. no. Code 807	06.93-09.98	GS	**0 280 217 517**
Mot.no. 017173→,Comp. no. Code 807	06.93-09.98	AG	**0 280 217 517**
Speed sensor, ignition/injection	06.93-09.98		**0 261 210 122**
Pedal position sensor, EMS (electronic engine management)	06.93-09.98	RLE	**0 205 001 302**
Wheel speed sensor, front	06.93-09.98	LAB	**0 265 001 410**
		RAB	**0 265 001 408**
Wheel speed sensor, rear	06.93-09.98	OAS	**0 265 002 220**
Fg.no. →A212244	06.93-09.98	ASR,LAB	**0 265 002 218**
		ASR,RAB	**0 265 002 234**
280 [220]	**2,8 l 150 kW M 112.922 6 Zyl.**		
Throttle valve assembly	01.99-08.02		**0 205 003 046**
Air mass meter, gasoline injection	01.99-08.05		**0 280 217 515**
Phase sensor	01.99-08.05		**0 232 103 050**
Speed sensor, ignition/injection	01.99-08.05		**0 261 210 170**
Knock sensor	01.99-08.05		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	01.99-08.05		**0 265 005 258**
Fg.no. A 138351→A 322443	01.99-08.02		**0 265 005 258**
Fg.no. A 322444→	01.99-08.02		**0 265 005 258**
Fg.no. →A 138350	01.99-08.02		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)	01.99-08.05		**0 265 005 303**
Wheel speed sensor, front	01.99-08.05		**0 265 007 002**
Wheel speed sensor, rear	01.99-08.05	LAB	**0 265 007 008**
		RAB	**0 265 007 006**
300 D Turbo [140]	**3,0 l 130 kW OM 606.961 6 Zyl.**		
Speed sensor, diesel	06.96-09.98		**0 281 002 123**
Pedal position sensor, diesel	06.96-09.98		**0 205 001 029**
Wheel speed sensor, front	06.96-09.98	LAB	**0 265 001 410**
		RAB	**0 265 001 408**
300 SD Turbo [140]	**3,5 l 100-110 kW OM 603.971 6 Zyl.**		
Air flow sensor, diesel	07.91-05.93		**0 281 002 077**
Pressure sensor, intake manifold, diesel	07.91-05.93		**0 281 002 059**
Temperature sensor, coolant, diesel	07.91-05.93		**0 280 130 035**
Wheel speed sensor, front	07.91-05.93	LAB	**0 265 001 410**
		RAB	**0 265 001 408**

Product			
Wheel speed sensor, rear			
Fg.no. A212245→	07.91-05.93	OAS	**0 265 002 248**
Fg.no. →A212244	07.91-05.93	OAS	**0 265 002 220**
300 SDL Turbo [126]	**3,0 l 107-110 kW OM 603.961 6 Zyl.**		
Air flow sensor, diesel	11.85-12.87		**0 281 002 024**
			0 281 002 028
Wheel speed sensor, front	11.85-12.87	ABS,LAB	**0 265 001 021**
		ABS,RAB	**0 265 001 020**
300 SE [126]	**3,0 l 132-138 kW M 103.981 6 Zyl.**		
Air flow sensor, gasoline injection	09.85-06.91		**0 438 121 033**
			0 986 439 333
Pressure sensor, intake manifold, gasoline	09.85-06.91		**0 280 101 003**
Temperature sensor, intake air, injection system	09.85-06.91		**0 280 130 047**
Temperature sensor, coolant, injection system	09.85-06.91	2PO	**0 280 130 044**
Wheel speed sensor, front	09.85-08.89	ABS,LAB	**0 265 001 021**
	09.89-06.91	LAB	**0 265 001 280**
Wheel speed sensor, rear	09.85-06.91		**0 265 002 258**
300 SE [140]	**3,2 l 170 kW M 104.994 6 Zyl.**		
Throttle valve assembly			
Mot.no. 073223→	03.91-04.93	ASR,LLE	**0 205 003 042**
Air mass meter, gasoline injection			
Mot.no. →073222,~~Comp. no. Code 807~~	03.91-04.93		**0 280 217 500**
Mot.no. 073223→,Comp. no. Code 807	03.91-04.93		**0 280 217 517**
Pedal position sensor, EMS (electronic engine management)	03.91-04.93	RLE	**0 205 001 302**
Wheel speed sensor, front	03.91-04.93	LAB	**0 265 001 410**
		RAB	**0 265 001 408**
Wheel speed sensor, rear	03.91-04.93	OAS	**0 265 002 220**
Fg.no. →A212244	03.91-04.93	ASR,LAB	**0 265 002 218**
		ASR,RAB	**0 265 002 234**
300 SE, SEL [126]	**3,0 l 132-138 kW M 103.981 6 Zyl.**		
Air flow sensor, gasoline injection	09.85-06.91		**0 438 121 033**
			0 986 439 333
Temperature sensor, intake air, injection system	09.85-06.91		**0 280 130 047**
Temperature sensor, coolant, injection system	09.85-06.91	2PO	**0 280 130 044**
Wheel speed sensor, front	09.85-08.89	ABS,LAB	**0 265 001 021**
		ABS,RAB	**0 265 001 020**
	09.89-06.91	LAB	**0 265 001 280**
		RAB	**0 265 001 278**
Wheel speed sensor, rear	09.85-06.91		**0 265 002 258**
300 SE, SEL [126]	**3,0 l 138 kW M 103.981 6 Zyl.**		
Air flow sensor, gasoline injection	12.85-08.87		**0 438 121 033**
			0 986 439 333
Temperature sensor, intake air, injection system	12.85-08.87		**0 280 130 047**
Temperature sensor, coolant, injection system	12.85-08.87	2PO	**0 280 130 044**
Wheel speed sensor, front	12.85-08.87	ABS,LAB	**0 265 001 021**
		ABS,RAB	**0 265 001 020**
300 SE 2.8 [140]	**2,8 l 142-145 kW M 104.944 6 Zyl.**		
Throttle valve assembly			
Mot.no. 001152→,Comp. no. Code 807	09.92-05.93	ASR,HMG	**0 205 003 042**
Mot.no. 017173→,Comp. no. Code 807	09.92-05.93	ASR,GMG	**0 205 003 042**
Air mass meter, gasoline injection			
Mot.no. →001151,~~Comp. no. Code 807~~	09.92-05.93	GS	**0 280 217 500**
Mot.no. →017172,~~Comp. no. Code 807~~	09.92-05.93	AG	**0 280 217 500**
Mot.no. 001152→,Comp. no. Code 807	09.92-05.93	GS	**0 280 217 517**
Mot.no. 017173→,Comp. no. Code 807	09.92-05.93	AG	**0 280 217 517**
Speed sensor, ignition/injection	09.92-05.93		**0 261 210 122**
Pedal position sensor, EMS (electronic engine management)	09.92-05.93	RLE	**0 205 001 302**
Wheel speed sensor, front	09.92-05.93	LAB	**0 265 001 410**
		RAB	**0 265 001 408**

Product			
Wheel speed sensor, rear	09.92-05.93	OAS	**0 265 002 220**
Fg.no. →A212244	09.92-05.93	ASR,LAB	**0 265 002 218**
		ASR,RAB	**0 265 002 234**
300 SEL [126]	**3,0 l 132 kW M 103.981 6 Zyl.**		
Air flow sensor, gasoline injection	09.85-06.91		**0 438 121 033**
			0 986 439 333
Pressure sensor, intake manifold, gasoline	09.85-06.91		**0 280 101 003**
Temperature sensor, intake air, injection system	09.85-06.91		**0 280 130 047**
Temperature sensor, coolant, injection system	09.85-06.91	2PO	**0 280 130 044**
Wheel speed sensor, front	09.85-08.89	ABS,LAB	**0 265 001 021**
		ABS,RAB	**0 265 001 020**
	09.89-06.91	LAB	**0 265 001 280**
		RAB	**0 265 001 278**
Wheel speed sensor, rear	09.89-06.91		**0 265 002 258**
300 SEL 3.2 [140]	**3,2 l 170 kW M 104.990 6 Zyl.**		
Air mass meter, gasoline injection	03.91-05.93		**0 280 213 018**
			0 986 280 125
Knock sensor	03.91-05.93		**0 261 231 056**
Temperature sensor, intake air, injection system	03.91-05.93		**0 280 130 047**
Pedal position sensor, EMS (electronic engine management)	03.91-05.93	RLE	**0 205 001 302**
Wheel speed sensor, front	03.91-05.93	LAB	**0 265 001 410**
		RAB	**0 265 001 408**
Wheel speed sensor, rear	03.91-05.93	OAS	**0 265 002 220**
Fg.no. →A212244	03.91-05.93	ASR,LAB	**0 265 002 218**
		ASR,RAB	**0 265 002 234**
320 [140]	**3,2 l 170 kW M 104.990 6 Zyl.**		
Air mass meter, gasoline injection	03.93-09.98		**0 280 213 018**
			0 986 280 125
Knock sensor	03.93-09.98		**0 261 231 056**
Temperature sensor, intake air, injection system	03.93-09.98		**0 280 130 047**
Pedal position sensor, EMS (electronic engine management)	03.93-09.98	RLE	**0 205 001 302**
Wheel speed sensor, front	03.93-09.98	LAB	**0 265 001 410**
		RAB	**0 265 001 408**
Wheel speed sensor, rear	03.93-09.98	OAS	**0 265 002 220**
Fg.no. →A212244	03.93-09.98	ASR,LAB	**0 265 002 218**
		ASR,RAB	**0 265 002 234**
320 [140]	**3,2 l 170 kW M 104.994 6 Zyl.**		
Throttle valve assembly			
Mot.no. 073223→	05.93-09.98	ASR,LLE	**0 205 003 042**
Air mass meter, gasoline injection			
Mot.no. →073222,~~Comp. no. Code 807~~	05.93-09.98		**0 280 217 500**
Mot.no. 073223→,Comp. no. Code 807	05.93-09.98		**0 280 217 517**
Pedal position sensor, EMS (electronic engine management)	05.93-09.98	RLE	**0 205 001 302**
Wheel speed sensor, front	05.93-09.98	LAB	**0 265 001 410**
		RAB	**0 265 001 408**
Wheel speed sensor, rear	05.93-09.98	OAS	**0 265 002 220**
Fg.no. →A212244	05.93-09.98	ASR,LAB	**0 265 002 218**
		ASR,RAB	**0 265 002 234**
320 [220]	**3,2 l 165 kW M 112.944 6 Zyl.**		
Throttle valve assembly	10.98-08.02		**0 205 003 046**
Air mass meter, gasoline injection	10.98-08.02		**0 280 217 515**
Phase sensor	10.98-08.02		**0 232 103 050**
Speed sensor, ignition/injection	10.98-08.02		**0 261 210 170**
Knock sensor	10.98-08.02		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. A 138351→A 322443	10.98-08.02		**0 265 005 258**
Fg.no. A 322444→	10.98-08.02		**0 265 005 258**
Fg.no. →A 138350	10.98-08.02		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)	10.98-08.02		**0 265 005 303**

Product			
Wheel speed sensor, front	10.98-08.02		**0 265 007 002**
Wheel speed sensor, rear	10.98-08.02	FMS,LAB	**0 265 007 121**
		FMS,RAB	**0 265 007 123**
		LAB	**0 265 007 008**
		LAB,OSS	**0 265 007 008**
		OSS,RAB	**0 265 007 006**
		RAB	**0 265 007 006**
320 CDI [220]	**3,2 l 145 kW OM 613.960 6 Zyl.**		
Speed sensor, diesel	06.99-08.02		**0 261 210 170**
High-pressure sensor (CR system)	06.99-08.02		**0 281 002 498**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. A 322444→	06.99-08.02		**0 265 005 258**
Fg.no. →A 322443	06.99-08.02		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	06.99-08.02		**0 265 005 303**
Wheel speed sensor, front	06.99-08.02		**0 265 007 002**
Wheel speed sensor, rear	06.99-08.02	FMS,LAB	**0 265 007 121**
		FMS,RAB	**0 265 007 123**
		LAB	**0 265 007 008**
		LAB,OSS	**0 265 007 008**
		OSS,RAB	**0 265 007 006**
		RAB	**0 265 007 006**
320 CDI [220]	**3,2 l 150 kW OM 648.960 6 Zyl.**		
Air mass meter, diesel	09.02-08.05		**0 281 002 535**
Speed sensor, diesel	09.02-08.05		**0 261 210 170**
High-pressure sensor (CR system)	09.02-08.05		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	09.02-08.05		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	09.02-08.05		**0 265 005 303**
Wheel speed sensor, front	09.02-08.05		**0 265 007 002**
Wheel speed sensor, rear	09.02-08.05	FMS,LAB	**0 265 007 121**
		FMS,RAB	**0 265 007 123**
		LAB	**0 265 007 008**
		LAB,OSS	**0 265 007 008**
		OSS,RAB	**0 265 007 006**
		RAB	**0 265 007 006**
320 CDI [221]	**3,0 l 173 kW OM 642.930 6 Zyl.**		
High-pressure sensor (CR system)	12.05→		**0 281 002 504**
350 [220]	**3,7 l 180 kW M 112.972 6 Zyl.**		
Air mass meter, gasoline injection	09.02-08.05		**0 280 217 515**
Phase sensor	09.02-08.05	NOC	**0 232 103 050**
Speed sensor, ignition/injection	09.02-08.05		**0 261 210 170**
Knock sensor	09.02-08.05		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	09.02-08.05		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	09.02-08.05		**0 265 005 303**
Wheel speed sensor, front	09.02-08.05		**0 265 007 002**
Wheel speed sensor, rear	09.02-08.05	FMS,LAB	**0 265 007 121**
		FMS,RAB	**0 265 007 123**
		LAB	**0 265 007 008**
		LAB,OSS	**0 265 007 008**
		OSS,RAB	**0 265 007 006**
		RAB	**0 265 007 006**
350 [221]	**3,5 l 200 kW M 272.965 6 Zyl.**		
Throttle valve assembly	09.05→		**0 280 750 017**
Air mass meter, gasoline injection	09.05→		**0 280 218 190**
Phase sensor	09.05→	LAB	**0 232 103 050**
Knock sensor	09.05→		**0 261 231 188**
350 D Turbo [140]	**3,5 l 100-110 kW OM 603.971 6 Zyl.**		
Air flow sensor, diesel	06.93-06.96		**0 281 002 077**
Pressure sensor, intake manifold, diesel	06.93-06.96		**0 281 002 059**
Temperature sensor, coolant, diesel	06.93-06.96		**0 280 130 035**

M

Product			
◀ Serie S			
Wheel speed sensor, front	06.93-06.96	LAB	**0 265 001 410**
		RAB	**0 265 001 408**
Wheel speed sensor, rear			
Fg.no. A212245→	06.93-06.96	OAS	**0 265 002 248**
Fg.no. →A212244	06.93-06.96	OAS	**0 265 002 220**
350 SDL Turbo [126]	**3,5 l 100 kW OM 603.970 6 Zyl.**		
Air flow sensor, diesel	03.90-06.91		**0 281 002 024**
			0 281 002 028
Pressure sensor, intake manifold, diesel	03.90-06.91		**0 281 002 059**
Temperature sensor, coolant, diesel	03.90-06.91		**0 280 130 035**
Wheel speed sensor, front	03.90-06.91	LAB	**0 265 001 280**
		RAB	**0 265 001 278**
Wheel speed sensor, rear	03.90-06.91		**0 265 002 258**
350 4MATIC [220]	**3,7 l 180 kW M 112.975 6 Zyl.**		
Air mass meter, gasoline injection	06.03-08.05		**0 280 217 515**
Phase sensor	06.03-08.05	NOC	**0 232 103 050**
Speed sensor, ignition/injection	06.03-08.05		**0 261 210 170**
Knock sensor	06.03-08.05		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	06.03-08.05		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	06.03-08.05		**0 265 005 303**
Wheel speed sensor, rear	06.03-08.05	LAB	**0 265 007 008**
		RAB	**0 265 007 006**
400 CDI [220]	**4,0 l 184/191 kW OM 628.960 8 Zyl.**		
Speed sensor, diesel	06.99-08.05		**0 261 210 170**
High-pressure sensor (CR system)	06.99-08.05		**0 281 002 498**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. A 322444→	06.99-08.05		**0 265 005 258**
Fg.no. →A 322443	06.99-08.05		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	06.99-08.05		**0 265 005 303**
Wheel speed sensor, front	06.99-08.05		**0 265 007 002**
Wheel speed sensor, rear	06.99-08.05	FMS,LAB	**0 265 007 121**
		FMS,RAB	**0 265 007 123**
		LAB	**0 265 007 008**
		LAB,OSS	**0 265 007 008**
		OSS,RAB	**0 265 007 006**
		RAB	**0 265 007 006**
400 SE [140]	**4,2 l 205-210 kW M 119.971;981 8 Zyl.**		
Throttle valve assembly			
Engine type M119.981	02.91-05.93		**0 205 003 037**
Air mass meter, gasoline injection	02.91-05.93		**0 280 214 004**
			0 986 280 121
Speed sensor, ignition/injection	02.91-05.93		**0 261 210 055**
Knock sensor	02.91-05.93		**0 261 231 054**
Temperature sensor, intake air, injection system	02.91-05.93		**0 280 130 047**
Pedal position sensor, EMS (electronic engine management)	02.91-05.93		**0 205 001 302**
Acceleration sensor, ABS	02.91-05.93		**0 265 005 107**
Wheel speed sensor, front	02.91-05.93	LAB	**0 265 001 410**
		RAB	**0 265 001 408**
Wheel speed sensor, rear	02.91-05.93	OAS	**0 265 002 220**
Fg.no. →A212244	02.91-05.93	ASR,LAB	**0 265 002 218**
		ASR,RAB	**0 265 002 234**
400 SEL [140]	**4,2 l 205-210 kW M 119.971;981 8 Zyl.**		
Throttle valve assembly			
Engine type M119.981	06.93-08.95		**0 205 003 037**
Air mass meter, gasoline injection			
Mot.no. M119.981	06.93-08.95		**0 280 217 807**
Engine type M119.971	06.93-08.95		**0 280 214 004**
			0 986 280 121
Speed sensor, ignition/injection	06.93-08.95		**0 261 210 055**
Knock sensor	06.93-08.95		**0 261 231 054**

Product			
Temperature sensor, intake air, injection system			
Engine type M119.971	06.93-08.95		**0 280 130 047**
Pedal position sensor, EMS (electronic engine management)	06.93-08.95		**0 205 001 302**
Wheel speed sensor, front	06.93-08.95	LAB	**0 265 001 410**
		RAB	**0 265 001 408**
Wheel speed sensor, rear	06.93-08.95	OAS	**0 265 002 220**
Fg.no. →A212244	06.93-08.95	ASR,LAB	**0 265 002 218**
		ASR,RAB	**0 265 002 234**
420 [140]	**4,2 l 205-210 kW M 119.971;981 8 Zyl.**		
Throttle valve assembly			
Engine type M119.981	06.93-09.98		**0 205 003 037**
Air mass meter, gasoline injection	06.93-09.98		**0 280 214 004**
			0 986 280 121
Speed sensor, ignition/injection	06.93-09.98		**0 261 210 055**
Knock sensor	06.93-09.98		**0 261 231 054**
Temperature sensor, intake air, injection system	06.93-09.98		**0 280 130 047**
Pedal position sensor, EMS (electronic engine management)	06.93-09.98		**0 205 001 302**
Acceleration sensor, ABS	06.93-05.94		**0 265 005 107**
	06.94-09.98		**0 265 005 107**
Wheel speed sensor, front	06.93-09.98	LAB	**0 265 001 410**
		RAB	**0 265 001 408**
Wheel speed sensor, rear	06.93-09.98	OAS	**0 265 002 220**
Fg.no. →A212244	06.93-09.98	ASR,LAB	**0 265 002 218**
		ASR,RAB	**0 265 002 234**
420 [140]	**4,2 l 210 kW M 119.971;981 8 Zyl.**		
Throttle valve assembly			
Engine type M119.981	09.95-09.98		**0 205 003 037**
Air mass meter, gasoline injection			
Mot.no. M119.981	09.95-09.98		**0 280 217 807**
Engine type M119.971	09.95-09.98		**0 280 214 004**
			0 986 280 121
Phase sensor	09.95-09.98		**0 232 103 037**
Speed sensor, ignition/injection	09.95-09.98		**0 281 002 123**
Knock sensor	09.95-09.98		**0 261 231 110**
Temperature sensor, intake air, injection system			
Engine type M119.971	09.95-09.98		**0 280 130 047**
Pedal position sensor, EMS (electronic engine management)	09.95-09.98		**0 205 001 302**
Duo sensor, acceleration and yaw rate, brake system	09.95-09.98		**0 265 005 201**
Wheel speed sensor, front	09.95-09.98	LAB	**0 265 001 410**
		RAB	**0 265 001 408**
Wheel speed sensor, rear	09.95-09.98	OAS	**0 265 002 220**
Fg.no. →A212244	09.95-09.98	ASR,LAB	**0 265 002 218**
		ASR,RAB	**0 265 002 234**
420 CDI [221]	**4,0 l 235 kW OM 629.911 8 Zyl.**		
Phase sensor	12.06→		**0 232 103 050**
420 Coupé [140]	**4,2 l 205-210 kW M 119.971;981 8 Zyl.**		
Throttle valve assembly			
Engine type M119.981	03.94-05.96		**0 205 003 037**
Air mass meter, gasoline injection			
Mot.no. M119.981	03.94-05.96		**0 280 217 807**
Engine type M119.971	03.94-05.96		**0 280 214 004**
			0 986 280 121
Speed sensor, ignition/injection	03.94-05.96		**0 261 210 055**
Knock sensor	03.94-05.96		**0 261 231 054**
Temperature sensor, intake air, injection system			
Engine type M119.971	03.94-05.96		**0 280 130 047**
Pedal position sensor, EMS (electronic engine management)	03.94-05.96		**0 205 001 302**

Product			
Duo sensor, acceleration and yaw rate, brake system	05.95-05.96		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)	05.95-05.96		**0 265 005 300**
Wheel speed sensor, front	03.94-05.96	LAB	**0 265 001 410**
		RAB	**0 265 001 408**
Wheel speed sensor, rear			
Fg.no. →A212244	03.94-05.96	LAB	**0 265 002 218**
		RAB	**0 265 002 216**
420 SE, SEL [126]	**4,2 l 150 kW M 116.965 8 Zyl.**		
Air flow sensor, gasoline injection	12.85-12.86		**0 438 121 037**
			0 986 439 337
Temperature sensor, intake air, injection system	12.85-12.86		**0 280 130 047**
Temperature sensor, coolant, injection system	12.85-12.86		**0 280 130 044**
Wheel speed sensor, front	12.85-12.86	ABS,LAB	**0 265 001 021**
		ABS,RAB	**0 265 001 020**
420 SE, SEL [126]	**4,2 l 150-170 kW M 116.965 8 Zyl.**		
Air flow sensor, gasoline injection	09.85-06.91		**0 438 121 037**
			0 986 439 337
Knock sensor	09.88-06.91		**0 261 231 009**
Temperature sensor, intake air, injection system	09.85-06.91		**0 280 130 047**
Temperature sensor, coolant, injection system	09.85-08.87		**0 280 130 044**
Wheel speed sensor, front	09.85-08.89	ABS,LAB	**0 265 001 021**
		ABS,RAB	**0 265 001 020**
	09.89-06.91	LAB	**0 265 001 280**
		RAB	**0 265 001 278**
Wheel speed sensor, rear	09.85-06.91		**0 265 002 258**
	09.87-06.91	ASR,LAB	**0 265 002 029**
		ASR,RAB	**0 265 002 027**
420 SEC [126]	**4,2 l 150-170 kW M 116.965 8 Zyl.**		
Air flow sensor, gasoline injection	10.85-06.91		**0 438 121 037**
			0 986 439 337
Knock sensor	09.88-06.91		**0 261 231 009**
Temperature sensor, intake air, injection system	10.85-06.91		**0 280 130 047**
Temperature sensor, coolant, injection system	10.85-08.87		**0 280 130 044**
Wheel speed sensor, front	10.85-08.89	ABS,LAB	**0 265 001 021**
		ABS,RAB	**0 265 001 020**
	09.89-06.91	LAB	**0 265 001 280**
		RAB	**0 265 001 278**
Wheel speed sensor, rear	10.85-06.91		**0 265 002 258**
	09.87-06.91	ASR,LAB	**0 265 002 029**
		ASR,RAB	**0 265 002 027**
420 SEL [126]	**4,2 l 150 kW M 116.965 8 Zyl.**		
Air flow sensor, gasoline injection	09.85-06.91		**0 438 121 037**
			0 986 439 337
Pressure sensor, intake manifold, gasoline	09.85-06.91		**0 280 101 003**
Temperature sensor, intake air, injection system	09.85-06.91		**0 280 130 047**
Temperature sensor, coolant, injection system	09.85-08.87		**0 280 130 044**
Wheel speed sensor, front	09.85-08.89	ABS,LAB	**0 265 001 021**
		ABS,RAB	**0 265 001 020**
	09.89-06.91	LAB	**0 265 001 280**
		RAB	**0 265 001 278**
Wheel speed sensor, rear	09.85-06.91		**0 265 002 258**
	09.87-06.91	ASR,LAB	**0 265 002 029**
		ASR,RAB	**0 265 002 027**
430 [220]	**4,3 l 205 kW M 113.941 8 Zyl.**		
Throttle valve assembly	10.98-08.05		**0 205 003 048**
Air mass meter, gasoline injection	10.98-08.05		**0 280 217 810**
Phase sensor	10.98-08.05	NOC	**0 232 103 050**
Speed sensor, ignition/injection	10.98-08.05	FKW	**0 261 210 170**
Knock sensor	10.98-08.05		**0 261 231 110**

Product			
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. A 138351→A 322443	10.98-08.05		**0 265 005 258**
Fg.no. A 322444→	10.98-08.05		**0 265 005 258**
Fg.no. →A 138350	10.98-08.05		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)	10.98-08.05		**0 265 005 303**
Wheel speed sensor, front	10.98-08.05		**0 265 007 002**
Wheel speed sensor, rear	10.98-08.05	FMS,LAB	**0 265 007 121**
		FMS,RAB	**0 265 007 123**
		LAB	**0 265 007 008**
		LAB,OSS	**0 265 007 008**
		OSS,RAB	**0 265 007 006**
		RAB	**0 265 007 006**
430 4MATIC [220]	**4,3 l 205 kW M 113.948 8 Zyl.**		
Air mass meter, gasoline injection	09.02-08.05		**0 280 217 810**
Phase sensor	09.02-08.05	NOC	**0 232 103 050**
Speed sensor, ignition/injection	09.02-08.05	FKW	**0 261 210 170**
Knock sensor	09.02-08.05		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	09.02-08.05		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	09.02-08.05		**0 265 005 303**
Wheel speed sensor, rear	09.02-08.05	FMS,LAB	**0 265 007 121**
		FMS,RAB	**0 265 007 123**
		LAB	**0 265 007 008**
		LAB,OSS	**0 265 007 008**
		OSS,RAB	**0 265 007 006**
		RAB	**0 265 007 006**
450 , 4MATIC [221]	**4,7 l 250 kW M 273.922 8 Zyl.**		
Throttle valve assembly	06.06→		**0 280 750 184**
Air mass meter, gasoline injection	06.06→		**0 280 218 190**
Phase sensor	06.06→	LAB	**0 232 103 050**
Knock sensor	06.06→		**0 261 231 188**
500 [140]	**5,0 l 235-240 kW M 119.970;980 8 Zyl.**		
Throttle valve assembly			
Engine type M119.980	06.93-09.98		**0 205 003 037**
Air mass meter, gasoline injection			
Mot.no. M119.980	06.93-09.98		**0 280 217 807**
Engine type M119.970	06.93-09.98		**0 280 214 004**
			0 986 280 121
Speed sensor, ignition/injection	06.93-09.98		**0 261 210 055**
Knock sensor	06.93-09.98		**0 261 231 054**
Temperature sensor, intake air, injection system			
Engine type M119.970	06.93-09.98		**0 280 130 047**
Pedal position sensor, EMS (electronic engine management)	06.93-09.98		**0 205 001 302**
Acceleration sensor, ABS	06.94-09.98		**0 265 005 107**
Wheel speed sensor, front	06.93-09.98	LAB	**0 265 001 410**
		RAB	**0 265 001 408**
Wheel speed sensor, rear	06.93-09.98	OAS	**0 265 002 220**
Fg.no. →A212244	06.93-09.98	ASR,LAB	**0 265 002 218**
		ASR,RAB	**0 265 002 234**
500 [220]	**5,0 l 225 kW M 113.960 8 Zyl.**		
Throttle valve assembly	10.98-08.05		**0 205 003 048**
Air mass meter, gasoline injection	10.98-08.05		**0 280 217 810**
Phase sensor	10.98-08.05	NOC	**0 232 103 050**
Speed sensor, ignition/injection	10.98-08.05	FKW	**0 261 210 170**
Knock sensor	10.98-08.05		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. A 138351→A 322443	10.98-08.05		**0 265 005 258**
Fg.no. A 322444→	10.98-08.05		**0 265 005 258**
Fg.no. →A 138350	10.98-08.05		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)	10.98-08.05		**0 265 005 303**

M

Product			
◀ Serie S			
Wheel speed sensor, front	10.98-08.05		**0 265 007 002**
Wheel speed sensor, rear	10.98-08.05	FMS,LAB	**0 265 007 121**
		FMS,RAB	**0 265 007 123**
		LAB	**0 265 007 008**
		LAB,OSS	**0 265 007 008**
		OSS,RAB	**0 265 007 006**
		RAB	**0 265 007 006**
500 [221]	**5,5 l 285 kW M 273.961 8 Zyl.**		
Throttle valve assembly	09.05→		**0 280 750 184**
Air mass meter, gasoline injection	09.05→		**0 280 218 190**
Phase sensor	09.05→	LAB	**0 232 103 050**
Knock sensor	09.05→		**0 261 231 188**
500 Coupé [140]	**5,0 l 235-240 kW M 119.970;980 8 Zyl.**		
Throttle valve assembly			
Engine type M119.980	06.93-08.96		**0 205 003 037**
Air mass meter, gasoline injection			
Mot.no. M119.980	06.93-08.96		**0 280 217 807**
Engine type M119.970	06.93-08.96		**0 280 214 004**
			0 986 280 121
Speed sensor, ignition/injection	06.93-08.96		**0 261 210 055**
Knock sensor	06.93-08.96		**0 261 231 054**
Temperature sensor, intake air, injection system			
Engine type M119.970	06.93-08.96		**0 280 130 047**
Pedal position sensor, EMS (electronic engine management)	06.93-08.96		**0 205 001 302**
Duo sensor, acceleration and yaw rate, brake system	05.95-08.96		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)	05.95-08.96		**0 265 005 300**
Wheel speed sensor, front	06.93-08.96	LAB	**0 265 001 410**
		RAB	**0 265 001 408**
Wheel speed sensor, rear	06.93-08.96	OAS	**0 265 002 220**
Fg.no. →A212244	06.93-08.96	ASR,LAB	**0 265 002 218**
		ASR,RAB	**0 265 002 216**
500 SE [140]	**5,0 l 235-240 kW M 119.970;980 8 Zyl.**		
Throttle valve assembly			
Engine type M119.980	02.91-05.93		**0 205 003 037**
Air mass meter, gasoline injection			
Mot.no. M119.980	02.91-05.93		**0 280 217 807**
Engine type M119.970	02.91-05.93		**0 280 214 004**
			0 986 280 121
Speed sensor, ignition/injection	02.91-05.93		**0 261 210 055**
Knock sensor	02.91-05.93		**0 261 231 054**
Temperature sensor, intake air, injection system			
Engine type M119.970	02.91-05.93		**0 280 130 047**
Pedal position sensor, EMS (electronic engine management)	02.91-05.93		**0 205 001 302**
Acceleration sensor, ABS	02.91-05.93		**0 265 005 107**
Wheel speed sensor, front	02.91-05.93	LAB	**0 265 001 410**
		RAB	**0 265 001 408**
Wheel speed sensor, rear	02.91-05.93	OAS	**0 265 002 220**
Fg.no. →A212244	02.91-05.93	ASR,LAB	**0 265 002 218**
		ASR,RAB	**0 265 002 234**
500 SE, SEL, SEC [126]	**5,0 l 164-195 kW M 117.965 8 Zyl.**		
Air flow sensor, gasoline injection	09.85-06.91		**0 438 121 037**
			0 986 439 337
Speed sensor, ignition/injection	09.85-06.91		**0 261 210 022**
Knock sensor	09.88-06.91		**0 261 231 009**
Temperature sensor, intake air, injection system	09.85-06.91		**0 280 130 047**
Temperature sensor, coolant, injection system	09.85-08.87		**0 280 130 044**
Wheel speed sensor, front	09.85-08.89	ABS,LAB	**0 265 001 021**
		ABS,RAB	**0 265 001 020**
	09.89-06.91	LAB	**0 265 001 280**
		RAB	**0 265 001 278**

Product			
Wheel speed sensor, rear	09.85-06.91		**0 265 002 258**
	09.87-06.91	ASR,LAB	**0 265 002 029**
		ASR,RAB	**0 265 002 027**
500 SEC [140]	**5,0 l 235-240 kW M 119.970;980 8 Zyl.**		
Throttle valve assembly			
Engine type M119.980	10.92-05.93		**0 205 003 037**
Air mass meter, gasoline injection			
Mot.no. M119.980	10.92-05.93		**0 280 217 807**
Engine type M119.970	10.92-05.93		**0 280 214 004**
			0 986 280 121
Speed sensor, ignition/injection	10.92-05.93		**0 261 210 055**
Knock sensor	10.92-05.93		**0 261 231 054**
Temperature sensor, intake air, injection system			
Engine type M119.970	10.92-05.93		**0 280 130 047**
Pedal position sensor, EMS (electronic engine management)	10.92-05.93		**0 205 001 302**
Wheel speed sensor, front	10.92-05.93	LAB	**0 265 001 410**
		RAB	**0 265 001 408**
Wheel speed sensor, rear	10.92-05.93	OAS	**0 265 002 220**
Fg.no. →A212244	10.92-05.93	ASR,LAB	**0 265 002 218**
		ASR,RAB	**0 265 002 216**
500 4MATIC [220]	**5,0 l 225 kW M 113.966 8 Zyl.**		
Air mass meter, gasoline injection	09.02-08.05		**0 280 217 810**
Phase sensor	09.02-08.05	NOC	**0 232 103 050**
Speed sensor, ignition/injection	09.02-08.05	FKW	**0 261 210 170**
Knock sensor	09.02-08.05		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	09.02-08.05		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	09.02-08.05		**0 265 005 303**
Wheel speed sensor, rear	09.02-08.05	FMS,LAB	**0 265 007 121**
		FMS,RAB	**0 265 007 123**
		LAB	**0 265 007 008**
		LAB,OSS	**0 265 007 008**
		OSS,RAB	**0 265 007 006**
		RAB	**0 265 007 006**
500 4MATIC [221]	**5,5 l 285 kW M 273.968 8 Zyl.**		
Throttle valve assembly	06.06→		**0 280 750 184**
Air mass meter, gasoline injection	06.06→		**0 280 218 190**
Phase sensor	06.06→	LAB	**0 232 103 050**
Knock sensor	06.06→		**0 261 231 188**
560 SEC [126]	**5,6 l 178 kW M 117.968 8 Zyl.**		
Air flow sensor, gasoline injection	10.85-06.91		**0 438 121 037**
			0 986 439 337
Speed sensor, ignition/injection	10.85-06.91		**0 261 210 022**
Knock sensor	09.88-06.91		**0 261 231 009**
Pressure sensor, intake manifold, gasoline	10.85-06.91		**0 280 101 003**
Temperature sensor, intake air, injection system	10.85-06.91		**0 280 130 047**
Temperature sensor, coolant, injection system	10.85-08.87		**0 280 130 044**
Wheel speed sensor, front	10.85-08.89	ABS,LAB	**0 265 001 021**
		ABS,RAB	**0 265 001 020**
	09.89-06.91	LAB	**0 265 001 280**
		RAB	**0 265 001 278**
Wheel speed sensor, rear	10.85-06.91		**0 265 002 258**
	09.87-06.91	ASR,LAB	**0 265 002 029**
		ASR,RAB	**0 265 002 027**
560 SEC [126]	**5,6 l 220 kW M 117.968 8 Zyl.**		
Air flow sensor, gasoline injection	10.85-08.87		**0 438 121 036**
Speed sensor, ignition/injection	10.85-08.87		**0 261 210 022**
Temperature sensor, intake air, injection system	10.85-08.87		**0 280 130 047**
Temperature sensor, coolant, injection system	10.85-08.87		**0 280 130 044**
Wheel speed sensor, front	10.85-08.87	ABS,LAB	**0 265 001 021**
		ABS,RAB	**0 265 001 020**

M

Product			
560 SEL [126]			**5,6 l 177 kW M 117.968 8 Zyl.**
Air flow sensor, gasoline injection	09.87-06.91		**0 438 121 037**
			0 986 439 337
Speed sensor, ignition/injection	09.87-06.91		**0 261 210 022**
Pressure sensor, intake manifold, gasoline	09.87-06.91		**0 280 101 003**
Temperature sensor, intake air, injection system	09.87-06.91		**0 280 130 047**
Wheel speed sensor, front	09.87-08.89	ABS,LAB	**0 265 001 021**
		ABS,RAB	**0 265 001 020**
	09.89-06.91	LAB	**0 265 001 280**
		RAB	**0 265 001 278**
Wheel speed sensor, rear	09.87-06.91		**0 265 002 258**
		ASR,LAB	**0 265 002 029**
		ASR,RAB	**0 265 002 027**
560 SEL [126]			**5,6 l 178 kW M 117.968 8 Zyl.**
Air flow sensor, gasoline injection	10.85-06.91		**0 438 121 037**
			0 986 439 337
Speed sensor, ignition/injection	10.85-06.91		**0 261 210 022**
Knock sensor	09.88-06.91		**0 261 231 009**
Pressure sensor, intake manifold, gasoline	10.85-06.91		**0 280 101 003**
Temperature sensor, intake air, injection system	10.85-06.91		**0 280 130 047**
Temperature sensor, coolant, injection system	10.85-08.87		**0 280 130 044**
Wheel speed sensor, front	10.85-08.89	ABS,LAB	**0 265 001 021**
		ABS,RAB	**0 265 001 020**
	09.89-06.91	LAB	**0 265 001 280**
		RAB	**0 265 001 278**
Wheel speed sensor, rear	10.85-06.91		**0 265 002 258**
	09.87-06.91	ASR,LAB	**0 265 002 029**
		ASR,RAB	**0 265 002 027**
560 SEL [126]			**5,6 l 220 kW M 117.968 8 Zyl.**
Air flow sensor, gasoline injection	10.85-08.87		**0 438 121 036**
Speed sensor, ignition/injection	10.85-08.87		**0 261 210 022**
Temperature sensor, intake air, injection system	10.85-08.87		**0 280 130 047**
Temperature sensor, coolant, injection system	10.85-08.87		**0 280 130 044**
Wheel speed sensor, front	10.85-08.87	ABS,LAB	**0 265 001 021**
		ABS,RAB	**0 265 001 020**
600 [140]			**6,0 l 290-300 kW M 120.980;982 12 Zyl.**
Throttle valve assembly			
Mot.no. 021143→,Engine type M120.982	06.93-09.98	LAB	**0 205 003 027**
		RAB	**0 205 003 029**
Engine type M120.982	06.93-09.98		**0 205 003 037**
Air mass meter, gasoline injection			
Engine type M120.980	06.93-09.98		**0 280 213 015**
			0 986 280 126
Engine type M120.982	06.93-09.98		**0 280 217 509**
Phase sensor	06.93-09.98	NOC	**0 232 103 050**
Knock sensor	06.93-09.98	LAB	**0 261 231 050**
		RAB	**0 261 231 052**
Temperature sensor, intake air, injection system			
Engine type M120.980	06.93-09.98		**0 280 130 047**
Pedal position sensor, EMS (electronic engine management)	06.93-09.98		**0 205 001 302**
Acceleration sensor, ABS	06.93-05.94		**0 265 005 107**
	06.94-09.98		**0 265 005 107**
Wheel speed sensor, front	06.93-09.98	LAB	**0 265 001 410**
		RAB	**0 265 001 408**
Wheel speed sensor, rear	06.93-09.98	OAS	**0 265 002 220**
Fg.no. →A212244	06.93-09.98	ASR,LAB	**0 265 002 218**
		ASR,RAB	**0 265 002 216**
600 [220]			**5,5 l 368 kW M 275.950 12 Zyl.**
Speed sensor, ignition/injection	09.02-08.05		**0 261 210 170**
Knock sensor	09.02-08.05		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	09.02-08.05		**0 265 005 258**

Product			
Pressure sensor, ESP, (electronic stability program)	09.02-08.05		**0 265 005 303**
Wheel speed sensor, front	09.02-08.05		**0 265 007 128**
Wheel speed sensor, rear	09.02-08.05	LAB	**0 265 007 121**
		RAB	**0 265 007 123**
600 [220]			**5,8 l 270 kW M 137.970 12 Zyl.**
Air mass meter, gasoline injection	08.99-08.05		**0 280 217 810**
Speed sensor, ignition/injection	08.99-08.05		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. A 322444→	08.99-08.05		**0 265 005 258**
Fg.no. →A 322443	08.99-08.05		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	08.99-08.05		**0 265 005 303**
Wheel speed sensor, front	08.99-08.05		**0 265 007 002**
Wheel speed sensor, rear	08.99-08.02	FMS,LAB	**0 265 007 121**
		FMS,RAB	**0 265 007 123**
	08.99-08.05	LAB	**0 265 007 008**
	08.99-08.02	LAB,OSS	**0 265 007 008**
		OSS,RAB	**0 265 007 006**
	08.99-08.05	RAB	**0 265 007 006**
600 [221]			**5,5 l 380 kW M 275.953 12 Zyl.**
Throttle valve assembly	12.05→		**0 280 750 125**
Speed sensor, ignition/injection	12.05→		**0 261 210 170**
Knock sensor	12.05→		**0 261 231 110**
600 Coupé [140]			**6,0 l 290-300 kW M 120.980;982 12 Zyl.**
Throttle valve assembly			
Mot.no. 021143→,Engine type M120.982	06.93-05.96	LAB	**0 205 003 027**
		RAB	**0 205 003 029**
Engine type M120.982	06.93-05.96		**0 205 003 037**
Air mass meter, gasoline injection			
Engine type M120.980	06.93-05.96		**0 280 213 015**
			0 986 280 126
Engine type M120.982	06.93-05.96		**0 280 217 509**
Phase sensor	06.93-05.96	NOC	**0 232 103 050**
Knock sensor	06.93-05.96	LAB	**0 261 231 050**
		RAB	**0 261 231 052**
Temperature sensor, intake air, injection system			
Engine type M120.980	06.93-05.96		**0 280 130 047**
Pedal position sensor, EMS (electronic engine management)	06.93-05.96		**0 205 001 302**
Acceleration sensor, ABS			
Fg.no. →A 290166	06.93-05.96	OFD	**0 265 005 107**
Duo sensor, acceleration and yaw rate, brake system	05.95-05.96		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)	05.95-05.96		**0 265 005 300**
Wheel speed sensor, front	06.93-05.96	LAB	**0 265 001 410**
		RAB	**0 265 001 408**
Wheel speed sensor, rear			
Fg.no. →A212244	06.93-05.96	LAB	**0 265 002 218**
		RAB	**0 265 002 216**
600 SE [140]			**6,0 l 290-300 kW M 120.980;982 12 Zyl.**
Throttle valve assembly			
Mot.no. 021143→,Engine type M120.982	04.91-05.93	LAB	**0 205 003 027**
		RAB	**0 205 003 029**
Engine type M120.982	04.91-05.93		**0 205 003 037**
Air mass meter, gasoline injection			
Engine type M120.980	04.91-05.93		**0 280 213 015**
			0 986 280 126
Engine type M120.982	04.91-05.93		**0 280 217 509**
Phase sensor	04.91-05.93	FKW	**0 281 002 123**
		NOC	**0 232 103 050**
Knock sensor	04.91-05.93	LAB	**0 261 231 050**
		RAB	**0 261 231 052**

M

Product

◀ Serie S

Temperature sensor, intake air, injection system			
Engine type M120.980	04.91-05.93		**0 280 130 047**
Pedal position sensor, EMS (electronic engine management)	04.91-05.93		**0 205 001 302**
Acceleration sensor, ABS	04.91-05.93		**0 265 005 107**
Wheel speed sensor, front	04.91-05.93	LAB	**0 265 001 410**
		RAB	**0 265 001 408**
Wheel speed sensor, rear	04.91-05.93	OAS	**0 265 002 220**
Fg.no. →A212244	04.91-05.93	ASR,LAB	**0 265 002 218**
		ASR,RAB	**0 265 002 216**
600 SEC [140]	**6,0 l 290-300 kW M 120.980;982 12 Zyl.**		
Throttle valve assembly			
Mot.no. 021143→,Engine type M120.982	09.92-05.93	LAB	**0 205 003 027**
		RAB	**0 205 003 029**
Engine type M120.982	09.92-05.93		**0 205 003 037**
Air mass meter, gasoline injection			
Engine type M120.980	09.92-05.93		**0 280 213 015**
			0 986 280 126
Engine type M120.982	09.92-05.93		**0 280 217 509**
Phase sensor	09.92-05.93	FKW	**0 281 002 123**
		NOC	**0 232 103 050**
Knock sensor	09.92-05.93	LAB	**0 261 231 050**
		RAB	**0 261 231 052**
Temperature sensor, intake air, injection system			
Engine type M120.980	09.92-05.93		**0 280 130 047**
Pedal position sensor, EMS (electronic engine management)	09.92-05.93		**0 205 001 302**
Acceleration sensor, ABS			
Fg.no. →A 290166	09.92-05.93	OFD	**0 265 005 107**
Wheel speed sensor, front	09.92-05.93	LAB	**0 265 001 410**
		RAB	**0 265 001 408**
Wheel speed sensor, rear			
Fg.no. →A212244	09.92-05.93	LAB	**0 265 002 218**
		RAB	**0 265 002 216**

Serie SL

55 AMG [230]	**5,4 l 368 kW M 113.992 8 Zyl.**		
Throttle valve assembly	10.01-08.02		**0 280 750 015**
Phase sensor	10.01-12.05		**0 232 103 050**
Speed sensor, ignition/injection	10.01-12.05		**0 261 210 170**
Knock sensor	10.01-12.05		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	10.01-05.04		**0 265 005 258**
	06.04-08.05		**0 265 005 298**
	09.05-12.05		**0 265 005 642**
Wheel speed sensor, front	10.01-12.05		**0 265 007 696**
Wheel speed sensor, rear			
Fg.no. F 030152→	10.01-12.05		**0 265 007 744**
Fg.no. →F 030151	10.01-12.05		**0 265 007 585**
55 AMG [230]	**5,4 l 380 kW M 113.995 8 Zyl.**		
Phase sensor	01.06→		**0 232 103 050**
Speed sensor, ignition/injection	01.06→		**0 261 210 170**
Knock sensor	01.06→		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	01.06→		**0 265 005 642**
Wheel speed sensor, front	01.06→		**0 265 007 743**
Wheel speed sensor, rear	01.06→		**0 265 007 744**
60 AMG [129]	**6,0 l 280 kW M 119.982 8 Zyl.**		
Phase sensor	07.93-06.98		**0 232 103 037**
Speed sensor, ignition/injection	07.93-06.98		**0 281 002 123**
Knock sensor	07.93-06.98		**0 261 231 110**
Wheel speed sensor, front	07.93-06.98	LAB	**0 265 001 224**
		RAB	**0 265 001 222**

Product

Wheel speed sensor, rear	07.93-06.98	OAS	**0 265 002 214**
Fg.no. F105255→	07.93-06.98	ASR,LAB	**0 265 006 186**
		ASR,RAB	**0 265 006 184**
Fg.no. →F105254	07.93-06.98	ASR,LAB	**0 265 002 224**
		ASR,RAB	**0 265 002 222**
65 AMG [230]	**6,0 l 450 kW M 275.981 12 Zyl.**		
Speed sensor, ignition/injection	09.04→		**0 261 210 170**
Knock sensor	09.04→		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	09.04-08.05		**0 265 005 298**
	09.05→		**0 265 005 642**
Wheel speed sensor, front	09.04→		**0 265 007 696**
Wheel speed sensor, rear	09.04→		**0 265 007 744**
280 [129]	**2,8 l 142 kW M 104.943 6 Zyl.**		
Air mass meter, gasoline injection			
Mot.no. →001545	07.93-05.98	GS	**0 280 217 500**
Mot.no. →006577	07.93-05.98	AG	**0 280 217 500**
Mot.no. 001546→	07.93-05.98	GS	**0 280 217 517**
Mot.no. 006578→	07.93-05.98	AG	**0 280 217 517**
Speed sensor, ignition/injection	07.93-05.98		**0 261 210 122**
Wheel speed sensor, front	07.93-05.98	LAB	**0 265 006 132**
		RAB	**0 265 006 130**
Wheel speed sensor, rear	07.93-05.98	OAS	**0 265 002 214**
Fg.no. F105255→	07.93-05.98	ASR,LAB	**0 265 006 186**
		ASR,RAB	**0 265 006 184**
Fg.no. →F105254	07.93-05.98	ASR,LAB	**0 265 002 224**
		ASR,RAB	**0 265 002 222**
280 [129]	**2,8 l 150 kW M 112.923 6 Zyl.**		
Throttle valve assembly	06.98-08.01		**0 205 003 046**
Air mass meter, gasoline injection	06.98-08.01		**0 280 217 515**
Phase sensor	06.98-08.01		**0 232 103 050**
Speed sensor, ignition/injection	06.98-08.01		**0 261 210 170**
Knock sensor	06.98-08.01		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	06.98-08.01		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. Ident 07/99→	06.98-08.01		**0 265 005 307**
Wheel speed sensor, front	06.98-08.01	LAB	**0 265 006 292**
		RAB	**0 265 006 280**
Wheel speed sensor, rear	06.98-08.01	LAB	**0 265 006 186**
		RAB	**0 265 006 184**
300 SL [107]	**3,0 l 132 kW M 103.982 6 Zyl.**		
Air flow sensor, gasoline injection	09.85-08.89		**0 438 121 033**
			0 986 439 333
Pressure sensor, intake manifold, gasoline	09.85-08.89		**0 280 101 003**
Temperature sensor, intake air, injection system	09.85-08.89		**0 280 130 047**
Temperature sensor, coolant, injection system	09.85-08.89	2PO	**0 280 130 044**
Wheel speed sensor	09.85-08.86	HI	**0 265 002 004**
	09.86-08.89	HI	**0 265 002 256**
		LAB,VO	**0 265 001 128**
		RAB,VO	**0 265 001 126**
	09.85-08.86	VO	**0 265 001 012**
300 SL [107]	**3,0 l 132-138 kW M 103.982 6 Zyl.**		
Air flow sensor, gasoline injection	09.85-08.89		**0 438 121 033**
			0 986 439 333
Temperature sensor, intake air, injection system	09.85-08.89		**0 280 130 047**
Temperature sensor, coolant, injection system	09.85-08.89	2PO	**0 280 130 044**
Wheel speed sensor	09.85-08.86	HI	**0 265 002 004**
	09.86-08.89	HI	**0 265 002 256**
		LAB,VO	**0 265 001 128**
		RAB,VO	**0 265 001 126**
	09.85-08.86	VO	**0 265 001 012**

Product			
300 SL [129]	**3,0 l 140 kW M 103.984 6 Zyl.**		
Air flow sensor, gasoline injection	03.89-06.93		**0 438 121 033**
			0 986 439 333
Temperature sensor, intake air, injection system	03.89-06.93		**0 280 130 047**
Wheel speed sensor, front	03.89-06.93	LAB	**0 265 001 224**
		RAB	**0 265 001 222**
Wheel speed sensor, rear	09.90-06.93	ASR,LAB	**0 265 002 224**
		ASR,RAB	**0 265 002 222**
	03.89-06.93	OAS	**0 265 002 202**
300 SL-24 [129]	**3,0 l 170 kW M 104.981 6 Zyl.**		
Air flow sensor, gasoline injection	03.89-06.93		**0 438 121 082**
			F 026 TX2 061
			0 986 439 382
Temperature sensor, intake air, injection system			
Fg.no. B091699→,F124697→	03.89-06.93		**0 280 130 047**
Wheel speed sensor, rear	09.90-06.93	ASR,LAB	**0 265 002 224**
		ASR,RAB	**0 265 002 222**
	03.89-06.93	OAS	**0 265 002 214**
320 [129]	**3,2 l 165 kW M 112.943 6 Zyl.**		
Throttle valve assembly	06.98-08.01		**0 205 003 046**
Air mass meter, gasoline injection	06.98-08.01		**0 280 217 515**
Phase sensor	06.98-08.01		**0 232 103 050**
Speed sensor, ignition/injection	06.98-08.01		**0 261 210 170**
Knock sensor	06.98-08.01		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	06.98-08.01		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. Ident 07/99→	06.98-08.01		**0 265 005 307**
Wheel speed sensor, front	06.98-08.01	LAB	**0 265 006 292**
		RAB	**0 265 006 280**
Wheel speed sensor, rear	06.98-08.01	LAB	**0 265 006 186**
		RAB	**0 265 006 184**
320 [129]	**3,2 l 170 kW M 104.991 6 Zyl.**		
Air mass meter, gasoline injection			
Mot.no. →12/52,22/62 022857, ~~Comp. no. Code 807~~	07.93-05.98		**0 280 217 500**
Mot.no. 022858→,~~Comp. no. Code 807~~	07.93-05.98		**0 280 218 080**
Mot.no. 022858→,Comp. no. Code 807	07.93-05.98		**0 280 217 517**
Wheel speed sensor, front	07.93-05.98	LAB	**0 265 006 132**
		RAB	**0 265 006 130**
Wheel speed sensor, rear	07.93-05.98	ASR,LAB	**0 265 002 224**
		ASR,RAB	**0 265 002 222**
		OAS	**0 265 002 214**
350 [230]	**3,5 l 200 kW M 272.966 6 Zyl.**		
Throttle valve assembly	01.06→		**0 280 750 017**
Phase sensor	01.06→	LAB	**0 232 103 050**
Knock sensor	01.06→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	01.06→		**0 265 005 642**
Wheel speed sensor, front	01.06→		**0 265 007 743**
Wheel speed sensor, rear	01.06→		**0 265 007 744**
350 [230]	**3,7 l 180 kW M 112.973 6 Zyl.**		
Air mass meter, gasoline injection	03.03-12.05		**0 280 217 515**
Phase sensor	03.03-12.05		**0 232 103 050**
Speed sensor, ignition/injection	03.03-12.05		**0 261 210 170**
Knock sensor	03.03-12.05		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	03.03-05.04		**0 265 005 258**
	06.04-08.05		**0 265 005 298**
	09.05-12.05		**0 265 005 642**
Wheel speed sensor, front	03.03-12.05		**0 265 007 696**
Wheel speed sensor, rear			
Fg.no. F 030152→	03.03-12.05		**0 265 007 744**
Fg.no. →F 030151	03.03-12.05		**0 265 007 585**

Product			
420 SL [107]	**4,2 l 150-160 kW M 116.964 8 Zyl.**		
Air flow sensor, gasoline injection	01.86-08.89		**0 438 121 037**
			0 986 439 337
Knock sensor	09.88-08.89		**0 261 231 009**
Temperature sensor, intake air, injection system	01.86-08.89		**0 280 130 047**
Temperature sensor, coolant, injection system	01.86-08.87		**0 280 130 044**
Wheel speed sensor	01.86-08.86	HI	**0 265 002 004**
	09.86-08.89	HI	**0 265 002 256**
		LAB,VO	**0 265 001 128**
		RAB,VO	**0 265 001 126**
	01.86-08.86	VO	**0 265 001 012**
500 [129]	**5,0 l 225 kW M 113.961 8 Zyl.**		
Throttle valve assembly	06.98-08.01		**0 205 003 048**
Air mass meter, gasoline injection	06.98-08.01		**0 280 217 810**
Phase sensor	06.98-08.01		**0 232 103 050**
Speed sensor, ignition/injection	06.98-08.01		**0 261 210 170**
Knock sensor	06.98-08.01		**0 261 231 110**
Pedal position sensor, EMS (electronic engine management)	06.98-08.01		**0 205 001 302**
Duo sensor, acceleration and yaw rate, brake system	06.98-08.01		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. Ident 07/99→	06.98-08.01		**0 265 005 307**
Wheel speed sensor, front	06.98-08.01	LAB	**0 265 006 292**
		RAB	**0 265 006 280**
Wheel speed sensor, rear	06.98-08.01	LAB	**0 265 006 186**
		RAB	**0 265 006 184**
500 [129]	**5,0 l 235-240 kW M 119.972 8 Zyl.**		
Air mass meter, gasoline injection	07.93-09.95		**0 280 214 004**
			0 986 280 121
Knock sensor	07.93-09.95		**0 261 231 026**
Temperature sensor, intake air, injection system	07.93-09.95		**0 280 130 047**
Wheel speed sensor, front	07.93-09.95	LAB	**0 265 001 224**
		RAB	**0 265 001 222**
Wheel speed sensor, rear	07.93-09.95	OAS	**0 265 002 214**
Fg.no. F105255→	07.93-09.95	ASR,LAB	**0 265 006 186**
		ASR,RAB	**0 265 006 184**
Fg.no. →F105254	07.93-09.95	ASR,LAB	**0 265 002 224**
		ASR,RAB	**0 265 002 222**
500 [129]	**5,0 l 235-240 kW M 119.982 8 Zyl.**		
Phase sensor	09.95-05.98		**0 232 103 037**
Speed sensor, ignition/injection	09.95-05.98		**0 281 002 123**
Knock sensor	09.95-05.98		**0 261 231 110**
Wheel speed sensor, front	09.95-05.98	LAB	**0 265 001 224**
		RAB	**0 265 001 222**
Wheel speed sensor, rear	09.95-05.98	OAS	**0 265 002 214**
Fg.no. F105255→	09.95-05.98	ASR,LAB	**0 265 006 186**
		ASR,RAB	**0 265 006 184**
Fg.no. →F105254	09.95-05.98	ASR,LAB	**0 265 002 224**
		ASR,RAB	**0 265 002 222**
500 [230]	**5,0 l 225 kW M 113.963 8 Zyl.**		
Throttle valve assembly	10.01-08.02		**0 280 750 015**
Air mass meter, gasoline injection	10.01-12.05		**0 280 217 810**
Phase sensor	10.01-12.05		**0 232 103 050**
Speed sensor, ignition/injection	10.01-12.05		**0 261 210 170**
Knock sensor	10.01-12.05		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	10.01-05.04		**0 265 005 258**
	06.04-08.05		**0 265 005 298**
	09.05-12.05		**0 265 005 642**
Wheel speed sensor, front	10.01-12.05		**0 265 007 696**
Wheel speed sensor, rear			
Fg.no. F 030152→	10.01-12.05		**0 265 007 744**
Fg.no. →F 030151	10.01-12.05		**0 265 007 585**

M

Product			
◀ Serie SL			
500 [230]	**5,5 l 285 kW M 273.965 8 Zyl.**		
Throttle valve assembly	01.06→		**0 280 750 184**
Phase sensor	01.06→	LAB	**0 232 103 050**
Knock sensor	01.06→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	01.06→		**0 265 005 642**
Wheel speed sensor, front	01.06→		**0 265 007 743**
Wheel speed sensor, rear	01.06→		**0 265 007 744**
500 SL [107]	**5,0 l 164-180 kW M 117.964 8 Zyl.**		
Air flow sensor, gasoline injection	01.86-08.89		**0 438 121 037**
			0 986 439 337
Speed sensor, ignition/injection	01.86-08.89		**0 261 210 039**
Knock sensor	09.88-08.89		**0 261 231 009**
Temperature sensor, intake air, injection system	01.86-08.89		**0 280 130 047**
Temperature sensor, coolant, injection system	01.86-08.89		**0 280 130 044**
Wheel speed sensor	01.86-08.86	HI	**0 265 002 004**
	09.86-08.89	HI	**0 265 002 256**
		LAB,VO	**0 265 001 128**
		RAB,VO	**0 265 001 126**
	01.86-08.86	VO	**0 265 001 012**
500 SL [129]	**5,0 l 235-240 kW M 119.960 8 Zyl.**		
Air flow sensor, gasoline injection	03.89-08.92		**F 026 TX2 057**
			F 026 TX2 057
Knock sensor	03.89-08.92		**0 261 231 026**
Temperature sensor, intake air, injection system	03.89-08.92		**0 280 130 047**
Wheel speed sensor, front	03.89-08.92	LAB	**0 265 001 224**
		RAB	**0 265 001 222**
Wheel speed sensor, rear	03.89-08.92	OAS	**0 265 002 214**
Fg.no. F105255→	03.89-08.92	ASR,LAB	**0 265 006 186**
		ASR,RAB	**0 265 006 184**
Fg.no. →F105254	03.89-08.92	ASR,LAB	**0 265 002 224**
		ASR,RAB	**0 265 002 222**
500 SL [129]	**5,0 l 235-240 kW M 119.972 8 Zyl.**		
Air mass meter, gasoline injection	09.92-06.93		**0 280 214 004**
			0 986 280 121
Knock sensor	09.92-06.93		**0 261 231 026**
Temperature sensor, intake air, injection system	09.92-06.93		**0 280 130 047**
Wheel speed sensor, front	09.92-06.93	LAB	**0 265 001 224**
		RAB	**0 265 001 222**
Wheel speed sensor, rear	09.92-06.93	OAS	**0 265 002 214**
Fg.no. F105255→	09.92-06.93	ASR,LAB	**0 265 006 186**
		ASR,RAB	**0 265 006 184**
Fg.no. →F105254	09.92-06.93	ASR,LAB	**0 265 002 224**
		ASR,RAB	**0 265 002 222**
560 SL [107]	**5,6 l 178 kW M 117.967 8 Zyl.**		
Air flow sensor, gasoline injection	09.85-08.89		**0 438 121 037**
			0 986 439 337
Speed sensor, ignition/injection	01.86-08.89		**0 261 210 039**
Pressure sensor, intake manifold, gasoline	09.85-08.89		**0 280 101 003**
Temperature sensor, coolant, injection system	09.85-08.89		**0 280 130 044**
Wheel speed sensor	09.85-08.86	HI	**0 265 002 004**
	09.86-08.89	HI	**0 265 002 256**
		LAB,VO	**0 265 001 128**
		RAB,VO	**0 265 001 126**
	09.85-08.86	VO	**0 265 001 012**
600 [129]	**6,0 l 290 kW M 120.981 12 Zyl.**		
Throttle valve assembly	09.93-09.95	LAB	**0 205 003 021**
		RAB	**0 205 003 023**
Air mass meter, gasoline injection	07.93-09.95		**0 280 213 015**
			0 986 280 126
Phase sensor	07.93-09.95	HI,LAB	**0 261 210 049**
		LAB,VO	**0 261 210 070**
		RAB,VO	**0 261 210 068**

Product			
Knock sensor	07.93-09.95	LAB	**0 261 231 082**
		RAB	**0 261 231 080**
Acceleration sensor, ABS	07.93-09.95		**0 265 005 107**
Duo sensor, acceleration and yaw rate, brake system	07.93-09.95		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)	09.95-09.95		**0 265 005 300**
Wheel speed sensor, front			
Fg.no. F125158→,Comp. no. Code 806, ~~Comp. no. Code 805~~	07.93-09.95	LAB	**0 265 006 292**
		RAB	**0 265 006 280**
Fg.no. →F125157,Comp. no. Code 805, ~~Comp. no. Code 806~~	07.93-09.95	LAB	**0 265 006 132**
Fg.no. →F125157,Comp. no. Code 806, ~~Comp. no. Code 805~~	07.93-09.95		**0 265 006 130**
Wheel speed sensor, rear			
Fg.no. F105255→	07.93-09.95	LAB	**0 265 006 186**
		RAB	**0 265 006 184**
Fg.no. →F105254	07.93-09.95	LAB	**0 265 002 114**
		RAB	**0 265 002 112**
600 [129]	**6,0 l 290 kW M 120.983 12 Zyl.**		
Throttle valve assembly	06.98-08.01		**0 205 003 039**
Air mass meter, gasoline injection	06.98-08.01		**0 280 217 509**
Phase sensor	09.95-08.01		**0 232 103 037**
Speed sensor, ignition/injection	09.95-08.01		**0 281 002 123**
Knock sensor	09.95-08.01		**0 261 231 110**
Pedal position sensor, EMS (electronic engine management)	06.98-08.01		**0 205 001 302**
Acceleration sensor, ABS	09.95-08.01		**0 265 005 107**
Duo sensor, acceleration and yaw rate, brake system	09.95-08.01		**0 265 005 201**
Pressure sensor, ESP, (electronic stability program)			
Fg.no. Ident 07/99→	06.98-08.01		**0 265 005 307**
Wheel speed sensor, front			
Fg.no. F125158→,Comp. no. Code 806, ~~Comp. no. Code 805~~	09.95-08.01	LAB	**0 265 006 292**
		RAB	**0 265 006 280**
Fg.no. →F125157,Comp. no. Code 805, ~~Comp. no. Code 806~~	09.95-08.01	LAB	**0 265 006 132**
Fg.no. →F125157,Comp. no. Code 806, ~~Comp. no. Code 805~~	09.95-08.01		**0 265 006 130**
Wheel speed sensor, rear			
Fg.no. F105255→	09.95-08.01	LAB	**0 265 006 186**
		RAB	**0 265 006 184**
Fg.no. →F105254	09.95-08.01	LAB	**0 265 002 114**
		RAB	**0 265 002 112**
600 [230]	**5,5 l 368 kW M 275.951 12 Zyl.**		
Throttle valve assembly	03.03-12.05		**0 280 750 125**
Speed sensor, ignition/injection	03.03-12.05		**0 261 210 170**
Knock sensor	03.03-12.05		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	03.03-05.04		**0 265 005 258**
	06.04-08.05		**0 265 005 298**
	09.05-12.05		**0 265 005 642**
Wheel speed sensor, front	03.03-12.05		**0 265 007 696**
Wheel speed sensor, rear	03.03-12.05		**0 265 007 744**
600 [230]	**5,5 l 380 kW M 275.954 12 Zyl.**		
Throttle valve assembly	01.06→		**0 280 750 125**
Speed sensor, ignition/injection	01.06→		**0 261 210 170**
Knock sensor	01.06→		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	01.06→		**0 265 005 642**
Wheel speed sensor, front	01.06→		**0 265 007 743**
Wheel speed sensor, rear	01.06→		**0 265 007 744**
600 SL [129]	**6,0 l 290 kW M 120.981;983 12 Zyl.**		
Throttle valve assembly	07.92-06.93	LAB	**0 205 003 021**
		RAB	**0 205 003 023**

Product			
Air mass meter, gasoline injection			
Engine type 120.981	07.92-06.93		**0 280 213 015**
			0 986 280 126
Engine type 120.983	07.92-06.93		**0 280 217 509**
Phase sensor	07.92-06.93		**0 232 103 037**
Speed sensor, ignition/injection	07.92-06.93		**0 281 002 123**
Knock sensor			
Engine type M 119.983	07.92-06.93		**0 261 231 110**
Engine type M 120.981	07.92-06.93	LAB	**0 261 231 082**
		RAB	**0 261 231 080**
Acceleration sensor, ABS	07.92-06.93		**0 265 005 107**
Duo sensor, acceleration and yaw rate, brake system	07.92-06.93		**0 265 005 201**
Wheel speed sensor, front			
Fg.no. F125158→,Comp. no. Code 806, ~~Comp. no. Code 805~~	07.92-06.93	LAB	**0 265 006 292**
		RAB	**0 265 006 280**
Fg.no. →F125157,Comp. no. Code 805, ~~Comp. no. Code 806~~	07.92-06.93	LAB	**0 265 006 132**
Fg.no. →F125157,Comp. no. Code 806, ~~Comp. no. Code 805~~	07.92-06.93		**0 265 006 130**
Wheel speed sensor, rear			
Fg.no. F105255→	07.92-06.93	LAB	**0 265 006 186**
		RAB	**0 265 006 184**
Fg.no. →F105254	07.92-06.93	LAB	**0 265 002 114**
		RAB	**0 265 002 112**

Serie SLK

32 AMG KOMPRESSOR [170]	**3,2 l 260 kW M 112.960 6 Zyl.**		
Phase sensor	06.99-03.04		**0 232 103 050**
Speed sensor, ignition/injection	06.99-03.04		**0 261 210 170**
Knock sensor	06.99-03.04		**0 261 231 110**
55 AMG [171]	**5,4 l 265 kW M 113.989 8 Zyl.**		
Throttle valve assembly	04.04→		**0 280 750 017**
Air mass meter, gasoline injection	04.04→		**0 280 217 810**
Phase sensor	04.04→		**0 232 103 050**
Speed sensor, ignition/injection	04.04→		**0 261 210 170**
Knock sensor	04.04→		**0 261 231 110**
200 [170]	**2,0 l 100 kW M 111.946 4 Zyl.**		
Air mass meter, gasoline injection	09.96-01.00	FGK	**0 280 217 114**
		KUT	**0 280 218 081**
Speed sensor, ignition/injection	07.98-01.00		**0 261 210 170**
	09.96-06.98		**0 281 002 123**
200 KOMPRESSOR [170]	**2,0 l 120 kW M 111.958 4 Zyl.**		
Throttle valve assembly	02.00-03.04		**0 280 750 045**
Speed sensor, ignition/injection	02.00-03.04		**0 261 210 170**
200 KOMPRESSOR [170]	**2,0 l 135 kW M 111.943 4 Zyl.**		
Throttle valve assembly	09.96-01.00		**0 205 003 044**
Air mass meter, gasoline injection	09.96-01.00	FGK	**0 280 217 114**
		KUT	**0 280 218 081**
Speed sensor, ignition/injection	07.98-01.00		**0 261 210 170**
	09.96-06.98		**0 281 002 123**
Pedal position sensor, EMS (electronic engine management)	09.96-01.00		**0 205 001 302**
200 KOMPRESSOR [171]	**1,8 l 120 kW M 271.944 4 Zyl.**		
Throttle valve assembly	04.04→		**0 280 750 076**
Phase sensor	04.04→		**0 232 103 050**
Speed sensor, ignition/injection	04.04→		**0 261 210 170**
230 KOMPRESSOR [170]	**2,3 l 142 kW M 111.973 4 Zyl.**		
Throttle valve assembly	09.96-01.00		**0 205 003 044**
Air mass meter, gasoline injection	09.96-01.00	FGK	**0 280 217 114**
		KUT	**0 280 218 081**
Speed sensor, ignition/injection	07.98-01.00		**0 261 210 170**
	09.96-06.98		**0 281 002 123**
Pedal position sensor, EMS (electronic engine management)	09.96-01.00		**0 205 001 302**
230 KOMPRESSOR [170]	**2,3 l 145 kW M 111.983 4 Zyl.**		
Throttle valve assembly	02.00-03.04		**0 280 750 045**
Speed sensor, ignition/injection	02.00-03.04		**0 261 210 170**
280 [171]	**3,0 l 170 kW M 272.942 6 Zyl.**		
Throttle valve assembly	05.05→		**0 280 750 017**
Air mass meter, gasoline injection	05.05→		**0 280 218 190**
Phase sensor	05.05→	LAB	**0 232 103 050**
Knock sensor	05.05→		**0 261 231 188**
320 [170]	**3,2 l 160 kW M 112.947 6 Zyl.**		
Air mass meter, gasoline injection	06.99-03.04	FGK	**0 280 217 515**
		KUT	**0 280 218 082**
Phase sensor	06.99-03.04		**0 232 103 050**
Speed sensor, ignition/injection	06.99-03.04		**0 261 210 170**
Knock sensor	06.99-03.04		**0 261 231 110**
350 [171]	**3,5 l 200 kW M 272.963 6 Zyl.**		
Throttle valve assembly	04.04→		**0 280 750 017**
Air mass meter, gasoline injection	04.04→		**0 280 218 190**
Phase sensor	04.04→	LAB	**0 232 103 050**
Knock sensor	04.04→		**0 261 231 188**

Serie SLR

5.4 [199]	**5,4 l 460 kW M 155.980 8 Zyl.**		
Phase sensor	04.04→		**0 232 103 050**
Speed sensor, ignition/injection	04.04→		**0 261 210 170**
Knock sensor	04.04→		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	04.04→		**0 265 005 258**
Wheel speed sensor, front	04.04→		**0 265 007 743**
Wheel speed sensor, rear	04.04→		**0 265 007 744**
5.4 722 Edition [199]	**5,4 l 478 kW M 155.980 8 Zyl.**		
Phase sensor	07.06→		**0 232 103 050**
Speed sensor, ignition/injection	07.06→		**0 261 210 170**
Knock sensor	07.06→		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system	07.06→		**0 265 005 258**
Wheel speed sensor, front	07.06→		**0 265 007 743**
Wheel speed sensor, rear	07.06→		**0 265 007 744**

Serie V

200 [638 T0N]	**2,0 l 95 kW M 111.950 4 Zyl.**		
Air mass meter, gasoline injection	04.96-09.03		**0 280 217 114**
Speed sensor, ignition/injection	04.96-09.03	FKW	**0 261 210 170**
Wheel speed sensor, front	04.96-09.03		**0 265 006 214**
Wheel speed sensor, rear	04.96-09.03		**0 265 006 215**
200 [638 T0N]	**2,0 l 100 kW M 111.948 4 Zyl.**		
Air mass meter, gasoline injection	04.96-09.03		**0 280 217 523**
Pedal position sensor, EMS (electronic engine management)	04.96-09.03		**0 205 001 029**
Wheel speed sensor, front	04.96-09.03		**0 265 006 214**
Wheel speed sensor, rear	04.96-09.03		**0 265 006 215**
200 CDI [638 T0N]	**2,2 l 75 kW OM 611.980 4 Zyl.**		
Air mass meter, diesel	06.99-09.03		**0 280 217 114**
Speed sensor, diesel	06.99-09.03	FKW	**0 261 210 170**
High-pressure sensor (CR system)	06.99-09.03		**0 281 002 700**
Wheel speed sensor, front	06.99-09.03		**0 265 006 214**
Wheel speed sensor, rear	06.99-09.03		**0 265 006 215**

M

Product

◀ Serie V

220 CDI [638 T0N]			**2,2 l 90 kW OM 611.980 4 Zyl.**
Air mass meter, diesel	06.99-09.03		**0 280 217 114**
Speed sensor, diesel	06.99-09.03	FKW	**0 261 210 170**
High-pressure sensor (CR system)	06.99-09.03		**0 281 002 700**
Wheel speed sensor, front	06.99-09.03		**0 265 006 214**
Wheel speed sensor, rear	06.99-09.03		**0 265 006 215**
230 [638 T0N]			**2,3 l 105 kW M 111.978 4 Zyl.**
Air mass meter, gasoline injection	04.96-09.03		**0 280 217 523**
Wheel speed sensor, front	04.96-09.03		**0 265 006 214**
Wheel speed sensor, rear	04.96-09.03		**0 265 006 215**
230 [638 T0N]			**2,3 l 105 kW M 111.980 4 Zyl.**
Air mass meter, gasoline injection	04.96-09.03		**0 280 217 114**
Speed sensor, ignition/injection	04.96-09.03		**0 261 210 170**
Wheel speed sensor, front	04.96-09.03		**0 265 006 214**
Wheel speed sensor, rear	04.96-09.03		**0 265 006 215**
230 TD [638 T0N]			**2,3 l 72 kW OM 601.970 4 Zyl.**
Air mass meter, diesel	04.96-09.03		**0 280 217 523**
Pedal position sensor, diesel	04.96-09.03		**0 205 001 029**
Wheel speed sensor, front	04.96-09.03		**0 265 006 214**
Wheel speed sensor, rear	04.96-09.03		**0 265 006 215**
280 [638 T0N]			**2,8 l 128 kW M 104.900 6 Zyl.**
Air mass meter, gasoline injection	04.96-09.03		**0 280 217 523**
Pedal position sensor, EMS (electronic engine management)	04.96-09.03		**0 205 001 029**
Wheel speed sensor, front	04.96-09.03		**0 265 006 214**
Wheel speed sensor, rear	04.96-09.03		**0 265 006 215**

Serie 124

200			**2,0 l 75-80 kW M 102.922 4 Zyl.**
Speed sensor, ignition/injection	12.84-10.90		**0 261 210 066**
Wheel speed sensor, front			
Fg.no. A060862→	12.84-10.90	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Fg.no. →A060861	12.84-10.90	LAB	**0 265 001 128**
		RAB	**0 265 001 126**
Wheel speed sensor, rear			
Fg.no. A203047→	12.84-10.90		**0 265 002 208**
200 CE Cabrio			**2,0 l 100 kW M 111.940 4 Zyl.**
Speed sensor, ignition/injection	06.91-06.93		**0 261 210 055**
Wheel speed sensor, front	06.91-06.93	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Wheel speed sensor, rear	06.91-06.93		**0 265 002 254**
200 CE Coupé			**2,0 l 90 kW M 102.963 4 Zyl.**
Air flow sensor, gasoline injection	09.89-06.93	KAT,VFA	**0 438 121 043**
			0 986 439 343
		OKA	**0 986 439 301**
			F 026 TX2 060
Speed sensor, ignition/injection	09.89-06.93		**0 261 210 066**
Temperature sensor, intake air, injection system	09.89-06.93	KAT,VFA	**0 280 130 047**
Temperature sensor, coolant, injection system	09.89-06.93	OKA	**0 280 130 035**
Mot.no. →009689	09.89-06.93	2PO,AG, KAT	**0 280 130 044**
Mot.no. →036265	09.89-06.93	2PO,GS, KAT	**0 280 130 044**
Wheel speed sensor, front	09.89-06.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	09.89-06.93		**0 265 002 208**
200 CE Coupé			**2,0 l 100 kW M 111.940 4 Zyl.**
Speed sensor, ignition/injection	09.92-06.93		**0 261 210 055**
Wheel speed sensor, front			
Fg.no. C009356→,B891779→C009354, Comp. no. Code 859	09.92-06.93	LAB	**0 265 006 111**
		RAB	**0 265 006 109**

Product

Wheel speed sensor, front			
Fg.no. →C009355,B891779→C009354, ~~Comp. no. Code 859~~	09.92-06.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	09.92-06.93		**0 265 002 208**
200 D			**2,0 l 53-55 kW OM 601.912 4 Zyl.**
Wheel speed sensor, front			
Fg.no. A060862→	12.84-06.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Fg.no. →A060861	12.84-06.93	LAB	**0 265 001 128**
		RAB	**0 265 001 126**
Wheel speed sensor, rear			
Fg.no. A203047→	12.84-06.93		**0 265 002 208**
200 E			**2,0 l 87-90 kW M 102.963 4 Zyl.**
Air flow sensor, gasoline injection	06.86-10.92	KAT,VFA	**0 438 121 043**
			0 986 439 343
		OKA	**0 986 439 301**
			F 026 TX2 060
Speed sensor, ignition/injection	06.86-10.92		**0 261 210 066**
Temperature sensor, intake air, injection system	06.86-10.92	KAT,VFA	**0 280 130 047**
Temperature sensor, coolant, injection system	06.86-10.92	OKA	**0 280 130 035**
Mot.no. →009689	06.86-10.92	2PO,AG, KAT	**0 280 130 044**
Mot.no. →036265	06.86-10.92	2PO,GS, KAT	**0 280 130 044**
Wheel speed sensor, front			
Fg.no. A060862→	06.86-10.92	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Fg.no. →A060861	06.86-10.92	LAB	**0 265 001 128**
		RAB	**0 265 001 126**
Wheel speed sensor, rear			
Fg.no. A203047→	06.86-10.92		**0 265 002 208**
200 E			**2,0 l 100 kW M 111.940 4 Zyl.**
Speed sensor, ignition/injection	09.92-06.93		**0 261 210 055**
Wheel speed sensor, front			
Fg.no. C009356→,B891779→C009354, Comp. no. Code 859	09.92-06.93	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Fg.no. →C009355,B891779→C009354, ~~Comp. no. Code 859~~	09.92-06.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	09.92-06.93		**0 265 002 208**
220 CE Cabrio			**2,2 l 110 kW M 111.960 4 Zyl.**
Air mass meter, gasoline injection	07.91-06.93		**0 280 217 100**
Speed sensor, ignition/injection			
Mot.no. →079783	07.91-06.93	AG,LLE	**0 261 210 055**
Mot.no. →080036	07.91-06.93	GS,LLE	**0 261 210 055**
Mot.no. 079784→	07.91-06.93	GS,LLE	**0 261 210 122**
Mot.no. 080037→	07.91-06.93	AG,LLE	**0 261 210 122**
Knock sensor			
Mot.no. →079783	07.91-06.93	AG	**0 261 231 098**
Mot.no. →080036	07.91-06.93	GS	**0 261 231 098**
Wheel speed sensor, front	07.91-06.93	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Wheel speed sensor, rear	07.91-06.93		**0 265 002 254**
220 CE Coupé			**2,2 l 110 kW M 111.960 4 Zyl.**
Air mass meter, gasoline injection	09.92-06.93		**0 280 217 100**
Speed sensor, ignition/injection			
Mot.no. →079783	09.92-06.93	AG,LLE	**0 261 210 055**
Mot.no. →080036	09.92-06.93	GS,LLE	**0 261 210 055**
Mot.no. 079784→	09.92-06.93	GS,LLE	**0 261 210 122**
Mot.no. 080037→	09.92-06.93	AG,LLE	**0 261 210 122**
Knock sensor			
Mot.no. →079783	09.92-06.93	AG	**0 261 231 098**
Mot.no. →080036	09.92-06.93	GS	**0 261 231 098**

Product			
Wheel speed sensor, front			
Fg.no. C009356→,B891779→C009354,	09.92-06.93	LAB	**0 265 006 111**
Comp. no. Code 859		RAB	**0 265 006 109**
Fg.no. →C009355,B891779→C009354,	09.92-06.93	LAB	**0 265 001 284**
~~Comp. no. Code 859~~		RAB	**0 265 001 282**
Wheel speed sensor, rear	09.92-06.93		**0 265 002 208**
220 E	**2,2 l 110 kW M 111.960 4 Zyl.**		
Air mass meter, gasoline injection	09.92-06.93		**0 280 217 100**
Speed sensor, ignition/injection			
Mot.no. →079783	09.92-06.93	AG,LLE	**0 261 210 055**
Mot.no. →080036	09.92-06.93	GS,LLE	**0 261 210 055**
Mot.no. 079784→	09.92-06.93	GS,LLE	**0 261 210 122**
Mot.no. 080037→	09.92-06.93	AG,LLE	**0 261 210 122**
Knock sensor			
Mot.no. →079783	09.92-06.93	AG	**0 261 231 098**
Mot.no. →080036	09.92-06.93	GS	**0 261 231 098**
Wheel speed sensor, front			
Fg.no. C009356→,B891779→C009354,	09.92-06.93	LAB	**0 265 006 111**
Comp. no. Code 859		RAB	**0 265 006 109**
Fg.no. →C009355,B891779→C009354,	09.92-06.93	LAB	**0 265 001 284**
~~Comp. no. Code 859~~		RAB	**0 265 001 282**
Wheel speed sensor, rear	09.92-06.93		**0 265 002 208**
230 CE Coupé	**2,3 l 97-100 kW M 102.982 4 Zyl.**		
Air flow sensor, gasoline injection	03.87-08.92	KAT,VFA	**0 438 121 043**
			0 986 439 343
		OKA	**0 986 439 301**
			F 026 TX2 060
Speed sensor, ignition/injection	03.87-08.92		**0 261 210 066**
Temperature sensor, intake air, injection system	03.87-08.92		**0 280 130 047**
Temperature sensor, coolant, injection system	03.87-08.92	OKA	**0 280 130 035**
		2PO,KAT	**0 280 130 044**
Wheel speed sensor, front	03.87-08.92	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	03.87-08.92		**0 265 002 208**
230 E	**2,3 l 97-100 kW M 102.982 4 Zyl.**		
Air flow sensor, gasoline injection	12.84-06.93	KAT,VFA	**0 438 121 043**
			0 986 439 343
		OKA	**0 986 439 301**
			F 026 TX2 060
Speed sensor, ignition/injection	12.84-06.93		**0 261 210 066**
Temperature sensor, intake air, injection system	12.84-06.93		**0 280 130 047**
Temperature sensor, coolant, injection system	12.84-06.93	OKA	**0 280 130 035**
		2PO,KAT	**0 280 130 044**
Wheel speed sensor, front			
Fg.no. A060862→	12.84-06.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Fg.no. →A060861	12.84-06.93	LAB	**0 265 001 128**
		RAB	**0 265 001 126**
Wheel speed sensor, rear			
Fg.no. A203047→	12.84-06.93		**0 265 002 208**
250 D	**2,5 l 66-69 kW OM 602.912 5 Zyl.**		
Wheel speed sensor, front			
Fg.no. A060862→	04.85-08.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Fg.no. →A060861	04.85-08.93	LAB	**0 265 001 128**
		RAB	**0 265 001 126**
Wheel speed sensor, rear			
Fg.no. A203047→	04.85-08.93		**0 265 002 208**
250 D	**2,5 l 69 kW OM 602.912 5 Zyl.**		
Wheel speed sensor, front	09.89-06.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear			
Fg.no. A203047→	09.89-06.93		**0 265 002 208**

Product			
250 D Turbo	**2,5 l 93 kW OM 602.962 5 Zyl.**		
Air flow sensor, diesel	09.88-06.93		**0 281 002 035**
Pressure sensor, intake manifold, diesel	09.88-06.93		**0 281 002 059**
Temperature sensor, coolant, diesel	09.88-06.93		**0 280 130 035**
Wheel speed sensor, front	09.88-06.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear			
Fg.no. A203047→	09.88-06.93		**0 265 002 208**
260 E	**2,6 l 118-122/125 kW M 103.940 6 Zyl.**		
Air flow sensor, gasoline injection	09.85-10.92		**0 438 121 033**
			0 986 439 333
Speed sensor, ignition/injection	09.85-10.92		**0 261 210 051**
Temperature sensor, intake air, injection system	09.85-10.92		**0 280 130 047**
Temperature sensor, coolant, injection system	09.85-10.92	2PO	**0 280 130 044**
Wheel speed sensor, front			
Fg.no. A060862→	09.85-10.92	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Fg.no. →A060861	09.85-10.92	LAB	**0 265 001 128**
		RAB	**0 265 001 126**
Wheel speed sensor, rear	09.85-10.92	AOS	**0 265 002 210**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
260 E 4MATIC	**2,6 l 118-122 kW M 103.943 6 Zyl.**		
Air flow sensor, gasoline injection	09.86-08.92		**0 438 121 033**
			0 986 439 333
Speed sensor, ignition/injection	09.86-08.92		**0 261 210 051**
Temperature sensor, intake air, injection system	09.86-08.92		**0 280 130 047**
Temperature sensor, coolant, injection system			
Mot.no. →000452	09.86-08.92	2PO,GS	**0 280 130 044**
Mot.no. →001081	09.86-08.92	2PO,AG	**0 280 130 044**
Wheel speed sensor, front	09.86-08.92	LAB	**0 265 001 300**
		RAB	**0 265 001 298**
Wheel speed sensor, rear			
Fg.no. A203047→	09.86-08.92		**0 265 002 208**
280 E	**2,8 l 142-145 kW M 104.942 6 Zyl.**		
Air mass meter, gasoline injection	09.89-06.93		**0 280 217 500**
Speed sensor, ignition/injection			
Mot.no. →005789	09.89-06.93	GS,LLE	**0 261 210 055**
		GS,RLE	**0 261 210 066**
Mot.no. →048696	09.89-06.93	AG,LLE	**0 261 210 055**
		AG,RLE	**0 261 210 066**
Mot.no. 005790→	09.89-06.93	GS	**0 261 210 122**
Mot.no. 048697→	09.89-06.93	AG	**0 261 210 122**
Wheel speed sensor, front			
Fg.no. C009356→,B891779→C009354,	09.89-06.93	LAB	**0 265 006 111**
Comp. no. Code 859		RAB	**0 265 006 109**
Fg.no. →C009355,B891779→C009354,	09.89-06.93	LAB	**0 265 001 284**
~~Comp. no. Code 859~~		RAB	**0 265 001 282**
Wheel speed sensor, rear	09.89-06.93	AOS	**0 265 002 210**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
300 AMG E 3.4	**3,4 l 200 kW M 104.980 6 Zyl.**		
Speed sensor, ignition/injection	02.92-02.94		**0 261 210 051**
Temperature sensor, intake air, injection system			
Fg.no. B091699→,F124697→	02.92-02.94		**0 280 130 047**
Wheel speed sensor, front	02.92-02.94	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	02.92-02.94	AOS	**0 265 002 210**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**

M

Product			
◀ Serie 124			
300 AMG CE 3.4 Coupé	**3,0 l 200 kW M 104.980 6 Zyl.**		
Speed sensor, ignition/injection	09.89-08.92		**0 261 210 051**
Temperature sensor, intake air, injection system			
Fg.no. B091699→,F124697→	09.89-08.92		**0 280 130 047**
Wheel speed sensor, front	09.89-08.92	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	09.89-08.92	AOS	**0 265 002 210**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
300 CE Cabrio	**3,2 l 162 kW M 104.992 6 Zyl.**		
Air mass meter, gasoline injection	04.92-04.93		**0 280 217 500**
Speed sensor, ignition/injection			
Mot.no. →004356	04.92-04.93	GS,LLE	**0 261 210 055**
Mot.no. →072236	04.92-04.93	AG,LLE	**0 261 210 055**
Mot.no. 004357→	04.92-04.93	GS,LLE	**0 261 210 122**
Mot.no. 072237→	04.92-04.93	AG,LLE	**0 261 210 122**
Wheel speed sensor, front	04.92-04.93	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Wheel speed sensor, rear	04.92-04.93	AOS	**0 265 002 244**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
300 CE Coupé	**3,0 l 132-138 kW M 103.983 6 Zyl.**		
Air flow sensor, gasoline injection	03.87-06.93		**0 438 121 033**
			0 986 439 333
Speed sensor, ignition/injection	03.87-06.93		**0 261 210 051**
Temperature sensor, intake air, injection system	03.87-06.93		**0 280 130 047**
Temperature sensor, coolant, injection system	03.87-06.93	2PO	**0 280 130 044**
Wheel speed sensor, front	03.87-06.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	03.87-06.93	AOS	**0 265 002 208**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
300 CE-24 Cabrio	**3,0 l 162 kW M 104.980 6 Zyl.**		
Speed sensor, ignition/injection	04.92-06.93		**0 261 210 051**
Temperature sensor, intake air, injection system			
Fg.no. B091699→,F124697→	04.92-06.93		**0 280 130 047**
Wheel speed sensor, front	04.92-06.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	04.92-06.93	AOS	**0 265 002 244**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
300 CE-24 Coupé	**3,0 l 162/170 kW M 104.980 6 Zyl.**		
Speed sensor, ignition/injection	09.89-06.93		**0 261 210 051**
Temperature sensor, intake air, injection system			
Fg.no. B091699→,F124697→	09.89-06.93		**0 280 130 047**
Wheel speed sensor, front	09.89-06.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	09.89-06.93	AOS	**0 265 002 210**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
300 D	**3,0 l 80-83 kW OM 603.912 6 Zyl.**		
Wheel speed sensor, front			
Fg.no. A060862→	01.85-06.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Fg.no. →A060861	01.85-06.93	LAB	**0 265 001 128**
		RAB	**0 265 001 126**
Wheel speed sensor, rear			
Fg.no. A203047→	01.85-06.93		**0 265 002 208**
300 D Turbo	**3,0 l 105-108 kW OM 603.960 6 Zyl.**		
Air flow sensor, diesel	09.86-06.93		**0 281 002 024**
			0 281 002 028
Pressure sensor, intake manifold, diesel	09.86-06.93		**0 280 101 003**
Temperature sensor, coolant, diesel	09.86-06.93		**0 280 130 035**

Product			
Wheel speed sensor, front	09.86-06.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear			
Fg.no. A203047→	09.86-06.93		**0 265 002 208**
300 D Turbo 2.5	**2,5 l 90 kW OM 602.962 5 Zyl.**		
Air flow sensor, diesel	09.89-08.92		**0 281 002 035**
Pressure sensor, intake manifold, diesel	09.89-08.92		**0 281 002 059**
Temperature sensor, coolant, diesel	09.89-08.92		**0 280 130 035**
Wheel speed sensor, front	09.89-08.92	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear			
Fg.no. A203047→	09.89-08.92		**0 265 002 208**
300 D Turbo 4MATIC	**3,0 l 105/108 kW OM 603.963 6 Zyl.**		
Air flow sensor, diesel	09.86-06.93		**0 281 002 024**
			0 281 002 028
Temperature sensor, coolant, diesel	09.86-06.93		**0 280 130 035**
Wheel speed sensor, front	09.86-06.93	LAB	**0 265 001 300**
		RAB	**0 265 001 298**
Wheel speed sensor, rear			
Fg.no. A203047→	09.86-06.93		**0 265 002 208**
300 D 4MATIC	**3,0 l 80-83 kW OM 603.913 6 Zyl.**		
Wheel speed sensor, front	09.86-06.93	LAB	**0 265 001 300**
		RAB	**0 265 001 298**
Wheel speed sensor, rear			
Fg.no. A203047→	09.86-06.93		**0 265 002 208**
300 E	**3,0 l 132-138 kW M 103.980;983 6 Zyl.**		
Air flow sensor, gasoline injection	01.85-08.93		**0 438 121 033**
			0 986 439 333
Speed sensor, ignition/injection	01.85-08.93		**0 261 210 051**
Pressure sensor, intake manifold, gasoline	01.85-08.93		**0 280 101 003**
Temperature sensor, intake air, injection system	01.85-08.93		**0 280 130 047**
Wheel speed sensor, front			
Fg.no. A060862→	01.85-08.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Fg.no. →A060861	01.85-08.93	LAB	**0 265 001 128**
		RAB	**0 265 001 126**
Wheel speed sensor, rear	01.85-08.93	ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
Fg.no. A203047→	01.85-08.93	AOS	**0 265 002 208**
300 E 2.8	**2,8 l 145 kW M 104.942 6 Zyl.**		
Air mass meter, gasoline injection	09.89-06.93		**0 280 217 500**
Speed sensor, ignition/injection			
Mot.no. →005789	09.89-06.93	GS,LLE	**0 261 210 055**
		GS,RLE	**0 261 210 066**
Mot.no. →048696	09.89-06.93	AG,LLE	**0 261 210 055**
		AG,RLE	**0 261 210 066**
Mot.no. 005790→	09.89-06.93	GS	**0 261 210 122**
Mot.no. 048697→	09.89-06.93	AG	**0 261 210 122**
Wheel speed sensor, front			
Fg.no. C009356→,B891779→C009354, Comp. no. Code 859	09.89-06.93	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Fg.no. →C009355,B891779→C009354, ~~Comp. no. Code 859~~	09.89-06.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	09.89-06.93	AOS	**0 265 002 210**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
300 E 4MATIC	**3,0 l 132-138 kW M 103.985 6 Zyl.**		
Air flow sensor, gasoline injection	09.86-06.93		**0 438 121 033**
			0 986 439 333
Speed sensor, ignition/injection	09.86-06.93		**0 261 210 051**
Temperature sensor, intake air, injection system	09.86-06.93		**0 280 130 047**

M

Product			
Temperature sensor, coolant, injection system			
Mot.no. →002187	09.86-06.93	2PO,GS	**0 280 130 044**
Mot.no. →008267	09.86-06.93	2PO,AG	**0 280 130 044**
Wheel speed sensor, front	09.86-06.93	LAB	**0 265 001 300**
		RAB	**0 265 001 298**
Wheel speed sensor, rear			
Fg.no. A203047→	09.86-06.93		**0 265 002 208**
300 E-24	**3,0 l 162-170 kW M 104.980 6 Zyl.**		
Speed sensor, ignition/injection	09.88-10.92		**0 261 210 051**
Temperature sensor, intake air, injection system			
Fg.no. B091699→,F124697→	09.88-10.92		**0 280 130 047**
Wheel speed sensor, front	09.88-10.92	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	09.88-10.92	AOS	**0 265 002 210**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
320 CE Coupé	**3,2 l 162 kW M 104.992 6 Zyl.**		
Air mass meter, gasoline injection	09.92-06.93		**0 280 217 500**
Speed sensor, ignition/injection			
Mot.no. →004356	09.92-06.93	GS,LLE	**0 261 210 055**
Mot.no. →072236	09.92-06.93	AG,LLE	**0 261 210 055**
Mot.no. 004357→	09.92-06.93	GS,LLE	**0 261 210 122**
Mot.no. 072237→	09.92-06.93	AG,LLE	**0 261 210 122**
Wheel speed sensor, front	09.92-06.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	09.92-06.93	AOS	**0 265 002 210**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
320 E	**3,2 l 162 kW M 104.992 6 Zyl.**		
Air mass meter, gasoline injection	09.92-06.93		**0 280 217 500**
Speed sensor, ignition/injection			
Mot.no. →004356	09.92-06.93	GS,LLE	**0 261 210 055**
Mot.no. →072236	09.92-06.93	AG,LLE	**0 261 210 055**
Mot.no. 004357→	09.92-06.93	GS,LLE	**0 261 210 122**
Mot.no. 072237→	09.92-06.93	AG,LLE	**0 261 210 122**
Wheel speed sensor, front			
Fg.no. C009356→,B891779→C009354,	09.92-06.93	LAB	**0 265 006 111**
Comp. no. Code 859		RAB	**0 265 006 109**
Fg.no. →C009355,B891779→C009354,	09.92-06.93	LAB	**0 265 001 284**
~~Comp. no. Code 859~~		RAB	**0 265 001 282**
Wheel speed sensor, rear	09.92-06.93	AOS	**0 265 002 210**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
400 E	**4,2 l 205/210 kW M 119.975 8 Zyl.**		
Air mass meter, gasoline injection	09.91-06.93		**0 280 214 004**
			0 986 280 121
Speed sensor, ignition/injection	09.91-06.93		**0 261 210 085**
Knock sensor	09.91-06.93		**0 261 231 062**
Temperature sensor, intake air, injection system	09.91-06.93		**0 280 130 047**
Wheel speed sensor, front			
Fg.no. C013141→	09.91-06.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Fg.no. →C013142	09.91-06.93	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Wheel speed sensor, rear	09.91-06.93	AOS	**0 265 002 210**
		ASR,LAB	**0 265 002 238**
		ASR,RAB	**0 265 002 108**
500 AMG E 6.0	**6,0 l 276 kW M 119.974 8 Zyl.**		
Air mass meter, gasoline injection	01.91-06.93		**0 280 214 004**
			0 986 280 121
Speed sensor, ignition/injection	01.91-06.93		**0 261 210 085**
Knock sensor	01.91-06.93		**0 261 231 062**

Product			
Temperature sensor, intake air, injection system	01.91-06.93		**0 280 130 047**
Wheel speed sensor, front			
Fg.no. C013141→	01.91-06.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Fg.no. →C013142	01.91-06.93	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Wheel speed sensor, rear	01.91-06.93	LAB	**0 265 002 238**
		RAB	**0 265 002 108**
500 E	**5,0 l 240 kW M 119.974 8 Zyl.**		
Air mass meter, gasoline injection	01.91-06.93		**0 280 214 004**
			0 986 280 121
Speed sensor, ignition/injection	01.91-06.93		**0 261 210 085**
Knock sensor	01.91-06.93		**0 261 231 062**
Temperature sensor, intake air, injection system	01.91-06.93		**0 280 130 047**
Wheel speed sensor, front			
Fg.no. C013141→	01.91-06.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Fg.no. →C013142	01.91-06.93	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Wheel speed sensor, rear	01.91-06.93	LAB	**0 265 002 238**
		RAB	**0 265 002 108**

Serie 124 (T-Modell)

200 T	**2,0 l 77-80 kW M 102.922 4 Zyl.**		
Speed sensor, ignition/injection	09.85-05.90		**0 261 210 066**
Wheel speed sensor, front	09.85-05.90	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear			
Fg.no. F005650→	09.85-05.90		**0 265 002 208**
200 TD	**2,0 l 53-55 kW OM 601.912 4 Zyl.**		
Wheel speed sensor, front	09.85-08.91	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear			
Fg.no. F005650→	09.85-08.91		**0 265 002 208**
200 TE	**2,0 l 87-90 kW M 102.963 4 Zyl.**		
Air flow sensor, gasoline injection	09.88-10.92	KAT,VFA	**0 438 121 043**
			0 986 439 343
		OKA	**0 986 439 301**
			F 026 TX2 060
Speed sensor, ignition/injection	09.88-10.92		**0 261 210 066**
Temperature sensor, intake air, injection system	09.88-10.92	KAT,VFA	**0 280 130 047**
Temperature sensor, coolant, injection system	09.88-10.92	OKA	**0 280 130 035**
Mot.no. →009689	09.88-10.92	2PO,AG, KAT	**0 280 130 044**
Mot.no. →036265	09.88-10.92	2PO,GS, KAT	**0 280 130 044**
Wheel speed sensor, front	09.88-10.92	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear			
Fg.no. F005650→	09.88-10.92		**0 265 002 208**
200 TE	**2,0 l 100 kW M 111.940 4 Zyl.**		
Speed sensor, ignition/injection	09.92-06.93		**0 261 210 055**
Wheel speed sensor, front			
Fg.no. F264121→	09.92-06.93	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Fg.no. →F264120	09.92-06.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear			
Fg.no. F005650→	09.92-06.93		**0 265 002 208**

M

Product

◀ Serie 124 (T-Modell)

220 TE			**2,2 l 110 kW M 111.960 4 Zyl.**
Air mass meter, gasoline injection	09.92-06.93		**0 280 217 100**
Speed sensor, ignition/injection			
Mot.no. →079783	09.92-06.93	AG,LLE	**0 261 210 055**
Mot.no. →080036	09.92-06.93	GS,LLE	**0 261 210 055**
Mot.no. 079784→	09.92-06.93	GS,LLE	**0 261 210 122**
Mot.no. 080037→	09.92-06.93	AG,LLE	**0 261 210 122**
Knock sensor			
Mot.no. →079783	09.92-06.93	AG	**0 261 231 098**
Mot.no. →080036	09.92-06.93	GS	**0 261 231 098**
Wheel speed sensor, front			
Fg.no. F264121→	09.92-06.93	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Fg.no. →F264120	09.92-06.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear			
Fg.no. F005650→	09.92-06.93		**0 265 002 208**
230 TE			**2,3 l 97-100 kW M 102.982 4 Zyl.**
Air flow sensor, gasoline injection	09.85-08.93	KAT,VFA	**0 438 121 043**
			0 986 439 343
		OKA	**0 986 439 301**
			F 026 TX2 060
Speed sensor, ignition/injection	09.85-08.93		**0 261 210 066**
Temperature sensor, intake air, injection system	09.85-08.93		**0 280 130 047**
Temperature sensor, coolant, injection system	09.85-08.93	OKA	**0 280 130 035**
		2PO,KAT	**0 280 130 044**
Wheel speed sensor, front	09.85-08.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear			
Fg.no. F005650→	09.85-08.93		**0 265 002 208**
250 TD			**2,5 l 66-69 kW OM 602.912 5 Zyl.**
Wheel speed sensor, front	01.85-06.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear			
Fg.no. F005650→	01.85-06.93		**0 265 002 208**
250 TD Turbo			**2,5 l 93 kW OM 602.962 5 Zyl.**
Wheel speed sensor, front	09.90-06.93	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Wheel speed sensor, rear			
Fg.no. F005650→	09.90-06.93		**0 265 002 208**
260 TE			**2,6 l 118-122 kW M 103.940 6 Zyl.**
Air flow sensor, gasoline injection	09.85-08.92		**0 438 121 033**
			0 986 439 333
Speed sensor, ignition/injection	09.85-08.92		**0 261 210 051**
Temperature sensor, intake air, injection system	09.85-08.92		**0 280 130 047**
Temperature sensor, coolant, injection system	09.85-08.92	2PO	**0 280 130 044**
Wheel speed sensor, front	09.85-08.92	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	09.85-08.92	ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
Fg.no. F005650→	09.85-08.92	AOS	**0 265 002 208**
280 TE			**2,8 l 142 kW M 104.942 6 Zyl.**
Air mass meter, gasoline injection	09.92-06.93		**0 280 217 500**
Speed sensor, ignition/injection			
Mot.no. →005789	09.92-06.93	GS,LLE	**0 261 210 055**
		GS,RLE	**0 261 210 066**
Mot.no. →048696	09.92-06.93	AG,LLE	**0 261 210 055**
		AG,RLE	**0 261 210 066**
Mot.no. 005790→	09.92-06.93	GS	**0 261 210 122**
Mot.no. 048697→	09.92-06.93	AG	**0 261 210 122**
Wheel speed sensor, front			
Fg.no. F264121→	09.92-06.93	LAB	**0 265 006 111**
		RAB	**0 265 006 109**

Product

Wheel speed sensor, front			
Fg.no. →F264120	09.92-06.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	09.92-06.93	AOS	**0 265 002 210**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
300 AMG TE 3.4			**3,4 l 190 kW M 104.980 6 Zyl.**
Speed sensor, ignition/injection	09.89-08.92		**0 261 210 051**
Temperature sensor, intake air, injection system			
Fg.no. B091699→,F124697→	09.89-08.92		**0 280 130 047**
Wheel speed sensor, front	09.89-08.92	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	09.89-08.92	AOS	**0 265 002 210**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
300 D Turbo 4MATIC T			**3,0 l 105/108 kW OM 603.963 6 Zyl.**
Air flow sensor, diesel	09.86-06.93		**0 281 002 024**
			0 281 002 028
Temperature sensor, coolant, diesel	09.86-06.93		**0 280 130 035**
Wheel speed sensor, front			
Fg.no. F128718→	09.86-06.93	LAB	**0 265 001 300**
		RAB	**0 265 001 298**
Fg.no. →F128717	09.86-06.93	LAB	**0 265 001 400**
		RAB	**0 265 001 398**
Wheel speed sensor, rear			
Fg.no. F005650→	09.86-06.93		**0 265 002 208**
300 TD			**3,0 l 80/83 kW OM 603.912 6 Zyl.**
Wheel speed sensor, front	09.86-06.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear			
Fg.no. F005650→	09.86-06.93		**0 265 002 208**
300 TD Turbo			**3,0 l 105-108 kW OM 603.960 6 Zyl.**
Air flow sensor, diesel	09.86-06.93		**0 281 002 024**
			0 281 002 028
Pressure sensor, intake manifold, diesel	09.86-06.93		**0 280 101 003**
Temperature sensor, coolant, diesel	09.86-06.93		**0 280 130 035**
Wheel speed sensor, front	09.86-06.93	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Wheel speed sensor, rear			
Fg.no. F005650→	09.86-06.93		**0 265 002 208**
300 TE			**3,0 l 132-138 kW M 103.983 6 Zyl.**
Air flow sensor, gasoline injection	01.86-08.92		**0 438 121 033**
			0 986 439 333
Speed sensor, ignition/injection	01.86-08.92		**0 261 210 051**
Temperature sensor, intake air, injection system	01.86-08.92		**0 280 130 047**
Temperature sensor, coolant, injection system	01.86-08.92	2PO	**0 280 130 044**
Wheel speed sensor, front	01.86-08.92	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	01.86-08.92	ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
Fg.no. F005650→	01.86-08.92	AOS	**0 265 002 208**
300 TE 4MATIC			**3,0 l 132/138 kW M 103.985 6 Zyl.**
Air flow sensor, gasoline injection	09.86-06.93		**0 438 121 033**
			0 986 439 333
Speed sensor, ignition/injection	09.86-06.93		**0 261 210 051**
Temperature sensor, intake air, injection system	09.86-06.93		**0 280 130 047**
Temperature sensor, coolant, injection system			
Mot.no. →002187	09.86-06.93	2PO,GS	**0 280 130 044**
Mot.no. →008267	09.86-06.93	2PO,AG	**0 280 130 044**

M

Product			
Wheel speed sensor, front			
Fg.no. F128718→	09.86-06.93	LAB	**0 265 001 300**
		RAB	**0 265 001 298**
Fg.no. →F128717	09.86-06.93	LAB	**0 265 001 400**
		RAB	**0 265 001 398**
Wheel speed sensor, rear			
Fg.no. F005650→	09.86-06.93		**0 265 002 208**
300 TE-24	**3,0 l 162 kW M 104.980 6 Zyl.**		
Speed sensor, ignition/injection	09.89-08.92		**0 261 210 051**
Temperature sensor, intake air, injection system			
Fg.no. B091699→,F124697→	09.89-08.92		**0 280 130 047**
Wheel speed sensor, front	09.89-08.92	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	09.89-08.92	AOS	**0 265 002 210**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**
320 TE	**3,2 l 162 kW M 104.992 6 Zyl.**		
Air mass meter, gasoline injection	09.92-06.93		**0 280 217 500**
Speed sensor, ignition/injection			
Mot.no. →004356	09.92-06.93	GS,LLE	**0 261 210 055**
Mot.no. →072236	09.92-06.93	AG,LLE	**0 261 210 055**
Mot.no. 004357→	09.92-06.93	GS,LLE	**0 261 210 122**
Mot.no. 072237→	09.92-06.93	AG,LLE	**0 261 210 122**
Wheel speed sensor, front			
Fg.no. F264121→	09.92-06.93	LAB	**0 265 006 111**
		RAB	**0 265 006 109**
Fg.no. →F264120	09.92-06.93	LAB	**0 265 001 284**
		RAB	**0 265 001 282**
Wheel speed sensor, rear	09.92-06.93	AOS	**0 265 002 210**
		ASR,LAB	**0 265 002 206**
		ASR,RAB	**0 265 002 204**

Serie 190

190 [201]	**2,0 l 63/66 kW M 102.921; M 102.938 4 Zyl.**		
Wheel speed sensor, front	10.82-09.88	LAB	**0 265 001 128**
		RAB	**0 265 001 126**
Wheel speed sensor, rear			
Fg.no. A287298→	10.82-09.88		**0 265 002 230**
Fg.no. →A287297	10.82-09.88		**0 265 002 008**
190 [201]	**2,0 l 75-77 kW M 102.924 4 Zyl.**		
Speed sensor, ignition/injection	09.88-08.93		**0 261 210 055**
Wheel speed sensor, front	09.88-08.93	LAB	**0 265 001 288**
		RAB	**0 265 001 286**
Wheel speed sensor, rear	09.88-08.93	EDS	**0 265 002 232**
		OED	**0 265 002 230**
190 D [201]	**2,0 l 53/55 kW OM 601.911 4 Zyl.**		
Wheel speed sensor, front	09.83-08.93	LAB	**0 265 001 288**
		RAB	**0 265 001 286**
Wheel speed sensor, rear	09.83-08.93	EDS	**0 265 002 232**
		OED	**0 265 002 230**
190 D 2.5 [201]	**2,5 l 66/69 kW OM 602.911 5 Zyl.**		
Wheel speed sensor, front	04.85-08.93	LAB	**0 265 001 288**
		RAB	**0 265 001 286**
Wheel speed sensor, rear	04.85-08.93	EDS	**0 265 002 232**
		OED	**0 265 002 230**
190 D 2.5 Turbo [201]	**2,5 l 90 kW OM 602.961 5 Zyl.**		
Wheel speed sensor, front	01.88-12.88	LAB	**0 265 001 288**
		RAB	**0 265 001 286**
Wheel speed sensor, rear	01.88-12.88		**0 265 002 232**
190 D 2.5 Turbo [201]	**2,5 l 93 kW OM 602.961 5 Zyl.**		
Air flow sensor, diesel	09.88-08.93		**0 281 002 035**
Temperature sensor, coolant, diesel	09.88-08.93		**0 280 130 035**

Product			
Wheel speed sensor, front	09.88-08.93	LAB	**0 265 001 288**
		RAB	**0 265 001 286**
Wheel speed sensor, rear	09.88-08.93		**0 265 002 232**
190 E [201]	**2,0 l 83 kW M 102.961 4 Zyl.**		
Temperature sensor, intake air, injection system	09.84-08.86		**0 280 130 047**
Temperature sensor, coolant, injection system	09.84-08.86		**0 280 130 035**
Wheel speed sensor, front	09.84-08.86	LAB	**0 265 001 288**
		RAB	**0 265 001 286**
Wheel speed sensor, rear	09.84-08.86	EDS	**0 265 002 232**
		OED	**0 265 002 230**
190 E [201]	**2,0 l 85 kW M 102.962 4 Zyl.**		
Air flow sensor, gasoline injection			
Mot.no. 026320→	09.85-08.86	AG	**0 438 121 043**
			0 986 439 343
Mot.no. 052714→	09.85-08.86	GS	**0 438 121 043**
			0 986 439 343
Speed sensor, ignition/injection	09.85-08.86		**0 261 210 055**
Temperature sensor, intake air, injection system	09.85-08.86		**0 280 130 047**
Temperature sensor, coolant, injection system			
Mot.no. →122335	09.85-08.86	AG	**0 280 130 044**
Mot.no. →236868	09.85-08.86	GS	**0 280 130 044**
Wheel speed sensor, front	09.85-08.86	LAB	**0 265 001 288**
		RAB	**0 265 001 286**
Wheel speed sensor, rear	09.85-08.86	EDS	**0 265 002 232**
		OED	**0 265 002 230**
190 E [201]	**2,0 l 89 kW M 102.961 4 Zyl.**		
Air flow sensor, gasoline injection	10.82-08.89		**0 986 439 301**
			F 026 TX2 060
Temperature sensor, intake air, injection system	10.82-08.89		**0 280 130 047**
Temperature sensor, coolant, injection system	10.82-08.89		**0 280 130 035**
Wheel speed sensor, front	10.82-08.89	LAB	**0 265 001 288**
		RAB	**0 265 001 286**
Wheel speed sensor, rear	10.82-08.89	EDS	**0 265 002 232**
		OED	**0 265 002 230**
190 E [201]	**2,0 l 90 kW M 102.962 4 Zyl.**		
Air flow sensor, gasoline injection	09.86-08.88		**0 438 121 043**
			0 986 439 343
Speed sensor, ignition/injection	09.84-08.88		**0 261 210 055**
Temperature sensor, intake air, injection system	09.84-08.88		**0 280 130 047**
Temperature sensor, coolant, injection system	09.84-08.88		**0 280 130 044**
Wheel speed sensor, front	09.84-08.88	LAB	**0 265 001 288**
		RAB	**0 265 001 286**
Wheel speed sensor, rear	09.84-08.88	EDS	**0 265 002 232**
		OED	**0 265 002 230**
190 E 1.8 [201]	**1,7 l 77 kW M 102.919 4 Zyl.**		
Air flow sensor, gasoline injection	05.92-08.93	KAT	**0 438 121 043**
			0 986 439 343
Speed sensor, ignition/injection	05.92-08.93		**0 261 210 055**
Temperature sensor, intake air, injection system	05.92-08.93		**0 280 130 047**
Temperature sensor, coolant, injection system	05.92-08.93	KOK	**0 280 130 035**
Wheel speed sensor, front	05.92-08.93	LAB	**0 265 001 288**
		RAB	**0 265 001 286**
Wheel speed sensor, rear	05.92-08.93	EDS	**0 265 002 232**
		OED	**0 265 002 230**
190 E 1.8 [201]	**1,8 l 80 kW M 102.910 4 Zyl.**		
Air flow sensor, gasoline injection	03.90-08.93	KAT	**0 438 121 043**
			0 986 439 343
Speed sensor, ignition/injection	03.90-08.93		**0 261 210 055**
Temperature sensor, intake air, injection system	03.90-08.93		**0 280 130 047**
Wheel speed sensor, front	03.90-08.93	LAB	**0 265 001 288**
		RAB	**0 265 001 286**
Wheel speed sensor, rear	03.90-08.93	EDS	**0 265 002 232**
		OED	**0 265 002 230**

M

Product

◀ Serie 190

190 E 2.0 [201]	**2,0 l 87 kW M 102.962 4 Zyl.**		
Air flow sensor, gasoline injection			
Mot.no. 026320→	09.86-09.93	AG	**0 438 121 043**
			0 986 439 343
Mot.no. 052714→	09.86-09.93	GS	**0 438 121 043**
			0 986 439 343
Speed sensor, ignition/injection	09.86-09.93		**0 261 210 055**
Temperature sensor, intake air, injection system	09.86-09.93		**0 280 130 047**
Temperature sensor, coolant, injection system			
Mot.no. →122335	09.86-09.93	AG	**0 280 130 044**
Mot.no. →236868	09.86-09.93	GS	**0 280 130 044**
Wheel speed sensor, front	09.86-09.93	LAB	**0 265 001 288**
		RAB	**0 265 001 286**
Wheel speed sensor, rear	09.86-09.93	EDS	**0 265 002 232**
		OED	**0 265 002 230**
190 E 2.3 [201]	**2,2 l 87 kW M 102.985 4 Zyl.**		
Speed sensor, ignition/injection	09.84-08.86		**0 261 210 055**
Temperature sensor, intake air, injection system	09.84-08.86		**0 280 130 047**
Temperature sensor, coolant, injection system			
Mot.no. →033729	09.84-08.86	GS	**0 280 130 044**
Mot.no. →080064	09.84-08.86	AG	**0 280 130 044**
Wheel speed sensor, front	09.84-08.86	LAB	**0 265 001 288**
		RAB	**0 265 001 286**
Wheel speed sensor, rear	09.84-08.86	EDS	**0 265 002 232**
		OED	**0 265 002 230**
190 E 2.3 [201]	**2,3 l 97 kW M 102.985 4 Zyl.**		
Air flow sensor, gasoline injection	09.89-08.92	KAT,VFA	**0 438 121 043**
			0 986 439 343
		OKA	**0 986 439 301**
			F 026 TX2 060
Speed sensor, ignition/injection	09.89-08.92		**0 261 210 055**
Pressure sensor, intake manifold, gasoline	09.89-08.92		**0 280 101 003**
Temperature sensor, intake air, injection system	09.89-08.92		**0 280 130 047**
Temperature sensor, coolant, injection system	09.89-08.92	KOK	**0 280 130 035**
Mot.no. →033729	09.89-08.92	GS	**0 280 130 044**
Mot.no. →080064	09.89-08.92	AG	**0 280 130 044**
Wheel speed sensor, front	09.89-08.92	LAB	**0 265 001 288**
		RAB	**0 265 001 286**
Wheel speed sensor, rear	09.89-08.92		**0 265 002 232**
190 E 2.3 [201]	**2,3 l 100 kW M 102.985 4 Zyl.**		
Air flow sensor, gasoline injection	09.86-08.93	KAT,VFA	**0 438 121 043**
			0 986 439 343
		OKA	**0 986 439 301**
			F 026 TX2 060
Speed sensor, ignition/injection	09.86-08.93		**0 261 210 055**
Temperature sensor, intake air, injection system	09.86-08.93		**0 280 130 047**
Temperature sensor, coolant, injection system	09.86-08.93	KOK	**0 280 130 035**
Mot.no. →033729	09.86-08.93	GS	**0 280 130 044**
Mot.no. →080064	09.86-08.93	AG	**0 280 130 044**
Wheel speed sensor, front	09.86-08.93	LAB	**0 265 001 288**
		RAB	**0 265 001 286**
Wheel speed sensor, rear	09.86-08.93		**0 265 002 232**
190 E 2.3-16 [201]	**2,3 l 125 kW M 102.983 4 Zyl.**		
Speed sensor, ignition/injection	09.85-12.88		**0 261 210 066**
Pressure sensor, intake manifold, gasoline	09.85-12.88		**0 280 101 003**
Temperature sensor, intake air, injection system	09.85-12.88		**0 280 130 047**
Temperature sensor, coolant, injection system	09.85-12.88		**0 280 130 044**
Wheel speed sensor, front	09.85-12.88	LAB	**0 265 001 128**
		RAB	**0 265 001 126**
Wheel speed sensor, rear			
Fg.no. A240012→,F205611→	09.85-12.88		**0 265 002 232**
Fg.no. →A240011,→F205610	09.85-12.88		**0 265 002 008**

Product

190 E 2.3-16 [201]	**2,3 l 130/136 kW M 102.983 4 Zyl.**		
Speed sensor, ignition/injection	04.84-08.88		**0 261 210 066**
Temperature sensor, intake air, injection system	04.84-08.88		**0 280 130 047**
Temperature sensor, coolant, injection system	04.84-08.88		**0 280 130 044**
Wheel speed sensor, front	04.84-08.88	LAB	**0 265 001 128**
		RAB	**0 265 001 126**
Wheel speed sensor, rear			
Fg.no. A240012→,F205611→	04.84-08.88		**0 265 002 232**
Fg.no. →A240011,→F205610	04.84-08.88		**0 265 002 008**
190 E 2.5-16 [201]	**2,5 l 143/150 kW M 102.990 4 Zyl.**		
Speed sensor, ignition/injection	09.88-08.93		**0 261 210 066**
Temperature sensor, intake air, injection system	09.88-08.93		**0 280 130 047**
Wheel speed sensor, front	09.88-08.93	LAB	**0 265 001 288**
		RAB	**0 265 001 286**
Wheel speed sensor, rear	09.88-08.93		**0 265 002 232**
190 E 2.5-16 Evolution I [201]	**2,5 l 143-150 kW M 102.991 4 Zyl.**		
Speed sensor, ignition/injection	03.89-04.90		**0 261 210 066**
Temperature sensor, intake air, injection system	03.89-04.90		**0 280 130 047**
Wheel speed sensor, front	03.89-04.90	LAB	**0 265 001 128**
		RAB	**0 265 001 126**
Wheel speed sensor, rear	03.89-04.90		**0 265 002 232**
190 E 2.5-16 Evolution II [201]	**2,5 l 173 kW M 102.992 4 Zyl.**		
Speed sensor, ignition/injection	05.90-08.93		**0 261 210 066**
Temperature sensor, intake air, injection system	05.90-08.93		**0 280 130 047**
Wheel speed sensor, front	05.90-08.93	LAB	**0 265 001 128**
		RAB	**0 265 001 126**
Wheel speed sensor, rear	05.90-08.93		**0 265 002 232**
190 E 2.6 [201]	**2,6 l 118/122 kW M 103.942 6 Zyl.**		
Air flow sensor, gasoline injection	09.86-08.93		**0 438 121 033**
			0 986 439 333
Speed sensor, ignition/injection	09.86-08.93		**0 261 210 049**
Pressure sensor, intake manifold, gasoline	09.86-08.93		**0 280 101 003**
Temperature sensor, intake air, injection system	09.86-08.93		**0 280 130 047**
Temperature sensor, coolant, injection system			
Mot.no. →014906	09.86-08.93	GS	**0 280 130 044**
Mot.no. →033963	09.86-08.93	AG	**0 280 130 044**
Wheel speed sensor, front	09.86-08.93	LAB	**0 265 001 288**
		RAB	**0 265 001 286**
Wheel speed sensor, rear	09.86-08.93		**0 265 002 232**
190 E 3.2 AMG [201]	**3,2 l 172 kW M 103.983 6 Zyl.**		
Air flow sensor, gasoline injection	09.88-08.93		**0 438 121 033**
			0 986 439 333
Temperature sensor, intake air, injection system	09.88-08.93		**0 280 130 047**
Temperature sensor, coolant, injection system			
Mot.no. →181461	09.88-08.93		**0 280 130 044**
Wheel speed sensor, front	09.88-08.93	LAB	**0 265 001 288**
		RAB	**0 265 001 286**
Wheel speed sensor, rear	09.88-08.93		**0 265 002 232**

Sprinter

208 CDI [T1N]	**2,2 l 60 kW OM 611.987 DE LA 4 Zyl.**		
Air mass meter, diesel	04.00-05.06		**0 280 217 517**
Speed sensor, diesel	04.00-05.06	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.00-05.06		**0 281 002 700**
Accelerator pedal module	04.00-05.06		**0 281 002 334**
		AG,SEG	**0 281 002 336**
Wheel speed sensor, front	04.00-05.06	H01	**0 265 004 009**
Wheel speed sensor, rear	04.00-05.06	H01	**0 265 004 010**
208 D [T1N]	**2,3 l 58-60 kW OM 601.943 4 Zyl.**		
Pedal position sensor, diesel	02.95-03.00		**0 205 001 029**
Wheel speed sensor, front	02.95-03.00	H01	**0 265 004 009**
Wheel speed sensor, rear	02.95-03.00	H01	**0 265 004 010**

M

Product			
209 CDI [NCV3]	**2,1 l 65 kW OM 646.984 DE 22 LA 4 Zyl.**		
Speed sensor, diesel	04.06→	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.06→		**0 281 002 682**
Boost pressure sensor, Diesel	04.06→		**0 261 230 143**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 628**
210 D [T1N]	**2,9 l 75 kW OM 602.980 DE LA 5 Zyl.**		
Speed sensor, diesel	01.97-03.00	OHL	**0 281 002 123**
Pedal position sensor, diesel	01.97-03.00		**0 205 001 029**
Wheel speed sensor, front	01.97-03.00	H01	**0 265 004 009**
Wheel speed sensor, rear	01.97-03.00	H01	**0 265 004 010**
211 CDI [NCV3]	**2,1 l 80 kW OM 646.985 DE 22 LA 4 Zyl.**		
Speed sensor, diesel	04.06→	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.06→		**0 281 002 682**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 628**
211 CDI [T1N]	**2,2 l 80 kW OM 611.981 DE LA 4 Zyl.**		
Air mass meter, diesel	04.00-05.06		**0 280 217 517**
Speed sensor, diesel	04.00-05.06	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.00-05.06		**0 281 002 700**
Accelerator pedal module	04.00-05.06		**0 281 002 334**
		AG,SEG	**0 281 002 336**
Wheel speed sensor, front	04.00-05.06	H01	**0 265 004 009**
Wheel speed sensor, rear	04.00-05.06	H01	**0 265 004 010**
212 D [T1N]	**2,9 l 90 kW OM 602.980 DE LA 5 Zyl.**		
Speed sensor, diesel	02.95-03.00	OHL	**0 281 002 123**
Pedal position sensor, diesel	02.95-03.00		**0 205 001 029**
Wheel speed sensor, front	02.95-03.00	H01	**0 265 004 009**
Wheel speed sensor, rear	02.95-03.00	H01	**0 265 004 010**
213 CDI [NCV3]	**2,1 l 95 kW OM 646.986 DE 22 LA 4 Zyl.**		
Speed sensor, diesel	04.06→	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.06→		**0 281 002 682**
Boost pressure sensor, Diesel			
Comp. no. 522630/13	04.06→	TNK	**0 261 230 143**
Comp. no. 522630/15	04.06→	TNK	**0 261 230 153**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 628**
213 CDI [T1N]	**2,2 l 95 kW OM 611.981 DE LA 4 Zyl.**		
Air mass meter, diesel	04.00-05.06		**0 280 217 517**
Speed sensor, diesel	04.00-05.06	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.00-05.06		**0 281 002 700**
Accelerator pedal module	04.00-05.06		**0 281 002 334**
		AG,SEG	**0 281 002 336**
Wheel speed sensor, front	04.00-05.06	H01	**0 265 004 009**
Wheel speed sensor, rear	04.00-05.06	H01	**0 265 004 010**
214 [T1N]	**2,3 l 105 kW M 111.979 4 Zyl.**		
Air mass meter, gasoline injection	02.95-03.00		**0 280 217 114**
Wheel speed sensor, front	02.95-03.00	H01	**0 265 004 009**
Wheel speed sensor, rear	02.95-03.00	H01	**0 265 004 010**
214 [T1N]	**2,3 l 105-108 kW M 111.984 4 Zyl.**		
Air mass meter, gasoline injection	04.00-05.06		**0 280 217 114**
Speed sensor, ignition/injection	04.00-05.06	FKW	**0 261 210 170**
Wheel speed sensor, front	04.00-05.06	H01	**0 265 004 009**
Wheel speed sensor, rear	04.00-05.06	H01	**0 265 004 010**
214 NGT [T1N]	**2,3 l 95 kW M 111 4 Zyl.**		
Wheel speed sensor, front	04.00-05.06	H01	**0 265 004 009**
Wheel speed sensor, rear	04.00-05.06	H01	**0 265 004 010**
215 CDI [NCV3]	**2,1 l 110 kW OM 646.9... DE 22 LA 4 Zyl.**		
Speed sensor, diesel	04.06→	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.06→		**0 281 002 682**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 628**

Product			
216 CDI [T1N]	**2,7 l 115 kW OM 612.981 DE LA 5 Zyl.**		
Air mass meter, diesel	04.00-05.06		**0 280 217 517**
Speed sensor, diesel	04.00-05.06	FKW	**0 261 210 170**
High-pressure sensor (CR system)			
Mot.no. →30 287865,→40 176145, →50 846433,→60 001942	04.00-05.06		**0 281 002 498**
Mot.no. 30 287866→,40 176146→, 50 846434→,60 001943→	04.00-05.06		**0 281 002 700**
Accelerator pedal module	04.00-05.06		**0 281 002 334**
		AG,SEG	**0 281 002 336**
Wheel speed sensor, front	04.00-05.06	H01	**0 265 004 009**
Wheel speed sensor, rear	04.00-05.06	H01	**0 265 004 010**
218 CDI [NCV3]	**3,0 l 135 kW OM 642.992 6 Zyl.**		
Air mass meter, diesel	04.06→		**0 281 002 656**
High-pressure sensor (CR system)	04.06→		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 628**
224 [NCV3]	**3,5 l 190 kW M 272.979 6 Zyl.**		
Air mass meter, gasoline injection	04.06→		**0 280 218 190**
Knock sensor	04.06→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 628**
308 CDI [T1N]	**2,2 l 60 kW OM 611.987 DE LA 4 Zyl.**		
Air mass meter, diesel	04.00-05.06		**0 280 217 517**
Speed sensor, diesel	04.00-05.06	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.00-05.06		**0 281 002 700**
Accelerator pedal module	04.00-05.06	AG,SEG	**0 281 002 336**
		GS	**0 281 002 334**
Wheel speed sensor, front	04.00-05.06	H01	**0 265 004 009**
Wheel speed sensor, rear	04.00-05.06	H01	**0 265 004 010**
308 D, D James Cook [T1N]	**2,3 l 58 kW OM 601.943 4 Zyl.**		
Pedal position sensor, diesel	02.95-03.00		**0 205 001 029**
Wheel speed sensor, front	02.95-03.00	H01	**0 265 004 009**
Wheel speed sensor, rear	02.95-03.00	H01	**0 265 004 010**
309 CDI [NCV3]	**2,1 l 65 kW OM 646.984 DE 22 LA 4 Zyl.**		
Speed sensor, diesel	04.06→	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.06→		**0 281 002 682**
Boost pressure sensor, Diesel	04.06→		**0 261 230 143**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 628**
310 D, D James Cook [T1N]	**2,9 l 75 kW OM 602.980 DE LA 5 Zyl.**		
Speed sensor, diesel	01.97-03.00	OHL	**0 281 002 123**
Pedal position sensor, diesel	01.97-03.00		**0 205 001 029**
Wheel speed sensor, front	01.97-03.00	H01	**0 265 004 009**
Wheel speed sensor, rear	01.97-03.00	H01	**0 265 004 010**
311 CDI	**2,2 l 80 kW OM 611 LA 4 Zyl.**		
Speed sensor, diesel	06.01-12.04	FKW	**0 261 210 170**
311 CDI [NCV3]	**2,1 l 80 kW OM 646.985 DE 22 LA 4 Zyl.**		
Speed sensor, diesel	04.06→	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.06→		**0 281 002 682**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 628**
311 CDI [T1N]	**2,1 l 80 kW OM 611.981 DE LA 4 Zyl.**		
Air mass meter, diesel	08.02-05.06		**0 280 217 517**
Speed sensor, diesel	08.02-05.06	FKW	**0 261 210 170**
High-pressure sensor (CR system)	08.02-05.06		**0 281 002 700**
Accelerator pedal module	08.02-05.06	AG,SEG	**0 281 002 336**
		GS	**0 281 002 334**
Wheel speed sensor, front	08.02-05.06	H01	**0 265 004 009**
Wheel speed sensor, rear	08.02-05.06	H01	**0 265 004 010**

M

Product			
◀ Sprinter			
311 CDI [T1N]	**2,2 l 80 kW OM 611.981 DE LA 4 Zyl.**		
Air mass meter, diesel	04.00-05.06		**0 280 217 517**
Speed sensor, diesel	04.00-05.06	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.00-05.06		**0 281 002 700**
Accelerator pedal module	04.00-05.06	AG,SEG	**0 281 002 336**
		GS	**0 281 002 334**
Wheel speed sensor, front	04.00-05.06	H01	**0 265 004 009**
Wheel speed sensor, rear	04.00-05.06	H01	**0 265 004 010**
312 D, D James Cook [T1N]	**2,9 l 90 kW OM 602.980 DE LA 5 Zyl.**		
Speed sensor, diesel	02.95-03.00	OHL	**0 281 002 123**
Pedal position sensor, diesel	02.95-03.00		**0 205 001 029**
Wheel speed sensor, front	02.95-03.00	H01	**0 265 004 009**
Wheel speed sensor, rear	02.95-03.00	H01	**0 265 004 010**
313 CDI	**2,2 l 95 kW OM 611 LA 4 Zyl.**		
Speed sensor, diesel	06.01→	FKW	**0 261 210 170**
313 CDI [NCV3]	**2,1 l 95 kW OM 646.986 DE 22 LA 4 Zyl.**		
Speed sensor, diesel	04.06→	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.06→		**0 281 002 682**
Boost pressure sensor, Diesel			
Comp. no. 522630/13	04.06→	TNK	**0 261 230 143**
Comp. no. 522630/15	04.06→	TNK	**0 261 230 153**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 628**
313 CDI [T1N]	**2,2 l 95 kW OM 611.981 DE LA 4 Zyl.**		
Air mass meter, diesel	04.00-05.06		**0 280 217 517**
Speed sensor, diesel	04.00-05.06	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.00-05.06		**0 281 002 700**
Accelerator pedal module	04.00-05.06	AG,SEG	**0 281 002 336**
		GS	**0 281 002 334**
Wheel speed sensor, front	04.00-05.06	H01	**0 265 004 009**
Wheel speed sensor, rear	04.00-05.06	H01	**0 265 004 010**
314 [T1N]	**2,3 l 105 kW M 111.979 4 Zyl.**		
Air mass meter, gasoline injection	02.95-03.00		**0 280 217 114**
Wheel speed sensor, front	02.95-03.00	H01	**0 265 004 009**
Wheel speed sensor, rear	02.95-03.00	H01	**0 265 004 010**
314 [T1N]	**2,3 l 105-108 kW M 111.984 4 Zyl.**		
Throttle valve assembly	04.00-05.06		**0 280 750 074**
Air mass meter, gasoline injection	04.00-05.06		**0 280 217 114**
Speed sensor, ignition/injection	04.00-05.06	FKW	**0 261 210 170**
Wheel speed sensor, front	04.00-05.06	H01	**0 265 004 009**
Wheel speed sensor, rear	04.00-05.06	H01	**0 265 004 010**
314 James Cook [T1N]	**2,3 l 105 kW M 111.979 4 Zyl.**		
Air mass meter, gasoline injection	02.95-08.02		**0 280 217 114**
Wheel speed sensor, front	02.95-08.02	H01	**0 265 004 009**
Wheel speed sensor, rear	02.95-08.02	H01	**0 265 004 010**
314 James Cook [T1N]	**2,3 l 105-108 kW M 111.984 4 Zyl.**		
Throttle valve assembly	08.02-05.06		**0 280 750 074**
Air mass meter, gasoline injection	08.02-05.06		**0 280 217 114**
Speed sensor, ignition/injection	08.02-05.06	FKW	**0 261 210 170**
Wheel speed sensor, front	08.02-05.06	H01	**0 265 004 009**
Wheel speed sensor, rear	08.02-05.06	H01	**0 265 004 010**
314 NGT [T1N]	**2,3 l 95 kW M 111 4 Zyl.**		
Wheel speed sensor, front	04.00-05.06	H01	**0 265 004 009**
Wheel speed sensor, rear	04.00-05.06	H01	**0 265 004 010**
315 CDI [NCV3]	**2,1 l 110 kW OM 646.9... DE 22 LA 4 Zyl.**		
Speed sensor, diesel	04.06→	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.06→		**0 281 002 682**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 628**
316 CDI [T1N]	**2,7 l 115 kW OM 612.981 DE LA 5 Zyl.**		
Air mass meter, diesel	04.00-05.06		**0 280 217 517**
Speed sensor, diesel	04.00-05.06	FKW	**0 261 210 170**
High-pressure sensor (CR system)			
Mot.no. →30 287865,→40 176145, →50 846433,→60 001942	04.00-05.06		**0 281 002 498**
Mot.no. 30 287866→,40 176146→, 50 846434→,60 001943→	04.00-05.06		**0 281 002 700**
Accelerator pedal module	04.00-05.06	AG,SEG	**0 281 002 336**
		GS	**0 281 002 334**
Wheel speed sensor, front	04.00-05.06	H01	**0 265 004 009**
Wheel speed sensor, rear	04.00-05.06	H01	**0 265 004 010**
316 CDI [T1N]	**2,7 l 115 kW OM 647.981 DE 27 LA 5 Zyl.**		
Air mass meter, diesel	10.04-05.06		**0 281 002 656**
Speed sensor, diesel	10.04-05.06	FKW	**0 261 210 170**
High-pressure sensor (CR system)	10.04-05.06		**0 281 002 504**
Wheel speed sensor, front	10.04-05.06	H01	**0 265 004 009**
Wheel speed sensor, rear	10.04-05.06	H01	**0 265 004 010**
316 CDI James Cook [T1N]	**2,7 l 115 kW OM 612.981 DE LA 5 Zyl.**		
Air mass meter, diesel	04.01-05.06		**0 280 217 517**
Speed sensor, diesel	04.01-05.06	FKW	**0 261 210 170**
High-pressure sensor (CR system)			
Mot.no. →30 287865,→40 176145, →50 846433,→60 001942	04.01-05.06		**0 281 002 498**
Mot.no. 30 287866→,40 176146→, 50 846434→,60 001943→	04.01-05.06		**0 281 002 700**
Accelerator pedal module	04.01-05.06	AG,SEG	**0 281 002 336**
		GS	**0 281 002 334**
Wheel speed sensor, front	04.01-05.06	H01	**0 265 004 009**
Wheel speed sensor, rear	04.01-05.06	H01	**0 265 004 010**
318 CDI [NCV3]	**3,0 l 135 kW OM 642.992 6 Zyl.**		
Air mass meter, diesel	04.06→		**0 281 002 656**
High-pressure sensor (CR system)	04.06→		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 628**
324 [NCV3]	**3,5 l 190 kW M 272.979 6 Zyl.**		
Air mass meter, gasoline injection	04.06→		**0 280 218 190**
Knock sensor	04.06→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 628**
408 CDI [T1N]	**2,2 l 60 kW OM 611.987 DE LA 4 Zyl.**		
Air mass meter, diesel	04.00-05.06		**0 280 217 517**
Speed sensor, diesel	04.00-05.06	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.00-05.06		**0 281 002 700**
Accelerator pedal module	04.00-05.06		**0 281 002 334**
		AG,SEG	**0 281 002 336**
Wheel speed sensor, front	04.00-05.06	H01	**0 265 004 009**
Wheel speed sensor, rear	04.00-05.06	H01	**0 265 004 010**
408 D [T1N]	**2,3 l 58 kW OM 601.943 4 Zyl.**		
Pedal position sensor, diesel	02.95-03.00		**0 205 001 029**
Wheel speed sensor, front	02.95-03.00	H01	**0 265 004 009**
Wheel speed sensor, rear	02.95-03.00	H01	**0 265 004 010**
410 D [T1N]	**2,9 l 75 kW OM 602.980 DE LA 5 Zyl.**		
Speed sensor, diesel	01.97-03.00	OHL	**0 281 002 123**
Pedal position sensor, diesel	01.97-03.00		**0 205 001 029**
Wheel speed sensor, front	01.97-03.00	H01	**0 265 004 009**
Wheel speed sensor, rear	01.97-03.00	H01	**0 265 004 010**
411 CDI [NCV3]	**2,1 l 80 kW OM 646.985 DE 22 LA 4 Zyl.**		
Speed sensor, diesel	04.06→	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.06→		**0 281 002 682**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 628**
411 CDI [T1N]	**2,2 l 80 kW OM 611.981 DE LA 4 Zyl.**		
Air mass meter, diesel	04.00-05.06		**0 280 217 517**
Speed sensor, diesel	04.00-05.06	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.00-05.06		**0 281 002 700**

Product			
Accelerator pedal module	04.00-05.06		**0 281 002 334**
		AG,SEG	**0 281 002 336**
Wheel speed sensor, front	04.00-05.06	H01	**0 265 004 009**
Wheel speed sensor, rear	04.00-05.06	H01	**0 265 004 010**
412 D [T1N]	**2,9 l 90 kW OM 602.980 DE LA 5 Zyl.**		
Speed sensor, diesel	02.95-03.00	OHL	**0 281 002 123**
Pedal position sensor, diesel	02.95-03.00		**0 205 001 029**
Wheel speed sensor, front	02.95-03.00	H01	**0 265 004 009**
Wheel speed sensor, rear	02.95-03.00	H01	**0 265 004 010**
413 CDI	**2,2 l 95 kW OM 611 LA 4 Zyl.**		
Speed sensor, diesel	06.01→	FKW	**0 261 210 170**
413 CDI [T1N]	**2,2 l 95 kW OM 611.981 DE LA 4 Zyl.**		
Air mass meter, diesel	04.00-05.06		**0 280 217 517**
Speed sensor, diesel	04.00-05.06	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.00-05.06		**0 281 002 700**
Accelerator pedal module	04.00-05.06		**0 281 002 334**
		AG,SEG	**0 281 002 336**
Wheel speed sensor, front	04.00-05.06	H01	**0 265 004 009**
Wheel speed sensor, rear	04.00-05.06	H01	**0 265 004 010**
414 [T1N]	**2,3 l 105 kW M 111.979 4 Zyl.**		
Air mass meter, gasoline injection	02.95-03.00		**0 280 217 114**
Wheel speed sensor, front	02.95-03.00	H01	**0 265 004 009**
Wheel speed sensor, rear	02.95-03.00	H01	**0 265 004 010**
414 [T1N]	**2,3 l 105-108 kW M 111.984 4 Zyl.**		
Air mass meter, gasoline injection	04.00-05.06		**0 280 217 114**
Speed sensor, ignition/injection	04.00-05.06	FKW	**0 261 210 170**
Wheel speed sensor, front	04.00-05.06	H01	**0 265 004 009**
Wheel speed sensor, rear	04.00-05.06	H01	**0 265 004 010**
415 CDI [NCV3]	**2,1 l 110 kW OM 646.9... DE 22 LA 4 Zyl.**		
Speed sensor, diesel	04.06→	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.06→		**0 281 002 682**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 628**
416 CDI [T1N]	**2,7 l 115 kW OM 612.981 DE LA 5 Zyl.**		
Air mass meter, diesel	04.00-05.06		**0 280 217 517**
Speed sensor, diesel	04.00-05.06	FKW	**0 261 210 170**
High-pressure sensor (CR system)			
Mot.no. →30 287865,→40 176145, →50 846433,→60 001942	04.00-05.06		**0 281 002 498**
Mot.no. 30 287866→,40 176146→, 50 846434→,60 001943→	04.00-05.06		**0 281 002 700**
Accelerator pedal module	04.00-05.06		**0 281 002 334**
		AG,SEG	**0 281 002 336**
Wheel speed sensor, front	04.00-05.06	H01	**0 265 004 009**
Wheel speed sensor, rear	04.00-05.06	H01	**0 265 004 010**
416 CDI [T1N]	**2,7 l 115 kW OM 647.981 DE 27 LA 5 Zyl.**		
Air mass meter, diesel	10.04-05.06		**0 281 002 656**
Speed sensor, diesel	10.04-05.06	FKW	**0 261 210 170**
High-pressure sensor (CR system)	10.04-05.06		**0 281 002 504**
Wheel speed sensor, front	10.04-05.06	H01	**0 265 004 009**
Wheel speed sensor, rear	10.04-05.06	H01	**0 265 004 010**
418 CDI [NCV3]	**3,0 l 135 kW OM 642.992 6 Zyl.**		
Air mass meter, diesel	04.06→		**0 281 002 656**
High-pressure sensor (CR system)	04.06→		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 628**
424 [NCV3]	**3,5 l 190 kW M 272.979 6 Zyl.**		
Air mass meter, gasoline injection	04.06→		**0 280 218 190**
Knock sensor	04.06→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 628**

Product			
509 CDI [NCV3]	**2,1 l 65 kW OM 646.984 DE 22 LA 4 Zyl.**		
Speed sensor, diesel	04.06→	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.06→		**0 281 002 682**
Boost pressure sensor, Diesel	04.06→		**0 261 230 143**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 628**
511 CDI [NCV3]	**2,1 l 80 kW OM 646.985 DE 22 LA 4 Zyl.**		
Speed sensor, diesel	04.06→	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.06→		**0 281 002 682**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 628**
515 CDI [NCV3]	**2,1 l 110 kW OM 646.9... DE 22 LA 4 Zyl.**		
Speed sensor, diesel	04.06→	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.06→		**0 281 002 682**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 628**
518 CDI [NCV3]	**3,0 l 135 kW OM 642.992 6 Zyl.**		
Air mass meter, diesel	04.06→		**0 281 002 656**
High-pressure sensor (CR system)	04.06→		**0 281 002 504**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 628**
524 [NCV3]	**3,5 l 190 kW M 272.979 6 Zyl.**		
Air mass meter, gasoline injection	04.06→		**0 280 218 190**
Knock sensor	04.06→		**0 261 231 188**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 628**
616 CDI [T1N]	**2,7 l 115 kW OM 612.981 DE LA 5 Zyl.**		
Air mass meter, diesel	02.01-05.06		**0 280 217 517**
Speed sensor, diesel	02.01-05.06	FKW	**0 261 210 170**
High-pressure sensor (CR system)			
Mot.no. →30 287865,→40 176145, →50 846433,→60 001942	02.01-05.06		**0 281 002 498**
Mot.no. 30 287866→,40 176146→, 50 846434→,60 001943→	02.01-05.06		**0 281 002 700**
Accelerator pedal module	02.01-05.06		**0 281 002 334**
		AG,SEG	**0 281 002 336**
Wheel speed sensor, front	02.01-05.06	H01	**0 265 004 009**
Wheel speed sensor, rear	02.01-05.06	H01	**0 265 004 010**

Vaneo

1.6 [414]	**1,6 l 60/75 kW M 166.961 4 Zyl.**		
Speed sensor, ignition/injection	02.02-08.05		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	02.02-08.05		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	02.02-08.05		**0 265 005 303**
Wheel speed sensor, front	02.02-08.05	LAB	**0 265 006 370**
		RAB	**0 265 006 368**
Wheel speed sensor, rear	02.02-08.05		**0 265 006 372**
1.7 CDI [414]	**1,7 l 55/67 kW OM 668.914 4 Zyl.**		
Air mass meter, diesel			
Mot.no. →30210110	02.02-08.05		**0 281 002 281**
Speed sensor, diesel	02.02-08.05		**0 261 210 170**
High-pressure sensor (CR system)	02.02-08.05		**0 281 002 498**
Duo sensor, acceleration and yaw rate, brake system	02.02-08.05		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	02.02-08.05		**0 265 005 303**
Wheel speed sensor, front	02.02-08.05	LAB	**0 265 006 370**
		RAB	**0 265 006 368**
Wheel speed sensor, rear	02.02-08.05		**0 265 006 372**

M

Product

◀ Vaneo

1.9 [414]			**1,9 l 92 kW M 166.991 4 Zyl.**
Speed sensor, ignition/injection	02.02-08.05		**0 261 210 170**
Duo sensor, acceleration and yaw rate, brake system	02.02-08.05		**0 265 005 258**
Pressure sensor, ESP, (electronic stability program)	02.02-08.05		**0 265 005 303**
Wheel speed sensor, front	02.02-08.05	LAB	**0 265 006 370**
		RAB	**0 265 006 368**
Wheel speed sensor, rear	02.02-08.05		**0 265 006 372**

Vario

O 810 [T2W]			**4,2 l 75 kW OM 904.904 LA 4 Zyl.**
Boost pressure sensor, Diesel			
Mot.no. →040487	09.96-01.01		**0 281 002 468**
Mot.no. 040488→	09.96-01.01		**0 281 002 244**
Wheel speed sensor, front	09.96-01.01	AA	**0 265 004 012**
		NAA	**0 265 004 011**
Wheel speed sensor, rear	09.96-01.01	LAB	**0 265 004 015**
		RAB	**0 265 004 016**
O 812 [T2W]			**2,9 l 90 kW OM 602.98... LA 5 Zyl.**
Speed sensor, diesel	09.96-01.01	OHL	**0 281 002 123**
Pedal position sensor, diesel	09.96-01.01		**0 205 001 029**
Wheel speed sensor, front	09.96-01.01	AA	**0 265 004 012**
		NAA	**0 265 004 011**
Wheel speed sensor, rear	09.96-01.01	LAB	**0 265 004 015**
		RAB	**0 265 004 016**
O 814 [T2W]			**4,2 l 100 kW OM 904.908 LA 4 Zyl.**
Boost pressure sensor, Diesel			
Mot.no. →040487	09.96-01.01		**0 281 002 468**
Mot.no. 040488→	09.96-01.01		**0 281 002 244**
Pedal position sensor, diesel	09.96-01.01		**0 205 001 029**
Wheel speed sensor, front	09.96-01.01	AA	**0 265 004 012**
		NAA	**0 265 004 011**
Wheel speed sensor, rear	09.96-01.01	LAB	**0 265 004 015**
		RAB	**0 265 004 016**
O 815 [T2W]			**4,2 l 112 kW OM 904.923 LA 4 Zyl.**
Boost pressure sensor, Diesel			
Mot.no. →040487	09.96-01.01		**0 281 002 468**
Mot.no. 040488→	09.96-01.01		**0 281 002 244**
Wheel speed sensor, front	09.96-01.01	AA	**0 265 004 012**
		NAA	**0 265 004 011**
Wheel speed sensor, rear	09.96-01.01	LAB	**0 265 004 015**
		RAB	**0 265 004 016**
512 D [T2W]			**2,9 l 90 kW OM 602.984 LA 5 Zyl.**
Speed sensor, diesel	09.96-01.01	OHL	**0 281 002 123**
Pedal position sensor, diesel	09.96-01.01		**0 205 001 029**
Wheel speed sensor, front	09.96-01.01	AA	**0 265 004 012**
		NAA	**0 265 004 011**
Wheel speed sensor, rear	09.96-01.01	LAB	**0 265 004 015**
		RAB	**0 265 004 016**
612 D [T2W]			**2,9 l 90 kW OM 602.984,985 LA 5 Zyl.**
Speed sensor, diesel	09.96-01.01	OHL	**0 281 002 123**
Pedal position sensor, diesel	09.96-01.01		**0 205 001 029**
Wheel speed sensor, front	09.96-01.01	AA	**0 265 004 012**
		NAA	**0 265 004 011**
Wheel speed sensor, rear	09.96-01.01	LAB	**0 265 004 015**
		RAB	**0 265 004 016**
613 D [T2W]			**4,2 l 95 kW OM 900.917 (904 LA) 4 Zyl.**
Boost pressure sensor, Diesel	09.06→		**0 281 002 468**
Wheel speed sensor, front	09.06→	AA	**0 265 004 012**
		NAA	**0 265 004 011**
Wheel speed sensor, rear	09.06→	LAB	**0 265 004 015**
		RAB	**0 265 004 016**

Product

614 D [T2W]			**4,2 l 100 kW OM 904.908 LA 4 Zyl.**
Boost pressure sensor, Diesel			
Mot.no. →040487	09.96-01.01		**0 281 002 468**
Mot.no. 040488→	09.96-01.01		**0 281 002 244**
Pedal position sensor, diesel	09.96-01.01		**0 205 001 029**
Wheel speed sensor, front	09.96-01.01	AA	**0 265 004 012**
		NAA	**0 265 004 011**
Wheel speed sensor, rear	09.96-01.01	LAB	**0 265 004 015**
		RAB	**0 265 004 016**
614 D [T2W]			**4,2 l 100 kW OM 904.914 LA 4 Zyl.**
Boost pressure sensor, Diesel			
Mot.no. →040487	01.01-09.06		**0 281 002 468**
Mot.no. 040488→	01.01-09.06		**0 281 002 244**
Wheel speed sensor, front	01.01-09.06	AA	**0 265 004 012**
		NAA	**0 265 004 011**
Wheel speed sensor, rear	01.01-09.06	LAB	**0 265 004 015**
		RAB	**0 265 004 016**
615 D [T2W]			**4,2 l 110/112 kW OM 904.923 LA; OM 904.936 LA 4 Zyl.**
Boost pressure sensor, Diesel			
Mot.no. →040487	10.98-09.06		**0 281 002 468**
Mot.no. 040488→	10.98-09.06		**0 281 002 244**
Wheel speed sensor, front	10.98-09.06	AA	**0 265 004 012**
		NAA	**0 265 004 011**
Wheel speed sensor, rear	10.98-09.06	LAB	**0 265 004 015**
		RAB	**0 265 004 016**
616 D [T2W]			**4,2 l 115 kW OM 900.918 (904 LA) 4 Zyl.**
Boost pressure sensor, Diesel	09.06→		**0 281 002 468**
Wheel speed sensor, front	09.06→	AA	**0 265 004 012**
		NAA	**0 265 004 011**
Wheel speed sensor, rear	09.06→	LAB	**0 265 004 015**
		RAB	**0 265 004 016**
618 D [T2W]			**4,2 l 130 kW OM 900.919 (904 LA) 4 Zyl.**
Boost pressure sensor, Diesel	09.06→		**0 281 002 468**
Wheel speed sensor, front	09.06→	AA	**0 265 004 012**
		NAA	**0 265 004 011**
Wheel speed sensor, rear	09.06→	LAB	**0 265 004 015**
		RAB	**0 265 004 016**
618 D [T2W]			**4,2 l 130 kW OM 904.964 LA 4 Zyl.**
Boost pressure sensor, Diesel			
Mot.no. →040487	06.03-09.06		**0 281 002 468**
Mot.no. 040488→	06.03-09.06		**0 281 002 244**
Wheel speed sensor, front	06.03-09.06	AA	**0 265 004 012**
		NAA	**0 265 004 011**
Wheel speed sensor, rear	06.03-09.06	LAB	**0 265 004 015**
		RAB	**0 265 004 016**
810 DT [T2W]			**4,2 l 75 kW OM 904.904 LA 4 Zyl.**
Boost pressure sensor, Diesel			
Mot.no. →040487	09.96-09.06		**0 281 002 468**
Mot.no. 040488→	09.96-09.06		**0 281 002 244**
Pedal position sensor, diesel	09.96-09.06		**0 205 001 029**
Wheel speed sensor, front	09.96-09.06	AA	**0 265 004 012**
		NAA	**0 265 004 011**
Wheel speed sensor, rear	09.96-09.06	LAB	**0 265 004 015**
		RAB	**0 265 004 016**
812 D [T2W]			**2,9 l 90 kW OM 602.984,985 LA 5 Zyl.**
Speed sensor, diesel	09.96-09.06	OHL	**0 281 002 123**
Pedal position sensor, diesel	09.96-09.06		**0 205 001 029**
Wheel speed sensor, front	09.96-09.06	AA	**0 265 004 012**
		NAA	**0 265 004 011**
Wheel speed sensor, rear	09.96-09.06	LAB	**0 265 004 015**
		RAB	**0 265 004 016**

Product			
813 D/DA [T2W]	**4,2 l 95 kW OM 900.917 (904 LA) 4 Zyl.**		
Boost pressure sensor, Diesel	09.06→		**0 281 002 468**
Wheel speed sensor, front	09.06→	AA	**0 265 004 012**
		NAA	**0 265 004 011**
Wheel speed sensor, rear	09.06→	LAB	**0 265 004 015**
		RAB	**0 265 004 016**
814 D [T2W]	**4,2 l 100 kW OM 904.908 LA 4 Zyl.**		
Boost pressure sensor, Diesel			
Mot.no. →040487	09.96-01.01		**0 281 002 468**
Mot.no. 040488→	09.96-01.01		**0 281 002 244**
Pedal position sensor, diesel	09.96-01.01		**0 205 001 029**
Wheel speed sensor, front	09.96-01.01	AA	**0 265 004 012**
		NAA	**0 265 004 011**
Wheel speed sensor, rear	09.96-01.01	LAB	**0 265 004 015**
		RAB	**0 265 004 016**
814 D [T2W]	**4,2 l 100 kW OM 904.914 LA 4 Zyl.**		
Boost pressure sensor, Diesel			
Mot.no. →040487	01.01-09.06		**0 281 002 468**
Mot.no. 040488→	01.01-09.06		**0 281 002 244**
Wheel speed sensor, front	01.01-09.06	AA	**0 265 004 012**
		NAA	**0 265 004 011**
Wheel speed sensor, rear	01.01-09.06	LAB	**0 265 004 015**
		RAB	**0 265 004 016**
814 DA [T2W]	**4,2 l 100-112 kW OM 904.908,923 LA 4 Zyl.**		
Boost pressure sensor, Diesel			
Mot.no. →040487	09.96-01.01		**0 281 002 468**
Mot.no. 040488→	09.96-01.01		**0 281 002 244**
Pedal position sensor, diesel	09.96-01.01		**0 205 001 029**
Wheel speed sensor, front	09.96-01.01	AA	**0 265 004 012**
		NAA	**0 265 004 011**
Wheel speed sensor, rear	09.96-01.01	LAB	**0 265 004 015**
		RAB	**0 265 004 016**
815 D [T2W]	**4,2 l 110 kW OM 904.936 LA 4 Zyl.**		
Boost pressure sensor, Diesel			
Mot.no. →040487	01.01-09.06		**0 281 002 468**
Mot.no. 040488→	01.01-09.06		**0 281 002 244**
Wheel speed sensor, front	01.01-09.06	AA	**0 265 004 012**
		NAA	**0 265 004 011**
Wheel speed sensor, rear	01.01-09.06	LAB	**0 265 004 015**
		RAB	**0 265 004 016**
815 D [T2W]	**4,2 l 110-112 kW OM 904.923,936 LA 4 Zyl.**		
Boost pressure sensor, Diesel			
Mot.no. →040487	09.96-01.01		**0 281 002 468**
Mot.no. 040488→	09.96-01.01		**0 281 002 244**
Pedal position sensor, diesel	09.96-01.01		**0 205 001 029**
Wheel speed sensor, front	09.96-01.01	AA	**0 265 004 012**
		NAA	**0 265 004 011**
Wheel speed sensor, rear	09.96-01.01	LAB	**0 265 004 015**
		RAB	**0 265 004 016**
815 DA [T2W]	**4,2 l 112 kW OM 904.908,923 LA 4 Zyl.**		
Boost pressure sensor, Diesel			
Mot.no. →040487	01.96-01.01		**0 281 002 468**
Mot.no. 040488→	01.96-01.01		**0 281 002 244**
Pedal position sensor, diesel	01.96-01.01		**0 205 001 029**
Wheel speed sensor, front	01.96-01.01	AA	**0 265 004 012**
		NAA	**0 265 004 011**
Wheel speed sensor, rear	01.96-01.01	LAB	**0 265 004 015**
		RAB	**0 265 004 016**
816 D/DA [T2W]	**4,2 l 115 kW OM 900.918 (904 LA) 4 Zyl.**		
Boost pressure sensor, Diesel	09.06→		**0 281 002 468**
Wheel speed sensor, front	09.06→	AA	**0 265 004 012**
		NAA	**0 265 004 011**

Product			
Wheel speed sensor, rear	09.06→	LAB	**0 265 004 015**
		RAB	**0 265 004 016**
818 D [T2W]	**4,2 l 130 kW OM 904.964 LA 4 Zyl.**		
Boost pressure sensor, Diesel			
Mot.no. →040487	06.03-09.06		**0 281 002 468**
Mot.no. 040488→	06.03-09.06		**0 281 002 244**
Wheel speed sensor, front	06.03-09.06	AA	**0 265 004 012**
		NAA	**0 265 004 011**
Wheel speed sensor, rear	06.03-09.06	LAB	**0 265 004 015**
		RAB	**0 265 004 016**
818 D/DA [T2W]	**4,2 l 130 kW OM 900.919 (904 LA) 4 Zyl.**		
Boost pressure sensor, Diesel	09.06→		**0 281 002 468**
Wheel speed sensor, front	09.06→	AA	**0 265 004 012**
		NAA	**0 265 004 011**
Wheel speed sensor, rear	09.06→	LAB	**0 265 004 015**
		RAB	**0 265 004 016**

Viano

2.0 CDI [639 T0N]	**2,1 l 80/85 kW OM 646.981; OM 646.982 4 Zyl.**		
Air mass meter, diesel	09.03→		**0 281 002 585**
Speed sensor, diesel	09.03→		**0 261 210 170**
High-pressure sensor (CR system)	09.03→		**0 281 002 504**
Boost pressure sensor, Diesel	09.03→		**0 261 230 141**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →195055	09.03→		**0 265 005 258**
Fg.no. 195056→	09.03→		**0 265 005 628**
Steering angle sensor, ESP (electronic stability program)	09.03→		**0 265 005 429**
2.2 CDI [639 T0N]	**2,1 l 110 kW OM 646.982 4 Zyl.**		
Air mass meter, diesel	09.03→		**0 281 002 585**
Speed sensor, diesel	09.03→		**0 261 210 170**
High-pressure sensor (CR system)	09.03→		**0 281 002 504**
Boost pressure sensor, Diesel	09.03→		**0 261 230 141**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →195055	09.03→		**0 265 005 258**
Fg.no. 195056→	09.03→		**0 265 005 628**
Steering angle sensor, ESP (electronic stability program)	09.03→		**0 265 005 429**
3.0 [639 T0N]	**3,2 l 140 kW M 112.951 6 Zyl.**		
Air mass meter, gasoline injection	09.03→		**0 280 217 515**
Phase sensor	09.03→	NOC	**0 232 103 037**
Speed sensor, ignition/injection	09.03→	FKW	**0 261 210 170**
Knock sensor	09.03→		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →195055	09.03→		**0 265 005 258**
Fg.no. 195056→	09.03→		**0 265 005 628**
Steering angle sensor, ESP (electronic stability program)	09.03→		**0 265 005 429**
3.0 CDI [639 T0N]	**3,0 l 150 kW OM 642.990 6 Zyl.**		
Air mass meter, diesel			
Fg.no. →298499	04.06-11.06		**0 281 002 656**
High-pressure sensor (CR system)	04.06→		**0 281 002 504**
Boost pressure sensor, Diesel	04.06→		**0 261 230 143**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →195055	04.06→		**0 265 005 258**
Fg.no. 195056→	04.06→		**0 265 005 628**
Steering angle sensor, ESP (electronic stability program)	04.06→		**0 265 005 429**

M

Product

◀ Viano

3.2 [639 T0N]			**3,2 l 160 kW M 112.951 6 Zyl.**
Air mass meter, gasoline injection	09.03→		**0 280 217 515**
Phase sensor	09.03→	NOC	**0 232 103 037**
Speed sensor, ignition/injection	09.03→	FKW	**0 261 210 170**
Knock sensor	09.03→		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →195055	09.03→		**0 265 005 258**
Fg.no. 195056→	09.03→		**0 265 005 628**
Steering angle sensor, ESP (electronic stability program)	09.03→		**0 265 005 429**
3.5 [639 T0N]			**3,7 l 170 kW M 112.976 6 Zyl.**
Throttle valve assembly	06.04→		**0 280 750 019**
Air mass meter, gasoline injection	06.04→		**0 280 217 515**
Phase sensor	06.04→	NOC	**0 232 103 037**
Speed sensor, ignition/injection	06.04→	FKW	**0 261 210 170**
Knock sensor	06.04→		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →195055	06.04→		**0 265 005 258**
Fg.no. 195056→	06.04→		**0 265 005 628**
Steering angle sensor, ESP (electronic stability program)	06.04→		**0 265 005 429**

Vito

108 CDI [638 T0N]			**2,2 l 60 kW OM 611.980 4 Zyl.**
Air mass meter, diesel	04.99-09.03		**0 280 217 114**
Speed sensor, diesel	04.99-09.03	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.99-09.03		**0 281 002 700**
Wheel speed sensor, front	04.99-09.03		**0 265 006 214**
Wheel speed sensor, rear	04.99-09.03		**0 265 006 215**
108 D [638 T0N]			**2,3 l 60 kW OM 601.942 4 Zyl.**
Air mass meter, diesel	11.95-09.03		**0 280 217 523**
Pedal position sensor, diesel	11.95-09.03		**0 205 001 029**
Wheel speed sensor, front	11.95-09.03		**0 265 006 214**
Wheel speed sensor, rear	11.95-09.03		**0 265 006 215**
109 CDI [639 T0N]			**2,1 l 65/70 kW OM 646.980; OM 646.983 4 Zyl.**
Air mass meter, diesel	10.03→		**0 281 002 585**
Speed sensor, diesel	10.03→		**0 261 210 170**
High-pressure sensor (CR system)	10.03→		**0 281 002 504**
Boost pressure sensor, Diesel	10.03→		**0 261 230 141**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →195055	10.03→		**0 265 005 258**
Fg.no. 195056→	10.03→		**0 265 005 628**
Steering angle sensor, ESP (electronic stability program)	10.03→		**0 265 005 429**
110 CDI [638 T0N]			**2,2 l 75 kW OM 611.980 4 Zyl.**
Air mass meter, diesel	04.99-09.03		**0 280 217 114**
Speed sensor, diesel	04.99-09.03	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.99-09.03		**0 281 002 700**
Wheel speed sensor, front	04.99-09.03		**0 265 006 214**
Wheel speed sensor, rear	04.99-09.03		**0 265 006 215**
110 D [638 T0N]			**2,3 l 72 kW OM 601.970 4 Zyl.**
Air mass meter, diesel	11.95-09.03		**0 280 217 523**
Pedal position sensor, diesel	11.95-09.03		**0 205 001 029**
Wheel speed sensor, front	11.95-09.03		**0 265 006 214**
Wheel speed sensor, rear	11.95-09.03		**0 265 006 215**
111 CDI [639 T0N]			**2,1 l 80/85 kW OM 646.981; OM 646.982 4 Zyl.**
Air mass meter, diesel	10.03→		**0 281 002 585**
Speed sensor, diesel	10.03→		**0 261 210 170**

Product

High-pressure sensor (CR system)	10.03→		**0 281 002 504**
Boost pressure sensor, Diesel	10.03→		**0 261 230 141**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →195055	10.03→		**0 265 005 258**
Fg.no. 195056→	10.03→		**0 265 005 628**
Steering angle sensor, ESP (electronic stability program)	10.03→		**0 265 005 429**
112 CDI [638 T0N]			**2,2 l 90 kW OM 611.980 4 Zyl.**
Air mass meter, diesel	04.99-09.03		**0 280 217 114**
Speed sensor, diesel	04.99-09.03	FKW	**0 261 210 170**
High-pressure sensor (CR system)	04.99-09.03		**0 281 002 700**
Wheel speed sensor, front	04.99-09.03		**0 265 006 214**
Wheel speed sensor, rear	04.99-09.03		**0 265 006 215**
113 [638 T0N]			**2,0 l 95 kW M 111.950 4 Zyl.**
Air mass meter, gasoline injection	11.95-09.03		**0 280 217 114**
Speed sensor, ignition/injection	11.95-09.03	FKW	**0 261 210 170**
Wheel speed sensor, front	11.95-09.03		**0 265 006 214**
Wheel speed sensor, rear	11.95-09.03		**0 265 006 215**
113 [638 T0N]			**2,0 l 100 kW M 111.948 4 Zyl.**
Air mass meter, gasoline injection	11.95-09.03		**0 280 217 523**
Pedal position sensor, EMS (electronic engine management)	11.95-09.03		**0 205 001 029**
Wheel speed sensor, front	11.95-09.03		**0 265 006 214**
Wheel speed sensor, rear	11.95-09.03		**0 265 006 215**
114 [638 T0N]			**2,3 l 105 kW M 111.978 4 Zyl.**
Air mass meter, gasoline injection	11.95-09.03		**0 280 217 523**
Wheel speed sensor, front	11.95-09.03		**0 265 006 214**
Wheel speed sensor, rear	11.95-09.03		**0 265 006 215**
114 [638 T0N]			**2,3 l 105 kW M 111.980 4 Zyl.**
Air mass meter, gasoline injection	11.95-09.03		**0 280 217 114**
Speed sensor, ignition/injection	11.95-09.03		**0 261 210 170**
Wheel speed sensor, front	11.95-09.03		**0 265 006 214**
Wheel speed sensor, rear	11.95-09.03		**0 265 006 215**
115 CDI [639 T0N]			**2,1 l 110 kW OM 646.982 4 Zyl.**
Air mass meter, diesel	10.03→		**0 281 002 585**
Speed sensor, diesel	10.03→		**0 261 210 170**
High-pressure sensor (CR system)	10.03→		**0 281 002 504**
Boost pressure sensor, Diesel	10.03→		**0 261 230 141**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →195055	10.03→		**0 265 005 258**
Fg.no. 195056→	10.03→		**0 265 005 628**
Steering angle sensor, ESP (electronic stability program)	10.03→		**0 265 005 429**
119 [639 T0N]			**3,2 l 140 kW M 112.951 6 Zyl.**
Air mass meter, gasoline injection	10.03→		**0 280 217 515**
Phase sensor	10.03→	NOC	**0 232 103 037**
Speed sensor, ignition/injection	10.03→	FKW	**0 261 210 170**
Knock sensor	10.03→		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →195055	10.03→		**0 265 005 258**
Fg.no. 195056→	10.03→		**0 265 005 628**
Steering angle sensor, ESP (electronic stability program)	10.03→		**0 265 005 429**
120 CDI [639 T0N]			**3,0 l 150 kW OM 642.990 6 Zyl.**
Air mass meter, diesel			
Fg.no. →298499	04.06-11.06		**0 281 002 656**
High-pressure sensor (CR system)	04.06→		**0 281 002 504**
Boost pressure sensor, Diesel	04.06→		**0 261 230 143**

Product			
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →195055	04.06→		**0 265 005 258**
Fg.no. 195056→	04.06→		**0 265 005 628**
Steering angle sensor, ESP (electronic stability program)	04.06→		**0 265 005 429**
122 [639 T0N]	**3,2 l 160 kW M 112.951 6 Zyl.**		
Air mass meter, gasoline injection	10.03→		**0 280 217 515**
Phase sensor	10.03→	NOC	**0 232 103 037**
Speed sensor, ignition/injection	10.03→	FKW	**0 261 210 170**
Knock sensor	10.03→		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →195055	10.03→		**0 265 005 258**
Fg.no. 195056→	10.03→		**0 265 005 628**
Steering angle sensor, ESP (electronic stability program)	10.03→		**0 265 005 429**
123 [639 T0N]	**3,7 l 170 kW M 112.976 6 Zyl.**		
Throttle valve assembly	06.04→		**0 280 750 019**
Air mass meter, gasoline injection	06.04→		**0 280 217 515**
Phase sensor	06.04→	NOC	**0 232 103 037**
Speed sensor, ignition/injection	06.04→	FKW	**0 261 210 170**
Knock sensor	06.04→		**0 261 231 110**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →195055	06.04→		**0 265 005 258**
Fg.no. 195056→	06.04→		**0 265 005 628**
Steering angle sensor, ESP (electronic stability program)	06.04→		**0 265 005 429**

2t

207 D [T1]	**2,4 l 53 kW OM 616.937,939 4 Zyl.**		
Wheel speed sensor, front	01.88-01.89		**0 265 001 126**
Wheel speed sensor, rear	01.88-08.88	LAB	**0 265 001 240**
		RAB	**0 265 001 239**
Fg.no. →P 217440	01.88-01.89	EFV,LAB	**0 265 001 240**
		EFV,RAB	**0 265 001 239**
208 D [T1]	**2,3 l 58-60 kW OM 601.940 4 Zyl.**		
Wheel speed sensor, front	10.88-06.95		**0 265 001 126**
Wheel speed sensor, rear			
Fg.no. →P 217440	10.88-06.95	EFV,LAB	**0 265 001 240**
		EFV,RAB	**0 265 001 239**
209 D [T1]	**3,0 l 65 kW OM 617.913 5 Zyl.**		
Wheel speed sensor, front	01.88-01.89		**0 265 001 126**
Wheel speed sensor, rear	01.88-08.88	LAB	**0 265 001 240**
		RAB	**0 265 001 239**
Fg.no. →P 217440	01.88-01.89	EFV,LAB	**0 265 001 240**
		EFV,RAB	**0 265 001 239**
210 [T1]	**2,3 l 70-77 kW M 102.942; M 102.945 4 Zyl.**		
Wheel speed sensor, front	01.88-06.95		**0 265 001 126**
Wheel speed sensor, rear	01.88-08.88	LAB	**0 265 001 240**
		RAB	**0 265 001 239**
Fg.no. →P 217440	01.88-06.95	EFV,LAB	**0 265 001 240**
		EFV,RAB	**0 265 001 239**
210 D [T1]	**2,9 l 70-72 kW OM 602.940 5 Zyl.**		
Wheel speed sensor, front	10.88-06.95		**0 265 001 126**
Wheel speed sensor, rear			
Fg.no. →P 217440	10.88-06.95	EFV,LAB	**0 265 001 240**
		EFV,RAB	**0 265 001 239**

3t

307 D [T1]	**2,4 l 53 kW OM 616.937,939 4 Zyl.**		
Wheel speed sensor, rear	01.88-08.88	LAB	**0 265 001 240**
	09.88-01.89	LAB	**0 265 001 240**
	01.88-08.88	RAB	**0 265 001 239**
	09.88-01.89	RAB	**0 265 001 239**
308 D [T1]	**2,3 l 58-60 kW OM 601.940 4 Zyl.**		
Wheel speed sensor, rear	10.88-06.95	LAB	**0 265 001 240**
	10.88-02.94	RAB	**0 265 001 239**
309 D [T1]	**3,0 l 65 kW OM 617.913 5 Zyl.**		
Wheel speed sensor, rear	01.88-08.88	LAB	**0 265 001 240**
	09.88-01.89	LAB	**0 265 001 240**
	01.88-08.88	RAB	**0 265 001 239**
	09.88-01.89	RAB	**0 265 001 239**
310 [T1]	**2,3 l 70-77 kW M 102.942 4 Zyl.**		
Wheel speed sensor, rear	01.88-08.88	LAB	**0 265 001 240**
	09.88-06.95	LAB	**0 265 001 240**
	01.88-08.88	RAB	**0 265 001 239**
310 [T1]	**2,3 l 70-77 kW M 102.942; M 102.945 4 Zyl.**		
Wheel speed sensor, rear	01.88-08.88	LAB	**0 265 001 240**
	09.88-02.94	RAB	**0 265 001 239**
310 [T1]	**2,3 l 70-77 kW M 102.945 4 Zyl.**		
Wheel speed sensor, rear	09.88-06.95	LAB	**0 265 001 240**
	01.88-08.88	RAB	**0 265 001 239**
	09.88-02.94	RAB	**0 265 001 239**
310 D [T1]	**2,9 l 70-72 kW OM 602.940 5 Zyl.**		
Wheel speed sensor, rear	10.88-06.95	LAB	**0 265 001 240**
	10.88-02.94	RAB	**0 265 001 239**

4t

407 D [T1]	**2,4 l 53 kW OM 616.913,939 4 Zyl.**		
Wheel speed sensor, rear	01.88-08.88	LAB	**0 265 001 240**
	09.88-01.89	LAB	**0 265 001 240**
	01.88-08.88	RAB	**0 265 001 239**
	09.88-01.89	RAB	**0 265 001 239**
408 D [T1]	**2,3 l 58-60 kW OM 601.940 4 Zyl.**		
Wheel speed sensor, rear	11.88-06.95	LAB	**0 265 001 240**
	11.88-02.94	RAB	**0 265 001 239**
409 D [T1]	**3,0 l 65 kW OM 617.913 5 Zyl.**		
Wheel speed sensor, rear	01.88-08.88	LAB	**0 265 001 240**
	09.88-01.89	LAB	**0 265 001 240**
	01.88-08.88	RAB	**0 265 001 239**
	09.88-01.89	RAB	**0 265 001 239**
410 [T1]	**2,3 l 70-77 kW M 102 4 Zyl.**		
Wheel speed sensor, rear	01.88-08.88	LAB	**0 265 001 240**
	09.88-06.95	LAB	**0 265 001 240**
	01.88-08.88	LAB	**0 265 001 240**
	09.88-06.95	LAB	**0 265 001 240**
	01.88-08.88	RAB	**0 265 001 239**
	09.88-02.94	RAB	**0 265 001 239**
	01.88-08.88	RAB	**0 265 001 239**
410 D [T1]	**2,9 l 70-72 kW OM 602.940 5 Zyl.**		
Wheel speed sensor, rear	11.88-06.95	LAB	**0 265 001 240**
	11.88-02.94	RAB	**0 265 001 239**

M

Product

MG

MGF

1.6 i 16V			**1,6 l 82 kW 16K4F 4 Zyl.**
Wheel speed sensor, front	10.01-03.02		**0 265 006 269**
Wheel speed sensor, rear	10.01-03.02	LAB	**0 265 006 270**
		RAB	**0 265 006 271**
1.8 i 16V			**1,8 l 88/107 kW 18K4F; 18K4K 4 Zyl.**
Wheel speed sensor, front	10.95-03.02		**0 265 006 269**
Wheel speed sensor, rear	10.95-03.02	LAB	**0 265 006 270**
		RAB	**0 265 006 271**
1.8 16V Trophy			**1,8 l 118 kW K-Serie 4 Zyl.**
Wheel speed sensor, front	03.01-03.02		**0 265 006 269**
Wheel speed sensor, rear	03.01-03.02	LAB	**0 265 006 270**
		RAB	**0 265 006 271**

MGTF

115 1.6i 16V			**1,6 l 85 kW 16 K4F K-Serie 4 Zyl.**
Wheel speed sensor, front	03.02-05.05		**0 265 006 269**
Wheel speed sensor, rear			
Fg.no. AD 9638→	03.02-05.05	LAB	**0 265 006 270**
		RAB	**0 265 006 271**
120 1.8i 16V Stepspeed			**1,8 l 88 kW 18 K4F K-Serie 4 Zyl.**
Wheel speed sensor, front	03.02-05.05		**0 265 006 269**
Wheel speed sensor, rear			
Fg.no. AD 9638→	03.02-05.05	LAB	**0 265 006 270**
		RAB	**0 265 006 271**
135 1.8i 16V			**1,8 l 100 kW 18 K4F K-Serie 4 Zyl.**
Wheel speed sensor, front	03.02-05.05		**0 265 006 269**
Wheel speed sensor, rear			
Fg.no. AD 9638→	03.02-05.05	LAB	**0 265 006 270**
		RAB	**0 265 006 271**
160 1.8i 16V			**1,8 l 118 kW 18 K4F K-Serie- VVC- 4 Zyl.**
Wheel speed sensor, front	03.02-05.05		**0 265 006 269**
Wheel speed sensor, rear			
Fg.no. AD 9638→	03.02-05.05	LAB	**0 265 006 270**
		RAB	**0 265 006 271**

ZR

2.0 D Turbo			**2,0 l 74 kW TCie 4 Zyl.**
Air mass meter, diesel	10.01-05.05		**0 280 218 012**
Speed sensor, diesel	10.01-05.05	BO	**0 281 002 121**
Pedal position sensor, diesel	10.01-05.05		**0 281 002 370**
Wheel speed sensor, front	10.01-05.05	LAB	**0 265 006 305**
		RAB	**0 265 006 306**
Wheel speed sensor, rear	10.01-05.05		**0 265 006 307**
105 1.4i 16V			**1,4 l 76 kW K-Serie 4 Zyl.**
Wheel speed sensor, front	10.01-05.05	LAB	**0 265 006 305**
		RAB	**0 265 006 306**
Wheel speed sensor, rear	10.01-05.05		**0 265 006 307**
120 1.8i 16V			**1,8 l 86 kW 18 K4F-K-Serie 4 Zyl.**
Wheel speed sensor, front	10.01-05.05	LAB	**0 265 006 305**
		RAB	**0 265 006 306**
Wheel speed sensor, rear	10.01-05.05		**0 265 006 307**
160 1.8i 16V			**1,8 l 118 kW 18 K4K -K-Serie-VVC 4 Zyl.**
Wheel speed sensor, front	10.01-05.05	LAB	**0 265 006 305**
		RAB	**0 265 006 306**
Wheel speed sensor, rear	10.01-05.05		**0 265 006 307**

Product

ZS

2.0 TD			**2,0 l 74 kW TCie 4 Zyl.**
Air mass meter, diesel	10.01-05.05		**0 280 218 012**
Speed sensor, diesel	10.01-05.05	BO	**0 281 002 121**
Temperature sensor, intake air, diesel	10.01-05.05		**0 280 130 039**
Pedal position sensor, diesel	10.01-05.05		**0 281 002 370**
Wheel speed sensor, front	10.01-05.05	LAB	**0 265 006 258**
		RAB	**0 265 006 259**
Wheel speed sensor, rear	10.01-05.05	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**
110 1.6i 16V			**1,6 l 80 kW K-Serie 4 Zyl.**
Wheel speed sensor, front			
Fg.no. YD 471064→	03.05-05.05	LAB	**0 265 006 258**
		RAB	**0 265 006 259**
Fg.no. →YD 471063	03.05-05.05	GS,LAB	**0 265 006 258**
		GS,RAB	**0 265 006 259**
Wheel speed sensor, rear	03.05-05.05	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**
120 1.8i 16V			**1,8 l 86 kW 18 K4F-K-Serie 4 Zyl.**
Wheel speed sensor, front	10.01-05.05	LAB	**0 265 006 258**
		RAB	**0 265 006 259**
Wheel speed sensor, rear	10.01-05.05	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**
180 2.5i 24V			**2,5 l 130 kW 2.5KV6 6 Zyl.**
Wheel speed sensor, front	10.01-05.05	LAB	**0 265 006 258**
		RAB	**0 265 006 259**
Wheel speed sensor, rear	10.01-05.05	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**

ZT

135 2.0 CDTi			**2,0 l 96 kW 204D2 4 Zyl.**
Air mass meter, diesel	10.02-05.05		**0 928 400 520**
190 2.0 CDT			**2,0 l 85 kW 204D2 4 Zyl.**
Air mass meter, diesel	10.01-05.05		**0 928 400 520**

ZT-Tourer

135 2.0 CDTi			**2,0 l 96 kW 204D2 4 Zyl.**
Air mass meter, diesel	10.02-05.05		**0 928 400 520**
190 2.0 CDT			**2,0 l 85 kW 204D2 4 Zyl.**
Air mass meter, diesel	10.01-05.05		**0 928 400 520**

MINI (BMW)

Mini Coupé

Cooper [R 56]			**1,6 l 88 kW N12 B16... 4 Zyl.**
Air mass meter, gasoline injection	11.06→		**0 280 218 205**
Phase sensor	11.06→	NOC	**0 232 103 064**
Pressure sensor, intake manifold, gasoline	11.06→		**0 261 230 136**
Cooper S [R 56]			**1,6 l 128 kW N14 B16A 4 Zyl.**
Air mass meter, gasoline injection	11.06→		**0 280 218 205**
Phase sensor	11.06→	NOC	**0 232 103 064**
Pressure sensor, intake manifold, gasoline	11.06→		**0 261 230 135**
Boost pressure sensor, gasoline	11.06→		**0 261 230 134**
One 1.4 d [R 50]			**1,4 l 55 kW 1 ND 4 Zyl.**
Air mass meter, diesel	03.03-09.05		**0 281 002 621**
One 1.4i [R 56]			**1,4 l 70 kW N12 B14A 4 Zyl.**
Phase sensor	03.07→	NOC	**0 232 103 064**
Pressure sensor, intake manifold, gasoline	03.07→		**0 261 230 136**

M

Product			

MITSUBISHI

Carisma

1.3 i 16V [DA]			**1,3 l 60 kW 4G13 4 Zyl.**
Wheel speed sensor, front	07.01-12.03	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
1.6 i 16V [DA]			**1,6 l 66/73-76 kW 4G92 Kat. 4 Zyl.**
Wheel speed sensor, front	05.96-12.03	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
Wheel speed sensor, rear	05.96-06.00	LAB,TBR	**0 265 006 327**
		RAB,TBR	**0 265 006 294**
1.8 GDI [DA]			**1,8 l 92 kW 4G93 4 Zyl.**
Wheel speed sensor, front	05.97-12.03	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
Wheel speed sensor, rear	05.97-06.00	LAB,TBR	**0 265 006 327**
	05.97-12.03	RAB,TBR	**0 265 006 294**
1.8 i 16V [DA]			**1,8 l 85/103 kW 4G93 DOHC/SOHC Kat. 4 Zyl.**
Wheel speed sensor, front	05.96-02.99	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
Wheel speed sensor, rear	05.96-02.99	LAB,TBR	**0 265 006 327**
		RAB,TBR	**0 265 006 294**
1.9 D Turbo [DA]			**1,9 l 66 kW F8Q 4 Zyl.**
Wheel speed sensor, front	05.96-06.00	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
Wheel speed sensor, rear	05.96-06.00	LAB	**0 265 006 327**
		RAB	**0 265 006 294**
1.9 DI-D [DA]			**1,9 l 75/85 kW F9Q-200; F9Q-204 4 Zyl.**
Wheel speed sensor, front	07.00-12.03	LAB	**0 265 006 224**
		RAB	**0 265 006 223**

Carisma Hatchback

1.6 i 16V [DA]			**1,6 l 66 kW 4G92 Kat. 4 Zyl.**
Wheel speed sensor, front	05.95-02.99	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
Wheel speed sensor, rear	05.96-02.99	LAB,TBR	**0 265 006 327**
	05.95-04.96	LAB,TBR	**0 265 006 328**
		RAB,TBR	**0 265 006 225**
	05.96-02.99	RAB,TBR	**0 265 006 294**
1.6 i 16V [DA]			**1,6 l 73-76 kW 4G92 Kat. 4 Zyl.**
Wheel speed sensor, front	05.97-12.03	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
Wheel speed sensor, rear	05.97-06.00	LAB,TBR	**0 265 006 327**
		RAB,TBR	**0 265 006 294**
1.8 GDI [DA]			**1,8 l 92 kW 4G93; 4G93 Kat. 4 Zyl.**
Wheel speed sensor, front	05.97-12.03	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
Wheel speed sensor, rear	05.97-06.00	LAB,TBR	**0 265 006 327**
	05.97-12.03	RAB,TBR	**0 265 006 294**
1.8 i 16V [DA]			**1,8 l 85 kW 4G93 SOHC Kat. 4 Zyl.**
Wheel speed sensor, front	05.95-02.99	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
Wheel speed sensor, rear	05.96-02.99	LAB,TBR	**0 265 006 327**
	05.95-04.96	LAB,TBR	**0 265 006 328**
		RAB,TBR	**0 265 006 225**
	05.96-02.99	RAB,TBR	**0 265 006 294**
1.8 i 16V [DA]			**1,8 l 103 kW 4G93 DOHC Kat. 4 Zyl.**
Wheel speed sensor, front	05.95-04.97	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
Wheel speed sensor, rear	05.95-04.96	LAB,TBR	**0 265 006 328**
		RAB,TBR	**0 265 006 225**
1.9 D Turbo [DA]			**1,9 l 66 kW F8Q 4 Zyl.**
Wheel speed sensor, front	05.96-06.00	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
Wheel speed sensor, rear	05.96-06.00	LAB	**0 265 006 327**
		RAB	**0 265 006 294**
1.9 DI-D [DA]			**1,9 l 75/85 kW F9Q-200; F9Q-204 4 Zyl.**
Wheel speed sensor, front	07.00-12.03	LAB	**0 265 006 224**
		RAB	**0 265 006 223**

Colt

CZT 1.5 Turbo [CZ]			**1,5 l 110 kW 4G15T 4 Zyl.**
Yaw rate sensor, brake system	01.05→		**0 265 005 600**
Wheel speed sensor, front	01.05→	LAB	**0 265 007 637**
		RAB	**0 265 007 683**
Wheel speed sensor, rear	01.05→		**0 265 007 638**
1.1 [CZ]			**1,1 l 55 kW 3A91 3 Zyl.**
Knock sensor	08.04→		**0 261 231 187**
Pressure sensor, intake manifold, gasoline	08.04→		**0 261 230 118**
Yaw rate sensor, brake system	08.04→		**0 265 005 600**
Wheel speed sensor, front	08.04→		**0 265 007 637**
Wheel speed sensor, rear	08.04→		**0 265 007 638**
1.3 [CZ]			**1,3 l 70 kW 4A90 4 Zyl.**
Knock sensor	04.04→		**0 261 231 187**
Pressure sensor, intake manifold, gasoline	04.04→		**0 261 230 118**
Yaw rate sensor, brake system	04.04→		**0 265 005 600**
Wheel speed sensor, front	04.04→		**0 265 007 637**
Wheel speed sensor, rear	04.04→		**0 265 007 638**
1.5 [CZ]			**1,5 l 80 kW 4A91 4 Zyl.**
Knock sensor	04.04→		**0 261 231 187**
Pressure sensor, intake manifold, gasoline	04.04→		**0 261 230 118**
Yaw rate sensor, brake system	04.04→		**0 265 005 600**
Wheel speed sensor, front	04.04→		**0 265 007 637**
Wheel speed sensor, rear	04.04→		**0 265 007 638**
1.5 DI-D [CZ]			**1,5 l 50/70 kW OM 639.393 3 Zyl.**
Yaw rate sensor, brake system	08.04→		**0 265 005 600**
Wheel speed sensor, front	08.04→		**0 265 007 637**
Wheel speed sensor, rear	08.04→		**0 265 007 638**

Spacestar

1.3 i [DG]			**1,3 l 60 kW 4G13 4 Zyl.**
Wheel speed sensor, front	06.98→	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
Wheel speed sensor, rear	06.98-04.02	LAB,TBR	**0 265 006 327**
		RAB,TBR	**0 265 006 294**
1.6 i [DG]			**1,6 l 72 kW 4G18 4 Zyl.**
Wheel speed sensor, front	04.01→	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
1.8 GDI [DG]			**1,8 l 87-90 kW 4G93-G 4 Zyl.**
Wheel speed sensor, front	08.98-08.02	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
Wheel speed sensor, rear	08.98-08.02	LAB,TBR	**0 265 006 327**
		RAB,TBR	**0 265 006 294**
1.8 i [DG]			**1,8 l 82 kW 4G93-3 4 Zyl.**
Wheel speed sensor, front	09.02→	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
1.9 DI-D [DG]			**1,9 l 75/85 kW F9Q 4 Zyl.**
Wheel speed sensor, front	06.00→	LAB	**0 265 006 224**
		RAB	**0 265 006 223**

M

Product			

NISSAN

Almera

1.6 [B10]			**1,6 l 79 kW QG16 4 Zyl.**
Temperature sensor, coolant, injection system	01.06→		**0 280 130 081**

Almera Hatchback

1.5 D Turbo [N16E]			**1,5 l 60 kW K9K 4 Zyl.**
Wheel speed sensor, front	10.02→	LAB	**0 265 006 702**
		RAB	**0 265 006 703**
1.5 i [N16E]			**1,5 l 66 kW QG15DE 4 Zyl.**
Air mass meter, gasoline injection	01.00-10.00		**0 280 218 005**
			0 986 280 232
	11.00-07.02		**0 280 218 094**
Temperature sensor, coolant, injection system	01.00-07.02		**0 280 130 081**
Wheel speed sensor, front	01.00-08.00	LAB	**0 265 006 605**
	09.00-07.02	LAB	**0 265 006 702**
	01.00-08.00	RAB	**0 265 006 606**
	09.00-07.02	RAB	**0 265 006 703**
1.5 i [N16E]			**1,5 l 72 kW QG15DE 4 Zyl.**
Air mass meter, gasoline injection	08.02-07.04		**0 280 218 094**
Wheel speed sensor, front	08.02→	LAB	**0 265 006 702**
		RAB	**0 265 006 703**
1.8 i [N16E]			**1,8 l 84 kW QG18DE 4 Zyl.**
Air mass meter, gasoline injection	01.00-10.00		**0 280 218 005**
			0 986 280 232
	11.00-07.02		**0 280 218 094**
Temperature sensor, coolant, injection system	01.00-07.02		**0 280 130 081**
Wheel speed sensor, front	01.00-08.00	LAB	**0 265 006 605**
	09.00-07.02	LAB	**0 265 006 702**
	01.00-08.00	RAB	**0 265 006 606**
	09.00-07.02	RAB	**0 265 006 703**
1.8 i [N16E]			**1,8 l 85 kW QG18DE 4 Zyl.**
Air mass meter, gasoline injection	08.02-07.04		**0 280 218 094**
Wheel speed sensor, front	08.02→	LAB	**0 265 007 553**
		RAB	**0 265 007 552**
Wheel speed sensor, rear	02.03→	LAB,MFD	**0 265 007 555**
		MFD,RAB	**0 265 007 554**
2.2 D Turbo [N16E]			**2,2 l 81 kW YD22DDT 4 Zyl.**
Air mass meter, diesel	01.00-02.03		**0 280 218 005**
			0 986 280 232
Temperature sensor, cylinder head	01.00-02.03		**0 280 130 081**
Wheel speed sensor, front	01.00-08.00	LAB	**0 265 006 605**
	09.00-02.03	LAB	**0 265 006 702**
	01.00-08.00	RAB	**0 265 006 606**
	09.00-02.03	RAB	**0 265 006 703**
2.2 D Turbo [N16E]			**2,2 l 82/100 kW YD22DDT 4 Zyl.**
Wheel speed sensor, front	02.03→	LAB	**0 265 007 553**
		RAB	**0 265 007 552**
Wheel speed sensor, rear	02.03→	LAB	**0 265 007 555**
		RAB	**0 265 007 554**

Almera Sedan

1.5 D Turbo [N16E]			**1,5 l 60 kW K9K 4 Zyl.**
Wheel speed sensor, front	10.02→	LAB	**0 265 006 702**
		RAB	**0 265 006 703**
1.5 i [N16E]			**1,5 l 66 kW QG15DE 4 Zyl.**
Air mass meter, gasoline injection	03.01-07.02		**0 280 218 094**
Temperature sensor, coolant, injection system	03.01-07.02		**0 280 130 081**
Wheel speed sensor, front	03.01-07.02	LAB	**0 265 006 702**
		RAB	**0 265 006 703**
1.5 i [N16E]			**1,5 l 72 kW QG15DE 4 Zyl.**
Air mass meter, gasoline injection	08.02-07.04		**0 280 218 094**
Wheel speed sensor, front	08.02→	LAB	**0 265 006 702**
		RAB	**0 265 006 703**
1.8 i [N16E]			**1,8 l 84 kW QG18DE 4 Zyl.**
Air mass meter, gasoline injection	03.01-07.02		**0 280 218 094**
Temperature sensor, coolant, injection system	03.01-07.02		**0 280 130 081**
Wheel speed sensor, front	03.01-07.02	LAB	**0 265 006 702**
		RAB	**0 265 006 703**
1.8 i [N16E]			**1,8 l 85 kW QG18DE 4 Zyl.**
Air mass meter, gasoline injection	08.02-07.04		**0 280 218 094**
Wheel speed sensor, front	08.02→	LAB	**0 265 007 553**
		RAB	**0 265 007 552**
Wheel speed sensor, rear	02.03→	LAB,MFD	**0 265 007 555**
		MFD,RAB	**0 265 007 554**
2.2 D Turbo [N16]			**2,2 l 81 kW YD22DDT 4 Zyl.**
Air mass meter, diesel	04.00-03.01		**0 280 218 005**
			0 986 280 232
2.2 D Turbo [N16E]			**2,2 l 81 kW YD22DDT 4 Zyl.**
Air mass meter, diesel	03.01-02.03		**0 280 218 005**
			0 986 280 232
Temperature sensor, cylinder head	03.01-02.03		**0 280 130 081**
Wheel speed sensor, front	03.01-02.03	LAB	**0 265 006 702**
		RAB	**0 265 006 703**
2.2 D Turbo [N16E]			**2,2 l 82/100 kW YD22DDT 4 Zyl.**
Wheel speed sensor, front	02.03→	LAB	**0 265 007 553**
		RAB	**0 265 007 552**
Wheel speed sensor, rear	02.03→	LAB	**0 265 007 555**
		RAB	**0 265 007 554**

Almera Tino

1.8 i [V10M]			**1,8 l 84-85 kW QG18DE 4 Zyl.**
Air mass meter, gasoline injection	05.00-11.00		**0 280 218 005**
			0 986 280 232
	12.00-07.04		**0 280 218 094**
Temperature sensor, coolant, injection system	05.00-12.05		**0 280 130 081**
Wheel speed sensor, front	12.00-02.03	LAB	**0 265 006 704**
	03.03-12.05	LAB	**0 265 007 557**
	12.00-02.03	RAB	**0 265 006 705**
	03.03-12.05	RAB	**0 265 007 556**
Wheel speed sensor, rear	03.03-12.05	LAB	**0 265 007 559**
		RAB	**0 265 007 558**
2.0 i [V10M]			**2,0 l 99-100 kW SR20DE 4 Zyl.**
Air mass meter, gasoline injection	05.00-01.03		**0 280 218 096**
Temperature sensor, coolant, injection system	05.00-01.03		**0 280 130 081**
Wheel speed sensor, front	12.00-01.03	LAB	**0 265 006 704**
		RAB	**0 265 006 705**
2.2 D Turbo [V10M]			**2,2 l 81-84 kW YD22DDTI 4 Zyl.**
Air mass meter, diesel	05.00-01.03		**0 280 218 005**
			0 986 280 232
Temperature sensor, coolant, diesel	05.00-01.03		**0 280 130 081**
Wheel speed sensor, front	12.00-01.03	LAB	**0 265 006 704**
		RAB	**0 265 006 705**
2.2 D Turbo [V10M]			**2,2 l 82/100 kW YD22DDTI 4 Zyl.**
Wheel speed sensor, front	02.03-12.05	LAB	**0 265 007 557**
		RAB	**0 265 007 556**
Wheel speed sensor, rear	02.03-12.05	LAB	**0 265 007 559**
		RAB	**0 265 007 558**

N

Product

Altima

2.4 i [L30]	**2,4 l 112-116 kW KA24DE 4 Zyl.**		
Temperature sensor, coolant, injection system	06.97-08.01		**0 280 130 081**
2.4 i [U13]	**2,4 l 110-112 kW KA24DE 4 Zyl.**		
Temperature sensor, coolant, injection system	08.94-02.96	TW	**0 280 130 081**
3.5 [L31]	**3,5 l 183 kW VQ35DE 6 Zyl.**		
Air mass meter, gasoline injection	09.01-09.03		**0 280 218 154**

Micra

1.0 i [K11E]	**1,0 l 40-44 kW CG10DE 4 Zyl.**		
Throttle valve assembly	08.00-12.00		**0 280 750 051**
	01.01-10.02		**0 280 750 117**
Throttle valve sensor	07.00-10.02		**0 280 122 014**
Phase sensor	07.00-10.02	NOC	**0 232 103 033**
Speed sensor, ignition/injection	07.00-10.02	FKW	**0 261 210 201**
Temperature sensor, coolant, injection system	08.92-12.95		**0 280 130 073**
	01.96-10.02		**0 280 130 081**
Wheel speed sensor, front	08.00-11.00	LAB	**0 265 006 658**
	12.00-10.02	LAB	**0 265 006 714**
	01.96-07.00	LAB,RBA	**0 265 006 255**
	12.00-10.02	RAB	**0 265 006 715**
	01.96-11.00	RAB,RBA	**0 265 006 254**
Wheel speed sensor, rear	01.96-02.98	RBA	**0 265 006 256**
	03.98-10.02	RBA	**0 265 006 382**
1.0 i [K12E]	**1,0 l 48 kW CG10DE 4 Zyl.**		
Temperature sensor, coolant, injection system	11.02-05.05		**0 280 130 081**
Wheel speed sensor, front	11.02-05.05		**0 265 007 537**
Wheel speed sensor, rear	11.02-05.05	LAB	**0 265 007 538**
		RAB	**0 265 007 539**
1.2 i [K12E]	**1,2 l 48/59 kW CG12DE; CR12DE 4 Zyl.**		
Temperature sensor, coolant, injection system	11.02→		**0 280 130 081**
Duo sensor, acceleration and yaw rate, brake system	08.03→		**0 265 005 265**
Wheel speed sensor, front	11.02→		**0 265 007 537**
Wheel speed sensor, rear	11.02→	LAB	**0 265 007 538**
		RAB	**0 265 007 539**
1.3 i [K11E]	**1,3 l 55 kW CG13DE 4 Zyl.**		
Temperature sensor, coolant, injection system	08.92-12.95		**0 280 130 073**
	05.95-02.98		**0 280 130 081**
	01.96-07.00		**0 280 130 081**
Wheel speed sensor, front	01.96→	LAB,RBA	**0 265 006 255**
		RAB,RBA	**0 265 006 254**
Wheel speed sensor, rear	01.96-02.98	RBA	**0 265 006 256**
	03.98-07.00	RBA	**0 265 006 382**
1.4 i [K11E]	**1,4 l 60 kW CGA3DE 4 Zyl.**		
Throttle valve assembly	07.00-12.00		**0 280 750 051**
	01.01-10.02		**0 280 750 117**
Throttle valve sensor	07.00-10.02		**0 280 122 014**
Phase sensor	07.00-10.02	NOC	**0 232 103 033**
Speed sensor, ignition/injection	07.00-10.02	FKW	**0 261 210 201**
Temperature sensor, coolant, injection system	07.00-10.02		**0 280 130 081**
Wheel speed sensor, front	07.00-11.00	LAB	**0 265 006 658**
	12.00-10.02	LAB	**0 265 006 714**
	07.00-11.00	RAB	**0 265 006 254**
	12.00-10.02	RAB	**0 265 006 715**
Wheel speed sensor, rear	07.00-10.02		**0 265 006 382**
1.4 i [K12E]	**1,4 l 65 kW CGA3DE; CR14DE 4 Zyl.**		
Temperature sensor, coolant, injection system	11.02→		**0 280 130 081**
Duo sensor, acceleration and yaw rate, brake system	08.03→		**0 265 005 265**
Wheel speed sensor, front	11.02→		**0 265 007 537**
Wheel speed sensor, rear	11.02→	LAB	**0 265 007 538**
		RAB	**0 265 007 539**
1.5 D [K11E]	**1,5 l 42 kW TD15 4 Zyl.**		
Wheel speed sensor, front	07.00-11.00	LAB	**0 265 006 658**
	12.00-10.02	LAB	**0 265 006 714**
	07.00-11.00	RAB	**0 265 006 254**
	12.00-10.02	RAB	**0 265 006 715**
Wheel speed sensor, rear	07.00-10.02		**0 265 006 382**
1.5 D Turbo [K12E]	**1,5 l 48-50/60-63 kW K9K 4 Zyl.**		
Wheel speed sensor, front	02.03→		**0 265 007 537**
Wheel speed sensor, rear	02.03→	LAB	**0 265 007 538**
		RAB	**0 265 007 539**
1.6 i [K12E]	**1,6 l 81 kW HR16DE 4 Zyl.**		
Temperature sensor, coolant, injection system	06.05→		**0 280 130 081**
Duo sensor, acceleration and yaw rate, brake system	06.05→		**0 265 005 265**
Wheel speed sensor, front	06.05→		**0 265 007 537**
Wheel speed sensor, rear	06.05→	LAB	**0 265 007 538**
		RAB	**0 265 007 539**

Micra CC

1.4 i [K12E]	**1,4 l 65 kW CR14DE 4 Zyl.**		
Temperature sensor, coolant, injection system	09.05→		**0 280 130 081**
Duo sensor, acceleration and yaw rate, brake system	09.05→		**0 265 005 265**
Wheel speed sensor, front	09.05→		**0 265 007 537**
Wheel speed sensor, rear	09.05→	LAB	**0 265 007 538**
		RAB	**0 265 007 539**
1.6 i [K12E]	**1,6 l 81 kW HR16DE 4 Zyl.**		
Temperature sensor, coolant, injection system	09.05→		**0 280 130 081**
Duo sensor, acceleration and yaw rate, brake system	09.05→		**0 265 005 265**
Wheel speed sensor, front	09.05→		**0 265 007 537**
Wheel speed sensor, rear	09.05→	LAB	**0 265 007 538**
		RAB	**0 265 007 539**

Navara

2.5 dCi [D40]	**2,5 l 106 kW YD25DDTI 4 Zyl.**		
Temperature sensor, coolant, diesel	05.05-02.06		**0 280 130 081**
2.5 dCi 4x4 [D40]	**2,5 l 128 kW YD25DDTI 4 Zyl.**		
Temperature sensor, coolant, diesel	05.05-02.06		**0 280 130 081**

Note

1.4 [E11]	**1,4 l 65 kW CR14DE 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	01.06→		**0 265 005 265**
Wheel speed sensor, front	01.06→		**0 265 007 537**
Wheel speed sensor, rear	01.06→	LAB	**0 265 007 538**
		RAB	**0 265 007 539**
1.5 dCi 70 [E11]	**1,5 l 50 kW K9K 4 Zyl.**		
Wheel speed sensor, front	01.06→		**0 265 007 537**
Wheel speed sensor, rear	01.06→	LAB	**0 265 007 538**
		RAB	**0 265 007 539**
1.5 dCi 90 [E11]	**1,5 l 63 kW K9K 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	01.06→		**0 265 005 265**
Wheel speed sensor, front	01.06→		**0 265 007 537**
Wheel speed sensor, rear	01.06→	LAB	**0 265 007 538**
		RAB	**0 265 007 539**

N

Product			
◀ Note			
1.6 [E11]			**1,6 l 81 kW HR16DE 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	01.06→		**0 265 005 265**
Wheel speed sensor, front	01.06→		**0 265 007 537**
Wheel speed sensor, rear	01.06→	LAB	**0 265 007 538**
		RAB	**0 265 007 539**

Pathfinder

2.5 D Turbo [R51]			**2,5 l 128 kW YD25DDTI 4 Zyl.**
Temperature sensor, cylinder head	01.05-02.06		**0 280 130 081**

Pintara

2.0 i [R31]			**2,0 l 78 kW CA20E 4 Zyl.**
Air flow sensor, gasoline injection	06.86-12.90		**0 280 202 111**
			0 986 280 073
Temperature sensor, coolant, injection system	01.87-12.89		**0 280 130 063**

Primera

2.0 i [P11E]			**2,0 l 103 kW SR20DE 4 Zyl.**
Air mass meter, gasoline injection	02.01→		**0 280 218 096**

Primera Hatchback

1.6 [P12E]			**1,6 l 78-80 kW QG16DE 4 Zyl.**
Air mass meter, gasoline injection	05.02-06.04		**0 280 218 094**
Temperature sensor, coolant, injection system	05.02→		**0 280 130 081**
Wheel speed sensor, front	05.02→	LAB	**0 265 007 463**
		RAB	**0 265 007 464**
Wheel speed sensor, rear	05.02-09.02	LAB	**0 265 007 465**
	10.02→	LAB	**0 265 007 632**
	05.02-09.02	RAB	**0 265 007 466**
	10.02→	RAB	**0 265 007 633**
1.6 i [P10E]			**1,6 l 71-75 kW GA16DE 4 Zyl.**
Temperature sensor, coolant, injection system	05.93-09.94		**0 280 130 071**
	09.94-06.96		**0 280 130 073**
1.6 i [P11E]			**1,6 l 66-73 kW GA16DE 4 Zyl.**
Temperature sensor, coolant, injection system	06.96-05.99		**0 280 130 081**
Wheel speed sensor, front	06.96-05.99	LAB	**0 265 006 233**
		RAB	**0 265 006 232**
Wheel speed sensor, rear	06.96-08.97	LAB	**0 265 006 237**
	05.98-05.99	LAB	**0 265 006 237**
	09.97-04.98	LAB	**0 265 006 379**
	05.98-05.99	RAB	**0 265 006 236**
	06.96-08.97	RAB	**0 265 006 236**
	09.97-04.98	RAB	**0 265 006 378**
1.6 i [P11E]			**1,6 l 73 kW GA16DE 4 Zyl.**
Temperature sensor, coolant, injection system	06.99-12.01		**0 280 130 081**
Wheel speed sensor, front	06.99-12.01	LAB	**0 265 006 233**
		RAB	**0 265 006 232**
Wheel speed sensor, rear	06.99-08.00	LAB	**0 265 006 237**
	09.00-12.01	LAB	**0 265 006 708**
	06.99-08.00	RAB	**0 265 006 236**
	09.00-12.01	RAB	**0 265 006 709**
1.6 i [P11E]			**1,6 l 78 kW QG16DE 4 Zyl.**
Air mass meter, gasoline injection	09.00-12.01		**0 280 218 094**
Temperature sensor, coolant, injection system	09.00-12.01		**0 280 130 081**
Wheel speed sensor, front	09.00-12.01	LAB	**0 265 006 233**
		RAB	**0 265 006 232**
Wheel speed sensor, rear	09.00-12.01	LAB	**0 265 006 708**
	09.00-09.00	LAB,TW	**0 265 006 237**
	09.00-12.01	RAB	**0 265 006 709**
	09.00-09.00	RAB,TW	**0 265 006 236**
1.8 [P12E]			**1,8 l 85 kW QG18DE 4 Zyl.**
Air mass meter, gasoline injection	05.02-06.04		**0 280 218 094**
Temperature sensor, coolant, injection system	05.02→		**0 280 130 081**
Duo sensor, acceleration and yaw rate, brake system	08.03→		**0 265 005 265**
Wheel speed sensor, front	05.02→	LAB	**0 265 007 463**
		RAB	**0 265 007 464**
Wheel speed sensor, rear	05.02-09.02	LAB	**0 265 007 465**
	10.02→	LAB	**0 265 007 632**
	05.02-09.02	RAB	**0 265 007 466**
	10.02→	RAB	**0 265 007 633**
1.8 i [P11E]			**1,8 l 84 kW QG18DE 4 Zyl.**
Air mass meter, gasoline injection	06.99-09.00		**0 280 218 005**
			0 986 280 232
	10.00-12.01		**0 280 218 094**
Temperature sensor, coolant, injection system	06.99-12.01		**0 280 130 081**
Wheel speed sensor, front	06.99-12.01	LAB	**0 265 006 233**
		RAB	**0 265 006 232**
Wheel speed sensor, rear	06.99-08.00	LAB	**0 265 006 237**
	09.00-12.01	LAB	**0 265 006 708**
	06.99-08.00	RAB	**0 265 006 236**
	09.00-12.01	RAB	**0 265 006 709**
1.9 D Turbo [P12E]			**1,9 l 85-88 kW F9Q 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	08.03→		**0 265 005 265**
Wheel speed sensor, front	01.03→	LAB	**0 265 007 463**
		RAB	**0 265 007 464**
Wheel speed sensor, rear	01.03→	LAB	**0 265 007 632**
		RAB	**0 265 007 633**
2.0 [P12E]			**2,0 l 103 kW QR20DE 4 Zyl.**
Air mass meter, gasoline injection	05.02-06.04		**0 280 218 096**
Duo sensor, acceleration and yaw rate, brake system	08.03→		**0 265 005 265**
Wheel speed sensor, front	05.02→	LAB	**0 265 007 463**
		RAB	**0 265 007 464**
Wheel speed sensor, rear	05.02-09.02	LAB	**0 265 007 465**
	10.02→	LAB	**0 265 007 632**
	05.02-09.02	RAB	**0 265 007 466**
	10.02→	RAB	**0 265 007 633**
2.0 D Turbo [P11E]			**2,0 l 66 kW CD20T 4 Zyl.**
Air mass meter, diesel	10.97-12.01		**0 281 002 207**
Temperature sensor, coolant, diesel	10.97-12.01		**0 280 130 081**
Wheel speed sensor, front	06.96-12.01	LAB	**0 265 006 233**
		RAB	**0 265 006 232**
Wheel speed sensor, rear	06.96-08.97	LAB	**0 265 006 237**
	05.98-08.00	LAB	**0 265 006 237**
	09.97-04.98	LAB	**0 265 006 379**
	09.00-12.01	LAB	**0 265 006 708**
	06.96-08.97	RAB	**0 265 006 236**
	05.98-08.00	RAB	**0 265 006 236**
	09.97-04.98	RAB	**0 265 006 378**
	09.00-12.01	RAB	**0 265 006 709**
2.0 i [P10E]			**2,0 l 85/89 kW SR20Di 4 Zyl.**
Temperature sensor, coolant, injection system	06.90-05.93		**0 280 130 064**
Wheel speed sensor, front	06.90-05.93	LAB	**0 265 001 274**
		RAB	**0 265 001 273**
Wheel speed sensor, rear	06.90-05.93	LAB	**0 265 001 276**
		RAB	**0 265 001 275**

N

Product			
2.0 i [P10E]		**2,0 l 85-92 kW SR20DE 4 Zyl.**	
Temperature sensor, coolant, injection system	09.94-06.96		**0 280 130 073**
Wheel speed sensor, front	09.94-06.96	LAB	**0 265 001 274**
		RAB	**0 265 001 273**
Wheel speed sensor, rear	09.94-06.96	LAB	**0 265 001 276**
		RAB	**0 265 001 275**
2.0 i [P10E]		**2,0 l 110 kW SR20DE 4 Zyl.**	
Temperature sensor, coolant, injection system	06.90-05.93		**0 280 130 064**
	06.93-09.94		**0 280 130 071**
	10.94-06.96		**0 280 130 073**
Wheel speed sensor, front	06.90-06.96	LAB	**0 265 001 274**
		RAB	**0 265 001 273**
Wheel speed sensor, rear	06.90-06.96	LAB	**0 265 001 276**
		RAB	**0 265 001 275**
2.0 i [P10E]		**2,0 l 112 kW SR20DE 4 Zyl.**	
Temperature sensor, coolant, injection system	06.90-05.93		**0 280 130 064**
Wheel speed sensor, front	06.90-05.93	LAB	**0 265 001 274**
		RAB	**0 265 001 273**
Wheel speed sensor, rear	06.90-05.93	LAB	**0 265 001 276**
		RAB	**0 265 001 275**
2.0 i [P11E]		**2,0 l 85/96 kW SR20DE; SR20DEL 4 Zyl.**	
Temperature sensor, coolant, injection system	06.96-06.99		**0 280 130 081**
Wheel speed sensor, front	06.96-06.99	LAB	**0 265 006 233**
		RAB	**0 265 006 232**
Wheel speed sensor, rear	06.96-08.97	LAB	**0 265 006 237**
	09.97-10.97	LAB	**0 265 006 379**
	06.96-08.97	RAB	**0 265 006 236**
	09.97-10.97	RAB	**0 265 006 378**
2.0 i [P11E]		**2,0 l 96 kW SR20DEL 4 Zyl.**	
Wheel speed sensor, rear	05.98-06.99	LAB	**0 265 006 237**
	10.97-04.98	LAB	**0 265 006 379**
	05.98-06.99	RAB	**0 265 006 236**
	10.97-04.98	RAB	**0 265 006 378**
2.0 i [P11E]		**2,0 l 103 kW SR20DE 4 Zyl.**	
Air mass meter, gasoline injection	06.99-12.01		**0 280 218 096**
Temperature sensor, coolant, injection system	06.99-12.01		**0 280 130 081**
Wheel speed sensor, front	06.99-12.01	LAB	**0 265 006 233**
		RAB	**0 265 006 232**
Wheel speed sensor, rear	06.99-08.00	LAB	**0 265 006 237**
	09.00-12.01	LAB	**0 265 006 708**
	06.99-08.00	RAB	**0 265 006 236**
	09.00-12.01	RAB	**0 265 006 709**
2.0 i GT [P11E]		**2,0 l 110 kW SR20DE; SR20DEH 4 Zyl.**	
Temperature sensor, coolant, injection system	06.96-06.99		**0 280 130 081**
Wheel speed sensor, front	06.96-06.99	LAB	**0 265 006 233**
		RAB	**0 265 006 232**
Wheel speed sensor, rear	06.96-08.97	LAB	**0 265 006 237**
	09.97-10.97	LAB	**0 265 006 379**
	06.96-08.97	RAB	**0 265 006 236**
	09.97-10.97	RAB	**0 265 006 378**
2.0 i GT [P11E]		**2,0 l 110 kW SR20DEH 4 Zyl.**	
Wheel speed sensor, rear	05.98-06.99	LAB	**0 265 006 237**
	10.97-04.98	LAB	**0 265 006 379**
	05.98-06.99	RAB	**0 265 006 236**
	10.97-04.98	RAB	**0 265 006 378**
2.0 i 4WD [P10E]		**2,0 l 85/89 kW SR20Di 4 Zyl.**	
Temperature sensor, coolant, injection system	04.91-05.93		**0 280 130 064**
Wheel speed sensor, front	04.91-05.93	LAB	**0 265 001 313**
		RAB	**0 265 001 312**
2.0 i 4WD [P10E]		**2,0 l 110 kW SR20DE 4 Zyl.**	
Temperature sensor, coolant, injection system	04.91-05.93		**0 280 130 064**
	06.93-09.94		**0 280 130 071**
	10.94-06.96		**0 280 130 073**
Wheel speed sensor, front	10.94-06.96	LAB	**0 265 001 274**
	04.91-09.94	LAB	**0 265 001 313**
	10.94-06.96	RAB	**0 265 001 273**
	04.91-09.94	RAB	**0 265 001 312**
Wheel speed sensor, rear	09.94-06.96	LAB	**0 265 001 276**
		RAB	**0 265 001 275**
2.0 i 4WD [P10E]		**2,0 l 112 kW SR20DE 4 Zyl.**	
Temperature sensor, coolant, injection system	04.91-05.93		**0 280 130 064**
Wheel speed sensor, front	04.91-05.93	LAB	**0 265 001 313**
		RAB	**0 265 001 312**
2.2 D Turbo [P12E]		**2,2 l 93 kW YD22DDT 4 Zyl.**	
Air mass meter, diesel	05.02-06.04		**0 280 218 005**
			0 986 280 232
Duo sensor, acceleration and yaw rate, brake system	08.03→		**0 265 005 265**
Wheel speed sensor, front	05.02→	LAB	**0 265 007 463**
		RAB	**0 265 007 464**
Wheel speed sensor, rear	05.02-09.02	LAB	**0 265 007 465**
	10.02→	LAB	**0 265 007 632**
	05.02-09.02	RAB	**0 265 007 466**
	10.02→	RAB	**0 265 007 633**
2.2 D Turbo [P12E]		**2,2 l 100-102 kW YD22DDT 4 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	08.03→		**0 265 005 265**
Wheel speed sensor, front	01.03→	LAB	**0 265 007 463**
		RAB	**0 265 007 464**
Wheel speed sensor, rear	01.03→	LAB	**0 265 007 632**
		RAB	**0 265 007 633**

Primera Sedan

1.6 [P12E]		**1,6 l 78-80 kW QG16DE 4 Zyl.**	
Air mass meter, gasoline injection	12.01-06.04		**0 280 218 094**
Temperature sensor, coolant, injection system	12.01→		**0 280 130 081**
Wheel speed sensor, front	12.01→	LAB	**0 265 007 463**
		RAB	**0 265 007 464**
Wheel speed sensor, rear	12.01-09.02	LAB	**0 265 007 465**
	10.02→	LAB	**0 265 007 632**
	12.01-09.02	RAB	**0 265 007 466**
	10.02→	RAB	**0 265 007 633**
1.6 i [P10E]		**1,6 l 71-75 kW GA16DE 4 Zyl.**	
Temperature sensor, coolant, injection system	05.93-09.94		**0 280 130 071**
	09.94-06.96		**0 280 130 073**
1.6 i [P11E]		**1,6 l 66-73 kW GA16DE 4 Zyl.**	
Temperature sensor, coolant, injection system	06.96-05.99		**0 280 130 081**
Wheel speed sensor, front	06.96-05.99	LAB	**0 265 006 233**
		RAB	**0 265 006 232**
Wheel speed sensor, rear	06.96-08.97	LAB	**0 265 006 237**
	05.98-05.99	LAB	**0 265 006 237**
	09.97-04.98	LAB	**0 265 006 379**
	06.96-08.97	RAB	**0 265 006 236**
	05.98-05.99	RAB	**0 265 006 236**
	09.97-04.98	RAB	**0 265 006 378**
1.6 i [P11E]		**1,6 l 73 kW GA16DE 4 Zyl.**	
Temperature sensor, coolant, injection system	06.99-12.01		**0 280 130 081**
Wheel speed sensor, front	06.99-12.01	LAB	**0 265 006 233**
		RAB	**0 265 006 232**
Wheel speed sensor, rear	06.99-08.00	LAB	**0 265 006 237**
	09.00-12.01	LAB	**0 265 006 708**
	06.99-08.00	RAB	**0 265 006 236**
	09.00-12.01	RAB	**0 265 006 709**

N

Product

◀ Primera Sedan

1.6 i [P11E]		**1,6 l 78 kW QG16DE 4 Zyl.**	
Air mass meter, gasoline injection	09.00-12.01		**0 280 218 094**
Temperature sensor, coolant, injection system	09.00-12.01		**0 280 130 081**
Wheel speed sensor, front	09.00-12.01	LAB	**0 265 006 233**
		RAB	**0 265 006 232**
Wheel speed sensor, rear	09.00-12.01	LAB	**0 265 006 708**
	09.00-09.00	LAB,TW	**0 265 006 237**
	09.00-12.01	RAB	**0 265 006 709**
	09.00-09.00	RAB,TW	**0 265 006 236**
1.8 [P12E]		**1,8 l 85 kW QG18DE 4 Zyl.**	
Air mass meter, gasoline injection	12.01-06.04		**0 280 218 094**
Temperature sensor, coolant, injection system	12.01→		**0 280 130 081**
Duo sensor, acceleration and yaw rate, brake system	08.03→		**0 265 005 265**
Wheel speed sensor, front	12.01→	LAB	**0 265 007 463**
		RAB	**0 265 007 464**
Wheel speed sensor, rear	12.01-09.02	LAB	**0 265 007 465**
	10.02→	LAB	**0 265 007 632**
	12.01-09.02	RAB	**0 265 007 466**
	10.02→	RAB	**0 265 007 633**
1.8 i [P11E]		**1,8 l 84 kW QG18DE 4 Zyl.**	
Air mass meter, gasoline injection	06.99-09.00		**0 280 218 005**
			0 986 280 232
	10.00-12.01		**0 280 218 094**
Temperature sensor, coolant, injection system	06.99-12.01		**0 280 130 081**
Wheel speed sensor, front	06.99-12.01	LAB	**0 265 006 233**
		RAB	**0 265 006 232**
Wheel speed sensor, rear	06.99-08.00	LAB	**0 265 006 237**
	09.00-12.01	LAB	**0 265 006 708**
	06.99-08.00	RAB	**0 265 006 236**
	09.00-12.01	RAB	**0 265 006 709**
1.9 D Turbo [P12E]		**1,9 l 85-88 kW F9Q 4 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	08.03→		**0 265 005 265**
Wheel speed sensor, front	01.03→	LAB	**0 265 007 463**
		RAB	**0 265 007 464**
Wheel speed sensor, rear	01.03→	LAB	**0 265 007 632**
		RAB	**0 265 007 633**
2.0 [P12E]		**2,0 l 103 kW QR20DE 4 Zyl.**	
Air mass meter, gasoline injection	12.01-06.04		**0 280 218 096**
Duo sensor, acceleration and yaw rate, brake system	08.03→		**0 265 005 265**
Wheel speed sensor, front	12.01→	LAB	**0 265 007 463**
		RAB	**0 265 007 464**
Wheel speed sensor, rear	12.01-09.02	LAB	**0 265 007 465**
	10.02→	LAB	**0 265 007 632**
	12.01-09.02	RAB	**0 265 007 466**
	10.02→	RAB	**0 265 007 633**
2.0 D Turbo [P11E]		**2,0 l 66 kW CD20T 4 Zyl.**	
Air mass meter, diesel	10.97-12.01		**0 281 002 207**
Temperature sensor, coolant, diesel	10.97-12.01		**0 280 130 081**
Wheel speed sensor, front	06.96-12.01	LAB	**0 265 006 233**
		RAB	**0 265 006 232**
Wheel speed sensor, rear	06.96-08.97	LAB	**0 265 006 237**
	05.98-08.00	LAB	**0 265 006 237**
	09.97-04.98	LAB	**0 265 006 379**
	09.00-12.01	LAB	**0 265 006 708**
	06.96-08.97	RAB	**0 265 006 236**
	05.98-08.00	RAB	**0 265 006 236**
	09.97-04.98	RAB	**0 265 006 378**
	09.00-12.01	RAB	**0 265 006 709**

Product

2.0 i [P10E]		**2,0 l 85/89 kW SR20Di 4 Zyl.**	
Temperature sensor, coolant, injection system	06.90-05.93		**0 280 130 064**
Wheel speed sensor, front	06.90-05.93	LAB	**0 265 001 274**
		RAB	**0 265 001 273**
Wheel speed sensor, rear	06.90-05.93	LAB	**0 265 001 276**
		RAB	**0 265 001 275**
2.0 i [P10E]		**2,0 l 85-92 kW SR20DE 4 Zyl.**	
Temperature sensor, coolant, injection system	09.94-06.96		**0 280 130 073**
Wheel speed sensor, front	09.94-06.96	LAB	**0 265 001 274**
		RAB	**0 265 001 273**
Wheel speed sensor, rear	09.94-06.96	LAB	**0 265 001 276**
		RAB	**0 265 001 275**
2.0 i [P10E]		**2,0 l 110 kW SR20DE 4 Zyl.**	
Temperature sensor, coolant, injection system	06.90-05.93		**0 280 130 064**
	06.93-09.94		**0 280 130 071**
	10.94-06.96		**0 280 130 073**
Wheel speed sensor, front	06.90-06.96	LAB	**0 265 001 274**
		RAB	**0 265 001 273**
Wheel speed sensor, rear	06.90-06.96	LAB	**0 265 001 276**
		RAB	**0 265 001 275**
2.0 i [P10E]		**2,0 l 112 kW SR20DE 4 Zyl.**	
Temperature sensor, coolant, injection system	06.90-05.93		**0 280 130 064**
Wheel speed sensor, front	06.90-05.93	LAB	**0 265 001 274**
		RAB	**0 265 001 273**
Wheel speed sensor, rear	06.90-05.93	LAB	**0 265 001 276**
		RAB	**0 265 001 275**
2.0 i [P11E]		**2,0 l 85/96 kW SR20DE; SR20DEL 4 Zyl.**	
Temperature sensor, coolant, injection system	06.96-06.99		**0 280 130 081**
Wheel speed sensor, front	06.96-06.99	LAB	**0 265 006 233**
		RAB	**0 265 006 232**
Wheel speed sensor, rear	06.96-08.97	LAB	**0 265 006 237**
	09.97-10.97	LAB	**0 265 006 379**
	06.96-08.97	RAB	**0 265 006 236**
	09.97-10.97	RAB	**0 265 006 378**
2.0 i [P11E]		**2,0 l 96 kW SR20DEL 4 Zyl.**	
Wheel speed sensor, rear	05.98-06.99	LAB	**0 265 006 237**
	10.97-04.98	LAB	**0 265 006 379**
	05.98-06.99	RAB	**0 265 006 236**
	10.97-04.98	RAB	**0 265 006 378**
2.0 i [P11E]		**2,0 l 103 kW SR20DE 4 Zyl.**	
Air mass meter, gasoline injection	06.99-12.01		**0 280 218 096**
Temperature sensor, coolant, injection system	06.99-12.01		**0 280 130 081**
Wheel speed sensor, front	06.99-12.01	LAB	**0 265 006 233**
		RAB	**0 265 006 232**
Wheel speed sensor, rear	06.99-08.00	LAB	**0 265 006 237**
	09.00-12.01	LAB	**0 265 006 708**
	06.99-08.00	RAB	**0 265 006 236**
	09.00-12.01	RAB	**0 265 006 709**
2.0 i GT [P11E]		**2,0 l 110 kW SR20DE; SR20DEH 4 Zyl.**	
Temperature sensor, coolant, injection system	06.96-06.99		**0 280 130 081**
Wheel speed sensor, front	06.96-06.99	LAB	**0 265 006 233**
		RAB	**0 265 006 232**
Wheel speed sensor, rear	06.96-08.97	LAB	**0 265 006 237**
	09.97-10.97	LAB	**0 265 006 379**
	06.96-08.97	RAB	**0 265 006 236**
	09.97-10.97	RAB	**0 265 006 378**
2.0 i GT [P11E]		**2,0 l 110 kW SR20DEH 4 Zyl.**	
Wheel speed sensor, rear	05.98-06.99	LAB	**0 265 006 237**
	10.97-04.98	LAB	**0 265 006 379**
	05.98-06.99	RAB	**0 265 006 236**
	10.97-04.98	RAB	**0 265 006 378**

N

Product			
2.0 i 4WD [P10E]		**2,0 l 85/89 kW SR20Di 4 Zyl.**	
Temperature sensor, coolant, injection system	04.91-05.93		**0 280 130 064**
Wheel speed sensor, front	04.91-05.93	LAB	**0 265 001 313**
		RAB	**0 265 001 312**
2.0 i 4WD [P10E]		**2,0 l 110 kW SR20DE 4 Zyl.**	
Temperature sensor, coolant, injection system	04.91-05.93		**0 280 130 064**
	06.93-09.94		**0 280 130 071**
	10.94-06.96		**0 280 130 073**
Wheel speed sensor, front	10.94-06.96	LAB	**0 265 001 274**
	04.91-09.94	LAB	**0 265 001 313**
	10.94-06.96	RAB	**0 265 001 273**
	04.91-09.94	RAB	**0 265 001 312**
Wheel speed sensor, rear	09.94-06.96	LAB	**0 265 001 276**
		RAB	**0 265 001 275**
2.0 i 4WD [P10E]		**2,0 l 112 kW SR20DE 4 Zyl.**	
Temperature sensor, coolant, injection system	04.91-05.93		**0 280 130 064**
Wheel speed sensor, front	04.91-05.93	LAB	**0 265 001 313**
		RAB	**0 265 001 312**
2.2 D Turbo [P12E]		**2,2 l 93 kW YD22DDT 4 Zyl.**	
Air mass meter, diesel	12.01-06.04		**0 280 218 005**
			0 986 280 232
Duo sensor, acceleration and yaw rate, brake system	08.03→		**0 265 005 265**
Wheel speed sensor, front	12.01→	LAB	**0 265 007 463**
		RAB	**0 265 007 464**
Wheel speed sensor, rear	12.01-09.02	LAB	**0 265 007 465**
	10.02→	LAB	**0 265 007 632**
	12.01-09.02	RAB	**0 265 007 466**
	10.02→	RAB	**0 265 007 633**
2.2 D Turbo [P12E]		**2,2 l 100-102 kW YD22DDT 4 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	08.03→		**0 265 005 265**
Wheel speed sensor, front	01.03→	LAB	**0 265 007 463**
		RAB	**0 265 007 464**
Wheel speed sensor, rear	01.03→	LAB	**0 265 007 632**
		RAB	**0 265 007 633**

Primera Wagon

1.6 [P12E]		**1,6 l 80 kW QG16DE 4 Zyl.**	
Air mass meter, gasoline injection	12.01-06.04		**0 280 218 094**
Temperature sensor, coolant, injection system	12.01→		**0 280 130 081**
Wheel speed sensor, front	12.01→	LAB	**0 265 007 463**
		RAB	**0 265 007 464**
Wheel speed sensor, rear	12.01-09.02	LAB	**0 265 007 465**
	10.02→	LAB	**0 265 007 632**
	12.01-09.02	RAB	**0 265 007 466**
	10.02→	RAB	**0 265 007 633**
1.6 i [WP11E]		**1,6 l 66 kW GA16DE 4 Zyl.**	
Temperature sensor, coolant, injection system	01.98-06.99		**0 280 130 081**
Wheel speed sensor, front	01.98-06.99	LAB	**0 265 006 233**
		RAB	**0 265 006 232**
Wheel speed sensor, rear	01.98-06.99	LAB	**0 265 006 237**
		RAB	**0 265 006 236**
1.6 i [WP11E]		**1,6 l 73 kW GA16DE 4 Zyl.**	
Temperature sensor, coolant, injection system	01.98-12.01		**0 280 130 081**
Wheel speed sensor, front	01.98-12.01	LAB	**0 265 006 233**
		RAB	**0 265 006 232**
Wheel speed sensor, rear	01.98-06.99	LAB	**0 265 006 237**
	06.99-12.01	LAB	**0 265 006 379**
	01.98-06.99	RAB	**0 265 006 236**
	06.99-12.01	RAB	**0 265 006 378**

Product			
1.8 [P12E]		**1,8 l 85 kW QG18DE 4 Zyl.**	
Air mass meter, gasoline injection	12.01-06.04		**0 280 218 094**
Temperature sensor, coolant, injection system	12.01→		**0 280 130 081**
Duo sensor, acceleration and yaw rate, brake system	08.03→		**0 265 005 265**
Wheel speed sensor, front	12.01→	LAB	**0 265 007 463**
		RAB	**0 265 007 464**
Wheel speed sensor, rear	12.01-09.02	LAB	**0 265 007 465**
	10.02→	LAB	**0 265 007 632**
	12.01-09.02	RAB	**0 265 007 466**
	10.02→	RAB	**0 265 007 633**
1.8 i [WP11E]		**1,8 l 84 kW QG18DE 4 Zyl.**	
Air mass meter, gasoline injection	06.99-09.00		**0 280 218 005**
			0 986 280 232
	10.00-12.01		**0 280 218 094**
Temperature sensor, coolant, injection system	06.99-12.01		**0 280 130 081**
Wheel speed sensor, front	06.99-12.01	LAB	**0 265 006 233**
		RAB	**0 265 006 232**
Wheel speed sensor, rear	06.99-12.01	LAB	**0 265 006 379**
		RAB	**0 265 006 378**
1.9 D Turbo [P12E]		**1,9 l 85-88 kW F9Q 4 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	08.03→		**0 265 005 265**
Wheel speed sensor, front	01.03→	LAB	**0 265 007 463**
		RAB	**0 265 007 464**
Wheel speed sensor, rear	01.03→	LAB	**0 265 007 632**
		RAB	**0 265 007 633**
2.0 [P12E]		**2,0 l 103 kW QR20DE 4 Zyl.**	
Air mass meter, gasoline injection	12.01-06.04		**0 280 218 096**
Duo sensor, acceleration and yaw rate, brake system	08.03→		**0 265 005 265**
Wheel speed sensor, front	12.01→	LAB	**0 265 007 463**
		RAB	**0 265 007 464**
Wheel speed sensor, rear	12.01-09.02	LAB	**0 265 007 465**
	10.02→	LAB	**0 265 007 632**
	12.01-09.02	RAB	**0 265 007 466**
	10.02→	RAB	**0 265 007 633**
2.0 D Turbo [WP11E]		**2,0 l 66 kW CD20T 4 Zyl.**	
Air mass meter, diesel	01.98-12.01		**0 281 002 207**
Temperature sensor, coolant, diesel	01.98-12.01		**0 280 130 081**
Wheel speed sensor, front	01.98-12.01	LAB	**0 265 006 233**
		RAB	**0 265 006 232**
Wheel speed sensor, rear	01.98-06.99	LAB	**0 265 006 237**
	07.99-12.01	LAB	**0 265 006 379**
	01.98-06.99	RAB	**0 265 006 236**
	07.99-12.01	RAB	**0 265 006 378**
2.0 i [WP11E]		**2,0 l 85/96 kW SR20DE 4 Zyl.**	
Temperature sensor, coolant, injection system	01.98-06.99		**0 280 130 081**
Wheel speed sensor, front	01.98-06.99	LAB	**0 265 006 233**
		RAB	**0 265 006 232**
Wheel speed sensor, rear	01.98-06.99	LAB	**0 265 006 237**
		RAB	**0 265 006 236**
2.0 i [WP11E]		**2,0 l 103 kW SR20DE 4 Zyl.**	
Air mass meter, gasoline injection	06.99-12.01		**0 280 218 096**
Temperature sensor, coolant, injection system	06.99-12.01		**0 280 130 081**
Wheel speed sensor, front	06.99-12.01	LAB	**0 265 006 233**
		RAB	**0 265 006 232**
Wheel speed sensor, rear	06.99-12.01	LAB	**0 265 006 379**
		RAB	**0 265 006 378**
2.0 i [W10]		**2,0 l 85/89 kW SR20Di 4 Zyl.**	
Temperature sensor, coolant, injection system	07.90-07.94		**0 280 130 064**
Wheel speed sensor, front	07.90-07.94	LAB	**0 265 001 274**
		RAB	**0 265 001 273**

N

Product			
◀ Primera Wagon			
Wheel speed sensor, rear	07.90-07.94	LAB	**0 265 001 276**
		RAB	**0 265 001 275**
2.2 D Turbo [P12E]		**2,2 l 93 kW YD22DDT 4 Zyl.**	
Air mass meter, diesel	12.01-06.04		**0 280 218 005**
			0 986 280 232
Duo sensor, acceleration and yaw rate, brake system	08.03→		**0 265 005 265**
Wheel speed sensor, front	12.01→	LAB	**0 265 007 463**
		RAB	**0 265 007 464**
Wheel speed sensor, rear	12.01-09.02	LAB	**0 265 007 465**
	10.02→	LAB	**0 265 007 632**
	12.01-09.02	RAB	**0 265 007 466**
	10.02→	RAB	**0 265 007 633**
2.2 D Turbo [P12E]		**2,2 l 100-102 kW YD22DDT 4 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	08.03→		**0 265 005 265**
Wheel speed sensor, front	01.03→	LAB	**0 265 007 463**
		RAB	**0 265 007 464**
Wheel speed sensor, rear	01.03→	LAB	**0 265 007 632**
		RAB	**0 265 007 633**

Pulsar Hatchback

1.8 i [N13]		**1,8 l 79 kW 18LE 4 Zyl.**	
Temperature sensor, coolant, injection system	08.87-10.91		**0 280 130 026**

Qashqai

1.5 dCi [J10]		**1,5 l 78 kW K9K 4 Zyl.**	
Wheel speed sensor, front	12.06→		**0 265 007 905**
Wheel speed sensor, rear	12.06→		**0 265 007 908**
1.6 [J10]		**1,6 l 84 kW HR16DE 4 Zyl.**	
Wheel speed sensor, front	12.06→		**0 265 007 905**
Wheel speed sensor, rear	12.06→		**0 265 007 908**
2.0 [J10]		**2,0 l 103 kW MR20DE 4 Zyl.**	
Wheel speed sensor, front	12.06→		**0 265 007 905**
Wheel speed sensor, rear	12.06→		**0 265 007 908**
2.0 4x4 [J10]		**2,0 l 103 kW MR20DE 4 Zyl.**	
Wheel speed sensor, front	12.06→		**0 265 007 905**
Wheel speed sensor, rear	12.06→		**0 265 007 909**

Quest

3.0 [V40]		**3,0 l 113 kW VG30E 6 Zyl.**	
Temperature sensor, coolant, injection system	10.95-09.98		**0 280 130 081**
Wheel speed sensor, front	04.92-09.98	LAB	**0 265 001 317**
	04.92-11.93	RAB	**0 265 001 316**
	09.95-09.98	RAB	**0 265 001 415**
Wheel speed sensor, rear	04.92-09.98	LAB	**0 265 001 319**
		RAB	**0 265 001 318**
3.3 s [V41]		**3,3 l 125 kW VG33E 6 Zyl.**	
Temperature sensor, coolant, injection system	10.98-04.03		**0 280 130 081**

Serena

1.6 i [C23M]		**1,6 l 71 kW GA16DE 4 Zyl.**	
Temperature sensor, coolant, injection system	07.92-09.94		**0 280 130 071**
	10.94-06.96		**0 280 130 073**
	07.96-11.01		**0 280 130 081**
2.0 i [C23M]		**2,0 l 93 kW SR20DE 4 Zyl.**	
Temperature sensor, coolant, injection system	07.92-11.01		**0 280 130 071**
	07.92-10.95		**0 280 130 071**
	07.92-11.01		**0 280 130 071**
	07.92-10.95		**0 280 130 071**
	11.95-06.96		**0 280 130 073**
	07.96-11.01		**0 280 130 081**

Terrano II

2.4 i [R20]		**2,4 l 85-87 kW KA24E 4 Zyl.**	
Temperature sensor, coolant, injection system	05.96-02.04		**0 280 130 081**
Wheel speed sensor, front	05.96-02.02	LAB	**0 265 006 670**
	03.02→	LAB	**0 265 006 756**
	05.96-02.02	RAB	**0 265 006 671**
	03.02→	RAB	**0 265 006 755**
Wheel speed sensor, rear	11.96-12.99		**0 265 006 281**
	05.96→	TU3	**0 265 006 281**
	05.96-02.02	TU5	**0 265 006 285**
	03.02→	TU5	**0 265 006 779**
2.7 D Turbo [R20]		**2,7 l 74 kW TD27T 4 Zyl.**	
Wheel speed sensor, front	10.99-02.02	LAB	**0 265 006 670**
		RAB	**0 265 006 671**
Wheel speed sensor, rear	10.99-02.02	TU3	**0 265 006 281**
		TU5	**0 265 006 285**
2.7 D Turbo [R20]		**2,7 l 92 kW TD27TI 4 Zyl.**	
Air mass meter, diesel	11.98→		**0 281 002 207**
	06.03→		**0 281 002 597**
	10.97→	GS	**0 281 002 207**
	10.00-02.02	GS	**0 281 002 207**
			0 281 002 440
Speed sensor, diesel	11.97→	GS	**0 281 002 191**
Temperature sensor, coolant, diesel	01.97→		**0 280 130 081**
Wheel speed sensor, front	11.96→	LAB	**0 265 006 670**
	01.96-02.02	LAB	**0 265 006 670**
	03.02→	LAB	**0 265 006 756**
	11.96→	RAB	**0 265 006 671**
	01.96-02.02	RAB	**0 265 006 671**
	03.02→	RAB	**0 265 006 755**
Wheel speed sensor, rear	11.96→		**0 265 006 281**
	11.98→	TU3	**0 265 006 281**
	01.96-06.02	TU3	**0 265 006 281**
	07.02→	TU3	**0 265 006 778**
	11.98→	TU5	**0 265 006 285**
	01.96-06.02	TU5	**0 265 006 285**
	07.02→	TU5	**0 265 006 779**
3.0 D Turbo [R20]		**3,0 l 113 kW ZD30 4 Zyl.**	
Wheel speed sensor, front	02.02→	LAB	**0 265 006 756**
		RAB	**0 265 006 755**
Wheel speed sensor, rear	02.02-06.02	TU3	**0 265 006 281**
	07.02→	TU3	**0 265 006 778**
	02.02-06.02	TU5	**0 265 006 285**
	07.02→	TU5	**0 265 006 779**

Vanette Cargo

1.6 i [C23M]		**1,6 l 71-72 kW GA16DE 4 Zyl.**	
Temperature sensor, coolant, injection system	07.92-11.01		**0 280 130 071**
	07.92-09.94		**0 280 130 071**
	10.94-06.96		**0 280 130 073**
	07.96-11.01		**0 280 130 081**

N

Product

OPEL

Agila

1.0 i			**1,0 l 43 kW Z 10 XE 3 Zyl.**
Throttle valve assembly	06.00-08.03		**0 280 750 044**
Air mass meter, gasoline injection	06.00-08.03		**0 280 218 031**
			0 986 280 230
Phase sensor	06.00-08.03	NOC	**0 232 103 021**
Speed sensor, ignition/injection	06.00-08.03	FKW	**0 261 210 151**
Knock sensor	06.00-08.03		**0 261 231 120**
Temperature sensor, coolant, injection system			
Mot.no. →19T85744	06.00-08.03		**0 281 002 169**
Mot.no. 19T85745→	06.00-08.03		**0 281 002 170**
1.0 Twinport			**1,0 l 44 kW Z 10 XEP 3 Zyl.**
Throttle valve assembly	08.03-02.08		**0 280 750 133**
Air mass meter, gasoline injection	08.03-02.08		**0 280 218 119**
Phase sensor			
Fg.no. →5G999999	08.03-02.08	NOC	**0 232 103 052**
Fg.no. 6G000001→	08.03-02.08	NOC	**0 232 103 067**
Speed sensor, ignition/injection	08.03-02.08	FKW	**0 261 210 151**
Knock sensor	08.03-02.08		**0 261 231 173**
1.2 i			**1,2 l 55 kW Z 12 XE 4 Zyl.**
Throttle valve assembly	06.00-06.04		**0 280 750 044**
Air mass meter, gasoline injection	06.00-06.04		**0 280 218 031**
			0 986 280 230
Phase sensor	06.00-06.04	NOC	**0 232 103 021**
Speed sensor, ignition/injection	06.00-06.04	FKW	**0 261 210 151**
Knock sensor	06.00-06.04		**0 261 231 120**
Temperature sensor, coolant, injection system			
Mot.no. →19T85744	06.00-06.04		**0 281 002 169**
Mot.no. 19T85745→	06.00-06.04		**0 281 002 170**
1.2 Twinport			**1,2 l 59 kW Z 12 XEP 4 Zyl.**
Throttle valve assembly	07.04-02.08		**0 280 750 133**
Air mass meter, gasoline injection	07.04-02.08		**0 280 218 119**
Phase sensor	07.04-02.08	NOC	**0 232 103 052**
Speed sensor, ignition/injection	07.04-02.08	FKW	**0 261 210 151**
Knock sensor	07.04-02.08		**0 261 231 173**
1.3 CDTI			**1,2 l 51 kW Z 13 DT 4 Zyl.**
Air mass meter, diesel	08.03-02.08		**0 281 002 619**
High-pressure sensor (CR system)	08.03-02.08		**0 281 002 534**
Pressure sensor, intake manifold, diesel	08.03-02.08		**0 281 002 510**

Antara

3.2 V6			**3,2 l 165-167 kW Z 32 SE 6 Zyl.**
Knock sensor	05.06→		**0 261 231 174**

Ascona

1.8 i [C]			**1,8 l 74 kW C 18 NE 4 Zyl.**
Throttle valve sensor	01.85-08.86		**0 280 120 301**
Air flow sensor, gasoline injection	01.85-08.86		**0 280 202 076**
Temperature sensor, coolant, injection system	01.85-08.86		**0 280 130 107**
1.8 i [C]			**1,8 l 85 kW 18 E 4 Zyl.**
Throttle valve sensor	09.82-08.86		**0 280 120 301**
Air flow sensor, gasoline injection	09.82-08.86		**0 280 202 033**
	CH,S 09.83-08.86		**0 280 202 054**
Temperature sensor, coolant, injection system	09.82-08.86		**0 280 130 107**
1.8 i [C]			**1,8 l 85 kW 18 SE 4 Zyl.**
Throttle valve sensor	09.86-08.88		**0 280 120 316**
Air flow sensor, gasoline injection	09.86-08.88		**0 280 202 602**
			0 986 280 019
Speed sensor, ignition/injection	09.86-08.88		**0 261 210 030**
Temperature sensor, coolant, injection system	09.86-08.88		**0 280 130 107**
1.8 S [C]			**1,8 l 62 kW E 18 NV ; S 18 NV 4 Zyl.**
Temperature sensor, coolant, injection system	09.87-08.88		**0 280 130 107**
2.0 i [C]			**2,0 l 74 kW 20 S (NEF) 4 Zyl.**
Temperature sensor, coolant, injection system	03.87-08.88		**0 280 130 107**
2.0 i [C]			**2,0 l 85/95 kW 20 NE, C 20 NE; 20 SEH 4 Zyl.**
Throttle valve sensor	09.86-08.88		**0 280 120 316**
Speed sensor, ignition/injection	09.86-08.88		**0 261 210 030**
Pressure sensor, intake manifold, gasoline	09.86-08.88		**0 280 101 007**
Temperature sensor, coolant, injection system	09.86-08.88		**0 280 130 107**
Wheel speed sensor	01.87-08.88	HI,LAB	**0 265 001 147**
		HI,RAB	**0 265 001 145**
		VO	**0 265 001 144**

Astra

1.2 i [G]			**1,2 l 48 kW X 12 XE 4 Zyl.**
Throttle valve assembly	09.97-09.03		**0 205 003 050**
Throttle valve sensor	09.97-09.03		**0 280 122 014**
Air mass meter, gasoline injection	09.97-09.03		**0 280 217 123**
Phase sensor	09.97-09.03	NOC	**0 232 103 021**
Speed sensor, ignition/injection	09.97-09.03	FKW	**0 261 210 151**
Knock sensor	09.97-09.03		**0 261 231 120**
Temperature sensor, coolant, injection system	09.97-09.03		**0 281 002 169**
1.2 i [G]			**1,2 l 55 kW Z 12 XE 4 Zyl.**
Throttle valve assembly	09.00-09.03		**0 280 750 044**
Air mass meter, gasoline injection	09.00-09.03		**0 280 218 031**
			0 986 280 230
Phase sensor	09.00-09.03	NOC	**0 232 103 021**
Speed sensor, ignition/injection	09.00-09.03	FKW	**0 261 210 151**
Knock sensor	09.00-09.03		**0 261 231 120**
Temperature sensor, coolant, injection system	09.00-09.03		**0 281 002 169**
1.2 i Twinport [H]			**1,2 l 59 kW Z 12 XEP 4 Zyl.**
Throttle valve assembly	03.07→		**0 280 750 133**
Air mass meter, gasoline injection	03.07→		**0 280 218 119**
Phase sensor	03.07→	NOC	**0 232 103 052**
Speed sensor, ignition/injection	03.07→	FKW	**0 261 210 151**
Knock sensor	03.07→		**0 261 231 173**
Temperature sensor, coolant, injection system	03.07→		**0 281 002 170**
1.3 CDTI [H]			**1,3 l 66 kW Z 13 DTH 4 Zyl.**
Air mass meter, diesel	08.05→		**0 281 002 683**
High-pressure sensor (CR system)	08.05→		**0 281 002 534**
Boost pressure sensor, Diesel	08.05→		**0 281 002 437**
1.4 i [F]			**1,4 l 44/60/66 kW C/X 14 NZ; X 14 XE; 14 SE / C 14 SE 4 Zyl.**
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
1.4 i [G]			**1,4 l 66 kW X 14 XE 4 Zyl.**
Temperature sensor, coolant, injection system	09.97-09.00		**0 281 002 169**
1.4 i [H]			**1,4 l 55 kW Z 14 XEL 4 Zyl.**
Throttle valve assembly	09.04-09.05		**0 280 750 133**
Air mass meter, gasoline injection	09.04-09.05		**0 280 218 119**
Phase sensor			
Fg.no. →52999999,→55999999, →58999999	09.04-09.05	NOC	**0 232 103 052**
Fg.no. 62000001→,65000001→, 68000001→	09.04-09.05	NOC	**0 232 103 067**
Speed sensor, ignition/injection	09.04-09.05	FKW	**0 261 210 151**
Knock sensor	09.04-09.05		**0 261 231 173**
Temperature sensor, coolant, injection system	09.04-09.05		**0 281 002 170**

O

Product			
◀ Astra			
1.4 Twinport [G]			**1,4 l 66 kW Z 14 XEP 4 Zyl.**
Throttle valve assembly	09.03-01.04		**0 280 750 133**
Phase sensor	09.03-01.04	NOC	**0 232 103 021**
Speed sensor, ignition/injection	09.03-01.04	FKW	**0 261 210 151**
Knock sensor	09.03-01.04		**0 261 231 173**
Temperature sensor, coolant, injection system	09.03-01.04		**0 281 002 170**
1.4 Twinport [H]			**1,4 l 66 kW Z 14 XEP 4 Zyl.**
Throttle valve assembly	03.04→		**0 280 750 133**
Air mass meter, gasoline injection	03.04→		**0 280 218 119**
Phase sensor			
Fg.no. →42999999,→45999999, →48999999	03.04→	NOC	**0 232 103 021**
Fg.no. 52000001→52999999, 55000001→55999999, 58000001→58999999	03.04→	NOC	**0 232 103 052**
Fg.no. 62000001→,65000001→, 68000001→	03.04→	NOC	**0 232 103 067**
Speed sensor, ignition/injection	03.04→	FKW	**0 261 210 151**
Knock sensor	03.04→		**0 261 231 173**
Temperature sensor, coolant, injection system	03.04→		**0 281 002 170**
1.6 i [F] 1,6 l 52/55 kW C/E 16 NZ; X 16 SZ,SZR; 16 LZ2,NZ2,16 NZR 4 Zyl.			
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
1.6 i [F] 1,6 l 74 kW C 16 SE; X 16 XEL 4 Zyl.			
Temperature sensor, coolant, injection system	03.92-02.98		**0 280 130 107**
1.6 i [G] 1,6 l 55/74 kW C 16 SEL; X 16 SZR; X 16 XEL 4 Zyl.			
Temperature sensor, coolant, injection system	09.97-01.04		**0 281 002 169**
1.6 i [G] 1,6 l 74 kW Z 16 XE 4 Zyl.			
Yaw rate sensor, brake system	09.00-01.04		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.00-01.04		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-01.04		**0 265 005 303**
1.6 i Twinport [G] 1,6 l 76 kW Z 16 XEP 4 Zyl.			
Yaw rate sensor, brake system	03.03-01.04		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	03.03-01.04		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	03.03-01.04		**0 265 005 303**
1.6 Turbo [H] 1,6 l 132 kW Z 16 LET 4 Zyl.			
Air mass meter, gasoline injection	02.07→		**0 280 218 142**
Phase sensor	02.07→	NOC	**0 232 103 052**
Knock sensor	02.07→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	02.07→		**0 261 230 009**
1.7 CDTI [G] 1,7 l 59 kW Z 17 DTL 4 Zyl.			
Air mass meter, diesel	03.03-01.04		**0 281 002 549**
1.7 CDTI [H] 1,7 l 59/74 kW Z 17 DTH; Z 17 DTL 4 Zyl.			
Air mass meter, diesel	03.04-03.07		**0 281 002 683**
1.7 DT [G] 1,7 l 50 kW X 17 DTL 4 Zyl.			
Air mass meter, diesel	03.98-08.00		**0 281 002 180**
Speed sensor, diesel	03.98-08.00		**0 281 002 285**
Temperature sensor, coolant, diesel	03.98-08.00		**0 281 002 259**
Accelerator pedal module	03.98-08.00	AG,LLE	**0 281 002 236**
		AG,RLE	**0 281 002 237**
1.7 DTI [G] 1,7 l 55 kW Y 17 DT 4 Zyl.			
Air mass meter, diesel	09.00-01.04		**0 281 002 180**
1.8 i [F] 1,8 l 66 kW C 18 NZ 4 Zyl.			
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
1.8 i [F] 1,8 l 82 kW 18 SE 4 Zyl.			
Throttle valve sensor	09.95-09.96		**0 280 120 316**
Air mass meter, gasoline injection	09.95-09.96		**0 280 217 003**
Temperature sensor, intake air, injection system	09.95-09.96		**0 280 130 073**
1.8 i [F] 1,8 l 85 kW C 18 SEL; C 18 XEL; X 18 XE 4 Zyl.			
Throttle valve sensor	09.95-08.98		**0 280 122 001**
1.8 i [F] 1,8 l 92 kW C 18 XE 4 Zyl.			
Throttle valve sensor	09.93-02.98		**0 280 122 001**

Product			
1.8 i [F] 1,8 l 99 kW 18SEL 16V 4 Zyl.			
Temperature sensor, intake air, injection system	01.96-12.98		**0 280 130 073**
1.8 i [G] 1,8 l 85 kW X 18 XE1 4 Zyl.			
Yaw rate sensor, brake system	09.97-08.00		**0 265 005 261**
Steering angle sensor, ESP (electronic stability program)	09.97-08.00		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.97-08.00		**0 265 005 303**
1.8 i [G] 1,8 l 85 kW Z 18 XEL 4 Zyl.			
Yaw rate sensor, brake system	03.01-01.04		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)			
Fg.no. 12000001→,1H000001→, 22000001→,25000001→, 26000001→,28000001→, 2H000001→,1B000001→	03.01-01.04		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	03.01-01.04		**0 265 005 303**
1.8 i [G] 1,8 l 92 kW Z 18 XE 4 Zyl.			
Yaw rate sensor, brake system	09.00-01.04		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.00-01.04		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-01.04		**0 265 005 303**
1.9 CDTI [H] 1,9 l 74 kW Z 19... 4 Zyl.			
Air mass meter, diesel	09.05→		**0 281 002 683**
Speed sensor, diesel	09.05→		**0 281 002 603**
Phase sensor	09.05→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	09.05→		**0 281 002 534**
1.9 CDTI [H] 1,9 l 88 kW Z 19 ... 4 Zyl.			
High-pressure sensor (CR system)	04.04→		**0 281 002 534**
Boost pressure sensor, Diesel	04.04→		**0 281 002 437**
1.9 CDTI [H] 1,9 l 110 kW Z 19 DTH 4 Zyl.			
Air mass meter, diesel	04.04→		**0 281 002 683**
Boost pressure sensor, Diesel	04.04→		**0 281 002 437**
2.0 DT [G] 2,0 l 60 kW X 20 DTL 4 Zyl.			
Air mass meter, diesel	03.98-08.00		**0 281 002 180**
Speed sensor, diesel	03.98-08.00		**0 281 002 138**
Temperature sensor, coolant, diesel	03.98-08.00		**0 281 002 169**
Accelerator pedal module	03.98-08.00	AG,LLE	**0 281 002 236**
		AG,RLE	**0 281 002 237**
2.0 DTI [G] 2,0 l 74 kW Y 20 DTH 4 Zyl.			
Air mass meter, diesel			
Fg.no. →Y2999999,→Y5999999, →Y6999999,→Y8999999, →YH999999	09.00-01.04		**0 281 002 180**
Fg.no. 12000001→22999999, 15000001→25999999, 16000001→26999999, 18000001→28999999, 1H000001→2B999999, →2H999999	09.00-01.04		**0 281 002 428**
Fg.no. 32000001→,35000001→, 36000001→,38000001→, 3B000001→,3H000001→	09.00-01.04		**0 281 002 478**
Speed sensor, diesel	09.00-01.04		**0 281 002 138**
Pressure sensor, intake manifold, diesel			
Fg.no. →Y2999999,→Y5999999, →Y6999999,→Y8999999, →YB999999,→YH999999	09.00-01.04		**0 281 002 137**
Fg.no. 12000001→22999999, 15000001→25999999, 16000001→26999999, 18000001→28999999, 1B000001→2B999999, 1H000001→2H999999	09.00-01.04		**0 281 002 438**

Product			
Temperature sensor, coolant, diesel	09.00-01.04		**0 281 002 169**
Accelerator pedal module	09.00-01.04	AG,LLE	**0 281 002 236**
		AG,RLE	**0 281 002 237**
2.0 DTL [G]			**2,0 l 60 kW Y 20 DTL 4 Zyl.**
Air mass meter, diesel			
Fg.no. →Y2999999,→Y5999999, →Y6999999,→Y8999999,→YH999999	09.00-01.04		**0 281 002 180**
Fg.no. 12000001→,15000001→, 16000001→,18000001→,1H000001→	09.00-01.04		**0 281 002 428**
Speed sensor, diesel	09.00-01.04		**0 281 002 138**
Temperature sensor, coolant, diesel	09.00-01.04		**0 281 002 169**
Accelerator pedal module	09.00-01.04	AG,LLE	**0 281 002 236**
		AG,RLE	**0 281 002 237**
2.0 i [F]			**2,0 l 85 kW C 20 NE / 20 NE 4 Zyl.**
Throttle valve sensor	09.91-02.98		**0 280 122 001**
Air mass meter, gasoline injection	09.91-02.98		**0 280 217 003**
Speed sensor, ignition/injection			
Fg.no. S2000001→,S3000001→, S4000001→,S5000001→, S6000001→,S8000001→	09.91-02.98		**0 261 210 030**
Temperature sensor, intake air, injection system	09.91-02.98		**0 280 130 073**
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
2.0 i [F]			**2,0 l 100 kW X 20 XEV 4 Zyl.**
Throttle valve sensor	01.95-02.98		**0 280 122 001**
2.0 i [F]			**2,0 l 110 kW C 20 XE / XE-LN 4 Zyl.**
Throttle valve sensor	09.91-08.92		**0 280 120 436**
	09.92-02.98		**0 280 122 004**
Air mass meter, gasoline injection			
Fg.no. P2500001→,P3000001→, P4000001→,P5000001→, P6000001→,P8000001→	09.91-02.98		**0 280 217 106**
Fg.no. →NA299999,→NE299999, →N2999999,→N4999999,→N5999999, →N6999999	09.91-02.98		**0 280 212 015**
			0 986 280 113
Speed sensor, ignition/injection	09.91-02.98		**0 261 210 030**
Knock sensor	09.91-06.95		**0 261 231 006**
Temperature sensor, intake air, injection system	09.91-02.98		**0 280 130 073**
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
2.0 i [G]			**2,0 l 100 kW X 20 XEV 4 Zyl.**
Throttle valve sensor	09.97-01.04		**0 280 122 014**
2.0 i [G]			**2,0 l 100 kW 20SEL 4 Zyl.**
Throttle valve sensor	10.99-12.01		**0 280 122 001**
Knock sensor	10.99-12.01		**0 261 231 007**
Temperature sensor, intake air, injection system	10.99-12.01		**0 280 130 073**
Temperature sensor, coolant, injection system	10.99-12.01		**0 280 130 107**
2.0 i [G]			**2,0 l 118 kW X 20 XER 4 Zyl.**
Throttle valve sensor	10.99-09.02		**0 280 122 014**
2.0 Turbo [G]			**2,0 l 141-147 kW Z 20 LET 4 Zyl.**
Air mass meter, gasoline injection	09.02-01.04		**0 280 218 051**
			0 986 280 231
Phase sensor	09.02-01.04		**0 232 103 015**
Speed sensor, ignition/injection	09.02-01.04	FKW	**0 261 210 150**
Knock sensor	09.02-01.04		**0 261 231 116**
Pressure sensor, intake manifold, gasoline	09.02-01.04		**0 261 230 009**
Temperature sensor, coolant, injection system	09.02-01.04		**0 281 002 169**
Yaw rate sensor, brake system	09.02-01.04		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.02-01.04		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.02-01.04		**0 265 005 303**
2.0 Turbo [H]			**2,0 l 125/147 kW Z 20 LEL; Z 20 LER 4 Zyl.**
Air mass meter, gasoline injection	03.04→		**0 280 218 142**
Phase sensor	03.04→	NOC	**0 232 103 015**
Speed sensor, ignition/injection	03.04→	FKW	**0 261 210 150**

Product			
Knock sensor	03.04→		**0 261 231 181**
Pressure sensor, intake manifold, gasoline	03.04→		**0 281 002 137**
Temperature sensor, coolant, injection system	03.04→		**0 281 002 169**
2.0 Turbo [H]			**2,0 l 177 kW Z 20 LEH 4 Zyl.**
Air mass meter, gasoline injection			
Fg.no. →52999999,→55999999, →58999999	09.05→		**0 280 218 164**
Fg.no. 62000001→,65000001→, 68000001→	09.05→		**0 280 218 211**
Phase sensor	09.05→	NOC	**0 232 103 015**
Speed sensor, ignition/injection	09.05→	FKW	**0 261 210 150**
Knock sensor	09.05→		**0 261 231 181**
Pressure sensor, intake manifold, gasoline	09.05→		**0 281 002 137**
Temperature sensor, coolant, injection system	09.05→		**0 281 002 169**
2.2 DTI [G]			**2,2 l 92 kW Y 22 DTR 4 Zyl.**
Air flow sensor, diesel	09.01-01.04		**0 281 002 478**
Speed sensor, diesel	09.01-01.04	FKW	**0 281 002 138**
Boost pressure sensor, Diesel	09.01-01.04		**0 281 002 437**
Temperature sensor, coolant, diesel	09.01-01.04		**0 281 002 170**
Yaw rate sensor, brake system			
Fg.no. 22000001→,2B000001→, 2H000001→,25000001→, 26000001→,28000001→	09.01-01.04		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)			
Fg.no. 12000001→,1H000001→, 22000001→,25000001→,26000001→, 28000001→,2H000001→,1B000001→	09.01-01.04		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.01-01.04		**0 265 005 303**
2.2 i [G]			**2,2 l 108 kW Z 22 SE 4 Zyl.**
Yaw rate sensor, brake system	09.00-01.04		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)			
Fg.no. 12000001→,1H000001→, 22000001→,25000001→,26000001→, 28000001→,2H000001→,1B000001→	09.00-01.04		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-01.04		**0 265 005 303**

Astra Cabrio

1.4 i [F]			**1,4 l 44/60/66 kW C/X 14 NZ; X 14 XE; 14 SE / C 14 SE 4 Zyl.**
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
1.4 i [G]			**1,4 l 66 kW X 14 XE 4 Zyl.**
Temperature sensor, coolant, injection system	09.97-02.05		**0 281 002 169**
1.6 i [F]			**1,6 l 52/55 kW C/E 16 NZ; X 16 SZ,SZR; 16 LZ2,NZ2,16 NZR 4 Zyl.**
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
1.6 i [F]			**1,6 l 74 kW X 16 XEL 4 Zyl.**
Temperature sensor, coolant, injection system	09.94-02.98		**0 280 130 107**
1.6 i [G]			**1,6 l 74 kW X 16 XEL 4 Zyl.**
Temperature sensor, coolant, injection system	09.97-08.00		**0 281 002 169**
1.6 i TwinTop [H]			**1,6 l 85 kW Z 16 XER 4 Zyl.**
Pressure sensor, intake manifold, gasoline	01.07→		**0 261 230 009**
1.6 i TwinTop [H]			**1,6 l 132 kW Z 16 LET 4 Zyl.**
Air mass meter, gasoline injection	02.07→		**0 280 218 142**
Phase sensor	02.07→	NOC	**0 232 103 052**
Pressure sensor, intake manifold, gasoline	02.07→		**0 261 230 009**
1.6 Twinport [G]			**1,6 l 76 kW Z 16 XEP 4 Zyl.**
Yaw rate sensor, brake system	03.03-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	03.03-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	03.03-08.05		**0 265 005 303**
1.7 CDTI [G]			**1,7 l 59 kW Z 17 DTL Turbo 4 Zyl.**
Air mass meter, diesel	03.03-08.05		**0 281 002 549**

Product

◀ Astra Cabrio

1.8 i [F]			**1,8 l 66 kW C 18 NZ 4 Zyl.**
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
1.8 i [F]			**1,8 l 85 kW C 18 XEL; X 18 XE 4 Zyl.**
Throttle valve sensor	09.95-08.98		**0 280 122 001**
1.8 i [F]			**1,8 l 92 kW C 18 XE 4 Zyl.**
Throttle valve sensor	09.93-02.98		**0 280 122 001**
1.8 i [G]			**1,8 l 92 kW Z 18 XE 4 Zyl.**
Yaw rate sensor, brake system	09.00-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)			
Fg.no. 1B000001→	09.00-08.05		**0 265 005 433**
Pressure sensor, ESP, (electronic stability program)	09.00-08.05		**0 265 005 303**
1.9 CDTi TwinTop [H]			**1,9 l 110 kW Z 19 DTH 4 Zyl.**
Air mass meter, diesel	09.05→		**0 281 002 683**
High-pressure sensor (CR system)	09.05→		**0 281 002 706**
Boost pressure sensor, Diesel	09.05→		**0 281 002 437**
2.0 i [F]			**2,0 l 85 kW C 20 NE / 20 NE 4 Zyl.**
Throttle valve sensor	09.91-02.98		**0 280 122 001**
Air mass meter, gasoline injection	09.91-02.98		**0 280 217 003**
Speed sensor, ignition/injection			
Fg.no. S2000001→,S3000001→, S4000001→,S5000001→, S6000001→,S8000001→	09.91-02.98		**0 261 210 030**
Temperature sensor, intake air, injection system	09.91-02.98		**0 280 130 073**
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
2.0 i [F]			**2,0 l 100 kW X 20 XEV 4 Zyl.**
Throttle valve sensor	01.95-02.98		**0 280 122 001**
2.0 i [F]			**2,0 l 110 kW C 20 XE / XE-LN 4 Zyl.**
Throttle valve sensor	09.91-08.92		**0 280 120 436**
	09.92-02.98		**0 280 122 004**
Air mass meter, gasoline injection			
Fg.no. P2500001→,P3000001→, P4000001→,P5000001→, P6000001→,P8000001→	09.91-02.98		**0 280 217 106**
Fg.no. →NA299999,→NE299999, →N2999999,→N4999999,→N5999999, →N6999999	09.91-02.98		**0 280 212 015**
			0 986 280 113
Speed sensor, ignition/injection	09.91-02.98		**0 261 210 030**
Knock sensor	09.91-06.95		**0 261 231 006**
Temperature sensor, intake air, injection system	09.91-02.98		**0 280 130 073**
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
2.0 i Turbo TwinTop [H]			**2,0 l 125/147 kW Z 20 LEL; Z 20 LER 4 Zyl.**
Air mass meter, gasoline injection	09.05→		**0 280 218 142**
Phase sensor	09.05→	NOC	**0 232 103 015**
Speed sensor, ignition/injection	09.05→	FKW	**0 261 210 150**
Knock sensor	09.05→		**0 261 231 181**
Pressure sensor, intake manifold, gasoline	09.05→		**0 281 002 137**
Temperature sensor, coolant, injection system	09.05→		**0 281 002 169**
2.0 Turbo [G]			**2,0 l 141-147 kW Z 20 LET 4 Zyl.**
Throttle valve sensor	03.02-08.05		**0 280 122 014**
Air mass meter, gasoline injection	03.02-08.05		**0 280 218 051**
			0 986 280 231
Phase sensor	03.02-08.05		**0 232 103 015**
Speed sensor, ignition/injection	03.02-08.05	FKW	**0 261 210 150**
Knock sensor	03.02-08.05		**0 261 231 116**
Temperature sensor, coolant, injection system	03.02-08.05		**0 281 002 169**
Yaw rate sensor, brake system	03.02-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)			
Fg.no. 12000001→,1H000001→, 22000001→,25000001→,26000001→, 28000001→,2H000001→,1B000001→	03.02-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	03.02-08.05		**0 265 005 303**

Product

2.2 DTI [G]			**2,2 l 92 kW Y 22 DTR 4 Zyl.**
Air flow sensor, diesel	03.02-08.05		**0 281 002 478**
Speed sensor, diesel	03.02-08.05	FKW	**0 281 002 138**
Boost pressure sensor, Diesel	03.02-08.05		**0 281 002 437**
Temperature sensor, coolant, diesel	03.02-08.05		**0 281 002 170**
Yaw rate sensor, brake system	03.02-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)			
Fg.no. →YB999999	03.02-08.05		**0 265 005 433**
Fg.no. 12000001→,1H000001→, 22000001→,25000001→,26000001→, 28000001→,2H000001→,1B000001→	03.02-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	03.02-08.05		**0 265 005 303**
2.2 i [G]			**2,2 l 108 kW Z 22 SE 4 Zyl.**
Yaw rate sensor, brake system	09.00-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.00-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-08.05		**0 265 005 303**

Astra Caravan

1.2 i [G]			**1,2 l 48 kW X 12 XE 4 Zyl.**
Throttle valve assembly	09.97-09.03		**0 205 003 050**
Throttle valve sensor	09.97-09.03		**0 280 122 014**
Air mass meter, gasoline injection	09.97-09.03		**0 280 217 123**
Phase sensor	09.97-09.03	NOC	**0 232 103 021**
Speed sensor, ignition/injection	09.97-09.03	FKW	**0 261 210 151**
Knock sensor	09.97-09.03		**0 261 231 120**
Temperature sensor, coolant, injection system	09.97-09.03		**0 281 002 169**
1.2 i [G]			**1,2 l 55 kW Z 12 XE 4 Zyl.**
Throttle valve assembly	09.00-09.03		**0 280 750 044**
Air mass meter, gasoline injection	09.00-09.03		**0 280 218 031**
			0 986 280 230
Phase sensor	09.00-09.03	NOC	**0 232 103 021**
Speed sensor, ignition/injection	09.00-09.03	FKW	**0 261 210 151**
Knock sensor	09.00-09.03		**0 261 231 120**
Temperature sensor, coolant, injection system	09.00-09.03		**0 281 002 169**
1.2 Twinport [H]			**1,2 l 59 kW Z 12 XEP 4 Zyl.**
Throttle valve assembly	03.07→		**0 280 750 133**
Air mass meter, gasoline injection	03.07→		**0 280 218 119**
Phase sensor	03.07→	NOC	**0 232 103 052**
Speed sensor, ignition/injection	03.07→	FKW	**0 261 210 151**
Knock sensor	03.07→		**0 261 231 173**
Temperature sensor, coolant, injection system	03.07→		**0 281 002 170**
1.3 CDTI [H]			**1,3 l 66 kW Z 13 DTH 4 Zyl.**
Air mass meter, diesel	08.05→		**0 281 002 683**
High-pressure sensor (CR system)	08.05→		**0 281 002 534**
Boost pressure sensor, Diesel	08.05→		**0 281 002 437**
1.4 [H]			**1,4 l 55 kW Z 14 XEL 4 Zyl.**
Throttle valve assembly	09.04-09.05		**0 280 750 133**
Air mass meter, gasoline injection	09.04-09.05		**0 280 218 119**
Phase sensor			
Fg.no. →52999999,→55999999, →58999999	09.04-09.05	NOC	**0 232 103 052**
Fg.no. 62000001→,65000001→, 68000001→	09.04-09.05	NOC	**0 232 103 067**
Speed sensor, ignition/injection	09.04-09.05	FKW	**0 261 210 151**
Knock sensor	09.04-09.05		**0 261 231 173**
Temperature sensor, coolant, injection system	09.04-09.05		**0 281 002 170**
1.4 i [F]			**1,4 l 44/60/66 kW C/X 14 NZ; X 14 XE; 14 SE / C 14 SE 4 Zyl.**
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
1.4 i [G]			**1,4 l 66 kW X 14 XE 4 Zyl.**
Temperature sensor, coolant, injection system	09.97-09.00		**0 281 002 169**

Product			
1.4 Twinport [G]			**1,4 l 66 kW Z 14 XEP 4 Zyl.**
Throttle valve assembly	09.03-03.04		**0 280 750 133**
Phase sensor	09.03-03.04	NOC	**0 232 103 021**
Speed sensor, ignition/injection	09.03-03.04	FKW	**0 261 210 151**
Knock sensor	09.03-03.04		**0 261 231 173**
Temperature sensor, coolant, injection system	09.03-03.04		**0 281 002 170**
1.4 Twinport [H]			**1,4 l 66 kW Z 14 XEP 4 Zyl.**
Throttle valve assembly	08.04→		**0 280 750 133**
Air mass meter, gasoline injection	08.04→		**0 280 218 119**
Phase sensor			
Fg.no. →42999999,→45999999, →48999999	08.04→	NOC	**0 232 103 021**
Fg.no. 52000001→52999999, 55000001→55999999, 58000001→58999999	08.04→	NOC	**0 232 103 052**
Fg.no. 62000001→,65000001→, 68000001→	08.04→	NOC	**0 232 103 067**
Speed sensor, ignition/injection	08.04→	FKW	**0 261 210 151**
Knock sensor	08.04→		**0 261 231 173**
Temperature sensor, coolant, injection system	08.04→		**0 281 002 170**
1.6 i [F]			**1,6 l 52/55 kW C/E 16 NZ; X 16 SZ,SZR; 16 LZ2,NZ2,NZR 4 Zyl.**
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
1.6 i [F]			**1,6 l 74 kW C 16 SE; X 16 XEL 4 Zyl.**
Temperature sensor, coolant, injection system	03.92-02.98		**0 280 130 107**
1.6 i [G]			**1,6 l 55/74 kW C 16 SEL; X 16 SZR; X 16 XEL 4 Zyl.**
Temperature sensor, coolant, injection system	09.97-06.04		**0 281 002 169**
1.6 i [G]			**1,6 l 74 kW Z 16 XE 4 Zyl.**
Yaw rate sensor, brake system	09.00-06.04		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.00-06.04		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-06.04		**0 265 005 303**
1.6 i CNG [G]			**1,6 l 69-73 kW Z 16 YNG 4 Zyl.**
Yaw rate sensor, brake system	09.02-06.04		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.02-06.04		**0 265 005 435**
1.6 i Twinport [G]			**1,6 l 76 kW Z 16 XEP 4 Zyl.**
Yaw rate sensor, brake system	03.03-06.04		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	03.03-06.04		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	03.03-06.04		**0 265 005 303**
1.6 Turbo [H]			**1,6 l 132 kW Z 16 LET 4 Zyl.**
Air mass meter, gasoline injection	09.07→		**0 280 218 142**
Phase sensor	09.07→	NOC	**0 232 103 052**
Knock sensor	09.07→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	09.07→		**0 261 230 009**
1.7 CDTI [G]			**1,7 l 59 kW Z 17 DTL 4 Zyl.**
Air mass meter, diesel	03.03-06.04		**0 281 002 549**
1.7 CDTI [H]			**1,7 l 59/74 kW Z 17 DTH; Z 17 DTL 4 Zyl.**
Air mass meter, diesel	08.04-03.07		**0 281 002 683**
1.7 DT [G]			**1,7 l 50 kW X 17 DTL 4 Zyl.**
Air mass meter, diesel	03.98-08.00		**0 281 002 180**
Speed sensor, diesel	03.98-08.00		**0 281 002 285**
Temperature sensor, coolant, diesel	03.98-08.00		**0 281 002 259**
Accelerator pedal module	03.98-08.00	AG,LLE	**0 281 002 236**
		AG,RLE	**0 281 002 237**
1.7 DTI [G]			**1,7 l 55 kW Y 17 DT 4 Zyl.**
Air mass meter, diesel	09.00-06.04		**0 281 002 180**
1.8 i [F]			**1,8 l 66 kW C 18 NZ 4 Zyl.**
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
1.8 i [F]			**1,8 l 82 kW 18 SE 4 Zyl.**
Throttle valve sensor	09.95-09.96		**0 280 120 316**
Air mass meter, gasoline injection	09.95-09.96		**0 280 217 003**
Temperature sensor, intake air, injection system	09.95-09.96		**0 280 130 073**

Product			
1.8 i [F]			**1,8 l 85 kW C 18 SEL; C 18 XEL; X 18 XE 4 Zyl.**
Throttle valve sensor	09.95-08.98		**0 280 122 001**
1.8 i [F]			**1,8 l 92 kW C 18 XE 4 Zyl.**
Throttle valve sensor	09.93-02.98		**0 280 122 001**
1.8 i [G]			**1,8 l 85 kW X 18 XE1 4 Zyl.**
Yaw rate sensor, brake system	09.97-08.00		**0 265 005 261**
Steering angle sensor, ESP (electronic stability program)	09.97-08.00		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.97-08.00		**0 265 005 303**
1.8 i [G]			**1,8 l 85 kW Z 18 XEL 4 Zyl.**
Yaw rate sensor, brake system	03.01-06.04		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)			
Fg.no. 12000001→,1H000001→, 22000001→,25000001→,26000001→, 28000001→,2H000001→,1B000001→	03.01-06.04		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	03.01-06.04		**0 265 005 303**
1.8 i [G]			**1,8 l 92 kW Z 18 XE 4 Zyl.**
Yaw rate sensor, brake system	09.00-06.04		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.00-06.04		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-06.04		**0 265 005 303**
1.9 CDTI [H]			**1,9 l 74 kW Z 19 ... 4 Zyl.**
Air mass meter, diesel	09.05→		**0 281 002 683**
Speed sensor, diesel	09.05→		**0 281 002 603**
Phase sensor	09.05→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	09.05→		**0 281 002 534**
1.9 CDTI [H]			**1,9 l 88 kW Z 19 ... 4 Zyl.**
High-pressure sensor (CR system)	09.04→		**0 281 002 534**
Boost pressure sensor, Diesel	09.04→		**0 281 002 437**
1.9 CDTI [H]			**1,9 l 110 kW Z 19 DTH 4 Zyl.**
Air mass meter, diesel	09.04→		**0 281 002 683**
Boost pressure sensor, Diesel	09.04→		**0 281 002 437**
2.0 DT [G]			**2,0 l 60 kW X 20 DTL 4 Zyl.**
Air mass meter, diesel	03.98-08.00		**0 281 002 180**
Speed sensor, diesel	03.98-08.00		**0 281 002 138**
Temperature sensor, coolant, diesel	03.98-08.00		**0 281 002 169**
Accelerator pedal module	03.98-08.00	AG,LLE	**0 281 002 236**
		AG,RLE	**0 281 002 237**
2.0 DTI [G]			**2,0 l 74 kW Y 20 DTH 4 Zyl.**
Air mass meter, diesel			
Fg.no. →Y2999999,→Y5999999, →Y6999999,→Y8999999,→YH999999	09.00-06.04		**0 281 002 180**
Fg.no. 12000001→22999999, 15000001→25999999, 16000001→26999999, 18000001→28999999, 1H000001→2B999999, →2H999999	09.00-06.04		**0 281 002 428**
Fg.no. 32000001→,35000001→, 36000001→,38000001→,3B000001→, 3H000001→	09.00-06.04		**0 281 002 478**
Speed sensor, diesel	09.00-06.04		**0 281 002 138**
Pressure sensor, intake manifold, diesel			
Fg.no. →Y2999999,→Y5999999, →Y6999999,→Y8999999, →YB999999,→YH999999	09.00-06.04		**0 281 002 137**
Fg.no. 12000001→22999999, 15000001→25999999, 16000001→26999999, 18000001→28999999, 1B000001→2B999999, 1H000001→2H999999	09.00-06.04		**0 281 002 438**

O

Product			
◀ Astra Caravan			
Temperature sensor, coolant, diesel	09.00-06.04		**0 281 002 169**
Accelerator pedal module	09.00-06.04	AG,LLE	**0 281 002 236**
		AG,RLE	**0 281 002 237**
2.0 DTL [G]		**2,0 l 60 kW Y 20 DTL 4 Zyl.**	
Air mass meter, diesel			
Fg.no. →Y2999999,→Y5999999, →Y6999999,→Y8999999,→YH999999	09.00-06.04		**0 281 002 180**
Fg.no. 12000001→,15000001→, 16000001→,18000001→,1H000001→	09.00-06.04		**0 281 002 428**
Speed sensor, diesel	09.00-06.04		**0 281 002 138**
Temperature sensor, coolant, diesel	09.00-06.04		**0 281 002 169**
Accelerator pedal module	09.00-06.04	AG,LLE	**0 281 002 236**
		AG,RLE	**0 281 002 237**
2.0 i [F]		**2,0 l 85 kW C 20 NE / 20 NE 4 Zyl.**	
Throttle valve sensor	09.91-02.98		**0 280 122 001**
Air mass meter, gasoline injection	09.91-02.98		**0 280 217 003**
Speed sensor, ignition/injection			
Fg.no. S2000001→,S3000001→, S4000001→,S5000001→, S6000001→,S8000001→	09.91-02.98		**0 261 210 030**
Temperature sensor, intake air, injection system	09.91-02.98		**0 280 130 073**
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
2.0 i [F]		**2,0 l 100 kW X 20 XEV 4 Zyl.**	
Throttle valve sensor	01.95-02.98		**0 280 122 001**
2.0 i [F]		**2,0 l 110 kW C 20 XE / XE-LN 4 Zyl.**	
Throttle valve sensor	09.91-08.92		**0 280 120 436**
	09.92-02.98		**0 280 122 004**
Air mass meter, gasoline injection			
Fg.no. P2500001→,P3000001→, P4000001→,P5000001→, P6000001→,P8000001→	09.91-02.98		**0 280 217 106**
Fg.no. →NA299999,→NE299999, →N2999999,→N4999999, →N5999999,→N6999999	09.91-02.98		**0 280 212 015**
			0 986 280 113
Speed sensor, ignition/injection	09.91-02.98		**0 261 210 030**
Knock sensor	09.91-06.95		**0 261 231 006**
Temperature sensor, intake air, injection system	09.91-02.98		**0 280 130 073**
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
2.0 i [G]		**2,0 l 100/118 kW X 20 XER; X 20 XEV 4 Zyl.**	
Throttle valve sensor	09.97-06.04		**0 280 122 014**
2.0 Turbo [G]		**2,0 l 141-147 kW Z 20 LET 4 Zyl.**	
Air mass meter, gasoline injection	09.01-06.04		**0 280 218 051**
			0 986 280 231
Phase sensor	09.01-06.04		**0 232 103 015**
Speed sensor, ignition/injection	09.01-06.04	FKW	**0 261 210 150**
Knock sensor	09.01-06.04		**0 261 231 116**
Pressure sensor, intake manifold, gasoline	09.01-06.04		**0 261 230 009**
Temperature sensor, coolant, injection system	09.01-06.04		**0 281 002 169**
Yaw rate sensor, brake system	09.01-06.04		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.01-06.04		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.01-06.04		**0 265 005 303**
2.0 Turbo [H]		**2,0 l 125/147 kW Z 20 LEL; Z 20 LER 4 Zyl.**	
Air mass meter, gasoline injection	08.04→		**0 280 218 142**
Phase sensor	08.04→	NOC	**0 232 103 015**
Speed sensor, ignition/injection	08.04→	FKW	**0 261 210 150**
Knock sensor	08.04→		**0 261 231 181**
Pressure sensor, intake manifold, gasoline	08.04→		**0 281 002 137**
Temperature sensor, coolant, injection system	08.04→		**0 281 002 169**
2.0 Turbo [H]		**2,0 l 177 kW Z 20 LEH 4 Zyl.**	
Air mass meter, gasoline injection			
Fg.no. →52999999,→55999999, →58999999	09.05→		**0 280 218 164**

Product			
Air mass meter, gasoline injection			
Fg.no. 62000001→,65000001→, 68000001→	09.05→		**0 280 218 211**
Phase sensor	09.05→	NOC	**0 232 103 015**
Speed sensor, ignition/injection	09.05→	FKW	**0 261 210 150**
Knock sensor	09.05→		**0 261 231 181**
Pressure sensor, intake manifold, gasoline	09.05→		**0 281 002 137**
Temperature sensor, coolant, injection system	09.05→		**0 281 002 169**
2.2 DTI [G]		**2,2 l 92 kW Y 22 DTR 4 Zyl.**	
Air flow sensor, diesel	09.01-06.04		**0 281 002 478**
Speed sensor, diesel	09.01-06.04	FKW	**0 281 002 138**
Boost pressure sensor, Diesel	09.01-06.04		**0 281 002 437**
Temperature sensor, coolant, diesel	09.01-06.04		**0 281 002 170**
Yaw rate sensor, brake system			
Fg.no. 22000001→,2B000001→, 2H000001→,25000001→,26000001→, 28000001→	09.01-06.04		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)			
Fg.no. 12000001→,1H000001→, 22000001→,25000001→,26000001→, 28000001→,2H000001→,1B000001→	09.01-06.04		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.01-06.04		**0 265 005 303**
2.2 i [G]		**2,2 l 108 kW Z 22 SE 4 Zyl.**	
Yaw rate sensor, brake system	09.00-06.04		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)			
Fg.no. 12000001→,1H000001→, 22000001→,25000001→,26000001→, 28000001→,2H000001→,1B000001→	09.00-06.04		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-06.04		**0 265 005 303**
Astra Classic			
1.4 i [F-Classic]		**1,4 l 44 kW X 14 NZ 4 Zyl.**	
Temperature sensor, intake air, injection system	09.97-08.00		**0 280 130 107**
1.6 i [F-Classic]		**1,6 l 55 kW X 16 SZR 4 Zyl.**	
Temperature sensor, intake air, injection system	09.97-08.00		**0 280 130 107**
1.6 i [F-Classic]		**1,6 l 74 kW X 16 XEL 4 Zyl.**	
Temperature sensor, coolant, injection system	09.97-08.00		**0 280 130 093**
Astra Classic Caravan			
1.4 i [F-Classic]		**1,4 l 44 kW X 14 NZ 4 Zyl.**	
Temperature sensor, intake air, injection system	09.97-08.00		**0 280 130 107**
1.6 i [F-Classic]		**1,6 l 55 kW X 16 SZR 4 Zyl.**	
Temperature sensor, intake air, injection system	09.97-08.00		**0 280 130 107**
1.6 i [F-Classic]		**1,6 l 74 kW X 16 XEL 4 Zyl.**	
Temperature sensor, coolant, injection system	09.97-08.00		**0 280 130 093**
Astra Coupé			
1.6 Twinport [G]		**1,6 l 76 kW Z 16 XEP 4 Zyl.**	
Pressure sensor, ESP, (electronic stability program)	03.03-02.05		**0 265 005 303**
1.7 CDTI [G]		**1,7 l 59 kW Z 17 DTL 4 Zyl.**	
Air mass meter, diesel	03.03-02.05		**0 281 002 549**
1.8 i [G]		**1,8 l 85 kW Z 18 XEL 4 Zyl.**	
Yaw rate sensor, brake system	03.01-02.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	03.01-02.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	03.01-02.05		**0 265 005 303**

Product			
1.8 i [G]			**1,8 l 92 kW Z 18 XE 4 Zyl.**
Yaw rate sensor, brake system	09.00-02.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.00-02.05		**0 265 005 433**
Pressure sensor, ESP, (electronic stability program)	09.00-02.05		**0 265 005 303**
2.0 Turbo [G]			**2,0 l 141-147 kW Z 20 LET 4 Zyl.**
Throttle valve sensor	09.00-02.05		**0 280 122 014**
Air mass meter, gasoline injection	09.00-02.05		**0 280 218 051**
			0 986 280 231
Phase sensor	09.00-02.05		**0 232 103 015**
Speed sensor, ignition/injection	09.00-02.05	FKW	**0 261 210 150**
Knock sensor	09.00-02.05		**0 261 231 116**
Temperature sensor, coolant, injection system	09.00-02.05		**0 281 002 169**
Yaw rate sensor, brake system	09.00-02.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)			
Fg.no. 12000001→,1H000001→, 22000001→,25000001→,26000001→, 28000001→,2H000001→,1B000001→	09.00-02.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-02.05		**0 265 005 303**
2.2 DTI [G]			**2,2 l 92 kW Y 22 DTR 4 Zyl.**
Air flow sensor, diesel	03.02-02.05		**0 281 002 478**
Speed sensor, diesel	03.02-02.05	FKW	**0 281 002 138**
Boost pressure sensor, Diesel	03.02-02.05		**0 281 002 437**
Temperature sensor, coolant, diesel	03.02-02.05		**0 281 002 170**
Yaw rate sensor, brake system	03.02-02.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)			
Fg.no. 12000001→,1H000001→, 22000001→,25000001→,26000001→, 28000001→,2H000001→,1B000001→	03.02-02.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	03.02-02.05		**0 265 005 303**
2.2 i [G]			**2,2 l 108 kW Z 22 SE 4 Zyl.**
Yaw rate sensor, brake system	09.00-02.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.00-02.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-02.05		**0 265 005 303**

Astra GTC

1.3 CDTI [H]			**1,3 l 66 kW Z 13 DTH 4 Zyl.**
Air mass meter, diesel	06.05→		**0 281 002 683**
High-pressure sensor (CR system)	06.05→		**0 281 002 534**
Boost pressure sensor, Diesel	06.05→		**0 281 002 437**
1.4 Twinport [H]			**1,4 l 55 kW Z 14 XEL 4 Zyl.**
Throttle valve assembly	09.05→		**0 280 750 133**
Air mass meter, gasoline injection	09.05→		**0 280 218 119**
Phase sensor			
Fg.no. →52999999,→55999999, →58999999	09.05→	NOC	**0 232 103 052**
Fg.no. 62000001→,65000001→, 68000001→	09.05→	NOC	**0 232 103 067**
Speed sensor, ignition/injection	09.05→	FKW	**0 261 210 151**
Knock sensor	09.05→		**0 261 231 173**
Temperature sensor, coolant, injection system	09.05→		**0 281 002 170**
1.4 Twinport [H]			**1,4 l 66 kW Z 14 XEP 4 Zyl.**
Throttle valve assembly	03.05→		**0 280 750 133**
Air mass meter, gasoline injection	03.05→		**0 280 218 119**
Phase sensor			
Fg.no. →42999999,→45999999, →48999999	03.05→	NOC	**0 232 103 021**
Fg.no. 52000001→52999999, 55000001→55999999, 58000001→58999999	03.05→	NOC	**0 232 103 052**
Phase sensor			
Fg.no. 62000001→,65000001→, 68000001→	03.05→	NOC	**0 232 103 067**
Speed sensor, ignition/injection	03.05→	FKW	**0 261 210 151**
Knock sensor	03.05→		**0 261 231 173**
Temperature sensor, coolant, injection system	03.05→		**0 281 002 170**
1.7 CDTI [H]			**1,7 l 59/74 kW Z 17 DTH; Z 17 DTL 4 Zyl.**
Air mass meter, diesel	03.05-03.07		**0 281 002 683**
1.9 CDTI [H]			**1,9 l 88/110 kW Z 19 DTH; Z 19 DTJ 4 Zyl.**
Air mass meter, diesel	03.05→		**0 281 002 683**
High-pressure sensor (CR system)	03.05→		**0 281 002 706**
Boost pressure sensor, Diesel	03.05→		**0 281 002 437**
2.0 Turbo [H]			**2,0 l 125/147 kW Z 20 LEL; Z 20 LER 4 Zyl.**
Air mass meter, gasoline injection	03.05→		**0 280 218 142**
Phase sensor	03.05→	NOC	**0 232 103 015**
Speed sensor, ignition/injection	03.05→	FKW	**0 261 210 150**
Knock sensor	03.05→		**0 261 231 181**
Pressure sensor, intake manifold, gasoline	03.05→		**0 281 002 137**
Temperature sensor, coolant, injection system	03.05→		**0 281 002 169**
2.0 Turbo [H]			**2,0 l 177 kW Z 20 LEH 4 Zyl.**
Air mass meter, gasoline injection			
Fg.no. →52999999,→55999999, →58999999	08.05→		**0 280 218 164**
Fg.no. 62000001→,65000001→, 68000001→	08.05→		**0 280 218 211**
Phase sensor	08.05→	NOC	**0 232 103 015**
Speed sensor, ignition/injection	08.05→	FKW	**0 261 210 150**
Knock sensor	08.05→		**0 261 231 181**
Pressure sensor, intake manifold, gasoline	08.05→		**0 281 002 137**
Temperature sensor, coolant, injection system	08.05→		**0 281 002 169**

Calibra

2.0 i			**2,0 l 85 kW C 20 NE 4 Zyl.**
Throttle valve sensor	06.90-03.97		**0 280 122 001**
Speed sensor, ignition/injection	06.90-03.97		**0 261 210 030**
Temperature sensor, coolant, injection system	06.90-03.97		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. L1000001→M1999999	06.90-03.97		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. L1000001→M1999999	06.90-03.97	AA,LAB	**0 265 001 226**
		LAB,NAA	**0 265 001 233**
		NAA,RAB	**0 265 001 232**
Fg.no. N1000001→	06.90-03.97	AA,LAB	**0 265 006 487**
		AA,RAB	**0 265 006 486**
		LAB,NAA	**0 265 003 094**
		NAA,RAB	**0 265 003 093**
2.0 i			**2,0 l 100 kW X 20 XEV 4 Zyl.**
Throttle valve sensor	09.93-08.96		**0 280 122 001**
Wheel speed sensor, front			
Fg.no. L1000001→M1999999	09.93-08.96		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. L1000001→M1999999	09.93-08.96	LAB,NAA	**0 265 001 233**
Fg.no. N1000001→	09.93-08.96	AA,LAB	**0 265 006 487**
		AA,RAB	**0 265 006 486**
		LAB,NAA	**0 265 003 094**
		NAA,RAB	**0 265 003 093**
2.0 i			**2,0 l 110 kW C 20 XE,XE-LN 4 Zyl.**
Throttle valve sensor	06.90-03.97		**0 280 120 326**
Air mass meter, gasoline injection			
Mot.no. →14002934	06.90-03.97		**0 280 212 015**
			0 986 280 113
Mot.no. 14002935→	06.90-03.97		**0 280 217 106**

Product

◀ Calibra

Speed sensor, ignition/injection	06.90-03.97		**0 261 210 030**
Knock sensor	06.90-03.97		**0 261 231 006**
Temperature sensor, intake air, injection system			
Fg.no. P1000001→,P9000001→	06.90-03.97		**0 280 130 073**
Temperature sensor, coolant, injection system	06.90-03.97		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. L1000001→M1999999	06.90-03.97		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. L1000001→M1999999	06.90-03.97	AA,LAB	**0 265 001 226**
		LAB,NAA	**0 265 001 233**
		NAA,RAB	**0 265 001 232**
Fg.no. N1000001→	06.90-03.97	AA,LAB	**0 265 006 487**
		AA,RAB	**0 265 006 486**
		LAB,NAA	**0 265 003 094**
		NAA,RAB	**0 265 003 093**
2.0 i Turbo		**2,0 l 150 kW C 20 LET 4 Zyl.**	
Throttle valve sensor	03.92-03.97		**0 280 122 004**
Air mass meter, gasoline injection	03.92-03.97		**0 280 213 024**
			0 986 280 140
Speed sensor, ignition/injection	03.92-03.97		**0 261 210 030**
Knock sensor	03.92-03.97		**0 261 231 006**
Temperature sensor, intake air, injection system	03.92-03.97		**0 280 130 039**
Temperature sensor, coolant, injection system	03.92-03.97		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. L1000001→M1999999	03.92-03.97		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. L1000001→M1999999	03.92-03.97	AA,LAB	**0 265 001 226**
		LAB,NAA	**0 265 001 233**
		NAA,RAB	**0 265 001 232**
Fg.no. N1000001→	03.92-03.97	AA,LAB	**0 265 006 487**
		AA,RAB	**0 265 006 486**
		LAB,NAA	**0 265 003 094**
		NAA,RAB	**0 265 003 093**
2.5 i V6		**2,5 l 125 kW C 25 XE; X 25 XE 6 Zyl.**	
Air mass meter, gasoline injection	04.93-03.97		**0 280 217 503**
Phase sensor			
Fg.no. →S1035178,→R9003232	04.93-03.97		**0 232 103 001**
Temperature sensor, coolant, injection system	04.93-03.97		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. L1000001→M1999999	04.93-03.97		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. L1000001→M1999999	04.93-03.97	LAB,NAA	**0 265 001 233**
Fg.no. N1000001→	04.93-03.97	AA,LAB	**0 265 006 487**
		AA,RAB	**0 265 006 486**
		LAB,NAA	**0 265 003 094**
		NAA,RAB	**0 265 003 093**

Combo

1.2 i		**1,2 l 33 kW C 12 NZ; X 12 SZ; 12 NZ 4 Zyl.**	
Temperature sensor, coolant, injection system			
Fg.no. W3000001→	09.94-10.01		**0 280 130 093**
Fg.no. →V6999999	09.94-10.01		**0 280 130 107**
1.3 CDTI [Tour]		**1,3 l 51/55 kW ... 13 DT; Z 13 DTJ 4 Zyl.**	
Air mass meter, diesel	09.04→		**0 281 002 549**
High-pressure sensor (CR system)	09.04→		**0 281 002 534**
Pressure sensor, intake manifold, diesel			
Fg.no. →53999999,→54999999, →56999999	09.04→		**0 281 002 510**
Fg.no. 63000001→,64000001→, 66000001→	09.04→		**0 281 002 844**

Product

1.4 i		**1,4 l 44 kW C 14 NZ; X 14 SZ 4 Zyl.**	
Temperature sensor, intake air, injection system			
Fg.no. W3000001→	09.94-10.01		**0 280 130 093**
Fg.no. →V6999999	09.94-10.01		**0 280 130 107**
Temperature sensor, coolant, injection system			
Fg.no. W3000001→	09.94-10.01		**0 280 130 093**
Fg.no. →V6999999	09.94-10.01		**0 280 130 107**
1.4 i		**1,4 l 60/66 kW C 14 SE; C 14 SEL 4 Zyl.**	
Temperature sensor, coolant, injection system			
Fg.no. W3000001→	09.94-10.01		**0 280 130 093**
Fg.no. →V6999999	09.94-10.01		**0 280 130 107**
1.4 i Twinport [Tour]		**1,4 l 66 kW Z 14 XEP 4 Zyl.**	
Throttle valve assembly	09.04→		**0 280 750 133**
Air mass meter, gasoline injection	09.04→		**0 280 218 119**
Phase sensor			
Fg.no. →44999999,→46999999	09.04→	NOC	**0 232 103 021**
Fg.no. 54000001→,56000001→	09.04→	NOC	**0 232 103 052**
Speed sensor, ignition/injection	09.04→	FKW	**0 261 210 151**
Knock sensor	09.04→		**0 261 231 173**
Temperature sensor, coolant, injection system	09.04→		**0 281 002 170**
1.6 CNG [Tour]		**1,6 l 69-71 kW Y 16 YNG 4 Zyl.**	
Pressure sensor, ESP, (electronic stability program)	04.05→		**0 265 005 303**
1.6 i [Tour]		**1,6 l 69 kW Z 16 YNG 4 Zyl.**	
Pressure sensor, ESP, (electronic stability program)	06.06→		**0 265 005 303**
1.7 CDTI [Tour]		**1,7 l 74 kW Z 17 DTH 4 Zyl.**	
Air mass meter, diesel	09.04→		**0 281 002 549**
1.7 DI [Tour]		**1,7 l 48 kW Y 17 DTL 4 Zyl.**	
Air mass meter, diesel	10.01-08.04		**0 281 002 180**
1.7 DTI [Tour]		**1,7 l 55 kW Y 17 DT 4 Zyl.**	
Air mass meter, diesel	10.01-08.04		**0 281 002 180**

Corsa

1.0 i [B]		**1,0 l 40 kW X 10 XE 3 Zyl.**	
Throttle valve sensor	09.96-09.00		**0 280 122 014**
Air mass meter, gasoline injection	09.96-09.00		**0 280 217 123**
Phase sensor	09.96-09.00	NOC	**0 232 103 021**
Speed sensor, ignition/injection	09.96-09.00	FKW	**0 261 210 151**
Knock sensor	09.96-09.00		**0 261 231 120**
Temperature sensor, coolant, injection system	09.96-09.00	KZB	**0 281 002 169**
1.0 i 12V [C]		**1,0 l 43 kW Z 10 XE 3 Zyl.**	
Air mass meter, gasoline injection	09.00-08.03		**0 280 218 031**
			0 986 280 230
Phase sensor	09.00-08.03	NOC	**0 232 103 021**
Speed sensor, ignition/injection	09.00-08.03	FKW	**0 261 210 151**
Knock sensor	09.00-08.03		**0 261 231 120**
Temperature sensor, coolant, injection system			
Mot.no. →19T75858	09.00-08.03		**0 281 002 169**
Mot.no. 19T75859→	09.00-08.03		**0 281 002 170**
1.0 Twinport [C]		**1,0 l 44 kW Z 10 XEP 3 Zyl.**	
Throttle valve assembly	09.03-09.06		**0 280 750 133**
Air mass meter, gasoline injection	09.03-09.06		**0 280 218 119**
Phase sensor	09.03-09.06	NOC,TW	**0 232 103 021**
Fg.no. →54999999,→56999999	09.03-09.06	NOC	**0 232 103 052**
Fg.no. 64000001→,66000001→	09.03-09.06	NOC	**0 232 103 067**
Speed sensor, ignition/injection	09.03-09.06	FKW	**0 261 210 151**
Knock sensor	09.03-09.06		**0 261 231 173**
Temperature sensor, coolant, injection system	09.03-09.06		**0 281 002 170**
Yaw rate sensor, brake system	09.03-09.06		**0 265 005 270**
Pressure sensor, ESP, (electronic stability program)	09.03-09.06		**0 265 005 303**
1.0 Twinport [D]		**1,0 l 44 kW Z 10 XEP 3 Zyl.**	
Throttle valve assembly	07.06→		**0 280 750 133**
Phase sensor	07.06→	NOC	**0 232 103 067**

Product			
Knock sensor	07.06→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	07.06→		**0 261 230 101**
Temperature sensor, coolant, injection system	07.06→		**0 281 002 170**
Yaw rate sensor, brake system	07.06→	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Wheel speed sensor, front	07.06→		**0 265 007 671**
Wheel speed sensor, rear	07.06→	STB	**0 265 007 768**
		4SB	**0 265 007 769**
1.2 i [A]	**1,2 l 33 kW C 12 NZ 4 Zyl.**		
Temperature sensor, coolant, injection system	09.90-08.94		**0 280 130 107**
1.2 i [B]	**1,2 l 33 kW C 12 NZ; X 12 SZ; 12 NZ 4 Zyl.**		
Temperature sensor, coolant, injection system			
Fg.no. W3000001→	03.93-08.00		**0 280 130 093**
Fg.no. →V6999999	03.93-08.00		**0 280 130 107**
1.2 i [B]	**1,2 l 48 kW X 12 XE 4 Zyl.**		
Throttle valve sensor	09.97-08.00		**0 280 122 014**
Air mass meter, gasoline injection	09.97-08.00		**0 280 217 123**
Phase sensor	09.97-08.00	NOC	**0 232 103 021**
Speed sensor, ignition/injection	09.97-08.00	FKW	**0 261 210 151**
Knock sensor	09.97-08.00		**0 261 231 120**
Temperature sensor, coolant, injection system	09.97-08.00	KZB	**0 281 002 169**
1.2 i Twinport [C]	**1,2 l 59 kW Z 12 XEP 4 Zyl.**		
Throttle valve assembly	07.04-09.06		**0 280 750 133**
Air mass meter, gasoline injection	07.04-09.06		**0 280 218 119**
Phase sensor	07.04-09.06	NOC	**0 232 103 021**
Fg.no. →54999999,→56999999	07.04-09.06	NOC	**0 232 103 052**
Fg.no. 64000001→,66000001→	07.04-09.06	NOC	**0 232 103 067**
Speed sensor, ignition/injection	07.04-09.06	FKW	**0 261 210 151**
Knock sensor	07.04-09.06		**0 261 231 173**
Temperature sensor, coolant, injection system	07.04-09.06		**0 281 002 170**
Yaw rate sensor, brake system	07.04-09.06		**0 265 005 270**
Pressure sensor, ESP, (electronic stability program)	07.04-09.06		**0 265 005 303**
1.2 i Twinport [D]	**1,2 l 59 kW Z 12 XEP 4 Zyl.**		
Throttle valve assembly	07.06→		**0 280 750 133**
Phase sensor	07.06→	NOC	**0 232 103 067**
Knock sensor	07.06→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	07.06→		**0 261 230 101**
Temperature sensor, coolant, injection system	07.06→		**0 281 002 170**
Yaw rate sensor, brake system	07.06→	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Wheel speed sensor, front	07.06→		**0 265 007 671**
Wheel speed sensor, rear	07.06→	STB	**0 265 007 768**
		4SB	**0 265 007 769**
1.2 i 16V [C]	**1,2 l 55 kW Z 12 XE 4 Zyl.**		
Air mass meter, gasoline injection	09.00-06.04		**0 280 218 031**
			0 986 280 230
Phase sensor	09.00-06.04	NOC	**0 232 103 021**
Speed sensor, ignition/injection	09.00-06.04	FKW	**0 261 210 151**
Knock sensor	09.00-06.04		**0 261 231 120**
Temperature sensor, coolant, injection system			
Mot.no. →19T75858	09.00-06.04		**0 281 002 169**
Mot.no. 19T75859→	09.00-06.04		**0 281 002 170**
Yaw rate sensor, brake system	09.00-06.04		**0 265 005 270**
1.3 CDTI [C]	**1,3 l 51 kW ... 13 DT 4 Zyl.**		
Air mass meter, diesel	09.03-09.06		**0 281 002 549**
High-pressure sensor (CR system)	09.03-09.06		**0 281 002 534**
Pressure sensor, intake manifold, diesel	09.03-09.06		**0 281 002 510**
Yaw rate sensor, brake system	09.03-09.06		**0 265 005 270**
Pressure sensor, ESP, (electronic stability program)	09.03-09.06		**0 265 005 303**
1.3 CDTI [C]	**1,3 l 55 kW Z 13 DTJ 4 Zyl.**		
Air mass meter, diesel	09.05-09.06		**0 281 002 683**
High-pressure sensor (CR system)	09.05-09.06		**0 281 002 706**

Product			
Pressure sensor, intake manifold, diesel	09.05-09.06		**0 281 002 510**
Pressure sensor, ESP, (electronic stability program)	09.05-09.06		**0 265 005 303**
1.3 CDTI [D]	**1,3 l 55/66 kW A 13 DTH; A 13 DTJ; Z 13 DTJ 4 Zyl.**		
High-pressure sensor (CR system)	07.06→		**0 281 002 706**
Pressure sensor, intake manifold, diesel	07.06→		**0 281 002 844**
Yaw rate sensor, brake system	07.06→	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Wheel speed sensor, front	07.06→		**0 265 007 671**
Wheel speed sensor, rear	07.06→	STB	**0 265 007 768**
		4SB	**0 265 007 769**
1.3 CDTI [D]	**1,3 l 66 kW Z 13 DTH 4 Zyl.**		
High-pressure sensor (CR system)	07.06→		**0 281 002 706**
Boost pressure sensor, Diesel	07.06→		**0 281 002 437**
Pressure sensor, intake manifold, diesel	07.06→		**0 281 002 844**
Yaw rate sensor, brake system	07.06→	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Wheel speed sensor, front	07.06→		**0 265 007 671**
Wheel speed sensor, rear	07.06→	STB	**0 265 007 768**
		4SB	**0 265 007 769**
1.4 i [A]	**1,4 l 40-44/60 kW C 14 NZ; C 14 SE 4 Zyl.**		
Temperature sensor, coolant, injection system	01.90-08.94		**0 280 130 107**
1.4 i [B]	**1,4 l 44 kW C 14 NZ; X 14 SZ 4 Zyl.**		
Temperature sensor, intake air, injection system			
Fg.no. W3000001→	03.93-09.00		**0 280 130 093**
Fg.no. →V6999999	03.93-09.00		**0 280 130 107**
Temperature sensor, coolant, injection system			
Fg.no. W3000001→	03.93-09.00		**0 280 130 093**
Fg.no. →V6999999	03.93-09.00		**0 280 130 107**
1.4 i [B]	**1,4 l 60/63/66 kW C 14 SE; C 14 SEL; X 14 XE 4 Zyl.**		
Temperature sensor, coolant, injection system			
Fg.no. W3000001→	03.93-08.00		**0 280 130 093**
Fg.no. →V6999999	03.93-08.00		**0 280 130 107**
1.4 Twinport [C]	**1,4 l 66 kW Z 14 XEP 4 Zyl.**		
Throttle valve assembly	09.03-09.06		**0 280 750 133**
Air mass meter, gasoline injection	09.03-09.06		**0 280 218 119**
Phase sensor	09.03-09.06	NOC	**0 232 103 021**
		NOC,RAB	**0 232 103 052**
Speed sensor, ignition/injection	09.03-09.06	FKW	**0 261 210 151**
Knock sensor	09.03-09.06		**0 261 231 173**
Temperature sensor, coolant, injection system	09.03-09.06		**0 281 002 170**
Yaw rate sensor, brake system	09.03-09.06		**0 265 005 270**
Pressure sensor, ESP, (electronic stability program)	09.03-09.06		**0 265 005 303**
1.4 Twinport [D]	**1,4 l 66 kW Z 14 XEP 4 Zyl.**		
Throttle valve assembly	07.06→		**0 280 750 133**
Phase sensor	07.06→	NOC	**0 232 103 067**
Knock sensor	07.06→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	07.06→		**0 261 230 101**
Temperature sensor, coolant, injection system	07.06→		**0 281 002 170**
Yaw rate sensor, brake system	07.06→	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Wheel speed sensor, front	07.06→		**0 265 007 671**
Wheel speed sensor, rear	07.06→	STB	**0 265 007 768**
		4SB	**0 265 007 769**
1.6 CNG [C]	**1,6 l 71 kW Y 16 YNG; Z 16 YNG 4 Zyl.**		
Yaw rate sensor, brake system	03.06-09.06		**0 265 005 270**
Pressure sensor, ESP, (electronic stability program)	03.06-09.06		**0 265 005 303**
1.6 GSI [B]	**1,6 l 80 kW C 16 XE 4 Zyl.**		
Temperature sensor, coolant, injection system			
Fg.no. →V6999999	03.93-08.00		**0 280 130 107**
1.6 i [A]	**1,6 l 55 kW C 16 NZ 4 Zyl.**		
Temperature sensor, coolant, injection system	04.89-08.94		**0 280 130 107**

O

Product

◀ Corsa

1.6 i [A]			**1,6 l 72 kW C16 SEI 4 Zyl.**
Throttle valve sensor	09.89-03.93		**0 280 122 001**
Air flow sensor, gasoline injection	09.89-03.93		**0 280 200 202**
			0 986 280 052
1.6 i [A]			**1,6 l 74 kW C 16 SE 4 Zyl.**
Air flow sensor, gasoline injection	05.88-03.93		**0 280 200 603**
1.6 i [A]			**1,6 l 74 kW E 16 SE 4 Zyl.**
Throttle valve sensor	05.88-03.93		**0 280 120 316**
Temperature sensor, coolant, injection system	05.88-08.94		**0 280 130 107**
1.6 i [B]			**1,6 l 74 kW C 16 SEL 4 Zyl.**
Temperature sensor, coolant, injection system			
Fg.no. W3000001→,W4000001→, W6000001→	06.98-08.00		**0 280 130 093**
1.6 i [C]			**1,6 l 62 kW Z 16 SE 4 Zyl.**
Yaw rate sensor, brake system	09.01-08.05		**0 265 005 270**
Pressure sensor, ESP, (electronic stability program)	09.01-08.05		**0 265 005 303**
1.6 i GSI [B]			**1,6 l 78 kW X 16 XE 4 Zyl.**
Temperature sensor, coolant, injection system			
Fg.no. W3000001→,W4000001→, W6000001→	03.93-08.99		**0 280 130 093**
Fg.no. →V6999999	03.93-08.99		**0 280 130 107**
1.6 i OPC Turbo [D]			**1,6 l 141 kW Z 16 LER 4 Zyl.**
Air mass meter, gasoline injection	02.07→		**0 280 218 142**
Phase sensor	02.07→	NOC	**0 232 103 052**
Knock sensor	02.07→		**0 261 231 173**
Yaw rate sensor, brake system	02.07→	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Wheel speed sensor, front	02.07→		**0 265 007 671**
Wheel speed sensor, rear	02.07→	STB	**0 265 007 768**
		4SB	**0 265 007 769**
1.7 CDTI [C]			**1,7 l 74 kW Z 17 DTH 4 Zyl.**
Air mass meter, diesel	09.03-09.06		**0 281 002 549**
Yaw rate sensor, brake system	09.03-09.06		**0 265 005 270**
Pressure sensor, ESP, (electronic stability program)	09.03-09.06		**0 265 005 303**
1.7 CDTI [D]			**1,7 l 92 kW A 17 DTR; Z 17 DTR 4 Zyl.**
Yaw rate sensor, brake system	07.06→	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Wheel speed sensor, front	07.06→		**0 265 007 671**
Wheel speed sensor, rear	07.06→	STB	**0 265 007 768**
		4SB	**0 265 007 769**
1.7 DI [C]			**1,7 l 48 kW Y 17 DTL 4 Zyl.**
Air mass meter, diesel	09.00-08.03		**0 281 002 180**
Pressure sensor, ESP, (electronic stability program)	09.00-08.03		**0 265 005 303**
1.7 DTi			**1,7 l 55 kW Y17DTL 4 Zyl.**
Air mass meter, gasoline injection	10.02-12.05		**0 281 002 184**
Air mass meter, diesel	10.02-12.05		**0 281 002 180**
1.7 DTI [C]			**1,7 l 55 kW Y 17 DT 4 Zyl.**
Air mass meter, diesel	09.00-08.03		**0 281 002 180**
Pressure sensor, ESP, (electronic stability program)	09.00-08.03		**0 265 005 303**
1.8 i 16V [C]			**1,8 l 92 kW Z 18 XE 4 Zyl.**
Yaw rate sensor, brake system	09.01-08.05		**0 265 005 270**
Pressure sensor, ESP, (electronic stability program)	09.01-08.05		**0 265 005 303**

Frontera

2.0 i [A]			**2,0 l 85 kW C 20 NE 4 Zyl.**
Throttle valve sensor	09.91-08.95		**0 280 122 001**
Air flow sensor, gasoline injection			
Fg.no. →NV522066	09.91-08.95		**0 280 202 210**
			0 986 280 063
Speed sensor, ignition/injection	09.91-08.95		**0 261 210 030**
Temperature sensor, coolant, injection system	09.91-08.95		**0 280 130 107**

Product

2.0 i [A]			**2,0 l 85 kW X 20 SE 4 Zyl.**
Throttle valve sensor	02.95-08.98		**0 280 122 001**
Air mass meter, gasoline injection	02.95-08.98		**0 280 217 003**
Speed sensor, ignition/injection	02.95-08.98		**0 261 210 030**
Knock sensor	02.95-08.98		**0 261 231 007**
2.2 DTI [B]			**2,2 l 85/88 kW X 22 DTH; Y 22 DTH 4 Zyl.**
Air mass meter, diesel	09.98-09.04		**0 281 002 184**
Speed sensor, diesel	09.98-09.04		**0 281 002 138**
Temperature sensor, coolant, diesel	09.98-09.04		**0 281 002 169**
Temperature sensor, intake air, diesel	09.98-09.04		**0 261 230 009**
2.2 i [A]			**2,2 l 100 kW X 22 XE 4 Zyl.**
Throttle valve sensor	02.95-08.98		**0 280 122 001**
Air mass meter, gasoline injection	02.95-08.98		**0 280 217 003**
Speed sensor, ignition/injection			
Fg.no. →TV899999	02.95-08.98		**0 261 210 030**
Knock sensor	02.95-08.98		**0 261 231 007**
Temperature sensor, coolant, injection system	02.95-08.98		**0 280 130 107**
2.3 TD [A]			**2,3 l 74 kW 23 DT 4 Zyl.**
Air mass meter, diesel	09.91-08.95		**0 281 002 144**
2.4 i [A]			**2,4 l 92 kW C 24 NE CIH 4 Zyl.**
Throttle valve sensor	09.91-08.95		**0 280 122 001**
Air flow sensor, gasoline injection	09.91-08.95		**0 280 202 211**
			0 986 280 091
Speed sensor, ignition/injection	09.91-08.95		**0 261 210 031**
Temperature sensor, coolant, injection system	09.91-08.95		**0 280 130 107**
2.5 TDS Turbo [A]			**2,5 l 85 kW Venturi-25TD VM41B 0 Zyl.**
Air mass meter, diesel	06.96-08.98		**0 281 002 144**
Speed sensor, diesel	06.96-08.98		**0 281 002 096**
Pedal position sensor, diesel	06.96-08.98	LLE	**0 205 001 055**
		RLE	**0 205 001 054**

Kadett

1.3 [E]			**1,3 l 44 kW 13 N, NB 4 Zyl.**
Wheel speed sensor, front	03.89-08.91		**0 265 006 488**
Wheel speed sensor, rear	03.89-08.91	LAB,LIM	**0 265 001 236**
		LIM,RAB	**0 265 001 235**
1.3 i [E]			**1,3 l 44 kW C 13 N 4 Zyl.**
Wheel speed sensor, front	03.89-08.91		**0 265 006 488**
Wheel speed sensor, rear	03.89-08.91	LAB,LIM	**0 265 001 236**
		LIM,RAB	**0 265 001 235**
1.4 [E]			**1,4 l 44/55 kW E 14 LV; 14 NV 4 Zyl.**
Wheel speed sensor, front	01.90-08.91		**0 265 006 488**
Wheel speed sensor, rear	01.90-08.91	LAB,LIM	**0 265 001 236**
		LIM,RAB	**0 265 001 235**
1.4 i [E]			**1,4 l 44 kW C 14 NZ 4 Zyl.**
Temperature sensor, coolant, injection system	01.90-08.91		**0 280 130 107**
Wheel speed sensor, front	01.90-08.91		**0 265 006 488**
Wheel speed sensor, rear	01.90-08.91	LAB,LIM	**0 265 001 236**
		LIM,RAB	**0 265 001 235**
1.5 TD [E]			**1,5 l 53 kW 15 DT 4 Zyl.**
Wheel speed sensor, front	03.89-08.91		**0 265 006 488**
Wheel speed sensor, rear	03.89-08.91	LAB,LIM	**0 265 001 236**
		LIM,RAB	**0 265 001 235**
1.6 [E]			**1,6 l 60 kW 16 SV 4 Zyl.**
Wheel speed sensor, front	03.89-08.91		**0 265 006 488**
Wheel speed sensor, rear	03.89-08.91	LAB,LIM	**0 265 001 236**
		LIM,RAB	**0 265 001 235**
1.6 i [E]			**1,6 l 55 kW C 16 LZ; C 16 NZ; E 16 NZ 4 Zyl.**
Temperature sensor, coolant, injection system			
Fg.no. J2791968→,J5273428→	09.86-08.93		**0 280 130 107**
Wheel speed sensor, front	03.89-08.93		**0 265 006 488**

Product				
Wheel speed sensor, rear		03.89-08.93	LAB,LIM	**0 265 001 236**
			LIM,RAB	**0 265 001 235**
1.6 i [E]			**1,6 l 74 kW E 16 SE 4 Zyl.**	
Throttle valve sensor		04.89-08.91		**0 280 120 316**
Air flow sensor, gasoline injection		04.89-08.91		**0 280 202 602**
				0 986 280 019
Temperature sensor, coolant, injection system		04.89-08.91		**0 280 130 026**
Wheel speed sensor, front		04.89-08.91		**0 265 006 488**
Wheel speed sensor, rear		04.89-08.91	LAB,LIM	**0 265 001 236**
			LIM,RAB	**0 265 001 235**
1.7 D/DR [E]			**1,7 l 42 kW 17 D/DR 4 Zyl.**	
Wheel speed sensor, front		03.89-08.91		**0 265 006 488**
Wheel speed sensor, rear		03.89-08.91	LAB,LIM	**0 265 001 236**
			LIM,RAB	**0 265 001 235**
1.7 TD [E]			**1,7 l 60 kW 17 DT /TC4 EE1 4 Zyl.**	
Wheel speed sensor, front		02.90-08.91		**0 265 006 488**
Wheel speed sensor, rear		02.90-08.91	LAB,LIM	**0 265 001 236**
			LIM,RAB	**0 265 001 235**
1.8 [E]			**1,8 l 62 kW S 18 NV 4 Zyl.**	
Temperature sensor, coolant, injection system		09.86-08.91		**0 280 130 107**
Wheel speed sensor, front		03.89-08.91		**0 265 006 488**
Wheel speed sensor, rear		03.89-08.91	LAB,LIM	**0 265 001 236**
			LIM,RAB	**0 265 001 235**
1.8 i [E]			**1,8 l 66 kW C 18 NZ 4 Zyl.**	
Temperature sensor, coolant, injection system		09.90-08.91		**0 280 130 107**
Wheel speed sensor, front		09.90-08.91		**0 265 006 488**
Wheel speed sensor, rear		09.90-08.91	LAB,LIM	**0 265 001 236**
			LIM,RAB	**0 265 001 235**
1.8 i [E]			**1,8 l 74 kW C 18 NE 4 Zyl.**	
Throttle valve sensor		10.85-08.86		**0 280 120 301**
Air flow sensor, gasoline injection		10.85-08.86		**0 280 202 076**
Temperature sensor, coolant, injection system		10.85-08.86		**0 280 130 107**
1.8 i [E]			**1,8 l 82-85 kW 18 E 4 Zyl.**	
Throttle valve sensor		09.86-08.91		**0 280 120 316**
Air flow sensor, gasoline injection		09.86-08.91		**0 280 202 602**
				0 986 280 019
Speed sensor, ignition/injection		09.86-08.91		**0 261 210 030**
Temperature sensor, coolant, injection system		09.86-08.91		**0 280 130 107**
Wheel speed sensor, front		03.89-08.91		**0 265 006 488**
Wheel speed sensor, rear		03.89-08.91	LAB,LIM	**0 265 001 236**
			LIM,RAB	**0 265 001 235**
1.8 i [E]			**1,8 l 85 kW 18 E 4 Zyl.**	
Throttle valve sensor		09.84-08.86		**0 280 120 301**
Air flow sensor, gasoline injection	CH,S	09.84-08.86		**0 280 202 054**
	~~CH,S~~	09.84-08.86		**0 280 202 033**
Temperature sensor, coolant, injection system		09.84-08.86		**0 280 130 107**
1.8 S [E]			**1,8 l 62 kW E 18 NV 4 Zyl.**	
Temperature sensor, coolant, injection system		09.87-08.91		**0 280 130 107**
Wheel speed sensor, front		03.89-08.91		**0 265 006 488**
Wheel speed sensor, rear		03.89-08.91	LAB,LIM	**0 265 001 236**
			LIM,RAB	**0 265 001 235**
2.0 i [E]			**2,0 l 85 kW C 20 NE; 20 NE 4 Zyl.**	
Throttle valve sensor		09.86-08.88		**0 280 120 316**
		09.88-08.91		**0 280 122 001**
Speed sensor, ignition/injection		09.86-08.91		**0 261 210 030**
Pressure sensor, intake manifold, gasoline		09.86-08.91		**0 280 101 007**
Temperature sensor, coolant, injection system		09.86-08.91		**0 280 130 107**
Wheel speed sensor, front		03.89-08.91		**0 265 006 488**
Wheel speed sensor, rear		03.89-08.91	LAB,LIM	**0 265 001 236**
			LIM,RAB	**0 265 001 235**
2.0 i [E]			**2,0 l 91 kW 20 SER 4 Zyl.**	
Throttle valve sensor		09.87-08.88		**0 280 120 316**
		09.88-08.91		**0 280 122 001**

Product				
Pressure sensor, intake manifold, gasoline		09.87-08.91		**0 280 101 007**
Temperature sensor, coolant, injection system		09.87-08.91		**0 280 130 107**
Wheel speed sensor, front		03.89-08.91		**0 265 006 488**
Wheel speed sensor, rear		03.89-08.91	LAB,LIM	**0 265 001 236**
			LIM,RAB	**0 265 001 235**
2.0 i [E]			**2,0 l 95 kW 20 SEH 4 Zyl.**	
Throttle valve sensor		09.86-08.88		**0 280 120 316**
		09.88-08.91		**0 280 122 001**
Speed sensor, ignition/injection		09.86-08.91		**0 261 210 030**
Pressure sensor, intake manifold, gasoline		09.86-08.91		**0 280 101 007**
Temperature sensor, coolant, injection system		09.86-08.91		**0 280 130 107**
Wheel speed sensor, front		03.89-08.91		**0 265 006 488**
Wheel speed sensor, rear		03.89-08.91	LAB,LIM	**0 265 001 236**
			LIM,RAB	**0 265 001 235**
2.0 i [E]			**2,0 l 110-115 kW C 20 XE / XEJ; 20 XE 4 Zyl.**	
Throttle valve sensor		03.88-08.91		**0 280 120 326**
Air mass meter, gasoline injection		03.88-08.91		**0 280 212 015**
				0 986 280 113
Speed sensor, ignition/injection		03.88-08.91		**0 261 210 030**
Knock sensor		03.88-08.91		**0 261 231 006**
Temperature sensor, coolant, injection system		03.88-08.91		**0 280 130 107**
Wheel speed sensor, front		03.89-08.91		**0 265 006 488**
Wheel speed sensor, rear		03.89-08.91	LAB,LIM	**0 265 001 236**
			LIM,RAB	**0 265 001 235**

Manta

2.0 i [B]			**2,0 l 77-81 kW 20 E CIH; 20 E CIH Kat. 4 Zyl.**	
Throttle valve sensor		09.81-08.88		**0 280 120 301**
Air flow sensor, gasoline injection		09.81-08.88		**0 280 202 030**
Temperature sensor, coolant, injection system		09.81-08.88		**0 280 130 026**

Meriva

1.3 CDTI			**1,3 l 55 kW ... 13 DT 4 Zyl.**	
Air mass meter, diesel		04.05→		**0 281 002 620**
High-pressure sensor (CR system)		04.05→		**0 281 002 706**
Yaw rate sensor, brake system				
Fg.no. →44999999		04.05→		**0 265 005 262**
Fg.no. 54000001→54999999		04.05→		**0 265 005 270**
Fg.no. 64000001→		04.05→	MBH	**0 265 005 657**
			NBA	**0 265 005 656**
Pressure sensor, ESP, (electronic stability program)		04.05→		**0 265 005 303**
1.3 CDTI			**1,3 l 55 kW Z 13 DTJ 4 Zyl.**	
High-pressure sensor (CR system)		09.03→		**0 281 002 706**
Yaw rate sensor, brake system				
Fg.no. →44999999		09.03→		**0 265 005 262**
Fg.no. 54000001→54999999		09.03→		**0 265 005 270**
Fg.no. 64000001→		09.03→	MBH	**0 265 005 657**
			NBA	**0 265 005 656**
Pressure sensor, ESP, (electronic stability program)		09.03→		**0 265 005 303**
1.4 i Twinport			**1,4 l 66 kW Z 14 XEP 4 Zyl.**	
Throttle valve assembly		07.04→		**0 280 750 133**
Air mass meter, gasoline injection		07.04→		**0 280 218 119**
Phase sensor				
Fg.no. →44999999		07.04→	NOC	**0 232 103 021**
Fg.no. 54000001→54999999		07.04→	NOC	**0 232 103 052**
Fg.no. 64000001→		07.04→	NOC	**0 232 103 067**
Speed sensor, ignition/injection		07.04→	FKW	**0 261 210 151**
Knock sensor		07.04→		**0 261 231 173**
Temperature sensor, coolant, injection system		07.04→		**0 281 002 170**

Product

◀ Meriva

Yaw rate sensor, brake system			
Fg.no. →44999999	07.04→		**0 265 005 262**
Fg.no. 54000001→54999999	07.04→		**0 265 005 270**
Fg.no. 64000001→	07.04→	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Pressure sensor, ESP, (electronic stability program)	07.04→		**0 265 005 303**
1.6 i		**1,6 l 64 kW Z 16 SE 4 Zyl.**	
Yaw rate sensor, brake system			
Fg.no. →44999999	03.03-09.05		**0 265 005 262**
Fg.no. 54000001→54999999	03.03-09.05		**0 265 005 270**
Fg.no. 64000001→	03.03-09.05	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Pressure sensor, ESP, (electronic stability program)	03.03-09.05		**0 265 005 303**
1.6 i OPC Turbo		**1,6 l 132 kW Z 16 LET 4 Zyl.**	
Air mass meter, gasoline injection	09.05→		**0 280 218 142**
Phase sensor	09.05→	NOC	**0 232 103 052**
Knock sensor	09.05→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	09.05→		**0 281 002 137**
Yaw rate sensor, brake system			
Fg.no. →44999999	09.05→		**0 265 005 262**
Fg.no. 54000001→54999999	09.05→		**0 265 005 270**
Fg.no. 64000001→	09.05→	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Pressure sensor, ESP, (electronic stability program)	09.05→		**0 265 005 303**
1.6 i 16V Twinport		**1,6 l 74/77 kW Z 16 XE; Z 16 XEP 4 Zyl.**	
Yaw rate sensor, brake system			
Fg.no. →44999999	03.03→		**0 265 005 262**
Fg.no. 54000001→54999999	03.03→		**0 265 005 270**
Fg.no. 64000001→	03.03→	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Pressure sensor, ESP, (electronic stability program)	03.03→		**0 265 005 303**
1.7 CDTI		**1,7 l 74 kW Z 17 DTH 4 Zyl.**	
Air mass meter, diesel	09.03-09.05		**0 281 002 620**
Yaw rate sensor, brake system			
Fg.no. →44999999	09.03-09.05		**0 265 005 262**
Fg.no. 54000001→54999999	09.03-09.05		**0 265 005 270**
Fg.no. 64000001→	09.03-09.05	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Pressure sensor, ESP, (electronic stability program)	09.03-09.05		**0 265 005 303**
1.7 CDTI		**1,7 l 92 kW A 17 ...; Z 17 DT... 4 Zyl.**	
Yaw rate sensor, brake system			
Fg.no. →44999999	09.06→		**0 265 005 262**
Fg.no. 54000001→54999999	09.06→		**0 265 005 270**
Fg.no. 64000001→	09.06→	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Pressure sensor, ESP, (electronic stability program)	09.06→		**0 265 005 303**
1.7 DTI		**1,7 l 55 kW Y 17 DT 4 Zyl.**	
Yaw rate sensor, brake system			
Fg.no. →44999999	03.03-09.05		**0 265 005 262**
Fg.no. 54000001→54999999	03.03-09.05		**0 265 005 270**
Fg.no. 64000001→	03.03-09.05	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Pressure sensor, ESP, (electronic stability program)	03.03-09.05		**0 265 005 303**
1.8 i 16V		**1,8 l 92 kW Z 18 XE 4 Zyl.**	
Yaw rate sensor, brake system			
Fg.no. →44999999	03.03→		**0 265 005 262**
Fg.no. 54000001→54999999	03.03→		**0 265 005 270**
Fg.no. 64000001→	03.03→	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Pressure sensor, ESP, (electronic stability program)	03.03→		**0 265 005 303**

Product

Monza

2.2 i [A]		**2,2 l 85 kW 22 E CIH 4 Zyl.**	
Throttle valve sensor	11.84-08.86		**0 280 120 301**
Air flow sensor, gasoline injection	11.84-08.86		**0 280 202 068**
Temperature sensor, coolant, injection system	11.84-08.86		**0 280 130 032**
Wheel speed sensor	11.84-08.86	HI	**0 265 001 056**
		VO	**0 265 001 055**
2.5 i [A]		**2,5 l 100 kW S 25 E CIH 6 Zyl.**	
Throttle valve sensor	09.84-08.86		**0 280 120 200**
Air flow sensor, gasoline injection	09.84-08.86		**0 280 202 024**
Temperature sensor, coolant, injection system	09.84-08.86		**0 280 130 026**
Relay, Jetronic	09.84-08.86		**0 332 514 124**
Wheel speed sensor	09.84-08.86	HI	**0 265 001 056**
		VO	**0 265 001 055**
2.5 i [A]		**2,5 l 100 kW 25 E CIH 6 Zyl.**	
Throttle valve sensor	05.81-08.86		**0 280 120 200**
Air flow sensor, gasoline injection	05.81-08.86		**0 280 202 024**
Temperature sensor, coolant, injection system	05.81-08.86		**0 280 130 026**
Relay, Jetronic	05.81-08.86		**0 332 514 124**
2.5 i [A]		**2,5 l 100-103 kW 25 E/H CIH 6 Zyl.**	
Throttle valve sensor	09.84-08.86		**0 280 120 301**
Air flow sensor, gasoline injection	09.84-08.86		**0 280 202 053**
Temperature sensor, coolant, injection system	09.84-08.86		**0 280 130 032**
Wheel speed sensor	09.84-08.86	HI	**0 265 001 056**
		VO	**0 265 001 055**
3.0 i [A]		**3,0 l 115 kW C 30 NE / LE 6 Zyl.**	
Throttle valve sensor	09.85-08.86		**0 280 120 301**
Air flow sensor, gasoline injection	09.85-08.86		**0 280 202 084**
Temperature sensor, coolant, injection system	09.85-08.86		**0 280 130 032**
Wheel speed sensor	09.85-08.86	HI	**0 265 001 056**
		VO	**0 265 001 055**
3.0 i [A]		**3,0 l 132 kW 30 E / S 30 E CIH 6 Zyl.**	
Throttle valve sensor	01.83-08.86		**0 280 120 200**
Air flow sensor, gasoline injection	01.83-08.86		**0 280 202 007**
Temperature sensor, coolant, injection system	01.83-08.86		**0 280 130 026**
Relay, Jetronic	01.83-08.86		**0 332 514 124**
Wheel speed sensor	09.83-08.86	HI	**0 265 001 056**
		VO	**0 265 001 055**
3.0 i [A]		**3,0 l 132 kW 30 E CIH 6 Zyl.**	
Throttle valve sensor	01.83-08.86		**0 280 120 301**
Air flow sensor, gasoline injection	01.83-08.86		**0 280 202 037**
Temperature sensor, coolant, injection system	01.83-08.86		**0 280 130 032**
Wheel speed sensor	09.83-08.86	HI	**0 265 001 056**
		VO	**0 265 001 055**

Omega

1.8 [A]		**1,8 l 60/65 kW E 18 NVR; S 18 NV; 18 NV 4 Zyl.**	
Speed sensor, ignition/injection	09.86-03.94		**0 261 210 030**
Temperature sensor, coolant, injection system	09.86-03.94		**0 280 130 107**
Wheel speed sensor	09.86-03.94	HI	**0 265 001 134**
Fg.no. J1185910→	09.86-03.94	VO	**0 265 001 220**
Fg.no. →J1185909	09.86-03.94	VO	**0 265 001 143**
1.8 i [A]		**1,8 l 85 kW 18 SEH 4 Zyl.**	
Throttle valve sensor	09.86-03.94		**0 280 120 316**
Air flow sensor, gasoline injection	09.86-03.94		**0 280 202 602**
			0 986 280 019
Speed sensor, ignition/injection	09.86-03.94		**0 261 210 030**
Temperature sensor, coolant, injection system	09.86-03.94		**0 280 130 107**
Wheel speed sensor	09.86-03.94	HI	**0 265 001 134**
Fg.no. J1185910→	09.86-03.94	VO	**0 265 001 220**
Fg.no. →J1185909	09.86-03.94	VO	**0 265 001 143**

Product			
1.8 S [A]			**1,8 l 66 kW 18 SV 4 Zyl.**
Speed sensor, ignition/injection	09.86-03.94		**0 261 210 030**
Temperature sensor, coolant, injection system	09.86-03.94		**0 280 130 107**
Wheel speed sensor	09.86-03.94	HI	**0 265 001 134**
Fg.no. J1185910→	09.86-03.94	VO	**0 265 001 220**
Fg.no. →J1185909	09.86-03.94	VO	**0 265 001 143**
2.0 DTI Turbo [B]			**2,0 l 74 kW X 20 DTH 4 Zyl.**
Air mass meter, diesel	09.97-08.00		**0 281 002 180**
Speed sensor, diesel	09.97-08.00		**0 281 002 138**
Temperature sensor, coolant, injection system	09.97-08.00		**0 281 002 169**
Pedal position sensor, diesel			
Fg.no. →V1999999	09.97-08.00		**0 205 001 039**
2.0 i [A]			**2,0 l 74 kW C 20 NEJ /NEF 4 Zyl.**
Throttle valve sensor			
Fg.no. L1019855→	06.89-02.92		**0 280 122 001**
Air flow sensor, gasoline injection			
Fg.no. →L1019854	06.89-02.92		**0 280 202 210**
			0 986 280 063
Speed sensor, ignition/injection	06.89-02.92		**0 261 210 030**
Temperature sensor, coolant, injection system	06.89-02.92		**0 280 130 107**
Wheel speed sensor	06.89-02.92	HI	**0 265 001 134**
Fg.no. J1185910→	06.89-02.92	VO	**0 265 001 220**
Fg.no. →J1185909	06.89-02.92	VO	**0 265 001 143**
2.0 i [A]			**2,0 l 85 kW C 20 NE 4 Zyl.**
Throttle valve sensor			
Fg.no. L1019855→	09.86-03.94		**0 280 122 001**
Fg.no. →L1019854	09.86-03.94		**0 280 120 316**
Air flow sensor, gasoline injection			
Fg.no. →L1019854	09.86-03.94		**0 280 202 210**
			0 986 280 063
Speed sensor, ignition/injection	09.86-03.94		**0 261 210 030**
Pressure sensor, intake manifold, gasoline	09.86-08.89		**0 280 101 007**
Temperature sensor, coolant, injection system	09.86-03.94		**0 280 130 107**
Wheel speed sensor	09.86-03.94	HI	**0 265 001 134**
Fg.no. J1185910→	09.86-03.94	VO	**0 265 001 220**
Fg.no. →J1185909	09.86-03.94	VO	**0 265 001 143**
2.0 i [A]			**2,0 l 90 kW 20 SE 4 Zyl.**
Throttle valve sensor			
Fg.no. L1019855→	09.86-03.94		**0 280 122 001**
Fg.no. →L1019854	09.86-03.94		**0 280 120 316**
Air flow sensor, gasoline injection	09.86-03.94		**0 280 202 210**
			0 986 280 063
Speed sensor, ignition/injection	09.86-03.94		**0 261 210 030**
Pressure sensor, intake manifold, gasoline	09.86-08.89		**0 280 101 007**
Temperature sensor, coolant, injection system	09.86-03.94		**0 280 130 107**
Wheel speed sensor	09.86-03.94	HI	**0 265 001 134**
Fg.no. J1185910→	09.86-03.94	VO	**0 265 001 220**
Fg.no. →J1185909	09.86-03.94	VO	**0 265 001 143**
2.0 i [B]			**2,0 l 85 kW X 20 SE; 20 SE 4 Zyl.**
Throttle valve sensor	04.94-08.98		**0 280 122 001**
Air mass meter, gasoline injection	04.94-08.98		**0 280 217 106**
Knock sensor	04.94-08.98		**0 261 231 006**
Temperature sensor, intake air, injection system	04.94-08.98		**0 280 130 073**
Temperature sensor, coolant, injection system	04.94-08.98		**0 280 130 107**
2.0 i [B]			**2,0 l 100 kW X 20 XEV 4 Zyl.**
Throttle valve sensor	09.93-08.99		**0 280 122 001**
2.2 DTI [B]			**2,2 l 88 kW Y 22 DTH Turbo 4 Zyl.**
Air mass meter, diesel	06.00-07.03		**0 281 002 428**
Speed sensor, diesel	06.00-07.03		**0 281 002 138**
Pedal position sensor, diesel	06.00-07.03		**0 280 752 027**

Product			
2.3 D [A]			**2,3 l 54 kW 23 YD 4 Zyl.**
Temperature sensor, coolant, diesel	09.86-03.94	2PO	**0 280 130 107**
Wheel speed sensor	09.86-03.94	HI	**0 265 001 134**
Fg.no. J1185910→	09.86-03.94	VO	**0 265 001 220**
Fg.no. →J1185909	09.86-03.94	VO	**0 265 001 143**
2.3 TD [A]			**2,3 l 66/74 kW 23 DTR; 23 YDT 4 Zyl.**
Temperature sensor, coolant, diesel	09.86-03.94	2PO	**0 280 130 107**
Wheel speed sensor	09.86-03.94	HI	**0 265 001 134**
Fg.no. J1185910→	09.86-03.94	VO	**0 265 001 220**
Fg.no. →J1185909	09.86-03.94	VO	**0 265 001 143**
2.4 i [A]			**2,4 l 92 kW C 24 NE CIH 4 Zyl.**
Throttle valve sensor	09.88-03.94		**0 280 122 001**
Air flow sensor, gasoline injection	09.88-03.94		**0 280 202 211**
			0 986 280 091
Speed sensor, ignition/injection	09.88-03.94		**0 261 210 031**
Temperature sensor, coolant, injection system	09.88-03.94		**0 280 130 107**
Wheel speed sensor	09.88-03.94	HI	**0 265 001 134**
Fg.no. J1185910→	09.88-03.94	VO	**0 265 001 220**
Fg.no. →J1185909	09.88-03.94	VO	**0 265 001 143**
2.5 DTI Turbo [B]			**2,5 l 110 kW Y 25 TD 6 Zyl.**
Air mass meter, diesel	06.01-09.03		**0 281 002 564**
2.5 i [B]			**2,5 l 125 kW X 25 XE 6 Zyl.**
Throttle valve sensor			
Fg.no. V1000001→	04.94-11.00		**0 280 122 014**
Fg.no. →T1999999	04.94-11.00		**0 280 122 001**
Air mass meter, gasoline injection			
Mot.no. →08137540	04.94-11.00		**0 280 217 503**
Mot.no. 08137541→	04.94-11.00		**0 280 217 519**
Phase sensor	04.94-11.00	MTS	**0 232 103 008**
		OTS	**0 232 103 001**
Mot.no. →08149313	04.94-11.00		**0 232 103 008**
Mot.no. 08149314→	04.94-11.00		**0 232 103 017**
Knock sensor			
Mot.no. →08137540	04.94-11.00		**0 261 231 079**
Mot.no. 08137541→	04.94-11.00		**0 261 231 116**
Temperature sensor, intake air, injection system			
Mot.no. →01837540	04.94-11.00		**0 280 130 073**
Mot.no. 08137541→	04.94-11.00		**0 280 130 092**
Temperature sensor, coolant, injection system			
Mot.no. →08137540	04.94-11.00		**0 280 130 107**
Mot.no. 08137541→	04.94-11.00		**0 280 130 093**
2.5 TD [B]			**2,5 l 96 kW U 25 TD -R6 Turbo; X 25 TD Turbo 6 Zyl.**
Pedal position sensor, diesel			
Fg.no. S1155598→	04.94-02.01	LLE	**0 205 001 039**
Fg.no. S1156241→	04.94-02.01	RLE	**0 205 001 039**
Fg.no. →S1155597	04.94-02.01	LLE	**0 205 001 019**
Fg.no. →S1156240	04.94-02.01	RLE	**0 205 001 019**
2.6 i [A]			**2,6 l 110 kW C 26 NE CIH 6 Zyl.**
Throttle valve sensor	09.90-03.94		**0 280 122 001**
Speed sensor, ignition/injection	09.90-03.94		**0 261 210 031**
Temperature sensor, coolant, injection system	09.90-03.94		**0 280 130 107**
Wheel speed sensor	09.90-03.94	HI	**0 265 001 134**
Fg.no. J1185910→	09.90-03.94	VO	**0 265 001 220**
Fg.no. →J1185909	09.90-03.94	VO	**0 265 001 143**
2.6 i [B]			**2,6 l 132 kW Y 26 SE 6 Zyl.**
Air mass meter, gasoline injection	09.00-09.03		**0 281 002 184**
Phase sensor	09.00-09.03		**0 232 103 025**
Speed sensor, ignition/injection			
Mot.no. 08149314→	09.00-09.03		**0 261 210 131**
Knock sensor			
Mot.no. 08137541→	09.00-09.03		**0 261 231 116**

Product

◀ Omega

3.0 i [A]			**3,0 l 115 kW C 30 LE CIH 6 Zyl.**
Throttle valve sensor	03.87-12.87		**0 280 120 301**
		AG	**0 280 120 412**
Air flow sensor, gasoline injection	03.87-12.87		**0 280 202 201**
Speed sensor, ignition/injection	03.87-12.87		**0 261 210 031**
Temperature sensor, coolant, injection system	03.87-12.87		**0 280 130 107**
3.0 i [A]			**3,0 l 130 kW C 30 NE CIH 6 Zyl.**
Throttle valve sensor			
Fg.no. L1019855→	01.88-03.94		**0 280 122 001**
Fg.no. →L1019854	01.88-03.94		**0 280 120 316**
Air flow sensor, gasoline injection	01.88-03.94		**0 280 203 032**
			0 986 280 074
Speed sensor, ignition/injection	01.88-03.94		**0 261 210 031**
Temperature sensor, coolant, injection system	01.88-03.94		**0 280 130 069**
Wheel speed sensor	01.88-03.94	HI	**0 265 001 134**
Fg.no. J1185910→	01.88-03.94	VO	**0 265 001 220**
Fg.no. →J1185909	01.88-03.94	VO	**0 265 001 143**
3.0 i [A]			**3,0 l 130 kW 30 NE CIH 6 Zyl.**
Throttle valve sensor	03.87-12.89		**0 280 120 301**
		AG	**0 280 120 405**
Temperature sensor, coolant, injection system	03.87-12.89		**0 280 130 069**
Wheel speed sensor	03.87-12.89	HI	**0 265 001 134**
Fg.no. J1185910→	03.87-12.89	VO	**0 265 001 220**
Fg.no. →J1185909	03.87-12.89	VO	**0 265 001 143**
3.0 i [A]			**3,0 l 147-150 kW C 30 SE, SEJ 6 Zyl.**
Throttle valve sensor	09.89-03.94		**0 280 122 001**
Air flow sensor, gasoline injection	09.89-03.94		**0 280 203 032**
			0 986 280 074
Knock sensor	09.89-03.94		**0 261 231 006**
Temperature sensor, coolant, injection system	09.89-03.94		**0 280 130 107**
Wheel speed sensor	09.89-03.94	HI	**0 265 001 134**
Fg.no. J1185910→	09.89-03.94	VO	**0 265 001 220**
Fg.no. →J1185909	09.89-03.94	VO	**0 265 001 143**
3.0 i [B]			**3,0 l 155 kW X 30 XE 6 Zyl.**
Throttle valve sensor	04.94-02.01		**0 280 122 001**
Fg.no. V1000001→	04.94-02.01		**0 280 122 014**
Air mass meter, gasoline injection			
Mot.no. →08137540	04.94-02.01		**0 280 217 503**
Mot.no. 08137541→	04.94-02.01		**0 280 217 519**
Phase sensor	04.94-02.01	MTS	**0 232 103 008**
		OTS	**0 232 103 001**
Mot.no. →08149313	04.94-02.01		**0 232 103 008**
Mot.no. 08149314→	04.94-02.01		**0 232 103 017**
Speed sensor, ignition/injection			
Mot.no. 08149314→	04.94-02.01		**0 261 210 131**
Knock sensor			
Mot.no. →08137540	04.94-02.01		**0 261 231 079**
Mot.no. 08137541→	04.94-02.01		**0 261 231 116**
Temperature sensor, intake air, injection system			
Mot.no. →01837540	04.94-02.01		**0 280 130 073**
Mot.no. 08137541→	04.94-02.01		**0 280 130 092**
Temperature sensor, coolant, injection system			
Mot.no. →08137540	04.94-02.01		**0 280 130 107**
Mot.no. 08137541→	04.94-02.01		**0 280 130 093**
3.2 i [B]			**3,2 l 160 kW Y 32 SE 6 Zyl.**
Throttle valve assembly	09.00-09.03		**0 280 750 006**
Air mass meter, gasoline injection	09.00-09.03		**0 281 002 184**
Phase sensor	09.00-09.03		**0 232 103 025**
Speed sensor, ignition/injection			
Mot.no. 08149314→	09.00-09.03		**0 261 210 131**
Knock sensor			
Mot.no. 08137541→	09.00-09.03		**0 261 231 116**

Product

Rekord

1.8 [E]			**1,8 l 55 kW 18 N 4 Zyl.**
Wheel speed sensor	09.84-08.86	VO	**0 265 001 055**
1.8 i [E]			**1,8 l 74 kW C 18 NV 4 Zyl.**
Throttle valve sensor	05.85-08.86		**0 280 120 301**
Air flow sensor, gasoline injection	05.85-08.86		**0 280 202 089**
Temperature sensor, coolant, injection system	05.85-08.86		**0 280 130 026**
Wheel speed sensor	05.85-08.86	VO	**0 265 001 055**
1.8 S [E]			**1,8 l 59/66 kW S 18 S; 18 S 4 Zyl.**
Wheel speed sensor	09.84-08.86	VO	**0 265 001 055**
2.0 S [E]			**2,0 l 74 kW 20 S CIH 4 Zyl.**
Wheel speed sensor	09.84-08.86	VO	**0 265 001 055**
2.2 i [E]			**2,2 l 85 kW 22 E CIH 4 Zyl.**
Throttle valve sensor	11.84-08.86		**0 280 120 301**
Air flow sensor, gasoline injection	11.84-08.86		**0 280 202 068**
Temperature sensor, coolant, injection system	11.84-08.86		**0 280 130 032**
Wheel speed sensor	11.84-08.86	VO	**0 265 001 055**
2.3 D [E]			**2,3 l 52 kW 23 D 4 Zyl.**
Wheel speed sensor	09.84-08.86	VO	**0 265 001 055**
2.3 TD [E]			**2,3 l 63 kW 23 DT 4 Zyl.**
Wheel speed sensor	09.84-08.86	VO	**0 265 001 055**

Senator

2.2 i [A]			**2,2 l 85 kW 22 E 4 Zyl.**
Throttle valve sensor	11.84-08.87		**0 280 120 301**
Air flow sensor, gasoline injection	11.84-08.87		**0 280 202 068**
Temperature sensor, coolant, injection system	11.84-08.87		**0 280 130 032**
Wheel speed sensor	11.84-08.87	HI	**0 265 001 056**
		VO	**0 265 001 055**
2.3 D Comprex [A]			**2,3 l 70 kW 23 DC 4 Zyl.**
Wheel speed sensor	11.84-08.87	HI	**0 265 001 056**
		VO	**0 265 001 055**
2.3 TD [A]			**2,3 l 64 kW 23 TD 4 Zyl.**
Wheel speed sensor	11.84-08.87	HI	**0 265 001 056**
		VO	**0 265 001 055**
2.5 i [A]			**2,5 l 100 kW S 25 E/H CIH 6 Zyl.**
Throttle valve sensor	09.84-08.87		**0 280 120 200**
Air flow sensor, gasoline injection	09.84-08.87		**0 280 202 024**
Temperature sensor, coolant, injection system	09.84-08.87		**0 280 130 026**
Relay, Jetronic	09.84-08.87		**0 332 514 124**
Wheel speed sensor	09.84-08.87	HI	**0 265 001 056**
		VO	**0 265 001 055**
2.5 i [A]			**2,5 l 100-103 kW 25 E CIH 6 Zyl.**
Throttle valve sensor	09.84-08.87		**0 280 120 301**
Air flow sensor, gasoline injection	09.84-08.87		**0 280 202 053**
Temperature sensor, coolant, injection system	09.84-08.87		**0 280 130 032**
Wheel speed sensor	09.84-08.87	HI	**0 265 001 056**
		VO	**0 265 001 055**
2.5 i [B]			**2,5 l 103 kW 25 NE CIH 6 Zyl.**
Throttle valve sensor	09.87-12.89		**0 280 120 301**
Air flow sensor, gasoline injection	09.87-12.89		**0 280 202 053**
Temperature sensor, coolant, injection system	09.87-12.89		**0 280 130 032**
Wheel speed sensor	09.87-12.89	HI	**0 265 001 134**
Fg.no. N1085998→	09.88-12.89	VO	**0 265 001 220**
Fg.no. →J1185909	09.87-12.89	VO	**0 265 001 143**
2.6 i [B]			**2,6 l 110 kW C 26 NE CIH 6 Zyl.**
Throttle valve sensor	09.90-09.93		**0 280 122 001**
Air flow sensor, gasoline injection	09.90-09.93		**0 280 202 207**
Speed sensor, ignition/injection	09.90-09.93		**0 261 210 031**
Temperature sensor, coolant, injection system	09.90-09.93		**0 280 130 107**

Product			
Wheel speed sensor	09.90-09.93	HI	**0 265 001 134**
Fg.no. N1085998→	09.90-09.93	VO	**0 265 001 220**
Fg.no. →J1185909	09.90-09.93	VO	**0 265 001 143**
3.0 i [A]	**3,0 l 115 kW C 30 NE/C 30LE 6 Zyl.**		
Throttle valve sensor	09.85-08.87		**0 280 120 301**
Air flow sensor, gasoline injection	09.85-08.87		**0 280 202 084**
Temperature sensor, coolant, injection system	09.85-08.87		**0 280 130 032**
Wheel speed sensor	09.85-08.87	HI	**0 265 001 056**
		VO	**0 265 001 055**
3.0 i [A]	**3,0 l 132 kW S 30 E CIH 6 Zyl.**		
Throttle valve sensor	01.83-08.87		**0 280 120 200**
Air flow sensor, gasoline injection	01.83-08.87		**0 280 202 007**
Temperature sensor, coolant, injection system	01.83-08.87		**0 280 130 026**
Relay, Jetronic	01.83-08.87		**0 332 514 124**
Wheel speed sensor	09.83-08.87	HI	**0 265 001 056**
		VO	**0 265 001 055**
3.0 i [A]	**3,0 l 132 kW 30 E CIH 6 Zyl.**		
Throttle valve sensor	01.83-08.87		**0 280 120 301**
Air flow sensor, gasoline injection	01.83-08.87		**0 280 202 037**
Temperature sensor, coolant, injection system	01.83-08.87		**0 280 130 032**
Wheel speed sensor	09.83-08.87	HI	**0 265 001 056**
		VO	**0 265 001 055**
3.0 i [B]	**3,0 l 115 kW C 30 LE CIH 6 Zyl.**		
Throttle valve sensor	09.87-09.93		**0 280 120 301**
	04.88-09.93	AG	**0 280 120 405**
Air flow sensor, gasoline injection	09.87-09.93		**0 280 202 201**
Speed sensor, ignition/injection	09.87-09.93		**0 261 210 031**
Temperature sensor, coolant, injection system	09.87-09.93		**0 280 130 107**
Wheel speed sensor	09.87-09.93	HI	**0 265 001 134**
Fg.no. N1085998→	09.88-09.93	VO	**0 265 001 220**
Fg.no. →J1185909	09.87-09.93	VO	**0 265 001 143**
3.0 i [B]	**3,0 l 130 kW C 30 NE CIH 6 Zyl.**		
Throttle valve sensor			
Fg.no. L1019855→	09.89-09.93		**0 280 122 001**
Fg.no. →L1019854	01.88-08.89		**0 280 120 316**
Fg.no. →1019854	04.88-09.93	AG	**0 280 120 412**
Air flow sensor, gasoline injection	01.88-09.93		**0 280 203 032**
			0 986 280 074
Speed sensor, ignition/injection	01.88-09.93		**0 261 210 031**
Temperature sensor, coolant, injection system	01.88-09.93		**0 280 130 107**
Wheel speed sensor	01.88-09.93	HI	**0 265 001 134**
Fg.no. N1085998→	09.88-09.93	VO	**0 265 001 220**
Fg.no. →J1185909	01.88-09.93	VO	**0 265 001 143**
3.0 i [B]	**3,0 l 130 kW 30 NE CIH 6 Zyl.**		
Throttle valve sensor	01.88-12.89		**0 280 120 301**
	04.88-12.89	AG	**0 280 120 405**
Temperature sensor, coolant, injection system	01.88-12.89		**0 280 130 032**
Wheel speed sensor	01.88-12.89	HI	**0 265 001 134**
Fg.no. N1085998→	09.88-12.89	VO	**0 265 001 220**
Fg.no. →J1185909	01.88-12.89	VO	**0 265 001 143**
3.0 i 24V [B]	**3,0 l 150 kW C 30 SE 6 Zyl.**		
Throttle valve sensor	09.89-09.93		**0 280 122 001**
Air flow sensor, gasoline injection	09.89-09.93		**0 280 203 032**
			0 986 280 074
Knock sensor	09.89-09.93		**0 261 231 006**
Temperature sensor, coolant, injection system	09.89-09.93		**0 280 130 107**
Wheel speed sensor	09.89-09.93	HI	**0 265 001 134**
Fg.no. N1085998→	09.89-09.93	VO	**0 265 001 220**
Fg.no. →J1185909	09.89-09.93	VO	**0 265 001 143**
3.6 i [B]	**3,6 l 145 kW C 3.6 NE Irmscher 6 Zyl.**		
Speed sensor, ignition/injection	08.89-09.93		**0 261 210 031**

Product			
4.0 i [B]	**4,0 l 200 kW C 40 SE 6 Zyl.**		
Air flow sensor, gasoline injection	01.91-09.93		**0 280 203 025**
			0 986 280 043

Signum

1.8 i	**1,8 l 90 kW Z 18 XE 4 Zyl.**		
Phase sensor	05.03-02.05	NOC	**0 232 103 021**
1.9 CDTI	**1,9 l 74 kW Z 19 DTL 4 Zyl.**		
Air mass meter, diesel	08.05→		**0 281 002 683**
Speed sensor, diesel	08.05→		**0 281 002 603**
Phase sensor	08.05→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	08.05→		**0 281 002 706**
Boost pressure sensor, Diesel	08.05→		**0 281 002 437**
1.9 CDTI	**1,9 l 88 kW Z 19 DT 4 Zyl.**		
Air mass meter, diesel	04.04→		**0 281 002 683**
Speed sensor, diesel	04.04→		**0 281 002 603**
Phase sensor	04.04→	NOC	**0 281 002 213**
Boost pressure sensor, Diesel	04.04→		**0 281 002 437**
1.9 CDTI	**1,9 l 110 kW Z 19 DTH 4 Zyl.**		
Air mass meter, diesel	04.04→		**0 281 002 683**
High-pressure sensor (CR system)	04.04→		**0 281 002 706**
Boost pressure sensor, Diesel	04.04→		**0 281 002 437**
2.0 DTI	**2,0 l 74 kW Y 20 DTH 4 Zyl.**		
Air mass meter, diesel	05.03-09.05		**0 281 002 479**
Speed sensor, diesel			
Fg.no. →17G23740	05.03-09.05	FKW	**0 281 002 138**
Fg.no. 17G23741→	05.03-09.05	FKW	**0 281 002 662**
Temperature sensor, coolant, diesel	05.03-09.05		**0 281 002 473**
2.0 Turbo	**2,0 l 129 kW Z 20 NET 4 Zyl.**		
Speed sensor, ignition/injection	05.03→	FKW	**0 261 210 229**
2.2 DTI	**2,2 l 86-92 kW Y 22 DTR 4 Zyl.**		
Air mass meter, diesel	05.03-09.05		**0 281 002 479**
Speed sensor, diesel	05.03-09.05	FKW	**0 281 002 138**
Temperature sensor, coolant, diesel	05.03-09.05		**0 281 002 473**
2.8 V6 Turbo	**2,8 l 169/184 kW Z 28 NEL; Z 28 NET 6 Zyl.**		
Knock sensor	09.05→		**0 261 231 174**
Pressure sensor, intake manifold, gasoline	09.05→		**0 261 230 101**
Temperature sensor, coolant, injection system	09.05→		**0 280 130 122**
3.0 CDTI	**3,0 l 130-135 kW Y 30 DT 6 Zyl.**		
Air mass meter, diesel	05.03→		**0 281 002 605**
3.0 CDTI	**3,0 l 130-135 kW Z 30 DT 6 Zyl.**		
Air mass meter, diesel	09.05→		**0 281 002 773**
3.2 V6	**3,2 l 155 kW Z 32 SE 6 Zyl.**		
Throttle valve assembly	05.03-09.05		**0 280 750 119**
Air mass meter, gasoline injection	05.03-09.05		**0 280 218 087**
Phase sensor	05.03-09.05	NOC	**0 232 103 025**
Speed sensor, ignition/injection	05.03-09.05	FKW	**0 261 210 206**
Knock sensor	05.03-09.05		**0 261 231 116**

Sintra

2.2 i 16V	**2,2 l 104 kW X 22 XE 4 Zyl.**		
Throttle valve sensor	09.96-09.99		**0 280 122 001**
Phase sensor	09.96-09.99	NOC	**0 232 103 015**
Knock sensor	09.96-09.99		**0 261 231 079**
Pressure sensor, intake manifold, gasoline	09.96-09.99		**0 261 230 009**
Temperature sensor, intake air, injection system			
Fg.no. XD100001→	09.96-09.99		**0 280 130 092**
Fg.no. →WD199999	09.96-09.99		**0 280 130 073**
Temperature sensor, coolant, injection system	09.96-09.99		**0 281 002 169**

Product

◀ Sintra

2.2 TD			**2,2 l 85 kW X 22 DTH 4 Zyl.**
Air mass meter, diesel	09.97-09.99		**0 281 002 184**
Speed sensor, diesel	09.97-09.99		**0 281 002 138**
Pressure sensor, intake manifold, diesel	09.97-09.99		**0 281 002 137**
Temperature sensor, coolant, injection system	09.97-09.99		**0 280 130 107**
Pedal position sensor, diesel	09.97-09.99	LLE	**0 205 001 039**
		RLE	**0 205 001 042**
3.0 i 24V			**3,0 l 148 kW X 30 XE 6 Zyl.**
Throttle valve sensor	09.96-09.99		**0 280 122 001**
Air mass meter, gasoline injection	09.96-09.99		**0 280 217 503**
Phase sensor	09.96-09.99		**0 232 103 008**
Knock sensor	09.96-09.99		**0 261 231 079**
Temperature sensor, intake air, injection system	09.96-09.99		**0 280 130 092**
Temperature sensor, coolant, injection system	09.96-09.99		**0 281 002 169**
Pedal position sensor, diesel	09.96-09.99	LLE	**0 205 001 039**
		RLE	**0 205 001 042**

Speedster

2.0 Turbo			**2,0 l 147 kW Z 20 LET 4 Zyl.**
Air mass meter, gasoline injection	04.03-09.06		**0 280 218 051**
			0 986 280 231
Phase sensor	04.03-09.06	NOC	**0 232 103 015**
Speed sensor, ignition/injection	04.03-09.06	FKW	**0 261 210 150**
Knock sensor	04.03-09.06		**0 261 231 116**
Pressure sensor, intake manifold, gasoline	04.03-09.06		**0 261 230 009**
Temperature sensor, coolant, injection system	04.03-09.06		**0 281 002 169**

Tigra

1.4 i [A]			**1,4 l 63-66 kW X 14 XE 4 Zyl.**
Temperature sensor, coolant, injection system			
Fg.no. W3000001→,W4000001→, W6000001→	09.94-08.99		**0 280 130 093**
Fg.no. →V6999999	09.94-08.99		**0 280 130 107**
1.6 i [A]			**1,6 l 78 kW X 16 XE 4 Zyl.**
Temperature sensor, coolant, injection system			
Fg.no. W3000001→	09.94-08.99		**0 280 130 093**
Fg.no. W3000001→,W4000001→, W6000001→	09.94-08.99		**0 280 130 093**
Fg.no. →V6999999	09.94-08.99		**0 280 130 107**
1.6 i 16V [A]			**1,6 l 74 kW C 16 SEL 4 Zyl.**
Temperature sensor, coolant, injection system			
Fg.no. W3000001→,W4000001→, W6000001→	08.97-08.98		**0 280 130 093**

Tigra TwinTop

1.3 CDTI [B]			**1,3 l 51 kW Z 13 DT 4 Zyl.**
Air mass meter, diesel	06.04→		**0 281 002 549**
High-pressure sensor (CR system)	06.04→		**0 281 002 534**
Pressure sensor, intake manifold, diesel	06.04→		**0 281 002 510**
Yaw rate sensor, brake system	06.04→		**0 265 005 270**
Pressure sensor, ESP, (electronic stability program)	06.04→		**0 265 005 303**
1.4 i [B]			**1,4 l 66 kW Z 14 XEP 4 Zyl.**
Throttle valve assembly	06.04→		**0 280 750 133**
Air mass meter, gasoline injection	06.04→		**0 280 218 119**
Phase sensor			
Fg.no. →4E999999	06.04→	NOC	**0 232 103 021**
Fg.no. 5E000001→5E999999	06.04→	NOC	**0 232 103 052**
Fg.no. 6E000001→	06.04→	NOC	**0 232 103 067**
Speed sensor, ignition/injection	06.04→	FKW	**0 261 210 151**
Knock sensor	06.04→		**0 261 231 173**
Temperature sensor, coolant, injection system	06.04→		**0 281 002 170**
Yaw rate sensor, brake system	06.04→		**0 265 005 270**
Pressure sensor, ESP, (electronic stability program)	06.04→		**0 265 005 303**
1.8 i [B]			**1,8 l 92 kW Z 18 XE 4 Zyl.**
Yaw rate sensor, brake system	06.04→		**0 265 005 270**
Pressure sensor, ESP, (electronic stability program)	06.04→		**0 265 005 303**

Vectra

1.4 [A]			**1,4 l 55 kW 14 NV 4 Zyl.**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.88-09.92		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	09.88-09.92	L10,RAB	**0 265 001 207**
		L13,LAB	**0 265 001 208**
1.6 i [A]			**1,6 l 52 kW X 16 SZ 4 Zyl.**
Temperature sensor, coolant, injection system	09.93-08.95		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.93-08.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	09.93-08.95	L10,RAB	**0 265 001 207**
		L13,LAB	**0 265 001 208**
1.6 i [A]			**1,6 l 55 kW C 16 LZ2; C 16 NZ2 4 Zyl.**
Speed sensor, ignition/injection	09.92-08.95		**0 261 210 030**
Temperature sensor, coolant, injection system	09.92-08.95		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.92-08.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	09.92-08.95	L10,RAB	**0 265 001 207**
		L13,LAB	**0 265 001 208**
1.6 i [B]			**1,6 l 55 kW X 16 SZR 4 Zyl.**
Temperature sensor, coolant, injection system			
Fg.no. →02GE3893,→V1999999, →V5999999,→V7999999	09.96-07.03		**0 280 130 107**
Fg.no. 02GE3894→,W1000001→, W5000001→,W7000001→	09.96-07.03		**0 280 130 093**
1.6 i [B]			**1,6 l 55 kW 16 LZ2 4 Zyl.**
Temperature sensor, coolant, injection system	09.95-07.03		**0 280 130 107**
1.6 i KAT [A]			**1,6 l 55-60 kW E 16 NZ / C 16 NZ 4 Zyl.**
Temperature sensor, coolant, injection system	09.88-08.95		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.88-08.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	09.88-08.95	L10,RAB	**0 265 001 207**
		L13,LAB	**0 265 001 208**
1.6 i 16V [B]			**1,6 l 74 kW X 16 XEL 4 Zyl.**
Temperature sensor, coolant, injection system	09.95-07.02		**0 280 130 093**
1.6 S [A]			**1,6 l 60 kW 16 SV 4 Zyl.**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.88-08.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	09.88-08.95	L10,RAB	**0 265 001 207**
		L13,LAB	**0 265 001 208**
1.7 D [A]			**1,7 l 42 kW 17 D/DR 4 Zyl.**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	10.88-08.95		**0 265 001 206**

Product			
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999,	10.88-08.95	L10,RAB	**0 265 001 207**
→N5999999		L13,LAB	**0 265 001 208**
1.7 TD [A]		**1,7 l 60 kW 17 DT/TC4 EE1 4 Zyl.**	
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039,	03.90-08.95		**0 265 001 206**
→MV999999			
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999,	03.90-08.95	L10,RAB	**0 265 001 207**
→N5999999		L13,LAB	**0 265 001 208**
1.8 [A]		**1,8 l 66 kW 18 SV 4 Zyl.**	
Speed sensor, ignition/injection			
Fg.no. →P1999999,→P5999999,	09.89-08.95		**0 261 210 030**
→P7999999			
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039,	09.89-08.95		**0 265 001 206**
→MV999999			
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999,	09.89-08.95	L10,RAB	**0 265 001 207**
→N5999999		L13,LAB	**0 265 001 208**
1.8 i [A]		**1,8 l 66 kW C 18 NZ 4 Zyl.**	
Speed sensor, ignition/injection			
Fg.no. →P1999999,→P5999999,	03.90-08.95		**0 261 210 030**
→P7999999			
Temperature sensor, coolant, injection system	03.90-08.95		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039,	03.90-08.95		**0 265 001 206**
→MV999999			
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999,	03.90-08.95	L10,RAB	**0 265 001 207**
→N5999999		L13,LAB	**0 265 001 208**
1.8 i 16V [B]		**1,8 l 85 kW X 18 XE 4 Zyl.**	
Throttle valve sensor	09.95-09.00		**0 280 122 001**
1.8 S [A]		**1,8 l 65 kW E 18 NVR 4 Zyl.**	
Speed sensor, ignition/injection	09.88-08.95		**0 261 210 030**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039,	09.88-08.95		**0 265 001 206**
→MV999999			
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999,	09.88-08.95	L10,RAB	**0 265 001 207**
→N5999999		L13,LAB	**0 265 001 208**
1.8 S 4x4 [A]		**1,8 l 65 kW E 18 NVR 4 Zyl.**	
Speed sensor, ignition/injection	01.89-08.95		**0 261 210 030**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039,	01.89-08.95		**0 265 001 206**
→MV999999			
Wheel speed sensor, rear			
Fg.no. N1000001→	01.89-08.95	AA,LAB	**0 265 006 487**
		AA,RAB	**0 265 006 486**
Fg.no. →M1999999	01.89-08.95	AA,LAB	**0 265 001 226**
1.8 4x4 [A]		**1,8 l 66 kW 18 SV 4 Zyl.**	
Speed sensor, ignition/injection			
Fg.no. →P1999999,→P5999999,	09.89-08.95		**0 261 210 030**
→P7999999			
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039,	09.89-08.95		**0 265 001 206**
→MV999999			
Wheel speed sensor, rear			
Fg.no. N1000001→	09.89-08.95	AA,LAB	**0 265 006 487**
		AA,RAB	**0 265 006 486**
Fg.no. →M1999999	09.89-08.95	AA,LAB	**0 265 001 226**

Product			
1.9 CDTI [C]		**1,9 l 74 kW Z 19 DTL 4 Zyl.**	
Air mass meter, diesel	09.05→		**0 281 002 683**
Speed sensor, diesel	09.05→		**0 281 002 603**
Phase sensor	09.05→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	09.05→		**0 281 002 706**
Boost pressure sensor, Diesel	09.05→		**0 281 002 437**
1.9 CDTI [C]		**1,9 l 88 kW Z 19 DT 4 Zyl.**	
Air mass meter, diesel	04.04→		**0 281 002 683**
Speed sensor, diesel	04.04→		**0 281 002 603**
Phase sensor	04.04→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	04.04→		**0 281 002 534**
Boost pressure sensor, Diesel	04.04→		**0 281 002 437**
1.9 CDTI [C]		**1,9 l 110 kW Z 19 DTH 4 Zyl.**	
Air mass meter, diesel	04.04-03.07		**0 281 002 683**
High-pressure sensor (CR system)	04.04-03.07		**0 281 002 534**
Boost pressure sensor, Diesel	04.04-03.07		**0 281 002 437**
1.9 CDTI GTS [C]		**1,9 l 74 kW Z 19 DTL 4 Zyl.**	
Air mass meter, diesel	09.05→		**0 281 002 683**
Speed sensor, diesel	09.05→		**0 281 002 603**
Phase sensor	09.05→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	09.05→		**0 281 002 706**
Boost pressure sensor, Diesel	09.05→		**0 281 002 437**
1.9 CDTI GTS [C]		**1,9 l 88 kW Z 19 DT 4 Zyl.**	
Air mass meter, diesel	04.04→		**0 281 002 683**
Speed sensor, diesel	04.04→		**0 281 002 603**
Phase sensor	04.04→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	04.04→		**0 281 002 534**
Boost pressure sensor, Diesel	04.04→		**0 281 002 437**
1.9 CDTI GTS [C]		**1,9 l 110 kW Z 19 DTH 4 Zyl.**	
Air mass meter, diesel	04.04-03.07		**0 281 002 683**
High-pressure sensor (CR system)	04.04-03.07		**0 281 002 534**
Boost pressure sensor, Diesel	04.04-03.07		**0 281 002 437**
2.0 DI [B]		**2,0 l 60 kW X 20 DTL 16V Turbo 4 Zyl.**	
Air mass meter, diesel			
Fg.no. W1000001→	09.96-08.02		**0 281 002 180**
Fg.no. →V7999999	09.96-08.02		**0 281 002 139**
Speed sensor, diesel	09.96-08.02		**0 281 002 138**
Pressure sensor, intake manifold, diesel	09.96-08.02		**0 281 002 137**
Temperature sensor, intake air, injection system	09.96-08.02		**0 280 130 073**
Temperature sensor, coolant, diesel	09.96-08.02		**0 281 002 169**
Temperature sensor, intake air, diesel	09.96-08.02		**0 280 130 073**
Pedal position sensor, diesel			
Fg.no. W1285447→,W7154259→	09.96-08.02	LLE	**0 281 002 476**
Fg.no. →W1285446,→W5276825,	09.96-08.02	LLE	**0 205 001 042**
→W7154258		RLE	**0 205 001 039**
2.0 DTI [B]		**2,0 l 74 kW X 20 DTH 4 Zyl.**	
Air mass meter, diesel	09.97-08.03		**0 281 002 180**
Speed sensor, diesel	09.97-08.03		**0 281 002 138**
Pressure sensor, intake manifold, diesel	09.97-08.03	TW	**0 281 002 137**
			0 281 002 438
Temperature sensor, coolant, diesel	09.97-08.03		**0 281 002 169**
Pedal position sensor, diesel			
Fg.no. W1285447→,W7154259→	09.97-08.03	LLE	**0 281 002 476**
Fg.no. →W1285446,→W5276825,	09.97-08.03	LLE	**0 205 001 042**
→W7154258		RLE	**0 205 001 039**
2.0 DTI [B]		**2,0 l 74 kW Y 20 DTH 4 Zyl.**	
Air mass meter, diesel	09.00-09.03		**0 281 002 428**
Speed sensor, diesel	09.00-09.03		**0 281 002 138**
Pressure sensor, intake manifold, diesel	09.00-09.03		**0 281 002 438**
Temperature sensor, coolant, diesel	09.00-09.03		**0 281 002 169**
Pedal position sensor, diesel	09.00-09.03	LLE	**0 281 002 476**

Product			
◀ Vectra			
2.0 DTI, DTI GTS [C]			**2,0 l 74 kW Y 20 DTH 4 Zyl.**
Air mass meter, diesel	04.02-09.05		**0 281 002 479**
Speed sensor, diesel	04.02-09.05		**0 281 002 138**
Speed sensor, ignition/injection			
Mot.no. →17G23740	04.02-09.05	FKW	**0 281 002 138**
Mot.no. 17G23741→	04.02-09.05	FKW	**0 281 002 662**
Temperature sensor, coolant, diesel	04.02-09.05		**0 281 002 473**
2.0 i [A]			**2,0 l 74-85 kW 20 NE,C 20 NE(NEF) 4 Zyl.**
Throttle valve sensor	09.88-08.90		**0 280 120 316**
	09.90-08.95		**0 280 122 004**
	09.88-08.90	AG	**0 280 120 412**
Air flow sensor, gasoline injection	09.88-08.89		**0 280 202 210**
			0 986 280 063
Speed sensor, ignition/injection			
Fg.no. →P1999999,→P5999999, →P7999999	09.88-08.95		**0 261 210 030**
Pressure sensor, intake manifold, gasoline	09.88-08.89		**0 280 101 007**
Temperature sensor, coolant, injection system	09.88-08.95		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.88-08.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	09.88-08.95	L10,RAB	**0 265 001 207**
		L13,LAB	**0 265 001 208**
2.0 i [A]			**2,0 l 95 kW 20 SEH 4 Zyl.**
Throttle valve sensor	09.88-08.90		**0 280 120 316**
	09.90-08.95		**0 280 122 001**
	09.88-08.90	AG	**0 280 120 412**
Air flow sensor, gasoline injection	09.88-08.95		**0 280 202 210**
			0 986 280 063
Speed sensor, ignition/injection	09.88-08.93		**0 261 210 030**
Pressure sensor, intake manifold, gasoline	09.88-08.89		**0 280 101 007**
Temperature sensor, coolant, injection system	09.88-08.95		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.88-08.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	09.88-08.95	L10,RAB	**0 265 001 207**
		L13,LAB	**0 265 001 208**
2.0 i [B]			**2,0 l 82 kW 20 NEJ 4 Zyl.**
Throttle valve sensor	09.95-02.02		**0 280 122 001**
Air mass meter, gasoline injection	09.95-02.02		**0 280 217 106**
Knock sensor	09.95-02.02		**0 261 231 006**
Temperature sensor, intake air, injection system	09.95-02.02		**0 280 130 073**
Temperature sensor, coolant, injection system	09.95-02.02		**0 280 130 107**
2.0 i [B]			**2,0 l 100 kW C 20 SEL 4 Zyl.**
Throttle valve sensor	05.97-09.02		**0 280 122 001**
2.0 i 4x4 [A]			**2,0 l 85 kW 20 NE, C 20 NE 4 Zyl.**
Throttle valve sensor	01.89-08.90		**0 280 120 316**
	09.90-08.95		**0 280 122 004**
	01.89-08.90	AG	**0 280 120 412**
Air flow sensor, gasoline injection	01.89-08.89		**0 280 202 210**
			0 986 280 063
Speed sensor, ignition/injection			
Fg.no. →P1999999,→P5999999, →P7999999	01.89-08.95		**0 261 210 030**
Pressure sensor, intake manifold, gasoline	01.89-08.89		**0 280 101 007**
Temperature sensor, coolant, injection system	01.89-08.95		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	01.89-08.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. N1000001→	01.89-08.95	AA,LAB	**0 265 006 487**
		AA,RAB	**0 265 006 486**
Fg.no. →M1999999	01.89-08.95	AA,LAB	**0 265 001 226**
2.0 i 4x4 [A]			**2,0 l 95 kW 20 SEH 4 Zyl.**
Throttle valve sensor	01.89-08.90		**0 280 120 316**
	09.90-08.95		**0 280 122 001**
	01.89-08.90	AG	**0 280 120 412**
Air flow sensor, gasoline injection	01.89-08.95		**0 280 202 210**
			0 986 280 063
Speed sensor, ignition/injection	01.89-08.93		**0 261 210 030**
Pressure sensor, intake manifold, gasoline	01.89-08.89		**0 280 101 007**
Temperature sensor, coolant, injection system	01.89-08.95		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	01.89-08.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. N1000001→	01.89-08.95	AA,LAB	**0 265 006 487**
		AA,RAB	**0 265 006 486**
Fg.no. →M1999999	01.89-08.95	AA,LAB	**0 265 001 226**
2.0 i 4x4 [A]			**2,0 l 150 kW C 20 LET Turbo 4 Zyl.**
Throttle valve sensor	09.92-08.95		**0 280 120 412**
Air mass meter, gasoline injection	09.92-08.95		**0 280 213 024**
			0 986 280 140
Speed sensor, ignition/injection	09.92-08.93		**0 261 210 030**
Knock sensor	09.92-08.95	MIL	**0 261 231 079**
		OHL	**0 261 231 006**
Temperature sensor, intake air, injection system	09.92-08.95		**0 280 130 039**
Temperature sensor, coolant, injection system	09.92-08.95		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.92-08.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. N1000001→	09.92-08.95	AA,LAB	**0 265 006 487**
		AA,RAB	**0 265 006 486**
Fg.no. →M1999999	09.92-08.95	AA,LAB	**0 265 001 226**
2.0 i 16V [A]			**2,0 l 100 kW X 20 XEV 4 Zyl.**
Throttle valve sensor	11.93-08.95		**0 280 122 001**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	11.93-08.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	11.93-08.95	L10,RAB	**0 265 001 207**
		L13,LAB	**0 265 001 208**
2.0 i 16V [A]			**2,0 l 110 kW C20XE (XEJ-LN); 20 XE / (XEJ) 4 Zyl.**
Throttle valve sensor			
Fg.no. →NV999999,→N1999999, →N5999999	09.92-08.95		**0 280 120 326**
Air mass meter, gasoline injection	09.92-08.95		**0 280 217 106**
Speed sensor, ignition/injection	09.92-08.93		**0 261 210 030**
Knock sensor	09.92-08.95	MIL	**0 261 231 079**
		OHL	**0 261 231 006**
Temperature sensor, intake air, injection system			
Fg.no. P1000001→,P5000001→, P7500001→	09.92-08.95		**0 280 130 073**
Temperature sensor, coolant, injection system	09.92-08.95		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.92-08.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. NV100001→NV999999, N1000001→N1999999, N5000001→N5999999	09.92-08.95	LAB	**0 265 003 094**
		RAB	**0 265 003 093**

Product			
Wheel speed sensor, rear			
Fg.no. →MV999999,→M1999999,	09.92-08.95	LAB	**0 265 001 233**
→M5999999		RAB	**0 265 001 232**
2.0 i 16V [B]	**2,0 l 100 kW X 20 XEV 4 Zyl.**		
Throttle valve sensor	09.95-09.02		**0 280 122 001**
2.0 Turbo, Turbo GTS [C]	**2,0 l 129 kW Z 20 NET 4 Zyl.**		
Speed sensor, ignition/injection	03.03→	FKW	**0 261 210 229**
2.2 DTI [B]	**2,2 l 92 kW Y 22 DTR 4 Zyl.**		
Air mass meter, diesel	09.00-09.03		**0 281 002 428**
Speed sensor, diesel	09.00-09.03		**0 281 002 138**
Pressure sensor, intake manifold, diesel	09.00-09.03		**0 281 002 438**
Temperature sensor, coolant, diesel	09.00-09.03		**0 281 002 169**
Pedal position sensor, diesel	09.00-09.03	LLE	**0 281 002 476**
2.2 DTI, DTI GTS [C]	**2,2 l 86-92 kW Y 22 DTR 4 Zyl.**		
Air mass meter, diesel	04.02-09.05		**0 281 002 479**
Speed sensor, diesel	04.02-09.05		**0 281 002 138**
Speed sensor, ignition/injection			
Mot.no. →17G23740	04.02-09.05	FKW	**0 281 002 138**
Mot.no. 17G23741→	04.02-09.05	FKW	**0 281 002 662**
Temperature sensor, coolant, diesel	04.02-09.05		**0 281 002 473**
2.2 i [B]	**2,2 l 106 kW C 22 SEL 4 Zyl.**		
Throttle valve sensor	06.00-09.02		**0 280 122 001**
2.5 i [A]	**2,5 l 125 kW C 25 XE V6 6 Zyl.**		
Throttle valve sensor	02.93-08.95		**0 280 122 001**
Phase sensor			
Fg.no. →S1035178	02.93-08.95		**0 232 103 001**
Knock sensor	02.93-08.95		**0 261 231 079**
Temperature sensor, intake air, injection system	02.93-08.95		**0 280 130 073**
Temperature sensor, coolant, injection system	02.93-08.95		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039,	02.93-08.95		**0 265 001 206**
→MV999999			
2.5 i V6 [B]	**2,5 l 125-143 kW X 25 XE 6 Zyl.**		
Throttle valve sensor			
Fg.no. W1000001→,W5000001→,	09.97-09.00		**0 280 122 014**
W7000001→,XL000001→			
Fg.no. →V1999999,→V5999999,	09.95-09.00		**0 280 122 001**
→V7999999			
Air mass meter, gasoline injection			
Fg.no. W1000001→,W5000001→,	09.95-09.00		**0 280 217 519**
W7000001→,XL000001→			
Fg.no. →V1999999,→V5999999,	09.95-09.00		**0 280 217 503**
→V7999999			
Knock sensor	09.95-09.00		**0 261 231 079**
Temperature sensor, intake air, injection system			
Fg.no. W1000001→	09.95-09.00		**0 280 130 092**
Fg.no. →V7999999	09.95-09.00		**0 280 130 073**
Temperature sensor, coolant, injection system			
Fg.no. W1000001→,W5000001→,	09.95-09.00		**0 280 130 093**
W7000001→,XL000001→			
Fg.no. →V7999999	09.95-09.00		**0 280 130 107**
2.6 V6 [B]	**2,6 l 130 kW Y 26 SE 6 Zyl.**		
Air mass meter, gasoline injection	09.00-09.02		**0 281 002 184**
Phase sensor	09.00-09.02		**0 232 103 025**
Speed sensor, ignition/injection	09.00-09.02		**0 261 210 206**
Knock sensor	09.00-09.02		**0 261 231 116**
Temperature sensor, coolant, injection system	09.00-09.02		**0 281 002 169**
2.8 GTS Turbo, Turbo [C]	**2,8 l 169/184-188 kW Z 28 NEL; Z 28 NET 6 Zyl.**		
Knock sensor	08.05→		**0 261 231 174**
Pressure sensor, intake manifold, gasoline	08.05→		**0 261 230 101**
Temperature sensor, coolant, injection system	08.05→		**0 280 130 122**
3.0 CDTI [C]	**3,0 l 130 kW Y 30 DT 6 Zyl.**		
Air mass meter, diesel	03.03-08.05		**0 281 002 605**

Product			
3.0 CDTI [C]	**3,0 l 135 kW Z 30 DT 6 Zyl.**		
Air mass meter, diesel	08.05→		**0 281 002 773**
3.0 CDTI GTS [C]	**3,0 l 130 kW Y 30 DT 6 Zyl.**		
Air mass meter, diesel	03.03-08.05		**0 281 002 605**
3.0 CDTI GTS [C]	**3,0 l 135 kW Z 30 DT 6 Zyl.**		
Air mass meter, diesel	08.05→		**0 281 002 773**
3.2 i, i GTS [C]	**3,2 l 155 kW Z 32 SE 6 Zyl.**		
Throttle valve assembly	08.02-09.05		**0 280 750 119**
Air mass meter, gasoline injection	08.02-09.05		**0 280 218 087**
Phase sensor	08.02-09.05	NOC	**0 232 103 025**
Speed sensor, ignition/injection	08.02-09.05	FKW	**0 261 210 206**
Knock sensor	08.02-09.05		**0 261 231 116**
Temperature sensor, coolant, injection system	08.02-09.05		**0 281 002 170**
2000 i 16V [A]	**2,0 l 110-115 kW C20XE (XEJ-LN); 20 XE / (XEJ) 4 Zyl.**		
Throttle valve sensor			
Fg.no. →NV999999,→N1999999,	09.89-08.92		**0 280 120 326**
→N5999999			
Air mass meter, gasoline injection	09.89-08.92		**0 280 212 015**
			0 986 280 113
Speed sensor, ignition/injection	09.89-08.92		**0 261 210 030**
Knock sensor	09.89-08.92	MIL	**0 261 231 079**
		OHL	**0 261 231 006**
Temperature sensor, intake air, injection system			
Fg.no. P1000001→,P5000001→,	09.89-08.92		**0 280 130 073**
P7500001→			
Temperature sensor, coolant, injection system	09.89-08.92		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039,	09.89-08.92		**0 265 001 206**
→MV999999			
Wheel speed sensor, rear			
Fg.no. NV100001→NV999999,	09.89-08.92	LAB	**0 265 003 094**
N1000001→N1999999,		RAB	**0 265 003 093**
N5000001→N5999999			
Fg.no. →MV999999,→M1999999,	09.89-08.92	LAB	**0 265 001 233**
→M5999999		RAB	**0 265 001 232**
2000 i 16V 4x4 [A]	**2,0 l 110 kW C20XE (XEJ-LN); 20 XE/ XEJ 4 Zyl.**		
Throttle valve sensor			
Fg.no. →NV999999,→N1999999,	09.89-08.92		**0 280 120 326**
→N5999999			
Air mass meter, gasoline injection	09.89-08.92		**0 280 212 015**
			0 986 280 113
Speed sensor, ignition/injection	09.89-08.92		**0 261 210 030**
Knock sensor	09.89-08.92	MIL	**0 261 231 079**
		OHL	**0 261 231 006**
Temperature sensor, intake air, injection system			
Fg.no. P1000001→,P5000001→,	09.89-08.92		**0 280 130 073**
P7500001→			
Temperature sensor, coolant, injection system	09.89-08.92		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039,	09.89-08.92		**0 265 001 206**
→MV999999			
Wheel speed sensor, rear			
Fg.no. N1000001→	09.89-08.92	AA,LAB	**0 265 006 487**
		AA,RAB	**0 265 006 486**
Fg.no. →M1999999	09.89-08.92	AA,LAB	**0 265 001 226**

Vectra Caravan

1.6 i [B]	**1,6 l 55 kW X 16 SZR 4 Zyl.**		
Temperature sensor, coolant, injection system			
Fg.no. →02GE3893,→V1999999,	09.96-09.00		**0 280 130 107**
→V5999999,→V7999999			

O

Product

◀ Vectra Caravan

Temperature sensor, coolant, injection system			
Fg.no. 02GE3894→,W1000001→, W5000001→,W7000001→	09.96-09.00		**0 280 130 093**
1.6 i [B]		**1,6 l 55 kW 16 LZ2 4 Zyl.**	
Temperature sensor, coolant, injection system	09.95-07.00		**0 280 130 107**
1.6 i 16V [B]		**1,6 l 74 kW X 16 XEL 4 Zyl.**	
Temperature sensor, coolant, injection system	11.96-07.02		**0 280 130 093**
1.8 i 16V [B]		**1,8 l 85 kW X 18 XE 4 Zyl.**	
Throttle valve sensor	09.95-09.00		**0 280 122 001**
1.9 CDTI [C]		**1,9 l 74 kW Z 19 DTL 4 Zyl.**	
Air mass meter, diesel	09.05→		**0 281 002 683**
Speed sensor, diesel	09.05→		**0 281 002 603**
Phase sensor	09.05→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	09.05→		**0 281 002 706**
Boost pressure sensor, Diesel	09.05→		**0 281 002 437**
1.9 CDTI [C]		**1,9 l 88 kW Z 19 DT 4 Zyl.**	
Air mass meter, diesel	04.04→		**0 281 002 683**
Speed sensor, diesel	04.04→		**0 281 002 603**
Phase sensor	04.04→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	04.04→		**0 281 002 534**
Boost pressure sensor, Diesel	04.04→		**0 281 002 437**
1.9 CDTI [C]		**1,9 l 110 kW Z 19 DTH 4 Zyl.**	
Air mass meter, diesel	04.04-03.07		**0 281 002 683**
High-pressure sensor (CR system)	04.04-03.07		**0 281 002 534**
Boost pressure sensor, Diesel	04.04-03.07		**0 281 002 437**
2.0 DI [B]		**2,0 l 60 kW X 20 DTL 16V Turbo 4 Zyl.**	
Air mass meter, diesel			
Fg.no. W1000001→	09.96-08.00		**0 281 002 180**
Fg.no. →V7999999	09.96-08.00		**0 281 002 139**
Speed sensor, diesel	09.96-08.00		**0 281 002 138**
Pressure sensor, intake manifold, diesel	09.96-08.00		**0 281 002 137**
Temperature sensor, intake air, injection system	09.96-08.00		**0 280 130 073**
Temperature sensor, coolant, diesel	09.96-08.00		**0 281 002 169**
Temperature sensor, intake air, diesel	09.96-08.00		**0 280 130 073**
Pedal position sensor, diesel			
Fg.no. W1285447→,W7154259→	09.96-08.00	LLE	**0 281 002 476**
Fg.no. →W1285446,→W5276825, →W7154258	09.96-08.00	LLE	**0 205 001 042**
		RLE	**0 205 001 039**
2.0 DTI [B]		**2,0 l 74 kW X 20 DTH 4 Zyl.**	
Air mass meter, diesel	09.97-08.03		**0 281 002 180**
Speed sensor, diesel	09.97-08.03		**0 281 002 138**
Pressure sensor, intake manifold, diesel	09.97-08.03	TW	**0 281 002 137**
			0 281 002 438
Temperature sensor, coolant, diesel	09.97-08.03		**0 281 002 169**
Pedal position sensor, diesel			
Fg.no. W1285447→,W7154259→	09.97-08.03	LLE	**0 281 002 476**
Fg.no. →W1285446,→W5276825, →W7154258	09.97-08.03	LLE	**0 205 001 042**
		RLE	**0 205 001 039**
2.0 DTI [B]		**2,0 l 74 kW Y 20 DTH 4 Zyl.**	
Air mass meter, diesel	09.00-09.03		**0 281 002 428**
Speed sensor, diesel	09.00-09.03		**0 281 002 138**
Pressure sensor, intake manifold, diesel	09.00-09.03		**0 281 002 438**
Temperature sensor, coolant, diesel	09.00-09.03		**0 281 002 169**
Pedal position sensor, diesel	09.00-09.03	LLE	**0 281 002 476**
2.0 DTI [C]		**2,0 l 74 kW Y 20 DTH 4 Zyl.**	
Air mass meter, diesel	09.03-09.05		**0 281 002 479**
Speed sensor, diesel	09.03-09.05		**0 281 002 138**
Speed sensor, ignition/injection			
Mot.no. →17G23740	09.03-09.05	FKW	**0 281 002 138**
Mot.no. 17G23741→	09.03-09.05	FKW	**0 281 002 662**
Temperature sensor, coolant, diesel	09.03-09.05		**0 281 002 473**

Product

2.0 i [B]		**2,0 l 82 kW 20 NEJ 4 Zyl.**	
Throttle valve sensor	09.95-02.02		**0 280 122 001**
Air mass meter, gasoline injection	09.95-02.02		**0 280 217 106**
Knock sensor	09.95-02.02		**0 261 231 006**
Temperature sensor, intake air, injection system	09.95-02.02		**0 280 130 073**
Temperature sensor, coolant, injection system	09.95-02.02		**0 280 130 107**
2.0 i [B]		**2,0 l 100 kW C 20 SEL 4 Zyl.**	
Throttle valve sensor	05.97-09.02		**0 280 122 001**
2.0 i 16V [B]		**2,0 l 100 kW X 20 XEV 4 Zyl.**	
Throttle valve sensor	09.95-09.02		**0 280 122 001**
2.0 Turbo [C]		**2,0 l 129 kW Z 20 NET 4 Zyl.**	
Speed sensor, ignition/injection	09.03→	FKW	**0 261 210 229**
2.2 DTI [B]		**2,2 l 92 kW Y 22 DTR 4 Zyl.**	
Air mass meter, diesel	09.00-09.03		**0 281 002 428**
Speed sensor, diesel	09.00-09.03		**0 281 002 138**
Pressure sensor, intake manifold, diesel	09.00-09.03		**0 281 002 438**
Temperature sensor, coolant, diesel	09.00-09.03		**0 281 002 169**
Pedal position sensor, diesel	09.00-09.03	LLE	**0 281 002 476**
2.2 DTI [C]		**2,2 l 86-92 kW Y 22 DTR 4 Zyl.**	
Air mass meter, diesel	09.03-09.05		**0 281 002 479**
Speed sensor, diesel	09.03-09.05		**0 281 002 138**
Speed sensor, ignition/injection			
Mot.no. →17G23740	09.03-09.05	FKW	**0 281 002 138**
Mot.no. 17G23741→	09.03-09.05	FKW	**0 281 002 662**
Temperature sensor, coolant, diesel	09.03-09.05		**0 281 002 473**
2.5 i V6 [B]		**2,5 l 125-143 kW X 25 XE 6 Zyl.**	
Throttle valve sensor			
Fg.no. W1000001→,W5000001→, W7000001→,XL000001→	09.97-06.00		**0 280 122 014**
Fg.no. →V1999999,→V5999999, →V7999999	09.96-06.00		**0 280 122 001**
Air mass meter, gasoline injection			
Fg.no. W1000001→,W5000001→, W7000001→,XL000001→	09.96-06.00		**0 280 217 519**
Fg.no. →V1999999,→V5999999, →V7999999	09.96-06.00		**0 280 217 503**
Knock sensor	09.96-06.00		**0 261 231 079**
Temperature sensor, intake air, injection system			
Fg.no. W1000001→	09.96-06.00		**0 280 130 092**
Fg.no. →V7999999	09.96-06.00		**0 280 130 073**
Temperature sensor, coolant, injection system			
Fg.no. W1000001→,W5000001→, W7000001→,XL000001→	09.96-06.00		**0 280 130 093**
Fg.no. →V7999999	09.96-06.00		**0 280 130 107**
2.6 V6 [B]		**2,6 l 130 kW Y 26 SE 6 Zyl.**	
Air mass meter, gasoline injection	09.00-09.02		**0 281 002 184**
Phase sensor	09.00-09.02		**0 232 103 025**
Speed sensor, ignition/injection	09.00-09.02		**0 261 210 206**
Knock sensor	09.00-09.02		**0 261 231 116**
Temperature sensor, coolant, injection system	09.00-09.02		**0 281 002 169**
2.8 Turbo [C]		**2,8 l 169/184-188 kW Z 28 NEL; Z 28 NET 6 Zyl.**	
Knock sensor	08.05→		**0 261 231 174**
Pressure sensor, intake manifold, gasoline	08.05→		**0 261 230 101**
Temperature sensor, coolant, injection system	08.05→		**0 280 130 122**
3.0 CDTI [C]		**3,0 l 130 kW Y 30 DT 6 Zyl.**	
Air mass meter, diesel	09.03-08.05		**0 281 002 605**
3.0 CDTI [C]		**3,0 l 135 kW Z 30 DT 6 Zyl.**	
Air mass meter, diesel	08.05→		**0 281 002 773**
3.2 i [C]		**3,2 l 155 kW Z 32 SE 6 Zyl.**	
Throttle valve assembly	09.03-09.05		**0 280 750 119**
Air mass meter, gasoline injection	09.03-09.05		**0 280 218 087**
Phase sensor	09.03-09.05	NOC	**0 232 103 025**

Product			
Speed sensor, ignition/injection	09.03-09.05	FKW	**0 261 210 206**
Knock sensor	09.03-09.05		**0 261 231 116**
Temperature sensor, coolant, injection system	09.03-09.05		**0 281 002 170**

Vivaro

1.9 CDTI			**1,9 l 60 kW F9Q-762 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 7V600001→,7Y000001→	03.01-10.06		**0 265 008 077**
1.9 DTI			**1,9 l 74 kW F9Q-760 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 7V600001→,7Y000001→	03.01-10.06		**0 265 008 077**
2.0 CDTI			**2,0 l 66/84 kW M9R-780 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 7V600001→,7Y000001→	08.06→		**0 265 008 077**
2.0 16V			**2,0 l 86-88 kW F4R-... 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 7V600001→,7Y000001→	03.01→		**0 265 008 077**
2.5 CDTI			**2,5 l 99/107 kW G9U-630; G9U-730 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 7V600001→,7Y000001→	09.02→		**0 265 008 077**

Zafira

1.6 i [A]			**1,6 l 74 kW X 16 XEL 4 Zyl.**
Temperature sensor, coolant, injection system	03.99-08.99		**0 281 002 169**
1.8 i [A]			**1,8 l 85 kW X 18 XE1 4 Zyl.**
Steering angle sensor, ESP (electronic stability program)			
Fg.no. →Y2999999,→YH999999	03.99-08.00		**0 265 005 433**
Pressure sensor, ESP, (electronic stability program)	03.99-08.00		**0 265 005 303**
1.8 i [A]			**1,8 l 92 kW Z 18 XE 4 Zyl.**
Yaw rate sensor, brake system	09.00-07.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.00-07.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-07.05		**0 265 005 303**
1.9 CDTI [B]			**1,9 l 74/88 kW Z 19 DT; Z 19 DTL 4 Zyl.**
Speed sensor, diesel	07.05→		**0 281 002 603**
Phase sensor	07.05→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	07.05→		**0 281 002 706**
Boost pressure sensor, Diesel	07.05→		**0 281 002 437**
1.9 CDTI [B]			**1,9 l 110 kW Z 19 DTH 4 Zyl.**
High-pressure sensor (CR system)	07.05→		**0 281 002 706**
Boost pressure sensor, Diesel	07.05→		**0 281 002 437**
2.0 DI [A]			**2,0 l 60 kW X 20 DTL Turbo 4 Zyl.**
Air mass meter, diesel			
Fg.no. →Y8999999,→YT999999	03.99-08.00		**0 281 002 180**
Fg.no. 12000001→,1T000001→	03.99-08.00		**0 281 002 428**
Speed sensor, diesel	03.99-08.00		**0 281 002 138**
Temperature sensor, coolant, diesel	03.99-08.00		**0 281 002 169**
Accelerator pedal module	03.99-08.00	LLE	**0 281 002 298**
		RLE	**0 281 002 299**
2.0 DTI [A]			**2,0 l 74 kW Y 20 DTH Turbo 4 Zyl.**
Air mass meter, diesel			
Fg.no. →Y2999999,→Y5999999, →Y6999999,→Y8999999,→YH999999	04.99-07.05		**0 281 002 180**
Fg.no. 12000001→22999999, 15000001→25999999, 16000001→26999999, 18000001→28999999, 1H000001→2H999999	04.99-07.05		**0 281 002 428**

Product			
Air mass meter, diesel			
Fg.no. 32000001→,35000001→, 36000001→,38000001→,3H000001→, 3H000001→	04.99-07.05		**0 281 002 478**
Speed sensor, diesel	04.99-07.05		**0 281 002 138**
Pressure sensor, intake manifold, diesel			
Fg.no. →Y2999999,→Y5999999,→Y6999999, →Y8999999,→YB999999,→YH999999	04.99-07.05		**0 281 002 137**
Fg.no. 12000001→22999999, 15000001→25999999, 16000001→26999999, 18000001→28999999, 1B000001→2B999999, 1H000001→2H999999	04.99-07.05		**0 281 002 438**
Fg.no. 32000001→,35000001→, 36000001→,38000001→,3B000001→, 3H000001→	04.99-07.05		**0 281 002 437**
Temperature sensor, coolant, diesel	04.99-07.05		**0 281 002 169**
Accelerator pedal module	04.99-07.05	LLE	**0 281 002 298**
		RLE	**0 281 002 299**
2.0 i Turbo [B]			**2,0 l 147 kW Z 20 LER 4 Zyl.**
Air mass meter, gasoline injection	07.05→		**0 280 218 142**
Phase sensor	07.05→	NOC	**0 232 103 015**
Speed sensor, ignition/injection	07.05→	FKW	**0 261 210 150**
Knock sensor	07.05→		**0 261 231 181**
Pressure sensor, intake manifold, gasoline	07.05→		**0 281 002 137**
Temperature sensor, coolant, injection system	07.05→		**0 281 002 169**
2.0 i Turbo [B]			**2,0 l 177 kW Z 20 LEH 4 Zyl.**
Air mass meter, gasoline injection	01.06→		**0 280 218 211**
Phase sensor	01.06→	NOC	**0 232 103 015**
Speed sensor, ignition/injection	01.06→	FKW	**0 261 210 150**
Knock sensor	01.06→		**0 261 231 181**
Pressure sensor, intake manifold, gasoline	01.06→		**0 281 002 137**
Temperature sensor, coolant, injection system	01.06→		**0 281 002 169**
2.0 Turbo [A]			**2,0 l 141-147 kW Z 20 LET 4 Zyl.**
Air mass meter, gasoline injection	09.01-07.05		**0 280 218 051**
			0 986 280 231
Phase sensor	09.01-07.05	NOC	**0 232 103 015**
Speed sensor, ignition/injection	09.01-07.05	FKW	**0 261 210 150**
Pressure sensor, intake manifold, gasoline	09.01-07.05		**0 261 230 009**
Temperature sensor, coolant, injection system	09.01-07.05		**0 281 002 169**
Yaw rate sensor, brake system	09.01-07.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.01-07.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.01-07.05		**0 265 005 303**
2.2 [A]			**2,2 l 108 kW Z 22 SE 4 Zyl.**
Yaw rate sensor, brake system	09.00-07.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.00-07.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-07.05		**0 265 005 303**
2.2 DTI [A]			**2,2 l 92 kW Y 22 DTR 4 Zyl.**
Air flow sensor, diesel	03.02-07.05		**0 281 002 478**
Speed sensor, diesel	03.02-07.05	FKW	**0 281 002 138**
Boost pressure sensor, Diesel	03.02-07.05		**0 281 002 437**
Temperature sensor, coolant, diesel	03.02-07.05		**0 281 002 170**
Yaw rate sensor, brake system	03.02-07.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	03.02-07.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	03.02-07.05		**0 265 005 303**

Product

PEUGEOT

Boxer

1.9 D [U3]			**1,9 l 50/51 kW DJY; D9B 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 15445358→	02.94-04.00		**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 15445358→	02.94-02.02	LAB	**0 265 006 405**
		RAB	**0 265 006 406**
1.9 D Turbo [U3]			**1,9 l 66/68 kW DHX; D8C 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 15445358→	02.94-04.00		**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 15445358→	02.94-02.02	LAB	**0 265 006 405**
		RAB	**0 265 006 406**
2.0 [U3]			**2,0 l 79 kW R5B 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 15445358→	02.94-04.00		**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 15445358→	02.94-02.02	LAB	**0 265 006 405**
		RAB	**0 265 006 406**
2.0 HDi [U3]			**2,0 l 62 kW RHV 4 Zyl.**
High-pressure sensor (CR system)	09.01-02.02		**0 281 002 283**
Wheel speed sensor, rear			
Fg.no. 15445358→	09.01-02.02	LAB	**0 265 006 405**
		RAB	**0 265 006 406**
2.0 HDi [U5]			**2,0 l 62 kW RHV 4 Zyl.**
High-pressure sensor (CR system)	02.02→		**0 281 002 283**
Yaw rate sensor, brake system	02.02→		**0 265 005 127**
2.0 i [U3]			**2,0 l 80 kW RFW 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 15445358→	02.94-04.00		**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 15445358→	02.94-02.02	LAB	**0 265 006 405**
		RAB	**0 265 006 406**
2.0 i [U5]			**2,0 l 80 kW RFL 4 Zyl.**
Yaw rate sensor, brake system	02.02→		**0 265 005 127**
2.2 HDi [U5]			**2,2 l 77 kW 4HY 4 Zyl.**
High-pressure sensor (CR system)	02.02→		**0 281 002 283**
Yaw rate sensor, brake system	02.02→		**0 265 005 127**
2.5 D [U3]			**2,5 l 62/63 kW T9A; 8140 67 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 15445358→	02.94-04.00		**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 15445358→	02.94-02.02	LAB	**0 265 006 405**
		RAB	**0 265 006 406**
2.5 D Turbo [U3]			**2,5 l 76 kW THZ; T8A 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 15445358→	02.94-04.00		**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 15445358→	02.94-02.02	LAB	**0 265 006 405**
		RAB	**0 265 006 406**
2.5 TDi [U3]			**2,5 l 79 kW THX 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 15445358→	10.96-04.00		**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 15445358→	10.96-02.02	LAB	**0 265 006 405**
		RAB	**0 265 006 406**
2.8 D [U3]			**2,8 l 64 kW 8140 63 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 15445358→	01.99-04.00		**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 15445358→	01.99-02.02	LAB	**0 265 006 405**
		RAB	**0 265 006 406**
2.8 D Turbo [U3]			**2,8 l 90 kW 8140 43 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 15445358→	10.99-04.00		**0 265 006 427**
Wheel speed sensor, rear			
Fg.no. 15445358→	10.99-02.02	LAB	**0 265 006 405**
		RAB	**0 265 006 406**
2.8 D Turbo [U5]			**2,8 l 90 kW 8140 43 4 Zyl.**
Yaw rate sensor, brake system	02.02→		**0 265 005 127**
2.8 HDi [U3]			**2,8 l 94 kW 8140 43s 4 Zyl.**
Wheel speed sensor, rear			
Fg.no. 15445358→	09.00-02.02	LAB	**0 265 006 405**
		RAB	**0 265 006 406**
2.8 HDi [U5]			**2,8 l 94/107 kW 8140 43s 4 Zyl.**
Yaw rate sensor, brake system	02.02→		**0 265 005 127**

Expert

1.6 HDi [G9]			**1,6 l 66 kW 9HU 4 Zyl.**
Yaw rate sensor, brake system	02.07→		**0 265 005 606**
Wheel speed sensor, front	02.07→		**0 265 007 790**
Wheel speed sensor, rear	02.07→		**0 265 007 791**
1.6 i [U64]			**1,6 l 58 kW 220 A2.000 4 Zyl.**
Temperature sensor, coolant, injection system	09.95→		**0 280 130 026**
Wheel speed sensor, front			
Org.no. 7481→9050	06.97-08.01		**0 265 006 388**
Org.no. 9051→	09.01→		**0 265 006 730**
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97		**0 265 006 426**
Org.no. 7602→9050	10.97-08.01		**0 265 006 504**
Org.no. 9051→	09.01→		**0 265 006 731**
1.8 i [U64]			**1,8 l 70 kW L6B 4 Zyl.**
Wheel speed sensor, front			
Org.no. 7481→9050	06.97-08.01		**0 265 006 388**
Org.no. 9051→	09.01→		**0 265 006 730**
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97		**0 265 006 426**
Org.no. 7602→9050	10.97-08.01		**0 265 006 504**
Org.no. 9051→	09.01→		**0 265 006 731**
1.9 D [U64]			**1,9 l 51 kW D9B 4 Zyl.**
Wheel speed sensor, front			
Org.no. 7481→9050	06.97-08.01		**0 265 006 388**
Org.no. 9051→	09.01→		**0 265 006 730**
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97		**0 265 006 426**
Org.no. 7602→9050	10.97-08.01		**0 265 006 504**
Org.no. 9051→	09.01→		**0 265 006 731**
1.9 D [U64]			**1,9 l 51 kW WJZ 4 Zyl.**
Wheel speed sensor, front	06.98-08.01		**0 265 006 388**
Wheel speed sensor, rear	06.98-08.01		**0 265 006 504**
1.9 D [U64]			**1,9 l 52 kW WJY 4 Zyl.**
Wheel speed sensor, front	09.01→		**0 265 006 730**
Wheel speed sensor, rear	09.01→		**0 265 006 731**
1.9 D Turbo [U64]			**1,9 l 66-68 kW DHX; D8B 4 Zyl.**
Wheel speed sensor, front			
Org.no. 7481→9050	06.97-08.01		**0 265 006 388**
Org.no. 9051→	09.01→		**0 265 006 730**
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97		**0 265 006 426**
Org.no. 7602→9050	10.97-08.01		**0 265 006 504**
Org.no. 9051→	09.01→		**0 265 006 731**

Product			
2.0 HDi [G9]			**2,0 l 88/100 kW RHK; RHR 4 Zyl.**
Yaw rate sensor, brake system	02.07→		**0 265 005 606**
Wheel speed sensor, front	02.07→		**0 265 007 790**
Wheel speed sensor, rear	02.07→		**0 265 007 791**
2.0 HDi [U64]			**2,0 l 70/80 kW RHX; RHZ 4 Zyl.**
High-pressure sensor (CR system)	10.99→	BO	**0 281 002 283**
Wheel speed sensor, front			
Org.no. →9050	10.99-08.01		**0 265 006 388**
Org.no. 9051→	09.01→		**0 265 006 730**
Wheel speed sensor, rear			
Org.no. →9050	10.99-08.01		**0 265 006 504**
Org.no. 9051→	09.01→		**0 265 006 731**
2.0 HDi [U64]			**2,0 l 81 kW RHW 4 Zyl.**
High-pressure sensor (CR system)	06.00→		**0 281 002 283**
Wheel speed sensor, front			
Org.no. →9050	06.00-08.01		**0 265 006 388**
Org.no. 9051→	09.01→		**0 265 006 730**
Wheel speed sensor, rear			
Org.no. →9050	06.00-08.01		**0 265 006 504**
Org.no. 9051→	09.01→		**0 265 006 731**
2.0 i 16V [G9]			**2,0 l 103 kW RFJ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	02.07→		**0 261 230 043**
Yaw rate sensor, brake system	02.07→		**0 265 005 606**
Wheel speed sensor, front	02.07→		**0 265 007 790**
Wheel speed sensor, rear	02.07→		**0 265 007 791**
2.0 i 16V [U64]			**2,0 l 100 kW RFN 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.00→		**0 261 230 057**
Wheel speed sensor, front			
Org.no. →9050	03.00-08.01		**0 265 006 388**
Org.no. 9051→	09.01→		**0 265 006 730**
Wheel speed sensor, rear			
Org.no. →9050	03.00-08.01		**0 265 006 504**
Org.no. 9051→	09.01→		**0 265 006 731**

Partner

Electrique [M4]24 kW SA18 0 Zyl.			
Wheel speed sensor, front	01.98-08.02		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	01.98-05.01		**0 265 006 209**
Org.no. 8939→	06.01-08.02		**0 265 006 659**
1.1 i [M4]			**1,1 l 44 kW HDY; HDZ 4 Zyl.**
Temperature sensor, coolant, injection system	07.96-08.02		**0 280 130 084**
Wheel speed sensor, front	07.96-08.02		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	07.96-05.01		**0 265 006 209**
Org.no. 8939→	06.01-08.02		**0 265 006 659**
1.1 i [M4]			**1,1 l 44 kW HFX 4 Zyl.**
Pressure sensor, intake manifold, gasoline	09.00-08.02		**0 261 230 043**
Wheel speed sensor, front	09.00-08.02		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	09.00-05.01		**0 265 006 209**
Org.no. 8939→	06.01-08.02		**0 265 006 659**
1.1 i [M5]			**1,1 l 44 kW HFX 4 Zyl.**
Knock sensor	09.02→		**0 261 231 128**
Pressure sensor, intake manifold, gasoline	09.02→		**0 261 230 043**
Wheel speed sensor, front			
Org.no. →10220	09.02-11.04		**0 265 006 200**
Org.no. 10221→	12.04→		**0 265 007 666**
Wheel speed sensor, rear			
Org.no. →9582	09.02-02.03		**0 265 006 659**
Org.no. 9583→10220	03.03-11.04		**0 265 006 793**
Org.no. 10221→	12.04→	LAB	**0 265 007 668**
Wheel speed sensor, rear			
Org.no. 10221→10478	12.04-07.05	RAB	**0 265 007 667**
Org.no. 10479→	08.05→	RAB	**0 265 007 883**
1.4 [M4]			**1,4 l 51-52 kW K5A 4 Zyl.**
Wheel speed sensor, front	11.96-08.02		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	11.96-05.01		**0 265 006 209**
Org.no. 8939→	06.01-08.02		**0 265 006 659**
1.4 i [M4]			**1,4 l 55 kW KFW 4 Zyl.**
Pressure sensor, intake manifold, gasoline	09.00-08.02		**0 261 230 043**
Wheel speed sensor, front	09.00-08.02		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	09.00-05.01		**0 265 006 209**
Org.no. 8939→	06.01-08.02		**0 265 006 659**
1.4 i [M4]			**1,4 l 55 kW KFX 4 Zyl.**
Knock sensor	04.98-08.02	N14	**0 261 231 128**
Pressure sensor, intake manifold, gasoline	07.96-08.02	BGB	**0 261 230 057**
Org.no. →8056	07.96-12.98		**0 261 230 012**
Org.no. 8057→	01.99-08.02		**0 261 230 057**
Wheel speed sensor, front	07.96-08.02		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	07.96-05.01		**0 265 006 209**
Org.no. 8939→	06.01-08.02		**0 265 006 659**
1.4 i [M4]			**1,4 l 55 kW K6C 4 Zyl.**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	06.98-12.98		**0 261 230 012**
Org.no. 8057→	01.99-08.02		**0 261 230 057**
Wheel speed sensor, front	06.98-08.02		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	06.98-05.01		**0 265 006 209**
Org.no. 8939→	06.01-08.02		**0 265 006 659**
1.4 i [M5]			**1,4 l 55 kW KFW 4 Zyl.**
Knock sensor	09.02→		**0 261 231 128**
Pressure sensor, intake manifold, gasoline	09.02→		**0 261 230 043**
Wheel speed sensor, front			
Org.no. →10220	09.02-11.04		**0 265 006 200**
Org.no. 10221→	12.04→		**0 265 007 666**
Wheel speed sensor, rear			
Org.no. →9582	09.02-02.03		**0 265 006 659**
Org.no. 9583→10220	03.03-11.04		**0 265 006 793**
Org.no. 10221→	12.04→	LAB	**0 265 007 668**
Org.no. 10221→10478	12.04-07.05	RAB	**0 265 007 667**
Org.no. 10479→	08.05→	RAB	**0 265 007 883**
1.6 HDi [M5]			**1,6 l 55 kW 9HW 4 Zyl.**
Wheel speed sensor, front	09.05→		**0 265 007 666**
1.6 HDi [M5]			**1,6 l 66 kW 9HX 4 Zyl.**
Yaw rate sensor, brake system	09.05→		**0 265 005 290**
Wheel speed sensor, front	09.05→		**0 265 007 666**
Wheel speed sensor, rear	09.05→	LAB	**0 265 007 668**
		RAB	**0 265 007 883**
1.6 i 16V [M4]			**1,6 l 80 kW NFU 4 Zyl.**
Throttle valve assembly	09.00-08.02		**0 280 750 085**
Knock sensor	09.00-08.02		**0 261 231 128**
Pressure sensor, intake manifold, gasoline	09.00-08.02		**0 261 230 043**
Wheel speed sensor, front	09.00-08.02		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	09.00-05.01		**0 265 006 209**
Org.no. 8939→	06.01-08.02		**0 265 006 659**
1.6 i 16V [M5]			**1,6 l 80 kW NFU 4 Zyl.**
Throttle valve assembly	09.02→		**0 280 750 085**
Knock sensor	09.02→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	09.02→		**0 261 230 043**
Yaw rate sensor, brake system	09.02→		**0 265 005 290**

P

Product

◀ Partner

Wheel speed sensor, front			
Org.no. →10220	09.02-11.04		**0 265 006 200**
Org.no. 10221→	12.04→		**0 265 007 666**
Wheel speed sensor, rear			
Org.no. →9582	09.02-02.03	TBR	**0 265 006 659**
Org.no. →10220	09.02-11.04	SBR	**0 265 006 732**
Org.no. 9583→10220	03.03-11.04	TBR	**0 265 006 793**
Org.no. 10221→	12.04→	LAB	**0 265 007 668**
Org.no. 10221→10478	12.04-07.05	RAB	**0 265 007 667**
Org.no. 10479→	08.05→	RAB	**0 265 007 883**
1.8 D [M4]			**1,8 l 43-44 kW A9A 4 Zyl.**
Wheel speed sensor, front	07.96-08.02		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	07.96-05.01		**0 265 006 209**
Org.no. 8939→	06.01-08.02		**0 265 006 659**
1.8 i			**1,8 l 66 kW XU7JB 4 Zyl.**
Temperature sensor, coolant, injection system	10.99→		**0 280 130 084**
1.8 i [M4]			**1,8 l 66 kW LFX 4 Zyl.**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	03.97-12.98		**0 261 230 012**
Org.no. 8057→	01.99-08.02		**0 261 230 057**
Wheel speed sensor, front	03.97-08.02		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	03.97-05.01		**0 265 006 209**
Org.no. 8939→	06.01-08.02		**0 265 006 659**
1.9 D [M4]			**1,9 l 50/51/52 kW DJY; D9B; WJY; WJZ 4 Zyl.**
Wheel speed sensor, front	07.96-08.02		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	07.96-05.01		**0 265 006 209**
Org.no. 8939→	06.01-08.02		**0 265 006 659**
1.9 D [M5]			**1,9 l 52 kW WJY 4 Zyl.**
Wheel speed sensor, front			
Org.no. →10220	09.02-11.04		**0 265 006 200**
Org.no. 10221→	12.04→		**0 265 007 666**
Wheel speed sensor, rear			
Org.no. →9582	09.02-02.03		**0 265 006 659**
Org.no. 9583→10220	03.03-11.04		**0 265 006 793**
Org.no. 10221→	12.04→	LAB	**0 265 007 668**
Org.no. 10221→10478	12.04-07.05	RAB	**0 265 007 667**
Org.no. 10479→	08.05→	RAB	**0 265 007 883**
2.0 HDi [M4]			**2,0 l 66 kW RHY 4 Zyl.**
High-pressure sensor (CR system)	12.99-08.02	BO	**0 281 002 283**
Wheel speed sensor, front	12.99-08.02		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	12.99-05.01		**0 265 006 209**
Org.no. 8939→	06.01-08.02		**0 265 006 659**
2.0 HDi [M5]			**2,0 l 66 kW RHY 4 Zyl.**
High-pressure sensor (CR system)	09.02→		**0 281 002 283**
Yaw rate sensor, brake system	09.02→		**0 265 005 290**
Wheel speed sensor, front			
Org.no. →10220	09.02-11.04		**0 265 006 200**
Org.no. 10221→	12.04→		**0 265 007 666**
Wheel speed sensor, rear			
Org.no. →9582	09.02-02.03	TBR	**0 265 006 659**
Org.no. →10220	09.02-11.04	SBR	**0 265 006 732**
Org.no. 9583→10220	03.03-11.04	TBR	**0 265 006 793**
Org.no. 10221→	12.04→	LAB	**0 265 007 668**
Org.no. 10221→10478	12.04-07.05	RAB	**0 265 007 667**
Org.no. 10479→	08.05→	RAB	**0 265 007 883**

Product

2.0 HDI			**2,0 l 66 kW DW10TD 4 Zyl.**
High-pressure sensor (CR system)	10.00→		**0 281 002 283**
Wheel speed sensor, front	10.00→	BO,LAB	**0 265 006 201**
		BO,RAB	**0 265 006 200**
Wheel speed sensor, rear	10.00→	LIM,SBR	**0 265 006 202**

Ranch

1.4 i [M4]			**1,4 l 55 kW KFX 4 Zyl.**
Knock sensor	04.98→	N14	**0 261 231 128**
Pressure sensor, intake manifold, gasoline	07.97→	BGB	**0 261 230 057**
Org.no. →8056	07.97-12.98		**0 261 230 012**
Org.no. 8057→	01.99→		**0 261 230 057**
Wheel speed sensor, front	07.97→		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	07.97-05.01		**0 265 006 209**
Org.no. 8939→	06.01→		**0 265 006 659**
1.9 D [M4]			**1,9 l 51 kW D9B 4 Zyl.**
Wheel speed sensor, front	07.97-10.98		**0 265 006 200**
Wheel speed sensor, rear	07.97-10.98		**0 265 006 209**
1.9 D [M4]			**1,9 l 51 kW WJZ 4 Zyl.**
Wheel speed sensor, front	11.98→		**0 265 006 200**
Wheel speed sensor, rear			
Org.no. →8938	11.98-05.01		**0 265 006 209**
Org.no. 8939→	06.01→		**0 265 006 659**

106

1.0 i [S1]			**1,0 l 33/37 kW CDY; CDZ 4 Zyl.**
Temperature sensor, coolant, injection system	07.92-04.96		**0 280 130 026**
1.1 i [S1]			**1,1 l 44 kW HDZ 4 Zyl.**
Temperature sensor, coolant, injection system	09.91-12.93		**0 280 130 026**
1.1 i [S2]			**1,1 l 44 kW HFX 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.00-05.05		**0 261 230 043**
1.3 i [S1]			**1,3 l 72-74 kW MFZ 4 Zyl.**
Knock sensor	10.93-04.96		**0 261 231 045**
Temperature sensor, coolant, injection system	10.93-04.96		**0 280 130 026**
1.4 i [S1]			**1,4 l 55 kW KDX 4 Zyl.**
Temperature sensor, coolant, injection system	12.92-04.96		**0 280 130 026**
1.4 i [S1]			**1,4 l 69/72 kW KFZ; K6B 4 Zyl.**
Throttle valve sensor	09.91-04.96		**0 280 122 001**
Temperature sensor, intake air, injection system	09.91-04.96		**0 280 130 039**
1.4 i [S2]			**1,4 l 55 kW KFW 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.00-05.05		**0 261 230 043**
1.4 i [S2]			**1,4 l 55 kW KFX 4 Zyl.**
Knock sensor	05.96-05.05	NL4	**0 261 231 128**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	05.96-12.98		**0 261 230 012**
Org.no. 8057→	01.99-05.05		**0 261 230 057**
1.6 i [S1]			**1,6 l 65-66 kW NFZ 4 Zyl.**
Throttle valve sensor	06.93-04.96	AG	**0 280 122 011**
	06.93-01.95	GS	**0 280 122 001**
	02.95-04.96	GS	**0 280 122 003**
Pressure sensor, intake manifold, gasoline	06.93-04.96		**0 261 230 004**
Temperature sensor, intake air, injection system	06.93-04.96		**0 280 130 039**
Temperature sensor, coolant, injection system	06.93-04.96		**0 280 130 026**
1.6 i [S1]			**1,6 l 76-77 kW NFY 4 Zyl.**
Throttle valve sensor	06.93-04.96		**0 280 122 003**
Knock sensor	06.93-04.96		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	06.93-04.96		**0 261 230 004**
Temperature sensor, intake air, injection system	06.93-04.96		**0 280 130 039**
Temperature sensor, coolant, injection system	06.93-04.96		**0 280 130 026**

Product

1.6 i [S2]			**1,6 l 65-66 kW NFZ 4 Zyl.**
Throttle valve sensor	05.96-05.05	AG	**0 280 122 011**
		GS	**0 280 122 003**
Pressure sensor, intake manifold, gasoline	05.96-05.05		**0 261 230 004**
Temperature sensor, intake air, injection system	05.96-05.05		**0 280 130 039**
1.6 i [S2]			**1,6 l 74-77 kW NFW; NFY 4 Zyl.**
Throttle valve sensor	05.96-05.05		**0 280 122 003**
Temperature sensor, intake air, injection system	05.96-05.05		**0 280 130 039**
1.6 i 16S [S2]			**1,6 l 87-88 kW NFX 4 Zyl.**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	05.96-12.98		**0 261 230 012**
Org.no. 8057→	01.99-05.05		**0 261 230 057**

107

1.0 i [B0]			**1,0 l 50 kW CFA 3 Zyl.**
Wheel speed sensor, front	06.05→		**0 265 007 687**
Wheel speed sensor, rear	06.05→		**0 265 007 688**
1.4 HDi [B0]			**1,4 l 40 kW 8HT 4 Zyl.**
Wheel speed sensor, front	06.05→		**0 265 007 687**
Wheel speed sensor, rear	06.05→		**0 265 007 688**

205

1.0 i			**1,0 l 33-37 kW CDZ,CDY 4 Zyl.**
Temperature sensor, coolant, injection system	07.92-09.98		**0 280 130 026**
1.1 i			**1,1 l 44 kW HDZ, HDY <TU1M> 4 Zyl.**
Temperature sensor, coolant, injection system	07.89-09.98		**0 280 130 026**
1.4 i 1,4 l 55-58 kW KDX <TU3MC Kat.(Gußmot.)>; KDY/KDZ <TU3M Kat.> 4 Zyl.			
Temperature sensor, coolant, injection system	07.88-09.98		**0 280 130 026**
1.6 i			**1,6 l 65 kW BDY <XU5M Kat.> 4 Zyl.**
Temperature sensor, intake air, injection system	11.90-09.98		**0 280 130 039**
1.6 i			**1,6 l 76 kW 180A,180Z 4 Zyl.**
Throttle valve sensor	10.88-10.90		**0 280 120 310**
Air flow sensor, gasoline injection	10.88-10.90		**0 280 202 056**
			0 986 280 028
Temperature sensor, coolant, injection system	10.88-10.90		**0 280 130 026**
Relay, Jetronic	10.88-10.90		**0 280 230 006**
1.6 i			**1,6 l 76 kW 180A,180Z, B6A,B6B 4 Zyl.**
Throttle valve sensor	10.83-10.87		**0 280 120 310**
Air flow sensor, gasoline injection	10.83-10.87		**0 280 202 056**
			0 986 280 028
Temperature sensor, coolant, injection system	10.83-10.87		**0 280 130 026**
Relay, Jetronic CH,S	10.83-10.87		**0 280 230 006**
1.6 i			**1,6 l 83 kW B6D <XU5JA> 4 Zyl.**
Throttle valve sensor	10.86-10.90		**0 280 120 327**
Air flow sensor, gasoline injection	10.85-10.90		**0 280 202 056**
			0 986 280 028
Temperature sensor, coolant, injection system	10.85-10.90		**0 280 130 026**
Relay, Jetronic	10.85-10.90		**0 280 230 006**
1.6 i			**1,6 l 83 kW B6E <XU5JA> 4 Zyl.**
Throttle valve sensor	11.90-09.98		**0 280 120 327**
Air flow sensor, gasoline injection	11.90-09.98		**0 280 202 056**
			0 986 280 028
1.9 i			**1,9 l 75 kW DFZ 4 Zyl.**
Throttle valve sensor	10.86-10.94		**0 280 120 327**
Air flow sensor, gasoline injection	10.86-10.94		**0 280 202 097**
			0 986 280 070
Temperature sensor, coolant, injection system	10.86-10.94		**0 280 130 026**
Relay, Jetronic	10.86-10.94		**0 280 230 006**

Product

1.9 i			**1,9 l 88 kW DFY,DKZ <XU9JAZ Kat.> 4 Zyl.**
Throttle valve sensor	10.87-10.94		**0 280 120 327**
Speed sensor, ignition/injection	10.87-10.94		**0 261 210 043**
Temperature sensor, coolant, injection system	10.87-10.94		**0 280 130 026**
1.9 i			**1,9 l 90-94 kW D6A; D6B 4 Zyl.**
Throttle valve sensor	10.86-09.98		**0 280 120 327**
Air flow sensor, gasoline injection	10.86-09.98		**0 280 202 109**
			0 986 280 013
Temperature sensor, coolant, injection system	10.86-09.98		**0 280 130 026**
Relay, Jetronic	10.86-09.98		**0 280 230 006**

206

1.1 i [T1]			**1,1 l 44 kW HFX 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.00→		**0 261 230 043**
Accelerator pedal module			
Org.no. →9932	03.00-02.04	LLE,PAK	**0 280 752 237**
1.1 i [T1]			**1,1 l 44 kW HFY; HFZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline			
Org.no. →8028	06.98-11.98		**0 261 230 012**
Org.no. 8029→	12.98→		**0 261 230 057**
Accelerator pedal module			
Org.no. →9932	06.98-02.04	LLE,PAK	**0 280 752 237**
1.4 HDi [T1]			**1,4 l 50 kW 8HX/ 8HZ 4 Zyl.**
High-pressure sensor (CR system)	09.01→		**0 281 002 283**
Accelerator pedal module			
Org.no. →9932	09.01-02.04	LLE,PAK	**0 280 752 237**
1.4 i			**1,4 l 55 kW TU3JP 4 Zyl.**
Pressure sensor, intake manifold, gasoline	02.04-12.05		**0 261 230 043**
1.4 i [T1]			**1,4 l 55 kW KFW 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.00→		**0 261 230 043**
Accelerator pedal module			
Org.no. →9932	03.00-02.04	LLE,PAK	**0 280 752 237**
1.4 i [T1]			**1,4 l 55 kW KFX 4 Zyl.**
Knock sensor	06.98→	IF4	**0 261 231 128**
Pressure sensor, intake manifold, gasoline			
Org.no. →8028	06.98-11.98		**0 261 230 012**
Org.no. 8029→	12.98→		**0 261 230 057**
Accelerator pedal module			
Org.no. →9932	06.98-02.04	LLE,PAK	**0 280 752 237**
1.4 i [T1]			**1,4 l 55 kW K6C/ K6D 4 Zyl.**
Pressure sensor, intake manifold, gasoline			
Org.no. →8028	06.98-11.98		**0 261 230 012**
Org.no. 8029→	12.98→		**0 261 230 057**
Accelerator pedal module			
Org.no. →9932	06.98-02.04	LLE,PAK	**0 280 752 237**
1.4 i 16V [T1]			**1,4 l 65 kW KFU 4 Zyl.**
Knock sensor	10.03→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	10.03→		**0 261 230 043**
Accelerator pedal module			
Org.no. →9932	10.03-02.04	LLE,PAK	**0 280 752 237**
1.6 i			**1,6 l 65 kW NFZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.99-10.03		**0 261 230 034**
1.6 i [T1]			**1,6 l 66 kW NFZ 4 Zyl.**
Knock sensor	06.98→		**0 261 231 128**
Pressure sensor, intake manifold, gasoline			
Org.no. →8028	06.98-11.98		**0 261 230 012**
Org.no. 8029→	12.98→		**0 261 230 057**
Accelerator pedal module			
Org.no. →9932	06.98-02.04	LLE,PAK	**0 280 752 237**

P

Product			
◀ 206			
1.6 i 16V			**1,6 l 79 kW TU5JP4 4 Zyl.**
Throttle valve assembly	06.01-04.05		**0 280 750 085**
Pressure sensor, intake manifold, gasoline	06.01-04.05		**0 261 230 043**
Accelerator pedal module	06.01-04.05		**0 280 755 026**
1.6 i 16V [T1]			**1,6 l 80 kW NFU 4 Zyl.**
Throttle valve assembly	03.00→		**0 280 750 085**
Knock sensor			
Org.no. 9457→	10.02→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	03.00→		**0 261 230 043**
Accelerator pedal module			
Org.no. →9932	03.00-02.04	LLE,PAK	**0 280 752 237**
1.9 D [T1]			**1,9 l 51/52 kW WJY; WJZ 4 Zyl.**
Accelerator pedal module			
Org.no. →9932	06.98-02.04	LLE,PAK	**0 280 752 237**
2.0 HDi [T1]			**2,0 l 66 kW RHY 4 Zyl.**
High-pressure sensor (CR system)	05.99→	BO	**0 281 002 283**
Accelerator pedal module			
Org.no. →9932	04.99-02.04	LLE,PAK	**0 280 752 237**
2.0 i RC [T1]			**2,0 l 130 kW RFK 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.03→		**0 261 230 043**
Accelerator pedal module			
Org.no. →9932	03.03-02.04	LLE,PAK	**0 280 752 237**
2.0 i S16 [T1]			**2,0 l 99 kW RFR 4 Zyl.**
Pressure sensor, intake manifold, gasoline	01.99-09.00		**0 261 230 034**
Accelerator pedal module	01.99-09.00	LLE,PAK	**0 280 752 237**
2.0 i S16 [T1]			**2,0 l 100 kW RFN 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.00→		**0 261 230 034**
Accelerator pedal module			
Org.no. →9932	10.00-02.04	LLE,PAK	**0 280 752 237**

206 CC

1.6 i 16V [T1]			**1,6 l 80 kW NFU 4 Zyl.**
Throttle valve assembly	09.00→		**0 280 750 085**
Knock sensor			
Org.no. 9457→	10.02→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	09.00→		**0 261 230 043**
Accelerator pedal module			
Org.no. →9932	09.00-02.04	LLE,PAK	**0 280 752 237**
2.0 i S16 [T1]			**2,0 l 100 kW RFN 4 Zyl.**
Pressure sensor, intake manifold, gasoline	09.00→		**0 261 230 034**
Accelerator pedal module			
Org.no. →9932	09.00-02.04	LLE,PAK	**0 280 752 237**

206 SW

1.1 i [T1]			**1,1 l 44 kW HFX 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.02→		**0 261 230 043**
Accelerator pedal module			
Org.no. →9932	03.02-02.04	LLE,PAK	**0 280 752 237**
1.4 HDi [T1]			**1,4 l 50 kW 8HX 4 Zyl.**
High-pressure sensor (CR system)	03.02→		**0 281 002 283**
Accelerator pedal module			
Org.no. →9932	03.02-02.04	LLE,PAK	**0 280 752 237**
1.4 i [T1]			**1,4 l 55 kW KFW 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.02→		**0 261 230 043**
Accelerator pedal module			
Org.no. →9932	03.02-02.04	LLE,PAK	**0 280 752 237**
1.4 i 16V [T1]			**1,4 l 65 kW KFU 4 Zyl.**
Knock sensor	10.03→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	10.03→		**0 261 230 043**
Accelerator pedal module			
Org.no. →9932	10.03-02.04	LLE,PAK	**0 280 752 237**

Product			
1.6 i 16V			**1,6 l 79 kW N6A 4 Zyl.**
Throttle valve assembly	03.04-04.05		**0 280 750 085**
Pressure sensor, intake manifold, gasoline	03.04-04.05		**0 261 230 043**
1.6 i 16V [T1]			**1,6 l 80 kW NFU 4 Zyl.**
Throttle valve assembly	03.02→		**0 280 750 085**
Knock sensor			
Org.no. 9457→	10.02→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	03.02→		**0 261 230 043**
Accelerator pedal module			
Org.no. →9932	03.02-02.04	LLE,PAK	**0 280 752 237**
2.0 HDi [T1]			**2,0 l 66 kW RHY 4 Zyl.**
High-pressure sensor (CR system)	03.02→		**0 281 002 283**
Accelerator pedal module			
Org.no. →9932	03.02-02.04	LLE,PAK	**0 280 752 237**
2.0 i S16 [T1]			**2,0 l 100 kW RFN 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.02→		**0 261 230 034**
Accelerator pedal module			
Org.no. →9932	03.02-02.04	LLE,PAK	**0 280 752 237**

207

1.4 HDi [A7]			**1,4 l 50 kW 8HZ 4 Zyl.**
Wheel speed sensor, rear	05.06→		**0 265 007 707**
1.4 i [A7]			**1,4 l 54 kW KFV 4 Zyl.**
Knock sensor	05.06→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	05.06→		**0 261 230 043**
Wheel speed sensor, rear	05.06→		**0 265 007 707**
1.4 i [A7]			**1,4 l 70 kW 8FS 4 Zyl.**
Phase sensor	06.07→		**0 232 103 064**
Pressure sensor, intake manifold, gasoline	06.07→		**0 261 230 136**
Wheel speed sensor, rear	06.07→		**0 265 007 707**
1.4 i 16V [A7]			**1,4 l 65 kW KFU 4 Zyl.**
Knock sensor	05.06→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	05.06→		**0 261 230 043**
Wheel speed sensor, rear	05.06→		**0 265 007 707**
1.6 HDi [A7]			**1,6 l 66/80 kW 9HV; 9HX; 9HZ / 9HY 4 Zyl.**
Wheel speed sensor, rear	05.06→		**0 265 007 707**
1.6 i [A7]			**1,6 l 80 kW NFU 4 Zyl.**
Knock sensor	05.06→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	05.06→		**0 261 230 043**
Wheel speed sensor, rear	05.06→		**0 265 007 707**
1.6 i [A7]			**1,6 l 88 kW 5FW 4 Zyl.**
Phase sensor	03.07→		**0 232 103 064**
Pressure sensor, intake manifold, gasoline	03.07→		**0 261 230 136**
Wheel speed sensor, rear	03.07→		**0 265 007 707**
1.6 i [A7]			**1,6 l 110 kW 5FX 4 Zyl.**
Phase sensor			
Org.no. 10958→	11.06→		**0 232 103 064**
Knock sensor	07.06→		**0 261 231 197**
Pressure sensor, intake manifold, gasoline	07.06→		**0 261 230 135**
Temperature sensor, intake air, injection system	07.06→		**0 261 230 134**
Wheel speed sensor, rear	07.06→		**0 265 007 707**
1.6 i RC [A7]			**1,6 l 128 kW 5FY 4 Zyl.**
Phase sensor	04.07→		**0 232 103 064**
Knock sensor	04.07→		**0 261 231 197**
Pressure sensor, intake manifold, gasoline	04.07→		**0 261 230 135**
Temperature sensor, intake air, injection system	04.07→		**0 261 230 134**
Wheel speed sensor, rear	04.07→		**0 265 007 707**

Product			

207 CC

1.6 HDi [A7]			**1,6 l 80 kW 9HZ 4 Zyl.**
Wheel speed sensor, rear	03.07→		**0 265 007 707**
1.6 i [A7]			**1,6 l 88 kW 5FW 4 Zyl.**
Phase sensor	03.07→		**0 232 103 064**
Pressure sensor, intake manifold, gasoline	03.07→		**0 261 230 136**
Wheel speed sensor, rear	03.07→		**0 265 007 707**
1.6 i [A7]			**1,6 l 110 kW 5FX 4 Zyl.**
Phase sensor	03.07→		**0 232 103 064**
Knock sensor	03.07→		**0 261 231 197**
Pressure sensor, intake manifold, gasoline	03.07→		**0 261 230 135**
Temperature sensor, intake air, injection system	03.07→		**0 261 230 134**
Wheel speed sensor, rear	03.07→		**0 265 007 707**

207 SW

1.4 i [A7]			**1,4 l 54 kW KFV 4 Zyl.**
Knock sensor	06.07→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	06.07→		**0 261 230 043**
Wheel speed sensor, rear	06.07→		**0 265 007 707**
1.4 i [A7]			**1,4 l 70 kW 8FS 4 Zyl.**
Phase sensor	06.07→		**0 232 103 064**
Pressure sensor, intake manifold, gasoline	06.07→		**0 261 230 136**
Wheel speed sensor, rear	06.07→		**0 265 007 707**
1.6 HDi [A7]			**1,6 l 66/80 kW 9HV; 9HX; 9HZ/ 9HY 4 Zyl.**
Wheel speed sensor, rear	06.07→		**0 265 007 707**
1.6 i [A7]			**1,6 l 88 kW 5FW 4 Zyl.**
Phase sensor	06.07→		**0 232 103 064**
Pressure sensor, intake manifold, gasoline	06.07→		**0 261 230 136**
Wheel speed sensor, rear	06.07→		**0 265 007 707**

305

1.9 i			**1,9 l 72 kW DFZ <XU9J1 Kat.> 4 Zyl.**
Throttle valve sensor	10.82-08.87		**0 280 120 310**
Air flow sensor, gasoline injection	10.82-07.90		**0 280 202 097**
			0 986 280 070
Temperature sensor, coolant, injection system	01.86-07.90		**0 280 130 026**
Relay, Jetronic	01.86-07.90		**0 280 230 006**

306

1.1 i [N3]			**1,1 l 40/44 kW HDY; HDZ 4 Zyl.**
Temperature sensor, coolant, injection system	01.93-12.95	BO	**0 280 130 026**
Wheel speed sensor, front	01.93-04.97	BO,LAB	**0 265 006 201**
		BO,RAB	**0 265 006 200**
Wheel speed sensor, rear	10.95-04.97	BO,LWG	**0 265 006 204**
		BO,NLW	**0 265 006 203**
	01.93-09.95	BO,TBR	**0 265 006 204**
1.4 [N3]			**1,4 l 44 kW K3A 4 Zyl.**
Wheel speed sensor, front	01.93-04.97	BO,LAB	**0 265 006 201**
		BO,RAB	**0 265 006 200**
Wheel speed sensor, rear	10.95-04.97	BO,NLW	**0 265 006 203**
	01.93-09.95	BO,TBR	**0 265 006 204**
1.4 [N3]			**1,4 l 55 kW K2D 4 Zyl.**
Wheel speed sensor, front	01.93-05.96	BO,LAB	**0 265 006 201**
		BO,RAB	**0 265 006 200**
Wheel speed sensor, rear	10.95-05.96	BO,LWG	**0 265 006 204**
		BO,NLW	**0 265 006 203**
	01.93-09.95	BO,TBR	**0 265 006 204**

Product			

1.4 [N3]			**1,4 l 55 kW K5A 4 Zyl.**
Wheel speed sensor, front	06.96-04.97	BO,LAB	**0 265 006 201**
		BO,RAB	**0 265 006 200**
Wheel speed sensor, rear	06.96-04.97	BO,LWG	**0 265 006 204**
		BO,NLW	**0 265 006 203**
1.4 [N5]			**1,4 l 55 kW K5A 4 Zyl.**
Wheel speed sensor, front	05.97-10.03	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-10.03	STB	**0 265 006 203**
1.4 i [N3]			**1,4 l 55 kW KDX 4 Zyl.**
Temperature sensor, coolant, injection system	01.93-04.97	BO	**0 280 130 026**
Wheel speed sensor, front	01.93-04.97	BO,LAB	**0 265 006 201**
		BO,RAB	**0 265 006 200**
Wheel speed sensor, rear	10.95-04.97	BO,LWG	**0 265 006 204**
		BO,NLW	**0 265 006 203**
	01.93-09.95	BO,TBR	**0 265 006 204**
1.4 i [N3]			**1,4 l 55 kW KFX 4 Zyl.**
Pressure sensor, intake manifold, gasoline	09.96-04.97		**0 261 230 012**
Wheel speed sensor, front	09.96-04.97	BO,LAB	**0 265 006 201**
		BO,RAB	**0 265 006 200**
Wheel speed sensor, rear	09.96-04.97	BO,LWG	**0 265 006 204**
		BO,NLW	**0 265 006 203**
1.4 i [N5]			**1,4 l 55 kW KFW 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.00-10.03		**0 261 230 043**
Wheel speed sensor, front	10.00-10.03	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	10.00-10.03	LIM,STB	**0 265 006 203**
		LWG,STB	**0 265 006 441**
1.4 i [N5]			**1,4 l 55 kW KFX 4 Zyl.**
Knock sensor	05.97-10.03	IF4	**0 261 231 128**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	05.97-12.98		**0 261 230 012**
Org.no. 8057→	01.99-10.03		**0 261 230 057**
Temperature sensor, coolant, injection system	05.97-10.03	BO	**0 280 130 084**
Wheel speed sensor, front	05.97-10.03	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-10.03	LIM,STB	**0 265 006 203**
		LWG,STB	**0 265 006 441**
1.4 i [N5]			**1,4 l 55 kW K6C 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.97-10.03		**0 261 230 043**
Org.no. →8056	05.97-12.98		**0 261 230 012**
Org.no. 8057→	01.99-10.03		**0 261 230 057**
Wheel speed sensor, front	05.97-10.03	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-10.03	LIM,STB	**0 265 006 203**
		LWG,STB	**0 265 006 441**
1.4 i [N5]			**1,4 l 55 kW K6D 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.97-10.03		**0 261 230 043**
Wheel speed sensor, front	05.97-10.03	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-10.03	LIM,STB	**0 265 006 203**
		LWG,STB	**0 265 006 441**
1.6 i [N3]			**1,6 l 65-66 kW NFZ 4 Zyl.**
Throttle valve sensor	01.93-04.97		**0 280 122 001**
Pressure sensor, intake manifold, gasoline	01.93-04.97		**0 261 230 004**
Temperature sensor, intake air, injection system	01.93-04.97		**0 280 130 039**
Temperature sensor, coolant, injection system	01.93-04.97	BO	**0 280 130 026**
Wheel speed sensor, front	01.93-04.97	BO,LAB	**0 265 006 201**
		BO,RAB	**0 265 006 200**
Wheel speed sensor, rear	10.95-04.97	BO,NLW	**0 265 006 203**
	01.93-09.95	BO,TBR	**0 265 006 204**

P

Product			
◀ 306			
1.6 i [N5]			**1,6 l 65-66 kW NFZ 4 Zyl.**
Throttle valve sensor			
Org.no. →7874	05.97-06.98		**0 280 122 003**
Knock sensor			
Org.no. 7875→	03.98-10.03		**0 261 231 128**
Pressure sensor, intake manifold, gasoline			
Org.no. →7874	05.97-05.98		**0 261 230 004**
Org.no. 7875→8119	06.98-02.99		**0 261 230 012**
Org.no. 8120→	03.99-10.03		**0 261 230 057**
Temperature sensor, intake air, injection system			
Org.no. →7874	05.97-05.98		**0 280 130 039**
Temperature sensor, coolant, injection system	05.97-10.03	BO	**0 280 130 084**
Wheel speed sensor, front	05.97-10.03	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-10.03	STB	**0 265 006 203**
1.6 i [N5]			**1,6 l 74 kW NFT 4 Zyl.**
Knock sensor	10.00-10.03		**0 261 231 128**
Pressure sensor, intake manifold, gasoline	10.00-10.03		**0 261 230 043**
Wheel speed sensor, front	10.00-10.03	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	10.00-10.03	STB	**0 265 006 203**
1.8 D [N3]			**1,8 l 44 kW A9A; 161A 4 Zyl.**
Wheel speed sensor, front	05.93-04.97	BO,LAB	**0 265 006 201**
		BO,RAB	**0 265 006 200**
Wheel speed sensor, rear	10.95-04.97	BO,LWG	**0 265 006 204**
		BO,NLW	**0 265 006 203**
	05.93-09.95	BO,TBR	**0 265 006 204**
1.8 D [N5]			**1,8 l 44 kW A9A,161A 4 Zyl.**
Wheel speed sensor, front	05.97-10.03	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-10.03	LIM,STB	**0 265 006 203**
		LWG,STB	**0 265 006 441**
1.8 i			**1,8 l 74 kW XU7JP 4 Zyl.**
Temperature sensor, coolant, injection system	03.97→		**0 280 130 068**
1.8 i [N3]			**1,8 l 74-76 kW LFZ; L6A 4 Zyl.**
Wheel speed sensor, front	01.93-04.97	BO,LAB	**0 265 006 201**
		BO,RAB	**0 265 006 200**
Wheel speed sensor, rear	10.95-04.97	BO,NLW	**0 265 006 203**
	01.93-09.95	BO,TBR	**0 265 006 204**
1.8 i [N5]			**1,8 l 74-76 kW LFZ; L6A 4 Zyl.**
Wheel speed sensor, front	05.97-10.03	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-10.03	STB	**0 265 006 203**
1.8 i 16V			**1,8 l 86 kW XU7JP4 4 Zyl.**
Temperature sensor, coolant, injection system	10.99→		**0 280 130 084**
Wheel speed sensor, front	10.99→		**0 265 006 203**
			0 265 006 389
		BO,LAB	**0 265 006 201**
		BO,RAB	**0 265 006 200**
Wheel speed sensor, rear	10.99→		**0 265 006 209**
1.8 i 16V [N5]			**1,8 l 81 kW LFY 4 Zyl.**
Throttle valve sensor	05.97-10.03		**0 280 122 003**
Pressure sensor, intake manifold, gasoline			
Org.no. →8035	05.97-11.98		**0 261 230 012**
Org.no. 8036→	12.98-10.03		**0 261 230 034**
Wheel speed sensor, front	05.97-10.03	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-10.03	4SB	**0 265 006 202**
1.9 D [N3]			**1,9 l 47-48 kW DJZ 4 Zyl.**
Wheel speed sensor, front	05.93-06.94	BO,LAB	**0 265 006 201**
		BO,RAB	**0 265 006 200**
Wheel speed sensor, rear	05.93-06.94	BO,TBR	**0 265 006 204**

Product			
1.9 D [N3]			**1,9 l 50/51 kW DJY; D9B 4 Zyl.**
Wheel speed sensor, front	05.93-04.97	BO,LAB	**0 265 006 201**
		BO,RAB	**0 265 006 200**
Wheel speed sensor, rear	10.95-04.97	BO,LWG	**0 265 006 204**
		BO,NLW	**0 265 006 203**
	05.93-09.95	BO,TBR	**0 265 006 204**
1.9 D [N5]			**1,9 l 50 kW DJY 4 Zyl.**
Wheel speed sensor, front	05.97-10.03	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-10.03	LIM,STB	**0 265 006 203**
		LWG,STB	**0 265 006 441**
1.9 D [N5]			**1,9 l 51 kW D9B 4 Zyl.**
Wheel speed sensor, front	05.97-10.03	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-10.03	STB	**0 265 006 203**
1.9 D [N5]			**1,9 l 51/52 kW WJY; WJZ 4 Zyl.**
Wheel speed sensor, front	09.98-10.03	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	09.98-10.03	LIM,STB	**0 265 006 203**
		LWG,STB	**0 265 006 441**
1.9 D Turbo [N3]			**1,9 l 66-67/68 kW DHY; D8A 4 Zyl.**
Wheel speed sensor, front	05.93-04.97	BO,LAB	**0 265 006 201**
		BO,RAB	**0 265 006 200**
Wheel speed sensor, rear	10.95-04.97	BO,NLW	**0 265 006 203**
	05.93-09.95	BO,TBR	**0 265 006 204**
1.9 D Turbo [N5]			**1,9 l 55/66 kW DHW; DHY 4 Zyl.**
Wheel speed sensor, front	05.97-10.03	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-10.03	STB	**0 265 006 203**
2.0 HDi [N5]			**2,0 l 66 kW RHY 4 Zyl.**
High-pressure sensor (CR system)	06.99-10.03	BO	**0 281 002 283**
Wheel speed sensor, front	06.99-10.03	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	06.99-10.03	4SB	**0 265 006 202**
2.0 HDI			**2,0 l 66 kW 4 Zyl.**
High-pressure sensor (CR system)	12.00→		**0 281 002 283**
Wheel speed sensor, front	12.00→	BO,LAB	**0 265 006 201**
		BO,RAB	**0 265 006 200**
Wheel speed sensor, rear	12.00→	LIM,SBR	**0 265 006 202**
2.0 i [N3]			**2,0 l 89-90 kW RFX; R6D 4 Zyl.**
Knock sensor	08.93-04.97		**0 261 231 071**
Wheel speed sensor, front	08.93-04.97	BO,LAB	**0 265 006 201**
		BO,RAB	**0 265 006 200**
Wheel speed sensor, rear	08.93-04.97		**0 265 006 202**
2.0 i 16V [N3]			**2,0 l 110-114 kW RFT; RFY 4 Zyl.**
Throttle valve sensor	08.93-06.95		**0 280 122 001**
	07.95-04.97		**0 280 122 003**
Knock sensor	08.93-04.97		**0 261 231 071**
Wheel speed sensor, front	08.93-04.97	BO,LAB	**0 265 006 201**
		BO,RAB	**0 265 006 200**
Wheel speed sensor, rear	08.93-04.97		**0 265 006 202**
2.0 i 16V [N3]			**2,0 l 120 kW RFS 4 Zyl.**
Throttle valve sensor	07.96-04.97		**0 280 122 009**
Pressure sensor, intake manifold, gasoline	07.96-04.97		**0 261 230 012**
Wheel speed sensor, front	07.96-04.97	BO,LAB	**0 265 006 201**
		BO,RAB	**0 265 006 200**
Wheel speed sensor, rear	07.96-04.97		**0 265 006 202**
2.0 i 16V [N5]			**2,0 l 97-99 kW RFV 4 Zyl.**
Throttle valve sensor	05.97-10.03	GS	**0 280 122 003**
Org.no. →7902	05.97-10.03	AG	**0 280 122 003**
Org.no. 7903→	07.98-10.03	AG	**0 280 122 005**

Product			
Knock sensor			
Org.no. →8133	05.97-02.99		**0 261 231 109**
Org.no. 8134→	03.99-10.03		**0 261 231 130**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	05.97-12.98		**0 261 230 012**
Org.no. 8057→	01.99-10.03		**0 261 230 057**
Wheel speed sensor, front	05.97-10.03	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-10.03	4SB	**0 265 006 202**
2.0 i 16V [N5]			**2,0 l 97-99 kW R6E 4 Zyl.**
Throttle valve sensor	05.97-10.03		**0 280 122 003**
Knock sensor			
Org.no. →8133	05.97-02.99		**0 261 231 109**
Org.no. 8134→	03.99-10.03		**0 261 231 130**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	05.97-12.98		**0 261 230 012**
Org.no. 8057→	01.99-10.03		**0 261 230 057**
Wheel speed sensor, front	05.97-10.03	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-10.03	4SB	**0 265 006 202**
2.0 i 16V [N5]			**2,0 l 120 kW RFS 4 Zyl.**
Throttle valve sensor	05.97-10.03		**0 280 122 009**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	05.97-12.98		**0 261 230 012**
Org.no. 8057→	01.99-10.03		**0 261 230 057**
Wheel speed sensor, front	05.97-10.03	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-10.03	4SB	**0 265 006 202**

306 Break

1.4 [N5]			**1,4 l 55 kW K5A 4 Zyl.**
Wheel speed sensor, front	05.97-03.02	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-03.02	STB	**0 265 006 441**
1.4 i [N5]			**1,4 l 55 kW KFW 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.00-03.02		**0 261 230 043**
Wheel speed sensor, front	10.00-03.02	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	10.00-03.02	STB	**0 265 006 441**
1.4 i [N5]			**1,4 l 55 kW KFX 4 Zyl.**
Knock sensor	05.97-03.02	IF4	**0 261 231 128**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	05.97-12.98		**0 261 230 012**
Org.no. 8057→	01.99-03.02		**0 261 230 057**
Temperature sensor, coolant, injection system	05.97-03.02	BO	**0 280 130 084**
Wheel speed sensor, front	05.97-03.02	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-03.02	STB	**0 265 006 441**
1.4 i [N5]			**1,4 l 55 kW K6C 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.97-03.02		**0 261 230 043**
Org.no. →8056	05.97-12.98		**0 261 230 012**
Org.no. 8057→	01.99-03.02		**0 261 230 057**
Wheel speed sensor, front	05.97-03.02	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-03.02	STB	**0 265 006 441**
1.4 i [N5]			**1,4 l 55 kW K6D 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.97-03.02		**0 261 230 043**
Wheel speed sensor, front	05.97-03.02	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-03.02	STB	**0 265 006 441**

Product			
1.6 i [N5]			**1,6 l 65-66 kW NFZ 4 Zyl.**
Throttle valve sensor			
Org.no. →7874	05.97-06.98		**0 280 122 003**
Knock sensor			
Org.no. 7875→	03.98-10.00		**0 261 231 128**
Pressure sensor, intake manifold, gasoline			
Org.no. →7874	05.97-05.98		**0 261 230 004**
Org.no. 7875→8119	06.98-02.99		**0 261 230 012**
Org.no. 8120→	03.99-10.00		**0 261 230 057**
Temperature sensor, intake air, injection system			
Org.no. →7874	05.97-05.98		**0 280 130 039**
Temperature sensor, coolant, injection system	05.97-10.00	BO	**0 280 130 084**
Wheel speed sensor, front	05.97-10.00	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-10.00	STB	**0 265 006 441**
1.6 i [N5]			**1,6 l 74 kW NFT 4 Zyl.**
Knock sensor	10.00-03.02		**0 261 231 128**
Pressure sensor, intake manifold, gasoline	10.00-03.02		**0 261 230 043**
Wheel speed sensor, front	10.00-03.02	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	10.00-03.02	STB	**0 265 006 441**
1.8 i [N5]			**1,8 l 74-76 kW LFZ; L6A 4 Zyl.**
Wheel speed sensor, front	05.97-03.02	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-03.02	STB	**0 265 006 441**
1.8 i 16V [N5]			**1,8 l 81 kW LFY 4 Zyl.**
Throttle valve sensor	05.97-03.02		**0 280 122 003**
Pressure sensor, intake manifold, gasoline			
Org.no. →8035	05.97-11.98		**0 261 230 012**
Org.no. 8036→	12.98-03.02		**0 261 230 034**
Wheel speed sensor, front	05.97-03.02	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-03.02	4SB	**0 265 006 202**
1.9 D [N5]			**1,9 l 50/51/52 kW DJY; D9B; WJY; WJZ 4 Zyl.**
Wheel speed sensor, front	05.97-03.02	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-03.02	STB	**0 265 006 441**
1.9 D Turbo [N5]			**1,9 l 55/66 kW DHV; DHY 4 Zyl.**
Wheel speed sensor, front	05.97-03.02	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-03.02	STB	**0 265 006 441**
2.0 HDi [N5]			**2,0 l 66 kW RHY 4 Zyl.**
High-pressure sensor (CR system)	06.99-03.02	BO	**0 281 002 283**
Wheel speed sensor, front	06.99-03.02	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	06.99-03.02	4SB	**0 265 006 202**
2.0 i 16V [N5]			**2,0 l 97-99 kW RFV 4 Zyl.**
Throttle valve sensor	05.97-03.02	GS	**0 280 122 003**
Org.no. →7902	05.97-03.02	AG	**0 280 122 003**
Org.no. 7903→	07.98-03.02	AG	**0 280 122 005**
Knock sensor			
Org.no. →8133	05.97-02.99		**0 261 231 109**
Org.no. 8134→	03.99-03.02		**0 261 231 130**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	05.97-12.98		**0 261 230 012**
Org.no. 8057→	01.99-03.02		**0 261 230 057**
Wheel speed sensor, front	05.97-03.02	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-03.02	4SB	**0 265 006 202**

P

Product

306 Cabriolet

1.6 i [N3]			**1,6 l 65-66 kW NFZ 4 Zyl.**
Throttle valve sensor	01.93-04.97		**0 280 122 001**
Pressure sensor, intake manifold, gasoline	01.93-04.97		**0 261 230 004**
Temperature sensor, intake air, injection system	01.93-04.97		**0 280 130 039**
Temperature sensor, coolant, injection system	01.93-04.97	BO	**0 280 130 026**
Wheel speed sensor, front	01.93-04.97	BO,LAB	**0 265 006 201**
		BO,RAB	**0 265 006 200**
Wheel speed sensor, rear	01.93-09.95	BO,TBR	**0 265 006 204**
1.6 i [N5]			**1,6 l 65-66 kW NFZ 4 Zyl.**
Throttle valve sensor			
Org.no. →7874	05.97-06.98		**0 280 122 003**
Knock sensor			
Org.no. 7875→	03.98-10.03		**0 261 231 128**
Pressure sensor, intake manifold, gasoline			
Org.no. →7874	05.97-05.98		**0 261 230 004**
Org.no. 7875→8119	06.98-02.99		**0 261 230 012**
Org.no. 8120→	03.99-10.03		**0 261 230 057**
Temperature sensor, intake air, injection system			
Org.no. →7874	05.97-05.98		**0 280 130 039**
Temperature sensor, coolant, injection system	05.97-10.03	BO	**0 280 130 084**
Wheel speed sensor, front	05.97-10.03	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-10.03	STB	**0 265 006 203**
1.6 i [N5]			**1,6 l 74 kW NFT 4 Zyl.**
Knock sensor	10.00-10.03		**0 261 231 128**
Pressure sensor, intake manifold, gasoline	10.00-10.03		**0 261 230 043**
Wheel speed sensor, front	10.00-10.03	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	10.00-10.03	STB	**0 265 006 203**
1.8 i [N3]			**1,8 l 74-76 kW LFZ; L6A 4 Zyl.**
Wheel speed sensor, front	01.93-04.97	BO,LAB	**0 265 006 201**
		BO,RAB	**0 265 006 200**
Wheel speed sensor, rear	01.93-09.95	BO,TBR	**0 265 006 204**
1.8 i [N5]			**1,8 l 74-76 kW LFZ 4 Zyl.**
Wheel speed sensor, front	05.97-10.03	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-10.03	STB	**0 265 006 203**
1.8 i 16V [N5]			**1,8 l 81 kW LFY 4 Zyl.**
Throttle valve sensor	05.97-10.03		**0 280 122 003**
Pressure sensor, intake manifold, gasoline			
Org.no. →8035	05.97-11.98		**0 261 230 012**
Org.no. 8036→	12.98-10.03		**0 261 230 034**
Wheel speed sensor, front	05.97-10.03	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-10.03	4SB	**0 265 006 202**
2.0 i [N3]			**2,0 l 89-90 kW RFX; R6D 4 Zyl.**
Knock sensor	08.93-04.97		**0 261 231 071**
Wheel speed sensor, front	08.93-04.97	BO,LAB	**0 265 006 201**
		BO,RAB	**0 265 006 200**
Wheel speed sensor, rear	08.93-04.97		**0 265 006 202**
2.0 i 16V [N5]			**2,0 l 97-99 kW RFV 4 Zyl.**
Throttle valve sensor	05.97-10.03	GS	**0 280 122 003**
Org.no. →7902	05.97-10.03	AG	**0 280 122 003**
Org.no. 7903→	07.98-10.03	AG	**0 280 122 005**
Knock sensor			
Org.no. →8133	05.97-02.99		**0 261 231 109**
Org.no. 8134→	03.99-10.03		**0 261 231 130**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	05.97-12.98		**0 261 230 012**
Org.no. 8057→	01.99-10.03		**0 261 230 057**

Product

Wheel speed sensor, front	05.97-10.03	LAB	**0 265 006 201**
		RAB	**0 265 006 200**
Wheel speed sensor, rear	05.97-10.03	4SB	**0 265 006 202**

307

1.4 HDi [T5]			**1,4 l 50 kW 8HZ 4 Zyl.**
High-pressure sensor (CR system)	10.01-05.05		**0 281 002 283**
Yaw rate sensor, brake system	10.01-05.05		**0 265 005 290**
Wheel speed sensor, front	10.01-05.05	TW	**0 265 007 423**
Wheel speed sensor, rear	10.01-05.05	TW	**0 265 007 424**
			0 265 007 664
			0 265 007 779
1.4 i [T5]			**1,4 l 55 kW KFW 4 Zyl.**
Pressure sensor, intake manifold, gasoline	08.00-05.05		**0 261 230 043**
Yaw rate sensor, brake system	08.00-05.05		**0 265 005 290**
Wheel speed sensor, front	08.00-05.05	TW	**0 265 007 423**
Wheel speed sensor, rear	08.00-05.05	TW	**0 265 007 424**
			0 265 007 664
			0 265 007 779
1.4 i [T6]			**1,4 l 65 kW KFU 4 Zyl.**
Knock sensor	06.05→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	06.05→		**0 261 230 043**
Yaw rate sensor, brake system	06.05→		**0 265 005 606**
Wheel speed sensor, rear	06.05→		**0 265 007 779**
1.4 i 16V [T5]			**1,4 l 65 kW KFU 4 Zyl.**
Knock sensor	11.03-05.05		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	11.03-05.05		**0 261 230 043**
Yaw rate sensor, brake system	11.03-05.05		**0 265 005 290**
Wheel speed sensor, front	11.03-05.05	TW	**0 265 007 423**
Wheel speed sensor, rear	11.03-05.05	TW	**0 265 007 424**
			0 265 007 664
			0 265 007 779
1.6 HDi [T5]			**1,6 l 80 kW 9HZ / 9HY 4 Zyl.**
Yaw rate sensor, brake system	02.04-05.05		**0 265 005 290**
Wheel speed sensor, front	02.04-05.05	TW	**0 265 007 423**
Wheel speed sensor, rear	02.04-05.05	TW	**0 265 007 424**
			0 265 007 664
			0 265 007 779
1.6 HDi [T6]			**1,6 l 66 kW 9HV 4 Zyl.**
Yaw rate sensor, brake system	06.07→		**0 265 005 714**
1.6 HDi [T6]			**1,6 l 66/80 kW 9HX; 9HZ / 9HY 4 Zyl.**
Yaw rate sensor, brake system	06.05→		**0 265 005 606**
Wheel speed sensor, rear	06.05→		**0 265 007 779**
1.6 i [T5]			**1,6 l 80 kW NFU 4 Zyl.**
Throttle valve assembly	08.00-05.05		**0 280 750 085**
Knock sensor			
Org.no. 9457→	10.02-05.05		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	08.00-05.05		**0 261 230 043**
Accelerator pedal module	08.00-05.05	LLE	**0 280 752 235**
		RLE	**0 280 752 236**
Yaw rate sensor, brake system	08.00-05.05		**0 265 005 290**
Wheel speed sensor, front	08.00-05.05	TW	**0 265 007 423**
Wheel speed sensor, rear	08.00-05.05	TW	**0 265 007 424**
			0 265 007 664
			0 265 007 779
1.6 i [T6]			**1,6 l 80 kW NFU 4 Zyl.**
Throttle valve assembly	06.05→		**0 280 750 085**
Knock sensor	06.05→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	06.05→		**0 261 230 043**
Accelerator pedal module	06.05→	LLE	**0 280 752 235**
		RLE	**0 280 752 236**

P

Product			
Yaw rate sensor, brake system	06.05→		**0 265 005 606**
Wheel speed sensor, rear	06.05→		**0 265 007 779**
1.6 i 16V [T5]			**1,6 l 78 kW NFU 4 Zyl.**
Throttle valve assembly	06.04→	BO	**0 280 750 085**
Knock sensor			
Org.no. 9457→	06.04→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	06.04→		**0 261 230 043**
Yaw rate sensor, brake system	06.04→		**0 265 005 290**
2.0 HDi [T5]			**2,0 l 66 kW RHY 4 Zyl.**
High-pressure sensor (CR system)	08.00-05.05	BO	**0 281 002 283**
Yaw rate sensor, brake system	08.00-05.05		**0 265 005 290**
Wheel speed sensor, front	08.00-05.05	TW	**0 265 007 423**
Wheel speed sensor, rear	08.00-05.05	TW	**0 265 007 424**
			0 265 007 664
			0 265 007 779
2.0 HDi [T5]			**2,0 l 79 kW RHS 4 Zyl.**
High-pressure sensor (CR system)	03.02-05.05		**0 281 002 283**
Yaw rate sensor, brake system	03.02-05.05		**0 265 005 290**
Wheel speed sensor, front	03.02-05.05	TW	**0 265 007 423**
Wheel speed sensor, rear	03.02-05.05	TW	**0 265 007 424**
			0 265 007 664
			0 265 007 779
2.0 HDi [T5]			**2,0 l 100 kW RHR 4 Zyl.**
Accelerator pedal module	10.03-05.05	LLE	**0 280 752 235**
		RLE	**0 280 752 236**
Yaw rate sensor, brake system	10.03-05.05		**0 265 005 290**
Wheel speed sensor, front	10.03-05.05	TW	**0 265 007 423**
Wheel speed sensor, rear	10.03-05.05	TW	**0 265 007 424**
			0 265 007 664
			0 265 007 779
2.0 HDi [T6]			**2,0 l 100 kW RHR 4 Zyl.**
Accelerator pedal module	06.05→	LLE	**0 280 752 235**
		RLE	**0 280 752 236**
Yaw rate sensor, brake system	06.05→		**0 265 005 606**
Wheel speed sensor, rear	06.05→		**0 265 007 779**
2.0 i [T5]			**2,0 l 100 kW RFN 4 Zyl.**
Pressure sensor, intake manifold, gasoline	08.00-05.05		**0 261 230 057**
Yaw rate sensor, brake system	08.00-05.05		**0 265 005 290**
Wheel speed sensor, front	08.00-05.05	TW	**0 265 007 423**
Wheel speed sensor, rear	08.00-05.05	TW	**0 265 007 424**
			0 265 007 664
			0 265 007 779
2.0 i [T6]			**2,0 l 103 kW RFJ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	06.05→		**0 261 230 043**
Yaw rate sensor, brake system	06.05→		**0 265 005 606**
Wheel speed sensor, rear	06.05→		**0 265 007 779**
2.0 i [T6]			**2,0 l 130 kW RFK 4 Zyl.**
Pressure sensor, intake manifold, gasoline	06.05→		**0 261 230 043**
Yaw rate sensor, brake system	06.05→		**0 265 005 606**
Wheel speed sensor, rear	06.05→		**0 265 007 664**
2.0 i 16V [T5]			**2,0 l 99 kW RFN 4 Zyl.**
Pressure sensor, intake manifold, gasoline	06.04-02.07		**0 261 230 058**
Yaw rate sensor, brake system	06.04-02.07		**0 265 005 290**

307 Break/SW

1.4 HDi [T5]			**1,4 l 50 kW 8HZ 4 Zyl.**
High-pressure sensor (CR system)	03.02-05.05		**0 281 002 283**
Yaw rate sensor, brake system	03.02-05.05		**0 265 005 290**
Wheel speed sensor, front	03.02-05.05	TW	**0 265 007 423**
Wheel speed sensor, rear	03.02-05.05	TW	**0 265 007 424**
			0 265 007 664
			0 265 007 779

Product			
1.4 i [T6]			**1,4 l 65 kW KFU 4 Zyl.**
Knock sensor	06.05→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	06.05→		**0 261 230 043**
Yaw rate sensor, brake system	06.05→		**0 265 005 606**
Wheel speed sensor, rear	06.05→		**0 265 007 779**
1.4 i 16V [T5]			**1,4 l 65 kW KFU 4 Zyl.**
Knock sensor	11.03-05.05		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	11.03-05.05		**0 261 230 043**
Yaw rate sensor, brake system	11.03-05.05		**0 265 005 290**
Wheel speed sensor, front	11.03-05.05	TW	**0 265 007 423**
Wheel speed sensor, rear	11.03-05.05	TW	**0 265 007 424**
			0 265 007 664
			0 265 007 779
1.6 HDi [T5]			**1,6 l 80 kW 9HZ / 9HY 4 Zyl.**
Yaw rate sensor, brake system	02.04-05.05		**0 265 005 290**
Wheel speed sensor, front	02.04-05.05	TW	**0 265 007 423**
Wheel speed sensor, rear	02.04-05.05	TW	**0 265 007 424**
			0 265 007 664
			0 265 007 779
1.6 HDi [T6]			**1,6 l 66 kW 9HV 4 Zyl.**
Yaw rate sensor, brake system	06.07→		**0 265 005 714**
1.6 HDi [T6]			**1,6 l 66/80 kW 9HX; 9HZ / 9HY 4 Zyl.**
Yaw rate sensor, brake system	06.05→		**0 265 005 606**
Wheel speed sensor, rear	06.05→		**0 265 007 779**
1.6 i [T5]			**1,6 l 80 kW NFU 4 Zyl.**
Throttle valve assembly	03.02-05.05		**0 280 750 085**
Knock sensor			
Org.no. 9457→	10.02-05.05		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	03.02-05.05		**0 261 230 043**
Accelerator pedal module	03.02-05.05	LLE	**0 280 752 235**
		RLE	**0 280 752 236**
Yaw rate sensor, brake system	03.02-05.05		**0 265 005 290**
Wheel speed sensor, front	03.02-05.05	TW	**0 265 007 423**
Wheel speed sensor, rear	03.02-05.05	TW	**0 265 007 424**
			0 265 007 664
			0 265 007 779
1.6 i 16V [T6]			**1,6 l 80 kW NFU 4 Zyl.**
Throttle valve assembly	06.05→		**0 280 750 085**
Knock sensor	06.05→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	06.05→		**0 261 230 043**
Accelerator pedal module	06.05→	LLE	**0 280 752 235**
		RLE	**0 280 752 236**
Yaw rate sensor, brake system	06.05→		**0 265 005 606**
Wheel speed sensor, rear	06.05→		**0 265 007 779**
2.0 HDi [T5]			**2,0 l 66 kW RHY 4 Zyl.**
High-pressure sensor (CR system)	03.02-05.05	BO	**0 281 002 283**
Yaw rate sensor, brake system	03.02-05.05		**0 265 005 290**
Wheel speed sensor, front	03.02-05.05	TW	**0 265 007 423**
Wheel speed sensor, rear	03.02-05.05	TW	**0 265 007 424**
			0 265 007 664
			0 265 007 779
2.0 HDi [T5]			**2,0 l 79 kW RHS 4 Zyl.**
High-pressure sensor (CR system)	03.02-05.05		**0 281 002 283**
Yaw rate sensor, brake system	03.02-05.05		**0 265 005 290**
Wheel speed sensor, front	03.02-05.05	TW	**0 265 007 423**
Wheel speed sensor, rear	03.02-05.05	TW	**0 265 007 424**
			0 265 007 664
			0 265 007 779
2.0 HDi [T5]			**2,0 l 100 kW RHR 4 Zyl.**
Accelerator pedal module	10.03-05.05	LLE	**0 280 752 235**
		RLE	**0 280 752 236**
Yaw rate sensor, brake system	10.03-05.05		**0 265 005 290**
Wheel speed sensor, front	10.03-05.05	TW	**0 265 007 423**

P

Product			
◀ 307 Break/SW			
Wheel speed sensor, rear	10.03-05.05	TW	**0 265 007 424**
			0 265 007 664
			0 265 007 779
2.0 HDi [T6]		**2,0 l 100 kW RHR 4 Zyl.**	
Accelerator pedal module	06.05→	LLE	**0 280 752 235**
		RLE	**0 280 752 236**
Yaw rate sensor, brake system	06.05→		**0 265 005 606**
Wheel speed sensor, rear	06.05→		**0 265 007 779**
2.0 i [T5]		**2,0 l 100 kW RFN 4 Zyl.**	
Pressure sensor, intake manifold, gasoline	03.02-05.05		**0 261 230 057**
Yaw rate sensor, brake system	03.02-05.05		**0 265 005 290**
Wheel speed sensor, front	03.02-05.05	TW	**0 265 007 423**
Wheel speed sensor, rear	03.02-05.05	TW	**0 265 007 424**
			0 265 007 664
			0 265 007 779
2.0 i [T6]		**2,0 l 103 kW RFJ 4 Zyl.**	
Pressure sensor, intake manifold, gasoline	06.05→		**0 261 230 043**
Yaw rate sensor, brake system	06.05→		**0 265 005 606**
Wheel speed sensor, rear	06.05→		**0 265 007 779**

307 CC

1.6 i [T6]		**1,6 l 80 kW NFU 4 Zyl.**	
Throttle valve assembly	06.05→		**0 280 750 085**
Knock sensor	06.05→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	06.05→		**0 261 230 043**
Accelerator pedal module	06.05→	LLE	**0 280 752 235**
		RLE	**0 280 752 236**
Yaw rate sensor, brake system	06.05→		**0 265 005 606**
Wheel speed sensor, rear	06.05→		**0 265 007 779**
2.0 HDi [T6]		**2,0 l 100 kW RHR 4 Zyl.**	
Accelerator pedal module	06.05→	LLE	**0 280 752 235**
		RLE	**0 280 752 236**
Yaw rate sensor, brake system	06.05→		**0 265 005 606**
Wheel speed sensor, rear	06.05→		**0 265 007 779**
2.0 i [T5]		**2,0 l 100 kW RFN 4 Zyl.**	
Pressure sensor, intake manifold, gasoline	10.03-05.05		**0 261 230 058**
Yaw rate sensor, brake system	10.03-05.05		**0 265 005 290**
Wheel speed sensor, front	10.03-05.05	TW	**0 265 007 423**
Wheel speed sensor, rear	10.03-05.05	TW	**0 265 007 424**
			0 265 007 664
			0 265 007 779
2.0 i [T6]		**2,0 l 103 kW RFJ 4 Zyl.**	
Pressure sensor, intake manifold, gasoline	06.05→		**0 261 230 043**
Yaw rate sensor, brake system	06.05→		**0 265 005 606**
Wheel speed sensor, rear	06.05→		**0 265 007 779**
2.0 i Sport [T5]		**2,0 l 130 kW RFK 4 Zyl.**	
Pressure sensor, intake manifold, gasoline	10.03-05.05		**0 261 230 043**
Yaw rate sensor, brake system	10.03-05.05		**0 265 005 290**
Wheel speed sensor, front	10.03-05.05	TW	**0 265 007 423**
Wheel speed sensor, rear	10.03-05.05	TW	**0 265 007 424**
			0 265 007 664
			0 265 007 779
2.0 i Sport [T6]		**2,0 l 130 kW RFK 4 Zyl.**	
Pressure sensor, intake manifold, gasoline	06.05→		**0 261 230 043**
Yaw rate sensor, brake system	06.05→		**0 265 005 606**
Wheel speed sensor, rear	06.05→		**0 265 007 664**

308

1.4 i [T7]		**1,4 l 70 kW 8FS 4 Zyl.**
Phase sensor	09.07→	**0 232 103 064**
Pressure sensor, intake manifold, gasoline	09.07→	**0 261 230 136**
Yaw rate sensor, brake system	09.07→	**0 265 005 714**
1.6 HDi [T7]		**1,6 l 66/80 kW 9HV; 9HX; 9HZ 4 Zyl.**
Yaw rate sensor, brake system	09.07→	**0 265 005 714**
1.6 i [T7]		**1,6 l 88 kW 5FW 4 Zyl.**
Phase sensor	09.07→	**0 232 103 064**
Pressure sensor, intake manifold, gasoline	09.07→	**0 261 230 136**
Yaw rate sensor, brake system	09.07→	**0 265 005 714**
1.6 i [T7]		**1,6 l 103-110 kW 5FX 4 Zyl.**
Phase sensor	09.07→	**0 232 103 064**
Knock sensor	09.07→	**0 261 231 197**
Pressure sensor, intake manifold, gasoline	09.07→	**0 261 230 135**
Temperature sensor, intake air, injection system	09.07→	**0 261 230 134**
Yaw rate sensor, brake system	09.07→	**0 265 005 715**
2.0 HDi [T7]		**2,0 l 100 kW RHR 4 Zyl.**
Yaw rate sensor, brake system	09.07→	**0 265 005 714**

309

1.1 i		**1,1 l 40-44 kW HDZ,HDY <TU1MZ Kat.> 4 Zyl.**
Temperature sensor, coolant, injection system	10.90-12.93	**0 280 130 026**
1.4 i		**1,4 l 55-58 kW KDY <TU3M Kat.>; KDZ <TU3M Kat.> 4 Zyl.**
Temperature sensor, coolant, injection system	10.88-12.93	**0 280 130 026**
1.6 i		**1,6 l 76/83 kW B6A,B6B <XU5J>; B6D <XU5JA> 4 Zyl.**
Throttle valve sensor	11.85-08.87	**0 280 120 310**
	09.87-09.90	**0 280 120 327**
Air flow sensor, gasoline injection	11.85-09.90	**0 280 202 056**
		0 986 280 028
Temperature sensor, coolant, injection system	11.85-09.90	**0 280 130 026**
Relay, Jetronic	11.85-09.90	**0 280 230 006**
1.6 i		**1,6 l 85 kW 180A,180Z <XU5J> 4 Zyl.**
Throttle valve sensor	11.85-08.87	**0 280 120 310**
	09.87-10.87	**0 280 120 327**
Air flow sensor, gasoline injection	11.85-10.87	**0 280 202 056**
		0 986 280 028
1.6 i		**1,6 l 90 kW B6E <XU5JA> 4 Zyl.**
Throttle valve sensor	10.90-12.93	**0 280 120 327**
Air flow sensor, gasoline injection	10.90-12.93	**0 280 202 056**
		0 986 280 028
1.9 GTI		**1,9 l 94 kW D6B <XU9JA> 4 Zyl.**
Throttle valve sensor	10.86-08.87	**0 280 120 310**
	09.87-12.93	**0 280 120 327**
Air flow sensor, gasoline injection	10.86-12.93	**0 280 202 109**
		0 986 280 013
Temperature sensor, coolant, injection system	10.86-12.93	**0 280 130 026**
Relay, Jetronic	10.86-12.93	**0 280 230 006**
1.9 i		**1,9 l 72 kW DFZ <XU9J1 Kat.> 4 Zyl.**
Throttle valve sensor	03.86-08.87	**0 280 120 310**
	09.87-12.93	**0 280 120 327**
Air flow sensor, gasoline injection	03.86-12.93	**0 280 202 097**
		0 986 280 070
Temperature sensor, coolant, injection system	03.86-12.93	**0 280 130 026**
Relay, Jetronic	03.86-12.93	**0 280 230 006**
1.9 i		**1,9 l 80 kW DDZ <XU9M Kat.> 4 Zyl.**
Temperature sensor, coolant, injection system	07.88-12.93	**0 280 130 026**
1.9 i		**1,9 l 88-90 kW DKZ,DFY <XU9JAZ Kat.> 4 Zyl.**
Throttle valve sensor	07.88-12.93	**0 280 120 327**
Speed sensor, ignition/injection	07.88-12.93	**0 261 210 043**
Temperature sensor, coolant, injection system	07.88-12.93	**0 280 130 026**

Product			
1.9 i 16V	**1,9 l 108/116 kW DFW; D6C <XU9J4/K> 4 Zyl.**		
Throttle valve sensor	02.90-12.93		**0 280 120 327**
Speed sensor, ignition/injection	02.90-12.93		**0 261 210 043**
Knock sensor	02.90-12.93		**0 261 231 006**
Temperature sensor, coolant, injection system	02.90-12.93		**0 280 130 026**

405

1.4 [4]	**1,4 l 55 kW K2D <TU3.2> 4 Zyl.**		
Wheel speed sensor, front	06.92-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-04.97	BO	**0 265 006 315**
1.4 [15]	**1,4 l 44/51/55 kW K1G <TU3A>; K2D <TU3F2>; K3A <TU3TR> 4 Zyl.**		
Wheel speed sensor, front	10.89-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	10.89-06.92	BO,OAA	**0 265 003 065**
1.4 i [4]	**1,4 l 55 kW KDX <TU3MC Kat.> 4 Zyl.**		
Temperature sensor, coolant, injection system	06.92-04.97		**0 280 130 026**
Wheel speed sensor, front	06.92-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-04.97	BO	**0 265 006 315**
1.6 [4]	**1,6 l 65/68 kW B2A <XU52C>; B5A <XU52C> 4 Zyl.**		
Wheel speed sensor, front	06.92-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-04.97	BO	**0 265 006 315**
1.6 [15]	**1,6 l 53/65/68 kW B1D/E <XU51C>; B2A/B/C,B5A <XU52C> 4 Zyl.**		
Wheel speed sensor, front	10.89-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	10.89-06.92	BO,OAA	**0 265 003 065**
1.6 i [4]	**1,6 l 65 kW BDY <XU5M Kat.> 4 Zyl.**		
Temperature sensor, intake air, injection system	06.92-04.97		**0 280 130 039**
Wheel speed sensor, front	06.92-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-04.97	BO	**0 265 006 315**
1.6 i [4]	**1,6 l 65 kW BFZ <XU5JP> 4 Zyl.**		
Wheel speed sensor, front	09.94-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	09.94-04.97	BO	**0 265 006 315**
1.6 i [15]	**1,6 l 65 kW BDY <XU5M Kat.> 4 Zyl.**		
Wheel speed sensor, front	09.90-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	09.90-06.92	BO,OAA	**0 265 003 065**
1.6 i [15]	**1,6 l 65 kW BDZ <XU5M Kat.> 4 Zyl.**		
Wheel speed sensor, front	10.89-09.90	BO,OAA	**0 265 003 064**
Wheel speed sensor, rear	10.89-09.90	BO,OAA	**0 265 003 065**
1.8 D [15]	**1,8 l 44 kW A9A <XUD7>; 161A <XUD7> 4 Zyl.**		
Wheel speed sensor, front	10.90-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	10.90-06.92	BO,OAA	**0 265 003 065**
1.8 D Turbo [15]	**1,8 l 64-66 kW AJZ <XUD7TEY>; A8A,A8B <XUD7TE> 4 Zyl.**		
Wheel speed sensor, front	10.89-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	10.89-06.92	BO,OAA	**0 265 003 065**
1.8 i	**1,8 l 74 kW XU7UP 4 Zyl.**		
Temperature sensor, coolant, injection system	04.96→		**0 280 130 068**
1.8 i [4]	**1,8 l 74 kW LFZ <XU7JP Kat.>; L6A <XU7JP> 4 Zyl.**		
Pressure sensor, intake manifold, gasoline	06.92-04.97	BO	**0 261 230 004**
Wheel speed sensor, front	06.92-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-04.97	BO	**0 265 006 315**
1.9 [4]	**1,9 l 71/80 kW D2H <XU92C>; D5A <XU92C> 4 Zyl.**		
Wheel speed sensor, front	06.92-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-04.97	BO	**0 265 006 315**

Product			
1.9 [15]	**1,9 l 70/71 kW D2C <XU92C>; D5A <XU92CTR> 4 Zyl.**		
Wheel speed sensor, front	10.89-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	10.89-06.92	BO,OAA	**0 265 003 065**
1.9 [15]	**1,9 l 80/81 kW D2D <XU92C>; D2H <XU92C> 4 Zyl.**		
Wheel speed sensor, front	07.87-12.92	AA,BO	**0 265 006 314**
	10.89-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	10.89-06.92	BO,OAA	**0 265 003 065**
1.9 D [4]	**1,9 l 47/50/51 kW DJY,DJZ <XUD9Y>; D9B <XUD9A> 4 Zyl.**		
Wheel speed sensor, front	06.92-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-04.97	BO	**0 265 006 315**
1.9 D [15]	**1,9 l 47/51 kW DJZ <XUD9Y>; D9B <XUD9A> 4 Zyl.**		
Wheel speed sensor, front	10.89-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	10.89-06.92	BO,OAA	**0 265 003 065**
1.9 D Turbo [4]	**1,9 l 66-68 kW DHY <XUD9TE Kat.>; D8A <XUD9TE> 4 Zyl.**		
Wheel speed sensor, front	06.92-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-04.97	BO	**0 265 006 315**
1.9 i [4]	**1,9 l 89 kW D6D <XU9J2> 4 Zyl.**		
Throttle valve sensor	06.92-04.97		**0 280 122 001**
Speed sensor, ignition/injection	06.92-04.97		**0 261 210 043**
Temperature sensor, intake air, injection system	06.92-04.97		**0 280 130 039**
Temperature sensor, coolant, injection system	06.92-04.97		**0 280 130 026**
Acceleration sensor, ABS	06.92-04.97		**0 265 005 111**
Wheel speed sensor, front	06.92-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-04.97	BO	**0 265 006 315**
1.9 i [15]	**1,9 l 77 kW DFZ <XU9J1 Kat.> 4 Zyl.**		
Throttle valve sensor	07.87-12.92		**0 280 120 327**
Air flow sensor, gasoline injection	07.87-12.92		**0 280 202 097**
			0 986 280 070
Temperature sensor, coolant, injection system	07.87-12.92		**0 280 130 026**
Relay, Jetronic	07.87-12.92		**0 280 230 006**
Acceleration sensor, ABS	07.87-12.92		**0 265 005 111**
Wheel speed sensor, front	07.87-12.92	AA,BO	**0 265 006 314**
	10.89-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	10.89-06.92	BO,OAA	**0 265 003 065**
1.9 i [15]	**1,9 l 80 kW DDZ <XU9M Kat.> 4 Zyl.**		
Temperature sensor, coolant, injection system	07.88-12.92		**0 280 130 026**
Acceleration sensor, ABS	07.88-12.92		**0 265 005 111**
Wheel speed sensor, front	07.88-12.92	AA,BO	**0 265 006 314**
	10.89-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	10.89-06.92	BO,OAA	**0 265 003 065**
1.9 i [15]	**1,9 l 82 kW DFV <XU9J2 Kat.> 4 Zyl.**		
Throttle valve sensor	07.87-12.92		**0 280 120 327**
Air flow sensor, gasoline injection	07.87-12.92		**0 280 202 602**
			0 986 280 019
Speed sensor, ignition/injection	07.87-12.92		**0 261 210 043**
Temperature sensor, coolant, injection system	07.87-12.92		**0 280 130 026**
Acceleration sensor, ABS	07.87-12.92		**0 265 005 111**
Wheel speed sensor, front	07.87-12.92	AA,BO	**0 265 006 314**
	10.89-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	10.89-06.92	BO,OAA	**0 265 003 065**

P

Product			
◀ 405			
1.9 i [15]	**1,9 l 88 kW DKZ,DFY <XU9JAZ Kat.> 4 Zyl.**		
Throttle valve sensor	07.88-12.92		**0 280 120 327**
Speed sensor, ignition/injection	07.88-12.92		**0 261 210 043**
Temperature sensor, coolant, injection system	07.88-12.92		**0 280 130 026**
Acceleration sensor, ABS	07.88-12.92		**0 265 005 111**
Wheel speed sensor, front	07.88-12.92	AA,BO	**0 265 006 314**
	10.89-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	10.89-06.92	BO,OAA	**0 265 003 065**
1.9 i [15]	**1,9 l 90-92 kW D6A <XU9J2> 4 Zyl.**		
Throttle valve sensor	07.87-12.92		**0 280 120 327**
Air flow sensor, gasoline injection	07.87-12.92		**0 280 202 602**
			0 986 280 019
Temperature sensor, coolant, injection system	07.87-12.92		**0 280 130 026**
Acceleration sensor, ABS	07.87-12.92		**0 265 005 111**
Wheel speed sensor, front	07.87-12.92	AA,BO	**0 265 006 314**
	10.89-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	10.89-06.92	BO,OAA	**0 265 003 065**
1.9 i [15]	**1,9 l 90-92 kW D6D <XU9J2> 4 Zyl.**		
Speed sensor, ignition/injection	07.87-12.92		**0 261 210 043**
Temperature sensor, coolant, injection system	07.87-12.92		**0 280 130 026**
Acceleration sensor, ABS	07.87-12.92		**0 265 005 111**
Wheel speed sensor, front	07.87-12.92	AA,BO	**0 265 006 314**
	10.89-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	10.89-06.92	BO,OAA	**0 265 003 065**
1.9 i 16V [15]	**1,9 l 108-111/116 kW DFW <XU9J4Z Kat.>; D6C <XU9J4/K> 4 Zyl.**		
Throttle valve sensor	07.87-12.92		**0 280 120 327**
Speed sensor, ignition/injection	07.87-12.92		**0 261 210 043**
Knock sensor	03.88-12.92		**0 261 231 006**
Temperature sensor, coolant, injection system	07.87-12.92		**0 280 130 026**
Acceleration sensor, ABS	07.87-12.92		**0 265 005 111**
Wheel speed sensor, front	07.87-12.92	AA,BO	**0 265 006 314**
	10.89-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	10.89-06.92	BO,OAA	**0 265 003 065**
2.0 i [4]	**2,0 l 89 kW RFX <XU10J2 Kat.>; R6D <XU10J2> 4 Zyl.**		
Knock sensor	06.92-04.97	BO	**0 261 231 071**
Acceleration sensor, ABS	06.92-04.97		**0 265 005 111**
Wheel speed sensor, front	06.92-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-04.97	BO	**0 265 006 315**
2.0 i Mi16 [4]	**2,0 l 110-118 kW RFT <XU10J4>; RFY <XU10J4> 4 Zyl.**		
Throttle valve sensor	01.93-06.95		**0 280 122 001**
	07.95-04.97		**0 280 122 003**
Knock sensor	01.93-04.97	BO	**0 261 231 071**
Acceleration sensor, ABS	01.93-04.97		**0 265 005 111**
Wheel speed sensor, front	01.93-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	01.93-04.97	BO	**0 265 006 315**
2.0 i T16 4x4 [4]	**2,0 l 144-159 kW RGZ <XU10J4TE> 4 Zyl.**		
Knock sensor	09.92-04.97	BO	**0 261 231 071**
Acceleration sensor, ABS	09.92-04.97		**0 265 005 111**
Wheel speed sensor, front	09.92-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	09.92-04.97	BO	**0 265 003 081**
2.0 i 4x4 [4]	**2,0 l 89 kW RFX <XU10J2 Kat.> 4 Zyl.**		
Knock sensor	06.92-04.97	BO	**0 261 231 071**
Acceleration sensor, ABS	06.92-04.97		**0 265 005 111**
Wheel speed sensor, front	06.92-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-04.97	BO	**0 265 003 081**

405 Break

Product			
1.4 [4]	**1,4 l 55 kW K2D <TU3.2> 4 Zyl.**		
Wheel speed sensor, front	06.92-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-04.97	BO	**0 265 006 315**
1.4 [15]	**1,4 l 55 kW K2D 4 Zyl.**		
Wheel speed sensor, front	06.91-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-09.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-09.92	BO	**0 265 006 315**
	06.91-06.92	BO,OAA	**0 265 003 065**
1.4 i [4]	**1,4 l 55 kW KDX <TU3MC Kat.> 4 Zyl.**		
Temperature sensor, coolant, injection system	06.92-04.97		**0 280 130 026**
Wheel speed sensor, front	06.92-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-04.97	BO	**0 265 006 315**
1.6 [4]	**1,6 l 65/68 kW B2A <XU52C>; B5A <XU52C> 4 Zyl.**		
Wheel speed sensor, front	06.92-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-04.97	BO	**0 265 006 315**
1.6 [15]	**1,6 l 53/65/68 kW B1D,B1E; B2A, B2B, B2C; B5A 4 Zyl.**		
Wheel speed sensor, front	10.89-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	10.89-06.92	BO,OAA	**0 265 003 065**
1.6 i [4]	**1,6 l 65 kW BDY <XU5M Kat.> 4 Zyl.**		
Temperature sensor, intake air, injection system	06.92-04.97		**0 280 130 039**
Wheel speed sensor, front	06.92-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-04.97	BO	**0 265 006 315**
1.6 i [4]	**1,6 l 65 kW BFZ <XU5JP> 4 Zyl.**		
Wheel speed sensor, front	09.94-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	09.94-04.97	BO	**0 265 006 315**
1.6 i [15]	**1,6 l 65 kW BDY 4 Zyl.**		
Wheel speed sensor, front	09.90-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	09.90-06.92	BO,OAA	**0 265 003 065**
1.6 i [15]	**1,6 l 65 kW BDZ 4 Zyl.**		
Wheel speed sensor, front	10.89-09.90	BO,OAA	**0 265 003 064**
Wheel speed sensor, rear	10.89-09.90	BO,OAA	**0 265 003 065**
1.8 D Turbo [15]	**1,8 l 64-66 kW AJZ; A8A,A8B 4 Zyl.**		
Wheel speed sensor, front	10.89-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	10.89-06.92	BO,OAA	**0 265 003 065**
1.8 i [4]	**1,8 l 74 kW LFZ <XU7JP Kat.>; L6A <XU7JP> 4 Zyl.**		
Pressure sensor, intake manifold, gasoline	06.92-04.97	BO	**0 261 230 004**
Wheel speed sensor, front	06.92-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-04.97	BO	**0 265 006 315**
1.9 [4]	**1,9 l 71/80 kW D2H <XU92C>; D5A <XU92C> 4 Zyl.**		
Wheel speed sensor, front	06.92-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-04.97	BO	**0 265 006 315**
1.9 [15]	**1,9 l 70/71 kW D2C; D5A 4 Zyl.**		
Wheel speed sensor, front	10.89-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	10.89-06.92	BO,OAA	**0 265 003 065**
1.9 [15]	**1,9 l 80/81 kW D2D; D2H 4 Zyl.**		
Wheel speed sensor, front	07.88-12.92	AA,BO	**0 265 006 314**
	10.89-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	10.89-06.92	BO,OAA	**0 265 003 065**
1.9 D [4]	**1,9 l 47/50/51 kW DJY,DJZ <XUD9Y>; D9B <XUD9A> 4 Zyl.**		
Wheel speed sensor, front	06.92-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-04.97	BO	**0 265 006 315**

Product			
1.9 D [15]			**1,9 l 47/51 kW DJZ; D9B 4 Zyl.**
Wheel speed sensor, front	10.89-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	10.89-06.92	BO,OAA	**0 265 003 065**
1.9 D Turbo [4]			**1,9 l 66-68 kW DHY <XUD9TE Kat.>; D8A <XUD9TE> 4 Zyl.**
Wheel speed sensor, front	06.92-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-04.97	BO	**0 265 006 315**
1.9 i [4]			**1,9 l 89 kW D6D <XU9J2> 4 Zyl.**
Throttle valve sensor	06.92-04.97		**0 280 122 001**
Speed sensor, ignition/injection	06.92-04.97		**0 261 210 043**
Temperature sensor, intake air, injection system	06.92-04.97		**0 280 130 039**
Temperature sensor, coolant, injection system	06.92-04.97		**0 280 130 026**
Acceleration sensor, ABS	06.92-04.97		**0 265 005 111**
Wheel speed sensor, front	06.92-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-04.97	BO	**0 265 006 315**
1.9 i [15]			**1,9 l 77 kW DFZ 4 Zyl.**
Throttle valve sensor	07.88-12.92		**0 280 120 327**
Air flow sensor, gasoline injection	07.88-12.92		**0 280 202 097**
			0 986 280 070
Temperature sensor, coolant, injection system	07.88-12.92		**0 280 130 026**
Relay, Jetronic	07.88-12.92		**0 280 230 006**
Acceleration sensor, ABS	07.88-12.92		**0 265 005 111**
Wheel speed sensor, front	07.88-12.92	AA,BO	**0 265 006 314**
	10.89-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	10.89-06.92	BO,OAA	**0 265 003 065**
1.9 i [15]			**1,9 l 80 kW DDZ 4 Zyl.**
Temperature sensor, coolant, injection system	07.88-12.92		**0 280 130 026**
Acceleration sensor, ABS	07.88-12.92		**0 265 005 111**
Wheel speed sensor, front	07.88-12.92	AA,BO	**0 265 006 314**
	10.89-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	10.89-06.92	BO,OAA	**0 265 003 065**
1.9 i [15]			**1,9 l 88 kW DKZ,DFY 4 Zyl.**
Throttle valve sensor	07.88-12.92		**0 280 120 327**
Speed sensor, ignition/injection	07.88-12.92		**0 261 210 043**
Temperature sensor, coolant, injection system	07.88-12.92		**0 280 130 026**
Acceleration sensor, ABS	07.88-12.92		**0 265 005 111**
Wheel speed sensor, front	07.88-12.92	AA,BO	**0 265 006 314**
	10.89-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	10.89-06.92	BO,OAA	**0 265 003 065**
1.9 i [15]			**1,9 l 90-92 kW D6A 4 Zyl.**
Throttle valve sensor	07.88-12.92		**0 280 120 327**
Air flow sensor, gasoline injection	07.88-12.92		**0 280 202 602**
			0 986 280 019
Temperature sensor, coolant, injection system	07.88-12.92		**0 280 130 026**
Acceleration sensor, ABS	07.88-12.92		**0 265 005 111**
Wheel speed sensor, front	07.88-12.92	AA,BO	**0 265 006 314**
	10.89-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	10.89-06.92	BO,OAA	**0 265 003 065**
1.9 i [15]			**1,9 l 90-92 kW D6D 4 Zyl.**
Speed sensor, ignition/injection	07.88-12.92		**0 261 210 043**
Temperature sensor, coolant, injection system	07.88-12.92		**0 280 130 026**
Acceleration sensor, ABS	07.88-12.92		**0 265 005 111**

Product			
Wheel speed sensor, front	07.88-12.92	AA,BO	**0 265 006 314**
	10.89-06.92	BO,OAA	**0 265 003 064**
Fg.no. →S71021434	06.92-12.92	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-12.92	BO	**0 265 006 315**
	10.89-06.92	BO,OAA	**0 265 003 065**
2.0 i [4]			**2,0 l 89 kW RFX <XU10J2 Kat.>; R6D <XU10J2> 4 Zyl.**
Knock sensor	06.92-04.97	BO	**0 261 231 071**
Acceleration sensor, ABS	06.92-04.97		**0 265 005 111**
Wheel speed sensor, front	06.92-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-04.97	BO	**0 265 006 315**
2.0 i 4x4 [4]			**2,0 l 89 kW RFX <XU10J2 Kat.> 4 Zyl.**
Knock sensor	06.92-04.97	BO	**0 261 231 071**
Wheel speed sensor, front	06.92-04.97	BO	**0 265 006 314**
Wheel speed sensor, rear	06.92-04.97	BO	**0 265 003 081**

406

1.6 i [D8]			**1,6 l 65 kW BFZ 4 Zyl.**
Wheel speed sensor, front	10.95-03.99		**0 265 006 205**
Wheel speed sensor, rear	10.95-03.99		**0 265 006 206**
1.6 i [D9]			**1,6 l 65 kW BFZ 4 Zyl.**
Yaw rate sensor, brake system			
Org.no. →9064	04.99-09.01		**0 265 005 290**
Org.no. 9065→	10.01-06.04		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	04.99-06.04		**0 265 005 404**
Wheel speed sensor, front	04.99-06.04		**0 265 006 205**
Wheel speed sensor, rear	04.99-06.04		**0 265 006 206**
1.8 i [D8]			**1,8 l 66 kW LFX 4 Zyl.**
Pressure sensor, intake manifold, gasoline			
Org.no. →8028	09.97-11.98		**0 261 230 012**
Wheel speed sensor, front	09.97-03.99		**0 265 006 205**
Wheel speed sensor, rear	09.97-03.99		**0 265 006 206**
1.8 i [D8]			**1,8 l 74-76 kW L6A 4 Zyl.**
Wheel speed sensor, front	12.95-03.99		**0 265 006 205**
Wheel speed sensor, rear	12.95-03.99		**0 265 006 206**
1.8 i [D9]			**1,8 l 66/74-76 kW LFX; L6A 4 Zyl.**
Yaw rate sensor, brake system			
Org.no. →9064	04.99-09.01		**0 265 005 290**
Org.no. 9065→	10.01-06.04		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	04.99-06.04		**0 265 005 404**
Wheel speed sensor, front	04.99-06.04		**0 265 006 205**
Wheel speed sensor, rear	04.99-06.04		**0 265 006 206**
1.8 i 16V [D8]			**1,8 l 81-82 kW LFY 4 Zyl.**
Throttle valve sensor	09.97-03.99	GS	**0 280 122 003**
Knock sensor	10.95-03.99	AG	**0 261 231 109**
Pressure sensor, intake manifold, gasoline			
Org.no. →8028	10.95-11.98		**0 261 230 012**
Wheel speed sensor, front	10.95-03.99		**0 265 006 205**
Wheel speed sensor, rear	10.95-03.99		**0 265 006 206**
1.8 i 16V [D9]			**1,8 l 81-82 kW LFY 4 Zyl.**
Throttle valve sensor	04.99-06.04	GS	**0 280 122 003**
Knock sensor	04.99-06.04	BO	**0 261 231 130**
Pressure sensor, intake manifold, gasoline	04.99-06.04	NGA	**0 261 230 057**
Yaw rate sensor, brake system			
Org.no. →9064	04.99-09.01		**0 265 005 290**
Org.no. 9065→	10.01-06.04		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	04.99-06.04		**0 265 005 404**
Wheel speed sensor, front	04.99-06.04		**0 265 006 205**
Wheel speed sensor, rear	04.99-06.04		**0 265 006 206**

P

Product			
◀ 406			
1.8 i 16V [D9]			**1,8 l 85 kW 6FZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.00-06.04	NGA	**0 261 230 057**
Yaw rate sensor, brake system			
Org.no. →9064	10.00-09.01		**0 265 005 290**
Org.no. 9065→	10.01-06.04		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	10.00-06.04		**0 265 005 404**
Wheel speed sensor, front	10.00-06.04		**0 265 006 205**
Wheel speed sensor, rear	10.00-06.04		**0 265 006 206**
1.9 D Turbo [D8]			**1,9 l 55/66-68 kW DHW; DHX; D8B 4 Zyl.**
Wheel speed sensor, front	12.95-03.99		**0 265 006 205**
Wheel speed sensor, rear	12.95-03.99		**0 265 006 206**
2.0 HDi [D8]			**2,0 l 80 kW RHZ 4 Zyl.**
Wheel speed sensor, front	10.98-03.99		**0 265 006 205**
Wheel speed sensor, rear	10.98-03.99		**0 265 006 206**
2.0 HDi [D9]			**2,0 l 66/79/80 kW RHS; RHY; RHZ 4 Zyl.**
High-pressure sensor (CR system)	04.99-06.04		**0 281 002 283**
Yaw rate sensor, brake system			
Org.no. →9064	04.99-09.01		**0 265 005 290**
Org.no. 9065→	10.01-06.04		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	04.99-06.04		**0 265 005 404**
Wheel speed sensor, front	04.99-06.04		**0 265 006 205**
Wheel speed sensor, rear	04.99-06.04		**0 265 006 206**
2.0 HPi [D9]			**2,0 l 103 kW RLZ 4 Zyl.**
Yaw rate sensor, brake system			
Org.no. →9064	10.00-09.01		**0 265 005 290**
Org.no. 9065→	10.01-06.04		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	10.00-06.04		**0 265 005 404**
Wheel speed sensor, front	10.00-06.04		**0 265 006 205**
Wheel speed sensor, rear	10.00-06.04		**0 265 006 206**
2.0 i Turbo [D8]			**2,0 l 108-110 kW RGX 4 Zyl.**
Throttle valve sensor	04.96-03.99		**0 280 122 003**
Knock sensor	04.96-03.99		**0 261 231 109**
Wheel speed sensor, front	04.96-03.99		**0 265 006 205**
Wheel speed sensor, rear	04.96-03.99		**0 265 006 206**
2.0 i 16V [D8]			**2,0 l 97-99 kW RFV; R6E 4 Zyl.**
Throttle valve sensor	10.95-03.99	AG	**0 280 122 005**
		GS	**0 280 122 003**
Knock sensor			
Org.no. →7664	10.95-11.97		**0 261 231 109**
Org.no. 7665→	12.97-03.99		**0 261 231 045**
Pressure sensor, intake manifold, gasoline			
Org.no. 7329→	01.97-03.99		**0 261 230 012**
Wheel speed sensor, front	10.95-03.99		**0 265 006 205**
Wheel speed sensor, rear	10.95-03.99		**0 265 006 206**
2.0 i 16V [D9]			**2,0 l 97 kW RFV 4 Zyl.**
Throttle valve sensor	04.99-06.04	AG	**0 280 122 005**
		GS	**0 280 122 003**
Knock sensor	04.99-06.04		**0 261 231 130**
Pressure sensor, intake manifold, gasoline	04.99-06.04		**0 261 230 034**
Yaw rate sensor, brake system			
Org.no. →9064	04.99-09.01		**0 265 005 290**
Org.no. 9065→	10.01-06.04		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	04.99-06.04		**0 265 005 404**
Wheel speed sensor, front	04.99-06.04		**0 265 006 205**
Wheel speed sensor, rear	04.99-06.04		**0 265 006 206**
2.0 i 16V [D9]			**2,0 l 99 kW RFR 4 Zyl.**
Pressure sensor, intake manifold, gasoline	04.99-08.00		**0 261 230 034**
Yaw rate sensor, brake system	04.99-08.00		**0 265 005 290**
Steering angle sensor, ESP (electronic stability program)	04.99-08.00		**0 265 005 404**
Wheel speed sensor, front	04.99-08.00		**0 265 006 205**
Wheel speed sensor, rear	04.99-08.00		**0 265 006 206**
2.0 i 16V [D9]			**2,0 l 100 kW RFN 4 Zyl.**
Yaw rate sensor, brake system			
Org.no. →9064	08.00-09.01		**0 265 005 290**
Org.no. 9065→	10.01-06.04		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	08.00-06.04		**0 265 005 404**
Wheel speed sensor, front	08.00-06.04		**0 265 006 205**
Wheel speed sensor, rear	08.00-06.04		**0 265 006 206**
2.1 D Turbo [D8]			**2,1 l 80-81 kW P8C 4 Zyl.**
Temperature sensor, intake air, diesel	12.95-03.99		**0 280 130 039**
Wheel speed sensor, front	12.95-03.99		**0 265 006 205**
Wheel speed sensor, rear	12.95-03.99		**0 265 006 206**
2.2 HDi [D9]			**2,2 l 98 kW 4HX 4 Zyl.**
High-pressure sensor (CR system)	03.00-06.04		**0 281 002 283**
Yaw rate sensor, brake system			
Org.no. →9064	03.00-09.01		**0 265 005 290**
Org.no. 9065→	10.01-06.04		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	03.00-06.04		**0 265 005 404**
Wheel speed sensor, front	03.00-06.04		**0 265 006 205**
Wheel speed sensor, rear	03.00-06.04		**0 265 006 206**
2.2 i 16V [D9]			**2,2 l 116 kW 3FZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	04.99-06.04		**0 261 230 057**
Yaw rate sensor, brake system			
Org.no. →9064	04.99-09.01		**0 265 005 290**
Org.no. 9065→	10.01-06.04		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	04.99-06.04		**0 265 005 404**
Wheel speed sensor, front	04.99-06.04		**0 265 006 205**
Wheel speed sensor, rear	04.99-06.04		**0 265 006 206**
3.0 i [D8]			**3,0 l 140 kW XFZ 6 Zyl.**
Knock sensor	08.96-03.99		**0 261 231 125**
Pressure sensor, intake manifold, gasoline			
Org.no. →8028	08.96-11.98		**0 261 230 012**
Wheel speed sensor, front	08.96-03.99		**0 265 006 205**
Wheel speed sensor, rear	08.96-03.99		**0 265 006 206**
3.0 i [D9]			**3,0 l 140 kW XFZ 6 Zyl.**
Throttle valve sensor	04.99-06.04		**0 280 122 009**
Knock sensor	04.99-06.04		**0 261 231 125**
Pressure sensor, intake manifold, gasoline	04.99-06.04		**0 261 230 034**
Yaw rate sensor, brake system			
Org.no. →9064	04.99-09.01		**0 265 005 290**
Org.no. 9065→	10.01-06.04		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	04.99-06.04		**0 265 005 404**
Wheel speed sensor, front	04.99-06.04		**0 265 006 205**
Wheel speed sensor, rear	04.99-06.04		**0 265 006 206**
3.0 i [D9]			**3,0 l 150 kW XFX 6 Zyl.**
Throttle valve assembly	12.99-06.04		**0 280 750 041**
Knock sensor	12.99-06.04	KZB	**0 261 231 071**
Pressure sensor, intake manifold, gasoline	12.99-06.04		**0 261 230 041**
Yaw rate sensor, brake system			
Org.no. →9064	12.99-09.01		**0 265 005 290**
Org.no. 9065→	10.01-06.04		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	12.99-06.04		**0 265 005 404**
Wheel speed sensor, front	12.99-06.04		**0 265 006 205**
Wheel speed sensor, rear	12.99-06.04		**0 265 006 206**

P

Product			

406 Break

1.8 i [D8]			**1,8 l 66 kW LFX 4 Zyl.**
Pressure sensor, intake manifold, gasoline			
Org.no. →8028	09.97-11.98		**0 261 230 012**
Wheel speed sensor, front	09.97-03.99		**0 265 006 205**
Wheel speed sensor, rear	09.97-03.99		**0 265 006 206**
1.8 i [D8]			**1,8 l 74-76 kW L6A 4 Zyl.**
Wheel speed sensor, front	10.96-03.99		**0 265 006 205**
Wheel speed sensor, rear	10.96-03.99		**0 265 006 206**
1.8 i [D9]			**1,8 l 66/74-76 kW LFX; L6A 4 Zyl.**
Yaw rate sensor, brake system			
Org.no. →9064	04.99-09.01		**0 265 005 290**
Org.no. 9065→	10.01-06.04		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	04.99-06.04		**0 265 005 404**
Wheel speed sensor, front	04.99-06.04		**0 265 006 205**
Wheel speed sensor, rear	04.99-06.04		**0 265 006 206**
1.8 i 16V [D8]			**1,8 l 81-82 kW LFY 4 Zyl.**
Throttle valve sensor	09.97-03.99	GS	**0 280 122 003**
Knock sensor	10.96-03.99	AG	**0 261 231 109**
Pressure sensor, intake manifold, gasoline			
Org.no. →8028	10.96-11.98		**0 261 230 012**
Wheel speed sensor, front	10.96-03.99		**0 265 006 205**
Wheel speed sensor, rear	10.96-03.99		**0 265 006 206**
1.8 i 16V [D9]			**1,8 l 81 kW LFY 4 Zyl.**
Throttle valve sensor	04.99-06.04	GS	**0 280 122 003**
Knock sensor	04.99-06.04	BO	**0 261 231 130**
Pressure sensor, intake manifold, gasoline	04.99-06.04	NGA	**0 261 230 057**
Yaw rate sensor, brake system			
Org.no. →9064	04.99-09.01		**0 265 005 290**
Org.no. 9065→	10.01-06.04		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	04.99-06.04		**0 265 005 404**
Wheel speed sensor, front	04.99-06.04		**0 265 006 205**
Wheel speed sensor, rear	04.99-06.04		**0 265 006 206**
1.8 i 16V [D9]			**1,8 l 85 kW 6FZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.00-06.04	NGA	**0 261 230 057**
Yaw rate sensor, brake system			
Org.no. →9064	10.00-09.01		**0 265 005 290**
Org.no. 9065→	10.01-06.04		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	10.00-06.04		**0 265 005 404**
Wheel speed sensor, front	10.00-06.04		**0 265 006 205**
Wheel speed sensor, rear	10.00-06.04		**0 265 006 206**
1.9 D Turbo [D8]			**1,9 l 55/66-68 kW DHW; DHX; D8B 4 Zyl.**
Wheel speed sensor, front	10.96-03.99		**0 265 006 205**
Wheel speed sensor, rear	10.96-03.99		**0 265 006 206**
2.0 HDi [D8]			**2,0 l 80 kW RHZ 4 Zyl.**
Wheel speed sensor, front	10.98-03.99		**0 265 006 205**
Wheel speed sensor, rear	10.98-03.99		**0 265 006 206**
2.0 HDi [D9]			**2,0 l 66/79/80 kW RHS; RHY; RHZ 4 Zyl.**
High-pressure sensor (CR system)	04.99-06.04		**0 281 002 283**
Yaw rate sensor, brake system			
Org.no. →9064	04.99-09.01		**0 265 005 290**
Org.no. 9065→	10.01-06.04		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	04.99-06.04		**0 265 005 404**
Wheel speed sensor, front	04.99-06.04		**0 265 006 205**
Wheel speed sensor, rear	04.99-06.04		**0 265 006 206**

Product			

2.0 HPi [D9]			**2,0 l 103 kW RLZ 4 Zyl.**
Yaw rate sensor, brake system			
Org.no. →9064	10.00-09.01		**0 265 005 290**
Org.no. 9065→	10.01-06.04		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	10.00-06.04		**0 265 005 404**
Wheel speed sensor, front	10.00-06.04		**0 265 006 205**
Wheel speed sensor, rear	10.00-06.04		**0 265 006 206**
2.0 i Turbo [D8]			**2,0 l 108-110 kW RGX 4 Zyl.**
Throttle valve sensor	10.96-03.99		**0 280 122 003**
Knock sensor	10.96-03.99		**0 261 231 109**
Wheel speed sensor, front	10.96-03.99		**0 265 006 205**
Wheel speed sensor, rear	10.96-03.99		**0 265 006 206**
2.0 i 16V [D8]			**2,0 l 97-99 kW RFV; R6E 4 Zyl.**
Throttle valve sensor	10.96-03.99	AG	**0 280 122 005**
		GS	**0 280 122 003**
Knock sensor			
Org.no. →7664	10.96-11.97		**0 261 231 109**
Org.no. 7665→	12.97-03.99		**0 261 231 045**
Pressure sensor, intake manifold, gasoline			
Org.no. 7329→	01.97-03.99		**0 261 230 012**
Wheel speed sensor, front	10.96-03.99		**0 265 006 205**
Wheel speed sensor, rear	10.96-03.99		**0 265 006 206**
2.0 i 16V [D9]			**2,0 l 97 kW RFV 4 Zyl.**
Throttle valve sensor	04.99-06.04	AG	**0 280 122 005**
		GS	**0 280 122 003**
Knock sensor	04.99-06.04		**0 261 231 130**
Pressure sensor, intake manifold, gasoline	04.99-06.04		**0 261 230 034**
Yaw rate sensor, brake system			
Org.no. →9064	04.99-09.01		**0 265 005 290**
Org.no. 9065→	10.01-06.04		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	04.99-06.04		**0 265 005 404**
Wheel speed sensor, front	04.99-06.04		**0 265 006 205**
Wheel speed sensor, rear	04.99-06.04		**0 265 006 206**
2.0 i 16V [D9]			**2,0 l 99 kW RFR 4 Zyl.**
Pressure sensor, intake manifold, gasoline	04.99-10.00		**0 261 230 034**
Yaw rate sensor, brake system	04.99-10.00		**0 265 005 290**
Steering angle sensor, ESP (electronic stability program)	04.99-10.00		**0 265 005 404**
Wheel speed sensor, front	04.99-10.00		**0 265 006 205**
Wheel speed sensor, rear	04.99-10.00		**0 265 006 206**
2.0 i 16V [D9]			**2,0 l 100 kW RFN 4 Zyl.**
Yaw rate sensor, brake system			
Org.no. →9064	10.00-09.01		**0 265 005 290**
Org.no. 9065→	10.01-06.04		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	10.00-06.04		**0 265 005 404**
Wheel speed sensor, front	10.00-06.04		**0 265 006 205**
Wheel speed sensor, rear	10.00-06.04		**0 265 006 206**
2.1 D Turbo [D8]			**2,1 l 80-81 kW P8C 4 Zyl.**
Temperature sensor, intake air, diesel	10.96-03.99		**0 280 130 039**
Wheel speed sensor, front	10.96-03.99		**0 265 006 205**
Wheel speed sensor, rear	10.96-03.99		**0 265 006 206**
2.2 HDi [D9]			**2,2 l 98 kW 4HX 4 Zyl.**
High-pressure sensor (CR system)	03.00-06.04		**0 281 002 283**
Yaw rate sensor, brake system			
Org.no. →9064	03.00-09.01		**0 265 005 290**
Org.no. 9065→	10.01-06.04		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	03.00-06.04		**0 265 005 404**
Wheel speed sensor, front	03.00-06.04		**0 265 006 205**
Wheel speed sensor, rear	03.00-06.04		**0 265 006 206**

P

Product			
◀ 406 Break			
2.2 i 16V [D9]			**2,2 l 116 kW 3FZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	04.99-06.04		**0 261 230 057**
Yaw rate sensor, brake system			
Org.no. →9064	04.99-09.01		**0 265 005 290**
Org.no. 9065→	10.01-06.04		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	04.99-06.04		**0 265 005 404**
Wheel speed sensor, front	04.99-06.04		**0 265 006 205**
Wheel speed sensor, rear	04.99-06.04		**0 265 006 206**
3.0 i [D8]			**3,0 l 140 kW XFZ 6 Zyl.**
Knock sensor	10.96-03.99		**0 261 231 125**
Pressure sensor, intake manifold, gasoline			
Org.no. →8028	10.96-11.98		**0 261 230 012**
Wheel speed sensor, front	10.96-03.99		**0 265 006 205**
Wheel speed sensor, rear	10.96-03.99		**0 265 006 206**
3.0 i [D9]			**3,0 l 140 kW XFZ 6 Zyl.**
Throttle valve sensor	04.99-06.04		**0 280 122 009**
Knock sensor	04.99-06.04		**0 261 231 125**
Pressure sensor, intake manifold, gasoline	04.99-06.04		**0 261 230 034**
Yaw rate sensor, brake system			
Org.no. →9064	04.99-09.01		**0 265 005 290**
Org.no. 9065→	10.01-06.04		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	04.99-06.04		**0 265 005 404**
Wheel speed sensor, front	04.99-06.04		**0 265 006 205**
Wheel speed sensor, rear	04.99-06.04		**0 265 006 206**
3.0 i [D9]			**3,0 l 150 kW XFX 6 Zyl.**
Throttle valve assembly	12.99-06.04		**0 280 750 041**
Knock sensor	12.99-06.04	KZB	**0 261 231 071**
Pressure sensor, intake manifold, gasoline	12.99-06.04		**0 261 230 041**
Yaw rate sensor, brake system			
Org.no. →9064	12.99-09.01		**0 265 005 290**
Org.no. 9065→	10.01-06.04		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	12.99-06.04		**0 265 005 404**
Wheel speed sensor, front	12.99-06.04		**0 265 006 205**
Wheel speed sensor, rear	12.99-06.04		**0 265 006 206**

406 Coupé

1.8 i 16V [D8]			**1,8 l 81 kW LFY 4 Zyl.**
Throttle valve sensor	09.97-03.99	GS	**0 280 122 003**
Knock sensor	09.97-03.99	AG	**0 261 231 109**
Pressure sensor, intake manifold, gasoline			
Org.no. →8028	09.97-11.98		**0 261 230 012**
Wheel speed sensor, front	09.97-03.99		**0 265 006 205**
Wheel speed sensor, rear	09.97-03.99		**0 265 006 206**
2.0 i 16V [D8]			**2,0 l 97-99 kW RFV 4 Zyl.**
Knock sensor			
Org.no. →7664	03.97-11.97		**0 261 231 109**
Org.no. 7665→	12.97-03.99		**0 261 231 045**
Pressure sensor, intake manifold, gasoline			
Org.no. 7329→	03.97-03.99		**0 261 230 012**
Wheel speed sensor, front	03.97-03.99		**0 265 006 205**
Wheel speed sensor, rear	03.97-03.99		**0 265 006 206**
2.0 i 16V [D9]			**2,0 l 97-99 kW RFV 4 Zyl.**
Throttle valve sensor	04.99-02.05	AG	**0 280 122 005**
		GS	**0 280 122 003**
Knock sensor	04.99-02.05		**0 261 231 130**
Pressure sensor, intake manifold, gasoline	04.99-02.05		**0 261 230 034**
Yaw rate sensor, brake system			
Org.no. →9064	04.99-09.01		**0 265 005 290**
Org.no. 9065→	10.01-02.05		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	04.99-02.05		**0 265 005 404**
Wheel speed sensor, front	04.99-02.05		**0 265 006 205**
Wheel speed sensor, rear	04.99-02.05		**0 265 006 206**
2.0 i 16V [D9]			**2,0 l 99 kW RFR 4 Zyl.**
Pressure sensor, intake manifold, gasoline	04.99-10.00		**0 261 230 034**
Yaw rate sensor, brake system	04.99-10.00		**0 265 005 290**
Steering angle sensor, ESP (electronic stability program)	04.99-10.00		**0 265 005 404**
Wheel speed sensor, front	04.99-10.00		**0 265 006 205**
Wheel speed sensor, rear	04.99-10.00		**0 265 006 206**
2.0 i 16V [D9]			**2,0 l 100 kW RFN 4 Zyl.**
Yaw rate sensor, brake system			
Org.no. →9064	10.00-09.01		**0 265 005 290**
Org.no. 9065→	10.01-02.05		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	10.00-02.05		**0 265 005 404**
Wheel speed sensor, front	10.00-02.05		**0 265 006 205**
Wheel speed sensor, rear	10.00-02.05		**0 265 006 206**
2.2 HDi [D9]			**2,2 l 98 kW 4HX 4 Zyl.**
High-pressure sensor (CR system)	03.00-02.05		**0 281 002 283**
Yaw rate sensor, brake system			
Org.no. →9064	03.00-09.01		**0 265 005 290**
Org.no. 9065→	10.01-02.05		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	03.00-02.05		**0 265 005 404**
Wheel speed sensor, front	03.00-02.05		**0 265 006 205**
Wheel speed sensor, rear	03.00-02.05		**0 265 006 206**
2.2 i 16V [D9]			**2,2 l 116 kW 3FZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.02-02.05		**0 261 230 057**
Yaw rate sensor, brake system	03.02-02.05		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	03.02-02.05		**0 265 005 404**
Wheel speed sensor, front	03.02-02.05		**0 265 006 205**
Wheel speed sensor, rear	03.02-02.05		**0 265 006 206**
3.0 i [D8]			**3,0 l 140 kW XFZ 6 Zyl.**
Knock sensor	03.97-03.99		**0 261 231 125**
Pressure sensor, intake manifold, gasoline			
Org.no. →8028	03.97-11.98		**0 261 230 012**
Wheel speed sensor, front	03.97-03.99		**0 265 006 205**
Wheel speed sensor, rear	03.97-03.99		**0 265 006 206**
3.0 i [D9]			**3,0 l 140 kW XFZ 6 Zyl.**
Throttle valve sensor	04.99-02.05		**0 280 122 009**
Knock sensor	04.99-02.05		**0 261 231 125**
Pressure sensor, intake manifold, gasoline	04.99-02.05		**0 261 230 034**
Yaw rate sensor, brake system			
Org.no. →9064	04.99-09.01		**0 265 005 290**
Org.no. 9065→	10.01-02.05		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	04.99-02.05		**0 265 005 404**
Wheel speed sensor, front	04.99-02.05		**0 265 006 205**
Wheel speed sensor, rear	04.99-02.05		**0 265 006 206**
3.0 i [D9]			**3,0 l 150 kW XFX 6 Zyl.**
Throttle valve assembly	12.99-02.05		**0 280 750 041**
Knock sensor	12.99-02.05	KZB	**0 261 231 071**
Pressure sensor, intake manifold, gasoline	12.99-02.05		**0 261 230 041**
Yaw rate sensor, brake system			
Org.no. →9064	12.99-09.01		**0 265 005 290**
Org.no. 9065→	10.01-02.05		**0 265 005 253**
Steering angle sensor, ESP (electronic stability program)	12.99-02.05		**0 265 005 404**
Wheel speed sensor, front	12.99-02.05		**0 265 006 205**
Wheel speed sensor, rear	12.99-02.05		**0 265 006 206**

Product			

407

1.8 i [D2]			**1,8 l 85/92 kW 6FY; 6FZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.04→		**0 261 230 043**
2.0 i [D2]			**2,0 l 103 kW RFJ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.05→		**0 261 230 043**
2.2 i [D2]			**2,2 l 116 kW 3FZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.04→		**0 261 230 057**
2.2 i [D2]			**2,2 l 120 kW 3FY 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.05→		**0 261 230 043**
3.0 i [D2]			**3,0 l 155 kW XFV 6 Zyl.**
Throttle valve assembly	05.04→		**0 280 750 041**
Knock sensor	05.04→	HI,KZB	**0 261 231 130**
		KZG,VO	**0 261 231 071**
Pressure sensor, intake manifold, gasoline	05.04→		**0 261 230 058**

407 Coupé

2.2 i [D2]			**2,2 l 120 kW 3FY 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.05→		**0 261 230 043**
3.0 i [D2]			**3,0 l 155 kW XFV 6 Zyl.**
Throttle valve assembly	10.05→		**0 280 750 041**
Knock sensor	10.05→	HI,KZB	**0 261 231 130**
		KZG,VO	**0 261 231 071**
Pressure sensor, intake manifold, gasoline	10.05→		**0 261 230 058**

407 SW

1.8 i [D2]			**1,8 l 85/92 kW 6FY; 6FZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.04→		**0 261 230 043**
2.0 i [D2]			**2,0 l 103 kW RFJ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.05→		**0 261 230 043**
2.2 i [D2]			**2,2 l 116 kW 3FZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.04→		**0 261 230 057**
2.2 i [D2]			**2,2 l 120 kW 3FY 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.05→		**0 261 230 043**
3.0 i [D2]			**3,0 l 155 kW XFV 6 Zyl.**
Throttle valve assembly	05.04→		**0 280 750 041**
Knock sensor	05.04→	HI,KZB	**0 261 231 130**
		KZG,VO	**0 261 231 071**
Pressure sensor, intake manifold, gasoline	05.04→		**0 261 230 058**

505

2.0 i			**2,0 l 71 kW 4 Zyl.**
Speed relay	07.81-06.87		**0 280 230 100**
			0 280 230 101
2.0 i			**2,0 l 81/83 kW 829B <ZEJ>; 829-90 <ZEJ> 4 Zyl.**
Air flow sensor, gasoline injection	08.79-12.89		**0 438 120 099**
2.2 i			**2,2 l 84 kW 851X <ZDJL Kat.> 4 Zyl.**
Throttle valve sensor	03.86-12.93		**0 280 120 301**
Air flow sensor, gasoline injection	03.86-12.93	KAT	**0 280 202 098**
Temperature sensor, coolant, injection system	03.86-12.93		**0 280 130 026**
Relay, Jetronic	03.86-12.93		**0 280 230 006**
	09.87-12.93		**0 280 230 014**
2.2 i			**2,2 l 90-96 kW 851B,851Y <ZDJL> 4 Zyl.**
Throttle valve sensor	08.83-12.93		**0 280 120 301**
Air flow sensor, gasoline injection	10.85-12.93	AGR,OKA	**0 280 202 070**
	08.83-12.93	OAR	**0 280 202 051**
			0 986 280 051
Temperature sensor, coolant, injection system	08.83-12.93		**0 280 130 026**
Relay, Jetronic	08.83-12.93		**0 280 230 006**

Product			

2.2 i Turbo			**2,2 l 105-116 kW 176W,176X 4 Zyl.**
Throttle valve sensor	03.84-12.88		**0 280 120 305**
Air flow sensor, gasoline injection	03.84-12.88		**0 280 202 057**
Knock sensor	01.86-12.88		**0 261 231 006**
Pressure sensor, intake manifold, gasoline	03.84-12.88		**0 280 101 001**
Temperature sensor, coolant, injection system	03.84-12.88		**0 280 130 026**
Relay, Jetronic	03.84-12.88		**0 280 230 009**
2.2 i Turbo			**2,2 l 114-120 kW 176A,176B, 176C <N9T> 4 Zyl.**
Throttle valve sensor	01.83-06.88		**0 280 120 305**
Air flow sensor, gasoline injection	10.82-06.88	OAR	**0 280 202 044**
Knock sensor	01.86-06.88		**0 261 231 006**
Pressure sensor, intake manifold, gasoline	10.82-06.88		**0 280 101 001**
Temperature sensor, coolant, injection system	01.83-06.88		**0 280 130 026**
Relay, Jetronic	01.83-06.88		**0 280 230 006**
2.3 D Turbo			**2,3 l 54-59 kW 147 4 Zyl.**
Air flow sensor, diesel	09.83-06.86		**0 281 002 008**
2.5 D Turbo			**2,5 l 66-70 kW 152A, 152Y <XD3T> 4 Zyl.**
Air flow sensor, diesel	10.83-12.93		**0 281 002 008**
2.5 D Turbo			**2,5 l 77 kW 152B <XD3TE> 4 Zyl.**
Air flow sensor, diesel	10.86-12.93		**0 281 002 029**
Pulse generator, diesel	10.86-12.93		**0 281 002 030**
Pressure sensor, intake manifold, diesel	10.86-12.93		**0 281 002 018**
Temperature sensor, coolant, diesel	10.86-12.93		**0 280 130 026**
Pedal position sensor, diesel	10.86-12.93		**0 132 009 305**
2.8 i V6			**2,8 l 105/122 kW 154F <ZN3J>; 154X <ZN3J Kat.> 6 Zyl.**
Throttle valve sensor	06.86-12.93		**0 280 120 301**
Air mass meter, gasoline injection	06.86-12.93		**0 280 213 006**
			0 986 280 115
Speed sensor, ignition/injection	06.86-12.93		**0 261 210 029**
Knock sensor	06.86-12.93		**0 261 231 007**
Temperature sensor, coolant, injection system	06.86-12.93		**0 280 130 032**

604

2.8 i V6			**2,8 l 110-114 kW 154A <ZNJK> 6 Zyl.**
Air flow sensor, gasoline injection	06.83-06.86		**0 438 120 065**
Speed relay	06.83-06.86		**0 280 230 112**
Relay, Jetronic	06.83-06.86		**0 280 230 112**

605

2.0 [Y30]			**2,0 l 79/84 kW R2A <XU102C>; R5A <XU102C> 4 Zyl.**
Wheel speed sensor, front	10.89-05.99	BO	**0 265 006 207**
Wheel speed sensor, rear	10.89-05.99	BO	**0 265 006 208**
2.0 i [Y30]			**2,0 l 79 kW RDZ <XU10M KAT.> 4 Zyl.**
Temperature sensor, intake air, injection system	06.89-06.94		**0 280 130 039**
Wheel speed sensor, front	06.89-06.94	BO	**0 265 006 207**
Wheel speed sensor, rear	06.89-06.94	BO	**0 265 006 208**
2.0 i [Y30]			**2,0 l 89-90 kW RFZ <XU10J2 KAT.> 4 Zyl.**
Throttle valve sensor	06.89-06.94		**0 280 122 001**
Pressure sensor, intake manifold, gasoline	06.93-06.94		**0 261 230 004**
Temperature sensor, intake air, injection system	06.89-06.94		**0 280 130 039**
Wheel speed sensor, front	06.89-06.94	BO	**0 265 006 207**
Wheel speed sensor, rear	06.89-06.94	BO	**0 265 006 208**
2.0 i [Y30]			**2,0 l 94 kW R6A <XU10J2> 4 Zyl.**
Throttle valve sensor	10.89-05.99	AG	**0 280 120 323**
	10.89-06.90	GS	**0 280 120 323**
Air flow sensor, gasoline injection	10.89-06.90		**0 280 202 118**
			0 986 280 057
	10.89-05.99	AG	**0 280 202 118**
			0 986 280 057
Temperature sensor, intake air, injection system	10.89-05.99		**0 280 130 039**

P

Product			
◀ 605			
Temperature sensor, coolant, injection system	10.89-09.90		**0 280 130 026**
	10.89-05.99	AG	**0 280 130 026**
Wheel speed sensor, front	10.89-05.99	BO	**0 265 006 207**
Wheel speed sensor, rear	10.89-05.99	BO	**0 265 006 208**
2.0 i Turbo [Y30]	**2,0 l 104 kW RGY <XU10J2TE KAT.> 4 Zyl.**		
Throttle valve sensor	07.92-06.94		**0 280 122 001**
Knock sensor	07.92-06.94	KZG	**0 261 231 071**
Wheel speed sensor, front	07.92-06.94	BO	**0 265 006 207**
Wheel speed sensor, rear	07.92-06.94	BO	**0 265 006 208**
2.0 i Turbo [Y30]	**2,0 l 104-110 kW RGX <XU10J2TE KAT.> 4 Zyl.**		
Throttle valve sensor	07.94-06.95		**0 280 122 001**
	07.95-05.99		**0 280 122 003**
Knock sensor	07.94-05.99		**0 261 231 109**
Wheel speed sensor, front	07.94-05.99	BO	**0 265 006 207**
Wheel speed sensor, rear	07.94-05.99	BO	**0 265 006 208**
2.0 i 16V [Y30]	**2,0 l 97 kW RFV,R6E <XU10J4R KAT.> 4 Zyl.**		
Throttle valve sensor	07.94-05.99		**0 280 122 003**
Knock sensor			
Org.no. →8133	07.94-02.99		**0 261 231 109**
Org.no. 8134→	03.99-05.99		**0 261 231 130**
Pressure sensor, intake manifold, gasoline			
Org.no. 7329→8056	01.97-12.98		**0 261 230 012**
Org.no. 8057→	01.99-05.99		**0 261 230 057**
Wheel speed sensor, front	07.94-05.99	BO	**0 265 006 207**
Wheel speed sensor, rear	07.94-05.99	BO	**0 265 006 208**
2.1 D [Y30]	**2,1 l 60-61 kW PJZ,P9A <XUD11A> 4 Zyl.**		
Wheel speed sensor, front	06.89-06.94	BO	**0 265 006 207**
Wheel speed sensor, rear	06.89-06.94	BO	**0 265 006 208**
2.1 D Turbo [Y30]	**2,1 l 80-81 kW PHZ,P8A,P8B <XUD11ATE> 4 Zyl.**		
Wheel speed sensor, front	06.89-10.96	BO	**0 265 006 207**
Wheel speed sensor, rear	06.89-10.96	BO	**0 265 006 208**
2.1 D Turbo [Y30]	**2,1 l 80-81 kW P8C <XUD11BTE> 4 Zyl.**		
Temperature sensor, intake air, diesel	07.94-05.99		**0 280 130 039**
Pedal position sensor, diesel			
Org.no. →6992	07.94-12.95	GS	**0 205 001 015**
Wheel speed sensor, front	07.94-05.99	BO	**0 265 006 207**
Wheel speed sensor, rear	07.94-05.99	BO	**0 265 006 208**
2.5 D Turbo [Y30]	**2,5 l 94-96 kW THY <DK5ATE> 4 Zyl.**		
Air flow sensor, diesel	07.94-05.99		**0 281 002 128**
Pressure sensor, intake manifold, diesel	07.94-05.99	N03,N07	**0 281 002 063**
		N05	**0 281 002 122**
Temperature sensor, intake air, diesel	07.94-05.99		**0 280 130 039**
Pedal position sensor, diesel	07.94-05.99		**0 205 001 015**
Wheel speed sensor, front	07.94-05.99	BO	**0 265 006 207**
Wheel speed sensor, rear	07.94-05.99	BO	**0 265 006 208**
3.0 i [Y30]	**3,0 l 123 kW SFZ <ZPJ KAT.> 6 Zyl.**		
Knock sensor	10.89-01.91	KZB	**0 261 231 033**
		KZU	**0 261 231 034**
Temperature sensor, intake air, injection system	10.89-10.93		**0 280 130 039**
Wheel speed sensor, front	10.89-10.93	BO	**0 265 006 207**
Wheel speed sensor, rear	10.89-10.93	BO	**0 265 006 208**
3.0 i [Y30]	**3,0 l 123-125 kW UFZ <ZPJ KAT.> 6 Zyl.**		
Throttle valve sensor	07.93-05.99	ASR	**0 280 122 005**
		OAS	**0 280 122 003**
Knock sensor	07.93-05.99	KZB	**0 261 231 070**
		KZG	**0 261 231 071**
Temperature sensor, intake air, injection system	07.93-05.99		**0 280 130 039**
Wheel speed sensor, front	07.93-05.99	BO	**0 265 006 207**
Wheel speed sensor, rear	07.93-05.99	BO	**0 265 006 208**
3.0 i [Y30]	**3,0 l 125 kW S6A <ZPJ> 6 Zyl.**		
Temperature sensor, intake air, injection system	10.89-10.93		**0 280 130 039**
Wheel speed sensor, front	10.89-10.93	BO	**0 265 006 207**
Wheel speed sensor, rear	10.89-10.93	BO	**0 265 006 208**

Product			
3.0 i [Y30]	**3,0 l 140-143 kW XFZ <ES9J4> 6 Zyl.**		
Throttle valve sensor	03.97-05.99		**0 280 122 009**
Knock sensor	03.97-05.99	KZG	**0 261 231 125**
Pressure sensor, intake manifold, gasoline	03.97-05.99		**0 261 230 012**
Wheel speed sensor, front	03.97-05.99	BO	**0 265 006 207**
Wheel speed sensor, rear	03.97-05.99	BO	**0 265 006 208**
3.0 i 24V [Y30]	**3,0 l 147 kW SKZ <ZPJ4 KAT.> 6 Zyl.**		
Knock sensor	06.90-01.91	KZB	**0 261 231 033**
		KZU	**0 261 231 034**
Temperature sensor, intake air, injection system	06.90-09.93		**0 280 130 039**
Wheel speed sensor, front	06.90-09.93	BO	**0 265 006 207**
Wheel speed sensor, rear	06.90-09.93	BO	**0 265 006 208**
3.0 i 24V [Y30]	**3,0 l 147 kW UKZ <ZPJ4 KAT.> 6 Zyl.**		
Throttle valve sensor	07.93-05.99	ASR	**0 280 122 005**
Knock sensor	07.93-05.99	KZB	**0 261 231 070**
		KZG	**0 261 231 071**
Temperature sensor, intake air, injection system	07.93-05.99		**0 280 130 039**
Wheel speed sensor, front	07.93-05.99	BO	**0 265 006 207**
Wheel speed sensor, rear	07.93-05.99	BO	**0 265 006 208**
607			
2.0 HDi [Z8]	**2,0 l 79/80 kW RHS; RHZ 4 Zyl.**		
High-pressure sensor (CR system)	03.00-11.04		**0 281 002 283**
Yaw rate sensor, brake system	03.00-11.04		**0 265 005 290**
Steering angle sensor, ESP (electronic stability program)	03.00-11.04		**0 265 005 404**
Wheel speed sensor, front	03.00-11.04		**0 265 006 544**
Wheel speed sensor, rear	03.00-11.04		**0 265 006 545**
2.0 HDi [Z9]	**2,0 l 79 kW RHS 4 Zyl.**		
High-pressure sensor (CR system)	12.04→		**0 281 002 283**
Yaw rate sensor, brake system			
Org.no. →10919	12.04→		**0 265 005 606**
Org.no. 10920→	12.04→		**0 265 005 629**
2.0 HDi [Z9]	**2,0 l 100 kW RHR / RHL 4 Zyl.**		
Yaw rate sensor, brake system			
Org.no. →10919	03.06→		**0 265 005 606**
Org.no. 10920→	03.06→		**0 265 005 629**
2.0 i 16V [Z8]	**2,0 l 100 kW RFN 4 Zyl.**		
Pressure sensor, intake manifold, gasoline	03.00-11.04		**0 261 230 057**
Yaw rate sensor, brake system	03.00-11.04		**0 265 005 290**
Steering angle sensor, ESP (electronic stability program)	03.00-11.04		**0 265 005 404**
Wheel speed sensor, front	03.00-11.04		**0 265 006 544**
Wheel speed sensor, rear	03.00-11.04		**0 265 006 545**
2.2 HDi [Z8]	**2,2 l 98 kW 4HX 4 Zyl.**		
High-pressure sensor (CR system)	03.00-11.04		**0 281 002 283**
Yaw rate sensor, brake system	03.00-11.04		**0 265 005 290**
Steering angle sensor, ESP (electronic stability program)	03.00-11.04		**0 265 005 404**
Wheel speed sensor, front	03.00-11.04		**0 265 006 544**
Wheel speed sensor, rear	03.00-11.04		**0 265 006 545**
2.2 HDi [Z9]	**2,2 l 98 kW 4HX 4 Zyl.**		
High-pressure sensor (CR system)	12.04→		**0 281 002 283**
Yaw rate sensor, brake system			
Org.no. →10919	12.04→		**0 265 005 606**
Org.no. 10920→	12.04→		**0 265 005 629**
2.2 HDi [Z9]	**2,2 l 125 kW 4H ... 4 Zyl.**		
Yaw rate sensor, brake system			
Org.no. →10919	05.06→		**0 265 005 606**
Org.no. 10920→	05.06→		**0 265 005 629**

P

Product			
2.2 i [Z9]			**2,2 l 116 kW 3FY; 3FZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	12.04→		**0 261 230 057**
Yaw rate sensor, brake system			
Org.no. →10919	12.04→		**0 265 005 606**
Org.no. 10920→	12.04→		**0 265 005 629**
2.2 i 16V [Z8]			**2,2 l 116 kW 3FZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.00-11.04		**0 261 230 034**
Yaw rate sensor, brake system	03.00-11.04		**0 265 005 290**
Steering angle sensor, ESP (electronic stability program)	03.00-11.04		**0 265 005 404**
Wheel speed sensor, front	03.00-11.04		**0 265 006 544**
Wheel speed sensor, rear	03.00-11.04		**0 265 006 545**
2.7 HDi [Z9]			**2,7 l 150 kW UHZ 6 Zyl.**
Yaw rate sensor, brake system			
Org.no. →10919	12.04→		**0 265 005 606**
Org.no. 10920→	12.04→		**0 265 005 629**
3.0 i [Z8]			**2,9 l 152 kW XFX 6 Zyl.**
Throttle valve assembly	03.00-11.04		**0 280 750 041**
Knock sensor	03.00-11.04	KZB	**0 261 231 071**
Pressure sensor, intake manifold, gasoline	03.00-11.04		**0 261 230 041**
Yaw rate sensor, brake system	03.00-11.04		**0 265 005 290**
Steering angle sensor, ESP (electronic stability program)	03.00-11.04		**0 265 005 404**
Wheel speed sensor, front	03.00-11.04		**0 265 006 544**
Wheel speed sensor, rear	03.00-11.04		**0 265 006 545**
3.0 i [Z9]			**3,0 l 155 kW XFV 6 Zyl.**
Throttle valve assembly	12.04→		**0 280 750 041**
Knock sensor	12.04→	HI,KZB	**0 261 231 130**
Pressure sensor, intake manifold, gasoline	12.04→		**0 261 230 058**
Yaw rate sensor, brake system			
Org.no. →10919	12.04→		**0 265 005 606**
Org.no. 10920→	12.04→		**0 265 005 629**

806

1.8 i [U60]			**1,8 l 73 kW LFW 4 Zyl.**
Wheel speed sensor, front			
Org.no. 7481→	06.97-08.02	BO	**0 265 006 388**
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97	BO	**0 265 006 426**
Org.no. 7602→	10.97-08.02	BO	**0 265 006 504**
1.9 D Turbo [U60]			**1,9 l 66-68 kW DHX; D8B 4 Zyl.**
Wheel speed sensor, front			
Org.no. 7481→	06.97-08.02	BO	**0 265 006 388**
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97	BO	**0 265 006 426**
Org.no. 7602→	10.97-08.02	BO	**0 265 006 504**
2.0 HDi [U60]			**2,0 l 80 kW RHZ 4 Zyl.**
High-pressure sensor (CR system)	08.99-08.02	BO	**0 281 002 283**
Wheel speed sensor, front	08.99-08.02		**0 265 006 388**
Wheel speed sensor, rear	08.99-08.02		**0 265 006 504**
2.0 HDi [U60]			**2,0 l 81 kW RHW 4 Zyl.**
High-pressure sensor (CR system)	06.00-08.02		**0 281 002 283**
Wheel speed sensor, front	06.00-08.02		**0 265 006 388**
Wheel speed sensor, rear	06.00-08.02		**0 265 006 504**
2.0 i [U60]			**2,0 l 89-90 kW RFU 4 Zyl.**
Knock sensor			
Org.no. →8133	06.94-02.99		**0 261 231 071**
Org.no. 8134→	03.99-08.02		**0 261 231 130**
Wheel speed sensor, front			
Org.no. 7481→	06.97-08.02	BO	**0 265 006 388**
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97	BO	**0 265 006 426**
Org.no. 7602→	10.97-08.02	BO	**0 265 006 504**
2.0 i Turbo [U60]			**2,0 l 108-110 kW RGX 4 Zyl.**
Throttle valve sensor			
Org.no. →6778	06.94-06.95		**0 280 122 001**
Org.no. 6779→	07.95-08.02		**0 280 122 003**
Knock sensor			
Org.no. →8133	06.94-02.99		**0 261 231 071**
Org.no. 8134→	03.99-08.02		**0 261 231 130**
Wheel speed sensor, front			
Org.no. 7481→	06.97-08.02	BO	**0 265 006 388**
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97	BO	**0 265 006 426**
Org.no. 7602→	10.97-08.02	BO	**0 265 006 504**
2.0 i 16V [U60]			**2,0 l 97-99 kW RFV 4 Zyl.**
Throttle valve sensor	05.98-09.00		**0 280 122 003**
Knock sensor			
Org.no. →8133	05.98-02.99		**0 261 231 109**
Org.no. 8134→	03.99-09.00	EFV	**0 261 231 130**
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	05.98-12.98		**0 261 230 012**
Org.no. 8057→	01.99-09.00		**0 261 230 057**
Wheel speed sensor, front	05.98-09.00		**0 265 006 388**
Wheel speed sensor, rear	05.98-09.00		**0 265 006 504**
2.0 i 16V [U60]			**2,0 l 100 kW RFN 4 Zyl.**
Pressure sensor, intake manifold, gasoline	09.00-08.02		**0 261 230 057**
Wheel speed sensor, front	09.00-08.02		**0 265 006 388**
Wheel speed sensor, rear	09.00-08.02		**0 265 006 504**
2.1 D Turbo [U60]			**2,1 l 80 kW P8C 4 Zyl.**
Temperature sensor, intake air, diesel	04.96-08.00		**0 280 130 039**
Wheel speed sensor, front			
Org.no. 7481→	06.97-08.00	BO	**0 265 006 388**
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97	BO	**0 265 006 426**
Org.no. 7602→	10.97-08.00	BO	**0 265 006 504**

807

2.0 HDi [V2]			**2,0 l 81 kW RHT / RHM; RHW 4 Zyl.**
High-pressure sensor (CR system)	06.02→		**0 281 002 283**
Yaw rate sensor, brake system			
Org.no. →10562	06.02-10.05		**0 265 005 290**
Org.no. 10563→	11.05→		**0 265 005 606**
Wheel speed sensor, front	06.02→	LAB	**0 265 007 083**
		RAB	**0 265 007 084**
2.0 HDi [V2]			**2,0 l 88/100 kW RHK; RHR 4 Zyl.**
Yaw rate sensor, brake system	03.06→		**0 265 005 606**
Wheel speed sensor, front	03.06→	LAB	**0 265 007 083**
		RAB	**0 265 007 084**
2.0 i 16V [V2]			**2,0 l 100 kW RFN 4 Zyl.**
Pressure sensor, intake manifold, gasoline	06.02→		**0 261 230 058**
Yaw rate sensor, brake system	06.02→		**0 265 005 290**
Wheel speed sensor, front	06.02→	LAB	**0 265 007 083**
		RAB	**0 265 007 084**
2.0 i 16V [V2]			**2,0 l 103 kW RFJ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.05→		**0 261 230 043**
Yaw rate sensor, brake system	10.05→		**0 265 005 606**
Wheel speed sensor, front	10.05→	LAB	**0 265 007 083**
		RAB	**0 265 007 084**

P

Product			
◀ 807			
2.2 HDi [V2]			**2,2 l 94 kW 4HW 4 Zyl.**
High-pressure sensor (CR system)	06.02→		**0 281 002 283**
Yaw rate sensor, brake system			
Org.no. →10562	06.02-10.05		**0 265 005 290**
Org.no. 10563→	11.05→		**0 265 005 606**
Wheel speed sensor, front	06.02→	LAB	**0 265 007 083**
		RAB	**0 265 007 084**
2.2 i 16V [V2]			**2,2 l 116 kW 3FZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	06.02→		**0 261 230 057**
Yaw rate sensor, brake system	06.02→		**0 265 005 290**
Wheel speed sensor, front	06.02→	LAB	**0 265 007 083**
		RAB	**0 265 007 084**
3.0 i [V2]			**2,9 l 152 kW XFW 6 Zyl.**
Throttle valve assembly	06.02→		**0 280 750 041**
Pressure sensor, intake manifold, gasoline	06.02→		**0 261 230 058**
Yaw rate sensor, brake system	06.02→		**0 265 005 290**
Wheel speed sensor, front	06.02→	LAB	**0 265 007 083**
		RAB	**0 265 007 084**

P

1007

1.4 i [A8]			**1,4 l 54/65 kW KFU; KFV 4 Zyl.**
Knock sensor	04.05→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	04.05→		**0 261 230 043**
1.6 i [A8]			**1,6 l 80 kW NFU 4 Zyl.**
Throttle valve assembly	04.05→		**0 280 750 085**
Knock sensor	04.05→		**0 261 231 168**
Pressure sensor, intake manifold, gasoline	04.05→		**0 261 230 043**

PONTIAC

Firebird Coupé

5.0 i Trans Am			**5,0 l 142 kW LB9 8 Zyl.**
Air mass meter, gasoline injection	09.86-07.89		**0 280 213 009**
			0 986 280 105
5.7 GTA			**5,7 l 168 kW L98 8 Zyl.**
Air mass meter, gasoline injection	09.87-07.89		**0 280 213 009**
			0 986 280 105

PORSCHE

Boxster

2.5 [986]			**2,5 l 150 kW M 96.20 6 Zyl.**
Throttle valve sensor	10.96-08.99		**0 280 122 016**
Phase sensor	10.96-08.97		**0 232 103 037**
	09.97-08.99	NOC	**0 232 103 022**
Speed sensor, ignition/injection	10.96-08.99		**0 261 210 204**
		EFV	**0 261 210 204**
Knock sensor	10.96-08.99		**0 261 231 120**
		EFV	**0 261 231 148**
Temperature sensor, intake air, injection system	10.96-08.99		**0 280 130 092**
Wheel speed sensor	10.96-08.99		**0 265 006 344**
2.7 [986]			**2,7 l 162 kW M 96.22 6 Zyl.**
Throttle valve assembly	09.99-08.02		**0 280 750 007**
Throttle valve sensor	09.99-08.02		**0 280 122 016**
Phase sensor	09.99-08.02	NOC	**0 232 103 022**
Speed sensor, ignition/injection	09.99-08.02		**0 261 210 204**
		EFV	**0 261 210 204**
Knock sensor	09.99-08.02		**0 261 231 120**
		EFV	**0 261 231 148**
Temperature sensor, intake air, injection system	09.99-08.02		**0 280 130 092**
Pedal position sensor, EMS (electronic engine management)	09.99-08.02		**0 280 752 010**
Wheel speed sensor	09.99-08.01		**0 265 006 344**
	09.01-08.02	MFD	**0 265 006 344**
		OFD	**0 265 007 439**
2.7 [986]			**2,7 l 168 kW M 96.23 6 Zyl.**
Throttle valve assembly	09.02-08.04		**0 280 750 007**
Throttle valve sensor	09.02-08.04		**0 280 122 016**
Phase sensor	09.02-08.04		**0 232 103 040**
Speed sensor, ignition/injection	09.02-08.04		**0 261 210 248**
Knock sensor	09.02-08.04		**0 261 231 120**
		EFV	**0 261 231 148**
Pedal position sensor, EMS (electronic engine management)	09.02-08.04		**0 280 752 010**
Wheel speed sensor	09.02-08.04	MFD	**0 265 006 344**
		OFD	**0 265 007 439**
2.7 [987]			**2,7 l 176/180 kW M 96.25; M 97.20 6 Zyl.**
Throttle valve assembly	09.04→		**0 280 750 007**
Phase sensor	09.04→		**0 232 103 057**
Knock sensor	09.04→		**0 261 231 173**
Wheel speed sensor	09.04→		**0 265 007 624**
3.2 S [986]			**3,2 l 185 kW M 96.21 6 Zyl.**
Throttle valve assembly	09.99-08.02		**0 280 750 007**
Throttle valve sensor	09.99-08.02		**0 280 122 016**
Phase sensor	09.99-08.02	NOC	**0 232 103 022**
Speed sensor, ignition/injection	09.99-08.02		**0 261 210 204**
		EFV	**0 261 210 204**
Knock sensor	09.99-08.02		**0 261 231 120**
		EFV	**0 261 231 148**
Temperature sensor, intake air, injection system	09.99-08.02		**0 280 130 092**
Pedal position sensor, EMS (electronic engine management)	09.99-08.02		**0 280 752 010**
Wheel speed sensor	09.99-08.01		**0 265 006 344**
	09.01-08.02	MFD	**0 265 006 344**
		OFD	**0 265 007 439**
3.2 S [986]			**3,2 l 191-196 kW M 96.24 6 Zyl.**
Throttle valve assembly	09.02-08.04		**0 280 750 007**
Throttle valve sensor	09.02-08.04		**0 280 122 016**
Phase sensor	09.02-08.04		**0 232 103 040**
Speed sensor, ignition/injection	09.02-08.04		**0 261 210 248**
Knock sensor	09.02-08.04		**0 261 231 120**
		EFV	**0 261 231 148**
Pedal position sensor, EMS (electronic engine management)	09.02-08.04		**0 280 752 010**
Wheel speed sensor	09.02-08.04	MFD	**0 265 006 344**
		OFD	**0 265 007 439**
3.2 S [987]			**3,2 l 206 kW M 96.26 6 Zyl.**
Throttle valve assembly	09.04-08.06		**0 280 750 007**
Phase sensor	09.04-08.06		**0 232 103 057**
Knock sensor	09.04-08.06		**0 261 231 173**
Wheel speed sensor	09.04-08.06		**0 265 007 624**
3.4 S [987]			**3,4 l 217 kW M 97.21 6 Zyl.**
Throttle valve assembly	09.06→		**0 280 750 007**
Phase sensor	09.06→		**0 232 103 057**
Knock sensor	09.06→		**0 261 231 173**
Wheel speed sensor	09.06→		**0 265 007 624**

Product			

Carrera GT

5.7			**5,7 l 450 kW M80.01 10 Zyl.**
Throttle valve assembly	10.04→		**0 280 750 007**
Phase sensor	10.04→		**0 232 103 040**
Knock sensor	10.04→		**0 261 231 148**
Pedal position sensor, EMS (electronic engine management)	10.04→		**0 280 752 010**

Cayenne

3.2 [9PA]			**3,2 l 184 kW M02.2Y 6 Zyl.**
Phase sensor	09.02-01.07		**0 232 103 019**
4.5 S [9PA]			**4,5 l 250 kW M48.00 8 Zyl.**
Air mass meter, gasoline injection	09.02-01.07		**0 281 002 435**
			0 986 284 006
Phase sensor	09.02-01.07	NOC	**0 232 103 022**
Speed sensor, ignition/injection	09.02-01.07		**0 261 210 239**
Knock sensor	09.02-01.07		**0 261 231 148**
4.5 Turbo [9PA]			**4,5 l 331/368 kW M48.50 8 Zyl.**
Air mass meter, gasoline injection	09.02-01.07		**0 280 218 071**
			0 986 280 221
Phase sensor	09.02-01.07	NOC	**0 232 103 022**
Speed sensor, ignition/injection	09.02-01.07		**0 261 210 239**
Knock sensor	09.02-01.07		**0 261 231 148**

Cayman

2.7 [987C]			**2,7 l 180 kW M97.20 6 Zyl.**
Phase sensor	09.06→		**0 232 103 057**
Speed sensor, ignition/injection	09.06→		**0 261 210 248**
Knock sensor	09.06→		**0 261 231 173**
Wheel speed sensor	09.06→		**0 265 007 624**

Cayman S

3.4 [987C]			**3,4 l 217 kW M97.21 6 Zyl.**
Phase sensor	11.05→		**0 232 103 057**
Speed sensor, ignition/injection	11.05→		**0 261 210 248**
Knock sensor	11.05→		**0 261 231 173**
Wheel speed sensor	11.05→		**0 265 007 624**

911

3.2 Carrera			**3,2 l 152/160/170 kW 930.20; 930.21; 930.25 6 Zyl.**
Throttle valve sensor	08.83-07.89		**0 280 120 309**
Air flow sensor, gasoline injection	08.83-07.89		**0 280 203 023**
			0 986 280 026
Speed sensor, ignition/injection	08.83-07.89		**0 261 210 005**
Temperature sensor, cylinder head	08.83-07.89		**0 280 130 034**
3.2 Carrera			**3,2 l 170 kW 930.26 6 Zyl.**
Air flow sensor, gasoline injection	08.84-07.88		**0 280 203 023**
			0 986 280 026
Speed sensor, ignition/injection	08.84-07.88		**0 261 210 005**
Temperature sensor, cylinder head	08.84-07.88		**0 280 130 034**
3.3 Turbo			**3,3 l 210 kW 930.68 6 Zyl.**
Throttle valve sensor	08.85-08.89		**0 280 120 107**
3.3 Turbo			**3,3 l 221 kW 930.66 6 Zyl.**
Air flow sensor, gasoline injection	08.82-08.88		**0 438 120 085**
3.3 Turbo [964]			**3,3 l 235 kW 30.69 6 Zyl.**
Throttle valve sensor	12.90-08.92		**0 280 120 107**
Speed sensor, ignition/injection	12.90-08.92		**0 261 210 059**
Knock sensor	12.90-08.92		**0 261 231 018**
Pressure sensor, intake manifold, gasoline	12.90-08.92		**0 280 101 001**
Temperature sensor, intake air, injection system	12.90-08.92		**0 261 220 002**
Wheel speed sensor, front	12.90-08.92		**0 265 001 229**
Wheel speed sensor, rear	12.90-08.92		**0 265 001 146**
3.4 24V Carrera [996]			**3,4 l 220 kW M96.01 6 Zyl.**
Throttle valve sensor	09.97-08.99		**0 280 122 016**
Phase sensor	09.97-08.99	NOC	**0 232 103 022**
Speed sensor, ignition/injection	09.97-08.99		**0 261 210 204**
Knock sensor	09.97-08.99		**0 261 231 120**
Temperature sensor, intake air, injection system	09.97-08.99		**0 280 130 092**
Wheel speed sensor	09.97-08.99		**0 265 006 344**
3.4 24V Carrera [996]			**3,4 l 220 kW M96.04 6 Zyl.**
Throttle valve sensor	09.99-08.01		**0 280 122 016**
Phase sensor	09.99-08.01	NOC	**0 232 103 022**
Speed sensor, ignition/injection	09.99-08.01		**0 261 210 204**
Knock sensor	09.99-08.01		**0 261 231 120**
Temperature sensor, intake air, injection system	09.99-08.01		**0 280 130 092**
Pedal position sensor, EMS (electronic engine management)	09.99-08.01		**0 280 752 010**
Wheel speed sensor	09.99-08.01		**0 265 006 344**
3.4 24V Carrera Cabrio [996]			**3,4 l 220 kW M96.01 6 Zyl.**
Throttle valve sensor	02.98-08.99		**0 280 122 016**
Phase sensor	02.98-08.99	NOC	**0 232 103 022**
Speed sensor, ignition/injection	02.98-08.99		**0 261 210 204**
Knock sensor	02.98-08.99		**0 261 231 120**
Temperature sensor, intake air, injection system	02.98-08.99		**0 280 130 092**
Wheel speed sensor	02.98-08.99		**0 265 006 344**
3.4 24V Carrera 4 [996]			**3,4 l 220 kW M96.02 6 Zyl.**
Throttle valve sensor	09.98-08.99		**0 280 122 016**
Phase sensor	09.98-08.99	NOC	**0 232 103 022**
Speed sensor, ignition/injection	09.98-08.99		**0 261 210 204**
Knock sensor	09.98-08.99		**0 261 231 120**
Temperature sensor, intake air, injection system	09.98-08.99		**0 280 130 092**
Lateral acceleration sensor, brake system	09.98-08.99		**0 265 005 127**
Wheel speed sensor	09.98-08.99		**0 265 006 344**
3.4 24V Carrera 4 Cabrio [996]			**3,4 l 220 kW M96.02 6 Zyl.**
Throttle valve sensor	09.98-08.99		**0 280 122 016**
Phase sensor	09.98-08.99	NOC	**0 232 103 022**
Speed sensor, ignition/injection	09.98-08.99		**0 261 210 204**
Knock sensor	09.98-08.99		**0 261 231 120**
Temperature sensor, intake air, injection system	09.98-08.99		**0 280 130 092**
Pedal position sensor, EMS (electronic engine management)	09.98-08.99		**0 280 752 010**
Lateral acceleration sensor, brake system	09.98-08.99		**0 265 005 127**
Wheel speed sensor	09.98-08.99		**0 265 006 344**
3.6 Carrera [993]			**3,6 l 200 kW M64.05 / M64.06 6 Zyl.**
Throttle valve sensor	09.93-08.95		**0 280 122 004**
Air mass meter, gasoline injection	09.93-08.95		**0 280 217 803**
Speed sensor, ignition/injection	09.93-08.95		**0 261 210 136**
Knock sensor	09.93-08.95		**0 261 231 118**
Temperature sensor, intake air, injection system	09.93-08.95		**0 280 130 073**
Lateral acceleration sensor, brake system	09.93-08.95	FMT	**0 265 005 108**
Wheel speed sensor, rear	09.93-08.95		**0 265 006 101**
3.6 Carrera [993]			**3,6 l 200 kW M64.07 / M64.08 6 Zyl.**
Throttle valve sensor	09.93-08.95		**0 280 122 004**
Air mass meter, gasoline injection	09.93-08.95		**0 280 217 803**
Speed sensor, ignition/injection	09.93-08.95	AG	**0 261 210 059**
Knock sensor	09.93-08.95		**0 261 231 118**
Temperature sensor, intake air, injection system	09.93-08.95		**0 280 130 073**
Lateral acceleration sensor, brake system	09.93-08.95	FMT	**0 265 005 108**
Wheel speed sensor, rear	09.93-08.95		**0 265 006 101**

P

Product

◀ 911

3.6 Carrera [993]	**3,6 l 210 kW M64.21 / M64.22 6 Zyl.**		
Throttle valve sensor	09.95-08.97		**0 280 122 004**
Air mass meter, gasoline injection	09.95-08.97		**0 280 217 803**
Speed sensor, ignition/injection	09.95-08.97		**0 261 210 136**
Knock sensor	09.95-08.97		**0 261 231 118**
Temperature sensor, cylinder head	09.95-08.97		**0 280 130 097**
Wheel speed sensor, front	09.95-08.97		**0 265 006 107**
3.6 Carrera [993]	**3,6 l 210 kW M64.23 / M64.24 6 Zyl.**		
Throttle valve sensor	09.95-08.97		**0 280 122 004**
Air mass meter, gasoline injection	09.95-08.97		**0 280 217 803**
Speed sensor, ignition/injection	09.95-08.97	AG	**0 261 210 059**
Knock sensor	09.95-08.97		**0 261 231 118**
Wheel speed sensor, front	09.95-08.97		**0 265 006 107**
3.6 Carrera [996]	**3,6 l 235 kW M96.03 6 Zyl.**		
Throttle valve sensor	09.01-07.04		**0 280 122 016**
Phase sensor	09.01-07.04	NOC	**0 232 103 022**
Speed sensor, ignition/injection	09.01-08.02		**0 261 210 204**
	09.02-07.04		**0 261 210 248**
Knock sensor	09.01-07.04		**0 261 231 120**
Temperature sensor, intake air, injection system	09.01-07.04		**0 280 130 092**
Pedal position sensor, EMS (electronic engine management)	09.01-07.04		**0 280 752 010**
Wheel speed sensor, front	09.01-07.04	MFD	**0 265 006 344**
		OFD	**0 265 007 439**
Wheel speed sensor, rear	09.01-07.04		**0 265 006 344**
3.6 Carrera [996]	**3,6 l 254 kW M96.03 6 Zyl.**		
Throttle valve sensor	06.02-07.04		**0 280 122 016**
Speed sensor, ignition/injection	09.02-07.04		**0 261 210 248**
Knock sensor	06.02-07.04		**0 261 231 120**
Temperature sensor, intake air, injection system	06.02-07.04		**0 280 130 092**
Wheel speed sensor, front	06.02-07.04	MFD	**0 265 006 344**
		OFD	**0 265 007 439**
Wheel speed sensor, rear	06.02-07.04		**0 265 006 344**
3.6 Carrera [997]	**3,6 l 235-239 kW M96.05 6 Zyl.**		
Phase sensor	08.04→		**0 232 103 057**
Speed sensor, ignition/injection	08.04→		**0 261 210 248**
Knock sensor	08.04→		**0 261 231 173**
Wheel speed sensor	08.04→		**0 265 007 624**
3.6 Carrera Cabrio [996]	**3,6 l 235 kW M96.03 6 Zyl.**		
Throttle valve sensor	09.01-07.04		**0 280 122 016**
Phase sensor	09.01-07.04	NOC	**0 232 103 022**
Speed sensor, ignition/injection	09.01-08.02		**0 261 210 204**
	09.02-07.04		**0 261 210 248**
Knock sensor	09.01-07.04		**0 261 231 120**
Temperature sensor, intake air, injection system	09.01-07.04		**0 280 130 092**
Pedal position sensor, EMS (electronic engine management)	09.01-07.04		**0 280 752 010**
Wheel speed sensor, front	09.01-07.04	MFD	**0 265 006 344**
		OFD	**0 265 007 439**
Wheel speed sensor, rear	09.01-07.04		**0 265 006 344**
3.6 Carrera Cabrio [996]	**3,6 l 254 kW M96.03 6 Zyl.**		
Throttle valve sensor	06.02-07.04		**0 280 122 016**
Speed sensor, ignition/injection	09.02-07.04		**0 261 210 248**
Knock sensor	06.02-07.04		**0 261 231 120**
Temperature sensor, intake air, injection system	06.02-07.04		**0 280 130 092**
Wheel speed sensor, front	06.02-07.04	MFD	**0 265 006 344**
		OFD	**0 265 007 439**
Wheel speed sensor, rear	06.02-07.04		**0 265 006 344**
3.6 Carrera Cabrio [997]	**3,6 l 235-239 kW M96.05 6 Zyl.**		
Phase sensor	04.05→		**0 232 103 057**
Speed sensor, ignition/injection	04.05→		**0 261 210 248**
Knock sensor	04.05→		**0 261 231 173**
Wheel speed sensor	04.05→		**0 265 007 624**

Product

3.6 Carrera Targa [996]	**3,6 l 235/254 kW M96.03 6 Zyl.**		
Throttle valve sensor	12.01-07.04		**0 280 122 016**
Phase sensor	12.01-07.04	NOC	**0 232 103 022**
Speed sensor, ignition/injection	12.01-08.02		**0 261 210 204**
	09.02-07.04		**0 261 210 248**
Knock sensor	12.01-07.04		**0 261 231 120**
Temperature sensor, intake air, injection system	12.01-07.04		**0 280 130 092**
Pedal position sensor, EMS (electronic engine management)	12.01-07.04		**0 280 752 010**
Wheel speed sensor, front	12.01-07.04	MFD	**0 265 006 344**
		OFD	**0 265 007 439**
Wheel speed sensor, rear	12.01-07.04		**0 265 006 344**
3.6 Carrera Turbo 4x4 [997]	**3,6 l 353 kW M97.70 6 Zyl.**		
Phase sensor	03.06→		**0 232 103 040**
Speed sensor, ignition/injection	03.06→	FMT	**0 261 210 248**
		GS	**0 261 210 205**
Knock sensor	03.06→		**0 261 231 148**
Wheel speed sensor	03.06→		**0 265 007 624**
3.6 Carrera 2 [964]	**3,6 l 184 kW 64.01/.02 6 Zyl.**		
Throttle valve sensor	09.89-08.93	AG	**9 999 999 999**
Speed sensor, ignition/injection	09.89-08.93		**0 261 210 059**
Knock sensor	09.89-08.93		**0 261 231 018**
Pressure sensor, intake manifold, gasoline	09.89-08.93		**0 280 101 001**
Temperature sensor, cylinder head	09.89-08.93		**0 280 130 059**
Wheel speed sensor, front	09.89-05.93		**0 265 001 229**
	05.93-08.93	LAB	**0 265 006 145**
		RAB	**0 265 006 144**
Wheel speed sensor, rear	09.89-08.92		**0 265 001 230**
	09.92-08.93		**0 265 006 146**
3.6 Carrera 2RS [964]	**3,6 l 184/191 kW 64.01; 64.03 6 Zyl.**		
Speed sensor, ignition/injection	08.91-08.93		**0 261 210 059**
Knock sensor	08.91-08.93		**0 261 231 018**
Pressure sensor, intake manifold, gasoline	08.91-08.93		**0 280 101 001**
Temperature sensor, cylinder head	08.91-08.93		**0 280 130 059**
Wheel speed sensor, front	08.91-05.93		**0 265 001 229**
	05.93-08.93	LAB	**0 265 006 145**
		RAB	**0 265 006 144**
Wheel speed sensor, rear	08.91-08.92		**0 265 001 230**
	09.92-08.93		**0 265 006 146**
3.6 Carrera 4 [964]	**3,6 l 184 kW 64.01 6 Zyl.**		
Speed sensor, ignition/injection	09.89-08.93		**0 261 210 059**
Knock sensor	09.89-08.93		**0 261 231 018**
Pressure sensor, intake manifold, gasoline	09.89-08.93		**0 280 101 001**
Temperature sensor, cylinder head	09.89-08.93		**0 280 130 059**
Wheel speed sensor, front	09.89-05.93		**0 265 001 229**
	05.93-08.93	LAB	**0 265 006 145**
		RAB	**0 265 006 144**
Wheel speed sensor, rear	09.89-08.92	TKV	**0 265 001 230**
	09.92-08.93	TKV	**0 265 006 146**
	09.89-08.92	TLV	**0 265 001 146**
	09.92-08.93	TLV	**0 265 006 142**
3.6 Carrera 4 [993]	**3,6 l 200 kW M64.05 6 Zyl.**		
Throttle valve sensor	09.94-08.95		**0 280 122 004**
Air mass meter, gasoline injection	09.94-08.95		**0 280 217 803**
Speed sensor, ignition/injection	09.94-08.95		**0 261 210 136**
Knock sensor	09.94-08.95		**0 261 231 118**
Temperature sensor, intake air, injection system	09.94-08.95		**0 280 130 073**
Lateral acceleration sensor, brake system	09.94-08.95	FMT	**0 265 005 108**
Wheel speed sensor, rear	09.94-08.95		**0 265 006 101**
3.6 Carrera 4 [993]	**3,6 l 200 kW M64.07 6 Zyl.**		
Throttle valve sensor	09.94-08.95		**0 280 122 004**
Air mass meter, gasoline injection	09.94-08.95		**0 280 217 803**
Knock sensor	09.94-08.95		**0 261 231 118**

Product			
Temperature sensor, intake air, injection system	09.94-08.95		**0 280 130 073**
Lateral acceleration sensor, brake system	09.94-08.95	FMT	**0 265 005 108**
Wheel speed sensor, rear	09.94-08.95		**0 265 006 101**
3.6 Carrera 4 [993]		**3,6 l 210 kW**	**M64.21 6 Zyl.**
Throttle valve sensor	09.95-08.97		**0 280 122 004**
Air mass meter, gasoline injection	09.95-08.97		**0 280 217 803**
Speed sensor, ignition/injection	09.95-08.97		**0 261 210 136**
Knock sensor	09.95-08.97		**0 261 231 118**
Temperature sensor, cylinder head	09.95-08.97		**0 280 130 097**
Wheel speed sensor, front	09.95-08.97		**0 265 006 107**
3.6 Carrera 4 [993]		**3,6 l 210 kW**	**M64.23 6 Zyl.**
Throttle valve sensor	09.95-08.97		**0 280 122 004**
Air mass meter, gasoline injection	09.95-08.97		**0 280 217 803**
Knock sensor	09.95-08.97		**0 261 231 118**
Wheel speed sensor, front	09.95-08.97		**0 265 006 107**
3.6 Carrera 4 [996]		**3,6 l 235 kW**	**M96.03 6 Zyl.**
Throttle valve sensor	09.01-07.04		**0 280 122 016**
Phase sensor	09.01-07.04	NOC	**0 232 103 022**
Speed sensor, ignition/injection	09.01-08.02		**0 261 210 204**
	09.02-07.04		**0 261 210 248**
Knock sensor	09.01-07.04		**0 261 231 120**
Temperature sensor, intake air, injection system	09.01-07.04		**0 280 130 092**
Pedal position sensor, EMS (electronic engine management)	09.01-07.04		**0 280 752 010**
Wheel speed sensor, front	09.01-07.04	MFD	**0 265 006 344**
		OFD	**0 265 007 439**
Wheel speed sensor, rear	09.01-07.04		**0 265 006 344**
3.6 Carrera 4 [996]		**3,6 l 254 kW**	**M96.03 6 Zyl.**
Throttle valve sensor	06.02-07.04		**0 280 122 016**
Speed sensor, ignition/injection	09.02-07.04		**0 261 210 248**
Knock sensor	06.02-07.04		**0 261 231 120**
Temperature sensor, intake air, injection system	06.02-07.04		**0 280 130 092**
Wheel speed sensor, front	06.02-07.04	MFD	**0 265 006 344**
		OFD	**0 265 007 439**
Wheel speed sensor, rear	06.02-07.04		**0 265 006 344**
3.6 Carrera 4 [997]		**3,6 l 235-239 kW**	**M96.05 6 Zyl.**
Phase sensor	08.04→		**0 232 103 057**
Speed sensor, ignition/injection	08.04→		**0 261 210 248**
Knock sensor	08.04→		**0 261 231 173**
Wheel speed sensor	08.04→		**0 265 007 624**
3.6 Carrera 4 Cabrio [996]		**3,6 l 235 kW**	**M96.03 6 Zyl.**
Throttle valve sensor	09.01-07.04		**0 280 122 016**
Phase sensor	09.01-07.04	NOC	**0 232 103 022**
Speed sensor, ignition/injection	09.01-08.02		**0 261 210 204**
	09.02-07.04		**0 261 210 248**
Knock sensor	09.01-07.04		**0 261 231 120**
Temperature sensor, intake air, injection system	09.01-07.04		**0 280 130 092**
Pedal position sensor, EMS (electronic engine management)	09.01-07.04		**0 280 752 010**
Wheel speed sensor, front	09.01-07.04	MFD	**0 265 006 344**
		OFD	**0 265 007 439**
Wheel speed sensor, rear	09.01-07.04		**0 265 006 344**
3.6 Carrera 4 Cabrio [996]		**3,6 l 254 kW**	**M96.03 6 Zyl.**
Throttle valve sensor	06.02-07.04		**0 280 122 016**
Phase sensor	06.02-07.04	NOC	**0 232 103 022**
Speed sensor, ignition/injection	06.02-08.02		**0 261 210 204**
	09.02-07.04		**0 261 210 248**
Knock sensor	06.02-07.04		**0 261 231 120**
Temperature sensor, intake air, injection system	06.02-07.04		**0 280 130 092**
Wheel speed sensor, front	06.02-07.04	MFD	**0 265 006 344**
		OFD	**0 265 007 439**
Wheel speed sensor, rear	06.02-07.04		**0 265 006 344**

Product			
3.6 Carrera 4 Cabrio [997]		**3,6 l 235-239 kW**	**M96.05 6 Zyl.**
Phase sensor	08.04→		**0 232 103 057**
Speed sensor, ignition/injection	08.04→		**0 261 210 248**
Knock sensor	08.04→		**0 261 231 173**
Wheel speed sensor	08.04→		**0 265 007 624**
3.6 Carrera 4 S [996]		**3,6 l 235 kW**	**M96.03 6 Zyl.**
Throttle valve sensor	09.01-07.04		**0 280 122 016**
Phase sensor	09.01-07.04	NOC	**0 232 103 022**
Speed sensor, ignition/injection	09.01-08.02		**0 261 210 204**
	09.02-07.04		**0 261 210 248**
	09.01-08.02	EFV	**0 261 210 204**
Knock sensor	09.01-07.04		**0 261 231 120**
Temperature sensor, intake air, injection system	09.01-07.04		**0 280 130 092**
Pedal position sensor, EMS (electronic engine management)	09.01-07.04		**0 280 752 010**
Wheel speed sensor, front	09.01-07.04	MFD	**0 265 006 344**
		OFD	**0 265 007 439**
Wheel speed sensor, rear	09.01-07.04		**0 265 006 344**
3.6 Carrera 4 S [996]		**3,6 l 254 kW**	**M96.03 6 Zyl.**
Throttle valve sensor	06.02-07.04		**0 280 122 016**
Speed sensor, ignition/injection	09.02-07.04		**0 261 210 248**
Knock sensor	06.02-07.04		**0 261 231 120**
Temperature sensor, intake air, injection system	06.02-07.04		**0 280 130 092**
Wheel speed sensor, front	06.02-07.04	MFD	**0 265 006 344**
		OFD	**0 265 007 439**
Wheel speed sensor, rear	06.02-07.04		**0 265 006 344**
3.6 Carrera 4 S Cabrio [996]		**3,6 l 235 kW**	**M96.03 6 Zyl.**
Throttle valve sensor	10.03-07.04		**0 280 122 016**
Phase sensor	10.03-07.04	NOC	**0 232 103 022**
Speed sensor, ignition/injection	10.03-07.04		**0 261 210 248**
Knock sensor	10.03-07.04		**0 261 231 120**
Temperature sensor, intake air, injection system	10.03-07.04		**0 280 130 092**
Wheel speed sensor, front	10.03-07.04	MFD	**0 265 006 344**
		OFD	**0 265 007 439**
Wheel speed sensor, rear	10.03-07.04		**0 265 006 344**
3.6 Carrera 4S [993]		**3,6 l 210 kW**	**M64.21 6 Zyl.**
Throttle valve sensor	09.95-08.97		**0 280 122 004**
Air mass meter, gasoline injection	09.95-08.97		**0 280 217 803**
Speed sensor, ignition/injection	09.95-08.97		**0 261 210 136**
Knock sensor	09.95-08.97		**0 261 231 118**
Temperature sensor, cylinder head	09.95-08.97		**0 280 130 097**
Wheel speed sensor, front	09.95-08.97		**0 265 006 107**
3.6 GT2 [996T/GT2, 3]		**3,6 l 340 kW**	**M96.70/S 6 Zyl.**
Throttle valve assembly	06.01→		**0 280 750 007**
Speed sensor, ignition/injection	06.01→		**0 261 210 205**
Knock sensor	06.01→		**0 261 231 148**
Pedal position sensor, EMS (electronic engine management)	06.01→		**0 280 752 010**
Wheel speed sensor	06.01-08.03		**0 265 006 344**
	09.03→		**0 265 007 439**
3.6 GT2 [996T/GT2, 3]		**3,6 l 355 kW**	**M96.70/S 6 Zyl.**
Throttle valve assembly	10.03→		**0 280 750 007**
Speed sensor, ignition/injection	10.03→		**0 261 210 205**
Knock sensor	10.03→		**0 261 231 148**
Pedal position sensor, EMS (electronic engine management)	10.03→		**0 280 752 010**
Wheel speed sensor	10.03→		**0 265 007 439**
3.6 GT3 [996T/GT2, 3]		**3,6 l 265 kW**	**M96.76 6 Zyl.**
Throttle valve sensor	03.99-08.01		**0 280 122 016**
Speed sensor, ignition/injection	03.99-08.01		**0 261 210 205**
Knock sensor	03.99-08.01		**0 261 231 148**
Temperature sensor, intake air, injection system	03.99-08.01		**0 280 130 092**
Wheel speed sensor	03.99-08.01		**0 265 006 344**

Product			
◀ 911			
3.6 GT3 [996T/GT2, 3]			**3,6 l 280 kW M96.79 6 Zyl.**
Throttle valve sensor	09.03→		**0 280 122 016**
Speed sensor, ignition/injection	09.03→		**0 261 210 249**
Knock sensor	09.03→		**0 261 231 148**
Wheel speed sensor	09.03→		**0 265 006 344**
3.6 GT3 [997 GT3]			**3,6 l 305 kW M97.76 6 Zyl.**
Phase sensor	03.06→		**0 232 103 057**
Speed sensor, ignition/injection	03.06→		**0 261 210 249**
Knock sensor	03.06→		**0 261 231 148**
Wheel speed sensor	03.06→		**0 265 007 624**
3.6 Targa [993]			**3,6 l 210 kW M64.21 / M64.22 6 Zyl.**
Throttle valve sensor	09.95-08.97		**0 280 122 004**
Air mass meter, gasoline injection	09.95-08.97		**0 280 217 803**
Speed sensor, ignition/injection	09.95-08.97		**0 261 210 136**
Knock sensor	09.95-08.97		**0 261 231 118**
Temperature sensor, cylinder head	09.95-08.97		**0 280 130 097**
Wheel speed sensor, front	09.95-08.97		**0 265 006 107**
3.6 Targa [993]			**3,6 l 210 kW M64.23 / M64.24 6 Zyl.**
Throttle valve sensor	09.95-08.97		**0 280 122 004**
Air mass meter, gasoline injection	09.95-08.97		**0 280 217 803**
Speed sensor, ignition/injection	09.95-08.97	AG	**0 261 210 059**
Knock sensor	09.95-08.97		**0 261 231 118**
Wheel speed sensor, front	09.95-08.97		**0 265 006 107**
3.6 Targa 4 [993]			**3,6 l 210 kW M64.21 6 Zyl.**
Throttle valve sensor	09.95-08.97		**0 280 122 004**
Air mass meter, gasoline injection	09.95-08.97		**0 280 217 803**
Speed sensor, ignition/injection	09.95-08.97		**0 261 210 136**
Knock sensor	09.95-08.97		**0 261 231 118**
Temperature sensor, cylinder head	09.95-08.97		**0 280 130 097**
Wheel speed sensor, front	09.95-08.97		**0 265 006 107**
3.6 Targa 4 [993]			**3,6 l 210 kW M64.23 6 Zyl.**
Throttle valve sensor	09.95-08.97		**0 280 122 004**
Air mass meter, gasoline injection	09.95-08.97		**0 280 217 803**
Knock sensor	09.95-08.97		**0 261 231 118**
Wheel speed sensor, front	09.95-08.97		**0 265 006 107**
3.6 Targa 4 [997]			**3,6 l 235-239 kW M96.05 6 Zyl.**
Phase sensor	08.06→		**0 232 103 057**
Speed sensor, ignition/injection	08.06→		**0 261 210 248**
Knock sensor	08.06→		**0 261 231 173**
Wheel speed sensor	08.06→		**0 265 007 624**
3.6 Turbo [964]			**3,6 l 265 kW 64.50 6 Zyl.**
Throttle valve sensor	02.93-08.93		**0 280 120 107**
Air flow sensor, gasoline injection	02.93-08.93		**0 438 120 221**
Pressure sensor, intake manifold, gasoline	02.93-08.93		**0 280 101 001**
Temperature sensor, intake air, injection system	02.93-08.93		**0 261 220 002**
Wheel speed sensor, front	02.93-05.93		**0 265 001 229**
	05.93-08.93	LAB	**0 265 006 145**
		RAB	**0 265 006 144**
Wheel speed sensor, rear	02.93-08.93		**0 265 006 142**
3.6 Turbo [993]			**3,6 l 300 kW M64.60 6 Zyl.**
Throttle valve sensor	09.94-08.97		**0 280 122 004**
Air mass meter, gasoline injection	09.94-08.97		**0 280 217 809**
Speed sensor, ignition/injection	09.94-08.97		**0 261 210 136**
Knock sensor	09.94-08.97		**0 261 231 118**
Temperature sensor, intake air, injection system	09.94-08.97		**0 280 130 085**
Temperature sensor, cylinder head	09.95-08.97		**0 280 130 097**
Wheel speed sensor, front	09.95-08.97		**0 265 006 107**
Wheel speed sensor, rear	09.94-08.95		**0 265 006 101**
3.6 Turbo Cabrio 4x4 [996T/GT2, 3]			**3,6 l 309 kW M96.70 6 Zyl.**
Throttle valve assembly	10.03→		**0 280 750 007**
Speed sensor, ignition/injection	10.03→	FMT	**0 261 210 248**
		GS	**0 261 210 205**
Knock sensor	10.03→		**0 261 231 148**
Pedal position sensor, EMS (electronic engine management)	10.03→		**0 280 752 010**
Wheel speed sensor	10.03→		**0 265 007 439**
3.6 Turbo Coupé 4x4 [996T/GT2, 3]			**3,6 l 309 kW M96.70 6 Zyl.**
Throttle valve assembly	06.00→		**0 280 750 007**
Phase sensor	06.00→	NOC	**0 232 103 022**
Speed sensor, ignition/injection	06.00-08.02	FMT	**0 261 210 204**
	09.02→	FMT	**0 261 210 248**
	06.00→	GS	**0 261 210 205**
Knock sensor	06.00→		**0 261 231 148**
Pedal position sensor, EMS (electronic engine management)	06.00→		**0 280 752 010**
Wheel speed sensor	06.00-08.03		**0 265 006 344**
	09.03→		**0 265 007 439**
3.6 Turbo GT2 Carrera [993]			**3,6 l 316 kW M64.60R 6 Zyl.**
Throttle valve sensor	01.95-05.97		**0 280 122 004**
Air mass meter, gasoline injection	01.95-05.97		**0 280 217 809**
Speed sensor, ignition/injection	01.95-05.97		**0 261 210 136**
Knock sensor	01.95-05.97		**0 261 231 118**
Temperature sensor, intake air, injection system	01.95-05.97		**0 280 130 085**
Temperature sensor, cylinder head	09.95-05.97		**0 280 130 097**
Wheel speed sensor, front	09.95-05.97		**0 265 006 107**
Wheel speed sensor, rear	01.95-08.95		**0 265 006 101**
3.6 Turbo S Cabrio 4x4 [996T/GT2, 3]			**3,6 l 331 kW M96.70E 6 Zyl.**
Throttle valve assembly	10.03→		**0 280 750 007**
Speed sensor, ignition/injection	10.03→	FMT	**0 261 210 248**
		GS	**0 261 210 205**
Knock sensor	10.03→		**0 261 231 148**
Pedal position sensor, EMS (electronic engine management)	10.03→		**0 280 752 010**
Wheel speed sensor	10.03→		**0 265 007 439**
3.6 Turbo S Coupé 4x4 [996T/GT2, 3]			**3,6 l 331 kW M96.70E 6 Zyl.**
Throttle valve assembly	02.03→		**0 280 750 007**
Speed sensor, ignition/injection	02.03→	FMT	**0 261 210 248**
		GS	**0 261 210 205**
Knock sensor	02.03→		**0 261 231 148**
Pedal position sensor, EMS (electronic engine management)	02.03→		**0 280 752 010**
Wheel speed sensor	02.03-08.03		**0 265 006 344**
	09.03→		**0 265 007 439**
3.8 Carrera RS [993]			**3,8 l 220 kW M64.20 6 Zyl.**
Throttle valve sensor	09.94-08.97		**0 280 122 004**
Air mass meter, gasoline injection	09.94-08.97		**0 280 217 803**
Speed sensor, ignition/injection	09.94-08.97		**0 261 210 136**
Knock sensor	09.94-08.97		**0 261 231 118**
Temperature sensor, cylinder head	09.95-08.97		**0 280 130 097**
Wheel speed sensor, front	09.95-08.97		**0 265 006 107**
Wheel speed sensor, rear	09.94-08.95		**0 265 006 101**
3.8 Carrera S [997]			**3,8 l 261 kW M97.01 6 Zyl.**
Phase sensor	08.04→		**0 232 103 057**
Speed sensor, ignition/injection	08.04→		**0 261 210 248**
Knock sensor	08.04→		**0 261 231 173**
Wheel speed sensor	08.04→		**0 265 007 624**
3.8 Carrera S Cabrio [997]			**3,8 l 261 kW M97.01 6 Zyl.**
Phase sensor	04.05→		**0 232 103 057**
Speed sensor, ignition/injection	04.05→		**0 261 210 248**
Knock sensor	04.05→		**0 261 231 173**
Wheel speed sensor	04.05→		**0 265 007 624**
3.8 Carrera 4S, Cabrio [997]			**3,8 l 261 kW M97.01 6 Zyl.**
Phase sensor	10.05→		**0 232 103 057**
Speed sensor, ignition/injection	10.05→		**0 261 210 248**
Knock sensor	10.05→		**0 261 231 173**
Wheel speed sensor	10.05→		**0 265 007 624**

P

Product		
3.8 Targa 4S [997]		**3,8 l 261 kW M97.01 6 Zyl.**
Phase sensor	08.06→	**0 232 103 057**
Speed sensor, ignition/injection	08.06→	**0 261 210 248**
Knock sensor	08.06→	**0 261 231 173**
Wheel speed sensor	08.06→	**0 265 007 624**

924

2.5 S		**2,5 l 110/118 kW M 44.07/.08; M 44.09/.10 4 Zyl.**
Throttle valve sensor	09.85-07.88	**0 280 120 308**
Air flow sensor, gasoline injection	09.85-07.88	**0 280 202 064**
		0 986 280 041
Speed sensor, ignition/injection	09.85-07.88	**0 261 210 003**
Temperature sensor, coolant, injection system	09.85-07.88	**0 280 130 026**

928

4.7 S		**4,7 l 228 kW M 28.21,.22 8 Zyl.**
Throttle valve sensor	08.83-07.86	**0 280 120 308**
Air mass meter, gasoline injection	08.83-07.86	**0 280 214 001**
		0 986 280 124
Speed sensor, ignition/injection	08.83-07.86	**0 261 210 003**
Temperature sensor, intake air, injection system	08.83-07.86	**0 280 130 039**
Temperature sensor, coolant, injection system	08.83-07.86	**0 280 130 032**
Wheel speed sensor, front	08.85-07.86	**0 265 001 119**
Wheel speed sensor, rear	08.85-07.86	**0 265 001 118**
5.0 GT		**5,0 l 243 kW M 28.47 8 Zyl.**
Throttle valve sensor	01.89-07.91	**0 280 120 322**
Air mass meter, gasoline injection	01.89-07.91	**0 280 214 001**
		0 986 280 124
Phase sensor	01.89-07.91	**0 232 101 005**
Speed sensor, ignition/injection	01.89-07.91	**0 261 210 003**
Knock sensor	01.89-07.90	**0 261 231 008**
	08.90-07.91	**0 261 231 036**
Temperature sensor, coolant, injection system	01.89-07.91	**0 280 130 032**
Wheel speed sensor, front	01.89-07.91	**0 265 001 119**
Wheel speed sensor, rear	01.89-07.91	**0 265 001 118**
5.0 S4		**5,0 l 200-215 kW M 28.43,.44; M 28.45,.46 8 Zyl.**
Throttle valve sensor	12.84-07.86	**0 280 120 308**
Air mass meter, gasoline injection	12.84-07.86	**0 280 214 001**
		0 986 280 124
Speed sensor, ignition/injection	12.84-07.86	**0 261 210 003**
Temperature sensor, intake air, injection system	12.84-07.86	**0 280 130 039**
Temperature sensor, coolant, injection system	12.84-07.86	**0 280 130 032**
Wheel speed sensor, front	08.85-07.86	**0 265 001 119**
Wheel speed sensor, rear	08.85-07.86	**0 265 001 118**
5.0 S4		**5,0 l 235 kW M 28.41,.42 8 Zyl.**
Throttle valve sensor	08.86-07.91	**0 280 120 322**
Air mass meter, gasoline injection	08.86-07.91	**0 280 214 001**
		0 986 280 124
Phase sensor	08.86-07.91	**0 232 101 005**
Speed sensor, ignition/injection	08.86-07.91	**0 261 210 003**
Knock sensor	08.86-07.90	**0 261 231 008**
	08.90-07.91	**0 261 231 036**
Temperature sensor, coolant, injection system	08.86-07.91	**0 280 130 032**
Wheel speed sensor, front	08.86-07.91	**0 265 001 119**
Wheel speed sensor, rear	08.86-07.91	**0 265 001 118**
5.0 S4/CS		**5,0 l 235 kW M 28.41 8 Zyl.**
Throttle valve sensor	08.87-07.89	**0 280 120 322**
Air mass meter, gasoline injection	08.87-07.89	**0 280 214 001**
		0 986 280 124
Phase sensor	08.87-07.89	**0 232 101 005**
Wheel speed sensor, front	08.87-07.89	**0 265 001 119**
Wheel speed sensor, rear	08.87-07.89	**0 265 001 118**
5.4 GTS		**5,4 l 257 kW M 28.49/.50 8 Zyl.**
Throttle valve sensor	08.91-08.93	**0 280 120 322**
	09.93-11.95	**0 280 120 437**
Air mass meter, gasoline injection	08.91-11.95	**0 280 214 001**
		0 986 280 124
Phase sensor	08.91-11.95	**0 232 101 005**
Speed sensor, ignition/injection	08.91-11.95	**0 261 210 003**
Knock sensor	08.91-11.95	**0 261 231 036**
Temperature sensor, coolant, injection system	08.91-11.95	**0 280 130 032**
Wheel speed sensor, front	08.91-05.93	**0 265 001 119**
	06.93-11.95	**0 265 006 141**
Wheel speed sensor, rear	08.91-11.95	**0 265 001 118**

944

2.5			**2,5 l 110/118/120 kW M 44.05/.06; M 44.07/.08; M 44.09/.10 4 Zyl.**
Throttle valve sensor	01.85-07.88		**0 280 120 308**
Air flow sensor, gasoline injection	01.85-07.88		**0 280 202 064**
			0 986 280 041
Speed sensor, ignition/injection	01.85-07.88		**0 261 210 003**
Temperature sensor, coolant, injection system	01.85-07.88		**0 280 130 026**
Wheel speed sensor, front	01.85-07.88		**0 265 001 119**
		EFV	**0 265 006 141**
Wheel speed sensor, rear	01.85-07.88		**0 265 001 146**
		EFV	**0 265 006 142**
2.5 S			**2,5 l 135-140 kW M 44.40 4 Zyl.**
Throttle valve sensor	08.86-07.88		**0 280 120 308**
Air flow sensor, gasoline injection	08.86-07.88		**0 280 203 029**
			0 986 280 048
Phase sensor	08.86-07.88		**0 232 101 005**
Speed sensor, ignition/injection	08.86-07.88		**0 261 210 003**
Temperature sensor, coolant, injection system	08.86-07.88		**0 280 130 026**
Wheel speed sensor, front	08.86-07.88		**0 265 001 119**
		EFV	**0 265 006 141**
Wheel speed sensor, rear	08.86-07.88		**0 265 001 146**
		EFV	**0 265 006 142**
2.5 Turbo			**2,5 l 162/184 kW M 44.50; M 44.51; M 44.52 4 Zyl.**
Throttle valve sensor	08.85-07.91		**0 280 120 400**
Air flow sensor, gasoline injection	08.85-07.91		**0 280 203 026**
			0 986 280 042
Speed sensor, ignition/injection	08.85-07.91		**0 261 210 003**
Knock sensor	08.85-07.91		**0 261 231 006**
Temperature sensor, coolant, injection system	08.85-07.91		**0 280 130 026**
Wheel speed sensor, front	08.85-07.91		**0 265 001 119**
		EFV	**0 265 006 141**
Wheel speed sensor, rear	08.85-07.91		**0 265 001 146**
		EFV	**0 265 006 142**
2.7			**2,7 l 121 kW M 44.11, .12 4 Zyl.**
Throttle valve sensor	11.88-07.89		**0 280 120 308**
Air flow sensor, gasoline injection	11.88-07.89		**0 280 202 064**
			0 986 280 041
Speed sensor, ignition/injection	11.88-07.89		**0 261 210 003**
Knock sensor	11.88-07.89		**0 261 231 006**
Temperature sensor, coolant, injection system	11.88-07.89		**0 280 130 026**
Wheel speed sensor, front	11.88-07.89		**0 265 001 119**
		EFV	**0 265 006 141**
Wheel speed sensor, rear	11.88-07.89		**0 265 001 146**
		EFV	**0 265 006 142**

P

Product

◀ 944

3.0 S2			**3,0 l 155 kW M 44.41 4 Zyl.**
Throttle valve sensor	12.88-07.91		**0 280 120 308**
Air flow sensor, gasoline injection	12.88-07.91		**0 280 203 029**
			0 986 280 048
Phase sensor	12.88-07.91		**0 232 101 005**
Speed sensor, ignition/injection	12.88-07.91		**0 261 210 003**
Knock sensor	12.88-07.91		**0 261 231 006**
Temperature sensor, coolant, injection system	12.88-07.91		**0 280 130 026**
Wheel speed sensor, front	12.88-07.91		**0 265 001 119**
		EFV	**0 265 006 141**
Wheel speed sensor, rear	12.88-07.91		**0 265 001 146**
		EFV	**0 265 006 142**

959

2.8			**2,8 l 330 kW 959.50 6 Zyl.**
Speed sensor, ignition/injection	05.86-07.88		**0 261 210 003**
Temperature sensor, coolant, injection system	05.86-07.88		**0 280 130 026**

968

3.0			**3,0 l 176 kW M 44.43/.44 4 Zyl.**
Throttle valve sensor	08.91-11.95		**0 280 122 001**
Air mass meter, gasoline injection	08.91-11.95		**0 280 213 017**
			0 986 280 139
Phase sensor	08.91-11.95		**0 232 101 013**
Speed sensor, ignition/injection	08.91-11.95		**0 261 210 003**
Knock sensor	08.91-11.95		**0 261 231 006**
Temperature sensor, coolant, injection system	08.91-11.95		**0 280 130 026**
Lateral acceleration sensor, brake system	08.93-08.95	FMT	**0 265 005 108**
Wheel speed sensor, front	08.91-05.93		**0 265 001 119**
	06.93-11.95		**0 265 006 141**
Wheel speed sensor, rear	08.91-05.93		**0 265 001 146**
	06.93-11.95		**0 265 006 142**

RENAULT

Alpine

A 610 3.0i Turbo [D503]			**3,0 l 184 kW Z7X 744 Kat. 6 Zyl.**
Knock sensor	03.91-12.95		**0 261 231 007**
Acceleration sensor, ABS	03.91-07.92		**0 265 005 004**
	08.92-12.95		**0 265 005 041**
2.5 i Turbo			**2,5 l 136/147 kW Z7U 730; Z7U 734 Kat. 6 Zyl.**
Acceleration sensor, ABS	03.85-08.92		**0 265 005 004**
2.9			**2,9 l 116 kW Z6W 700; Z6W 702 6 Zyl.**
Acceleration sensor, ABS	03.85-08.92		**0 265 005 004**

Avantime

2.0 16V Turbo [XEO]			**2,0 l 120 kW F4R 760; F4R 761; F4R 769 4 Zyl.**
Wheel speed sensor, front	09.01-12.03	LAB	**0 265 006 283**
		RAB	**0 265 006 282**
Wheel speed sensor, rear	09.01-12.03		**0 265 006 284**
2.2 DCI [XEO]			**2,2 l 110 kW G9T 712 4 Zyl.**
High-pressure sensor (CR system)	12.01-12.03		**0 281 002 534**
Wheel speed sensor, front	12.01-12.03	LAB	**0 265 006 283**
		RAB	**0 265 006 282**
Wheel speed sensor, rear	12.01-12.03		**0 265 006 284**

Product

3.0 V6 24V [XEO]			**3,0 l 152 kW L7X 720; L7X 721; L7X 722 6 Zyl.**
Wheel speed sensor, front	09.01-12.03	LAB	**0 265 006 283**
		RAB	**0 265 006 282**
Wheel speed sensor, rear	09.01-12.03		**0 265 006 284**

Clio

1.6 i 16V			**1,6 l 81 kW K4M 740 4 Zyl.**
Wheel speed sensor, front	06.00→	LAB	**0 265 006 384**
		RAB	**0 265 006 383**
Wheel speed sensor, rear	06.00→		**0 265 006 385**
1.6 i 16V [BB01]			**1,6 l 81 kW K4M 740 4 Zyl.**
Wheel speed sensor, front	05.00→	LAB	**0 265 006 384**
		RAB	**0 265 006 383**
Wheel speed sensor, rear	05.00→		**0 265 006 385**

Clio I

Electrique [X57]			**21 kW 2BD 701 0 Zyl.**
Wheel speed sensor, rear	06.95-02.98	LAB	**0 265 006 443**
		RAB	**0 265 006 444**
1.1 [X57]			**1,1 l 35-36 kW C1E 700 4 Zyl.**
Wheel speed sensor, rear	06.90-03.96	LAB	**0 265 006 443**
		RAB	**0 265 006 444**
1.2 [X57]			**1,2 l 40-44 kW E5F 710; E5F 716 4 Zyl.**
Wheel speed sensor, rear	06.90-02.98	LAB	**0 265 006 443**
		RAB	**0 265 006 444**
1.2 i [X57]			**1,2 l 40 kW C3G 700,720 4 Zyl.**
Wheel speed sensor, rear	09.95-03.96	LAB	**0 265 006 443**
		RAB	**0 265 006 444**
1.2 i [X57]			**1,2 l 40-44 kW D7F 730; E7F 700,704,706,750 Kat. 4 Zyl.**
Wheel speed sensor, front	06.90-02.98		**0 265 006 442**
Wheel speed sensor, rear	06.90-02.98	LAB	**0 265 006 443**
		RAB	**0 265 006 444**
1.2 i [X57]			**1,2 l 44 kW E7F 708; E7F 708 Kat. 4 Zyl.**
Wheel speed sensor, front	01.94-02.98		**0 265 006 442**
Wheel speed sensor, rear	01.94-02.98	LAB	**0 265 006 443**
		RAB	**0 265 006 444**
1.4 [X57]			**1,4 l 55-57 kW E6J 712,713; E6J 718; E6J 760 4 Zyl.**
Wheel speed sensor, rear	06.90-02.98	LAB	**0 265 006 443**
		RAB	**0 265 006 444**
1.4 i [X57]			**1,4 l 55-59 kW E7J 601,716,718,719,754,756,757 Kat. 4 Zyl.**
Wheel speed sensor, front	06.90-02.98		**0 265 006 442**
Wheel speed sensor, rear	06.90-02.98	LAB	**0 265 006 443**
		RAB	**0 265 006 444**
1.4 i [X57]			**1,4 l 58-59 kW E7J 710,711 Kat. 4 Zyl.**
Wheel speed sensor, front	06.90-02.98		**0 265 006 442**
Wheel speed sensor, rear	06.90-02.98	LAB	**0 265 006 443**
		RAB	**0 265 006 444**
1.6 i			**1,6 l 66 kW K7M 746 4 Zyl.**
Speed sensor, ignition/injection	01.96-06.97		**0 261 210 137**
Temperature sensor, intake air, injection system	01.96-06.97		**3 437 010 533**
Temperature sensor, coolant, injection system	01.96-06.97		**0 280 130 068**
Wheel speed sensor, front	01.96-06.97	LAB	**0 265 006 384**
		RAB	**0 265 006 383**
Wheel speed sensor, rear	01.96-06.97		**0 265 006 385**
1.7 [X57]			**1,7 l 66-68 kW F2N 770 4 Zyl.**
Wheel speed sensor, front	06.90-03.96		**0 265 006 442**
Wheel speed sensor, rear	06.90-03.96	LAB	**0 265 006 443**
		RAB	**0 265 006 444**

Product			
1.8 i [X57]	**1,8 l 65-70 kW F3P 710,714,744,745,754,755 Kat. 4 Zyl.**		
Wheel speed sensor, front	06.90-02.98		**0 265 006 442**
Wheel speed sensor, rear	06.90-02.98	LAB	**0 265 006 443**
		RAB	**0 265 006 444**
1.8 i [X57]	**1,8 l 66/79-81 kW F3P 712,755,758 Kat.; F3P 748,758 4 Zyl.**		
Wheel speed sensor, front	07.92-02.98		**0 265 006 442**
Wheel speed sensor, rear	07.92-02.98	LAB	**0 265 006 443**
		RAB	**0 265 006 444**
1.8 i 16V [X57]	**1,8 l 99-103 kW F7P 720; F7P 722 Kat. 4 Zyl.**		
Wheel speed sensor, front	03.91-03.96		**0 265 006 442**
Wheel speed sensor, rear	03.91-03.96	LAB	**0 265 006 443**
		RAB	**0 265 006 444**
1.9 D [X57]	**1,9 l 47 kW F8Q 672,676,678,692,696 4 Zyl.**		
Wheel speed sensor, front	10.94-02.98		**0 265 006 442**
Wheel speed sensor, rear	10.94-02.98	LAB	**0 265 006 443**
		RAB	**0 265 006 444**
1.9 D [X57]	**1,9 l 47-48 kW F8Q 714,730,732 4 Zyl.**		
Wheel speed sensor, front	06.90-02.98		**0 265 006 442**
Wheel speed sensor, rear	06.90-02.98	LAB	**0 265 006 443**
		RAB	**0 265 006 444**
2.0 i Williams [X57]	**2,0 l 108-110 kW F7R 700 4 Zyl.**		
Wheel speed sensor, front	07.92-03.96		**0 265 006 442**
Wheel speed sensor, rear	07.92-03.96	LAB	**0 265 006 443**
		RAB	**0 265 006 444**

Clio II

1.0 i [BB./CB./SB.]	**1,0 l 43 kW D7D 760 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	03.99-11.04		**0 265 005 263**
Wheel speed sensor, front	03.99-11.02		**0 265 006 383**
	12.02-11.04		**0 265 007 527**
Wheel speed sensor, rear	03.99-11.02	LAB,OTK	**0 265 006 384**
	12.02-11.04	LAB,OTK	**0 265 007 529**
	03.99-11.02	OTK,RAB	**0 265 006 385**
	12.02-11.04	OTK,RAB	**0 265 007 528**
1.0 i 16V [BB./CB./SB.]	**1,0 l 50 kW D4D 700 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	06.01-11.04		**0 265 005 263**
Wheel speed sensor, front	06.01-11.02		**0 265 006 383**
	12.02-11.04		**0 265 007 527**
Wheel speed sensor, rear	06.01-11.02	LAB,OTK	**0 265 006 384**
	12.02-11.04	LAB,OTK	**0 265 007 529**
	06.01-11.02	OTK,RAB	**0 265 006 385**
	12.02-11.04	OTK,RAB	**0 265 007 528**
1.0 i 16V [BB./CB./SB.]	**1,0 l 50 kW D4D 706 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	12.04-10.07		**0 265 005 263**
Wheel speed sensor, front	12.04-10.07		**0 265 007 527**
Wheel speed sensor, rear	12.04-10.07	LAB,OTK	**0 265 007 529**
		OTK,RAB	**0 265 007 528**
1.2 i [BB./CB./SB.]	**1,2 l 43 kW D7F 720,722,726,744,746 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	03.98-10.07		**0 265 005 263**
Wheel speed sensor, front	03.98-11.02		**0 265 006 383**
	12.02-10.07		**0 265 007 527**
Wheel speed sensor, rear	03.98-11.02	LAB,OTK	**0 265 006 384**
	12.02-10.07	LAB,OTK	**0 265 007 529**
	03.98-11.02	OTK,RAB	**0 265 006 385**
	12.02-10.07	OTK,RAB	**0 265 007 528**

Product			
1.2 i [BB./CB./SB.]	**1,2 l 43 kW D7F 764,766 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	03.98-10.07		**0 265 005 263**
Wheel speed sensor, front	03.98-11.02		**0 265 006 383**
	12.02-10.07		**0 265 007 527**
Wheel speed sensor, rear	03.98-11.02	LAB,OTK	**0 265 006 384**
	12.02-10.07	LAB,OTK	**0 265 007 529**
	03.98-11.02	OTK,RAB	**0 265 006 385**
	12.02-10.07	OTK,RAB	**0 265 007 528**
1.2 i 16V [BB./CB./SB.]	**1,2 l 55 kW D4F 706,712,714 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	03.00-03.04		**0 265 005 263**
Wheel speed sensor, front	03.00-11.02		**0 265 006 383**
	12.02-03.04		**0 265 007 527**
Wheel speed sensor, rear	03.00-11.02	LAB,OTK	**0 265 006 384**
	12.02-03.04	LAB,OTK	**0 265 007 529**
	03.00-11.02	OTK,RAB	**0 265 006 385**
	12.02-03.04	OTK,RAB	**0 265 007 528**
1.2 i 16V [BB./CB./SB.]	**1,2 l 55 kW D4F 722; D4F 728 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	10.03-10.07		**0 265 005 263**
Wheel speed sensor, front	10.03-10.07		**0 265 007 527**
Wheel speed sensor, rear	10.03-10.07	LAB,OTK	**0 265 007 529**
		OTK,RAB	**0 265 007 528**
1.4 i [BB./CB./SB.]	**1,4 l 55 kW E7J 634; E7J 635; E7J 780; K7J 700 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	03.98-10.07		**0 265 005 263**
Wheel speed sensor, front	03.98-11.02		**0 265 006 383**
	12.02-10.07		**0 265 007 527**
Wheel speed sensor, rear	03.98-11.02	LAB,OTK	**0 265 006 384**
	12.02-10.07	LAB,OTK	**0 265 007 529**
	03.98-11.02	OTK,RAB	**0 265 006 385**
	12.02-10.07	OTK,RAB	**0 265 007 528**
1.4 i 16V [BB./CB./SB.]	**1,4 l 70-72 kW K4J 710,711,712,713,715 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	10.99-10.07		**0 265 005 263**
Wheel speed sensor, front	10.99-11.02		**0 265 006 383**
	12.02-10.07		**0 265 007 527**
Wheel speed sensor, rear	10.99-11.02	LAB,OTK	**0 265 006 384**
	12.02-10.07	LAB,OTK	**0 265 007 529**
	10.99-11.02	OTK,RAB	**0 265 006 385**
	12.02-10.07	OTK,RAB	**0 265 007 528**
1.5 DCI [BB./CB./SB.]	**1,5 l 48 kW K9K 700; K9K 704 4 Zyl.**		
Boost pressure sensor, Diesel	12.02-10.07		**0 281 002 593**
Duo sensor, acceleration and yaw rate, brake system	06.01-10.07		**0 265 005 263**
Wheel speed sensor, front	06.01-11.02		**0 265 006 383**
	12.02-10.07		**0 265 007 527**
Wheel speed sensor, rear	06.01-11.02	LAB,OTK	**0 265 006 384**
	12.02-10.07	LAB,OTK	**0 265 007 529**
	06.01-11.02	OTK,RAB	**0 265 006 385**
	12.02-10.07	OTK,RAB	**0 265 007 528**
1.5 DCI [BB./CB./SB.]	**1,5 l 50 kW K9K 714 4 Zyl.**		
Boost pressure sensor, Diesel	10.05-10.07		**0 281 002 593**
Duo sensor, acceleration and yaw rate, brake system	10.05-10.07		**0 265 005 263**
Wheel speed sensor, front	10.05-10.07		**0 265 007 527**
Wheel speed sensor, rear	10.05-10.07	LAB,OTK	**0 265 007 529**
		OTK,RAB	**0 265 007 528**
1.5 DCI [BB./CB./SB.]	**1,5 l 60 kW K9K 702; K9K 710 4 Zyl.**		
Boost pressure sensor, Diesel	12.02-10.07		**0 281 002 593**
Duo sensor, acceleration and yaw rate, brake system	06.01-10.07		**0 265 005 263**

R

Product			
◀ Clio II			
Wheel speed sensor, front	06.01-11.02		**0 265 006 383**
	12.02-10.07		**0 265 007 527**
Wheel speed sensor, rear	06.01-11.02	LAB,OTK	**0 265 006 384**
	12.02-10.07	LAB,OTK	**0 265 007 529**
	06.01-11.02	OTK,RAB	**0 265 006 385**
	12.02-10.07	OTK,RAB	**0 265 007 528**
1.5 DCI [BB./CB./SB.]		**1,5 l 74 kW K9K 712 4 Zyl.**	
Boost pressure sensor, Diesel	03.03-10.07		**0 281 002 573**
Duo sensor, acceleration and yaw rate, brake system	03.03-10.07		**0 265 005 263**
Wheel speed sensor, front	03.03-10.07		**0 265 007 527**
Wheel speed sensor, rear	03.03-10.07	LAB,OTK	**0 265 007 529**
		OTK,RAB	**0 265 007 528**
1.6 i [BB./CB./SB.]		**1,6 l 66 kW K4M 736,742 4 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	12.02-10.07		**0 265 005 263**
Wheel speed sensor, front	12.02-10.07		**0 265 007 527**
Wheel speed sensor, rear	12.02-10.07	LAB,OTK	**0 265 007 529**
		OTK,RAB	**0 265 007 528**
1.6 i [BB./CB./SB.]		**1,6 l 66 kW K4M 743,744,745,746; K7M 744 4 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	03.98-10.07		**0 265 005 263**
Wheel speed sensor, front	03.98-11.02		**0 265 006 383**
	12.02-10.07		**0 265 007 527**
Wheel speed sensor, rear	03.98-11.02	LAB,OTK	**0 265 006 384**
	12.02-10.07	LAB,OTK	**0 265 007 529**
	03.98-11.02	OTK,RAB	**0 265 006 385**
	12.02-10.07	OTK,RAB	**0 265 007 528**
1.6 i [BB./CB./SB.]		**1,6 l 66/81 kW K4M 740; K7M 745 4 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	03.98-10.07		**0 265 005 263**
Wheel speed sensor, front	03.98-11.02		**0 265 006 383**
	12.02-10.07		**0 265 007 527**
Wheel speed sensor, rear	03.98-11.02	LAB,OTK	**0 265 006 384**
	12.02-10.07	LAB,OTK	**0 265 007 529**
	03.98-11.02	OTK,RAB	**0 265 006 385**
	12.02-10.07	OTK,RAB	**0 265 007 528**
1.6 i 16V [BB./CB./SB.]		**1,6 l 79 kW K4M 708; K4M 748 4 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	06.98-10.07		**0 265 005 263**
Wheel speed sensor, front	06.98-11.02		**0 265 006 383**
	12.02-10.07		**0 265 007 527**
Wheel speed sensor, rear	06.98-11.02	LAB,OTK	**0 265 006 384**
	12.02-10.07	LAB,OTK	**0 265 007 529**
	06.98-11.02	OTK,RAB	**0 265 006 385**
	12.02-10.07	OTK,RAB	**0 265 007 528**
1.9 D [BB./CB./SB.]		**1,9 l 47-48 kW F8Q 630; F8Q 632; F8Q 662 4 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	03.98-10.07		**0 265 005 263**
Wheel speed sensor, front	03.98-11.02		**0 265 006 383**
	12.02-10.07		**0 265 007 527**
Wheel speed sensor, rear	03.98-11.02	LAB,OTK	**0 265 006 384**
	12.02-10.07	LAB,OTK	**0 265 007 529**
	03.98-11.02	OTK,RAB	**0 265 006 385**
	12.02-10.07	OTK,RAB	**0 265 007 528**
1.9 D DTI [BB./CB./SB.]		**1,9 l 59 kW F9Q 780; F9Q 782 4 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	03.99-10.07		**0 265 005 263**
Wheel speed sensor, front	03.99-11.02		**0 265 006 383**
	12.02-10.07		**0 265 007 527**
Wheel speed sensor, rear	03.99-11.02	LAB,OTK	**0 265 006 384**
	12.02-10.07	LAB,OTK	**0 265 007 529**
	03.99-11.02	OTK,RAB	**0 265 006 385**
	12.02-10.07	OTK,RAB	**0 265 007 528**
2.0 16V [BB./CB./SB.]		**2,0 l 124 kW F4R 730; F4R 732; F4R 736 4 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	03.99-10.07		**0 265 005 263**
Wheel speed sensor, front	03.99-11.02		**0 265 006 383**
	12.02-10.07		**0 265 007 527**
Wheel speed sensor, rear	03.99-11.02	LAB,OTK	**0 265 006 384**
	12.02-10.07	LAB,OTK	**0 265 007 529**
	03.99-11.02	OTK,RAB	**0 265 006 385**
	12.02-10.07	OTK,RAB	**0 265 007 528**
2.0 16V [BB./CB./SB.]		**2,0 l 124 kW F4R 738 4 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	03.03-10.07		**0 265 005 263**
Wheel speed sensor, front	03.03-10.07		**0 265 007 527**
Wheel speed sensor, rear	03.03-10.07	LAB,OTK	**0 265 007 529**
		OTK,RAB	**0 265 007 528**
3.0 24V Sport [BB./CB./SB.]		**3,0 l 170 kW L7X 760 6 Zyl.**	
Pressure sensor, intake manifold, gasoline	09.00-11.02		**0 261 230 041**
Wheel speed sensor, front	09.00-11.02	LAB	**0 265 006 384**
		RAB	**0 265 006 385**
Wheel speed sensor, rear	09.00-11.02	LAB	**0 265 006 384**
		RAB	**0 265 006 383**
3.0 24V Sport [BB./CB./SB.]		**3,0 l 170/188 kW L7X 762 6 Zyl.**	
Throttle valve assembly	09.00-06.05		**0 280 750 154**
Pressure sensor, intake manifold, gasoline	09.00-06.05		**0 261 230 041**
Wheel speed sensor, front	09.00-06.05	LAB	**0 265 006 384**
		RAB	**0 265 006 385**
Wheel speed sensor, rear	09.00-06.05	LAB	**0 265 006 384**
		RAB	**0 265 006 383**

Clio III

1.2 [BR./CR.]		**1,1 l 55/57,5 kW D4F 740; D4F 764 4 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	06.05→		**0 265 005 263**
Wheel speed sensor, front	06.05→		**0 265 007 742**
Wheel speed sensor, rear	06.05→	LAB,OTK	**0 265 007 606**
		OTK,RAB	**0 265 007 607**
		TKO	**0 265 007 597**
1.4 [BR./CR.]		**1,4 l 72 kW K4J 780 4 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	06.05→		**0 265 005 263**
Wheel speed sensor, front	06.05→		**0 265 007 742**
Wheel speed sensor, rear	06.05→	LAB,OTK	**0 265 007 606**
		OTK,RAB	**0 265 007 607**
		TKO	**0 265 007 597**
1.5 DCI [BR./CR.]		**1,5 l 50 kW K9K 752 4 Zyl.**	
Boost pressure sensor, Diesel	11.05→		**0 281 002 593**
Duo sensor, acceleration and yaw rate, brake system	11.05→		**0 265 005 263**
Wheel speed sensor, front	11.05→		**0 265 007 742**
Wheel speed sensor, rear	11.05→	LAB,OTK	**0 265 007 606**
		OTK,RAB	**0 265 007 607**
		TKO	**0 265 007 597**
1.5 DCI [BR./CR.]		**1,5 l 50/63 kW K9K 760; K9K 762; K9K 766; K9K 768 4 Zyl.**	
Boost pressure sensor, Diesel	06.05→		**0 281 002 566**
Duo sensor, acceleration and yaw rate, brake system	06.05→		**0 265 005 263**
Wheel speed sensor, front	06.05→		**0 265 007 742**

Product			
Wheel speed sensor, rear	06.05→	LAB,OTK	**0 265 007 606**
		OTK,RAB	**0 265 007 607**
		TKO	**0 265 007 597**
1.5 DCI [BR./CR.]		**1,5 l 65 kW K9K 750 4 Zyl.**	
Boost pressure sensor, Diesel	11.05→		**0 281 002 573**
Duo sensor, acceleration and yaw rate, brake system	11.05→		**0 265 005 263**
Wheel speed sensor, front	11.05→		**0 265 007 742**
Wheel speed sensor, rear	11.05→	LAB,OTK	**0 265 007 606**
		OTK,RAB	**0 265 007 607**
		TKO	**0 265 007 597**
1.5 DCI [BR./CR.]		**1,5 l 78 kW K9K 764 4 Zyl.**	
Boost pressure sensor, Diesel	06.05→		**0 281 002 566**
Duo sensor, acceleration and yaw rate, brake system	06.05→		**0 265 005 263**
Wheel speed sensor, front	06.05→		**0 265 007 742**
Wheel speed sensor, rear	06.05→	LAB,OTK	**0 265 007 606**
		OTK,RAB	**0 265 007 607**
		TKO	**0 265 007 597**
1.5 DCI [BR./CR.]		**1,5 l 78 kW K9K 772 4 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	03.06→		**0 265 005 263**
Wheel speed sensor, front	03.06→		**0 265 007 742**
Wheel speed sensor, rear	03.06→	LAB,OTK	**0 265 007 606**
		OTK,RAB	**0 265 007 607**
		TKO	**0 265 007 597**
1.6 [BR./CR.]		**1,6 l 65/82 kW K4M 800; K4M 801; K4M 802; K4M 804 4 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	06.05→		**0 265 005 263**
Wheel speed sensor, front	06.05→		**0 265 007 742**
Wheel speed sensor, rear	06.05→	LAB,OTK	**0 265 007 606**
		OTK,RAB	**0 265 007 607**
		TKO	**0 265 007 597**
2.0 [BR./CR.]		**2,0 l 102 kW M4R 700; M4R 701 4 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	06.05→		**0 265 005 263**
Wheel speed sensor, front	06.05→		**0 265 007 742**
Wheel speed sensor, rear	06.05→	LAB,OTK	**0 265 007 606**
		OTK,RAB	**0 265 007 607**
		TKO	**0 265 007 597**
2.0 Sport [BR./CR.]		**2,0 l 145 kW F4R 830 4 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	12.05→		**0 265 005 263**
Wheel speed sensor, front	12.05→	LAB	**0 265 007 810**
		RAB	**0 265 007 809**
Wheel speed sensor, rear	12.05→		**0 265 007 811**

Clio Sedan

1.6 i 16V		**1,6 l 81 kW K4M 740 4 Zyl.**	
Wheel speed sensor, front	01.01→	LAB	**0 265 006 384**
		RAB	**0 265 006 383**
Wheel speed sensor, rear	01.01→		**0 265 006 385**

Espace I

2.0 i [J11/13]		**2,0 l 86 kW J7R 760 4 Zyl.**	
Throttle valve sensor	06.87-12.90		**0 280 120 301**
Wheel speed sensor, front	01.88-12.90	LAB	**0 265 001 069**
		RAB	**0 265 001 068**
Wheel speed sensor, rear	01.88-12.90		**0 265 001 242**
2.0 i Quadra [J11/13]		**2,0 l 86 kW J7R 760 4 Zyl.**	
Throttle valve sensor	01.88-12.90		**0 280 120 301**
Acceleration sensor, ABS	01.88-12.90		**0 265 005 012**
Wheel speed sensor, front	01.88-12.90	LAB	**0 265 001 069**
		RAB	**0 265 001 068**
2.2 i [J11/13]		**2,2 l 79-81 kW J7T 770 Kat. 4 Zyl.**	
Throttle valve sensor	07.86-12.90		**0 280 120 301**
Wheel speed sensor, front	01.88-12.90	LAB	**0 265 001 069**
		RAB	**0 265 001 068**
Wheel speed sensor, rear	01.88-12.90		**0 265 001 242**
2.2 i Quadra [J11/13]		**2,2 l 79-81 kW J7T 770 Kat. 4 Zyl.**	
Throttle valve sensor	01.88-12.90		**0 280 120 301**
Acceleration sensor, ABS	01.88-12.90		**0 265 005 012**
Wheel speed sensor, front	01.88-12.90	LAB	**0 265 001 069**
		RAB	**0 265 001 068**

Espace II

2.0 i [J63]		**2,0 l 77 kW J7R 768 4 Zyl.**	
Throttle valve sensor	01.91-09.96	GS	**0 280 120 301**
Wheel speed sensor, front	01.91-09.96	LAB	**0 265 001 069**
		RAB	**0 265 001 068**
Wheel speed sensor, rear	01.91-09.96		**0 265 001 242**
2.1 D Turbo [J63]		**2,1 l 65 kW J8S 610 4 Zyl.**	
Wheel speed sensor, front	06.92-09.96	LAB	**0 265 001 069**
		RAB	**0 265 001 068**
Wheel speed sensor, rear	06.92-09.96		**0 265 001 242**
2.1 D Turbo [J63]		**2,1 l 65 kW J8S 772 4 Zyl.**	
Acceleration sensor, ABS	01.91-09.92	AA	**0 265 005 012**
	10.92-10.93	AA	**0 265 005 038**
Wheel speed sensor, front	01.91-10.93	LAB	**0 265 001 069**
		RAB	**0 265 001 068**
Wheel speed sensor, rear	01.91-10.93		**0 265 001 242**
2.1 D Turbo [J63]		**2,1 l 65/66 kW J8S 612; J8S 776; J8S 778 4 Zyl.**	
Wheel speed sensor, front	01.91-09.96	LAB	**0 265 001 069**
		RAB	**0 265 001 068**
Wheel speed sensor, rear	01.91-09.96		**0 265 001 242**
2.2 i [J63]		**2,2 l 79-81 kW J7T 772; J7T 772,773 4 Zyl.**	
Throttle valve sensor	01.91-09.96	GS	**0 280 120 301**
Acceleration sensor, ABS	01.91-09.92	AA	**0 265 005 012**
	10.92-09.96	AA	**0 265 005 038**
Wheel speed sensor, front	01.91-09.96	LAB	**0 265 001 069**
		RAB	**0 265 001 068**
Wheel speed sensor, rear	01.91-09.96		**0 265 001 242**
2.2 i [J63]		**2,2 l 79-81 kW J7T 776 4 Zyl.**	
Throttle valve sensor	05.93-09.96	GS	**0 280 120 301**
Wheel speed sensor, front	05.93-09.96	LAB	**0 265 001 069**
		RAB	**0 265 001 068**
Wheel speed sensor, rear	05.93-09.96		**0 265 001 242**
2.9 i [J63]		**2,9 l 110-113 kW Z7W 712,713; Z7W 717 6 Zyl.**	
Wheel speed sensor, front	01.91-09.96	LAB	**0 265 001 069**
		RAB	**0 265 001 068**
Wheel speed sensor, rear	01.91-09.96		**0 265 001 242**

Espace III

1.9 dTi [JE0]		**1,9 l 72 kW F9Q 720; F9Q 722 4 Zyl.**	
Wheel speed sensor, front	02.99-10.02	LAB	**0 265 006 283**
		RAB	**0 265 006 282**
Wheel speed sensor, rear	02.99-10.02		**0 265 006 284**
2.0 i [JE0]		**2,0 l 83,5 kW F3R 728; F3R 729; F3R 768; F3R 769 4 Zyl.**	
Wheel speed sensor, front	10.96-10.02	LAB	**0 265 006 283**
		RAB	**0 265 006 282**
Wheel speed sensor, rear	10.96-10.02		**0 265 006 284**
2.0 i GPL [JE0]		**2,0 l 83,5 kW F3R 742 4 Zyl.**	
Wheel speed sensor, front	02.98-10.02	LAB	**0 265 006 283**
		RAB	**0 265 006 282**
Wheel speed sensor, rear	02.98-10.02		**0 265 006 284**

R

Product			
◀ Espace III			
2.0 i 16V [JE0]	**2,0 l 102-103 kW F4R 700; F4R 701 4 Zyl.**		
Wheel speed sensor, front	10.98-10.02	LAB	**0 265 006 283**
		RAB	**0 265 006 282**
Wheel speed sensor, rear	10.98-10.02		**0 265 006 284**
2.2 D Turbo [JE0]	**2,2 l 83 kW G8T 714; G8T 716 4 Zyl.**		
Wheel speed sensor, front	10.96-10.02	LAB	**0 265 006 283**
		RAB	**0 265 006 282**
Wheel speed sensor, rear	10.96-10.02		**0 265 006 284**
2.2 DCI [JE0]	**2,2 l 95 kW G9T 710 4 Zyl.**		
Wheel speed sensor, front	07.00-10.02	LAB	**0 265 006 283**
		RAB	**0 265 006 282**
Wheel speed sensor, rear	07.00-10.02		**0 265 006 284**
3.0 i V6 [JE0]	**3,0 l 123 kW Z7X 775 4 Zyl.**		
Knock sensor	10.96-10.02	KZB	**0 261 231 070**
		KZG	**0 261 231 071**
Wheel speed sensor, front	10.96-10.02	LAB	**0 265 006 283**
		RAB	**0 265 006 282**
Wheel speed sensor, rear	10.96-10.02		**0 265 006 284**
3.0 i V6 24V [JE0]	**3,0 l 140 kW L7X 727 6 Zyl.**		
Knock sensor	10.98-10.02		**0 261 231 125**
Wheel speed sensor, front	10.98-10.02	LAB	**0 265 006 283**
		RAB	**0 265 006 282**
Wheel speed sensor, rear	10.98-10.02		**0 265 006 284**

Espace IV

1.9 DCI [JK0]	**1,9 l 88 kW F9Q 820 4 Zyl.**		
Boost pressure sensor, Diesel	11.02-08.03		**0 281 002 552**
	09.03-12.06		**0 281 002 566**
2.0 DCI [JK0]	**2,0 l 110/127 kW M9R 760 4 Zyl.**		
Boost pressure sensor, Diesel	05.05→		**0 281 002 740**
2.0 Turbo [JK0]	**2,0 l 120 kW F4R 794; F4R 795 4 Zyl.**		
Boost pressure sensor, gasoline	09.03-12.06		**0 281 002 616**
2.0 Turbo [JK0]	**2,0 l 125 kW F4R 796; F4R 797; F4R 896; F4R 897 4 Zyl.**		
Pressure sensor, intake manifold, gasoline	06.04→		**0 281 002 616**
2.0 16V [JK0]	**2,0 l 100 kW F4R 792 4 Zyl.**		
Pressure sensor, intake manifold, gasoline	07.04→		**0 281 002 616**
2.2 DCI [JK0]	**2,2 l 102 kW G9T 645 4 Zyl.**		
Boost pressure sensor, Diesel	07.05→		**0 281 002 566**
2.2 DCI [JK0]	**2,2 l 110 kW G9T 642 4 Zyl.**		
High-pressure sensor (CR system)	11.02-12.06		**0 281 002 534**
2.2 DCI [JK0]	**2,2 l 110 kW G9T 742; G9T 743 4 Zyl.**		
Boost pressure sensor, Diesel	11.02-08.03		**0 281 002 552**
	09.03-12.06		**0 281 002 566**
3.0 dV6 [JK0]	**3,0 l 130/133 kW P9X 701; P9X 715 6 Zyl.**		
Air mass meter, diesel	11.02→		**0 280 218 079**

Kangoo

1.0 i [FC./KC.]	**1,0 l 43 kW D7D 700; D7D 760 4 Zyl.**		
Wheel speed sensor, front	09.98-03.03		**0 265 006 528**
	04.03→		**0 265 007 527**
Wheel speed sensor, rear	09.98-03.03	ERH,LAB	**0 265 006 400**
	04.03→	ERH,LAB	**0 265 007 532**
	09.98-03.03	ERH,RAB	**0 265 006 401**
	04.03→	ERH,RAB	**0 265 007 531**
	09.98-03.03	LAB,NON	**0 265 006 386**
	04.03→	LAB,NON	**0 265 007 534**
	09.98-03.03	NON,RAB	**0 265 006 387**
	04.03→	NON,RAB	**0 265 007 533**
1.0 i 16V [FC./KC.]	**1,0 l 50 kW D4D 700; D4D 720 4 Zyl.**		
Wheel speed sensor, front	02.01-03.03		**0 265 006 528**
	04.03→		**0 265 007 527**
Wheel speed sensor, rear	02.01-03.03	ERH,LAB	**0 265 006 400**
	04.03→	ERH,LAB	**0 265 007 532**
	02.01-03.03	ERH,RAB	**0 265 006 401**
	04.03→	ERH,RAB	**0 265 007 531**
	02.01-03.03	LAB,NON	**0 265 006 386**
	04.03→	LAB,NON	**0 265 007 534**
	02.01-03.03	NON,RAB	**0 265 006 387**
	04.03→	NON,RAB	**0 265 007 533**
1.2 GPL [FC./KC.]	**1,2 l 44 kW D7F 710; D7F 722 4 Zyl.**		
Wheel speed sensor, front	10.97-03.03		**0 265 006 528**
	04.03→		**0 265 007 527**
Wheel speed sensor, rear	10.97-03.03	ERH,LAB	**0 265 006 400**
	04.03→	ERH,LAB	**0 265 007 532**
	10.97-03.03	ERH,RAB	**0 265 006 401**
	04.03→	ERH,RAB	**0 265 007 531**
	10.97-03.03	LAB,NON	**0 265 006 386**
	04.03→	LAB,NON	**0 265 007 534**
	10.97-03.03	NON,RAB	**0 265 006 387**
	04.03→	NON,RAB	**0 265 007 533**
1.2 i [FC./KC.]	**1,2 l 44 kW D7F 710 4 Zyl.**		
Wheel speed sensor, front	10.97-04.98		**0 265 006 528**
Wheel speed sensor, rear	10.97-04.98	ERH,LAB	**0 265 006 400**
		ERH,RAB	**0 265 006 401**
		LAB,NON	**0 265 006 386**
		NON,RAB	**0 265 006 387**
1.2 i [FC./KC.]	**1,2 l 44 kW D7F 720,726,744,746,764 4 Zyl.**		
Wheel speed sensor, front	03.98-03.03		**0 265 006 528**
	04.03→		**0 265 007 527**
Wheel speed sensor, rear	03.98-03.03	ERH,LAB	**0 265 006 400**
	04.03→	ERH,LAB	**0 265 007 532**
	03.98-03.03	ERH,RAB	**0 265 006 401**
	04.03→	ERH,RAB	**0 265 007 531**
	03.98-03.03	LAB,NON	**0 265 006 386**
	04.03→	LAB,NON	**0 265 007 534**
	03.98-03.03	NON,RAB	**0 265 006 387**
	04.03→	NON,RAB	**0 265 007 533**
1.2 i [FC./KC.]	**1,2 l 44 kW D7F 766 4 Zyl.**		
Wheel speed sensor, front	03.02-03.03		**0 265 006 528**
	04.03→		**0 265 007 527**
Wheel speed sensor, rear	03.02-03.03	ERH,LAB	**0 265 006 400**
	04.03→	ERH,LAB	**0 265 007 532**
	03.02-03.03	ERH,RAB	**0 265 006 401**
	04.03→	ERH,RAB	**0 265 007 531**
	03.02-03.03	LAB,NON	**0 265 006 386**
	04.03→	LAB,NON	**0 265 007 534**
	03.02-03.03	NON,RAB	**0 265 006 387**
	04.03→	NON,RAB	**0 265 007 533**
1.2 i 16V [FC./KC.]	**1,2 l 55 kW D4F 712,714,716 4 Zyl.**		
Wheel speed sensor, front	05.00-03.03		**0 265 006 528**
	04.03→		**0 265 007 527**
Wheel speed sensor, rear	05.00-03.03	ERH,LAB	**0 265 006 400**
	04.03→	ERH,LAB	**0 265 007 532**
	05.00-03.03	ERH,RAB	**0 265 006 401**
	04.03→	ERH,RAB	**0 265 007 531**
	05.00-03.03	LAB,NON	**0 265 006 386**
	04.03→	LAB,NON	**0 265 007 534**
	05.00-03.03	NON,RAB	**0 265 006 387**
	04.03→	NON,RAB	**0 265 007 533**

R

Product			
1.2 i 16V [FC./KC.]			**1,2 l 55 kW D4F 730 4 Zyl.**
Wheel speed sensor, front	04.04→		**0 265 007 527**
Wheel speed sensor, rear	04.04→	ERH,LAB	**0 265 007 532**
		ERH,RAB	**0 265 007 531**
		LAB,NON	**0 265 007 534**
		NON,RAB	**0 265 007 533**
1.4 i [FC./KC.]			**1,4 l 55 kW E7J 634,635,780; K7J 700,701 4 Zyl.**
Wheel speed sensor, front	10.97-03.03		**0 265 006 528**
	04.03→		**0 265 007 527**
Wheel speed sensor, rear	10.97-03.03	ERH,LAB	**0 265 006 400**
	04.03→	ERH,LAB	**0 265 007 532**
	10.97-03.03	ERH,RAB	**0 265 006 401**
	04.03→	ERH,RAB	**0 265 007 531**
	10.97-03.03	LAB,NON	**0 265 006 386**
	04.03→	LAB,NON	**0 265 007 534**
	10.97-03.03	NON,RAB	**0 265 006 387**
	04.03→	NON,RAB	**0 265 007 533**
1.5 DCI [FC./KC.]			**1,5 l K9K 716 4 Zyl.**
Boost pressure sensor, Diesel	04.05→		**0 281 002 593**
Wheel speed sensor, front	04.05→		**0 265 007 527**
Wheel speed sensor, rear	04.05→	ERH,LAB	**0 265 007 532**
		ERH,RAB	**0 265 007 531**
		LAB,NON	**0 265 007 534**
		NON,RAB	**0 265 007 533**
1.5 DCI [FC./KC.]			**1,5 l 48 kW K9K 700; K9K 704 4 Zyl.**
Boost pressure sensor, Diesel	11.02→		**0 281 002 593**
Wheel speed sensor, front	05.00-03.03		**0 265 006 528**
	04.03→		**0 265 007 527**
Wheel speed sensor, rear	05.00-03.03	ERH,LAB	**0 265 006 400**
	04.03→	ERH,LAB	**0 265 007 532**
	05.00-03.03	ERH,RAB	**0 265 006 401**
	04.03→	ERH,RAB	**0 265 007 531**
	05.00-03.03	LAB,NON	**0 265 006 386**
	04.03→	LAB,NON	**0 265 007 534**
	05.00-03.03	NON,RAB	**0 265 006 387**
	04.03→	NON,RAB	**0 265 007 533**
1.5 DCI [FC./KC.]			**1,5 l 50 kW K9K 714 4 Zyl.**
Boost pressure sensor, Diesel	04.05→		**0 281 002 593**
Wheel speed sensor, front	04.05→		**0 265 007 527**
Wheel speed sensor, rear	04.05→	ERH,LAB	**0 265 007 532**
		ERH,RAB	**0 265 007 531**
		LAB,NON	**0 265 007 534**
		NON,RAB	**0 265 007 533**
1.5 DCI [FC./KC.]			**1,5 l 60 kW K9K 702; K9K 710 4 Zyl.**
Boost pressure sensor, Diesel	11.02→		**0 281 002 593**
Wheel speed sensor, front	02.01-03.03		**0 265 006 528**
	04.03→		**0 265 007 527**
Wheel speed sensor, rear	02.01-03.03	ERH,LAB	**0 265 006 400**
	04.03→	ERH,LAB	**0 265 007 532**
	02.01-03.03	ERH,RAB	**0 265 006 401**
	04.03→	ERH,RAB	**0 265 007 531**
	02.01-03.03	LAB,NON	**0 265 006 386**
	04.03→	LAB,NON	**0 265 007 534**
	02.01-03.03	NON,RAB	**0 265 006 387**
	04.03→	NON,RAB	**0 265 007 533**
1.5 DCI [FC./KC.]			**1,5 l 62 kW K9K 718 4 Zyl.**
Boost pressure sensor, Diesel	04.05→		**0 281 002 593**
Wheel speed sensor, front	04.05→		**0 265 007 527**
Wheel speed sensor, rear	04.05→	ERH,LAB	**0 265 007 532**
		ERH,RAB	**0 265 007 531**
		LAB,NON	**0 265 007 534**
		NON,RAB	**0 265 007 533**

Product			
1.6 i [FC./KC.]			**1,6 l 66/70 kW K4M 708,730,732,754; K7M 746 4 Zyl.**
Wheel speed sensor, front	09.99-03.03		**0 265 006 528**
	04.03→		**0 265 007 527**
Wheel speed sensor, rear	09.99-03.03	ERH,LAB	**0 265 006 400**
	04.03→	ERH,LAB	**0 265 007 532**
	09.99-03.03	ERH,RAB	**0 265 006 401**
	04.03→	ERH,RAB	**0 265 007 531**
	09.99-03.03	LAB,NON	**0 265 006 386**
	04.03→	LAB,NON	**0 265 007 534**
	09.99-03.03	NON,RAB	**0 265 006 387**
	04.03→	NON,RAB	**0 265 007 533**
1.6 i [FC./KC.]			**1,6 l 70 kW K4M 750,752,753 4 Zyl.**
Wheel speed sensor, front	06.00-03.03		**0 265 006 528**
	04.03→		**0 265 007 527**
Wheel speed sensor, rear	06.00-03.03	ERH,LAB	**0 265 006 400**
	04.03→	ERH,LAB	**0 265 007 532**
	06.00-03.03	ERH,RAB	**0 265 006 401**
	04.03→	ERH,RAB	**0 265 007 531**
	06.00-03.03	LAB,NON	**0 265 006 386**
	04.03→	LAB,NON	**0 265 007 534**
	06.00-03.03	NON,RAB	**0 265 006 387**
	04.03→	NON,RAB	**0 265 007 533**
1.6 i 4x4 [FC./KC.]			**1,6 l 70 kW K4M 708,750,752,753,754 4 Zyl.**
Wheel speed sensor, front	06.00→		**0 265 006 710**
Wheel speed sensor, rear	06.00→		**0 265 006 711**
1.9 D [FC./KC.]			**1,9 l 40/47-48 kW F8Q 630,632,662 4 Zyl.**
Wheel speed sensor, front	10.97-03.03		**0 265 006 528**
	04.03→		**0 265 007 527**
Wheel speed sensor, rear	10.97-03.03	ERH,LAB	**0 265 006 400**
	04.03→	ERH,LAB	**0 265 007 532**
	10.97-03.03	ERH,RAB	**0 265 006 401**
	04.03→	ERH,RAB	**0 265 007 531**
	10.97-03.03	LAB,NON	**0 265 006 386**
	04.03→	LAB,NON	**0 265 007 534**
	10.97-03.03	NON,RAB	**0 265 006 387**
	04.03→	NON,RAB	**0 265 007 533**
1.9 D DCI [FC./KC.]			**1,9 l 59 kW F9Q 790 4 Zyl.**
Wheel speed sensor, front	05.00-03.03		**0 265 006 528**
	04.03→		**0 265 007 527**
Wheel speed sensor, rear	05.00-03.03	ERH,LAB	**0 265 006 400**
	04.03→	ERH,LAB	**0 265 007 532**
	05.00-03.03	ERH,RAB	**0 265 006 401**
	04.03→	ERH,RAB	**0 265 007 531**
	05.00-03.03	LAB,NON	**0 265 006 386**
	04.03→	LAB,NON	**0 265 007 534**
	05.00-03.03	NON,RAB	**0 265 006 387**
	04.03→	NON,RAB	**0 265 007 533**
1.9 D DCI 4x4 [FC./KC.]			**1,9 l 59 kW F9Q 782; F9Q 790 4 Zyl.**
Wheel speed sensor, front	05.00→		**0 265 006 710**
Wheel speed sensor, rear	05.00→		**0 265 006 711**
1.9 D DTI [FC./KC.]			**1,9 l 59 kW F9Q 780 4 Zyl.**
Wheel speed sensor, front	09.98-03.03		**0 265 006 528**
	04.03→		**0 265 007 527**
Wheel speed sensor, rear	09.98-03.03	ERH,LAB	**0 265 006 400**
	04.03→	ERH,LAB	**0 265 007 532**
	09.98-03.03	ERH,RAB	**0 265 006 401**
	04.03→	ERH,RAB	**0 265 007 531**
	09.98-03.03	LAB,NON	**0 265 006 386**
	04.03→	LAB,NON	**0 265 007 534**
	09.98-03.03	NON,RAB	**0 265 006 387**
	04.03→	NON,RAB	**0 265 007 533**

R

Product			

Laguna I

1.9 DTI [B56]			**1,9 l 72 kW F9Q 716 4 Zyl.**
Speed sensor, diesel	10.97-09.99		**0 281 002 175**
2.0 i 16V [B56]			**2,0 l 102 kW N7Q 700; N7Q 704 4 Zyl.**
Phase sensor	09.95-02.01		**0 232 101 030**
3.0 i [B56]			**3,0 l 123-125 kW Z7X 760; Z7X 765; Z7X 767 6 Zyl.**
Knock sensor	01.94-02.01	KZB	**0 261 231 070**
		KZG	**0 261 231 071**
3.0 i 24V [B56]			**3,0 l 143 kW L7X 700; L7X 701 6 Zyl.**
Knock sensor	03.97-02.01		**0 261 231 125**

Laguna I Grandtour

1.9 DTI [K56]			**1,9 l 72 kW F9Q 716 4 Zyl.**
Speed sensor, diesel	10.97-09.99		**0 281 002 175**
1.9 DTI [S56]			**1,9 l 72 kW F9Q 716 4 Zyl.**
Speed sensor, diesel	03.98-02.01		**0 281 002 175**
2.0 i 16V [K56]			**2,0 l 102 kW N7Q 700; N7Q 704 4 Zyl.**
Phase sensor	09.95-02.01		**0 232 101 030**
3.0 i [K56]			**3,0 l 123-125 kW Z7X 765; Z7X 767 6 Zyl.**
Knock sensor	03.96-02.01	KZB	**0 261 231 070**
		KZG	**0 261 231 071**
3.0 i 24V [K56]			**3,0 l 143 kW L7X 700; L7X 701 6 Zyl.**
Knock sensor	03.97-02.01		**0 261 231 125**

Laguna II

1.9 DCI [BG.]			**1,9 l 68 kW F9Q 664 4 Zyl.**
Boost pressure sensor, Diesel	01.05-09.07		**0 281 002 566**
1.9 DCI [BG.]			**1,9 l 74 kW F9Q 752; F9Q 754 4 Zyl.**
Boost pressure sensor, Diesel	03.01-09.07		**0 281 002 552**
1.9 DCI [BG.]			**1,9 l 81-96 kW F9Q 670; F9Q 674 4 Zyl.**
Boost pressure sensor, Diesel	09.04-09.07		**0 281 002 566**
1.9 DCI [BG.]			**1,9 l 88 kW F9Q 750 4 Zyl.**
Boost pressure sensor, Diesel	03.01-08.03		**0 281 002 552**
	09.03-09.07		**0 281 002 566**
2.0 DCI [BG.]			**2,0 l 110/127 kW M9R 740; M9R 760 4 Zyl.**
Boost pressure sensor, Diesel	09.04-09.07		**0 281 002 740**
2.0 T [BG.]			**2,0 l 120 kW F4R 764 4 Zyl.**
Pressure sensor, intake manifold, gasoline	09.03-09.07		**0 281 002 616**
2.0 T [BG.]			**2,0 l 120/150 kW F4R 765,784,786,787,886 4 Zyl.**
Pressure sensor, intake manifold, gasoline	07.02-09.07		**0 281 002 616**
2.0 T [BG.]			**2,0 l 150 kW F4R 887 4 Zyl.**
Pressure sensor, intake manifold, gasoline	01.05-09.07		**0 281 002 616**
2.2 DCI [BG.]			**2,2 l 102 kW G9T 605 4 Zyl.**
Boost pressure sensor, Diesel	07.05-09.07		**0 281 002 566**
2.2 DCI [BG.]			**2,2 l 110 kW G9T 600 4 Zyl.**
High-pressure sensor (CR system)	07.02-09.07		**0 281 002 534**
Boost pressure sensor, Diesel	07.02-09.07		**0 281 002 566**
2.2 DCI [BG.]			**2,2 l 110 kW G9T 702; G9T 703 4 Zyl.**
Boost pressure sensor, Diesel	03.01-09.07		**0 281 002 552**
3.0 V6 24V [BG.]			**3,0 l 152 kW L7X 731; L7X 733 6 Zyl.**
Pressure sensor, intake manifold, gasoline	03.01-09.07		**0 261 230 041**

Laguna II Grandtour

1.9 DCI [KG.]			**1,9 l 68 kW F9Q 664 4 Zyl.**
Boost pressure sensor, Diesel	01.05-09.07		**0 281 002 566**
1.9 DCI [KG.]			**1,9 l 74 kW F9Q 752; F9Q 754 4 Zyl.**
Boost pressure sensor, Diesel	03.01-09.07		**0 281 002 552**
1.9 DCI [KG.]			**1,9 l 81-96 kW F9Q 670; F9Q 674 4 Zyl.**
Boost pressure sensor, Diesel	01.05-09.07		**0 281 002 566**
1.9 DCI [KG.]			**1,9 l 88 kW F9Q 750 4 Zyl.**
Boost pressure sensor, Diesel	03.01-08.03		**0 281 002 552**
	09.03-09.07		**0 281 002 566**
2.0 DCI [KG.]			**2,0 l 110/127 kW M9R 740,760 4 Zyl.**
Boost pressure sensor, Diesel	09.04-09.07		**0 281 002 740**
2.0 T [KG.]			**2,0 l 120 kW F4R 764,765,786,787,886 4 Zyl.**
Pressure sensor, intake manifold, gasoline	09.03-09.07		**0 281 002 616**
2.0 T [KG.]			**2,0 l 120/150 kW F4R 784,887 4 Zyl.**
Pressure sensor, intake manifold, gasoline	01.05-09.07		**0 281 002 616**
2.2 DCI [KG.]			**2,2 l 102 kW G9T 605 4 Zyl.**
Boost pressure sensor, Diesel	07.05-09.07		**0 281 002 566**
2.2 DCI [KG.]			**2,2 l 110 kW G9T 600 4 Zyl.**
High-pressure sensor (CR system)	07.02-09.07		**0 281 002 534**
Boost pressure sensor, Diesel	07.02-09.07		**0 281 002 566**
2.2 DCI [KG.]			**2,2 l 110 kW G9T 702; G9T 703 4 Zyl.**
Boost pressure sensor, Diesel	03.01-09.07		**0 281 002 552**
3.0 V6 24V [KG.]			**3,0 l 152 kW L7X 733 6 Zyl.**
Pressure sensor, intake manifold, gasoline	04.04-09.07		**0 261 230 041**

Logan

1.4 MPI [KS./LS.]			**1,4 l 55 kW K7J 710 4 Zyl.**
Wheel speed sensor, front	07.04→		**0 265 007 742**
Wheel speed sensor, rear	07.04→	LAB	**0 265 007 583**
		RAB	**0 265 007 582**
1.5 dCi [KS./LS.]			**1,5 l 48/50 kW K9K 790,792 4 Zyl.**
Boost pressure sensor, Diesel	06.05→		**0 281 002 593**
Wheel speed sensor, front	06.05→		**0 265 007 742**
Wheel speed sensor, rear	06.05→	LAB	**0 265 007 583**
		RAB	**0 265 007 582**
1.6 MPI [KS./LS.]			**1,6 l 64 kW K7M 710 4 Zyl.**
Wheel speed sensor, front	07.04→		**0 265 007 742**
Wheel speed sensor, rear	07.04→	LAB	**0 265 007 583**
		RAB	**0 265 007 582**
1.6 16V [KS./LS.]			**1,6 l 77 kW K4M 690 4 Zyl.**
Wheel speed sensor, front	12.05→		**0 265 007 742**
Wheel speed sensor, rear	12.05→	LAB	**0 265 007 583**
		RAB	**0 265 007 582**

Master

T28 -35			**2,2 l 67 kW J7T 782 Kat. 4 Zyl.**
Throttle valve sensor	09.80-09.97		**0 280 120 301**
1.9 dCi 80 [X70]			**1,9 l 60 kW F9Q 774 4 Zyl.**
Boost pressure sensor, Diesel	10.03-10.06		**0 281 002 573**
2.2 dCi 90 [X70]			**2,2 l 66 kW G9T 750 4 Zyl.**
Boost pressure sensor, Diesel	10.03-10.06		**0 281 002 573**
2.5 dCi 16V			**2,5 l 85 kW G9U-724 4 Zyl.**
Boost pressure sensor, Diesel	10.04→		**0 281 002 573**
2.5 dCi 100, dCi 110 [X70]			**2,5 l 73 kW G9U 754 4 Zyl.**
Boost pressure sensor, Diesel	10.03-10.06		**0 281 002 573**
2.5 dCi 120 [X70]			**2,5 l 84 kW G9U 724; G9U 750; G9U 754 4 Zyl.**
Boost pressure sensor, Diesel	07.02-10.06		**0 281 002 573**
2.5 dCi 120 FAP			**2,5 l 88 kW G9U 632 (M1) 4 Zyl.**
Boost pressure sensor, Diesel	11.06→		**0 281 002 566**
2.5 dCi 150 FAP			**2,5 l 107 kW G9U 632 (MY) 4 Zyl.**
Boost pressure sensor, Diesel	11.06→		**0 281 002 566**
2.8 dTi 110 [X70]			**2,8 l 84 kW S9W 700 4 Zyl.**
Speed sensor, diesel	10.97-12.98		**0 281 002 093**
2.8 dTi 120 [X70]			**2,8 l 84 kW S9W 702 4 Zyl.**
Speed sensor, diesel	10.97-12.98		**0 281 002 093**
3.0 dCi 140 [X70]			**3,0 l 100 kW ZD3 200; ZD3 202 4 Zyl.**
High-pressure sensor (CR system)	10.03-10.06		**0 281 002 534**

Product			

Megane I

1.4 i [X64]			**1,4 l 51-55 kW E7J 626 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.99-10.02		**0 281 002 616**
1.4 i 16V [X64]			**1,4 l 70 kW K4J 714; K4J 750 4 Zyl.**
Pressure sensor, intake manifold, gasoline	06.98-10.02		**0 281 002 616**
Duo sensor, acceleration and yaw rate, brake system	01.01-10.02	TKO	**0 265 005 263**
1.6 i 16V [X64]			**1,6 l 79 kW K4M 700; K4M 701 4 Zyl.**
Pressure sensor, intake manifold, gasoline	06.98-10.02		**0 281 002 616**
Duo sensor, acceleration and yaw rate, brake system	01.01-10.02	TKO	**0 265 005 263**
1.6 i 16V [X64]			**1,6 l 79 kW K4M 704; K4M 706 4 Zyl.**
Pressure sensor, intake manifold, gasoline	03.99-10.02		**0 281 002 616**
1.6 i 16V [X64]			**1,6 l 79 kW K4M 708 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.00-10.02		**0 281 002 616**
Duo sensor, acceleration and yaw rate, brake system	01.01-10.02	TKO	**0 265 005 263**
1.6 i 16V [X64]			**1,6 l 79 kW K4M 709; K4M 712 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.00-10.02		**0 281 002 616**
1.8 i 16V [X64]			**1,8 l 85/88 kW F4P 720; F4P 722 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.99-10.02	TKO	**0 265 005 263**
1.9 DTI [X64]			**1,9 l 59 kW F9Q 744 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	01.01-10.02	TKO	**0 265 005 263**
1.9 DTI [X64]			**1,9 l 69 kW F9Q 730 4 Zyl.**
Air mass meter, diesel	06.97-02.99		**0 281 002 195**
Speed sensor, diesel	06.97-02.99		**0 281 002 175**
Pedal position sensor, diesel	06.97-02.99	LLE	**0 206 001 021**
		RLE	**0 281 002 221**
1.9 DTI [X64]			**1,9 l 72 kW F9Q 731 4 Zyl.**
Pedal position sensor, diesel	03.99-03.99	LLE	**0 206 001 021**
		RLE	**0 281 002 221**
1.9 DTI [X64]			**1,9 l 72 kW F9Q 734 4 Zyl.**
Speed sensor, diesel	06.97-06.98		**0 281 002 175**
Pedal position sensor, diesel	06.97-02.99	LLE	**0 206 001 021**
		RLE	**0 281 002 221**
1.9 DTI [X64]			**1,9 l 72 kW F9Q 736 4 Zyl.**
Pedal position sensor, diesel	03.99-03.99	LLE	**0 206 001 021**
		RLE	**0 281 002 221**
2.0 i 16V [X64]			**2,0 l 101,5 kW F4R 740 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.00-10.02		**0 281 002 616**
Duo sensor, acceleration and yaw rate, brake system	05.00-10.02		**0 265 005 263**
2.0 i 16V [X64]			**2,0 l 103 kW F4R 746 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	05.00-10.02		**0 265 005 263**
2.0 i 16V [X64]			**2,0 l 108-110 kW F7R 710; F7R 714 4 Zyl.**
Knock sensor	01.96-10.02		**0 261 231 046**

Megane I Cabrio

2.0 i 16V [X64]			**2,0 l 108 kW F7R 710; F7R 714 4 Zyl.**
Knock sensor	09.96-09.03		**0 261 231 046**

Megane I Classic

1.9 DCI [X64]			**1,9 l 72-75 kW F9Q 732 4 Zyl.**
Boost pressure sensor, Diesel	11.02-09.03		**0 281 002 593**
1.9 DTI [X64]			**1,9 l 59 kW F9Q 744 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	11.00-09.03		**0 265 005 263**
1.9 DTI [X64]			**1,9 l 72 kW F9Q 730 4 Zyl.**
Air mass meter, diesel	08.97-09.03		**0 281 002 195**
Pulse generator, diesel	08.97-09.03		**0 281 002 175**
Pedal position sensor, diesel	08.97-09.03	LLE	**0 206 001 021**
		RLE	**0 281 002 221**
1.9 DTI [X64]			**1,9 l 72 kW F9Q 734 4 Zyl.**
Pulse generator, diesel	08.97-06.98		**0 281 002 175**
Pedal position sensor, diesel	08.97-02.99	LLE	**0 206 001 021**
		RLE	**0 281 002 221**

Megane I Coupé

1.9 DTI [X64]			**1,9 l 72 kW F9Q 734 4 Zyl.**
Pulse generator, diesel	06.97-06.98		**0 281 002 175**
2.0 i 16V [X64]			**2,0 l 108 kW F7R 710; F7R 714 4 Zyl.**
Knock sensor	01.96-10.02		**0 261 231 046**

Megane I Grandtour

1.9 DCI [X64]			**1,9 l 72-75 kW F9Q 732 4 Zyl.**
Boost pressure sensor, Diesel	11.02-09.03		**0 281 002 593**

Megane II

1.4 16V [LM.]			**1,4 l 72 kW K4J 730,732,740 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.03→		**0 265 005 263**
1.5 DCI [LM.]			**1,5 l 60 kW K4J 730,732,740 4 Zyl.**
Boost pressure sensor, Diesel	11.02→		**0 281 002 573**
Duo sensor, acceleration and yaw rate, brake system	11.02→		**0 265 005 263**
1.5 DCI [LM.]			**1,5 l 63/78 kW K9K 724; K9K 732 4 Zyl.**
Boost pressure sensor, Diesel	09.04→		**0 281 002 566**
Duo sensor, acceleration and yaw rate, brake system	09.04→		**0 265 005 263**
1.6 16V [LM.]			**1,6 l 83 kW K4M 760,761,762,764,768 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.03→		**0 265 005 263**
1.6 16V [LM.]			**1,6 l 83 kW K4M 812; K4M 813 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	05.05→		**0 265 005 263**
1.9 DCI [LM.]			**1,9 l 68/88 kW F9Q 800; F9Q 808 4 Zyl.**
Boost pressure sensor, Diesel	10.03→		**0 281 002 566**
Duo sensor, acceleration and yaw rate, brake system	10.03→		**0 265 005 263**
1.9 DCI [LM.]			**1,9 l 96 kW F9Q 803; F9Q 804; F9Q 814 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	05.04→		**0 265 005 263**
2.0 DCI [LM.]			**2,0 l 110 kW M9R 700 4 Zyl.**
Boost pressure sensor, Diesel	09.04→		**0 281 002 740**
Duo sensor, acceleration and yaw rate, brake system	09.04→		**0 265 005 263**
2.0 16V [LM.]			**2,0 l 99 kW F4R 770; F4R 771 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.02→		**0 265 005 263**

Megane II Cabrio

1.5 DCI [EM.]			**1,5 l 78 kW K9K 732 4 Zyl.**
Boost pressure sensor, Diesel	12.05→		**0 281 002 566**
Duo sensor, acceleration and yaw rate, brake system	12.05→		**0 265 005 263**

R

Product

◀ Megane II Cabrio

1.6 16V [EM.]	**1,6 l 83 kW K4M 760; K4M 761; K4M 812; K4M 813 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	10.03→		**0 265 005 263**
1.9 DCI [EM.]	**1,9 l 88 kW F9Q 800 4 Zyl.**		
Boost pressure sensor, Diesel	10.03→		**0 281 002 566**
Duo sensor, acceleration and yaw rate, brake system	10.03→		**0 265 005 263**
1.9 DCI [EM.]	**1,9 l 96 kW F9Q 803; F9Q 804; F9Q 814 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	05.04→		**0 265 005 263**
2.0 DCI [EM.]	**2,0 l 110 kW M9R 700 4 Zyl.**		
Boost pressure sensor, Diesel	09.04→		**0 281 002 740**
Duo sensor, acceleration and yaw rate, brake system	09.04→		**0 265 005 263**
2.0 T [EM.]	**2,0 l 120 kW F4R 776 4 Zyl.**		
Boost pressure sensor, gasoline	10.03→		**0 281 002 616**
Duo sensor, acceleration and yaw rate, brake system	10.03→		**0 265 005 263**
2.0 16V [EM.]	**2,0 l 99 kW F4R 770; F4R 771 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	10.03→		**0 265 005 263**

R

Megane II Grandtour

1.4 16V [KM.]	**1,4 l 72 kW K4J 730; K4J 740 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	10.03→		**0 265 005 263**
1.5 DCI [KM.]	**1,5 l 60 kW K9K 722; K9K 728; K9K 729 4 Zyl.**		
Boost pressure sensor, Diesel	10.03→		**0 281 002 573**
Duo sensor, acceleration and yaw rate, brake system	10.03→		**0 265 005 263**
1.5 DCI [KM.]	**1,5 l 63/78 kW K9K 724; K9K 732 4 Zyl.**		
Boost pressure sensor, Diesel	10.04→		**0 281 002 566**
Duo sensor, acceleration and yaw rate, brake system	10.04→		**0 265 005 263**
1.6 16V [KM.]	**1,6 l 83 kW K4M 760,761,762,764,768 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	10.03→		**0 265 005 263**
1.6 16V [KM.]	**1,6 l 83 kW K4M 812; K4M 813 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	05.05→		**0 265 005 263**
1.9 DCI [KM.]	**1,9 l 68/88 kW F9Q 800; F9Q 808 4 Zyl.**		
Boost pressure sensor, Diesel	10.03→		**0 281 002 566**
Duo sensor, acceleration and yaw rate, brake system	10.03→		**0 265 005 263**
1.9 DCI [KM.]	**1,9 l 96 kW F9Q 803; F9Q 804; F9Q 814 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	05.04→		**0 265 005 263**
2.0 DCI [KM.]	**2,0 l 110 kW M9R 700 4 Zyl.**		
Boost pressure sensor, Diesel	09.04→		**0 281 002 740**
Duo sensor, acceleration and yaw rate, brake system	09.04→		**0 265 005 263**
2.0 16V [KM.]	**2,0 l 99 kW F4R 770; F4R 771 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	10.03→		**0 265 005 263**

Megane II Hatchback

1.4 16V [BM./CM./GM./SM.]	**1,4 l 72 kW K4J 730; K4J 732; K4J 740 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	11.02→		**0 265 005 263**

Product

1.5 DCI [BM./CM./GM./SM.]	**1,5 l 60 kW K9K 722; K9K 728; K9K 729 4 Zyl.**		
Boost pressure sensor, Diesel	11.02→		**0 281 002 573**
Duo sensor, acceleration and yaw rate, brake system	11.02→		**0 265 005 263**
1.5 DCI [BM./CM./GM./SM.]	**1,5 l 63/78 kW K9K 724; K9K 732 4 Zyl.**		
Boost pressure sensor, Diesel	10.04→		**0 281 002 566**
Duo sensor, acceleration and yaw rate, brake system	10.04→		**0 265 005 263**
1.6 16V [BM./CM./GM./SM.]	**1,6 l 83 kW K4M 760,761,764,788,812 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	11.02→		**0 265 005 263**
1.6 16V [BM./CM./GM./SM.]	**1,6 l 83 kW K4M 813 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	05.05→		**0 265 005 263**
1.9 DCI [BM./CM./GM./SM.]	**1,9 l 68/88 kW F9Q 800; F9Q 808 4 Zyl.**		
Boost pressure sensor, Diesel	11.02→		**0 281 002 566**
Duo sensor, acceleration and yaw rate, brake system	11.02→		**0 265 005 263**
1.9 DCI [BM./CM./GM./SM.]	**1,9 l 96 kW F9Q 803; F9Q 804; F9Q 814 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	05.04→		**0 265 005 263**
2.0 DCI [BM./CM./GM./SM.]	**2,0 l 110 kW M9R 700 4 Zyl.**		
Boost pressure sensor, Diesel	09.04→		**0 281 002 740**
Duo sensor, acceleration and yaw rate, brake system	09.04→		**0 265 005 263**
2.0 T [BM./CM./GM./SM.]	**2,0 l 120 kW F4R 776 4 Zyl.**		
Boost pressure sensor, gasoline	05.04→		**0 281 002 616**
Duo sensor, acceleration and yaw rate, brake system	05.04→		**0 265 005 263**
2.0 16V [BM./CM./GM./SM.]	**2,0 l 99 kW F4R 770; F4R 771 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	11.02→		**0 265 005 263**
2.0 16V Sport [BM./CM./GM./SM.]	**2,0 l 165 kW F4R 774 4 Zyl.**		
Boost pressure sensor, gasoline	03.03→		**0 281 002 616**
Duo sensor, acceleration and yaw rate, brake system	03.03→		**0 265 005 263**

Modus

1.2 i 16V [FP./JP.]	**1,2 l 55/57,5 kW D4F 740; D4F 764 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	09.04→		**0 265 005 263**
Wheel speed sensor, front	09.04→		**0 265 007 742**
Wheel speed sensor, rear	09.04→	LAB,OTK	**0 265 007 606**
		OTK,RAB	**0 265 007 607**
		TKO	**0 265 007 597**
1.4 i 16V [FP./JP.]	**1,4 l 72 kW K4J 770; K4J 780 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	06.04-12.06		**0 265 005 263**
Wheel speed sensor, front	06.04-12.06		**0 265 007 742**
Wheel speed sensor, rear	06.04-12.06	LAB,OTK	**0 265 007 606**
		OTK,RAB	**0 265 007 607**
		TKO	**0 265 007 597**
1.5 DCI [FP./JP.]	**1,5 l 50 kW K9K 752 4 Zyl.**		
Boost pressure sensor, Diesel	09.04→		**0 281 002 593**
Duo sensor, acceleration and yaw rate, brake system	09.04→		**0 265 005 263**
Wheel speed sensor, front	09.04→		**0 265 007 742**
Wheel speed sensor, rear	09.04→	LAB,OTK	**0 265 007 606**
		OTK,RAB	**0 265 007 607**
		TKO	**0 265 007 597**

Product			
1.5 DCI [FP./JP.]	**1,5 l 50/63 kW K9K 760,762,766,768 4 Zyl.**		
Boost pressure sensor, Diesel	09.04→		**0 281 002 566**
Duo sensor, acceleration and yaw rate, brake system	09.04→		**0 265 005 263**
Wheel speed sensor, front	09.04→		**0 265 007 742**
Wheel speed sensor, rear	09.04→	LAB,OTK	**0 265 007 606**
		OTK,RAB	**0 265 007 607**
		TKO	**0 265 007 597**
1.5 DCI [FP./JP.]	**1,5 l 65 kW K9K 750 4 Zyl.**		
Boost pressure sensor, Diesel	09.04-12.06		**0 281 002 573**
Duo sensor, acceleration and yaw rate, brake system	09.04-12.06		**0 265 005 263**
Wheel speed sensor, front	09.04-12.06		**0 265 007 742**
Wheel speed sensor, rear	09.04-12.06	LAB,OTK	**0 265 007 606**
		OTK,RAB	**0 265 007 607**
		TKO	**0 265 007 597**
1.5 DCI [FP./JP.]	**1,5 l 78 kW K9K 764 4 Zyl.**		
Boost pressure sensor, Diesel	09.04→		**0 281 002 566**
Duo sensor, acceleration and yaw rate, brake system	09.04→		**0 265 005 263**
Wheel speed sensor, front	09.04→		**0 265 007 742**
Wheel speed sensor, rear	09.04→	LAB,OTK	**0 265 007 606**
		OTK,RAB	**0 265 007 607**
		TKO	**0 265 007 597**
1.5 DCI [FP./JP.]	**1,5 l 78 kW K9K 772 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	02.06→		**0 265 005 263**
Wheel speed sensor, front	02.06→		**0 265 007 742**
Wheel speed sensor, rear	02.06→	LAB,OTK	**0 265 007 606**
		OTK,RAB	**0 265 007 607**
		TKO	**0 265 007 597**
1.6 i 16V [FP./JP.]	**1,6 l 65/82/83 kW K4M 790,792,794,800,801 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	09.04→		**0 265 005 263**
Wheel speed sensor, front	09.04→		**0 265 007 742**
Wheel speed sensor, rear	09.04→	LAB,OTK	**0 265 007 606**
		OTK,RAB	**0 265 007 607**
		TKO	**0 265 007 597**
1.6 i 16V [FP./JP.]	**1,6 l 83 kW K4M 791 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	09.04→		**0 265 005 263**
Wheel speed sensor, front	09.04→		**0 265 007 742**
Wheel speed sensor, rear	09.04→	LAB,OTK	**0 265 007 606**
		OTK,RAB	**0 265 007 607**
		TKO	**0 265 007 597**

Safrane

2.0 i [B54]	**2,0 l 77/97-99 kW J7R 732,733,734,735,738,739 4 Zyl.**		
Wheel speed sensor, front	04.92-09.96	LAB	**0 265 006 361**
		RAB	**0 265 006 362**
Wheel speed sensor, rear	04.92-09.96		**0 265 006 363**
2.0 i 16V [B54]	**2,0 l 100 kW N7Q 710; N7Q 711 4 Zyl.**		
Phase sensor	10.96-12.00		**0 232 101 030**
Wheel speed sensor, front	10.96-12.00	LAB	**0 265 006 361**
		RAB	**0 265 006 362**
Wheel speed sensor, rear	10.96-12.00		**0 265 006 363**
2.1 D Turbo [B54]	**2,1 l 65-66 kW J8S 760 4 Zyl.**		
Wheel speed sensor, front	04.92-09.96	LAB	**0 265 006 361**
		RAB	**0 265 006 362**
Wheel speed sensor, rear	04.92-09.96		**0 265 006 363**

Product			
2.2 i [B54]	**2,2 l 79-81/101-104 kW J7T 760,761,762,763,766,767 4 Zyl.**		
Wheel speed sensor, front	04.92-09.96	LAB	**0 265 006 361**
		RAB	**0 265 006 362**
Wheel speed sensor, rear	04.92-09.96		**0 265 006 363**
2.2 12V D Turbo [B54]	**2,2 l 83 kW G8T 740 4 Zyl.**		
Wheel speed sensor, front	10.96-12.00	LAB	**0 265 006 361**
		RAB	**0 265 006 362**
Wheel speed sensor, rear	10.96-12.00		**0 265 006 363**
2.5 D Turbo [B54]	**2,5 l 83-85 kW S8U 762,763 4 Zyl.**		
Wheel speed sensor, front	04.92-09.96	LAB	**0 265 006 361**
		RAB	**0 265 006 362**
Wheel speed sensor, rear	04.92-09.96		**0 265 006 363**
2.5 i 20V [B54]	**2,5 l 121 kW N7U 700; N7U 701 5 Zyl.**		
Air mass meter, gasoline injection	10.96-12.00		**0 280 217 107**
Phase sensor	10.96-12.00		**0 232 101 030**
Wheel speed sensor, front	10.96-12.00	LAB	**0 265 006 361**
		RAB	**0 265 006 362**
Wheel speed sensor, rear	10.96-12.00		**0 265 006 363**
3.0 i [B54]	**3,0 l 123-125 kW Z7X 721 6 Zyl.**		
Knock sensor	08.92-09.96	LAB	**0 261 231 071**
		RAB	**0 261 231 070**
Acceleration sensor, ABS	08.92-07.93	AA	**0 265 005 111**
3.0 i [B54]	**3,0 l 123-125 kW Z7X 721; Z7X 722,723 6 Zyl.**		
Knock sensor	04.92-09.96	LAB	**0 261 231 071**
		RAB	**0 261 231 070**
Acceleration sensor, ABS	07.93-09.96	AA	**0 265 005 111**
Wheel speed sensor, front	08.92-09.96	LAB	**0 265 006 361**
		RAB	**0 265 006 362**
Wheel speed sensor, rear	08.92-09.96		**0 265 006 363**
3.0 i [B54]	**3,0 l 123-125 kW Z7X 722,723 6 Zyl.**		
Acceleration sensor, ABS	04.92-07.93	AA	**0 265 005 111**
3.0 i [B54]	**3,0 l 123-125 kW Z7X 722,723; Z7X 753 6 Zyl.**		
Knock sensor	08.92-09.96	LAB	**0 261 231 071**
		RAB	**0 261 231 070**
Acceleration sensor, ABS	07.93-09.96	AA	**0 265 005 111**
Wheel speed sensor, front	04.92-09.96	LAB	**0 265 006 361**
		RAB	**0 265 006 362**
Wheel speed sensor, rear	04.92-09.96		**0 265 006 363**
3.0 i [B54]	**3,0 l 123-125 kW Z7X 753 6 Zyl.**		
Acceleration sensor, ABS	08.92-07.93	AA	**0 265 005 111**
	07.93-09.96	AA	**0 265 005 111**
Wheel speed sensor, front	08.92-09.96	LAB	**0 265 006 361**
		RAB	**0 265 006 362**
Wheel speed sensor, rear	08.92-09.96		**0 265 006 363**
3.0 i [B54]	**3,0 l 123-125 kW Z7X 755 6 Zyl.**		
Knock sensor	10.96-12.00	LAB	**0 261 231 071**
		RAB	**0 261 231 070**
Wheel speed sensor, front	10.96-12.00	LAB	**0 265 006 361**
		RAB	**0 265 006 362**
Wheel speed sensor, rear	10.96-12.00		**0 265 006 363**
3.0 i Biturbo [B54]	**3,0 l 190-197 kW Z7X 726 6 Zyl.**		
Knock sensor	02.93-09.96	LAB	**0 261 231 071**
		RAB	**0 261 231 070**
Acceleration sensor, ABS	02.93-07.93	AA	**0 265 005 111**
	07.93-09.96	AA	**0 265 005 111**
Wheel speed sensor, front	02.93-09.96	LAB	**0 265 006 361**
		RAB	**0 265 006 362**
Wheel speed sensor, rear	02.93-09.96		**0 265 006 363**
3.0 i 24V [B54]	**3,0 l 140 kW L7X 713 6 Zyl.**		
Knock sensor	03.99-12.00		**0 261 231 125**
Wheel speed sensor, front	03.99-12.00	LAB	**0 265 006 361**
		RAB	**0 265 006 362**
Wheel speed sensor, rear	03.99-12.00		**0 265 006 363**

Product

Scenic I

1.4 i [JA]	**1,4 l 70 kW K4J 714; K4J 750 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	08.98-04.03		**0 265 005 263**
1.6 i [JA]	**1,6 l 79 kW K4M 700,701,706,707,708 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	08.98→		**0 265 005 263**
1.6 i [JA]	**1,6 l 79 kW K4M 709; K4M 712 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	03.99-04.03		**0 265 005 263**
1.6 i [JA]	**1,6 l 79 kW K4M 776 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	05.05→		**0 265 005 263**
1.8 i [JA]	**1,8 l 85/88 kW F4P 720; F4P 722 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	09.00-04.03		**0 265 005 263**
1.9 DCI [JA]	**1,9 l 75 kW F9Q 732 4 Zyl.**		
Boost pressure sensor, Diesel	10.01-04.03		**0 281 002 593**
Duo sensor, acceleration and yaw rate, brake system	03.99-04.03		**0 265 005 263**
1.9 DCI [JA]	**1,9 l 75 kW F9Q 733 4 Zyl.**		
Boost pressure sensor, Diesel	11.02-04.03		**0 281 002 593**
Duo sensor, acceleration and yaw rate, brake system	10.99-04.03		**0 265 005 263**
1.9 DCI [JA]	**1,9 l 75 kW F9Q 738 4 Zyl.**		
Boost pressure sensor, Diesel	09.00-04.03		**0 281 002 593**
Duo sensor, acceleration and yaw rate, brake system	09.00-04.03		**0 265 005 263**
1.9 DCI [JA]	**1,9 l 75 kW F9Q 740 4 Zyl.**		
Boost pressure sensor, Diesel	10.01-04.03		**0 281 002 593**
Duo sensor, acceleration and yaw rate, brake system	06.00-04.03		**0 265 005 263**
1.9 DCI [JA]	**1,9 l 75 kW F9Q 746; F9Q 748 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	02.01-04.03		**0 265 005 263**
1.9 DCI [JA]	**1,9 l 75 kW F9Q 796 4 Zyl.**		
Boost pressure sensor, Diesel	11.02-04.03		**0 281 002 593**
Duo sensor, acceleration and yaw rate, brake system	06.97-04.03		**0 265 005 263**
1.9 DCI RX4 [JA]	**1,9 l 75 kW F9Q 732 4 Zyl.**		
Boost pressure sensor, Diesel	10.01-04.03		**0 281 002 593**
1.9 DCI RX4 [JA]	**1,9 l 75 kW F9Q 733 4 Zyl.**		
Boost pressure sensor, Diesel	11.02-04.03		**0 281 002 593**
1.9 DCI RX4 [JA]	**1,9 l 75 kW F9Q 740 4 Zyl.**		
Boost pressure sensor, Diesel	10.01-01.03		**0 281 002 593**
1.9 DCI RX4 [JA]	**1,9 l 75 kW F9Q 746; F9Q 748 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	02.01-04.03		**0 265 005 263**
1.9 DCI RX4 [JA]	**1,9 l 75 kW F9Q 796 4 Zyl.**		
Boost pressure sensor, Diesel	11.02-04.03		**0 281 002 593**
1.9 DTI [JA]	**1,9 l 59 kW F9Q 744 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	11.00-04.03		**0 265 005 263**
1.9 DTI [JA]	**1,9 l 72 kW F9Q 734 4 Zyl.**		
Speed sensor, diesel	06.97-06.98		**0 281 002 175**
Pedal position sensor, diesel	06.97-01.99	LLE	**0 206 001 021**
	06.97-02.99	RLE	**0 281 002 255**
2.0 i [JA]	**2,0 l 101,5/102 kW F4R 740,741,744,746,747 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	03.99→		**0 265 005 263**

R

Product

Scenic II

1.4 16V [JM.]	**1,4 l 72 kW K4J 730; K4J 740 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	05.03→		**0 265 005 263**
1.5 DCI [JM.]	**1,5 l 60-63 kW K9K 722 4 Zyl.**		
Boost pressure sensor, Diesel	05.03-12.06		**0 281 002 573**
Duo sensor, acceleration and yaw rate, brake system	05.03-12.06		**0 265 005 263**
1.5 DCI [JM.]	**1,5 l 63 kW K9K 724 4 Zyl.**		
Boost pressure sensor, Diesel	09.05-12.06		**0 281 002 566**
Duo sensor, acceleration and yaw rate, brake system	09.05-12.06		**0 265 005 263**
1.5 DCI [JM.]	**1,5 l 74-78 kW K9K 728; K9K 729 4 Zyl.**		
Boost pressure sensor, Diesel	05.03→		**0 281 002 573**
Duo sensor, acceleration and yaw rate, brake system	05.03→		**0 265 005 263**
1.5 DCI [JM.]	**1,5 l 78 kW K9K 732 4 Zyl.**		
Boost pressure sensor, Diesel	09.04→		**0 281 002 566**
Duo sensor, acceleration and yaw rate, brake system	09.04→		**0 265 005 263**
1.6 16V [JM.]	**1,6 l 83 kW K4M 760,761,762,764,766 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	05.03→		**0 265 005 263**
1.6 16V [JM.]	**1,6 l 83 kW K4M 782,788,812,813 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	05.03→		**0 265 005 263**
1.9 DCI [JM.]	**1,9 l 88 kW F9Q 812 4 Zyl.**		
Boost pressure sensor, Diesel	05.03→		**0 281 002 566**
Duo sensor, acceleration and yaw rate, brake system	05.03→		**0 265 005 263**
1.9 DCI [JM.]	**1,9 l 96 kW F9Q 803; F9Q 804; F9Q 814 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	05.03→		**0 265 005 263**
2.0 DCI [JM.]	**2,0 l 110 kW M9R 700 4 Zyl.**		
Boost pressure sensor, Diesel	09.04→		**0 281 002 740**
Duo sensor, acceleration and yaw rate, brake system	09.04→		**0 265 005 263**
2.0 DCI [JM.]	**2,0 l 110 kW M9R 720; M9R 721 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	09.04→		**0 265 005 263**
2.0 16V [JM.]	**2,0 l 99 kW F4R 770; F4R 771 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	05.03→		**0 265 005 263**
2.0 16V Turbo [JM.]	**2,0 l 120 kW F4R 776 4 Zyl.**		
Pressure sensor, intake manifold, gasoline	06.03→		**0 281 002 616**
Duo sensor, acceleration and yaw rate, brake system	06.03→		**0 265 005 263**

Sport Spider

2.0	**2,0 l 108-110 kW F7R 710; F7R 712; F7R 714; F7R 720 4 Zyl.**		
Knock sensor	05.96-10.99		**0 261 231 046**

Thalia II

1.0 i 16V [LB.]	**1,0 l 50 kW D4D 700 4 Zyl.**		
Duo sensor, acceleration and yaw rate, brake system	06.01-11.04		**0 265 005 263**
Wheel speed sensor, front	06.01-11.02		**0 265 006 383**
	12.02-11.04		**0 265 007 527**
Wheel speed sensor, rear	06.01-11.04	LAB	**0 265 006 384**
		RAB	**0 265 006 385**

Product			
1.2 i [LB.]			**1,2 l 43 kW D7F 726 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	06.01-10.07		**0 265 005 263**
Wheel speed sensor, front	06.01-11.02		**0 265 006 383**
	12.02-10.07		**0 265 007 527**
Wheel speed sensor, rear	06.01-10.07	LAB	**0 265 006 384**
		RAB	**0 265 006 385**
1.2 i 16V [LB.]			**1,2 l 55 kW D4F 706 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.01-03.04		**0 265 005 263**
Wheel speed sensor, front	09.01-11.02		**0 265 006 383**
	12.02-03.04		**0 265 007 527**
Wheel speed sensor, rear	09.01-03.04	LAB	**0 265 006 384**
		RAB	**0 265 006 385**
1.2 i 16V [LB.]			**1,2 l 55 kW D4F 712 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.01-10.07		**0 265 005 263**
Wheel speed sensor, front	09.01-11.02		**0 265 006 383**
	12.02-10.07		**0 265 007 527**
Wheel speed sensor, rear	09.01-11.02	LAB,OTK	**0 265 006 384**
	12.02-10.07	LAB,OTK	**0 265 007 529**
	09.01-11.02	OTK,RAB	**0 265 006 385**
	12.02-10.07	OTK,RAB	**0 265 007 528**
1.2 i 16V [LB.]			**1,2 l 55 kW D4F 728 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	04.04-10.07		**0 265 005 263**
Wheel speed sensor, front	04.04-10.07		**0 265 007 527**
Wheel speed sensor, rear	04.04-10.07	LAB,OTK	**0 265 007 529**
		OTK,RAB	**0 265 007 528**
1.4 i [LB.]			**1,4 l 55 kW K7J 700 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.99-10.07		**0 265 005 263**
Wheel speed sensor, front	10.99-11.02		**0 265 006 383**
	12.02-10.07		**0 265 007 527**
Wheel speed sensor, rear	10.99-10.07	LAB	**0 265 006 384**
		RAB	**0 265 006 385**
1.4 i 16V [LB.]			**1,4 l 70-72 kW K4J 712; K4J 713 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	06.01-10.07		**0 265 005 263**
Wheel speed sensor, front	06.01-11.02		**0 265 006 383**
	12.02-10.07		**0 265 007 527**
Wheel speed sensor, rear	06.01-10.07	LAB	**0 265 006 384**
		RAB	**0 265 006 385**
1.5 DCI [LB.]			**1,5 l 48 kW K9K 700 4 Zyl.**
Boost pressure sensor, Diesel	12.02-10.07		**0 281 002 593**
Duo sensor, acceleration and yaw rate, brake system	09.01-10.07		**0 265 005 263**
Wheel speed sensor, front	09.01-11.02		**0 265 006 383**
	12.02-10.07		**0 265 007 527**
Wheel speed sensor, rear	09.01-10.07	LAB	**0 265 006 384**
		RAB	**0 265 006 385**
1.5 DCI [LB.]			**1,5 l 60 kW K9K 706 4 Zyl.**
Boost pressure sensor, Diesel	05.04-10.07		**0 281 002 552**
Duo sensor, acceleration and yaw rate, brake system	05.04-10.07		**0 265 005 263**
Wheel speed sensor, front	05.04-10.07		**0 265 007 527**
1.6 i [LB.]			**1,6 l 66 kW K4M 732; K4M 734 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	11.01-10.07		**0 265 005 263**
Wheel speed sensor, front	11.01-11.02		**0 265 006 383**
	12.02-10.07		**0 265 007 527**
Wheel speed sensor, rear	11.01-10.07	LAB	**0 265 006 384**
		RAB	**0 265 006 385**

Product			
1.6 i [LB.]			**1,6 l 66 kW K4M 742; K4M 743 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	01.04-10.07		**0 265 005 263**
Wheel speed sensor, front	01.04-10.07		**0 265 007 527**
Wheel speed sensor, rear	01.04-10.07	LAB,OTK	**0 265 007 529**
		OTK,RAB	**0 265 007 528**
1.6 i [LB.]			**1,6 l 66/81 kW K4M 740; K4M 746 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.99-10.07		**0 265 005 263**
Wheel speed sensor, front	10.99-11.02		**0 265 006 383**
	12.02-10.07		**0 265 007 527**
Wheel speed sensor, rear	10.99-10.07	LAB	**0 265 006 384**
		RAB	**0 265 006 385**
1.9 D [LB.]			**1,9 l 47-48 kW F8Q 630 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.99-10.07		**0 265 005 263**
Wheel speed sensor, front	10.99-11.02		**0 265 006 383**
	12.02-10.07		**0 265 007 527**
Wheel speed sensor, rear	10.99-10.07	LAB	**0 265 006 384**
		RAB	**0 265 006 385**

Trafic

1.4			**1,4 l 36 kW 847 700 4 Zyl.**
Wheel speed sensor, front	09.80-10.97	LAB	**0 265 006 156**
		RAB	**0 265 006 157**
Wheel speed sensor, rear	09.80-10.97	LAB	**0 265 006 154**
		RAB	**0 265 006 155**
1.6			**1,6 l 48/49 kW A1M 707; A1M 708 4 Zyl.**
Wheel speed sensor, front	09.80-02.89	LAB	**0 265 006 156**
		RAB	**0 265 006 157**
Wheel speed sensor, rear	09.80-02.89	LAB	**0 265 006 154**
		RAB	**0 265 006 155**
1.7			**1,7 l 50-58 kW F1N 720; F1N 724,720 4 Zyl.**
Wheel speed sensor, front	10.84-10.97	LAB	**0 265 006 156**
		RAB	**0 265 006 157**
Wheel speed sensor, rear	10.84-10.97	LAB	**0 265 006 154**
		RAB	**0 265 006 155**
1.9 D			**1,9 l 47-48 kW F8Q 600; F8Q 606 4 Zyl.**
Wheel speed sensor, front	11.97-05.01	LAB	**0 265 006 156**
		RAB	**0 265 006 157**
Wheel speed sensor, rear	11.97-05.01	LAB	**0 265 006 154**
		RAB	**0 265 006 155**
1.9 DCI [EL./FL./JL.]			**1,9 l 60/74 kW F9Q 760; F9Q 762 4 Zyl.**
Boost pressure sensor, Diesel	12.02-12.06		**0 281 002 593**
2.0			**2,0 l 59 kW J5R 716 4 Zyl.**
Wheel speed sensor, front	09.80-10.97	LAB	**0 265 006 156**
		RAB	**0 265 006 157**
Wheel speed sensor, rear	09.80-10.97	LAB	**0 265 006 154**
		RAB	**0 265 006 155**
2.1 D			**2,1 l 43/47 kW J8S 622; J8S 758; 852 750 4 Zyl.**
Wheel speed sensor, front	09.80-10.97	LAB	**0 265 006 156**
		RAB	**0 265 006 157**
Wheel speed sensor, rear	09.80-10.97	LAB	**0 265 006 154**
		RAB	**0 265 006 155**
2.2 i			**2,2 l 69-71 kW J7T 780 Kat. 4 Zyl.**
Throttle valve sensor	03.89-10.97		**0 280 120 301**
Wheel speed sensor, front	03.89-10.97	LAB	**0 265 006 156**
		RAB	**0 265 006 157**
Wheel speed sensor, rear	03.89-10.97	LAB	**0 265 006 154**
		RAB	**0 265 006 155**

R

Product

◀ Trafic

2.2 i			**2,2 l 74 kW J7T 600 Kat. 4 Zyl.**
Wheel speed sensor, front	09.94-10.97	LAB	**0 265 006 156**
		RAB	**0 265 006 157**
Wheel speed sensor, rear	09.94-10.97	LAB	**0 265 006 154**
		RAB	**0 265 006 155**
2.5 D			**2,5 l 55 kW S8U 758; S8U 782; 8140.67.2500; 8140.67.2580 4 Zyl.**
Wheel speed sensor, front	03.89-05.01	LAB	**0 265 006 156**
		RAB	**0 265 006 157**
Wheel speed sensor, rear	03.89-05.01	LAB	**0 265 006 154**
		RAB	**0 265 006 155**
2.5 D 4x4			**2,5 l 55 kW S8U 758; S8U 780; S8U 782 4 Zyl.**
Wheel speed sensor, front	11.97-05.01	LAB	**0 265 006 156**
		RAB	**0 265 006 157**
Wheel speed sensor, rear	11.97-05.01	LAB	**0 265 006 154**
		RAB	**0 265 006 155**
2.5 DCI [EL./FL./JL.]			**2,5 l 98 kW G9U 730 4 Zyl.**
Boost pressure sensor, Diesel	06.02-12.06		**0 281 002 552**

Twingo I

1.2 i [C0./S0.]			**1,2 l 40-44 kW D7F 700; D7F 701 4 Zyl.**
Wheel speed sensor, rear	12.02-05.07	LAB	**0 265 007 583**
		RAB	**0 265 007 582**
1.2 i [C0./S0.]			**1,2 l 43 kW D7F 702 4 Zyl.**
Wheel speed sensor, front	12.02-05.07		**0 265 007 527**
Wheel speed sensor, rear	12.02-05.07	LAB	**0 265 007 583**
		RAB	**0 265 007 582**
1.2 i [C0./S0.]			**1,2 l 43 kW D7F 703 4 Zyl.**
Wheel speed sensor, rear	12.02-05.07	LAB	**0 265 007 583**
		RAB	**0 265 007 582**
1.2 i [C0./S0.]			**1,2 l 43 kW D7F 703 EOBD; D7F 704 4 Zyl.**
Wheel speed sensor, front	12.02-05.07		**0 265 007 527**
Wheel speed sensor, rear	12.02-05.07	LAB	**0 265 007 583**
		RAB	**0 265 007 582**
1.2 i [C0./S0.]			**1,2 l 43 kW D7F 706 4 Zyl.**
Wheel speed sensor, rear	12.02-05.07	LAB	**0 265 007 583**
		RAB	**0 265 007 582**
1.2 i [C0./S0.]			**1,2 l 43 kW D7F 708 4 Zyl.**
Wheel speed sensor, front	12.02-05.07		**0 265 007 527**
Wheel speed sensor, rear	12.02-05.07	LAB	**0 265 007 583**
		RAB	**0 265 007 582**
1.2 i 16V [C0./S0.]			**1,2 l 55 kW D4F 702; D4F 704; D4F 708 4 Zyl.**
Wheel speed sensor, front	12.02-05.07		**0 265 007 527**
Wheel speed sensor, rear	12.02-05.07	LAB	**0 265 007 583**
		RAB	**0 265 007 582**

Vel Satis

2.0 [BJ0]			**2,0 l 120 kW F4R 762; F4R 763; F4R 764 4 Zyl.**
Pressure sensor, intake manifold, gasoline	09.03-12.06		**0 281 002 616**
2.0 [BJ0]			**2,0 l 120 kW F4R 765; F4R 766; F4R 767 4 Zyl.**
Pressure sensor, intake manifold, gasoline	04.02-12.06		**0 281 002 616**
2.0 T [BJ0]			**2,0 l 125 kW F4R 867 4 Zyl.**
Pressure sensor, intake manifold, gasoline	07.05→		**0 281 002 616**
2.2 DCI [BJ0]			**2,2 l 102 kW G9T 606 4 Zyl.**
Boost pressure sensor, Diesel	07.05→		**0 281 002 566**
2.2 DCI [BJ0]			**2,2 l 110 kW G9T 600 4 Zyl.**
High-pressure sensor (CR system)	09.02→		**0 281 002 534**
Boost pressure sensor, Diesel	09.02→		**0 281 002 566**
2.2 DCI [BJ0]			**2,2 l 110 kW G9T 702; G9T 703 4 Zyl.**
Boost pressure sensor, Diesel	04.02-08.03		**0 281 002 552**
	09.03→		**0 281 002 566**

Product

3.0 DCI V6 [BJ0]			**3,0 l 130/133 kW P9X 701; P9X 715 6 Zyl.**
Air mass meter, diesel	04.02→		**0 280 218 079**

Winnebago

2.2 i			**2,2 l 79 kW J7T 736 4 Zyl.**
Throttle valve sensor	03.88-12.00		**0 280 120 301**

5

1.7 i			**1,7 l 69 kW F3N 702,722 Kat. 4 Zyl.**
Throttle valve sensor	10.86-12.96		**0 280 120 301**

11

1.7 i			**1,7 l 69 kW F3N 708,722 Kat. 4 Zyl.**
Throttle valve sensor	06.87-03.91		**0 280 120 301**

18 Break

2.2 i			**2,2 l 76-77 kW J7T 718,719 Kat. 4 Zyl.**
Throttle valve sensor	10.83-02.86		**0 280 120 301**
Air flow sensor, gasoline injection	10.83-02.86		**0 280 202 049**
			0 986 280 053
Pressure sensor, intake manifold, gasoline	10.83-02.86		**0 280 101 001**
Temperature sensor, coolant, injection system	10.83-02.86		**0 280 130 023**
Relay, Jetronic	10.83-02.86		**0 280 230 006**

19

1.2 i [X53]			**1,2 l 46 kW E7F 730 Kat. 4 Zyl.**
Wheel speed sensor, front	04.93-12.01	BO	**0 265 006 735**
Wheel speed sensor, rear	04.93-12.01	BO,LAB	**0 265 006 737**
		BO,RAB	**0 265 006 736**
1.4 i [X53]			**1,4 l 55-59 kW E7J 700,706,742,745 Kat. 4 Zyl.**
Wheel speed sensor, front	04.93-12.01	BO	**0 265 006 735**
Wheel speed sensor, rear	04.93-12.01	BO,LAB	**0 265 006 737**
		BO,RAB	**0 265 006 736**
1.7 [X53]			**1,7 l 55-56/68 kW F2N 720,721,724,726,727 4 Zyl.**
Wheel speed sensor, front	04.93-12.95	BO	**0 265 006 735**
Wheel speed sensor, rear	04.93-12.95	BO,LAB	**0 265 006 737**
		BO,RAB	**0 265 006 736**
1.7 i [X53]			**1,7 l 54 kW F3N 740 Kat.; F3N 741 Kat. 4 Zyl.**
Knock sensor	09.88-12.95		**0 261 231 006**
Wheel speed sensor, front	04.93-12.95	BO	**0 265 006 735**
Wheel speed sensor, rear	04.93-12.95	BO,LAB	**0 265 006 737**
		BO,RAB	**0 265 006 736**
1.7 i [X53]			**1,7 l 66-70 kW F3N 742 Kat.; F3N 743 Kat. 4 Zyl.**
Throttle valve sensor	09.88-12.95		**0 280 120 301**
Wheel speed sensor, front	04.93-12.95	BO	**0 265 006 735**
Wheel speed sensor, rear	04.93-12.95	BO,LAB	**0 265 006 737**
		BO,RAB	**0 265 006 736**
1.7 i [X53]			**1,7 l 66-70 kW F3N 746 4 Zyl.**
Knock sensor	06.89-12.95		**0 261 231 006**
Wheel speed sensor, front	04.93-12.95	BO	**0 265 006 735**
Wheel speed sensor, rear	04.93-12.95	BO,LAB	**0 265 006 737**
		BO,RAB	**0 265 006 736**
1.8 i [X53]			**1,8 l 65 kW F3P 704,705,706,707,708 Kat. 4 Zyl.**
Wheel speed sensor, front	04.93-12.95	BO	**0 265 006 735**
Wheel speed sensor, rear	04.93-12.95	BO,LAB	**0 265 006 737**
		BO,RAB	**0 265 006 736**

Product			
1.8 i [X53]	**1,8 l 65-66/79-83 kW F3P 682,700,706,760,765 Kat. 4 Zyl.**		
Wheel speed sensor, front	04.93-12.95	BO	**0 265 006 735**
Wheel speed sensor, rear	04.93-12.95	BO,LAB	**0 265 006 737**
		BO,RAB	**0 265 006 736**
1.8 i 16V [X53]	**1,8 l 99-101 kW F7P 704 Kat. 4 Zyl.**		
Wheel speed sensor, front	04.93-12.95	BO	**0 265 006 735**
Wheel speed sensor, rear	04.93-12.95	BO,LAB	**0 265 006 737**
		BO,RAB	**0 265 006 736**
1.9 D [X53]	**1,9 l 47 kW F8Q 706,742,764 4 Zyl.**		
Wheel speed sensor, front	04.93-12.01	BO	**0 265 006 735**
Wheel speed sensor, rear	04.93-12.01	BO,LAB	**0 265 006 737**
		BO,RAB	**0 265 006 736**
1.9 D Turbo [X53]	**1,9 l 66-68 kW F8Q 610,740,744,768 4 Zyl.**		
Wheel speed sensor, front	04.93-12.01	BO	**0 265 006 735**
Wheel speed sensor, rear	04.93-12.01	BO,LAB	**0 265 006 737**
		BO,RAB	**0 265 006 736**

19 Cabrio

1.7 i [X53]	**1,7 l 66-70 kW F3N 742,743 Kat. 4 Zyl.**		
Throttle valve sensor	09.88-12.95		**0 280 120 301**
Wheel speed sensor, front	04.93-12.95	BO	**0 265 006 735**
Wheel speed sensor, rear	04.93-12.95	BO,LAB	**0 265 006 737**
		BO,RAB	**0 265 006 736**
1.8 i [X53]	**1,8 l 65 kW F3P 704,705,706,707,708 Kat. 4 Zyl.**		
Wheel speed sensor, front	04.93-12.95	BO	**0 265 006 735**
Wheel speed sensor, rear	04.93-12.95	BO,LAB	**0 265 006 737**
		BO,RAB	**0 265 006 736**
1.8 i [X53]	**1,8 l 65-66/79-83 kW F3P 682,706,760,764,765 Kat. 4 Zyl.**		
Wheel speed sensor, front	04.93-12.95	BO	**0 265 006 735**
Wheel speed sensor, rear	04.93-12.95	BO,LAB	**0 265 006 737**
		BO,RAB	**0 265 006 736**
1.8 i 16V [X53]	**1,8 l 99-101 kW F7P 704 Kat. 4 Zyl.**		
Wheel speed sensor, front	04.93-12.95	BO	**0 265 006 735**
Wheel speed sensor, rear	04.93-12.95	BO,LAB	**0 265 006 737**
		BO,RAB	**0 265 006 736**

19 Sedan

1.6 i	**1,6 l 61 kW C3L 4 Zyl.**		
Speed sensor, ignition/injection	01.93-05.00		**0 261 210 137**
Temperature sensor, intake air, injection system	01.93-05.00		**0 280 130 068**

21

1.7 i [L48]	**1,7 l 66-70 kW F3N 722,723 Kat. 4 Zyl.**		
Throttle valve sensor	03.86-12.94	GS	**0 280 120 301**
2.0 i [L48]	**2,0 l 86/88/98-102 kW J7R 746,747 Kat.; J7R 750,751,754 4 Zyl.**		
Throttle valve sensor	10.86-12.94	GS	**0 280 120 301**
2.0 i Turbo [L48]	**2,0 l 119-129 kW J7R 752 4 Zyl.**		
Throttle valve sensor	04.87-03.92	GS	**0 280 120 301**
2.2 i [L48]	**2,2 l 79-81 kW J7T 754,755 Kat. 4 Zyl.**		
Throttle valve sensor	07.86-12.94	GS	**0 280 120 301**

21 Fastback

1.7 i [B48]	**1,7 l 66-70 kW F3N 722,723 Kat. 4 Zyl.**		
Throttle valve sensor	09.89-12.93	GS	**0 280 120 301**
2.0 i [B48]	**2,0 l 85-86/88 kW J7R 746,747 Kat.; J7R 750,751 4 Zyl.**		
Throttle valve sensor	09.89-12.93	GS	**0 280 120 301**
2.2 i [B48]	**2,2 l 79-81 kW J7T 754,755 Kat. 4 Zyl.**		
Throttle valve sensor	09.89-12.93	GS	**0 280 120 301**

21 Nevada

1.7 i [K48]	**1,7 l 66-70 kW F3N 722,723 Kat. 4 Zyl.**		
Throttle valve sensor	06.86-12.95		**0 280 120 301**
2.0 i [K48]	**2,0 l 85-88 kW J7R 750,751 4 Zyl.**		
Throttle valve sensor	10.86-12.95		**0 280 120 301**
2.2 i [K48]	**2,2 l 79-81 kW J7T 754,755 Kat.; J7T 756 Kat. 4 Zyl.**		
Throttle valve sensor	10.86-12.95		**0 280 120 301**

25

2.0	**2,0 l 74 kW J6R 706,707; J6R 760,762,763 4 Zyl.**		
Wheel speed sensor, front	01.85-12.92	LAB	**0 265 001 069**
		RAB	**0 265 001 068**
Wheel speed sensor, rear	01.85-12.92	LAB	**0 265 001 071**
		RAB	**0 265 001 070**
2.0 i	**2,0 l 88/99-100/103 kW J7R 720,721; J7R 722,723; J7R 726 Kat. 4 Zyl.**		
Throttle valve sensor	06.87-12.92		**0 280 120 301**
Wheel speed sensor, front	06.87-12.92	LAB	**0 265 001 069**
		RAB	**0 265 001 068**
Wheel speed sensor, rear	06.87-12.92	LAB	**0 265 001 071**
		RAB	**0 265 001 070**
2.1 D	**2,1 l 46/50-51 kW J8S 706; J8S 736 4 Zyl.**		
Wheel speed sensor, front	01.85-12.92	LAB	**0 265 001 069**
		RAB	**0 265 001 068**
Wheel speed sensor, rear	01.85-12.92	LAB	**0 265 001 071**
		RAB	**0 265 001 070**
2.1 D Turbo	**2,1 l 63 kW J8S 708; J8S 738 4 Zyl.**		
Wheel speed sensor, front	01.85-12.92	LAB	**0 265 001 069**
		RAB	**0 265 001 068**
Wheel speed sensor, rear	01.85-12.92	LAB	**0 265 001 071**
		RAB	**0 265 001 070**
2.2 i	**2,2 l 79 kW J7T 708 4 Zyl.**		
Throttle valve sensor	10.85-10.86		**0 280 120 301**
Air flow sensor, gasoline injection	10.85-10.86		**0 280 202 049**
			0 986 280 053
Pressure sensor, intake manifold, gasoline	10.85-10.86		**0 280 101 001**
Relay, Jetronic	10.85-10.86		**0 280 230 006**
Wheel speed sensor, front	10.85-10.86	LAB	**0 265 001 069**
		RAB	**0 265 001 068**
Wheel speed sensor, rear	10.85-10.86	LAB	**0 265 001 071**
		RAB	**0 265 001 070**
2.2 i	**2,2 l 79-81 kW J7T 732,733 Kat. 4 Zyl.**		
Throttle valve sensor	10.86-12.92		**0 280 120 301**
Wheel speed sensor, front	10.86-12.92	LAB	**0 265 001 069**
		RAB	**0 265 001 068**
Wheel speed sensor, rear	10.86-12.92	LAB	**0 265 001 071**
		RAB	**0 265 001 070**
2.2 i	**2,2 l 89 kW J7T 706,707 4 Zyl.**		
Throttle valve sensor	10.85-10.86		**0 280 120 301**
Temperature sensor, coolant, injection system	01.84-10.86		**0 280 130 026**
Wheel speed sensor, front	01.85-10.86	LAB	**0 265 001 069**
		RAB	**0 265 001 068**
Wheel speed sensor, rear	01.85-10.86	LAB	**0 265 001 071**
		RAB	**0 265 001 070**
2.2 i	**2,2 l 89 kW J7T 714 4 Zyl.**		
Temperature sensor, coolant, injection system	01.84-04.88		**0 280 130 026**
Wheel speed sensor, front	01.85-04.88	LAB	**0 265 001 069**
		RAB	**0 265 001 068**
Wheel speed sensor, rear	01.85-04.88	LAB	**0 265 001 071**
		RAB	**0 265 001 070**

R

Product			
◀ 25			
2.2 i			**2,2 l 89 kW J7T 715 4 Zyl.**
Wheel speed sensor, front	01.85-04.88	LAB	**0 265 001 069**
		RAB	**0 265 001 068**
Wheel speed sensor, rear	01.85-04.88	LAB	**0 265 001 071**
		RAB	**0 265 001 070**
2.2 i			**2,2 l 91 kW J7T 730,731 4 Zyl.**
Throttle valve sensor	10.86-05.90		**0 280 120 301**
Wheel speed sensor, front	10.86-05.90	LAB	**0 265 001 069**
		RAB	**0 265 001 068**
Wheel speed sensor, rear	10.86-05.90	LAB	**0 265 001 071**
		RAB	**0 265 001 070**
2.5 i Turbo			**2,5 l 133/147-151 kW Z7U 700; Z7U 702,704 6 Zyl.**
Wheel speed sensor, front	01.85-12.92	LAB	**0 265 001 069**
		RAB	**0 265 001 068**
Wheel speed sensor, rear	01.85-12.92	LAB	**0 265 001 071**
		RAB	**0 265 001 070**
2.7 i			**2,7 l 104 kW Z7V 708; Z7V 709; Z7V 711 6 Zyl.**
Air flow sensor, gasoline injection	01.84-08.89		**0 438 121 021**
Temperature sensor, coolant, injection system	01.84-08.89		**0 280 130 028**
Wheel speed sensor, front	01.85-08.89	LAB	**0 265 001 069**
		RAB	**0 265 001 068**
Wheel speed sensor, rear	01.85-08.89	LAB	**0 265 001 071**
		RAB	**0 265 001 070**
2.9 i			**2,9 l 100 kW Z7W 702 6 Zyl.**
Air flow sensor, gasoline injection	10.86-06.87		**0 438 121 048**
Temperature sensor, coolant, injection system	10.86-06.87		**0 280 130 028**
Wheel speed sensor, front	10.86-06.87	LAB	**0 265 001 069**
		RAB	**0 265 001 068**
Wheel speed sensor, rear	10.86-06.87	LAB	**0 265 001 071**
		RAB	**0 265 001 070**
2.9 i			**2,9 l 110-112/115 kW Z7W 700,701,709; Z7W 706,707 Kat. 6 Zyl.**
Wheel speed sensor, front	06.87-12.92	LAB	**0 265 001 069**
		RAB	**0 265 001 068**
Wheel speed sensor, rear	06.87-12.92	LAB	**0 265 001 071**
		RAB	**0 265 001 070**

ROLLS-ROYCE

Corniche

6.8			**6,8 l 162 kW OHV V8 8 Zyl.**
Throttle valve sensor	07.89-12.90		**0 280 120 300**
Air flow sensor, gasoline injection	07.89-03.93		**F 026 TX2 056**
			F 026 TX2 056
Speed sensor, ignition/injection	07.89-03.93		**0 261 210 047**
Temperature sensor, coolant, injection system	07.89-03.93		**0 280 130 026**
6.8			**6,8 l 176 kW OHV V8 8 Zyl.**
Throttle valve sensor	01.86-12.90		**0 280 120 300**
Air flow sensor, gasoline injection	07.89-03.93		**F 026 TX2 056**
			F 026 TX2 056
	01.86-03.89		**0 438 120 213**
Speed sensor, ignition/injection	07.89-03.93		**0 261 210 047**
Temperature sensor, coolant, injection system	01.89-03.93		**0 280 130 026**
6.8			**6,8 l 176 kW OHV V8 Kat. 8 Zyl.**
Throttle valve sensor	01.87-05.90		**0 280 120 300**
Air flow sensor, gasoline injection	01.87-05.90		**0 438 120 214**
6.8			**6,8 l 184 kW L 410 M 8 Zyl.**
Throttle valve sensor	04.93-08.94		**0 280 122 007**
Air mass meter, gasoline injection	04.93-08.94		**0 280 217 801**
Speed sensor, ignition/injection	04.93-08.94		**0 261 210 047**
Temperature sensor, intake air, injection system	04.93-08.94		**0 280 130 039**
Temperature sensor, coolant, injection system	04.93-08.94		**0 280 130 026**

Drophead

6.8 [RR2]		**6,7 l 338 kW N73 B68 12 Zyl.**
Air mass meter, gasoline injection	06.07→	**0 280 218 076**

Flying

6.8 Spur V8		**6,8 l 182 kW OHV V8 8 Zyl.**
Throttle valve sensor	08.94-07.95	**0 280 122 007**
Air mass meter, gasoline injection	08.94-07.95	**0 280 217 801**
Phase sensor	08.94-07.95	**0 232 103 010**
Pulse generator, ignition/Jetronic	08.94-07.95	**0 261 210 047**
Pressure sensor, intake manifold, gasoline	08.94-07.95	**0 261 230 004**
Temperature sensor, intake air, injection system	08.94-07.95	**0 280 130 039**
Temperature sensor, coolant, injection system	08.94-07.95	**0 280 130 026**

Phantom

6.8 [RR1]		**6,7 l 338 kW N73 B68 12 Zyl.**
Air mass meter, gasoline injection	03.03→	**0 280 218 076**

Silver Spirit

6.8		**6,8 l 162 kW OHV V8 8 Zyl.**
Throttle valve sensor	01.87-03.93	**0 280 120 300**
Air flow sensor, gasoline injection	07.89-03.93	**F 026 TX2 056**
		F 026 TX2 056
	01.87-07.89	**0 438 120 214**
Speed sensor, ignition/injection	07.89-03.93	**0 261 210 047**
6.8		**6,8 l 176 kW OHV V8 8 Zyl.**
Throttle valve sensor	03.86-03.89	**0 280 120 300**
Air flow sensor, gasoline injection	07.89-03.93	**F 026 TX2 056**
		F 026 TX2 056
	03.86-03.89	**0 438 120 213**
Speed sensor, ignition/injection	07.89-03.93	**0 261 210 047**
6.8		**6,8 l 180 kW OHV V8 8 Zyl.**
Air flow sensor, gasoline injection	10.80-12.86	**0 438 120 157**
6.8		**6,8 l 184 kW L 410 MN 1T 4 Zyl.**
Throttle valve sensor	03.94-05.98	**0 280 122 007**
Air mass meter, gasoline injection	03.94-05.98	**0 280 217 801**
Phase sensor	08.95-05.98	**0 232 103 010**
Speed sensor, ignition/injection	03.94-05.98	**0 261 210 047**
Pressure sensor, intake manifold, gasoline	08.95-05.98	**0 261 230 004**
Temperature sensor, intake air, injection system	03.94-08.95	**0 280 130 039**
	08.95-05.98	**0 280 130 039**
Temperature sensor, coolant, injection system	03.94-05.98	**0 280 130 026**

Silver Spur

6.8		**6,8 l 162 kW OHV V8 8 Zyl.**
Throttle valve sensor	01.87-03.93	**0 280 120 300**
Air flow sensor, gasoline injection	07.89-03.93	**F 026 TX2 056**
		F 026 TX2 056
	01.87-07.89	**0 438 120 214**
Speed sensor, ignition/injection	07.89-03.93	**0 261 210 047**
6.8		**6,8 l 176 kW OHV V8 8 Zyl.**
Throttle valve sensor	03.86-05.90	**0 280 120 300**
Air flow sensor, gasoline injection	03.86-05.90	**0 438 120 213**
6.8		**6,8 l 180 kW OHV V8 8 Zyl.**
Air flow sensor, gasoline injection	10.80-12.86	**0 438 120 157**
6.8		**6,8 l 182 kW OHV V8 8 Zyl.**
Throttle valve sensor	04.93-12.98	**0 280 122 007**
Air mass meter, gasoline injection	04.93-12.98	**0 280 217 801**

Product			
Phase sensor	08.95-12.98		**0 232 103 010**
Speed sensor, ignition/injection	04.93-12.98		**0 261 210 047**
Pressure sensor, intake manifold, gasoline	08.95-12.98		**0 261 230 004**
Temperature sensor, intake air, injection system	08.95-12.98		**0 280 130 039**
Temperature sensor, coolant, injection system	04.93-12.98		**0 280 130 026**

ROVER

Maestro

2.0 i			**2,0 l 83 kW 20 H- EFI 4 Zyl.**
Relay, Jetronic	09.88-12.93	DID	**0 332 014 112**

Montego

2.0 i, i Estate			**2,0 l 83 kW 20 H 4 Zyl.**
Relay, Jetronic	09.88-12.93	DID	**0 332 014 112**

Serie 200

211 i			**1,1 l 44-45 kW 11K2D 4 Zyl.**
Wheel speed sensor, front	03.96-03.00	LAB	**0 265 006 305**
	11.95-02.96	LAB	**0 265 006 474**
	03.96-03.00	RAB	**0 265 006 306**
	11.95-02.96	RAB	**0 265 006 473**
Wheel speed sensor, rear	11.95-02.96	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
Fg.no. WD 267264→	11.95-03.00	4SB	**0 265 006 307**
214 Cabrio			**1,4 l 66 kW 14 K4C 4 Zyl.**
Wheel speed sensor, front	10.92-02.96	LAB	**0 265 006 474**
		RAB	**0 265 006 473**
Wheel speed sensor, rear	10.92-02.96	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
214 i			**1,4 l 55 kW 14K2A 4 Zyl.**
Wheel speed sensor, front	01.93-02.96	LAB	**0 265 006 474**
		RAB	**0 265 006 473**
Wheel speed sensor, rear	01.93-02.96	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
214 i			**1,4 l 55 kW 14K2F 4 Zyl.**
Wheel speed sensor, front	03.96-03.00	LAB	**0 265 006 305**
	10.95-02.96	LAB	**0 265 006 474**
	03.96-03.00	RAB	**0 265 006 306**
	10.95-02.96	RAB	**0 265 006 473**
Wheel speed sensor, rear	10.95-02.96	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
Fg.no. WD 267264→	10.95-03.00	4SB	**0 265 006 307**
214 i 16V			**1,4 l 66-70 kW 14K4C 4 Zyl.**
Wheel speed sensor, front	10.89-09.93	LAB	**0 265 006 474**
		RAB	**0 265 006 473**
Wheel speed sensor, rear	10.89-09.93	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
214 S			**1,4 l 55-56 kW 4 Zyl.**
Wheel speed sensor, front	10.89-12.92	LAB	**0 265 006 474**
		RAB	**0 265 006 473**
Wheel speed sensor, rear	10.89-12.92	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
214 Si 16V			**1,4 l 76 kW K16 4 Zyl.**
Wheel speed sensor, front	10.92-02.96	LAB	**0 265 006 474**
		RAB	**0 265 006 473**
Wheel speed sensor, rear	10.92-02.96	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
214 Si 16V Cabrio			**1,4 l 76 kW K16 4 Zyl.**
Wheel speed sensor, front	03.96-03.96	LAB	**0 265 006 305**
	10.92-02.96	LAB	**0 265 006 474**
	03.96-03.96	RAB	**0 265 006 306**
	10.92-02.96	RAB	**0 265 006 473**
Wheel speed sensor, rear	03.96-03.96	LAB	**0 265 006 267**
	10.92-02.96	LAB	**0 265 006 476**
	03.96-03.96	RAB	**0 265 006 268**
	10.92-02.96	RAB	**0 265 006 475**
214 16V Coupé			**1,4 l 76 kW 14KAF 4 Zyl.**
Wheel speed sensor, front	03.96-03.00	LAB	**0 265 006 305**
	10.95-02.96	LAB	**0 265 006 474**
	03.96-03.00	RAB	**0 265 006 306**
	10.95-02.96	RAB	**0 265 006 473**
Wheel speed sensor, rear	10.95-02.96	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
Fg.no. WD 267264→	10.95-03.00	4SB	**0 265 006 307**
216 GTi 16V			**1,6 l 90-96 kW D16A... 4 Zyl.**
Wheel speed sensor, rear	09.90-02.96	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
216 GTi 16V Cabrio			**1,6 l 90 kW D16A8 4 Zyl.**
Wheel speed sensor, rear	01.92-02.96	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
216 i 16V			**1,6 l 82-85 kW D16... 4 Zyl.**
Wheel speed sensor, rear	10.89-02.96	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
216 i 16V Cabrio, i 16V Coupé			**1,6 l 82 kW 16K4F 4 Zyl.**
Wheel speed sensor, front	03.96-03.00	LAB	**0 265 006 305**
		RAB	**0 265 006 306**
Wheel speed sensor, rear	03.96-03.00	LAB	**0 265 006 267**
		RAB	**0 265 006 268**
216 i 16V Coupé			**1,6 l 90 kW D16Z2 4 Zyl.**
Wheel speed sensor, rear	10.89-02.96	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
216 Vitesse			**1,6 l 76 kW 16 H 4 Zyl.**
Relay, Jetronic	03.85-12.89	DID	**0 332 014 112**
216 16V			**1,6 l 82 kW 16K4F 4 Zyl.**
Wheel speed sensor, front	03.96-03.00	LAB	**0 265 006 305**
	10.95-02.96	LAB	**0 265 006 474**
	03.96-03.00	RAB	**0 265 006 306**
	10.95-02.96	RAB	**0 265 006 473**
Wheel speed sensor, rear	03.96-03.00		**0 265 006 307**
	10.95-02.96	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
Fg.no. WD 267264→	10.95-03.00	4SB	**0 265 006 307**
218 D Turbo			**1,8 l 65 kW XUD7TE 4 Zyl.**
Wheel speed sensor, front	10.92-02.96	LAB	**0 265 006 474**
		RAB	**0 265 006 473**
Wheel speed sensor, rear	10.92-02.96	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
218 i 16V			**1,8 l 88/107 kW S; 18K4K -VVC- 4 Zyl.**
Wheel speed sensor, front	03.96-03.00	LAB	**0 265 006 305**
	09.95-02.96	LAB	**0 265 006 474**
	03.96-03.00	RAB	**0 265 006 306**
	09.95-02.96	RAB	**0 265 006 473**
Wheel speed sensor, rear	09.95-02.96	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
Fg.no. WD 267264→	09.95-03.00	4SB	**0 265 006 307**
218 i 16V Coupé			**1,8 l 107 kW 4 Zyl.**
Wheel speed sensor, front	03.96-03.00	LAB	**0 265 006 305**
		RAB	**0 265 006 306**
Wheel speed sensor, rear	03.96-03.00	LAB	**0 265 006 267**
		RAB	**0 265 006 268**

R

Product			
◀ Serie 200			
218 1.9 D			**1,9 l 52 kW PSA 4 Zyl.**
Wheel speed sensor, front	10.92-12.94	LAB	**0 265 006 474**
		RAB	**0 265 006 473**
Wheel speed sensor, rear	10.92-12.94	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
220 GTi 16V			**2,0 l 103 kW T16 4 Zyl.**
Wheel speed sensor, front	03.96-06.96	LAB	**0 265 006 305**
	09.91-02.96	LAB	**0 265 006 474**
	03.96-06.96	RAB	**0 265 006 306**
	09.91-02.96	RAB	**0 265 006 473**
Wheel speed sensor, rear	03.96-06.96		**0 265 006 307**
	09.91-02.96	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
220 GTi/GSi			**2,0 l 100 kW T16 4 Zyl.**
Wheel speed sensor, front	03.96-06.96	LAB	**0 265 006 305**
	10.92-02.96	LAB	**0 265 006 474**
	03.96-06.96	RAB	**0 265 006 306**
	10.92-02.96	RAB	**0 265 006 473**
Wheel speed sensor, rear	03.96-06.96		**0 265 006 307**
	10.92-02.96	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
220 i Turbo, i Turbo Coupé			**2,0 l 147 kW 20T4G 4 Zyl.**
Wheel speed sensor, front	03.96-06.96	LAB	**0 265 006 305**
	01.93-02.96	LAB	**0 265 006 474**
	03.96-06.96	RAB	**0 265 006 306**
	01.93-02.96	RAB	**0 265 006 473**
Wheel speed sensor, rear	03.96-06.96		**0 265 006 307**
	01.93-02.96	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
220 SD			**2,0 l 63 kW 20 T 2R 4 Zyl.**
Air mass meter, diesel			
Fg.no. YD 471565→	09.95-03.00		**0 280 218 012**
Fg.no. →YD 471564	09.95-03.00		**0 281 002 120**
Speed sensor, diesel	09.95-03.00	BO	**0 281 002 121**
Pressure sensor, intake manifold, diesel			
Fg.no. →YD 471564	09.95-03.00		**0 281 002 119**
Temperature sensor, intake air, diesel	09.95-03.00		**0 280 130 039**
Wheel speed sensor, front	03.96-03.00	LAB	**0 265 006 305**
	09.95-02.96	LAB	**0 265 006 474**
	03.96-03.00	RAB	**0 265 006 306**
	09.95-02.96	RAB	**0 265 006 473**
Wheel speed sensor, rear	09.95-02.96	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
Fg.no. WD 267264→	09.95-03.00	4SB	**0 265 006 307**
220 SDI			**2,0 l 77 kW 20T 2N 4 Zyl.**
Air mass meter, diesel			
Fg.no. YD 471565→	09.95-03.00		**0 280 218 012**
Fg.no. →YD 471564	09.95-03.00		**0 281 002 120**
Speed sensor, diesel	09.95-03.00	BO	**0 281 002 121**
Pressure sensor, intake manifold, diesel			
Fg.no. →YD 471564	09.95-03.00		**0 281 002 119**
Temperature sensor, intake air, diesel	09.95-03.00		**0 280 130 039**
Wheel speed sensor, front	03.96-03.00	LAB	**0 265 006 305**
	09.95-02.96	LAB	**0 265 006 474**
	03.96-03.00	RAB	**0 265 006 306**
	09.95-02.96	RAB	**0 265 006 473**
Wheel speed sensor, rear	09.95-02.96	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
Fg.no. WD 267264→	09.95-03.00	4SB	**0 265 006 307**

Product			
Serie 400			
414 Si 16V			**1,4 l 76 kW K16 4 Zyl.**
Wheel speed sensor, front	05.95-03.00	LAB	**0 265 006 258**
		RAB	**0 265 006 259**
Wheel speed sensor, rear	05.95-03.00	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**
414 16V			**1,4 l 66-70 kW 14K4C 4 Zyl.**
Wheel speed sensor, front	04.90-10.92	LAB	**0 265 006 474**
		RAB	**0 265 006 473**
Wheel speed sensor, rear	04.90-10.92	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
414 16V			**1,4 l 76 kW K14K4F 4 Zyl.**
Wheel speed sensor, front	05.95-02.96	GS,LAB	**0 265 006 258**
		GS,RAB	**0 265 006 259**
	01.93-04.95	LAB	**0 265 006 474**
		RAB	**0 265 006 473**
Wheel speed sensor, rear	01.93-04.95	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
	05.95-02.96	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**
416 GSi 16V			**1,6 l 82-85 kW D16Z2 4 Zyl.**
Wheel speed sensor, front	05.95-02.96	GS,LAB	**0 265 006 258**
		GS,RAB	**0 265 006 259**
Wheel speed sensor, rear	04.90-02.96	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
	05.95-02.96	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**
416 GTi 16V			**1,6 l 90-96 kW 16V ZC 4 Zyl.**
Wheel speed sensor, front	05.95-02.96	GS,LAB	**0 265 006 258**
		GS,RAB	**0 265 006 259**
Wheel speed sensor, rear	04.90-02.96	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
	05.95-02.96	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**
416 i 16V			**1,6 l 82/83 kW ; K16 4 Zyl.**
Wheel speed sensor, front	05.95-02.96	GS,LAB	**0 265 006 258**
		GS,RAB	**0 265 006 259**
	03.96-03.00	LAB	**0 265 006 305**
		RAB	**0 265 006 306**
Wheel speed sensor, rear	05.95-03.00	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**
418 D 1.9			**1,9 l 49 kW XUD9 4 Zyl.**
Wheel speed sensor, front	09.91-04.95	LAB	**0 265 006 474**
		RAB	**0 265 006 473**
Wheel speed sensor, rear	09.91-04.95	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
418 GSi 16V Coupé			**1,8 l 107 kW 4 Zyl.**
Wheel speed sensor, front	01.97-12.98	GS,LAB	**0 265 006 258**
		GS,RAB	**0 265 006 259**
Wheel speed sensor, rear	01.97-12.98	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**
418 TD			**1,8 l 65 kW XUD7TE 4 Zyl.**
Wheel speed sensor, front	05.95-02.96	GS,LAB	**0 265 006 258**
		GS,RAB	**0 265 006 259**
	09.91-04.95	LAB	**0 265 006 474**
		RAB	**0 265 006 473**
Wheel speed sensor, rear	09.91-04.95	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
	05.95-02.96	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**

R

Product			
420 i Turbo 16V			**2,0 l 147 kW 20 T4G 4 Zyl.**
Wheel speed sensor, front	05.95-02.96	GS,LAB	**0 265 006 258**
		GS,RAB	**0 265 006 259**
	01.93-04.95	LAB	**0 265 006 474**
		RAB	**0 265 006 473**
Wheel speed sensor, rear	01.93-04.95	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
	05.95-02.96	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**
420 SD			**2,0 l 63 kW 20T2R-TCieM 4 Zyl.**
Air mass meter, diesel			
Fg.no. YD 471064→	10.95-03.00		**0 280 218 012**
Fg.no. →YD 471063	10.95-03.00		**0 281 002 120**
Speed sensor, diesel	10.95-03.00	BO	**0 281 002 121**
Pressure sensor, intake manifold, diesel			
Fg.no. →YD 471063	10.95-03.00		**0 281 002 119**
Temperature sensor, intake air, diesel	10.95-03.00		**0 280 130 039**
Wheel speed sensor, front	10.95-03.00	GS,LAB	**0 265 006 258**
		GS,RAB	**0 265 006 259**
Wheel speed sensor, rear	10.95-03.00	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**
420 SDI			**2,0 l 77 kW 20T2N-TCie 4 Zyl.**
Air mass meter, diesel			
Fg.no. YD 471064→	10.95-03.00		**0 280 218 012**
Fg.no. →YD 471063	10.95-03.00		**0 281 002 120**
Speed sensor, diesel	10.95-03.00	BO	**0 281 002 121**
Pressure sensor, intake manifold, diesel			
Fg.no. →YD 471063	10.95-03.00		**0 281 002 119**
Temperature sensor, intake air, diesel	10.95-03.00		**0 280 130 039**
Wheel speed sensor, front	10.95-03.00	GS,LAB	**0 265 006 258**
		GS,RAB	**0 265 006 259**
Wheel speed sensor, rear	10.95-03.00	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**
420 16V			**2,0 l 100 kW 20T 4H 4 Zyl.**
Wheel speed sensor, front	10.95-03.00	GS,LAB	**0 265 006 258**
		GS,RAB	**0 265 006 259**
Wheel speed sensor, rear	10.95-03.00	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**
420 16V			**2,0 l 103 kW T16 4 Zyl.**
Wheel speed sensor, front	05.95-02.96	GS,LAB	**0 265 006 258**
		GS,RAB	**0 265 006 259**
	02.92-04.95	LAB	**0 265 006 474**
		RAB	**0 265 006 473**
Wheel speed sensor, rear	02.92-04.95	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
	05.95-02.96	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**

Serie 400 Tourer

414 Si 16V			**1,4 l 76 kW K16 4 Zyl.**
Wheel speed sensor, front	05.95-03.00	LAB	**0 265 006 258**
		RAB	**0 265 006 259**
Wheel speed sensor, rear	05.95-03.00	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**
416 GSi 16V			**1,6 l 82-85 kW D16Z2 4 Zyl.**
Wheel speed sensor, front	05.95-02.96	GS,LAB	**0 265 006 258**
		GS,RAB	**0 265 006 259**
Wheel speed sensor, rear	04.90-02.96	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
	05.95-02.96	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**

Product			
416 GTi 16V			**1,6 l 90-96 kW 16V ZC 4 Zyl.**
Wheel speed sensor, front	05.95-02.96	GS,LAB	**0 265 006 258**
		GS,RAB	**0 265 006 259**
Wheel speed sensor, rear	04.90-02.96	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
	05.95-02.96	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**
416 i 16V			**1,6 l 82 kW D16B2/D16Y3 4 Zyl.**
Wheel speed sensor, front	03.96-03.00	LAB	**0 265 006 305**
		RAB	**0 265 006 306**
Wheel speed sensor, rear	02.96-03.00	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**
418 D 1.9			**1,9 l 49 kW XUD9 4 Zyl.**
Wheel speed sensor, front	09.91-04.95	LAB	**0 265 006 474**
		RAB	**0 265 006 473**
Wheel speed sensor, rear	09.91-04.95	LAB	**0 265 006 476**
		RAB	**0 265 006 475**
418 i 16V			**1,8 l 107 kW 4 Zyl.**
Wheel speed sensor, front	03.96-12.98	LAB	**0 265 006 305**
		RAB	**0 265 006 306**
Wheel speed sensor, rear	03.96-12.98	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**
418 TD			**1,8 l 65 kW XUD7TE 4 Zyl.**
Wheel speed sensor, front	03.96-03.00	LAB	**0 265 006 305**
		RAB	**0 265 006 306**
Wheel speed sensor, rear	02.96-03.00	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**

Serie 600

620 i 16V Turbo			**2,0 l 147 kW T16-Turbo 4 Zyl.**
Wheel speed sensor, front			
Fg.no. →AM 246796	04.93-12.98	LAB	**0 265 006 168**
		RAB	**0 265 006 167**
Wheel speed sensor, rear			
Fg.no. →AM 246796	04.93-12.98	LAB	**0 265 006 170**
		RAB	**0 265 006 169**
620 SDi			**2,0 l 77 kW 20T2N-TCIE 4 Zyl.**
Air mass meter, diesel	03.95-12.98	BO	**0 281 002 120**
Speed sensor, diesel	03.95-12.98		**0 281 002 121**
Pressure sensor, intake manifold, diesel	03.95-12.98		**0 281 002 119**
Temperature sensor, coolant, diesel	03.95-12.98		**0 280 130 026**
Temperature sensor, intake air, diesel	03.95-12.98		**0 280 130 039**
Wheel speed sensor, front			
Fg.no. →AM 246796	03.95-12.98	LAB	**0 265 006 168**
		RAB	**0 265 006 167**
Wheel speed sensor, rear			
Fg.no. →AM 246796	03.95-12.98	LAB	**0 265 006 170**
		RAB	**0 265 006 169**

Serie 800

820			**2,0 l 74/88 kW ; 20 HS 4 Zyl.**
Wheel speed sensor, front	10.86-10.91	LAB	**0 265 006 104**
		RAB	**0 265 006 103**
Wheel speed sensor, rear	10.86-10.91	LAB	**0 265 006 106**
		RAB	**0 265 006 105**
820 i			**2,0 l 98/103 kW M16i; 20H 4 Zyl.**
Relay, Jetronic	10.86-10.91	DID	**0 332 014 112**
Wheel speed sensor, front	10.86-10.91	LAB	**0 265 006 104**
		RAB	**0 265 006 103**
Wheel speed sensor, rear	10.86-10.91	LAB	**0 265 006 106**
		RAB	**0 265 006 105**

R

Product			
◀ Serie 800			
820 i 16V			**2,0 l 100-103 kW ; 20T4H 4 Zyl.**
Wheel speed sensor, front	01.92-09.99	LAB	**0 265 006 104**
		RAB	**0 265 006 103**
Wheel speed sensor, rear	01.92-09.99	LAB	**0 265 006 106**
		RAB	**0 265 006 105**
820 i 16V Turbo			**2,0 l 132-147 kW T16 4 Zyl.**
Wheel speed sensor, front	01.92-01.99	LAB	**0 265 006 104**
		RAB	**0 265 006 103**
Wheel speed sensor, rear	01.92-01.99	LAB	**0 265 006 106**
		RAB	**0 265 006 105**
825 i			**2,5 l 110/125 kW C25A V6 6 Zyl.**
Wheel speed sensor, front	10.86-10.88	LAB	**0 265 006 104**
		RAB	**0 265 006 103**
Wheel speed sensor, rear	10.86-10.88	LAB	**0 265 006 106**
		RAB	**0 265 006 105**
825 i, i Coupé			**2,5 l 129 kW 25K4F 6 Zyl.**
Wheel speed sensor, front	01.96-12.98	LAB	**0 265 006 104**
		RAB	**0 265 006 103**
Wheel speed sensor, rear	01.96-12.98	LAB	**0 265 006 106**
		RAB	**0 265 006 105**
825 i Si			**2,5 l 129 kW C25A V6 6 Zyl.**
Wheel speed sensor, front	10.86-10.88	LAB	**0 265 006 104**
		RAB	**0 265 006 103**
Wheel speed sensor, rear	10.86-10.88	LAB	**0 265 006 106**
		RAB	**0 265 006 105**
825 i Sterling			**2,5 l 110/125 kW C25A V6 6 Zyl.**
Wheel speed sensor, front	01.87-10.88	LAB	**0 265 006 104**
		RAB	**0 265 006 103**
Wheel speed sensor, rear	01.87-10.88	LAB	**0 265 006 106**
		RAB	**0 265 006 105**
825 TD			**2,5 l 87 kW VM 4 Zyl.**
Wheel speed sensor, front	10.88-10.91	LAB	**0 265 006 104**
		RAB	**0 265 006 103**
Wheel speed sensor, rear	10.88-10.91	LAB	**0 265 006 106**
		RAB	**0 265 006 105**
825 TD			**2,5 l 87/88 kW VM-425-SLIER; VM-425-SLIRR 4 Zyl.**
Speed sensor, diesel	10.91-12.98		**0 281 002 145**
Wheel speed sensor, front	10.91-12.98	LAB	**0 265 006 104**
		RAB	**0 265 006 103**
Wheel speed sensor, rear	10.91-12.98	LAB	**0 265 006 106**
		RAB	**0 265 006 105**
825 TD			**2,5 l 92 kW VM-425-CLIER 4 Zyl.**
Air mass meter, diesel	01.96-12.98		**0 281 002 120**
Speed sensor, diesel			
Fg.no. 230967→	01.96-12.98		**0 281 002 145**
Temperature sensor, coolant, diesel	01.96-12.98		**0 280 130 055**
Wheel speed sensor, front	01.96-12.98	LAB	**0 265 006 104**
		RAB	**0 265 006 103**
Wheel speed sensor, rear	01.96-12.98	LAB	**0 265 006 106**
		RAB	**0 265 006 105**
827 i Si, i Sterling			**2,7 l 124/130 kW C27A V6 6 Zyl.**
Wheel speed sensor, front	02.88-10.91	LAB	**0 265 006 104**
		RAB	**0 265 006 103**
Wheel speed sensor, rear	02.88-10.91	LAB	**0 265 006 106**
		RAB	**0 265 006 105**
827 i 24V			**2,7 l 124-130 kW C27A1 V6 6 Zyl.**
Wheel speed sensor, front	01.92-01.96	LAB	**0 265 006 104**
		RAB	**0 265 006 103**
Wheel speed sensor, rear	01.92-01.96	LAB	**0 265 006 106**
		RAB	**0 265 006 105**
827 i 24V Coupé			**2,7 l 124 kW C27A V6 6 Zyl.**
Wheel speed sensor, front	01.92-01.96	LAB	**0 265 006 104**
		RAB	**0 265 006 103**
Wheel speed sensor, rear	01.92-01.96	LAB	**0 265 006 106**
		RAB	**0 265 006 105**

Product			
Wheel speed sensor, rear	01.92-01.96	LAB	**0 265 006 106**
		RAB	**0 265 006 105**
25			
1.1 i 16V			**1,1 l 55 kW 11 K4F 4 Zyl.**
Wheel speed sensor, front	02.03-05.05	LAB	**0 265 006 305**
		RAB	**0 265 006 306**
Wheel speed sensor, rear			
Fg.no. →YD 471564	02.03-05.05	4SB	**0 265 006 307**
1.4 i 16V			**1,4 l 62/76 kW 14 K4F; 14 K4M 4 Zyl.**
Wheel speed sensor, front	02.00-05.05	LAB	**0 265 006 305**
		RAB	**0 265 006 306**
Wheel speed sensor, rear			
Fg.no. →YD 471564	02.00-05.05	4SB	**0 265 006 307**
1.6 i 16V			**1,6 l 80 kW 16 K4F 4 Zyl.**
Wheel speed sensor, front	02.00-05.05	LAB	**0 265 006 305**
		RAB	**0 265 006 306**
Wheel speed sensor, rear			
Fg.no. →YD 471564	02.00-05.05	4SB	**0 265 006 307**
1.8 i 16V			**1,8 l 86/107 kW 18 K4F; 18 K4K-VVC 4 Zyl.**
Wheel speed sensor, front	02.00-10.04	LAB	**0 265 006 305**
		RAB	**0 265 006 306**
Wheel speed sensor, rear			
Fg.no. →YD 471564	02.00-10.04	4SB	**0 265 006 307**
2.0 iDT			**2,0 l 74/83 kW TCie; 20 T2N-TCie 4 Zyl.**
Air mass meter, diesel			
Fg.no. YD 471565→	02.00-05.05		**0 280 218 012**
Fg.no. →YD 471564	02.00-05.05		**0 281 002 120**
Speed sensor, diesel	02.00-05.05	BO	**0 281 002 121**
Boost pressure sensor, Diesel			
Fg.no. YD 471565→	02.00-05.05		**0 281 002 389**
Fg.no. →YD 471564	02.00-05.05		**0 281 002 119**
Temperature sensor, intake air, diesel	02.00-05.05		**0 280 130 039**
Pedal position sensor, diesel			
Fg.no. YD 471565→	02.00-05.05		**0 281 002 370**
Wheel speed sensor, front	02.00-05.05	LAB	**0 265 006 305**
		RAB	**0 265 006 306**
Wheel speed sensor, rear			
Fg.no. →YD 471564	02.00-05.05	4SB	**0 265 006 307**
45			
1.4 16V			**1,4 l 76 kW 14 K4F 4 Zyl.**
Wheel speed sensor, front	02.00-05.05	LAB	**0 265 006 258**
		RAB	**0 265 006 259**
Wheel speed sensor, rear	02.00-05.05	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**
1.6 16V			**1,6 l 80 kW 16 K4F 4 Zyl.**
Wheel speed sensor, front	02.00-05.05	LAB	**0 265 006 258**
		RAB	**0 265 006 259**
Wheel speed sensor, rear	02.00-05.05	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**
1.8 16V			**1,8 l 86 kW 18 K4F 4 Zyl.**
Wheel speed sensor, front	02.00-05.05	LAB	**0 265 006 258**
		RAB	**0 265 006 259**
Wheel speed sensor, rear	02.00-05.05	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**
2.0 iDT			**2,0 l 74/83 kW TCie; 20 T2N -TCie 4 Zyl.**
Air mass meter, diesel			
Fg.no. YD 471064→	02.00-05.05		**0 280 218 012**
Fg.no. →YD 471063	02.00-05.05		**0 281 002 120**
Speed sensor, diesel	02.00-05.05	BO	**0 281 002 121**

R

Product			
Pressure sensor, intake manifold, diesel			
Fg.no. →YD 471063	02.00-05.05		**0 281 002 119**
Temperature sensor, intake air, diesel	02.00-05.05		**0 280 130 039**
Pedal position sensor, diesel			
Fg.no. YD 471064→	02.00-05.05		**0 281 002 370**
Wheel speed sensor, front	02.00-05.05	LAB	**0 265 006 258**
		RAB	**0 265 006 259**
Wheel speed sensor, rear	02.00-05.05	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**
2.0 V6		**2,0 l 110 kW 20 K4F 6 Zyl.**	
Wheel speed sensor, front	02.00-05.05	LAB	**0 265 006 258**
		RAB	**0 265 006 259**
Wheel speed sensor, rear	02.00-05.05	4SB,LAB	**0 265 006 267**
		4SB,RAB	**0 265 006 268**

75

2.0 CDT		**2,0 l 85 kW M 47 R 4 Zyl.**	
Air mass meter, diesel	01.99-12.02		**0 928 400 520**
2.0 CDTi		**2,0 l 96 kW M 47 R 4 Zyl.**	
Air mass meter, diesel	01.03-05.05		**0 928 400 520**

75 Tourer

2.0 CDT		**2,0 l 85 kW M 47 R 4 Zyl.**	
Air mass meter, diesel	01.01-12.02		**0 928 400 520**
2.0 CDTi		**2,0 l 96 kW M 47 R 4 Zyl.**	
Air mass meter, diesel	01.03-05.05		**0 928 400 520**

2000-3500

3500 Vitesse Inj.		**3,5 l 139-142 kW V 8 8 Zyl.**	
Air flow sensor, gasoline injection	10.82-10.86		**0 280 202 046**
			0 986 280 027
Relay, Jetronic	10.82-10.86		**0 332 014 113**

SAAB (SAAB AUTOMOBILE AB)

9-3

1.8 t [9440]		**2,0 l 110 kW B207E 4 Zyl.**	
Speed sensor, ignition/injection	09.02→		**0 261 210 229**
1.9 TiD [9440]		**1,9 l 88 kW Z19DT 4 Zyl.**	
Speed sensor, diesel	09.04→		**0 281 002 603**
Phase sensor	09.04→		**0 281 002 213**
Boost pressure sensor, Diesel	09.04→		**0 281 002 437**
1.9 TiD [9440]		**1,9 l 110 kW Z19DTH 4 Zyl.**	
Boost pressure sensor, Diesel	09.04→		**0 281 002 437**
2.0 i 16V [9400]		**2,0 l 96 kW B204I 4 Zyl.**	
Throttle valve sensor	03.98-08.00		**0 280 122 014**
Air mass meter, gasoline injection	03.98-08.00		**0 280 217 120**
Speed sensor, ignition/injection	03.98-08.00		**0 261 210 269**
Knock sensor	03.98-08.00		**0 261 231 046**
Temperature sensor, coolant, injection system	03.98-08.00		**0 280 130 094**
Wheel speed sensor, front	03.98-08.00		**0 265 006 331**
2.0 i 16V Turbo [9400]		**2,0 l 110 kW B205E 4 Zyl.**	
Throttle valve sensor	09.99-08.02		**0 280 122 014**
Air mass meter, gasoline injection	09.99-08.02		**0 280 217 120**
Speed sensor, ignition/injection	09.99-08.02		**0 261 210 269**
Knock sensor	09.99-08.02		**0 261 231 046**
Temperature sensor, coolant, injection system	09.99-08.02		**0 280 130 094**
Wheel speed sensor, front	09.99-08.02		**0 265 006 331**
2.0 i 16V Turbo [9400]		**2,0 l 113 kW B204E 4 Zyl.**	
Throttle valve sensor	09.98-08.00		**0 280 122 014**
Air mass meter, gasoline injection	09.98-08.00		**0 280 217 120**
Speed sensor, ignition/injection	09.98-08.00		**0 261 210 030**
Knock sensor	09.98-08.00		**0 261 231 046**
Temperature sensor, coolant, injection system	09.98-08.00		**0 280 130 094**
Wheel speed sensor, front	09.98-08.00		**0 265 006 331**
2.0 i 16V Turbo [9400]		**2,0 l 136 kW B204L 4 Zyl.**	
Throttle valve sensor	03.98-08.00		**0 280 122 014**
Air mass meter, gasoline injection	03.98-08.00		**0 280 217 120**
Speed sensor, ignition/injection	03.98-08.00		**0 261 210 269**
Knock sensor	03.98-08.00		**0 261 231 046**
Temperature sensor, coolant, injection system	03.98-08.00		**0 280 130 094**
Wheel speed sensor, front	03.98-08.00		**0 265 006 331**
2.0 i 16V Turbo [9400]		**2,0 l 136 kW B205L 4 Zyl.**	
Throttle valve sensor	09.99-08.02		**0 280 122 014**
Air mass meter, gasoline injection	09.99-08.02		**0 280 217 120**
Speed sensor, ignition/injection	09.99-08.02		**0 261 210 269**
Temperature sensor, coolant, injection system	09.99-08.02		**0 280 130 094**
Wheel speed sensor, front	09.99-08.02		**0 265 006 331**
2.0 i 16V Turbo [9400]		**2,0 l 147 kW B204R 4 Zyl.**	
Throttle valve sensor	09.98-08.00		**0 280 122 014**
Air mass meter, gasoline injection	09.98-08.00		**0 280 217 120**
Speed sensor, ignition/injection	09.98-08.00		**0 261 210 269**
Knock sensor	09.98-08.00		**0 261 231 046**
Temperature sensor, coolant, injection system	09.98-08.00		**0 280 130 094**
Wheel speed sensor, front	09.98-08.00		**0 265 006 331**
2.0 i 16V Turbo [9400]		**2,0 l 151 kW B205R 4 Zyl.**	
Throttle valve sensor	09.99-08.02		**0 280 122 014**
Air mass meter, gasoline injection	09.99-08.02		**0 280 217 120**
Speed sensor, ignition/injection	09.99-08.02		**0 261 210 269**
Temperature sensor, coolant, injection system	09.99-08.02		**0 280 130 094**
Wheel speed sensor, front	09.99-08.02		**0 265 006 331**
2.0 T Aero [9440]		**2,0 l 154 kW B207R 4 Zyl.**	
Speed sensor, ignition/injection	02.03→		**0 261 210 229**
2.0 t Sport [9440]		**2,0 l 129 kW B207L 4 Zyl.**	
Speed sensor, ignition/injection	09.02-08.06		**0 261 210 229**
2.2 16V D Turbo [9400]		**2,2 l 85/92 kW D223L 4 Zyl.**	
Air mass meter, diesel			
Fg.no. →12020000	03.98-09.02		**0 281 002 212**
Fg.no. 12020001→	03.98-09.02		**0 281 002 443**
Speed sensor, diesel	03.98-09.02		**0 281 002 138**
Wheel speed sensor, front	03.98-09.02		**0 265 006 331**
2.3 i 16V [9400]		**2,3 l 110 kW B234I 4 Zyl.**	
Throttle valve sensor	03.98-08.00		**0 280 122 014**
Air mass meter, gasoline injection	03.98-08.00		**0 280 217 120**
Speed sensor, ignition/injection	03.98-08.00		**0 261 210 269**
Knock sensor	03.98-08.00		**0 261 231 046**
Temperature sensor, coolant, injection system	03.98-08.00		**0 280 130 094**
Wheel speed sensor, front	03.98-08.00		**0 265 006 331**
2.3 i 16V Turbo [9400]		**2,3 l 125/169 kW B235R 4 Zyl.**	
Throttle valve sensor	01.99-08.00		**0 280 122 014**
Air mass meter, gasoline injection	01.99-08.00		**0 280 217 120**
Speed sensor, ignition/injection	01.99-08.00		**0 261 210 269**
Knock sensor	01.99-08.00		**0 261 231 046**
Temperature sensor, coolant, injection system	01.99-08.00		**0 280 130 094**
Wheel speed sensor, front	01.99-08.00		**0 265 006 331**
2.8 Turbo V6 [9440]		**2,8 l 184 kW B284 6 Zyl.**	
Pressure sensor, intake manifold, gasoline	09.05→		**0 261 230 101**
Temperature sensor, coolant, injection system	09.05→		**0 280 130 122**

S

Product

9-3 Cabriolet

1.8 t [9440]		**1,8 l 110 kW B207E 4 Zyl.**
Speed sensor, ignition/injection	08.03→	**0 261 210 229**
1.9 TiD [9440]		**1,9 l 110 kW Z19DTH 4 Zyl.**
Boost pressure sensor, Diesel	01.06→	**0 281 002 437**
2.0 i 16V [9400]		**2,0 l 96 kW B204I 4 Zyl.**
Throttle valve sensor	03.98-08.00	**0 280 122 014**
Air mass meter, gasoline injection	03.98-08.00	**0 280 217 120**
Speed sensor, ignition/injection	03.98-08.00	**0 261 210 269**
Knock sensor	03.98-08.00	**0 261 231 046**
Temperature sensor, coolant, injection system	03.98-08.00	**0 280 130 094**
Wheel speed sensor, front	03.98-08.00	**0 265 006 331**
2.0 i 16V Turbo [9400]		**2,0 l 113 kW B204E 4 Zyl.**
Throttle valve sensor	09.98-08.00	**0 280 122 014**
Air mass meter, gasoline injection	09.98-08.00	**0 280 217 120**
Speed sensor, ignition/injection	09.98-08.00	**0 261 210 030**
Knock sensor	09.98-08.00	**0 261 231 046**
Temperature sensor, coolant, injection system	09.98-08.00	**0 280 130 094**
Wheel speed sensor, front	09.98-08.00	**0 265 006 331**
2.0 i 16V Turbo [9400]		**2,0 l 136 kW B204L 4 Zyl.**
Throttle valve sensor	03.98-08.00	**0 280 122 014**
Air mass meter, gasoline injection	03.98-08.00	**0 280 217 120**
Speed sensor, ignition/injection	03.98-08.00	**0 261 210 269**
Knock sensor	03.98-08.00	**0 261 231 046**
Temperature sensor, coolant, injection system	03.98-08.00	**0 280 130 094**
Wheel speed sensor, front	03.98-08.00	**0 265 006 331**
2.0 i 16V Turbo [9400]		**2,0 l 136 kW B205L 4 Zyl.**
Throttle valve sensor	09.99-08.03	**0 280 122 014**
Air mass meter, gasoline injection	09.99-08.03	**0 280 217 120**
Speed sensor, ignition/injection	09.99-08.03	**0 261 210 269**
Temperature sensor, coolant, injection system	09.99-08.03	**0 280 130 094**
Wheel speed sensor, front	09.99-08.03	**0 265 006 331**
2.0 i 16V Turbo [9400]		**2,0 l 147 kW B204R 4 Zyl.**
Throttle valve sensor	09.98-08.00	**0 280 122 014**
Air mass meter, gasoline injection	09.98-08.00	**0 280 217 120**
Speed sensor, ignition/injection	09.98-08.00	**0 261 210 269**
Knock sensor	09.98-08.00	**0 261 231 046**
Temperature sensor, coolant, injection system	09.98-08.00	**0 280 130 094**
Wheel speed sensor, front	09.98-08.00	**0 265 006 331**
2.0 t [9400]		**2,0 l 110 kW B205E 4 Zyl.**
Air mass meter, gasoline injection	10.98-07.03	**0 280 217 120**
Speed sensor, ignition/injection	10.98-07.03	**0 261 210 269**
Wheel speed sensor, front	10.98-07.03	**0 265 006 331**
2.0 t [9440]		**2,0 l 129 kW B207L 4 Zyl.**
Speed sensor, ignition/injection	08.03→	**0 261 210 229**
2.0 T [9400]		**2,0 l 151 kW B205R 4 Zyl.**
Air mass meter, gasoline injection	10.99-07.03	**0 280 217 120**
Speed sensor, ignition/injection	10.99-07.03	**0 261 210 269**
Wheel speed sensor, front	10.99-07.03	**0 265 006 331**
2.0 T [9440]		**2,0 l 154 kW B207R 4 Zyl.**
Speed sensor, ignition/injection	08.03→	**0 261 210 229**
2.3 i 16V [9400]		**2,3 l 110 kW B234I 4 Zyl.**
Throttle valve sensor	03.98-08.00	**0 280 122 014**
Air mass meter, gasoline injection	03.98-08.00	**0 280 217 120**
Speed sensor, ignition/injection	03.98-08.00	**0 261 210 269**
Knock sensor	03.98-08.00	**0 261 231 046**
Temperature sensor, coolant, injection system	03.98-08.00	**0 280 130 094**
Wheel speed sensor, front	03.98-08.00	**0 265 006 331**
2.8 Turbo V6 [9440]		**2,8 l 184 kW B284 6 Zyl.**
Pressure sensor, intake manifold, gasoline	09.05→	**0 261 230 101**
Temperature sensor, coolant, injection system	09.05→	**0 280 130 122**

S

Product

9-3 Coupé

2.0 i 16V [9400]		**2,0 l 96 kW B204I 4 Zyl.**
Throttle valve sensor	03.98-08.00	**0 280 122 014**
Air mass meter, gasoline injection	03.98-08.00	**0 280 217 120**
Speed sensor, ignition/injection	03.98-08.00	**0 261 210 269**
Knock sensor	03.98-08.00	**0 261 231 046**
Temperature sensor, coolant, injection system	03.98-08.00	**0 280 130 094**
Wheel speed sensor, front	03.98-08.00	**0 265 006 331**
2.0 i 16V Turbo [9400]		**2,0 l 136 kW B204L 4 Zyl.**
Throttle valve sensor	03.98-08.00	**0 280 122 014**
Air mass meter, gasoline injection	03.98-08.00	**0 280 217 120**
Speed sensor, ignition/injection	03.98-08.00	**0 261 210 269**
Knock sensor	03.98-08.00	**0 261 231 046**
Temperature sensor, coolant, injection system	03.98-08.00	**0 280 130 094**
Wheel speed sensor, front	03.98-08.00	**0 265 006 331**
2.0 i 16V Turbo [9400]		**2,0 l 136 kW B205L 4 Zyl.**
Throttle valve sensor	09.99-08.03	**0 280 122 014**
Air mass meter, gasoline injection	09.99-08.03	**0 280 217 120**
Speed sensor, ignition/injection	09.99-08.03	**0 261 210 269**
Temperature sensor, coolant, injection system	09.99-08.03	**0 280 130 094**
Wheel speed sensor, front	09.99-08.03	**0 265 006 331**
2.0 i 16V Turbo [9400]		**2,0 l 147 kW B204R 4 Zyl.**
Throttle valve sensor	09.98-08.00	**0 280 122 014**
Air mass meter, gasoline injection	09.98-08.00	**0 280 217 120**
Speed sensor, ignition/injection	09.98-08.00	**0 261 210 269**
Knock sensor	09.98-08.00	**0 261 231 046**
Temperature sensor, coolant, injection system	09.98-08.00	**0 280 130 094**
Wheel speed sensor, front	09.98-08.00	**0 265 006 331**
2.0 i 16V Turbo [9400]		**2,0 l 151 kW B205R 4 Zyl.**
Throttle valve sensor	09.99-08.02	**0 280 122 014**
Air mass meter, gasoline injection	09.99-08.02	**0 280 217 120**
Speed sensor, ignition/injection	09.99-08.02	**0 261 210 269**
Temperature sensor, coolant, injection system	09.99-08.02	**0 280 130 094**
Wheel speed sensor, front	09.99-08.02	**0 265 006 331**
2.2 16V D Turbo [9400]		**2,2 l 92 kW D223L 4 Zyl.**
Air mass meter, diesel		
Fg.no. →12020000	11.00-09.02	**0 281 002 212**
Fg.no. 12020001→	11.00-09.02	**0 281 002 443**
Speed sensor, diesel	11.00-09.02	**0 281 002 138**
Wheel speed sensor, front	11.00-09.02	**0 265 006 331**
2.3 i 16V Turbo [9400]		**2,3 l 165 kW B235R 4 Zyl.**
Throttle valve sensor	09.99-08.00	**0 280 122 014**
Air mass meter, gasoline injection	09.99-08.00	**0 280 217 120**
Speed sensor, ignition/injection	09.99-08.00	**0 261 210 269**
Knock sensor	09.99-08.00	**0 261 231 046**
Temperature sensor, coolant, injection system	09.99-08.00	**0 280 130 094**
Wheel speed sensor, front	09.99-08.00	**0 265 006 331**

9-3 Kombi

1.9 TiD [9440]		**1,9 l 88 kW Z19DT 4 Zyl.**
Speed sensor, diesel	03.05→	**0 281 002 603**
Phase sensor	03.05→	**0 281 002 213**
Boost pressure sensor, Diesel	03.05→	**0 281 002 437**
1.9 TiD [9440]		**1,9 l 110 kW Z19DTH 4 Zyl.**
Boost pressure sensor, Diesel	03.05→	**0 281 002 437**
2.8 T Sport V6 [9440]		**2,8 l 184 kW B284 6 Zyl.**
Pressure sensor, intake manifold, gasoline	03.05→	**0 261 230 101**
Temperature sensor, coolant, injection system	03.05→	**0 280 130 122**

Product			

9-5

1.9 TiD			**1,9 l 110 kW Z19DTH 4 Zyl.**
Pressure sensor, intake manifold, diesel	09.05→		**0 281 002 437**
Pressure sensor, ESP, (electronic stability program)	09.05→		**0 265 005 303**
2.0 t			**2,0 l 110/140 kW B205E 4 Zyl.**
Speed sensor, ignition/injection	06.97→		**0 261 210 269**
2.2 TiD			**2,2 l 88 kW D223L 4 Zyl.**
Speed sensor, diesel	03.02→		**0 281 002 138**
Pedal position sensor, diesel	03.02→		**0 281 002 539**
2.3 t			**2,3 l 125/136 kW B235E 4 Zyl.**
Speed sensor, ignition/injection	06.97→		**0 261 210 269**
2.3 T			**2,3 l 162 kW B235L 4 Zyl.**
Speed sensor, ignition/injection	09.03→		**0 261 210 269**
2.3 Turbo			**2,3 l 169/184 kW B235R 4 Zyl.**
Speed sensor, ignition/injection	05.99→		**0 261 210 269**
3.0 t			**3,0 l 147 kW B308E 6 Zyl.**
Speed sensor, ignition/injection	06.97-08.03		**0 261 210 169**
3.0 TiD			**3,0 l 130 kW D308L 6 Zyl.**
Air mass meter, diesel			
Fg.no. 330027124→	09.01→		**0 281 002 605**
Pedal position sensor, diesel	09.01→	RLE	**0 281 002 539**

9-5 Kombi

1.9 TiD			**1,9 l 110 kW Z19DTH 4 Zyl.**
Pressure sensor, intake manifold, diesel	01.06→		**0 281 002 437**
Pressure sensor, ESP, (electronic stability program)	01.06→		**0 265 005 303**
2.0 t			**2,0 l 110/140 kW B205E 4 Zyl.**
Speed sensor, ignition/injection	06.98→		**0 261 210 269**
2.2 TiD			**2,2 l 88 kW D223L 4 Zyl.**
Speed sensor, diesel	03.02→		**0 281 002 138**
Pedal position sensor, diesel	03.02→		**0 281 002 539**
2.3 t			**2,3 l 125/136 kW B235E 4 Zyl.**
Speed sensor, ignition/injection	06.99→		**0 261 210 269**
2.3 T			**2,3 l 162 kW B235L 4 Zyl.**
Speed sensor, ignition/injection	09.03→		**0 261 210 269**
2.3 Turbo			**2,3 l 169/184 kW B235R 4 Zyl.**
Speed sensor, ignition/injection	05.99→		**0 261 210 269**
3.0 t			**3,0 l 147 kW B308E 6 Zyl.**
Speed sensor, ignition/injection	06.97-08.03		**0 261 210 169**
3.0 TiD			**3,0 l 130 kW D308L 6 Zyl.**
Air mass meter, diesel			
Fg.no. 330027124→	09.01→		**0 281 002 605**
Pedal position sensor, diesel	09.01→	RLE	**0 281 002 539**

900

2.0 i			**2,0 l 81 kW B 201 I Kat. 4 Zyl.**
Throttle valve sensor	02.84-08.91	AG	**0 280 120 300**
Air flow sensor, gasoline injection	09.83-08.91		**0 438 120 159**
2.0 i			**2,0 l 85-87 kW B 201 I 4 Zyl.**
Air flow sensor, gasoline injection	09.83-08.90		**0 438 120 071**
2.0 i [II]			**2,0 l 98 kW B 206 I Kat. 4 Zyl.**
Throttle valve sensor	09.93-08.95		**0 280 122 001**
	09.95-08.96		**0 280 122 004**
	09.96-08.98		**0 280 122 014**
Air mass meter, gasoline injection	09.93-08.95		**0 280 217 105**
	09.95-08.96		**0 280 217 119**
	09.96-08.98		**0 280 217 120**
Speed sensor, ignition/injection	09.93-08.95		**0 261 210 030**
	09.95-08.98		**0 261 210 269**
Knock sensor	09.96-08.98		**0 261 231 046**
Temperature sensor, coolant, injection system	09.93-08.95		**0 280 130 075**
	09.95-08.98		**0 280 130 094**
Wheel speed sensor, front	09.95-08.98		**0 265 006 331**
2.0 i Cabrio, i Coupé [II]			**2,0 l 98 kW B 206 I Kat. 4 Zyl.**
Throttle valve sensor	03.94-08.95		**0 280 122 001**
	09.95-08.96		**0 280 122 004**
	09.96-08.98		**0 280 122 014**
Air mass meter, gasoline injection	03.94-08.95		**0 280 217 105**
	09.95-08.96		**0 280 217 119**
	09.96-08.98		**0 280 217 120**
Speed sensor, ignition/injection	03.94-08.95		**0 261 210 030**
	09.95-08.98		**0 261 210 269**
Knock sensor	03.94-08.98		**0 261 231 046**
Temperature sensor, coolant, injection system	03.94-08.95		**0 280 130 075**
	09.95-08.98		**0 280 130 094**
Wheel speed sensor, front	09.95-08.98		**0 265 006 331**
2.0 i S, i S Cabrio, i S Coupé [II]			**2,0 l 96 kW B 204 I Kat. 4 Zyl.**
Throttle valve sensor	09.94-08.95		**0 280 122 001**
	09.95-08.96		**0 280 122 004**
	09.96-08.98		**0 280 122 014**
Air mass meter, gasoline injection	09.94-08.95		**0 280 217 105**
	09.95-08.96		**0 280 217 119**
	09.96-08.98		**0 280 217 120**
Speed sensor, ignition/injection	09.94-08.95		**0 261 210 030**
	09.95-08.98		**0 261 210 269**
Knock sensor	09.96-08.98		**0 261 231 046**
Temperature sensor, coolant, injection system	09.94-08.95		**0 280 130 075**
	09.95-08.98		**0 280 130 094**
Wheel speed sensor, front	09.95-08.98		**0 265 006 331**
2.0 i Turbo [II]			**2,0 l 136 kW B 204 L Kat. 4 Zyl.**
Throttle valve sensor	09.93-08.95		**0 280 122 001**
	09.95-08.96		**0 280 122 004**
	09.96-08.98		**0 280 122 014**
Air mass meter, gasoline injection	09.93-08.95		**0 280 217 105**
	09.95-08.96		**0 280 217 119**
	09.96-08.98		**0 280 217 120**
Speed sensor, ignition/injection	09.93-08.95		**0 261 210 030**
	09.95-08.98		**0 261 210 269**
Temperature sensor, coolant, injection system	09.93-08.95		**0 280 130 075**
	09.95-08.98		**0 280 130 094**
Wheel speed sensor, front	09.95-08.98		**0 265 006 331**
2.0 i Turbo Cabrio, i Turbo Coupé [II]			**2,0 l 136 kW B 204 L Kat. 4 Zyl.**
Throttle valve sensor	03.94-08.95		**0 280 122 001**
	09.95-08.96		**0 280 122 004**
	09.96-08.98		**0 280 122 014**
Air mass meter, gasoline injection	03.94-08.95		**0 280 217 105**
	09.95-08.96		**0 280 217 119**
	09.96-08.98		**0 280 217 120**
Speed sensor, ignition/injection	03.94-08.95		**0 261 210 030**
	09.95-08.98		**0 261 210 269**
Temperature sensor, coolant, injection system	03.94-08.95		**0 280 130 075**
	09.95-08.98		**0 280 130 094**
Wheel speed sensor, front	09.95-08.98		**0 265 006 331**
2.0 i 16			**2,0 l 92-93 kW B 202 I Kat. 4 Zyl.**
Throttle valve sensor	09.85-08.92		**0 280 120 300**
Air mass meter, gasoline injection	09.85-08.87		**0 280 212 005**
			0 986 280 112
	09.87-08.92		**0 280 212 013**
			0 986 280 109
Knock sensor	09.85-07.86		**0 261 231 001**
	08.86-08.92		**0 261 231 006**
Temperature sensor, coolant, injection system	09.85-08.92		**0 280 130 026**

S

Product			
◀ 900			
2.0 i 16			**2,0 l 92-98 kW B 202 I 4 Zyl.**
Throttle valve sensor	09.88-08.93		**0 280 120 300**
Air mass meter, gasoline injection	09.88-08.93		**0 280 212 017**
			0 986 280 119
Knock sensor	09.88-08.93		**0 261 231 006**
Temperature sensor, coolant, injection system	09.88-08.93		**0 280 130 026**
2.0 i 16			**2,0 l 92-98 kW B 202 I Kat. 4 Zyl.**
Throttle valve sensor	09.89-08.92		**0 280 120 300**
Air mass meter, gasoline injection	09.89-08.92		**0 280 212 013**
			0 986 280 109
Knock sensor	09.89-08.92		**0 261 231 006**
Temperature sensor, coolant, injection system	09.89-08.92		**0 280 130 026**
2.0 i 16 Cabrio			**2,0 l 92-99 kW B 202 I Kat. 4 Zyl.**
Throttle valve sensor	09.89-08.93		**0 280 120 300**
Air mass meter, gasoline injection	09.89-08.93		**0 280 212 013**
			0 986 280 109
Knock sensor	09.89-08.93		**0 261 231 006**
Temperature sensor, coolant, injection system	09.89-08.93		**0 280 130 026**
2.0 turbo			**2,0 l 102-110 kW B 201 S 4 Zyl.**
Air flow sensor, gasoline injection	09.85-08.90		**0 438 120 087**
Knock sensor	09.85-07.86		**0 261 231 001**
	08.86-08.90		**0 261 231 006**
2.0 turbo			**2,0 l 103 kW B 201 S Kat. 4 Zyl.**
Throttle valve sensor	09.85-09.90	AG	**0 280 120 300**
Air flow sensor, gasoline injection	09.85-09.90		**0 438 120 159**
Knock sensor	09.85-07.86		**0 261 231 001**
	08.86-09.90		**0 261 231 006**
2.0 turbo 16			**2,0 l 104-107 kW B 202 S Kat. 4 Zyl.**
Throttle valve sensor	09.91-08.93	BO	**0 280 120 300**
Air mass meter, gasoline injection	09.91-08.93	BO	**0 280 212 013**
			0 986 280 109
Temperature sensor, coolant, injection system	09.91-08.93	BO	**0 280 130 026**
2.0 turbo 16			**2,0 l 118 kW B 202 L Kat. 4 Zyl.**
Throttle valve sensor	08.84-08.89		**0 280 120 300**
Air mass meter, gasoline injection	08.84-08.88		**0 280 212 005**
			0 986 280 112
	09.88-08.93		**0 280 212 013**
			0 986 280 109
Knock sensor	08.84-07.86		**0 261 231 001**
	08.86-08.93		**0 261 231 006**
Temperature sensor, coolant, injection system	08.84-08.89		**0 280 130 026**
2.0 turbo 16			**2,0 l 129-132 kW B 202 L 4 Zyl.**
Throttle valve sensor	02.84-08.89		**0 280 120 300**
Air mass meter, gasoline injection	02.84-08.88		**0 280 212 005**
			0 986 280 112
	09.88-08.89		**0 280 212 017**
			0 986 280 119
Knock sensor	02.84-07.86		**0 261 231 001**
	08.86-08.93		**0 261 231 006**
Temperature sensor, coolant, injection system	02.84-08.89		**0 280 130 026**
2.0 turbo 16 Cabrio			**2,0 l 118 kW B 202 L Kat. 4 Zyl.**
Throttle valve sensor	09.90-08.93	BO	**0 280 120 300**
Air mass meter, gasoline injection	09.90-08.93	BO	**0 280 212 013**
			0 986 280 109
Knock sensor	09.90-08.93		**0 261 231 006**
Temperature sensor, coolant, injection system	09.90-08.93	BO	**0 280 130 026**
2.1 i 16			**2,1 l 100-103 kW B 212 I Kat. 4 Zyl.**
Throttle valve sensor	09.90-08.93		**0 280 122 001**
Air mass meter, gasoline injection	09.90-08.93		**0 280 212 019**
			0 986 280 117
Knock sensor	09.90-08.93		**0 261 231 006**
Temperature sensor, coolant, injection system	09.90-08.93		**0 280 130 026**

Product			
2.1 i 16 Cabrio			**2,1 l 103 kW B 212 I Kat. 4 Zyl.**
Throttle valve sensor	09.91-08.93		**0 280 122 001**
Air mass meter, gasoline injection	09.91-08.93		**0 280 212 019**
			0 986 280 117
Knock sensor	09.91-08.93		**0 261 231 006**
Temperature sensor, coolant, injection system	09.91-08.93		**0 280 130 026**
2.3 i [II]			**2,3 l 110 kW B 234 I Kat. 4 Zyl.**
Throttle valve sensor	09.93-08.95		**0 280 122 001**
	09.95-08.96		**0 280 122 004**
	09.96-08.98		**0 280 122 014**
Air mass meter, gasoline injection	09.93-08.95		**0 280 217 105**
	09.95-08.96		**0 280 217 119**
	09.96-08.98		**0 280 217 120**
Speed sensor, ignition/injection	09.93-08.95		**0 261 210 030**
	09.95-08.98		**0 261 210 269**
Knock sensor	09.96-08.98		**0 261 231 046**
Temperature sensor, coolant, injection system	09.93-08.95		**0 280 130 075**
	09.95-08.98		**0 280 130 094**
Wheel speed sensor, front	09.95-08.98		**0 265 006 331**
2.3 i Cabrio, Coupé [II]			**2,3 l 110 kW B 234 I Kat. 4 Zyl.**
Throttle valve sensor	03.94-08.95		**0 280 122 001**
	09.95-08.96		**0 280 122 004**
	09.96-08.98		**0 280 122 014**
Air mass meter, gasoline injection	03.94-08.95		**0 280 217 105**
	09.95-08.96		**0 280 217 119**
	09.96-08.98		**0 280 217 120**
Speed sensor, ignition/injection	03.94-08.95		**0 261 210 030**
	09.95-08.98		**0 261 210 269**
Knock sensor	09.96-08.98		**0 261 231 046**
Temperature sensor, coolant, injection system	03.94-08.95		**0 280 130 075**
	09.95-08.98		**0 280 130 094**
Wheel speed sensor, front	09.95-08.98		**0 265 006 331**
2.5 i [II]			**2,5 l 125 kW B 258 I 6 Zyl.**
Air mass meter, gasoline injection	09.93-08.95		**0 280 217 105**
	09.95-08.96		**0 280 217 119**
	09.96-10.98		**0 280 217 120**
	09.93-08.95		**0 280 217 503**
	09.96-10.98		**0 280 217 519**
	09.95-08.96		**0 280 217 520**
Knock sensor	09.95-10.98		**0 261 231 115**
Temperature sensor, intake air, injection system	09.93-08.95		**0 280 130 073**
	09.95-10.98		**0 280 130 092**
Temperature sensor, coolant, injection system	09.93-10.98		**0 280 130 068**
Wheel speed sensor, front	09.95-10.98		**0 265 006 331**
2.5 i Cabrio [II]			**2,5 l 125 kW B 258 I 6 Zyl.**
Air mass meter, gasoline injection	03.94-08.95		**0 280 217 503**
	09.96-10.98		**0 280 217 519**
	09.95-08.96		**0 280 217 520**
Knock sensor	09.95-10.98		**0 261 231 115**
Temperature sensor, intake air, injection system	03.94-08.95		**0 280 130 073**
	09.95-10.98		**0 280 130 092**
Temperature sensor, coolant, injection system	03.94-10.98		**0 280 130 068**
Wheel speed sensor, front	09.95-10.98		**0 265 006 331**
2.5 i Coupé [II]			**2,5 l 125 kW B 258 I 6 Zyl.**
Air mass meter, gasoline injection	03.94-08.95		**0 280 217 105**
	09.95-08.96		**0 280 217 119**
	09.96-10.98		**0 280 217 120**
Knock sensor	09.95-10.98		**0 261 231 115**
Temperature sensor, intake air, injection system	03.94-08.95		**0 280 130 073**
	09.95-10.98		**0 280 130 092**
Temperature sensor, coolant, injection system	03.94-10.98		**0 280 130 068**
Wheel speed sensor, front	09.95-10.98		**0 265 006 331**

S

Product			

9000

2.0 CD Turbo			**2,0 l 118-120 kW B 202 L 4 Zyl.**
Throttle valve sensor	05.88-08.90		**0 280 120 300**
Air mass meter, gasoline injection	05.88-08.88		**0 280 212 005**
			0 986 280 112
	09.88-08.93		**0 280 212 013**
			0 986 280 109
Temperature sensor, coolant, injection system	05.88-08.93		**0 280 130 026**
2.0 CD Turbo			**2,0 l 129-136 kW B 202 L 4 Zyl.**
Throttle valve sensor	05.88-08.90		**0 280 120 300**
	09.90-08.92		**0 280 122 001**
Air mass meter, gasoline injection	05.88-08.88		**0 280 212 005**
			0 986 280 112
	09.89-08.90		**0 280 212 017**
			0 986 280 119
	09.90-08.92		**0 280 212 018**
Knock sensor	05.88-08.92	TW	**0 261 231 006**
Temperature sensor, coolant, injection system	05.88-08.92		**0 280 130 026**
2.0 CD Turbo 16V			**2,0 l 108 kW B 202 S 4 Zyl.**
Air mass meter, gasoline injection	09.92-12.98	KAT	**0 280 212 013**
			0 986 280 109
		OKA	**0 280 212 018**
Speed sensor, ignition/injection	09.93-12.98		**0 261 210 030**
Knock sensor	09.92-08.93		**0 261 231 006**
Temperature sensor, coolant, injection system	09.92-08.93		**0 280 130 026**
	09.93-12.98	ASR	**0 280 130 032**
		OAS	**0 280 130 075**
2.0 CD 16V			**2,0 l 92-96 kW B 202 I 4 Zyl.**
Throttle valve sensor	09.89-08.90		**0 280 120 300**
	09.90-08.93		**0 280 122 001**
Temperature sensor, coolant, injection system	09.89-08.93		**0 280 130 026**
2.0 CS			**2,0 l 96 kW B 204 L 4 Zyl.**
Throttle valve sensor	09.93-08.94		**0 280 122 001**
	09.94-08.96		**0 280 122 008**
	09.96-12.98		**0 280 122 014**
Speed sensor, ignition/injection	09.93-12.98		**0 261 210 030**
Temperature sensor, coolant, injection system	09.93-12.98		**0 280 130 075**
2.0 CS Turbo			**2,0 l 110 kW B 204 E 4 Zyl.**
Throttle valve sensor	09.96-12.98		**0 280 122 014**
Speed sensor, ignition/injection	09.94-12.98		**0 261 210 030**
2.0 i 16V			**2,0 l 90-92 kW B 202 I 4 Zyl.**
Throttle valve sensor	08.86-08.90		**0 280 120 300**
	09.90-08.93		**0 280 122 001**
Air mass meter, gasoline injection	08.86-08.87	KAT	**0 280 212 009**
			0 986 280 135
	09.87-08.93	KAT	**0 280 212 011**
			0 986 280 131
	08.86-08.93	OKA	**0 280 212 014**
			0 986 280 108
Knock sensor	08.87-08.93		**0 261 231 006**
Temperature sensor, coolant, injection system	08.86-08.93		**0 280 130 026**
2.0 i 16V			**2,0 l 94-96 kW B 202 I 4 Zyl.**
Throttle valve sensor	12.85-08.90		**0 280 120 300**
	09.90-08.93		**0 280 122 001**
Air mass meter, gasoline injection	12.85-08.87		**0 280 212 009**
			0 986 280 135
	09.87-08.90		**0 280 212 014**
			0 986 280 108
	09.90-08.93		**0 280 212 022**
			0 986 280 133
Knock sensor	08.86-08.93	TW	**0 261 231 006**
Temperature sensor, coolant, injection system	12.85-08.93		**0 280 130 026**

Product			
2.0 Turbo 16V			**2,0 l 118 kW B 202 L 4 Zyl.**
Throttle valve sensor	09.84-08.88		**0 280 120 300**
Air mass meter, gasoline injection	09.84-08.88		**0 280 212 005**
			0 986 280 112
Knock sensor	09.84-07.86		**0 261 231 001**
Temperature sensor, coolant, injection system	09.84-08.88		**0 280 130 026**
		AG	**0 280 130 055**
2.0 Turbo 16V			**2,0 l 118-120 kW B 202 L 4 Zyl.**
Throttle valve sensor	09.85-08.88		**0 280 120 300**
Air mass meter, gasoline injection	09.85-08.88		**0 280 212 005**
			0 986 280 112
Knock sensor	09.85-07.86		**0 261 231 001**
	08.86-08.88	TW	**0 261 231 006**
Temperature sensor, coolant, injection system	09.85-08.88		**0 280 130 026**
		AG	**0 280 130 055**
2.0 Turbo 16V			**2,0 l 118-121 kW B 202 L 4 Zyl.**
Throttle valve sensor	01.90-08.90		**0 280 120 300**
	09.90-08.93		**0 280 122 001**
Air mass meter, gasoline injection	01.90-08.93		**0 280 212 013**
			0 986 280 109
Knock sensor	01.90-08.93	TW	**0 261 231 006**
2.0 Turbo 16V			**2,0 l 127-129 kW B 202 L 4 Zyl.**
Throttle valve sensor	09.84-08.90		**0 280 120 300**
Air mass meter, gasoline injection	09.84-08.88		**0 280 212 005**
			0 986 280 112
	09.89-08.90		**0 280 212 017**
			0 986 280 119
Knock sensor	08.86-08.90	TW	**0 261 231 006**
Temperature sensor, coolant, injection system	09.84-08.90		**0 280 130 026**
2.3 CD Turbo			**2,3 l 143 kW B 234 L 4 Zyl.**
Throttle valve sensor	09.90-08.93		**0 280 122 001**
Air mass meter, gasoline injection	09.90-08.93		**0 280 213 012**
			0 986 280 110
Temperature sensor, coolant, injection system	09.90-08.93		**0 280 130 026**
2.3 CD Turbo Ecopow.			**2,3 l 125 kW B 234 E 4 Zyl.**
Throttle valve sensor	09.93-08.94		**0 280 122 001**
	09.94-08.96		**0 280 122 008**
	09.96-12.98		**0 280 122 014**
Speed sensor, ignition/injection	09.93-12.98		**0 261 210 030**
Temperature sensor, coolant, injection system	09.93-12.98		**0 280 130 075**
2.3 CD Turbo S			**2,3 l 143 kW B 234 L 4 Zyl.**
Throttle valve sensor	09.90-08.93		**0 280 122 001**
Air mass meter, gasoline injection	09.90-08.93		**0 280 213 012**
			0 986 280 110
Temperature sensor, coolant, injection system	09.90-08.93		**0 280 130 026**
2.3 CD 16V			**2,3 l 107 kW B 234 I 4 Zyl.**
Throttle valve sensor	09.89-08.90		**0 280 120 300**
	09.90-08.93		**0 280 122 001**
Air mass meter, gasoline injection	09.89-08.93		**0 280 212 019**
			0 986 280 117
Temperature sensor, coolant, injection system	09.89-08.93		**0 280 130 026**
2.3 CD 16V			**2,3 l 108 kW B 234 I 4 Zyl.**
Throttle valve sensor	09.93-08.94		**0 280 122 001**
	09.94-08.96		**0 280 122 008**
	09.96-12.98		**0 280 122 014**
Speed sensor, ignition/injection	09.93-12.98		**0 261 210 030**
Temperature sensor, coolant, injection system	09.93-12.98		**0 280 130 075**
2.3 CD 16V			**2,3 l 110 kW B 234 I 4 Zyl.**
Throttle valve sensor	09.90-08.93		**0 280 122 001**
Air mass meter, gasoline injection	09.90-08.93		**0 280 212 022**
			0 986 280 133
Temperature sensor, coolant, injection system	09.90-08.93		**0 280 130 026**

S

Product

◀ 9000

2.3 CDE Turbo			**2,3 l 147 kW B 234 L 4 Zyl.**
Throttle valve sensor	09.93-08.94		**0 280 122 001**
	09.94-08.96		**0 280 122 008**
	09.96-12.98		**0 280 122 014**
Speed sensor, ignition/injection	09.93-12.98		**0 261 210 030**
Temperature sensor, coolant, injection system	09.93-12.98		**0 280 130 075**
2.3 CDE Turbo Ecopower			**2,3 l 125 kW B 234 E 4 Zyl.**
Throttle valve sensor	09.96-12.98		**0 280 122 014**
Speed sensor, ignition/injection	09.94-12.98		**0 261 210 030**
2.3 CS Aero Turbo			**2,3 l 165 kW B 234 R 4 Zyl.**
Throttle valve sensor	09.94-08.96		**0 280 122 008**
	09.96-12.98		**0 280 122 014**
Air mass meter, gasoline injection	09.92-08.93		**0 280 213 012**
			0 986 280 110
2.3 CS Turbo			**2,3 l 143 kW B 234 L 4 Zyl.**
Throttle valve sensor	09.91-08.93		**0 280 122 001**
Air mass meter, gasoline injection	09.91-08.93		**0 280 213 012**
			0 986 280 110
Temperature sensor, coolant, injection system	09.91-08.93		**0 280 130 026**
2.3 CS Turbo Ecopower			**2,3 l 125 kW B 234 E 4 Zyl.**
Throttle valve sensor	09.93-08.94		**0 280 122 001**
	09.94-08.96		**0 280 122 008**
	09.96-12.98		**0 280 122 014**
Speed sensor, ignition/injection	09.93-12.98		**0 261 210 030**
Temperature sensor, coolant, injection system	09.93-12.98		**0 280 130 075**
2.3 CS Turbo S			**2,3 l 143 kW B 234 L 4 Zyl.**
Throttle valve sensor	09.91-08.93		**0 280 122 001**
Air mass meter, gasoline injection	09.91-08.93		**0 280 213 012**
			0 986 280 110
Temperature sensor, coolant, injection system	09.91-08.93		**0 280 130 026**
2.3 CS 16V			**2,3 l 107 kW B 234 l 4 Zyl.**
Throttle valve sensor	09.91-08.93		**0 280 122 001**
Air mass meter, gasoline injection	09.91-08.93		**0 280 212 019**
			0 986 280 117
Temperature sensor, coolant, injection system	09.91-08.93		**0 280 130 026**
2.3 CS 16V			**2,3 l 108 kW B 234 l 4 Zyl.**
Throttle valve sensor	09.93-08.94		**0 280 122 001**
	09.94-08.96		**0 280 122 008**
	09.96-12.98		**0 280 122 014**
Speed sensor, ignition/injection	09.93-12.98		**0 261 210 030**
Temperature sensor, coolant, injection system	09.93-12.98		**0 280 130 075**
2.3 CSE Turbo			**2,3 l 147 kW B 234 L 4 Zyl.**
Throttle valve sensor	09.93-08.94		**0 280 122 001**
	09.94-08.96		**0 280 122 008**
	09.96-12.98		**0 280 122 014**
Speed sensor, ignition/injection	09.93-12.98		**0 261 210 030**
Temperature sensor, coolant, injection system	09.93-12.98		**0 280 130 075**
2.3 i 16V			**2,3 l 107-114 kW B 234 l 4 Zyl.**
Throttle valve sensor	09.89-08.90		**0 280 120 300**
	09.90-08.93		**0 280 122 001**
Air mass meter, gasoline injection	09.89-08.93		**0 280 212 019**
			0 986 280 117
Temperature sensor, coolant, injection system	09.89-08.93		**0 280 130 026**
2.3 i 16V			**2,3 l 110 kW B 234 l 4 Zyl.**
Throttle valve sensor	09.90-08.93		**0 280 122 001**
Air mass meter, gasoline injection	09.90-08.93		**0 280 212 022**
			0 986 280 133
Temperature sensor, coolant, injection system	09.90-08.93		**0 280 130 026**
2.3 Turbo 16V			**2,3 l 143 kW B 234 L 4 Zyl.**
Throttle valve sensor	09.90-08.93		**0 280 122 001**
Air mass meter, gasoline injection	09.90-08.93		**0 280 213 012**
			0 986 280 110
Temperature sensor, coolant, injection system	09.90-08.93		**0 280 130 026**

Product

3.0 CD, CS			**3,0 l 155 kW B 308 l 6 Zyl.**
Air mass meter, gasoline injection	09.96-12.98		**0 280 217 522**
	09.94-08.95		**0 280 217 525**
	09.95-08.96		**0 280 217 525**
	09.94-08.95		**0 280 217 525**
	09.95-08.96	ALA	**0 280 217 521**
3.0 Griffin			**3,0 l 155 kW B 308 l 6 Zyl.**
Air mass meter, gasoline injection	09.96-12.98		**0 280 217 522**
	09.94-08.96		**0 280 217 525**

SEAT

Alhambra

1.8 T [7V8]			**1,8 l 110 kW AJH 4 Zyl.**
Air mass meter, gasoline injection	05.98-02.00		**0 280 217 117**
			0 986 280 201
Phase sensor	05.98-02.00		**0 232 101 024**
Speed sensor, ignition/injection	05.98-02.00		**0 261 210 147**
Temperature sensor, intake air, injection system	05.98-02.00		**0 280 130 085**
1.8 T [7V9]			**1,8 l 110 kW AWC 4 Zyl.**
Throttle valve assembly	06.00→		**0 280 750 065**
Air mass meter, gasoline injection	06.00→		**0 280 218 060**
			0 986 280 216
Phase sensor	06.00→		**0 232 101 024**
Knock sensor	06.00→		**0 261 231 146**
Boost pressure sensor, gasoline			
Fg.no. →7M..2..510 000	06.00-08.01		**0 281 002 177**
Fg.no. 7M..2..510 001→	09.01→		**0 281 002 399**
Temperature sensor, intake air, injection system	06.00→		**0 280 130 085**
1.9 TDI [7V8]			**1,9 l 66 kW AHU 4 Zyl.**
Air mass meter, diesel			
Fg.no. 7M..W..507 042→	09.97-02.00		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Pedal position sensor, diesel			
Fg.no. →7M..W..507 041	07.96-08.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
1.9 TDI [7V8]			**1,9 l 66 kW 1Z 4 Zyl.**
Pedal position sensor, diesel	03.96-07.96	AG	**0 205 001 031**
		GS	**0 205 001 032**
1.9 TDI [7V8]			**1,9 l 81 kW AFN 4 Zyl.**
Air mass meter, diesel			
Fg.no. 7M..W..507 042→	09.97-02.00		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
1.9 TDI [7V9]			**1,9 l 66/85 kW ANU; AUY 4 Zyl.**
Air mass meter, diesel	06.00→		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel			
Fg.no. →7M..2..505 000	06.00-06.01		**0 281 002 177**
Fg.no. 7M..2..505 001→	07.01→		**0 281 002 399**
1.9 TDI [7V9]			**1,9 l 85 kW BVK 4 Zyl.**
Air mass meter, diesel	11.05-05.06		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	11.05-05.06		**0 281 002 399**
1.9 TDI [7V9]			**1,9 l 96/110 kW ASZ; BTB 4 Zyl.**
Air mass meter, diesel	11.02-06.06		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	11.02-06.06		**0 281 002 401**

S

Product			
1.9 TDI 4Motion [7V9]			**1,9 l 85 kW AUY 4 Zyl.**
Air mass meter, diesel	06.00→		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel			
Fg.no. →7M..2..505 000	06.00-06.01		**0 281 002 177**
Fg.no. 7M..2..505 001→	07.01→		**0 281 002 399**
1.9 TDI 4Motion [7V9]			**1,9 l 96 kW ASZ 4 Zyl.**
Air mass meter, diesel	11.02-05.06		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	11.02-05.06		**0 281 002 401**
2.0 [7V8]			**2,0 l 85 kW ADY 4 Zyl.**
Knock sensor	03.96-02.00		**0 261 231 077**
Temperature sensor, intake air, injection system	03.96-02.00		**0 280 130 073**
2.0 [7V9]			**2,0 l 85 kW ATM 4 Zyl.**
Throttle valve assembly	06.00→		**0 280 750 057**
Air mass meter, gasoline injection	06.00→		**0 280 218 060**
			0 986 280 216
Phase sensor	06.00→		**0 232 101 031**
Knock sensor	06.00→		**0 261 231 146**
2.0 TDI [7V9]			**2,0 l 103 kW BRT 4 Zyl.**
Air mass meter, diesel	11.05→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	11.05→		**0 281 002 401**
2.8 [7V9]			**2,8 l 150 kW AYL 6 Zyl.**
Throttle valve assembly	06.00→		**0 280 750 086**
Air mass meter, gasoline injection	06.00→		**0 280 218 017**
			0 986 280 208
Phase sensor	06.00→		**0 232 103 019**
Knock sensor	06.00→	OHL	**0 261 231 146**
2.8 4Motion [7V9]			**2,8 l 150 kW AYL 6 Zyl.**
Throttle valve assembly	05.02→		**0 280 750 086**
Air mass meter, gasoline injection	05.02→		**0 280 218 017**
			0 986 280 208
Phase sensor	05.02→		**0 232 103 019**
Knock sensor	05.02→	OHL	**0 261 231 146**

Altea

1.4 [5P]			**1,4 l 63 kW BXW 4 Zyl.**
Knock sensor	05.06→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.06→		**0 261 230 095**
1.6 [5P]			**1,6 l 75 kW BGU; BSE; BSF 4 Zyl.**
Speed sensor, ignition/injection	03.04→		**0 261 210 199**
Knock sensor	03.04→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	03.04→		**0 261 230 031**
1.8 TFSI [5P]			**1,8 l 118 kW BYT; BZB 4 Zyl.**
Boost pressure sensor, gasoline	01.07→		**0 261 230 073**
1.9 TDI [5P]			**1,9 l 77 kW BJB; BKC 4 Zyl.**
Air mass meter, diesel	04.04-05.06		**0 281 002 531**
			0 986 284 009
Speed sensor, diesel	04.04-05.06	TW	**0 261 210 233**
Boost pressure sensor, Diesel	04.04-05.06		**0 281 002 399**
1.9 TDI [5P]			**1,9 l 77 kW BLS 4 Zyl.**
Air mass meter, diesel	10.05→		**0 281 002 531**
			0 986 284 009
Speed sensor, diesel	10.05→	TW	**0 261 210 233**
Boost pressure sensor, Diesel	10.05→		**0 281 002 401**
1.9 TDI [5P]			**1,9 l 77 kW BXE 4 Zyl.**
Air mass meter, diesel	02.06→		**0 281 002 531**
			0 986 284 009
Speed sensor, diesel	02.06→	TW	**0 261 210 233**
Boost pressure sensor, Diesel	02.06→		**0 281 002 399**

Product			
2.0 FSI [5P]			**2,0 l 110 kW BLR; BLY; BVY; BVZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.04→		**0 261 230 031**
2.0 TDI [5P]			**2,0 l 100/103/125 kW AZV; BKD; BMM; BMN 4 Zyl.**
Air mass meter, diesel	03.04→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	03.04→		**0 281 002 401**
2.0 TFSI [5P]			**2,0 l 147 kW BWA 4 Zyl.**
Speed sensor, ignition/injection	05.06→		**0 261 210 199**
Boost pressure sensor, gasoline	05.06→		**0 261 230 073**

Arosa

1.0 [6H1]			**1,0 l 37 kW AER 4 Zyl.**
Knock sensor	02.97-09.99		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	02.97-09.99		**0 261 230 011**
Accelerator pedal module	02.97-09.99	GS,LLE	**0 280 752 214**
Pedal position sensor, EMS (electronic engine management)	02.97-09.99	AG,RLE	**0 280 752 018**
1.0 [6H1]			**1,0 l 37 kW AHT 4 Zyl.**
Accelerator pedal module	10.97-02.00	GS,LLE	**0 280 752 214**
Pedal position sensor, EMS (electronic engine management)	10.97-02.00	AG,RLE	**0 280 752 018**
1.0 [6H1]			**1,0 l 37 kW ALD 4 Zyl.**
Throttle valve assembly			
Fg.no. →6H..Y..006 230	01.99-11.99		**0 280 750 049**
Fg.no. 6H..Y..006 231→	12.99-07.00		**0 280 750 095**
Speed sensor, ignition/injection			
Fg.no. →6H..Y..023 700	01.99-06.00		**0 261 210 188**
Pressure sensor, intake manifold, gasoline	01.99-07.00		**0 261 230 031**
Accelerator pedal module	01.99-07.00	GS,LLE	**0 280 752 214**
Pedal position sensor, EMS (electronic engine management)	01.99-07.00	AG,RLE	**0 280 752 018**
1.0 [6H1]			**1,0 l 37 kW ALL 4 Zyl.**
Knock sensor	10.97-05.99		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	10.97-05.99		**0 261 230 011**
Accelerator pedal module	10.97-05.99	GS,LLE	**0 280 752 214**
Pedal position sensor, EMS (electronic engine management)	10.97-05.99	AG,RLE	**0 280 752 018**
1.0 [6H1]			**1,0 l 37 kW ANV 4 Zyl.**
Throttle valve assembly			
Fg.no. →6H..Y..006 230	01.99-11.99		**0 280 750 049**
Fg.no. 6H..Y..006 231→	12.99-07.00		**0 280 750 095**
Speed sensor, ignition/injection			
Fg.no. →6H..Y..023 700	01.99-06.00		**0 261 210 188**
Knock sensor	01.99-07.00		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	01.99-07.00		**0 261 230 031**
Accelerator pedal module	01.99-07.00	GS,LLE	**0 280 752 214**
Pedal position sensor, EMS (electronic engine management)	01.99-07.00	AG,RLE	**0 280 752 018**
1.0 [6H1]			**1,0 l 37 kW AUC 4 Zyl.**
Throttle valve assembly	05.00-06.04		**0 280 750 095**
Speed sensor, ignition/injection			
Fg.no. →6H..Y..023 700	05.00-06.00		**0 261 210 188**
Fg.no. 6H..Y..027 001→6H..1..004 300	09.00-10.00		**0 261 210 188**
Fg.no. 6H..1..004 301→	11.00-06.04		**0 261 210 213**
Knock sensor	05.00-06.04		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	05.00-06.04		**0 261 230 031**
Accelerator pedal module	05.00-06.04	GS,LLE	**0 280 752 214**
Pedal position sensor, EMS (electronic engine management)	05.00-06.04	AG,RLE	**0 280 752 018**
1.4 [6H1]			**1,4 l 44 kW AEX 4 Zyl.**
Knock sensor	02.97-11.97		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	02.97-11.97		**0 261 230 011**

S

Product

◀ Arosa

Accelerator pedal module	02.97-11.97	GS,LLE	**0 280 752 214**
Pedal position sensor, EMS (electronic engine management)	02.97-11.97	AG,RLE	**0 280 752 018**
1.4 [6H1]			**1,4 l 44 kW AKK 4 Zyl.**
Throttle valve assembly			
Fg.no. →6H..Y..006 230	01.99-11.99		**0 280 750 049**
Fg.no. 6H..Y..006 231→	12.99-10.00		**0 280 750 095**
Speed sensor, ignition/injection	01.99-10.00		**0 261 210 188**
Pressure sensor, intake manifold, gasoline	01.99-10.00		**0 261 230 031**
Accelerator pedal module	01.99-10.00	GS,LLE	**0 280 752 214**
Pedal position sensor, EMS (electronic engine management)	01.99-10.00	AG,RLE	**0 280 752 018**
1.4 [6H1]			**1,4 l 44 kW AKV 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.97-09.99		**0 261 230 011**
Accelerator pedal module	05.97-09.99	GS,LLE	**0 280 752 214**
Pedal position sensor, EMS (electronic engine management)	05.97-09.99	AG,RLE	**0 280 752 018**
1.4 [6H1]			**1,4 l 44 kW ANW 4 Zyl.**
Throttle valve assembly			
Fg.no. →6H..Y..006 230	01.99-11.99		**0 280 750 049**
Fg.no. 6H..Y..006 231→	12.99-10.00		**0 280 750 095**
Speed sensor, ignition/injection	01.99-10.00		**0 261 210 188**
Knock sensor	01.99-10.00		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	01.99-10.00		**0 261 230 031**
Accelerator pedal module	01.99-10.00	GS,LLE	**0 280 752 214**
Pedal position sensor, EMS (electronic engine management)	01.99-10.00	AG,RLE	**0 280 752 018**
1.4 [6H1]			**1,4 l 44 kW APQ 4 Zyl.**
Knock sensor	12.97-08.98		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	12.97-08.98		**0 261 230 011**
Accelerator pedal module	12.97-08.98	GS,LLE	**0 280 752 214**
Pedal position sensor, EMS (electronic engine management)	12.97-08.98	AG,RLE	**0 280 752 018**
1.4 [6H1]			**1,4 l 44 kW AUD 4 Zyl.**
Throttle valve assembly	01.99-06.04		**0 280 750 095**
Knock sensor	01.99-06.04		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	01.99-06.04		**0 261 230 031**
Accelerator pedal module	01.99-06.04	GS,LLE	**0 280 752 214**
Pedal position sensor, EMS (electronic engine management)	01.99-06.04	AG,RLE	**0 280 752 018**
1.4 TDI [6H1]			**1,4 l 55 kW AMF 3 Zyl.**
Air mass meter, diesel	01.98-06.04		**0 281 002 318**
			0 986 284 002
Boost pressure sensor, Diesel	01.98-06.04		**0 281 002 177**
1.4 16V [6H1]			**1,4 l 74 kW AFK; AQQ; AUB 4 Zyl.**
Accelerator pedal module	01.99-06.04	GS,LLE	**0 280 752 214**
Pedal position sensor, EMS (electronic engine management)	01.99-06.04	AG,RLE	**0 280 752 018**

Cordoba

1.0 [6K2]			**1,0 l 37 kW AER 4 Zyl.**
Knock sensor	09.96-06.99		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	09.96-06.99		**0 261 230 011**
1.0 [6K2]			**1,0 l 37 kW ALD 4 Zyl.**
Throttle valve assembly	05.99-12.02		**0 280 750 049**
Speed sensor, ignition/injection			
Fg.no. →6K..1..071 000	05.99-06.00	TW	**0 261 210 188**
Fg.no. 6K..1..158 801→	11.00-12.02	TW	**0 261 210 213**
Knock sensor	05.99-12.02		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	05.99-12.02		**0 261 230 011**
Pedal position sensor, EMS (electronic engine management)	05.99-12.02		**0 280 752 012**

Product

1.0 [6K2]			**1,0 l 37 kW ANV 4 Zyl.**
Throttle valve assembly			
Mot.no. →027 842	05.99-07.00		**0 280 750 049**
Mot.no. 027 843→	05.99-07.00		**0 280 750 095**
Speed sensor, ignition/injection	05.99-07.00	TW	**0 261 210 188**
Knock sensor	05.99-07.00		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	05.99-07.00		**0 261 230 011**
Pedal position sensor, EMS (electronic engine management)	05.99-07.00		**0 280 752 012**
1.0 [6K2]			**1,0 l 37 kW AUC 4 Zyl.**
Throttle valve assembly	07.00-12.02		**0 280 750 049**
Speed sensor, ignition/injection			
Fg.no. 6K..1..158 801→	11.00-12.02	TW	**0 261 210 213**
Knock sensor	07.00-12.02		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	07.00-12.02		**0 261 230 011**
Pedal position sensor, EMS (electronic engine management)	07.00-12.02		**0 280 752 012**
1.2 [6L2]			**1,2 l 47 kW AZQ 3 Zyl.**
Pressure sensor, intake manifold, gasoline	10.02-04.04		**0 261 230 031**
Accelerator pedal module	10.02-04.04	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	10.02-04.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.02-04.04		**0 265 005 303**
1.2 [6L2]			**1,2 l 47 kW BME 3 Zyl.**
Pressure sensor, intake manifold, gasoline	11.04-06.06		**0 261 230 031**
Accelerator pedal module	11.04-06.06	GS,LLE	**0 280 752 214**
Fg.no. →6L..6..570 000	11.04-05.06	AG,RLE	**0 280 752 220**
Duo sensor, acceleration and yaw rate, brake system	11.04-06.06		**0 265 005 601**
1.2 [6L2]			**1,2 l 51 kW BXV 3 Zyl.**
Pressure sensor, intake manifold, gasoline	05.06→		**0 261 230 031**
Accelerator pedal module	05.06→	GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	05.06→		**0 265 005 601**
1.4 [6K2]			**1,4 l 44 kW AEX 4 Zyl.**
Knock sensor	01.96-12.97		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	01.96-12.97		**0 261 230 011**
1.4 [6K2]			**1,4 l 44 kW AKK 4 Zyl.**
Throttle valve assembly	05.99-12.02		**0 280 750 049**
Speed sensor, ignition/injection			
Fg.no. →6K..1..158 800	05.99-10.00	BM6	**0 261 210 188**
Fg.no. 6K..1..158 801→	11.00-12.02	BM6	**0 261 210 213**
Knock sensor	05.99-12.02		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	05.99-12.02		**0 261 230 031**
Pedal position sensor, EMS (electronic engine management)	05.99-12.02		**0 280 752 012**
1.4 [6K2]			**1,4 l 44 kW AKV 4 Zyl.**
Knock sensor	12.97-06.99		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	12.97-06.99		**0 261 230 011**
1.4 [6K2]			**1,4 l 44 kW ANW 4 Zyl.**
Throttle valve assembly			
Mot.no. →051 560	05.99-08.00		**0 280 750 049**
Mot.no. 051 561→	05.99-08.00		**0 280 750 095**
Speed sensor, ignition/injection	05.99-08.00	TW	**0 261 210 188**
Knock sensor	05.99-08.00		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	05.99-08.00		**0 261 230 031**
Pedal position sensor, EMS (electronic engine management)	05.99-08.00		**0 280 752 012**
1.4 [6K2]			**1,4 l 44 kW ANX; APQ 4 Zyl.**
Knock sensor	12.97-05.98		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	12.97-05.98		**0 261 230 011**

Product			
1.4 [6K2]			**1,4 l 44 kW AUD 4 Zyl.**
Throttle valve assembly			
Mot.no. →020 027	06.00-12.02		**0 280 750 049**
Mot.no. 020 028→	06.00-12.02		**0 280 750 095**
Speed sensor, ignition/injection			
Fg.no. →6K..1..158 800	06.00-10.00	BM6	**0 261 210 188**
Fg.no. 6K..1..158 801→	11.00-12.02	BM6	**0 261 210 213**
Knock sensor	06.00-12.02		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	06.00-12.02		**0 261 230 031**
Pedal position sensor, EMS (electronic engine management)	06.00-12.02		**0 280 752 012**
1.4 [6K2]			**1,4 l 55 kW APE; AUA 4 Zyl.**
Knock sensor	09.99-12.02		**0 261 231 045**
Pedal position sensor, EMS (electronic engine management)	09.99-12.02		**0 280 752 012**
1.4 [6K2]			**1,4 l 74 kW AFH 4 Zyl.**
Knock sensor	07.96-12.02		**0 261 231 045**
1.4 [6K2]			**1,4 l 74 kW AQQ; AUB 4 Zyl.**
Knock sensor	09.99-12.02		**0 261 231 045**
Pedal position sensor, EMS (electronic engine management)	09.99-12.02		**0 280 752 012**
1.4 [6L2]			**1,4 l 55 kW BBY 4 Zyl.**
Speed sensor, ignition/injection			
Fg.no. 6L..3..126 001→	11.02-04.04	GS	**0 261 210 257**
Knock sensor	09.02-04.04		**0 261 231 146**
Accelerator pedal module	09.02-04.04	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	09.02-04.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	09.02-04.04		**0 265 005 303**
1.4 [6L2]			**1,4 l 55 kW BKY 4 Zyl.**
Knock sensor	05.04-06.06		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.04-06.06		**0 261 230 095**
Accelerator pedal module	05.04-06.06	GS,LLE	**0 280 752 214**
Fg.no. →6L..6..570 000	05.04-05.06	AG,RLE	**0 280 752 220**
Duo sensor, acceleration and yaw rate, brake system	05.04-06.06		**0 265 005 601**
1.4 [6L2]			**1,4 l 63 kW BXW 4 Zyl.**
Knock sensor	05.06-11.06		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.06-11.06		**0 261 230 095**
Accelerator pedal module	05.06-11.06	GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	05.06-11.06		**0 265 005 601**
1.4 [6L2]			**1,4 l 74 kW BBZ 4 Zyl.**
Knock sensor	10.02→		**0 261 231 146**
Accelerator pedal module	10.02→	GS,LLE	**0 280 752 214**
Fg.no. →6L..6..570 000	10.02-05.06	AG,RLE	**0 280 752 220**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	10.02-04.04		**0 265 005 252**
Fg.no. 6L..4..232 601→	05.04→		**0 265 005 601**
1.4 TDI [6L2]			**1,4 l 51 kW BNM 3 Zyl.**
Air mass meter, diesel	05.05→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	05.05→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	05.05→		**0 265 005 601**
1.4 TDI [6L2]			**1,4 l 55 kW AMF 3 Zyl.**
Air mass meter, diesel	10.02-12.05		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	10.02-12.05		**0 281 002 399**

Product			
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	10.02-04.04		**0 265 005 252**
Fg.no. 6L..4..232 601→	05.04-12.05		**0 265 005 601**
1.4 TDI [6L2]			**1,4 l 58/59 kW BMS; BNV 3 Zyl.**
Air mass meter, diesel	05.05→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	05.05→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	05.05→		**0 265 005 601**
1.6			**1,6 l 74 kW AKL 4 Zyl.**
Speed sensor, ignition/injection	10.99→	FKW	**0 261 210 147**
1.6 [6K2]			**1,6 l 55 kW AEE; ALM 4 Zyl.**
Knock sensor	03.97-12.02		**0 261 231 045**
1.6 [6K2]			**1,6 l 74 kW AEH 4 Zyl.**
Phase sensor	05.99-12.02		**0 232 101 031**
		WW	**0 232 101 038**
Speed sensor, ignition/injection	05.99-12.02		**0 261 210 147**
1.6 [6K2]			**1,6 l 74 kW AFT 4 Zyl.**
Knock sensor	12.95-11.02		**0 261 231 036**
Temperature sensor, intake air, injection system	12.95-11.02		**0 280 130 039**
1.6 [6K2]			**1,6 l 74 kW AKL 4 Zyl.**
Phase sensor	05.99-12.02		**0 232 101 031**
		WW	**0 232 101 038**
Speed sensor, ignition/injection	05.99-12.02		**0 261 210 147**
1.6 [6K2]			**1,6 l 74 kW APF 4 Zyl.**
Phase sensor	09.99-10.00		**0 232 101 031**
Speed sensor, ignition/injection	09.99-10.00		**0 261 210 199**
1.6 [6K2]			**1,6 l 74 kW AUR 4 Zyl.**
Phase sensor	05.00-12.02		**0 232 101 031**
		WW	**0 232 101 038**
Speed sensor, ignition/injection	05.00-12.02		**0 261 210 199**
1.6 [6L2]			**1,6 l 74 kW BAH 4 Zyl.**
Knock sensor	04.03→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	04.03→		**0 261 230 095**
Accelerator pedal module	04.03→	GS,LLE	**0 280 752 214**
Fg.no. →6L..6..570 000	04.03-05.06	AG,RLE	**0 280 752 220**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	04.03-04.04		**0 265 005 252**
Fg.no. 6L..4..232 601→	05.04→		**0 265 005 601**
1.6 [6L2]			**1,6 l 77 kW BTS 4 Zyl.**
Knock sensor	11.06→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	11.06→		**0 261 230 095**
Accelerator pedal module	11.06→	GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	11.06→		**0 265 005 601**
1.8 [6K2]			**1,8 l 95 kW ADL 4 Zyl.**
Knock sensor	09.93-06.96		**0 261 231 077**
1.8 T Cupra [6K2]			**1,8 l 115 kW AQX; AYP 4 Zyl.**
Throttle valve assembly	05.99-12.02		**0 280 750 036**
Air mass meter, gasoline injection	05.99-12.02		**0 280 218 032**
			0 986 280 210
Phase sensor	05.99-12.02		**0 232 101 024**
Speed sensor, ignition/injection	05.99-12.02		**0 261 210 147**
Temperature sensor, intake air, injection system	05.99-12.02		**0 280 130 085**
Pedal position sensor, EMS (electronic engine management)	05.99-12.02		**0 280 752 012**
1.9 SDI [6K2]			**1,9 l 47 kW AEY 4 Zyl.**
Pedal position sensor, diesel	12.95-12.02		**0 205 001 032**

S

Product			
◀ Cordoba			
1.9 SDI [6L2]			**1,9 l 47 kW ASY 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	09.02-04.04		**0 265 005 252**
Fg.no. 6L..4..232 601→	05.04-12.05		**0 265 005 601**
1.9 TDI			**1,9 l 66 kW AGR 4 Zyl.**
Air mass meter, diesel	01.00→		**0 281 002 216**
			0 986 284 001
Pedal position sensor, diesel	01.00→		**0 281 002 286**
	10.00→		**0 281 002 339**
1.9 TDI [6K2]			**1,9 l 66 kW AGR 4 Zyl.**
Air mass meter, diesel	05.99-12.02		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	05.99-12.02		**0 281 002 177**
1.9 TDI [6K2]			**1,9 l 66 kW AHU 4 Zyl.**
Pressure sensor, intake manifold, diesel	07.96-12.02		**0 261 230 037**
Pedal position sensor, diesel	07.96-12.02		**0 205 001 032**
1.9 TDI [6K2]			**1,9 l 66 kW ALH 4 Zyl.**
Air mass meter, diesel	05.99-05.01		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	05.99-05.01		**0 281 002 177**
1.9 TDI [6K2]			**1,9 l 66 kW 1Z 4 Zyl.**
Pressure sensor, intake manifold, diesel	07.96-12.96		**0 261 230 037**
Pedal position sensor, diesel	07.96-12.96		**0 205 001 032**
1.9 TDI [6K2]			**1,9 l 81 kW AFN 4 Zyl.**
Pressure sensor, intake manifold, diesel	03.97-12.02		**0 261 230 037**
Pedal position sensor, diesel	03.97-12.02		**0 205 001 032**
1.9 TDI [6K2]			**1,9 l 81 kW ASV 4 Zyl.**
Air mass meter, diesel	05.99-12.02		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	05.99-12.02		**0 281 002 177**
1.9 TDI [6L2]			**1,9 l 74 kW ATD 4 Zyl.**
Air mass meter, diesel	09.02-09.05		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	09.02-09.05		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	09.02-04.04		**0 265 005 252**
Fg.no. 6L..4..232 601→	05.04-09.05		**0 265 005 601**
1.9 TDI [6L2]			**1,9 l 74 kW AXR 4 Zyl.**
Air mass meter, diesel	05.05→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	05.05→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	05.05→		**0 265 005 601**
1.9 TDI [6L2]			**1,9 l 74 kW BMT 4 Zyl.**
Air mass meter, diesel	09.06-12.06		**0 281 002 531**
			0 986 284 009
Duo sensor, acceleration and yaw rate, brake system	09.06-12.06		**0 265 005 601**
1.9 TDI [6L2]			**1,9 l 96 kW ASZ 4 Zyl.**
Air mass meter, diesel	10.02-09.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	10.02-09.05		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	10.02-04.04		**0 265 005 252**
Fg.no. 6L..4..232 601→	05.04-09.05		**0 265 005 601**
1.9 TDI [6L2]			**1,9 l 96 kW BLT 4 Zyl.**
Air mass meter, diesel	05.05→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	05.05→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	05.05→		**0 265 005 601**
2.0 [6K2]			**2,0 l 85 kW AGG 4 Zyl.**
Knock sensor	04.96-12.02		**0 261 231 077**
2.0 [6K2]			**2,0 l 85 kW 2E 4 Zyl.**
Speed sensor, ignition/injection	09.93-04.96		**0 356 914 213**
Knock sensor	09.93-04.96		**0 261 231 077**
2.0 [6K2]			**2,0 l 110 kW ABF 4 Zyl.**
Knock sensor	06.96-12.02		**0 261 231 077**
2.0 [6L2]			**2,0 l 85 kW AZL 4 Zyl.**
Throttle valve assembly			
Fg.no. →6L..4..184 000	09.02-02.04		**0 280 750 061**
Air mass meter, gasoline injection	09.02-04.05		**0 280 218 060**
			0 986 280 216
Phase sensor	09.02-04.05		**0 232 101 031**
Speed sensor, ignition/injection	09.02-04.05		**0 261 210 199**
Knock sensor	09.02-04.05		**0 261 231 146**
Accelerator pedal module	09.02-04.05	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	09.02-04.04		**0 265 005 252**
Fg.no. 6L..4..232 601→	05.04-04.05		**0 265 005 601**
Pressure sensor, ESP, (electronic stability program)	09.02-04.05		**0 265 005 303**
2.0 [6L2]			**2,0 l 85 kW BBX 4 Zyl.**
Throttle valve assembly	04.03-06.06	TW	**0 280 750 061**
Air mass meter, gasoline injection	04.03-06.06		**0 280 218 060**
			0 986 280 216
Phase sensor	04.03-06.06		**0 232 101 031**
Speed sensor, ignition/injection	04.03-06.06		**0 261 210 199**
Knock sensor	04.03-06.06		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	04.03-06.06		**0 261 230 095**
Accelerator pedal module	04.03-06.06	GS,LLE	**0 280 752 214**
Fg.no. →6L..6..570 000	04.03-05.06	AG,RLE	**0 280 752 220**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	04.03-04.04		**0 265 005 252**
Fg.no. 6L..4..232 601→	05.04-06.06		**0 265 005 601**

Cordoba Vario

1.4 [6K5]			**1,4 l 44 kW AEX 4 Zyl.**
Knock sensor	05.97-08.97		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	05.97-08.97		**0 261 230 011**
1.4 [6K5]			**1,4 l 44 kW AKK 4 Zyl.**
Throttle valve assembly	08.99-08.02		**0 280 750 049**
Speed sensor, ignition/injection			
Fg.no. →6K..1..158 800	08.99-10.00	BM6	**0 261 210 188**
Fg.no. 6K..1..158 801→	11.00-08.02	BM6	**0 261 210 213**
Knock sensor	08.99-08.02		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	08.99-08.02		**0 261 230 031**
Pedal position sensor, EMS (electronic engine management)	08.99-08.02		**0 280 752 012**
1.4 [6K5]			**1,4 l 44 kW AKV 4 Zyl.**
Knock sensor	09.97-12.02		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	09.97-12.02		**0 261 230 011**
1.4 [6K5]			**1,4 l 44 kW ANW 4 Zyl.**
Throttle valve assembly			
Mot.no. →051 560	05.99-08.00		**0 280 750 049**
Mot.no. 051 561→	05.99-08.00		**0 280 750 095**
Speed sensor, ignition/injection	05.99-08.00	TW	**0 261 210 188**
Knock sensor	05.99-08.00		**0 261 231 045**

Product			
Pressure sensor, intake manifold, gasoline	05.99-08.00		**0 261 230 031**
Pedal position sensor, EMS (electronic engine management)	05.99-08.00		**0 280 752 012**
1.4 [6K5]			**1,4 l 44 kW ANX; APQ 4 Zyl.**
Knock sensor	12.97-12.02		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	12.97-12.02		**0 261 230 011**
1.4 [6K5]			**1,4 l 44 kW AUD 4 Zyl.**
Throttle valve assembly			
Mot.no. →020 027	06.00-12.02		**0 280 750 049**
Mot.no. 020 028→	06.00-12.02		**0 280 750 095**
Speed sensor, ignition/injection			
Fg.no. →6K..1..158 800	06.00-10.00	BM6	**0 261 210 188**
Fg.no. 6K..1..158 801→	11.00-12.02	BM6	**0 261 210 213**
Knock sensor	06.00-12.02		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	06.00-12.02		**0 261 230 031**
Pedal position sensor, EMS (electronic engine management)	06.00-12.02		**0 280 752 012**
1.4 [6K5]			**1,4 l 55/74 kW APE; AQQ 4 Zyl.**
Knock sensor	05.99-07.00		**0 261 231 045**
Pedal position sensor, EMS (electronic engine management)	05.99-07.00		**0 280 752 012**
1.6			**1,6 l 76 kW AKL 4 Zyl.**
Speed sensor, ignition/injection	10.99→	FKW	**0 261 210 147**
1.6 [6K5]			**1,6 l 55 kW AEE; ALM 4 Zyl.**
Knock sensor	05.97-08.02		**0 261 231 045**
1.6 [6K5]			**1,6 l 74 kW AEH 4 Zyl.**
Phase sensor	05.99-12.02		**0 232 101 031**
		WW	**0 232 101 038**
Speed sensor, ignition/injection	05.99-12.02		**0 261 210 147**
1.6 [6K5]			**1,6 l 74 kW AFT 4 Zyl.**
Knock sensor	04.97-06.99		**0 261 231 036**
Temperature sensor, intake air, injection system	04.97-06.99		**0 280 130 039**
1.6 [6K5]			**1,6 l 74 kW AKL 4 Zyl.**
Air mass meter, gasoline injection	06.99-09.99		**0 280 218 032**
			0 986 280 210
Phase sensor	06.99-08.02		**0 232 101 031**
		WW	**0 232 101 038**
Speed sensor, ignition/injection	06.99-08.02		**0 261 210 147**
1.6 [6K5]			**1,6 l 74 kW APF 4 Zyl.**
Phase sensor	09.99-10.00		**0 232 101 031**
Speed sensor, ignition/injection	09.99-10.00		**0 261 210 199**
1.6 [6K5]			**1,6 l 74 kW AUR 4 Zyl.**
Phase sensor	07.00-08.02		**0 232 101 031**
		WW	**0 232 101 038**
Speed sensor, ignition/injection	07.00-08.02		**0 261 210 199**
1.9 SDI [6K5]			**1,9 l 47 kW AEY 4 Zyl.**
Pedal position sensor, diesel	06.97-06.99		**0 205 001 032**
1.9 TDI [6K5]			**1,9 l 66 kW AGR 4 Zyl.**
Air mass meter, diesel	05.99-08.02		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	05.99-08.02		**0 281 002 177**
1.9 TDI [6K5]			**1,9 l 66 kW AHU 4 Zyl.**
Pressure sensor, intake manifold, diesel	06.97-06.99		**0 261 230 037**
Pedal position sensor, diesel	06.97-06.99		**0 205 001 032**
1.9 TDI [6K5]			**1,9 l 66 kW ALH 4 Zyl.**
Air mass meter, diesel	05.99-05.01		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	05.99-05.01		**0 281 002 177**
1.9 TDI [6K5]			**1,9 l 81 kW AFN 4 Zyl.**
Pressure sensor, intake manifold, diesel	02.98-06.99		**0 261 230 037**
Pedal position sensor, diesel	02.98-06.99		**0 205 001 032**

Product			
1.9 TDI [6K5]			**1,9 l 81 kW ASV 4 Zyl.**
Air mass meter, diesel	05.99-08.02		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	05.99-08.02		**0 281 002 177**

Ibiza

1.0 [6K1]			**1,0 l 37 kW AER 4 Zyl.**
Knock sensor	09.96-10.99		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	09.96-10.99		**0 261 230 011**
1.0 [6K1]			**1,0 l 37 kW ALD 4 Zyl.**
Throttle valve assembly	05.99-05.02		**0 280 750 049**
Speed sensor, ignition/injection			
Fg.no. →6K..1..071 000	05.99-06.00	TW	**0 261 210 188**
Fg.no. 6K..1..158 801→	11.00-05.02	TW	**0 261 210 213**
Knock sensor	05.99-05.02		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	05.99-05.02		**0 261 230 011**
Pedal position sensor, EMS (electronic engine management)	05.99-05.02		**0 280 752 012**
1.0 [6K1]			**1,0 l 37 kW ANV 4 Zyl.**
Throttle valve assembly			
Mot.no. →027 842	05.99-07.00		**0 280 750 049**
Mot.no. 027 843→	05.99-07.00		**0 280 750 095**
Speed sensor, ignition/injection	05.99-07.00	TW	**0 261 210 188**
Knock sensor	05.99-07.00		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	05.99-07.00		**0 261 230 011**
Pedal position sensor, EMS (electronic engine management)	05.99-07.00		**0 280 752 012**
1.0 [6K1]			**1,0 l 37 kW AUC 4 Zyl.**
Throttle valve assembly	07.00-05.02		**0 280 750 049**
Speed sensor, ignition/injection			
Fg.no. 6K..1..158 801→	11.00-05.02	TW	**0 261 210 213**
Knock sensor	07.00-05.02		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	07.00-05.02		**0 261 230 011**
Pedal position sensor, EMS (electronic engine management)	07.00-05.02		**0 280 752 012**
1.2 [6L1]			**1,2 l 44 kW BBM 4 Zyl.**
Knock sensor	06.07→		**0 261 231 146**
1.2 [6L1]			**1,2 l 47 kW AZQ 3 Zyl.**
Pressure sensor, intake manifold, gasoline	11.01-04.04		**0 261 230 031**
Accelerator pedal module	11.01-04.04	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	11.01-04.04		**0 265 005 252**
1.2 [6L1]			**1,2 l 47 kW BME 3 Zyl.**
Knock sensor	11.04→	2PO	**0 261 231 146**
Pressure sensor, intake manifold, gasoline	11.04→		**0 261 230 031**
Accelerator pedal module	11.04→	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	11.04→		**0 265 005 601**
1.2 [6L1]			**1,2 l 51 kW BXV 3 Zyl.**
Knock sensor	05.06→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.06→		**0 261 230 031**
Accelerator pedal module	05.06→	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	05.06→		**0 265 005 601**
1.2 i [Y..]			**1,2 l 51 kW 021 C.1000 4 Zyl.**
Throttle valve sensor	12.89-05.93		**0 280 120 315**
Air flow sensor, gasoline injection	12.89-05.93		**0 280 200 052**
			0 986 280 058

S

Product			
◀ Ibiza			
Temperature sensor, cylinder head	12.89-05.93		**0 280 130 026**
Relay, Jetronic	12.89-05.93		**0 280 230 009**
1.4 [6K1]			**1,4 l 44 kW AEX 4 Zyl.**
Knock sensor	12.95-12.97		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	12.95-12.97		**0 261 230 011**
1.4 [6K1]			**1,4 l 44 kW AKK 4 Zyl.**
Throttle valve assembly	05.99-05.02		**0 280 750 049**
Speed sensor, ignition/injection			
Fg.no. →6K..1..158 800	05.99-10.00	BM6	**0 261 210 188**
Fg.no. 6K..1..158 801→	11.00-05.02	BM6	**0 261 210 213**
Knock sensor	05.99-05.02		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	05.99-05.02		**0 261 230 031**
Pedal position sensor, EMS (electronic engine management)	05.99-05.02		**0 280 752 012**
1.4 [6K1]			**1,4 l 44 kW AKV 4 Zyl.**
Knock sensor	12.97-10.99		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	12.97-10.99		**0 261 230 011**
1.4 [6K1]			**1,4 l 44 kW ANW 4 Zyl.**
Throttle valve assembly			
Mot.no. →051 560	05.99-08.00		**0 280 750 049**
Mot.no. 051 561→	05.99-08.00		**0 280 750 095**
Speed sensor, ignition/injection	05.99-08.00	TW	**0 261 210 188**
Knock sensor	05.99-08.00		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	05.99-08.00		**0 261 230 031**
Pedal position sensor, EMS (electronic engine management)	05.99-08.00		**0 280 752 012**
1.4 [6K1]			**1,4 l 44 kW ANX; APQ 4 Zyl.**
Knock sensor	12.97-10.99		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	12.97-10.99		**0 261 230 011**
1.4 [6K1]			**1,4 l 44 kW AUD 4 Zyl.**
Throttle valve assembly			
Mot.no. →020 027	06.00-05.02		**0 280 750 049**
Mot.no. 020 028→	06.00-05.02		**0 280 750 095**
Speed sensor, ignition/injection			
Fg.no. →6K..1..158 800	06.00-10.00	BM6	**0 261 210 188**
Fg.no. 6K..1..158 801→	11.00-05.02	BM6	**0 261 210 213**
Knock sensor	06.00-05.02		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	06.00-05.02		**0 261 230 031**
Pedal position sensor, EMS (electronic engine management)	06.00-05.02		**0 280 752 012**
1.4 [6K1]			**1,4 l 55 kW APE; AUA 4 Zyl.**
Knock sensor	05.99-05.02		**0 261 231 045**
Pedal position sensor, EMS (electronic engine management)	05.99-05.02		**0 280 752 012**
1.4 [6K1]			**1,4 l 74 kW AFH 4 Zyl.**
Knock sensor	11.96-10.99		**0 261 231 045**
1.4 [6K1]			**1,4 l 74 kW AQQ; AUB 4 Zyl.**
Knock sensor	09.99-05.02		**0 261 231 045**
Pedal position sensor, EMS (electronic engine management)	09.99-05.02		**0 280 752 012**
1.4 [6L1]			**1,4 l 55 kW BBY 4 Zyl.**
Speed sensor, ignition/injection			
Fg.no. 6L..3..126 001→	11.02-04.04	GS	**0 261 210 257**
Accelerator pedal module	01.02-04.04	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	01.02-04.04		**0 265 005 252**
1.4 [6L1]			**1,4 l 55 kW BKY 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.04→		**0 261 230 095**
Accelerator pedal module	05.04→	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	05.04→		**0 265 005 601**

Product			
1.4 [6L1]			**1,4 l 63 kW BXW 4 Zyl.**
Knock sensor	05.06→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.06→		**0 261 230 095**
Accelerator pedal module	05.06→	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	05.06→		**0 265 005 601**
1.4 [6L1]			**1,4 l 74 kW AUB 4 Zyl.**
Knock sensor	09.01-05.02		**0 261 231 146**
Accelerator pedal module	09.01-05.02	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	09.01-05.02		**0 265 005 252**
1.4 [6L1]			**1,4 l 74 kW BBZ 4 Zyl.**
Knock sensor	04.02→		**0 261 231 146**
Accelerator pedal module	04.02→	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	04.02-04.04		**0 265 005 252**
Fg.no. 6L..4..232 601→	05.04→		**0 265 005 601**
1.4 TDI [6L1]			**1,4 l 51 kW BNM 3 Zyl.**
Air mass meter, diesel	05.05→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	05.05→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	05.05→		**0 265 005 601**
1.4 TDI [6L1]			**1,4 l 55 kW AMF 3 Zyl.**
Air mass meter, diesel	05.02→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	05.02→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	05.02-04.04		**0 265 005 252**
Fg.no. 6L..4..232 601→	05.04→		**0 265 005 601**
1.4 TDI [6L1]			**1,4 l 59 kW BMS; BNV 3 Zyl.**
Air mass meter, diesel	05.05→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	05.05→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	05.05→		**0 265 005 601**
1.5 i [Y..]			**1,5 l 65-70 kW 4 Zyl.**
Air flow sensor, gasoline injection	11.89-05.93		**0 280 200 050**
Temperature sensor, cylinder head	11.89-05.93		**0 280 130 026**
Relay, Jetronic	11.89-05.93		**0 280 230 009**
1.5 i [Y..]			**1,5 l 66 kW 021 A 2000 4 Zyl.**
Throttle valve sensor	10.86-05.93		**0 280 120 315**
Air flow sensor, gasoline injection	10.86-05.93		**0 280 200 050**
Temperature sensor, cylinder head	10.86-05.93		**0 280 130 026**
Relay, Jetronic	10.86-05.93		**0 280 230 009**
1.5 i [Y..]			**1,5 l 74 kW 021 A 2000 4 Zyl.**
Throttle valve sensor	10.86-05.93		**0 280 120 315**
Air flow sensor, gasoline injection	10.86-05.93		**0 280 200 045**
Temperature sensor, cylinder head	10.86-05.93		**0 280 130 026**
Relay, Jetronic	10.86-05.93		**0 280 230 009**
1.6			**1,6 l 76 kW AKL 4 Zyl.**
Speed sensor, ignition/injection	10.99→	FKW	**0 261 210 147**
1.6 [6K1]			**1,6 l 55 kW AEE; ALM 4 Zyl.**
Knock sensor	03.97-05.02		**0 261 231 045**
1.6 [6K1]			**1,6 l 74 kW AEH 4 Zyl.**
Phase sensor	05.99-05.02		**0 232 101 031**
		WW	**0 232 101 038**
Speed sensor, ignition/injection	05.99-05.02		**0 261 210 147**

S

Product			
1.6 [6K1]			**1,6 l 74 kW AFT 4 Zyl.**
Knock sensor	12.95-10.99		**0 261 231 036**
Temperature sensor, intake air, injection system	12.95-10.99		**0 280 130 039**
1.6 [6K1]			**1,6 l 74 kW AKL 4 Zyl.**
Phase sensor	05.99-05.02		**0 232 101 031**
		WW	**0 232 101 038**
Speed sensor, ignition/injection	05.99-05.02		**0 261 210 147**
1.6 [6K1]			**1,6 l 74 kW APF 4 Zyl.**
Phase sensor	09.99-10.00		**0 232 101 031**
Speed sensor, ignition/injection	09.99-10.00		**0 261 210 199**
1.6 [6K1]			**1,6 l 74 kW AUR 4 Zyl.**
Phase sensor	07.00-05.02		**0 232 101 031**
		WW	**0 232 101 038**
Speed sensor, ignition/injection	07.00-05.02		**0 261 210 199**
1.6 [6L1]			**1,6 l 74 kW BAH 4 Zyl.**
Knock sensor	04.03→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	04.03→		**0 261 230 095**
Accelerator pedal module	04.03→	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	04.03-04.04		**0 265 005 252**
Fg.no. 6L..4..232 601→	05.04→		**0 265 005 601**
1.6 [6L1]			**1,6 l 77 kW BTS 4 Zyl.**
Knock sensor	11.06→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	11.06→		**0 261 230 095**
Accelerator pedal module	11.06→	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	11.06→		**0 265 005 601**
1.7 i [Y..]			**1,7 l 72-76 kW 4 Zyl.**
Throttle valve sensor	01.91-05.93		**0 280 120 315**
Temperature sensor, cylinder head	01.91-05.93		**0 280 130 026**
Relay, Jetronic	01.91-05.93		**0 280 230 009**
1.8 [6K1]			**1,8 l 95 kW ADL 4 Zyl.**
Knock sensor	09.93-06.96		**0 261 231 077**
1.8 T [6L1]			**1,8 l 110 kW BJX 4 Zyl.**
Throttle valve assembly	12.03→		**0 280 750 115**
Air mass meter, gasoline injection	12.03→		**0 280 218 063**
			0 986 280 217
Phase sensor	12.03→		**0 232 101 024**
Speed sensor, ignition/injection	12.03→		**0 261 210 199**
Knock sensor	12.03→		**0 261 231 146**
Boost pressure sensor, gasoline	12.03→		**0 281 002 399**
Accelerator pedal module	12.03→	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	12.03-04.04		**0 265 005 252**
Fg.no. 6L..4..232 601→	05.04→		**0 265 005 601**
1.8 T [6L1]			**1,8 l 110 kW BKV 4 Zyl.**
Throttle valve assembly	12.03→		**0 280 750 115**
Air mass meter, gasoline injection	12.03→		**0 280 218 063**
			0 986 280 217
Phase sensor	12.03→		**0 232 101 024**
Speed sensor, ignition/injection	12.03→		**0 261 210 199**
Knock sensor	12.03→		**0 261 231 146**
Accelerator pedal module	12.03→	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	12.03-04.04		**0 265 005 252**
Fg.no. 6L..4..232 601→	05.04→		**0 265 005 601**

Product			
1.8 T Cupra [6K1]			**1,8 l 115 kW AQX; AYP 4 Zyl.**
Throttle valve assembly	10.99-05.02		**0 280 750 036**
Air mass meter, gasoline injection	10.99-05.02		**0 280 218 032**
			0 986 280 210
Phase sensor	10.99-05.02		**0 232 101 024**
Speed sensor, ignition/injection	10.99-05.02		**0 261 210 147**
Temperature sensor, intake air, injection system	10.99-05.02		**0 280 130 085**
Pedal position sensor, EMS (electronic engine management)	10.99-05.02		**0 280 752 012**
1.8 T Cupra R [6L1]			**1,8 l 132 kW BBU; BLZ 4 Zyl.**
Throttle valve assembly	05.04→		**0 280 750 115**
Air mass meter, gasoline injection	05.04→		**0 280 218 063**
			0 986 280 217
Phase sensor	05.04→		**0 232 101 024**
Speed sensor, ignition/injection	05.04→		**0 261 210 199**
Knock sensor	05.04→		**0 261 231 146**
Boost pressure sensor, gasoline	05.04→		**0 281 002 399**
Accelerator pedal module			
Fg.no. →6L..7..029 300	05.04-06.06	LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	05.04→		**0 265 005 601**
1.9 SDI [6K1]			**1,9 l 47 kW AEY 4 Zyl.**
Pedal position sensor, diesel	12.95-10.99		**0 205 001 032**
1.9 SDI [6L1]			**1,9 l 47 kW ASY 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	01.02-04.04		**0 265 005 252**
Fg.no. 6L..4..232 601→	05.04-12.05		**0 265 005 601**
1.9 TDI [6K1]			**1,9 l 66 kW AGR 4 Zyl.**
Air mass meter, diesel	05.99-05.02		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	05.99-05.02		**0 281 002 177**
1.9 TDI [6K1]			**1,9 l 66 kW AHU 4 Zyl.**
Pressure sensor, intake manifold, diesel	12.96-06.99		**0 261 230 037**
Pedal position sensor, diesel	12.96-06.99		**0 205 001 032**
1.9 TDI [6K1]			**1,9 l 66 kW ALH 4 Zyl.**
Air mass meter, diesel	05.99-05.02		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	05.99-05.02		**0 281 002 177**
1.9 TDI [6K1]			**1,9 l 66 kW 1Z 4 Zyl.**
Pressure sensor, intake manifold, diesel	07.96-12.96		**0 261 230 037**
Pedal position sensor, diesel	07.96-12.96		**0 205 001 032**
1.9 TDI [6K1]			**1,9 l 81 kW AFN 4 Zyl.**
Pressure sensor, intake manifold, diesel	03.97-06.99		**0 261 230 037**
Pedal position sensor, diesel	03.97-06.99		**0 205 001 032**
1.9 TDI [6K1]			**1,9 l 81 kW ASV 4 Zyl.**
Air mass meter, diesel	05.99-05.02		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	05.99-05.02		**0 281 002 177**
1.9 TDI [6L1]			**1,9 l 74 kW ATD 4 Zyl.**
Air mass meter, diesel			
Fg.no. →6L..2..050 000	09.01-03.02		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 6L..2..050 001→	04.02→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	09.01→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	09.01-04.04		**0 265 005 252**
Fg.no. 6L..4..232 601→	05.04→		**0 265 005 601**

S

Product

◀ Ibiza

1.9 TDI [6L1]			**1,9 l 74 kW AXR; BMT 4 Zyl.**
Air mass meter, diesel	05.05→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	05.05→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	05.05→		**0 265 005 601**
1.9 TDI [6L1]			**1,9 l 96 kW ASZ 4 Zyl.**
Air mass meter, diesel	11.01→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	11.01→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	11.01-04.04		**0 265 005 252**
Fg.no. 6L..4..232 601→	05.04→		**0 265 005 601**
1.9 TDI [6L1]			**1,9 l 96/118 kW BLT; BUK 4 Zyl.**
Air mass meter, diesel	05.05→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	05.05→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	05.05→		**0 265 005 601**
1.9 TDI Cupra R [6L1]			**1,9 l 118 kW BPX 4 Zyl.**
Air mass meter, diesel	03.04→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	03.04→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	03.04-04.04		**0 265 005 252**
Fg.no. 6L..4..232 601→	05.04→		**0 265 005 601**
2.0 [6K1]			**2,0 l 85 kW AGG 4 Zyl.**
Knock sensor	04.96-10.99		**0 261 231 077**
2.0 [6K1]			**2,0 l 85 kW 2E 4 Zyl.**
Speed sensor, ignition/injection	03.93-04.96		**0 356 914 213**
Knock sensor	03.93-04.96		**0 261 231 077**
2.0 [6K1]			**2,0 l 110 kW ABF 4 Zyl.**
Knock sensor	06.96-10.99		**0 261 231 077**
2.0 [6L1]			**2,0 l 85 kW AZL 4 Zyl.**
Throttle valve assembly			
Fg.no. →6L..4..184 000	07.02-02.04		**0 280 750 061**
Air mass meter, gasoline injection	07.02-04.04		**0 280 218 060**
			0 986 280 216
Phase sensor	07.02-04.04		**0 232 101 031**
Speed sensor, ignition/injection	07.02-04.04		**0 261 210 199**
Knock sensor	07.02-04.04		**0 261 231 146**
Accelerator pedal module	07.02-04.04	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	07.02-04.04		**0 265 005 252**
2.0 [6L1]			**2,0 l 85 kW BBX 4 Zyl.**
Throttle valve assembly			
Fg.no. →6L..4..184 000	04.03-02.04		**0 280 750 061**
Air mass meter, gasoline injection	04.03→		**0 280 218 060**
			0 986 280 216
Phase sensor	04.03→		**0 232 101 031**
Speed sensor, ignition/injection	04.03→		**0 261 210 199**
Knock sensor	04.03→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	04.03→		**0 261 230 095**
Accelerator pedal module	04.03→	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	04.03-04.04		**0 265 005 252**
Fg.no. 6L..4..232 601→	05.04→		**0 265 005 601**

Product

Inca

1.4 [6K9]			**1,4 l 44 kW AEX; AKV; APQ 4 Zyl.**
Knock sensor	11.95-06.03		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	11.95-06.03		**0 261 230 011**
1.4 [6K9]			**1,4 l 44 kW AUD 4 Zyl.**
Throttle valve assembly			
Mot.no. →020 027	09.00-06.03		**0 280 750 049**
Mot.no. 020 028→	09.00-06.03		**0 280 750 095**
Speed sensor, ignition/injection	09.00-06.03		**0 261 210 188**
Knock sensor	09.00-06.03		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	09.00-06.03	TW	**0 261 230 011**
			0 261 230 031
1.4 [6K9]			**1,4 l 55 kW AUA 4 Zyl.**
Knock sensor	09.00-06.03		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	09.00-06.03	TW	**0 261 230 011**
1.6 [6K9]			**1,6 l 55 kW AEE 4 Zyl.**
Knock sensor	06.97-09.00		**0 261 231 045**
1.6 EFI			**1,6 l 66 kW MY4 4 Zyl.**
Pressure sensor, intake manifold, gasoline	11.98→		**0 261 230 095**

Leon

1.4 [1M1]			**1,4 l 55 kW AHW 4 Zyl.**
Knock sensor	12.99-05.02		**0 261 231 146**
Accelerator pedal module	12.99-05.02	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.4 [1M1]			**1,4 l 55 kW APE 4 Zyl.**
Phase sensor	12.99-05.00		**0 232 101 031**
Knock sensor	12.99-05.00		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	12.99-05.00		**0 261 230 031**
Accelerator pedal module	12.99-05.00	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.4 [1M1]			**1,4 l 55 kW AXP; BCA 4 Zyl.**
Knock sensor	06.00-04.04		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	06.00-04.04		**0 261 230 031**
Accelerator pedal module	06.00-04.04	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.4 [1P1]			**1,4 l 63 kW BXW 4 Zyl.**
Knock sensor	06.06→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	06.06→		**0 261 230 095**
1.6 [1M1]			**1,6 l 74 kW AEH; AKL 4 Zyl.**
Phase sensor	10.98-07.04		**0 232 101 031**
Speed sensor, ignition/injection	10.98-07.04		**0 261 210 147**
Accelerator pedal module	10.98-07.04	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
Fg.no. 1M..Y..000 001→	05.99-07.04	GS,RLE	**0 280 752 210**
1.6 [1M1]			**1,6 l 75 kW BFQ 4 Zyl.**
Speed sensor, ignition/injection	10.05→		**0 261 210 199**
Knock sensor	10.05→		**0 261 231 146**
Accelerator pedal module	10.05→	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.6 [1M1]			**1,6 l 77 kW AUS 4 Zyl.**
Speed sensor, ignition/injection			
Fg.no. →1M..1..033 000	06.00-09.00		**0 261 210 194**
Knock sensor			
Fg.no. →1M..1..026 000	06.00-08.00		**0 261 231 045**
Fg.no. 1M..1..026 001→	09.00-04.01		**0 261 231 146**

S

Product			
Accelerator pedal module	06.00-04.01	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.6 [1M1]			**1,6 l 77 kW AZD 4 Zyl.**
Speed sensor, ignition/injection			
Fg.no. →1M..1..033 000	09.00-09.00		**0 261 210 194**
Knock sensor	09.00-04.02		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	09.00-04.02		**0 261 230 031**
Accelerator pedal module	09.00-04.02	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.6 [1M1]			**1,6 l 77 kW BCB 4 Zyl.**
Knock sensor	04.02→		**0 261 231 146**
Accelerator pedal module	04.02→	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.6 [1P1]			**1,6 l 75 kW BSE; BSF 4 Zyl.**
Speed sensor, ignition/injection	07.05→		**0 261 210 199**
Knock sensor	07.05→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	07.05→		**0 261 230 031**
1.8 [1M1]			**1,8 l 92 kW AGN 4 Zyl.**
Air mass meter, gasoline injection	10.98-12.03		**0 280 218 002**
			0 986 280 205
Phase sensor	10.98-12.03		**0 232 101 024**
Speed sensor, ignition/injection	10.98-12.03		**0 261 210 147**
Knock sensor			
Fg.no. →1M..X..025 000	10.98-04.99	KZA	**0 261 231 075**
Accelerator pedal module	10.98-12.03	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
Fg.no. 1M..Y..000 001→	05.99-12.03	GS,RLE	**0 280 752 210**
1.8 [1M1]			**1,8 l 92 kW APG 4 Zyl.**
Throttle valve assembly	12.99-07.04		**0 280 750 026**
Air mass meter, gasoline injection	12.99-07.04		**0 280 218 060**
			0 986 280 216
Phase sensor	12.99-07.04		**0 232 101 024**
Speed sensor, ignition/injection	12.99-07.04		**0 261 210 147**
Accelerator pedal module	12.99-07.04	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.8 FSI [1P1]			**1,8 l 118 kW BZB 4 Zyl.**
Boost pressure sensor, gasoline	06.07→		**0 261 230 073**
1.8 T [1M1]			**1,8 l 132 kW APP 4 Zyl.**
Throttle valve assembly	12.99-12.00		**0 280 750 036**
Air mass meter, gasoline injection			
Fg.no. →1M..1B023 000,→1M..1R028 000	12.99-07.00		**0 280 218 032**
			0 986 280 210
Fg.no. 1M..1B023 001→,1M..1R028 001→	08.00-12.00		**0 280 218 063**
			0 986 280 217
Phase sensor	12.99-12.00		**0 232 101 024**
Speed sensor, ignition/injection	12.99-12.00		**0 261 210 147**
Boost pressure sensor, gasoline	12.99-12.00		**0 281 002 177**
Temperature sensor, intake air, injection system	12.99-12.00		**0 280 130 085**
Accelerator pedal module	12.99-12.00	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.8 T [1M1]			**1,8 l 132 kW ARY; AUQ 4 Zyl.**
Throttle valve assembly	09.00-04.04		**0 280 750 036**
Air mass meter, gasoline injection	09.00-04.04		**0 280 218 063**
			0 986 280 217
Phase sensor	09.00-04.04		**0 232 101 024**
Speed sensor, ignition/injection	09.00-04.04		**0 261 210 199**
Knock sensor	09.00-04.04	KZA	**0 261 231 146**

Product			
Boost pressure sensor, gasoline			
Fg.no. →1M..3..112 874	09.00-02.03		**0 281 002 177**
Fg.no. 1M..3..112 875→	03.03-04.04		**0 281 002 399**
Temperature sensor, intake air, injection system	09.00-04.04		**0 280 130 085**
Accelerator pedal module	09.00-04.04	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.8 T Cupra R [1M1]			**1,8 l 154/165 kW AMK; BAM 4 Zyl.**
Throttle valve assembly	05.02→		**0 280 750 036**
Air mass meter, gasoline injection	05.02→		**0 280 218 065**
			0 986 280 218
Phase sensor	05.02→		**0 232 101 024**
Speed sensor, ignition/injection	05.02→		**0 261 210 178**
Knock sensor	05.02→		**0 261 231 146**
Boost pressure sensor, gasoline	05.02→		**0 261 230 073**
Temperature sensor, intake air, injection system	05.02→		**0 280 130 085**
Accelerator pedal module	05.02→	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.8 T Syncro [1M1]			**1,8 l 132 kW AJQ 4 Zyl.**
Throttle valve assembly	03.00-01.01		**0 280 750 036**
Air mass meter, gasoline injection	03.00-01.01		**0 280 218 032**
			0 986 280 210
Speed sensor, ignition/injection	03.00-01.01		**0 261 210 147**
Boost pressure sensor, gasoline	03.00-01.01		**0 281 002 177**
Temperature sensor, intake air, injection system	03.00-01.01		**0 280 130 085**
Accelerator pedal module	03.00-01.01	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.8 T Syncro [1M1]			**1,8 l 132 kW ARY 4 Zyl.**
Throttle valve assembly	09.00-04.04		**0 280 750 036**
Air mass meter, gasoline injection	09.00-04.04		**0 280 218 063**
			0 986 280 217
Phase sensor	09.00-04.04		**0 232 101 024**
Speed sensor, ignition/injection	09.00-04.04		**0 261 210 199**
Knock sensor	09.00-04.04	KZA	**0 261 231 146**
Boost pressure sensor, gasoline			
Fg.no. →1M..3..112 874	09.00-02.03		**0 281 002 177**
Fg.no. 1M..3..112 875→	03.03-04.04		**0 281 002 399**
Temperature sensor, intake air, injection system	09.00-04.04		**0 280 130 085**
Accelerator pedal module	09.00-04.04	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.9 TDI [1M1]			**1,9 l 66 kW AGR 4 Zyl.**
Air mass meter, diesel	12.99-09.02		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel	12.99-09.02		**0 281 002 177**
1.9 TDI [1M1]			**1,9 l 66 kW ALH 4 Zyl.**
Air mass meter, diesel	03.99-07.04	EU2	**0 281 002 757**
		EU2,WW	**0 280 217 121**
			0 986 280 202
		EU3	**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1M..3..112 874	03.99-02.03		**0 281 002 177**
Fg.no. 1M..3..112 875→	03.03-07.04		**0 281 002 399**
1.9 TDI [1M1]			**1,9 l 74 kW AXR 4 Zyl.**
Air mass meter, diesel	10.05→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	10.05→		**0 281 002 399**

S

Product			
◀ Leon			
1.9 TDI [1M1]			**1,9 l 81 kW AHF 4 Zyl.**
Air mass meter, diesel	04.99-09.02		**0 281 002 757**
	10.98-09.02	WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel	10.98-09.02		**0 281 002 177**
1.9 TDI [1M1]			**1,9 l 81 kW ASV 4 Zyl.**
Air mass meter, diesel	10.99-07.04	EU2	**0 281 002 757**
		EU2,WW	**0 280 217 121**
			0 986 280 202
		EU3	**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1M..3..112 874	10.99-02.03		**0 281 002 177**
Fg.no. 1M..3..112 875→	03.03-07.04		**0 281 002 399**
1.9 TDI [1M1]			**1,9 l 96 kW ASZ 4 Zyl.**
Air mass meter, diesel	05.03→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	05.03→		**0 281 002 401**
1.9 TDI [1P1]			**1,9 l 66 kW BXF 4 Zyl.**
Speed sensor, diesel	06.07→		**0 261 210 233**
1.9 TDI [1P1]			**1,9 l 77 kW BKC; BLS 4 Zyl.**
Air mass meter, diesel	07.05→		**0 281 002 531**
			0 986 284 009
Speed sensor, diesel	07.05→		**0 261 210 233**
		TW	**0 261 210 233**
Boost pressure sensor, Diesel	07.05→		**0 281 002 399**
1.9 TDI [1P1]			**1,9 l 77 kW BXE 4 Zyl.**
Speed sensor, diesel	02.06→		**0 261 210 233**
1.9 TDI Cupra, Cupra Syncro [1M1]			**1,9 l 110 kW ARL 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1M..3..011 800	09.00-05.02		**0 280 217 529**
			0 986 280 204
Fg.no. 1M..3..011 801→	06.02-07.04		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	09.00-07.04		**0 281 002 401**
2.0 FSI [1P1]			**2,0 l 110 kW BLR; BLY; BVY; BVZ 4 Zyl.**
Knock sensor	07.05→	TW	**0 261 231 146**
Pressure sensor, intake manifold, gasoline	07.05→		**0 261 230 031**
2.0 TDI [1P1]			**2,0 l 100/103 kW AZV; BKD; BMM 4 Zyl.**
Air mass meter, diesel	07.05→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	07.05→		**0 281 002 401**
2.0 TFSI [1P1]			**2,0 l 136-147 kW BWA 4 Zyl.**
Speed sensor, ignition/injection	11.05→		**0 261 210 199**
Boost pressure sensor, gasoline	11.05→		**0 261 230 073**
2.0 TFSI [1P1]			**2,0 l 177 kW BWJ 4 Zyl.**
Speed sensor, ignition/injection	11.06→		**0 261 210 199**
2.8 [1M1]			**2,8 l 150 kW AUE 6 Zyl.**
Throttle valve assembly	10.00-07.01		**0 280 750 097**
Air mass meter, gasoline injection	10.00-07.01		**0 280 218 017**
			0 986 280 208
Phase sensor	10.00-07.01		**0 232 103 019**
Knock sensor	10.00-07.01	TW	**0 261 231 146**
Accelerator pedal module	10.00-07.01	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
2.8 [1M1]			**2,8 l 150 kW BDE 6 Zyl.**
Throttle valve assembly	05.02-04.04		**0 280 750 097**
Air mass meter, gasoline injection	05.02-04.04		**0 280 218 017**
			0 986 280 208
Phase sensor	05.02-04.04		**0 232 103 019**
Knock sensor	05.02-04.04	TW	**0 261 231 146**
Accelerator pedal module	05.02-04.04	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
2.8 Cupra Syncro [1M1]			**2,8 l 150 kW AUE; BDE 6 Zyl.**
Throttle valve assembly	10.00-04.04		**0 280 750 097**
Air mass meter, gasoline injection	10.00-04.04		**0 280 218 017**
			0 986 280 208
Phase sensor	10.00-04.04		**0 232 103 019**
Knock sensor	10.00-04.04	TW	**0 261 231 146**
Accelerator pedal module	10.00-04.04	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**

Malaga

1.2 i			**1,2 l 51 kW 4 Zyl.**
Throttle valve sensor	12.89-12.93		**0 280 120 315**
Air flow sensor, gasoline injection	12.89-12.93		**0 280 200 052**
			0 986 280 058
Temperature sensor, cylinder head	12.89-12.93		**0 280 130 026**
Relay, Jetronic	12.89-12.93		**0 280 230 009**
1.5 i			**1,5 l 66/70 kW ; 021 A 2000 4 Zyl.**
Throttle valve sensor	10.86-12.93		**0 280 120 315**
Air flow sensor, gasoline injection	10.86-12.93		**0 280 200 050**
Temperature sensor, cylinder head	10.86-12.93		**0 280 130 026**
Relay, Jetronic	10.86-12.93		**0 280 230 009**
1.7 i			**1,7 l 77 kW 4 Zyl.**
Throttle valve sensor	01.91-12.93		**0 280 120 315**
Temperature sensor, cylinder head	01.91-12.93		**0 280 130 026**
Relay, Jetronic	01.91-12.93		**0 280 230 009**

Toledo

1.4 [1M2]			**1,4 l 55 kW AHW 4 Zyl.**
Knock sensor	07.99-05.02		**0 261 231 146**
Accelerator pedal module	07.99-05.02	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.4 [1M2]			**1,4 l 55 kW AXP 4 Zyl.**
Knock sensor	06.00-02.02		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	06.00-02.02		**0 261 230 031**
Accelerator pedal module	06.00-02.02	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.4 [5P2]			**1,4 l 63 kW BXW 4 Zyl.**
Knock sensor	05.06-06.07		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.06-06.07		**0 261 230 095**
1.6 [1L2]			**1,6 l 55 kW ABN; EZ; 1F 4 Zyl.**
Knock sensor	05.91-03.99		**0 261 231 036**
1.6 [1L2]			**1,6 l 74 kW AFT 4 Zyl.**
Knock sensor	11.96-03.99		**0 261 231 036**
Temperature sensor, intake air, injection system	11.96-03.99	HDK	**0 280 130 039**
1.6 [1M2]			**1,6 l 74 kW AEH; AKL 4 Zyl.**
Phase sensor	04.99-05.02		**0 232 101 031**
Speed sensor, ignition/injection	04.99-05.02		**0 261 210 147**
Accelerator pedal module	04.99-05.02	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
Fg.no. 1M..Y..000 001→	05.99-05.02	GS,RLE	**0 280 752 210**
1.6 [1M2]			**1,6 l 77 kW AUS 4 Zyl.**
Speed sensor, ignition/injection			
Fg.no. →1M..1..033 000	06.00-09.00		**0 261 210 194**

Product			
Knock sensor			
Fg.no. →1M..1..026 000	06.00-08.00		**0 261 231 045**
Fg.no. 1M..1..026 001→	09.00-04.01		**0 261 231 146**
Accelerator pedal module	06.00-04.01	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.6 [1M2]			**1,6 l 77 kW AZD 4 Zyl.**
Speed sensor, ignition/injection			
Fg.no. →1M..1..033 000	09.00-09.00		**0 261 210 194**
Knock sensor	09.00-04.02		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	09.00-04.02		**0 261 230 031**
Accelerator pedal module	09.00-04.02	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.6 [1M2]			**1,6 l 77 kW BCB 4 Zyl.**
Knock sensor	04.02-07.04		**0 261 231 146**
Accelerator pedal module	04.02-07.04	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.6 [5P2]			**1,6 l 75 kW BGU; BSE; BSF 4 Zyl.**
Speed sensor, ignition/injection	09.04→		**0 261 210 199**
Knock sensor	09.04→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	09.04→		**0 261 230 031**
1.8 [1L2]			**1,8 l 66 kW RP 4 Zyl.**
Knock sensor	05.91-11.93		**0 261 231 036**
1.8 [1L2]			**1,8 l 95 kW PL 4 Zyl.**
Air flow sensor, gasoline injection	05.91-03.94		**F 026 TX2 063**
			F 026 TX2 063
Knock sensor	05.91-03.94		**0 261 231 036**
1.8 [1L2]			**1,8 l 98-102 kW KR 4 Zyl.**
Air flow sensor, gasoline injection	05.91-11.92		**F 026 TX2 050**
			F 026 TX2 050
Knock sensor	05.91-11.92		**0 261 231 036**
1.8 [1M2]			**1,8 l 92 kW AGN 4 Zyl.**
Air mass meter, gasoline injection	04.99-12.03		**0 280 218 002**
			0 986 280 205
Phase sensor	04.99-12.03		**0 232 101 024**
Speed sensor, ignition/injection	04.99-12.03		**0 261 210 147**
Knock sensor			
Fg.no. →1M..X..025 000	04.99-04.99		**0 261 231 075**
Accelerator pedal module	04.99-12.03	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
Fg.no. 1M..Y..000 001→	05.99-12.03	GS,RLE	**0 280 752 210**
1.8 [1M2]			**1,8 l 92 kW APG 4 Zyl.**
Throttle valve assembly	05.99-05.02		**0 280 750 026**
Air mass meter, gasoline injection	05.99-05.02		**0 280 218 060**
			0 986 280 216
Phase sensor	05.99-05.02		**0 232 101 024**
Speed sensor, ignition/injection	05.99-05.02		**0 261 210 147**
Accelerator pedal module	05.99-05.02	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.8 FSI [5P2]			**1,8 l 118 kW BZB 4 Zyl.**
Boost pressure sensor, gasoline	06.07→		**0 261 230 073**
1.8 T [1M2]			**1,8 l 132 kW AUQ 4 Zyl.**
Throttle valve assembly	09.00-05.02		**0 280 750 036**
Air mass meter, gasoline injection	09.00-05.02		**0 280 218 063**
			0 986 280 217
Phase sensor	09.00-05.02		**0 232 101 024**
Speed sensor, ignition/injection	09.00-05.02		**0 261 210 199**
Knock sensor	09.00-05.02	KZA	**0 261 231 146**
Boost pressure sensor, gasoline	09.00-05.02		**0 281 002 177**
Temperature sensor, intake air, injection system	09.00-05.02		**0 280 130 085**

Product			
Accelerator pedal module	09.00-05.02	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.9 TDI [1L2]			**1,9 l 66/81 kW AFN; AHU; 1Z 4 Zyl.**
Pressure sensor, intake manifold, diesel	04.95-03.99		**0 261 230 037**
Pedal position sensor, diesel	04.95-03.99		**0 205 001 032**
1.9 TDI [1M2]			**1,9 l 66 kW AGR 4 Zyl.**
Air mass meter, diesel	04.99-09.02		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel	04.99-09.02		**0 281 002 177**
1.9 TDI [1M2]			**1,9 l 66 kW ALH 4 Zyl.**
Air mass meter, dieselPR no. 0GD,PR no. 0GE	04.99-07.04	OOB	**0 281 002 757**
		OOB,WW	**0 280 217 121**
			0 986 280 202
PR no. 0GZ	04.99-07.04	OBD	**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1M..3..112 874	04.99-02.03		**0 281 002 177**
Fg.no. 1M..3..112 875→	03.03-07.04		**0 281 002 399**
1.9 TDI [1M2]			**1,9 l 81 kW AHF 4 Zyl.**
Air mass meter, diesel	04.99-09.02		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel	04.99-09.02		**0 281 002 177**
1.9 TDI [1M2]			**1,9 l 81 kW ASV 4 Zyl.**
Air mass meter, dieselPR no. 0GD,PR no. 0GE	05.99-12.03	OOB	**0 281 002 757**
		OOB,WW	**0 280 217 121**
			0 986 280 202
PR no. 0GZ	05.99-12.03	OBD	**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1M..3..112 874	05.99-02.03		**0 281 002 177**
Fg.no. 1M..3..112 875→	03.03-12.03		**0 281 002 399**
1.9 TDI [1M2]			**1,9 l 96 kW ASZ 4 Zyl.**
Air mass meter, diesel	05.03-07.04		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	05.03-07.04		**0 281 002 401**
1.9 TDI [1M2]			**1,9 l 110 kW ARL 4 Zyl.**
Air mass meter, diesel	09.00-05.02		**0 280 217 529**
			0 986 280 204
Boost pressure sensor, Diesel	09.00-05.02		**0 281 002 394**
1.9 TDI [5P2]			**1,9 l 77 kW BJB; BKC 4 Zyl.**
Air mass meter, diesel	09.04-02.06		**0 281 002 531**
			0 986 284 009
Speed sensor, diesel	09.04-02.06	TW	**0 261 210 233**
Boost pressure sensor, Diesel	09.04-02.06		**0 281 002 399**
1.9 TDI [5P2]			**1,9 l 77 kW BLS 4 Zyl.**
Air mass meter, diesel	10.05→		**0 281 002 531**
			0 986 284 009
Speed sensor, diesel	10.05→	TW	**0 261 210 233**
Boost pressure sensor, Diesel	10.05→		**0 281 002 401**
1.9 TDI [5P2]			**1,9 l 77 kW BXE 4 Zyl.**
Air mass meter, diesel	02.06→		**0 281 002 531**
			0 986 284 009
Speed sensor, diesel	02.06→	TW	**0 261 210 233**
Boost pressure sensor, Diesel	02.06→		**0 281 002 399**
2.0 [1L2]			**2,0 l 85 kW AGG 4 Zyl.**
Knock sensor	03.96-03.99		**0 261 231 077**
2.0 [1L2]			**2,0 l 85 kW 2E 4 Zyl.**
Speed sensor, ignition/injection	05.91-06.96		**0 356 914 213**
Knock sensor	05.91-06.96		**0 261 231 077**

S

Product

◀ Toledo

2.0 [1L2]			**2,0 l 110 kW ABF 4 Zyl.**
Knock sensor	03.94-03.99		**0 261 231 077**
2.0 FSI [5P2]			**2,0 l 110 kW BLR; BLY; BVY; BVZ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	09.04→		**0 261 230 031**
2.0 TDI [5P2]			**2,0 l 100/103/125 kW AZV; BKD; BMM; BMN 4 Zyl.**
Air mass meter, diesel	09.04→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	09.04→		**0 281 002 401**
2.0 TFSI [5P2]			**2,0 l 147 kW BWA 4 Zyl.**
Boost pressure sensor, gasoline	11.05→		**0 261 230 073**
2.3 [1M2]			**2,3 l 110 kW AGZ 5 Zyl.**
Air mass meter, gasoline injection	04.99-11.00		**0 280 217 529**
			0 986 280 204
Phase sensor	04.99-11.00		**0 232 103 019**
Speed sensor, ignition/injection	04.99-11.00		**0 261 210 177**
Knock sensor	04.99-11.00		**0 261 231 146**
Temperature sensor, intake air, injection system	04.99-11.00		**0 280 130 085**
Accelerator pedal module	04.99-11.00	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
Fg.no. 1M..Y..000 001→	05.99-11.00	GS,RLE	**0 280 752 210**
2.3 [1M2]			**2,3 l 125 kW AQN 5 Zyl.**
Throttle valve assembly	09.00-11.03		**0 280 750 097**
Air mass meter, gasoline injection	09.00-11.03		**0 280 218 017**
			0 986 280 208
Phase sensor	09.00-11.03		**0 232 103 019**
Knock sensor	09.00-11.03	OHL	**0 261 231 146**
Accelerator pedal module	09.00-11.03	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**

SKODA

Fabia

1.2 [6Y3]			**1,2 l 40 kW AWY 3 Zyl.**
Knock sensor	08.02-05.04		**0 261 231 146**
Accelerator pedal module	08.02-05.04	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	08.02-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-05.04		**0 265 005 692**
1.2 [6Y3]			**1,2 l 47 kW AZQ 3 Zyl.**
Pressure sensor, intake manifold, gasoline	02.03-11.04		**0 261 230 031**
Accelerator pedal module	02.03-11.04	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	02.03-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-11.04		**0 265 005 692**
1.4 [6Y3]			**1,4 l 44/50 kW AME; AQW; AZE; AZF 4 Zyl.**
Accelerator pedal module	09.99-05.03	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	09.99-05.03		**0 265 005 252**
1.4 [6Y3]			**1,4 l 55 kW AUA 4 Zyl.**
Knock sensor	09.99-08.03		**0 261 231 146**
Accelerator pedal module	09.99-08.03	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	09.99-08.03		**0 265 005 252**

Product

1.4 [6Y3]			**1,4 l 55 kW BBY 4 Zyl.**
Speed sensor, ignition/injection			
Fg.no. 6Y..3..712 485→	12.02-05.04	GS	**0 261 210 257**
Knock sensor	09.00-05.04		**0 261 231 146**
Pressure sensor, intake manifold, gasoline			
Fg.no. 6Y..4..893 313→	09.03-05.04		**0 261 230 095**
Accelerator pedal module	09.00-05.04	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	09.00-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-05.04		**0 265 005 692**
1.4 [6Y3]			**1,4 l 55 kW BKY 4 Zyl.**
Knock sensor	05.04-12.07		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.04-12.07		**0 261 230 095**
Accelerator pedal module	05.04-12.07	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	05.04-12.07		**0 265 005 692**
1.4 [6Y3]			**1,4 l 74 kW AUB 4 Zyl.**
Knock sensor	09.99-08.03		**0 261 231 146**
Accelerator pedal module	09.99-08.03	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	09.99-08.03		**0 265 005 252**
1.4 [6Y3]			**1,4 l 74 kW BBZ 4 Zyl.**
Knock sensor	09.00-12.07		**0 261 231 146**
Accelerator pedal module	09.00-12.07	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	09.00-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-12.07		**0 265 005 692**
1.4 TDI [6Y3]			**1,4 l 51 kW BNM 3 Zyl.**
Air mass meter, diesel	10.05-12.07		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	10.05-12.07		**0 281 002 399**
Accelerator pedal module	10.05-12.07	GS,LLE	**0 281 002 377**
Duo sensor, acceleration and yaw rate, brake system	10.05-12.07		**0 265 005 692**
1.4 TDI [6Y3]			**1,4 l 55 kW AMF 3 Zyl.**
Air mass meter, diesel	05.03-10.05		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	05.03-10.05		**0 281 002 399**
Accelerator pedal module	05.03-10.05	GS,LLE	**0 281 002 377**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	05.03-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-10.05		**0 265 005 692**
1.4 TDI [6Y3]			**1,4 l 59 kW BNV 3 Zyl.**
Air mass meter, diesel	10.05-12.07		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	10.05-12.07		**0 281 002 399**
Accelerator pedal module	10.05-12.07	GS,LLE	**0 281 002 377**
Duo sensor, acceleration and yaw rate, brake system	10.05-12.07		**0 265 005 692**
1.9 SDI [6Y3]			**1,9 l 47 kW ASY 4 Zyl.**
Accelerator pedal module	09.99-12.07	GS,LLE	**0 281 002 377**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	09.99-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-12.07		**0 265 005 692**

Product			
1.9 TDI [6Y3]			**1,9 l 74 kW ATD 4 Zyl.**
Air mass meter, diesel			
Fg.no. →6Y..2..532 833,→6Y..2X040 209	09.99-04.02		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 6Y..2..532 834→,6Y..2X040 210→	05.02-10.05		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →6Y..4..115 000	09.99-04.04		**0 281 002 177**
Fg.no. 6Y..4..115 001→	05.04-10.05		**0 281 002 399**
Accelerator pedal module	09.99-10.05	GS,LLE	**0 281 002 377**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	09.99-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-10.05		**0 265 005 692**
2.0 [6Y3]			**2,0 l 85 kW AZL 4 Zyl.**
Throttle valve assembly			
Fg.no. →6Y..4..095 000	07.00-03.04		**0 280 750 061**
Air mass meter, gasoline injection	07.00-12.07		**0 280 218 060**
			0 986 280 216
Phase sensor	07.00-12.07		**0 232 101 031**
Speed sensor, ignition/injection			
Fg.no. →6Y..2..389 395	07.00-09.01		**0 261 210 147**
Fg.no. 6Y..2..389 396→	10.01-12.07		**0 261 210 199**
Knock sensor	07.00-12.07		**0 261 231 146**
Accelerator pedal module	07.00-12.07	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	07.00-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-12.07		**0 265 005 692**

Fabia Combi

1.2 [5J5]			**1,2 l 51 kW BZG 3 Zyl.**
Knock sensor	10.07→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	10.07→		**0 261 230 031**
1.2 [6Y5]			**1,2 l 40 kW AWY 3 Zyl.**
Knock sensor	08.02-05.04		**0 261 231 146**
Accelerator pedal module	08.02-05.04	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	08.02-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-05.04		**0 265 005 692**
1.2 [6Y5]			**1,2 l 40 kW BMD 3 Zyl.**
Knock sensor	05.04-12.07		**0 261 231 146**
Accelerator pedal module	05.04-12.07	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	05.04-12.07		**0 265 005 692**
1.2 [6Y5]			**1,2 l 47 kW AZQ 3 Zyl.**
Pressure sensor, intake manifold, gasoline	02.03-11.04		**0 261 230 031**
Accelerator pedal module	02.03-11.04	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	02.03-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-11.04		**0 265 005 692**
1.2 [6Y5]			**1,2 l 47 kW BME 3 Zyl.**
Knock sensor	11.04-12.07		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	11.04-12.07		**0 261 230 031**
Accelerator pedal module	11.04-12.07	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	11.04-12.07		**0 265 005 692**
1.4 [5J5]			**1,4 l 63 kW BXW 4 Zyl.**
Knock sensor	10.07→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	10.07→		**0 261 230 095**
1.4 [6Y5]			**1,4 l 44/50 kW AME; AQW; ATZ; AZE; AZF 4 Zyl.**
Accelerator pedal module	12.99-05.03	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	12.99-05.03		**0 265 005 252**
1.4 [6Y5]			**1,4 l 55 kW AUA 4 Zyl.**
Knock sensor	09.00-08.03		**0 261 231 146**
Accelerator pedal module	09.00-08.03	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	09.00-08.03		**0 265 005 252**
1.4 [6Y5]			**1,4 l 55 kW BBY 4 Zyl.**
Speed sensor, ignition/injection			
Fg.no. 6Y..3..712 485→	12.02-05.04	GS	**0 261 210 257**
Knock sensor	09.00-05.04		**0 261 231 146**
Pressure sensor, intake manifold, gasoline			
Fg.no. 6Y..4..893 313→	09.03-05.04		**0 261 230 095**
Accelerator pedal module	09.00-05.04	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	09.00-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-05.04		**0 265 005 692**
1.4 [6Y5]			**1,4 l 55 kW BKY 4 Zyl.**
Knock sensor	05.04-12.07		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.04-12.07		**0 261 230 095**
Accelerator pedal module	05.04-12.07	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	05.04-12.07		**0 265 005 692**
1.4 [6Y5]			**1,4 l 74 kW AUB 4 Zyl.**
Knock sensor	09.00-08.03		**0 261 231 146**
Accelerator pedal module	09.00-08.03	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	09.00-08.03		**0 265 005 252**
1.4 [6Y5]			**1,4 l 74 kW BBZ 4 Zyl.**
Knock sensor	09.00-12.07		**0 261 231 146**
Accelerator pedal module	09.00-12.07	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	09.00-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-12.07		**0 265 005 692**
1.4 TDI [5J5]			**1,4 l 51/59 kW BMS; BNM; BNV 4 Zyl.**
Air mass meter, diesel	10.07→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	10.07→		**0 281 002 399**
1.4 TDI [6Y5]			**1,4 l 51 kW BNM 3 Zyl.**
Air mass meter, diesel	10.05-12.07		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	10.05-12.07		**0 281 002 399**
Accelerator pedal module	10.05-12.07	GS,LLE	**0 281 002 377**
Duo sensor, acceleration and yaw rate, brake system	10.05-12.07		**0 265 005 692**

S

Product			
◀ Fabia Combi			
1.4 TDI [6Y5]			**1,4 l 55 kW AMF 3 Zyl.**
Air mass meter, diesel	05.03-10.05		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	05.03-10.05		**0 281 002 399**
Accelerator pedal module	05.03-10.05	GS,LLE	**0 281 002 377**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	05.03-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-10.05		**0 265 005 692**
1.4 TDI [6Y5]			**1,4 l 59 kW BNV 3 Zyl.**
Air mass meter, diesel	10.05-12.07		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	10.05-12.07		**0 281 002 399**
Accelerator pedal module	10.05-12.07	GS,LLE	**0 281 002 377**
Duo sensor, acceleration and yaw rate, brake system	10.05-12.07		**0 265 005 692**
1.6 [5J5]			**1,6 l 77 kW BTS 4 Zyl.**
Knock sensor	10.07→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	10.07→		**0 261 230 095**
1.9 SDI [6Y5]			**1,9 l 47 kW ASY 4 Zyl.**
Accelerator pedal module	08.00-12.07	GS,LLE	**0 281 002 377**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	08.00-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-12.07		**0 265 005 692**
1.9 TDI [5J5]			**1,9 l 77 kW BLS; BSW 4 Zyl.**
Air mass meter, diesel	10.07→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	10.07→		**0 281 002 399**
1.9 TDI [6Y5]			**1,9 l 74 kW ATD 4 Zyl.**
Air mass meter, diesel			
Fg.no. →6Y..2..532 833,→6Y..2X040 209	08.00-04.02		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 6Y..2..532 834→,6Y..2X040 210→	05.02-10.05		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →6Y..4..115 000	08.00-04.04		**0 281 002 177**
Fg.no. 6Y..4..115 001→	05.04-10.05		**0 281 002 399**
Accelerator pedal module	08.00-10.05	GS,LLE	**0 281 002 377**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	08.00-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-10.05		**0 265 005 692**
1.9 TDI [6Y5]			**1,9 l 74 kW AXR 4 Zyl.**
Air mass meter, diesel	10.05-12.07		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	10.05-12.07		**0 281 002 399**
Accelerator pedal module	10.05-12.07	GS,LLE	**0 281 002 377**
2.0 [6Y5]			**2,0 l 85 kW AZL 4 Zyl.**
Throttle valve assembly			
Fg.no. →6Y..4..095 000	09.00-03.04		**0 280 750 061**
Air mass meter, gasoline injection	09.00-12.07		**0 280 218 060**
			0 986 280 216
Phase sensor	09.00-12.07		**0 232 101 031**
Speed sensor, ignition/injection			
Fg.no. →6Y..2..389 395	09.00-09.01		**0 261 210 147**
Fg.no. 6Y..2..389 396→	10.01-12.07		**0 261 210 199**
Knock sensor	09.00-12.07		**0 261 231 146**
Accelerator pedal module	09.00-12.07	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**

Product			
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	09.00-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-12.07		**0 265 005 692**

Fabia Schrägheck

1.0 [6Y2]			**1,0 l 37 kW AQV; ARV 4 Zyl.**
Accelerator pedal module	09.99-08.02	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	09.99-08.02		**0 265 005 252**
1.2 [5J2]			**1,2 l 44 kW BBM 3 Zyl.**
Knock sensor	12.06→		**0 261 231 146**
Accelerator pedal module	12.06→	GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	12.06→		**0 265 005 692**
1.2 [5J2]			**1,2 l 51 kW BZG 3 Zyl.**
Knock sensor	01.07→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	01.07→		**0 261 230 031**
Accelerator pedal module	01.07→	GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	01.07→		**0 265 005 692**
1.2 [6Y2]			**1,2 l 40 kW AWY 3 Zyl.**
Knock sensor	07.01-05.04		**0 261 231 146**
Accelerator pedal module	07.01-05.04	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	07.01-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-05.04		**0 265 005 692**
1.2 [6Y2]			**1,2 l 40 kW BMD 3 Zyl.**
Knock sensor	05.04-04.07		**0 261 231 146**
Accelerator pedal module	05.04-04.07	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	05.04-04.07		**0 265 005 692**
1.2 [6Y2]			**1,2 l 47 kW AZQ 3 Zyl.**
Pressure sensor, intake manifold, gasoline	02.03-11.04		**0 261 230 031**
Accelerator pedal module	02.03-11.04	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	02.03-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-11.04		**0 265 005 692**
1.2 [6Y2]			**1,2 l 47 kW BME 3 Zyl.**
Knock sensor	11.04-04.07		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	11.04-04.07		**0 261 230 031**
Accelerator pedal module	11.04-04.07	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	11.04-04.07		**0 265 005 692**
1.4 [5J2]			**1,4 l 63 kW BXW 4 Zyl.**
Knock sensor	01.07→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	01.07→		**0 261 230 095**
Accelerator pedal module	01.07→	GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	01.07→		**0 265 005 692**
1.4 [6Y2]			**1,4 l 44/50 kW AME; AQW; ATZ; AZE; AZF 4 Zyl.**
Accelerator pedal module	09.99-05.03	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	09.99-05.03		**0 265 005 252**

S

Product			
1.4 [6Y2]			**1,4 l 55 kW AUA 4 Zyl.**
Knock sensor	09.99-08.03		**0 261 231 146**
Accelerator pedal module	09.99-08.03	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	09.99-08.03		**0 265 005 252**
1.4 [6Y2]			**1,4 l 55 kW BBY 4 Zyl.**
Speed sensor, ignition/injection			
Fg.no. 6Y..3..712 485→	12.02-05.04	GS	**0 261 210 257**
Knock sensor	09.00-05.04		**0 261 231 146**
Pressure sensor, intake manifold, gasoline			
Fg.no. 6Y..4..893 313→	09.03-05.04		**0 261 230 095**
Accelerator pedal module	09.00-05.04	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	09.00-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-05.04		**0 265 005 692**
1.4 [6Y2]			**1,4 l 55 kW BKY 4 Zyl.**
Knock sensor	05.04-04.07		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.04-04.07		**0 261 230 095**
Accelerator pedal module	05.04-04.07	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	05.04-04.07		**0 265 005 692**
1.4 [6Y2]			**1,4 l 74 kW AUB 4 Zyl.**
Knock sensor	09.99-08.03		**0 261 231 146**
Accelerator pedal module	09.99-08.03	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	09.99-08.03		**0 265 005 252**
1.4 [6Y2]			**1,4 l 74 kW BBZ 4 Zyl.**
Knock sensor	09.00-04.07		**0 261 231 146**
Accelerator pedal module	09.00-04.07	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	09.00-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-04.07		**0 265 005 692**
1.4 TDI [5J2]			**1,4 l 51/59 kW BMS; BNM; BNV 4 Zyl.**
Air mass meter, diesel	01.07→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	01.07→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	01.07→		**0 265 005 692**
1.4 TDI [6Y2]			**1,4 l 51 kW BNM 3 Zyl.**
Air mass meter, diesel	10.05-04.07		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	10.05-04.07		**0 281 002 399**
Accelerator pedal module	10.05-04.07	GS,LLE	**0 281 002 377**
Duo sensor, acceleration and yaw rate, brake system	10.05-04.07		**0 265 005 692**
1.4 TDI [6Y2]			**1,4 l 55 kW AMF 3 Zyl.**
Air mass meter, diesel	05.03-04.07		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	05.03-04.07		**0 281 002 399**
Accelerator pedal module	05.03-04.07	GS,LLE	**0 281 002 377**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	05.03-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-04.07		**0 265 005 692**

Product			
1.4 TDI [6Y2]			**1,4 l 59 kW BNV 3 Zyl.**
Air mass meter, diesel	10.05-04.07		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	10.05-04.07		**0 281 002 399**
Accelerator pedal module	10.05-04.07	GS,LLE	**0 281 002 377**
Duo sensor, acceleration and yaw rate, brake system	10.05-04.07		**0 265 005 692**
1.6 [5J2]			**1,6 l 77 kW BTS 4 Zyl.**
Knock sensor	04.07→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	04.07→		**0 261 230 095**
Accelerator pedal module	04.07→	GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	04.07→		**0 265 005 692**
1.9 SDI [6Y2]			**1,9 l 47 kW ASY 4 Zyl.**
Accelerator pedal module	09.99-04.07	GS,LLE	**0 281 002 377**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	09.99-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-04.07		**0 265 005 692**
1.9 TDI [5J2]			**1,9 l 77 kW BLS; BSW 4 Zyl.**
Air mass meter, diesel	04.07→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	04.07→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	04.07→		**0 265 005 692**
1.9 TDI [6Y2]			**1,9 l 74 kW ATD 4 Zyl.**
Air mass meter, diesel			
Fg.no. →6Y..2..532 833,→6Y..2X040 209	09.99-04.02		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 6Y..2..532 834→,6Y..2X040 210→	05.02-04.07		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →6Y..4..115 000	09.99-04.04		**0 281 002 177**
Fg.no. 6Y..4..115 001→	05.04-04.07		**0 281 002 399**
Accelerator pedal module	09.99-04.07	GS,LLE	**0 281 002 377**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	09.99-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-04.07		**0 265 005 692**
1.9 TDI [6Y2]			**1,9 l 74 kW AXR 4 Zyl.**
Air mass meter, diesel	10.05-04.07		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	10.05-04.07		**0 281 002 399**
Accelerator pedal module	10.05-04.07	GS,LLE	**0 281 002 377**
1.9 TDI RS [6Y2]			**1,9 l 96 kW ASZ 4 Zyl.**
Air mass meter, diesel	06.03-10.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	06.03-10.05		**0 281 002 401**
Accelerator pedal module	06.03-10.05	GS,LLE	**0 281 002 377**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	06.03-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-10.05		**0 265 005 692**
1.9 TDI RS [6Y2]			**1,9 l 96 kW BLT 4 Zyl.**
Air mass meter, diesel	10.05-04.07		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	10.05-04.07		**0 281 002 401**
2.0 [6Y2]			**2,0 l 85 kW AZL 4 Zyl.**
Throttle valve assembly			
Fg.no. →6Y..4..095 000	07.00-03.04		**0 280 750 061**
Air mass meter, gasoline injection	07.00-04.07		**0 280 218 060**
			0 986 280 216

S

Product			
◀ Fabia Schrägheck			
Phase sensor	07.00-04.07		**0 232 101 031**
Speed sensor, ignition/injection			
Fg.no. →6Y..2..389 395	07.00-09.01		**0 261 210 147**
Fg.no. 6Y..2..389 396→	10.01-04.07		**0 261 210 199**
Knock sensor	07.00-04.07		**0 261 231 146**
Accelerator pedal module	07.00-04.07	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	07.00-04.04		**0 265 005 252**
Fg.no. 6Y..4..115 001→	05.04-04.07		**0 265 005 692**
Favorit			
135			**1,3 l 40 kW 4 Zyl.**
Speed sensor, ignition/injection	05.89-10.93		**0 261 210 064**
Temperature sensor, coolant, injection system	05.89-09.94		**0 280 130 026**
136 i.e.			**1,3 l 40 kW A01 4 Zyl.**
Speed sensor, ignition/injection	08.92-12.92		**0 261 210 064**
Temperature sensor, coolant, injection system	08.92-09.94		**0 280 130 026**
136 i.e.			**1,3 l 40/50 kW A02 4 Zyl.**
Temperature sensor, coolant, injection system	09.94-12.98		**0 280 130 026**
136 i.e.			**1,3 l 50 kW A01 4 Zyl.**
Temperature sensor, coolant, injection system	07.93-09.94		**0 280 130 026**
Felicia Fun			
1.3 [6UF]			**1,3 l 50 kW AMH 4 Zyl.**
Temperature sensor, coolant, injection system	08.96-03.01		**0 280 130 026**
1.6 [6UF]			**1,6 l 55 kW AEE 4 Zyl.**
Temperature sensor, coolant, injection system	08.96-03.01		**0 280 130 026**
1.9 D [6UF]			**1,9 l 47 kW AEF 4 Zyl.**
Temperature sensor, coolant, diesel	08.96-03.01		**0 280 130 026**
Forman			
1.3 i.e.			**1,3 l 40/50 kW 4 Zyl.**
Temperature sensor, coolant, injection system	08.92-12.95		**0 280 130 026**
Octavia			
1.4 [1U2]			**1,4 l 44 kW AMD 4 Zyl.**
Accelerator pedal module	06.99-03.01	GS,LLE	**0 280 752 214**
1.4 [1U2]			**1,4 l 55 kW AXP 4 Zyl.**
Knock sensor	08.00-01.02		**0 261 231 146**
Temperature sensor, intake air, injection system	08.00-01.02		**0 261 230 031**
Accelerator pedal module	08.00-01.02	GS,LLE	**0 280 752 214**
1.4 [1U2]			**1,4 l 55 kW BCA 4 Zyl.**
Speed sensor, ignition/injection	01.02→		**0 261 210 213**
Knock sensor	01.02→		**0 261 231 146**
Temperature sensor, intake air, injection system	01.02→		**0 261 230 031**
Accelerator pedal module	01.02→	GS,LLE	**0 280 752 214**
1.4 [1Z3]			**1,4 l 55 kW BCA 4 Zyl.**
Knock sensor	05.04→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.04→		**0 261 230 095**
1.4 [1Z3]			**1,4 l 59 kW BUD 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.06→		**0 261 230 095**
1.6 [1U2]			**1,6 l 55 kW AEE 4 Zyl.**
Knock sensor	09.96-09.04		**0 261 231 045**
Accelerator pedal module			
Fg.no. 1U.. X..134 001→	09.98-09.04	GS,LLE	**0 280 752 214**

Product			
Pedal position sensor, EMS (electronic engine management)			
Fg.no. 1U..V..033 907→1U..X..134 000	08.97-08.98	GS,LLE	**0 281 002 269**
1.6 [1U2]			**1,6 l 74 kW AEH 4 Zyl.**
Phase sensor	11.96-09.04		**0 232 101 031**
Speed sensor, ignition/injection	11.96-09.04		**0 261 210 147**
Temperature sensor, intake air, injection system			
Fg.no. →1U..V..029 000	11.96-07.97		**0 280 130 085**
Accelerator pedal module			
Fg.no. 1U.. X..134 001→	09.98-09.04	GS,LLE	**0 280 752 214**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. 1U..V..033 907→1U..X..134 000	08.97-08.98	GS,LLE	**0 281 002 269**
1.6 [1U2]			**1,6 l 74 kW AKL 4 Zyl.**
Phase sensor	08.00-05.07		**0 232 101 031**
Speed sensor, ignition/injection	08.00-05.07		**0 261 210 147**
Accelerator pedal module	08.00-05.07	GS,LLE	**0 280 752 214**
1.6 [1U2]			**1,6 l 75 kW AVU 4 Zyl.**
Phase sensor	08.00-04.02		**0 232 101 038**
Speed sensor, ignition/injection	08.00-04.02		**0 261 210 199**
Accelerator pedal module	08.00-04.02	GS,LLE	**0 280 752 214**
1.6 [1U2]			**1,6 l 75 kW BFQ 4 Zyl.**
Speed sensor, ignition/injection	08.00→		**0 261 210 199**
Knock sensor	08.00→		**0 261 231 146**
Accelerator pedal module	08.00→	GS,LLE	**0 280 752 214**
1.6 [1Z3]			**1,6 l 75 kW BGU; BSE; BSF 4 Zyl.**
Speed sensor, ignition/injection	05.04→		**0 261 210 199**
Knock sensor	05.04→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.04→		**0 261 230 031**
1.6 FSI [1Z3]			**1,6 l 85 kW BLF 4 Zyl.**
Speed sensor, ignition/injection	05.04→	AG	**0 261 210 250**
Knock sensor	05.04→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.04→		**0 261 230 095**
1.8 [1U2]			**1,8 l 92 kW AGN 4 Zyl.**
Air mass meter, gasoline injection			
Fg.no. 1U..V..028 928→	07.97-04.99		**0 280 218 002**
			0 986 280 205
Phase sensor	09.96-04.99		**0 232 101 024**
Speed sensor, ignition/injection	09.96-04.99		**0 261 210 147**
Temperature sensor, intake air, injection system	09.96-04.99		**0 280 130 085**
Accelerator pedal module			
Fg.no. 1U.. X..134 001→	09.98-04.99	GS,LLE	**0 280 752 214**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. 1U..V..033 907→1U..X..134 000	08.97-08.98	GS,LLE	**0 281 002 269**
1.8 RS [1U2]			**1,8 l 132 kW AUQ 4 Zyl.**
Throttle valve assembly	08.00-09.04		**0 280 750 036**
Air mass meter, gasoline injection	08.00-09.04		**0 280 218 063**
			0 986 280 217
Phase sensor	08.00-09.04		**0 232 101 024**
Speed sensor, ignition/injection	08.00-09.04		**0 261 210 199**
Knock sensor	08.00-09.04		**0 261 231 146**
Boost pressure sensor, gasoline			
Fg.no. →1U..3..758 379,→1U..3A016 199, →1U..38692 715	08.00-01.03		**0 281 002 177**
Fg.no. 1U..3..758 380→,1U..3A016 200→, 1U..38692 716→	02.03-09.04		**0 281 002 399**
Temperature sensor, intake air, injection system			
Fg.no. →1U..3..716 385,→1U..3A008 026, →1U..38680 305	08.00-09.02		**0 280 130 085**
Accelerator pedal module	08.00-09.04	GS,LLE	**0 280 752 214**

S

Product			
1.8 T [1U2]			**1,8 l 110 kW AGU 4 Zyl.**
Air mass meter, gasoline injection	03.98-09.04		**0 280 217 117**
			0 986 280 201
Phase sensor	03.98-09.04		**0 232 101 024**
Speed sensor, ignition/injection	03.98-09.04		**0 261 210 147**
Boost pressure sensor, gasoline			
Fg.no. →1U..3..758 379,→1U..3A016 199, →1U..38692 715	03.98-01.03		**0 281 002 177**
Fg.no. 1U..3..758 380→,1U..3A016 200→, 1U..38692 716→	02.03-09.04		**0 281 002 399**
Temperature sensor, intake air, injection system			
Fg.no. →1U..3..716 385,→1U..3A008 026, →1U..38680 305	03.98-09.02		**0 280 130 085**
Accelerator pedal module			
Fg.no. 1U.. X..134 001→	09.98-09.04	GS,LLE	**0 280 752 214**
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →1U..X..134 000	03.98-08.98	GS,LLE	**0 281 002 269**
1.8 T [1U2]			**1,8 l 110 kW ARX 4 Zyl.**
Throttle valve assembly	08.00-01.06		**0 280 750 036**
Air mass meter, gasoline injection	08.00-01.06		**0 280 218 063**
			0 986 280 217
Phase sensor	08.00-01.06		**0 232 101 024**
Speed sensor, ignition/injection	08.00-01.06		**0 261 210 147**
Knock sensor	08.00-01.06		**0 261 231 146**
Boost pressure sensor, gasoline			
Fg.no. →1U..3..758 379,→1U..3A016 199, →1U..38692 715	08.00-01.03		**0 281 002 177**
Fg.no. 1U..3..758 380→,1U..3A016 200→, 1U..38692 716→	02.03-01.06		**0 281 002 399**
Temperature sensor, intake air, injection system			
Fg.no. →1U..3..716 385,→1U..3A008 026, →1U..38680 305	08.00-09.02		**0 280 130 085**
Accelerator pedal module	08.00-01.06	GS,LLE	**0 280 752 214**
1.8 T [1U2]			**1,8 l 110 kW ARZ 4 Zyl.**
Throttle valve assembly	01.00-07.00		**0 280 750 036**
Air mass meter, gasoline injection	01.00-07.00		**0 280 218 032**
			0 986 280 210
Phase sensor	01.00-07.00		**0 232 101 024**
Speed sensor, ignition/injection	01.00-07.00		**0 261 210 147**
Temperature sensor, intake air, injection system	01.00-07.00		**0 280 130 085**
Accelerator pedal module	01.00-07.00	GS,LLE	**0 280 752 214**
1.8 T [1U2]			**1,8 l 110 kW AUM 4 Zyl.**
Throttle valve assembly	08.00→		**0 280 750 036**
Air mass meter, gasoline injection	08.00→		**0 280 218 063**
			0 986 280 217
Phase sensor	08.00→		**0 232 101 024**
Speed sensor, ignition/injection	08.00→		**0 261 210 147**
Knock sensor	08.00→		**0 261 231 146**
Boost pressure sensor, gasoline			
Fg.no. →1U..3..758 379,→1U..3A016 199, →1U..38692 715	08.00-01.03		**0 281 002 177**
Fg.no. 1U..3..758 380→,1U..3A016 200→, 1U..38692 716→	02.03→		**0 281 002 399**
Temperature sensor, intake air, injection system			
Fg.no. →1U..3..716 385,→1U..3A008 026, →1U..38680 305	08.00-09.02		**0 280 130 085**
Accelerator pedal module	08.00→	GS,LLE	**0 280 752 214**
1.8 T 4x4 [1U2]			**1,8 l 110 kW AGU 4 Zyl.**
Air mass meter, gasoline injection	08.00→		**0 280 217 117**
			0 986 280 201
Phase sensor	08.00→		**0 232 101 024**

Product			
Speed sensor, ignition/injection	08.00→		**0 261 210 147**
Boost pressure sensor, gasoline			
Fg.no. →1U..3..758 379,→1U..3A016 199, →1U..38692 715	08.00-01.03		**0 281 002 177**
Fg.no. 1U..3..758 380→,1U..3A016 200→, 1U..38692 716→	02.03→		**0 281 002 399**
Temperature sensor, intake air, injection system			
Fg.no. →1U..3..716 385,→1U..3A008 026, →1U..38680 305	08.00-09.02		**0 280 130 085**
Accelerator pedal module	08.00→	GS,LLE	**0 280 752 214**
1.8 T 4x4 [1U2]			**1,8 l 110 kW ARX 4 Zyl.**
Throttle valve assembly	08.00-01.06		**0 280 750 036**
Air mass meter, gasoline injection	08.00-01.06		**0 280 218 063**
			0 986 280 217
Phase sensor	08.00-01.06		**0 232 101 024**
Speed sensor, ignition/injection	08.00-01.06		**0 261 210 147**
Knock sensor	08.00-01.06		**0 261 231 146**
Boost pressure sensor, gasoline			
Fg.no. →1U..3..758 379,→1U..3A016 199, →1U..38692 715	08.00-01.03		**0 281 002 177**
Fg.no. 1U..3..758 380→,1U..3A016 200→, 1U..38692 716→	02.03-01.06		**0 281 002 399**
Temperature sensor, intake air, injection system			
Fg.no. →1U..3..716 385,→1U..3A008 026, →1U..38680 305	08.00-09.02		**0 280 130 085**
Accelerator pedal module	08.00-01.06	GS,LLE	**0 280 752 214**
1.8 T 4x4 [1U2]			**1,8 l 110 kW ARZ 4 Zyl.**
Throttle valve assembly	01.00-07.00		**0 280 750 036**
Air mass meter, gasoline injection	01.00-07.00		**0 280 218 032**
			0 986 280 210
Phase sensor	01.00-07.00		**0 232 101 024**
Speed sensor, ignition/injection	01.00-07.00		**0 261 210 147**
Temperature sensor, intake air, injection system	01.00-07.00		**0 280 130 085**
Accelerator pedal module	01.00-07.00	GS,LLE	**0 280 752 214**
1.8 T 4x4 [1U2]			**1,8 l 110 kW AUM 4 Zyl.**
Throttle valve assembly	08.00→		**0 280 750 036**
Air mass meter, gasoline injection	08.00→		**0 280 218 063**
			0 986 280 217
Phase sensor	08.00→		**0 232 101 024**
Speed sensor, ignition/injection	08.00→		**0 261 210 147**
Knock sensor	08.00→		**0 261 231 146**
Boost pressure sensor, gasoline			
Fg.no. →1U..3..758 379,→1U..3A016 199, →1U..38692 715	08.00-01.03		**0 281 002 177**
Fg.no. 1U..3..758 380→,1U..3A016 200→, 1U..38692 716→	02.03→		**0 281 002 399**
Temperature sensor, intake air, injection system			
Fg.no. →1U..3..716 385,→1U..3A008 026, →1U..38680 305	08.00-09.02		**0 280 130 085**
Accelerator pedal module	08.00→	GS,LLE	**0 280 752 214**
1.9 TDI [1U2]			**1,9 l 66 kW AGR 4 Zyl.**
Air mass meter, diesel			
Fg.no. 1U..W..134 001→	08.98→		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel			
Fg.no. →1U..3..768 637,→1U..3A016 277, →1U..38696 292	09.96-02.03		**0 281 002 177**
Fg.no. 1U..3..768 638→,1U..3A016 278→, 1U..38696 293→	03.03→		**0 281 002 399**

S

Product			
◀ Octavia			
1.9 TDI [1U2]			**1,9 l 66 kW ALH 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1U..3..836 957,→1U..3A016 708, →1U..38712 468	08.00-07.03		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 1U..3..836 958→,1U..3A016 709→, 1U..38712 469→	08.03→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1U..3..768 637,→1U..3A016 277, →1U..38696 292	08.00-02.03		**0 281 002 177**
Fg.no. 1U..3..768 638→,1U..3A016 278→, 1U..38696 293→	03.03→		**0 281 002 399**
1.9 TDI [1U2]			**1,9 l 74 kW ATD 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1U..3..666 021,→1U..38665 263	08.00-04.02		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 1U..3..666 022→,1U..38665 264→	05.02-09.04		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1U..3..768 637,→1U..3A016 277, →1U..38696 292	08.00-02.03		**0 281 002 177**
Fg.no. 1U..3..768 638→,1U..3A016 278→, 1U..38696 293→	03.03-09.04		**0 281 002 399**
1.9 TDI [1U2]			**1,9 l 74 kW AXR 4 Zyl.**
Air mass meter, diesel	10.05→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	10.05→		**0 281 002 399**
1.9 TDI [1U2]			**1,9 l 81 kW AHF 4 Zyl.**
Air mass meter, diesel			
Fg.no. 1U..W..134 001→	08.98-01.06		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel			
Fg.no. →1U..3..768 637,→1U..3A016 277, →1U..38696 292	05.97-02.03		**0 281 002 177**
Fg.no. 1U..3..768 638→,1U..3A016 278→, 1U..38696 293→	03.03-01.06		**0 281 002 399**
1.9 TDI [1U2]			**1,9 l 81 kW ASV 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1U..3..836 957,→1U..3A016 708, →1U..38712 468	08.00-07.03		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 1U..3..836 958→,1U..3A016 709→, 1U..38712 469→	08.03-01.06		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1U..3..768 637,→1U..3A016 277, →1U..38696 292	08.00-02.03		**0 281 002 177**
Fg.no. 1U..3..768 638→,1U..3A016 278→, 1U..38696 293→	03.03-01.06		**0 281 002 399**
1.9 TDI [1U2]			**1,9 l 96 kW ASZ 4 Zyl.**
Air mass meter, diesel	01.03-09.04		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	01.03-09.04		**0 281 002 401**
1.9 TDI [1Z3]			**1,9 l 77 kW BJB; BKC; BLS; BXE 4 Zyl.**
Air mass meter, diesel	05.04→		**0 281 002 531**
			0 986 284 009
Pressure sensor, intake manifold, diesel	05.04→		**0 281 002 399**
1.9 TDI 4x4 [1Z3]			**1,9 l 77 kW BKC; BLS; BXE 4 Zyl.**
Air mass meter, diesel	11.04→		**0 281 002 531**
			0 986 284 009
Pressure sensor, intake manifold, diesel	11.04→		**0 281 002 399**

Product			
2.0 [1U2]			**2,0 l 85 kW APK; AQY 4 Zyl.**
Air mass meter, gasoline injection	06.99-05.07		**0 280 218 002**
			0 986 280 205
Phase sensor	06.99-05.07		**0 232 101 031**
Speed sensor, ignition/injection	06.99-05.07		**0 261 210 147**
Knock sensor	06.99-05.07		**0 261 231 146**
Accelerator pedal module	06.99-05.07	GS,LLE	**0 280 752 214**
2.0 [1U2]			**2,0 l 85 kW AZH 4 Zyl.**
Throttle valve assembly	08.00-09.04		**0 280 750 061**
Air mass meter, gasoline injection	08.00-09.04		**0 280 218 002**
			0 986 280 205
Phase sensor	08.00-09.04		**0 232 101 031**
Speed sensor, ignition/injection	08.00-09.04		**0 261 210 147**
Knock sensor	08.00-09.04		**0 261 231 146**
Accelerator pedal module	08.00-09.04	GS,LLE	**0 280 752 214**
2.0 [1U2]			**2,0 l 85 kW AZJ 4 Zyl.**
Throttle valve assembly	03.02-09.04		**0 280 750 061**
Air mass meter, gasoline injection	03.02-09.04		**0 280 218 060**
			0 986 280 216
Phase sensor	03.02-09.04		**0 232 101 031**
Knock sensor	03.02-09.04		**0 261 231 146**
Accelerator pedal module	03.02-09.04	GS,LLE	**0 280 752 214**
2.0 FSI [1Z3]			**2,0 l 110 kW BLR; BLY; BVY; BVZ 4 Zyl.**
Knock sensor	11.04→	OHL	**0 261 231 146**
Pressure sensor, intake manifold, gasoline	11.04→		**0 261 230 031**
2.0 FSI 4x4 [1Z3]			**2,0 l 110 kW BLX; BVX 4 Zyl.**
Knock sensor	12.04→	OHL	**0 261 231 146**
Pressure sensor, intake manifold, gasoline	12.04→		**0 261 230 031**
2.0 i [1U2]			**2,0 l 85 kW AEG 4 Zyl.**
Air mass meter, gasoline injection	08.00-01.05		**0 280 218 002**
			0 986 280 205
Phase sensor	08.00-01.05		**0 232 101 031**
Speed sensor, ignition/injection	08.00-01.05		**0 261 210 147**
Knock sensor	08.00-01.05		**0 261 231 146**
Accelerator pedal module	08.00-01.05	GS,LLE	**0 280 752 214**
2.0 RS [1Z3]			**2,0 l 147 kW BWA 4 Zyl.**
Speed sensor, ignition/injection	10.05→		**0 261 210 199**
Boost pressure sensor, gasoline	10.05→		**0 261 230 073**
2.0 TDI [1Z3]			**2,0 l 100/103 kW AZV; BKD; BMM 4 Zyl.**
Air mass meter, diesel	05.04→		**0 281 002 461**
			0 986 284 007
Pressure sensor, intake manifold, diesel	05.04→		**0 281 002 401**
2.0 4x4 [1U2]			**2,0 l 85 kW AZH 4 Zyl.**
Throttle valve assembly	08.00-09.04		**0 280 750 061**
Air mass meter, gasoline injection	08.00-09.04		**0 280 218 002**
			0 986 280 205
Phase sensor	08.00-09.04		**0 232 101 031**
Speed sensor, ignition/injection	08.00-09.04		**0 261 210 147**
Knock sensor	08.00-09.04		**0 261 231 146**
Accelerator pedal module	08.00-09.04	GS,LLE	**0 280 752 214**
2.0 4x4 [1U2]			**2,0 l 85 kW AZJ 4 Zyl.**
Throttle valve assembly	03.02-09.04		**0 280 750 061**
Air mass meter, gasoline injection	03.02-09.04		**0 280 218 060**
			0 986 280 216
Phase sensor	03.02-09.04		**0 232 101 031**
Knock sensor	03.02-09.04		**0 261 231 146**
Accelerator pedal module	03.02-09.04	GS,LLE	**0 280 752 214**

S

Product

Octavia Combi

1.4 [1U5]			**1,4 l 55 kW AXP 4 Zyl.**
Knock sensor	08.00-01.02		**0 261 231 146**
Temperature sensor, intake air, injection system	08.00-01.02		**0 261 230 031**
Accelerator pedal module	08.00-01.02	GS,LLE	**0 280 752 214**
1.4 [1U5]			**1,4 l 55 kW BCA 4 Zyl.**
Speed sensor, ignition/injection	01.02→		**0 261 210 213**
Knock sensor	01.02→		**0 261 231 146**
Temperature sensor, intake air, injection system	01.02→		**0 261 230 031**
Accelerator pedal module	01.02→	GS,LLE	**0 280 752 214**
1.4 [1Z5]			**1,4 l 55 kW BCA 4 Zyl.**
Knock sensor	05.04→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.04→		**0 261 230 095**
1.4 [1Z5]			**1,4 l 59 kW BUD 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.06→		**0 261 230 095**
1.6 [1U5]			**1,6 l 55 kW AEE 4 Zyl.**
Knock sensor	08.00-09.04		**0 261 231 045**
Accelerator pedal module	08.00-09.04	GS,LLE	**0 280 752 214**
1.6 [1U5]			**1,6 l 74 kW AEH; AKL 4 Zyl.**
Phase sensor	02.97-09.04		**0 232 101 031**
Speed sensor, ignition/injection	02.97-09.04		**0 261 210 147**
Temperature sensor, intake air, injection system Fg.no. →1U..V..029 000	02.97-07.97		**0 280 130 085**
Accelerator pedal module Fg.no. 1U.. X..134 001→	09.98-09.04	GS,LLE	**0 280 752 214**
Pedal position sensor, EMS (electronic engine management) Fg.no. 1U..V..033 907→1U..X..134 000	08.97-08.98	GS,LLE	**0 281 002 269**
1.6 [1U5]			**1,6 l 75 kW AVU 4 Zyl.**
Phase sensor	08.00-04.02		**0 232 101 038**
Speed sensor, ignition/injection	08.00-04.02		**0 261 210 199**
Accelerator pedal module	08.00-04.02	GS,LLE	**0 280 752 214**
1.6 [1U5]			**1,6 l 75 kW BFQ 4 Zyl.**
Speed sensor, ignition/injection	08.00→		**0 261 210 199**
Knock sensor	08.00→		**0 261 231 146**
Accelerator pedal module	08.00→	GS,LLE	**0 280 752 214**
1.6 [1Z5]			**1,6 l 75 kW BGU; BSE; BSF 4 Zyl.**
Speed sensor, ignition/injection	05.04→		**0 261 210 199**
Knock sensor	05.04→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.04→		**0 261 230 031**
1.6 FSI [1Z5]			**1,6 l 85 kW BLF 4 Zyl.**
Speed sensor, ignition/injection	05.04→	AG	**0 261 210 250**
Knock sensor	05.04→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.04→		**0 261 230 095**
1.8 [1U5]			**1,8 l 92 kW AGN 4 Zyl.**
Air mass meter, gasoline injection Fg.no. 1U..V..028 928→	07.97-04.99		**0 280 218 002**
			0 986 280 205
Phase sensor	10.96-04.99		**0 232 101 024**
Speed sensor, ignition/injection	10.96-04.99		**0 261 210 147**
Temperature sensor, intake air, injection system	10.96-04.99		**0 280 130 085**
Accelerator pedal module Fg.no. 1U.. X..134 001→	09.98-04.99	GS,LLE	**0 280 752 214**
Pedal position sensor, EMS (electronic engine management) Fg.no. 1U..V..033 907→1U..X..134 000	08.97-08.98	GS,LLE	**0 281 002 269**
1.8 RS [1U5]			**1,8 l 132 kW AUQ 4 Zyl.**
Throttle valve assembly	01.03-01.06		**0 280 750 036**
Air mass meter, gasoline injection	01.03-01.06		**0 280 218 063**
			0 986 280 217
Speed sensor, ignition/injection	01.03-01.06		**0 261 210 199**
Knock sensor	01.03-01.06		**0 261 231 146**
Boost pressure sensor, gasoline Fg.no. →1U..3..758 379,→1U..3A016 199, →1U..38692 715	01.03-01.03		**0 281 002 177**
Fg.no. 1U..3..758 380→,1U..3A016 200→, 1U..38692 716→	02.03-01.06		**0 281 002 399**
Accelerator pedal module	01.03-01.06	GS,LLE	**0 280 752 214**
1.8 T [1U5]			**1,8 l 110 kW AGU 4 Zyl.**
Air mass meter, gasoline injection	03.98→		**0 280 217 117**
			0 986 280 201
Phase sensor	03.98→		**0 232 101 024**
Speed sensor, ignition/injection	03.98→		**0 261 210 147**
Boost pressure sensor, gasoline Fg.no. →1U..3..758 379,→1U..3A016 199, →1U..38692 715	03.98-01.03		**0 281 002 177**
Fg.no. 1U..3..758 380→,1U..3A016 200→, 1U..38692 716→	02.03→		**0 281 002 399**
Temperature sensor, intake air, injection system Fg.no. →1U..3..716 385,→1U..3A008 026, →1U..38680 305	03.98-09.02		**0 280 130 085**
Accelerator pedal module Fg.no. 1U.. X..134 001→	09.98→	GS,LLE	**0 280 752 214**
Pedal position sensor, EMS (electronic engine management) Fg.no. →1U..X..134 000	03.98-08.98	GS,LLE	**0 281 002 269**
1.8 T [1U5]			**1,8 l 110 kW ARX 4 Zyl.**
Throttle valve assembly	08.00-01.06		**0 280 750 036**
Air mass meter, gasoline injection	08.00-01.06		**0 280 218 063**
			0 986 280 217
Phase sensor	08.00-01.06		**0 232 101 024**
Speed sensor, ignition/injection	08.00-01.06		**0 261 210 147**
Knock sensor	08.00-01.06		**0 261 231 146**
Boost pressure sensor, gasoline Fg.no. →1U..3..758 379,→1U..3A016 199, →1U..38692 715	08.00-01.03		**0 281 002 177**
Fg.no. 1U..3..758 380→,1U..3A016 200→, 1U..38692 716→	02.03-01.06		**0 281 002 399**
Temperature sensor, intake air, injection system Fg.no. →1U..3..716 385,→1U..3A008 026, →1U..38680 305	08.00-09.02		**0 280 130 085**
Accelerator pedal module	08.00-01.06	GS,LLE	**0 280 752 214**
1.8 T [1U5]			**1,8 l 110 kW ARZ 4 Zyl.**
Throttle valve assembly	01.00-07.00		**0 280 750 036**
Air mass meter, gasoline injection	01.00-07.00		**0 280 218 032**
			0 986 280 210
Phase sensor	01.00-07.00		**0 232 101 024**
Speed sensor, ignition/injection	01.00-07.00		**0 261 210 147**
Temperature sensor, intake air, injection system	01.00-07.00		**0 280 130 085**
Accelerator pedal module	01.00-07.00	GS,LLE	**0 280 752 214**
1.8 T [1U5]			**1,8 l 110 kW AUM 4 Zyl.**
Throttle valve assembly	08.00→		**0 280 750 036**
Air mass meter, gasoline injection	08.00→		**0 280 218 063**
			0 986 280 217
Phase sensor	08.00→		**0 232 101 024**
Speed sensor, ignition/injection	08.00→		**0 261 210 147**
Knock sensor	08.00→		**0 261 231 146**
Boost pressure sensor, gasoline Fg.no. →1U..3..758 379,→1U..3A016 199, →1U..38692 715	08.00-01.03		**0 281 002 177**
Fg.no. 1U..3..758 380→,1U..3A016 200→, 1U..38692 716→	02.03→		**0 281 002 399**

S

Product			
◀ Octavia Combi			
Temperature sensor, intake air, injection system			
Fg.no. →1U..3..716 385,→1U..3A008 026, →1U..38680 305	08.00-09.02		**0 280 130 085**
Accelerator pedal module	08.00→	GS,LLE	**0 280 752 214**
1.8 T 4x4 [1U5]			**1,8 l 110 kW AGU 4 Zyl.**
Air mass meter, gasoline injection	08.00→		**0 280 217 117**
			0 986 280 201
Phase sensor	08.00→		**0 232 101 024**
Speed sensor, ignition/injection	08.00→		**0 261 210 147**
Boost pressure sensor, gasoline			
Fg.no. →1U..3..758 379,→1U..3A016 199, →1U..38692 715	08.00-01.03		**0 281 002 177**
Fg.no. 1U..3..758 380→,1U..3A016 200→, 1U..38692 716→	02.03→		**0 281 002 399**
Temperature sensor, intake air, injection system			
Fg.no. →1U..3..716 385,→1U..3A008 026, →1U..38680 305	08.00-09.02		**0 280 130 085**
Accelerator pedal module	08.00→	GS,LLE	**0 280 752 214**
1.8 T 4x4 [1U5]			**1,8 l 110 kW ARX 4 Zyl.**
Throttle valve assembly	08.00-01.06		**0 280 750 036**
Air mass meter, gasoline injection	08.00-01.06		**0 280 218 063**
			0 986 280 217
Phase sensor	08.00-01.06		**0 232 101 024**
Speed sensor, ignition/injection	08.00-01.06		**0 261 210 147**
Knock sensor	08.00-01.06		**0 261 231 146**
Boost pressure sensor, gasoline			
Fg.no. →1U..3..758 379,→1U..3A016 199, →1U..38692 715	08.00-01.03		**0 281 002 177**
Fg.no. 1U..3..758 380→,1U..3A016 200→, 1U..38692 716→	02.03-01.06		**0 281 002 399**
Temperature sensor, intake air, injection system			
Fg.no. →1U..3..716 385,→1U..3A008 026, →1U..38680 305	08.00-09.02		**0 280 130 085**
Accelerator pedal module	08.00-01.06	GS,LLE	**0 280 752 214**
1.8 T 4x4 [1U5]			**1,8 l 110 kW ARZ 4 Zyl.**
Throttle valve assembly	01.00-07.00		**0 280 750 036**
Air mass meter, gasoline injection	01.00-07.00		**0 280 218 032**
			0 986 280 210
Phase sensor	01.00-07.00		**0 232 101 024**
Speed sensor, ignition/injection	01.00-07.00		**0 261 210 147**
Temperature sensor, intake air, injection system	01.00-07.00		**0 280 130 085**
Accelerator pedal module	01.00-07.00	GS,LLE	**0 280 752 214**
1.8 T 4x4 [1U5]			**1,8 l 110 kW AUM 4 Zyl.**
Throttle valve assembly	08.00→		**0 280 750 036**
Air mass meter, gasoline injection	08.00→		**0 280 218 063**
			0 986 280 217
Phase sensor	08.00→		**0 232 101 024**
Speed sensor, ignition/injection	08.00→		**0 261 210 147**
Knock sensor	08.00→		**0 261 231 146**
Boost pressure sensor, gasoline			
Fg.no. →1U..3..758 379,→1U..3A016 199, →1U..38692 715	08.00-01.03		**0 281 002 177**
Fg.no. 1U..3..758 380→,1U..3A016 200→, 1U..38692 716→	02.03→		**0 281 002 399**
Temperature sensor, intake air, injection system			
Fg.no. →1U..3..716 385,→1U..3A008 026, →1U..38680 305	08.00-09.02		**0 280 130 085**
Accelerator pedal module	08.00→	GS,LLE	**0 280 752 214**
1.9 TDI [1U5]			**1,9 l 66 kW AGR 4 Zyl.**
Air mass meter, diesel	08.00→		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202

Product			
Boost pressure sensor, Diesel			
Fg.no. →1U..3..768 637,→1U..3A016 277, →1U..38696 292	08.00-02.03		**0 281 002 177**
Fg.no. 1U..3..768 638→,1U..3A016 278→, 1U..38696 293→	03.03→		**0 281 002 399**
1.9 TDI [1U5]			**1,9 l 66 kW ALH 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1U..3..836 957,→1U..3A016 708, →1U..38712 468	08.00-07.03		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 1U..3..836 958→,1U..3A016 709→, 1U..38712 469→	08.03→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1U..3..768 637,→1U..3A016 277, →1U..38696 292	08.00-02.03		**0 281 002 177**
Fg.no. 1U..3..768 638→,1U..3A016 278→, 1U..38696 293→	03.03→		**0 281 002 399**
1.9 TDI [1U5]			**1,9 l 74 kW ATD 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1U..3..666 021,→1U..38665 263	08.00-04.02		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 1U..3..666 022→,1U..38665 264→	05.02-09.04		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1U..3..768 637,→1U..3A016 277, →1U..38696 292	08.00-02.03		**0 281 002 177**
Fg.no. 1U..3..768 638→,1U..3A016 278→, 1U..38696 293→	03.03-09.04		**0 281 002 399**
1.9 TDI [1U5]			**1,9 l 74 kW AXR 4 Zyl.**
Air mass meter, diesel	10.05→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	10.05→		**0 281 002 399**
1.9 TDI [1U5]			**1,9 l 81 kW AHF 4 Zyl.**
Air mass meter, diesel			
Fg.no. 1U..W..134 001→	08.98-01.06		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel			
Fg.no. →1U..3..768 637,→1U..3A016 277, →1U..38696 292	08.97-02.03		**0 281 002 177**
Fg.no. 1U..3..768 638→,1U..3A016 278→, 1U..38696 293→	03.03-01.06		**0 281 002 399**
1.9 TDI [1U5]			**1,9 l 81 kW ASV 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1U..3..836 957,→1U..3A016 708, →1U..38712 468	08.00-07.03		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 1U..3..836 958→,1U..3A016 709→, 1U..38712 469→	08.03-01.06		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1U..3..768 637,→1U..3A016 277, →1U..38696 292	08.00-02.03		**0 281 002 177**
Fg.no. 1U..3..768 638→,1U..3A016 278→, 1U..38696 293→	03.03-01.06		**0 281 002 399**
1.9 TDI [1U5]			**1,9 l 96 kW ASZ 4 Zyl.**
Air mass meter, diesel	01.03-09.04		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	01.03-09.04		**0 281 002 401**
1.9 TDI [1Z5]			**1,9 l 77 kW BJB; BKC; BLS; BXE 4 Zyl.**
Air mass meter, diesel	05.04→		**0 281 002 531**
			0 986 284 009
Pressure sensor, intake manifold, diesel	05.04→		**0 281 002 399**

S

Product			
1.9 TDI 4x4 [1U5]			**1,9 l 66 kW AGR 4 Zyl.**
Air mass meter, diesel	08.00→		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel			
Fg.no. →1U..3..768 637,→1U..3A016 277, →1U..38696 292	08.00-02.03		**0 281 002 177**
Fg.no. 1U..3..768 638→,1U..3A016 278→, 1U..38696 293→	03.03→		**0 281 002 399**
1.9 TDI 4x4 [1U5]			**1,9 l 74 kW ATD 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1U..3..666 021,→1U..38665 263	08.00-04.02		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 1U..3..666 022→,1U..38665 264→	05.02-01.06		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1U..3..768 637,→1U..3A016 277, →1U..38696 292	08.00-02.03		**0 281 002 177**
Fg.no. 1U..3..768 638→,1U..3A016 278→, 1U..38696 293→	03.03-01.06		**0 281 002 399**
1.9 TDI 4x4 [1Z5]			**1,9 l 77 kW BKC 4 Zyl.**
Air mass meter, diesel	11.04→		**0 281 002 531**
			0 986 284 009
Speed sensor, diesel	11.04→	TW	**0 261 210 233**
Pressure sensor, intake manifold, diesel	11.04→		**0 281 002 399**
1.9 TDI 4x4 [1Z5]			**1,9 l 77 kW BLS 4 Zyl.**
Air mass meter, diesel	05.06→		**0 281 002 531**
			0 986 284 009
Pressure sensor, intake manifold, diesel	05.06→		**0 281 002 399**
1.9 TDI 4x4 [1Z5]			**1,9 l 77 kW BXE 4 Zyl.**
Air mass meter, diesel	03.06→		**0 281 002 531**
			0 986 284 009
Speed sensor, diesel	03.06→	TW	**0 261 210 233**
Pressure sensor, intake manifold, diesel	03.06→		**0 281 002 399**
2.0 [1U5]			**2,0 l 85 kW AEG; APK; AQY 4 Zyl.**
Air mass meter, gasoline injection	08.00-01.05		**0 280 218 002**
			0 986 280 205
Phase sensor	08.00-01.05		**0 232 101 031**
Speed sensor, ignition/injection	08.00-01.05		**0 261 210 147**
Knock sensor	08.00-01.05		**0 261 231 146**
Accelerator pedal module	08.00-01.05	GS,LLE	**0 280 752 214**
2.0 [1U5]			**2,0 l 85 kW AZH 4 Zyl.**
Throttle valve assembly	08.00-09.04		**0 280 750 061**
Air mass meter, gasoline injection	08.00-09.04		**0 280 218 002**
			0 986 280 205
Phase sensor	08.00-09.04		**0 232 101 031**
Speed sensor, ignition/injection	08.00-09.04		**0 261 210 147**
Knock sensor	08.00-09.04		**0 261 231 146**
Accelerator pedal module	08.00-09.04	GS,LLE	**0 280 752 214**
2.0 [1U5]			**2,0 l 85 kW AZJ 4 Zyl.**
Throttle valve assembly	03.02-01.06		**0 280 750 061**
Air mass meter, gasoline injection	03.02-01.06		**0 280 218 060**
			0 986 280 216
Phase sensor	03.02-01.06		**0 232 101 031**
Speed sensor, ignition/injection	03.02-01.06		**0 261 210 199**
Knock sensor	03.02-01.06		**0 261 231 146**
Accelerator pedal module	03.02-01.06	GS,LLE	**0 280 752 214**
2.0 FSI [1Z5]			**2,0 l 110 kW BLR; BLY; BVY; BVZ 4 Zyl.**
Knock sensor	11.04→	OHL	**0 261 231 146**
Pressure sensor, intake manifold, gasoline	11.04→		**0 261 230 031**

Product			
2.0 FSI 4x4 [1Z5]			**2,0 l 110 kW BLX; BVX 4 Zyl.**
Knock sensor	11.04→	OHL	**0 261 231 146**
Pressure sensor, intake manifold, gasoline	11.04→		**0 261 230 031**
2.0 RS [1Z5]			**2,0 l 147 kW BWA 4 Zyl.**
Speed sensor, ignition/injection	10.05→		**0 261 210 199**
Boost pressure sensor, gasoline	10.05→		**0 261 230 073**
2.0 TDI [1Z5]			**2,0 l 100/103 kW AZV; BKD; BMM 4 Zyl.**
Air mass meter, diesel	05.04→		**0 281 002 461**
			0 986 284 007
Pressure sensor, intake manifold, diesel	05.04→		**0 281 002 401**
2.0 TDI 4x4 [1Z5]			**2,0 l 103 kW BMM 4 Zyl.**
Air mass meter, diesel	12.05→		**0 281 002 461**
			0 986 284 007
Pressure sensor, intake manifold, diesel	12.05→		**0 281 002 401**
2.0 4x4 [1U5]			**2,0 l 85 kW AEG; APK; AQY 4 Zyl.**
Air mass meter, gasoline injection	08.00-01.05		**0 280 218 002**
			0 986 280 205
Phase sensor	08.00-01.05		**0 232 101 031**
Speed sensor, ignition/injection	08.00-01.05		**0 261 210 147**
Knock sensor	08.00-01.05		**0 261 231 146**
Accelerator pedal module	08.00-01.05	GS,LLE	**0 280 752 214**
2.0 4x4 [1U5]			**2,0 l 85 kW AZH 4 Zyl.**
Throttle valve assembly	08.00-09.04		**0 280 750 061**
Air mass meter, gasoline injection	08.00-09.04		**0 280 218 002**
			0 986 280 205
Phase sensor	08.00-09.04		**0 232 101 031**
Speed sensor, ignition/injection	08.00-09.04		**0 261 210 147**
Knock sensor	08.00-09.04		**0 261 231 146**
Accelerator pedal module	08.00-09.04	GS,LLE	**0 280 752 214**
2.0 4x4 [1U5]			**2,0 l 85 kW AZJ 4 Zyl.**
Throttle valve assembly	03.02-01.06		**0 280 750 061**
Air mass meter, gasoline injection	03.02-01.06		**0 280 218 060**
			0 986 280 216
Phase sensor	03.02-01.06		**0 232 101 031**
Knock sensor	03.02-01.06		**0 261 231 146**
Accelerator pedal module	03.02-01.06	GS,LLE	**0 280 752 214**

Pick-Up

135 i.e.			**1,3 l 40 kW 4 Zyl.**
Temperature sensor, coolant, injection system	07.93-12.97		**0 280 130 026**

Roomster

1.2 [5J7]			**1,2 l 47 kW BME 3 Zyl.**
Knock sensor	05.06-01.07		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.06-01.07		**0 261 230 031**
Accelerator pedal module	05.06-01.07	GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	05.06-01.07		**0 265 005 692**
1.2 [5J7]			**1,2 l 51 kW BZG 3 Zyl.**
Pressure sensor, intake manifold, gasoline	01.07→		**0 261 230 031**
Accelerator pedal module	01.07→	GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	01.07→		**0 265 005 692**
1.4 [5J7]			**1,4 l 63 kW BXW 4 Zyl.**
Knock sensor	05.06→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.06→		**0 261 230 095**
Accelerator pedal module	05.06→	GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	05.06→		**0 265 005 692**

S

Product

◀ Roomster

1.4 TDI [5J7]			**1,4 l 51/59 kW BMS; BNM; BNV 3 Zyl.**
Air mass meter, diesel	05.06→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	05.06→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	05.06→		**0 265 005 692**
1.6 [5J7]			**1,6 l 77 kW BTS 4 Zyl.**
Knock sensor	05.06→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.06→		**0 261 230 095**
Accelerator pedal module	05.06→	GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	05.06→		**0 265 005 692**
1.9 TDI [5J7]			**1,9 l 74/77 kW AXR; BLS; BSW 4 Zyl.**
Air mass meter, diesel	03.06→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	03.06→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	03.06→		**0 265 005 692**

Superb

1.8 T [3U4]			**1,8 l 110 kW AWT 4 Zyl.**
Throttle valve assembly	12.01→		**0 280 750 009**
Air mass meter, gasoline injection	12.01→		**0 280 218 100**
			0 986 280 223
Phase sensor	12.01→		**0 232 101 024**
Speed sensor, ignition/injection	12.01→		**0 281 002 222**
Boost pressure sensor, gasoline			
Fg.no. →3U..3..033 808	12.01-12.02		**0 281 002 177**
Fg.no. 3U..3..033 809→	01.03→		**0 261 230 073**
Temperature sensor, intake air, injection system			
Fg.no. →3U..3..026 512	12.01-08.02		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	12.01→		**0 265 005 252**
1.9 TDI [3U4]			**1,9 l 74 kW AVB 4 Zyl.**
Air mass meter, diesel	02.02-10.05		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →3U..3..023 228	02.02-06.02		**0 281 002 177**
Fg.no. 3U..3..023 229→	07.02-10.05		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	02.02-10.05		**0 265 005 252**
1.9 TDI [3U4]			**1,9 l 77/85 kW BPZ; BSV 4 Zyl.**
Air mass meter, diesel	10.05→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	10.05→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	10.05→		**0 265 005 252**
1.9 TDI [3U4]			**1,9 l 96 kW AVF; AWX 4 Zyl.**
Air mass meter, diesel	12.01→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	12.01→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	12.01→		**0 265 005 252**
2.0 [3U4]			**2,0 l 85 kW AZM 4 Zyl.**
Phase sensor	12.01→		**0 232 101 031**
Speed sensor, ignition/injection	12.01→		**0 261 210 147**
Duo sensor, acceleration and yaw rate, brake system	12.01→		**0 265 005 252**
2.0 TDI [3U4]			**2,0 l 91/103 kW BSS; BWW 4 Zyl.**
Air mass meter, diesel	10.05→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	10.05→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	10.05→		**0 265 005 252**
2.5 TDI [3U4]			**2,5 l 114 kW AYM 6 Zyl.**
Speed sensor, diesel	12.01-08.03		**0 281 002 222**
Boost pressure sensor, Diesel	12.01-08.03		**0 281 002 177**
Duo sensor, acceleration and yaw rate, brake system	12.01-08.03		**0 265 005 252**
2.5 TDI [3U4]			**2,5 l 120 kW BDG 6 Zyl.**
Speed sensor, diesel	06.03→		**0 281 002 222**
Boost pressure sensor, Diesel	06.03→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	06.03→		**0 265 005 252**
2.8 [3U4]			**2,8 l 140/142 kW AMX; BBG 6 Zyl.**
Throttle valve assembly	12.01→		**0 280 750 030**
Phase sensor	12.01→		**0 232 101 024**
Speed sensor, ignition/injection	12.01→	AG	**0 261 210 147**
		GS	**0 261 210 178**
Temperature sensor, intake air, injection system			
Fg.no. →3U..3..026 512	12.01-08.02		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	12.01→		**0 265 005 252**

SMART (MCC)

Forfour

1.1			**1,1 l 47/55 kW 3 Zyl.**
Pressure sensor, intake manifold, gasoline	01.04-06.07		**0 261 230 118**
Lateral acceleration sensor, brake system	01.04-06.07		**0 265 005 600**
Wheel speed sensor, front	01.04-06.07		**0 265 007 637**
Wheel speed sensor, rear	01.04-06.07		**0 265 007 638**
1.3			**1,3 l 70 kW 4 Zyl.**
Pressure sensor, intake manifold, gasoline	01.04-06.07		**0 261 230 118**
Lateral acceleration sensor, brake system	01.04-06.07		**0 265 005 600**
Wheel speed sensor, front	01.04-06.07		**0 265 007 637**
Wheel speed sensor, rear	01.04-06.07		**0 265 007 638**
1.5			**1,5 l 80 kW 4 Zyl.**
Pressure sensor, intake manifold, gasoline	01.04-06.07		**0 261 230 118**
Lateral acceleration sensor, brake system	01.04-06.07		**0 265 005 600**
Wheel speed sensor, front	01.04-06.07		**0 265 007 637**
Wheel speed sensor, rear	01.04-06.07		**0 265 007 638**
1.5 Brabus			**1,5 l 130 kW 4 Zyl.**
Lateral acceleration sensor, brake system	04.05-06.07		**0 265 005 600**
Wheel speed sensor, front	04.05-06.07		**0 265 007 637**
Wheel speed sensor, rear	04.05-06.07		**0 265 007 638**
1.5 cdi			**1,5 l 50/70 kW 639.939 3 Zyl.**
Speed sensor, diesel	09.04-06.07	FKW	**0 261 210 170**
High-pressure sensor (CR system)	09.04-06.07		**0 281 002 504**
Lateral acceleration sensor, brake system	09.04-06.07		**0 265 005 600**
Wheel speed sensor, front	09.04-06.07		**0 265 007 637**
Wheel speed sensor, rear	09.04-06.07		**0 265 007 638**
1.5 Sportstyle			**1,5 l 90 kW 4 Zyl.**
Pressure sensor, intake manifold, gasoline	04.04-06.07		**0 261 230 118**
Lateral acceleration sensor, brake system	04.04-06.07		**0 265 005 600**
Wheel speed sensor, front	04.04-06.07		**0 265 007 637**
Wheel speed sensor, rear	04.04-06.07		**0 265 007 638**

Fortwo Cabrio

0.7			**0,7 l 45 kW 160.920 3 Zyl.**
Throttle valve assembly	02.04-03.07		**0 205 003 055**
Speed sensor, ignition/injection	02.04-03.07		**0 261 210 141**

Product			
Knock sensor	02.04-03.07		**0 261 231 133**
Pressure sensor, intake manifold, gasoline	02.04-03.07		**0 261 230 049**
0.7 Brabus		**0,7 l 55 kW 160.910 3 Zyl.**	
Throttle valve assembly	02.04-03.07		**0 205 003 055**
Speed sensor, ignition/injection	02.04-03.07		**0 261 210 141**
Knock sensor	02.04-03.07		**0 261 231 133**
Pressure sensor, intake manifold, gasoline	02.04-03.07		**0 261 230 049**
0.8		**0,8 l 33 kW 3 Zyl.**	
Speed sensor, diesel	04.07→		**0 261 210 141**
Pressure sensor, intake manifold, diesel	04.07→		**0 261 230 141**
Duo sensor, acceleration and yaw rate, brake system	04.07→		**0 265 005 687**
0.8 cdi		**0,8 l 30 kW OM 660.940 3 Zyl.**	
Speed sensor, diesel	02.04-03.07	FKW	**0 261 210 141**
Pressure sensor, intake manifold, gasoline	02.04-03.07		**0 261 230 049**
High-pressure sensor (CR system)	02.04-03.07		**0 281 002 238**
1.0		**1,0 l 52/62 kW 3 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	04.07→		**0 265 005 687**
1.0 Brabus		**1,0 l 72 kW 3 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	04.07→		**0 265 005 687**
1.0 mhd		**1,0 l 52 kW 3 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	10.07→		**0 265 005 687**

Fortwo Coupé

0.7		**0,7 l 37/45 kW 3 Zyl.**	
Throttle valve assembly	02.04-03.07		**0 205 003 055**
Speed sensor, ignition/injection	02.04-03.07		**0 261 210 141**
Knock sensor	02.04-03.07		**0 261 231 133**
Pressure sensor, intake manifold, gasoline	02.04-03.07		**0 261 230 049**
0.7 Brabus		**0,7 l 55 kW 3 Zyl.**	
Throttle valve assembly	02.04-03.07		**0 205 003 055**
Speed sensor, ignition/injection	02.04-03.07		**0 261 210 141**
Knock sensor	02.04-03.07		**0 261 231 133**
Pressure sensor, intake manifold, gasoline	02.04-03.07		**0 261 230 049**
0.8		**0,8 l 33 kW 3 Zyl.**	
Speed sensor, diesel	04.07→		**0 261 210 141**
Pressure sensor, intake manifold, diesel	04.07→		**0 261 230 141**
Duo sensor, acceleration and yaw rate, brake system	04.07→		**0 265 005 687**
0.8 cdi		**0,8 l 30 kW OM 660.940 3 Zyl.**	
Speed sensor, diesel	02.04-03.07	FKW	**0 261 210 141**
Pressure sensor, intake manifold, gasoline	02.04-03.07		**0 261 230 049**
High-pressure sensor (CR system)	02.04-03.07		**0 281 002 238**
1.0		**1,0 l 45/52/62 kW 3 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	04.07→		**0 265 005 687**
1.0 Brabus		**1,0 l 72 kW 3 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	04.07→		**0 265 005 687**
1.0 mhd		**1,0 l 52 kW 3 Zyl.**	
Duo sensor, acceleration and yaw rate, brake system	10.07→		**0 265 005 687**

Roadster

0.7		**0,7 l 45/60 kW 160.921; 160.922 3 Zyl.**	
Throttle valve assembly	04.03-11.05		**0 205 003 055**
Speed sensor, ignition/injection	04.03-11.05		**0 261 210 141**
Knock sensor	04.03-11.05		**0 261 231 133**
Pressure sensor, intake manifold, gasoline	04.03-11.05		**0 261 230 049**
Wheel speed sensor, front	04.03-11.05		**0 265 006 753**
Brabus		**0,7 l 74 kW 160.923 3 Zyl.**	
Throttle valve assembly	12.03-11.05		**0 205 003 055**
Speed sensor, ignition/injection	12.03-11.05		**0 261 210 141**
Knock sensor	12.03-11.05		**0 261 231 133**
Pressure sensor, intake manifold, gasoline	12.03-11.05		**0 261 230 049**
Wheel speed sensor, front	12.03-11.05		**0 265 006 753**

Roadster-Coupé

0.7		**0,7 l 45/60 kW 160.921; 160.922 3 Zyl.**	
Throttle valve assembly	04.03-11.05		**0 205 003 055**
Speed sensor, ignition/injection	04.03-11.05		**0 261 210 141**
Knock sensor	04.03-11.05		**0 261 231 133**
Pressure sensor, intake manifold, gasoline	04.03-11.05		**0 261 230 049**
Wheel speed sensor, front	04.03-11.05		**0 265 006 753**
Brabus		**0,7 l 74 kW 160.923 3 Zyl.**	
Throttle valve assembly	12.03-11.05		**0 205 003 055**
Speed sensor, ignition/injection	12.03-11.05		**0 261 210 141**
Knock sensor	12.03-11.05		**0 261 231 133**
Pressure sensor, intake manifold, gasoline	12.03-11.05		**0 261 230 049**
Wheel speed sensor, front	12.03-11.05		**0 265 006 753**

Smart Cabrio

0.6		**0,6 l 40/45/52 kW 3 Zyl.**	
Throttle valve assembly	03.00-01.04		**0 205 003 055**
Speed sensor, ignition/injection	03.00-01.04		**0 261 210 141**
Knock sensor	03.00-01.04		**0 261 231 133**
Pressure sensor, intake manifold, gasoline	03.00-01.04		**0 261 230 049**
0.7		**0,7 l 45 kW 3 Zyl.**	
Throttle valve assembly	01.03-01.04		**0 205 003 055**
Speed sensor, ignition/injection	01.03-01.04		**0 261 210 141**
Knock sensor	01.03-01.04		**0 261 231 133**
Pressure sensor, intake manifold, gasoline	01.03-01.04		**0 261 230 049**
BRABUS		**0,7 l 55 kW 3 Zyl.**	
Throttle valve assembly	01.03-01.04		**0 205 003 055**
Speed sensor, ignition/injection	01.03-01.04		**0 261 210 141**
Knock sensor	01.03-01.04		**0 261 231 133**
cdi		**0,8 l 30 kW OM 660 3 Zyl.**	
Speed sensor, diesel	03.01-01.04	FKW	**0 261 210 141**
Pressure sensor, intake manifold, gasoline	03.01-01.04		**0 261 230 049**
High-pressure sensor (CR system)	03.01-01.04		**0 281 002 238**

Smart Coupé

0.6		**0,6 l 33/37/40/45/52 kW 3 Zyl.**	
Throttle valve assembly	07.98-01.04		**0 205 003 055**
Speed sensor, ignition/injection	07.98-01.04		**0 261 210 141**
Knock sensor	07.98-01.04		**0 261 231 133**
Pressure sensor, intake manifold, gasoline	07.98-01.04		**0 261 230 049**
0.7		**0,7 l 45 kW 3 Zyl.**	
Throttle valve assembly	01.03-01.04		**0 205 003 055**
Speed sensor, ignition/injection	01.03-01.04		**0 261 210 141**
Knock sensor	01.03-01.04		**0 261 231 133**
Pressure sensor, intake manifold, gasoline	01.03-01.04		**0 261 230 049**
BRABUS		**0,7 l 55 kW 3 Zyl.**	
Throttle valve assembly	01.03-01.04		**0 205 003 055**
Speed sensor, ignition/injection	01.03-01.04		**0 261 210 141**
Knock sensor	01.03-01.04		**0 261 231 133**
Pressure sensor, intake manifold, gasoline	01.03-01.04		**0 261 230 049**

Product

◀ Smart Coupé

cdi			**0,8 l 30 kW OM 660 3 Zyl.**
Speed sensor, diesel	11.99-01.04	FKW	**0 261 210 141**
Pressure sensor, intake manifold, gasoline	11.99-01.04		**0 261 230 049**
High-pressure sensor (CR system)	11.99-01.04		**0 281 002 238**

Smart Crossblade

0.6			**0,6 l 52 kW 3 Zyl.**
Throttle valve assembly	10.02-01.04		**0 205 003 055**
Speed sensor, ignition/injection	10.02-01.04		**0 261 210 141**
Knock sensor	10.02-01.04		**0 261 231 133**
Pressure sensor, intake manifold, gasoline	10.02-01.04		**0 261 230 049**

SSANGYONG

Istana

2.3 i 16V [L]			**2,3 l 110 kW M161 E23 4 Zyl.**
Air mass meter, gasoline injection	11.96→		**0 280 217 100**
Speed sensor, ignition/injection	11.96→		**0 281 002 123**
Wheel speed sensor, front	11.96→	LAB	**0 265 006 338**
		RAB	**0 265 006 339**
Wheel speed sensor, rear	11.96→		**0 265 006 341**

Korando

2.0 i [KJ]			**2,0 l 94 kW M161 E20 4 Zyl.**
Air mass meter, gasoline injection	07.96-12.05		**0 280 217 100**
Speed sensor, ignition/injection	07.96-12.05		**0 281 002 123**
Wheel speed sensor, front	07.96-12.05		**0 265 006 134**
Wheel speed sensor, rear	07.96-12.05		**0 265 006 343**
2.3 D [KJ]			**2,3 l 58-59 kW OM661 D23 4 Zyl.**
Wheel speed sensor, front	07.96-12.05		**0 265 006 134**
Wheel speed sensor, rear	07.96-12.05		**0 265 006 343**
2.3 i 16V [KJ]			**2,3 l 103-105 kW M161 E23 4 Zyl.**
Air mass meter, gasoline injection	07.96-12.05		**0 280 217 100**
Speed sensor, ignition/injection	07.96-12.05		**0 281 002 123**
Wheel speed sensor, front	07.96-12.05		**0 265 006 134**
Wheel speed sensor, rear	07.96-12.05		**0 265 006 343**
2.9 D [KJ]			**2,9 l 70-73 kW OM662 D29 5 Zyl.**
Wheel speed sensor, front	07.96-12.05		**0 265 006 134**
Wheel speed sensor, rear	07.96-12.05		**0 265 006 343**
2.9 TD Intercooler [KJ]			**2,9 l 88-97 kW OM662 LA 5 Zyl.**
Wheel speed sensor, front	07.96-12.05		**0 265 006 134**
Wheel speed sensor, rear	07.96-12.05		**0 265 006 343**
3.2 i [KJ]			**3,2 l 154-162 kW M162.995 E32 6 Zyl.**
Speed sensor, ignition/injection	07.96-12.05		**0 261 210 122**
Wheel speed sensor, front	07.96-12.05		**0 265 006 134**
Wheel speed sensor, rear	07.96-12.05		**0 265 006 343**

Musso

2.0 i [MJ]			**2,0 l 100 kW M161 E20 4 Zyl.**
Air mass meter, gasoline injection	05.96-12.05		**0 280 217 100**
Speed sensor, ignition/injection	05.96-12.05		**0 281 002 123**
Wheel speed sensor, front	05.96-12.05		**0 265 006 134**
Wheel speed sensor, rear	05.96-12.05		**0 265 006 135**
2.3 D [MJ]			**2,3 l 57-58 kW OM661 D23 4 Zyl.**
Wheel speed sensor, front	07.93-12.05		**0 265 006 134**
Wheel speed sensor, rear	07.93-12.05		**0 265 006 135**
2.3 i [MJ]			**2,3 l 103-110 kW M161 E23 4 Zyl.**
Air mass meter, gasoline injection	05.96-12.05		**0 280 217 100**
Speed sensor, ignition/injection	05.96-12.05		**0 281 002 123**
Wheel speed sensor, front	05.96-12.05		**0 265 006 134**
Wheel speed sensor, rear	05.96-12.05		**0 265 006 135**
2.9 D [MJ]			**2,9 l 70-73 kW OM 662 D29 5 Zyl.**
Wheel speed sensor, front	07.93-12.05		**0 265 006 134**
Wheel speed sensor, rear	07.93-12.05		**0 265 006 135**
2.9 D [MJ]			**2,9 l 88 kW OM 662 5 Zyl.**
Wheel speed sensor, front	07.93-04.05		**0 265 006 134**
2.9 TD Intercooler [MJ]			**2,9 l 88 kW OM 662 D29 5 Zyl.**
Wheel speed sensor, front	05.97-12.05		**0 265 006 134**
Wheel speed sensor, rear	05.97-12.05		**0 265 006 135**
3.2 i [MJ]			**3,2 l 162 kW M162 E32 6 Zyl.**
Air mass meter, gasoline injection	01.96-12.05		**0 280 217 517**
Speed sensor, ignition/injection	07.96-12.05		**0 261 210 122**
Wheel speed sensor, front	01.96-12.05		**0 265 006 134**
Wheel speed sensor, rear	01.96-12.05		**0 265 006 135**

STEYR (STEYR-DAIMLER-PUCH AG)

G

300 DT			**3,0 l 130 kW MB OM 606.964 6 Zyl.**
Speed sensor, diesel	01.98→		**0 281 002 123**
Pedal position sensor, diesel	01.98→		**0 205 001 029**
Wheel speed sensor, front	01.98→		**0 265 002 262**
320			**3,2 l 158 kW MB M 112.945 6 Zyl.**
Throttle valve assembly	01.98→		**0 205 003 046**
Air mass meter, gasoline injection	01.98→		**0 280 217 515**
Phase sensor	01.98→	NOC	**0 232 103 022**
			0 232 103 037
Speed sensor, ignition/injection	01.98→		**0 261 210 170**
Knock sensor	01.98→		**0 261 231 110**
Wheel speed sensor, front	01.98→		**0 265 002 262**
500 V8			**5,0 l 218 kW MB M 113.962 8 Zyl.**
Throttle valve assembly	01.98→		**0 205 003 048**
Air mass meter, gasoline injection	01.98→		**0 280 217 810**
Speed sensor, ignition/injection	01.98→		**0 261 210 170**
Knock sensor	01.98→		**0 261 231 110**
Wheel speed sensor, front	01.98→		**0 265 002 262**

SUZUKI

Alto

0.8 i			**0,8 l 26,5 kW JL368Q3 3 Zyl.**
Throttle valve sensor	07.99-06.07		**0 280 122 019**
Knock sensor	07.99-06.07		**0 261 231 036**
Pressure sensor, intake manifold, gasoline	07.99-06.07		**0 261 230 011**
Temperature sensor, intake air, injection system	07.99-06.07		**0 280 130 037**

Ignis Hatchback

1.3 DDiS D Turbo			**1,2 l 51 kW Z13DT 4 Zyl.**
Air mass meter, diesel	10.03-12.06		**0 281 002 619**
Pressure sensor, intake manifold, diesel	10.03-12.06		**0 281 002 510**

Product

Swift Hatchback

1.3 DDiS D Turbo [MZ]		1,2 l 51 kW Z13DT 4 Zyl.
Air mass meter, diesel	08.05→	**0 281 002 619**
Pressure sensor, intake manifold, diesel	08.05→	**0 281 002 510**

Wagon R+

1.3 DDiS D Turbo [MM]		1,3 l 51 kW Z13DT 4 Zyl.
Air mass meter, diesel	09.03-03.06	**0 281 002 619**
Pressure sensor, intake manifold, diesel	09.03-03.06	**0 281 002 510**

TATA (TELCO)

Estate

2.0 i 16V [TE]		2,0 l 103 kW 4PL 4 Zyl.
Throttle valve sensor	10.95→	**0 280 122 001**
Air mass meter, gasoline injection	10.95→	**0 280 217 111**
Phase sensor	10.95→	**0 232 103 003**
Speed sensor, ignition/injection	10.95→	**0 281 002 102**
Knock sensor	10.95→	**0 261 231 091**
Temperature sensor, coolant, injection system	10.95→	**0 280 130 026**

Sierra

2.0 i 16V		2,0 l 103 kW 4PL 4 Zyl.
Throttle valve sensor	10.95→	**0 280 122 001**
Air mass meter, gasoline injection	10.95→	**0 280 217 111**
Phase sensor	10.95→	**0 232 103 003**
Speed sensor, ignition/injection	10.95→	**0 281 002 102**
Knock sensor	10.95→	**0 261 231 091**
Temperature sensor, coolant, injection system	10.95→	**0 280 130 026**

Tatamobile

2.0 i 16V		2,0 l 103 kW 4 Zyl.
Throttle valve sensor	10.95→	**0 280 122 001**
Air mass meter, gasoline injection	10.95→	**0 280 217 111**
Phase sensor	10.95→	**0 232 103 003**
Speed sensor, ignition/injection	10.95→	**0 281 002 102**
Knock sensor	10.95→	**0 261 231 091**
Temperature sensor, coolant, injection system	10.95→	**0 280 130 026**

TOYOTA

Auris

1.4 [E15]			1,4 l 71 kW 4ZZFE 4 Zyl.
Phase sensor	10.06→	NOC	**0 232 103 029**
Knock sensor	10.06→		**0 261 231 149**
1.4 D-4D [E15]			**1,4 l 66 kW 1NDTV 4 Zyl.**
Wheel speed sensor, rear	03.07→	DRK	**0 265 007 802**
2.0 D-4D [E15]			**2,0 l 93 kW 1ADFTV 4 Zyl.**
Wheel speed sensor, rear	10.06→	DRK	**0 265 007 802**
2.2 D-CAT [E15]			**2,2 l 130 kW 2AD-FHV 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	02.07→		**0 265 005 650**
Wheel speed sensor, front	02.07→	LAB	**0 265 007 806**
Wheel speed sensor, rear	02.07→	DRK	**0 265 007 802**

Product

Avensis

1.6 i 16V [T25]			1,6 l 81 kW 3ZZFE 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	01.03-04.06		**0 265 005 273**
	05.06→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	01.03→		**0 265 005 487**
Wheel speed sensor, front	01.03→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
1.8 i 16V [T25]			**1,8 l 95 kW 1ZZFE 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	01.03-04.06		**0 265 005 273**
	05.06→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	01.03→		**0 265 005 487**
Wheel speed sensor, front	01.03→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
2.0 D Turbo [T25]			**2,0 l 85 kW 1CDFTV 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.03-04.06		**0 265 005 273**
Steering angle sensor, ESP (electronic stability program)	03.03-04.06		**0 265 005 487**
Wheel speed sensor, front	03.03-04.06	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
2.0 D-4D [T25]			**2,0 l 93 kW 1ADFTV 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	04.06→		**0 265 005 487**
Wheel speed sensor, front	04.06→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
2.0 i 16V [T25]			**2,0 l 108-114 kW 1AZFSE 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	01.03-04.06		**0 265 005 273**
	05.06→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	01.03→		**0 265 005 487**
Wheel speed sensor, front	01.03→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
2.2 D-CAT [T25]			**2,2 l 130 kW 2AD-FHV 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	04.05-04.06		**0 265 005 273**
	05.06→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	04.05→		**0 265 005 487**
Wheel speed sensor, front	04.05→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
2.2 D-4D [T25]			**2,2 l 110 kW 2AD-FTV 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	04.05-04.06		**0 265 005 273**
	05.06→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	04.05→		**0 265 005 487**
Wheel speed sensor, front	04.05→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
2.4 i [T25]			**2,4 l 120 kW 2AZFSE 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.03-04.06		**0 265 005 273**
	05.06→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	09.03→		**0 265 005 487**
Wheel speed sensor, front	09.03→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**

Product			

Avensis Liftback

1.6 i 16V [T22]			**1,6 l 74/81 kW 4AFE 4 Zyl.**
Knock sensor	10.97-07.00	LLE	**0 261 231 045**
Wheel speed sensor, front	10.97-07.00	LAB	**0 265 006 665**
		RAB	**0 265 006 666**
Wheel speed sensor, rear	10.97-07.00	LAB	**0 265 006 667**
		RAB	**0 265 006 668**
1.6 i 16V [T22]			**1,6 l 81 kW 3ZZFE 4 Zyl.**
Wheel speed sensor, front	07.00-01.03	LAB	**0 265 006 665**
		RAB	**0 265 006 666**
Wheel speed sensor, rear	07.00-01.03	LAB	**0 265 006 667**
		RAB	**0 265 006 668**
1.6 i 16V [T25]			**1,6 l 81 kW 3ZZFE 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	01.03-04.06		**0 265 005 273**
	05.06→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	01.03→		**0 265 005 487**
Wheel speed sensor, front	01.03→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
1.8 i 16V [T22]			**1,8 l 81/95 kW 1ZZFE; 7AFE 4 Zyl.**
Wheel speed sensor, front	10.97-01.03	LAB	**0 265 006 665**
		RAB	**0 265 006 666**
Wheel speed sensor, rear	10.97-01.03	LAB	**0 265 006 667**
		RAB	**0 265 006 668**
1.8 i 16V [T25]			**1,8 l 95 kW 1ZZFE 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	01.03-04.06		**0 265 005 273**
	05.06→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	01.03→		**0 265 005 487**
Wheel speed sensor, front	01.03→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
2.0 D Turbo [T22]			**2,0 l 66/85 kW 1CDFTV; 2CTE 4 Zyl.**
Wheel speed sensor, front	10.97-01.03	LAB	**0 265 006 665**
		RAB	**0 265 006 666**
Wheel speed sensor, rear	10.97-01.03	LAB	**0 265 006 667**
		RAB	**0 265 006 668**
2.0 D Turbo [T25]			**2,0 l 85 kW 1CDFTV 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.03-04.06		**0 265 005 273**
Steering angle sensor, ESP (electronic stability program)	03.03-04.06		**0 265 005 487**
Wheel speed sensor, front	03.03-04.06	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
2.0 D-4D [T25]			**2,0 l 93 kW 1ADFTV 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	04.06→		**0 265 005 487**
Wheel speed sensor, front	04.06→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
2.0 i 16V [T22]			**2,0 l 94/110 kW 1AZFSE; 3SFE 4 Zyl.**
Wheel speed sensor, front	10.97-01.03	LAB	**0 265 006 665**
		RAB	**0 265 006 666**
Wheel speed sensor, rear	10.97-01.03	LAB	**0 265 006 667**
		RAB	**0 265 006 668**
2.0 i 16V [T25]			**2,0 l 110 kW 1AZFSE 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	01.03-04.06		**0 265 005 273**
	05.06→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	01.03→		**0 265 005 487**
Wheel speed sensor, front	01.03→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
2.2 D-CAT [T25]			**2,2 l 130 kW 2AD-FHV 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	04.05-04.06		**0 265 005 273**
	05.06→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	04.05→		**0 265 005 487**
Wheel speed sensor, front	04.05→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
2.2 D-4D [T25]			**2,2 l 110 kW 2AD-FTV 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	04.05-04.06		**0 265 005 273**
	05.06→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	04.05→		**0 265 005 487**
Wheel speed sensor, front	04.05→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
2.4 i [T25]			**2,4 l 120 kW 2AZFSE 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.03-04.06		**0 265 005 273**
	05.06→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	09.03→		**0 265 005 487**
Wheel speed sensor, front	09.03→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**

Avensis Sedan

1.6 i 16V [T22]			**1,6 l 74/81 kW 4AFE 4 Zyl.**
Knock sensor	10.97-07.00	LLE	**0 261 231 045**
Wheel speed sensor, front	10.97-07.00	LAB	**0 265 006 665**
		RAB	**0 265 006 666**
Wheel speed sensor, rear	10.97-07.00	LAB	**0 265 006 667**
		RAB	**0 265 006 668**
1.6 i 16V [T22]			**1,6 l 81 kW 3ZZFE 4 Zyl.**
Wheel speed sensor, front	07.00-01.03	LAB	**0 265 006 665**
		RAB	**0 265 006 666**
Wheel speed sensor, rear	07.00-01.03	LAB	**0 265 006 667**
		RAB	**0 265 006 668**
1.8 i 16V [T22]			**1,8 l 81/95 kW 1ZZFE; 7AFE 4 Zyl.**
Wheel speed sensor, front	10.97-01.03	LAB	**0 265 006 665**
		RAB	**0 265 006 666**
Wheel speed sensor, rear	10.97-01.03	LAB	**0 265 006 667**
		RAB	**0 265 006 668**
2.0 D Turbo [T22]			**2,0 l 66/85 kW 1CDFTV; 2CT; 2CTE 4 Zyl.**
Wheel speed sensor, front	10.97-01.03	LAB	**0 265 006 665**
		RAB	**0 265 006 666**
Wheel speed sensor, rear	10.97-01.03	LAB	**0 265 006 667**
		RAB	**0 265 006 668**
2.0 i 16V [T22]			**2,0 l 94/110 kW 1AZFSE; 3SFE 4 Zyl.**
Wheel speed sensor, front	10.97-01.03	LAB	**0 265 006 665**
		RAB	**0 265 006 666**
Wheel speed sensor, rear	10.97-01.03	LAB	**0 265 006 667**
		RAB	**0 265 006 668**

Avensis Wagon

1.6 i 16V [T22]			**1,6 l 74/81 kW 4AFE 4 Zyl.**
Knock sensor	10.97-07.00	LLE	**0 261 231 045**
Wheel speed sensor, front	10.97-07.00	LAB	**0 265 006 665**
		RAB	**0 265 006 666**
Wheel speed sensor, rear	10.97-07.00	LAB	**0 265 006 667**
		RAB	**0 265 006 668**
1.6 i 16V [T22]			**1,6 l 81 kW 3ZZFE 4 Zyl.**
Wheel speed sensor, front	07.00-01.03	LAB	**0 265 006 665**
		RAB	**0 265 006 666**

Product			
Wheel speed sensor, rear	07.00-01.03	LAB	**0 265 006 667**
		RAB	**0 265 006 668**
1.6 i 16V [T25]			**1,6 l 81 kW 3ZZFE 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	01.03-04.06		**0 265 005 273**
	05.06→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	01.03→		**0 265 005 487**
Wheel speed sensor, front	01.03→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
1.8 i 16V [T22]			**1,8 l 81/95 kW 1ZZFE; 7AFE 4 Zyl.**
Wheel speed sensor, front	10.97-01.03	LAB	**0 265 006 665**
		RAB	**0 265 006 666**
Wheel speed sensor, rear	10.97-01.03	LAB	**0 265 006 667**
		RAB	**0 265 006 668**
1.8 i 16V [T25]			**1,8 l 95 kW 1ZZFE 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	01.03-04.06		**0 265 005 273**
	05.06→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	01.03→		**0 265 005 487**
Wheel speed sensor, front	01.03→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
2.0 D Turbo [T22]			**2,0 l 66/85 kW 1CDFTV; 2CTE 4 Zyl.**
Wheel speed sensor, front	10.97-01.03	LAB	**0 265 006 665**
		RAB	**0 265 006 666**
Wheel speed sensor, rear	10.97-01.03	LAB	**0 265 006 667**
		RAB	**0 265 006 668**
2.0 D Turbo [T25]			**2,0 l 85 kW 1CDFTV 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	03.03-04.06		**0 265 005 273**
Steering angle sensor, ESP (electronic stability program)	03.03-04.06		**0 265 005 487**
Wheel speed sensor, front	03.03-04.06	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
2.0 D-4D [T25]			**2,0 l 93 kW 1ADFTV 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	04.06→		**0 265 005 487**
Wheel speed sensor, front	04.06→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
2.0 i 16V [T22]			**2,0 l 94/110 kW 1AZFSE; 3SFE 4 Zyl.**
Wheel speed sensor, front	10.97-01.03	LAB	**0 265 006 665**
		RAB	**0 265 006 666**
Wheel speed sensor, rear	10.97-01.03	LAB	**0 265 006 667**
		RAB	**0 265 006 668**
2.0 i 16V [T25]			**2,0 l 110 kW 1AZFSE 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	01.03-04.06		**0 265 005 273**
	05.06→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	01.03→		**0 265 005 487**
Wheel speed sensor, front	01.03→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
2.2 D-CAT [T25]			**2,2 l 130 kW 2AD-FHV 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	04.05-04.06		**0 265 005 273**
	05.06→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	04.05→		**0 265 005 487**
Wheel speed sensor, front	04.05→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
2.2 D-4D [T25]			**2,2 l 110 kW 2AD-FTV 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	04.05-04.06		**0 265 005 273**
	05.06→		**0 265 005 297**

Product			
Steering angle sensor, ESP (electronic stability program)	04.05→		**0 265 005 487**
Wheel speed sensor, front	04.05→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
2.4 i [T25]			**2,4 l 120 kW 2AZFSE 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.03-04.06		**0 265 005 273**
	05.06→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	09.03→		**0 265 005 487**
Wheel speed sensor, front	09.03→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**

Aygo

1.0 i			**1,0 l 50 kW 1KRFE 3 Zyl.**
Phase sensor	02.05→		**0 232 103 069**
Wheel speed sensor, front	02.05→		**0 265 007 687**
Wheel speed sensor, rear	02.05→		**0 265 007 688**
1.4 HDi			**1,4 l 40 kW 2WZTV 4 Zyl.**
Wheel speed sensor, front	02.05→		**0 265 007 687**
Wheel speed sensor, rear	02.05→		**0 265 007 688**

Carina E Liftback

1.6 i 16V [T19]			**1,6 l 75 kW 4AFE 4 Zyl.**
Throttle valve sensor	02.94-01.96		**0 280 122 008**
Knock sensor	03.94-01.96	GS	**0 261 231 103**
Wheel speed sensor, front	11.94-01.96	LAB	**0 265 001 417**
		RAB	**0 265 001 416**
1.6 i 16V [T19]			**1,6 l 79 kW 4AFE 4 Zyl.**
Throttle valve sensor	12.93-10.97		**0 280 122 008**
Knock sensor	03.94-10.97	GS	**0 261 231 103**
Wheel speed sensor, front	11.94-01.96	LAB	**0 265 001 417**
	02.96-10.97	LAB	**0 265 001 417**
	11.94-01.96	RAB	**0 265 001 416**
	02.96-10.97	RAB	**0 265 001 416**
Wheel speed sensor, rear	02.96-10.97	LAB	**0 265 001 419**
		RAB	**0 265 001 418**
1.6 i 16V [T19]			**1,6 l 85 kW 4AFE 4 Zyl.**
Knock sensor	03.94-10.97	GS	**0 261 231 103**
Wheel speed sensor, front	11.94-01.96	LAB	**0 265 001 417**
	02.96-10.97	LAB	**0 265 001 417**
	11.94-01.96	RAB	**0 265 001 416**
	02.96-10.97	RAB	**0 265 001 416**
Wheel speed sensor, rear	02.96-10.97	LAB	**0 265 001 419**
		RAB	**0 265 001 418**
1.8 i 16V [T19]			**1,8 l 79 kW 7AFE 4 Zyl.**
Wheel speed sensor, front	12.94-01.96	LAB	**0 265 001 417**
	02.96-10.97	LAB	**0 265 001 417**
	12.94-01.96	RAB	**0 265 001 416**
	02.96-10.97	RAB	**0 265 001 416**
Wheel speed sensor, rear	02.96-10.97	LAB	**0 265 001 419**
		RAB	**0 265 001 418**
2.0 D [T19]			**2,0 l 53-54 kW 2C 4 Zyl.**
Wheel speed sensor, front	11.94-01.96	LAB	**0 265 001 417**
		RAB	**0 265 001 416**
2.0 D Turbo [T19]			**2,0 l 61 kW 2CT 4 Zyl.**
Wheel speed sensor, front	01.96-10.97	LAB	**0 265 001 417**
	02.96-10.97	RAB	**0 265 001 416**
Wheel speed sensor, rear	02.96-10.97	LAB	**0 265 001 419**
		RAB	**0 265 001 418**

T

Product			
◀ Carina E Liftback			
2.0 i 16V [T19]			**2,0 l 98 kW 3SFE 4 Zyl.**
Wheel speed sensor, front	11.94-01.96	LAB	**0 265 001 417**
	02.96-10.97	LAB	**0 265 001 417**
	11.94-01.96	RAB	**0 265 001 416**
	02.96-10.97	RAB	**0 265 001 416**
Wheel speed sensor, rear	02.96-10.97	LAB	**0 265 001 419**
		RAB	**0 265 001 418**

Carina E Sedan

1.6 i 16V [T19]			**1,6 l 75 kW 4AFE 4 Zyl.**
Throttle valve sensor	02.94-01.96		**0 280 122 008**
Knock sensor	03.94-01.96	GS	**0 261 231 103**
Wheel speed sensor, front	11.94-01.96	LAB	**0 265 001 417**
		RAB	**0 265 001 416**
1.6 i 16V [T19]			**1,6 l 79 kW 4AFE 4 Zyl.**
Throttle valve sensor	12.92-10.97		**0 280 122 008**
Knock sensor	03.94-10.97	GS	**0 261 231 103**
Wheel speed sensor, front	11.94-01.96	LAB	**0 265 001 417**
	02.96-10.97	LAB	**0 265 001 417**
	11.94-01.96	RAB	**0 265 001 416**
	02.96-10.97	RAB	**0 265 001 416**
Wheel speed sensor, rear	02.96-10.97	LAB	**0 265 001 419**
		RAB	**0 265 001 418**
1.6 i 16V [T19]			**1,6 l 85 kW 4AFE 4 Zyl.**
Knock sensor	03.94-10.97	GS	**0 261 231 103**
Wheel speed sensor, front	11.94-01.96	LAB	**0 265 001 417**
	02.96-10.97	LAB	**0 265 001 417**
	11.94-01.96	RAB	**0 265 001 416**
	02.96-10.97	RAB	**0 265 001 416**
Wheel speed sensor, rear	02.96-10.97	LAB	**0 265 001 419**
		RAB	**0 265 001 418**
1.8 i 16V [T19]			**1,8 l 79 kW 7AFE 4 Zyl.**
Wheel speed sensor, front	12.94-01.96	LAB	**0 265 001 417**
	02.96-10.97	LAB	**0 265 001 417**
	12.94-01.96	RAB	**0 265 001 416**
	02.96-10.97	RAB	**0 265 001 416**
Wheel speed sensor, rear	02.96-10.97	LAB	**0 265 001 419**
		RAB	**0 265 001 418**
2.0 D [T19]			**2,0 l 53-54 kW 2C 4 Zyl.**
Wheel speed sensor, front	11.94-01.96	LAB	**0 265 001 417**
		RAB	**0 265 001 416**
2.0 D Turbo [T19]			**2,0 l 61 kW 2CT 4 Zyl.**
Wheel speed sensor, front	01.96-10.97	LAB	**0 265 001 417**
	02.96-10.97	RAB	**0 265 001 416**
Wheel speed sensor, rear	02.96-10.97	LAB	**0 265 001 419**
		RAB	**0 265 001 418**
2.0 i 16V [T19]			**2,0 l 98 kW 3SFE 4 Zyl.**
Wheel speed sensor, front	11.94-01.96	LAB	**0 265 001 417**
	02.96-10.97	LAB	**0 265 001 417**
	11.94-01.96	RAB	**0 265 001 416**
	02.96-10.97	RAB	**0 265 001 416**
Wheel speed sensor, rear	02.96-10.97	LAB	**0 265 001 419**
		RAB	**0 265 001 418**

Carina E Wagon

1.6 i 16V [T19]			**1,6 l 79 kW 4AFE 4 Zyl.**
Knock sensor	05.95-10.97	GS	**0 261 231 103**
Wheel speed sensor, front	05.95-01.96	LAB	**0 265 001 417**
	02.96-10.97	LAB	**0 265 001 417**
	05.95-01.96	RAB	**0 265 001 416**
	02.96-10.97	RAB	**0 265 001 416**
Wheel speed sensor, rear	02.96-10.97	LAB	**0 265 001 419**
		RAB	**0 265 001 418**
1.8 i 16V [T19]			**1,8 l 79 kW 7AFE 4 Zyl.**
Wheel speed sensor, front	05.95-01.96	LAB	**0 265 001 417**
	02.96-10.97	LAB	**0 265 001 417**
	05.95-01.96	RAB	**0 265 001 416**
	02.96-10.97	RAB	**0 265 001 416**
Wheel speed sensor, rear	02.96-10.97	LAB	**0 265 001 419**
		RAB	**0 265 001 418**
2.0 D [T19]			**2,0 l 53-54 kW 2C 4 Zyl.**
Wheel speed sensor, front	05.95-01.96	LAB	**0 265 001 417**
		RAB	**0 265 001 416**
2.0 D Turbo [T19]			**2,0 l 61 kW 2CT 4 Zyl.**
Wheel speed sensor, front	01.96-10.97	LAB	**0 265 001 417**
	02.96-10.97	RAB	**0 265 001 416**
Wheel speed sensor, rear	02.96-10.97	LAB	**0 265 001 419**
		RAB	**0 265 001 418**
2.0 i 16V [T19]			**2,0 l 98 kW 3SFE 4 Zyl.**
Wheel speed sensor, front	05.95-01.96	LAB	**0 265 001 417**
	02.96-10.97	LAB	**0 265 001 417**
	05.95-01.96	RAB	**0 265 001 416**
	02.96-10.97	RAB	**0 265 001 416**
Wheel speed sensor, rear	02.96-10.97	LAB	**0 265 001 419**
		RAB	**0 265 001 418**

Corolla

1.4 i [E12]			**1,4 l 71 kW 4ZZFE 4 Zyl.**
Speed sensor, ignition/injection	09.02-07.07	NOC	**0 232 103 029**
Knock sensor	09.02-07.07		**0 261 231 149**

Corolla Altis

1.6 i			**1,6 l 82 kW 3ZZFE 4 Zyl.**
Phase sensor	05.01→		**0 281 002 406**
1.8 i			**1,8 l 101 kW 1ZZFE 4 Zyl.**
Phase sensor	03.99→		**0 281 002 406**

Corolla Hatchback

1.4 D Turbo [E12]			**1,4 l 66 kW 1NDTV 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.02→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	09.02→		**0 265 005 487**
1.4 i 16V [E11]			**1,4 l 71 kW 4ZZFE 4 Zyl.**
Throttle valve sensor	10.99-07.01		**0 280 122 008**
Knock sensor	10.99-07.01		**0 261 231 149**
1.4 i 16V [E12]			**1,4 l 71 kW 4ZZFE 4 Zyl.**
Speed sensor, ignition/injection	11.01→	NOC	**0 232 103 029**
Knock sensor	11.01→		**0 261 231 149**
Duo sensor, acceleration and yaw rate, brake system	11.01→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	11.01→		**0 265 005 487**
1.6 i 16V [E12]			**1,6 l 81 kW 3ZZFE 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	11.01→		**0 265 005 297**
1.8 i 16V [E12]			**1,8 l 140-165 kW 2ZZGE 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	11.01-05.04		**0 265 005 273**
	06.04→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	11.01→		**0 265 005 487**

Product			
Wheel speed sensor, front	11.01→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**

Corolla Liftback

1.4 i 16V [E11]			**1,4 l 71 kW 4ZZFE 4 Zyl.**
Throttle valve sensor	10.99-09.01		**0 280 122 008**
Knock sensor	10.99-09.01		**0 261 231 149**

Corolla RunX

1.4 i [E12]			**1,4 l 71 kW 4ZZFE 4 Zyl.**
Speed sensor, ignition/injection	09.02-07.07	NOC	**0 232 103 029**
Knock sensor	09.02-07.07		**0 261 231 149**

Corolla Sedan

1.4 D Turbo [E12]			**1,4 l 66 kW 1NDTV 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	01.02→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	01.02→		**0 265 005 487**
1.4 i 16V [E11]			**1,4 l 71 kW 4ZZFE 4 Zyl.**
Throttle valve sensor	10.99-09.01		**0 280 122 008**
Knock sensor	10.99-09.01		**0 261 231 149**
1.4 i 16V [E12]			**1,4 l 71 kW 4ZZFE 4 Zyl.**
Speed sensor, ignition/injection	10.01→	NOC	**0 232 103 029**
Knock sensor	10.01→		**0 261 231 149**
Duo sensor, acceleration and yaw rate, brake system	10.01→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	10.01→		**0 265 005 487**
1.6 i 16V [E12]			**1,6 l 81 kW 3ZZFE 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.01→		**0 265 005 297**
1.8 i 16V			**1,8 l 100 kW 1ZZFE 4 Zyl.**
Wheel speed sensor, front	05.02→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**

Corolla Verso

1.6 i 16V [R10/11]			**1,6 l 81 kW 3ZZFE 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	02.04→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	02.04→	TW	**0 265 005 487**
Wheel speed sensor, front	02.04→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
1.8 i 16V [R10/11]			**1,8 l 95 kW 1ZZFE 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	02.04→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	02.04→	TW	**0 265 005 487**
Wheel speed sensor, front	02.04→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
1.8 i 16V [R11]			**1,8 l 95 kW 1ZZFE 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	02.04→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	02.04→	TW	**0 265 005 487**
Wheel speed sensor, front	02.04→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
2.0 D Turbo [E12]			**2,0 l 66 kW 1CDFTV 4 Zyl.**
Knock sensor	09.01-01.04		**0 261 231 149**
2.0 D Turbo [R10/11]			**2,0 l 66 kW 1CDFTV 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	02.04-08.05		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	02.04-08.05	TW	**0 265 005 432**
Wheel speed sensor, front	02.04-08.05	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
2.2 D-CAT [R10/11]			**2,2 l 130 kW 2AD-FHV 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	08.05→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	08.05→		**0 265 005 487**
Wheel speed sensor, front	08.05→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**
2.2 D-4D [R10/11]			**2,2 l 100 kW 2AD-FTV 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	08.05→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	08.05→		**0 265 005 487**
Wheel speed sensor, front	08.05→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**

Corolla Wagon

1.4 D Turbo [E12]			**1,4 l 66 kW 1NDTV 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	01.02→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	01.02→		**0 265 005 487**
1.4 i 16V [E11]			**1,4 l 71 kW 4ZZFE 4 Zyl.**
Throttle valve sensor	10.99-09.01		**0 280 122 008**
Knock sensor	10.99-09.01		**0 261 231 149**
1.4 i 16V [E12]			**1,4 l 71 kW 4ZZFE 4 Zyl.**
Speed sensor, ignition/injection	10.01→	NOC	**0 232 103 029**
Knock sensor	10.01→		**0 261 231 149**
Duo sensor, acceleration and yaw rate, brake system	10.01→		**0 265 005 297**
Steering angle sensor, ESP (electronic stability program)	10.01→		**0 265 005 487**
1.6 i 16V [E12]			**1,6 l 81 kW 3ZZFE 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.01→		**0 265 005 297**
1.8 i 16V Fielder			**1,8 l 100 kW 1ZZFE 4 Zyl.**
Wheel speed sensor, front	05.04→	LAB	**0 265 006 676**
		RAB	**0 265 006 677**

Yaris

1.0 i 16V [P1]			**1,0 l 50 kW 1SZ-FE 4 Zyl.**
Knock sensor	01.01-02.03		**0 261 231 045**
Wheel speed sensor, front	01.01→	LAB	**0 265 006 674**
		RAB	**0 265 006 675**
1.0 VVT-i [P9]			**1,0 l 51 kW 1KR-FE 3 Zyl.**
Phase sensor	08.05→	NOC	**0 232 103 069**
1.3 i 16V [P1]			**1,3 l 63 kW 2SZ-FE 4 Zyl.**
Phase sensor	05.02→	NOC	**0 232 103 036**
Wheel speed sensor, front	05.02→	LAB	**0 265 006 674**
		RAB	**0 265 006 675**
1.3 VVT-i [P9]			**1,3 l 64 kW 2SZ-FE 4 Zyl.**
Phase sensor	11.05→	NOC	**0 232 103 036**

T

Product			
◀ Yaris			
1.4 D Turbo [P1]			**1,4 l 55 kW 1ND-TV 4 Zyl.**
Phase sensor	10.01→		**0 281 002 406**
Wheel speed sensor, front	02.03→	LAB	**0 265 006 674**
		RAB	**0 265 006 675**
1.4 D-4D [P9]			**1,4 l 66 kW 1ND-TV 4 Zyl.**
Speed sensor, diesel	11.05→	NOC	**0 281 002 406**
Yaris Verso			
1.4 D Turbo [P2]			**1,4 l 55 kW 1ND-TV 4 Zyl.**
Phase sensor	08.01-09.05	FKW	**0 281 002 406**
UAZ			
Hunter			
2.2 D 4x4 [UAZ-315148]			**2,2 l 72 kW 5143.1 4 Zyl.**
Throttle valve sensor	01.06→		**0 280 122 001**
Speed sensor, ignition/injection	01.06→		**0 261 210 113**
2.7 i 4x4 [UAZ-315195]			**2,7 l 105 kW 409.10 4 Zyl.**
Throttle valve sensor	01.06→		**0 280 122 001**
Air mass meter, gasoline injection	01.06→	TW	**0 280 212 014**
			0 986 280 108
			0 280 218 037
			0 986 280 108
			0 986 280 108
Phase sensor	01.06→		**0 232 103 006**
Speed sensor, ignition/injection	01.06→		**0 261 210 113**
Knock sensor	01.06→		**0 261 231 046**
Pressure sensor, intake manifold, gasoline	01.06→	TW	**0 261 230 004**
			0 261 230 037
Patriot			
2.7 4x4 [UAZ-3163]			**2,7 l 105 kW 409.10 4 Zyl.**
Throttle valve sensor	09.05→		**0 280 122 001**
Air mass meter, gasoline injection	09.05→		**0 280 218 037**
		TW	**0 280 212 014**
			0 986 280 108
			0 280 218 037
			0 986 280 108
			0 986 280 108
Phase sensor	09.05→		**0 232 103 006**
Speed sensor, ignition/injection	09.05→		**0 261 210 113**
Knock sensor	09.05→		**0 261 231 046**
Pressure sensor, intake manifold, gasoline	09.05→	TW	**0 261 230 004**
			0 261 230 037
Acceleration sensor, ABS	09.06→		**0 265 005 146**
Wheel speed sensor, front	09.06→	LAB	**0 265 007 799**
		RAB	**0 265 007 800**
3160			
2.4 i			**2,4 l 66 kW 420.10 4 Zyl.**
Throttle valve sensor	08.97→		**0 280 122 001**
Air mass meter, gasoline injection	08.97→		**0 280 212 022**
			0 986 280 133
Phase sensor	08.97→		**0 232 103 006**
Knock sensor	08.97→		**0 261 231 046**

Product			
31605			
2.9 i			**2,9 l 75 kW 4213.10 4 Zyl.**
Throttle valve sensor	08.97→		**0 280 122 001**
Air mass meter, gasoline injection	08.97→		**0 280 212 022**
			0 986 280 133
Phase sensor	08.97→		**0 232 103 006**
Knock sensor	08.97→		**0 261 231 046**
VAUXHALL			
Agila			
1.0 i			**1,0 l 43 kW Z 10 XE 3 Zyl.**
Throttle valve assembly	09.99-08.03		**0 280 750 044**
Air mass meter, gasoline injection	09.99-08.03		**0 280 218 031**
			0 986 280 230
Phase sensor	09.99-08.03	NOC	**0 232 103 021**
Speed sensor, ignition/injection	09.99-08.03	FKW	**0 261 210 151**
Knock sensor	09.99-08.03		**0 261 231 120**
Temperature sensor, coolant, injection system			
Mot.no. →19T85744	09.99-08.03		**0 281 002 169**
Mot.no. 19T85745→	09.99-08.03		**0 281 002 170**
1.0 Twinport			**1,0 l 44 kW Z 10 XEP 3 Zyl.**
Throttle valve assembly	08.03-02.08		**0 280 750 133**
Air mass meter, gasoline injection	08.03-02.08		**0 280 218 119**
Phase sensor			
Fg.no. →5G999999	08.03-02.08	NOC	**0 232 103 052**
Fg.no. 6G000001→	08.03-02.08	NOC	**0 232 103 067**
Speed sensor, ignition/injection	08.03-02.08	FKW	**0 261 210 151**
Knock sensor	08.03-02.08		**0 261 231 173**
1.2 i			**1,2 l 55 kW Z 12 XE 4 Zyl.**
Throttle valve assembly	09.00-06.04		**0 280 750 044**
Air mass meter, gasoline injection	09.00-06.04		**0 280 218 031**
			0 986 280 230
Phase sensor	09.00-06.04	NOC	**0 232 103 021**
Speed sensor, ignition/injection	09.00-06.04	FKW	**0 261 210 151**
Knock sensor	09.00-06.04		**0 261 231 120**
Temperature sensor, coolant, injection system			
Mot.no. →19T85744	09.00-06.04		**0 281 002 169**
Mot.no. 19T85745→	09.00-06.04		**0 281 002 170**
1.2 Twinport			**1,2 l 59 kW Z 12 XEP 4 Zyl.**
Throttle valve assembly	07.04-02.08		**0 280 750 133**
Air mass meter, gasoline injection	07.04-02.08		**0 280 218 119**
Phase sensor	07.04-02.08	NOC	**0 232 103 052**
Speed sensor, ignition/injection	07.04-02.08	FKW	**0 261 210 151**
Knock sensor	07.04-02.08		**0 261 231 173**
Antara			
3.2 V6			**3,2 l 165 kW Z 32 SE 6 Zyl.**
Knock sensor	05.06→		**0 261 231 174**
Astra			
1.2 i [G]			**1,2 l 48 kW X 12 XE 4 Zyl.**
Throttle valve assembly	09.97-08.00		**0 205 003 050**
Throttle valve sensor	09.97-08.00		**0 280 122 014**
Air mass meter, gasoline injection	09.97-08.00		**0 280 217 123**
Phase sensor	09.97-08.00	NOC	**0 232 103 021**
Speed sensor, ignition/injection	09.97-08.00	FKW	**0 261 210 151**

Product			
Knock sensor	09.97-08.00		**0 261 231 120**
Temperature sensor, coolant, injection system	09.97-08.00		**0 281 002 169**
1.2 i [G]		**1,2 l 55 kW Z 12 XE 4 Zyl.**	
Air mass meter, gasoline injection	09.00-08.05		**0 280 218 031**
			0 986 280 230
Phase sensor	09.00-08.05	NOC	**0 232 103 021**
Speed sensor, ignition/injection	09.00-08.05	FKW	**0 261 210 151**
Knock sensor	09.00-08.05		**0 261 231 120**
Temperature sensor, coolant, injection system	09.00-08.05		**0 281 002 169**
1.2 Twinport [H]		**1,2 l 59 kW Z 12 XEP 4 Zyl.**	
Throttle valve assembly	03.07→		**0 280 750 133**
Air mass meter, gasoline injection	03.07→		**0 280 218 119**
Phase sensor	03.07→	NOC	**0 232 103 052**
Speed sensor, ignition/injection	03.07→	FKW	**0 261 210 151**
Knock sensor	03.07→		**0 261 231 173**
Temperature sensor, coolant, injection system	03.07→		**0 281 002 170**
1.3 [E]		**1,3 l 44 kW 13 N, NB 4 Zyl.**	
Wheel speed sensor, front	03.89-08.91		**0 265 006 488**
Wheel speed sensor, rear	03.89-08.91	LAB,LIM	**0 265 001 236**
		LIM,RAB	**0 265 001 235**
1.3 CDTI [H]		**1,3 l 66 kW Z 13 DTH 4 Zyl.**	
High-pressure sensor (CR system)	01.06→		**0 281 002 534**
Boost pressure sensor, Diesel	01.06→		**0 281 002 437**
1.3 i [E]		**1,3 l 44 kW C 13 N 4 Zyl.**	
Wheel speed sensor, front	03.89-08.91		**0 265 006 488**
Wheel speed sensor, rear	03.89-08.91	LAB,LIM	**0 265 001 236**
		LIM,RAB	**0 265 001 235**
1.4 i [E]		**1,4 l 44 kW C 14 NZ 4 Zyl.**	
Temperature sensor, coolant, injection system	01.90-08.91		**0 280 130 107**
1.4 i [F]		**1,4 l 44/60/66 kW C 14 NZ; X 14 NZ/XE; 14 SE/ C 14 SE 4 Zyl.**	
Temperature sensor, coolant, injection system	09.90-02.98		**0 280 130 107**
1.4 i [G]		**1,4 l 66 kW X 14 XE 4 Zyl.**	
Temperature sensor, coolant, injection system	09.97-08.00		**0 281 002 169**
1.4 i [H]		**1,4 l 55 kW Z 14 XEL 4 Zyl.**	
Throttle valve assembly	09.04→		**0 280 750 133**
Air mass meter, gasoline injection	09.04→		**0 280 218 119**
Phase sensor			
Fg.no. →52999999,→55999999, →58999999	09.04→	NOC	**0 232 103 052**
Fg.no. 62000001→,65000001→, 68000001→	09.04→	NOC	**0 232 103 067**
Speed sensor, ignition/injection	09.04→	FKW	**0 261 210 151**
Knock sensor	09.04→		**0 261 231 173**
Temperature sensor, coolant, injection system	09.04→		**0 281 002 170**
1.4 Twinport [H]		**1,4 l 66 kW Z 14 XEP 4 Zyl.**	
Throttle valve assembly	03.04→		**0 280 750 133**
Air mass meter, gasoline injection	03.04→		**0 280 218 119**
Phase sensor			
Fg.no. →42999999,→45999999, →48999999	03.04→	NOC	**0 232 103 021**
Fg.no. 52000001→52999999, 55000001→55999999, 58000001→58999999	03.04→	NOC	**0 232 103 052**
Fg.no. 62000001→,65000001→, 68000001→	03.04→	NOC	**0 232 103 067**
Speed sensor, ignition/injection	03.04→	FKW	**0 261 210 151**
Knock sensor	03.04→		**0 261 231 173**
Temperature sensor, coolant, injection system	03.04→		**0 281 002 170**
1.4 Twinport Dualfuel [H]		**1,4 l 66 kW Z 14 XEP 4 Zyl.**	
Throttle valve assembly	04.05→		**0 280 750 133**
Air mass meter, gasoline injection	04.05→		**0 280 218 119**

Product			
Phase sensor			
Fg.no. →42999999,→45999999, →48999999	04.05→	NOC	**0 232 103 021**
Fg.no. 52000001→52999999, 55000001→55999999, 58000001→58999999	04.05→	NOC	**0 232 103 052**
Fg.no. 62000001→,65000001→, 68000001→	04.05→	NOC	**0 232 103 067**
Speed sensor, ignition/injection	04.05→	FKW	**0 261 210 151**
Knock sensor	04.05→		**0 261 231 173**
Temperature sensor, coolant, injection system	04.05→		**0 281 002 170**
1.6 i [E]		**1,6 l 55 kW C 16 LZ; C 16 NZ; E 16 NZ 4 Zyl.**	
Temperature sensor, coolant, injection system			
Fg.no. J2791968→,J5273428→	09.84-12.91		**0 280 130 107**
1.6 i [F]		**1,6 l 52/55/74 kW C/E 16 NZ; C 16 SE; X 16 SZ/SZR; 16 LZ2/NZ2 4 Zyl.**	
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
1.6 i [F]		**1,6 l 74 kW X 16 XEL 4 Zyl.**	
Temperature sensor, coolant, injection system	01.94-02.98		**0 280 130 107**
1.6 i [G]		**1,6 l 55 kW X 16 SZR 4 Zyl.**	
Temperature sensor, coolant, injection system	09.97-08.05		**0 281 002 169**
1.6 i [G]		**1,6 l 62 kW Z 16 SE 4 Zyl.**	
Yaw rate sensor, brake system	09.00-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.00-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-08.05		**0 265 005 303**
1.6 i [G]		**1,6 l 74 kW C 16 SEL; X 16 XEL 4 Zyl.**	
Temperature sensor, coolant, injection system	09.97-08.05		**0 281 002 169**
1.6 i [G]		**1,6 l 74 kW Z 16 XE 4 Zyl.**	
Yaw rate sensor, brake system	09.00-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.00-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-08.05		**0 265 005 303**
1.6 i [G]		**1,6 l 74 kW Z 16 XEP 4 Zyl.**	
Yaw rate sensor, brake system	09.02-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.02-08.05		**0 265 005 435**
1.6 i Dualfuel [G]		**1,6 l 63-73 kW Z 16 YNG 4 Zyl.**	
Yaw rate sensor, brake system	09.02-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.02-08.05		**0 265 005 435**
1.6 Turbo [H]		**1,6 l 132 kW Z 16 LET 4 Zyl.**	
Air mass meter, gasoline injection	03.07→		**0 280 218 142**
Phase sensor	03.07→	NOC	**0 232 103 052**
Knock sensor	03.07→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	03.07→		**0 261 230 009**
1.7 CDTI 16V [G]		**1,7 l 59 kW Z 17 DTL 4 Zyl.**	
Air mass meter, diesel	03.03-08.05		**0 281 002 549**
1.7 DT [G]		**1,7 l 50 kW X 17 DTL 4 Zyl.**	
Air mass meter, diesel	03.98-08.00		**0 281 002 180**
Speed sensor, diesel	03.98-08.00		**0 281 002 285**
Temperature sensor, coolant, diesel	03.98-08.00		**0 281 002 259**
Accelerator pedal module	03.98-08.00	LLE	**0 281 002 278**
1.7 DTI [G]		**1,7 l 55 kW Y 17 DT 4 Zyl.**	
Air mass meter, diesel	09.00-08.05		**0 281 002 180**
1.8 i [E]		**1,8 l 74/82 kW C 18 NE; 18 E 4 Zyl.**	
Temperature sensor, coolant, injection system	09.84-08.91		**0 280 130 107**
1.8 i [E]		**1,8 l 82-85 kW 18 SE 4 Zyl.**	
Throttle valve sensor	09.86-08.91		**0 280 120 316**
Air flow sensor, gasoline injection	09.86-08.91		**0 280 202 602**
			0 986 280 019
Speed sensor, ignition/injection	09.86-08.91		**0 261 210 030**
Temperature sensor, coolant, injection system	09.86-08.91		**0 280 130 107**

V

Product			
◀ Astra			
1.8 i [F]			**1,8 l 66 kW C 18 NZ 4 Zyl.**
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
1.8 i [F]			**1,8 l 82 kW 18 SE 4 Zyl.**
Air mass meter, gasoline injection	06.96-02.98		**0 280 217 003**
Temperature sensor, intake air, injection system	06.96-02.98		**0 280 130 073**
1.8 i [G]			**1,8 l 92 kW Z 18 XE 4 Zyl.**
Yaw rate sensor, brake system	09.00-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.00-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-08.05		**0 265 005 303**
1.8 i Dualfuel [G]			**1,8 l 87-93 kW Z 18 XE 4 Zyl.**
Yaw rate sensor, brake system	09.02-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.02-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.02-08.05		**0 265 005 303**
1.9 CDTI [H]			**1,9 l 74 kW Z 19 ... 4 Zyl.**
Phase sensor	09.05→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	09.05→		**0 281 002 534**
1.9 CDTI [H]			**1,9 l 88 kW Z 19 DTJ 4 Zyl.**
High-pressure sensor (CR system)	03.04→		**0 281 002 534**
Pressure sensor, intake manifold, diesel	03.04→		**0 281 002 437**
1.9 CDTI [H]			**1,9 l 110 kW Z 19 DTH 4 Zyl.**
Pressure sensor, intake manifold, diesel	03.04→		**0 281 002 437**
2.0 DTI [G]			**2,0 l 74 kW Y 20 DTH 4 Zyl.**
Air mass meter, diesel			
Fg.no. →Y8999999,→YT999999	09.00-08.05		**0 281 002 180**
Mot.no. 12000001→,1T000001→	09.00-08.05		**0 281 002 428**
Speed sensor, diesel	09.00-08.05		**0 281 002 138**
Temperature sensor, coolant, diesel	09.00-08.05		**0 281 002 169**
Accelerator pedal module	09.00-08.05	GS,LLE	**0 281 002 278**
Yaw rate sensor, brake system	09.00-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.00-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-08.05		**0 265 005 303**
2.0 DTL [G]			**2,0 l 60 kW X 20 DTL 4 Zyl.**
Air mass meter, diesel			
Fg.no. →Y8999999,→YT999999	03.98-08.00		**0 281 002 180**
Mot.no. 12000001→,1T000001→	03.98-08.00		**0 281 002 428**
Speed sensor, diesel	03.98-08.00		**0 281 002 138**
Temperature sensor, coolant, diesel	03.98-08.00		**0 281 002 169**
Accelerator pedal module	03.98-08.00	AG,LLE	**0 281 002 236**
		AG,RLE	**0 281 002 237**
		GS,LLE	**0 281 002 278**
Yaw rate sensor, brake system			
Fg.no. →12999999,→1H999999	03.98-08.00		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)			
Fg.no. 22000001→,2H000001→	03.98-08.00		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	03.98-08.00		**0 265 005 303**
2.0 DTL [G]			**2,0 l 60 kW Y 20 DTL 4 Zyl.**
Air mass meter, diesel			
Mot.no. 12000001→,1T000001→	09.00-08.05		**0 281 002 428**
Speed sensor, diesel	09.00-08.05		**0 281 002 138**
Temperature sensor, coolant, diesel	09.00-08.05		**0 281 002 169**
Accelerator pedal module	09.00-08.05	AG,LLE	**0 281 002 236**
		AG,RLE	**0 281 002 237**
		GS,LLE	**0 281 002 278**
Yaw rate sensor, brake system	09.00-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.00-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-08.05		**0 265 005 303**
2.0 i [E]			**2,0 l 85 kW C 20 NE; 20 NE 4 Zyl.**
Temperature sensor, coolant, injection system	09.86-08.91		**0 280 130 107**

Product			
2.0 i [E]			**2,0 l 95 kW 20 SEH 4 Zyl.**
Throttle valve sensor	09.86-08.91		**0 280 120 316**
Air flow sensor, gasoline injection	09.86-08.91		**0 280 202 210**
			0 986 280 063
Speed sensor, ignition/injection	09.86-08.91		**0 261 210 030**
Pressure sensor, intake manifold, gasoline	09.86-08.91		**0 280 101 007**
Temperature sensor, coolant, injection system	09.86-08.91		**0 280 130 107**
2.0 i [E]			**2,0 l 110-115 kW C20 XE (XEJ); 20 XE 4 Zyl.**
Temperature sensor, coolant, injection system	05.88-08.91		**0 280 130 107**
2.0 i [F]			**2,0 l 85 kW C 20 NE , 20 NE 4 Zyl.**
Throttle valve sensor	09.91-02.98		**0 280 122 001**
Air mass meter, gasoline injection	09.91-02.98		**0 280 217 003**
Temperature sensor, intake air, injection system	09.91-02.98		**0 280 130 073**
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
2.0 i [F]			**2,0 l 110 kW C 20 XE,XE-LN 4 Zyl.**
Throttle valve sensor	09.91-02.98		**0 280 120 436**
Air mass meter, gasoline injection			
Mot.no. →14002934	09.91-02.98		**0 280 212 015**
			0 986 280 113
Mot.no. 14002935→	09.91-02.98		**0 280 217 106**
Temperature sensor, intake air, injection system	09.91-02.98		**0 280 130 073**
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
2.0 i [G]			**2,0 l 100 kW X 20 XEV 4 Zyl.**
Throttle valve sensor	09.97-08.05		**0 280 122 014**
Yaw rate sensor, brake system			
Fg.no. →12999999,→1H999999	09.97-08.05		**0 265 005 262**
Fg.no. 22000001→,2B000001→, 2H000001→	09.97-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)			
Fg.no. 22000001→,2H000001→	09.97-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.97-08.05		**0 265 005 303**
2.0 i [G]			**2,0 l 118 kW X 20 XER 4 Zyl.**
Yaw rate sensor, brake system	09.00-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.00-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-08.05		**0 265 005 303**
2.0 Turbo [G]			**2,0 l 141 kW Z 20 LET 4 Zyl.**
Air mass meter, gasoline injection	07.02-08.05		**0 280 218 051**
			0 986 280 231
Phase sensor	07.02-08.05		**0 232 103 015**
Speed sensor, ignition/injection	07.02-08.05	FKW	**0 261 210 150**
Knock sensor	07.02-08.05		**0 261 231 116**
Pressure sensor, intake manifold, gasoline	07.02-08.05		**0 261 230 009**
Temperature sensor, coolant, injection system	07.02-08.05		**0 281 002 169**
Yaw rate sensor, brake system	07.02-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	07.02-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	07.02-08.05		**0 265 005 303**
2.0 Turbo [H]			**2,0 l 125 kW Z 20 LEL 4 Zyl.**
Air mass meter, gasoline injection	03.04→		**0 280 218 142**
Phase sensor	03.04→	NOC	**0 232 103 015**
Speed sensor, ignition/injection	03.04→	FKW	**0 261 210 150**
Knock sensor	03.04→		**0 261 231 181**
2.0 Turbo [H]			**2,0 l 177 kW Z 20 LEH 4 Zyl.**
Air mass meter, gasoline injection			
Fg.no. →52999999,→55999999, →58999999	03.05→		**0 280 218 164**
Fg.no. 62000001→,65000001→, 68000001→	03.05→		**0 280 218 211**
Phase sensor	03.05→	NOC	**0 232 103 015**
Speed sensor, ignition/injection	03.05→	FKW	**0 261 210 150**
Knock sensor	03.05→		**0 261 231 181**

V

Product

Pressure sensor, intake manifold, gasoline	03.05→		**0 281 002 137**
Temperature sensor, coolant, injection system	03.05→		**0 281 002 169**
2.0 Turbo 16V [H]		**2,0 l 147 kW Z 20 LER 4 Zyl.**	
Air mass meter, gasoline injection	03.04→		**0 280 218 142**
Phase sensor	03.04→	NOC	**0 232 103 015**
Speed sensor, ignition/injection	03.04→	FKW	**0 261 210 150**
Knock sensor	03.04→		**0 261 231 181**
Pressure sensor, intake manifold, gasoline	03.04→		**0 281 002 137**
Temperature sensor, coolant, injection system	03.04→		**0 281 002 169**
2.2 DTI [G]		**2,2 l 92 kW Y 22 DTR 4 Zyl.**	
Yaw rate sensor, brake system	09.01-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.01-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.01-08.05		**0 265 005 303**
2.2 i [G]		**2,2 l 108 kW Z 22 SE 4 Zyl.**	
Yaw rate sensor, brake system	09.00-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.00-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-08.05		**0 265 005 303**

Astra Cabrio

1.6 i TwinTop [H]		**1,6 l 85 kW Z 16 XER 4 Zyl.**	
Pressure sensor, intake manifold, gasoline	03.07→		**0 261 230 009**
1.6 i TwinTop [H]		**1,6 l 132 kW Z 16 LET 4 Zyl.**	
Air mass meter, gasoline injection	03.07→		**0 280 218 142**
Phase sensor	03.07→	NOC	**0 232 103 052**
Pressure sensor, intake manifold, gasoline	03.07→		**0 261 230 009**
1.9 CDTi TwinTop [H]		**1,9 l 110 kW Z 19 DTH 4 Zyl.**	
High-pressure sensor (CR system)	09.05→		**0 281 002 706**
Boost pressure sensor, Diesel	09.05→		**0 281 002 437**
2.0 i Turbo TwinTop [H]		**2,0 l 125/147 kW Z 20 LEL; Z 20 LER 4 Zyl.**	
Air mass meter, gasoline injection	09.05→		**0 280 218 142**
Phase sensor	09.05→	NOC	**0 232 103 015**
Speed sensor, ignition/injection	09.05→	FKW	**0 261 210 150**
Knock sensor	09.05→		**0 261 231 181**
Pressure sensor, intake manifold, gasoline	09.05→		**0 281 002 137**
Temperature sensor, coolant, injection system	09.05→		**0 281 002 169**

Astra Convertible

1.4 i [F]		**1,4 l 44/60/66 kW C 14 NZ; X 14 XE; 14 SE/ C 14 SE 4 Zyl.**	
Temperature sensor, coolant, injection system	09.90-02.98		**0 280 130 107**
1.6 i [F]		**1,6 l 52/55/74 kW X 16 SZ; X 16 SZR; X 16 XEL; 16 LZ2,16NZ2 4 Zyl.**	
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
1.6 i [G]		**1,6 l 74 kW Z 16 XE 4 Zyl.**	
Yaw rate sensor, brake system	09.00-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.00-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-08.05		**0 265 005 303**
1.6 i Twinport [G]		**1,6 l 76 kW Z 16 XEP 4 Zyl.**	
Yaw rate sensor, brake system	03.03-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	03.03-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	03.03-08.05		**0 265 005 303**
1.8 i [F]		**1,8 l 66 kW C 18 NZ 4 Zyl.**	
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
1.8 i [G]		**1,8 l 92 kW Z 18 XE 4 Zyl.**	
Yaw rate sensor, brake system	09.00-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.00-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-08.05		**0 265 005 303**

Product

2.0 i [F]		**2,0 l 85 kW C 20 NE , 20 NE 4 Zyl.**	
Throttle valve sensor	09.91-02.98		**0 280 122 001**
Air mass meter, gasoline injection	09.91-02.98		**0 280 217 003**
Temperature sensor, intake air, injection system	09.91-02.98		**0 280 130 073**
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
2.0 i Turbo [G]		**2,0 l 141 kW Z 20 LET 4 Zyl.**	
Air mass meter, gasoline injection	03.02-08.05		**0 280 218 051**
			0 986 280 231
Phase sensor	03.02-08.05		**0 232 103 015**
Speed sensor, ignition/injection	03.02-08.05		**0 261 210 150**
Knock sensor	03.02-08.05		**0 261 231 116**
Temperature sensor, coolant, injection system	03.02-08.05		**0 281 002 169**
Yaw rate sensor, brake system	03.02-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	03.02-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	03.02-08.05		**0 265 005 303**
2.2 i [G]		**2,2 l 108 kW Z 22 SE 4 Zyl.**	
Yaw rate sensor, brake system	09.00-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.00-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-08.05		**0 265 005 303**

Astra Coupé

1.6 i Twinport [G]		**1,6 l 76 kW Z 16 XEP 4 Zyl.**	
Pressure sensor, ESP, (electronic stability program)	03.03-08.05		**0 265 005 303**
1.8 i [G]		**1,8 l 85/92 kW Z 18 XE; Z 18 XEL 4 Zyl.**	
Yaw rate sensor, brake system	09.00-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.00-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-08.05		**0 265 005 303**
1.8 i Dualfuel [G]		**1,8 l 87-93 kW Z 18 XE 4 Zyl.**	
Yaw rate sensor, brake system	09.02-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.02-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.02-08.05		**0 265 005 303**
2.0 i Turbo [G]		**2,0 l 141 kW Z 20 LET 4 Zyl.**	
Air mass meter, gasoline injection	09.00-08.05		**0 280 218 051**
			0 986 280 231
Phase sensor	09.00-08.05		**0 232 103 015**
Speed sensor, ignition/injection	09.00-08.05		**0 261 210 150**
Knock sensor	09.00-08.05		**0 261 231 116**
Temperature sensor, coolant, injection system	09.00-08.05		**0 281 002 169**
Yaw rate sensor, brake system	09.00-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.00-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-08.05		**0 265 005 303**
2.2 i [G]		**2,2 l 108 kW Z 22 SE 4 Zyl.**	
Yaw rate sensor, brake system	09.00-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.00-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-08.05		**0 265 005 303**

Astra Estate

1.2 Twinport [H]		**1,2 l 59 kW Z 12 XEP 4 Zyl.**	
Throttle valve assembly	03.07→		**0 280 750 133**
Air mass meter, gasoline injection	03.07→		**0 280 218 119**
Phase sensor	03.07→	NOC	**0 232 103 052**
Speed sensor, ignition/injection	03.07→	FKW	**0 261 210 151**
Knock sensor	03.07→		**0 261 231 173**
Temperature sensor, coolant, injection system	03.07→		**0 281 002 170**

V

Product

◀ Astra Estate

1.3 CDTI [H]			**1,3 l 66 kW Z 13 DTH 4 Zyl.**
High-pressure sensor (CR system)	06.05→		**0 281 002 534**
Boost pressure sensor, Diesel	06.05→		**0 281 002 437**
1.4 [H]			**1,4 l 55 kW Z 14 XEL 4 Zyl.**
Throttle valve assembly	09.04→		**0 280 750 133**
Air mass meter, gasoline injection	09.04→		**0 280 218 119**
Phase sensor			
Fg.no. →52999999,→55999999, →58999999	09.04→	NOC	**0 232 103 052**
Fg.no. 62000001→,65000001→, 68000001→	09.04→	NOC	**0 232 103 067**
Speed sensor, ignition/injection	09.04→	FKW	**0 261 210 151**
Knock sensor	09.04→		**0 261 231 173**
Temperature sensor, coolant, injection system	09.04→		**0 281 002 170**
1.4 i [F] 1,4 l 44/60/66 kW C 14 NZ; X 14 NZ; X 14 XE; 14 SE/ C 14 SE 4 Zyl.			
Temperature sensor, coolant, injection system	09.90-02.98		**0 280 130 107**
1.4 Twinport [H]			**1,4 l 66 kW Z 14 XEP 4 Zyl.**
Throttle valve assembly	08.04→		**0 280 750 133**
Air mass meter, gasoline injection	08.04→		**0 280 218 119**
Phase sensor			
Fg.no. →42999999,→45999999, →48999999	08.04→	NOC	**0 232 103 021**
Fg.no. 52000001→52999999, 55000001→55999999, 58000001→58999999	08.04→	NOC	**0 232 103 052**
Fg.no. 62000001→,65000001→, 68000001→	08.04→	NOC	**0 232 103 067**
Speed sensor, ignition/injection	08.04→	FKW	**0 261 210 151**
Knock sensor	08.04→		**0 261 231 173**
Temperature sensor, coolant, injection system	08.04→		**0 281 002 170**
1.6 i [F] 1,6 l 52/55/74 kW C/E 16 NZ; C 16 SE; X 16 SZ/SZR; 16 LZ2/Z2 4 Zyl.			
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
1.6 i [F]			**1,6 l 74 kW X 16 XEL 4 Zyl.**
Temperature sensor, coolant, injection system	01.94-02.98		**0 280 130 107**
1.6 i Dualfuel [G]			**1,6 l 63-73 kW Z 16 YNG 4 Zyl.**
Yaw rate sensor, brake system	09.02-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.02-08.05		**0 265 005 435**
1.6 Turbo [H]			**1,6 l 132 kW Z 16 LET 4 Zyl.**
Air mass meter, gasoline injection	09.07→		**0 280 218 142**
Phase sensor	09.07→	NOC	**0 232 103 052**
Knock sensor	09.07→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	09.07→		**0 261 230 009**
1.7 CDTI [G]			**1,7 l 59 kW Z 17 DTL 4 Zyl.**
Air mass meter, diesel	03.03-08.05		**0 281 002 549**
1.8 i [F]			**1,8 l 66 kW C 18 NZ 4 Zyl.**
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
1.8 i Dualfuel [G]			**1,8 l 87-93 kW Z 18 XE 4 Zyl.**
Yaw rate sensor, brake system	09.02-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.02-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.02-08.05		**0 265 005 303**
1.9 CDTI [H]			**1,9 l 74 kW Z 19 ... 4 Zyl.**
Phase sensor	09.05→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	09.05→		**0 281 002 534**
1.9 CDTI [H]			**1,9 l 88 kW Z 19 DTJ 4 Zyl.**
High-pressure sensor (CR system)	08.04→		**0 281 002 534**
Pressure sensor, intake manifold, diesel	08.04→		**0 281 002 437**
1.9 CDTI [H]			**1,9 l 110 kW Z 19 DTH 4 Zyl.**
Pressure sensor, intake manifold, diesel	08.04→		**0 281 002 437**
2.0 i [F]			**2,0 l 85 kW C 20 NE , 20 NE 4 Zyl.**
Throttle valve sensor	09.91-02.98		**0 280 122 001**
Air mass meter, gasoline injection	09.91-02.98		**0 280 217 003**

Product

Temperature sensor, intake air, injection system	09.91-02.98		**0 280 130 073**
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
2.0 i [F]			**2,0 l 110 kW C 20 XE,XE-LN 4 Zyl.**
Throttle valve sensor	09.91-02.98		**0 280 120 436**
Air mass meter, gasoline injection			
Mot.no. →14002934	09.91-02.98		**0 280 212 015**
			0 986 280 113
Mot.no. 14002935→	09.91-02.98		**0 280 217 106**
Temperature sensor, intake air, injection system	09.91-02.98		**0 280 130 073**
Temperature sensor, coolant, injection system	09.91-02.98		**0 280 130 107**
2.0 Turbo [G]			**2,0 l 141 kW Z 20 LET 4 Zyl.**
Air mass meter, gasoline injection	09.02-08.05		**0 280 218 051**
			0 986 280 231
Phase sensor	09.02-08.05		**0 232 103 015**
Speed sensor, ignition/injection	09.02-08.05		**0 261 210 150**
Knock sensor	09.02-08.05		**0 261 231 116**
Temperature sensor, coolant, injection system	09.02-08.05		**0 281 002 169**
Yaw rate sensor, brake system	09.02-08.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.02-08.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.02-08.05		**0 265 005 303**
2.0 Turbo [H]			**2,0 l 125 kW Z 20 LEL 4 Zyl.**
Air mass meter, gasoline injection	08.04→		**0 280 218 142**
Phase sensor	08.04→	NOC	**0 232 103 015**
Speed sensor, ignition/injection	08.04→	FKW	**0 261 210 150**
Knock sensor	08.04→		**0 261 231 181**
Pressure sensor, intake manifold, gasoline	08.04→		**0 281 002 137**
Temperature sensor, coolant, injection system	08.04→		**0 281 002 169**
2.0 Turbo [H]			**2,0 l 177 kW Z 20 LEH 4 Zyl.**
Air mass meter, gasoline injection			
Fg.no. →52999999,→55999999, →58999999	09.05→		**0 280 218 164**
Fg.no. 62000001→,65000001→, 68000001→	09.05→		**0 280 218 211**
Phase sensor	09.05→	NOC	**0 232 103 015**
Speed sensor, ignition/injection	09.05→	FKW	**0 261 210 150**
Knock sensor	09.05→		**0 261 231 181**
Pressure sensor, intake manifold, gasoline	09.05→		**0 281 002 137**
Temperature sensor, coolant, injection system	09.05→		**0 281 002 169**
2.0 Turbo 16V [H]			**2,0 l 147 kW Z 20 LER 4 Zyl.**
Air mass meter, gasoline injection	08.04→		**0 280 218 142**
Phase sensor	08.04→	NOC	**0 232 103 015**
Speed sensor, ignition/injection	08.04→	FKW	**0 261 210 150**
Knock sensor	08.04→		**0 261 231 181**
Pressure sensor, intake manifold, gasoline	08.04→		**0 281 002 137**
Temperature sensor, coolant, injection system	08.04→		**0 281 002 169**

Astra GTC

1.4 Twinport [H]			**1,4 l 55 kW Z 14 XEL 4 Zyl.**
Throttle valve assembly	09.05→		**0 280 750 133**
Air mass meter, gasoline injection	09.05→		**0 280 218 119**
Phase sensor			
Fg.no. →52999999,→55999999, →58999999	09.05→	NOC	**0 232 103 052**
Fg.no. 62000001→,65000001→, 68000001→	09.05→	NOC	**0 232 103 067**
Speed sensor, ignition/injection	09.05→	FKW	**0 261 210 151**
Knock sensor	09.05→		**0 261 231 173**
Temperature sensor, coolant, injection system	09.05→		**0 281 002 170**
1.4 Twinport [H]			**1,4 l 66 kW Z 14 XEP 4 Zyl.**
Throttle valve assembly	06.05→		**0 280 750 133**
Air mass meter, gasoline injection	06.05→		**0 280 218 119**

Product			
Phase sensor			
Fg.no. →42999999,→45999999, →48999999	06.05→	NOC	**0 232 103 021**
Fg.no. 52000001→52999999, 55000001→55999999, 58000001→58999999	06.05→	NOC	**0 232 103 052**
Fg.no. 62000001→,65000001→, 68000001→	06.05→	NOC	**0 232 103 067**
Speed sensor, ignition/injection	06.05→	FKW	**0 261 210 151**
Knock sensor	06.05→		**0 261 231 173**
Temperature sensor, coolant, injection system	06.05→		**0 281 002 170**
1.7 CDTI [H]	**1,7 l 59/74 kW Z 17 DTH; Z 17 DTL 4 Zyl.**		
Speed sensor, ignition/injection	06.05-03.07	FKW	**0 281 002 603**
1.9 CDTI [H]	**1,9 l 88 kW Z 19 DTJ 4 Zyl.**		
High-pressure sensor (CR system)	06.05→		**0 281 002 534**
Pressure sensor, intake manifold, diesel	06.05→		**0 281 002 437**
1.9 CDTI [H]	**1,9 l 110 kW Z 19 DTH 4 Zyl.**		
Pressure sensor, intake manifold, diesel	06.05→		**0 281 002 437**
2.0 Turbo [H]	**2,0 l 125 kW Z 20 LEL 4 Zyl.**		
Air mass meter, gasoline injection	06.05→		**0 280 218 142**
Phase sensor	06.05→	NOC	**0 232 103 015**
Speed sensor, ignition/injection	06.05→	FKW	**0 261 210 150**
Knock sensor	06.05→		**0 261 231 181**
Pressure sensor, intake manifold, gasoline	06.05→		**0 281 002 137**
Temperature sensor, coolant, injection system	06.05→		**0 281 002 169**
2.0 Turbo 16V [H]	**2,0 l 147 kW Z 20 LER 4 Zyl.**		
Air mass meter, gasoline injection	06.05→		**0 280 218 142**
Phase sensor	06.05→	NOC	**0 232 103 015**
Speed sensor, ignition/injection	06.05→	FKW	**0 261 210 150**
Knock sensor	06.05→		**0 261 231 181**
Pressure sensor, intake manifold, gasoline	06.05→		**0 281 002 137**
Temperature sensor, coolant, injection system	06.05→		**0 281 002 169**
2.0 Turbo 16V [H]	**2,0 l 177 kW Z 20 LEH 4 Zyl.**		
Air mass meter, gasoline injection			
Fg.no. →52999999,→55999999, →58999999	06.05→		**0 280 218 164**
Fg.no. 62000001→,65000001→, 68000001→	06.05→		**0 280 218 211**
Phase sensor	06.05→	NOC	**0 232 103 015**
Speed sensor, ignition/injection	06.05→	FKW	**0 261 210 150**
Knock sensor	06.05→		**0 261 231 181**
Pressure sensor, intake manifold, gasoline	06.05→		**0 281 002 137**
Temperature sensor, coolant, injection system	06.05→		**0 281 002 169**

Belmont

1.8 i	**1,8 l 82-85 kW 18 SE 4 Zyl.**		
Throttle valve sensor	09.86-09.93		**0 280 120 316**
Air flow sensor, gasoline injection	09.86-09.93		**0 280 202 602**
			0 986 280 019
Speed sensor, ignition/injection	09.86-09.93		**0 261 210 030**
Temperature sensor, coolant, injection system	09.86-09.93		**0 280 130 026**

Calibra

2.0 i	**2,0 l 85 kW C 20 NE 4 Zyl.**		
Throttle valve sensor	03.90-03.98		**0 280 120 316**
Temperature sensor, coolant, injection system	03.90-03.98		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. L1000001→M1999999	03.90-03.98		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. L1000001→M1999999	03.90-03.98	AA,LAB	**0 265 001 226**
		LAB,NAA	**0 265 001 233**
		NAA,RAB	**0 265 001 232**
Fg.no. N1000001→	03.90-03.98	AA,LAB	**0 265 006 487**
		AA,RAB	**0 265 006 486**
		LAB,NAA	**0 265 003 094**
		NAA,RAB	**0 265 003 093**
2.0 i	**2,0 l 100 kW X 20 XEV 4 Zyl.**		
Wheel speed sensor, front			
Fg.no. L1000001→M1999999	09.93-07.97		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. L1000001→M1999999	09.93-07.97	AA,LAB	**0 265 001 226**
		LAB,NAA	**0 265 001 233**
		NAA,RAB	**0 265 001 232**
Fg.no. N1000001→	09.93-07.97	AA,LAB	**0 265 006 487**
		AA,RAB	**0 265 006 486**
		LAB,NAA	**0 265 003 094**
		NAA,RAB	**0 265 003 093**
2.0 i	**2,0 l 110 kW C 20 XE,XE-LN 4 Zyl.**		
Throttle valve sensor	03.90-03.97		**0 280 120 326**
Air mass meter, gasoline injection			
Mot.no. →14002934	03.90-03.97		**0 280 212 015**
			0 986 280 113
Mot.no. 14002935→	03.90-03.97		**0 280 217 106**
Knock sensor	03.90-03.97		**0 261 231 006**
Temperature sensor, coolant, injection system	03.90-03.97		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. L1000001→M1999999	03.90-03.97		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. L1000001→M1999999	03.90-03.97	AA,LAB	**0 265 001 226**
		LAB,NAA	**0 265 001 233**
		NAA,RAB	**0 265 001 232**
Fg.no. N1000001→	03.90-03.97	AA,LAB	**0 265 006 487**
		AA,RAB	**0 265 006 486**
		LAB,NAA	**0 265 003 094**
		NAA,RAB	**0 265 003 093**
2.0 i turbo	**2,0 l 150 kW C 20 LET 4 Zyl.**		
Air mass meter, gasoline injection	03.92-07.97		**0 280 213 024**
			0 986 280 140
Temperature sensor, intake air, injection system	03.92-07.97		**0 280 130 039**
Temperature sensor, coolant, injection system	03.92-07.97		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. L1000001→M1999999	03.92-07.97		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. L1000001→M1999999	03.92-07.97	AA,LAB	**0 265 001 226**
		LAB,NAA	**0 265 001 233**
		NAA,RAB	**0 265 001 232**
Fg.no. N1000001→	03.92-07.97	AA,LAB	**0 265 006 487**
		AA,RAB	**0 265 006 486**
		LAB,NAA	**0 265 003 094**
		NAA,RAB	**0 265 003 093**
2.5 i	**2,5 l 125 kW C25XE,X25XE V6 6 Zyl.**		
Air mass meter, gasoline injection	04.93-03.97		**0 280 217 503**
Phase sensor			
Fg.no. →S1035178,→R9003232	04.93-03.97		**0 232 103 001**
Temperature sensor, coolant, injection system	04.93-03.97		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. L1000001→M1999999	04.93-03.97		**0 265 001 206**

V

Product

◀ Calibra

Wheel speed sensor, rear			
Fg.no. L1000001→M1999999	04.93-03.97	AA,LAB	**0 265 001 226**
		LAB,NAA	**0 265 001 233**
		NAA,RAB	**0 265 001 232**
Fg.no. N1000001→	04.93-03.97	AA,LAB	**0 265 006 487**
		AA,RAB	**0 265 006 486**
		LAB,NAA	**0 265 003 094**
		NAA,RAB	**0 265 003 093**

Carlton

1.8 [III]	**1,8 l 60/65-66 kW 18 NV; 18 SV /18NVR 4 Zyl.**		
Speed sensor, ignition/injection	09.86-10.94		**0 261 210 030**
Temperature sensor, coolant, injection system	09.86-10.94		**0 280 130 107**
Wheel speed sensor	09.86-10.94		**0 265 001 134**
Fg.no. J1185910→	09.86-10.94	VO	**0 265 001 220**
Fg.no. →J1185909	09.86-10.94	VO	**0 265 001 143**
1.8 i [III]	**1,8 l 85 kW 18 SEH 4 Zyl.**		
Throttle valve sensor	09.86-10.94		**0 280 120 316**
Air flow sensor, gasoline injection	09.86-10.94		**0 280 202 602**
			0 986 280 019
Speed sensor, ignition/injection	09.86-10.94		**0 261 210 030**
Temperature sensor, coolant, injection system	09.86-10.94		**0 280 130 107**
Wheel speed sensor	09.86-10.94		**0 265 001 134**
Fg.no. J1185910→	09.86-10.94	VO	**0 265 001 220**
Fg.no. →J1185909	09.86-10.94	VO	**0 265 001 143**
2.0 i [III]	**2,0 l 73-74/85 kW C 20 NE; C 20 NEJ/NEF 4 Zyl.**		
Air flow sensor, gasoline injection			
Fg.no. →L1019854	09.86-10.94		**0 280 202 210**
			0 986 280 063
Speed sensor, ignition/injection	09.86-10.94		**0 261 210 030**
Temperature sensor, coolant, injection system	09.86-10.94		**0 280 130 107**
Wheel speed sensor	09.86-10.94		**0 265 001 134**
Fg.no. J1185910→	09.86-10.94	VO	**0 265 001 220**
Fg.no. →J1185909	09.86-10.94	VO	**0 265 001 143**
2.0 i [III]	**2,0 l 90 kW 20 SE 4 Zyl.**		
Throttle valve sensor	09.86-10.94		**0 280 120 316**
Air flow sensor, gasoline injection	09.86-10.94		**0 280 202 210**
			0 986 280 063
Speed sensor, ignition/injection	09.86-10.94		**0 261 210 030**
Pressure sensor, intake manifold, gasoline	09.86-10.94		**0 280 101 007**
Temperature sensor, coolant, injection system	09.86-10.94		**0 280 130 107**
Wheel speed sensor	09.86-10.94		**0 265 001 134**
Fg.no. J1185910→	09.86-10.94	VO	**0 265 001 220**
Fg.no. →J1185909	09.86-10.94	VO	**0 265 001 143**
2.3 D [III]	**2,3 l 54 kW 23 YD 4 Zyl.**		
Temperature sensor, coolant, diesel	09.86-10.94	2PO	**0 280 130 107**
Wheel speed sensor	09.86-10.94		**0 265 001 134**
Fg.no. J1185910→	09.86-10.94	VO	**0 265 001 220**
Fg.no. →J1185909	09.86-10.94	VO	**0 265 001 143**
2.3 TD Interc. [III]	**2,3 l 74 kW 23 DTR 4 Zyl.**		
Temperature sensor, coolant, diesel	09.88-10.94	2PO	**0 280 130 107**
Wheel speed sensor	09.88-10.94		**0 265 001 134**
Fg.no. J1185910→	09.88-10.94	VO	**0 265 001 220**
Fg.no. →J1185909	09.88-10.94	VO	**0 265 001 143**
2.3 YTD [III]	**2,3 l 66 kW 23 YDT 4 Zyl.**		
Temperature sensor, coolant, diesel	09.86-09.88	2PO	**0 280 130 107**
Wheel speed sensor	09.86-09.88		**0 265 001 134**
Fg.no. J1185910→	09.86-09.88	VO	**0 265 001 220**
Fg.no. →J1185909	09.86-09.88	VO	**0 265 001 143**

Product

2.4 i [III]	**2,4 l 92 kW C 24 NE CIH 4 Zyl.**		
Air flow sensor, gasoline injection	09.86-10.94		**0 280 202 211**
			0 986 280 091
Temperature sensor, coolant, injection system	09.86-10.94		**0 280 130 107**
Wheel speed sensor	09.86-10.94		**0 265 001 134**
Fg.no. J1185910→	09.86-10.94	VO	**0 265 001 220**
Fg.no. →J1185909	09.86-10.94	VO	**0 265 001 143**
2.6 i [III]	**2,6 l 110 kW C 26 NE CIH 6 Zyl.**		
Temperature sensor, coolant, injection system	09.90-10.94		**0 280 130 107**
Wheel speed sensor	09.90-10.94		**0 265 001 134**
Fg.no. J1185910→	09.90-10.94	VO	**0 265 001 220**
Fg.no. →J1185909	09.90-10.94	VO	**0 265 001 143**
3.0 i [III]	**3,0 l 115 kW C 30 LE CIH 6 Zyl.**		
Air flow sensor, gasoline injection	03.87-12.87		**0 280 202 201**
Temperature sensor, coolant, injection system	03.87-12.87		**0 280 130 107**
3.0 i [III]	**3,0 l 130 kW C 30 NE CIH 6 Zyl.**		
Air flow sensor, gasoline injection	03.87-10.94		**0 280 203 032**
			0 986 280 074
Speed sensor, ignition/injection	03.87-10.94		**0 261 210 031**
Temperature sensor, coolant, injection system	03.87-10.94		**0 280 130 069**
Wheel speed sensor	03.87-10.94		**0 265 001 134**
Fg.no. J1185910→	03.87-10.94	VO	**0 265 001 220**
Fg.no. →J1185909	03.87-10.94	VO	**0 265 001 143**
3.0 i [III]	**3,0 l 130 kW 30 NE CIH 6 Zyl.**		
Temperature sensor, coolant, injection system	03.87-10.94		**0 280 130 069**
Wheel speed sensor	03.87-10.94		**0 265 001 134**
Fg.no. J1185910→	03.87-10.94	VO	**0 265 001 220**
Fg.no. →J1185909	03.87-10.94	VO	**0 265 001 143**
3.0 i [III]	**3,0 l 147-150 kW C 30 SE/SEJ 6 Zyl.**		
Air flow sensor, gasoline injection	01.89-10.94		**0 280 203 032**
			0 986 280 074
Temperature sensor, coolant, injection system	01.89-10.94		**0 280 130 107**
Wheel speed sensor	01.89-10.94		**0 265 001 134**
Fg.no. J1185910→	01.89-10.94	VO	**0 265 001 220**
Fg.no. →J1185909	01.89-10.94	VO	**0 265 001 143**

Cavalier

1.4 [III]	**1,4 l 55 kW 14 NV 4 Zyl.**		
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.88-11.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	09.88-11.95	L10,RAB	**0 265 001 207**
		L13,LAB	**0 265 001 208**
1.6 i [III]	**1,6 l 52 kW X 16 SZ 4 Zyl.**		
Temperature sensor, coolant, injection system	09.94-11.95		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.94-11.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	09.94-11.95	L10,RAB	**0 265 001 207**
		L13,LAB	**0 265 001 208**
1.6 i [III]	**1,6 l 55 kW C 16 LZ2 4 Zyl.**		
Speed sensor, ignition/injection	09.94-08.95		**0 261 210 030**
Temperature sensor, coolant, injection system	09.94-08.95		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.94-08.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	09.94-08.95	L10,RAB	**0 265 001 207**
		L13,LAB	**0 265 001 208**

Product			
1.6 i KAT [III]	**1,6 l 55-60 kW E16 NZ,C16 NZ 4 Zyl.**		
Temperature sensor, coolant, injection system	09.88-11.95		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.88-11.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	09.88-11.95	L10,RAB	**0 265 001 207**
		L13,LAB	**0 265 001 208**
1.6 S [III]	**1,6 l 60 kW 16 SV 4 Zyl.**		
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.88-08.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	09.88-08.95	L10,RAB	**0 265 001 207**
		L13,LAB	**0 265 001 208**
1.7 D [III]	**1,7 l 42 kW 17 D / DR 4 Zyl.**		
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.88-11.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	09.88-11.95	L10,RAB	**0 265 001 207**
		L13,LAB	**0 265 001 208**
1.7 TD [III]	**1,7 l 60 kW 17 DT/TC4 EE1 4 Zyl.**		
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.88-11.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	09.88-11.95	L10,RAB	**0 265 001 207**
		L13,LAB	**0 265 001 208**
1.8 [II]	**1,8 l 62 kW E 18 NV / S 18 NV 4 Zyl.**		
Temperature sensor, intake air, injection system	08.86-08.88		**0 280 130 107**
1.8 [III]	**1,8 l 66 kW 18 SV 4 Zyl.**		
Speed sensor, ignition/injection			
Fg.no. →P1999999,→P5999999, →P7999999	09.88-08.95		**0 261 210 030**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.88-08.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	09.88-08.95	L10,RAB	**0 265 001 207**
		L13,LAB	**0 265 001 208**
1.8 i [II]	**1,8 l 74 kW C 18 NE 4 Zyl.**		
Temperature sensor, intake air, injection system	01.85-08.86		**0 280 130 107**
1.8 i [II]	**1,8 l 82 kW 18 SE 4 Zyl.**		
Throttle valve sensor	09.86-08.88		**0 280 120 316**
Air flow sensor, gasoline injection	09.86-08.88		**0 280 202 602**
			0 986 280 019
Speed sensor, ignition/injection	09.86-08.88		**0 261 210 030**
Temperature sensor, intake air, injection system	09.86-08.88		**0 280 130 107**
1.8 i [II]	**1,8 l 85 kW 18 E 4 Zyl.**		
Temperature sensor, intake air, injection system	09.81-08.88		**0 280 130 107**
1.8 i [III]	**1,8 l 66 kW C 18 NZ 4 Zyl.**		
Speed sensor, ignition/injection			
Fg.no. →P1999999,→P5999999, →P7999999	09.88-11.95		**0 261 210 030**
Temperature sensor, coolant, injection system	09.88-11.95		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.88-11.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	09.88-11.95	L10,RAB	**0 265 001 207**
		L13,LAB	**0 265 001 208**

Product			
1.8 S [III]	**1,8 l 65 kW E 18 NVR 4 Zyl.**		
Speed sensor, ignition/injection	09.88-08.95		**0 261 210 030**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.88-08.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	09.88-08.95	L10,RAB	**0 265 001 207**
		L13,LAB	**0 265 001 208**
2.0 i [II]	**2,0 l 85/90-95 kW 20 NE,C 20 NE; 20 SE/ SEH 4 Zyl.**		
Throttle valve sensor	09.86-08.88		**0 280 120 316**
Air flow sensor, gasoline injection	09.86-08.88		**0 280 202 210**
			0 986 280 063
Speed sensor, ignition/injection	09.86-08.88		**0 261 210 030**
Pressure sensor, intake manifold, gasoline	09.86-08.88		**0 280 101 007**
Temperature sensor, intake air, injection system	09.86-08.88		**0 280 130 107**
2.0 i [III]	**2,0 l 85/86 kW C 20 NE; 20 NE 4 Zyl.**		
Speed sensor, ignition/injection			
Fg.no. →P1999999,→P5999999, →P7999999	09.88-11.95		**0 261 210 030**
Temperature sensor, coolant, injection system	09.88-11.95		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.88-11.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	09.88-11.95	L10,RAB	**0 265 001 207**
		L13,LAB	**0 265 001 208**
2.0 i [III]	**2,0 l 95 kW 20 SEH 4 Zyl.**		
Air flow sensor, gasoline injection	09.88-08.95		**0 280 202 210**
			0 986 280 063
Speed sensor, ignition/injection	09.88-08.95		**0 261 210 030**
Temperature sensor, coolant, injection system	09.88-08.95		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.88-08.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	09.88-08.95	L10,RAB	**0 265 001 207**
		L13,LAB	**0 265 001 208**
2.0 i 4x4 [III]	**2,0 l 95 kW 20 SEH 4 Zyl.**		
Air flow sensor, gasoline injection	09.88-08.95		**0 280 202 210**
			0 986 280 063
Speed sensor, ignition/injection	09.88-08.95		**0 261 210 030**
Temperature sensor, coolant, injection system	09.88-08.95		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.88-08.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. N1000001→	09.88-08.95	AA,LAB	**0 265 006 487**
		AA,RAB	**0 265 006 486**
Fg.no. →M1999999	09.88-08.95	AA,LAB	**0 265 001 226**
2.0 i 4x4 [III]	**2,0 l 150 kW C20LET 4 Zyl.**		
Speed sensor, ignition/injection	09.92-08.95		**0 261 210 030**
Knock sensor	09.92-08.95	MIL	**0 261 231 079**
		OHL	**0 261 231 006**
Temperature sensor, intake air, injection system	09.92-08.95		**0 280 130 039**
Temperature sensor, coolant, injection system	09.92-08.95		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.92-08.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. N1000001→	09.92-08.95	AA,LAB	**0 265 006 487**
		AA,RAB	**0 265 006 486**
Fg.no. →M1999999	09.92-08.95	AA,LAB	**0 265 001 226**

V

Product			
◀ Cavalier			
2.0 i 16V [III]			**2,0 l 100 kW X 20 XEV 4 Zyl.**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.93-11.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	09.93-11.95	L10,RAB	**0 265 001 207**
		L13,LAB	**0 265 001 208**
2.0 i 16V [III]			**2,0 l 110 kW C20XE(XEJ-LN); 20 XE/XEJ 4 Zyl.**
Throttle valve sensor			
Fg.no. →NV999999,→N1999999, →N5999999	09.88-08.95		**0 280 120 326**
Speed sensor, ignition/injection	09.88-11.95		**0 261 210 030**
Knock sensor	09.88-11.95	MIL	**0 261 231 079**
		OHL	**0 261 231 006**
Temperature sensor, intake air, injection system			
Fg.no. P1000001→,P5000001→, P7500001→	09.88-11.95		**0 280 130 073**
Temperature sensor, coolant, injection system	09.88-11.95		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.88-11.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. NV100001→NV999999, N1000001→N1999999, N5000001→N5999999	09.88-11.95	LAB	**0 265 003 094**
		RAB	**0 265 003 093**
Fg.no. →MV999999,→M1999999, →M5999999	09.88-11.95	LAB	**0 265 001 233**
		RAB	**0 265 001 232**
2.0 i 16V 4x4 [III]			**2,0 l 110 kW C 20 XE (XEJ-LN) 4 Zyl.**
Throttle valve sensor			
Fg.no. →NV999999,→N1999999, →N5999999	09.88-08.95		**0 280 120 326**
Speed sensor, ignition/injection	09.88-11.95		**0 261 210 030**
Knock sensor	09.88-11.95	MIL	**0 261 231 079**
		OHL	**0 261 231 006**
Temperature sensor, intake air, injection system			
Fg.no. P1000001→,P5000001→, P7500001→	09.88-11.95		**0 280 130 073**
Temperature sensor, coolant, injection system	09.88-11.95		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.88-11.95		**0 265 001 206**
Wheel speed sensor, rear			
Fg.no. N1000001→	09.88-11.95	AA,LAB	**0 265 006 487**
		AA,RAB	**0 265 006 486**
Fg.no. →M1999999	09.88-11.95	AA,LAB	**0 265 001 226**
2.5 i [III]			**2,5 l 125 kW C 25XE V6 6 Zyl.**
Phase sensor			
Fg.no. →S1035178	02.93-11.95		**0 232 103 001**
Knock sensor	02.93-11.95		**0 261 231 079**
Temperature sensor, intake air, injection system	02.93-11.95		**0 280 130 073**
Temperature sensor, coolant, injection system	02.93-11.95		**0 280 130 107**
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	02.93-11.95		**0 265 001 206**

Combo

1.2 i			**1,2 l 33 kW C 12 NZ; X 12 SZ; 12 NZ 4 Zyl.**
Temperature sensor, coolant, injection system			
Fg.no. W3000001→	09.94-10.01		**0 280 130 093**
Fg.no. →V6999999	09.94-10.01		**0 280 130 107**
1.3 CDTi [Tour]			**1,3 l 51/55 kW ... 13 DT; Z 13 DTJ 4 Zyl.**
Air mass meter, diesel	09.04→		**0 281 002 549**
High-pressure sensor (CR system)	09.04→		**0 281 002 534**
Pressure sensor, intake manifold, diesel			
Fg.no. →53999999,→54999999, →56999999	09.04→		**0 281 002 510**
Fg.no. 63000001→,64000001→, 66000001→	09.04→		**0 281 002 844**
1.4 i			**1,4 l 44/60/66 kW C 14 NZ; C 14 SE; C 14 SEL; X 14 SZ 4 Zyl.**
Temperature sensor, coolant, injection system			
Fg.no. W3000001→	09.94-10.01		**0 280 130 093**
Fg.no. →V6999999	09.94-10.01		**0 280 130 107**
1.4 i Twinport [Tour]			**1,4 l 66 kW Z 14 XEP 4 Zyl.**
Throttle valve assembly	01.04→		**0 280 750 133**
Air mass meter, gasoline injection	01.04→		**0 280 218 119**
Phase sensor			
Fg.no. →44999999,→46999999	01.04→	NOC	**0 232 103 021**
Fg.no. 54000001→,56000001→	01.04→	NOC	**0 232 103 052**
Speed sensor, ignition/injection	01.04→	FKW	**0 261 210 151**
Knock sensor	01.04→		**0 261 231 173**
Temperature sensor, coolant, injection system	01.04→		**0 281 002 170**
1.4 i Twinport Dualfuel [Tour]			**1,4 l 65 kW Z 14 XEP 4 Zyl.**
Throttle valve assembly	09.04→		**0 280 750 133**
Air mass meter, gasoline injection	09.04→		**0 280 218 119**
Phase sensor			
Fg.no. →44999999,→46999999	09.04→	NOC	**0 232 103 021**
Fg.no. 54000001→,56000001→	09.04→	NOC	**0 232 103 052**
Speed sensor, ignition/injection	09.04→	FKW	**0 261 210 151**
Knock sensor	09.04→		**0 261 231 173**
Temperature sensor, coolant, injection system	09.04→		**0 281 002 170**
1.6 CNG [Tour]			**1,6 l 69-71 kW Y 16 YNG 4 Zyl.**
Pressure sensor, ESP, (electronic stability program)	04.05→		**0 265 005 303**
1.6 i [Tour]			**1,6 l 69 kW Z 16 YNG 4 Zyl.**
Pressure sensor, ESP, (electronic stability program)	06.06→		**0 265 005 303**
1.7 CDTi [Tour]			**1,7 l 74 kW Z 17 DTH 4 Zyl.**
Air mass meter, diesel	09.04→		**0 281 002 549**
1.7 DI [Tour]			**1,7 l 48 kW Y 17 DTL Turbo 4 Zyl.**
Air mass meter, diesel	09.01-08.04		**0 281 002 180**
1.7 DTI [Tour]			**1,7 l 55 kW Y 17 DT Turbo 4 Zyl.**
Air mass meter, diesel	10.01-08.04		**0 281 002 180**

Corsa

1.0 i [B]			**1,0 l 40 kW X 10 XE 3 Zyl.**
Throttle valve sensor	09.96-09.00		**0 280 122 014**
Air mass meter, gasoline injection	09.96-09.00		**0 280 217 123**
Phase sensor	09.96-09.00	NOC	**0 232 103 021**
Speed sensor, ignition/injection	09.96-09.00	FKW	**0 261 210 151**
Knock sensor	09.96-09.00		**0 261 231 120**
Temperature sensor, coolant, injection system	09.96-09.00	KZB	**0 281 002 169**
1.0 i 12V [C]			**1,0 l 43 kW Z 10 XE 3 Zyl.**
Air mass meter, gasoline injection	09.00-08.03		**0 280 218 031**
			0 986 280 230
Phase sensor	09.00-08.03	NOC	**0 232 103 021**
Speed sensor, ignition/injection	09.00-08.03	FKW	**0 261 210 151**
Knock sensor	09.00-08.03		**0 261 231 120**
Temperature sensor, coolant, injection system			
Mot.no. →19T75858	09.00-08.03		**0 281 002 169**
Mot.no. 19T5859→	09.00-08.03		**0 281 002 170**
1.0 Twinport [C]			**1,0 l 44 kW Z 10 XEP 3 Zyl.**
Throttle valve assembly	09.03-08.05		**0 280 750 133**
Air mass meter, gasoline injection	09.03-08.05		**0 280 218 119**

Product			
Phase sensor	09.03-08.05	NOC,TW	**0 232 103 021**
Fg.no. →54999999,→56999999	09.03-08.05	NOC	**0 232 103 052**
Fg.no. 64000001→,66000001→	09.03-08.05	NOC	**0 232 103 067**
Speed sensor, ignition/injection	09.03-08.05	FKW	**0 261 210 151**
Knock sensor	09.03-08.05		**0 261 231 173**
Temperature sensor, coolant, injection system	09.03-08.05		**0 281 002 170**
Yaw rate sensor, brake system	09.03-08.05		**0 265 005 270**
1.0 Twinport [D]		**1,0 l 44 kW Z 10 XEP 3 Zyl.**	
Throttle valve assembly	07.06→		**0 280 750 133**
Phase sensor	07.06→	NOC	**0 232 103 067**
Knock sensor	07.06→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	07.06→		**0 261 230 101**
Temperature sensor, coolant, injection system	07.06→		**0 281 002 170**
Yaw rate sensor, brake system	07.06→	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Wheel speed sensor, front	07.06→		**0 265 007 671**
Wheel speed sensor, rear	07.06→	STB	**0 265 007 768**
		4SB	**0 265 007 769**
1.2 i [B]	**1,2 l 33 kW C 12 NZ; X 12 SZ; 12 NZ 4 Zyl.**		
Temperature sensor, coolant, injection system			
Fg.no. W3000001→	09.94-08.00		**0 280 130 093**
Fg.no. →V6999999	09.94-08.00		**0 280 130 107**
1.2 i [B]	**1,2 l 48 kW X 12 XE 4 Zyl.**		
Throttle valve sensor	09.97-08.00		**0 280 122 014**
Air mass meter, gasoline injection	09.97-08.00		**0 280 217 123**
Phase sensor	09.97-08.00	NOC	**0 232 103 021**
Speed sensor, ignition/injection	09.97-08.00	FKW	**0 261 210 151**
Knock sensor	09.97-08.00		**0 261 231 120**
Temperature sensor, coolant, injection system	09.97-08.00	KZB	**0 281 002 169**
1.2 i 16V [C]	**1,2 l 55 kW Z 12 XE 4 Zyl.**		
Air mass meter, gasoline injection	09.00-08.04		**0 280 218 031**
			0 986 280 230
Phase sensor	09.00-08.04	NOC	**0 232 103 021**
Speed sensor, ignition/injection	09.00-08.04	FKW	**0 261 210 151**
Knock sensor	09.00-08.04		**0 261 231 120**
Temperature sensor, coolant, injection system			
Mot.no. →19T75858	09.00-08.04		**0 281 002 169**
Mot.no. 19T5859→	09.00-08.04		**0 281 002 170**
1.2 Twinport [C]	**1,2 l 59 kW Z 12 XEP 4 Zyl.**		
Throttle valve assembly	09.04-09.06		**0 280 750 133**
Air mass meter, gasoline injection	09.04-09.06		**0 280 218 119**
Phase sensor	09.04-09.06	NOC,TW	**0 232 103 021**
Fg.no. →54999999,→56999999	09.04-09.06	NOC	**0 232 103 052**
Fg.no. 64000001→,66000001→	09.04-09.06	NOC	**0 232 103 067**
Speed sensor, ignition/injection	09.04-09.06	FKW	**0 261 210 151**
Knock sensor	09.04-09.06		**0 261 231 173**
Temperature sensor, coolant, injection system	09.04-09.06		**0 281 002 170**
Yaw rate sensor, brake system	09.04-09.06		**0 265 005 270**
Pressure sensor, ESP, (electronic stability program)	09.04-09.06		**0 265 005 303**
1.2 Twinport [D]	**1,2 l 59 kW Z 12 XEP 4 Zyl.**		
Throttle valve assembly	07.06→		**0 280 750 133**
Phase sensor	07.06→	NOC	**0 232 103 067**
Knock sensor	07.06→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	07.06→		**0 261 230 101**
Temperature sensor, coolant, injection system	07.06→		**0 281 002 170**
Yaw rate sensor, brake system	07.06→	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Wheel speed sensor, front	07.06→		**0 265 007 671**
Wheel speed sensor, rear	07.06→	STB	**0 265 007 768**
		4SB	**0 265 007 769**
1.2 Twinport Dualfuel [C]	**1,2 l 59 kW Z 12 XEP 4 Zyl.**		
Throttle valve assembly	09.04-09.06		**0 280 750 133**
Air mass meter, gasoline injection	09.04-09.06		**0 280 218 119**

Product			
Phase sensor	09.04-09.06	NOC,TW	**0 232 103 021**
Fg.no. →54999999,→56999999	09.04-09.06	NOC	**0 232 103 052**
Fg.no. 64000001→,66000001→	09.04-09.06	NOC	**0 232 103 067**
Speed sensor, ignition/injection	09.04-09.06	FKW	**0 261 210 151**
Knock sensor	09.04-09.06		**0 261 231 173**
Temperature sensor, coolant, injection system	09.04-09.06		**0 281 002 170**
Yaw rate sensor, brake system	09.04-09.06		**0 265 005 270**
Pressure sensor, ESP, (electronic stability program)	09.04-09.06		**0 265 005 303**
1.2 16V Dualfuel [C]	**1,2 l 55 kW Z 12 XE 4 Zyl.**		
Air mass meter, gasoline injection	08.01-08.04		**0 280 218 031**
			0 986 280 230
Phase sensor	08.01-08.04	NOC	**0 232 103 021**
Speed sensor, ignition/injection	08.01-08.04	FKW	**0 261 210 151**
Knock sensor	08.01-08.04		**0 261 231 120**
Temperature sensor, coolant, injection system			
Mot.no. →19T75858	08.01-08.04		**0 281 002 169**
Mot.no. 19T5859→	08.01-08.04		**0 281 002 170**
1.3 CDTI [C]	**1,3 l 51 kW ... 13 DT 4 Zyl.**		
Air mass meter, diesel	09.03-09.06		**0 281 002 549**
High-pressure sensor (CR system)	09.03-09.06		**0 281 002 534**
Pressure sensor, intake manifold, diesel	09.03-09.06		**0 281 002 510**
Yaw rate sensor, brake system	09.03-09.06		**0 265 005 270**
1.3 CDTI [C]	**1,3 l 55 kW Z 13 DTJ 4 Zyl.**		
High-pressure sensor (CR system)	09.05-09.06		**0 281 002 706**
Pressure sensor, intake manifold, diesel	09.05-09.06		**0 281 002 510**
Pressure sensor, ESP, (electronic stability program)	09.05-09.06		**0 265 005 303**
1.3 CDTI [D]	**1,3 l 55/66 kW A 13 DTH; A 13 DTJ; Z 13 DTJ 4 Zyl.**		
High-pressure sensor (CR system)	07.06→		**0 281 002 706**
Pressure sensor, intake manifold, diesel	07.06→		**0 281 002 844**
Yaw rate sensor, brake system	07.06→	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Wheel speed sensor, front	07.06→		**0 265 007 671**
Wheel speed sensor, rear	07.06→	STB	**0 265 007 768**
		4SB	**0 265 007 769**
1.3 CDTI [D]	**1,3 l 66 kW Z 13 DTH 4 Zyl.**		
High-pressure sensor (CR system)	07.06→		**0 281 002 706**
Boost pressure sensor, Diesel	07.06→		**0 281 002 437**
Pressure sensor, intake manifold, diesel	07.06→		**0 281 002 844**
Yaw rate sensor, brake system	07.06→	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Wheel speed sensor, front	07.06→		**0 265 007 671**
Wheel speed sensor, rear	07.06→	STB	**0 265 007 768**
		4SB	**0 265 007 769**
1.4 i [B]	**1,4 l 44 kW C 14 NZ; X 14 SZ 4 Zyl.**		
Temperature sensor, intake air, injection system			
Fg.no. W3000001→	09.94-08.00		**0 280 130 093**
Fg.no. →V6999999	09.94-08.00		**0 280 130 107**
Temperature sensor, coolant, injection system	09.94-08.00	KOB	**0 280 130 093**
Fg.no. W3000001→	09.94-08.00		**0 280 130 093**
Fg.no. →V6999999	09.94-08.00		**0 280 130 107**
1.4 i [B]	**1,4 l 60/63 kW C 14 SE; C 14 SEL 4 Zyl.**		
Temperature sensor, coolant, injection system			
Fg.no. W3000001→	09.94-08.00		**0 280 130 093**
Fg.no. →V6999999	09.94-08.00		**0 280 130 107**
1.4 i [B]	**1,4 l 66 kW X 14 XE 4 Zyl.**		
Temperature sensor, coolant, injection system	09.94-08.99	KOB	**0 280 130 093**
Fg.no. W3000001→	09.94-08.99		**0 280 130 093**
Fg.no. →V6999999	09.94-08.99		**0 280 130 107**
1.4 Twinport [C]	**1,4 l 66 kW Z 14 XEP 4 Zyl.**		
Throttle valve assembly	09.03-08.05		**0 280 750 133**
Air mass meter, gasoline injection	09.03-08.05		**0 280 218 119**
Phase sensor	09.03-08.05	NOC	**0 232 103 021**
Speed sensor, ignition/injection	09.03-08.05	FKW	**0 261 210 151**

V

Product

◀ Corsa

Knock sensor	09.03-08.05		**0 261 231 173**
Temperature sensor, coolant, injection system	09.03-08.05		**0 281 002 170**
Yaw rate sensor, brake system	09.03-08.05		**0 265 005 270**
1.4 Twinport [D]		**1,4 l 66 kW Z 14 XEP 4 Zyl.**	
Throttle valve assembly	07.06→		**0 280 750 133**
Phase sensor	07.06→	NOC	**0 232 103 067**
Knock sensor	07.06→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	07.06→		**0 261 230 101**
Temperature sensor, coolant, injection system	07.06→		**0 281 002 170**
Yaw rate sensor, brake system	07.06→	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Wheel speed sensor, front	07.06→		**0 265 007 671**
Wheel speed sensor, rear	07.06→	STB	**0 265 007 768**
		4SB	**0 265 007 769**
1.6 Dualfuel [C]		**1,6 l 71 kW Y 16 YNG; Z 16 YNG 4 Zyl.**	
Yaw rate sensor, brake system	03.06-09.06		**0 265 005 270**
Pressure sensor, ESP, (electronic stability program)	03.06-09.06		**0 265 005 303**
1.6 GSI [B]		**1,6 l 80 kW C 16 XE 4 Zyl.**	
Temperature sensor, coolant, injection system			
Fg.no. →V6999999	09.94-08.00		**0 280 130 107**
1.6 i [B]		**1,6 l 74/78 kW C 16 SEL; X 16 XE 4 Zyl.**	
Temperature sensor, coolant, injection system			
Fg.no. W3000001→	09.94-08.00		**0 280 130 093**
Fg.no. →V6999999	09.94-08.00		**0 280 130 107**
1.6 i OPC Turbo [D]		**1,6 l 141 kW Z 16 LER 4 Zyl.**	
Air mass meter, gasoline injection	02.07→		**0 280 218 142**
Phase sensor	02.07→	NOC	**0 232 103 052**
Knock sensor	02.07→		**0 261 231 173**
Yaw rate sensor, brake system	02.07→	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Wheel speed sensor, front	02.07→		**0 265 007 671**
Wheel speed sensor, rear	02.07→	STB	**0 265 007 768**
		4SB	**0 265 007 769**
1.7 CDTI [C]		**1,7 l 74 kW Z 17 DTH 4 Zyl.**	
Air mass meter, diesel	09.03-08.05		**0 281 002 549**
Yaw rate sensor, brake system	09.03-08.05		**0 265 005 270**
1.7 CDTI [D]		**1,7 l 92 kW A 17 DTR; Z 17 DTR 4 Zyl.**	
Yaw rate sensor, brake system	07.06→	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Wheel speed sensor, front	07.06→		**0 265 007 671**
Wheel speed sensor, rear	07.06→	STB	**0 265 007 768**
		4SB	**0 265 007 769**
1.7 DI [C]		**1,7 l 48 kW Y 17 DTL 4 Zyl.**	
Air mass meter, diesel	09.00-08.03		**0 281 002 180**
1.7 DTI [C]		**1,7 l 55 kW Y 17 DT 4 Zyl.**	
Air mass meter, diesel	09.00-08.03		**0 281 002 180**
1.8 i 16V [C]		**1,8 l 92 kW Z 18 XE 4 Zyl.**	
Yaw rate sensor, brake system	09.01-08.05		**0 265 005 270**
Pressure sensor, ESP, (electronic stability program)	09.01-08.05		**0 265 005 303**

Frontera

2.0 i [A]		**2,0 l 85 kW C 20 NE 4 Zyl.**	
Throttle valve sensor	01.92-08.95		**0 280 122 001**
Air flow sensor, gasoline injection			
Fg.no. →NV522066	01.92-08.95		**0 280 202 210**
			0 986 280 063
Speed sensor, ignition/injection	01.92-08.95		**0 261 210 030**
Temperature sensor, coolant, injection system	01.92-08.95		**0 280 130 107**
2.0 i [A]		**2,0 l 85 kW X 20 SE 4 Zyl.**	
Throttle valve sensor	02.95-08.98		**0 280 122 001**
Air mass meter, gasoline injection	02.95-08.98		**0 280 217 003**

Product

Speed sensor, ignition/injection	02.95-08.98		**0 261 210 030**
Knock sensor	02.95-08.98		**0 261 231 007**
2.2 DTI [B]		**2,2 l 85/88 kW X 22 DTH; Y 22 DTH 4 Zyl.**	
Air mass meter, diesel	09.98-09.04		**0 281 002 184**
Speed sensor, diesel	09.98-09.04		**0 281 002 138**
Temperature sensor, coolant, diesel	09.98-09.04		**0 281 002 169**
Temperature sensor, intake air, diesel	09.98-09.04		**0 261 230 009**
2.2 i [A]		**2,2 l 100 kW X 22 XE 4 Zyl.**	
Throttle valve sensor	02.95-08.98		**0 280 122 001**
Air mass meter, gasoline injection	02.95-08.98		**0 280 217 003**
Speed sensor, ignition/injection			
Fg.no. →TV899999	02.95-08.98		**0 261 210 030**
Knock sensor	02.95-08.98		**0 261 231 007**
Temperature sensor, coolant, injection system	02.95-08.98		**0 280 130 107**
2.3 TD [A]		**2,3 l 74 kW 23 DT 4 Zyl.**	
Air mass meter, diesel	01.92-08.95		**0 281 002 144**
2.4 i [A]		**2,4 l 92 kW C 24 NE CIH 4 Zyl.**	
Throttle valve sensor	01.92-08.95		**0 280 122 001**
Air flow sensor, gasoline injection	01.92-08.95		**0 280 202 211**
			0 986 280 091
Speed sensor, ignition/injection	01.92-08.95		**0 261 210 031**
Temperature sensor, coolant, injection system	01.92-08.95		**0 280 130 107**
2.5 TDS Turbo [A]		**2,5 l 85 kW Venturi-25TD VM41B 4 Zyl.**	
Air mass meter, diesel	06.96-08.98		**0 281 002 144**
Pedal position sensor, diesel	06.96-08.98	LLE	**0 205 001 055**
		RLE	**0 205 001 054**

Meriva

1.3 CDTI		**1,2 l 55 kW ... 13 DT 4 Zyl.**	
Air mass meter, diesel	09.05→		**0 281 002 620**
High-pressure sensor (CR system)	09.05→		**0 281 002 706**
Yaw rate sensor, brake system			
Fg.no. →44999999	09.05→		**0 265 005 262**
Fg.no. 54000001→54999999	09.05→		**0 265 005 270**
Fg.no. 64000001→	09.05→	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Pressure sensor, ESP, (electronic stability program)	09.05→		**0 265 005 303**
1.3 CDTI		**1,2 l 55 kW Z 13 DTJ 4 Zyl.**	
High-pressure sensor (CR system)	09.03→		**0 281 002 706**
Yaw rate sensor, brake system			
Fg.no. →44999999	09.03→		**0 265 005 262**
Fg.no. 54000001→54999999	09.03→		**0 265 005 270**
Fg.no. 64000001→	09.03→	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Pressure sensor, ESP, (electronic stability program)	09.03→		**0 265 005 303**
1.4 16V Twinport		**1,4 l 66 kW Z 14 XEP 4 Zyl.**	
Throttle valve assembly	07.04→		**0 280 750 133**
Air mass meter, gasoline injection	07.04→		**0 280 218 119**
Phase sensor			
Fg.no. →44999999	07.04→	NOC	**0 232 103 021**
Fg.no. 54000001→54999999	07.04→	NOC	**0 232 103 052**
Fg.no. 64000001→	07.04→	NOC	**0 232 103 067**
Speed sensor, ignition/injection	07.04→	FKW	**0 261 210 151**
Knock sensor	07.04→		**0 261 231 173**
Temperature sensor, coolant, injection system	07.04→		**0 281 002 170**
Yaw rate sensor, brake system	07.04→		**0 265 005 262**
Pressure sensor, ESP, (electronic stability program)	07.04→		**0 265 005 303**
1.6 i		**1,6 l 64 kW Z 16 SE 4 Zyl.**	
Yaw rate sensor, brake system	03.03-09.05		**0 265 005 262**
1.6 i OPC Turbo		**1,6 l 132 kW Z 16 LET 4 Zyl.**	
Air mass meter, gasoline injection	09.05→		**0 280 218 142**
Phase sensor	09.05→	NOC	**0 232 103 052**

Product			
Knock sensor	09.05→		**0 261 231 173**
Pressure sensor, intake manifold, gasoline	09.05→		**0 281 002 137**
Yaw rate sensor, brake system			
Fg.no. →44999999	09.05→		**0 265 005 262**
Fg.no. 54000001→54999999	09.05→		**0 265 005 270**
Fg.no. 64000001→	09.05→	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Pressure sensor, ESP, (electronic stability program)	09.05→		**0 265 005 303**
1.6 i 16V			**1,6 l 74 kW Z 16 XE 4 Zyl.**
Yaw rate sensor, brake system	03.03-02.06		**0 265 005 262**
1.6 i 16V			**1,6 l 77 kW Z 16 XEP 4 Zyl.**
Yaw rate sensor, brake system			
Fg.no. →44999999	01.06→		**0 265 005 262**
Fg.no. 54000001→54999999	01.06→		**0 265 005 270**
Fg.no. 64000001→	01.06→	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Pressure sensor, ESP, (electronic stability program)	01.06→		**0 265 005 303**
1.7 CDTI			**1,7 l 74 kW Z 17 DTH 4 Zyl.**
Air mass meter, diesel	09.03-09.05		**0 281 002 620**
Yaw rate sensor, brake system	09.03-09.05		**0 265 005 262**
1.7 CDTI			**1,7 l 92 kW A 17 ...; Z 17 ... 4 Zyl.**
Yaw rate sensor, brake system			
Fg.no. →44999999	09.06→		**0 265 005 262**
Fg.no. 54000001→54999999	09.06→		**0 265 005 270**
Fg.no. 64000001→	09.06→	MBH	**0 265 005 657**
		NBA	**0 265 005 656**
Pressure sensor, ESP, (electronic stability program)	09.06→		**0 265 005 303**
1.7 DTI			**1,7 l 55 kW Y 17 DT 4 Zyl.**
Yaw rate sensor, brake system	03.03-09.05		**0 265 005 262**
1.8 i 16V			**1,8 l 92 kW Z 18 XE 4 Zyl.**
Yaw rate sensor, brake system	03.03→		**0 265 005 262**

Nova

1.2 i			**1,2 l 33 kW C 12 NZ 4 Zyl.**
Temperature sensor, coolant, injection system	09.90-08.94		**0 280 130 107**
1.4 i			**1,4 l 44/60 kW C 14 NZ; C 14 SE 4 Zyl.**
Temperature sensor, coolant, injection system	01.90-08.94		**0 280 130 107**
1.6 i			**1,6 l 55/74 kW C 16 NZ; E 16 SE 4 Zyl.**
Temperature sensor, coolant, injection system	05.88-08.94		**0 280 130 107**

Omega

2.0 DTI [B]			**2,0 l 74 kW X 20 DTH Turbo 4 Zyl.**
Air mass meter, diesel	09.97-08.00		**0 281 002 180**
Speed sensor, diesel	09.97-08.00		**0 281 002 138**
Temperature sensor, coolant, diesel	09.97-08.00		**0 281 002 169**
Pedal position sensor, diesel			
Fg.no. →V1999999	09.97-08.00		**0 205 001 039**
2.0 i [B]			**2,0 l 85 kW X 20 SE; 20 SE 4 Zyl.**
Throttle valve sensor	04.94-12.00		**0 280 122 001**
Air mass meter, gasoline injection	04.94-12.00		**0 280 217 106**
Knock sensor	04.94-12.00		**0 261 231 006**
Temperature sensor, intake air, injection system	04.94-12.00		**0 280 130 073**
Temperature sensor, coolant, injection system	04.94-12.00		**0 280 130 107**
2.0 i [B]			**2,0 l 100 kW X 20 XEV 4 Zyl.**
Throttle valve sensor	09.93-08.99		**0 280 122 001**
2.2 DTI [B]			**2,2 l 88 kW Y 22 DTH Turbo 4 Zyl.**
Air mass meter, diesel	06.00-09.03		**0 281 002 428**
Speed sensor, diesel	06.00-09.03		**0 281 002 138**
Pedal position sensor, diesel	06.00-09.03		**0 280 752 027**

Product			
2.5 i [B]			**2,5 l 125 kW X 25 XE 6 Zyl.**
Throttle valve sensor			
Fg.no. V1000001→	04.94-09.04		**0 280 122 014**
Fg.no. →T1999999	04.94-09.04		**0 280 122 001**
Air mass meter, gasoline injection			
Mot.no. →01837540	04.94-09.04		**0 280 217 503**
Mot.no. 08137541→	04.94-09.04		**0 280 217 519**
Phase sensor	04.94-09.04	MTS	**0 232 103 008**
		OTS	**0 232 103 001**
Mot.no. →08149313	04.94-09.04		**0 232 103 008**
Mot.no. 08149314→	04.94-09.04		**0 232 103 017**
Knock sensor			
Mot.no. →08137540	04.94-09.04		**0 261 231 079**
Mot.no. 08137541→	04.94-09.04		**0 261 231 116**
Temperature sensor, intake air, injection system			
Mot.no. →08137540	04.94-09.04		**0 280 130 073**
Mot.no. 08137541→	04.94-09.04		**0 280 130 092**
Temperature sensor, coolant, injection system			
Mot.no. →08137540	04.94-09.04		**0 280 130 107**
Mot.no. 08137541→	04.94-09.04		**0 280 130 093**
2.5 TD [B]			**2,5 l 96 kW U 25 TD -R6 Turbo 6 Zyl.**
Pedal position sensor, diesel			
Fg.no. S1155598→	04.94-02.01	LLE	**0 205 001 039**
Fg.no. S1156241→	04.94-02.01	RLE	**0 205 001 039**
Fg.no. →S1155597	04.94-02.01	LLE	**0 205 001 019**
Fg.no. →S1156240	04.94-02.01	RLE	**0 205 001 019**
2.5 TDI [B]			**2,5 l 96 kW X 25 TD Turbo 6 Zyl.**
Pedal position sensor, diesel			
Fg.no. S1155598→	04.96-09.04	LLE	**0 205 001 039**
Fg.no. S1156241→	04.96-09.04	RLE	**0 205 001 039**
Fg.no. →S1155597	04.96-09.04	LLE	**0 205 001 019**
Fg.no. →S1156240	04.96-09.04	RLE	**0 205 001 019**
2.5 TDI [B]			**2,5 l 110 kW Y 25 TD Turbo 6 Zyl.**
Air mass meter, diesel	09.01-09.04		**0 281 002 564**
2.6 i [B]			**2,6 l 132 kW Y 26 SE 6 Zyl.**
Air mass meter, gasoline injection	09.00-09.04		**0 281 002 184**
Phase sensor	09.00-09.04		**0 232 103 025**
Speed sensor, ignition/injection			
Mot.no. 08149314→	09.00-09.04		**0 261 210 131**
Knock sensor			
Mot.no. 08137541→	09.00-09.04		**0 261 231 116**
3.0 i [B]			**3,0 l 155 kW X 30 XE 6 Zyl.**
Throttle valve sensor			
Fg.no. V1000001→	04.94-02.01		**0 280 122 014**
Fg.no. →T1999999	04.94-02.01		**0 280 122 001**
Air mass meter, gasoline injection			
Mot.no. →01837540	04.94-02.01		**0 280 217 503**
Mot.no. 08137541→	04.94-02.01		**0 280 217 519**
Phase sensor	04.94-02.01	MTS	**0 232 103 008**
		OTS	**0 232 103 001**
Mot.no. →08149313	04.94-02.01		**0 232 103 008**
Mot.no. 08149314→	04.94-02.01		**0 232 103 017**
Speed sensor, ignition/injection			
Mot.no. 08149314→	04.94-02.01		**0 261 210 131**
Knock sensor			
Mot.no. →08137540	04.94-02.01		**0 261 231 079**
Mot.no. 08137541→	04.94-02.01		**0 261 231 116**
Temperature sensor, intake air, injection system			
Mot.no. →08137540	04.94-02.01		**0 280 130 073**
Mot.no. 08137541→	04.94-02.01		**0 280 130 092**
Temperature sensor, coolant, injection system			
Mot.no. →08137540	04.94-02.01		**0 280 130 107**
Mot.no. 08137541→	04.94-02.01		**0 280 130 093**

V

Product

◀ Omega

3.2 i [B]			**3,2 l 160 kW Y 32 SE 6 Zyl.**
Air mass meter, gasoline injection	09.00-09.04		**0 281 002 184**
Phase sensor	09.00-09.04		**0 232 103 025**
Speed sensor, ignition/injection			
Mot.no. 08149314→	09.00-09.04		**0 261 210 131**
Knock sensor			
Mot.no. 08137541→	09.00-09.04		**0 261 231 116**

Senator

2.5 i [B]			**2,5 l 103 kW 25 NE CIH 6 Zyl.**
Air flow sensor, gasoline injection	09.87-10.90		**0 280 202 053**
Temperature sensor, coolant, injection system	09.87-10.90		**0 280 130 069**
2.6 i [B]			**2,6 l 110 kW C 26 NE CIH 6 Zyl.**
Air flow sensor, gasoline injection	09.90-08.93		**0 280 202 207**
Temperature sensor, coolant, injection system	09.90-08.93		**0 280 130 107**
3.0 i [B]			**3,0 l 115 kW C 30 LE CIH 6 Zyl.**
Air flow sensor, gasoline injection	09.87-08.93		**0 280 202 201**
Temperature sensor, coolant, injection system	09.87-08.93		**0 280 130 107**
3.0 i [B]			**3,0 l 130 kW C 30 NE CIH 6 Zyl.**
Air flow sensor, gasoline injection	01.88-08.93		**0 280 203 032**
			0 986 280 074
Temperature sensor, coolant, injection system	01.88-08.93		**0 280 130 107**
3.0 i [B]			**3,0 l 130 kW 30 NE CIH 6 Zyl.**
Temperature sensor, coolant, injection system	01.88-09.90		**0 280 130 069**
3.0 i 24V [B]			**3,0 l 150 kW C 30 SE 6 Zyl.**
Air flow sensor, gasoline injection	09.89-08.93		**0 280 203 032**
			0 986 280 074
Temperature sensor, coolant, injection system	09.89-08.93		**0 280 130 107**

Signum

1.9 CDTI			**1,9 l 74 kW Z 19 DTL 4 Zyl.**
Speed sensor, diesel	09.05→		**0 281 002 603**
Phase sensor	09.05→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	09.05→		**0 281 002 706**
Boost pressure sensor, Diesel	09.05→		**0 281 002 437**
1.9 CDTI			**1,9 l 88 kW Z 19 DT 4 Zyl.**
Speed sensor, diesel	04.04→		**0 281 002 603**
Phase sensor	04.04→	NOC	**0 281 002 213**
Pressure sensor, intake manifold, diesel	04.04→		**0 281 002 437**
1.9 CDTI			**1,9 l 110 kW Z 19 DTH 4 Zyl.**
High-pressure sensor (CR system)	04.04→		**0 281 002 706**
Pressure sensor, intake manifold, diesel	04.04→		**0 281 002 437**
2.0 DTI			**2,0 l 74 kW Y 20 DTH 4 Zyl.**
Air mass meter, diesel	05.03-09.05		**0 281 002 479**
Speed sensor, diesel			
Fg.no. →17G23740	05.03-09.05	FKW	**0 281 002 138**
Fg.no. 17G23741→	05.03-09.05	FKW	**0 281 002 662**
Temperature sensor, coolant, diesel	05.03-09.05		**0 281 002 473**
2.0 Turbo			**2,0 l 129 kW Z 20 NET 4 Zyl.**
Speed sensor, ignition/injection	05.03→	FKW	**0 261 210 229**
2.2 DTI			**2,2 l 86-92 kW Y 22 DTR 4 Zyl.**
Air mass meter, diesel	05.03→		**0 281 002 479**
Speed sensor, diesel	05.03→	FKW	**0 281 002 138**
Temperature sensor, coolant, diesel	05.03→		**0 281 002 473**
2.8 V6 Turbo			**2,8 l 169/184 kW Z 28 NEL; Z 28 NET 6 Zyl.**
Knock sensor	08.05→		**0 261 231 174**
Pressure sensor, intake manifold, gasoline	08.05→		**0 261 230 101**
Temperature sensor, coolant, injection system	08.05→		**0 280 130 122**
3.0 CDTI			**3,0 l 130-135 kW Y 30 DT 6 Zyl.**
Air mass meter, diesel	05.03→		**0 281 002 605**

Product

3.0 CDTI			**3,0 l 130-135 kW Z 30 DT 6 Zyl.**
Air mass meter, diesel	09.05→		**0 281 002 773**
3.2 i			**3,2 l 155 kW Z 32 SE 6 Zyl.**
Throttle valve assembly	05.03-09.05		**0 280 750 119**
Air mass meter, gasoline injection	05.03-09.05		**0 280 218 087**
Phase sensor	05.03-09.05	NOC	**0 232 103 025**
Speed sensor, ignition/injection	05.03-09.05	FKW	**0 261 210 206**
Knock sensor	05.03-09.05		**0 261 231 116**

Sintra

2.2 i 16V			**2,2 l 104 kW X 22 XE 4 Zyl.**
Throttle valve sensor	09.96-09.99		**0 280 122 001**
Phase sensor	09.96-09.99		**0 232 103 015**
Knock sensor	09.96-09.99		**0 261 231 079**
Pressure sensor, intake manifold, gasoline	09.96-09.99		**0 261 230 009**
Temperature sensor, intake air, injection system			
Fg.no. XD100001→	09.96-09.99		**0 280 130 092**
Fg.no. →WD199999	09.96-09.99		**0 280 130 073**
Temperature sensor, coolant, injection system	09.96-09.99		**0 281 002 169**
2.2 TD			**2,2 l 85 kW X 22 DTH Turbo 4 Zyl.**
Air mass meter, diesel	09.97-09.99		**0 281 002 184**
Speed sensor, diesel	09.97-09.99		**0 281 002 138**
Pressure sensor, intake manifold, diesel	09.97-09.99		**0 281 002 137**
Temperature sensor, coolant, injection system	09.97-09.99		**0 280 130 107**
Pedal position sensor, diesel	09.97-09.99	LLE	**0 205 001 039**
		RLE	**0 205 001 042**
3.0 i 24V			**3,0 l 148 kW X 30 XE V6 6 Zyl.**
Throttle valve sensor	09.96-09.99		**0 280 122 001**
Air mass meter, gasoline injection	09.96-09.99		**0 280 217 503**
Phase sensor	09.96-09.99		**0 232 103 008**
Knock sensor	09.96-09.99		**0 261 231 079**
Temperature sensor, intake air, injection system	09.96-09.99		**0 280 130 092**
Temperature sensor, coolant, injection system	09.96-09.99		**0 281 002 169**
Pedal position sensor, diesel	09.96-09.99	LLE	**0 205 001 039**
		RLE	**0 205 001 042**

Tigra

1.4 i			**1,4 l 66 kW X 14 XE 4 Zyl.**
Temperature sensor, coolant, injection system			
Fg.no. W3000001→	09.94-08.99		**0 280 130 093**
Fg.no. →V6999999	09.94-08.99		**0 280 130 107**
1.6 i			**1,6 l 78 kW X 16 XE 4 Zyl.**
Temperature sensor, coolant, injection system			
Fg.no. W3000001→	09.94-08.99		**0 280 130 093**
Fg.no. →V6999999	09.94-08.99		**0 280 130 107**

Tigra Twin Top

1.3 CDTI [B]			**1,3 l 51 kW Z 13 DT 4 Zyl.**
Air mass meter, diesel	06.04→		**0 281 002 549**
High-pressure sensor (CR system)	06.04→		**0 281 002 534**
Pressure sensor, intake manifold, diesel	06.04→		**0 281 002 510**
Yaw rate sensor, brake system	06.04→		**0 265 005 270**
Pressure sensor, ESP, (electronic stability program)	06.04→		**0 265 005 303**
1.4 i [B]			**1,4 l 66 kW Z 14 XEP 4 Zyl.**
Throttle valve assembly	06.04→		**0 280 750 133**
Air mass meter, gasoline injection	06.04→		**0 280 218 119**
Phase sensor			
Fg.no. →4E999999	06.04→	NOC	**0 232 103 021**
Fg.no. 5E000001→5E999999	06.04→	NOC	**0 232 103 052**
Fg.no. 6E000001→	06.04→	NOC	**0 232 103 067**

Product			
Speed sensor, ignition/injection	06.04→	FKW	**0 261 210 151**
Knock sensor	06.04→		**0 261 231 173**
Temperature sensor, coolant, injection system	06.04→		**0 281 002 170**
Yaw rate sensor, brake system	06.04→		**0 265 005 270**
Pressure sensor, ESP, (electronic stability program)	06.04→		**0 265 005 303**
1.8 i [B]		**1,8 l 92 kW Z 18 XE 4 Zyl.**	
Yaw rate sensor, brake system	06.04→		**0 265 005 270**
Pressure sensor, ESP, (electronic stability program)	06.04→		**0 265 005 303**

Vectra

1.6 i [B]		**1,6 l 55 kW X 16 SZR 4 Zyl.**	
Temperature sensor, intake air, injection system			
Fg.no. →02GE3893,→V1999999, →V5999999,→V7999999	09.96-08.00		**0 280 130 107**
Temperature sensor, coolant, injection system			
Fg.no. 02GE3894→,W1000001→, W5000001→,W7000001→	09.96-08.00		**0 280 130 093**
1.6 i [B]		**1,6 l 55 kW 16 LZ2 4 Zyl.**	
Speed sensor, ignition/injection	09.95-08.00		**0 261 210 030**
Temperature sensor, coolant, injection system	09.95-08.00		**0 280 130 107**
1.6 i 16V [B]		**1,6 l 74 kW X 16 XEL 4 Zyl.**	
Temperature sensor, coolant, injection system	09.95-08.00		**0 280 130 093**
1.8 i 16V [B]		**1,8 l 85 kW X 18 XE 4 Zyl.**	
Throttle valve sensor	09.95-08.99		**0 280 122 001**
1.9 CDTI [C]		**1,9 l 74 kW Z 19 DTL 4 Zyl.**	
Air mass meter, diesel	09.05→		**0 281 002 479**
Speed sensor, diesel	09.05→		**0 281 002 603**
Phase sensor	09.05→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	09.05→		**0 281 002 706**
Boost pressure sensor, Diesel	09.05→		**0 281 002 437**
1.9 CDTI [C]		**1,9 l 88 kW Z 19 DT 4 Zyl.**	
Air mass meter, diesel	04.04→		**0 281 002 479**
Speed sensor, diesel	04.04→		**0 281 002 603**
Phase sensor	04.04→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	04.04→		**0 281 002 534**
Boost pressure sensor, Diesel	04.04→		**0 281 002 437**
1.9 CDTI [C]		**1,9 l 110 kW Z 19 DTH 4 Zyl.**	
Air mass meter, diesel	04.04→		**0 281 002 479**
High-pressure sensor (CR system)	04.04→		**0 281 002 534**
Boost pressure sensor, Diesel	04.04→		**0 281 002 437**
2.0 DI [B]		**2,0 l 60 kW X 20 DTL 16V Turbo 4 Zyl.**	
Air mass meter, diesel			
Fg.no. W1000001→	09.96-08.00		**0 281 002 180**
Fg.no. →V7999999	09.96-08.00		**0 281 002 139**
Speed sensor, diesel	09.96-08.00		**0 281 002 138**
Pressure sensor, intake manifold, diesel	09.96-08.00		**0 281 002 137**
Temperature sensor, coolant, diesel	09.96-08.00		**0 281 002 169**
Temperature sensor, intake air, diesel	09.96-08.00		**0 280 130 073**
Pedal position sensor, diesel			
Fg.no. W1285447→,W7154259→	09.96-08.00	LLE	**0 281 002 476**
Fg.no. →W1285446,→W5276825,	09.96-08.00	LLE	**0 205 001 042**
→W7154258		RLE	**0 205 001 039**
2.0 DTI [B]		**2,0 l 74 kW X 20 DTH 16V Turbo 4 Zyl.**	
Air mass meter, diesel	09.97-08.00		**0 281 002 180**
Speed sensor, diesel	09.97-08.00		**0 281 002 138**
Pressure sensor, intake manifold, diesel	09.97-08.00	TW	**0 281 002 137**
			0 281 002 438
Temperature sensor, coolant, diesel	09.97-08.00		**0 281 002 169**
Pedal position sensor, diesel			
Fg.no. W1285447→,W7154259→	09.97-08.00	LLE	**0 281 002 476**
Fg.no. →W1285446,→W5276825,	09.97-08.00	LLE	**0 205 001 042**
→W7154258		RLE	**0 205 001 039**

Product			
2.0 DTI [B]		**2,0 l 74 kW Y 20 DTH 16V Turbo 4 Zyl.**	
Air mass meter, diesel	09.00-08.01		**0 281 002 428**
Speed sensor, diesel	09.00-08.01		**0 281 002 138**
Pressure sensor, intake manifold, diesel	09.00-08.01		**0 281 002 438**
Temperature sensor, coolant, diesel	09.00-08.01		**0 281 002 169**
Pedal position sensor, diesel	09.00-08.01	LLE	**0 281 002 476**
2.0 DTI [C]		**2,0 l 74 kW Y 20 DTH 4 Zyl.**	
Air mass meter, diesel	04.02-09.05		**0 281 002 479**
Speed sensor, diesel	04.02-09.05		**0 281 002 138**
Speed sensor, ignition/injection			
Mot.no. →17G23740	04.02-09.05	FKW	**0 281 002 138**
Mot.no. 17G23741→	04.02-09.05	FKW	**0 281 002 662**
2.0 i [B]		**2,0 l 82 kW 20 NEJ 4 Zyl.**	
Throttle valve sensor	09.95-08.01		**0 280 122 001**
Air mass meter, gasoline injection	09.95-08.01		**0 280 217 106**
Knock sensor	09.95-08.01		**0 261 231 006**
Temperature sensor, intake air, injection system	09.95-08.01		**0 280 130 073**
Temperature sensor, coolant, injection system	09.95-08.01		**0 280 130 107**
2.0 i [B]		**2,0 l 100 kW C 20 SEL 4 Zyl.**	
Throttle valve sensor	05.97-09.02		**0 280 122 001**
2.0 i 16V [B]		**2,0 l 100 kW X 20 XEV 4 Zyl.**	
Throttle valve sensor	09.95-08.01		**0 280 122 001**
2.0 Turbo [C]		**2,0 l 129 kW Z 20 NET 4 Zyl.**	
Speed sensor, ignition/injection	03.03→	FKW	**0 261 210 229**
2.2 DTI [B]		**2,2 l 92 kW Y 22 DTR Turbo 4 Zyl.**	
Air mass meter, diesel	09.00-08.01		**0 281 002 428**
Speed sensor, diesel	09.00-08.01		**0 281 002 138**
Pressure sensor, intake manifold, diesel	09.00-08.01		**0 281 002 438**
Temperature sensor, coolant, diesel	09.00-08.01		**0 281 002 169**
Pedal position sensor, diesel	09.00-08.01	LLE	**0 281 002 476**
2.2 DTI [C]		**2,2 l 86-92 kW Y 22 DTR 4 Zyl.**	
Air mass meter, diesel	04.02-09.05		**0 281 002 479**
Speed sensor, diesel	04.02-09.05		**0 281 002 138**
Speed sensor, ignition/injection			
Mot.no. →17G23740	04.02-09.05	FKW	**0 281 002 138**
Mot.no. 17G23741→	04.02-09.05	FKW	**0 281 002 662**
2.2 i [B]		**2,2 l 106 kW C 22 SEL 4 Zyl.**	
Throttle valve sensor	10.99-08.01		**0 280 122 001**
2.5 i V6 [B]		**2,5 l 125-143 kW X 25 XE 6 Zyl.**	
Throttle valve sensor			
Fg.no. W1000001→	09.95-08.01		**0 280 122 014**
Fg.no. →V7999999	09.95-08.01		**0 280 122 001**
Air mass meter, gasoline injection			
Fg.no. W1000001→	09.95-08.01		**0 280 217 519**
Fg.no. →V7999999	09.95-08.01		**0 280 217 503**
Knock sensor	09.95-08.01		**0 261 231 079**
Temperature sensor, intake air, injection system			
Fg.no. W1000001→	09.95-08.01		**0 280 130 092**
Fg.no. →W1000001	09.95-08.01		**0 280 130 073**
Temperature sensor, coolant, injection system			
Fg.no. W1000001→,W5000001→, W7000001→,XL000001→	09.95-08.01		**0 280 130 093**
Fg.no. →V7999999	09.95-08.01		**0 280 130 107**
2.6 V6 [B]		**2,6 l 130 kW Y 26 SE 6 Zyl.**	
Air mass meter, gasoline injection	09.00-08.01		**0 281 002 184**
Phase sensor	09.00-08.01		**0 232 103 025**
Speed sensor, ignition/injection	09.00-08.01	FKW	**0 261 210 206**
Knock sensor	09.00-08.01		**0 261 231 116**
Temperature sensor, coolant, injection system	09.00-08.01		**0 281 002 169**
2.8 GTS Turbo, Turbo [C]		**2,8 l 169/184-188 kW Z 28 NEL; Z 28 NET 6 Zyl.**	
Knock sensor	09.05→		**0 261 231 174**
Pressure sensor, intake manifold, gasoline	09.05→		**0 261 230 101**
Temperature sensor, coolant, injection system	09.05→		**0 280 130 122**

V

Product

◀ Vectra

3.0 CDTI [C]	**3,0 l 130-135 kW Y 30 DT 6 Zyl.**		
Air mass meter, diesel	03.03→		**0 281 002 605**
3.0 CDTI [C]	**3,0 l 130-135 kW Z 30 DT 6 Zyl.**		
Air mass meter, diesel	09.05→		**0 281 002 773**
3.2 i [C]	**3,2 l 155 kW Z 32 SE 6 Zyl.**		
Air mass meter, gasoline injection	08.02-09.05		**0 280 218 087**
Phase sensor	08.02-09.05	NOC	**0 232 103 025**
Speed sensor, ignition/injection	08.02-09.05	FKW	**0 261 210 206**
Knock sensor	08.02-09.05		**0 261 231 116**

Vectra Estate

1.6 i 16V [B]	**1,6 l 55 kW X 16 SZR 4 Zyl.**		
Temperature sensor, intake air, injection system			
Fg.no. →02GE3893,→V1999999, →V5999999,→V7999999	09.96-08.00		**0 280 130 107**
Temperature sensor, coolant, injection system			
Fg.no. 02GE3894→,W1000001→, W5000001→,W7000001→	09.96-08.00		**0 280 130 093**
1.6 i 16V [B]	**1,6 l 55 kW 16 LZ2 4 Zyl.**		
Speed sensor, ignition/injection	09.95-08.00		**0 261 210 030**
Temperature sensor, coolant, injection system	09.95-08.00		**0 280 130 107**
1.6 i 16V [B]	**1,6 l 74 kW X 16 XEL 4 Zyl.**		
Temperature sensor, coolant, injection system	09.95-08.00		**0 280 130 093**
1.8 i 16V [B]	**1,8 l 85 kW X 18 XE 4 Zyl.**		
Throttle valve sensor	09.95-08.99		**0 280 122 001**
1.9 CDTI [C]	**1,9 l 74 kW Z 19 DTL 4 Zyl.**		
Air mass meter, diesel	09.05→		**0 281 002 479**
Speed sensor, diesel	09.05→		**0 281 002 603**
Phase sensor	09.05→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	09.05→		**0 281 002 706**
Boost pressure sensor, Diesel	09.05→		**0 281 002 437**
1.9 CDTI [C]	**1,9 l 88 kW Z 19 DT 4 Zyl.**		
Air mass meter, diesel	04.04→		**0 281 002 479**
Speed sensor, diesel	04.04→		**0 281 002 603**
Phase sensor	04.04→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	04.04→		**0 281 002 534**
Boost pressure sensor, Diesel	04.04→		**0 281 002 437**
1.9 CDTI [C]	**1,9 l 110 kW Z 19 DTH 4 Zyl.**		
Air mass meter, diesel	04.04→		**0 281 002 479**
High-pressure sensor (CR system)	04.04→		**0 281 002 534**
Boost pressure sensor, Diesel	04.04→		**0 281 002 437**
2.0 DI [B]	**2,0 l 60 kW X 20 DTL 16V Turbo 4 Zyl.**		
Air mass meter, diesel			
Fg.no. W1000001→	09.96-08.00		**0 281 002 180**
Fg.no. →V7999999	09.96-08.00		**0 281 002 139**
Speed sensor, diesel	09.96-08.00		**0 281 002 138**
Pressure sensor, intake manifold, diesel	09.96-08.00		**0 281 002 137**
Temperature sensor, coolant, diesel	09.96-08.00		**0 281 002 169**
Temperature sensor, intake air, diesel	09.96-08.00		**0 280 130 073**
Pedal position sensor, diesel			
Fg.no. W1285447→,W7154259→	09.96-08.00	LLE	**0 281 002 476**
Fg.no. →W1285446,→W5276825, →W7154258	09.96-08.00	LLE	**0 205 001 042**
		RLE	**0 205 001 039**
2.0 DTI [B]	**2,0 l 74 kW X 20 DTH 16V Turbo 4 Zyl.**		
Air mass meter, diesel	09.97-08.00		**0 281 002 180**
Speed sensor, diesel	09.97-08.00		**0 281 002 138**
Pressure sensor, intake manifold, diesel	09.97-08.00	TW	**0 281 002 137**
			0 281 002 438
Temperature sensor, coolant, diesel	09.97-08.00		**0 281 002 169**
Pedal position sensor, diesel			
Fg.no. W1285447→,W7154259→	09.97-08.00	LLE	**0 281 002 476**

Product

Pedal position sensor, diesel			
Fg.no. →W1285446,→W5276825, →W7154258	09.97-08.00	LLE	**0 205 001 042**
		RLE	**0 205 001 039**
2.0 DTI [B]	**2,0 l 74 kW Y 20 DTH 16V Turbo 4 Zyl.**		
Air mass meter, diesel	09.00-08.01		**0 281 002 428**
Speed sensor, diesel	09.00-08.01		**0 281 002 138**
Pressure sensor, intake manifold, diesel	09.00-08.01		**0 281 002 438**
Temperature sensor, coolant, diesel	09.00-08.01		**0 281 002 169**
Pedal position sensor, diesel	09.00-08.01	LLE	**0 281 002 476**
2.0 DTI [C]	**2,0 l 74 kW Y 20 DTH 4 Zyl.**		
Air mass meter, diesel	09.03-09.05		**0 281 002 479**
Speed sensor, diesel	09.03-09.05		**0 281 002 138**
Speed sensor, ignition/injection			
Mot.no. →17G23740	09.03-09.05	FKW	**0 281 002 138**
Mot.no. 17G23741→	09.03-09.05	FKW	**0 281 002 662**
Temperature sensor, coolant, diesel	09.03-09.05		**0 281 002 473**
2.0 i 16V [B]	**2,0 l 100 kW X 20 XEV 4 Zyl.**		
Throttle valve sensor	09.95-08.01		**0 280 122 001**
2.0 Turbo [C]	**2,0 l 129 kW Z 20 NET 4 Zyl.**		
Speed sensor, ignition/injection	09.03→	FKW	**0 261 210 229**
2.2 DTI [B]	**2,2 l 92 kW Y 22 DTR Turbo 4 Zyl.**		
Air mass meter, diesel	09.00-08.01		**0 281 002 428**
Speed sensor, diesel	09.00-08.01		**0 281 002 138**
Pressure sensor, intake manifold, diesel	09.00-08.01		**0 281 002 438**
Temperature sensor, coolant, diesel	09.00-08.01		**0 281 002 169**
Pedal position sensor, diesel	09.00-08.01	LLE	**0 281 002 476**
2.2 DTI [C]	**2,2 l 86-92 kW Y 22 DTR 4 Zyl.**		
Air mass meter, diesel	09.03-09.05		**0 281 002 479**
Speed sensor, diesel	09.03-09.05		**0 281 002 138**
Speed sensor, ignition/injection			
Mot.no. →17G23740	09.03-09.05	FKW	**0 281 002 138**
Mot.no. 17G23741→	09.03-09.05	FKW	**0 281 002 662**
Temperature sensor, coolant, diesel	09.03-09.05		**0 281 002 473**
2.5 i V6 [B]	**2,5 l 125-143 kW X 25 XE 6 Zyl.**		
Throttle valve sensor			
Fg.no. W1000001→	09.95-08.01		**0 280 122 014**
Fg.no. →V7999999	09.95-08.01		**0 280 122 001**
Air mass meter, gasoline injection			
Fg.no. W1000001→	09.95-08.01		**0 280 217 519**
Fg.no. →V7999999	09.95-08.01		**0 280 217 503**
Knock sensor	09.95-08.01		**0 261 231 079**
Temperature sensor, intake air, injection system			
Fg.no. W1000001→	09.95-08.01		**0 280 130 092**
Fg.no. →W1000001	09.95-08.01		**0 280 130 073**
Temperature sensor, coolant, injection system			
Fg.no. W1000001→,W5000001→, W7000001→,XL000001→	09.95-08.01		**0 280 130 093**
Fg.no. →V7999999	09.95-08.01		**0 280 130 107**
2.6 V6 [B]	**2,6 l 130 kW Y 26 SE 6 Zyl.**		
Air mass meter, gasoline injection	09.00-08.01		**0 281 002 184**
Phase sensor	09.00-08.01		**0 232 103 025**
Speed sensor, ignition/injection	09.00-08.01	FKW	**0 261 210 206**
Knock sensor	09.00-08.01		**0 261 231 116**
Temperature sensor, coolant, injection system	09.00-08.01		**0 281 002 169**
2.8 Turbo [C]	**2,8 l 169/184-188 kW Z 28 NEL; Z 28 NET 6 Zyl.**		
Knock sensor	09.05→		**0 261 231 174**
Pressure sensor, intake manifold, gasoline	09.05→		**0 261 230 101**
Temperature sensor, coolant, injection system	09.05→		**0 280 130 122**
3.0 CDTI [C]	**3,0 l 130-135 kW Y 30 DT 6 Zyl.**		
Air mass meter, diesel	09.03→		**0 281 002 605**
3.0 CDTI [C]	**3,0 l 130-135 kW Z 30 DT 6 Zyl.**		
Air mass meter, diesel	09.05→		**0 281 002 773**

Product			
3.2 i [C]			**3,2 l 155 kW Z 32 SE 6 Zyl.**
Throttle valve assembly	09.03-09.05		**0 280 750 119**
Air mass meter, gasoline injection	09.03-09.05		**0 280 218 087**
Phase sensor	09.03-09.05	NOC	**0 232 103 025**
Speed sensor, ignition/injection	09.03-09.05	FKW	**0 261 210 206**
Knock sensor	09.03-09.05		**0 261 231 116**
Temperature sensor, coolant, injection system	09.03-09.05		**0 281 002 170**

Vivaro

1.9 DI			**1,9 l 59-60 kW F9Q-762 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 7V600001→,7Y000001→	03.01-10.06		**0 265 008 077**
1.9 TDI			**1,9 l 74 kW F9Q-760 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 7V600001→,7Y000001→	03.01-10.06		**0 265 008 077**
2.0 CDTI			**2,0 l 66/84 kW M9R-780 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 7V600001→,7Y000001→	08.06→		**0 265 008 077**
2.0 16V			**2,0 l 86-88 kW F4R-... 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 7V600001→,7Y000001→	03.01→		**0 265 008 077**
2.5 CDTI			**2,5 l 84/107 kW ; G9U-630 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 7V600001→,7Y000001→	08.06→		**0 265 008 077**
2.5 DTI			**2,5 l 99 kW G9U-730 4 Zyl.**
Wheel speed sensor, front			
Fg.no. 7V600001→,7Y000001→	04.04-10.06		**0 265 008 077**

VX 220

2.0 i 16V Turbo			**2,0 l 147 kW Z 20 LET 4 Zyl.**
Air mass meter, gasoline injection	04.03-09.05		**0 280 218 051**
			0 986 280 231
Phase sensor	04.03-09.05	NOC	**0 232 103 015**
Speed sensor, ignition/injection	04.03-09.05	FKW	**0 261 210 150**
Knock sensor	04.03-09.05		**0 261 231 116**
Pressure sensor, intake manifold, diesel	04.03-09.05		**0 281 002 137**
Temperature sensor, coolant, injection system	04.03-09.05		**0 281 002 169**

Zafira

1.6 i [A]			**1,6 l 74 kW X 16 XEL 4 Zyl.**
Temperature sensor, coolant, injection system	09.98-08.99		**0 281 002 169**
Yaw rate sensor, brake system			
Fg.no. →12999999,→1H999999	09.98-08.99		**0 265 005 262**
Fg.no. 22000001→,2B000001→, 2H000001→	09.98-08.99		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)			
Fg.no. →12999999,→1H999999	09.98-08.99	TW	**0 265 005 434**
Fg.no. 22000001→,2H000001→	09.98-08.99		**0 265 005 435**
1.6 i [A]			**1,6 l 74 kW Z 16 XE 4 Zyl.**
Yaw rate sensor, brake system			
Fg.no. →12999999,→1H999999	09.99-06.05		**0 265 005 262**
Fg.no. 22000001→,2B000001→, 2H000001→	09.99-06.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)			
Fg.no. →12999999,→1H999999	09.99-06.05	TW	**0 265 005 434**
Fg.no. 22000001→,2H000001→	09.99-06.05		**0 265 005 435**
1.6 i CNG [A]			**1,6 l 69-73 kW Z 16 YNG 4 Zyl.**
Yaw rate sensor, brake system			
Fg.no. 22000001→,2B000001→, 2H000001→	09.01-06.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)			
Fg.no. 22000001→,2H000001→	09.01-06.05		**0 265 005 435**
1.6 i Dualfuel [A]			**1,6 l 74 kW Z 16 XE 4 Zyl.**
Yaw rate sensor, brake system			
Fg.no. →12999999,→1H999999	09.99-06.05		**0 265 005 262**
1.8 i [A]			**1,8 l 85 kW X 18 XE1 4 Zyl.**
Yaw rate sensor, brake system			
Fg.no. →12999999,→1H999999	03.99-09.00		**0 265 005 262**
Fg.no. 22000001→,2B000001→, 2H000001→	03.99-09.00		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)			
Fg.no. →12999999,→1H999999	03.99-09.00	TW	**0 265 005 434**
Fg.no. 22000001→,2H000001→	03.99-09.00		**0 265 005 435**
1.8 i, i Dualfuel [A]			**1,8 l 92 kW Z 18 XE 4 Zyl.**
Yaw rate sensor, brake system	09.00-06.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.00-06.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-06.05		**0 265 005 303**
1.9 CDTI [B]			**1,9 l 74 kW Z 19 DTL 4 Zyl.**
Speed sensor, diesel	07.05→		**0 281 002 603**
Phase sensor	07.05→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	07.05→		**0 281 002 706**
Pressure sensor, intake manifold, diesel	07.05→		**0 281 002 437**
1.9 CDTI [B]			**1,9 l 88 kW Z 19 DT 4 Zyl.**
Speed sensor, diesel	07.05→		**0 281 002 603**
Phase sensor	07.05→	NOC	**0 281 002 213**
High-pressure sensor (CR system)	07.05→		**0 281 002 706**
Boost pressure sensor, Diesel	07.05→		**0 281 002 437**
Pressure sensor, intake manifold, diesel	07.05→		**0 281 002 437**
1.9 CDTI [B]			**1,9 l 110 kW Z 19 DTH 4 Zyl.**
High-pressure sensor (CR system)	07.05→		**0 281 002 706**
Boost pressure sensor, Diesel	07.05→		**0 281 002 437**
Pressure sensor, intake manifold, diesel	07.05→		**0 281 002 437**
2.0 DI [A]			**2,0 l 60 kW X 20 DTL 4 Zyl.**
Air mass meter, diesel			
Fg.no. →Y8999999,→YT999999	03.99-08.00		**0 281 002 180**
Mot.no. 12000001→,1T000001→	03.99-08.00		**0 281 002 428**
Speed sensor, diesel	03.99-08.00		**0 281 002 138**
Temperature sensor, coolant, diesel	03.99-08.00		**0 281 002 169**
Accelerator pedal module	03.99-08.00	LLE	**0 281 002 298**
		RLE	**0 281 002 299**
Yaw rate sensor, brake system			
Fg.no. →12999999,→1H999999	03.99-08.00		**0 265 005 262**
Fg.no. 22000001→,2B000001→, 2H000001→	03.99-08.00		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)			
Fg.no. →12999999,→1H999999	03.99-08.00	TW	**0 265 005 434**
Fg.no. 22000001→,2H000001→	03.99-08.00		**0 265 005 435**
2.0 DTI [A]			**2,0 l 74 kW Y 20 DTH 4 Zyl.**
Air mass meter, diesel			
Fg.no. →Y2999999,→Y5999999, →Y6999999,→Y8999999,→YH999999	04.99-06.05		**0 281 002 180**

V

Product			
◀ Zafira			
Air mass meter, diesel			
Fg.no. 12000001→22999999, 15000001→25999999, 16000001→26999999, 18000001→28999999, 1H000001→2H999999	04.99-06.05		**0 281 002 428**
Fg.no. 32000001→,35000001→, 36000001→,38000001→,3H000001→, 3H000001→	04.99-06.05		**0 281 002 478**
Speed sensor, diesel	04.99-06.05		**0 281 002 138**
Pressure sensor, intake manifold, diesel			
Fg.no. →Y2999999,→Y5999999, →Y6999999,→Y8999999,→YB999999, →YH999999	04.99-06.05		**0 281 002 137**
Fg.no. 12000001→22999999, 15000001→25999999, 16000001→26999999, 18000001→28999999, 1B000001→2B999999, 1H000001→2H999999	04.99-06.05		**0 281 002 438**
Fg.no. 32000001→,35000001→, 36000001→,38000001→,3B000001→, 3H000001→	04.99-06.05		**0 281 002 437**
Temperature sensor, coolant, diesel	04.99-06.05		**0 281 002 169**
Accelerator pedal module	04.99-06.05	LLE	**0 281 002 298**
		RLE	**0 281 002 299**
Yaw rate sensor, brake system			
Fg.no. →12999999,→1H999999	04.99-06.05		**0 265 005 262**
Fg.no. 22000001→,2B000001→, 2H000001→	04.99-06.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)			
Fg.no. →12999999,→1H999999	04.99-06.05	TW	**0 265 005 434**
Fg.no. 22000001→,2H000001→	04.99-06.05		**0 265 005 435**
2.0 i Turbo [B]		**2,0 l 147 kW Z 20 LER 4 Zyl.**	
Air mass meter, gasoline injection	07.05→		**0 280 218 142**
Air mass meter, diesel	07.05→		**0 280 218 142**
Phase sensor	07.05→	NOC	**0 232 103 015**
Speed sensor, ignition/injection	07.05→	FKW	**0 261 210 150**
Knock sensor	07.05→		**0 261 231 181**
Pressure sensor, intake manifold, gasoline	07.05→		**0 281 002 137**
Temperature sensor, coolant, injection system	07.05→		**0 281 002 169**
2.0 i Turbo [B]		**2,0 l 177 kW Z 20 LEH 4 Zyl.**	
Air mass meter, gasoline injection	09.05→		**0 280 218 211**
Phase sensor	09.05→	NOC	**0 232 103 015**
Speed sensor, ignition/injection	09.05→	FKW	**0 261 210 150**
Knock sensor	09.05→		**0 261 231 181**
Pressure sensor, intake manifold, gasoline	09.05→		**0 281 002 137**
Temperature sensor, coolant, injection system	09.05→		**0 281 002 169**
2.0 Turbo [A]		**2,0 l 141 kW Z 20 LET 4 Zyl.**	
Air mass meter, gasoline injection	09.01-06.05		**0 280 218 051**
			0 986 280 231
Phase sensor	09.01-06.05	NOC	**0 232 103 015**
Speed sensor, ignition/injection	09.01-06.05	FKW	**0 261 210 150**
Pressure sensor, intake manifold, gasoline	09.01-06.05		**0 261 230 009**
Temperature sensor, coolant, injection system	09.01-06.05		**0 281 002 169**
Yaw rate sensor, brake system	09.01-06.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.01-06.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.01-06.05		**0 265 005 303**

Product			
2.2 [A]		**2,2 l 108 kW Z 22 SE 4 Zyl.**	
Yaw rate sensor, brake system	09.00-06.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)	09.00-06.05		**0 265 005 435**
Pressure sensor, ESP, (electronic stability program)	09.00-06.05		**0 265 005 303**
2.2 DTI [A]		**2,2 l 92 kW Y 22 DTR 4 Zyl.**	
Yaw rate sensor, brake system			
Fg.no. 22000001→,2B000001→, 2H000001→	03.02-06.05		**0 265 005 262**
Steering angle sensor, ESP (electronic stability program)			
Fg.no. 22000001→,2H000001→	03.02-06.05		**0 265 005 435**

VOLGA

3110

2.3 16V		**2,3 l 110 kW ZMZ 406 4 Zyl.**	
Throttle valve sensor	01.95→		**0 280 122 001**
Air mass meter, gasoline injection	01.95→		**0 280 212 014**
			0 986 280 108
Phase sensor	01.95→		**0 232 103 006**
Speed sensor, ignition/injection	01.95→		**0 261 210 113**
Knock sensor	01.95→		**0 261 231 046**
Pressure sensor, intake manifold, gasoline	01.95→		**0 261 230 004**

VOLVO

C30

D5		**2,4 l 120/132 kW D5244T8; D5244T9 5 Zyl.**	
Throttle valve assembly	10.06→		**0 281 002 701**
T5		**2,5 l 162/169 kW B5254T3; B5254T7 5 Zyl.**	
Throttle valve assembly	10.06→		**0 280 750 146**
Air mass meter, gasoline injection	10.06→		**0 280 218 134**
Knock sensor	10.06→		**0 261 231 178**
Boost pressure sensor, gasoline	10.06→	UE	**0 261 230 090**

C70 Coupé

2.0 T		**2,0 l 120 kW B 5204 T4 5 Zyl.**	
Air mass meter, gasoline injection	08.99-07.02		**0 280 218 108**
Knock sensor	08.99-07.02		**0 261 231 142**
2.0 T		**2,0 l 132 kW B5204T2 5 Zyl.**	
Throttle valve sensor	01.97-07.98		**0 280 122 001**
Air mass meter, gasoline injection	01.97-07.98		**0 280 217 107**
Phase sensor	01.97-07.98	NOC	**0 232 101 030**
Knock sensor	01.97-07.98		**0 261 231 121**
Pressure sensor, intake manifold, gasoline	01.97-07.98		**0 261 230 018**
2.0 T		**2,0 l 166 kW B 5204 T3 5 Zyl.**	
Throttle valve sensor	01.97-07.00		**0 280 122 001**
Air mass meter, gasoline injection	01.97-07.98		**0 280 217 107**
	08.98-07.00		**0 280 218 108**
Phase sensor	01.97-07.98	NOC	**0 232 101 030**
Knock sensor	01.97-07.98		**0 261 231 121**
	08.98-07.00		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	01.97-07.00		**0 261 230 018**
2.3 T5		**2,3 l 176 kW B5234T3 5 Zyl.**	
Throttle valve sensor	09.97-07.02		**0 280 122 001**
Air mass meter, gasoline injection	09.97-07.98		**0 280 217 107**
	08.98-07.02		**0 280 218 108**
Phase sensor	09.97-07.98	NOC	**0 232 101 030**

Product			
Knock sensor	09.97-07.98		**0 261 231 121**
	08.98-07.02		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	09.97-07.02		**0 261 230 018**
2.4 20V		**2,4 l 121 kW B5244S 5 Zyl.**	
Throttle valve sensor	03.99-07.00		**0 280 122 001**
2.5 LPT		**2,4 l 142 kW B5254T 5 Zyl.**	
Throttle valve sensor	01.98-07.99		**0 280 122 001**
Air mass meter, gasoline injection	01.98-07.98		**0 280 217 107**
	08.98-07.99		**0 280 218 108**
Phase sensor	01.98-07.98	NOC	**0 232 101 030**
Knock sensor	01.98-07.98		**0 261 231 121**
	08.98-07.99		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	01.98-07.99		**0 261 230 018**
2.5 T		**2,4 l 142 kW B5244T 5 Zyl.**	
Air mass meter, gasoline injection	08.99-07.02		**0 280 218 108**
Knock sensor	08.99-07.02		**0 261 231 142**
2.5 20V		**2,4 l 125 kW B5254S 5 Zyl.**	
Throttle valve sensor	08.99-07.00		**0 280 122 001**

C70 I Cabrio

2.0 T		**2,0 l 120 kW B5204T4 5 Zyl.**	
Air mass meter, gasoline injection	08.02-03.06		**0 280 218 088**
	08.99-07.02		**0 280 218 108**
Knock sensor	08.99-03.06		**0 261 231 142**
2.0 T		**2,0 l 132 kW B5204T2 5 Zyl.**	
Throttle valve sensor	03.98-07.98		**0 280 122 001**
Air mass meter, gasoline injection	03.98-07.98		**0 280 217 107**
Phase sensor	03.98-07.98	NOC	**0 232 101 030**
Knock sensor	03.98-07.98		**0 261 231 121**
2.0 T		**2,0 l 166 kW B5204T3 5 Zyl.**	
Air mass meter, gasoline injection	08.98-07.00		**0 280 218 108**
Knock sensor	08.98-07.00		**0 261 231 142**
2.3 T5		**2,3 l 176 kW B5234T3 5 Zyl.**	
Throttle valve sensor	02.98-07.02		**0 280 122 001**
Air mass meter, gasoline injection	02.98-07.98		**0 280 217 107**
	08.98-07.02		**0 280 218 108**
Phase sensor	02.98-07.98	NOC	**0 232 101 030**
Knock sensor	02.98-07.98		**0 261 231 121**
	08.98-07.02		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	02.98-07.02		**0 261 230 018**
2.3 T5		**2,3 l 180 kW B5234T9 5 Zyl.**	
Throttle valve sensor	08.02-03.06		**0 280 122 001**
Air mass meter, gasoline injection	08.02-03.06		**0 280 218 088**
Knock sensor	08.02-03.06		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	08.02-03.06		**0 261 230 018**
2.4		**2,4 l 103 kW B5244S 5 Zyl.**	
Throttle valve sensor	03.99-07.00		**0 280 122 001**
2.4 T		**2,4 l 142 kW B5244T 5 Zyl.**	
Air mass meter, gasoline injection	08.99-07.02		**0 280 218 108**
Knock sensor	08.99-07.02		**0 261 231 142**
2.4 T		**2,4 l 142 kW B5254T 5 Zyl.**	
Throttle valve sensor	08.98-07.99		**0 280 122 001**
Air mass meter, gasoline injection	08.98-07.99		**0 280 218 108**
Knock sensor	08.98-07.99		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	08.98-07.99		**0 261 230 018**
2.4 T5		**2,4 l 147 kW B5244T7 5 Zyl.**	
Throttle valve sensor	08.02-03.06		**0 280 122 001**
Air mass meter, gasoline injection	08.02-03.06		**0 280 218 088**
Knock sensor	08.02-03.06		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	08.02-03.06		**0 261 230 018**

C70 II Cabrio

2.4		**2,4 l 103 kW B5244S4 5 Zyl.**	
Temperature sensor, fuel	03.06→		**0 261 230 109**
2.4 D		**2,4 l 120 kW D5244T9 5 Zyl.**	
Phase sensor	08.06→	NOC	**0 232 103 063**
Boost pressure sensor, Diesel	08.06→		**0 261 230 105**
2.4 D5		**2,4 l 132 kW D5244T8 5 Zyl.**	
Phase sensor	08.06→	NOC	**0 232 103 063**
Boost pressure sensor, Diesel	08.06→		**0 261 230 105**
2.4 i		**2,4 l 125 kW B5244S5 5 Zyl.**	
Temperature sensor, fuel	03.06→		**0 261 230 109**
2.5 T5		**2,5 l 162 kW B5254T3 5 Zyl.**	
Throttle valve assembly	03.06→		**0 280 750 146**
Air mass meter, gasoline injection	03.06→		**0 280 218 134**
Knock sensor	03.06→		**0 261 231 178**
Boost pressure sensor, gasoline	03.06-07.07		**0 261 230 090**
	08.07→		**0 261 230 105**
Temperature sensor, fuel	03.06→		**0 261 230 110**
2.5 T5		**2,5 l 169 kW B5254T7 5 Zyl.**	
Throttle valve assembly	08.07→		**0 280 750 146**
Air mass meter, gasoline injection	08.07→		**0 280 218 134**
Knock sensor	08.07→		**0 261 231 178**
Boost pressure sensor, gasoline	08.07→		**0 261 230 105**
Temperature sensor, fuel	08.07→		**0 261 230 110**

S40 I

1.6 16V		**1,6 l 77 kW B4164S 4 Zyl.**	
Phase sensor	01.97-07.99	NOC	**0 232 101 029**
Wheel speed sensor, front	09.97-07.99		**0 265 006 425**
	01.97-08.97	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
Wheel speed sensor, rear	01.97-07.99		**0 265 006 366**
1.6 16V		**1,6 l 80 kW B4164S2 4 Zyl.**	
Wheel speed sensor, front	08.99-01.04		**0 265 006 425**
Wheel speed sensor, rear			
Fg.no. →985261	08.99-01.04		**0 265 006 366**
Fg.no. 985262→	08.99-01.04		**0 265 006 698**
1.8 16V		**1,8 l 85 kW B4184S 4 Zyl.**	
Phase sensor	09.95-07.99	NOC	**0 232 101 029**
Knock sensor	09.95-07.99		**0 261 231 046**
Wheel speed sensor, front	09.97-07.99		**0 265 006 425**
	09.95-08.97	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
Wheel speed sensor, rear	09.95-07.99		**0 265 006 366**
1.8 16V		**1,8 l 90 kW B4184SJ; B4184S2; B4184S3; B4184S9; B4184S10 4 Zyl.**	
Wheel speed sensor, front	08.99-01.04		**0 265 006 425**
Wheel speed sensor, rear			
Fg.no. →985261	08.99-01.04		**0 265 006 366**
Fg.no. 985262→	08.99-01.04		**0 265 006 698**
1.8 16V		**1,8 l 92 kW B4184SM 4 Zyl.**	
Wheel speed sensor, front	09.97-07.00		**0 265 006 425**
Wheel speed sensor, rear	09.97-07.00		**0 265 006 366**
1.9 D		**1,9 l 66 kW D4192T 4 Zyl.**	
Speed sensor, diesel	05.96-07.99		**0 281 002 349**
Wheel speed sensor, front	09.97-07.99		**0 265 006 425**
	05.96-08.97	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
Wheel speed sensor, rear	05.96-07.99		**0 265 006 366**
1.9 D		**1,9 l 70 kW D4192T2 4 Zyl.**	
Wheel speed sensor, front	03.98-07.00		**0 265 006 425**
Wheel speed sensor, rear	03.98-07.00		**0 265 006 366**

V

Product			
◀ S40 I			
1.9 D	**1,9 l 75/85 kW D4192T3/DI; D4192T4/DI 4 Zyl.**		
Wheel speed sensor, front	08.00-01.04		**0 265 006 425**
Wheel speed sensor, rear			
Fg.no. →985261	08.00-01.04		**0 265 006 366**
Fg.no. 985262→	08.00-01.04		**0 265 006 698**
1.9 T4	**1,9 l 147 kW B4194T 4 Zyl.**		
Phase sensor	05.97-07.99	NOC	**0 232 101 029**
Wheel speed sensor, front	09.97-07.99		**0 265 006 425**
	05.97-08.97	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
Wheel speed sensor, rear	05.97-07.99		**0 265 006 366**
1.9 T4	**1,9 l 147 kW B4194T2 4 Zyl.**		
Wheel speed sensor, front	08.99-07.00		**0 265 006 425**
Wheel speed sensor, rear	08.99-07.00		**0 265 006 366**
2.0 T	**1,9 l 120/121 kW B4204T3 4 Zyl.**		
Pressure sensor, intake manifold, gasoline	08.00-01.04		**0 261 230 029**
Wheel speed sensor, front	08.00-01.04		**0 265 006 425**
Wheel speed sensor, rear			
Fg.no. →985261	08.00-01.04		**0 265 006 366**
Fg.no. 985262→	08.00-01.04		**0 265 006 698**
2.0 T 16V	**1,9 l 118 kW B4204T2 4 Zyl.**		
Wheel speed sensor, front	08.99-07.00		**0 265 006 425**
Wheel speed sensor, rear	08.99-07.00		**0 265 006 366**
2.0 T 16V	**2,0 l 118 kW B4204T 4 Zyl.**		
Phase sensor	04.98-07.99	NOC	**0 232 101 029**
Wheel speed sensor, front	04.98-07.99		**0 265 006 425**
Wheel speed sensor, rear	04.98-07.99		**0 265 006 366**
2.0 T4	**1,9 l 147 kW B4204T5 4 Zyl.**		
Pressure sensor, intake manifold, gasoline	08.00-01.04		**0 261 230 029**
Wheel speed sensor, front	08.00-01.04		**0 265 006 425**
Wheel speed sensor, rear			
Fg.no. →985261	08.00-01.04		**0 265 006 366**
Fg.no. 985262→	08.00-01.04		**0 265 006 698**
2.0 16V	**2,0 l 100 kW B4204S2 4 Zyl.**		
Wheel speed sensor, front	08.99-01.04		**0 265 006 425**
Wheel speed sensor, rear			
Fg.no. →985261	08.99-01.04		**0 265 006 366**
Fg.no. 985262→	08.99-01.04		**0 265 006 698**
2.0 16V	**2,0 l 103 kW B4204S 4 Zyl.**		
Phase sensor	09.95-07.99	NOC	**0 232 101 029**
Knock sensor	09.95-07.99		**0 261 231 046**
Wheel speed sensor, front	09.97-07.99		**0 265 006 425**
	09.95-08.97	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
Wheel speed sensor, rear	09.95-07.99		**0 265 006 366**

S40 II

D5 [P 11]	**2,4 l 120/132 kW D5244T8; D5244T9 5 Zyl.**		
Throttle valve assembly	03.06→		**0 281 002 701**
Phase sensor	03.06→	NOC	**0 232 103 063**
High-pressure sensor (CR system)	03.06→		**0 281 002 706**
Boost pressure sensor, Diesel	03.06→		**0 261 230 105**
1.8 [P 11]	**1,8 l 92 kW B4184S11 4 Zyl.**		
Pressure sensor, intake manifold, gasoline	04.04→		**0 261 230 044**
1.8 F [P 11]	**1,8 l 92 kW B4184S8 4 Zyl.**		
Pressure sensor, intake manifold, gasoline	04.06→		**0 261 230 044**
2.0 [P 11]	**2,0 l 107 kW B4204S3 4 Zyl.**		
Pressure sensor, intake manifold, gasoline	10.06→		**0 261 230 044**
2.4 [P 11]	**2,4 l 103/125 kW B5244S4; B5244S5 5 Zyl.**		
Temperature sensor, fuel	12.03→		**0 261 230 109**
2.4 i [P 11]	**2,4 l 125 kW B5244S7 5 Zyl.**		
Temperature sensor, fuel	08.05→		**0 261 230 109**
2.5 T5	**2,5 l 162 kW B 5254 T3 5 Zyl.**		
Throttle valve assembly	12.03→		**0 280 750 146**
Air mass meter, gasoline injection	12.03→		**0 280 218 134**
Knock sensor	12.03→		**0 261 231 178**
2.5 T5 [P 11]	**2,5 l 162 kW B5254T3 5 Zyl.**		
Throttle valve assembly	12.03→		**0 280 750 146**
Air mass meter, gasoline injection	12.03→		**0 280 218 134**
Knock sensor	12.03→		**0 261 231 178**
Pressure sensor, intake manifold, gasoline	12.03→		**0 261 230 110**
Boost pressure sensor, gasoline	12.03-07.07		**0 261 230 090**
	08.07→		**0 261 230 105**
Temperature sensor, fuel	12.03→		**0 261 230 110**
2.5 T5 [P 11]	**2,5 l 169 kW B5254T7 5 Zyl.**		
Throttle valve assembly	08.07→		**0 280 750 146**
Air mass meter, gasoline injection	08.07→		**0 280 218 134**
Knock sensor	08.07→		**0 261 231 178**
Pressure sensor, intake manifold, gasoline	08.07→		**0 261 230 110**
Boost pressure sensor, gasoline	08.07→		**0 261 230 105**
Temperature sensor, fuel	08.07→		**0 261 230 110**
2.5 T5 AWD [P 11]	**2,5 l 162 kW B5254T3 5 Zyl.**		
Throttle valve assembly	04.04→		**0 280 750 146**
Air mass meter, gasoline injection	04.04→		**0 280 218 134**
Knock sensor	04.04→		**0 261 231 178**
Pressure sensor, intake manifold, gasoline	04.04→		**0 261 230 110**
Boost pressure sensor, gasoline	04.04-07.07		**0 261 230 090**
	08.07→		**0 261 230 105**
Temperature sensor, fuel	04.04→		**0 261 230 110**
2.5 T5 AWD [P 11]	**2,5 l 169 kW B5254T7 5 Zyl.**		
Throttle valve assembly	08.07→		**0 280 750 146**
Air mass meter, gasoline injection	08.07→		**0 280 218 134**
Knock sensor	08.07→		**0 261 231 178**
Pressure sensor, intake manifold, gasoline	08.07→		**0 261 230 110**
Boost pressure sensor, gasoline	08.07→		**0 261 230 105**
Temperature sensor, fuel	08.07→		**0 261 230 110**

S60

D [P 24]	**2,4 l 93 kW D5244T7 5 Zyl.**		
Throttle valve assembly	08.05→		**0 281 002 701**
Phase sensor	08.05→	NOC	**0 232 103 063**
High-pressure sensor (CR system)	08.05→		**0 281 002 706**
Boost pressure sensor, Diesel	08.05→		**0 261 230 105**
Temperature sensor, fuel	08.05→		**0 281 002 623**
D5 [P 24]	**2,4 l 136 kW D5244T4 5 Zyl.**		
Throttle valve assembly	08.05→		**0 281 002 701**
Phase sensor	08.05→	NOC	**0 232 103 063**
High-pressure sensor (CR system)	08.05→		**0 281 002 706**
Boost pressure sensor, Diesel	08.05→		**0 261 230 105**
Temperature sensor, fuel	08.05→		**0 281 002 623**
R [P 24]	**2,5 l 220 kW B5254T4 5 Zyl.**		
Throttle valve assembly	03.03-07.07		**0 280 750 131**
Air mass meter, gasoline injection	03.03-07.07		**0 280 218 089**
Knock sensor	03.03-07.07		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	03.03-07.07		**0 261 230 110**
Boost pressure sensor, gasoline	03.03-07.07		**0 261 230 105**
Temperature sensor, fuel	03.03-07.07		**0 261 230 110**
2.0 T [P 24]	**2,0 l 132 kW B5204T5 5 Zyl.**		
Throttle valve assembly	08.01→		**0 280 750 131**
Air mass meter, gasoline injection	08.01→		**0 280 218 088**
	11.00-07.01		**0 280 218 108**
Knock sensor	11.00→		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	11.00→		**0 261 230 110**

V

Product			
Boost pressure sensor, gasoline	08.02→		**0 261 230 090**
Temperature sensor, fuel	11.00→		**0 261 230 110**
2.3 T5 [P 24]		**2,3 l 184-195 kW B5234T3 5 Zyl.**	
Throttle valve assembly	08.01-03.04		**0 280 750 131**
Air mass meter, gasoline injection	08.01-03.04		**0 280 218 088**
	11.00-07.01		**0 280 218 108**
Knock sensor	11.00-03.04		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	11.00-03.04		**0 261 230 110**
Boost pressure sensor, gasoline	08.02-03.04		**0 261 230 090**
Temperature sensor, fuel	11.00-03.04		**0 261 230 110**
2.4 [P 24]		**2,4 l 103/125 kW B5244S; B5244S2 5 Zyl.**	
Temperature sensor, fuel	08.02→		**0 261 230 109**
2.4 Bi-Fuel CNG [P 24]		**2,4 l 103 kW B5244SG 5 Zyl.**	
Temperature sensor, fuel	08.02→		**0 261 230 109**
2.4 Bi-Fuel LPG [P 24]		**2,4 l 103 kW B5244SG2 5 Zyl.**	
Temperature sensor, fuel	08.02→		**0 261 230 109**
2.4 D [P 24]		**2,4 l 96/120 kW D5244T; D5244T2 5 Zyl.**	
Air mass meter, diesel	08.01-07.06		**0 280 218 088**
Phase sensor	08.01-07.06	NOC	**0 232 103 042**
Boost pressure sensor, Diesel	08.01-07.06		**0 261 230 090**
2.4 D [P 24]		**2,4 l 120 kW D5244T5 5 Zyl.**	
Throttle valve assembly	08.06→		**0 281 002 701**
Phase sensor	08.06→	NOC	**0 232 103 063**
High-pressure sensor (CR system)	08.06→		**0 281 002 706**
Boost pressure sensor, Diesel	08.06→		**0 261 230 105**
Temperature sensor, fuel	08.06→		**0 281 002 623**
2.4 T [P 24]		**2,4 l 147 kW B5244T3 5 Zyl.**	
Throttle valve assembly	08.01-07.03		**0 280 750 131**
Air mass meter, gasoline injection	08.01-07.03		**0 280 218 088**
	11.00-07.01		**0 280 218 108**
Knock sensor	11.00-07.03		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	11.00-07.03		**0 261 230 110**
Boost pressure sensor, gasoline	08.02-07.03		**0 261 230 090**
Temperature sensor, fuel	11.00-07.03		**0 261 230 110**
2.4 T [P 24]		**2,4 l 147 kW B5244T4 5 Zyl.**	
Throttle valve assembly	08.03→		**0 280 750 131**
Air mass meter, gasoline injection	08.03→		**0 280 218 089**
Knock sensor	08.03→		**0 261 231 142**
Boost pressure sensor, gasoline	08.03→		**0 261 230 090**
Temperature sensor, fuel	08.03→		**0 261 230 110**
2.4 T AWD [P 24]		**2,4 l 147 kW B5244T3 5 Zyl.**	
Throttle valve assembly	11.01-07.03		**0 280 750 131**
Air mass meter, gasoline injection	11.01-07.03		**0 280 218 088**
Knock sensor	11.01-07.03		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	11.01-07.03		**0 261 230 110**
Boost pressure sensor, gasoline	08.02-07.03		**0 261 230 090**
Temperature sensor, fuel	11.01-07.03		**0 261 230 110**
2.4 T AWD [P 24]		**2,4 l 147 kW B5244T4 5 Zyl.**	
Throttle valve assembly	08.03→		**0 280 750 131**
Air mass meter, gasoline injection	08.03→		**0 280 218 089**
Knock sensor	08.03→		**0 261 231 142**
Boost pressure sensor, gasoline	08.03→		**0 261 230 090**
Temperature sensor, fuel	08.03→		**0 261 230 110**
2.4 T5 [P 24]		**2,4 l 191 kW B5244T5 5 Zyl.**	
Throttle valve assembly	04.04→		**0 280 750 131**
Air mass meter, gasoline injection	04.04→		**0 280 218 089**
Knock sensor	04.04→		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	04.04→		**0 261 230 110**
Boost pressure sensor, gasoline	04.04→		**0 261 230 105**
Temperature sensor, fuel	04.04→		**0 261 230 110**
2.5 T, T AWD [P 24]		**2,5 l 154 kW B5254T2 5 Zyl.**	
Throttle valve assembly	04.04→		**0 280 750 131**
Air mass meter, gasoline injection	04.04→		**0 280 218 088**

Product			
Knock sensor	04.04→		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	04.04→		**0 261 230 110**
Boost pressure sensor, gasoline	04.04→		**0 261 230 090**
Temperature sensor, fuel	04.04→		**0 261 230 110**

S70

R 2.3 T, T AWD		**2,3 l 184 kW B5234T4 5 Zyl.**	
Throttle valve sensor	01.97-07.98		**0 280 122 001**
Air mass meter, gasoline injection	01.97-07.98		**0 280 217 107**
Phase sensor	01.97-07.98	NOC	**0 232 101 030**
Knock sensor	01.97-07.98		**0 261 231 121**
2.0		**2,0 l 93 kW B5202 S 5 Zyl.**	
Throttle valve sensor	01.97-07.99		**0 280 122 001**
Phase sensor	01.97-07.99	NOC	**0 232 101 030**
Knock sensor	01.97-07.99		**0 261 231 121**
2.0		**2,0 l 105 kW B 5204 S 5 Zyl.**	
Throttle valve sensor	01.97-07.98		**0 280 122 001**
Air mass meter, gasoline injection	01.97-07.98		**0 280 217 107**
Phase sensor	01.97-07.98	NOC	**0 232 101 030**
Knock sensor	01.97-07.98		**0 261 231 121**
2.0 T		**2,0 l 132/155 kW B5204T; B5204T2 5 Zyl.**	
Throttle valve sensor	01.97-07.98		**0 280 122 001**
Air mass meter, gasoline injection	01.97-07.98		**0 280 217 107**
Phase sensor	01.97-07.98	NOC	**0 232 101 030**
Knock sensor	01.97-07.98		**0 261 231 121**
2.0 T		**2,0 l 166 kW B 5204 T3 5 Zyl.**	
Throttle valve sensor	08.98-07.00		**0 280 122 001**
Air mass meter, gasoline injection	08.98-07.00		**0 280 218 108**
Knock sensor	08.98-07.00		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	08.98-07.00		**0 261 230 018**
2.0 T AWD		**2,0 l 166 kW B5204T3 5 Zyl.**	
Throttle valve sensor	08.98-07.00		**0 280 122 001**
Air mass meter, gasoline injection	08.98-07.00		**0 280 218 108**
Knock sensor	08.98-07.00		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	08.98-07.00		**0 261 230 018**
2.0 T 20V		**2,0 l 120 kW B5204T4 5 Zyl.**	
Throttle valve sensor	08.98-07.00		**0 280 122 001**
Air mass meter, gasoline injection	08.98-07.00		**0 280 218 108**
Knock sensor	08.98-07.00		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	08.98-07.00		**0 261 230 018**
2.3		**2,3 l 120 kW B5234S 5 Zyl.**	
Throttle valve sensor	01.97-07.99		**0 280 122 001**
Air mass meter, gasoline injection	01.97-07.98		**0 280 217 107**
Phase sensor	01.97-07.98	NOC	**0 232 101 030**
Knock sensor	01.97-07.98		**0 261 231 121**
	08.98-07.99		**0 261 231 142**
2.3		**2,3 l 140 kW B5234T7 5 Zyl.**	
Throttle valve sensor	08.98-07.00		**0 280 122 001**
Air mass meter, gasoline injection	08.98-07.00		**0 280 218 108**
Knock sensor	08.98-07.00		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	08.98-07.00		**0 261 230 018**
2.3		**2,3 l 160 kW B5234T2 5 Zyl.**	
Throttle valve sensor	01.97-07.98		**0 280 122 001**
Air mass meter, gasoline injection	01.97-07.98		**0 280 217 107**
Phase sensor	01.97-07.98	NOC	**0 232 101 030**
Knock sensor	01.97-07.98		**0 261 231 121**
Pressure sensor, intake manifold, gasoline	01.97-07.98		**0 261 230 018**
2.3 T-5		**2,3 l 176 kW B5234T3 5 Zyl.**	
Throttle valve sensor	01.97-07.00		**0 280 122 001**
Air mass meter, gasoline injection	01.97-07.98		**0 280 217 107**
	08.98-07.00		**0 280 218 108**
Phase sensor	01.97-07.98	NOC	**0 232 101 030**

V

Product			
◀ S70			
Knock sensor	01.97-07.98		**0 261 231 121**
	08.98-07.00		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	01.97-07.00		**0 261 230 018**
2.4	**2,4 l 103/125 kW B5244S; B5244S2 5 Zyl.**		
Throttle valve sensor	08.99-07.00		**0 280 122 001**
Knock sensor	08.99-07.00		**0 261 231 142**
2.4	**2,4 l 142 kW B5244T 5 Zyl.**		
Throttle valve sensor	01.99-07.00		**0 280 122 001**
Air mass meter, gasoline injection	01.99-07.00		**0 280 218 108**
Knock sensor	01.99-07.00		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	01.99-07.00		**0 261 230 018**
2.4 AWD	**2,4 l 125 kW B5244S 5 Zyl.**		
Throttle valve sensor	08.99-07.00		**0 280 122 001**
Knock sensor	08.99-07.00		**0 261 231 142**
2.5	**2,4 l 106 kW B5252S 5 Zyl.**		
Throttle valve sensor	01.97-07.99		**0 280 122 001**
Phase sensor	01.97-07.99	NOC	**0 232 101 030**
Knock sensor	01.97-07.99		**0 261 231 121**
2.5 BI-FUEL	**2,4 l 106 kW B5252S 5 Zyl.**		
Throttle valve sensor	08.98-07.99		**0 280 122 001**
Phase sensor	08.98-07.99	NOC	**0 232 101 030**
2.5 T	**2,4 l 142 kW B5254T 5 Zyl.**		
Throttle valve sensor	01.97-07.99		**0 280 122 001**
Air mass meter, gasoline injection	01.97-07.98		**0 280 217 107**
	08.98-07.99		**0 280 218 108**
Phase sensor	01.97-07.98	NOC	**0 232 101 030**
Knock sensor	01.97-07.98		**0 261 231 121**
	08.98-07.99		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	01.97-07.99		**0 261 230 018**
2.5 T AWD	**2,4 l 142 kW B5254T 5 Zyl.**		
Throttle valve sensor	08.98-07.99		**0 280 122 001**
Air mass meter, gasoline injection	08.98-07.99		**0 280 218 108**
Knock sensor	08.98-07.99		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	08.98-07.99		**0 261 230 018**
2.5 TDI	**2,5 l 103 kW D5252 T 5 Zyl.**		
Air flow sensor, diesel			
Fg.no. →596595	01.97-07.00		**0 281 002 155**
Air mass meter, diesel			
Fg.no. 596596→	01.97-07.00		**0 280 218 108**
2.5 20V	**2,4 l 121 kW B5254S 5 Zyl.**		
Throttle valve sensor	01.97-07.99		**0 280 122 001**
Air mass meter, gasoline injection	01.97-07.98		**0 280 217 107**
Phase sensor	01.97-07.98	NOC	**0 232 101 030**
Knock sensor	01.97-07.98		**0 261 231 121**
	08.98-07.99		**0 261 231 142**

S80 I

D5 [P 23]	**2,4 l 120 kW D5244T 5 Zyl.**		
Air mass meter, diesel	08.01-07.06		**0 280 218 088**
Phase sensor	08.01-07.06	NOC	**0 232 103 042**
Boost pressure sensor, Diesel	08.01-07.06	UE	**0 261 230 090**
2.0 T [P 23]	**2,0 l 120 kW B5204T4 5 Zyl.**		
Air mass meter, gasoline injection	08.98-07.00		**0 280 218 108**
Knock sensor	08.98-07.00		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	08.98-07.00		**0 261 230 110**
		OE	**0 261 230 029**
Boost pressure sensor, gasoline	08.98-07.00	UE	**0 261 230 090**
Temperature sensor, fuel	08.98-07.00		**0 261 230 110**
2.0 T [P 23]	**2,0 l 132 kW B5204T5 5 Zyl.**		
Throttle valve assembly	08.02-07.06		**0 280 750 131**
Air mass meter, gasoline injection	08.01-07.06		**0 280 218 088**
	08.99-07.01		**0 280 218 108**
Knock sensor	08.99-07.06		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	08.99-07.02		**0 261 230 110**
		OE	**0 261 230 029**
Boost pressure sensor, gasoline	08.99-07.06	UE	**0 261 230 090**
Temperature sensor, fuel	08.99-07.06		**0 261 230 110**
2.0 T5 [P 23]	**2,0 l 166 kW B5204T3 5 Zyl.**		
Air mass meter, gasoline injection	08.98-07.00		**0 280 218 108**
Knock sensor	08.98-07.00		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	08.98-07.00		**0 261 230 110**
		OE	**0 261 230 029**
Boost pressure sensor, gasoline	08.98-07.00	UE	**0 261 230 090**
Temperature sensor, fuel	08.98-07.00		**0 261 230 110**
2.3 R [P 23]	**2,3 l 195 kW B5234T7 5 Zyl.**		
Throttle valve assembly	08.01-07.05		**0 280 750 131**
Air mass meter, gasoline injection	08.01-07.05		**0 280 218 088**
	04.00-07.01		**0 280 218 108**
Knock sensor	04.00-07.05		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	04.00-07.02		**0 261 230 110**
		OE	**0 261 230 029**
Boost pressure sensor, gasoline	04.00-07.05	UE	**0 261 230 090**
Temperature sensor, fuel	04.00-07.05		**0 261 230 110**
2.4 D [P 23]	**2,4 l 96 kW D5244T2 5 Zyl.**		
Air mass meter, diesel	10.01-07.06		**0 280 218 088**
Phase sensor	10.01-07.06	NOC	**0 232 103 042**
Boost pressure sensor, Diesel	10.01-07.06	UE	**0 261 230 090**
2.4 T, T AWD [P 23]	**2,4 l 147 kW B5244T3 5 Zyl.**		
Throttle valve assembly	08.01-07.03		**0 280 750 131**
Air mass meter, gasoline injection	08.01-07.03		**0 280 218 088**
	08.00-07.01		**0 280 218 108**
Knock sensor	08.00-07.03		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	08.00-07.02		**0 261 230 110**
		OE	**0 261 230 029**
Boost pressure sensor, gasoline	08.00-07.03	UE	**0 261 230 090**
Temperature sensor, fuel	08.00-07.03		**0 261 230 110**
2.5 , AWD [P 23]	**2,5 l 154 kW B5254T2 5 Zyl.**		
Throttle valve assembly	08.03-07.06		**0 280 750 131**
Air mass meter, gasoline injection	08.03-07.06		**0 280 218 088**
Knock sensor	08.03-07.06		**0 261 231 142**
Boost pressure sensor, gasoline	08.03-07.06	UE	**0 261 230 090**
Temperature sensor, fuel	08.03-07.06		**0 261 230 110**
2.5 TDI [P 23]	**2,5 l 103 kW D5252T 5 Zyl.**		
Air mass meter, diesel	08.98-07.01		**0 280 218 108**
2.8 T6 [P 23]	**2,8 l 200 kW B6284 T; B6284T 6 Zyl.**		
Air mass meter, gasoline injection	06.98-07.01		**0 280 218 109**
Knock sensor	06.98-07.01		**0 261 231 142**
Boost pressure sensor, gasoline	06.98-07.01	UE	**0 261 230 090**
2.9 [P 23]	**2,9 l 147/150 kW B6294S; B6304 S3; B6304S3 6 Zyl.**		
Air mass meter, gasoline injection	06.98-07.01		**0 280 218 108**
Knock sensor	06.98-07.01		**0 261 231 142**
3.0 [P 23]	**2,9 l 144 kW B6294S2 6 Zyl.**		
Throttle valve assembly	08.01-07.06		**0 280 750 131**
Air mass meter, gasoline injection	08.01-07.06		**0 280 218 088**
Knock sensor	08.01-07.06		**0 261 231 142**
3.0 T6 [P 23]	**2,9 l 200 kW B6294T 6 Zyl.**		
Throttle valve assembly	08.02-07.06		**0 280 750 131**
Air mass meter, gasoline injection	08.01-07.06		**0 280 218 089**
Knock sensor	08.01-07.06		**0 261 231 142**
Boost pressure sensor, gasoline	08.01-07.06	UE	**0 261 230 090**

V

Product			

S80 II

2.4 D			**2,4 l 120 kW D5244T5 5 Zyl.**
Throttle valve assembly	08.06→		**0 281 002 701**
Phase sensor	08.06→	NOC	**0 232 103 063**
Boost pressure sensor, Diesel	08.06→		**0 261 230 105**
2.4 D5, D5 AWD			**2,4 l 136 kW D5244T4 5 Zyl.**
Throttle valve assembly	03.06→		**0 281 002 701**
Phase sensor	03.06→	NOC	**0 232 103 063**
Boost pressure sensor, Diesel	03.06→		**0 261 230 105**
2.5 T			**2,5 l 147 kW B5254T6 5 Zyl.**
Throttle valve assembly	03.06→		**0 280 750 146**
Air mass meter, gasoline injection	03.06→		**0 280 218 134**
Knock sensor	03.06→		**0 261 231 178**
Boost pressure sensor, gasoline	03.06→		**0 261 230 105**
Temperature sensor, fuel	03.06→		**0 261 230 110**
3.0 T6 AWD			**3,0 l 210 kW B6304T2 6 Zyl.**
Boost pressure sensor, gasoline	01.07→		**0 261 230 105**
Temperature sensor, fuel	01.07→		**0 261 230 110**
3.2 , AWD			**3,2 l 175 kW B6324S 6 Zyl.**
Pressure sensor, intake manifold, gasoline	08.06→		**0 261 230 110**
Temperature sensor, fuel	08.06→		**0 261 230 110**
4.4 V8 AWD			**4,4 l 232 kW B8444S 8 Zyl.**
Temperature sensor, fuel	03.06→		**0 261 230 110**

S90

2.4			**2,4 l 120 kW B6244S 6 Zyl.**
Throttle valve sensor	05.97-12.99		**0 280 122 001**
Air mass meter, gasoline injection	05.97-12.99		**0 280 217 511**
2.9			**2,9 l 132 kW B6304S 6 Zyl.**
Throttle valve sensor	01.97-05.98		**0 280 122 001**
Air mass meter, gasoline injection	01.97-05.98		**0 280 217 511**
2.9 , Exekutive, Exekutive Plus			**2,9 l 150 kW B6304S 6 Zyl.**
Throttle valve sensor	01.97-05.98		**0 280 122 001**
Air mass meter, gasoline injection	01.97-05.98		**0 280 217 511**
Phase sensor	01.97-05.98	NOC	**0 232 101 030**
Knock sensor	01.97-05.98		**0 261 231 046**

V40

1.6 16V			**1,6 l 77 kW B4164S 4 Zyl.**
Phase sensor	01.97-07.99	NOC	**0 232 101 029**
Wheel speed sensor, front	09.97-07.99		**0 265 006 425**
	01.97-08.97	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
Wheel speed sensor, rear	01.97-07.99		**0 265 006 366**
1.6 16V			**1,6 l 80 kW B4164S2 4 Zyl.**
Wheel speed sensor, front	08.99-04.04		**0 265 006 425**
Wheel speed sensor, rear			
Fg.no. →985261	08.99-04.04		**0 265 006 366**
Fg.no. 985262→	08.99-04.04		**0 265 006 698**
1.8 16V			**1,8 l 85 kW B4184S 4 Zyl.**
Phase sensor	01.95-07.99	NOC	**0 232 101 029**
Wheel speed sensor, front	09.97-07.99		**0 265 006 425**
	09.95-08.97	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
Wheel speed sensor, rear	01.95-07.99		**0 265 006 366**
1.8 16V			**1,8 l 90 kW B4184SJ; B4184S2; B4184S3; B4184S9 4 Zyl.**
Wheel speed sensor, front	08.99-04.04		**0 265 006 425**
Wheel speed sensor, rear			
Fg.no. →985261	08.99-04.04		**0 265 006 366**
Fg.no. 985262→	08.99-04.04		**0 265 006 698**

Product			

1.8 16V			**1,8 l 90 kW B4184S10 4 Zyl.**
Phase sensor	04.99-08.99	NOC	**0 232 101 029**
Wheel speed sensor, front	04.99-06.04		**0 265 006 425**
Wheel speed sensor, rear			
Fg.no. →985261	04.99-06.04		**0 265 006 366**
Fg.no. 985262→	04.99-06.04		**0 265 006 698**
1.8 16V			**1,8 l 92 kW B4184SM 4 Zyl.**
Wheel speed sensor, front	09.97-07.00		**0 265 006 425**
Wheel speed sensor, rear			
Fg.no. →985261	08.97-07.00		**0 265 006 366**
Fg.no. 985262→	08.97-07.00		**0 265 006 698**
1.9 D			**1,9 l 66 kW D4192T 4 Zyl.**
Speed sensor, diesel	01.96-07.99		**0 281 002 349**
Wheel speed sensor, front	09.97-07.99		**0 265 006 425**
	01.96-08.97	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
Wheel speed sensor, rear	01.96-07.99		**0 265 006 366**
1.9 D			**1,9 l 70/75/85 kW D4192T2; D4192T3/DI; D4192T4/DI 4 Zyl.**
Wheel speed sensor, front	08.98-04.04		**0 265 006 425**
Wheel speed sensor, rear			
Fg.no. →985261	08.98-04.04		**0 265 006 366**
Fg.no. 985262→	08.98-04.04		**0 265 006 698**
1.9 T4			**1,9 l 147 kW B4194T 4 Zyl.**
Phase sensor	05.97-07.99	NOC	**0 232 101 029**
Wheel speed sensor, front	09.97-07.99		**0 265 006 425**
	05.97-08.97	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
Wheel speed sensor, rear	05.97-07.99		**0 265 006 366**
1.9 T4			**1,9 l 147 kW B4194T2 4 Zyl.**
Wheel speed sensor, front	08.99-07.00		**0 265 006 425**
Wheel speed sensor, rear			
Fg.no. →985261	08.99-07.00		**0 265 006 366**
Fg.no. 985262→	08.99-07.00		**0 265 006 698**
2.0			**2,0 l 103 kW B4204S 4 Zyl.**
Phase sensor	01.96-07.99	NOC	**0 232 101 029**
Wheel speed sensor, front	09.97-07.99		**0 265 006 425**
	01.96-08.97	LAB	**0 265 006 224**
		RAB	**0 265 006 223**
Wheel speed sensor, rear	01.96-07.99		**0 265 006 366**
2.0 T			**1,9 l 120 kW B4204T3 4 Zyl.**
Pressure sensor, intake manifold, gasoline	08.01-04.04		**0 261 230 029**
Wheel speed sensor, front	08.01-04.04		**0 265 006 425**
Wheel speed sensor, rear			
Fg.no. →985261	08.01-04.04		**0 265 006 366**
Fg.no. 985262→	08.01-04.04		**0 265 006 698**
2.0 T			**2,0 l 121 kW B4204T3 4 Zyl.**
Pressure sensor, intake manifold, gasoline	08.00-07.01		**0 261 230 029**
Wheel speed sensor, front	08.00-07.01		**0 265 006 425**
Wheel speed sensor, rear			
Fg.no. →985261	08.00-07.01		**0 265 006 366**
Fg.no. 985262→	08.00-07.01		**0 265 006 698**
2.0 T4 T			**2,0 l 147 kW B4204T5 4 Zyl.**
Pressure sensor, intake manifold, gasoline	08.00-04.04		**0 261 230 029**
Wheel speed sensor, front	08.00-04.04		**0 265 006 425**
Wheel speed sensor, rear			
Fg.no. →985261	08.00-04.04		**0 265 006 366**
Fg.no. 985262→	08.00-04.04		**0 265 006 698**
2.0 16V			**2,0 l 100 kW B4204S2 4 Zyl.**
Wheel speed sensor, front	08.99-04.04		**0 265 006 425**
Wheel speed sensor, rear			
Fg.no. →985261	08.99-04.04		**0 265 006 366**
Fg.no. 985262→	08.99-04.04		**0 265 006 698**

V

Product			
◀ V40			
2.0 16V T			**1,9 l 118 kW B4204T2 4 Zyl.**
Wheel speed sensor, front	08.99-07.00		**0 265 006 425**
Wheel speed sensor, rear			
Fg.no. 985262→	08.99-07.00		**0 265 006 698**
2.0 16V T			**2,0 l 118 kW B4204T 4 Zyl.**
Phase sensor	04.98-07.99	NOC	**0 232 101 029**
Wheel speed sensor, front	04.98-07.99		**0 265 006 425**
Wheel speed sensor, rear	04.98-07.99		**0 265 006 366**

V50

D5 [P 12]			**2,4 l 120/132 kW D5244T8; D5244T9 5 Zyl.**
Throttle valve assembly	04.06→		**0 281 002 701**
Phase sensor	04.06→	NOC	**0 232 103 063**
High-pressure sensor (CR system)	04.06→		**0 281 002 706**
Boost pressure sensor, Diesel	04.06→		**0 261 230 105**
T5 [P 12]			**2,5 l 162 kW B5254T3 5 Zyl.**
Throttle valve assembly	04.04→		**0 280 750 146**
Air mass meter, gasoline injection	04.04→		**0 280 218 134**
Knock sensor	04.04→		**0 261 231 178**
Boost pressure sensor, gasoline	04.04-07.07		**0 261 230 090**
	08.07→		**0 261 230 105**
Temperature sensor, fuel	04.04→		**0 261 230 110**
T5 [P 12]			**2,5 l 169 kW B5254T7 5 Zyl.**
Throttle valve assembly	08.07→		**0 280 750 146**
Air mass meter, gasoline injection	08.07→		**0 280 218 134**
Knock sensor	08.07→		**0 261 231 178**
Boost pressure sensor, gasoline	08.07→		**0 261 230 105**
Temperature sensor, fuel	08.07→		**0 261 230 110**
T5 AWD [P 12]			**2,5 l 162 kW B5254T3 5 Zyl.**
Throttle valve assembly	04.04→		**0 280 750 146**
Air mass meter, gasoline injection	04.04→		**0 280 218 134**
Knock sensor	04.04→		**0 261 231 178**
Boost pressure sensor, gasoline	04.04-07.07		**0 261 230 090**
	08.07→		**0 261 230 105**
Temperature sensor, fuel	04.04→		**0 261 230 110**
T5 AWD [P 12]			**2,5 l 169 kW B5254T7 5 Zyl.**
Throttle valve assembly	08.07→		**0 280 750 146**
Air mass meter, gasoline injection	08.07→		**0 280 218 134**
Knock sensor	08.07→		**0 261 231 178**
Boost pressure sensor, gasoline	08.07→		**0 261 230 105**
Temperature sensor, fuel	08.07→		**0 261 230 110**
1.8 [P 12]			**1,8 l 92 kW B4184S11 4 Zyl.**
Pressure sensor, intake manifold, gasoline	04.04→		**0 261 230 044**
1.8 F [P 12]			**1,8 l 92 kW B4184S8 4 Zyl.**
Pressure sensor, intake manifold, gasoline	04.06→		**0 261 230 044**
2.0 [P 12]			**2,0 l 107 kW B4204S3 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.06→		**0 261 230 044**
2.4 [P 12]			**2,4 l 103 kW B5244S5 5 Zyl.**
Temperature sensor, fuel	04.04→		**0 261 230 109**
2.4 i [P 12]			**2,4 l 125 kW B5244S4; B5244S7 5 Zyl.**
Temperature sensor, fuel	04.04→		**0 261 230 109**

V70 I

2.0			**2,0 l 93 kW B5202FS 5 Zyl.**
Phase sensor	01.97-07.98	NOC	**0 232 101 030**
Knock sensor	01.97-07.98		**0 261 231 121**
	08.98-07.99		**0 261 231 142**
2.0			**2,0 l 105 kW B5204S 5 Zyl.**
Throttle valve sensor	01.97-07.98		**0 280 122 001**
Air mass meter, gasoline injection	01.97-07.98		**0 280 217 107**
Phase sensor	01.97-07.98	NOC	**0 232 101 030**
Knock sensor	01.97-07.98		**0 261 231 121**
Pressure sensor, intake manifold, gasoline	01.97-07.99		**0 261 230 018**
2.0 T 20V			**2,0 l 120 kW B5204T4 5 Zyl.**
Throttle valve sensor	08.98-03.00		**0 280 122 001**
Air mass meter, gasoline injection	08.98-03.00		**0 280 218 108**
Knock sensor	08.98-03.00		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	08.98-03.00		**0 261 230 018**
2.0 Turbo			**2,0 l 132 kW B5204T2 5 Zyl.**
Throttle valve sensor	01.97-07.98		**0 280 122 001**
Air mass meter, gasoline injection	01.97-07.98		**0 280 217 107**
Phase sensor	01.97-07.98	NOC	**0 232 101 030**
Knock sensor	01.97-07.98		**0 261 231 121**
2.0 Turbo			**2,0 l 155 kW B5204T 5 Zyl.**
Throttle valve sensor	01.97-03.00		**0 280 122 001**
Air mass meter, gasoline injection	01.97-07.98		**0 280 217 107**
	08.98-03.00		**0 280 218 108**
Phase sensor	01.97-07.98	NOC	**0 232 101 030**
Knock sensor	01.97-07.98		**0 261 231 121**
	08.98-03.00		**0 261 231 142**
2.0 Turbo			**2,0 l 166 kW B5204T3 5 Zyl.**
Throttle valve sensor	01.97-07.99		**0 280 122 001**
Air mass meter, gasoline injection	01.97-07.98		**0 280 217 107**
	08.98-07.99		**0 280 218 108**
Phase sensor	01.97-07.98	NOC	**0 232 101 030**
Knock sensor	01.97-07.98		**0 261 231 121**
	08.98-07.99		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	01.97-07.99		**0 261 230 018**
2.3			**2,3 l 160 kW B5234T2 5 Zyl.**
Throttle valve sensor	01.97-07.98		**0 280 122 001**
Air mass meter, gasoline injection	01.97-07.98		**0 280 217 107**
Phase sensor	01.97-07.98	NOC	**0 232 101 030**
Knock sensor	01.97-07.98		**0 261 231 121**
Pressure sensor, intake manifold, gasoline	01.97-07.98		**0 261 230 018**
2.3 AWD			**2,3 l 195 kW B5234T8 5 Zyl.**
Throttle valve sensor	12.98-03.00		**0 280 122 001**
Air mass meter, gasoline injection	12.98-03.00		**0 280 218 108**
Knock sensor	12.98-03.00		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	12.98-03.00		**0 261 230 018**
2.3 R			**2,3 l 184 kW B5234T4 5 Zyl.**
Throttle valve sensor	01.97-07.98		**0 280 122 001**
Air mass meter, gasoline injection	01.97-07.98		**0 280 217 107**
Phase sensor	01.97-07.98	NOC	**0 232 101 030**
Knock sensor	01.97-07.98		**0 261 231 121**
2.3 R AWD			**2,3 l 184 kW B5234T4 5 Zyl.**
Throttle valve sensor	08.97-07.98		**0 280 122 001**
Air mass meter, gasoline injection	08.97-07.98		**0 280 217 107**
Phase sensor	08.97-07.98	NOC	**0 232 101 030**
Knock sensor	08.97-07.98		**0 261 231 121**
Pressure sensor, intake manifold, gasoline	08.97-07.98		**0 261 230 018**
2.3 T-5			**2,3 l 176 kW B5234T3 5 Zyl.**
Throttle valve sensor	01.97-03.00		**0 280 122 001**
Air mass meter, gasoline injection	01.97-07.98		**0 280 217 107**
	08.98-03.00		**0 280 218 108**
Phase sensor	01.97-07.98	NOC	**0 232 101 030**

Product			
Knock sensor	01.97-07.98		**0 261 231 121**
	08.98-03.00		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	01.97-03.00		**0 261 230 018**
2.3 T-5 AWD		**2,3 l 176 kW B5234T6 5 Zyl.**	
Throttle valve sensor	01.97-03.00		**0 280 122 001**
Air mass meter, gasoline injection	01.97-07.98		**0 280 217 107**
	08.98-03.00		**0 280 218 108**
Phase sensor	01.97-07.98	NOC	**0 232 101 030**
Knock sensor	01.97-07.98		**0 261 231 121**
	08.98-03.00		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	01.97-03.00		**0 261 230 018**
2.5		**2,4 l 106 kW B5252S 5 Zyl.**	
Phase sensor	01.97-07.98	NOC	**0 232 101 030**
Knock sensor	01.97-07.98		**0 261 231 121**
	08.98-03.00		**0 261 231 142**
2.5 AWD		**2,4 l 195 kW B5244T2 5 Zyl.**	
Throttle valve sensor	03.99-03.00		**0 280 122 001**
Air mass meter, gasoline injection	03.99-03.00		**0 280 218 108**
Knock sensor	03.99-03.00		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	03.99-03.00		**0 261 230 018**
2.5 BI-FUEL		**2,4 l 103 kW GB5252S 5 Zyl.**	
Phase sensor	08.97-07.98	NOC	**0 232 101 030**
Knock sensor	08.97-07.98		**0 261 231 121**
2.5 T		**2,4 l 142 kW B5254T 5 Zyl.**	
Throttle valve sensor	01.97-03.00		**0 280 122 001**
Air mass meter, gasoline injection	01.97-07.98		**0 280 217 107**
	08.98-03.00		**0 280 218 108**
Phase sensor	01.97-07.98	NOC	**0 232 101 030**
Knock sensor	01.97-07.98		**0 261 231 121**
	08.98-03.00		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	01.97-03.00		**0 261 230 018**
2.5 T AWD		**2,4 l 142 kW B5254T 5 Zyl.**	
Throttle valve sensor	01.97-03.00		**0 280 122 001**
Air mass meter, gasoline injection	01.97-07.98		**0 280 217 107**
Phase sensor	01.97-07.98	NOC	**0 232 101 030**
Knock sensor	01.97-07.98		**0 261 231 121**
	08.98-03.00		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	01.97-03.00		**0 261 230 018**
2.5 T XC, T XC AWD		**2,4 l 142 kW B5254T 5 Zyl.**	
Air mass meter, gasoline injection	01.97-07.98		**0 280 217 107**
	08.98-03.00		**0 280 218 108**
Knock sensor	01.97-07.98		**0 261 231 121**
	08.98-03.00		**0 261 231 142**
2.5 TDI		**2,5 l 103 kW D5252T 5 Zyl.**	
Air flow sensor, diesel			
Fg.no. →587536	01.97-03.00		**0 281 002 155**
Air mass meter, diesel			
Fg.no. 587537→	01.97-03.00		**0 280 218 108**
2.5 20V		**2,4 l 121 kW B5254S 5 Zyl.**	
Throttle valve sensor	01.97-07.98		**0 280 122 001**
Air mass meter, gasoline injection	01.97-07.98		**0 280 217 107**
Phase sensor	01.97-07.98	NOC	**0 232 101 030**
Knock sensor	01.97-07.98		**0 261 231 121**

V70 II

2.0 T		**2,0 l 132 kW B5204T5 5 Zyl.**	
Throttle valve assembly	08.01-07.02		**0 280 750 103**
	08.02-07.07		**0 280 750 131**
Air mass meter, gasoline injection	08.01-07.07		**0 280 218 088**
	03.00-07.01		**0 280 218 108**
Knock sensor	03.00-07.07		**0 261 231 142**
Boost pressure sensor, gasoline	08.02-07.07		**0 261 230 090**
Temperature sensor, fuel	03.00-07.07		**0 261 230 110**
2.3 T5		**2,3 l 184 kW B5234T3 5 Zyl.**	
Throttle valve assembly	08.01-07.02		**0 280 750 103**
	08.02-07.04		**0 280 750 131**
Air mass meter, gasoline injection	08.01-07.04		**0 280 218 088**
	03.00-07.01		**0 280 218 108**
Knock sensor	03.00-07.04		**0 261 231 142**
Boost pressure sensor, gasoline	08.02-07.04		**0 261 230 090**
Temperature sensor, fuel	03.00-07.04		**0 261 230 110**
2.4		**2,4 l 103/125 kW B5244S; B5244S2; B5244S6 5 Zyl.**	
Temperature sensor, fuel	08.02-07.07		**0 261 230 109**
2.4 D		**2,4 l 90/93 kW D5244T6; D5244T7 5 Zyl.**	
Phase sensor	08.06-07.07	NOC	**0 232 103 063**
2.4 D		**2,4 l 96/120 kW D5244T; D5244T2 5 Zyl.**	
Air mass meter, diesel	08.01-07.06		**0 280 218 088**
Phase sensor	08.01-07.06	NOC	**0 232 103 042**
2.4 D		**2,4 l 120 kW D5244T5 5 Zyl.**	
Phase sensor	08.06-07.07	NOC	**0 232 103 063**
2.4 D AWD		**2,4 l 120 kW D5244T 5 Zyl.**	
Air mass meter, diesel	08.02-07.06		**0 280 218 088**
Phase sensor	08.02-07.06	NOC	**0 232 103 042**
2.4 D5		**2,4 l 136 kW D5244T3 5 Zyl.**	
Air mass meter, diesel	12.05-07.06		**0 280 218 088**
Phase sensor	12.05-07.06	NOC	**0 232 103 042**
2.4 D5		**2,4 l 136 kW D5244T4 5 Zyl.**	
Phase sensor	08.06-07.07	NOC	**0 232 103 063**
2.4 D5 AWD		**2,4 l 136 kW D5244T3 5 Zyl.**	
Air mass meter, diesel	12.05-07.06		**0 280 218 088**
Phase sensor	12.05-07.06	NOC	**0 232 103 042**
2.4 D5 AWD		**2,4 l 136 kW D5244T4 5 Zyl.**	
Phase sensor	08.06-07.07	NOC	**0 232 103 063**
2.4 T		**2,4 l 147 kW B5244T3 5 Zyl.**	
Throttle valve assembly	08.01-07.02		**0 280 750 103**
	08.02-07.03		**0 280 750 131**
Air mass meter, gasoline injection	08.01-07.03		**0 280 218 088**
	03.00-07.01		**0 280 218 108**
Knock sensor	03.00-07.03		**0 261 231 142**
Boost pressure sensor, gasoline	08.02-07.03		**0 261 230 090**
Temperature sensor, fuel	03.00-07.03		**0 261 230 110**
2.4 T5		**2,4 l 191 kW B5244T5 5 Zyl.**	
Throttle valve assembly	04.04-07.07		**0 280 750 131**
Air mass meter, gasoline injection	04.04-07.07		**0 280 218 089**
Knock sensor	04.04-07.07		**0 261 231 142**
Boost pressure sensor, gasoline	04.04-07.07		**0 261 230 090**
Temperature sensor, fuel	04.04-07.07		**0 261 230 110**
2.4 XC, XC AWD		**2,4 l 147 kW B5244T3 5 Zyl.**	
Throttle valve assembly	08.01-07.02		**0 280 750 103**
Air mass meter, gasoline injection	08.01-07.02		**0 280 218 088**
	09.00-07.01		**0 280 218 108**
Knock sensor	09.00-07.02		**0 261 231 142**
Temperature sensor, fuel	09.00-07.02		**0 261 230 110**
2.5 BI-FUEL CNG		**2,5 l 103 kW B5244SG 5 Zyl.**	
Temperature sensor, fuel	08.02-07.07		**0 261 230 109**
2.5 BI-FUEL LPG		**2,5 l 103 kW B5244SG2 5 Zyl.**	
Temperature sensor, fuel	08.02-07.06		**0 261 230 109**
2.5 D		**2,5 l 103 kW D5252T 5 Zyl.**	
Air mass meter, diesel	03.00-07.01		**0 280 218 108**
2.5 T		**2,5 l 154 kW B5254T2 5 Zyl.**	
Throttle valve assembly	04.04-07.07		**0 280 750 131**
Air mass meter, gasoline injection	04.04-07.07		**0 280 218 088**
Knock sensor	04.04-07.07		**0 261 231 142**

V

Product

◀ V70 II

Boost pressure sensor, gasoline	04.04-07.07		**0 261 230 090**
Temperature sensor, fuel	04.04-07.07		**0 261 230 110**
2.5 T AWD		**2,5 l 154 kW B5254T2 5 Zyl.**	
Throttle valve assembly	08.02-07.07		**0 280 750 131**
Air mass meter, gasoline injection	08.02-07.07		**0 280 218 088**
Knock sensor	08.02-07.07		**0 261 231 142**
Boost pressure sensor, gasoline	08.02-07.07		**0 261 230 090**
Temperature sensor, fuel	08.02-07.07		**0 261 230 110**
2.5 T AWD R		**2,5 l 220 kW B5254T4 5 Zyl.**	
Throttle valve assembly	03.03-07.07		**0 280 750 131**
Air mass meter, gasoline injection	03.03-07.07		**0 280 218 089**
Knock sensor	03.03-07.07		**0 261 231 142**
Pressure sensor, intake manifold, gasoline	03.03-07.07		**0 261 230 105**
Temperature sensor, fuel	03.03-07.07		**0 261 230 110**

V

V70 III

2.4 D		**2,4 l 120 kW D5244T4 5 Zyl.**	
Throttle valve assembly	08.07→		**0 281 002 701**
Phase sensor	08.07→	NOC	**0 232 103 063**
Boost pressure sensor, Diesel	08.07→		**0 261 230 105**
2.4 D5		**2,4 l 136 kW D5244T5 5 Zyl.**	
Throttle valve assembly	08.07→		**0 281 002 701**
Phase sensor	08.07→	NOC	**0 232 103 063**
Boost pressure sensor, Diesel	08.07→		**0 261 230 105**
2.5 T		**2,5 l 147 kW B5254T6 5 Zyl.**	
Throttle valve assembly	08.07→		**0 280 750 146**
Air mass meter, gasoline injection	08.07→		**0 280 218 134**
Knock sensor	08.07→		**0 261 231 178**
Boost pressure sensor, gasoline	08.07→		**0 261 230 105**
Temperature sensor, fuel	08.07→		**0 261 230 110**
3.0 T6 AWD		**3,0 l 210 kW B6304T2 6 Zyl.**	
Temperature sensor, fuel	08.07→		**0 261 230 110**
3.2 , AWD		**3,2 l 175 kW B6324S 6 Zyl.**	
Temperature sensor, fuel	08.07→		**0 261 230 110**

V90

3.0		**2,9 l 132 kW 6 Zyl.**	
Throttle valve sensor	01.97-07.98		**0 280 122 001**
Air mass meter, gasoline injection	01.97-07.98		**0 280 217 511**
Phase sensor	01.97-07.98	NOC	**0 232 101 030**
3.0		**2,9 l 150 kW B6304S 6 Zyl.**	
Throttle valve sensor	01.97-07.98		**0 280 122 001**
Air mass meter, gasoline injection	01.97-07.98		**0 280 217 511**
Phase sensor	01.97-07.98	NOC	**0 232 101 030**
Knock sensor	01.97-07.98		**0 261 231 046**

XC70 I

2.3 T		**2,3 l 140 kW B5234T7 5 Zyl.**	
Throttle valve assembly	08.02-07.04		**0 280 750 131**
Air mass meter, gasoline injection	08.02-07.04		**0 280 218 088**
Knock sensor	08.02-07.04		**0 261 231 142**
Boost pressure sensor, gasoline	08.02-07.04	UE	**0 261 230 090**
Temperature sensor, fuel	08.02-07.04		**0 261 230 110**
2.4 D		**2,4 l 120 kW D5244T 5 Zyl.**	
Air mass meter, diesel	08.02-07.06		**0 280 218 088**
Phase sensor	08.02-07.06	NOC	**0 232 103 063**
Boost pressure sensor, Diesel	08.02-07.06	UE	**0 261 230 090**

Product

2.4 D5		**2,4 l 136 kW D5244T4 5 Zyl.**	
Throttle valve assembly	12.05-07.07		**0 281 002 701**
Phase sensor	12.05-07.07	NOC	**0 232 103 063**
Boost pressure sensor, Diesel	12.05-07.07		**0 261 230 105**
2.4 T		**2,4 l 147 kW B5244T4 5 Zyl.**	
Throttle valve assembly	08.04-07.07		**0 280 750 131**
Air mass meter, gasoline injection	08.04-07.07		**0 280 218 089**
Knock sensor	08.04-07.07		**0 261 231 142**
Boost pressure sensor, gasoline	08.04-07.07		**0 261 230 105**
Temperature sensor, fuel	08.04-07.07		**0 261 230 110**
2.5 T		**2,5 l 154 kW B5254T2 5 Zyl.**	
Throttle valve assembly	08.02-07.07		**0 280 750 131**
Air mass meter, gasoline injection	08.02-07.07		**0 280 218 088**
Knock sensor	08.02-07.07		**0 261 231 142**
Boost pressure sensor, gasoline	08.02-07.07	UE	**0 261 230 090**
Temperature sensor, fuel	08.02-07.07		**0 261 230 110**

XC70 II

2.4 D5		**2,4 l 136 kW D5244T4 5 Zyl.**	
Phase sensor	08.07→	NOC	**0 232 103 063**
Boost pressure sensor, Diesel	08.07→		**0 261 230 105**
3.2		**3,2 l 175 kW B6324S 6 Zyl.**	
Temperature sensor, fuel	08.07→		**0 261 230 110**

XC90

D5		**2,4 l 120 kW D5244T 5 Zyl.**	
Air mass meter, diesel	01.03-07.06		**0 280 218 088**
Phase sensor	01.03-07.06	NOC	**0 232 103 042**
Boost pressure sensor, Diesel	01.03-07.06	UE	**0 261 230 090**
D5		**2,4 l 136 kW D5244T4 5 Zyl.**	
Throttle valve assembly	05.05→		**0 281 002 701**
Phase sensor	05.05→	NOC	**0 232 103 042**
Boost pressure sensor, Diesel	05.05→		**0 261 230 105**
T6		**2,9 l 200 kW B6294T 6 Zyl.**	
Throttle valve assembly	01.03-07.06		**0 280 750 131**
Air mass meter, gasoline injection	01.03-07.06		**0 280 218 089**
Knock sensor	01.03-07.06		**0 261 231 142**
Boost pressure sensor, gasoline	01.03-07.06		**0 261 230 090**
V8		**4,4 l 232 kW B8444S 8 Zyl.**	
Temperature sensor, fuel	03.05→		**0 261 230 110**
2.5 T, T AWD		**2,5 l 154 kW B5254T2 5 Zyl.**	
Throttle valve assembly	01.03→		**0 280 750 131**
Air mass meter, gasoline injection	01.03→		**0 280 218 088**
Knock sensor	01.03→		**0 261 231 142**
Boost pressure sensor, gasoline	01.03→	UE	**0 261 230 090**
Temperature sensor, fuel	01.03→		**0 261 230 110**
3.2		**3,2 l 175 kW B6324S 6 Zyl.**	
Temperature sensor, fuel	08.06→		**0 261 230 110**

240

2.0 Injection		**2,0 l 82 kW B200F Kat. 4 Zyl.**	
Throttle valve sensor	04.91-07.92		**0 280 120 325**
Air mass meter, gasoline injection	04.91-07.92		**0 280 212 016**
			0 986 280 101
Knock sensor	04.91-07.92		**0 261 231 046**
Temperature sensor, coolant, injection system	04.91-07.92		**0 280 130 032**
Wheel speed sensor, front	08.91-07.92		**0 265 001 332**
2.0 Injection		**2,0 l 82-86 kW B200E 4 Zyl.**	
Air flow sensor, gasoline injection	08.84-07.92		**0 438 120 076**
Wheel speed sensor, front	08.91-07.92		**0 265 001 332**

Product			
2.1 Injection Turbo			**2,1 l 114 kW B21ET 4 Zyl.**
Air flow sensor, gasoline injection	08.80-07.86		**0 438 120 134**
2.3			**2,3 l 78-81 kW B230K 4 Zyl.**
Knock sensor	08.84-07.90		**0 261 231 006**
2.3 Injection			**2,3 l 84 kW B230F Kat. 4 Zyl.**
Throttle valve sensor	08.88-07.93		**0 280 120 325**
Air mass meter, gasoline injection			
Fg.no. →334099	08.88-07.93	LIM	**0 280 212 007**
			0 986 280 102
Fg.no. →808999	08.88-07.93	KOB	**0 280 212 007**
			0 986 280 102
Fg.no. 334100→	08.88-07.93	LIM	**0 280 212 016**
			0 986 280 101
Fg.no. 809000→	08.88-07.93	KOB	**0 280 212 016**
			0 986 280 101
Knock sensor	08.88-07.93		**0 261 231 046**
Temperature sensor, coolant, injection system	08.88-07.92		**0 280 130 032**
Wheel speed sensor, front	08.91-07.93		**0 265 001 332**
2.3 Injection			**2,3 l 85 kW B230F Kat. 4 Zyl.**
Throttle valve sensor	08.84-07.87		**0 280 120 301**
	08.87-07.88		**0 280 120 325**
Air mass meter, gasoline injection			
Fg.no. →334099	08.84-07.88	LIM	**0 280 212 007**
			0 986 280 102
Fg.no. →808999	08.84-07.88	KOB	**0 280 212 007**
			0 986 280 102
Fg.no. 334100→	08.87-07.88	LIM	**0 280 212 016**
			0 986 280 101
Fg.no. 809000→	08.87-07.88	KOB	**0 280 212 016**
			0 986 280 101
Temperature sensor, coolant, injection system	08.84-07.88		**0 280 130 032**
2.3 Injection			**2,3 l 95-96 kW B230E 4 Zyl.**
Air flow sensor, gasoline injection	08.84-07.92		**0 438 120 203**
Wheel speed sensor, front	08.91-07.92		**0 265 001 332**
2.3 Injection			**2,3 l 100 kW B230F 4 Zyl.**
Throttle valve sensor	08.92-07.93		**0 280 120 325**
Air mass meter, gasoline injection			
Fg.no. →334099	08.92-07.93	LIM	**0 280 212 007**
			0 986 280 102
Fg.no. →808999	08.92-07.93	KOB	**0 280 212 007**
			0 986 280 102
Fg.no. 334100→	08.92-07.93	LIM	**0 280 212 016**
			0 986 280 101
Fg.no. 809000→	08.92-07.93	KOB	**0 280 212 016**
			0 986 280 101
Knock sensor	08.92-07.93		**0 261 231 046**
Temperature sensor, coolant, injection system	08.92-07.93		**0 280 130 032**
Wheel speed sensor, front	08.92-07.93		**0 265 001 332**
2.4 D			**2,4 l 58-60 kW D24 6 Zyl.**
Wheel speed sensor, front	08.91-07.93		**0 265 001 332**

340

2.0 i			**2,0 l 86 kW B200E 4 Zyl.**
Throttle valve sensor	08.84-07.87		**0 280 120 301**
	08.87-07.88		**0 280 120 325**
Air flow sensor, gasoline injection	08.84-07.88		**0 280 202 034**
			0 986 280 059
Temperature sensor, coolant, injection system	08.84-07.88		**0 280 130 032**
Relay, Jetronic	08.84-07.88		**0 280 230 005**

360

2.0 i			**2,0 l 80 kW B200F Kat. 4 Zyl.**
Throttle valve sensor	01.86-07.87		**0 280 120 301**
	08.87-07.90		**0 280 120 325**
Air flow sensor, gasoline injection	01.86-07.89		**0 280 202 096**
Temperature sensor, coolant, injection system	01.86-07.90		**0 280 130 026**
Relay, Jetronic	01.86-07.90		**0 280 230 005**
2.0 i			**2,0 l 86 kW B200E 4 Zyl.**
Throttle valve sensor	08.84-07.87		**0 280 120 301**
	08.87-07.89		**0 280 120 325**
Air flow sensor, gasoline injection	08.84-07.89		**0 280 202 034**
			0 986 280 059
Temperature sensor, coolant, injection system	08.84-07.89		**0 280 130 026**
Relay, Jetronic	08.84-07.89		**0 280 230 005**

440

1.6 i			**1,6 l 61 kW B16F Kat. 4 Zyl.**
Throttle valve sensor	09.93-07.97		**0 280 122 001**
1.7 i			**1,7 l 70-75 kW B18F Kat. 4 Zyl.**
Throttle valve sensor	09.88-07.91		**0 280 120 301**
Air mass meter, gasoline injection	09.88-07.91		**0 280 212 007**
			0 986 280 102
Knock sensor	09.88-07.91		**0 261 231 006**
Temperature sensor, coolant, injection system	09.88-07.91		**0 280 130 032**
1.7 i			**1,7 l 75 kW B18FP Kat. 4 Zyl.**
Throttle valve sensor	09.89-07.91		**0 280 122 001**
Knock sensor	09.89-07.91		**0 261 231 006**
1.7 i			**1,7 l 78-80 kW B18EP 4 Zyl.**
Throttle valve sensor	09.88-07.94		**0 280 120 301**
Knock sensor	09.88-07.94		**0 261 231 006**
1.7 T			**1,7 l 88 kW B18FT Kat. 4 Zyl.**
Throttle valve sensor	09.88-07.96		**0 280 120 400**
Air mass meter, gasoline injection	09.88-12.90		**0 280 212 007**
			0 986 280 102
	01.91-07.96		**0 280 212 021**
			0 986 280 107
Knock sensor	09.88-07.96		**0 261 231 006**
Temperature sensor, coolant, injection system	09.88-07.96		**0 280 130 032**
1.8 i			**1,8 l 66 kW B18U Kat. 4 Zyl.**
Knock sensor	09.91-07.97		**0 261 231 006**
2.0 i			**2,0 l 80 kW B20F Kat. 4 Zyl.**
Throttle valve sensor	09.92-12.96		**0 280 122 001**
Knock sensor	09.92-12.96		**0 261 231 006**

460

1.7 i			**1,7 l 75 kW B18FP Kat. 4 Zyl.**
Throttle valve sensor	03.90-07.93		**0 280 122 001**
Knock sensor	03.90-07.93		**0 261 231 006**
Temperature sensor, coolant, injection system	03.90-07.93		**0 280 130 032**
1.7 i T			**1,7 l 88 kW B18FT Kat. 4 Zyl.**
Throttle valve sensor	03.90-07.96		**0 280 120 400**
Air mass meter, gasoline injection	03.90-12.90		**0 280 212 007**
			0 986 280 102
	01.91-07.96		**0 280 212 021**
			0 986 280 107
Knock sensor	03.90-07.96		**0 261 231 006**
Temperature sensor, coolant, injection system	03.90-07.96		**0 280 130 032**

V

Product			

◀ 460

1.8 i			**1,8 l 66 kW B18U Kat. 4 Zyl.**
Knock sensor	09.91-07.97		**0 261 231 006**
2.0 i			**2,0 l 80 kW B20F Kat. 4 Zyl.**
Throttle valve sensor	09.92-12.96		**0 280 122 001**
Knock sensor	09.92-12.96		**0 261 231 006**

480

1.7 i [E 12]			**1,7 l 70-75 kW B18F Kat. 4 Zyl.**
Throttle valve sensor	05.87-07.89		**0 280 120 319**
Knock sensor	05.87-07.89		**0 261 231 006**
Temperature sensor, coolant, injection system	05.87-07.89		**0 280 130 032**
1.7 i [E 12]			**1,7 l 75 kW B18FP Kat. 4 Zyl.**
Throttle valve sensor	08.89-12.93		**0 280 122 001**
Knock sensor	08.89-12.93		**0 261 231 006**
1.7 i [E 12]			**1,7 l 78-80 kW B18E 4 Zyl.**
Throttle valve sensor	04.86-07.89		**0 280 120 301**
Knock sensor	04.86-07.89		**0 261 231 006**
1.7 i T [E 12]			**1,7 l 88-90 kW B18FT Kat. 4 Zyl.**
Throttle valve sensor	08.88-07.95		**0 280 120 400**
Air mass meter, gasoline injection			
Fg.no. →567599	08.88-07.95		**0 280 212 007**
			0 986 280 102
Fg.no. 567600→	08.88-07.95		**0 280 212 021**
			0 986 280 107
Knock sensor	08.88-07.95		**0 261 231 006**
Temperature sensor, coolant, injection system	08.88-07.95		**0 280 130 032**
2.0 i [E 12]			**2,0 l 81 kW B20F Kat. 4 Zyl.**
Throttle valve sensor	09.92-12.96		**0 280 122 001**
Knock sensor	09.92-12.96		**0 261 231 006**

740

2.0			**2,0 l 76 kW B200K 4 Zyl.**
Air mass meter, gasoline injection	08.88-07.89		**0 280 212 016**
			0 986 280 101
Knock sensor	08.84-07.89		**0 261 231 006**
Wheel speed sensor, front	08.84-08.87		**0 265 001 064**
Fg.no. →176799	08.87-07.89	KOB	**0 265 001 184**
Fg.no. →294099	08.87-07.89	LIM	**0 265 001 184**
Fg.no. 176800→	08.87-07.89	KOB	**0 265 001 231**
Fg.no. 294100→	08.87-07.89	LIM	**0 265 001 231**
Wheel speed sensor, rear	08.84-07.87		**0 265 001 065**
	08.87-07.88		**0 265 001 185**
2.0 i			**2,0 l 80 kW B200G 4 Zyl.**
Throttle valve sensor	08.91-07.94		**0 280 120 325**
Air mass meter, gasoline injection	08.91-07.94		**0 280 212 021**
			0 986 280 107
Knock sensor	08.91-07.94		**0 261 231 006**
Temperature sensor, coolant, injection system	08.91-07.94		**0 280 130 032**
Wheel speed sensor, front			
Fg.no. →176799	08.91-07.94	KOB	**0 265 001 184**
Fg.no. →294099	08.91-07.94	LIM	**0 265 001 184**
Fg.no. 176800→	08.91-07.94	KOB	**0 265 001 231**
Fg.no. 294100→	08.91-07.94	LIM	**0 265 001 231**
2.0 i			**2,0 l 82 kW B200F Kat. 4 Zyl.**
Throttle valve sensor	08.89-07.93		**0 280 120 325**
Air mass meter, gasoline injection	08.89-07.93		**0 280 212 016**
			0 986 280 101
Knock sensor	08.89-07.93		**0 261 231 006**
Temperature sensor, coolant, injection system	08.89-07.93		**0 280 130 032**
Wheel speed sensor, front			
Fg.no. →176799	08.89-07.93	KOB	**0 265 001 184**
Fg.no. →294099	08.89-07.93	LIM	**0 265 001 184**
Fg.no. 176800→	08.89-07.93	KOB	**0 265 001 231**
Fg.no. 294100→	08.89-07.93	LIM	**0 265 001 231**
2.0 i			**2,0 l 88 kW B200E 4 Zyl.**
Air flow sensor, gasoline injection	08.84-07.91		**0 438 120 076**
Knock sensor	08.84-07.91		**0 261 231 006**
Wheel speed sensor, front	08.84-08.87		**0 265 001 064**
Fg.no. →176799	08.87-07.91	KOB	**0 265 001 184**
Fg.no. →294099	08.87-07.91	LIM	**0 265 001 184**
Fg.no. 176800→	08.87-07.91	KOB	**0 265 001 231**
Fg.no. 294100→	08.87-07.91	LIM	**0 265 001 231**
Wheel speed sensor, rear	08.84-07.87		**0 265 001 065**
	08.87-07.88		**0 265 001 185**
2.0 i T			**2,0 l 114 kW B200FT Kat. 4 Zyl.**
Throttle valve sensor	08.90-07.92		**0 280 120 325**
Air mass meter, gasoline injection	08.90-07.92		**0 280 212 016**
			0 986 280 101
Knock sensor	08.90-07.92		**0 261 231 006**
Temperature sensor, coolant, injection system	08.90-07.92		**0 280 130 032**
Wheel speed sensor, front			
Fg.no. →176799	08.90-07.92	KOB	**0 265 001 184**
Fg.no. →294099	08.90-07.92	LIM	**0 265 001 184**
Fg.no. 176800→	08.90-07.92	KOB	**0 265 001 231**
Fg.no. 294100→	08.90-07.92	LIM	**0 265 001 231**
2.0 i T			**2,0 l 120-121 kW B200ET 4 Zyl.**
Throttle valve sensor	08.84-04.87		**0 280 120 301**
	05.87-07.89		**0 280 120 325**
Air flow sensor, gasoline injection	08.84-07.89		**0 280 202 067**
Speed sensor, ignition/injection	08.84-07.89		**0 261 210 003**
Knock sensor	08.84-07.89		**0 261 231 006**
Temperature sensor, coolant, injection system	08.84-07.89		**0 280 130 032**
Wheel speed sensor, front	08.84-08.87		**0 265 001 064**
Fg.no. →176799	08.87-07.89	KOB	**0 265 001 184**
Fg.no. →294099	08.87-07.89	LIM	**0 265 001 184**
Fg.no. 176800→	08.87-07.89	KOB	**0 265 001 231**
Fg.no. 294100→	08.87-07.89	LIM	**0 265 001 231**
Wheel speed sensor, rear	08.84-07.87		**0 265 001 065**
	08.87-07.88		**0 265 001 185**
2.0 i 16V			**2,0 l 100-103 kW B204E 4 Zyl.**
Throttle valve sensor	08.88-07.90		**0 280 120 325**
Air mass meter, gasoline injection	08.88-07.90		**0 280 212 007**
			0 986 280 102
Knock sensor	08.88-07.90		**0 261 231 006**
Temperature sensor, coolant, injection system	08.88-07.90		**0 280 130 032**
Wheel speed sensor, front			
Fg.no. →176799	08.88-07.90	KOB	**0 265 001 184**
Fg.no. →294099	08.88-07.90	LIM	**0 265 001 184**
Fg.no. 176800→	08.88-07.90	KOB	**0 265 001 231**
Fg.no. 294100→	08.88-07.90	LIM	**0 265 001 231**
2.0 i 16V T			**2,0 l 136/140 kW B204FT Kat.; B204GT 4 Zyl.**
Throttle valve sensor	08.89-07.90		**0 280 120 400**
Air mass meter, gasoline injection	08.89-07.90		**0 280 213 012**
			0 986 280 110
Knock sensor	08.89-07.90		**0 261 231 006**
Temperature sensor, coolant, injection system	08.89-07.90		**0 280 130 032**
Wheel speed sensor, front			
Fg.no. →176799	08.89-07.90	KOB	**0 265 001 184**
Fg.no. →294099	08.89-07.90	LIM	**0 265 001 184**
Fg.no. 176800→	08.89-07.90	KOB	**0 265 001 231**
Fg.no. 294100→	08.89-07.90	LIM	**0 265 001 231**

Product			
2.3			**2,3 l 80-86 kW B230K 4 Zyl.**
Knock sensor	08.84-07.90		**0 261 231 006**
Wheel speed sensor, front	08.84-08.87		**0 265 001 064**
Fg.no. →176799	08.87-07.90	KOB	**0 265 001 184**
Fg.no. →294099	08.87-07.90	LIM	**0 265 001 184**
Fg.no. 176800→	08.87-07.90	KOB	**0 265 001 231**
Fg.no. 294100→	08.87-07.90	LIM	**0 265 001 231**
Wheel speed sensor, rear	08.84-07.87		**0 265 001 065**
	08.87-07.88		**0 265 001 185**
2.3			**2,3 l 82 kW B230A 4 Zyl.**
Knock sensor	08.84-07.87		**0 261 231 006**
Wheel speed sensor, front	08.84-07.87		**0 265 001 064**
Wheel speed sensor, rear	08.84-07.87		**0 265 001 065**
2.3 i			**2,3 l 85 kW B230F Kat. 4 Zyl.**
Throttle valve sensor	08.84-07.88		**0 280 120 301**
	08.88-07.89		**0 280 120 325**
	08.88-07.95		**0 280 120 325**
Air mass meter, gasoline injection	08.84-07.88		**0 280 212 007**
			0 986 280 102
	08.88-07.89		**0 280 212 016**
			0 986 280 101
	08.88-07.95		**0 280 212 016**
			0 986 280 101
	08.88-07.89		**0 280 212 016**
			0 986 280 101
Knock sensor	08.84-07.95		**0 261 231 006**
Temperature sensor, coolant, injection system	08.84-07.88		**0 280 130 026**
	08.88-07.95		**0 280 130 032**
Wheel speed sensor, front	08.84-08.87		**0 265 001 064**
Fg.no. →176799	08.87-07.95	KOB	**0 265 001 184**
Fg.no. →294099	08.87-07.95	LIM	**0 265 001 184**
Fg.no. 176800→	08.87-07.95	KOB	**0 265 001 231**
Fg.no. 294100→	08.87-07.95	LIM	**0 265 001 231**
Wheel speed sensor, rear	08.84-07.87		**0 265 001 065**
	08.87-07.88		**0 265 001 185**
2.3 i			**2,3 l 94 kW B230G 4 Zyl.**
Air mass meter, gasoline injection	08.91-07.95		**0 280 212 021**
			0 986 280 107
Knock sensor	08.91-07.95		**0 261 231 006**
Temperature sensor, coolant, injection system	08.91-07.95		**0 280 130 032**
Wheel speed sensor, front			
Fg.no. →176799	08.91-07.95	KOB	**0 265 001 184**
Fg.no. →294099	08.91-07.95	LIM	**0 265 001 184**
Fg.no. 176800→	08.91-07.95	KOB	**0 265 001 231**
Fg.no. 294100→	08.91-07.95	LIM	**0 265 001 231**
2.3 i			**2,3 l 96 kW B 230 FB Kat. 4 Zyl.**
Knock sensor	08.90-07.95		**0 261 231 006**
Wheel speed sensor, front			
Fg.no. →176799	08.90-07.95	KOB	**0 265 001 184**
Fg.no. →294099	08.90-07.95	LIM	**0 265 001 184**
Fg.no. 176800→	08.90-07.95	KOB	**0 265 001 231**
Fg.no. 294100→	08.90-07.95	LIM	**0 265 001 231**
2.3 i			**2,3 l 96 kW B230E 4 Zyl.**
Air flow sensor, gasoline injection	08.84-07.91		**0 438 120 203**
Knock sensor	08.84-07.91		**0 261 231 006**
Wheel speed sensor, front	08.84-08.87		**0 265 001 064**
Fg.no. →176799	08.87-07.91	KOB	**0 265 001 184**
Fg.no. →294099	08.87-07.91	LIM	**0 265 001 184**
Fg.no. 176800→	08.87-07.91	KOB	**0 265 001 231**
Fg.no. 294100→	08.87-07.91	LIM	**0 265 001 231**
Wheel speed sensor, rear	08.84-07.87		**0 265 001 065**
	08.87-07.88		**0 265 001 185**

Product			
2.3 i			**2,3 l 96 kW B230F Kat. 4 Zyl.**
Throttle valve sensor	08.90-07.92		**0 280 120 325**
Air mass meter, gasoline injection	08.90-07.92		**0 280 212 016**
			0 986 280 101
Knock sensor	08.90-07.92		**0 261 231 006**
Temperature sensor, coolant, injection system	08.90-07.92		**0 280 130 032**
Wheel speed sensor, front			
Fg.no. →176799	08.90-07.92	KOB	**0 265 001 184**
Fg.no. →294099	08.90-07.92	LIM	**0 265 001 184**
Fg.no. 176800→	08.90-07.92	KOB	**0 265 001 231**
Fg.no. 294100→	08.90-07.92	LIM	**0 265 001 231**
2.3 i T			**2,3 l 114-119 kW B230FT Kat. 4 Zyl.**
Throttle valve sensor	08.84-04.87		**0 280 120 301**
	05.87-07.91		**0 280 120 325**
Air mass meter, gasoline injection	08.84-07.91		**0 280 212 007**
			0 986 280 102
	08.89-07.91		**0 280 212 016**
			0 986 280 101
Knock sensor	08.84-07.91		**0 261 231 006**
Temperature sensor, coolant, injection system	08.84-07.91		**0 280 130 032**
Wheel speed sensor, front	08.84-08.87		**0 265 001 064**
Fg.no. →176799	08.87-07.91	KOB	**0 265 001 184**
Fg.no. →294099	08.87-07.91	LIM	**0 265 001 184**
Fg.no. 176800→	08.87-07.91	KOB	**0 265 001 231**
Fg.no. 294100→	08.87-07.91	LIM	**0 265 001 231**
Wheel speed sensor, rear	08.84-07.87		**0 265 001 065**
	08.87-07.88		**0 265 001 185**
2.3 i T			**2,3 l 120 kW B230GT 4 Zyl.**
Throttle valve sensor	08.89-07.90		**0 280 120 325**
Air mass meter, gasoline injection	08.89-07.90		**0 280 212 016**
			0 986 280 101
Knock sensor	08.89-07.90		**0 261 231 006**
Temperature sensor, coolant, injection system	08.89-07.90		**0 280 130 032**
Wheel speed sensor, front			
Fg.no. →176799	08.89-07.90	KOB	**0 265 001 184**
Fg.no. →294099	08.89-07.90	LIM	**0 265 001 184**
Fg.no. 176800→	08.89-07.90	KOB	**0 265 001 231**
Fg.no. 294100→	08.89-07.90	LIM	**0 265 001 231**
2.3 i T			**2,3 l 130 kW B230ET 4 Zyl.**
Throttle valve sensor	08.84-04.87		**0 280 120 301**
	05.87-07.89		**0 280 120 325**
Air flow sensor, gasoline injection	08.84-07.89		**0 280 202 035**
			0 986 280 045
Speed sensor, ignition/injection	08.84-07.89		**0 261 210 003**
Knock sensor	08.84-07.89		**0 261 231 006**
Temperature sensor, coolant, injection system	08.84-07.89		**0 280 130 032**
Wheel speed sensor, front	08.84-08.87		**0 265 001 064**
Fg.no. →176799	08.87-07.89	KOB	**0 265 001 184**
Fg.no. →294099	08.87-07.89	LIM	**0 265 001 184**
Fg.no. 176800→	08.87-07.89	KOB	**0 265 001 231**
Fg.no. 294100→	08.87-07.89	LIM	**0 265 001 231**
Wheel speed sensor, rear	08.84-07.87		**0 265 001 065**
	08.87-07.88		**0 265 001 185**
2.3 i 16V			**2,3 l 111-117 kW B234F Kat. 4 Zyl.**
Throttle valve sensor	04.88-07.90		**0 280 120 325**
Air mass meter, gasoline injection	08.88-07.90		**0 280 212 016**
			0 986 280 101
	04.88-07.88		**0 280 213 010**
			0 986 280 138
Knock sensor	04.88-07.90		**0 261 231 006**
Temperature sensor, coolant, injection system	04.88-07.90		**0 280 130 032**

V

Product			
◀ 740			
Wheel speed sensor, front			
Fg.no. →176799	04.88-07.90	KOB	0 265 001 184
Fg.no. →294099	04.88-07.90	LIM	0 265 001 184
Fg.no. 176800→	04.88-07.90	KOB	0 265 001 231
Fg.no. 294100→	04.88-07.90	LIM	0 265 001 231
Wheel speed sensor, rear	04.88-07.88		0 265 001 185
2.3 i 16V			**2,3 l 114 kW B234G 4 Zyl.**
Throttle valve sensor	08.90-07.92		0 280 120 325
Air mass meter, gasoline injection	08.90-07.92		0 280 212 021
			0 986 280 107
Knock sensor	08.90-07.92		0 261 231 006
Temperature sensor, coolant, injection system	08.90-07.92		0 280 130 032
Wheel speed sensor, front			
Fg.no. →176799	08.90-07.92	KOB	0 265 001 184
Fg.no. →294099	08.90-07.92	LIM	0 265 001 184
Fg.no. 176800→	08.90-07.92	KOB	0 265 001 231
Fg.no. 294100→	08.90-07.92	LIM	0 265 001 231
2.4 D			**2,4 l 60 kW D24 6 Zyl.**
Wheel speed sensor, front	04.84-08.87		0 265 001 064
Fg.no. →176799	08.87-07.92	KOB	0 265 001 184
Fg.no. →294099	08.87-07.92	LIM	0 265 001 184
Fg.no. 176800→	08.87-07.92	KOB	0 265 001 231
Fg.no. 294100→	08.87-07.92	LIM	0 265 001 231
Wheel speed sensor, rear	04.84-07.87		0 265 001 065
	08.87-07.88		0 265 001 185
2.4 TD			**2,4 l 80 kW D24T 6 Zyl.**
Wheel speed sensor, front	04.85-08.87		0 265 001 064
Fg.no. →176799	08.87-07.92	KOB	0 265 001 184
Fg.no. →294099	08.87-07.92	LIM	0 265 001 184
Fg.no. 176800→	08.87-07.92	KOB	0 265 001 231
Fg.no. 294100→	08.87-07.92	LIM	0 265 001 231
Wheel speed sensor, rear	04.85-07.87		0 265 001 065
	08.87-07.88		0 265 001 185
2.4 TD			**2,4 l 85 kW D24TIC 6 Zyl.**
Wheel speed sensor, front			
Fg.no. →176799	08.87-07.92	KOB	0 265 001 184
Fg.no. →294099	08.87-07.92	LIM	0 265 001 184
Fg.no. 176800→	08.87-07.92	KOB	0 265 001 231
Fg.no. 294100→	08.87-07.92	LIM	0 265 001 231
Wheel speed sensor, rear	08.87-07.88		0 265 001 185

760

2.0 i T			**2,0 l 120 kW B200ET 4 Zyl.**
Throttle valve sensor	08.84-04.87		0 280 120 301
	05.87-07.89		0 280 120 325
Air flow sensor, gasoline injection	08.84-07.89		0 280 202 067
Speed sensor, ignition/injection	08.84-07.89		0 261 210 003
Temperature sensor, coolant, injection system	08.84-07.89		0 280 130 032
Wheel speed sensor, front	08.84-07.87		0 265 001 064
Fg.no. →176799	08.87-07.89	KOB	0 265 001 184
Fg.no. →294099	08.87-07.89	LIM	0 265 001 184
Fg.no. 176800→	08.87-07.89	KOB	0 265 001 231
Fg.no. 294100→	08.87-07.89	LIM	0 265 001 231
Wheel speed sensor, rear	08.84-07.87		0 265 001 065
	08.87-07.89		0 265 001 185
2.3 i T			**2,3 l 114-119 kW B230FT Kat. 4 Zyl.**
Throttle valve sensor	08.84-04.87		0 280 120 301
	05.87-07.92		0 280 120 325
Air mass meter, gasoline injection	08.84-07.89		0 280 212 007
			0 986 280 102
	08.89-07.92		0 280 212 016
			0 986 280 101

Product			
Knock sensor	08.84-03.86		0 261 231 001
	04.86-07.90		0 261 231 006
	08.90-07.92		0 261 231 046
Temperature sensor, coolant, injection system	08.84-07.92		0 280 130 032
Wheel speed sensor, front	08.84-07.87		0 265 001 064
Fg.no. →176799	08.87-07.92	KOB	0 265 001 184
Fg.no. →294099	08.87-07.92	LIM	0 265 001 184
Fg.no. 176800→	08.87-07.92	KOB	0 265 001 231
Fg.no. 294100→	08.87-07.92	LIM	0 265 001 231
Wheel speed sensor, rear	08.84-07.87		0 265 001 065
	08.87-07.92		0 265 001 185
2.3 i T			**2,3 l 120 kW B230GT 4 Zyl.**
Throttle valve sensor	08.89-07.90		0 280 120 325
Air mass meter, gasoline injection	08.89-07.90		0 280 212 016
			0 986 280 101
Knock sensor	08.89-07.90		0 261 231 006
Temperature sensor, coolant, injection system	08.89-07.90		0 280 130 032
Wheel speed sensor, front			
Fg.no. →176799	08.89-07.90	KOB	0 265 001 184
Fg.no. →294099	08.89-07.90	LIM	0 265 001 184
Fg.no. 176800→	08.89-07.90	KOB	0 265 001 231
Fg.no. 294100→	08.89-07.90	LIM	0 265 001 231
Wheel speed sensor, rear	08.89-07.90		0 265 001 185
2.3 i T			**2,3 l 134 kW B230ET 4 Zyl.**
Throttle valve sensor	08.84-04.87		0 280 120 301
	05.87-07.89		0 280 120 325
Air flow sensor, gasoline injection	08.84-07.89		0 280 202 035
			0 986 280 045
Speed sensor, ignition/injection	08.84-07.89		0 261 210 003
Temperature sensor, coolant, injection system	08.84-07.89		0 280 130 032
Wheel speed sensor, front	08.84-07.87		0 265 001 064
Fg.no. →176799	08.87-07.89	KOB	0 265 001 184
Fg.no. →294099	08.87-07.89	LIM	0 265 001 184
Fg.no. 176800→	08.87-07.89	KOB	0 265 001 231
Fg.no. 294100→	08.87-07.89	LIM	0 265 001 231
Wheel speed sensor, rear	08.84-07.87		0 265 001 065
	08.87-07.89		0 265 001 185
2.4 D			**2,4 l 60 kW D24 6 Zyl.**
Wheel speed sensor, front	08.83-07.87		0 265 001 064
Wheel speed sensor, rear	08.83-07.87		0 265 001 065
2.4 TD			**2,4 l 79/80 kW D24T 6 Zyl.**
Wheel speed sensor, front	08.83-07.87		0 265 001 064
Wheel speed sensor, rear	08.83-07.87		0 265 001 065
2.4 TD			**2,4 l 85 kW D24TIC 6 Zyl.**
Wheel speed sensor, front			
Fg.no. →176799	08.87-07.92	KOB	0 265 001 184
Fg.no. →294099	08.87-07.92	LIM	0 265 001 184
Fg.no. 176800→	08.87-07.92	KOB	0 265 001 231
Fg.no. 294100→	08.87-07.92	LIM	0 265 001 231
Wheel speed sensor, rear	08.87-07.92		0 265 001 185
2.8			**2,8 l 95-96 kW B28A 6 Zyl.**
Wheel speed sensor, front	08.83-07.86		0 265 001 064
Wheel speed sensor, rear	08.83-07.86		0 265 001 065
2.8 i			**2,8 l 100 kW B28F Kat. 6 Zyl.**
Air flow sensor, gasoline injection	08.82-04.86		0 438 120 132
Temperature sensor, coolant, injection system	08.82-04.86		0 280 130 028
Wheel speed sensor, front	08.83-04.86		0 265 001 064
Wheel speed sensor, rear	08.83-04.86		0 265 001 065
2.8 i			**2,8 l 105/108-125 kW B280E; B280F Kat. 6 Zyl.**
Throttle valve sensor	05.86-04.87		0 280 120 301
	05.87-07.91		0 280 120 325
Air mass meter, gasoline injection	05.86-07.91		0 280 213 006
			0 986 280 115

Product			
Speed sensor, ignition/injection	05.86-07.91		**0 261 210 029**
Knock sensor	05.86-07.91		**0 261 231 007**
Temperature sensor, coolant, injection system	05.86-07.91		**0 280 130 032**
Wheel speed sensor, front	05.86-07.87		**0 265 001 064**
Fg.no. →176799	08.87-07.91	KOB	**0 265 001 184**
Fg.no. →294099	08.87-07.91	LIM	**0 265 001 184**
Fg.no. 176800→	08.87-07.91	KOB	**0 265 001 231**
Fg.no. 294100→	08.87-07.91	LIM	**0 265 001 231**
Wheel speed sensor, rear	05.86-07.87		**0 265 001 065**
	08.87-07.91		**0 265 001 185**
2.8 i		**2,8 l 115 kW B28E 6 Zyl.**	
Air flow sensor, gasoline injection	02.82-04.86		**0 438 120 065**
Temperature sensor, coolant, injection system	08.83-04.86		**0 280 130 028**
Wheel speed sensor, front	08.83-04.86		**0 265 001 064**
Wheel speed sensor, rear	08.83-04.86		**0 265 001 065**

780

2.0 i T		**2,0 l 120 kW B200ET 4 Zyl.**	
Throttle valve sensor	01.86-07.87		**0 280 120 301**
	08.87-07.89		**0 280 120 325**
Air flow sensor, gasoline injection	01.86-07.89		**0 280 202 067**
Speed sensor, ignition/injection	01.86-07.89		**0 261 210 003**
Temperature sensor, coolant, injection system	01.86-07.89		**0 280 130 032**
Wheel speed sensor, front	01.86-07.87		**0 265 001 064**
Fg.no. →6499	08.87-07.89		**0 265 001 184**
Fg.no. 6500→	08.87-07.89		**0 265 001 231**
Wheel speed sensor, rear	01.86-07.87		**0 265 001 065**
2.0 i 16V T		**2,0 l 136 kW B204GT 4 Zyl.**	
Throttle valve sensor	08.89-07.90		**0 280 120 400**
Air mass meter, gasoline injection	08.89-07.90		**0 280 213 012**
			0 986 280 110
Knock sensor	08.89-07.90		**0 261 231 006**
Temperature sensor, coolant, injection system	08.89-07.90		**0 280 130 032**
Wheel speed sensor, front			
Fg.no. →6499	08.89-07.90		**0 265 001 184**
Fg.no. 6500→	08.89-07.90		**0 265 001 231**
2.4 TD		**2,4 l 85 kW D24TIC 6 Zyl.**	
Wheel speed sensor, front	08.85-07.87		**0 265 001 064**
Fg.no. →6499	08.87-07.91		**0 265 001 184**
Fg.no. 6500→	08.87-07.91		**0 265 001 231**
Wheel speed sensor, rear	08.85-07.87		**0 265 001 065**
	08.87-07.88		**0 265 001 186**
2.8 i		**2,8 l 108-125 kW B280E; B280F Kat. 6 Zyl.**	
Throttle valve sensor	05.86-07.87		**0 280 120 301**
	08.87-07.91		**0 280 120 325**
Air mass meter, gasoline injection	05.86-07.91		**0 280 213 006**
			0 986 280 115
Speed sensor, ignition/injection	05.86-07.91		**0 261 210 029**
Knock sensor	05.86-07.91		**0 261 231 007**
Temperature sensor, coolant, injection system	05.86-07.91		**0 280 130 032**
Wheel speed sensor, front	05.86-07.87		**0 265 001 064**
Fg.no. →6499	08.87-07.91		**0 265 001 184**
Fg.no. 6500→	08.87-07.91		**0 265 001 231**
Wheel speed sensor, rear	05.86-07.87		**0 265 001 065**
	08.87-07.88		**0 265 001 186**

850

R		**2,3 l 184 kW B5234T4 Kat. 5 Zyl.**	
Throttle valve sensor	08.95-07.97		**0 280 122 001**
Air mass meter, gasoline injection	08.95-07.97		**0 280 217 107**
Phase sensor	08.95-07.97	NOC	**0 232 101 030**

Product			
Knock sensor	08.95-08.96		**0 261 231 046**
	09.96-07.97		**0 261 231 121**
TDI		**2,5 l 103 kW D5252T 5 Zyl.**	
Air flow sensor, diesel	05.96-07.97		**0 281 002 155**
T-5		**2,0 l 155 kW B5204FT Kat. 5 Zyl.**	
Throttle valve sensor	01.94-07.96		**0 280 122 001**
Air mass meter, gasoline injection	01.94-07.96		**0 280 217 107**
Phase sensor	01.94-07.96	NOC	**0 232 101 030**
Knock sensor	01.94-07.96		**0 261 231 046**
T-5		**2,3 l 166 kW B5234FT Kat. 5 Zyl.**	
Throttle valve sensor	09.93-07.96		**0 280 122 001**
Air mass meter, gasoline injection	09.93-07.96		**0 280 217 107**
Phase sensor	09.93-07.96	NOC	**0 232 101 030**
Knock sensor	09.93-07.96		**0 261 231 046**
T-5R		**2,3 l 177 kW B5234T Kat. 5 Zyl.**	
Throttle valve sensor	09.94-07.97		**0 280 122 001**
Air mass meter, gasoline injection	09.94-07.97		**0 280 217 107**
Phase sensor	09.94-07.97	NOC	**0 232 101 030**
Knock sensor	09.94-08.96		**0 261 231 046**
	09.96-07.97		**0 261 231 121**
2.0		**2,0 l 93 kW B5202S Kat. 5 Zyl.**	
Throttle valve sensor	09.94-12.96		**0 280 122 001**
Phase sensor	09.94-12.96	NOC	**0 232 101 030**
Knock sensor	09.96-12.96		**0 261 231 121**
2.0		**2,0 l 105 kW B5204S Kat. 5 Zyl.**	
Throttle valve sensor	09.91-12.96		**0 280 122 001**
Air mass meter, gasoline injection	08.96-12.96		**0 280 217 107**
Phase sensor	09.91-12.96	NOC	**0 232 101 030**
Knock sensor	09.91-08.96		**0 261 231 046**
	09.96-12.96		**0 261 231 121**
2.0 GLT		**2,0 l 129-132 kW B5204T2 Kat. 5 Zyl.**	
Throttle valve sensor	01.96-07.97		**0 280 122 001**
Air mass meter, gasoline injection	01.96-07.97		**0 280 217 107**
Phase sensor	01.96-07.97	NOC	**0 232 101 030**
Knock sensor	01.96-08.96		**0 261 231 046**
	09.96-07.97		**0 261 231 121**
2.0 Turbo		**2,0 l 155 kW B5204T Kat. 5 Zyl.**	
Throttle valve sensor	01.95-07.97		**0 280 122 001**
Air mass meter, gasoline injection	01.95-07.97		**0 280 217 107**
Phase sensor	01.95-07.97	NOC	**0 232 101 030**
Knock sensor	01.95-08.96		**0 261 231 046**
	09.96-07.97		**0 261 231 121**
2.3		**2,3 l 120 kW B5234S Kat. 5 Zyl.**	
Throttle valve sensor	09.97-07.98		**0 280 122 001**
Air mass meter, gasoline injection	09.97-07.98		**0 280 217 107**
Phase sensor	09.97-07.98	NOC	**0 232 101 030**
Knock sensor	09.97-07.98		**0 261 231 121**
Pressure sensor, intake manifold, gasoline	09.97-07.98		**0 261 230 018**
2.5 AWD		**2,4 l 140 kW B5254T Kat. 5 Zyl.**	
Throttle valve sensor	09.96-07.97		**0 280 122 001**
Air mass meter, gasoline injection	09.96-07.97		**0 280 217 107**
Phase sensor	09.96-07.97	NOC	**0 232 101 030**
Knock sensor	09.96-07.97		**0 261 231 121**
Pressure sensor, intake manifold, gasoline	09.96-07.97		**0 261 230 018**
2.5 GLE		**2,5 l 103-106 kW B5252S Kat. 5 Zyl.**	
Throttle valve sensor	09.92-07.97		**0 280 122 001**
Phase sensor	09.92-07.97	NOC	**0 232 101 030**
Knock sensor	09.96-07.97		**0 261 231 121**
2.5 GLT		**2,4 l 125 kW B5254S Kat. 5 Zyl.**	
Throttle valve sensor	09.93-07.97		**0 280 122 001**
Air mass meter, gasoline injection	08.96-07.97		**0 280 217 107**
Phase sensor	09.93-07.97	NOC	**0 232 101 030**

V

Product			
◀ 850			
Knock sensor	09.93-08.96		**0 261 231 046**
	09.96-07.97		**0 261 231 121**
Pressure sensor, intake manifold, gasoline	09.93-07.97		**0 261 230 006**
2.5 GLT	**2,5 l 125 kW B5254S Kat. 5 Zyl.**		
Throttle valve sensor	09.91-07.97		**0 280 122 001**
Air mass meter, gasoline injection	08.96-07.97		**0 280 217 107**
Phase sensor	09.91-07.97	NOC	**0 232 101 030**
Knock sensor	09.91-08.96		**0 261 231 046**
	09.96-07.97		**0 261 231 121**
Pressure sensor, intake manifold, gasoline	09.95-07.97		**0 261 230 006**
2.5 Turbo	**2,4 l 140 kW B5254T Kat. 5 Zyl.**		
Throttle valve sensor	09.96-07.97		**0 280 122 001**
Air mass meter, gasoline injection	09.96-07.97		**0 280 217 107**
Phase sensor	09.96-07.97	NOC	**0 232 101 030**
Knock sensor	09.96-07.97		**0 261 231 121**
Pressure sensor, intake manifold, gasoline	09.96-07.97		**0 261 230 018**
2.5 Turbo	**2,5 l 140-142 kW B5254T Kat. 5 Zyl.**		
Throttle valve sensor	09.96-07.97		**0 280 122 001**
Air mass meter, gasoline injection	09.96-07.97		**0 280 217 107**
Phase sensor	09.96-07.97	NOC	**0 232 101 030**
Knock sensor	09.96-07.97		**0 261 231 121**
Pressure sensor, intake manifold, gasoline	09.96-07.97		**0 261 230 018**

850 Kombi

R	**2,3 l 184 kW B5234T4 Kat. 5 Zyl.**		
Throttle valve sensor	08.95-07.97		**0 280 122 001**
Air mass meter, gasoline injection	08.95-07.97		**0 280 217 107**
Phase sensor	08.95-07.97	NOC	**0 232 101 030**
Knock sensor	08.95-08.96		**0 261 231 046**
	09.96-07.97		**0 261 231 121**
TDI	**2,5 l 103 kW D5252T 5 Zyl.**		
Air flow sensor, diesel	05.96-07.97		**0 281 002 155**
T-5	**2,0 l 155 kW B5204FT Kat. 5 Zyl.**		
Throttle valve sensor	01.94-07.96		**0 280 122 001**
Air mass meter, gasoline injection	01.94-07.96		**0 280 217 107**
Phase sensor	01.94-07.96	NOC	**0 232 101 030**
Knock sensor	01.94-07.96		**0 261 231 046**
T-5	**2,3 l 166 kW B5234FT Kat. 5 Zyl.**		
Throttle valve sensor	09.93-07.96		**0 280 122 001**
Air mass meter, gasoline injection	09.93-07.96		**0 280 217 107**
Phase sensor	09.93-07.96	NOC	**0 232 101 030**
Knock sensor	09.93-07.96		**0 261 231 046**
T-5R	**2,3 l 177 kW B5234T Kat. 5 Zyl.**		
Throttle valve sensor	09.94-07.97		**0 280 122 001**
Air mass meter, gasoline injection	09.94-07.97		**0 280 217 107**
Phase sensor	09.94-07.97	NOC	**0 232 101 030**
Knock sensor	09.94-08.96		**0 261 231 046**
	09.96-07.97		**0 261 231 121**
2.0	**2,0 l 93 kW B5202S Kat. 5 Zyl.**		
Throttle valve sensor	09.94-12.96		**0 280 122 001**
Phase sensor	09.94-12.96	NOC	**0 232 101 030**
Knock sensor	09.96-12.96		**0 261 231 121**
2.0	**2,0 l 105 kW B5204S Kat. 5 Zyl.**		
Throttle valve sensor	03.92-12.96		**0 280 122 001**
Air mass meter, gasoline injection	08.96-12.96		**0 280 217 107**
Phase sensor	03.92-12.96	NOC	**0 232 101 030**
Knock sensor	03.92-08.96		**0 261 231 046**
	09.96-12.96		**0 261 231 121**
2.0 GLT	**2,0 l 129-132 kW B5204T2 Kat. 5 Zyl.**		
Throttle valve sensor	01.96-07.97		**0 280 122 001**
Air mass meter, gasoline injection	01.96-07.97		**0 280 217 107**
Phase sensor	01.96-07.97	NOC	**0 232 101 030**
Knock sensor	01.96-08.96		**0 261 231 046**
	09.96-07.97		**0 261 231 121**
2.0 Turbo	**2,0 l 155 kW B5204T Kat. 5 Zyl.**		
Throttle valve sensor	01.95-07.97		**0 280 122 001**
Air mass meter, gasoline injection	01.95-07.97		**0 280 217 107**
Phase sensor	01.95-07.97	NOC	**0 232 101 030**
Knock sensor	01.95-08.96		**0 261 231 046**
	09.96-07.97		**0 261 231 121**
2.3	**2,3 l 120 kW B5234S Kat. 5 Zyl.**		
Throttle valve sensor	09.93-07.96		**0 280 122 001**
	09.97-07.98		**0 280 122 001**
Air mass meter, gasoline injection	09.97-07.98		**0 280 217 107**
Phase sensor	09.93-07.96	NOC	**0 232 101 030**
	09.97-07.98	NOC	**0 232 101 030**
Knock sensor	09.93-07.96		**0 261 231 046**
	09.97-07.98		**0 261 231 121**
Pressure sensor, intake manifold, gasoline	09.97-07.98		**0 261 230 018**
2.5 AWD	**2,5 l 140 kW B5254T Kat. 5 Zyl.**		
Throttle valve sensor	09.96-07.97		**0 280 122 001**
Air mass meter, gasoline injection	09.96-07.97		**0 280 217 107**
Phase sensor	09.96-07.97	NOC	**0 232 101 030**
Knock sensor	09.96-07.97		**0 261 231 121**
Pressure sensor, intake manifold, gasoline	09.96-07.97		**0 261 230 018**
2.5 GLE	**2,5 l 103-106 kW B5252S Kat. 5 Zyl.**		
Throttle valve sensor	09.92-07.97		**0 280 122 001**
Phase sensor	09.92-07.97	NOC	**0 232 101 030**
Knock sensor	09.96-07.97		**0 261 231 121**
2.5 GLT	**2,4 l 125 kW B5254S Kat. 5 Zyl.**		
Throttle valve sensor	09.93-07.97		**0 280 122 001**
Air mass meter, gasoline injection	08.96-07.97		**0 280 217 107**
Phase sensor	09.93-07.97	NOC	**0 232 101 030**
Knock sensor	09.93-08.96		**0 261 231 046**
	09.96-07.97		**0 261 231 121**
Pressure sensor, intake manifold, gasoline	09.93-07.97		**0 261 230 006**
2.5 GLT	**2,5 l 125 kW B5254S Kat. 5 Zyl.**		
Throttle valve sensor	09.91-07.97		**0 280 122 001**
Air mass meter, gasoline injection	08.96-07.97		**0 280 217 107**
Phase sensor	09.91-07.97	NOC	**0 232 101 030**
Knock sensor	09.91-08.96		**0 261 231 046**
	09.96-07.97		**0 261 231 121**
Pressure sensor, intake manifold, gasoline	09.95-07.97		**0 261 230 006**
2.5 Turbo	**2,5 l 140-142 kW B5254T Kat. 5 Zyl.**		
Throttle valve sensor	09.96-07.97		**0 280 122 001**
Air mass meter, gasoline injection	09.96-07.97		**0 280 217 107**
Phase sensor	09.96-07.97	NOC	**0 232 101 030**
Knock sensor	09.96-07.97		**0 261 231 121**
Pressure sensor, intake manifold, gasoline	09.96-07.97		**0 261 230 018**

940

2.0	**2,0 l 80-89 kW B200G 4 Zyl.**		
Throttle valve sensor	09.91-07.95		**0 280 120 325**
Air mass meter, gasoline injection	09.91-07.95		**0 280 212 021**
			0 986 280 107
Knock sensor	09.91-07.95		**0 261 231 046**
Temperature sensor, coolant, injection system	09.91-07.95		**0 280 130 032**
Wheel speed sensor, front	09.91-07.95		**0 265 001 231**
2.0	**2,0 l 82 kW B200F Kat. 4 Zyl.**		
Throttle valve sensor	01.92-07.95		**0 280 120 325**
Air mass meter, gasoline injection	01.92-07.95		**0 280 212 016**
			0 986 280 101
Knock sensor	01.92-07.95		**0 261 231 046**

Product		
Temperature sensor, coolant, injection system	01.92-07.95	**0 280 130 032**
Wheel speed sensor, front	01.92-07.95	**0 265 001 231**
2.0		**2,0 l 88 kW B200E 4 Zyl.**
Air flow sensor, gasoline injection	09.90-07.91	**0 438 120 076**
Knock sensor	09.90-07.91	**0 261 231 046**
Wheel speed sensor, front	09.90-07.91	**0 265 001 231**
2.0 Turbo		**2,0 l 114 kW B200GT . 4 Zyl.**
Throttle valve sensor	04.96-09.98	**0 280 120 325**
Air mass meter, gasoline injection	04.96-09.98	**0 280 212 016**
		0 986 280 101
Knock sensor	04.96-09.98	**0 261 231 046**
Temperature sensor, coolant, injection system	04.96-09.98	**0 280 130 032**
Wheel speed sensor, front	04.96-09.98	**0 265 001 231**
2.0 Turbo Interc.		**2,0 l 114 kW B200FT Kat. 4 Zyl.**
Throttle valve sensor	09.91-07.97	**0 280 120 325**
Air mass meter, gasoline injection	09.91-07.97	**0 280 212 016**
		0 986 280 101
Knock sensor	09.91-07.97	**0 261 231 046**
Temperature sensor, coolant, injection system	09.91-07.97	**0 280 130 032**
Wheel speed sensor, front	09.91-07.97	**0 265 001 231**
2.0 16V		**2,0 l 100-103 kW B204E 4 Zyl.**
Throttle valve sensor	09.90-07.91	**0 280 120 325**
Air mass meter, gasoline injection	09.90-07.91	**0 280 212 007**
		0 986 280 102
Knock sensor	09.90-07.91	**0 261 231 046**
Temperature sensor, coolant, injection system	09.90-07.91	**0 280 130 032**
Wheel speed sensor, front	09.90-07.91	**0 265 001 231**
2.3		**2,3 l 84 kW B230F Kat.; B230FD Kat. 4 Zyl.**
Throttle valve sensor	09.92-07.95	**0 280 120 325**
Air mass meter, gasoline injection	09.92-07.95	**0 280 212 016**
		0 986 280 101
Knock sensor	09.92-07.95	**0 261 231 046**
Temperature sensor, coolant, injection system	09.92-07.95	**0 280 130 032**
Wheel speed sensor, front	09.92-07.95	**0 265 001 231**
2.3		**2,3 l 96 kW B230G 4 Zyl.**
Throttle valve sensor	09.91-07.95	**0 280 120 325**
Air mass meter, gasoline injection	09.91-07.95	**0 280 212 021**
		0 986 280 107
Knock sensor	09.91-07.95	**0 261 231 046**
Temperature sensor, coolant, injection system	09.91-07.95	**0 280 130 032**
Wheel speed sensor, front	09.91-07.95	**0 265 001 231**
2.3		**2,3 l 96-99 kW B230F Kat. 4 Zyl.**
Throttle valve sensor	06.91-07.95	**0 280 120 325**
Air mass meter, gasoline injection	06.91-07.95	**0 280 212 016**
		0 986 280 101
Knock sensor	06.91-07.95	**0 261 231 046**
Temperature sensor, coolant, injection system	06.91-07.95	**0 280 130 032**
Wheel speed sensor, front	06.91-07.95	**0 265 001 231**
2.3 Turbo		**2,3 l 99 kW B230FK Kat. 4 Zyl.**
Air mass meter, gasoline injection	09.94-07.98	**0 280 212 016**
		0 986 280 101
Knock sensor	09.94-07.98	**0 261 231 046**
Temperature sensor, coolant, injection system	09.94-07.98	**0 280 130 032**
Wheel speed sensor, front	09.94-07.98	**0 265 001 231**
2.3 Turbo Interc.		**2,3 l 104 kW B230GK 4 Zyl.**
Throttle valve sensor	09.91-07.97	**0 280 120 325**
Air mass meter, gasoline injection	09.91-07.97	**0 280 212 021**
		0 986 280 107
Knock sensor	09.91-07.97	**0 261 231 046**
Temperature sensor, coolant, injection system	09.91-07.97	**0 280 130 032**
Wheel speed sensor, front	09.91-07.97	**0 265 001 231**

Product		
2.3 Turbo Interc.		**2,3 l 113-121 kW B230FT Kat.; B230FT4 4 Zyl.**
Throttle valve sensor	09.90-10.98	**0 280 120 325**
Air mass meter, gasoline injection	09.90-10.98	**0 280 212 016**
		0 986 280 101
Knock sensor	09.90-10.98	**0 261 231 046**
Temperature sensor, coolant, injection system	09.90-10.98	**0 280 130 032**
Wheel speed sensor, front	09.90-10.98	**0 265 001 231**
2.3 16V		**2,3 l 114 kW B234F Kat. 4 Zyl.**
Throttle valve sensor	09.90-07.92	**0 280 120 325**
Air mass meter, gasoline injection	09.90-07.92	**0 280 212 016**
		0 986 280 101
Knock sensor	09.90-07.92	**0 261 231 046**
Temperature sensor, coolant, injection system	09.90-07.92	**0 280 130 032**
Wheel speed sensor, front	09.90-07.92	**0 265 001 231**
2.3 16V		**2,3 l 114 kW B234G 4 Zyl.**
Throttle valve sensor	09.90-07.92	**0 280 120 325**
Air mass meter, gasoline injection	09.90-07.92	**0 280 212 021**
		0 986 280 107
Knock sensor	09.90-07.92	**0 261 231 046**
Temperature sensor, coolant, injection system	09.90-07.92	**0 280 130 032**
Wheel speed sensor, front	09.90-07.92	**0 265 001 231**
2.4 D		**2,4 l 60 kW D24 4 Zyl.**
Wheel speed sensor, front	09.90-07.93	**0 265 001 231**
2.4 TD		**2,4 l 80/90 kW D24T; D24TIC 6 Zyl.**
Wheel speed sensor, front	09.90-07.97	**0 265 001 231**

960

2.0 T		**2,0 l 103 kW B204E 4 Zyl.**
Throttle valve sensor	09.91-07.94	**0 280 120 325**
Air mass meter, gasoline injection	09.91-07.94	**0 280 212 016**
		0 986 280 101
Knock sensor	09.91-07.94	**0 261 231 046**
Temperature sensor, coolant, injection system	09.91-07.94	**0 280 130 032**
Wheel speed sensor, front	09.91-07.94	**0 265 001 231**
Wheel speed sensor, rear	09.91-07.94	**0 265 001 187**
2.0 T 16V		**2,0 l 140 kW B204FT Kat. 4 Zyl.**
Throttle valve sensor	09.91-07.94	**0 280 120 400**
Air mass meter, gasoline injection	09.91-07.94	**0 280 213 012**
		0 986 280 110
Knock sensor	09.91-07.94	**0 261 231 046**
Temperature sensor, coolant, injection system	09.91-07.94	**0 280 130 032**
Wheel speed sensor, front	09.91-07.94	**0 265 001 231**
Wheel speed sensor, rear	09.91-07.94	**0 265 001 187**
2.3 T		**2,3 l 121 kW B230FT Kat. 4 Zyl.**
Throttle valve sensor	03.93-07.93	**0 280 120 325**
Air mass meter, gasoline injection	03.93-07.93	**0 280 212 016**
		0 986 280 101
Knock sensor	03.93-07.93	**0 261 231 046**
Temperature sensor, coolant, injection system	03.93-07.93	**0 280 130 032**
Wheel speed sensor, front	03.93-07.93	**0 265 001 231**
Wheel speed sensor, rear	03.93-07.93	**0 265 001 187**
2.3 T		**2,3 l 125 kW B230GK 4 Zyl.**
Throttle valve sensor	09.91-07.97	**0 280 120 325**
Air mass meter, gasoline injection	09.91-07.97	**0 280 212 021**
		0 986 280 107
Knock sensor	09.91-07.97	**0 261 231 046**
Temperature sensor, coolant, injection system	09.91-07.97	**0 280 130 032**
Wheel speed sensor, front	09.91-08.94	**0 265 001 231**
	09.94-07.97	**0 265 001 380**
Wheel speed sensor, rear	09.91-07.97	**0 265 001 187**

V

Product			
◀ 960			
2.4			**2,4 l 120 kW B6244S Kat. 6 Zyl.**
Phase sensor	09.94-07.97	NOC	**0 232 101 030**
Wheel speed sensor, front	09.94-07.97		**0 265 001 380**
Wheel speed sensor, rear	09.94-07.97		**0 265 001 187**
2.4 TD			**2,4 l 85 kW D24TIC 6 Zyl.**
Wheel speed sensor, front	08.90-08.94		**0 265 001 231**
	09.94-07.97		**0 265 001 380**
Wheel speed sensor, rear	08.90-07.97		**0 265 001 187**
2.5			**2,5 l 125 kW B6254S 6 Zyl.**
Throttle valve sensor	09.94-07.97		**0 280 122 001**
Air mass meter, gasoline injection	09.94-08.95		**0 280 213 026**
	09.95-07.97		**0 280 217 511**
Phase sensor	09.94-07.97	NOC	**0 232 101 030**
Knock sensor	09.94-07.97		**0 261 231 046**
Wheel speed sensor, front	09.94-07.97		**0 265 001 380**
Wheel speed sensor, rear	09.94-07.97		**0 265 001 187**
2.5			**2,5 l 125 kW B6254S Kat. 6 Zyl.**
Throttle valve sensor	09.94-07.97		**0 280 122 001**
Air mass meter, gasoline injection	09.95-07.97		**0 280 213 025**
			0 986 280 114
	09.94-08.95		**0 280 213 025**
			0 986 280 114
	09.95-07.97		**0 280 217 511**
Phase sensor	09.94-07.97	NOC	**0 232 101 030**
Knock sensor	09.94-07.97		**0 261 231 046**
Wheel speed sensor, front	09.94-07.97		**0 265 001 380**
Wheel speed sensor, rear	09.94-07.97		**0 265 001 187**
2.8			**2,8 l 110/125 kW B280E; B280F Kat. 6 Zyl.**
Throttle valve sensor	09.90-07.91		**0 280 120 325**
Air mass meter, gasoline injection	09.90-07.91		**0 280 213 006**
			0 986 280 115
Speed sensor, ignition/injection	09.90-07.91		**0 261 210 029**
Knock sensor	09.90-07.91		**0 261 231 007**
Temperature sensor, coolant, injection system	09.90-07.91		**0 280 130 032**
Wheel speed sensor, front	09.90-07.91		**0 265 001 231**
Wheel speed sensor, rear	09.90-07.91		**0 265 001 187**
3.0			**3,0 l 150 kW B6304FS Kat. 6 Zyl.**
Throttle valve sensor	09.90-07.98		**0 280 122 001**
Air mass meter, gasoline injection	09.94-08.95		**0 280 213 002**
			0 986 280 118
	09.90-08.94		**0 280 213 012**
			0 986 280 110
	09.95-07.98		**0 280 217 511**
Phase sensor	09.90-07.98	NOC	**0 232 101 030**
Knock sensor	09.90-07.98		**0 261 231 046**
Wheel speed sensor, front	09.90-08.94		**0 265 001 231**
	09.94-07.97		**0 265 001 380**
Wheel speed sensor, rear	09.90-07.97		**0 265 001 187**
3.0			**3,0 l 150 kW B6304GS 6 Zyl.**
Throttle valve sensor	09.91-07.97		**0 280 122 001**
Air mass meter, gasoline injection	09.91-08.94		**0 280 213 020**
			0 986 280 132
	09.94-08.95		**0 280 213 026**
	09.95-07.97		**0 280 217 511**
Phase sensor	09.91-07.97	NOC	**0 232 101 030**
Knock sensor	09.91-07.97		**0 261 231 046**
Wheel speed sensor, front	09.91-08.94		**0 265 001 231**
	09.94-07.97		**0 265 001 380**
Wheel speed sensor, rear	09.91-07.97		**0 265 001 187**
3.0			**3,0 l 150 kW B6304S Kat. 6 Zyl.**
Throttle valve sensor	09.94-07.95		**0 280 122 001**
Air mass meter, gasoline injection	09.94-07.95		**0 280 213 025**
			0 986 280 114

Product			
Phase sensor	09.94-07.95	NOC	**0 232 101 030**
Knock sensor	09.94-07.95		**0 261 231 046**
Wheel speed sensor, front	09.94-07.95		**0 265 001 380**
Wheel speed sensor, rear	09.94-07.95		**0 265 001 187**

VW (VOLKSWAGEN)

Bora

1.4 [1J2]			**1,4 l 55 kW AHW 4 Zyl.**
Knock sensor	09.98-04.01		**0 261 231 045**
	05.01-05.05		**0 261 231 146**
Accelerator pedal module	05.01-05.05	GS,LLE	**0 280 752 214**
Fg.no. 1J..Y..000 001→	05.99-05.05	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.4 [1J2]			**1,4 l 55 kW AKQ 4 Zyl.**
Speed sensor, ignition/injection			
Mot.no. 001 001→001 068	09.98-05.00		**0 261 210 194**
Knock sensor	09.98-05.00		**0 261 231 045**
Accelerator pedal module			
Fg.no. 1J..Y..000 001→	05.99-05.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.4 [1J2]			**1,4 l 55 kW APE 4 Zyl.**
Knock sensor	01.99-05.00		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	01.99-05.00		**0 261 230 031**
Accelerator pedal module			
Fg.no. 1J..Y..000 001→	05.99-05.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.4 [1J2]			**1,4 l 55 kW AXP 4 Zyl.**
Knock sensor	05.00-10.01		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.00-10.01		**0 261 230 031**
Accelerator pedal module	05.00-10.01	AG,RLE	**0 280 752 213**
	05.01-10.01	GS,LLE	**0 280 752 214**
	05.00-10.01	GS,RLE	**0 280 752 210**
1.4 [1J2]			**1,4 l 55 kW BCA 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.01-05.05		**0 261 230 031**
Accelerator pedal module	10.01-05.05	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.6 [1J2]			**1,6 l 74 kW AEH; AKL 4 Zyl.**
Phase sensor	09.98-05.05		**0 232 101 031**
Speed sensor, ignition/injection	09.98-05.05		**0 261 210 147**
Accelerator pedal module	05.01-05.05	GS,LLE	**0 280 752 214**
Fg.no. 1J..Y..000 001→	05.99-05.05	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.6 [1J2]			**1,6 l 74 kW APF 4 Zyl.**
Phase sensor	05.99-09.00		**0 232 101 031**
Speed sensor, ignition/injection	05.99-09.00		**0 261 210 199**
Accelerator pedal module	05.99-09.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.6 [1J2]			**1,6 l 75 kW AVU 4 Zyl.**
Phase sensor	09.00-05.05		**0 232 101 038**
Speed sensor, ignition/injection	09.00-05.05		**0 261 210 199**
Accelerator pedal module	09.00-05.05	AG,RLE	**0 280 752 213**
	05.01-05.05	GS,LLE	**0 280 752 214**
	09.00-05.05	GS,RLE	**0 280 752 210**
1.6 [1J2]			**1,6 l 75 kW BFQ 4 Zyl.**
Speed sensor, ignition/injection	05.02-05.03		**0 261 210 199**
Knock sensor	05.02-05.03		**0 261 231 146**
Accelerator pedal module	05.02-05.03	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**

Product			
1.6 [1J2]			**1,6 l 77 kW ATN 4 Zyl.**
Throttle valve assembly	08.99-05.00		**0 280 750 049**
Speed sensor, ignition/injection	08.99-05.00		**0 261 210 194**
Knock sensor	08.99-05.00		**0 261 231 045**
Accelerator pedal module	08.99-05.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.6 [1J2]			**1,6 l 77 kW AUS 4 Zyl.**
Throttle valve assembly	05.00-10.00		**0 280 750 049**
Knock sensor	05.00-10.00		**0 261 231 045**
Accelerator pedal module	05.00-10.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.6 [1J2]			**1,6 l 77 kW AZD 4 Zyl.**
Throttle valve assembly	09.00-11.01		**0 280 750 049**
Speed sensor, ignition/injection	09.00-11.01		**0 261 210 194**
Knock sensor	09.00-11.01		**0 261 231 146**
Accelerator pedal module	09.00-11.01	AG,RLE	**0 280 752 213**
	05.01-11.01	GS,LLE	**0 280 752 214**
	09.00-11.01	GS,RLE	**0 280 752 210**
1.6 [1J2]			**1,6 l 77 kW BCB 4 Zyl.**
Speed sensor, ignition/injection	11.01-05.05		**0 261 210 213**
Knock sensor	11.01-05.05		**0 261 231 146**
Accelerator pedal module	11.01-05.05	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.6 FSI [1J2]			**1,6 l 81 kW BAD 4 Zyl.**
Throttle valve assembly	08.01-05.05		**0 280 750 059**
Air mass meter, gasoline injection	08.01-05.05		**0 280 218 060**
			0 986 280 216
Knock sensor	08.01-05.05		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	08.01-05.05		**0 261 230 079**
Accelerator pedal module	08.01-05.05	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.6 i			**1,6 l 78 kW AWB 4 Zyl.**
Air mass meter, gasoline injection	06.02-02.07		**0 280 218 060**
			0 986 280 216
Speed sensor, ignition/injection	06.02-02.07		**0 261 210 254**
1.6 4 Motion [1J2]			**1,6 l 77 kW AZD 4 Zyl.**
Throttle valve assembly	09.00-11.01		**0 280 750 049**
Speed sensor, ignition/injection	09.00-11.01		**0 261 210 194**
Knock sensor	09.00-11.01		**0 261 231 146**
Accelerator pedal module	09.00-11.01	AG,RLE	**0 280 752 213**
	05.01-11.01	GS,LLE	**0 280 752 214**
	09.00-11.01	GS,RLE	**0 280 752 210**
1.8 [1J2]			**1,8 l 92 kW AGN 4 Zyl.**
Air mass meter, gasoline injection	09.98-10.00		**0 280 218 002**
			0 986 280 205
Phase sensor	09.98-10.00		**0 232 101 024**
Speed sensor, ignition/injection	09.98-10.00		**0 261 210 147**
Accelerator pedal module			
Fg.no. 1J..Y..000 001→	05.99-10.00	AG,RLE	**0 280 752 213**
1.8 i			**1,8 l 92 kW BAF 4 Zyl.**
Throttle valve assembly	08.01-03.03		**0 280 750 026**
	04.03→		**0 280 750 159**
Phase sensor	08.01→		**0 232 101 024**
Speed sensor, ignition/injection	08.01→		**0 261 210 147**
1.8 i Turbo			**1,8 l 110 kW BAE 4 Zyl.**
Throttle valve assembly	08.01-01.06		**0 280 750 036**
Air mass meter, gasoline injection	08.01-01.06		**0 280 218 063**
			0 986 280 217
Phase sensor	08.01-01.06		**0 232 101 024**
Speed sensor, ignition/injection	08.01-01.06		**0 261 210 147**

Product			
Knock sensor	08.01-01.06	ZE	**0 261 231 146**
Temperature sensor, intake air, injection system	08.01-01.06		**0 280 130 085**
1.8 T [1J2]			**1,8 l 110 kW AGU 4 Zyl.**
Air mass meter, gasoline injection	05.00-05.05		**0 280 217 117**
			0 986 280 201
Speed sensor, ignition/injection	05.00-05.05		**0 261 210 199**
Boost pressure sensor, gasoline			
Fg.no. →1J..3..525 000	05.00-03.03		**0 281 002 177**
Fg.no. 1J..3..525 001→	04.03-05.05		**0 281 002 399**
Temperature sensor, intake air, injection system			
Fg.no. →1J..3D013 548,→1J..3W335 000	05.00-09.02		**0 280 130 085**
Fg.no. 1J..3D013 549→,1J..3W335 001→	10.02-05.05		**0 280 130 116**
Accelerator pedal module	05.00-05.05	AG,RLE	**0 280 752 213**
	05.01-05.05	GS,LLE	**0 280 752 214**
	05.00-05.05	GS,RLE	**0 280 752 210**
1.8 T [1J2]			**1,8 l 110 kW ARX 4 Zyl.**
Accelerator pedal module	09.00-04.01	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.8 T [1J2]			**1,8 l 110 kW AUM 4 Zyl.**
Throttle valve assembly	09.00-05.05		**0 280 750 036**
Air mass meter, gasoline injection	09.00-05.05		**0 280 218 063**
			0 986 280 217
Phase sensor	09.00-05.05		**0 232 101 024**
Speed sensor, ignition/injection	09.00-05.05		**0 261 210 199**
Knock sensor	09.00-05.05		**0 261 231 146**
Boost pressure sensor, gasoline			
Fg.no. →1J..3..525 000	09.00-03.03		**0 281 002 177**
Fg.no. 1J..3..525 001→	04.03-05.05		**0 281 002 399**
Temperature sensor, intake air, injection system			
Fg.no. →1J..3D013 548,→1J..3W335 000	09.00-09.02		**0 280 130 085**
Fg.no. 1J..3D013 549→,1J..3W335 001→	10.02-05.05		**0 280 130 116**
Accelerator pedal module	09.00-05.05	AG,RLE	**0 280 752 213**
	05.01-05.05	GS,LLE	**0 280 752 214**
	09.00-05.05	GS,RLE	**0 280 752 210**
1.8 T [1J2]			**1,8 l 132 kW AUQ 4 Zyl.**
Throttle valve assembly	05.02-05.03		**0 280 750 036**
Air mass meter, gasoline injection	05.02-05.03		**0 280 218 063**
			0 986 280 217
Phase sensor	05.02-05.03		**0 232 101 024**
Speed sensor, ignition/injection	05.02-05.03		**0 261 210 199**
Boost pressure sensor, gasoline			
Fg.no. →1J..3..525 000	05.02-03.03		**0 281 002 177**
Fg.no. 1J..3..525 001→	04.03-05.03		**0 281 002 399**
Temperature sensor, intake air, injection system			
Fg.no. →1J..3D013 548,→1J..3W335 000	05.02-09.02		**0 280 130 085**
Fg.no. 1J..3D013 549→,1J..3W335 001→	10.02-05.03		**0 280 130 116**
Accelerator pedal module	05.02-05.03	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.8 4 Motion [1J2]			**1,8 l 92 kW AGN 4 Zyl.**
Air mass meter, gasoline injection	02.99-10.00		**0 280 218 002**
			0 986 280 205
Phase sensor	02.99-10.00		**0 232 101 024**
Speed sensor, ignition/injection	02.99-10.00		**0 261 210 147**
Accelerator pedal module			
Fg.no. 1J..Y..000 001→	05.99-10.00	AG,RLE	**0 280 752 213**
1.9 TDI			**1,9 l 74 kW ATD 4 Zyl.**
Air mass meter, diesel			
Fg.no. 1J..2..380 001→,1J..2D420 000→	02.04-06.06		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. 1J..3..525 001→	02.04-06.06		**0 281 002 399**

V

Product			
◀ Bora			
1.9 TDI [1J2]			**1,9 l 66 kW AGR; ALH 4 Zyl.**
Air mass meter, diesel	09.98-05.05		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel			
Fg.no. →1J..3..525 000	09.98-03.03		**0 281 002 177**
Fg.no. 1J..3..525 001→	04.03-05.05		**0 281 002 399**
1.9 TDI [1J2]			**1,9 l 74 kW ATD; AXR 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1J..2..380 000,→1J..2D420 000	01.00-10.01		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 1J..2..380 001→,1J..2D420 000→	11.01-05.05		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1J..3..525 000	01.00-03.03		**0 281 002 177**
Fg.no. 1J..3..525 001→	04.03-05.05		**0 281 002 399**
1.9 TDI [1J2]			**1,9 l 81 kW AHF; ASV 4 Zyl.**
Air mass meter, diesel	09.98-05.05		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel			
Fg.no. →1J..3..525 000	09.98-03.03		**0 281 002 177**
Fg.no. 1J..3..525 001→	04.03-05.05		**0 281 002 399**
1.9 TDI [1J2]			**1,9 l 85 kW AJM; AUY 4 Zyl.**
Air mass meter, diesel	09.98-05.01		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel	09.98-05.01		**0 281 002 177**
1.9 TDI [1J2]			**1,9 l 96 kW ASZ 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1J..2..600 000	01.01-04.02		**0 280 217 529**
			0 986 280 204
Fg.no. 1J..2..600 001→	05.02-05.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	01.01-05.05		**0 281 002 177**
1.9 TDI [1J2]			**1,9 l 110 kW ARL 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1J..2..600 000	01.00-04.02		**0 280 217 529**
			0 986 280 204
Fg.no. 1J..2..600 001→	05.02-05.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	01.00-05.05		**0 281 002 394**
1.9 TDI 4 Motion [1J2]			**1,9 l 66 kW AGR 4 Zyl.**
Air mass meter, diesel	01.99-05.05		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel			
Fg.no. →1J..3..525 000	01.99-03.03		**0 281 002 177**
Fg.no. 1J..3..525 001→	04.03-05.05		**0 281 002 399**
1.9 TDI 4 Motion [1J2]			**1,9 l 74 kW ATD 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1J..2..380 000,→1J..2D420 000	01.00-10.01		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 1J..2..380 001→,1J..2D420 000→	11.01-05.05		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1J..3..525 000	01.00-03.03		**0 281 002 177**
Fg.no. 1J..3..525 001→	04.03-05.05		**0 281 002 399**

Product			
1.9 TDI 4 Motion [1J2]			**1,9 l 85 kW AJM; AUY 4 Zyl.**
Air mass meter, diesel	02.99-04.01		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel	02.99-04.01		**0 281 002 177**
1.9 TDI 4 Motion [1J2]			**1,9 l 96 kW ASZ 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1J..2..600 000	01.01-04.02		**0 280 217 529**
			0 986 280 204
Fg.no. 1J..2..600 001→	05.02-05.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	01.01-05.05		**0 281 002 177**
1.9 TDI 4 Motion [1J2]			**1,9 l 110 kW ARL 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1J..2..600 000	09.00-04.02		**0 280 217 529**
			0 986 280 204
Fg.no. 1J..2..600 001→	05.02-05.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	09.00-05.05		**0 281 002 394**
2.0			**2,0 l 85 kW APK 4 Zyl.**
Phase sensor	12.00-06.03		**0 232 101 031**
Speed sensor, ignition/injection	12.00-06.03		**0 261 210 147**
Knock sensor	12.00-06.03		**0 261 231 146**
2.0			**2,0 l 85 kW BER 4 Zyl.**
Throttle valve assembly	09.02→		**0 280 750 061**
Air mass meter, gasoline injection	09.02→		**0 280 218 060**
			0 986 280 216
Speed sensor, ignition/injection	09.02→		**0 261 210 147**
Knock sensor	09.02→		**0 261 231 146**
2.0 [1J2]			**2,0 l 85 kW APK; AQY 4 Zyl.**
Air mass meter, gasoline injection	09.98-05.05		**0 280 218 002**
			0 986 280 205
Phase sensor	09.98-05.05		**0 232 101 031**
Speed sensor, ignition/injection	09.98-05.05		**0 261 210 147**
Knock sensor	09.98-04.01		**0 261 231 045**
	05.01-05.05		**0 261 231 146**
Accelerator pedal module	05.01-05.05	GS,LLE	**0 280 752 214**
Fg.no. 1J..Y..000 001→	05.99-05.05	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
2.0 [1J2]			**2,0 l 85 kW AZH 4 Zyl.**
Throttle valve assembly	04.00-06.01		**0 280 750 061**
Air mass meter, gasoline injection	04.00-06.01		**0 280 218 002**
			0 986 280 205
Speed sensor, ignition/injection	04.00-06.01		**0 261 210 147**
Knock sensor	04.00-06.01		**0 261 231 146**
Accelerator pedal module	04.00-06.01	AG,RLE	**0 280 752 213**
	05.01-06.01	GS,LLE	**0 280 752 214**
	04.00-06.01	GS,RLE	**0 280 752 210**
2.0 [1J2]			**2,0 l 85 kW AZJ 4 Zyl.**
Throttle valve assembly	05.01-05.05		**0 280 750 059**
Air mass meter, gasoline injection	05.01-05.05		**0 280 218 060**
			0 986 280 216
Phase sensor	05.01-05.05		**0 232 101 031**
Speed sensor, ignition/injection	05.01-05.05		**0 261 210 199**
Knock sensor	05.01-05.05		**0 261 231 146**
Accelerator pedal module	05.01-05.05	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
2.0 4 Motion [1J2]			**2,0 l 85 kW AZH 4 Zyl.**
Throttle valve assembly	04.00-06.01		**0 280 750 061**
Air mass meter, gasoline injection	04.00-06.01		**0 280 218 002**
			0 986 280 205
Speed sensor, ignition/injection	04.00-06.01		**0 261 210 147**

Product			
Knock sensor	04.00-06.01		**0 261 231 146**
Accelerator pedal module	04.00-06.01	AG,RLE	**0 280 752 213**
	05.01-06.01	GS,LLE	**0 280 752 214**
	04.00-06.01	GS,RLE	**0 280 752 210**
2.0 4 Motion [1J2]			**2,0 l 85 kW AZJ 4 Zyl.**
Throttle valve assembly	05.01-05.05		**0 280 750 059**
Air mass meter, gasoline injection	05.01-05.05		**0 280 218 060**
			0 986 280 216
Phase sensor	05.01-05.05		**0 232 101 031**
Speed sensor, ignition/injection	05.01-05.05		**0 261 210 199**
Knock sensor	05.01-05.05		**0 261 231 146**
Accelerator pedal module	05.01-05.05	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
2.3 [1J2]			**2,3 l 110 kW AGZ 5 Zyl.**
Air mass meter, gasoline injection	09.98-02.01		**0 280 217 529**
			0 986 280 204
Phase sensor	09.98-02.01		**0 232 103 019**
Speed sensor, ignition/injection	09.98-02.01		**0 261 210 177**
Knock sensor	09.98-02.01		**0 261 231 146**
Temperature sensor, intake air, injection system	09.98-02.01		**0 280 130 085**
Accelerator pedal module			
Fg.no. 1J..Y..000 001→	05.99-02.01	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
2.3 [1J2]			**2,3 l 125 kW AQN 5 Zyl.**
Throttle valve assembly	09.00-05.05		**0 280 750 097**
Air mass meter, gasoline injection	09.00-05.05		**0 280 218 017**
			0 986 280 208
Phase sensor	09.00-05.05		**0 232 103 019**
Knock sensor	09.00-05.05	OHL	**0 261 231 146**
Accelerator pedal module	09.00-05.05	AG,RLE	**0 280 752 213**
	05.01-05.05	GS,LLE	**0 280 752 214**
	09.00-05.05	GS,RLE	**0 280 752 210**
2.3 4 Motion [1J2]			**2,3 l 110 kW AGZ 5 Zyl.**
Air mass meter, gasoline injection	01.99-02.01		**0 280 217 529**
			0 986 280 204
Phase sensor	01.99-02.01		**0 232 103 019**
Speed sensor, ignition/injection	01.99-02.01		**0 261 210 177**
Knock sensor	01.99-02.01		**0 261 231 146**
Temperature sensor, intake air, injection system	01.99-02.01		**0 280 130 085**
Accelerator pedal module			
Fg.no. 1J..Y..000 001→	05.99-02.01	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
2.3 4 Motion [1J2]			**2,3 l 125 kW AQN 5 Zyl.**
Throttle valve assembly	09.00-05.05		**0 280 750 097**
Air mass meter, gasoline injection	09.00-05.05		**0 280 218 017**
			0 986 280 208
Phase sensor	09.00-05.05		**0 232 103 019**
Knock sensor	09.00-05.05	OHL	**0 261 231 146**
Accelerator pedal module	09.00-05.05	AG,RLE	**0 280 752 213**
	05.01-05.05	GS,LLE	**0 280 752 214**
	09.00-05.05	GS,RLE	**0 280 752 210**
2.8 4 Motion [1J2]			**2,8 l 150 kW AQP; AUE 6 Zyl.**
Throttle valve assembly			
Fg.no. →1J..Y..620 000	05.99-01.00	LLE	**0 280 750 086**
		RLE	**0 280 750 097**
Fg.no. 1J..Y..620 001→	02.00-04.01		**0 280 750 097**
Air mass meter, gasoline injection	05.99-04.01		**0 280 218 017**
			0 986 280 208
Phase sensor	05.99-04.01		**0 232 103 019**
Knock sensor	05.99-04.01	OHL	**0 261 231 146**
Accelerator pedal module	05.99-04.01	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**

Product			
2.8 4 Motion [1J2]			**2,8 l 150 kW BDE 6 Zyl.**
Throttle valve assembly	05.01-05.05		**0 280 750 097**
Air mass meter, gasoline injection	05.01-05.05		**0 280 218 017**
			0 986 280 208
Phase sensor	05.01-05.05		**0 232 103 019**
Knock sensor	05.01-05.05	OHL	**0 261 231 146**
Accelerator pedal module	05.01-05.05	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**

Bora Variant

1.4 [1J6]			**1,4 l 55 kW AHW 4 Zyl.**
Knock sensor	05.00-04.01		**0 261 231 045**
	05.01-05.05		**0 261 231 146**
Accelerator pedal module	05.00-05.05	AG,RLE	**0 280 752 213**
	05.01-05.05	GS,LLE	**0 280 752 214**
	05.00-05.05	GS,RLE	**0 280 752 210**
1.4 [1J6]			**1,4 l 55 kW AXP 4 Zyl.**
Knock sensor	05.00-10.01		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.00-10.01		**0 261 230 031**
Accelerator pedal module	05.00-10.01	AG,RLE	**0 280 752 213**
	05.01-10.01	GS,LLE	**0 280 752 214**
	05.00-10.01	GS,RLE	**0 280 752 210**
1.4 [1J6]			**1,4 l 55 kW BCA 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.01-05.05		**0 261 230 031**
Accelerator pedal module	10.01-05.05	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.6 [1J6]			**1,6 l 74 kW AEH 4 Zyl.**
Phase sensor	05.99-04.01		**0 232 101 031**
Speed sensor, ignition/injection	05.99-04.01		**0 261 210 147**
Accelerator pedal module	05.99-04.01	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.6 [1J6]			**1,6 l 74 kW AKL 4 Zyl.**
Phase sensor	05.99-05.05		**0 232 101 031**
Speed sensor, ignition/injection	05.99-05.05		**0 261 210 147**
Accelerator pedal module	05.99-05.05	AG,RLE	**0 280 752 213**
	05.01-05.05	GS,LLE	**0 280 752 214**
	05.99-05.05	GS,RLE	**0 280 752 210**
1.6 [1J6]			**1,6 l 74 kW APF 4 Zyl.**
Phase sensor	05.99-09.00		**0 232 101 031**
Speed sensor, ignition/injection	05.99-09.00		**0 261 210 199**
Accelerator pedal module	05.99-09.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.6 [1J6]			**1,6 l 75 kW AVU 4 Zyl.**
Phase sensor	09.00-05.05		**0 232 101 038**
Speed sensor, ignition/injection	09.00-05.05		**0 261 210 199**
Accelerator pedal module	09.00-05.05	AG,RLE	**0 280 752 213**
	05.01-05.05	GS,LLE	**0 280 752 214**
	09.00-05.05	GS,RLE	**0 280 752 210**
1.6 [1J6]			**1,6 l 75 kW BFQ 4 Zyl.**
Speed sensor, ignition/injection	05.02-05.03		**0 261 210 199**
Knock sensor	05.02-05.03		**0 261 231 146**
Accelerator pedal module	05.02-05.03	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.6 [1J6]			**1,6 l 77 kW ATN 4 Zyl.**
Throttle valve assembly	08.99-05.00		**0 280 750 049**
Speed sensor, ignition/injection	08.99-05.00		**0 261 210 194**
Knock sensor	08.99-05.00		**0 261 231 045**
Accelerator pedal module	08.99-05.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**

Product			
◀ Bora Variant			
1.6 [1J6]			**1,6 l 77 kW AUS 4 Zyl.**
Throttle valve assembly	05.00-10.00		**0 280 750 049**
Knock sensor	05.00-10.00		**0 261 231 045**
Accelerator pedal module	05.00-10.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.6 [1J6]			**1,6 l 77 kW AZD 4 Zyl.**
Throttle valve assembly	09.00-11.01		**0 280 750 049**
Speed sensor, ignition/injection	09.00-11.01		**0 261 210 194**
Knock sensor	09.00-11.01		**0 261 231 146**
Accelerator pedal module	09.00-11.01	AG,RLE	**0 280 752 213**
	05.01-11.01	GS,LLE	**0 280 752 214**
	09.00-11.01	GS,RLE	**0 280 752 210**
1.6 [1J6]			**1,6 l 77 kW BCB 4 Zyl.**
Speed sensor, ignition/injection	11.01-05.05		**0 261 210 213**
Knock sensor	11.01-05.05		**0 261 231 146**
Accelerator pedal module	11.01-05.05	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.6 FSI [1J6]			**1,6 l 81 kW BAD 4 Zyl.**
Throttle valve assembly	08.01-05.05		**0 280 750 059**
Air mass meter, gasoline injection	08.01-05.05		**0 280 218 060**
			0 986 280 216
Knock sensor	08.01-05.05		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	08.01-05.05		**0 261 230 079**
Accelerator pedal module	08.01-05.05	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.6 4 Motion [1J6]			**1,6 l 77 kW AUS 4 Zyl.**
Throttle valve assembly	05.00-10.00		**0 280 750 049**
Knock sensor	05.00-10.00		**0 261 231 045**
Accelerator pedal module	05.00-10.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.6 4 Motion [1J6]			**1,6 l 77 kW AZD 4 Zyl.**
Throttle valve assembly	09.00-11.01		**0 280 750 049**
Speed sensor, ignition/injection	09.00-11.01		**0 261 210 194**
Knock sensor	09.00-11.01		**0 261 231 146**
Accelerator pedal module	09.00-11.01	AG,RLE	**0 280 752 213**
	05.01-11.01	GS,LLE	**0 280 752 214**
	09.00-11.01	GS,RLE	**0 280 752 210**
1.8 T [1J6]			**1,8 l 110 kW AGU 4 Zyl.**
Air mass meter, gasoline injection	05.00-05.05		**0 280 217 117**
			0 986 280 201
Speed sensor, ignition/injection	05.00-05.05		**0 261 210 199**
Boost pressure sensor, gasoline			
Fg.no. →1J..3..525 000	05.00-03.03		**0 281 002 177**
Fg.no. 1J..3..525 001→	04.03-05.05		**0 281 002 399**
Temperature sensor, intake air, injection system			
Fg.no. →1J..3D013 548,→1J..3W335 000	05.00-09.02		**0 280 130 085**
Fg.no. 1J..3D013 549→,1J..3W335 001→	10.02-05.05		**0 280 130 116**
Accelerator pedal module	05.00-05.05	AG,RLE	**0 280 752 213**
	05.01-05.05	GS,LLE	**0 280 752 214**
	05.00-05.05	GS,RLE	**0 280 752 210**
1.8 T [1J6]			**1,8 l 110 kW ARX 4 Zyl.**
Accelerator pedal module	09.00-04.01	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.8 T [1J6]			**1,8 l 110 kW AUM 4 Zyl.**
Throttle valve assembly	09.00-05.05		**0 280 750 036**
Air mass meter, gasoline injection	09.00-05.05		**0 280 218 063**
			0 986 280 217
Phase sensor	09.00-05.05		**0 232 101 024**
Speed sensor, ignition/injection	09.00-05.05		**0 261 210 199**
Knock sensor	09.00-05.05		**0 261 231 146**

Product			
Boost pressure sensor, gasoline			
Fg.no. →1J..3..525 000	09.00-03.03		**0 281 002 177**
Fg.no. 1J..3..525 001→	04.03-05.05		**0 281 002 399**
Temperature sensor, intake air, injection system			
Fg.no. →1J..3D013 548,→1J..3W335 000	09.00-09.02		**0 280 130 085**
Fg.no. 1J..3D013 549→,1J..3W335 001→	10.02-05.05		**0 280 130 116**
Accelerator pedal module	09.00-05.05	AG,RLE	**0 280 752 213**
	05.01-05.05	GS,LLE	**0 280 752 214**
	09.00-05.05	GS,RLE	**0 280 752 210**
1.8 T [1J6]			**1,8 l 132 kW AUQ 4 Zyl.**
Throttle valve assembly	05.02-05.03		**0 280 750 036**
Air mass meter, gasoline injection	05.02-05.03		**0 280 218 063**
			0 986 280 217
Phase sensor	05.02-05.03		**0 232 101 024**
Speed sensor, ignition/injection	05.02-05.03		**0 261 210 199**
Boost pressure sensor, gasoline			
Fg.no. →1J..3..525 000	05.02-03.03		**0 281 002 177**
Fg.no. 1J..3..525 001→	04.03-05.03		**0 281 002 399**
Temperature sensor, intake air, injection system			
Fg.no. →1J..3D013 548,→1J..3W335 000	05.02-09.02		**0 280 130 085**
Fg.no. 1J..3D013 549→,1J..3W335 001→	10.02-05.03		**0 280 130 116**
Accelerator pedal module	05.02-05.03	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.8 4 Motion [1J6]			**1,8 l 92 kW AGN 4 Zyl.**
Air mass meter, gasoline injection	05.99-10.00		**0 280 218 002**
			0 986 280 205
Phase sensor	05.99-10.00		**0 232 101 024**
Speed sensor, ignition/injection	05.99-10.00		**0 261 210 147**
Accelerator pedal module	05.99-10.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.9 TDI [1J6]			**1,9 l 66 kW AGR 4 Zyl.**
Air mass meter, diesel	09.98-05.05		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel			
Fg.no. →1J..3..525 000	09.98-03.03		**0 281 002 177**
Fg.no. 1J..3..525 001→	04.03-05.05		**0 281 002 399**
1.9 TDI [1J6]			**1,9 l 74 kW ATD; AXR 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1J..2..380 000,→1J..2D420 000	05.00-10.01		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 1J..2..380 001→,1J..2D420 000→	11.01-05.05		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1J..3..525 000	05.00-03.03		**0 281 002 177**
Fg.no. 1J..3..525 001→	04.03-05.05		**0 281 002 399**
1.9 TDI [1J6]			**1,9 l 81 kW AHF; ASV 4 Zyl.**
Air mass meter, diesel	05.99-05.05		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel			
Fg.no. →1J..3..525 000	05.99-03.03		**0 281 002 177**
Fg.no. 1J..3..525 001→	04.03-05.05		**0 281 002 399**
1.9 TDI [1J6]			**1,9 l 85 kW AJM; AUY 4 Zyl.**
Air mass meter, diesel	05.99-04.01		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel	05.99-04.01		**0 281 002 177**

V

Product			
1.9 TDI [1J6]			**1,9 l 96 kW ASZ 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1J..2..600 000	01.01-04.02		**0 280 217 529**
			0 986 280 204
Fg.no. 1J..2..600 001→	05.02-05.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	01.01-05.05		**0 281 002 177**
1.9 TDI [1J6]			**1,9 l 110 kW ARL 4 Zyl.**
Air mass meter, diesel	05.02-05.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	05.02-05.05		**0 281 002 394**
1.9 TDI 4 Motion [1J6]			**1,9 l 74 kW ATD 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1J..2..380 000,→1J..2D420 000	05.00-10.01		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 1J..2..380 001→,1J..2D420 000→	11.01-05.05		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1J..3..525 000	05.00-03.03		**0 281 002 177**
Fg.no. 1J..3..525 001→	04.03-05.05		**0 281 002 399**
1.9 TDI 4 Motion [1J6]			**1,9 l 85 kW AJM; AUY 4 Zyl.**
Air mass meter, diesel	05.99-04.01		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel	05.99-04.01		**0 281 002 177**
1.9 TDI 4 Motion [1J6]			**1,9 l 96 kW ASZ 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1J..2..600 000	01.01-04.02		**0 280 217 529**
			0 986 280 204
Fg.no. 1J..2..600 001→	05.02-05.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	01.01-05.05		**0 281 002 177**
1.9 TDI 4 Motion [1J6]			**1,9 l 110 kW ARL 4 Zyl.**
Air mass meter, diesel	05.02-05.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	05.02-05.05		**0 281 002 394**
2.0 [1J6]			**2,0 l 85 kW APK; AQY 4 Zyl.**
Air mass meter, gasoline injection	05.99-05.05		**0 280 218 002**
			0 986 280 205
Phase sensor	05.99-05.05		**0 232 101 031**
Speed sensor, ignition/injection	05.99-05.05		**0 261 210 147**
Knock sensor	05.99-04.01		**0 261 231 045**
	05.01-05.05		**0 261 231 146**
Accelerator pedal module	05.99-05.05	AG,RLE	**0 280 752 213**
	05.01-05.05	GS,LLE	**0 280 752 214**
	05.99-05.05	GS,RLE	**0 280 752 210**
2.0 [1J6]			**2,0 l 85 kW AZG 4 Zyl.**
Throttle valve assembly	05.01-05.05		**0 280 750 061**
Air mass meter, gasoline injection	05.01-05.05		**0 280 218 060**
			0 986 280 216
Speed sensor, ignition/injection	05.01-05.05		**0 261 210 199**
Accelerator pedal module	05.01-05.05	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
2.0 [1J6]			**2,0 l 85 kW AZH 4 Zyl.**
Throttle valve assembly	04.00-06.01		**0 280 750 061**
Air mass meter, gasoline injection	04.00-06.01		**0 280 218 002**
			0 986 280 205
Speed sensor, ignition/injection	04.00-06.01		**0 261 210 147**
Knock sensor	04.00-06.01		**0 261 231 146**
Accelerator pedal module	04.00-06.01	AG,RLE	**0 280 752 213**
	05.01-06.01	GS,LLE	**0 280 752 214**
	04.00-06.01	GS,RLE	**0 280 752 210**
2.0 [1J6]			**2,0 l 85 kW AZJ 4 Zyl.**
Throttle valve assembly	05.01-05.05		**0 280 750 059**
Air mass meter, gasoline injection	05.01-05.05		**0 280 218 060**
			0 986 280 216
Phase sensor	05.01-05.05		**0 232 101 031**
Speed sensor, ignition/injection	05.01-05.05		**0 261 210 199**
Knock sensor	05.01-05.05		**0 261 231 146**
Accelerator pedal module	05.01-05.05	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
2.0 4 Motion [1J6]			**2,0 l 85 kW AZH 4 Zyl.**
Throttle valve assembly	04.00-06.01		**0 280 750 061**
Air mass meter, gasoline injection	04.00-06.01		**0 280 218 002**
			0 986 280 205
Speed sensor, ignition/injection	04.00-06.01		**0 261 210 147**
Knock sensor	04.00-06.01		**0 261 231 146**
Accelerator pedal module	04.00-06.01	AG,RLE	**0 280 752 213**
	05.01-06.01	GS,LLE	**0 280 752 214**
	04.00-06.01	GS,RLE	**0 280 752 210**
2.0 4 Motion [1J6]			**2,0 l 85 kW AZJ 4 Zyl.**
Throttle valve assembly	05.01-05.05		**0 280 750 059**
Air mass meter, gasoline injection	05.01-05.05		**0 280 218 060**
			0 986 280 216
Phase sensor	05.01-05.05		**0 232 101 031**
Speed sensor, ignition/injection	05.01-05.05		**0 261 210 199**
Knock sensor	05.01-05.05		**0 261 231 146**
Accelerator pedal module	05.01-05.05	AG,RLE	**0 280 752 213**
		GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
2.3 [1J6]			**2,3 l 110 kW AGZ 5 Zyl.**
Air mass meter, gasoline injection	05.99-02.01		**0 280 217 529**
			0 986 280 204
Phase sensor	05.99-02.01		**0 232 103 019**
Speed sensor, ignition/injection	05.99-02.01		**0 261 210 177**
Knock sensor	05.99-02.01		**0 261 231 146**
Temperature sensor, intake air, injection system	05.99-02.01		**0 280 130 085**
Accelerator pedal module	05.99-02.01	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
2.3 [1J6]			**2,3 l 125 kW AQN 5 Zyl.**
Throttle valve assembly	09.00-05.05		**0 280 750 097**
Air mass meter, gasoline injection	09.00-05.05		**0 280 218 017**
			0 986 280 208
Phase sensor	09.00-05.05		**0 232 103 019**
Knock sensor	09.00-05.05	OHL	**0 261 231 146**
Accelerator pedal module	09.00-05.05	AG,RLE	**0 280 752 213**
	05.01-05.05	GS,LLE	**0 280 752 214**
	09.00-05.05	GS,RLE	**0 280 752 210**
2.3 4 Motion [1J6]			**2,3 l 110 kW AGZ 5 Zyl.**
Air mass meter, gasoline injection	05.00-02.01		**0 280 217 529**
			0 986 280 204
Phase sensor	05.00-02.01		**0 232 103 019**
Speed sensor, ignition/injection	05.00-02.01		**0 261 210 177**
Knock sensor	05.00-02.01		**0 261 231 146**
Temperature sensor, intake air, injection system	05.00-02.01		**0 280 130 085**
Accelerator pedal module	05.00-02.01	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
2.3 4 Motion [1J6]			**2,3 l 125 kW AQN 5 Zyl.**
Throttle valve assembly	09.00-05.05		**0 280 750 097**
Air mass meter, gasoline injection	09.00-05.05		**0 280 218 017**
			0 986 280 208

V

Product			
◀ Bora Variant			
Phase sensor	09.00-05.05		0 232 103 019
Knock sensor	09.00-05.05	OHL	0 261 231 146
Accelerator pedal module	09.00-05.05	AG,RLE	0 280 752 213
	05.01-05.05	GS,LLE	0 280 752 214
	09.00-05.05	GS,RLE	0 280 752 210
2.8 4 Motion [1J6]			**2,8 l 150 kW AQP; AUE 6 Zyl.**
Throttle valve assembly			
Fg.no. →1J..Y..620 000	05.99-01.00	LLE	0 280 750 086
		RLE	0 280 750 097
Fg.no. 1J..Y..620 001→	02.00-04.01		0 280 750 097
Air mass meter, gasoline injection	05.99-04.01		0 280 218 017
			0 986 280 208
Phase sensor	05.99-04.01		0 232 103 019
Knock sensor	05.99-04.01	OHL	0 261 231 146
Accelerator pedal module	05.99-04.01	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
2.8 4 Motion [1J6]			**2,8 l 150 kW BDE 6 Zyl.**
Throttle valve assembly	05.01-05.05		0 280 750 097
Air mass meter, gasoline injection	05.01-05.05		0 280 218 017
			0 986 280 208
Phase sensor	05.01-05.05		0 232 103 019
Knock sensor	05.01-05.05	OHL	0 261 231 146
Accelerator pedal module	05.01-05.05	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210

Bus

1.6 D [24, 25]			**1,6 l 37 kW CS 4 Zyl.**
Wheel speed sensor, front	08.85-07.87		0 265 001 149
Wheel speed sensor, rear	08.85-07.87		0 265 001 151
1.6 D Turbo [24, 25]			**1,6 l 51 kW JX 4 Zyl.**
Wheel speed sensor, front	08.85-07.92		0 265 001 149
Wheel speed sensor, rear	08.85-07.92		0 265 001 151
1.6 D Turbo Syncro [24, 25]			**1,6 l 51 kW JX 4 Zyl.**
Wheel speed sensor, front	03.86-07.92	LAB	0 265 001 196
		RAB	0 265 001 198
Wheel speed sensor, rear	03.86-07.92		0 265 001 149
1.7 D [24, 25]			**1,7 l 42 kW KY 4 Zyl.**
Wheel speed sensor, front	10.86-07.92		0 265 001 149
Wheel speed sensor, rear	10.86-07.92		0 265 001 151
1.9 [24, 25]			**1,9 l 40 kW EY 4 Zyl.**
Wheel speed sensor, rear	08.85-05.88		0 265 001 151
1.9 [24, 25]			**1,9 l 44 kW DF 4 Zyl.**
Wheel speed sensor, front	08.85-07.92		0 265 001 149
Wheel speed sensor, rear	08.85-07.92		0 265 001 151
1.9 [24, 25]			**1,9 l 54 kW SP 4 Zyl.**
Wheel speed sensor, rear	08.86-10.88		0 265 001 151
1.9 [24, 25]			**1,9 l 57 kW DG 4 Zyl.**
Wheel speed sensor, front	08.85-07.92		0 265 001 149
Wheel speed sensor, rear	08.85-07.92		0 265 001 151
1.9 Syncro [24, 25]			**1,9 l 54 kW SP 4 Zyl.**
Wheel speed sensor, front	10.86-10.88	LAB	0 265 001 196
		RAB	0 265 001 198
Wheel speed sensor, rear	10.86-10.88		0 265 001 149
2.1 [24, 25]			**2,1 l 64/68/70 kW MV; SR; SS 4 Zyl.**
Air flow sensor, gasoline injection	08.85-07.92		0 280 202 079
			0 986 280 011
Wheel speed sensor, rear	08.85-07.92		0 265 001 151
2.1 [24, 25]			**2,1 l 82 kW DJ 4 Zyl.**
Air flow sensor, gasoline injection	08.85-07.92		0 280 202 079
			0 986 280 011
Wheel speed sensor, front	08.85-07.92		0 265 001 149
Wheel speed sensor, rear	08.85-07.92		0 265 001 151
2.1 Syncro [24, 25]			**2,1 l 64 kW SR 4 Zyl.**
Wheel speed sensor, front	10.86-07.92	LAB	0 265 001 196
		RAB	0 265 001 198
Wheel speed sensor, rear	10.86-07.92		0 265 001 149
2.1 Syncro [24, 25]			**2,1 l 70/82 kW DJ; MV 4 Zyl.**
Air flow sensor, gasoline injection	08.85-07.92		0 280 202 079
			0 986 280 011
Wheel speed sensor, front	08.85-07.92	LAB	0 265 001 196
		RAB	0 265 001 198
Wheel speed sensor, rear	08.85-07.92		0 265 001 149

Caddy

1.4 [2KA,2KB]			**1,4 l 55 kW BCA 4 Zyl.**
Knock sensor	02.04-05.06		0 261 231 146
Pressure sensor, intake manifold, gasoline	02.04-05.06		0 261 230 095
1.4 [9K9]			**1,4 l 44 kW AEX; AKV; APQ 4 Zyl.**
Knock sensor	11.95-06.03	KZA	0 261 231 045
Pressure sensor, intake manifold, gasoline	11.95-06.03		0 261 230 011
1.4 [9K9]			**1,4 l 44 kW AUD 4 Zyl.**
Throttle valve assembly			
Mot.no. AUD 020 028→	06.01-06.03		0 280 750 095
Mot.no. →AUD 020 027	09.00-05.01		0 280 750 049
Speed sensor, ignition/injection	09.00-06.03		0 261 210 188
Knock sensor	09.00-06.03	KZA	0 261 231 045
Pressure sensor, intake manifold, gasoline	09.00-06.03		0 261 230 031
		WW	0 261 230 011
1.4 [9K9]			**1,4 l 55 kW AUA 4 Zyl.**
Knock sensor	09.00-06.03	KZA	0 261 231 045
Pressure sensor, intake manifold, gasoline	09.00-06.03		0 261 230 011
1.6 [2KA,2KB]			**1,6 l 75 kW BGU; BSE; BSF 4 Zyl.**
Speed sensor, ignition/injection	04.04→		0 261 210 199
Knock sensor	04.04→		0 261 231 146
Pressure sensor, intake manifold, gasoline	04.04→		0 261 230 031
1.6 [9K9]			**1,6 l 55 kW AEE 4 Zyl.**
Knock sensor	06.97-09.00	KZA	0 261 231 045
1.7 SDI [9K9]			**1,7 l 42 kW AHB 4 Zyl.**
Pedal position sensor, diesel	07.96-09.00		0 205 001 032
1.9 SDI [9K9]			**1,9 l 47 kW AEY 4 Zyl.**
Pedal position sensor, diesel	11.95-09.00		0 205 001 032
1.9 SDI [9K9]			**1,9 l 47 kW AYQ 4 Zyl.**
Pedal position sensor, diesel	09.00-06.03		0 281 002 269
1.9 TDI [2KA,2KB]			**1,9 l 55/77 kW BJB; BLS; BSU 4 Zyl.**
Air mass meter, diesel	02.04→		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	02.04→		0 281 002 399
1.9 TDI [9K9]			**1,9 l 66 kW AHU; ALE 4 Zyl.**
Pressure sensor, intake manifold, diesel	12.96-09.00		0 261 230 037
Pedal position sensor, diesel	12.96-09.00		0 205 001 032
1.9 TDI [9K9]			**1,9 l 66 kW ALH 4 Zyl.**
Air mass meter, diesel	09.00-06.03		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	09.00-06.03		0 281 002 177
Pedal position sensor, diesel	09.00-06.03		0 281 002 269
1.9 TDI [9K9]			**1,9 l 66 kW 1Z 4 Zyl.**
Pressure sensor, intake manifold, diesel	10.96-03.97		0 261 230 037
Pedal position sensor, diesel	10.96-03.97		0 205 001 032
2.0 Eco Fuel [2KA,2KB]			**2,0 l 80 kW BSX 4 Zyl.**
Phase sensor	04.06→		0 232 101 031
Speed sensor, ignition/injection	04.06→		0 261 210 199

Product			
Knock sensor	04.06→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	04.06→		**0 261 230 095**
2.0 SDI [2KA,2KB]			**2,0 l 51 kW BDJ 4 Zyl.**
Pressure sensor, intake manifold, diesel	02.04→		**0 281 002 399**
2.0 SDI [2KA,2KB]			**2,0 l 51 kW BST 4 Zyl.**
Air mass meter, diesel	06.05→		**0 281 002 531**
			0 986 284 009
Pressure sensor, intake manifold, diesel	06.05→		**0 281 002 399**

Caddy Pickup

1.6 [9U7]			**1,6 l 55 kW AEE 4 Zyl.**
Temperature sensor, coolant, injection system	06.96-12.00		**0 280 130 026**
1.8 [14, 1A]			**1,8 l 70 kW JH 4 Zyl.**
Air flow sensor, gasoline injection	08.85-07.92		**0 438 120 162**
1.9 D [9U7]			**1,9 l 47 kW AEF 4 Zyl.**
Temperature sensor, coolant, diesel	06.96-12.00		**0 280 130 026**

California T4

1.8 [70]			**1,8 l 49 kW PD 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	12.90-07.92		**0 265 005 214**
Wheel speed sensor, front	12.90-07.92		**0 265 006 407**
Wheel speed sensor, rear	12.90-07.92	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
1.9 D [70]			**1,9 l 45 kW 1X 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.90-04.97		**0 265 005 214**
Wheel speed sensor, front	09.90-04.97		**0 265 006 407**
Wheel speed sensor, rear	09.90-04.97	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-04.97	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
1.9 D Turbo [70]			**1,9 l 50 kW ABL 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.92-06.03		**0 265 005 214**
Wheel speed sensor, front	10.92-06.03		**0 265 006 407**
Wheel speed sensor, rear	10.92-06.03	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-06.03	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.0 [70]			**2,0 l 62 kW AAC 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.90-06.03		**0 265 005 214**
Wheel speed sensor, front	09.90-06.03		**0 265 006 407**
Wheel speed sensor, rear	09.90-06.03	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-06.03	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.4 D [70]			**2,4 l 55 kW AJA 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	05.97-06.03		**0 265 005 214**
Wheel speed sensor, front	05.97-06.03		**0 265 006 407**
Wheel speed sensor, rear	05.97-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.4 D [70]			**2,4 l 57 kW AAB 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.90-05.98		**0 265 005 214**
Wheel speed sensor, front	09.90-05.98		**0 265 006 407**
Wheel speed sensor, rear	09.90-05.98	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-05.98	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.4 D Syncro [7D]			**2,4 l 57 kW AAB 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	11.92-09.98		**0 265 005 214**
Wheel speed sensor, front	11.92-09.98		**0 265 006 407**
Wheel speed sensor, rear	11.92-09.98	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-09.98	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.5 [70]			**2,5 l 81 kW AAF 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	11.90-12.93		**0 265 005 214**
Wheel speed sensor, front	11.90-12.93		**0 265 006 407**
Wheel speed sensor, rear	11.90-12.93	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
2.5 [70]			**2,5 l 81 kW ACU 5 Zyl.**
Knock sensor	07.94-10.96	L30	**0 261 231 066**
		L34	**0 261 231 077**
Duo sensor, acceleration and yaw rate, brake system	07.94-10.96		**0 265 005 214**
Wheel speed sensor, front	07.94-10.96		**0 265 006 407**
Wheel speed sensor, rear	07.94-10.96	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-10.96	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.5 [70]			**2,5 l 81 kW AEN 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.95-12.95		**0 265 005 214**
Wheel speed sensor, front	09.95-12.95		**0 265 006 407**
Wheel speed sensor, rear	09.95-12.95	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
2.5 [70]			**2,5 l 81 kW AEU 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	08.96-06.03		**0 265 005 214**
Wheel speed sensor, front	08.96-06.03		**0 265 006 407**
Wheel speed sensor, rear	08.96-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 [70]			**2,5 l 85 kW AET; APL; AVT 5 Zyl.**
Knock sensor	08.96-06.03	L30	**0 261 231 066**
		L34	**0 261 231 077**
Duo sensor, acceleration and yaw rate, brake system	08.96-06.03		**0 265 005 214**
Wheel speed sensor, front	08.96-06.03		**0 265 006 407**
Wheel speed sensor, rear	08.96-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 Syncro [7D]			**2,5 l 81 kW AAF 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	11.92-12.93		**0 265 005 214**
Wheel speed sensor, front	11.92-12.93		**0 265 006 407**
Wheel speed sensor, rear	11.92-12.93	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
2.5 Syncro [7D]			**2,5 l 81 kW ACU 5 Zyl.**
Knock sensor	01.94-10.96	L30	**0 261 231 066**
		L34	**0 261 231 077**
Duo sensor, acceleration and yaw rate, brake system	01.94-10.96		**0 265 005 214**

V

Product			
◀ California T4			
Wheel speed sensor, front	01.94-10.96		**0 265 006 407**
Wheel speed sensor, rear	01.94-10.96	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-10.96	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.5 Syncro [7D]			**2,5 l 81 kW AEU 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	06.97-11.01		**0 265 005 214**
Wheel speed sensor, front	06.97-11.01		**0 265 006 407**
Wheel speed sensor, rear	06.97-11.01	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 Syncro [7D]			**2,5 l 85 kW AET; APL; AVT 5 Zyl.**
Knock sensor	08.96-06.03	L30	**0 261 231 066**
		L34	**0 261 231 077**
Duo sensor, acceleration and yaw rate, brake system	08.96-06.03		**0 265 005 214**
Wheel speed sensor, front	08.96-06.03		**0 265 006 407**
Wheel speed sensor, rear	08.96-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 65 kW AJT 5 Zyl.**
Air mass meter, diesel			
Fg.no. →70..1H048 284,→70..1X047 893	05.98-08.00		**0 281 002 216**
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	05.98-04.01		**0 281 002 177**
Fg.no. 70..1..200 001→	05.01-06.03		**0 281 002 399**
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	05.98-05.99	GS	**0 205 001 020**
Duo sensor, acceleration and yaw rate, brake system	05.98-06.03		**0 265 005 214**
Wheel speed sensor, front	05.98-06.03		**0 265 006 407**
Wheel speed sensor, rear	05.98-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 65 kW AYY 5 Zyl.**
Air mass meter, diesel	10.01-06.03		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel	10.01-06.03		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	10.01-06.03		**0 265 005 214**
Wheel speed sensor, front	10.01-06.03		**0 265 006 407**
Wheel speed sensor, rear	10.01-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 75 kW ACV 5 Zyl.**
Air mass meter, diesel			
Fg.no. →70..1H048 284,→70..1X047 893	05.98-08.00		**0 281 002 216**
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	01.95-04.01		**0 281 002 177**
Fg.no. 70..1..200 001→	05.01-06.03		**0 281 002 399**
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	01.95-05.99	GS	**0 205 001 020**

Product			
Duo sensor, acceleration and yaw rate, brake system	01.95-06.03		**0 265 005 214**
Wheel speed sensor, front	01.95-06.03		**0 265 006 407**
Wheel speed sensor, rear	01.95-06.03	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-06.03	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 75 kW AUF 5 Zyl.**
Air mass meter, diesel			
Fg.no. →70..1H048 284,→70..1X047 893	05.99-08.00		**0 281 002 216**
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	05.99-04.01		**0 281 002 177**
Fg.no. 70..1..200 001→	05.01-06.03		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	05.99-06.03		**0 265 005 214**
Wheel speed sensor, front	05.99-06.03		**0 265 006 407**
Wheel speed sensor, rear	05.99-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 75 kW AXL 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	04.01-06.03		**0 265 005 214**
Wheel speed sensor, front	04.01-06.03		**0 265 006 407**
Wheel speed sensor, rear	04.01-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 75 kW AYC 5 Zyl.**
Air mass meter, diesel	04.01-06.03		**0 281 002 463**
			0 986 284 008
Duo sensor, acceleration and yaw rate, brake system	04.01-06.03		**0 265 005 214**
Wheel speed sensor, front	04.01-06.03		**0 265 006 407**
Wheel speed sensor, rear	04.01-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 111 kW AHY 5 Zyl.**
Air mass meter, diesel			
Fg.no. →70..1..001 319	05.98-05.00		**0 280 217 529**
			0 986 280 204
Fg.no. 70..1..001 320→	06.00-09.00		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	05.98-09.00		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	05.98-05.99	GS	**0 205 001 020**
Duo sensor, acceleration and yaw rate, brake system	05.98-09.00		**0 265 005 214**
Wheel speed sensor, front	05.98-09.00		**0 265 006 407**
Wheel speed sensor, rear	05.98-09.00	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 111 kW AXG 5 Zyl.**
Air mass meter, diesel	09.00-06.03		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	09.00-04.01		**0 281 002 177**
Fg.no. 70..1..200 001→	05.01-06.03		**0 281 002 399**

Product			
Duo sensor, acceleration and yaw rate, brake system	09.00-06.03		**0 265 005 214**
Wheel speed sensor, front	09.00-06.03		**0 265 006 407**
Wheel speed sensor, rear	09.00-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI Syncro [7D]			**2,5 l 75 kW ACV 5 Zyl.**
Air mass meter, diesel			
Fg.no. →70..1H048 284,→70..1X047 893	05.98-08.00		**0 281 002 216**
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	03.98-04.01		**0 281 002 177**
Fg.no. 70..1..200 001→	05.01-06.03		**0 281 002 399**
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	03.98-05.99	GS	**0 205 001 020**
Duo sensor, acceleration and yaw rate, brake system	03.98-06.03		**0 265 005 214**
Wheel speed sensor, front	03.98-06.03		**0 265 006 407**
Wheel speed sensor, rear	03.98-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI Syncro [7D]			**2,5 l 75 kW AXL 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	04.01-06.03		**0 265 005 214**
Wheel speed sensor, front	04.01-06.03		**0 265 006 407**
Wheel speed sensor, rear	04.01-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.8 [70]			**2,8 l 103 kW AES 6 Zyl.**
Air mass meter, gasoline injection	05.96-05.00		**0 280 217 512**
			0 986 280 203
Phase sensor			
Mot.no. AES 010 241→	12.97-05.00		**0 232 103 019**
Speed sensor, ignition/injection	05.96-05.00		**0 261 210 107**
Temperature sensor, intake air, injection system	05.96-05.00		**0 280 130 039**
Duo sensor, acceleration and yaw rate, brake system	05.96-05.00		**0 265 005 214**
Wheel speed sensor, front	05.96-05.00		**0 265 006 407**
Wheel speed sensor, rear	05.96-05.00	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.8 [70]			**2,8 l 150 kW AMV 6 Zyl.**
Throttle valve assembly	05.00-06.03		**0 280 750 086**
Air mass meter, gasoline injection	05.00-06.03		**0 280 218 017**
			0 986 280 208
Phase sensor	05.00-06.03		**0 232 103 019**
Duo sensor, acceleration and yaw rate, brake system	05.00-06.03		**0 265 005 214**
Wheel speed sensor, front	05.00-06.03		**0 265 006 407**
Wheel speed sensor, rear	05.00-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**

California T5

Product			
1.9 TDI [7H]			**1,9 l 62/63/75/77 kW AXB; AXC; BRR; BRS 4 Zyl.**
Air mass meter, diesel	04.03→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	04.03→		**0 281 002 399**
2.0 [7H]			**2,0 l 85 kW AXA 4 Zyl.**
Throttle valve assembly	06.03→		**0 280 750 167**
Air mass meter, gasoline injection	06.03→		**0 280 218 060**
			0 986 280 216
Phase sensor	06.03→		**0 232 101 031**
Knock sensor	06.03→	OHL	**0 261 231 146**
2.5 TDI [7H]			**2,5 l 96/120/128 kW AXD; AXE; BLJ 5 Zyl.**
Air mass meter, diesel	02.03→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	02.03→		**0 281 002 401**
2.5 TDI 4Motion [7H]			**2,5 l 96/128 kW AXD; AXE 5 Zyl.**
Air mass meter, diesel	07.04→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	07.04→		**0 281 002 401**
3.2 [7H]			**3,2 l 170/173 kW BDL; BKK 6 Zyl.**
Throttle valve assembly	02.03→		**0 280 750 086**
Air mass meter, gasoline injection	02.03→		**0 280 218 073**
			0 986 280 222
Phase sensor	02.03→		**0 232 103 019**
Knock sensor	02.03→	OHL	**0 261 231 146**
3.2 4 Motion [7H]			**3,2 l 173 kW BKK 6 Zyl.**
Throttle valve assembly	07.04→		**0 280 750 086**
Air mass meter, gasoline injection	07.04→		**0 280 218 073**
			0 986 280 222
Phase sensor	07.04→		**0 232 103 019**
Knock sensor	07.04→	OHL	**0 261 231 146**

Caravelle T4

Product			
1.8 [70]			**1,8 l 49 kW PD 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	12.90-07.92		**0 265 005 214**
Wheel speed sensor, front	12.90-07.92		**0 265 006 407**
Wheel speed sensor, rear	12.90-07.92	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
1.9 D [70]			**1,9 l 45 kW 1X 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.90-04.97		**0 265 005 214**
Wheel speed sensor, front	10.90-04.97		**0 265 006 407**
Wheel speed sensor, rear	10.90-04.97	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-04.97	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
1.9 D Turbo [70]			**1,9 l 50 kW ABL 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.92-06.03		**0 265 005 214**
Wheel speed sensor, front	10.92-06.03		**0 265 006 407**
Wheel speed sensor, rear	10.92-06.03	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-06.03	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.0 [70]			**2,0 l 62 kW AAC 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.90-06.03		**0 265 005 214**
Wheel speed sensor, front	09.90-06.03		**0 265 006 407**

V

Product			
◀ Caravelle T4			
Wheel speed sensor, rear	09.90-06.03	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-06.03	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.4 D [70]			**2,4 l 55 kW AJA 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	05.97-06.03		**0 265 005 214**
Wheel speed sensor, front	05.97-06.03		**0 265 006 407**
Wheel speed sensor, rear	05.97-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.4 D [70]			**2,4 l 57 kW AAB 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.90-05.98		**0 265 005 214**
Wheel speed sensor, front	09.90-05.98		**0 265 006 407**
Wheel speed sensor, rear	09.90-05.98	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-05.98	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.4 D Syncro [7D]			**2,4 l 57 kW AAB 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	11.92-09.98		**0 265 005 214**
Wheel speed sensor, front	11.92-09.98		**0 265 006 407**
Wheel speed sensor, rear	11.92-09.98	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-09.98	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.5 [70]			**2,5 l 81 kW AAF 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	11.90-12.93		**0 265 005 214**
Wheel speed sensor, front	11.90-12.93		**0 265 006 407**
Wheel speed sensor, rear	11.90-12.93	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
2.5 [70]			**2,5 l 81 kW ACU 5 Zyl.**
Knock sensor	07.94-10.96	L30	**0 261 231 066**
		L34	**0 261 231 077**
Duo sensor, acceleration and yaw rate, brake system	07.94-10.96		**0 265 005 214**
Wheel speed sensor, front	07.94-10.96		**0 265 006 407**
Wheel speed sensor, rear	07.94-10.96	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-10.96	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.5 [70]			**2,5 l 81 kW AEN 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.95-12.95		**0 265 005 214**
Wheel speed sensor, front	09.95-12.95		**0 265 006 407**
Wheel speed sensor, rear	09.95-12.95	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
2.5 [70]			**2,5 l 81 kW AEU 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	08.96-06.03		**0 265 005 214**
Wheel speed sensor, front	08.96-06.03		**0 265 006 407**
Wheel speed sensor, rear	08.96-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 [70]			**2,5 l 85 kW AET; APL; AVT 5 Zyl.**
Knock sensor	08.96-06.03	L30	**0 261 231 066**
		L34	**0 261 231 077**
Duo sensor, acceleration and yaw rate, brake system	08.96-06.03		**0 265 005 214**

Product			
Wheel speed sensor, front	08.96-06.03		**0 265 006 407**
Wheel speed sensor, rear	08.96-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 Syncro [7D]			**2,5 l 81 kW AAF 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	11.92-12.93		**0 265 005 214**
Wheel speed sensor, front	11.92-12.93		**0 265 006 407**
Wheel speed sensor, rear	11.92-12.93	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
2.5 Syncro [7D]			**2,5 l 81 kW ACU 5 Zyl.**
Knock sensor	01.94-10.96	L30	**0 261 231 066**
		L34	**0 261 231 077**
Duo sensor, acceleration and yaw rate, brake system	01.94-10.96		**0 265 005 214**
Wheel speed sensor, front	01.94-10.96		**0 265 006 407**
Wheel speed sensor, rear	01.94-10.96	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-10.96	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.5 Syncro [7D]			**2,5 l 81 kW AEU 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	06.97-11.01		**0 265 005 214**
Wheel speed sensor, front	06.97-11.01		**0 265 006 407**
Wheel speed sensor, rear	06.97-11.01	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 Syncro [7D]			**2,5 l 85 kW AET; APL; AVT 5 Zyl.**
Knock sensor	08.96-06.03	L30	**0 261 231 066**
		L34	**0 261 231 077**
Duo sensor, acceleration and yaw rate, brake system	08.96-06.03		**0 265 005 214**
Wheel speed sensor, front	08.96-06.03		**0 265 006 407**
Wheel speed sensor, rear	08.96-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 65 kW AJT 5 Zyl.**
Air mass meter, diesel			
Fg.no. →70..1H048 284,→70..1X047 893	05.98-08.00		**0 281 002 216**
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	05.98-04.01		**0 281 002 177**
Fg.no. 70..1..200 001→	05.01-06.03		**0 281 002 399**
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	05.98-05.99	GS	**0 205 001 020**
Duo sensor, acceleration and yaw rate, brake system	05.98-06.03		**0 265 005 214**
Wheel speed sensor, front	05.98-06.03		**0 265 006 407**
Wheel speed sensor, rear	05.98-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 65 kW AYY 5 Zyl.**
Air mass meter, diesel	10.01-06.03		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel	10.01-06.03		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	10.01-06.03		**0 265 005 214**

Product			
Wheel speed sensor, front	10.01-06.03		**0 265 006 407**
Wheel speed sensor, rear	10.01-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 75 kW ACV 5 Zyl.**
Air mass meter, diesel			
Fg.no. →70..1H048 284,→70..1X047 893	05.98-08.00		**0 281 002 216**
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	01.95-04.01		**0 281 002 177**
Fg.no. 70..1..200 001→	05.01-06.03		**0 281 002 399**
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	01.95-05.99	GS	**0 205 001 020**
Duo sensor, acceleration and yaw rate, brake system	01.95-06.03		**0 265 005 214**
Wheel speed sensor, front	01.95-06.03		**0 265 006 407**
Wheel speed sensor, rear	01.95-06.03	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-06.03	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 75 kW AUF 0 Zyl.**
Air mass meter, diesel			
Fg.no. →70..1H048 284,→70..1X047 893	05.99-08.00		**0 281 002 216**
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	05.99-04.01		**0 281 002 177**
Fg.no. 70..1..200 001→	05.01-06.03		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	05.99-06.03		**0 265 005 214**
Wheel speed sensor, front	05.99-06.03		**0 265 006 407**
Wheel speed sensor, rear	05.99-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 75 kW AXL 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	04.01-06.03		**0 265 005 214**
Wheel speed sensor, front	04.01-06.03		**0 265 006 407**
Wheel speed sensor, rear	04.01-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 75 kW AYC 5 Zyl.**
Air mass meter, diesel	04.01-06.03		**0 281 002 463**
			0 986 284 008
Duo sensor, acceleration and yaw rate, brake system	04.01-06.03		**0 265 005 214**
Wheel speed sensor, front	04.01-06.03		**0 265 006 407**
Wheel speed sensor, rear	04.01-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 111 kW AHY 5 Zyl.**
Air mass meter, diesel			
Fg.no. →70..1..001 319	05.98-05.00		**0 280 217 529**
			0 986 280 204
Fg.no. 70..1..001 320→	06.00-09.00		**0 281 002 461**
			0 986 284 007

Product			
Boost pressure sensor, Diesel	05.98-09.00		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	05.98-05.99	GS	**0 205 001 020**
Duo sensor, acceleration and yaw rate, brake system	05.98-09.00		**0 265 005 214**
Wheel speed sensor, front	05.98-09.00		**0 265 006 407**
Wheel speed sensor, rear	05.98-09.00	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 111 kW AXG 5 Zyl.**
Air mass meter, diesel	09.00-06.03		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	09.00-04.01		**0 281 002 177**
Fg.no. 70..1..200 001→	05.01-06.03		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	09.00-06.03		**0 265 005 214**
Wheel speed sensor, front	09.00-06.03		**0 265 006 407**
Wheel speed sensor, rear	09.00-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI Syncro [7D]			**2,5 l 75 kW ACV 5 Zyl.**
Air mass meter, diesel			
Fg.no. →70..1H048 284,→70..1X047 893	05.98-08.00		**0 281 002 216**
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	03.98-04.01		**0 281 002 177**
Fg.no. 70..1..200 001→	05.01-06.03		**0 281 002 399**
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	03.98-05.99	GS	**0 205 001 020**
Duo sensor, acceleration and yaw rate, brake system	03.98-06.03		**0 265 005 214**
Wheel speed sensor, front	03.98-06.03		**0 265 006 407**
Wheel speed sensor, rear	03.98-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI Syncro [7D]			**2,5 l 75 kW AXL 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	04.01-06.03		**0 265 005 214**
Wheel speed sensor, front	04.01-06.03		**0 265 006 407**
Wheel speed sensor, rear	04.01-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.8 [70]			**2,8 l 103 kW AES 6 Zyl.**
Air mass meter, gasoline injection	01.96-05.00		**0 280 217 512**
			0 986 280 203
Phase sensor			
Mot.no. AES 010 241→	12.97-05.00		**0 232 103 019**
Speed sensor, ignition/injection	01.96-05.00		**0 261 210 107**
Temperature sensor, intake air, injection system	01.96-05.00		**0 280 130 039**
Duo sensor, acceleration and yaw rate, brake system	01.96-05.00		**0 265 005 214**
Wheel speed sensor, front	01.96-05.00		**0 265 006 407**
Wheel speed sensor, rear	01.96-05.00	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**

V

Product			

◀ Caravelle T4

2.8 [70]			**2,8 l 150 kW AMV 6 Zyl.**
Throttle valve assembly	05.00-06.03		**0 280 750 086**
Air mass meter, gasoline injection	05.00-06.03		**0 280 218 017**
			0 986 280 208
Phase sensor	05.00-06.03		**0 232 103 019**
Duo sensor, acceleration and yaw rate, brake system	05.00-06.03		**0 265 005 214**
Wheel speed sensor, front	05.00-06.03		**0 265 006 407**
Wheel speed sensor, rear	05.00-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**

Caravelle T5

1.9 TDI [7H]			**1,9 l 62/63/75/77 kW AXB; AXC; BRR; BRS 4 Zyl.**
Air mass meter, diesel	04.03→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	04.03→		**0 281 002 399**
2.0 [7H]			**2,0 l 85 kW AXA 4 Zyl.**
Throttle valve assembly	06.03→		**0 280 750 167**
Air mass meter, gasoline injection	06.03→		**0 280 218 060**
			0 986 280 216
Phase sensor	06.03→		**0 232 101 031**
Knock sensor	06.03→	OHL	**0 261 231 146**
2.5 TDI [7H]			**2,5 l 96/120/128 kW AXD; AXE; BLJ 5 Zyl.**
Air mass meter, diesel	02.03→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	02.03→		**0 281 002 401**
2.5 TDI 4 Motion [7H]			**2,5 l 96/128 kW AXD; AXE 5 Zyl.**
Air mass meter, diesel	07.04→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	07.04→		**0 281 002 401**
3.2 [7H]			**3,2 l 170/173 kW BDL; BKK 6 Zyl.**
Throttle valve assembly	02.03→		**0 280 750 086**
Air mass meter, gasoline injection	02.03→		**0 280 218 073**
			0 986 280 222
Phase sensor	02.03→		**0 232 103 019**
Knock sensor	02.03→	OHL	**0 261 231 146**
3.2 4 Motion [7H]			**3,2 l 173 kW BKK 6 Zyl.**
Throttle valve assembly	07.04→		**0 280 750 086**
Air mass meter, gasoline injection	07.04→		**0 280 218 073**
			0 986 280 222
Phase sensor	07.04→		**0 232 103 019**
Knock sensor	07.04→	OHL	**0 261 231 146**

Corrado

1.8 G60 [50]			**1,8 l 118 kW PG 4 Zyl.**
Knock sensor	09.88-09.93	KZG	**0 261 231 038**
1.8 16V [50]			**1,8 l 98-102 kW KR 4 Zyl.**
Air flow sensor, gasoline injection	09.88-07.92		**F 026 TX2 050**
			F 026 TX2 050
2.0 [50]			**2,0 l 85 kW 2E 4 Zyl.**
Knock sensor	04.93-09.94	KZA	**0 261 231 064**
2.0 16V [50]			**2,0 l 100 kW 9A 4 Zyl.**
Throttle valve sensor	08.91-07.95	AG	**0 280 120 433**
		GS	**0 280 120 426**
Air flow sensor, gasoline injection			
Fg.no. →50-N-035 000	08.91-07.92		**0 438 121 076**
			0 986 439 376

Product			

Air flow sensor, gasoline injection			
Fg.no. 50-P-000 001→	08.91-07.95		**0 986 439 389**
			F 026 TX2 059
			0 986 439 389
Pulse generator, ignition/Jetronic	08.91-07.95		**0 356 914 213**
Temperature sensor, intake air, injection system	08.91-07.95		**0 280 130 040**
2.8 [50]			**2,8 l 128 kW AAA 6 Zyl.**
Air mass meter, gasoline injection			
Fg.no. →50-P-020 000	08.91-07.93		**0 280 213 021**
			0 986 280 122
Fg.no. 50-R-000 001→	07.93-07.95		**0 280 217 504**
Temperature sensor, intake air, injection system	08.91-07.95		**0 280 130 039**
2.9 [50]			**2,9 l 140 kW ABV 6 Zyl.**
Air mass meter, gasoline injection			
Fg.no. →50-P-020 000	08.91-07.93		**0 280 213 021**
			0 986 280 122
Fg.no. 50-R-000 001→	07.93-07.95		**0 280 217 504**
Speed sensor, ignition/injection	08.91-07.95		**0 261 210 080**
Knock sensor	08.91-07.95	KZA	**0 261 231 064**
		KZW	**0 261 231 047**
Temperature sensor, intake air, injection system	08.91-07.95		**0 280 130 039**

Crafter 30

2.5 TDI [2E]			**2,5 l 65/80/100/120 kW BJJ; BJK; BJL; BJM 5 Zyl.**
Boost pressure sensor, Diesel	04.06→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 628**

Crafter 35

2.5 TDI [2E]			**2,5 l 65/80/100/120 kW BJJ; BJK; BJL; BJM 5 Zyl.**
Boost pressure sensor, Diesel	04.06→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 628**

Crafter 50

2.5 TDI [2E]			**2,5 l 80/100/120 kW BJK; BJL; BJM 5 Zyl.**
Boost pressure sensor, Diesel	04.06→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	04.06→		**0 265 005 628**

Eos

1.6 FSI [1F7]			**1,6 l 85 kW BLF 4 Zyl.**
Speed sensor, ignition/injection	05.06→	AG	**0 261 210 250**
Knock sensor	05.06→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.06→		**0 261 230 095**
2.0 FSI [1F7]			**2,0 l 110 kW BVY; BVZ 4 Zyl.**
Knock sensor	05.06→	OHL	**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.06→		**0 261 230 031**
2.0 TDI [1F7]			**2,0 l 103 kW BMM 4 Zyl.**
Air mass meter, diesel	05.06→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	05.06→		**0 281 002 401**
2.0 TFSI [1F7]			**2,0 l 147 kW BWA 4 Zyl.**
Boost pressure sensor, gasoline	05.06→		**0 261 230 073**
3.2 [1F7]			**3,2 l 184 kW BUB 6 Zyl.**
Air mass meter, gasoline injection	05.06→		**0 280 218 073**
			0 986 280 222
Phase sensor	05.06→		**0 232 103 019**
Knock sensor	05.06→	OHL	**0 261 231 146**

Product

Eurovan

2.5 [70]			**2,5 l 81 kW AAF 5 Zyl.**
Wheel speed sensor, front			
Fg.no. →70-H-199 999	09.91-12.93		**0 265 006 407**
2.5 [70]			**2,5 l 81 kW ACU 5 Zyl.**
Knock sensor	01.94-05.96	KZA	**0 261 231 077**
		KZS	**0 261 231 066**
Wheel speed sensor, front			
Fg.no. →70-H-199 999	01.94-12.95		**0 265 006 407**
2.8 [70]			**2,8 l 103 kW AES 6 Zyl.**
Speed sensor, ignition/injection	05.96-05.00		**0 261 210 107**
Temperature sensor, intake air, injection system	05.96-05.00		**0 280 130 039**
Wheel speed sensor, rear			
Fg.no. 70-T-200 001→	05.96-05.00	OVA,RAB	**0 265 006 409**

Fox

1.2 [5Z1]			**1,2 l 40 kW BMD 3 Zyl.**
Knock sensor	04.05→		**0 261 231 146**
Accelerator pedal module			
Fg.no. →5Z..70030 000,→5Z..74051 000	04.05-03.07	LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 601**
1.4 [5Z1]			**1,4 l 55 kW BKR 4 Zyl.**
Knock sensor	04.05→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	04.05→		**0 261 230 095**
Accelerator pedal module			
Fg.no. →5Z..70030 000,→5Z..74051 000	04.05-03.07	LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 601**
1.4 TDI [5Z1]			**1,4 l 51 kW BNM 3 Zyl.**
Air mass meter, diesel	04.05→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	04.05→		**0 281 002 177**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 601**

Gol II

1.0 Mi 16V			**1,0 l 51 kW AZP 4 Zyl.**
Knock sensor	09.97-04.99		**0 261 231 122**
2.0 Mi 16V GTI			**2,0 l 107 kW AJE 4 Zyl.**
Knock sensor	10.95-07.98		**0 261 231 075**
	10.95-07.00	KZA	**0 261 231 077**
Temperature sensor, coolant, injection system	10.95-07.00		**0 280 130 040**

Gol III

1.0 Mi			**1,0 l 40 kW AZN 4 Zyl.**
Knock sensor	05.99-07.01		**0 261 231 066**
Pressure sensor, intake manifold, gasoline	05.99-01.01		**0 261 230 011**
	02.01-07.01		**0 261 230 031**
1.0 Mi			**1,0 l 48 kW AZN 4 Zyl.**
Speed sensor, ignition/injection	08.01-01.02		**0 261 210 207**
Knock sensor	08.01-02.05		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	08.01-05.02		**0 261 230 031**
	06.02-02.05		**0 261 230 095**

Product

Golf

1.8 [1G1]			**1,8 l 79 kW PF 4 Zyl.**
Air flow sensor, gasoline injection	12.88-12.91		**0 280 202 106**
			0 986 280 008
Knock sensor	12.88-12.91	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
1.8 [19]			**1,8 l 63 kW GX 4 Zyl.**
Air flow sensor, gasoline injection	08.84-07.87		**0 438 120 162**
1.8 [19]			**1,8 l 74-77 kW HT, RD 4 Zyl.**
Air flow sensor, gasoline injection	11.84-12.86		**F 026 TX2 063**
			F 026 TX2 063
Knock sensor	11.84-12.86		**0 261 231 002**
Temperature sensor, coolant, injection system	11.84-12.86		**0 280 130 040**
1.8 16V [1G1]			**1,8 l 95 kW PL 4 Zyl.**
Air flow sensor, gasoline injection	12.88-07.89		**F 026 TX2 063**
			F 026 TX2 063
Knock sensor	12.88-07.89	KZG	**0 261 231 038**
Temperature sensor, coolant, injection system	12.88-07.89		**0 280 130 040**
2.0 16V [1G1]			**2,0 l 100 kW 9A 4 Zyl.**
Air flow sensor, gasoline injection	01.90-12.91		**0 438 121 076**
			0 986 439 376
Knock sensor	01.90-12.91	KZB	**0 261 231 036**
Temperature sensor, coolant, injection system	01.90-12.91		**0 280 130 040**

Golf Cabriolet

2.0 [1E, 1V]			**2,0 l 85 kW ABA 4 Zyl.**
Air mass meter, gasoline injection			
Fg.no. →1E..X..899 000	01.96-07.99		**0 280 217 117**
			0 986 280 201
Fg.no. 1V..Y..800 001→	08.99-06.02		**0 280 218 023**
			0 986 280 209
Knock sensor	01.96-06.02		**0 261 231 036**
Temperature sensor, intake air, injection system	01.96-06.02		**0 280 130 039**
2.0 [1E, 1V]			**2,0 l 85 kW ADC 4 Zyl.**
Knock sensor	08.96-09.98		**0 261 231 036**

Golf I

1.6 i [15, 16]			**1,6 l 74 kW AFX 4 Zyl.**
Knock sensor	09.98→	KZA	**0 261 231 077**
Pressure sensor, intake manifold, gasoline	09.98→		**0 261 230 011**
Temperature sensor, intake air, injection system	09.98→		**0 280 130 039**
1.8 [15, 16]			**1,8 l 70 kW HV 4 Zyl.**
Knock sensor	01.88-12.97	KZA	**0 261 231 045**
1.8 i [15, 16]			**1,8 l 82 kW DX 4 Zyl.**
Air flow sensor, gasoline injection	01.83-12.95		**F 026 TX2 051**
			F 026 TX2 051

Golf I Cabriolet

1.8 [15]			**1,8 l 70 kW JH 4 Zyl.**
Air flow sensor, gasoline injection	08.83-08.93		**0 438 120 162**
1.8 [15]			**1,8 l 72 kW 2H 4 Zyl.**
Air flow sensor, gasoline injection	08.89-08.93		**0 280 202 106**
			0 986 280 008
Knock sensor	08.89-04.90	KZG	**0 261 231 014**
	05.90-08.93	KZG	**0 261 231 038**
1.8 [15]			**1,8 l 82 kW DX; KT 4 Zyl.**
Air flow sensor, gasoline injection	01.86-07.92		**F 026 TX2 051**
			F 026 TX2 051

V

Product

Golf II

1.3 [19, 1G]			**1,3 l 40 kW NZ 4 Zyl.**
Air flow sensor, gasoline injection	08.85-07.92		**0 280 200 048**
			0 986 280 030
1.6 [19, 1G]			**1,6 l 51-53 kW EZ, EZA; PN; RF 4 Zyl.**
Temperature sensor, coolant, injection system	08.83-07.92		**0 280 130 040**
1.8 [19, 1G]			**1,8 l 62/66 kW GU; RH 4 Zyl.**
Temperature sensor, coolant, injection system	11.83-10.91		**0 280 130 040**
1.8 [19, 1G]			**1,8 l 66 kW GX 4 Zyl.**
Air flow sensor, gasoline injection	01.84-07.88		**F 026 TX2 063**
			F 026 TX2 063
	08.86-07.88		**0 438 120 162**
Temperature sensor, coolant, injection system	01.84-07.88		**0 280 130 040**
1.8 [19, 1G]			**1,8 l 77/79 kW PF; RV 4 Zyl.**
Air flow sensor, gasoline injection	01.87-11.92		**0 280 202 106**
			0 986 280 008
Knock sensor	08.88-11.92		**0 261 231 036**
	01.87-07.88		**0 261 231 038**
1.8 [19, 1G]			**1,8 l 79 kW RD 4 Zyl.**
Air flow sensor, gasoline injection	08.85-10.87		**F 026 TX2 063**
			F 026 TX2 063
Knock sensor	08.85-10.87		**0 261 231 038**
Temperature sensor, coolant, injection system	08.85-10.87		**0 280 130 040**
1.8 [19, 1G]			**1,8 l 79 kW RG 4 Zyl.**
Air flow sensor, gasoline injection	08.86-07.87		**F 026 TX2 051**
			F 026 TX2 051
1.8 [19, 1G]			**1,8 l 82 kW EV; GZ 4 Zyl.**
Air flow sensor, gasoline injection			
Fg.no. →19..G..640 000	01.84-03.86		**0 438 120 189**
Fg.no. 16..G..640 001→	04.86-07.87	FOB	**F 026 TX2 051**
			F 026 TX2 051
1.8 [19, 1G]			**1,8 l 82 kW PB 4 Zyl.**
Air flow sensor, gasoline injection	01.87-10.91		**0 280 202 106**
			0 986 280 008
Knock sensor	08.88-10.91		**0 261 231 036**
	01.87-07.88		**0 261 231 038**
1.8 [19, 1G]			**1,8 l 95 kW PL 4 Zyl.**
Throttle valve sensor	02.86-10.91		**0 280 120 426**
Air flow sensor, gasoline injection	02.86-10.91		**F 026 TX2 063**
			F 026 TX2 063
Knock sensor	08.88-10.91		**0 261 231 036**
	02.86-07.88		**0 261 231 038**
1.8 [19, 1G]			**1,8 l 102 kW KR 4 Zyl.**
Throttle valve sensor	02.86-10.91		**0 280 120 426**
Air flow sensor, gasoline injection	02.86-10.91		**F 026 TX2 050**
			F 026 TX2 050
1.8 G60 [19, 1G]			**1,8 l 118 kW PG 4 Zyl.**
Knock sensor	04.90-07.91		**0 261 231 036**
1.8 G60 syncro [19, 1G1, 1G4]			**1,8 l 118 kW PG 4 Zyl.**
Knock sensor	01.90-07.91	KZB	**0 261 231 036**
Temperature sensor, coolant, injection system	01.90-07.91		**0 280 130 040**
1.8 G60 syncro [19, 1G1, 1G4]			**1,8 l 118 kW 1H 4 Zyl.**
Knock sensor	04.89-07.89	KZG	**0 261 231 038**
Temperature sensor, coolant, injection system	04.89-12.89		**0 280 130 040**
1.8 i			**1,8 l 82 kW EV 4 Zyl.**
Air flow sensor, gasoline injection			
Fg.no. 19..G..6400.000→	11.84-12.92		**0 438 120 189**
Fg.no. 19..G..6400.001→	11.84-12.92		**F 026 TX2 051**
			F 026 TX2 051
1.8 i			**1,8 l 102 kW KR 16V 4 Zyl.**
Air flow sensor, gasoline injection	09.86-12.90		**F 026 TX2 050**
			F 026 TX2 050

Product

1.8 syncro [19, 1G1, 1G4]			**1,8 l 66 kW GX 4 Zyl.**
Air flow sensor, gasoline injection	02.86-07.88		**F 026 TX2 063**
			F 026 TX2 063
1.8 syncro [19, 1G1, 1G4]			**1,8 l 66-72 kW 1P 4 Zyl.**
Air flow sensor, gasoline injection	08.88-07.91		**0 280 202 106**
			0 986 280 008
Knock sensor	08.88-07.91		**0 261 231 038**
2.0 i			**2,0 l 110 kW AAL 4 Zyl.**
Air flow sensor, gasoline injection	08.89-10.92		**F 026 TX2 050**
			F 026 TX2 050

Golf III

1.4 [1H1]			**1,4 l 40-44 kW AEX 4 Zyl.**
Knock sensor	07.95-12.97	KZA	**0 261 231 045**
Pressure sensor, intake manifold, gasoline	07.95-12.97		**0 261 230 011**
1.6 [1H1]			**1,6 l 55 kW AEE 4 Zyl.**
Knock sensor	07.95-12.97	KZA	**0 261 231 045**
1.6 [1H1]			**1,6 l 74 kW AEK 4 Zyl.**
Air mass meter, gasoline injection	10.94-12.95		**0 280 217 103**
Knock sensor	10.94-12.95	KZB	**0 261 231 036**
Temperature sensor, intake air, injection system	10.94-12.95		**0 280 130 039**
1.6 [1H1]			**1,6 l 74 kW AFT; AKS 4 Zyl.**
Knock sensor	12.95-12.97	KZB	**0 261 231 036**
Temperature sensor, intake air, injection system	12.95-12.97		**0 280 130 039**
1.6 i [1H4]			**1,6 l 74 kW AFX 4 Zyl.**
Pressure sensor, intake manifold, gasoline	11.96-12.99		**0 261 230 011**
1.8 i [1H4]			**1,8 l 82 kW AFV 4 Zyl.**
Pressure sensor, intake manifold, gasoline	11.96-12.99		**0 261 230 011**
1.8 syncro [1H1]			**1,8 l 66 kW ABS 4 Zyl.**
Temperature sensor, coolant, injection system	01.93-09.94		**0 280 130 040**
1.9 SDI [1H1]			**1,9 l 47 kW AEY 4 Zyl.**
Pedal position sensor, diesel	01.95-12.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
1.9 TDI [1H1]			**1,9 l 66 kW AHU; ALE 4 Zyl.**
Pedal position sensor, diesel	08.96-12.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
1.9 TDI [1H1]			**1,9 l 66 kW 1Z 4 Zyl.**
Pressure sensor, intake manifold, diesel			
Fg.no. →1H..SP078 090,→1H..SK009 001	09.93-09.94		**0 261 230 037**
Pedal position sensor, diesel	08.95→	AG	**0 205 001 031**
		GS	**0 205 001 032**
1.9 TDI [1H1]			**1,9 l 81 kW AFN 4 Zyl.**
Pedal position sensor, diesel	03.96-12.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
1.9 TDI syncro [1H1]			**1,9 l 66 kW 1Z 4 Zyl.**
Pedal position sensor, diesel	03.95-07.96	LLE	**0 205 001 024**
		RLE	**0 205 001 023**
2.0 [1H1]			**2,0 l 79 kW AEP 4 Zyl.**
Knock sensor	01.95-12.97	KZA	**0 261 231 077**
2.0 [1H1]			**2,0 l 85 kW ABA 4 Zyl.**
Air mass meter, gasoline injection	01.94-12.97		**0 280 217 103**
Pulse generator, ignition/Jetronic			
Fg.no. →1H-P-999 000	10.92-08.93		**0 261 210 094**
Knock sensor	10.92-10.97	KZB	**0 261 231 036**
Temperature sensor, intake air, injection system	01.94-12.97		**0 280 130 039**
2.0 [1H1]			**2,0 l 85/110 kW ABF; ADY; AGG; 2E 4 Zyl.**
Knock sensor	11.91-12.97	KZA	**0 261 231 077**
2.0 i			**2,0 l 71 kW AEP 4 Zyl.**
Knock sensor	01.95-12.97	KZA	**0 261 231 077**
2.0 i [1H4]			**2,0 l 85 kW AFW 4 Zyl.**
Pressure sensor, intake manifold, gasoline	11.96-12.99		**0 261 230 011**

Product			
2.0 i [1H4]			**2,0 l 85 kW 2E 4 Zyl.**
Knock sensor	11.92-12.96	KZA	**0 261 231 077**
2.0 Mi			**2,0 l 85 kW 4 Zyl.**
Knock sensor	01.94-07.98		**0 261 231 036**
Temperature sensor, intake air, injection system	01.94-07.98		**0 280 130 039**
2.0 syncro [1H1]			**2,0 l 85 kW AGG 4 Zyl.**
Knock sensor	07.95-12.97	KZA	**0 261 231 077**
2.8 [1H1]			**2,8 l 120 kW AAA 6 Zyl.**
Air mass meter, gasoline injection	07.94-05.96		**0 280 217 504**
	06.96-12.97		**0 280 217 512**
			0 986 280 203
Speed sensor, ignition/injection	07.94-12.97		**0 261 210 080**
Knock sensor	07.94-12.97	KZA	**0 261 231 077**
		KZW	**0 261 231 047**
Temperature sensor, intake air, injection system	07.94-12.97		**0 280 130 039**
2.8 [1H1]			**2,8 l 128 kW AAA 6 Zyl.**
Air mass meter, gasoline injection	01.92-06.92		**0 280 213 021**
			0 986 280 122
	08.94-07.95		**0 280 217 504**
	07.92-05.96		**0 280 217 504**
	06.96-12.97		**0 280 217 512**
			0 986 280 203
Fg.no. 1H-T-000 001→	07.95→		**0 280 217 512**
			0 986 280 203
Speed sensor, ignition/injection	01.92→		**0 261 210 080**
Knock sensor	01.92→	KZA	**0 261 231 077**
		KZW	**0 261 231 047**
Temperature sensor, intake air, injection system	01.92→		**0 280 130 039**
2.8 i VR6			**2,8 l 120 kW AAA 6 Zyl.**
Air mass meter, gasoline injection	07.94-05.96		**0 280 217 504**
	06.96-12.97		**0 280 217 512**
			0 986 280 203
Speed sensor, ignition/injection	07.94-12.97		**0 261 210 080**
Knock sensor	07.94-12.97	KZA	**0 261 231 077**
		KZW	**0 261 231 047**
Temperature sensor, intake air, injection system	07.94-12.97		**0 280 130 039**
2.8 i VR6 [1H4]			**2,8 l 128 kW AAA 6 Zyl.**
Air mass meter, gasoline injection	10.93-06.94		**0 280 213 021**
			0 986 280 122
	07.94-05.96		**0 280 217 504**
	06.96-12.99		**0 280 217 512**
			0 986 280 203
Knock sensor	10.93-12.99	KZA	**0 261 231 077**
Temperature sensor, intake air, injection system	10.93-12.99		**0 280 130 039**
2.9 syncro [1H1]			**2,9 l 140 kW ABV 6 Zyl.**
Air mass meter, gasoline injection	01.94-12.97		**0 280 217 504**
Speed sensor, ignition/injection			
Fg.no. →1H-S-990 000	01.94-07.95		**0 261 210 080**
Fg.no. 1H-T-000 001→	07.95-12.97		**0 261 210 107**
Knock sensor	01.94-12.97	KZA	**0 261 231 077**
		KZW	**0 261 231 047**
Temperature sensor, intake air, injection system	01.94-12.97		**0 280 130 039**

Golf III Cabriolet

1.6 [1E7]			**1,6 l 74 kW AEK 4 Zyl.**
Air mass meter, gasoline injection	10.94-12.95		**0 280 217 103**
Temperature sensor, intake air, injection system	10.94-12.95		**0 280 130 039**
1.6 [1E7]			**1,6 l 74 kW AFT; AKS 4 Zyl.**
Temperature sensor, intake air, injection system	12.95-04.98		**0 280 130 039**
1.9 TDI [1E7]			**1,9 l 66 kW AHU; 1Z 4 Zyl.**
Pedal position sensor, diesel	08.95-04.98	AG	**0 205 001 031**
		GS	**0 205 001 032**
1.9 TDI [1E7]			**1,9 l 81 kW AFN 4 Zyl.**
Pedal position sensor, diesel	09.96-04.98		**0 205 001 032**
2.0 [1E7]			**2,0 l 85 kW ADY; AGG; AKR 4 Zyl.**
Knock sensor	10.94-04.98	KZA	**0 261 231 077**
2.0 [1E7]			**2,0 l 85 kW 2E 4 Zyl.**
Pulse generator, ignition/Jetronic	09.93-09.94		**0 356 914 213**
Knock sensor	09.93-09.94	KZA	**0 261 231 077**

Golf III Variant

1.4 [1H5]			**1,4 l 44 kW AEX; APQ 4 Zyl.**
Knock sensor	07.95-02.99		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	07.95-02.99		**0 261 230 011**
1.6 [1H5]			**1,6 l 74 kW AEK 4 Zyl.**
Air mass meter, gasoline injection	10.94-12.95		**0 280 217 103**
Knock sensor	10.94-12.95		**0 261 231 036**
Temperature sensor, intake air, injection system	10.94-12.95		**0 280 130 039**
1.6 [1H5]			**1,6 l 74 kW AFT; AKS 4 Zyl.**
Knock sensor	12.95-02.99		**0 261 231 036**
Temperature sensor, intake air, injection system	12.95-02.99		**0 280 130 039**
1.9 SDI [1H5]			**1,9 l 47 kW AEY 4 Zyl.**
Pedal position sensor, diesel	01.95-02.99	AG	**0 205 001 031**
		GS	**0 205 001 032**
1.9 TDI [1H5]			**1,9 l 66 kW AHU; ALE 4 Zyl.**
Pedal position sensor, diesel	08.96-02.99	AG	**0 205 001 031**
		GS	**0 205 001 032**
1.9 TDI [1H5]			**1,9 l 66 kW 1Z 4 Zyl.**
Boost pressure sensor, Diesel	07.93-07.96		**0 261 230 037**
Pedal position sensor, diesel	07.93-06.96	LLE	**0 205 001 024**
		RLE	**0 205 001 023**
1.9 TDI [1H5]			**1,9 l 81 kW AFN 4 Zyl.**
Pedal position sensor, diesel	02.96-02.99	AG	**0 205 001 031**
		GS	**0 205 001 032**
1.9 TDI syncro [1H5]			**1,9 l 66 kW 1Z 4 Zyl.**
Pedal position sensor, diesel	10.94-07.96	LLE	**0 205 001 024**
		RLE	**0 205 001 023**
2.0 [1H5]			**2,0 l 85 kW ADY; AGG; AKR 4 Zyl.**
Knock sensor	10.94-02.99		**0 261 231 077**
2.0 [1H5]			**2,0 l 85 kW 2E 4 Zyl.**
Pulse generator, ignition/Jetronic	07.93-09.94		**0 356 914 213**
Knock sensor	07.93-09.94		**0 261 231 077**
2.0 syncro [1H5]			**2,0 l 85 kW AGG 4 Zyl.**
Knock sensor	07.95-12.97	KZA	**0 261 231 077**
2.9 syncro [1H5]			**2,9 l 140 kW ABV 6 Zyl.**
Air mass meter, gasoline injection			
Fg.no. →1H-S 990 000	07.95-07.95		**0 280 217 504**
Fg.no. 1H-T 000 001→	08.95-12.97		**0 280 217 512**
			0 986 280 203
Speed sensor, ignition/injection	07.95-12.97		**0 261 210 107**
Knock sensor	07.95-12.97	KZA	**0 261 231 077**
		KZW	**0 261 231 047**
Temperature sensor, intake air, injection system	07.95-12.97		**0 280 130 039**

Golf IV

1.4 [1J1]			**1,4 l 55 kW AHW 4 Zyl.**
Knock sensor	10.97-05.04		**0 261 231 045**
		WW	**0 261 231 146**
Accelerator pedal module	05.02-05.04	GS,LLE	**0 280 752 214**
Fg.no. 1J..Y..000 001→	05.99-04.02	AG,RLE	**0 280 752 213**
	05.99-05.04	RLE	**0 280 752 210**

V

Product			
◀ Golf IV			
1.4 [1J1]			**1,4 l 55 kW AKQ 4 Zyl.**
Speed sensor, ignition/injection			
Mot.no. 001 001→001 068	10.97-05.00		**0 261 210 194**
Knock sensor	10.97-05.00		**0 261 231 045**
Accelerator pedal module			
Fg.no. 1J..Y..000 001→	05.99-05.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.4 [1J1]			**1,4 l 55 kW APE; AXP 4 Zyl.**
Knock sensor	05.99-10.01		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.99-10.01		**0 261 230 031**
Accelerator pedal module	05.99-10.01	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.4 [1J1]			**1,4 l 55 kW BCA 4 Zyl.**
Speed sensor, ignition/injection	10.01-05.04		**0 261 210 213**
Knock sensor	10.01-05.04		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	10.01-05.04		**0 261 230 031**
Accelerator pedal module	10.01-04.02	AG,RLE	**0 280 752 213**
	05.02-05.04	GS,LLE	**0 280 752 214**
	10.01-05.04	GS,RLE	**0 280 752 210**
1.6 [1J1]			**1,6 l 74 kW AEH 4 Zyl.**
Phase sensor	01.98-05.04		**0 232 101 031**
Speed sensor, ignition/injection	01.98-05.04		**0 261 210 147**
Accelerator pedal module			
Fg.no. 1J..Y..000 001→	05.99-04.02	AG,RLE	**0 280 752 213**
	05.99-04.01	GS,RLE	**0 280 752 210**
1.6 [1J1]			**1,6 l 74 kW AKL 4 Zyl.**
Phase sensor	10.97-05.04		**0 232 101 031**
Speed sensor, ignition/injection	10.97-05.04		**0 261 210 147**
Accelerator pedal module	05.02-05.04	GS,LLE	**0 280 752 214**
Fg.no. 1J..Y..000 001→	05.99-04.02	AG,RLE	**0 280 752 213**
	05.99-05.04	RLE	**0 280 752 210**
1.6 [1J1]			**1,6 l 74 kW APF 4 Zyl.**
Phase sensor	05.99-08.00		**0 232 101 031**
Speed sensor, ignition/injection	05.99-08.00		**0 261 210 199**
Accelerator pedal module	05.99-08.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.6 [1J1]			**1,6 l 75 kW AVU 4 Zyl.**
Phase sensor	09.00-05.04		**0 232 101 038**
Speed sensor, ignition/injection	09.00-05.04		**0 261 210 199**
Accelerator pedal module	09.00-04.02	AG,RLE	**0 280 752 213**
	05.02-05.04	GS,LLE	**0 280 752 214**
	09.00-05.04	GS,RLE	**0 280 752 210**
1.6 [1J1]			**1,6 l 75 kW BFQ 4 Zyl.**
Speed sensor, ignition/injection	05.02-05.04		**0 261 210 199**
Knock sensor	05.02-05.04		**0 261 231 146**
Accelerator pedal module	05.02-05.04	GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.6 [1J1]			**1,6 l 77 kW ATN; AUS 4 Zyl.**
Speed sensor, ignition/injection	11.99-10.00		**0 261 210 194**
Knock sensor	11.99-10.00		**0 261 231 045**
Temperature sensor, intake air, injection system	11.99-10.00		**0 280 130 085**
Accelerator pedal module	11.99-10.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.6 [1J1]			**1,6 l 77 kW AZD 4 Zyl.**
Speed sensor, ignition/injection	09.00-04.01		**0 261 210 194**
Knock sensor	09.00-11.01		**0 261 231 146**
Temperature sensor, intake air, injection system	09.00-11.01		**0 280 130 085**
Accelerator pedal module	09.00-11.01	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**

Product			
1.6 [1J1]			**1,6 l 77 kW BCB 4 Zyl.**
Knock sensor	11.01-05.04		**0 261 231 146**
Accelerator pedal module	11.01-04.02	AG,RLE	**0 280 752 213**
	05.02-05.04	GS,LLE	**0 280 752 214**
	11.01-05.04	GS,RLE	**0 280 752 210**
1.6 [9B1]			**1,6 l 74 kW AKL 4 Zyl.**
Speed sensor, ignition/injection	08.99-06.01		**0 261 210 147**
1.6 [9B1]			**1,6 l 74 kW BAH 4 Zyl.**
Speed sensor, ignition/injection	02.01-09.02		**0 261 210 188**
Knock sensor	02.01-03.07		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	02.01-03.07		**0 261 230 095**
Boost pressure sensor, Diesel	02.01-03.07		**0 261 230 095**
1.6 FSI [1J1]			**1,6 l 81 kW BAD 4 Zyl.**
Throttle valve assembly	08.01-05.04		**0 280 750 059**
Air mass meter, gasoline injection	08.01-05.04		**0 280 218 060**
			0 986 280 216
Knock sensor	08.01-05.04		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	08.01-05.04		**0 261 230 079**
Accelerator pedal module	08.01-04.02	AG,RLE	**0 280 752 213**
	05.02-05.04	GS,LLE	**0 280 752 214**
	08.01-05.04	GS,RLE	**0 280 752 210**
1.6 i			**1,6 l 75 kW BFQ 4 Zyl.**
Speed sensor, ignition/injection	07.03-02.07		**0 261 210 199**
Knock sensor	07.03-02.07		**0 261 231 146**
1.6 i			**1,6 l 78 kW AWB 4 Zyl.**
Air mass meter, gasoline injection	07.03→		**0 280 218 060**
			0 986 280 216
Speed sensor, ignition/injection	07.03→		**0 261 210 254**
1.6 i [1J1]			**1,6 l 74 kW AEH; AKL 4 Zyl.**
Speed sensor, ignition/injection	10.97-12.05	AG5,GS	**0 261 210 147**
Accelerator pedal module	04.99-12.05	AG,RLE	**0 280 752 213**
Fg.no. 1J-Y-000 001→	05.99-12.05	GS,RLE	**0 280 752 210**
1.8 [1J1]			**1,8 l 92 kW AGN 4 Zyl.**
Air mass meter, gasoline injection	10.97-10.00		**0 280 218 002**
			0 986 280 205
Phase sensor	10.97-10.00		**0 232 101 024**
Speed sensor, ignition/injection	10.97-10.00		**0 261 210 147**
Temperature sensor, intake air, injection system	10.97-10.00		**0 280 130 085**
Accelerator pedal module			
Fg.no. 1J..Y..000 001→	05.99-10.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.8 GTI Turbo [9B1]			**1,8 l 110 kW AGU 4 Zyl.**
Air mass meter, gasoline injection	08.99-06.02		**0 280 217 117**
			0 986 280 201
Speed sensor, ignition/injection	08.99-06.01		**0 261 210 147**
	07.01-06.02		**0 261 210 199**
Boost pressure sensor, gasoline	08.99-06.02		**0 281 002 177**
Temperature sensor, intake air, injection system	08.99-06.02		**0 280 130 085**
1.8 GTI Turbo [9B1]			**1,8 l 132 kW AUQ 4 Zyl.**
Throttle valve assembly	07.02-03.07		**0 280 750 036**
Air mass meter, gasoline injection	07.02-03.07		**0 280 218 063**
			0 986 280 217
Speed sensor, ignition/injection	07.02-03.07		**0 261 210 199**
Knock sensor	07.02-03.07		**0 261 231 146**
Boost pressure sensor, gasoline	07.02-03.07		**0 281 002 177**
Temperature sensor, intake air, injection system	07.02-03.07		**0 280 130 085**
1.8 i			**1,8 l 92 kW BAF 4 Zyl.**
Throttle valve assembly	07.03→		**0 280 750 159**
Phase sensor	07.03→		**0 232 101 024**
Speed sensor, ignition/injection	07.03→		**0 261 210 147**

V

Product			
1.8 i [1J1]			**1,8 l 92 kW AGN 4 Zyl.**
Air mass meter, gasoline injection	02.99-08.00		**0 280 218 002**
			0 986 280 205
Speed sensor, ignition/injection	02.99-08.00	AG5,GS	**0 261 210 147**
Accelerator pedal module	04.99-08.00	AG,RLE	**0 280 752 213**
Fg.no. 1J-Y-000 001→	05.99-08.00	GS,RLE	**0 280 752 210**
1.8 T [1J1]			**1,8 l 110 kW AGU 4 Zyl.**
Air mass meter, gasoline injection	10.97-12.05		**0 280 217 117**
			0 986 280 201
Phase sensor	10.97-05.03		**0 232 101 024**
Speed sensor, ignition/injection	10.97-05.03		**0 261 210 147**
	02.99-12.05	AG5,GS	**0 261 210 147**
		TW	**0 261 210 199**
	10.97-05.03	WW	**0 261 210 199**
Boost pressure sensor, gasoline	10.97-05.03		**0 281 002 177**
Temperature sensor, intake air, injection system	02.99-12.05		**0 280 130 085**
Fg.no. →1J..3B065 915,→1J..3D013 548, →1J..3P064 809,→1J..3U201 122, →1J..3W335 000	10.97-09.02		**0 280 130 085**
Fg.no. 1J..3B065 916→,1J..3D013 549→, 1J..3P064 810→,1J..3U201 123→, 1J..3W335 001→	10.02-05.03		**0 280 130 116**
Accelerator pedal module	04.99-12.05	AG,RLE	**0 280 752 213**
	05.02-05.03	GS,LLE	**0 280 752 214**
Fg.no. 1J..Y..000 001→	05.99-04.02	AG,RLE	**0 280 752 213**
	05.99-05.03	RLE	**0 280 752 210**
Fg.no. 1J-Y-000 001→	05.99-12.05	GS,RLE	**0 280 752 210**
1.8 T [1J1]			**1,8 l 110 kW ARZ 4 Zyl.**
Throttle valve assembly	05.99-09.00		**0 280 750 036**
Air mass meter, gasoline injection	05.99-09.00		**0 280 218 032**
			0 986 280 210
Speed sensor, ignition/injection	05.99-09.00		**0 261 210 147**
Boost pressure sensor, gasoline	05.99-09.00		**0 281 002 177**
Temperature sensor, intake air, injection system	05.99-09.00		**0 280 130 085**
Accelerator pedal module	05.99-09.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.8 T [1J1]			**1,8 l 110 kW AUM 4 Zyl.**
Throttle valve assembly	09.00-05.03		**0 280 750 036**
Air mass meter, gasoline injection	09.00-05.03		**0 280 218 063**
			0 986 280 217
Phase sensor	09.00-05.03		**0 232 101 024**
Speed sensor, ignition/injection	09.00-05.03		**0 261 210 199**
Knock sensor	09.00-05.03		**0 261 231 146**
Boost pressure sensor, gasoline	09.00-05.03		**0 281 002 177**
Temperature sensor, intake air, injection system			
Fg.no. →1J..3B065 915,→1J..3D013 548, →1J..3P064 809,→1J..3U201 122, →1J..3W335 000	09.00-09.02		**0 280 130 085**
Fg.no. 1J..3B065 916→,1J..3D013 549→, 1J..3P064 810→,1J..3U201 123→, 1J..3W335 001→	10.02-05.03		**0 280 130 116**
Accelerator pedal module	09.00-04.02	AG,RLE	**0 280 752 213**
	05.02-05.03	GS,LLE	**0 280 752 214**
	09.00-05.03	GS,RLE	**0 280 752 210**
1.8 T [1J1]			**1,8 l 132 kW AUQ 4 Zyl.**
Throttle valve assembly	06.01-05.04		**0 280 750 036**
Air mass meter, gasoline injection	06.01-12.05		**0 280 218 063**
			0 986 280 217
Phase sensor	06.01-05.04		**0 232 101 024**
Speed sensor, ignition/injection	06.01-05.04		**0 261 210 199**
	05.03-12.05	TW	**0 261 210 199**
Knock sensor	06.01-12.05		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.03-12.05		**0 280 101 001**

Product			
Boost pressure sensor, gasoline	06.01-05.04		**0 281 002 177**
Temperature sensor, intake air, injection system			
Fg.no. →1J..3B065 915,→1J..3D013 548, →1J..3P064 809,→1J..3U201 122, →1J..3W335 000	06.01-09.02		**0 280 130 085**
Fg.no. 1J..3B065 916→,1J..3D013 549→, 1J..3P064 810→,1J..3U201 123→, 1J..3W335 001→	10.02-05.04		**0 280 130 116**
Accelerator pedal module	06.01-04.02	AG,RLE	**0 280 752 213**
	05.02-05.04	GS,LLE	**0 280 752 214**
	06.01-05.04	GS,RLE	**0 280 752 210**
1.8 4 Motion [1J1]			**1,8 l 92 kW AGN 4 Zyl.**
Air mass meter, gasoline injection	07.98-10.00		**0 280 218 002**
			0 986 280 205
Phase sensor	07.98-10.00		**0 232 101 024**
Speed sensor, ignition/injection	07.98-10.00		**0 261 210 147**
Temperature sensor, intake air, injection system	07.98-10.00		**0 280 130 085**
Accelerator pedal module			
Fg.no. 1J..Y..000 001→	05.99-10.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.9 SDI [1J1]			**1,9 l 50 kW AGP 4 Zyl.**
Pedal position sensor, diesel			
Fg.no. →1J..XB044 157,→1J..XD091 223, →1J..XP072 544,→1J..XW180 709	10.97-07.98	GS,LLE	**0 281 002 269**
1.9 TDI [1J1]			**1,9 l 66 kW AGR 4 Zyl.**
Air mass meter, diesel			
Fg.no. 1J..XB045 001→,1J..XD092 001→,	08.98-09.02		**0 281 002 757**
1J..XP073 001→,1J..XW181 001→	10.97-07.98	WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel	10.97-09.02		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. →1J..XB044 157,→1J..XD091 223, →1J..XP072 544,→1J..XW180 709	10.97-07.98	GS,LLE	**0 281 002 269**
1.9 TDI [1J1]			**1,9 l 66 kW ALH 4 Zyl.**
Air mass meter, diesel	10.97-05.04		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel			
Fg.no. →1J..3W385 000,→1J..3P278 330, →1J..3D390 630,→1J..3B139 990, →1J..3U346 620	10.97-11.02		**0 281 002 177**
Fg.no. 1J..3W385 001→,1J..3P278 331→, 1J..3D390 631→,1J..3B139 991→, 1J..3U346 621→	12.02-05.04		**0 281 002 399**
Pedal position sensor, diesel			
Fg.no. →1J..XB044 157,→1J..XD091 223, →1J..XP072 544,→1J..XW180 709	10.97-07.98	GS,LLE	**0 281 002 269**
1.9 TDI [1J1]			**1,9 l 74 kW ATD 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1J..2B088 000,→1J..2D420 000, →1J..2P055 000,→1J..2U030 000, →1J..2W350 000	02.00-11.01		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 1J..2B088 001→,1J..2D420 001→, 1J..2P055 001→,1J..2U030 001→, 1J..2W350 001→	12.01-05.04		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1J..3W385 000,→1J..3P278 330, →1J..3D390 630,→1J..3B139 990, →1J..3U346 620	02.00-11.02		**0 281 002 177**
Fg.no. 1J..3W385 001→,1J..3P278 331→, 1J..3D390 631→,1J..3B139 991→, 1J..3U346 621→	12.02-05.04		**0 281 002 399**

V

Product

◀ Golf IV

1.9 TDI [1J1]			**1,9 l 74 kW AXR 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1J..2B088 000,→1J..2D420 000, →1J..2P055 000,→1J..2U030 000, →1J..2W350 000	05.01-11.01		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 1J..2B088 001→,1J..2D420 001→, 1J..2P055 001→,1J..2U030 001→, 1J..2W350 001→	12.01-05.04		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	05.01-05.04		**0 281 002 399**
1.9 TDI [1J1]			**1,9 l 81 kW AHF 4 Zyl.**
Air mass meter, diesel	05.00-12.05		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 1J..XB045 001→,1J..XD092 001→, 1J..XP073 001→,1J..XW181 001→	08.98-05.04		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel	05.00-12.05		**0 281 002 177**
Fg.no. →1J..3W385 000,→1J..3P278 330, →1J..3D390 630,→1J..3B139 990, →1J..3U346 620	10.97-11.02		**0 281 002 177**
Fg.no. 1J..3W385 001→,1J..3P278 331→, 1J..3D390 631→,1J..3B139 991→, 1J..3U346 621→	12.02-05.04		**0 281 002 399**
Pedal position sensor, diesel			
Fg.no. →1J-XB044 157,→1J-XD091 223, →1J-XP072 544	05.00-12.05	GS,LLE	**0 281 002 269**
Fg.no. →1J..XB044 157,→1J..XD091 223, →1J..XP072 544,→1J..XW180 709	10.97-07.98	GS,LLE	**0 281 002 269**
Fg.no. →1J-XW180 709	05.00-12.05	GS,LLE	**0 281 002 269**
1.9 TDI [1J1]			**1,9 l 81 kW ASV 4 Zyl.**
Air mass meter, diesel	05.00-05.04		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel			
Fg.no. →1J..3W385 000,→1J..3P278 330, →1J..3D390 630,→1J..3B139 990, →1J..3U346 620	05.00-11.02		**0 281 002 177**
Fg.no. 1J..3W385 001→,1J..3P278 331→, 1J..3D390 631→,1J..3B139 991→, 1J..3U346 621→	12.02-05.04		**0 281 002 399**
1.9 TDI [1J1]			**1,9 l 85 kW AJM; AUY 4 Zyl.**
Air mass meter, diesel	05.99-07.01		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel	05.99-07.01		**0 281 002 177**
1.9 TDI [1J1]			**1,9 l 96 kW ASZ 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1J..2..600 000	04.01-04.02		**0 280 217 529**
			0 986 280 204
Fg.no. 1J..2..600 001→	05.02-05.04		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	04.01-05.04		**0 281 002 177**
1.9 TDI [1J1]			**1,9 l 110 kW ARL 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1J..2..600 000	09.00-04.02		**0 280 217 529**
			0 986 280 204
Fg.no. 1J..2..600 001→	05.02-05.04		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	09.00-05.04		**0 281 002 177**
		WW	**0 281 002 394**

Product

1.9 TDI [9B1]			**1,9 l 66 kW AGR; ALH 4 Zyl.**
Air mass meter, diesel	07.01-03.07		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
1.9 TDI 4 Motion [1J1]			**1,9 l 66 kW AGR 4 Zyl.**
Air mass meter, diesel			
Fg.no. 1J..XB045 001→,1J..XD092 001→, 1J..XP073 001→,1J..XW181 001→	08.98-04.02		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel	07.98-04.02		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. →1J..XB044 157,→1J..XD091 223, →1J..XP072 544,→1J..XW180 709	07.98-07.98	GS,LLE	**0 281 002 269**
1.9 TDI 4 Motion [1J1]			**1,9 l 74 kW ATD 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1J..2B088 000,→1J..2D420 000, →1J..2P055 000,→1J..2U030 000, →1J..2W350 000	02.00-11.01		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 1J..2B088 001→,1J..2D420 001→, 1J..2P055 001→,1J..2U030 001→, 1J..2W350 001→	12.01-06.05		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1J..3W385 000,→1J..3P278 330, →1J..3D390 630,→1J..3B139 990, →1J..3U346 620	02.00-11.02		**0 281 002 177**
Fg.no. 1J..3W385 001→,1J..3P278 331→, 1J..3D390 631→,1J..3B139 991→, 1J..3U346 621→	12.02-06.05		**0 281 002 399**
1.9 TDI 4 Motion [1J1]			**1,9 l 85 kW AJM; AUY 4 Zyl.**
Air mass meter, diesel	05.99-07.01		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel	05.99-07.01		**0 281 002 177**
1.9 TDI 4 Motion [1J1]			**1,9 l 96 kW ASZ 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1J..2..600 000	04.01-04.02		**0 280 217 529**
			0 986 280 204
Fg.no. 1J..2..600 001→	05.02-06.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	04.01-06.05		**0 281 002 177**
1.9 TDI 4 Motion [1J1]			**1,9 l 110 kW ARL 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1J..2..600 000	09.00-04.02		**0 280 217 529**
			0 986 280 204
Fg.no. 1J..2..600 001→	05.02-06.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	09.00-06.05		**0 281 002 177**
		WW	**0 281 002 394**
2.0 [1J1]			**2,0 l 85 kW APK; AQY 4 Zyl.**
Air mass meter, gasoline injection	08.98-05.04		**0 280 218 002**
			0 986 280 205
Phase sensor	08.98-05.04		**0 232 101 031**
Speed sensor, ignition/injection	08.98-05.04		**0 261 210 147**
Knock sensor	08.98-05.04		**0 261 231 045**
		WW	**0 261 231 146**
Accelerator pedal module	05.02-05.04	GS,LLE	**0 280 752 214**
Fg.no. 1J..Y..000 001→	05.99-04.02	AG,RLE	**0 280 752 213**
	05.99-05.04	RLE	**0 280 752 210**

V

Product			
2.0 [1J1]			**2,0 l 85 kW AZG 4 Zyl.**
Throttle valve assembly	05.01-04.02		**0 280 750 061**
Air mass meter, gasoline injection	05.01-04.02		**0 280 218 060**
			0 986 280 216
Phase sensor	05.01-04.02		**0 232 101 031**
Speed sensor, ignition/injection	05.01-04.02		**0 261 210 199**
Accelerator pedal module	05.01-04.02	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
2.0 [1J1]			**2,0 l 85 kW AZJ 4 Zyl.**
Throttle valve assembly	05.01-05.04		**0 280 750 061**
Air mass meter, gasoline injection	05.01-05.04		**0 280 218 060**
			0 986 280 216
Phase sensor	05.01-05.04		**0 232 101 031**
Speed sensor, ignition/injection	05.01-05.04		**0 261 210 199**
Knock sensor	05.01-05.04		**0 261 231 146**
Accelerator pedal module	05.01-04.02	AG,RLE	**0 280 752 213**
	05.02-05.04	GS,LLE	**0 280 752 214**
	05.01-05.04	GS,RLE	**0 280 752 210**
2.0 [1J1]			**2,0 l 85 kW BEH 4 Zyl.**
Throttle valve assembly	05.02-05.03		**0 280 750 061**
Air mass meter, gasoline injection	05.02-05.03		**0 280 218 060**
			0 986 280 216
Phase sensor	05.02-05.03		**0 232 101 031**
Speed sensor, ignition/injection	05.02-05.03		**0 261 210 199**
Knock sensor	05.02-05.03		**0 261 231 146**
Accelerator pedal module	05.02-05.03	GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
2.0 [9B1]			**2,0 l 85 kW APK 4 Zyl.**
Air mass meter, gasoline injection	08.99-06.02		**0 280 218 002**
			0 986 280 205
Speed sensor, ignition/injection	08.99-06.02		**0 261 210 147**
Knock sensor	08.99-09.00		**0 261 231 045**
	10.00-06.02		**0 261 231 146**
2.0 [9B1]			**2,0 l 85 kW BER 4 Zyl.**
Throttle valve assembly	03.02-03.07		**0 280 750 061**
Air mass meter, gasoline injection	03.02-06.02		**0 280 218 060**
			0 986 280 216
Phase sensor	03.02-03.07		**0 232 101 031**
Speed sensor, ignition/injection	03.02-03.07		**0 261 210 147**
Knock sensor	03.02-03.07		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	03.02-11.02		**0 261 230 031**
	12.02-03.07		**0 261 230 095**
2.0 i			**2,0 l 85 kW APK 4 Zyl.**
Speed sensor, ignition/injection	07.03-02.04		**0 261 210 147**
Knock sensor	07.03-02.04	ZE	**0 261 231 146**
2.0 i [1J1]			**2,0 l 85 kW APK 4 Zyl.**
Throttle valve assembly	02.99-12.05	FMP	**0 280 750 061**
Air mass meter, gasoline injection	02.99-12.05		**0 280 218 002**
			0 986 280 205
Speed sensor, ignition/injection	02.99-12.05	AG5,GS	**0 261 210 147**
Knock sensor	02.99-12.05	KZA	**0 261 231 045**
		WW	**0 261 231 146**
Accelerator pedal module	04.99-12.05	AG,RLE	**0 280 752 213**
Fg.no. 1J-Y-000 001→	05.99-12.05	GS,RLE	**0 280 752 210**
2.0 4 Motion [1J1]			**2,0 l 85 kW AZH 4 Zyl.**
Throttle valve assembly	04.00-06.01		**0 280 750 061**
Air mass meter, gasoline injection	04.00-06.01		**0 280 218 002**
			0 986 280 205
Phase sensor	04.00-06.01		**0 232 101 031**
Speed sensor, ignition/injection	04.00-06.01		**0 261 210 147**
Knock sensor	04.00-06.01		**0 261 231 045**
		WW	**0 261 231 146**

Product			
Accelerator pedal module	04.00-06.01	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
2.0 4 Motion [1J1]			**2,0 l 85 kW AZJ 4 Zyl.**
Throttle valve assembly	05.01-06.05		**0 280 750 061**
Air mass meter, gasoline injection	05.01-06.05		**0 280 218 060**
			0 986 280 216
Phase sensor	05.01-06.05		**0 232 101 031**
Speed sensor, ignition/injection	05.01-06.05		**0 261 210 199**
Knock sensor	05.01-06.05		**0 261 231 146**
Accelerator pedal module	05.01-04.02	AG,RLE	**0 280 752 213**
	05.02-06.05	GS,LLE	**0 280 752 214**
	05.01-06.05	GS,RLE	**0 280 752 210**
2.3 [1J1]			**2,3 l 110 kW AGZ 5 Zyl.**
Air mass meter, gasoline injection	10.97-02.01		**0 280 217 529**
			0 986 280 204
Phase sensor	10.97-02.01		**0 232 103 019**
Speed sensor, ignition/injection	10.97-02.01		**0 261 210 177**
Knock sensor	10.97-02.01		**0 261 231 146**
Temperature sensor, intake air, injection system	10.97-02.01		**0 280 130 085**
Accelerator pedal module			
Fg.no. 1J..Y..000 001→	05.99-02.01	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
2.3 [1J1]			**2,3 l 125 kW AQN 5 Zyl.**
Throttle valve assembly	09.00-05.04		**0 280 750 097**
Air mass meter, gasoline injection	09.00-05.04		**0 280 218 017**
			0 986 280 208
Phase sensor	09.00-05.04		**0 232 103 019**
Knock sensor	09.00-05.04		**0 261 231 146**
Accelerator pedal module	09.00-04.02	AG,RLE	**0 280 752 213**
	05.02-05.04	GS,LLE	**0 280 752 214**
	09.00-05.04	GS,RLE	**0 280 752 210**
2.3 4 Motion [1J1]			**2,3 l 110 kW AGZ 5 Zyl.**
Air mass meter, gasoline injection	07.98-02.01		**0 280 217 529**
			0 986 280 204
Phase sensor	07.98-02.01		**0 232 103 019**
Speed sensor, ignition/injection	07.98-02.01		**0 261 210 177**
Knock sensor	07.98-02.01		**0 261 231 146**
Temperature sensor, intake air, injection system	07.98-02.01		**0 280 130 085**
Accelerator pedal module			
Fg.no. 1J..Y..000 001→	05.99-02.01	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
2.3 4 Motion [1J1]			**2,3 l 125 kW AQN 5 Zyl.**
Throttle valve assembly	09.00-06.05		**0 280 750 097**
Air mass meter, gasoline injection	09.00-06.05		**0 280 218 017**
			0 986 280 208
Phase sensor	09.00-06.05		**0 232 103 019**
Knock sensor	09.00-06.05		**0 261 231 146**
Accelerator pedal module	09.00-04.02	AG,RLE	**0 280 752 213**
	05.02-06.05	GS,LLE	**0 280 752 214**
	09.00-06.05	GS,RLE	**0 280 752 210**
2.8 [1J1]			**2,8 l 130 kW AFP 6 Zyl.**
Throttle valve assembly	12.98-09.00		**0 205 003 053**
2.8 VR6 [9B1]			**2,8 l 147 kW BDF 6 Zyl.**
Throttle valve assembly	07.02-07.03		**0 280 750 097**
Air mass meter, gasoline injection	07.02-07.03		**0 280 218 017**
			0 986 280 208
Phase sensor	07.02-07.03		**0 232 103 019**
Knock sensor	07.02-07.03		**0 261 231 146**
2.8 4 Motion [1J1]			**2,8 l 150 kW AQP; AUE 6 Zyl.**
Throttle valve assembly			
Fg.no. →1J..Y..620 000	05.99-01.00	LLE	**0 280 750 086**
		RLE	**0 280 750 097**
Fg.no. 1J..Y..620 001→	02.00-04.01		**0 280 750 097**

V

Product			
◀ Golf IV			
Air mass meter, gasoline injection	05.99-04.01		**0 280 218 017**
			0 986 280 208
Phase sensor	05.99-04.01		**0 232 103 019**
Knock sensor	05.99-04.01		**0 261 231 146**
Accelerator pedal module	05.99-04.01	AG,RLE	**0 280 752 213**
2.8 4 Motion [1J1]			**2,8 l 150 kW BDE 6 Zyl.**
Throttle valve assembly	05.01-06.05		**0 280 750 097**
Air mass meter, gasoline injection	05.01-06.05		**0 280 218 017**
			0 986 280 208
Phase sensor	05.01-06.05		**0 232 103 019**
Knock sensor	05.01-06.05		**0 261 231 146**
Accelerator pedal module	05.01-04.02	AG,RLE	**0 280 752 213**
	05.02-06.05	GS,LLE	**0 280 752 214**
	05.01-06.05	GS,RLE	**0 280 752 210**
3.2 4 Motion R32 [1J1]			**3,2 l 177 kW BFH 6 Zyl.**
Air mass meter, gasoline injection	06.02-05.04	AG	**0 280 218 073**
			0 986 280 222
		GS	**0 280 218 071**
			0 986 280 221
Phase sensor	06.02-05.04		**0 232 103 019**
Knock sensor	06.02-05.04		**0 261 231 146**
Accelerator pedal module	06.02-05.04	GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
3.2 4 Motion R32 [1J1]			**3,2 l 177 kW BML 6 Zyl.**
Air mass meter, gasoline injection	10.03-05.04		**0 280 218 071**
			0 986 280 221
Knock sensor	10.03-05.04		**0 261 231 146**
Accelerator pedal module	10.03-05.04	GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**

Golf IV Cabriolet

1.6 [1E7]			**1,6 l 74 kW AFT; AKS 4 Zyl.**
Knock sensor	04.98-10.00		**0 261 231 036**
Temperature sensor, intake air, injection system	04.98-10.00		**0 280 130 039**
1.9 TDI [1E7]			**1,9 l 66/81 kW AFN; AHU; ALE 4 Zyl.**
Pedal position sensor, diesel	04.98-12.01	AG	**0 205 001 031**
		GS	**0 205 001 032**
2.0 [1E7]			**2,0 l 85 kW AGG; AKR 4 Zyl.**
Knock sensor	04.98-12.01		**0 261 231 077**
2.0 [1E7]			**2,0 l 85 kW ATU; AWF; AWG 4 Zyl.**
Air mass meter, gasoline injection	06.99-06.02		**0 280 218 023**
			0 986 280 209
Knock sensor	06.99-06.02		**0 261 231 036**
Temperature sensor, intake air, injection system	06.99-06.02		**0 280 130 039**

Golf IV Station Wagon

1.6 i [1J5]			**1,6 l 74 kW AKL 4 Zyl.**
Speed sensor, ignition/injection	01.01-12.05	AG5,GS	**0 261 210 147**
Accelerator pedal module	01.01-12.05	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**

Golf IV Variant

1.4 [1J5]			**1,4 l 55 kW AHW 4 Zyl.**
Knock sensor	05.99-06.06		**0 261 231 045**
		WW	**0 261 231 146**
Accelerator pedal module	05.99-04.02	AG,RLE	**0 280 752 213**
	05.02-06.06	GS,LLE	**0 280 752 214**
	05.99-06.06	GS,RLE	**0 280 752 210**

Product			
1.4 [1J5]			**1,4 l 55 kW AKQ 4 Zyl.**
Speed sensor, ignition/injection			
Mot.no. 001 001→001 068	05.99-05.00		**0 261 210 194**
Knock sensor	05.99-05.00		**0 261 231 045**
Accelerator pedal module	05.99-05.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.4 [1J5]			**1,4 l 55 kW APE; AXP 4 Zyl.**
Knock sensor	05.99-10.01		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.99-10.01		**0 261 230 031**
Accelerator pedal module	05.99-10.01	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.4 [1J5]			**1,4 l 55 kW BCA 4 Zyl.**
Speed sensor, ignition/injection	10.01-06.06		**0 261 210 213**
Knock sensor	10.01-06.06		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	10.01-06.06		**0 261 230 031**
Accelerator pedal module	10.01-04.02	AG,RLE	**0 280 752 213**
	05.02-06.06	GS,LLE	**0 280 752 214**
	10.01-06.06	GS,RLE	**0 280 752 210**
1.6 [1J5]			**1,6 l 74 kW AEH 4 Zyl.**
Phase sensor	05.99-06.06		**0 232 101 031**
Speed sensor, ignition/injection	05.99-06.06		**0 261 210 147**
Accelerator pedal module	05.99-04.02	AG,RLE	**0 280 752 213**
	05.99-04.01	GS,RLE	**0 280 752 210**
1.6 [1J5]			**1,6 l 74 kW AKL 4 Zyl.**
Phase sensor	05.99-06.06		**0 232 101 031**
Speed sensor, ignition/injection	05.99-06.06		**0 261 210 147**
Accelerator pedal module	05.99-04.02	AG,RLE	**0 280 752 213**
	05.02-06.06	GS,LLE	**0 280 752 214**
	05.99-06.06	GS,RLE	**0 280 752 210**
1.6 [1J5]			**1,6 l 74 kW APF 4 Zyl.**
Phase sensor	05.00-08.00		**0 232 101 031**
Speed sensor, ignition/injection	05.00-08.00		**0 261 210 199**
Accelerator pedal module	05.00-08.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.6 [1J5]			**1,6 l 75 kW AVU 4 Zyl.**
Phase sensor	09.00-06.06		**0 232 101 038**
Speed sensor, ignition/injection	09.00-06.06		**0 261 210 199**
Accelerator pedal module	09.00-04.02	AG,RLE	**0 280 752 213**
	05.02-06.06	GS,LLE	**0 280 752 214**
	09.00-06.06	GS,RLE	**0 280 752 210**
1.6 [1J5]			**1,6 l 75 kW BFQ 4 Zyl.**
Speed sensor, ignition/injection	05.02-06.06		**0 261 210 199**
Knock sensor	05.02-06.06		**0 261 231 146**
Accelerator pedal module	05.02-06.06	GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.6 [1J5]			**1,6 l 77 kW ATN; AUS 4 Zyl.**
Speed sensor, ignition/injection	05.99-10.00		**0 261 210 194**
Knock sensor	05.99-10.00		**0 261 231 045**
Temperature sensor, intake air, injection system	05.99-10.00		**0 280 130 085**
Accelerator pedal module	05.99-10.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.6 [1J5]			**1,6 l 77 kW AZD 4 Zyl.**
Speed sensor, ignition/injection	09.00-04.01		**0 261 210 194**
Knock sensor	09.00-11.01		**0 261 231 146**
Temperature sensor, intake air, injection system	09.00-11.01		**0 280 130 085**
Accelerator pedal module	09.00-11.01	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.6 [1J5]			**1,6 l 77 kW BCB 4 Zyl.**
Knock sensor	11.01-06.06		**0 261 231 146**
Accelerator pedal module	11.01-04.02	AG,RLE	**0 280 752 213**
	05.02-06.06	GS,LLE	**0 280 752 214**
	11.01-06.06	GS,RLE	**0 280 752 210**

Product			
1.6 FSI [1J5]			**1,6 l 81 kW BAD 4 Zyl.**
Throttle valve assembly	08.01-06.06		**0 280 750 059**
Air mass meter, gasoline injection	08.01-06.06		**0 280 218 060**
			0 986 280 216
Knock sensor	08.01-06.06		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	08.01-06.06		**0 261 230 079**
Accelerator pedal module	08.01-04.02	AG,RLE	**0 280 752 213**
	05.02-06.06	GS,LLE	**0 280 752 214**
	08.01-06.06	GS,RLE	**0 280 752 210**
1.8 T [1J5]			**1,8 l 110 kW AGU 4 Zyl.**
Air mass meter, gasoline injection	05.00-05.03		**0 280 217 117**
			0 986 280 201
Phase sensor	05.00-05.03		**0 232 101 024**
Speed sensor, ignition/injection	05.00-05.03		**0 261 210 147**
		WW	**0 261 210 199**
Boost pressure sensor, gasoline	05.00-05.03		**0 281 002 177**
Temperature sensor, intake air, injection system			
Fg.no. →1J..3B065 915,→1J..3D013 548, →1J..3P064 809,→1J..3U201 122, →1J..3W335 000	05.00-09.02		**0 280 130 085**
Fg.no. 1J..3B065 916→,1J..3D013 549→, 1J..3P064 810→,1J..3U201 123→, 1J..3W335 001→	10.02-05.03		**0 280 130 116**
Accelerator pedal module	05.00-04.02	AG,RLE	**0 280 752 213**
	05.02-05.03	GS,LLE	**0 280 752 214**
	05.00-05.03	GS,RLE	**0 280 752 210**
1.8 T [1J5]			**1,8 l 110 kW ARZ 4 Zyl.**
Throttle valve assembly	05.99-09.00		**0 280 750 036**
Air mass meter, gasoline injection	05.99-09.00		**0 280 218 032**
			0 986 280 210
Speed sensor, ignition/injection	05.99-09.00		**0 261 210 147**
Boost pressure sensor, gasoline	05.99-09.00		**0 281 002 177**
Temperature sensor, intake air, injection system	05.99-09.00		**0 280 130 085**
Accelerator pedal module	05.99-09.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.8 T [1J5]			**1,8 l 110 kW AUM 4 Zyl.**
Throttle valve assembly	09.00-05.03		**0 280 750 036**
Air mass meter, gasoline injection	09.00-05.03		**0 280 218 063**
			0 986 280 217
Phase sensor	09.00-05.03		**0 232 101 024**
Speed sensor, ignition/injection	09.00-05.03		**0 261 210 199**
Knock sensor	09.00-05.03		**0 261 231 146**
Boost pressure sensor, gasoline	09.00-05.03		**0 281 002 177**
Temperature sensor, intake air, injection system			
Fg.no. →1J..3B065 915,→1J..3D013 548, →1J..3P064 809,→1J..3U201 122, →1J..3W335 000	09.00-09.02		**0 280 130 085**
Fg.no. 1J..3B065 916→,1J..3D013 549→, 1J..3P064 810→,1J..3U201 123→, 1J..3W335 001→	10.02-05.03		**0 280 130 116**
Accelerator pedal module	09.00-04.02	AG,RLE	**0 280 752 213**
	05.02-05.03	GS,LLE	**0 280 752 214**
	09.00-05.03	GS,RLE	**0 280 752 210**
1.8 4 Motion [1J5]			**1,8 l 92 kW AGN 4 Zyl.**
Air mass meter, gasoline injection	05.99-10.00		**0 280 218 002**
			0 986 280 205
Phase sensor	05.99-10.00		**0 232 101 024**
Speed sensor, ignition/injection	05.99-10.00		**0 261 210 147**
Temperature sensor, intake air, injection system	05.99-10.00		**0 280 130 085**
Accelerator pedal module	05.99-10.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**

Product			
1.9 TDI [1J5]			**1,9 l 66 kW AGR 4 Zyl.**
Air mass meter, diesel	05.99-09.02		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel	05.99-09.02		**0 281 002 177**
1.9 TDI [1J5]			**1,9 l 66 kW ALH 4 Zyl.**
Air mass meter, diesel	05.99-06.06		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel			
Fg.no. →1J..3W385 000,→1J..3P278 330, →1J..3D390 630,→1J..3B139 990, →1J..3U346 620	05.99-11.02		**0 281 002 177**
Fg.no. 1J..3W385 001→,1J..3P278 331→, 1J..3D390 631→,1J..3B139 991→, 1J..3U346 621→	12.02-06.06		**0 281 002 399**
1.9 TDI [1J5]			**1,9 l 74 kW ATD 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1J..2B088 000,→1J..2D420 000, →1J..2P055 000,→1J..2U030 000, →1J..2W350 000	01.00-11.01		**0 281 002 757**
	02.00-11.01	WW	**0 280 217 121**
			0 986 280 202
Fg.no. 1J..2B088 001→,1J..2D420 001→, 1J..2P055 001→,1J..2U030 001→, 1J..2W350 001→	12.01-06.06		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1J..3W385 000,→1J..3P278 330, →1J..3D390 630,→1J..3B139 990, →1J..3U346 620	01.00-11.02		**0 281 002 177**
Fg.no. 1J..3W385 001→,1J..3P278 331→, 1J..3D390 631→,1J..3B139 991→, 1J..3U346 621→	12.02-06.06		**0 281 002 399**
1.9 TDI [1J5]			**1,9 l 74 kW AXR 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1J..2B088 000,→1J..2D420 000, →1J..2P055 000,→1J..2U030 000, →1J..2W350 000	05.01-11.01		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 1J..2B088 001→,1J..2D420 001→, 1J..2P055 001→,1J..2U030 001→, 1J..2W350 001→	12.01-06.06		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	05.01-06.06		**0 281 002 399**
1.9 TDI [1J5]			**1,9 l 81 kW AHF; ASV 4 Zyl.**
Air mass meter, diesel	05.99-06.06		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel			
Fg.no. →1J..3W385 000,→1J..3P278 330, →1J..3D390 630,→1J..3B139 990, →1J..3U346 620	05.99-11.02		**0 281 002 177**
Fg.no. 1J..3W385 001→,1J..3P278 331→, 1J..3D390 631→,1J..3B139 991→, 1J..3U346 621→	12.02-06.06		**0 281 002 399**
1.9 TDI [1J5]			**1,9 l 85 kW AJM; AUY 4 Zyl.**
Air mass meter, diesel	05.99-07.01		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel	05.99-07.01		**0 281 002 177**
1.9 TDI [1J5]			**1,9 l 96 kW ASZ 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1J..2..600 000	04.01-04.02		**0 280 217 529**
			0 986 280 204
Fg.no. 1J..2..600 001→	05.02-06.06		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	04.01-06.06		**0 281 002 177**

V

Product			
◀ Golf IV Variant			
1.9 TDI 4 Motion [1J5]			**1,9 l 66 kW AGR 4 Zyl.**
Air mass meter, diesel	05.99-04.02		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel	05.99-04.02		**0 281 002 177**
1.9 TDI 4 Motion [1J5]			**1,9 l 74 kW ATD 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1J..2B088 000,→1J..2D420 000, →1J..2P055 000,→1J..2U030 000, →1J..2W350 000	02.00-11.01		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 1J..2B088 001→,1J..2D420 001→, 1J..2P055 001→,1J..2U030 001→, 1J..2W350 001→	12.01-06.06		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1J..3W385 000,→1J..3P278 330, →1J..3D390 630,→1J..3B139 990, →1J..3U346 620	02.00-11.02		**0 281 002 177**
Fg.no. 1J..3W385 001→,1J..3P278 331→, 1J..3D390 631→,1J..3B139 991→, 1J..3U346 621→	12.02-06.06		**0 281 002 399**
1.9 TDI 4 Motion [1J5]			**1,9 l 85 kW AJM; AUY 4 Zyl.**
Air mass meter, diesel	05.99-07.01		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel	05.99-07.01		**0 281 002 177**
1.9 TDI 4 Motion [1J5]			**1,9 l 96 kW ASZ 4 Zyl.**
Air mass meter, diesel			
Fg.no. →1J..2..600 000	04.01-04.02		**0 280 217 529**
			0 986 280 204
Fg.no. 1J..2..600 001→	05.02-06.06		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	04.01-06.06		**0 281 002 177**
2.0 [1J5]			**2,0 l 85 kW APK; AQY 4 Zyl.**
Air mass meter, gasoline injection	05.99-06.06		**0 280 218 002**
			0 986 280 205
Phase sensor	05.99-06.06		**0 232 101 031**
Speed sensor, ignition/injection	05.99-06.06		**0 261 210 147**
Knock sensor	05.99-06.06		**0 261 231 045**
		WW	**0 261 231 146**
Accelerator pedal module	05.99-04.02	AG,RLE	**0 280 752 213**
	05.02-06.06	GS,LLE	**0 280 752 214**
	05.99-06.06	GS,RLE	**0 280 752 210**
2.0 [1J5]			**2,0 l 85 kW AZJ 4 Zyl.**
Throttle valve assembly	05.01-06.06		**0 280 750 061**
Air mass meter, gasoline injection	05.01-06.06		**0 280 218 060**
			0 986 280 216
Phase sensor	05.01-06.06		**0 232 101 031**
Speed sensor, ignition/injection	05.01-06.06		**0 261 210 199**
Knock sensor	05.01-06.06		**0 261 231 146**
Accelerator pedal module	05.01-04.02	AG,RLE	**0 280 752 213**
	05.02-06.06	GS,LLE	**0 280 752 214**
	05.01-06.06	GS,RLE	**0 280 752 210**
2.0 Bi-Fuel [1J5]			**2,0 l 85 kW BEH 4 Zyl.**
Throttle valve assembly	05.02-06.06		**0 280 750 061**
Air mass meter, gasoline injection	05.02-06.06		**0 280 218 060**
			0 986 280 216
Phase sensor	05.02-06.06		**0 232 101 031**
Speed sensor, ignition/injection	05.02-06.06		**0 261 210 199**
Knock sensor	05.02-06.06		**0 261 231 146**
Accelerator pedal module	05.02-06.06	GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**

Product			
2.0 4 Motion [1J5]			**2,0 l 85 kW AZH 4 Zyl.**
Throttle valve assembly	04.00-06.01		**0 280 750 061**
Air mass meter, gasoline injection	04.00-06.01		**0 280 218 002**
			0 986 280 205
Phase sensor	04.00-06.01		**0 232 101 031**
Speed sensor, ignition/injection	04.00-06.01		**0 261 210 147**
Knock sensor	04.00-06.01		**0 261 231 045**
		WW	**0 261 231 146**
Accelerator pedal module	04.00-06.01	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
2.0 4 Motion [1J5]			**2,0 l 85 kW AZJ 4 Zyl.**
Throttle valve assembly	05.01-06.06		**0 280 750 061**
Air mass meter, gasoline injection	05.01-06.06		**0 280 218 060**
			0 986 280 216
Phase sensor	05.01-06.06		**0 232 101 031**
Speed sensor, ignition/injection	05.01-06.06		**0 261 210 199**
Knock sensor	05.01-06.06		**0 261 231 146**
Accelerator pedal module	05.01-04.02	AG,RLE	**0 280 752 213**
	05.02-06.06	GS,LLE	**0 280 752 214**
	05.01-06.06	GS,RLE	**0 280 752 210**
2.3 [1J5]			**2,3 l 110 kW AGZ 5 Zyl.**
Air mass meter, gasoline injection	05.99-02.01		**0 280 217 529**
			0 986 280 204
Phase sensor	05.99-02.01		**0 232 103 019**
Speed sensor, ignition/injection	05.99-02.01		**0 261 210 177**
Knock sensor	05.99-02.01		**0 261 231 146**
Temperature sensor, intake air, injection system	05.99-02.01		**0 280 130 085**
Accelerator pedal module	05.99-02.01	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
2.3 [1J5]			**2,3 l 125 kW AQN 5 Zyl.**
Throttle valve assembly	09.00-06.06		**0 280 750 097**
Air mass meter, gasoline injection	09.00-06.06		**0 280 218 017**
			0 986 280 208
Phase sensor	09.00-06.06		**0 232 103 019**
Knock sensor	09.00-06.06		**0 261 231 146**
Accelerator pedal module	09.00-04.02	AG,RLE	**0 280 752 213**
	05.02-06.06	GS,LLE	**0 280 752 214**
	05.01-06.06	GS,RLE	**0 280 752 210**
2.3 4 Motion [1J5]			**2,3 l 110 kW AGZ 5 Zyl.**
Air mass meter, gasoline injection	05.99-02.01		**0 280 217 529**
			0 986 280 204
Phase sensor	05.99-02.01		**0 232 103 019**
Speed sensor, ignition/injection	05.99-02.01		**0 261 210 177**
Knock sensor	05.99-02.01		**0 261 231 146**
Temperature sensor, intake air, injection system	05.99-02.01		**0 280 130 085**
Accelerator pedal module	05.99-02.01	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
2.3 4 Motion [1J5]			**2,3 l 125 kW AQN 5 Zyl.**
Throttle valve assembly	09.00-06.06		**0 280 750 097**
Air mass meter, gasoline injection	09.00-06.06		**0 280 218 017**
			0 986 280 208
Phase sensor	09.00-06.06		**0 232 103 019**
Knock sensor	09.00-06.06		**0 261 231 146**
Accelerator pedal module	09.00-04.02	AG,RLE	**0 280 752 213**
	05.02-06.06	GS,LLE	**0 280 752 214**
	09.00-06.06	GS,RLE	**0 280 752 210**
2.8 4 Motion [1J5]			**2,8 l 150 kW AQP; AUE 6 Zyl.**
Throttle valve assembly			
Fg.no. →1J..Y..620 000	05.99-01.00	LLE	**0 280 750 086**
		RLE	**0 280 750 097**
Fg.no. 1J..Y..620 001→	02.00-04.01		**0 280 750 097**
Air mass meter, gasoline injection	05.99-04.01		**0 280 218 017**
			0 986 280 208

Product			
Phase sensor	05.99-04.01		**0 232 103 019**
Knock sensor	05.99-04.01		**0 261 231 146**
Accelerator pedal module	05.99-04.01	AG,RLE	**0 280 752 213**
2.8 4 Motion [1J5]			**2,8 l 150 kW BDE 6 Zyl.**
Throttle valve assembly	05.01-06.06		**0 280 750 097**
Air mass meter, gasoline injection	05.01-06.06		**0 280 218 017**
			0 986 280 208
Phase sensor	05.01-06.06		**0 232 103 019**
Knock sensor	05.01-06.06		**0 261 231 146**
Accelerator pedal module	05.01-04.02	AG,RLE	**0 280 752 213**
	05.02-06.06	GS,LLE	**0 280 752 214**
	05.01-06.06	GS,RLE	**0 280 752 210**

Golf Plus

1.4 [5M1]			**1,4 l 55/59 kW BCA; BUD 4 Zyl.**
Speed sensor, ignition/injection	01.05-07.07	TW	**0 261 210 199**
			0 261 210 250
Knock sensor	01.05-07.07		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	01.05-07.07		**0 261 230 095**
1.4 FSI [5M1]			**1,4 l 66 kW BLN 4 Zyl.**
Speed sensor, ignition/injection	07.05-05.06	TW	**0 261 210 199**
			0 261 210 250
Knock sensor	07.05-05.06		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	07.05-05.06		**0 261 230 095**
1.4 TSI [5M1]			**1,4 l 90 kW CAXA 4 Zyl.**
Knock sensor	07.07→		**0 261 231 146**
Boost pressure sensor, gasoline	07.07→		**0 281 002 399**
1.4 TSI [5M1]			**1,4 l 103/125 kW BLG; BMY 4 Zyl.**
Speed sensor, ignition/injection	05.06→	TW	**0 261 210 199**
			0 261 210 250
Knock sensor	05.06→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.06→		**0 261 230 081**
Boost pressure sensor, gasoline	05.06→		**0 281 002 401**
1.6 [5M1]			**1,6 l 75 kW BSE; BSF 4 Zyl.**
Speed sensor, ignition/injection	05.05→	TW	**0 261 210 199**
			0 261 210 250
Knock sensor	05.05→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.05→		**0 261 230 031**
1.6 [5M1]			**1,6 l 75 kW CCSA 4 Zyl.**
Speed sensor, ignition/injection	11.07→		**0 261 210 199**
Knock sensor	11.07→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	11.07→		**0 261 230 031**
1.6 FSI [5M1]			**1,6 l 85 kW BLF 4 Zyl.**
Speed sensor, ignition/injection	01.05→	TW	**0 261 210 199**
			0 261 210 250
Knock sensor	01.05→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	01.05→		**0 261 230 095**
1.9 TDI [5M1]			**1,9 l 66/77 kW BKC; BLS; BRU; BXE; BXF 4 Zyl.**
Air mass meter, diesel	01.05→		**0 281 002 531**
			0 986 284 009
Speed sensor, diesel	01.05→	TW	**0 261 210 233**
			0 261 210 250
Boost pressure sensor, Diesel	01.05→		**0 281 002 399**
2.0 FSI [5M1]			**2,0 l 110 kW BLR; BLY; BVY; BVZ 4 Zyl.**
Speed sensor, ignition/injection	05.05→	TW	**0 261 210 199**
			0 261 210 250
Knock sensor	05.05→	OHL	**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.05→		**0 261 230 031**
2.0 TDI [5M1]			**2,0 l 96/100/103 kW AZV; BEE; BKD 4 Zyl.**
Air mass meter, diesel	01.05→		**0 281 002 461**
			0 986 284 007

Product			
Speed sensor, diesel	01.05→	TW	**0 261 210 233**
			0 261 210 250
Boost pressure sensor, Diesel	01.05→		**0 281 002 401**
2.0 TDI [5M1]			**2,0 l 103 kW BMM 4 Zyl.**
Speed sensor, diesel	12.05→	TW	**0 261 210 233**
			0 261 210 250
Boost pressure sensor, Diesel	12.05→		**0 281 002 401**

Golf V

1.4 [1K1]			**1,4 l 55 kW BCA 4 Zyl.**
Knock sensor	10.03-05.06		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	10.03-05.06		**0 261 230 095**
1.4 [1K1]			**1,4 l 59 kW BUD 4 Zyl.**
Knock sensor	05.07→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.07→		**0 261 230 095**
1.4 FSI [1K1]			**1,4 l 59/66 kW BKG; BLN; BUD 4 Zyl.**
Knock sensor	10.03-11.06		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	10.03-11.06		**0 261 230 095**
1.4 FSI [1K1]			**1,4 l 88 kW CAXA 4 Zyl.**
Knock sensor	07.07→		**0 261 231 146**
Boost pressure sensor, gasoline	07.07→		**0 281 002 399**
1.4 TSI [1K1]			**1,4 l 103/125 kW BLG; BMY 4 Zyl.**
Knock sensor	11.05→		**0 261 231 146**
Boost pressure sensor, gasoline	11.05→		**0 281 002 401**
1.6 [1K1]			**1,6 l 75 kW BGU; BSE; BSF; CCSA 4 Zyl.**
Speed sensor, ignition/injection	01.04→		**0 261 210 199**
Knock sensor	01.04→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	01.04→		**0 261 230 031**
1.6 FSI [1K1]			**1,6 l 85 kW BAG; BLF; BLP 4 Zyl.**
Speed sensor, ignition/injection	10.03→	AG	**0 261 210 250**
Knock sensor	10.03→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	10.03→		**0 261 230 095**
1.9 TDI [1K1]			**1,9 l 66 kW BRU 4 Zyl.**
Air mass meter, diesel	05.04-02.06		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	05.04-02.06		**0 281 002 399**
Pressure sensor, intake manifold, diesel	05.04-02.06		**0 281 002 399**
1.9 TDI [1K1]			**1,9 l 66 kW BXF 4 Zyl.**
Air mass meter, diesel	02.06→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	02.06→		**0 281 002 399**
1.9 TDI [1K1]			**1,9 l 66 kW BXJ 4 Zyl.**
Boost pressure sensor, Diesel	05.07→		**0 281 002 399**
1.9 TDI [1K1]			**1,9 l 77 kW BKC 4 Zyl.**
Air mass meter, diesel	10.03-02.06		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	10.03-02.06		**0 281 002 399**
Pressure sensor, intake manifold, diesel	10.03-02.06		**0 281 002 399**
1.9 TDI [1K1]			**1,9 l 77 kW BLS; BXE 4 Zyl.**
Air mass meter, diesel	08.05→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	08.05→		**0 281 002 399**
1.9 TDI 4 Motion [1K1]			**1,9 l 77 kW BKC 4 Zyl.**
Air mass meter, diesel	10.03-02.06		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	10.03-02.06		**0 281 002 399**
Pressure sensor, intake manifold, diesel	10.03-02.06		**0 281 002 399**
1.9 TDI 4 Motion [1K1]			**1,9 l 77 kW BLS; BXE 4 Zyl.**
Air mass meter, diesel	08.05→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	08.05→		**0 281 002 399**

Product			
◀ Golf V			
2.0 FSI [1K1]	**2,0 l 110 kW AXW; BLR; BLX; BLY; BVX 4 Zyl.**		
Knock sensor	01.04→	OHL	**0 261 231 146**
Pressure sensor, intake manifold, gasoline	01.04→		**0 261 230 031**
2.0 FSI [1K1]	**2,0 l 110 kW BVY; BVZ 4 Zyl.**		
Knock sensor	11.05→	OHL	**0 261 231 146**
Pressure sensor, intake manifold, gasoline	11.05→		**0 261 230 031**
2.0 FSI 4 Motion [1K1]	**2,0 l 110 kW AXW; BLR; BLX; BLY; BVX 4 Zyl.**		
Knock sensor	01.04→	OHL	**0 261 231 146**
Pressure sensor, intake manifold, gasoline	01.04→		**0 261 230 031**
2.0 FSI 4 Motion [1K1]	**2,0 l 110 kW BVY; BVZ 4 Zyl.**		
Knock sensor	11.05→	OHL	**0 261 231 146**
Pressure sensor, intake manifold, gasoline	11.05→		**0 261 230 031**
2.0 GTI [1K1]	**2,0 l 147 kW AXX; BPY; BWA 4 Zyl.**		
Speed sensor, ignition/injection	09.04→		**0 261 210 199**
Boost pressure sensor, gasoline	09.04→		**0 261 230 073**
2.0 GTI [1K1]	**2,0 l 169 kW BYD 4 Zyl.**		
Speed sensor, ignition/injection	09.06→		**0 261 210 199**
Boost pressure sensor, gasoline	09.06→		**0 281 002 401**
2.0 SDI [1K1]	**2,0 l 55 kW BDK 4 Zyl.**		
Air mass meter, diesel	01.04→		**0 281 002 531**
			0 986 284 009
Pressure sensor, intake manifold, diesel	01.04→		**0 281 002 399**
2.0 TDI [1K1]	**2,0 l 100/103 kW AZV; BKD 4 Zyl.**		
Air mass meter, diesel	10.03→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	10.03→		**0 281 002 401**
Pressure sensor, intake manifold, diesel	10.03→		**0 281 002 401**
2.0 TDI [1K1]	**2,0 l 103/125 kW BMM; BMN 4 Zyl.**		
Air mass meter, diesel	12.04→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	12.04→		**0 281 002 401**
2.0 TDI 4 Motion [1K1]	**2,0 l 103 kW BKD 4 Zyl.**		
Air mass meter, diesel	10.03→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	10.03→		**0 281 002 401**
Pressure sensor, intake manifold, diesel	10.03→		**0 281 002 401**
2.0 TDI 4 Motion [1K1]	**2,0 l 103 kW BMM 4 Zyl.**		
Air mass meter, diesel	12.04→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	12.04→		**0 281 002 401**
3.2 R32 4 Motion [1K1]	**3,2 l 184 kW BUB 6 Zyl.**		
Air mass meter, gasoline injection	11.05→		**0 280 218 073**
			0 986 280 222
Phase sensor	11.05→		**0 232 103 019**
Knock sensor	11.05→	OHL	**0 261 231 146**

Golf V Variant

Product			
1.4 FSI [1K5]	**1,4 l 59 kW BUD 4 Zyl.**		
Knock sensor	08.07→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	08.07→		**0 261 230 095**
1.4 FSI [1K5]	**1,4 l 88 kW CAXA 4 Zyl.**		
Boost pressure sensor, gasoline	08.07→		**0 281 002 399**
1.4 TSI [1K5]	**1,4 l 103/125 kW BLG; BMY 4 Zyl.**		
Knock sensor	05.07→		**0 261 231 146**
Boost pressure sensor, gasoline	05.07→		**0 281 002 401**
1.6 [1K5]	**1,6 l 75 kW BSE; BSF 4 Zyl.**		
Speed sensor, ignition/injection	05.07→		**0 261 210 199**
Knock sensor	05.07→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.07→		**0 261 230 031**
1.9 TDI [1K5]	**1,9 l 77 kW BLS 4 Zyl.**		
Air mass meter, diesel	05.07→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	05.07→		**0 281 002 401**
1.9 TDI [1K5]	**1,9 l 77 kW BXE 4 Zyl.**		
Air mass meter, diesel	05.07→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	05.07→		**0 281 002 399**
2.0 GTI [1K5]	**2,0 l 147 kW BWA 4 Zyl.**		
Speed sensor, ignition/injection	05.07→		**0 261 210 199**
Boost pressure sensor, gasoline	05.07→		**0 261 230 073**
2.0 TDI [1K5]	**2,0 l 100/103 kW AZV; BKD 4 Zyl.**		
Air mass meter, diesel	05.07→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	05.07→		**0 281 002 401**
Pressure sensor, intake manifold, diesel	05.07→		**0 281 002 401**
2.0 TDI [1K5]	**2,0 l 103 kW BMM 4 Zyl.**		
Air mass meter, diesel	05.07→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	05.07→		**0 281 002 401**

Jetta

Product			
1.3 [1G2, 19E]	**1,3 l 40 kW NZ 4 Zyl.**		
Air flow sensor, gasoline injection	02.87-07.92		**0 280 200 048**
			0 986 280 030
1.4 TSI [1K2]	**1,4 l 103/125 kW BLG; BMY 4 Zyl.**		
Boost pressure sensor, gasoline	07.06→		**0 281 002 401**
1.6 [1G2, 19E]	**1,6 l 51-55 kW ABN; EZ, EZA; PN; RF 4 Zyl.**		
Temperature sensor, coolant, injection system	01.84-07.92		**0 280 130 040**
1.6 [1K2]	**1,6 l 75 kW BSE; BSF 4 Zyl.**		
Speed sensor, ignition/injection	10.05→		**0 261 210 199**
Knock sensor	10.05→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	10.05→		**0 261 230 031**
1.6 CEX, GEX	**1,6 l 53 kW ANL 4 Zyl.**		
Speed sensor, ignition/injection	10.98-12.99		**0 261 210 145**
Knock sensor	10.98-12.99	ZE	**0 261 231 045**
1.6 FSI [1K2]	**1,6 l 85 kW BLF 4 Zyl.**		
Knock sensor	09.05→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	09.05→		**0 261 230 095**
1.6 i CI, GI, CIX, GIX	**1,6 l 64 kW ATK 4 Zyl.**		
Phase sensor	10.99-02.07		**0 232 101 031**
Speed sensor, ignition/injection	10.99-02.07		**0 261 210 145**
Knock sensor	10.99-02.07		**0 261 231 146**
Temperature sensor, intake air, injection system	10.99-02.07		**0 280 130 039**
1.6 i King GT, GTX, AT	**1,6 l 74 kW AHP 4 Zyl.**		
Air mass meter, gasoline injection	05.98-01.02		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Phase sensor	05.98-01.02		**0 232 101 024**
Speed sensor, ignition/injection	05.98-01.02		**0 261 210 145**
Knock sensor	05.98-01.02		**0 261 231 045**
Temperature sensor, intake air, injection system	05.98-01.02		**0 280 130 039**
1.8 [1G2, 19E]	**1,8 l 66 kW GU 4 Zyl.**		
Temperature sensor, coolant, injection system	01.84-10.91		**0 280 130 040**
1.8 [1G2, 19E]	**1,8 l 66 kW GX 4 Zyl.**		
Air flow sensor, gasoline injection	08.84-10.87	KAT	**F 026 TX2 063**
			F 026 TX2 063
		OKA	**0 438 120 162**
1.8 [1G2, 19E]	**1,8 l 77/79 kW PF; RV 4 Zyl.**		
Knock sensor	08.89-07.92	KZB	**0 261 231 036**
	02.87-07.92	KZG	**0 261 231 038**

Product			
1.8 [1G2, 19E]			**1,8 l 79 kW RD 4 Zyl.**
Air flow sensor, gasoline injection	08.85-10.87		**F 026 TX2 063**
			F 026 TX2 063
Knock sensor	08.85-10.87	KZG	**0 261 231 038**
1.8 [1G2, 19E]			**1,8 l 79 kW RG 4 Zyl.**
Air flow sensor, gasoline injection	08.86-07.87		**F 026 TX2 051**
			F 026 TX2 051
1.8 [1G2, 19E]			**1,8 l 82 kW EV; GZ 4 Zyl.**
Air flow sensor, gasoline injection			
Fg.no. →16..G..640 000	01.84-03.86		**0 438 120 189**
Fg.no. 16..G..640 001→	04.86-07.87	FOB	**F 026 TX2 051**
			F 026 TX2 051
1.8 [1G2, 19E]			**1,8 l 82 kW PB 4 Zyl.**
Knock sensor	08.89-10.91	KZB	**0 261 231 036**
	02.87-10.91	KZG	**0 261 231 038**
1.8 [1H2]			**1,8 l 77 kW RV 4 Zyl.**
Air flow sensor, gasoline injection	07.89-12.91		**0 280 202 106**
			0 986 280 008
Knock sensor	07.89-12.91		**0 261 231 004**
		KZG	**0 261 231 038**
1.8 [16]			**1,8 l 79 kW PF 4 Zyl.**
Air flow sensor, gasoline injection	12.88-12.91		**0 280 202 106**
			0 986 280 008
Knock sensor	12.88-12.91		**0 261 231 004**
		KZG	**0 261 231 038**
1.8 syncro [1G2, 19E]			**1,8 l 66 kW GX 4 Zyl.**
Air flow sensor, gasoline injection	08.87-07.88		**F 026 TX2 063**
			F 026 TX2 063
1.8 syncro [1G2, 19E]			**1,8 l 72 kW 1P 4 Zyl.**
Air flow sensor, gasoline injection	08.88-07.92		**0 280 202 106**
			0 986 280 008
Knock sensor	08.88-07.92	KZG	**0 261 231 038**
1.8 16V [1G2, 19E]			**1,8 l 95 kW PL 4 Zyl.**
Air flow sensor, gasoline injection	08.86-10.91		**F 026 TX2 063**
			F 026 TX2 063
Knock sensor	08.89-10.91	KZB	**0 261 231 036**
	08.86-10.91	KZG	**0 261 231 038**
1.8 16V [1G2, 19E]			**1,8 l 102 kW KR 4 Zyl.**
Air flow sensor, gasoline injection	08.86-10.91		**F 026 TX2 050**
			F 026 TX2 050
1.9 TDI [1H2]			**1,9 l 66 kW 1Z 4 Zyl.**
Pedal position sensor, diesel	08.95→	AG	**0 205 001 031**
		GS	**0 205 001 018**
1.9 TDI [1K2]			**1,9 l 74 kW BRM 4 Zyl.**
Air mass meter, diesel	01.05→		**0 281 002 531**
			0 986 284 009
1.9 TDI [1K2]			**1,9 l 77 kW BKC; BLS 4 Zyl.**
Air mass meter, diesel	09.05→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	09.05→		**0 281 002 399**
2.0 [1H2]			**2,0 l 85 kW ABA 4 Zyl.**
Knock sensor	10.92→	KZB	**0 261 231 036**
2.0 FSI [1K2]			**2,0 l 110 kW BLR; BLY; BVY; BVZ 4 Zyl.**
Knock sensor	08.05→	OHL	**0 261 231 146**
Pressure sensor, intake manifold, gasoline	08.05→		**0 261 230 031**
2.0 GTI [1K2]			**2,0 l 147 kW BWA 4 Zyl.**
Speed sensor, ignition/injection	09.05→		**0 261 210 199**
Boost pressure sensor, gasoline	09.05→		**0 261 230 073**
2.0 TDI [1K2]			**2,0 l 100/103 kW AZV; BKD; BMM 4 Zyl.**
Air mass meter, diesel	08.05→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	08.05→		**0 281 002 401**

Product			
2.8 [1H2]			**2,8 l 128 kW AAA 6 Zyl.**
Air mass meter, gasoline injection			
Fg.no. →1H-S-999 000	01.94-07.95		**0 280 217 504**
Fg.no. 1H-T-000 001→	08.95→		**0 280 217 512**
			0 986 280 203
Speed sensor, ignition/injection	01.94→		**0 261 210 080**
Knock sensor	01.94→	KZA	**0 261 231 077**
		KZW	**0 261 231 047**
Temperature sensor, intake air, injection system	01.94→		**0 280 130 039**

Jetta I

1.8 i			**1,8 l 82 kW DX 4 Zyl.**
Air flow sensor, gasoline injection	05.83-12.95		**F 026 TX2 051**
			F 026 TX2 051

Jetta II

1.8 i			**1,8 l 82 kW EV 4 Zyl.**
Air flow sensor, gasoline injection	08.85-11.90		**F 026 TX2 051**
			F 026 TX2 051
1.8 i			**1,8 l 102 kW KR 16V 4 Zyl.**
Air flow sensor, gasoline injection	06.87-12.90		**F 026 TX2 050**
			F 026 TX2 050

Jetta III

1.6 i [1H8]			**1,6 l 74 kW AFX 4 Zyl.**
Pressure sensor, intake manifold, gasoline	11.96-12.99		**0 261 230 011**
1.8 i [1H8]			**1,8 l 82 kW AFV 4 Zyl.**
Pressure sensor, intake manifold, gasoline	11.96-12.99		**0 261 230 011**
2.8 i VR6 [1H8]			**2,8 l 128 kW AAA 6 Zyl.**
Speed sensor, ignition/injection	10.93-12.99		**0 261 210 080**
Knock sensor	10.93-12.99	KZW	**0 261 231 047**

Jetta IV

1.6 i			**1,6 l 74 kW AKL 4 Zyl.**
Phase sensor	09.99-12.05		**0 232 101 031**
Speed sensor, ignition/injection	09.99-12.05		**0 261 210 147**
1.8 T			**1,8 l 110 kW AGU 4 Zyl.**
Air mass meter, gasoline injection	09.03-12.05		**0 280 218 023**
			0 986 280 209
Phase sensor	09.03-12.05		**0 232 101 024**
Temperature sensor, intake air, injection system	09.03-12.05		**0 280 130 085**
			0 280 130 116
2.0 i			**2,0 l 85 kW APK 4 Zyl.**
Air mass meter, gasoline injection	09.99-12.05		**0 280 218 002**
			0 986 280 205
Phase sensor	09.99-12.05		**0 232 101 031**
Speed sensor, ignition/injection	09.99-12.05		**0 261 210 147**

Jetta V

1.9 TDI [1K6]			**1,9 l 77 kW BKC 4 Zyl.**
Air mass meter, diesel	03.06→		**0 281 002 531**
			0 986 284 009
2.0 T FSI [1K6]			**2,0 l 147 kW BWA 4 Zyl.**
Speed sensor, ignition/injection	03.06→		**0 261 210 199**
2.0 TDI [1K6]			**2,0 l 103 kW BKD 4 Zyl.**
Air mass meter, diesel	03.06→		**0 281 002 461**
			0 986 284 007

V

Product			
LT			
28 2.3 [2D, 2H]			**2,3 l 105 kW AGL 4 Zyl.**
Wheel speed sensor, front	01.97-11.01	H01	**0 265 004 009**
Wheel speed sensor, rear	05.96-11.01	H01	**0 265 004 010**
28 2.5 SDI [2D, 2H]			**2,5 l 55 kW AGX 5 Zyl.**
Air mass meter, diesel			
Fg.no. 2D..X..027 194→	03.99-04.01		**0 281 002 216**
			0 986 284 001
Wheel speed sensor, front	01.97-04.01	H01	**0 265 004 009**
Wheel speed sensor, rear	05.96-04.01	H01	**0 265 004 010**
28 2.5 TDI [2D, 2H]			**2,5 l 61 kW BBE 5 Zyl.**
Air mass meter, diesel	04.01-04.06		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel	04.01-04.06		**0 281 002 399**
Wheel speed sensor, front	04.01-04.06	H01	**0 265 004 009**
Wheel speed sensor, rear	04.01-04.06	H01	**0 265 004 010**
28 2.5 TDI [2D, 2H]			**2,5 l 66 kW APA 5 Zyl.**
Air mass meter, diesel	05.99-04.01		**0 281 002 216**
			0 986 284 001
Wheel speed sensor, front	05.99-04.01	H01	**0 265 004 009**
Wheel speed sensor, rear	05.99-04.01	H01	**0 265 004 010**
28 2.5 TDI [2D, 2H]			**2,5 l 70 kW BBF 5 Zyl.**
Air mass meter, diesel	04.01-04.06		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel	04.01-04.06		**0 281 002 399**
Wheel speed sensor, front	04.01-04.06	H01	**0 265 004 009**
Wheel speed sensor, rear	04.01-04.06	H01	**0 265 004 010**
28 2.5 TDI [2D, 2H]			**2,5 l 75 kW AHD 5 Zyl.**
Wheel speed sensor, front	01.97-05.99	H01	**0 265 004 009**
Wheel speed sensor, rear	05.96-05.99	H01	**0 265 004 010**
28 2.5 TDI [2D, 2H]			**2,5 l 80 kW ANJ 5 Zyl.**
Air mass meter, diesel			
Fg.no. →2D..1..013 334	05.99-08.00		**0 281 002 216**
			0 986 284 001
Fg.no. 2D..1..013 335→	09.00-04.06		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →2D..1..040 000	05.99-04.01		**0 281 002 177**
Fg.no. 2D..1..040 001→	05.01-04.06		**0 281 002 399**
Wheel speed sensor, front	05.99-04.06	H01	**0 265 004 009**
Wheel speed sensor, rear	05.99-04.06	H01	**0 265 004 010**
28 2.5 TDI [2D, 2H]			**2,5 l 80 kW AVR 5 Zyl.**
Air mass meter, diesel	12.02-04.06		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel	12.02-04.06		**0 281 002 399**
Wheel speed sensor, front	12.02-04.06	H01	**0 265 004 009**
Wheel speed sensor, rear	12.02-04.06	H01	**0 265 004 010**
28 2.8 D Turbo [2D, 2H]			**2,8 l 92/96 kW AGK; ATA 4 Zyl.**
Air mass meter, diesel	07.97-01.02		**0 281 002 461**
			0 986 284 007
Wheel speed sensor, front	07.97-01.02	H01	**0 265 004 009**
Wheel speed sensor, rear	07.97-01.02	H01	**0 265 004 010**
28 2.8 TDI [2D, 2H]			**2,8 l 116 kW AUH; BCQ 4 Zyl.**
Air mass meter, diesel	02.02-04.06		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	06.03-04.06		**0 281 002 177**
Wheel speed sensor, front	02.02-04.06	H01	**0 265 004 009**
Wheel speed sensor, rear	02.02-04.06	H01	**0 265 004 010**
35 2.3 [2D, 2H]			**2,3 l 105 kW AGL 4 Zyl.**
Wheel speed sensor, front	01.97-11.01	H01	**0 265 004 009**
Wheel speed sensor, rear	05.96-11.01	H01	**0 265 004 010**

Product			
35 2.5 SDI [2D, 2H]			**2,5 l 55 kW AGX 5 Zyl.**
Air mass meter, diesel			
Fg.no. 2D..X..027 194→	03.99-04.01		**0 281 002 216**
			0 986 284 001
Wheel speed sensor, front	01.97-04.01	H01	**0 265 004 009**
Wheel speed sensor, rear	05.96-04.01	H01	**0 265 004 010**
35 2.5 TDI [2D, 2H]			**2,5 l 61 kW BBE 5 Zyl.**
Air mass meter, diesel	04.01-04.06		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel	04.01-04.06		**0 281 002 399**
Wheel speed sensor, front	04.01-04.06	H01	**0 265 004 009**
Wheel speed sensor, rear	04.01-04.06	H01	**0 265 004 010**
35 2.5 TDI [2D, 2H]			**2,5 l 66 kW APA 5 Zyl.**
Air mass meter, diesel	05.99-04.01		**0 281 002 216**
			0 986 284 001
Wheel speed sensor, front	05.99-04.01	H01	**0 265 004 009**
Wheel speed sensor, rear	05.99-04.01	H01	**0 265 004 010**
35 2.5 TDI [2D, 2H]			**2,5 l 70 kW BBF 5 Zyl.**
Air mass meter, diesel	04.01-04.06		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel	04.01-04.06		**0 281 002 399**
Wheel speed sensor, front	04.01-04.06	H01	**0 265 004 009**
Wheel speed sensor, rear	04.01-04.06	H01	**0 265 004 010**
35 2.5 TDI [2D, 2H]			**2,5 l 75 kW AHD 5 Zyl.**
Wheel speed sensor, front	01.97-05.99	H01	**0 265 004 009**
Wheel speed sensor, rear	05.96-05.99	H01	**0 265 004 010**
35 2.5 TDI [2D, 2H]			**2,5 l 80 kW ANJ 5 Zyl.**
Air mass meter, diesel			
Fg.no. →2D..1..013 334	05.99-08.00		**0 281 002 216**
			0 986 284 001
Fg.no. 2D..1..013 335→	09.00-04.06		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →2D..1..040 000	05.99-04.01		**0 281 002 177**
Fg.no. 2D..1..040 001→	05.01-04.06		**0 281 002 399**
Wheel speed sensor, front	05.99-04.06	H01	**0 265 004 009**
Wheel speed sensor, rear	05.99-04.06	H01	**0 265 004 010**
35 2.5 TDI [2D, 2H]			**2,5 l 80 kW AVR 5 Zyl.**
Air mass meter, diesel	12.02-04.06		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel	12.02-04.06		**0 281 002 399**
Wheel speed sensor, front	12.02-04.06	H01	**0 265 004 009**
Wheel speed sensor, rear	12.02-04.06	H01	**0 265 004 010**
35 2.8 D Turbo [2D, 2H]			**2,8 l 92/96 kW AGK; ATA 4 Zyl.**
Air mass meter, diesel	07.97-01.02		**0 281 002 461**
			0 986 284 007
Wheel speed sensor, front	07.97-01.02	H01	**0 265 004 009**
Wheel speed sensor, rear	07.97-01.02	H01	**0 265 004 010**
35 2.8 TDI [2D, 2H]			**2,8 l 116 kW AUH; BCQ 4 Zyl.**
Air mass meter, diesel	02.02-04.06		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	06.03-04.06		**0 281 002 177**
Wheel speed sensor, front	02.02-04.06	H01	**0 265 004 009**
Wheel speed sensor, rear	02.02-04.06	H01	**0 265 004 010**
46 2.3 [2D, 2H]			**2,3 l 105 kW AGL 4 Zyl.**
Wheel speed sensor, front	01.97-11.01	H01	**0 265 004 009**
Wheel speed sensor, rear	05.96-11.01	H01	**0 265 004 010**
46 2.5 SDI [2D, 2H]			**2,5 l 55 kW AGX 5 Zyl.**
Air mass meter, diesel			
Fg.no. 2D..X..027 194→	03.99-04.01		**0 281 002 216**
			0 986 284 001
Wheel speed sensor, front	01.97-04.01	H01	**0 265 004 009**
Wheel speed sensor, rear	05.96-04.01	H01	**0 265 004 010**

Product			
46 2.5 TDI [2D, 2H]			**2,5 l 61 kW BBE 5 Zyl.**
Air mass meter, diesel	04.01-04.06		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel	04.01-04.06		**0 281 002 399**
Wheel speed sensor, front	04.01-04.06	H01	**0 265 004 009**
Wheel speed sensor, rear	04.01-04.06	H01	**0 265 004 010**
46 2.5 TDI [2D, 2H]			**2,5 l 66 kW APA 5 Zyl.**
Air mass meter, diesel	05.99-04.01		**0 281 002 216**
			0 986 284 001
Wheel speed sensor, front	05.99-04.01	H01	**0 265 004 009**
Wheel speed sensor, rear	05.99-04.01	H01	**0 265 004 010**
46 2.5 TDI [2D, 2H]			**2,5 l 70 kW BBF 5 Zyl.**
Air mass meter, diesel	04.01-04.06		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel	04.01-04.06		**0 281 002 399**
Wheel speed sensor, front	04.01-04.06	H01	**0 265 004 009**
Wheel speed sensor, rear	04.01-04.06	H01	**0 265 004 010**
46 2.5 TDI [2D, 2H]			**2,5 l 75 kW AHD 5 Zyl.**
Wheel speed sensor, front	01.97-05.99	H01	**0 265 004 009**
Wheel speed sensor, rear	05.96-05.99	H01	**0 265 004 010**
46 2.5 TDI [2D, 2H]			**2,5 l 80 kW ANJ 5 Zyl.**
Air mass meter, diesel			
Fg.no. →2D..1..013 334	05.99-08.00		**0 281 002 216**
			0 986 284 001
Fg.no. 2D..1..013 335→	09.00-04.06		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →2D..1..040 000	05.99-04.01		**0 281 002 177**
Fg.no. 2D..1..040 001→	05.01-04.06		**0 281 002 399**
Wheel speed sensor, front	05.99-04.06	H01	**0 265 004 009**
Wheel speed sensor, rear	05.99-04.06	H01	**0 265 004 010**
46 2.5 TDI [2D, 2H]			**2,5 l 80 kW AVR 5 Zyl.**
Air mass meter, diesel	12.02-04.06		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel	12.02-04.06		**0 281 002 399**
Wheel speed sensor, front	12.02-04.06	H01	**0 265 004 009**
Wheel speed sensor, rear	12.02-04.06	H01	**0 265 004 010**
46 2.8 D Turbo [2D, 2H]			**2,8 l 92/96 kW AGK; ATA 4 Zyl.**
Air mass meter, diesel	07.97-01.02		**0 281 002 461**
			0 986 284 007
Wheel speed sensor, front	07.97-01.02	H01	**0 265 004 009**
Wheel speed sensor, rear	07.97-01.02	H01	**0 265 004 010**
46 2.8 TDI [2D, 2H]			**2,8 l 116 kW AUH 4 Zyl.**
Air mass meter, diesel	02.02-04.06		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	06.03-04.06		**0 281 002 177**
Wheel speed sensor, front	02.02-04.06	H01	**0 265 004 009**
Wheel speed sensor, rear	02.02-04.06	H01	**0 265 004 010**

Lupo

Product			
1.0 [6X1]			**1,0 l 37 kW AER 4 Zyl.**
Pressure sensor, intake manifold, gasoline	10.98-05.00		**0 261 230 011**
1.0 [6X1]			**1,0 l 37 kW ALD 4 Zyl.**
Throttle valve assembly			
Fg.no. →6E..Y..007 000,→6X..Y..060 000	10.98-03.00		**0 280 750 049**
Fg.no. 6E..Y..007 001→,6X..Y..060 001→	04.00-07.05		**0 280 750 095**
Speed sensor, ignition/injection			
Fg.no. →6X..1..020 000	10.98-07.00		**0 261 210 188**
Fg.no. 6X..1..020 001→	08.00-07.05		**0 261 210 213**
Knock sensor	10.98-07.05		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	10.98-07.05		**0 261 230 031**
Accelerator pedal module	06.03-07.05	GS	**0 280 752 214**
1.0 [6X1]			**1,0 l 37 kW ALL 4 Zyl.**
Knock sensor	10.98-05.00		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	10.98-05.00		**0 261 230 011**
1.0 [6X1]			**1,0 l 37 kW ANV 4 Zyl.**
Throttle valve assembly			
Fg.no. →6E..Y..007 000,→6X..Y..060 000	10.98-03.00		**0 280 750 049**
Fg.no. 6E..Y..007 001→,6X..Y..060 001→	04.00-05.00		**0 280 750 095**
Speed sensor, ignition/injection	10.98-05.00		**0 261 210 188**
Knock sensor	10.98-05.00		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	10.98-05.00		**0 261 230 031**
1.0 [6X1]			**1,0 l 37 kW AUC 4 Zyl.**
Throttle valve assembly	05.00-07.05		**0 280 750 095**
Speed sensor, ignition/injection			
Fg.no. →6X..1..020 000	05.00-07.00		**0 261 210 188**
Fg.no. 6X..1..020 001→	08.00-07.05		**0 261 210 213**
Knock sensor	05.00-07.05		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	05.00-07.05		**0 261 230 031**
Accelerator pedal module	06.03-07.05	GS	**0 280 752 214**
1.2 TDI 3L [6X1]			**1,2 l 45 kW ANY 3 Zyl.**
Air mass meter, diesel	10.98-11.00		**0 280 218 002**
			0 986 280 205
Boost pressure sensor, Diesel	10.98-11.00		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. 6X..X..200 001→	05.99-11.00	RLE	**0 281 002 269**
1.2 TDI 3L [6X1]			**1,2 l 45 kW AYZ 3 Zyl.**
Air mass meter, diesel	11.00-07.05		**0 280 218 002**
			0 986 280 205
Boost pressure sensor, Diesel			
Fg.no. →6E..3..002 000,→6X..3..008 000	11.00-10.02		**0 281 002 177**
Fg.no. 6E..3..002 000→,6X..3..008 000→	11.02-07.05		**0 281 002 399**
Pedal position sensor, diesel	11.00-07.05	RLE	**0 281 002 269**
1.4 [6X1]			**1,4 l 44 kW AUD 4 Zyl.**
Throttle valve assembly	09.00-07.05		**0 280 750 095**
Speed sensor, ignition/injection	09.00-07.05		**0 261 210 213**
Knock sensor	09.00-07.05		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	09.00-07.05		**0 261 230 031**
Accelerator pedal module	06.03-07.05	GS	**0 280 752 214**
1.4 [6X1]			**1,4 l 55 kW AHW 4 Zyl.**
Knock sensor	10.98-05.04		**0 261 231 045**
Accelerator pedal module	06.03-05.04	GS	**0 280 752 214**
1.4 [6X1]			**1,4 l 55 kW AKQ 4 Zyl.**
Knock sensor	10.98-05.99		**0 261 231 045**
Pedal position sensor, EMS (electronic engine management)	10.98-05.99	AG,RLE	**0 280 752 018**
1.4 [6X1]			**1,4 l 55 kW APE; AUA 4 Zyl.**
Knock sensor	05.99-04.02		**0 261 231 045**
1.4 [6X1]			**1,4 l 55 kW BBY 4 Zyl.**
Knock sensor	11.01-07.05		**0 261 231 045**
Accelerator pedal module	06.03-07.05	GS	**0 280 752 214**
1.4 [6X1]			**1,4 l 74 kW AQQ 4 Zyl.**
Knock sensor	05.99-05.00		**0 261 231 045**
1.4 [6X1]			**1,4 l 74 kW AUB 4 Zyl.**
Knock sensor	05.00-07.05		**0 261 231 045**
Accelerator pedal module	06.03-07.05	GS	**0 280 752 214**
1.4 FSI [6X1]			**1,4 l 77 kW ARR 4 Zyl.**
Throttle valve assembly	09.00-11.03		**0 280 750 059**
Air mass meter, gasoline injection	09.00-11.03		**0 280 218 056**
			0 986 280 214
Speed sensor, ignition/injection	09.00-11.03		**0 261 210 213**
Knock sensor	09.00-11.03		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	09.00-11.03		**0 261 230 071**
Accelerator pedal module	06.03-11.03	GS	**0 280 752 214**

V

Product				
◀ Lupo				
1.4 TDI [6X1]			**1,4 l 55 kW AMF 3 Zyl.**	
Air mass meter, diesel	06.98-07.05		**0 281 002 318**	
			0 986 284 002	
Boost pressure sensor, Diesel				
Fg.no. →6E..3..002 000,→6X..3..008 000	06.98-10.02		**0 281 002 177**	
Fg.no. 6E..3..002 000→,6X..3..008 000→	11.02-07.05		**0 281 002 399**	
Pedal position sensor, diesel				
Fg.no. 6X..X..200 001→	05.99-07.05	RLE	**0 281 002 269**	
1.6 GTI [6X1]			**1,6 l 92 kW AVY 4 Zyl.**	
Speed sensor, ignition/injection				
Fg.no. →6X..1..020 000	05.00-07.00		**0 261 210 188**	
Fg.no. 6X..1..020 001→	08.00-07.05		**0 261 210 213**	
Knock sensor	05.00-07.05		**0 261 231 045**	
Accelerator pedal module	05.00-07.05	GS,LLE	**0 280 752 214**	
Pedal position sensor, EMS (electronic engine management)	05.00-07.05	AG,RLE	**0 280 752 018**	
1.7 SDI [6X1]			**1,7 l 42 kW AKU 4 Zyl.**	
Pedal position sensor, diesel				
Fg.no. 6X..X..200 001→	05.99-07.05	RLE	**0 281 002 269**	

Multivan T4

1.8 [70]			**1,8 l 49 kW PD 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	12.90-07.92		**0 265 005 214**
Wheel speed sensor, front	12.90-07.92		**0 265 006 407**
Wheel speed sensor, rear	12.90-07.92	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
1.9 D [70]			**1,9 l 45 kW 1X 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.90-04.97		**0 265 005 214**
Wheel speed sensor, front	09.90-04.97		**0 265 006 407**
Wheel speed sensor, rear	09.90-04.97	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-04.97	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
1.9 D Turbo [70]			**1,9 l 50 kW ABL 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.92-06.03		**0 265 005 214**
Wheel speed sensor, front	10.92-06.03		**0 265 006 407**
Wheel speed sensor, rear	10.92-06.03	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-06.03	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.0 [70]			**2,0 l 62 kW AAC 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.90-06.03		**0 265 005 214**
Wheel speed sensor, front	09.90-06.03		**0 265 006 407**
Wheel speed sensor, rear	09.90-06.03	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-06.03	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.4 D [70]			**2,4 l 55 kW AJA 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	05.97-06.03		**0 265 005 214**
Wheel speed sensor, front	05.97-06.03		**0 265 006 407**
Wheel speed sensor, rear	05.97-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**

Product			
2.4 D [70]			**2,4 l 57 kW AAB 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.90-05.98		**0 265 005 214**
Wheel speed sensor, front	09.90-05.98		**0 265 006 407**
Wheel speed sensor, rear	09.90-05.98	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-05.98	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.4 D Syncro [7D]			**2,4 l 57 kW AAB 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	11.92-09.98		**0 265 005 214**
Wheel speed sensor, front	11.92-09.98		**0 265 006 407**
Wheel speed sensor, rear	11.92-09.98	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-09.98	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.5 [70]			**2,5 l 81 kW AAF 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	11.90-12.93		**0 265 005 214**
Wheel speed sensor, front	11.90-12.93		**0 265 006 407**
Wheel speed sensor, rear	11.90-12.93	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
2.5 [70]			**2,5 l 81 kW ACU 5 Zyl.**
Knock sensor	07.94-10.96	L30	**0 261 231 066**
		L34	**0 261 231 077**
Duo sensor, acceleration and yaw rate, brake system	07.94-10.96		**0 265 005 214**
Wheel speed sensor, front	07.94-10.96		**0 265 006 407**
Wheel speed sensor, rear	07.94-10.96	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-10.96	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.5 [70]			**2,5 l 81 kW AEN 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.95-12.95		**0 265 005 214**
Wheel speed sensor, front	09.95-12.95		**0 265 006 407**
Wheel speed sensor, rear	09.95-12.95	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
2.5 [70]			**2,5 l 81 kW AEU 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	08.96-06.03		**0 265 005 214**
Wheel speed sensor, front	08.96-06.03		**0 265 006 407**
Wheel speed sensor, rear	08.96-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 [70]			**2,5 l 85 kW AET; APL; AVT 5 Zyl.**
Knock sensor	08.96-06.03	L30	**0 261 231 066**
		L34	**0 261 231 077**
Duo sensor, acceleration and yaw rate, brake system	08.96-06.03		**0 265 005 214**
Wheel speed sensor, front	08.96-06.03		**0 265 006 407**
Wheel speed sensor, rear	08.96-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 Syncro [7D]			**2,5 l 81 kW AAF 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	11.92-12.93		**0 265 005 214**
Wheel speed sensor, front	11.92-12.93		**0 265 006 407**
Wheel speed sensor, rear	11.92-12.93	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**

Product			
2.5 Syncro [7D]			**2,5 l 81 kW ACU 5 Zyl.**
Knock sensor	01.94-10.96	L30	**0 261 231 066**
		L34	**0 261 231 077**
Duo sensor, acceleration and yaw rate, brake system	01.94-10.96		**0 265 005 214**
Wheel speed sensor, front	01.94-10.96		**0 265 006 407**
Wheel speed sensor, rear	01.94-10.96	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-10.96	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.5 Syncro [7D]			**2,5 l 81 kW AEU 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	06.97-11.01		**0 265 005 214**
Wheel speed sensor, front	06.97-11.01		**0 265 006 407**
Wheel speed sensor, rear	06.97-11.01	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 Syncro [7D]			**2,5 l 85 kW AET; APL; AVT 5 Zyl.**
Knock sensor	08.96-06.03	L30	**0 261 231 066**
		L34	**0 261 231 077**
Duo sensor, acceleration and yaw rate, brake system	08.96-06.03		**0 265 005 214**
Wheel speed sensor, front	08.96-06.03		**0 265 006 407**
Wheel speed sensor, rear	08.96-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 65 kW AJT 5 Zyl.**
Air mass meter, diesel			
Fg.no. →70..1H048 284,→70..1X047 893	05.98-08.00		**0 281 002 216**
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	05.98-04.01		**0 281 002 177**
Fg.no. 70..1..200 001→	05.01-06.03		**0 281 002 399**
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	05.98-05.99	GS	**0 205 001 020**
Duo sensor, acceleration and yaw rate, brake system	05.98-06.03		**0 265 005 214**
Wheel speed sensor, front	05.98-06.03		**0 265 006 407**
Wheel speed sensor, rear	05.98-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 65 kW AYY 5 Zyl.**
Air mass meter, diesel	10.01-06.03		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel	10.01-06.03		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	10.01-06.03		**0 265 005 214**
Wheel speed sensor, front	10.01-06.03		**0 265 006 407**
Wheel speed sensor, rear	10.01-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 75 kW ACV 5 Zyl.**
Air mass meter, diesel			
Fg.no. →70..1H048 284,→70..1X047 893	05.98-08.00		**0 281 002 216**
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		**0 281 002 463**
			0 986 284 008

Product			
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	01.95-04.01		**0 281 002 177**
Fg.no. 70..1..200 001→	05.01-06.03		**0 281 002 399**
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	01.95-05.99	GS	**0 205 001 020**
Duo sensor, acceleration and yaw rate, brake system	01.95-06.03		**0 265 005 214**
Wheel speed sensor, front	01.95-06.03		**0 265 006 407**
Wheel speed sensor, rear	01.95-06.03	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-06.03	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 75 kW AUF 5 Zyl.**
Air mass meter, diesel			
Fg.no. →70..1H048 284,→70..1X047 893	05.99-08.00		**0 281 002 216**
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	05.99-04.01		**0 281 002 177**
Fg.no. 70..1..200 001→	05.01-06.03		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	05.99-06.03		**0 265 005 214**
Wheel speed sensor, front	05.99-06.03		**0 265 006 407**
Wheel speed sensor, rear	05.99-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 75 kW AXL 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	04.01-06.03		**0 265 005 214**
Wheel speed sensor, front	04.01-06.03		**0 265 006 407**
Wheel speed sensor, rear	04.01-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 75 kW AYC 5 Zyl.**
Air mass meter, diesel	04.01-06.03		**0 281 002 463**
			0 986 284 008
Duo sensor, acceleration and yaw rate, brake system	04.01-06.03		**0 265 005 214**
Wheel speed sensor, front	04.01-06.03		**0 265 006 407**
Wheel speed sensor, rear	04.01-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 111 kW AHY 5 Zyl.**
Air mass meter, diesel			
Fg.no. →70..1..001 319	05.98-05.00		**0 280 217 529**
			0 986 280 204
Fg.no. 70..1..001 320→	06.00-09.00		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	05.98-09.00		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	05.98-05.99	GS	**0 205 001 020**
Duo sensor, acceleration and yaw rate, brake system	05.98-09.00		**0 265 005 214**
Wheel speed sensor, front	05.98-09.00		**0 265 006 407**
Wheel speed sensor, rear	05.98-09.00	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**

V

Product			

◀ Multivan T4

2.5 TDI [70]			**2,5 l 111 kW AXG 5 Zyl.**
Air mass meter, diesel	09.00-06.03		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	09.00-04.01		**0 281 002 177**
Fg.no. 70..1..200 001→	05.01-06.03		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	09.00-06.03		**0 265 005 214**
Wheel speed sensor, front	09.00-06.03		**0 265 006 407**
Wheel speed sensor, rear	09.00-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI Syncro [7D]			**2,5 l 75 kW ACV 5 Zyl.**
Air mass meter, diesel			
Fg.no. →70..1H048 284,→70..1X047 893	05.98-08.00		**0 281 002 216**
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	03.98-04.01		**0 281 002 177**
Fg.no. 70..1..200 001→	05.01-06.03		**0 281 002 399**
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	03.98-05.99	GS	**0 205 001 020**
Duo sensor, acceleration and yaw rate, brake system	03.98-06.03		**0 265 005 214**
Wheel speed sensor, front	03.98-06.03		**0 265 006 407**
Wheel speed sensor, rear	03.98-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI Syncro [7D]			**2,5 l 75 kW AXL 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	04.01-06.03		**0 265 005 214**
Wheel speed sensor, front	04.01-06.03		**0 265 006 407**
Wheel speed sensor, rear	04.01-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.8 [70]			**2,8 l 103 kW AES 6 Zyl.**
Air mass meter, gasoline injection	01.96-05.00		**0 280 217 512**
			0 986 280 203
Phase sensor			
Mot.no. AES 010 241→	12.97-05.00		**0 232 103 019**
Speed sensor, ignition/injection	01.96-05.00		**0 261 210 107**
Temperature sensor, intake air, injection system	01.96-05.00		**0 280 130 039**
Duo sensor, acceleration and yaw rate, brake system	01.96-05.00		**0 265 005 214**
Wheel speed sensor, front	01.96-05.00		**0 265 006 407**
Wheel speed sensor, rear	01.96-05.00	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.8 [70]			**2,8 l 150 kW AMV 6 Zyl.**
Throttle valve assembly	05.00-06.03		**0 280 750 086**
Air mass meter, gasoline injection	05.00-06.03		**0 280 218 017**
			0 986 280 208
Phase sensor	05.00-06.03		**0 232 103 019**
Duo sensor, acceleration and yaw rate, brake system	05.00-06.03		**0 265 005 214**
Wheel speed sensor, front	05.00-06.03		**0 265 006 407**
Wheel speed sensor, rear	05.00-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**

Multivan T5

1.9 TDI [7H]			**1,9 l 62/63/75/77 kW AXB; AXC; BRR; BRS 4 Zyl.**
Air mass meter, diesel	04.03→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	04.03→		**0 281 002 399**
2.0 [7H]			**2,0 l 85 kW AXA 4 Zyl.**
Throttle valve assembly	06.03→		**0 280 750 167**
Air mass meter, gasoline injection	06.03→		**0 280 218 060**
			0 986 280 216
Phase sensor	06.03→		**0 232 101 031**
Knock sensor	06.03→	OHL	**0 261 231 146**
2.5 TDI [7H]			**2,5 l 96/120/128 kW AXD; AXE; BLJ 5 Zyl.**
Air mass meter, diesel	02.03→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	02.03→		**0 281 002 401**
2.5 TDI 4 Motion [7H]			**2,5 l 96/128 kW AXD; AXE 5 Zyl.**
Air mass meter, diesel	07.04→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	07.04→		**0 281 002 401**
3.2 [7H]			**3,2 l 170/173 kW BDL; BKK 6 Zyl.**
Throttle valve assembly	02.03→		**0 280 750 086**
Air mass meter, gasoline injection	02.03→		**0 280 218 073**
			0 986 280 222
Phase sensor	02.03→		**0 232 103 019**
Knock sensor	02.03→	OHL	**0 261 231 146**
3.2 4 Motion [7H]			**3,2 l 173 kW BKK 6 Zyl.**
Throttle valve assembly	07.04→		**0 280 750 086**
Air mass meter, gasoline injection	07.04→		**0 280 218 073**
			0 986 280 222
Phase sensor	07.04→		**0 232 103 019**
Knock sensor	07.04→	OHL	**0 261 231 146**

New Beetle

1.4 [1C1/9C1]			**1,4 l 55 kW BCA 4 Zyl.**
Knock sensor	11.01→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	11.01→		**0 261 230 031**
Accelerator pedal module	11.01→	GS,RLE	**0 280 752 210**
Fg.no. 1C..3..433 666→,9C..3..621 302→	02.03→	GS,LLE	**0 280 752 214**
1.6 [1C1/9C1]			**1,6 l 74 kW AWH 4 Zyl.**
Phase sensor	10.99-10.00		**0 232 101 031**
Speed sensor, ignition/injection	10.99-10.00		**0 261 210 199**
Accelerator pedal module	10.99-10.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.6 [1C1/9C1]			**1,6 l 75 kW AYD 4 Zyl.**
Phase sensor	06.00-06.05		**0 232 101 038**
Speed sensor, ignition/injection	06.00-06.05		**0 261 210 199**
Accelerator pedal module	06.00-05.01	AG,RLE	**0 280 752 213**
	06.00-06.05	GS,RLE	**0 280 752 210**
1.6 [1C1/9C1]			**1,6 l 75 kW BFS 4 Zyl.**
Phase sensor	06.02→		**0 232 101 038**
Speed sensor, ignition/injection	06.02→		**0 261 210 199**
Knock sensor	06.02→		**0 261 231 146**
Accelerator pedal module	06.02→	GS,RLE	**0 280 752 210**
Fg.no. 1C..3..433 666→,9C..3..621 302→	02.03→	GS,LLE	**0 280 752 214**

Product			
1.8 T [1C1/9C1]			**1,8 l 110 kW AGU 4 Zyl.**
Accelerator pedal module	01.98-07.99	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.8 T [1C1/9C1]			**1,8 l 110 kW APH 4 Zyl.**
Throttle valve assembly	11.98-05.01		**0 280 750 036**
Air mass meter, gasoline injection	11.98-05.01		**0 280 218 002**
			0 986 280 205
Phase sensor	11.98-05.01		**0 232 101 024**
Speed sensor, ignition/injection	11.98-05.01		**0 261 210 147**
Knock sensor			
Fg.no. →1C..Y..499 000,→9C..Y..699 000	11.98-04.00		**0 261 231 045**
Fg.no. 1C..1..400 001→,9C..1..600 001→	05.00-05.01		**0 261 231 146**
Boost pressure sensor, gasoline	11.98-05.01		**0 281 002 177**
Temperature sensor, intake air, injection system	11.98-05.01		**0 280 130 085**
Accelerator pedal module	11.98-05.01	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.8 T [1C1/9C1]			**1,8 l 110 kW AVC 4 Zyl.**
Throttle valve assembly	05.99-10.00		**0 280 750 036**
Air mass meter, gasoline injection	05.99-10.00		**0 280 218 002**
			0 986 280 205
Speed sensor, ignition/injection	05.99-10.00		**0 261 210 147**
Knock sensor			
Fg.no. →1C..Y..499 000,→9C..Y..699 000	05.99-04.00		**0 261 231 045**
Fg.no. 1C..1..400 001→,9C..1..600 001→	05.00-10.00		**0 261 231 146**
Boost pressure sensor, gasoline	05.99-10.00		**0 281 002 177**
Temperature sensor, intake air, injection system	05.99-10.00		**0 280 130 085**
Accelerator pedal module	05.99-10.00	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.8 T [1C1/9C1]			**1,8 l 110 kW AWU 4 Zyl.**
Throttle valve assembly	10.00→		**0 280 750 099**
Air mass meter, gasoline injection	10.00→		**0 280 218 063**
			0 986 280 217
Phase sensor	10.00→		**0 232 101 024**
Speed sensor, ignition/injection	10.00→		**0 261 210 147**
Knock sensor	10.00→		**0 261 231 146**
Boost pressure sensor, gasoline	10.00→		**0 281 002 177**
Temperature sensor, intake air, injection system			
Fg.no. →9C..3..608 500	10.00-09.02		**0 280 130 085**
Fg.no. 9C..3..608 501→9C..4..622 249	10.02-06.04		**0 280 130 116**
Accelerator pedal module	10.00-05.01	AG,RLE	**0 280 752 213**
	10.00→	GS,RLE	**0 280 752 210**
Fg.no. 1C..3..433 666→,9C..3..621 302→	02.03→	GS,LLE	**0 280 752 214**
1.8 T [1C1/9C1]			**1,8 l 110 kW AWV 4 Zyl.**
Throttle valve assembly	06.00-06.04		**0 280 750 099**
Air mass meter, gasoline injection	06.00-06.04		**0 280 218 063**
			0 986 280 217
Phase sensor	06.00-06.04		**0 232 101 024**
Knock sensor	06.00-06.04		**0 261 231 146**
Boost pressure sensor, gasoline	06.00-06.04		**0 281 002 177**
Temperature sensor, intake air, injection system			
Fg.no. →9C..3..608 500	06.00-09.02		**0 280 130 085**
Fg.no. 9C..3..608 501→	10.02-06.04		**0 280 130 116**
Accelerator pedal module	06.00-05.01	AG,RLE	**0 280 752 213**
	06.00-06.04	GS,RLE	**0 280 752 210**
Fg.no. 1C..3..433 666→,9C..3..621 302→	02.03-06.04	GS,LLE	**0 280 752 214**
1.8 T [1C1/9C1]			**1,8 l 110 kW BKF 4 Zyl.**
Throttle valve assembly	07.04-06.05		**0 280 750 099**
Air mass meter, gasoline injection	07.04-06.05		**0 280 218 060**
			0 986 280 216
Phase sensor	07.04-06.05		**0 232 101 024**
Boost pressure sensor, gasoline	07.04-06.05		**0 281 002 177**
Accelerator pedal module	07.04-06.05	GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**

Product			
1.8 T [1C1/9C1]			**1,8 l 132 kW AWP 4 Zyl.**
Throttle valve assembly	06.01-06.05		**0 280 750 099**
Air mass meter, gasoline injection	06.01-06.05		**0 280 218 063**
			0 986 280 217
Phase sensor	06.01-06.05		**0 232 101 024**
Speed sensor, ignition/injection	06.01-06.05		**0 261 210 199**
Knock sensor	06.01-06.05		**0 261 231 146**
Boost pressure sensor, gasoline	06.01-06.05		**0 281 002 177**
Temperature sensor, intake air, injection system			
Fg.no. →9C..3..608 500	06.01-09.02		**0 280 130 085**
Fg.no. 9C..3..608 501→9C..4..622 249	10.02-06.04		**0 280 130 116**
Accelerator pedal module	06.01-06.05	GS,RLE	**0 280 752 210**
Fg.no. 1C..3..433 666→,9C..3..621 302→	02.03-06.05	GS,LLE	**0 280 752 214**
1.8 T [1C1/9C1]			**1,8 l 132 kW BNU 4 Zyl.**
Throttle valve assembly	07.04-06.05		**0 280 750 099**
Air mass meter, gasoline injection	07.04-06.05		**0 280 218 060**
			0 986 280 216
Phase sensor	07.04-06.05		**0 232 101 024**
Boost pressure sensor, gasoline	07.04-06.05		**0 281 002 177**
Accelerator pedal module	07.04-06.05	GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
1.9 TDI [1C1/9C1]			**1,9 l 66 kW ALH 4 Zyl.**
Air mass meter, diesel	01.98-06.04		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel	01.98-06.04		**0 281 002 177**
Accelerator pedal module	06.01-06.04	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
Pedal position sensor, diesel			
Fg.no. →1C..W..499 000	01.98-07.98	GS,LLE	**0 281 002 269**
1.9 TDI [1C1/9C1]			**1,9 l 74 kW ATD 4 Zyl.**
Air mass meter, diesel	10.00-06.05		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	10.00-06.05		**0 281 002 399**
Accelerator pedal module	06.01-06.05	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.9 TDI [1C1/9C1]			**1,9 l 74 kW BEW 4 Zyl.**
Air mass meter, diesel	07.03→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	07.05→		**0 281 002 177**
	07.03-06.05		**0 281 002 399**
Accelerator pedal module	07.03→	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
1.9 TDI [1C1/9C1]			**1,9 l 77 kW BSW 4 Zyl.**
Air mass meter, diesel	07.05→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	07.05→		**0 281 002 177**
Accelerator pedal module	07.05→	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**
2.0 [1C1/9C1]			**2,0 l 85 kW AEG 4 Zyl.**
Air mass meter, gasoline injection	01.98-10.01		**0 280 218 002**
			0 986 280 205
Phase sensor	01.98-10.01		**0 232 101 031**
Speed sensor, ignition/injection	01.98-10.01		**0 261 210 147**
Knock sensor	01.98-10.01		**0 261 231 146**
Accelerator pedal module	01.98-05.01	AG,RLE	**0 280 752 213**
	01.98-10.01	GS,RLE	**0 280 752 210**
2.0 [1C1/9C1]			**2,0 l 85 kW APK 4 Zyl.**
Air mass meter, gasoline injection	06.00-06.05		**0 280 218 002**
			0 986 280 205
Phase sensor	06.00-06.05		**0 232 101 031**
Speed sensor, ignition/injection	06.00-06.05		**0 261 210 147**
Knock sensor	06.00-06.05		**0 261 231 146**

V

Product

◀ New Beetle

Accelerator pedal module	06.00-05.01	AG,RLE	**0 280 752 213**
	06.00-06.05	GS,RLE	**0 280 752 210**
Fg.no. 1C..3..433 666→,9C..3..621 302→	02.03-06.05	GS,LLE	**0 280 752 214**
2.0 [1C1/9C1]			**2,0 l 85 kW AQY 4 Zyl.**
Air mass meter, gasoline injection	11.98-06.05		**0 280 218 002**
			0 986 280 205
Phase sensor	11.98-06.05		**0 232 101 031**
Speed sensor, ignition/injection	11.98-06.05		**0 261 210 147**
Knock sensor	11.98-05.01		**0 261 231 045**
	06.01-06.05		**0 261 231 146**
Accelerator pedal module	11.98-05.01	AG,RLE	**0 280 752 213**
	11.98-06.05	GS,RLE	**0 280 752 210**
Fg.no. 1C..3..433 666→,9C..3..621 302→	02.03-06.05	GS,LLE	**0 280 752 214**
2.0 [1C1/9C1]			**2,0 l 85 kW AVH 4 Zyl.**
Throttle valve assembly	09.00-06.05		**0 280 750 061**
Air mass meter, gasoline injection	09.00-06.05		**0 280 218 060**
			0 986 280 216
Phase sensor	09.00-06.05		**0 232 101 031**
Speed sensor, ignition/injection	09.00-06.05		**0 261 210 199**
Knock sensor	09.00-06.05		**0 261 231 146**
Accelerator pedal module	09.00-05.01	AG,RLE	**0 280 752 213**
	09.00-06.05	GS,RLE	**0 280 752 210**
Fg.no. 1C..3..433 666→,9C..3..621 302→	02.03-06.05	GS,LLE	**0 280 752 214**
2.0 [1C1/9C1]			**2,0 l 85 kW AZG 4 Zyl.**
Throttle valve assembly	08.00-06.05		**0 280 750 061**
Air mass meter, gasoline injection	08.00-06.05		**0 280 218 060**
			0 986 280 216
Phase sensor	08.00-06.05		**0 232 101 031**
Accelerator pedal module	08.00-05.01	AG,RLE	**0 280 752 213**
	08.00-06.05	GS,RLE	**0 280 752 210**
Fg.no. 1C..3..433 666→,9C..3..621 302→	02.03-06.05	GS,LLE	**0 280 752 214**
2.0 [1C1/9C1]			**2,0 l 85 kW AZJ 4 Zyl.**
Throttle valve assembly	06.01→		**0 280 750 061**
Air mass meter, gasoline injection	06.01→		**0 280 218 060**
			0 986 280 216
Phase sensor	06.01→		**0 232 101 031**
Speed sensor, ignition/injection	06.01→		**0 261 210 199**
Knock sensor	06.01→		**0 261 231 146**
Accelerator pedal module	06.01→	GS,RLE	**0 280 752 210**
Fg.no. 1C..3..433 666→,9C..3..621 302→	02.03→	GS,LLE	**0 280 752 214**
2.0 [1C1/9C1]			**2,0 l 85 kW BBW 4 Zyl.**
Accelerator pedal module	06.02-06.04	GS,RLE	**0 280 752 210**
Fg.no. 1C..3..433 666→,9C..3..621 302→	02.03-06.04	GS,LLE	**0 280 752 214**
2.0 [1C1/9C1]			**2,0 l 85 kW BEJ 4 Zyl.**
Throttle valve assembly	11.01-06.05		**0 280 750 061**
Air mass meter, gasoline injection	11.01-06.05		**0 280 218 060**
			0 986 280 216
Speed sensor, ignition/injection	11.01-06.05		**0 261 210 199**
Accelerator pedal module	11.01-06.05	GS,RLE	**0 280 752 210**
Fg.no. 1C..3..433 666→,9C..3..621 302→	02.03-06.05	GS,LLE	**0 280 752 214**
2.0 [1C1/9C1]			**2,0 l 85 kW BER 4 Zyl.**
Throttle valve assembly	01.03→	NOR	**0 280 750 061**
Air mass meter, gasoline injection	01.03→		**0 280 218 060**
			0 986 280 216
Phase sensor	01.03→		**0 232 101 031**
Speed sensor, ignition/injection			
Fg.no. →1C..7..512 080,→9C..7..555 760	01.03-11.06		**0 261 210 147**
Fg.no. 1C..7..512 081→,9C..7..555 761→	12.06→		**0 261 210 178**
Knock sensor	01.03→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	01.03→		**0 261 230 095**
Accelerator pedal module	01.03→	GS,RLE	**0 280 752 210**
Fg.no. 1C..3..433 666→,9C..3..621 302→	02.03→	GS,LLE	**0 280 752 214**

Product

2.0 [1C1/9C1]			**2,0 l 85 kW BEV 4 Zyl.**
Throttle valve assembly	07.04-06.05	NOR	**0 280 750 061**
Air mass meter, gasoline injection	07.04-06.05		**0 280 218 060**
			0 986 280 216
Phase sensor	07.04-06.05		**0 232 101 031**
Speed sensor, ignition/injection	07.04-06.05		**0 261 210 199**
Accelerator pedal module	07.04-06.05	GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
2.0 [1C1/9C1]			**2,0 l 85 kW BHP 4 Zyl.**
Throttle valve assembly	07.03→	NOR	**0 280 750 061**
Air mass meter, gasoline injection	07.03→		**0 280 218 060**
			0 986 280 216
Phase sensor	07.03→		**0 232 101 031**
Speed sensor, ignition/injection			
Fg.no. →1C..7..512 080,→9C..7..555 760	07.03-11.06		**0 261 210 147**
Fg.no. 1C..7..512 081→,9C..7..555 761→	12.06→		**0 261 210 178**
Knock sensor	07.03→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	07.03→		**0 261 230 095**
Accelerator pedal module	07.03→	GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
2.3 [1C1/9C1]			**2,3 l 125 kW AQN 5 Zyl.**
Throttle valve assembly	10.00-06.05		**0 280 750 097**
Air mass meter, gasoline injection	10.00-06.05		**0 280 218 017**
			0 986 280 208
Phase sensor	10.00-06.05		**0 232 103 019**
Knock sensor	10.00-06.05		**0 261 231 146**
Accelerator pedal module	10.00-05.01	AG,RLE	**0 280 752 213**
	10.00-06.05	GS,RLE	**0 280 752 210**
Fg.no. 1C..3..433 666→,9C..3..621 302→	02.03-06.05	GS,LLE	**0 280 752 214**
2.5 [1C1/9C1]			**2,5 l 110 kW BPR; BPS 5 Zyl.**
Air mass meter, gasoline injection	07.05→		**0 280 218 071**
			0 986 280 221
Pressure sensor, intake manifold, gasoline	07.05→		**0 261 230 081**
Accelerator pedal module	07.05→	GS,LLE	**0 280 752 214**
		GS,RLE	**0 280 752 210**
3.2 RSI [1C1/9C1]			**3,2 l 165 kW AXJ 6 Zyl.**
Throttle valve assembly	10.00-05.01		**0 280 750 086**
Air mass meter, gasoline injection	10.00-05.01		**0 280 218 017**
			0 986 280 208
Phase sensor	10.00-05.01		**0 232 103 019**
Accelerator pedal module	10.00-05.01	AG,RLE	**0 280 752 213**
		GS,RLE	**0 280 752 210**

New Beetle Cabriolet

1.4 [1Y7]			**1,4 l 55 kW BCA 4 Zyl.**
Knock sensor	01.03→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	01.03→		**0 261 230 031**
Accelerator pedal module	01.03→	FMT,RLE	**0 280 752 213**
		FOT,RLE	**0 280 752 210**
1.6 [1Y7]			**1,6 l 75 kW BFS 4 Zyl.**
Speed sensor, ignition/injection	01.03→		**0 261 210 199**
Knock sensor	01.03→		**0 261 231 146**
Accelerator pedal module	01.03→	FMT,RLE	**0 280 752 213**
		FOT,RLE	**0 280 752 210**
1.8 T [1Y7]			**1,8 l 110 kW AWU 4 Zyl.**
Throttle valve assembly	12.03→		**0 280 750 099**
Air mass meter, gasoline injection	12.03→		**0 280 218 063**
			0 986 280 217
Phase sensor	12.03→		**0 232 101 024**
Speed sensor, ignition/injection	12.03→		**0 261 210 147**
Knock sensor	12.03→		**0 261 231 146**
Boost pressure sensor, gasoline	12.03→		**0 281 002 177**

Product			
Accelerator pedal module	12.03→	FMT,RLE	**0 280 752 213**
		FOT,RLE	**0 280 752 210**
1.8 T [1Y7]			**1,8 l 110 kW AWV 4 Zyl.**
Throttle valve assembly	01.03-06.04		**0 280 750 099**
Air mass meter, gasoline injection	01.03-06.04		**0 280 218 063**
			0 986 280 217
Phase sensor	01.03-06.04		**0 232 101 024**
Speed sensor, ignition/injection	01.03-06.04		**0 261 210 199**
Knock sensor	01.03-06.04		**0 261 231 146**
Boost pressure sensor, gasoline	01.03-06.04		**0 281 002 177**
Temperature sensor, intake air, injection system			
Fg.no. →1Y..4..309 197	01.03-08.03		**0 280 130 116**
Accelerator pedal module	01.03-06.04	FMT,RLE	**0 280 752 213**
		FOT,RLE	**0 280 752 210**
1.8 T [1Y7]			**1,8 l 110 kW BKF 4 Zyl.**
Throttle valve assembly	07.04-06.05		**0 280 750 099**
Air mass meter, gasoline injection	07.04-06.05		**0 280 218 060**
			0 986 280 216
Speed sensor, ignition/injection	07.04-06.05		**0 261 210 199**
Boost pressure sensor, gasoline	07.04-06.05		**0 281 002 177**
Accelerator pedal module	07.04-06.05	FMT,RLE	**0 280 752 213**
		FOT,RLE	**0 280 752 210**
1.9 TDI [1Y7]			**1,9 l 74 kW AXR 4 Zyl.**
Air mass meter, diesel	06.03-06.05		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	06.03-06.05	TW	**0 281 002 177**
			0 281 002 399
1.9 TDI [1Y7]			**1,9 l 77 kW BSW 4 Zyl.**
Air mass meter, diesel	07.05→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	07.05→		**0 281 002 177**
Pressure sensor, intake manifold, diesel	07.05→		**0 281 002 399**
2.0 [1Y7]			**2,0 l 85 kW AZJ; BDC 4 Zyl.**
Throttle valve assembly	01.03→		**0 280 750 061**
Air mass meter, gasoline injection	01.03→		**0 280 218 060**
			0 986 280 216
Phase sensor	01.03→		**0 232 101 031**
Speed sensor, ignition/injection	01.03→		**0 261 210 199**
Knock sensor	01.03→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	01.03→		**0 281 002 177**
Accelerator pedal module	01.03→	FMT,RLE	**0 280 752 213**
		FOT,RLE	**0 280 752 210**
2.0 [1Y7]			**2,0 l 85 kW BEV 4 Zyl.**
Speed sensor, ignition/injection	07.04→		**0 261 210 147**
Pressure sensor, intake manifold, gasoline	07.04→		**0 281 002 177**
Accelerator pedal module	07.04→	FMT,RLE	**0 280 752 213**
		FOT,RLE	**0 280 752 210**
2.0 [1Y7]			**2,0 l 85 kW BGD 4 Zyl.**
Air mass meter, gasoline injection	01.03-06.05		**0 280 218 060**
			0 986 280 216
Phase sensor	01.03-06.05		**0 232 101 031**
Speed sensor, ignition/injection	01.03-06.05		**0 261 210 199**
Knock sensor	01.03-06.05		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	01.03-06.05		**0 281 002 177**
Accelerator pedal module	01.03-06.05	FMT,RLE	**0 280 752 213**
		FOT,RLE	**0 280 752 210**
2.5 [1Y7]			**2,5 l 110 kW BPR; BPS 5 Zyl.**
Air mass meter, gasoline injection	07.05→		**0 280 218 071**
			0 986 280 221
Pressure sensor, intake manifold, gasoline	07.05→		**0 261 230 081**
Accelerator pedal module	07.05→	FMT,RLE	**0 280 752 213**
		FOT,RLE	**0 280 752 210**

Product			

Parati III

1.8 Mi			**1,8 l 72 kW UDH 4 Zyl.**
Knock sensor	08.99-08.05		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	08.99-08.05		**0 261 230 095**
Wheel speed sensor, front	08.99-08.05		**0 265 006 218**
Wheel speed sensor, rear	08.99-08.05	LAB,TU2	**0 265 006 222**
		LAB,TU4	**0 265 006 410**
		RAB,TU2	**0 265 006 221**
		RAB,TU4	**0 265 006 411**

Passat

1.6 [3B2]			**1,6 l 74 kW ADP 4 Zyl.**
Knock sensor	10.96-11.00	KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	10.96-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	10.96-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	10.96-11.00	5PO	**0 265 005 207**
1.6 [3B2]			**1,6 l 74 kW AHL 4 Zyl.**
Phase sensor	10.96-11.00		**0 232 103 019**
Speed sensor, ignition/injection	10.96-11.00	AG5,GS	**0 261 210 147**
Knock sensor	10.96-11.00	KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	10.96-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	10.96-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	10.96-11.00	5PO	**0 265 005 207**
1.6 [3B2]			**1,6 l 74 kW ANA; ARM 4 Zyl.**
Speed sensor, ignition/injection	01.99-11.00	AG5,GS	**0 261 210 147**
Knock sensor	01.99-11.00	KZG	**0 261 231 038**
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	01.99-11.00	5PO	**0 265 005 207**
1.6 [3B3]			**1,6 l 75 kW ALZ 4 Zyl.**
Phase sensor			
Fg.no. →3B..2..240 126	10.00-10.01		**0 232 101 038**
Speed sensor, ignition/injection	10.00-05.05		**0 281 002 222**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
1.6 [3C2]			**1,6 l 75 kW BSE; BSF 4 Zyl.**
Speed sensor, ignition/injection	03.05→		**0 261 210 199**
Knock sensor	03.05→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	03.05→		**0 261 230 031**
1.6 [31, 35, 3A..]			**1,6 l 55 kW 1F 4 Zyl.**
Temperature sensor, coolant, injection system	08.88-07.90		**0 280 130 040**
1.6 [31, 35, 3A..]			**1,6 l 74 kW AEK 4 Zyl.**
Air mass meter, gasoline injection	10.94-12.95		**0 280 217 103**
Knock sensor	10.94-12.95	KZB	**0 261 231 036**
1.6 [31, 35, 3A..]			**1,6 l 74 kW AFT 4 Zyl.**
Knock sensor	12.95-03.97	KZB	**0 261 231 036**
Temperature sensor, intake air, injection system	12.95-03.97		**0 280 130 039**
1.6 FSI [3C2]			**1,6 l 85 kW BLF 4 Zyl.**
Speed sensor, ignition/injection	03.05→	AG	**0 261 210 250**
Knock sensor	03.05→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	03.05→		**0 261 230 095**

V

Product			
◀ Passat			
1.8 [B5]			**1,8 l 92 kW ANQ 4 Zyl.**
Air mass meter, gasoline injection	11.99-02.03		**0 280 218 013**
			0 986 280 206
Phase sensor	11.99-02.03		**0 232 101 024**
Speed sensor, ignition/injection	11.99-02.03		**0 261 210 147**
Knock sensor	11.99-02.03	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	11.99-02.03		**0 280 130 085**
1.8 [3B2]			**1,8 l 85 kW AFY 4 Zyl.**
Temperature sensor, intake air, injection system	01.97-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.97-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	01.97-11.00	5PO	**0 265 005 207**
1.8 [3B2]			**1,8 l 92 kW ADR 4 Zyl.**
Air mass meter, gasoline injection			
Fg.no. 3B..X..400 001→	01.99-01.99		**0 280 218 013**
			0 986 280 206
Phase sensor	12.96-01.99		**0 232 101 024**
Knock sensor	12.96-01.99	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	12.96-01.99		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	12.96-01.99	6PO	**0 265 005 214**
Yaw rate sensor, brake system	12.96-01.99	5PO	**0 265 005 207**
1.8 [3B2]			**1,8 l 92 kW APT; ARG 4 Zyl.**
Throttle valve assembly			
Fg.no. 3B..X..550 001→	05.99-11.00		**0 280 750 080**
Air mass meter, gasoline injection	01.99-11.00		**0 280 218 013**
			0 986 280 206
Knock sensor	01.99-11.00	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	01.99-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	01.99-11.00	5PO	**0 265 005 207**
1.8 [3B3]			**1,8 l 110 kW AWT 4 Zyl.**
Throttle valve assembly	10.00-05.05		**0 280 750 009**
Air mass meter, gasoline injection			
Fg.no. →3B..2..100 000	10.00-06.01		**0 280 218 063**
			0 986 280 217
Fg.no. 3B..2..100 001→	07.01-05.05		**0 280 218 100**
			0 986 280 223
Phase sensor	10.00-05.05		**0 232 101 024**
Speed sensor, ignition/injection	10.00-05.05		**0 281 002 222**
Boost pressure sensor, gasoline			
Fg.no. →3B..3..350 000	10.00-02.03		**0 281 002 177**
Fg.no. 3B..3..350 001→	03.03-05.05		**0 261 230 073**
Temperature sensor, intake air, injection system	10.00-05.05		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
1.8 [3B3]			**1,8 l 125 kW AWM 4 Zyl.**
Throttle valve assembly	10.00-05.05		**0 280 750 009**
Air mass meter, gasoline injection			
Fg.no. →3B..2..100 000	10.00-06.01		**0 280 218 063**
			0 986 280 217
Fg.no. 3B..2..100 001→	07.01-05.05		**0 280 218 100**
			0 986 280 223

Product			
Boost pressure sensor, gasoline			
Fg.no. →3B..3..350 000	10.00-02.03		**0 281 002 177**
Fg.no. 3B..3..350 001→	03.03-05.05		**0 261 230 073**
Temperature sensor, intake air, injection system	10.00-05.05		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
1.8 [31, 35, 3A..]			**1,8 l 55/66 kW AAM; ABS 4 Zyl.**
Temperature sensor, coolant, injection system	08.90-03.97		**0 280 130 040**
1.8 [31, 35, 3A..]			**1,8 l 66 kW RP 4 Zyl.**
Knock sensor	08.88-07.91	KZG	**0 261 231 004**
Temperature sensor, coolant, injection system	04.88-07.91		**0 280 130 040**
1.8 [31, 35, 3A..]			**1,8 l 79 kW PF 4 Zyl.**
Air flow sensor, gasoline injection	04.88-07.90		**0 280 202 106**
			0 986 280 008
Knock sensor	08.88-07.90	KZG	**0 261 231 004**
1.8 [31, 35, 3A..]			**1,8 l 82 kW PB 4 Zyl.**
Air flow sensor, gasoline injection	04.88-07.90		**0 280 200 041**
Knock sensor	04.88-07.90		**0 261 231 038**
1.8 [31, 35, 3A..]			**1,8 l 100 kW KR 4 Zyl.**
Air flow sensor, gasoline injection	04.88-07.92		**F 026 TX2 050**
			F 026 TX2 050
1.8 [32B]			**1,8 l 66 kW JN 4 Zyl.**
Air flow sensor, gasoline injection	08.84-03.88		**F 026 TX2 063**
			F 026 TX2 063
1.8 G60 syncro [312,315,3A5]			**1,8 l 118 kW PG 4 Zyl.**
Knock sensor	09.89-07.93	KZG	**0 261 231 038**
1.8 syncro [3B2]			**1,8 l 92 kW ADR 4 Zyl.**
Throttle valve assembly			
Fg.no. 3B..X..550 001→	05.99-11.00		**0 280 750 080**
Air mass meter, gasoline injection			
Fg.no. 3B..X..400 001→	02.99-11.00		**0 280 218 013**
			0 986 280 206
Phase sensor	06.97-11.00		**0 232 101 024**
Knock sensor	06.97-11.00	KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	06.97-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	06.97-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	06.97-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	06.97-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
Fg.no. 3B..X..338 107→	11.98-11.00	ALR,LAB, OFD	**0 265 006 575**
		ALR,OFD, RAB	**0 265 006 573**
		OFD,OLW	**0 265 006 573**
1.8 syncro [3B2]			**1,8 l 92 kW APT 4 Zyl.**
Throttle valve assembly			
Fg.no. 3B..X..550 001→	05.99-11.00		**0 280 750 080**
Air mass meter, gasoline injection	01.99-11.00		**0 280 218 013**
			0 986 280 206
Phase sensor	01.99-11.00		**0 232 101 024**
Knock sensor	01.99-11.00	KZG	**0 261 231 038**
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	**0 265 005 214**

Product			
Yaw rate sensor, brake system	01.99-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	01.99-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,LAB, OFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		ALR,OFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
		OFD,OWR	**0 265 006 573**
1.8 syncro [3B2]			**1,8 l 92 kW ARG 4 Zyl.**
Throttle valve assembly			
Fg.no. 3B..X..550 001→	05.99-11.00		**0 280 750 080**
Air mass meter, gasoline injection	02.99-11.00		**0 280 218 013**
			0 986 280 206
Phase sensor	02.99-11.00		**0 232 101 024**
Knock sensor	02.99-11.00	KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	02.99-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	02.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	02.99-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	02.99-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,LAB, OFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		ALR,OFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
		OFD,OWR	**0 265 006 573**
1.8 Turbo [B5]			**1,8 l 110 kW AWL 4 Zyl.**
Throttle valve assembly	10.01→		**0 280 750 009**
Air mass meter, gasoline injection	10.01-07.02		**0 280 218 063**
			0 986 280 217
	08.02→		**0 280 218 100**
			0 986 280 223
Phase sensor	10.01→		**0 232 101 024**
Speed sensor, ignition/injection	10.01→		**0 281 002 222**
Knock sensor	10.01→	KZB	**0 261 231 036**
		KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	10.01→		**0 280 130 085**
1.8 Turbo [3B2]			**1,8 l 110 kW AEB 4 Zyl.**
Air mass meter, gasoline injection			
Fg.no. WE175000/WP150000→	09.97-11.00		**0 280 217 117**
			0 986 280 201
Fg.no. →WE175000/WP150000	10.96-08.97		**0 280 217 112**
Phase sensor	10.96-11.00		**0 232 101 024**
Knock sensor	10.96-11.00	KZG	**0 261 231 038**
Pressure sensor, intake manifold, gasoline	10.96-11.00		**0 280 101 001**
Temperature sensor, intake air, injection system	10.96-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	10.96-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	10.96-11.00	5PO	**0 265 005 207**
1.8 Turbo [3B2]			**1,8 l 110 kW ANB; APU 4 Zyl.**
Throttle valve assembly	08.98-11.00		**0 280 750 009**
Air mass meter, gasoline injection	08.98-11.00		**0 280 218 023**
			0 986 280 209
Knock sensor	08.98-11.00	KZG	**0 261 231 038**
Duo sensor, acceleration and yaw rate, brake system	08.98-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	08.98-11.00	5PO	**0 265 005 207**

Product			
1.9 TDI [3B2]			**1,9 l 66 kW AHH 4 Zyl.**
Air mass meter, diesel	08.97-11.00		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	08.97-11.00		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. →3B..W..140 000	08.97-08.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
Fg.no. 3B..W..140 001→3B..W..222 092	08.97-10.97	AG	**0 281 002 254**
		GS	**0 281 002 229**
Fg.no. 3B..W..222 093→3B..X..600 000	10.97-04.99	AG	**0 281 002 289**
		GS	**0 281 002 286**
Duo sensor, acceleration and yaw rate, brake system	08.97-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	08.97-11.00	5PO	**0 265 005 207**
1.9 TDI [3B2]			**1,9 l 66 kW AHU 4 Zyl.**
Air mass meter, diesel			
Fg.no. WE118001/WP100001→	09.97-11.00		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	10.96-11.00		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. →3B..W..140 000	10.96-08.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
Fg.no. 3B..W..140 001→3B..W..222 092	08.97-10.97	AG	**0 281 002 254**
		GS	**0 281 002 229**
Fg.no. 3B..W..222 093→3B..X..600 000	10.97-04.99	AG	**0 281 002 289**
		GS	**0 281 002 286**
Duo sensor, acceleration and yaw rate, brake system	10.96-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	10.96-11.00	5PO	**0 265 005 207**
1.9 TDI [3B2]			**1,9 l 74 kW AVB 4 Zyl.**
Air mass meter, diesel	02.00-11.00		**0 281 002 216**
			0 986 284 001
Yaw rate sensor, brake system	02.00-11.00		**0 265 005 207**
		5PO	**0 265 005 207**
1.9 TDI [3B2]			**1,9 l 81 kW AFN 4 Zyl.**
Air mass meter, diesel			
Fg.no. WE118001/WP100001→	09.97-11.00		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	10.96-11.00		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. →3B..W..140 000	10.96-08.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
Fg.no. 3B..W..140 001→3B..W..222 092	08.97-10.97	AG	**0 281 002 254**
		GS	**0 281 002 229**
Fg.no. 3B..W..222 093→3B..X..600 000	10.97-04.99	AG	**0 281 002 289**
		GS	**0 281 002 286**
Duo sensor, acceleration and yaw rate, brake system	10.96-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	10.96-11.00	5PO	**0 265 005 207**
1.9 TDI [3B2]			**1,9 l 81 kW AVG 4 Zyl.**
Air mass meter, diesel	08.99-11.00		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	08.99-11.00		**0 281 002 177**
Duo sensor, acceleration and yaw rate, brake system	08.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	08.99-11.00	5PO	**0 265 005 207**
1.9 TDI [3B2]			**1,9 l 85 kW AJM 4 Zyl.**
Air mass meter, diesel	01.98-11.00		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	01.98-11.00		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. →3B..X..600 000	01.98-04.99	AG	**0 281 002 289**
		GS	**0 281 002 286**

V

Product

◀ Passat

Duo sensor, acceleration and yaw rate, brake system	01.98-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	01.98-11.00	5PO	**0 265 005 207**
1.9 TDI [3B2]			**1,9 l 85 kW ATJ 4 Zyl.**
Air mass meter, diesel	12.99-11.00		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	12.99-11.00		**0 281 002 177**
Duo sensor, acceleration and yaw rate, brake system	12.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	12.99-11.00	5PO	**0 265 005 207**
1.9 TDI [3B3]			**1,9 l 74 kW AVB 4 Zyl.**
Air mass meter, diesel			
Fg.no. →3B..2P241 613,→3B..2P240 805, →3B..2E262 022	10.00-10.01		**0 281 002 216**
			0 986 284 001
Fg.no. 3B..2P241 614→,3B..2P240 806→, 3B..2E262 023→	11.01-05.05		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →3B..2..250 000	10.00-10.01		**0 281 002 177**
Fg.no. 3B..2..250 000→	11.01-05.05		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
1.9 TDI [3B3]			**1,9 l 96 kW AVF; AWX 4 Zyl.**
Air mass meter, diesel			
Fg.no. →3B..1..400 000	10.00-04.01		**0 280 217 529**
			0 986 280 204
Fg.no. 3B..2..000 001→	05.01-05.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	10.00-05.05		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
1.9 TDI [3C2]			**1,9 l 77 kW BKC; BLS; BXE 4 Zyl.**
Air mass meter, diesel	03.05→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	03.05→		**0 281 002 399**
1.9 TDI [31, 35, 3A..]			**1,9 l 66 kW AHU 4 Zyl.**
Pedal position sensor, diesel	08.96-12.96	LLE	**0 205 001 032**
		RLE	**0 205 001 024**
1.9 TDI [31, 35, 3A..]			**1,9 l 66 kW 1Z 4 Zyl.**
Pressure sensor, intake manifold, diesel			
Fg.no. →3A..SE085 001,→3A..SB012 818, →3A..RE027 690	10.93-09.94		**0 261 230 037**
Pedal position sensor, diesel			
Fg.no. →3A..S..192 818	10.93-04.95	LLE	**0 205 001 024**
		RLE	**0 205 001 023**
Fg.no. 3A..S..192 819→	05.95-07.96	AG	**0 205 001 031**
		GS	**0 205 001 032**
1.9 TDI syncro [3B2]			**1,9 l 81 kW AFN 4 Zyl.**
Air mass meter, diesel			
Fg.no. WE 106 001→,WP 090 001→	08.97-11.00		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	06.97-11.00		**0 281 002 177**

Product

Pedal position sensor, diesel			
Fg.no. →3B..W..140 000	06.97-08.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
Fg.no. 3B..W..140 001→3B..W..222 092	09.97-10.97	GS	**0 281 002 229**
Fg.no. 3B..W..140 001→3B..X..600 000	09.97-04.99	AG	**0 281 002 289**
Fg.no. 3B..W..222 093→3B..X..600 000	11.97-04.99	GS	**0 281 002 286**
Duo sensor, acceleration and yaw rate, brake system	06.97-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	06.97-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	06.97-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
Fg.no. 3B..X..338 107→	11.98-11.00	ALR,LAB, OFD	**0 265 006 575**
		ALR,OFD, RAB	**0 265 006 573**
		OFD,OLW	**0 265 006 573**
1.9 TDI syncro [3B2]			**1,9 l 81 kW AVG 4 Zyl.**
Air mass meter, diesel	08.99-08.00		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel			
Fg.no. 3B..W..040 001→	08.99-08.00		**0 281 002 177**
Duo sensor, acceleration and yaw rate, brake system	08.99-08.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	08.99-08.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	08.99-08.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,LAB, OFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		ALR,OFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
		OFD,OWR	**0 265 006 573**
1.9 TDI syncro [3B2]			**1,9 l 85 kW AJM 4 Zyl.**
Pedal position sensor, diesel			
Fg.no. →3B..X..600 000	11.97-04.99	AG	**0 281 002 289**
		GS	**0 281 002 286**
Duo sensor, acceleration and yaw rate, brake system	11.97-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	11.97-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	11.97-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
Fg.no. 3B..X..338 107→	11.98-11.00	ALR,LAB, OFD	**0 265 006 575**
		ALR,OFD, RAB	**0 265 006 573**
		OFD,OLW	**0 265 006 573**
1.9 TDI 4 Motion [3B3]			**1,9 l 96 kW AVF; AWX 4 Zyl.**
Air mass meter, diesel			
Fg.no. →3B..1..400 000	10.00-04.01		**0 280 217 529**
			0 986 280 204
Fg.no. 3B..2..000 001→	05.01-05.05		**0 281 002 461**
			0 986 284 007
Pressure sensor, intake manifold, diesel	10.00-05.05		**0 281 002 401**

Product			
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05		**0 265 006 573**
2.0 [3B2]			**2,0 l 88 kW ASU; AUZ 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	01.00-08.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	01.00-08.00	5PO	**0 265 005 207**
2.0 [3B3]			**2,0 l 85 kW AZM 4 Zyl.**
Phase sensor	10.00-05.05		**0 232 101 031**
Speed sensor, ignition/injection	10.00-05.05		**0 261 210 147**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
2.0 [3B3]			**2,0 l 95 kW ALT 4 Zyl.**
Throttle valve assembly	11.01-05.05		**0 280 750 088**
Air mass meter, gasoline injection	11.01-05.05		**0 280 218 058**
			0 986 280 215
Phase sensor	11.01-05.05		**0 232 101 024**
Speed sensor, ignition/injection	11.01-05.05		**0 281 002 222**
Pressure sensor, ESP, (electronic stability program)	11.01-05.05		**0 265 005 303**
Wheel speed sensor, front	11.01-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	11.01-05.05	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
2.0 [31, 35, 3A..]			**2,0 l 85 kW ADY 4 Zyl.**
Knock sensor	10.94-07.95	KZG	**0 261 231 004**
2.0 [31, 35, 3A..]			**2,0 l 85 kW AGG 4 Zyl.**
Knock sensor	07.95-03.97	KZG	**0 261 231 038**
2.0 [31, 35, 3A..]			**2,0 l 85 kW 2E 4 Zyl.**
Knock sensor	03.90-09.94	KZB	**0 261 231 036**
2.0 [31, 35, 3A..]			**2,0 l 100 kW 9A 4 Zyl.**
Throttle valve sensor	08.88-09.93	AG	**0 280 120 433**
		GS	**0 280 120 426**
Air flow sensor, gasoline injection			
Fg.no. →31-N-400 000	08.88-07.92		**0 438 121 076**
			0 986 439 376
Fg.no. 31-P-000 001→	07.92-09.93		**0 986 439 389**
			F 026 TX2 059
			0 986 439 389
Knock sensor	08.88-09.93	KZG	**0 261 231 004**
Temperature sensor, coolant, injection system	08.88-09.93		**0 280 130 040**
2.0 [31, 35, 3A..]			**2,0 l 110 kW ABF 4 Zyl.**
Knock sensor	01.94-03.97	KZG	**0 261 231 004**
2.0 [32B]			**2,0 l 85 kW HP; JS 5 Zyl.**
Air flow sensor, gasoline injection	08.83-01.86	MZF	**0 438 121 005**
2.0 FSI [3C2]			**2,0 l 110 kW BLR; BLY; BVY; BVZ 4 Zyl.**
Knock sensor	03.05→	OHL	**0 261 231 146**
Pressure sensor, intake manifold, gasoline	03.05→		**0 261 230 031**
2.0 FSI 4 Motion [3C2]			**2,0 l 110 kW BLX; BLY; BVX 4 Zyl.**
Knock sensor	09.05→	OHL	**0 261 231 146**
Pressure sensor, intake manifold, gasoline	09.05→		**0 261 230 031**
2.0 i [B5]			**2,0 l 85 kW BFF 4 Zyl.**
Air mass meter, gasoline injection	03.03-02.07		**0 280 218 132**
Phase sensor	03.03-02.07		**0 232 101 094**

Product			
Speed sensor, ignition/injection	03.03-02.07		**0 261 210 241**
Knock sensor	03.03-02.07		**0 261 231 146**
2.0 syncro [312,315,3A5]			**2,0 l 85 kW 2E 4 Zyl.**
Air flow sensor, gasoline injection	10.90-09.94		**0 280 202 106**
			0 986 280 008
Knock sensor	10.90-09.94	KZB	**0 261 231 036**
2.0 TDI [3B3]			**2,0 l 100 kW BGW 4 Zyl.**
Air mass meter, diesel	11.03-05.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	11.03-05.05		**0 281 002 401**
Pressure sensor, ESP, (electronic stability program)	11.03-05.05		**0 265 005 303**
Wheel speed sensor, front	11.03-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	11.03-05.05	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
2.0 TDI [3C2]			**2,0 l 88/90/100/103 kW BKP; BMA; BVD; BVE; BWV 4 Zyl.**
Air mass meter, diesel	03.05→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	03.05→		**0 281 002 401**
2.0 TDI [3C2]			**2,0 l 103/120/125 kW BMP; BMR; BUZ 4 Zyl.**
Air mass meter, diesel	03.05→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	03.05→		**0 281 002 401**
2.0 TDI 4 Motion [3C2]			**2,0 l 103 kW BKP; BMP 4 Zyl.**
Air mass meter, diesel	03.05→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	03.05→		**0 281 002 401**
2.0 TFSI [3C2]			**2,0 l 147 kW AXX; BPY; BWA 4 Zyl.**
Speed sensor, ignition/injection	03.05→		**0 261 210 199**
Boost pressure sensor, gasoline	03.05→		**0 261 230 073**
2.0 4 Motion [3B3]			**2,0 l 85 kW AZM 4 Zyl.**
Phase sensor	10.00-05.05		**0 232 101 031**
Speed sensor, ignition/injection	10.00-05.05		**0 261 210 147**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05		**0 265 006 573**
2.2 [32B]			**2,2 l 85 kW KX 5 Zyl.**
Air flow sensor, gasoline injection	08.85-03.88		**F 026 TX2 064**
			F 026 TX2 064
Pressure sensor, intake manifold, gasoline	08.85-03.88		**0 280 101 001**
Temperature sensor, coolant, injection system	08.85-03.88		**0 280 130 037**
2.2 [32B]			**2,2 l 100 kW HY 5 Zyl.**
Air flow sensor, gasoline injection	02.86-03.88		**0 438 120 211**
	01.85-01.86	MZF	**0 438 121 005**
2.2 [32B]			**2,2 l 100 kW KV 5 Zyl.**
Air flow sensor, gasoline injection	01.85-01.86	MZF	**0 438 121 005**
2.3 [3B2]			**2,3 l 110 kW AGZ 5 Zyl.**
Air mass meter, gasoline injection	10.96-11.00		**0 280 217 529**
			0 986 280 204
Phase sensor	10.96-11.00		**0 232 103 019**
Speed sensor, ignition/injection	10.96-11.00	AG5,GS	**0 261 210 139**
Temperature sensor, intake air, injection system			
Fg.no. →3B..X..030 000	10.96-05.98		**0 280 130 039**
Fg.no. 3B..X..030 001→	05.98-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	10.96-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	10.96-11.00	5PO	**0 265 005 207**

V

Product			
◀ Passat			
2.3 [3B3]			**2,3 l 125 kW AZX 5 Zyl.**
Throttle valve assembly	10.00-05.05		**0 280 750 097**
Air mass meter, gasoline injection	10.00-05.05		**0 280 218 017**
			0 986 280 208
Phase sensor	10.00-05.05		**0 232 103 019**
Speed sensor, ignition/injection	10.00-05.05		**0 261 210 177**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
2.3 syncro [3B2]			**2,3 l 110 kW AGZ 5 Zyl.**
Air mass meter, gasoline injection	06.97-11.00		**0 280 217 529**
			0 986 280 204
Phase sensor	06.97-11.00		**0 232 103 019**
Speed sensor, ignition/injection	06.97-11.00		**0 261 210 139**
Temperature sensor, intake air, injection system			
Fg.no. →3B..X..132 000	06.97-08.98		**0 280 130 039**
Fg.no. 3B..X..132 001→	09.98-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	06.97-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	06.97-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	06.97-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
Fg.no. 3B..X..338 107→	11.98-11.00	ALR,LAB, OFD	**0 265 006 575**
		ALR,OFD, RAB	**0 265 006 573**
		OFD,OLW	**0 265 006 573**
2.3 4 Motion [3B3]			**2,3 l 125 kW AZX 5 Zyl.**
Throttle valve assembly	01.01-05.05		**0 280 750 097**
Air mass meter, gasoline injection	01.01-05.05		**0 280 218 017**
			0 986 280 208
Phase sensor	01.01-05.05		**0 232 103 019**
Speed sensor, ignition/injection	01.01-05.05		**0 261 210 177**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	01.01-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	01.01-05.05		**0 265 005 303**
Wheel speed sensor, front	01.01-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	01.01-05.05		**0 265 006 573**
2.5 TDI [3B2]			**2,5 l 110 kW AFB; AKN 6 Zyl.**
Air mass meter, diesel	08.98-11.00		**0 281 002 224**
Speed sensor, diesel	08.98-11.00		**0 281 002 222**
Boost pressure sensor, Diesel	08.98-11.00		**0 281 002 177**
Duo sensor, acceleration and yaw rate, brake system	08.98-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	08.98-11.00	5PO	**0 265 005 207**
2.5 TDI [3B3]			**2,5 l 110 kW AKN 6 Zyl.**
Speed sensor, diesel	10.00-05.03		**0 281 002 222**
Boost pressure sensor, Diesel	10.00-05.03		**0 281 002 177**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.03		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.03		**0 265 005 303**
Wheel speed sensor, front	10.00-05.03	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.03	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
2.5 TDI [3B3]			**2,5 l 120 kW BDG 6 Zyl.**
Speed sensor, diesel	05.03-05.05		**0 281 002 222**
Boost pressure sensor, Diesel	05.03-05.05		**0 281 002 399**
Pressure sensor, ESP, (electronic stability program)	05.03-05.05		**0 265 005 303**
Wheel speed sensor, front	05.03-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	05.03-05.05	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
2.5 TDI syncro [3B2]			**2,5 l 110 kW AFB 6 Zyl.**
Air mass meter, diesel	08.98-11.00		**0 281 002 224**
Speed sensor, diesel	08.98-04.99		**0 261 210 178**
	05.99-11.00		**0 281 002 222**
Pedal position sensor, diesel			
Fg.no. →3B..X..600 000	08.98-04.99	AG	**0 281 002 289**
Duo sensor, acceleration and yaw rate, brake system	08.98-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	08.98-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	08.98-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
Fg.no. 3B..X..338 107→	11.98-11.00	ALR,LAB, OFD	**0 265 006 575**
		ALR,OFD, RAB	**0 265 006 573**
		OFD,OLW	**0 265 006 573**
2.5 TDI syncro [3B2]			**2,5 l 110 kW AKN 6 Zyl.**
Air mass meter, diesel			
Fg.no. →3B..Y..200 000	08.98-11.99		**0 281 002 224**
Fg.no. 3B..Y..200 001→	12.99-11.00		**0 281 002 403**
			0 986 284 004
Speed sensor, diesel	08.98-04.99		**0 261 210 178**
	05.99-11.00		**0 281 002 222**
Duo sensor, acceleration and yaw rate, brake system	08.98-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	08.98-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	08.98-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
Fg.no. 3B..X..338 107→	11.98-11.00	ALR,LAB, OFD	**0 265 006 575**
		ALR,OFD, RAB	**0 265 006 573**
		OFD,OLW	**0 265 006 573**
2.5 TDI 4 Motion [3B3]			**2,5 l 110 kW AKN 6 Zyl.**
Speed sensor, diesel	10.00-01.03		**0 281 002 222**
Boost pressure sensor, Diesel	10.00-01.03		**0 281 002 177**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-01.03		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-01.03		**0 265 005 303**
Wheel speed sensor, front	10.00-01.03	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-01.03		**0 265 006 573**
2.5 TDI 4 Motion [3B3]			**2,5 l 132 kW BAU; BDH 6 Zyl.**
Speed sensor, diesel	01.03-05.05		**0 281 002 222**
Boost pressure sensor, Diesel	01.03-05.05		**0 281 002 399**
Pressure sensor, ESP, (electronic stability program)	01.03-05.05		**0 265 005 303**

V

Product			
Wheel speed sensor, front	01.03-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	01.03-05.05		**0 265 006 573**
2.8 [B5]		**2,8 l 140 kW BBG 6 Zyl.**	
Throttle valve assembly	01.02-02.07		**0 280 750 030**
Phase sensor	01.02-02.07		**0 232 101 024**
Speed sensor, ignition/injection	01.02-02.07		**0 281 002 222**
Temperature sensor, intake air, injection system	01.02-02.07		**0 280 130 085**
2.8 [3B2]		**2,8 l 132 kW AGE 6 Zyl.**	
Phase sensor	01.97-11.00		**0 232 101 024**
Speed sensor, ignition/injection			
Fg.no. →3B..W..055 000	01.97-06.97	AG5,GS	**0 261 210 134**
Fg.no. 3B..W..055 001→	06.97-11.00	AG5,GS	**0 261 210 178**
Knock sensor	01.97-11.00	KZB	**0 261 231 036**
Temperature sensor, intake air, injection system	01.97-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.97-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	01.97-11.00	5PO	**0 265 005 207**
2.8 [3B2]		**2,8 l 140 kW ATX 6 Zyl.**	
Throttle valve assembly	10.99-11.00		**0 280 750 030**
Duo sensor, acceleration and yaw rate, brake system	10.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	10.99-11.00	5PO	**0 265 005 207**
2.8 [3B2]		**2,8 l 142 kW ACK 6 Zyl.**	
Phase sensor	01.97-11.00		**0 232 101 024**
Speed sensor, ignition/injection			
Fg.no. →3B..W..055 000	01.97-06.97	AG5,GS	**0 261 210 134**
Fg.no. 3B..W..055 001→	06.97-11.00	AG	**0 261 210 147**
		AG5,GS	**0 261 210 178**
Knock sensor	01.97-11.00	KZB	**0 261 231 036**
Temperature sensor, intake air, injection system	01.97-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.97-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	01.97-11.00	5PO	**0 265 005 207**
2.8 [3B2]		**2,8 l 142 kW APR 6 Zyl.**	
Phase sensor	01.99-11.00		**0 232 101 024**
Speed sensor, ignition/injection	01.99-11.00	AG5	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	01.99-11.00	KZB	**0 261 231 036**
Temperature sensor, intake air, injection system	01.99-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	01.99-11.00	5PO	**0 265 005 207**
2.8 [3B2]		**2,8 l 142 kW AQD 6 Zyl.**	
Throttle valve assembly	01.99-11.00		**0 280 750 030**
Temperature sensor, intake air, injection system	01.99-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	01.99-11.00	5PO	**0 265 005 207**
2.8 [3B3]		**2,8 l 140/142 kW AMX; BBG 6 Zyl.**	
Throttle valve assembly	10.00-05.05		**0 280 750 030**
Phase sensor	10.00-05.05		**0 232 101 024**
Speed sensor, ignition/injection	10.00-05.05	AG	**0 261 210 147**
		GS	**0 261 210 178**
Temperature sensor, intake air, injection system	10.00-05.05		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**

Product			
2.8 [3B3]		**2,8 l 142 kW ATQ 6 Zyl.**	
Throttle valve assembly	10.00-05.05		**0 280 750 030**
Phase sensor	10.00-05.05		**0 232 101 024**
Temperature sensor, intake air, injection system	10.00-05.05		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
2.8 [31, 35, 3A..]		**2,8 l 128 kW AAA 6 Zyl.**	
Air mass meter, gasoline injection	06.91-07.93		**0 280 213 021**
			0 986 280 122
	08.93-03.97		**0 280 217 504**
Speed sensor, ignition/injection			
Fg.no. →3A-S-300 000	06.91-07.95		**0 261 210 080**
Fg.no. 3A-T-000 001→	07.95-03.97		**0 261 210 107**
Knock sensor	06.91-03.97	KZG	**0 261 231 004**
		KZS	**0 261 231 064**
		KZW	**0 261 231 047**
Temperature sensor, intake air, injection system	06.91-03.97		**0 280 130 039**
2.8 syncro [3B2]		**2,8 l 142 kW ACK 6 Zyl.**	
Phase sensor	01.97-11.00		**0 232 101 024**
Speed sensor, ignition/injection			
Fg.no. →3B..W..055 000	01.97-06.98		**0 261 210 134**
Fg.no. 3B..W..055 001→	07.98-11.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	01.97-11.00	KZB	**0 261 231 036**
Temperature sensor, intake air, injection system	01.97-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.97-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	01.97-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	01.97-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
Fg.no. 3B..X..338 107→	11.98-11.00	ALR,LAB, OFD	**0 265 006 575**
		ALR,OFD, RAB	**0 265 006 573**
		OFD,OLW	**0 265 006 573**
2.8 syncro [3B2]		**2,8 l 142 kW ALG 6 Zyl.**	
Phase sensor	06.97-11.00		**0 232 101 024**
Speed sensor, ignition/injection	06.97-11.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	06.97-11.00	KZB	**0 261 231 036**
Temperature sensor, intake air, injection system	06.97-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	06.97-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	06.97-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	06.97-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
Fg.no. 3B..X..338 107→	11.98-11.00	ALR,LAB, OFD	**0 265 006 575**
		ALR,OFD, RAB	**0 265 006 573**
		OFD,OLW	**0 265 006 573**

V

Product

◀ Passat

2.8 syncro [3B2]			**2,8 l 142 kW APR 6 Zyl.**
Throttle valve assembly	01.99-11.00		**0 280 750 030**
Phase sensor	01.99-11.00		**0 232 101 024**
Speed sensor, ignition/injection	01.99-11.00	AG	**0 261 210 147**
Knock sensor			
Fg.no. →3B..X..600 000	01.99-04.99	KZB	**0 261 231 036**
Temperature sensor, intake air, injection system	01.99-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	01.99-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	01.99-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,LAB, OFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		ALR,OFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
		OFD,OWR	**0 265 006 573**
2.8 syncro [3B2]			**2,8 l 142 kW AQD 6 Zyl.**
Throttle valve assembly	01.99-11.00		**0 280 750 030**
Phase sensor	01.99-11.00		**0 232 101 024**
Speed sensor, ignition/injection	01.99-11.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →3B..X..600 000	01.99-04.99	KZB	**0 261 231 036**
Temperature sensor, intake air, injection system	01.99-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	01.99-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	01.99-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,LAB, OFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		ALR,OFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
		OFD,OWR	**0 265 006 573**
2.8 syncro [3B2]			**2,8 l 142 kW ATX 6 Zyl.**
Throttle valve assembly	10.99-11.00		**0 280 750 030**
Temperature sensor, intake air, injection system	10.99-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	10.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	10.99-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	10.99-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,LAB, OFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		ALR,OFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
		OFD,OWR	**0 265 006 573**
2.8 4 Motion [3B3]			**2,8 l 140/142 kW AMX; BBG 6 Zyl.**
Throttle valve assembly	10.00-05.05		**0 280 750 030**
Phase sensor	10.00-05.05		**0 232 101 024**
Speed sensor, ignition/injection	10.00-05.05	AG	**0 261 210 147**
		GS	**0 261 210 178**
Temperature sensor, intake air, injection system	10.00-05.05		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05		**0 265 006 573**
2.8 4 Motion [3B3]			**2,8 l 142 kW ATQ 6 Zyl.**
Throttle valve assembly	10.00-05.05		**0 280 750 030**
Phase sensor	10.00-05.05		**0 232 101 024**
Temperature sensor, intake air, injection system	10.00-05.05		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05		**0 265 006 573**
3.2 FSI 4 Motion [3C2]			**3,2 l 184 kW AXZ 6 Zyl.**
Air mass meter, gasoline injection	09.05→		**0 280 218 175**
Knock sensor	09.05→	OHL	**0 261 231 146**
3.6 FSI, FSI 4 Motion [3C2]			**3,6 l 206 kW BLV 6 Zyl.**
Air mass meter, gasoline injection	09.05→		**0 280 218 175**
Knock sensor	09.05→	TW	**0 261 231 146**
4.0 [3B3]			**4,0 l 202 kW BDN; BDP 8 Zyl.**
Air mass meter, gasoline injection	05.02-09.04		**0 280 218 073**
			0 986 280 222
Phase sensor	05.02-09.04		**0 232 103 019**
Pressure sensor, ESP, (electronic stability program)	05.02-09.04		**0 265 005 303**
Wheel speed sensor, front	05.02-09.04	FMS	**0 265 006 578**
Wheel speed sensor, rear	05.02-09.04	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
4.0 4 Motion [3B3]			**4,0 l 202 kW BDN; BDP 8 Zyl.**
Air mass meter, gasoline injection	09.01-09.04		**0 280 218 073**
			0 986 280 222
Phase sensor	09.01-09.04		**0 232 103 019**
Duo sensor, acceleration and yaw rate, brake system	09.01-09.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	09.01-09.04		**0 265 005 303**
Wheel speed sensor, front	09.01-09.04	FMS	**0 265 006 578**
Wheel speed sensor, rear	09.01-09.04		**0 265 006 573**

Passat Variant

1.6 [3B5]			**1,6 l 74 kW ADP 4 Zyl.**
Temperature sensor, intake air, injection system	01.97-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.97-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	01.97-11.00	5PO	**0 265 005 207**
1.6 [3B5]			**1,6 l 74 kW AHL 4 Zyl.**
Phase sensor	05.97-11.00		**0 232 103 019**
Speed sensor, ignition/injection	05.97-11.00	AG5,GS	**0 261 210 147**
Knock sensor	05.97-11.00	KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	05.97-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	05.97-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	05.97-11.00	5PO	**0 265 005 207**
1.6 [3B5]			**1,6 l 74 kW ANA; ARM 4 Zyl.**
Speed sensor, ignition/injection	01.99-11.00	AG5,GS	**0 261 210 147**
Knock sensor	01.99-11.00	KZG	**0 261 231 038**
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	01.99-11.00	5PO	**0 265 005 207**

Product			
1.6 [3B6]			**1,6 l 75 kW ALZ 4 Zyl.**
Phase sensor			
Fg.no. →3B..2..240 126	10.00-10.01		**0 232 101 038**
Speed sensor, ignition/injection	10.00-05.05		**0 281 002 222**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
1.6 [3C5]			**1,6 l 75 kW BSE; BSF 4 Zyl.**
Speed sensor, ignition/injection	08.05→		**0 261 210 199**
Knock sensor	08.05→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	08.05→		**0 261 230 031**
1.6 [31, 35, 3A..]			**1,6 l 55 kW 1F 4 Zyl.**
Temperature sensor, coolant, injection system	08.88-07.90		**0 280 130 040**
1.6 [31, 35, 3A..]			**1,6 l 74 kW AEK 4 Zyl.**
Air mass meter, gasoline injection	10.94-12.95		**0 280 217 103**
Knock sensor	10.94-12.95	KZB	**0 261 231 036**
1.6 [31, 35, 3A..]			**1,6 l 74 kW AFT 4 Zyl.**
Knock sensor	12.95-03.97	KZB	**0 261 231 036**
Temperature sensor, intake air, injection system	12.95-03.97		**0 280 130 039**
1.6 FSI [3C5]			**1,6 l 85 kW BLF 4 Zyl.**
Speed sensor, ignition/injection	08.05→	AG	**0 261 210 250**
Knock sensor	08.05→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	08.05→		**0 261 230 095**
1.8 [3B5]			**1,8 l 85 kW AFY 4 Zyl.**
Temperature sensor, intake air, injection system	05.97-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	05.97-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	05.97-11.00	5PO	**0 265 005 207**
1.8 [3B5]			**1,8 l 92 kW ADR 4 Zyl.**
Throttle valve assembly			
Fg.no. 3B..X..550 001→	05.99-11.00		**0 280 750 080**
Air mass meter, gasoline injection			
Fg.no. 3B..X..400 001→	01.99-11.00		**0 280 218 013**
			0 986 280 206
Phase sensor	05.97-11.00		**0 232 101 024**
Knock sensor	05.97-11.00	KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	05.97-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	05.97-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	05.97-11.00	5PO	**0 265 005 207**
1.8 [3B5]			**1,8 l 92 kW APT; ARG 4 Zyl.**
Throttle valve assembly			
Fg.no. 3B..X..550 001→	05.99-11.00		**0 280 750 080**
Air mass meter, gasoline injection	01.99-11.00		**0 280 218 013**
			0 986 280 206
Knock sensor	01.99-11.00	KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	01.99-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	01.99-11.00	5PO	**0 265 005 207**
1.8 [3B6]			**1,8 l 110 kW AWT 4 Zyl.**
Throttle valve assembly	10.00-05.05		**0 280 750 009**
Air mass meter, gasoline injection			
Fg.no. →3B..2..100 000	10.00-06.01		**0 280 218 063**
			0 986 280 217
Fg.no. 3B..2..100 001→	07.01-05.05		**0 280 218 100**
			0 986 280 223
Phase sensor	10.00-05.05		**0 232 101 024**

Product			
Speed sensor, ignition/injection	10.00-05.05		**0 281 002 222**
Boost pressure sensor, gasoline			
Fg.no. →3B..3..350 000	10.00-02.03		**0 281 002 177**
Fg.no. 3B..3..350 001→	03.03-05.05		**0 261 230 073**
Temperature sensor, intake air, injection system	10.00-05.05		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
1.8 [31, 35, 3A..]			**1,8 l 55/66 kW AAM; ABS 4 Zyl.**
Temperature sensor, coolant, injection system	08.90-03.97		**0 280 130 040**
1.8 [31, 35, 3A..]			**1,8 l 66 kW RP 4 Zyl.**
Knock sensor	08.88-07.91	KZG	**0 261 231 004**
Temperature sensor, coolant, injection system	04.88-07.91		**0 280 130 040**
1.8 [31, 35, 3A..]			**1,8 l 79 kW PF 4 Zyl.**
Air flow sensor, gasoline injection	04.88-07.90		**0 280 202 106**
			0 986 280 008
Knock sensor	08.88-07.90	KZG	**0 261 231 004**
1.8 [31, 35, 3A..]			**1,8 l 82 kW PB 4 Zyl.**
Air flow sensor, gasoline injection	04.88-07.90		**0 280 200 041**
Knock sensor	08.88-07.90	KZG	**0 261 231 038**
1.8 [31, 35, 3A..]			**1,8 l 100 kW KR 4 Zyl.**
Air flow sensor, gasoline injection	04.88-07.92		**F 026 TX2 050**
			F 026 TX2 050
1.8 [32B]			**1,8 l 66 kW JN 4 Zyl.**
Air flow sensor, gasoline injection	08.84-03.88		**F 026 TX2 063**
			F 026 TX2 063
1.8 G60 syncro [312,315,3A5]			**1,8 l 118 kW PG 4 Zyl.**
Knock sensor	09.89-07.93		**0 261 231 038**
1.8 syncro [3B5]			**1,8 l 92 kW ADR 4 Zyl.**
Throttle valve assembly			
Fg.no. 3B..X..550 001→	05.99-11.00		**0 280 750 080**
Air mass meter, gasoline injection			
Fg.no. 3B..X..400 001→	02.99-11.00		**0 280 218 013**
			0 986 280 206
Phase sensor	08.97-11.00		**0 232 101 024**
Knock sensor	08.97-11.00	KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	08.97-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	08.97-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	08.97-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	08.97-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
Fg.no. 3B..X..338 107→	11.98-11.00	ALR,LAB, OFD	**0 265 006 575**
		ALR,OFD, RAB	**0 265 006 573**
		OFD,OLW	**0 265 006 573**
1.8 syncro [3B5]			**1,8 l 92 kW APT 4 Zyl.**
Throttle valve assembly			
Fg.no. 3B..X..550 001→	05.99-11.00		**0 280 750 080**
Air mass meter, gasoline injection	01.99-11.00		**0 280 218 013**
			0 986 280 206
Phase sensor	01.99-11.00		**0 232 101 024**
Knock sensor	01.99-11.00	KZG	**0 261 231 038**

V

Product			
◀ Passat Variant			
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	01.99-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	01.99-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,LAB, OFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		ALR,OFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
		OFD,OWR	**0 265 006 573**
1.8 syncro [3B5]			**1,8 l 92 kW ARG 4 Zyl.**
Throttle valve assembly			
Fg.no. 3B..X..550 001→	05.99-11.00		**0 280 750 080**
Air mass meter, gasoline injection	02.99-11.00		**0 280 218 013**
			0 986 280 206
Phase sensor	02.99-11.00		**0 232 101 024**
Knock sensor	02.99-11.00	KZG	**0 261 231 038**
Temperature sensor, intake air, injection system	02.99-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	02.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	02.99-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	02.99-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,LAB, OFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		ALR,OFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
		OFD,OWR	**0 265 006 573**
1.8 syncro [32B]			**1,8 l 68 kW JN 4 Zyl.**
Air flow sensor, gasoline injection	01.86-03.88		**F 026 TX2 063**
			F 026 TX2 063
1.8 Turbo [3B5]			**1,8 l 110 kW AEB 4 Zyl.**
Air mass meter, gasoline injection			
Fg.no. WE175000/WP150000→	09.97-11.00		**0 280 217 117**
			0 986 280 201
Fg.no. →WE175000/WP150000	05.97-08.97		**0 280 217 112**
Phase sensor	05.97-11.00		**0 232 101 024**
Knock sensor	05.97-11.00	KZG	**0 261 231 038**
Pressure sensor, intake manifold, gasoline	05.97-11.00		**0 280 101 001**
Temperature sensor, intake air, injection system	05.97-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	05.97-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	05.97-11.00	5PO	**0 265 005 207**
1.8 Turbo [3B5]			**1,8 l 110 kW ANB; APU 4 Zyl.**
Throttle valve assembly	01.99-11.00		**0 280 750 009**
Air mass meter, gasoline injection	01.99-11.00		**0 280 218 032**
			0 986 280 210
Knock sensor	01.99-11.00	KZG	**0 261 231 038**
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	01.99-11.00	5PO	**0 265 005 207**
1.9 TDI [3B5]			**1,9 l 66 kW AHH 4 Zyl.**
Air mass meter, diesel	05.98-11.00		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	05.98-11.00		**0 281 002 177**

Product			
Pedal position sensor, diesel			
Fg.no. →3B..X..600 000	05.98-04.99	AG	**0 281 002 289**
		GS	**0 281 002 286**
Yaw rate sensor, brake system	05.98-11.00	5PO	**0 265 005 207**
1.9 TDI [3B5]			**1,9 l 66 kW AHU 4 Zyl.**
Air mass meter, diesel			
Fg.no. WE118001/WP100001→	09.97-11.00		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	05.97-11.00		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. →3B..W..140 000	05.97-08.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
Fg.no. 3B..W..140 001→3B..W..222 092	08.97-10.97	AG	**0 281 002 254**
		GS	**0 281 002 229**
Fg.no. 3B..W..222 093→3B..X..600 000	10.97-04.99	AG	**0 281 002 289**
		GS	**0 281 002 286**
Yaw rate sensor, brake system	05.97-11.00	5PO	**0 265 005 207**
1.9 TDI [3B5]			**1,9 l 74 kW AVB 4 Zyl.**
Air mass meter, diesel	02.00-11.00		**0 281 002 216**
			0 986 284 001
Yaw rate sensor, brake system	02.00-11.00	5PO	**0 265 005 207**
1.9 TDI [3B5]			**1,9 l 81 kW AFN 4 Zyl.**
Air mass meter, diesel			
Fg.no. WE118001/WP100001→	09.97-11.00		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	05.97-11.00		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. →3B..W..140 000	05.97-08.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
Fg.no. 3B..W..140 001→3B..W..222 092	08.97-10.97	AG	**0 281 002 254**
		GS	**0 281 002 229**
Fg.no. 3B..W..222 093→3B..X..600 000	10.97-04.99	AG	**0 281 002 289**
		GS	**0 281 002 286**
Yaw rate sensor, brake system	05.97-11.00	5PO	**0 265 005 207**
1.9 TDI [3B5]			**1,9 l 81 kW AVG 4 Zyl.**
Air mass meter, diesel	08.99-11.00		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	08.99-11.00		**0 281 002 177**
Yaw rate sensor, brake system	08.99-11.00	5PO	**0 265 005 207**
1.9 TDI [3B5]			**1,9 l 85 kW AJM 4 Zyl.**
Air mass meter, diesel	03.99-11.00		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	03.99-11.00		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. →3B..X..600 000	03.99-04.99	AG	**0 281 002 289**
		GS	**0 281 002 286**
Yaw rate sensor, brake system	03.99-11.00	5PO	**0 265 005 207**
1.9 TDI [3B5]			**1,9 l 85 kW ATJ 4 Zyl.**
Air mass meter, diesel	12.99-11.00		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	12.99-11.00		**0 281 002 177**
Yaw rate sensor, brake system	12.99-11.00	5PO	**0 265 005 207**
1.9 TDI [3B6]			**1,9 l 74 kW AVB 4 Zyl.**
Air mass meter, diesel			
Fg.no. →3B..2P241 613,→3B..2P240 805, →3B..2E262 022	10.00-10.01		**0 281 002 216**
			0 986 284 001
Fg.no. 3B..2P241 614→,3B..2P240 806→, 3B..2E262 023→	11.01-05.05		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →3B..2..250 000	10.00-10.01		**0 281 002 177**
Fg.no. 3B..2..250 000→	11.01-05.05		**0 281 002 399**

Product			
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
1.9 TDI [3B6]			**1,9 l 96 kW AVF; AWX 4 Zyl.**
Air mass meter, diesel			
Fg.no. →3B..1..400 000	10.00-04.01		**0 280 217 529**
			0 986 280 204
Fg.no. 3B..2..000 001→	05.01-05.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	10.00-05.05		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
1.9 TDI [3C5]			**1,9 l 77 kW BKC; BLS; BXE 4 Zyl.**
Air mass meter, diesel	08.05→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	08.05→		**0 281 002 399**
1.9 TDI [31, 35, 3A..]			**1,9 l 66 kW AHU 4 Zyl.**
Pedal position sensor, diesel	08.96-03.97	LLE	**0 205 001 032**
		RLE	**0 205 001 024**
1.9 TDI [31, 35, 3A..]			**1,9 l 66 kW 1Z 4 Zyl.**
Pressure sensor, intake manifold, diesel			
Fg.no. →3A..SE085 001,→3A..SB012 818, →3A..RE027 690	10.93-09.94		**0 261 230 037**
Pedal position sensor, diesel			
Fg.no. →3A..S..192 818	10.93-04.95	LLE	**0 205 001 024**
		RLE	**0 205 001 023**
Fg.no. 3A..S..192 819→	05.95-07.96	AG	**0 205 001 031**
		GS	**0 205 001 032**
1.9 TDI syncro [3B5]			**1,9 l 81 kW AFN 4 Zyl.**
Air mass meter, diesel			
Fg.no. WE 106 001→,WP 090 001→	08.97-11.00		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	06.97-11.00		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. →3B..W..140 000	06.97-08.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
Fg.no. 3B..W..140 001→3B..W..222 092	09.97-10.97	GS	**0 281 002 229**
Fg.no. 3B..W..140 001→3B..X..600 000	09.97-04.99	AG	**0 281 002 289**
Fg.no. 3B..W..222 093→3B..X..600 000	11.97-04.99	GS	**0 281 002 286**
Duo sensor, acceleration and yaw rate, brake system	06.97-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	06.97-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	06.97-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
Fg.no. 3B..X..338 107→	11.98-11.00	ALR,LAB, OFD	**0 265 006 575**
		ALR,OFD, RAB	**0 265 006 573**
		OFD,OLW	**0 265 006 573**

Product			
1.9 TDI syncro [3B5]			**1,9 l 81 kW AVG 4 Zyl.**
Air mass meter, diesel	08.99-08.00		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	08.99-08.00		**0 281 002 177**
Duo sensor, acceleration and yaw rate, brake system	08.99-08.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	08.99-08.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	08.99-08.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,LAB, OFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		ALR,OFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
		OFD,OWR	**0 265 006 573**
1.9 TDI syncro [3B5]			**1,9 l 85 kW AJM 4 Zyl.**
Pedal position sensor, diesel			
Fg.no. →3B..X..600 000	01.99-04.99	AG	**0 281 002 289**
		GS	**0 281 002 286**
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	01.99-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	01.99-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,LAB, OFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		ALR,OFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
		OFD,OWR	**0 265 006 573**
1.9 TDI syncro [3B5]			**1,9 l 85 kW ATJ 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	01.00-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	01.00-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	01.00-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,LAB, OFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		ALR,OFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
		OFD,OWR	**0 265 006 573**
1.9 TDI 4 Motion [3B6]			**1,9 l 96 kW AVF; AWX 4 Zyl.**
Air mass meter, diesel			
Fg.no. →3B..1..400 000	10.00-04.01		**0 280 217 529**
			0 986 280 204
Fg.no. 3B..2..000 001→	05.01-05.05		**0 281 002 461**
			0 986 284 007
Pressure sensor, intake manifold, diesel	10.00-05.05		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05		**0 265 006 573**

V

Product			
◀ Passat Variant			
2.0 [3B6]			**2,0 l 85 kW AZM 4 Zyl.**
Phase sensor	10.00-05.05		**0 232 101 031**
Speed sensor, ignition/injection	10.00-05.05		**0 261 210 147**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
2.0 [3B6]			**2,0 l 95 kW ALT 4 Zyl.**
Throttle valve assembly	11.01-05.05		**0 280 750 088**
Air mass meter, gasoline injection	11.01-05.05		**0 280 218 058**
			0 986 280 215
Phase sensor	11.01-05.05		**0 232 101 024**
Speed sensor, ignition/injection	11.01-05.05		**0 281 002 222**
Pressure sensor, ESP, (electronic stability program)	11.01-05.05		**0 265 005 303**
Wheel speed sensor, front	11.01-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	11.01-05.05	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
2.0 [31, 35, 3A..]			**2,0 l 85 kW ADY 4 Zyl.**
Knock sensor	10.94-07.95	KZG	**0 261 231 004**
2.0 [31, 35, 3A..]			**2,0 l 85 kW AGG 4 Zyl.**
Knock sensor	07.95-03.97	KZG	**0 261 231 038**
2.0 [31, 35, 3A..]			**2,0 l 85 kW 2E 4 Zyl.**
Knock sensor	03.90-09.94	KZB	**0 261 231 036**
2.0 [31, 35, 3A..]			**2,0 l 100 kW 9A 4 Zyl.**
Throttle valve sensor	08.88-09.93	AG	**0 280 120 433**
		GS	**0 280 120 426**
Air flow sensor, gasoline injection			
Fg.no. →31-N-400 000	08.88-07.92		**0 438 121 076**
			0 986 439 376
Fg.no. 31-P-000 001→	07.92-09.93		**0 986 439 389**
			F 026 TX2 059
			0 986 439 389
Knock sensor	08.88-09.93	KZG	**0 261 231 004**
Temperature sensor, coolant, injection system	08.88-09.93		**0 280 130 040**
2.0 [31, 35, 3A..]			**2,0 l 110 kW ABF 4 Zyl.**
Knock sensor	01.94-03.97	KZG	**0 261 231 004**
2.0 [32B]			**2,0 l 85 kW HP; JS 5 Zyl.**
Air flow sensor, gasoline injection	08.83-01.86	MZF	**0 438 121 005**
2.0 FSI [3C5]			**2,0 l 110 kW BLR; BLY; BVY; BVZ 4 Zyl.**
Knock sensor	08.05→	OHL	**0 261 231 146**
Pressure sensor, intake manifold, gasoline	08.05→		**0 261 230 031**
2.0 FSI 4 Motion [3C5]			**2,0 l 110 kW BLX; BLY; BVX 4 Zyl.**
Knock sensor	09.05→	OHL	**0 261 231 146**
Pressure sensor, intake manifold, gasoline	09.05→		**0 261 230 031**
2.0 syncro [32B]			**2,0 l 85 kW HP 5 Zyl.**
Air flow sensor, gasoline injection	02.86-03.88		**0 438 120 211**
2.0 syncro [312,315,3A5]			**2,0 l 85 kW 2E 4 Zyl.**
Air flow sensor, gasoline injection	10.90-09.94		**0 280 202 106**
			0 986 280 008
Knock sensor	10.90-09.94	KZB	**0 261 231 036**
2.0 TDI [3B6]			**2,0 l 100 kW BGW 4 Zyl.**
Air mass meter, diesel	11.03-05.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	11.03-05.05		**0 281 002 401**
Pressure sensor, ESP, (electronic stability program)	11.03-05.05		**0 265 005 303**
Wheel speed sensor, front	11.03-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	11.03-05.05	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**

Product			
2.0 TDI [3C5]			**2,0 l 88/100/103/120 kW BKP; BMA; BMP; BUZ; BWV 4 Zyl.**
Air mass meter, diesel	08.05→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	08.05→		**0 281 002 401**
2.0 TDI [3C5]			**2,0 l 90/125 kW BMR; BVD; BVE 4 Zyl.**
Air mass meter, diesel	08.05→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	08.05→		**0 281 002 401**
2.0 TDI 4 Motion [3C5]			**2,0 l 103 kW BKP; BMP 4 Zyl.**
Air mass meter, diesel	08.05→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	08.05→		**0 281 002 401**
2.0 TFSI [3C5]			**2,0 l 147 kW AXX; BWA 4 Zyl.**
Speed sensor, ignition/injection	08.05→		**0 261 210 199**
Boost pressure sensor, gasoline	08.05→		**0 261 230 073**
2.0 4 Motion [3B6]			**2,0 l 85 kW AZM 4 Zyl.**
Phase sensor	10.00-05.05		**0 232 101 031**
Speed sensor, ignition/injection	10.00-05.05		**0 261 210 147**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05		**0 265 006 573**
2.2 [32B]			**2,2 l 85 kW KX 5 Zyl.**
Air flow sensor, gasoline injection	08.85-03.88		**F 026 TX2 064**
			F 026 TX2 064
Pressure sensor, intake manifold, gasoline	08.85-03.88		**0 280 101 001**
Temperature sensor, coolant, injection system	08.85-03.88		**0 280 130 037**
2.2 [32B]			**2,2 l 100 kW HY 5 Zyl.**
Air flow sensor, gasoline injection	02.86-03.88		**0 438 120 211**
	01.85-01.86	MZF	**0 438 121 005**
2.2 [32B]			**2,2 l 100 kW KV 5 Zyl.**
Air flow sensor, gasoline injection	01.85-01.86	MZF	**0 438 121 005**
2.2 syncro [32B]			**2,2 l 85 kW KX 5 Zyl.**
Air flow sensor, gasoline injection	08.85-03.88		**F 026 TX2 064**
			F 026 TX2 064
Pressure sensor, intake manifold, gasoline	08.85-03.88		**0 280 101 001**
Temperature sensor, coolant, injection system	08.85-03.88		**0 280 130 037**
2.2 syncro [32B]			**2,2 l 88 kW JT 5 Zyl.**
Air flow sensor, gasoline injection	08.85-03.88		**F 026 TX2 064**
			F 026 TX2 064
Temperature sensor, coolant, injection system	08.85-03.88		**0 280 130 037**
2.2 syncro [32B]			**2,2 l 100 kW HY 5 Zyl.**
Air flow sensor, gasoline injection	02.86-03.88		**0 438 120 211**
2.3 [3B5]			**2,3 l 110 kW AGZ 5 Zyl.**
Air mass meter, gasoline injection	09.97-11.00		**0 280 217 529**
			0 986 280 204
Phase sensor	09.97-11.00		**0 232 103 019**
Speed sensor, ignition/injection	09.97-11.00	AG5,GS	**0 261 210 139**
Temperature sensor, intake air, injection system			
Fg.no. →3B..X..030 000	09.97-05.98		**0 280 130 039**
Fg.no. 3B..X..030 001→	05.98-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	09.97-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	09.97-11.00	5PO	**0 265 005 207**
2.3 [3B6]			**2,3 l 125 kW AZX 5 Zyl.**
Throttle valve assembly	10.00-05.05		**0 280 750 097**
Air mass meter, gasoline injection	10.00-05.05		**0 280 218 017**
			0 986 280 208
Phase sensor	10.00-05.05		**0 232 103 019**
Speed sensor, ignition/injection	10.00-05.05		**0 261 210 177**

Product			
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
2.3 syncro [3B5]			**2,3 l 110 kW AGZ 5 Zyl.**
Air mass meter, gasoline injection	09.97-11.00		**0 280 217 529**
			0 986 280 204
Phase sensor	09.97-11.00		**0 232 103 019**
Speed sensor, ignition/injection	09.97-11.00		**0 261 210 139**
Temperature sensor, intake air, injection system			
Fg.no. →3B..X..132 000	09.97-08.98		**0 280 130 039**
Fg.no. 3B..X..132 001→	09.98-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	09.97-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	09.97-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	09.97-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
Fg.no. 3B..X..338 107→	11.98-11.00	ALR,LAB, OFD	**0 265 006 575**
		ALR,OFD, RAB	**0 265 006 573**
		OFD,OLW	**0 265 006 573**
2.3 4 Motion [3B6]			**2,3 l 125 kW AZX 5 Zyl.**
Throttle valve assembly	01.01-05.05		**0 280 750 097**
Air mass meter, gasoline injection	01.01-05.05		**0 280 218 017**
			0 986 280 208
Phase sensor	01.01-05.05		**0 232 103 019**
Speed sensor, ignition/injection	01.01-05.05		**0 261 210 177**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	01.01-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	01.01-05.05		**0 265 005 303**
Wheel speed sensor, front	01.01-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	01.01-05.05		**0 265 006 573**
2.5 TDI [3B5]			**2,5 l 110 kW AFB; AKN 6 Zyl.**
Air mass meter, diesel	08.98-11.00		**0 281 002 224**
Speed sensor, diesel	08.98-11.00		**0 281 002 222**
Boost pressure sensor, Diesel	08.98-11.00		**0 281 002 177**
Yaw rate sensor, brake system	08.98-11.00	5PO	**0 265 005 207**
2.5 TDI [3B6]			**2,5 l 110 kW AKN 6 Zyl.**
Speed sensor, diesel	10.00-05.03		**0 281 002 222**
Boost pressure sensor, Diesel	10.00-05.03		**0 281 002 177**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.03		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.03		**0 265 005 303**
Wheel speed sensor, front	10.00-05.03	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.03	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
2.5 TDI [3B6]			**2,5 l 120 kW BDG 6 Zyl.**
Speed sensor, diesel	05.03-05.05		**0 281 002 222**
Boost pressure sensor, Diesel	05.03-05.05		**0 281 002 399**
Pressure sensor, ESP, (electronic stability program)	05.03-05.05		**0 265 005 303**

Product			
Wheel speed sensor, front	05.03-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	05.03-05.05	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
2.5 TDI syncro [3B5]			**2,5 l 110 kW AFB 6 Zyl.**
Air mass meter, diesel	02.99-11.00		**0 281 002 224**
Speed sensor, diesel	02.99-04.99		**0 261 210 178**
	05.99-11.00		**0 281 002 222**
Pedal position sensor, diesel			
Fg.no. →3B..X..600 000	02.99-04.99	AG	**0 281 002 289**
Duo sensor, acceleration and yaw rate, brake system	02.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	02.99-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	02.99-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
Fg.no. 3B..X..338 107→	02.99-11.00	ALR,LAB, OFD	**0 265 006 575**
		ALR,OFD, RAB	**0 265 006 573**
		OFD,OLW	**0 265 006 573**
2.5 TDI syncro [3B5]			**2,5 l 110 kW AKN 6 Zyl.**
Air mass meter, diesel			
Fg.no. →3B..Y..200 000	05.99-11.99		**0 281 002 224**
Fg.no. 3B..Y..200 001→	12.99-11.00		**0 281 002 403**
			0 986 284 004
Speed sensor, diesel	05.99-11.00		**0 281 002 222**
Duo sensor, acceleration and yaw rate, brake system	05.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	05.99-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	05.99-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,LAB, OFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		ALR,OFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
		OFD,OWR	**0 265 006 573**
2.5 TDI 4 Motion [3B6]			**2,5 l 110 kW AKN 6 Zyl.**
Speed sensor, diesel	10.00-01.03		**0 281 002 222**
Boost pressure sensor, Diesel	10.00-01.03		**0 281 002 177**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-01.03		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-01.03		**0 265 005 303**
Wheel speed sensor, front	10.00-01.03	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-01.03		**0 265 006 573**
2.5 TDI 4 Motion [3B6]			**2,5 l 132 kW BAU; BDH 6 Zyl.**
Speed sensor, diesel	01.03-05.05		**0 281 002 222**
Boost pressure sensor, Diesel	01.03-05.05		**0 281 002 399**
Pressure sensor, ESP, (electronic stability program)	01.03-05.05		**0 265 005 303**
Wheel speed sensor, front	01.03-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	01.03-05.05		**0 265 006 573**
2.8 [3B5]			**2,8 l 140 kW ATX 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	10.99-11.00	5PO	**0 265 005 207**

V

Product

◀ Passat Variant

2.8 [3B5]			**2,8 l 142 kW ACK 6 Zyl.**
Phase sensor	06.97-11.00		**0 232 101 024**
Speed sensor, ignition/injection			
Fg.no. →3B..W..055 000	06.97-06.97	AG5,GS	**0 261 210 134**
Fg.no. 3B..W..055 001→	06.97-11.00	AG	**0 261 210 147**
		AG5,GS	**0 261 210 178**
Knock sensor	06.97-11.00	KZB	**0 261 231 036**
Temperature sensor, intake air, injection system	06.97-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	06.97-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	06.97-11.00	5PO	**0 265 005 207**
2.8 [3B5]			**2,8 l 142 kW APR 6 Zyl.**
Phase sensor	01.99-11.00		**0 232 101 024**
Speed sensor, ignition/injection	01.99-11.00	AG5	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	01.99-11.00	KZB	**0 261 231 036**
Temperature sensor, intake air, injection system	01.99-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	01.99-11.00	5PO	**0 265 005 207**
2.8 [3B5]			**2,8 l 142 kW AQD 6 Zyl.**
Throttle valve assembly	05.99-11.00		**0 280 750 030**
Temperature sensor, intake air, injection system	05.99-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	05.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	05.99-11.00	5PO	**0 265 005 207**
2.8 [3B6]			**2,8 l 140/142 kW AMX; BBG 6 Zyl.**
Throttle valve assembly	10.00-05.05		**0 280 750 030**
Phase sensor	10.00-05.05		**0 232 101 024**
Speed sensor, ignition/injection	10.00-05.05	AG	**0 261 210 147**
		GS	**0 261 210 178**
Temperature sensor, intake air, injection system	10.00-05.05		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
2.8 [3B6]			**2,8 l 142 kW ATQ 6 Zyl.**
Throttle valve assembly	10.00-05.05		**0 280 750 030**
Phase sensor	10.00-05.05		**0 232 101 024**
Temperature sensor, intake air, injection system	10.00-05.05		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
2.8 [31, 35, 3A..]			**2,8 l 128 kW AAA 6 Zyl.**
Air mass meter, gasoline injection	06.91-07.93		**0 280 213 021**
			0 986 280 122
	08.93-03.97		**0 280 217 504**
Speed sensor, ignition/injection			
Fg.no. →3A-S-300 000	06.91-07.95		**0 261 210 080**
Fg.no. 3A-T-000 001→	07.95-03.97		**0 261 210 107**
Knock sensor	06.91-03.97	KZG	**0 261 231 004**
		KZS	**0 261 231 064**
		KZW	**0 261 231 047**
Temperature sensor, intake air, injection system	06.91-03.97		**0 280 130 039**

Product

2.8 syncro [3B5]			**2,8 l 142 kW ACK 6 Zyl.**
Phase sensor	01.97-11.00		**0 232 101 024**
Speed sensor, ignition/injection			
Fg.no. →3B..W..055 000	01.97-06.98		**0 261 210 134**
Fg.no. 3B..W..055 001→	07.98-11.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	01.97-11.00	KZB	**0 261 231 036**
Temperature sensor, intake air, injection system	01.97-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.97-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	01.97-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	01.97-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
Fg.no. 3B..X..338 107→	11.98-11.00	ALR,LAB, OFD	**0 265 006 575**
		ALR,OFD, RAB	**0 265 006 573**
		OFD,OLW	**0 265 006 573**
2.8 syncro [3B5]			**2,8 l 142 kW AHA 6 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.94-12.95	6PO	**0 265 005 214**
Yaw rate sensor, brake system	10.94-12.95	5PO	**0 265 005 207**
2.8 syncro [3B5]			**2,8 l 142 kW ALG 6 Zyl.**
Phase sensor	06.97-11.00		**0 232 101 024**
Speed sensor, ignition/injection	06.97-11.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor	06.97-11.00	KZB	**0 261 231 036**
Temperature sensor, intake air, injection system	06.97-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	06.97-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	06.97-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	06.97-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
Fg.no. 3B..X..338 107→	11.98-11.00	ALR,LAB, OFD	**0 265 006 575**
		ALR,OFD, RAB	**0 265 006 573**
		OFD,OLW	**0 265 006 573**
2.8 syncro [3B5]			**2,8 l 142 kW APR 6 Zyl.**
Throttle valve assembly	01.99-11.00		**0 280 750 030**
Phase sensor	01.99-11.00		**0 232 101 024**
Speed sensor, ignition/injection	01.99-11.00	AG	**0 261 210 147**
Knock sensor			
Fg.no. →3B..X..600 000	01.99-04.99	KZB	**0 261 231 036**
Temperature sensor, intake air, injection system	01.99-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	01.99-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	01.99-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,LAB, OFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		ALR,OFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
		OFD,OWR	**0 265 006 573**

Product			
2.8 syncro [3B5]			**2,8 l 142 kW AQD 6 Zyl.**
Throttle valve assembly	01.99-11.00		**0 280 750 030**
Phase sensor	01.99-11.00		**0 232 101 024**
Speed sensor, ignition/injection	01.99-11.00	AG	**0 261 210 147**
		GS	**0 261 210 178**
Knock sensor			
Fg.no. →3B..X..600 000	01.99-04.99	KZB	**0 261 231 036**
Temperature sensor, intake air, injection system	01.99-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	01.99-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	01.99-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,LAB, OFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		ALR,OFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
		OFD,OWR	**0 265 006 573**
2.8 syncro [3B5]			**2,8 l 142 kW ATX 6 Zyl.**
Throttle valve assembly	10.99-11.00		**0 280 750 030**
Temperature sensor, intake air, injection system	10.99-11.00		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system	10.99-11.00	6PO	**0 265 005 214**
Yaw rate sensor, brake system	10.99-11.00	5PO	**0 265 005 207**
Wheel speed sensor, rear	10.99-11.00	ALR,LAB, MFD	**0 265 006 575**
		ALR,LAB, OFD	**0 265 006 575**
		ALR,MFD, RAB	**0 265 006 573**
		ALR,OFD, RAB	**0 265 006 573**
		MFD,OLW	**0 265 006 573**
		OFD,OWR	**0 265 006 573**
2.8 4 Motion [3B6]			**2,8 l 140/142 kW AMX; BBG 6 Zyl.**
Throttle valve assembly	10.00-05.05		**0 280 750 030**
Phase sensor	10.00-05.05		**0 232 101 024**
Speed sensor, ignition/injection	10.00-05.05	AG	**0 261 210 147**
		GS	**0 261 210 178**
Temperature sensor, intake air, injection system	10.00-05.05		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05		**0 265 006 573**
2.8 4 Motion [3B6]			**2,8 l 142 kW ATQ 6 Zyl.**
Throttle valve assembly	10.00-05.05		**0 280 750 030**
Phase sensor	10.00-05.05		**0 232 101 024**
Temperature sensor, intake air, injection system	10.00-05.05		**0 280 130 085**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		**0 265 005 214**
Fg.no. 3B..1..400 001→	05.01-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		**0 265 005 303**
Wheel speed sensor, front	10.00-05.05	FMS	**0 265 006 578**
Wheel speed sensor, rear	10.00-05.05		**0 265 006 573**

Product			
2.9 syncro [312,315,3A5]			**2,9 l 135 kW ABV 6 Zyl.**
Air mass meter, gasoline injection	01.94-03.97		**0 280 217 504**
Speed sensor, ignition/injection			
Fg.no. →3A-S-300 000	01.94-07.95		**0 261 210 080**
Fg.no. 3A-T-000 001→	07.95-03.97		**0 261 210 107**
Knock sensor	01.94-03.97	KZS	**0 261 231 064**
		KZW	**0 261 231 047**
Temperature sensor, intake air, injection system	01.94-03.97		**0 280 130 039**
3.2 FSI 4 Motion [3C5]			**3,2 l 184 kW AXZ 6 Zyl.**
Air mass meter, gasoline injection	11.05→		**0 280 218 175**
Knock sensor	11.05→	OHL	**0 261 231 146**
3.6 FSI, FSI 4 Motion [3C5]			**3,6 l 206 kW BLV 6 Zyl.**
Air mass meter, gasoline injection	09.05→		**0 280 218 175**
Knock sensor	09.05→	TW	**0 261 231 146**
4.0 [3B6]			**4,0 l 202 kW BDN; BDP 8 Zyl.**
Air mass meter, gasoline injection	05.02-09.04		**0 280 218 073**
			0 986 280 222
Phase sensor	05.02-09.04		**0 232 103 019**
Pressure sensor, ESP, (electronic stability program)	05.02-09.04		**0 265 005 303**
Wheel speed sensor, front	05.02-09.04	FMS	**0 265 006 578**
Wheel speed sensor, rear	05.02-09.04	ALR,LAB	**0 265 006 575**
		ALR,RAB	**0 265 006 573**
4.0 4 Motion [3B6]			**4,0 l 202 kW BDN; BDP 8 Zyl.**
Air mass meter, gasoline injection	09.01-09.04		**0 280 218 073**
			0 986 280 222
Phase sensor	09.01-09.04		**0 232 103 019**
Duo sensor, acceleration and yaw rate, brake system	09.01-09.04		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	09.01-09.04		**0 265 005 303**
Wheel speed sensor, front	09.01-09.04	FMS	**0 265 006 578**
Wheel speed sensor, rear	09.01-09.04		**0 265 006 573**

Phaeton

3.0 TDI 4 Motion [3D]			**3,0 l 165 kW BMK 6 Zyl.**
Speed sensor, diesel	09.04-05.07		**0 261 210 145**
Boost pressure sensor, Diesel	09.04-05.07		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	09.04-05.07		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	09.04-05.07		**0 265 005 303**
Wheel speed sensor, front	09.04-05.07	LAB	**0 265 007 728**
Fg.no. →3D..5..003 200	09.04-11.04	RAB	**0 265 007 406**
Fg.no. 3D..5..003 201→	12.04-05.07	RAB	**0 265 007 726**
Wheel speed sensor, rear	09.04-05.07	RAB	**0 265 007 728**
Fg.no. →3D..5..003 200	09.04-11.04	LAB	**0 265 007 406**
Fg.no. 3D..5..003 201→	12.04-05.07	LAB	**0 265 007 726**
3.0 TDI 4 Motion [3D]			**3,0 l 171 kW CARA 6 Zyl.**
Speed sensor, diesel	06.07→		**0 261 210 145**
Boost pressure sensor, Diesel	06.07→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	06.07→		**0 265 005 252**
Wheel speed sensor, front	06.07→	LAB	**0 265 007 930**
		RAB	**0 265 007 928**
Wheel speed sensor, rear	06.07→	LAB	**0 265 007 928**
		RAB	**0 265 007 930**
3.2 [3D]			**3,2 l 177 kW AYT; BKL 6 Zyl.**
Air mass meter, gasoline injection	05.02-05.05		**0 280 218 073**
			0 986 280 222
Phase sensor	05.02-05.05		**0 232 103 019**
Knock sensor	05.02-05.05	OHL	**0 261 231 146**
Duo sensor, acceleration and yaw rate, brake system	05.02-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	05.02-05.05		**0 265 005 303**

V

Product

◀ Phaeton

Wheel speed sensor, front	05.02-05.05	LAB	**0 265 007 728**
Fg.no. →3D..5..003 200	05.02-11.04	RAB	**0 265 007 406**
Fg.no. 3D..5..003 201→	12.04-05.05	RAB	**0 265 007 726**
Wheel speed sensor, rear	05.02-05.05	RAB	**0 265 007 728**
Fg.no. →3D..5..003 200	05.02-11.04	LAB	**0 265 007 406**
Fg.no. 3D..5..003 201→	12.04-05.05	LAB	**0 265 007 726**
3.2 4 Motion [3D]		**3,2 l 177 kW BKL; BRK 6 Zyl.**	
Air mass meter, gasoline injection	02.04→		**0 280 218 073**
			0 986 280 222
Phase sensor	02.04→		**0 232 103 019**
Knock sensor	02.04→	OHL	**0 261 231 146**
Duo sensor, acceleration and yaw rate, brake system	02.04→		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	02.04→		**0 265 005 303**
Wheel speed sensor, front	02.04→	LAB	**0 265 007 728**
Fg.no. →3D..5..003 200	02.04-11.04	RAB	**0 265 007 406**
Fg.no. 3D..5..003 201→	12.04→	RAB	**0 265 007 726**
Wheel speed sensor, rear	02.04→	RAB	**0 265 007 728**
Fg.no. →3D..5..003 200	02.04-11.04	LAB	**0 265 007 406**
Fg.no. 3D..5..003 201→	12.04→	LAB	**0 265 007 726**
4.2 4 Motion [3D]		**4,2 l 246 kW BGH; BGJ 8 Zyl.**	
Throttle valve assembly	05.03→		**0 280 750 047**
Air mass meter, gasoline injection	05.03→		**0 280 218 060**
			0 986 280 216
Phase sensor	05.03→		**0 232 101 024**
Speed sensor, ignition/injection	05.03→		**0 261 210 264**
Duo sensor, acceleration and yaw rate, brake system	05.03→		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	05.03→		**0 265 005 303**
Wheel speed sensor, front	05.03→	LAB	**0 265 007 728**
Fg.no. →3D..5..003 200	05.03-11.04	RAB	**0 265 007 406**
Fg.no. 3D..5..003 201→	12.04→	RAB	**0 265 007 726**
Wheel speed sensor, rear	05.03→	RAB	**0 265 007 728**
Fg.no. →3D..5..003 200	05.03-11.04	LAB	**0 265 007 406**
Fg.no. 3D..5..003 201→	12.04→	LAB	**0 265 007 726**
5.0 TDI 4 Motion [3D]		**5,0 l 230 kW AJS 10 Zyl.**	
Air mass meter, diesel	11.02-10.06		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	11.02-10.06		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	11.02-10.06		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	11.02-10.06		**0 265 005 303**
Wheel speed sensor, front	11.02-10.06	LAB	**0 265 007 728**
Fg.no. →3D..5..003 200	11.02-11.04	RAB	**0 265 007 406**
Fg.no. 3D..5..003 201→	12.04-10.06	RAB	**0 265 007 726**
Wheel speed sensor, rear	11.02-10.06	RAB	**0 265 007 728**
Fg.no. →3D..5..003 200	11.02-11.04	LAB	**0 265 007 406**
Fg.no. 3D..5..003 201→	12.04-10.06	LAB	**0 265 007 726**
6.0 4 Motion [3D]		**6,0 l 309 kW BAN 12 Zyl.**	
Throttle valve assembly	05.02-05.05		**0 280 750 107**
Air mass meter, gasoline injection	05.02-05.05		**0 280 218 071**
			0 986 280 221
Phase sensor	05.02-05.05		**0 232 103 019**
Duo sensor, acceleration and yaw rate, brake system	05.02-05.05		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	05.02-05.05		**0 265 005 303**
Wheel speed sensor, front	05.02-05.05	LAB	**0 265 007 728**
Fg.no. →3D..5..003 200	05.02-11.04	RAB	**0 265 007 406**
Fg.no. 3D..5..003 201→	12.04-05.05	RAB	**0 265 007 726**
Wheel speed sensor, rear	05.02-05.05	RAB	**0 265 007 728**
Fg.no. →3D..5..003 200	05.02-11.04	LAB	**0 265 007 406**
Fg.no. 3D..5..003 201→	12.04-05.05	LAB	**0 265 007 726**

Product

6.0 4 Motion [3D]		**6,0 l 309 kW BAP 12 Zyl.**	
Throttle valve assembly	07.03-05.05		**0 280 750 107**
Air mass meter, gasoline injection	07.03-05.05		**0 280 218 071**
			0 986 280 221
6.0 4 Motion [3D]		**6,0 l 331 kW BRN; BTT 12 Zyl.**	
Throttle valve assembly	05.05→		**0 280 750 107**
Air mass meter, gasoline injection	05.05→		**0 280 218 071**
			0 986 280 221
Phase sensor	05.05→		**0 232 103 019**
Duo sensor, acceleration and yaw rate, brake system	05.05→		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	05.05→		**0 265 005 303**
Wheel speed sensor, front	05.05→	LAB	**0 265 007 728**
		RAB	**0 265 007 726**
Wheel speed sensor, rear	05.05→	LAB	**0 265 007 726**
		RAB	**0 265 007 728**

Polo

1.0 [6N1]		**1,0 l 37 kW AER; ALL 4 Zyl.**	
Knock sensor	03.96-12.99	KZA	**0 261 231 045**
Pressure sensor, intake manifold, gasoline	03.96-12.99		**0 261 230 011**
1.0 [6N2]		**1,0 l 37 kW ALD; AUC 4 Zyl.**	
Speed sensor, ignition/injection	07.98-09.01		**0 261 210 188**
Knock sensor	07.98-09.01	KZA	**0 261 231 045**
Pressure sensor, intake manifold, gasoline	07.98-09.01		**0 261 230 031**
1.0 16V		**1,0 l 43 kW ARA 4 Zyl.**	
Knock sensor	07.02-05.05		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	07.02-05.05		**0 261 230 095**
Accelerator pedal module	07.02-05.05	GS	**0 280 752 214**
1.2 [9N1]		**1,2 l 40 kW AWY 3 Zyl.**	
Accelerator pedal module	11.01-05.04	GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →9N..4..250 000	11.01-04.04		**0 265 005 252**
Fg.no. 9N..5..000 001→	05.04-05.04		**0 265 005 601**
Pressure sensor, ESP, (electronic stability program)	11.01-05.04		**0 265 005 303**
1.2 [9N1]		**1,2 l 40 kW BMD 3 Zyl.**	
Accelerator pedal module	05.04-05.05	GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	05.04-05.05		**0 265 005 601**
1.2 [9N1]		**1,2 l 47 kW AZQ 3 Zyl.**	
Pressure sensor, intake manifold, gasoline	11.01-05.04		**0 261 230 031**
Accelerator pedal module	11.01-05.04	GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →9N..4..250 000	11.01-04.04		**0 265 005 252**
Fg.no. 9N..5..000 001→	05.04-05.04		**0 265 005 601**
Pressure sensor, ESP, (electronic stability program)	11.01-05.04		**0 265 005 303**
1.2 [9N1]		**1,2 l 47 kW BME 3 Zyl.**	
Pressure sensor, intake manifold, gasoline	11.04-05.05		**0 261 230 031**
Accelerator pedal module	11.04-05.05	GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	11.04-05.05		**0 265 005 601**
1.2 [9N3]		**1,2 l 40 kW BMD 3 Zyl.**	
Knock sensor	04.05-05.07		**0 261 231 146**
Accelerator pedal module			
Fg.no. →9N..6..300 000	04.05-05.06	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	04.05-05.07		**0 265 005 601**

Product			
1.2 [9N3]			**1,2 l 44 kW BBM 3 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	05.07→		**0 265 005 692**
1.2 [9N3]			**1,2 l 47 kW BME 3 Zyl.**
Pressure sensor, intake manifold, gasoline	04.05→		**0 261 230 031**
Accelerator pedal module			
Fg.no. →9N..6..300 000	04.05-05.06	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 601**
1.2 [9N3]			**1,2 l 51 kW BZG 3 Zyl.**
Pressure sensor, intake manifold, gasoline	05.07→		**0 261 230 031**
Duo sensor, acceleration and yaw rate, brake system	05.07→		**0 265 005 692**
1.3 [6N1]			**1,3 l 40 kW ADX 4 Zyl.**
Knock sensor	07.96-12.99	KZA	**0 261 231 045**
	10.94-07.95	KZA	**0 261 231 045**
1.3 [80]			**1,3 l 40/56-59 kW NZ; 3F 4 Zyl.**
Air flow sensor, gasoline injection	10.90-09.94		**0 280 200 048**
			0 986 280 030
1.3 [86,87]			**1,3 l 40 kW NZ 4 Zyl.**
Air flow sensor, gasoline injection	12.86-08.90		**0 280 200 048**
			0 986 280 030
1.3 [86,87]			**1,3 l 56-59 kW 3F 4 Zyl.**
Air flow sensor, gasoline injection	10.89-08.90		**0 280 200 048**
			0 986 280 030
Temperature sensor, coolant, injection system	10.89-08.90		**0 280 130 037**
1.4 [6N1]			**1,4 l 40-44 kW AEX 4 Zyl.**
Knock sensor	07.95-12.99	KZA	**0 261 231 045**
Pressure sensor, intake manifold, gasoline	07.95-12.99		**0 261 230 011**
1.4 [6N1]			**1,4 l 44 kW AKV; ANX; APQ 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.97-12.99		**0 261 230 011**
1.4 [6N1]			**1,4 l 74 kW AFH 4 Zyl.**
Knock sensor	04.96-12.99	KZA	**0 261 231 045**
1.4 [6N2]			**1,4 l 40/44 kW AKK; AKP; AUD 4 Zyl.**
Speed sensor, ignition/injection	09.98-09.01		**0 261 210 188**
Knock sensor	09.98-09.01	KZA	**0 261 231 045**
Pressure sensor, intake manifold, gasoline	09.98-09.01		**0 261 230 031**
1.4 [9N1]			**1,4 l 55 kW AUA 4 Zyl.**
Knock sensor	09.01-01.02		**0 261 231 146**
Accelerator pedal module	09.01-01.02	GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	09.01-01.02		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	09.01-01.02		**0 265 005 303**
1.4 [9N1]			**1,4 l 55 kW BBY 4 Zyl.**
Speed sensor, ignition/injection			
Fg.no. 9N..3..170 001→	04.03-05.04	GS	**0 261 210 257**
Knock sensor	09.01-05.04		**0 261 231 146**
Pressure sensor, intake manifold, gasoline			
Fg.no. 9N..4..000 001→	06.03-05.04		**0 261 230 095**
Accelerator pedal module	09.01-05.04	GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →9N..4..250 000	09.01-04.04		**0 265 005 252**
Fg.no. 9N..5..000 001→	05.04-05.04		**0 265 005 601**
Pressure sensor, ESP, (electronic stability program)	09.01-05.04		**0 265 005 303**
1.4 [9N1]			**1,4 l 55 kW BKY 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.04-05.05		**0 261 230 095**
Accelerator pedal module	05.04-05.05	GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	05.04-05.05		**0 265 005 601**

Product			
1.4 [9N1]			**1,4 l 74 kW AUB 4 Zyl.**
Knock sensor	11.01-04.02		**0 261 231 146**
Accelerator pedal module	11.01-04.02	GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	11.01-04.02		**0 265 005 252**
Pressure sensor, ESP, (electronic stability program)	11.01-04.02		**0 265 005 303**
1.4 [9N1]			**1,4 l 74 kW BBZ 4 Zyl.**
Knock sensor	09.01-04.05		**0 261 231 146**
Accelerator pedal module	09.01-04.05	GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →9N..4..250 000	09.01-04.04		**0 265 005 252**
Fg.no. 9N..5..000 001→	05.04-04.05		**0 265 005 601**
Pressure sensor, ESP, (electronic stability program)	09.01-04.05		**0 265 005 303**
1.4 [9N2]			**1,4 l 55 kW BBY; BKY 4 Zyl.**
Speed sensor, ignition/injection	07.03→	GS	**0 261 210 257**
Knock sensor	07.03→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	07.03→		**0 261 230 095**
Accelerator pedal module	07.03→	GS	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	07.03→	TW	**0 265 005 252**
			0 265 005 601
1.4 [9N2]			**1,4 l 63/74 kW BBZ; BLM 4 Zyl.**
Knock sensor	11.03→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	11.03→		**0 261 230 095**
Accelerator pedal module	11.03→	GS	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	11.03→	TW	**0 265 005 252**
			0 265 005 601
1.4 [9N3]			**1,4 l 55 kW BKY 4 Zyl.**
Knock sensor	04.05-07.07		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	04.05-07.07		**0 261 230 095**
Accelerator pedal module	04.05-07.07	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	04.05-07.07		**0 265 005 601**
1.4 [9N3]			**1,4 l 74 kW BBZ 4 Zyl.**
Knock sensor	04.05-05.07		**0 261 231 146**
Accelerator pedal module	04.05-05.07	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	04.05-05.07		**0 265 005 601**
1.4 FSI [9N1]			**1,4 l 63 kW AXU 3 Zyl.**
Knock sensor	09.01-05.05		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	09.01-05.05		**0 261 230 095**
Accelerator pedal module	09.01-05.05	GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →9N..4..250 000	09.01-04.04		**0 265 005 252**
Fg.no. 9N..5..000 001→	05.04-05.05		**0 265 005 601**
Pressure sensor, ESP, (electronic stability program)	09.01-05.05		**0 265 005 303**
1.4 FSI [9N3]			**1,4 l 59 kW BUD 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.06→		**0 261 230 095**
Accelerator pedal module			
Fg.no. →9N..6..300 000	05.06-05.06	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	05.06→		**0 265 005 601**
1.4 FSI [9N3]			**1,4 l 63 kW AXU 3 Zyl.**
Knock sensor	04.05-07.06		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	04.05-07.06		**0 261 230 095**
Accelerator pedal module	04.05-07.06	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	04.05-07.06		**0 265 005 601**

V

Product			
◀ Polo			
1.4 i			**1,4 l 55 kW BCC 4 Zyl.**
Knock sensor	06.03→		**0 261 231 146**
1.4 i [9N5]			**1,4 l 55 kW BBY 4 Zyl.**
Speed sensor, ignition/injection	10.02-05.05	FKW,GS	**0 261 210 257**
Knock sensor	10.02-05.05		**0 261 231 146**
1.4 i [9N5/9N6]			**1,4 l 55 kW BKY 4 Zyl.**
Knock sensor	06.04→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	06.04→		**0 261 230 095**
Duo sensor, acceleration and yaw rate, brake system	06.04→		**0 265 005 252**
1.4 TDI [6N2]			**1,4 l 55 kW AMF 3 Zyl.**
Air mass meter, diesel	10.99-09.01		**0 281 002 318**
			0 986 284 002
Boost pressure sensor, Diesel	10.99-09.01		**0 281 002 177**
Accelerator pedal module	10.99-09.01	GS,LLE	**0 281 002 321**
1.4 TDI [9N1]			**1,4 l 55 kW AMF; BAY 3 Zyl.**
Air mass meter, diesel			
Fg.no. →9N..2..120 000	09.01-04.02		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 9N..3..000 001→	05.02-05.05		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	09.01-05.05	TW	**0 281 002 177**
			0 281 002 399
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →9N..4..250 000	09.01-04.04		**0 265 005 252**
Fg.no. 9N..5..000 001→	05.04-05.05		**0 265 005 601**
Pressure sensor, ESP, (electronic stability program)	09.01-05.05		**0 265 005 303**
1.4 TDI [9N2]			**1,4 l 55 kW BAY 3 Zyl.**
Air mass meter, diesel	07.03→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	07.03→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	07.03→	TW	**0 265 005 252**
			0 265 005 601
1.4 TDI [9N3]			**1,4 l 51/58/59 kW BMS; BNM; BNV; BWB 3 Zyl.**
Air mass meter, diesel	04.05→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	04.05→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 601**
1.4 TDI [9N5]			**1,4 l 55 kW AMF 3 Zyl.**
Air mass meter, diesel	10.02-12.03		**0 281 002 757**
Boost pressure sensor, Diesel	10.02-12.03		**0 281 002 177**
1.4 TDI [9N5/9N6]			**1,4 l 55 kW AMF 3 Zyl.**
Air mass meter, diesel	10.03-05.05		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel	10.03-05.05		**0 281 002 177**
		TW	**0 281 002 399**
1.4 8V			**1,4 l 61 kW BLM 4 Zyl.**
Knock sensor	05.02-07.06		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.02-07.06		**0 261 230 095**
1.4 16V			**1,4 l 55 kW BBY 4 Zyl.**
Knock sensor	09.02-02.05		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	09.02-02.05		**0 261 230 095**
Accelerator pedal module	09.02-02.05	GS	**0 280 752 214**
1.4 16V			**1,4 l 55 kW BKY 4 Zyl.**
Knock sensor	08.06→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	08.06→		**0 261 230 095**
1.4 16V [6N2]			**1,4 l 55/74 kW AFK; AHW; AUA; AUB 4 Zyl.**
Knock sensor	09.98-09.01	KZA	**0 261 231 045**

Product			
1.6			**1,6 l 74 kW BAH 4 Zyl.**
Speed sensor, ignition/injection	05.02-07.06		**0 261 210 188**
Knock sensor	05.02→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.02→		**0 261 230 095**
Accelerator pedal module	05.02-07.06	GS	**0 280 752 214**
1.6 [6N1]			**1,6 l 55/88 kW AEA; AEE; AHS; AJV 4 Zyl.**
Knock sensor	10.94-12.99	KZA	**0 261 231 045**
1.6 [6N2]			**1,6 l 92 kW ARC 4 Zyl.**
Knock sensor	11.99-09.01	KZA	**0 261 231 045**
1.6 [9N2]			**1,6 l 74 kW BAH 4 Zyl.**
Knock sensor	07.03→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	07.03→		**0 261 230 095**
Accelerator pedal module	07.03→	GS	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	07.03→	TW	**0 265 005 252**
			0 265 005 601
1.6 [9N3]			**1,6 l 77 kW BTS 4 Zyl.**
Pressure sensor, intake manifold, gasoline	05.06→		**0 261 230 095**
Accelerator pedal module			
Fg.no. →9N..6..300 000	05.06-05.06	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	05.06→		**0 265 005 601**
1.6 i			**1,6 l 74 kW BCD 4 Zyl.**
Speed sensor, ignition/injection	06.03→		**0 261 210 199**
Knock sensor	06.03→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	06.03→		**0 261 230 031**
Accelerator pedal module	06.03→		**0 280 752 214**
1.6 i [9N5/9N6]			**1,6 l 74 kW BAH 4 Zyl.**
Knock sensor	10.03→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	10.03→		**0 261 230 095**
1.7 SDI [6N1]			**1,7 l 42 kW AHG 4 Zyl.**
Pedal position sensor, diesel			
Fg.no. →6N-WW 045 000,→6N-WY 066 000	04.97-07.97		**0 205 001 032**
1.7 SDI [6N2]			**1,7 l 42/44 kW AHG; AKU 4 Zyl.**
Accelerator pedal module	10.99-09.01	GS,LLE	**0 281 002 321**
1.8 GTI [9N3]			**1,8 l 110/132 kW BBU; BJX 4 Zyl.**
Throttle valve assembly	08.05→		**0 280 750 115**
Air mass meter, gasoline injection	08.05→		**0 280 218 063**
			0 986 280 217
Phase sensor	08.05→		**0 232 101 024**
Speed sensor, ignition/injection	08.05→		**0 261 210 199**
Knock sensor	08.05→		**0 261 231 146**
Boost pressure sensor, gasoline	08.05→		**0 281 002 399**
Accelerator pedal module			
Fg.no. →9N..6..300 000	08.05-05.06	AG,RLE	**0 280 752 220**
		GS,LLE	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	08.05→		**0 265 005 601**
1.9 D [6N1]			**1,9 l 47 kW AGD 4 Zyl.**
Pedal position sensor, diesel			
Fg.no. →6N-WW 045 000,→6N-WY 066 000	07.96-07.97		**0 205 001 032**
1.9 SDI [6N2]			**1,9 l 47 kW AGD; ASX 4 Zyl.**
Accelerator pedal module	10.99-09.01	GS,LLE	**0 281 002 321**
1.9 SDI [9N1]			**1,9 l 47 kW ASY 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →9N..4..250 000	09.01-04.04		**0 265 005 252**
Fg.no. 9N..5..000 001→	05.04-05.05		**0 265 005 601**
Pressure sensor, ESP, (electronic stability program)	09.01-05.05		**0 265 005 303**
1.9 SDI [9N2]			**1,9 l 47 kW ASY 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	11.03→	TW	**0 265 005 252**
			0 265 005 601

V

Product			
1.9 SDI [9N3]			**1,9 l 47 kW ASY 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 601**
1.9 TDi [9N5/9N6]			**1,9 l 96 kW ASZ 4 Zyl.**
Air mass meter, diesel	10.03→		**0 281 002 461**
			0 986 284 007
			0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	10.03→		**0 281 002 401**
1.9 TDi [9N6]			**1,9 l 74 kW ATD 4 Zyl.**
Air mass meter, diesel	10.04→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	10.04→	TW	**0 281 002 399**
1.9 TDI [9N1]			**1,9 l 74 kW ATD; AXR 4 Zyl.**
Air mass meter, diesel			
Fg.no. →9N..2..120 000	09.01-04.02		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Fg.no. 9N..3..000 001→	05.02-05.05		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	09.01-05.05	TW	**0 281 002 177**
			0 281 002 399
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →9N..4..250 000	09.01-04.04		**0 265 005 252**
Fg.no. 9N..5..000 001→	05.04-05.05		**0 265 005 601**
Pressure sensor, ESP, (electronic stability program)	09.01-05.05		**0 265 005 303**
1.9 TDI [9N1]			**1,9 l 96 kW ASZ 4 Zyl.**
Air mass meter, diesel	11.03-05.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	11.03-05.05		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →9N..4..250 000	11.03-04.04		**0 265 005 252**
Fg.no. 9N..5..000 001→	05.04-05.05		**0 265 005 601**
Pressure sensor, ESP, (electronic stability program)	11.03-05.05		**0 265 005 303**
1.9 TDI [9N1]			**1,9 l 96 kW BLT 4 Zyl.**
Air mass meter, diesel	05.04-05.05		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	05.04-05.05		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	05.04-05.05		**0 265 005 601**
Pressure sensor, ESP, (electronic stability program)	05.04-05.05		**0 265 005 303**
1.9 TDI [9N2]			**1,9 l 74 kW ATD 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	07.03→	TW	**0 265 005 252**
			0 265 005 601
1.9 TDI [9N3]			**1,9 l 74 kW ATD; AXR; BMT 4 Zyl.**
Air mass meter, diesel	04.05→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	04.05→		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 601**
1.9 TDI [9N3]			**1,9 l 96 kW ASZ; BLT 4 Zyl.**
Air mass meter, diesel	04.05→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	04.05→		**0 281 002 401**
Duo sensor, acceleration and yaw rate, brake system	04.05→		**0 265 005 601**
2.0			**2,0 l 85 kW BBX 4 Zyl.**
Throttle valve assembly	05.02-07.06		**0 280 750 061**
Air mass meter, gasoline injection	05.02-07.06		**0 280 218 060**
			0 986 280 216
Speed sensor, ignition/injection	05.02-07.06		**0 261 210 199**

Product			
Knock sensor	05.02-07.06		**0 261 231 146**
Pressure sensor, intake manifold, gasoline			
Fg.no. F 9A-3-033 710→	03.03-07.06		**0 261 230 095**
Fg.no. →F 9A-3-033 709	05.02-02.03		**0 261 230 031**
Accelerator pedal module	05.02-07.06	GS	**0 280 752 214**
2.0 [9N2]			**2,0 l 85 kW BBX 4 Zyl.**
Throttle valve assembly	07.03→		**0 280 750 061**
Speed sensor, ignition/injection	07.03→		**0 261 210 199**
Knock sensor	07.03→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	07.03→		**0 261 230 095**
Accelerator pedal module	07.03→	GS	**0 280 752 214**
Duo sensor, acceleration and yaw rate, brake system	07.03→	TW	**0 265 005 252**
			0 265 005 601

Polo Classic

1.3 [80]			**1,3 l 40/56-59 kW NZ; 3F 4 Zyl.**
Air flow sensor, gasoline injection	10.90-09.94		**0 280 200 048**
			0 986 280 030
1.3 [86,87]			**1,3 l 40 kW NZ 4 Zyl.**
Air flow sensor, gasoline injection	12.86-08.90		**0 280 200 048**
			0 986 280 030
1.3 [86,87]			**1,3 l 56-59 kW 3F 4 Zyl.**
Air flow sensor, gasoline injection	10.89-08.90		**0 280 200 048**
			0 986 280 030
Temperature sensor, coolant, injection system	10.89-08.90		**0 280 130 037**
1.4 [6V2]			**1,4 l 44 kW AEX 4 Zyl.**
Knock sensor	05.96-12.97		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	05.96-12.97		**0 261 230 011**
1.4 [6V2]			**1,4 l 44 kW AKK 4 Zyl.**
Throttle valve assembly	10.99-09.01		**0 280 750 049**
Speed sensor, ignition/injection			
Fg.no. →6K..1..529 200	10.99-10.00	BM6	**0 261 210 188**
Fg.no. 6K..1..529 201→	11.00-09.01	BM6	**0 261 210 213**
Knock sensor	10.99-09.01		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	10.99-09.01		**0 261 230 031**
1.4 [6V2]			**1,4 l 44 kW AKV 4 Zyl.**
Knock sensor	12.97-08.99		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	12.97-08.99		**0 261 230 011**
1.4 [6V2]			**1,4 l 44 kW ANW 4 Zyl.**
Throttle valve assembly			
Mot.no. ANW 051 561→	10.99-08.00		**0 280 750 095**
Mot.no. →ANW 051 560	10.99-08.00		**0 280 750 049**
Speed sensor, ignition/injection	10.99-08.00	BM6	**0 261 210 188**
Knock sensor	10.99-08.00		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	10.99-08.00		**0 261 230 031**
1.4 [6V2]			**1,4 l 44 kW ANX; APQ 4 Zyl.**
Knock sensor	12.97-08.99		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	12.97-08.99		**0 261 230 011**
1.4 [6V2]			**1,4 l 44 kW AUD 4 Zyl.**
Throttle valve assembly			
Mot.no. AUD 020 028→	06.00-09.01		**0 280 750 095**
Mot.no. →AUD 020 027	06.00-09.01		**0 280 750 049**
Speed sensor, ignition/injection			
Fg.no. →6K..1..529 200	06.00-10.00	BM6	**0 261 210 188**
Fg.no. 6K..1..529 201→	11.00-09.01	BM6	**0 261 210 213**
Knock sensor	06.00-09.01		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	06.00-09.01		**0 261 230 031**
1.4 [6V2]			**1,4 l 55 kW APE; AUA 4 Zyl.**
Knock sensor	10.99-09.01		**0 261 231 045**
1.4 i			**1,4 l 62 kW AGY 0 Zyl.**
Knock sensor	12.94-10.03	KZA	**0 261 231 045**
Temperature sensor, intake air, injection system	12.94-10.03		**0 280 130 039**

V

Product			
◀ Polo Classic			
1.6 [6V2]			**1,6 l 55 kW AEE; ALM 4 Zyl.**
Knock sensor	04.97-09.01		**0 261 231 045**
1.6 [6V2]			**1,6 l 74 kW AEH 4 Zyl.**
Phase sensor	10.99-09.01		**0 232 101 031**
Speed sensor, ignition/injection	10.99-09.01		**0 261 210 147**
1.6 [6V2]			**1,6 l 74 kW AFT 4 Zyl.**
Knock sensor	12.95-08.99		**0 261 231 036**
Temperature sensor, intake air, injection system	12.95-08.99		**0 280 130 039**
1.6 [6V2]			**1,6 l 74 kW AKL 4 Zyl.**
Phase sensor	10.99-09.01		**0 232 101 031**
Speed sensor, ignition/injection	10.99-09.01		**0 261 210 147**
1.6 [6V2]			**1,6 l 74 kW APF; AUR 4 Zyl.**
Phase sensor	03.00-09.01		**0 232 101 031**
Speed sensor, ignition/injection	03.00-09.01		**0 261 210 199**
1.6 i			**1,6 l 74 kW AFX 0 Zyl.**
Knock sensor	12.94-10.03	KZA	**0 261 231 045**
Temperature sensor, intake air, injection system	12.94-10.03		**0 280 130 039**
1.7 SDI [6V2]			**1,7 l 44 kW AKW 4 Zyl.**
Pedal position sensor, diesel	11.97-08.99		**0 205 001 032**
1.9 SDI [6V2]			**1,9 l 47 kW AEY 4 Zyl.**
Pedal position sensor, diesel	12.95-08.99		**0 205 001 032**
1.9 SDI [6V2]			**1,9 l 50 kW AGP; AQM 4 Zyl.**
Pedal position sensor, diesel	10.99-09.01		**0 281 002 269**
1.9 TDI			**1,9 l 66 kW AGR 4 Zyl.**
Air mass meter, diesel	09.00→		**0 281 002 216**
			0 986 284 001
Pedal position sensor, diesel	09.00→		**0 281 002 269**
1.9 TDI [6V2]			**1,9 l 66 kW AGR 4 Zyl.**
Air mass meter, diesel	10.99-09.01		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	10.99-09.01		**0 281 002 177**
Pedal position sensor, diesel	10.99-09.01		**0 281 002 269**
1.9 TDI [6V2]			**1,9 l 66 kW AHU; ALE 4 Zyl.**
Pressure sensor, intake manifold, diesel	07.96-08.99		**0 261 230 037**
Pedal position sensor, diesel	07.96-08.99		**0 205 001 032**
1.9 TDI [6V2]			**1,9 l 66 kW ALH 4 Zyl.**
Air mass meter, diesel	10.99-09.01		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	10.99-09.01		**0 281 002 177**
Pedal position sensor, diesel	10.99-09.01		**0 281 002 269**
1.9 TDI [6V2]			**1,9 l 81 kW AFN 4 Zyl.**
Pressure sensor, intake manifold, diesel	08.98-08.99		**0 261 230 037**
Pedal position sensor, diesel	08.98-08.99		**0 205 001 032**
1.9 TDI [6V2]			**1,9 l 81 kW ASV 4 Zyl.**
Air mass meter, diesel	10.99-09.01		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	10.99-09.01		**0 281 002 177**
Pedal position sensor, diesel	10.99-09.01		**0 281 002 269**
2.0 [6V2]			**2,0 l 85 kW ADC 4 Zyl.**
Knock sensor	08.99-09.01		**0 261 231 036**
Temperature sensor, intake air, injection system	08.99-09.01		**0 280 130 039**

Polo Coupé

1.3 [80]			**1,3 l 40/56-59 kW NZ; 3F 4 Zyl.**
Air flow sensor, gasoline injection	10.90-09.94		**0 280 200 048**
			0 986 280 030
1.3 [86,87]			**1,3 l 40 kW NZ 4 Zyl.**
Air flow sensor, gasoline injection	12.86-08.90		**0 280 200 048**
			0 986 280 030
1.3 [86,87]			**1,3 l 56-59 kW 3F 4 Zyl.**
Air flow sensor, gasoline injection	10.89-08.90		**0 280 200 048**
			0 986 280 030
Temperature sensor, coolant, injection system	10.89-08.90		**0 280 130 037**
1.3 G40 [80]			**1,3 l 85 kW PY 4 Zyl.**
Air flow sensor, gasoline injection	10.90-09.94		**0 280 200 041**
Knock sensor	10.90-12.90		**0 261 231 004**
		KZG	**0 261 231 038**
	12.90-09.94	KZS	**0 261 231 066**
1.3 G40 [86,87]			**1,3 l 85 kW PY 4 Zyl.**
Air flow sensor, gasoline injection	01.87-08.90		**0 280 200 041**

Polo Hatchback

1.4 i			**1,4 l 55 kW BCC 4 Zyl.**
Knock sensor	04.02→		**0 261 231 146**
1.6 i			**1,6 l 74 kW BCD 4 Zyl.**
Speed sensor, ignition/injection	09.02→		**0 261 210 199**
Knock sensor	09.02→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	09.02→		**0 261 230 031**
Accelerator pedal module	09.02→		**0 280 752 214**

Polo Playa

1.4 i			**1,4 l 62 kW AGY 4 Zyl.**
Knock sensor	10.98-10.02	KZA	**0 261 231 045**
Temperature sensor, intake air, injection system	10.98-10.02		**0 280 130 039**
1.6 i			**1,6 l 74 kW AFX 4 Zyl.**
Knock sensor	10.98-10.02	KZA	**0 261 231 045**
Temperature sensor, intake air, injection system	10.98-10.02		**0 280 130 039**
1.8 i			**1,8 l 82 kW AFV 4 Zyl.**
Knock sensor	10.98-10.02	KZA	**0 261 231 045**
Temperature sensor, intake air, injection system	10.98-10.02		**0 280 130 039**

Polo Sedan

1.4 TDI			**1,4 l 55 kW BAY 3 Zyl.**
Pressure sensor, intake manifold, diesel	06.03-03.05		**0 281 002 399**
1.4 8V			**1,4 l 61 kW BLM 4 Zyl.**
Knock sensor	05.02-07.06		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	05.02-07.06		**0 261 230 095**
1.4 16V			**1,4 l 55 kW BBY 4 Zyl.**
Speed sensor, ignition/injection	11.02-02.05	GS	**0 261 210 257**
Knock sensor	11.02-02.05		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	11.02-02.05		**0 261 230 095**
Accelerator pedal module	11.02-02.05	GS	**0 280 752 214**
1.6			**1,6 l 74 kW BAH 4 Zyl.**
Speed sensor, ignition/injection	11.02-07.06		**0 261 210 188**
Knock sensor	11.02-07.06		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	11.02-07.06		**0 261 230 095**
Accelerator pedal module	11.02-07.06	GS	**0 280 752 214**

Polo Variant

1.4 [6V5]			**1,4 l 44 kW AEX 4 Zyl.**
Knock sensor	05.97-12.97		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	05.97-12.97		**0 261 230 011**
1.4 [6V5]			**1,4 l 44 kW AKK 4 Zyl.**
Throttle valve assembly	10.99-09.01		**0 280 750 049**
Speed sensor, ignition/injection			
Fg.no. →6K..1..529 200	10.99-10.00	BM6	**0 261 210 188**
Fg.no. 6K..1..529 201→	11.00-09.01	BM6	**0 261 210 213**

V

Product			
Knock sensor	10.99-09.01		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	10.99-09.01		**0 261 230 031**
1.4 [6V5]			**1,4 l 44 kW AKV 4 Zyl.**
Knock sensor	12.97-08.99		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	12.97-08.99		**0 261 230 011**
1.4 [6V5]			**1,4 l 44 kW ANW 4 Zyl.**
Throttle valve assembly			
Mot.no. ANW 051 561→	10.99-08.00		**0 280 750 095**
Mot.no. →ANW 051 560	10.99-08.00		**0 280 750 049**
Speed sensor, ignition/injection	10.99-08.00	BM6	**0 261 210 188**
Knock sensor	10.99-08.00		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	10.99-08.00		**0 261 230 031**
1.4 [6V5]			**1,4 l 44 kW ANX; APQ 4 Zyl.**
Knock sensor	12.97-08.99		**0 261 231 045**
Pressure sensor, intake manifold, gasoline	12.97-08.99		**0 261 230 011**
1.4 [6V5]			**1,4 l 55 kW APE; AUA 4 Zyl.**
Knock sensor	10.99-09.01		**0 261 231 045**
1.6 [6V5]			**1,6 l 55 kW AEE; ALM 4 Zyl.**
Knock sensor	09.97-09.01		**0 261 231 045**
1.6 [6V5]			**1,6 l 74 kW AEH 4 Zyl.**
Phase sensor	10.99-09.01		**0 232 101 031**
Speed sensor, ignition/injection	10.99-09.01		**0 261 210 147**
1.6 [6V5]			**1,6 l 74 kW AFT 4 Zyl.**
Knock sensor	05.97-08.99		**0 261 231 036**
Temperature sensor, intake air, injection system	05.97-08.99		**0 280 130 039**
1.6 [6V5]			**1,6 l 74 kW AKL 4 Zyl.**
Phase sensor	10.99-09.01		**0 232 101 031**
Speed sensor, ignition/injection	10.99-09.01		**0 261 210 147**
1.6 [6V5]			**1,6 l 74 kW APF; AUR 4 Zyl.**
Phase sensor	03.00-09.01		**0 232 101 031**
Speed sensor, ignition/injection	03.00-09.01		**0 261 210 199**
1.7 SDI [6V5]			**1,7 l 44 kW AKW 4 Zyl.**
Pedal position sensor, diesel	11.97-08.99		**0 205 001 032**
1.9 SDI [6V5]			**1,9 l 47 kW AEY 4 Zyl.**
Pedal position sensor, diesel	06.97-08.99		**0 205 001 032**
1.9 SDI [6V5]			**1,9 l 50 kW AGP; AQM 4 Zyl.**
Pedal position sensor, diesel	10.99-09.01		**0 281 002 269**
1.9 TDI [6V5]			**1,9 l 66 kW AGR 4 Zyl.**
Air mass meter, diesel	10.99-09.01		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	10.99-09.01		**0 281 002 177**
Pedal position sensor, diesel	10.99-09.01		**0 281 002 269**
1.9 TDI [6V5]			**1,9 l 66 kW AHU; ALE 4 Zyl.**
Pressure sensor, intake manifold, diesel	06.97-08.99		**0 261 230 037**
Pedal position sensor, diesel	06.97-08.99		**0 205 001 032**
1.9 TDI [6V5]			**1,9 l 66 kW ALH 4 Zyl.**
Air mass meter, diesel	10.99-09.01		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	10.99-09.01		**0 281 002 177**
Pedal position sensor, diesel	10.99-09.01		**0 281 002 269**
1.9 TDI [6V5]			**1,9 l 81 kW AFN 4 Zyl.**
Pressure sensor, intake manifold, diesel	06.98-08.99		**0 261 230 037**
Pedal position sensor, diesel	06.98-08.99		**0 205 001 032**
1.9 TDI [6V5]			**1,9 l 81 kW ASV 4 Zyl.**
Air mass meter, diesel	10.99-09.01		**0 281 002 216**
			0 986 284 001
Boost pressure sensor, Diesel	10.99-09.01		**0 281 002 177**
Pedal position sensor, diesel	10.99-09.01		**0 281 002 269**

Product			
Santana			
1.6 i			**1,6 l 64 kW AYF 4 Zyl.**
Knock sensor	12.00→		**0 261 231 036**
Pressure sensor, intake manifold, gasoline	12.00→		**0 261 230 011**
Temperature sensor, coolant, injection system	12.00→		**0 280 130 040**
2.0 [32]			**2,0 l 85 kW JS 5 Zyl.**
Air flow sensor, gasoline injection	02.86-03.88		**0 438 120 211**
	06.85-01.86	MZF	**0 438 121 005**
Saveiro III			
1.9 D			**1,9 l 47 kW 4 Zyl.**
Wheel speed sensor, front	06.98-05.02		**0 265 006 218**
Wheel speed sensor, rear	06.98-05.02	LAB,TU2	**0 265 006 222**
		LAB,TU4	**0 265 006 410**
		RAB,TU2	**0 265 006 221**
		RAB,TU4	**0 265 006 411**
Scirocco II			
1.8 [53]			**1,8 l 68-70 kW JH 4 Zyl.**
Air flow sensor, gasoline injection	05.83-07.92		**0 438 120 162**
1.8 [53]			**1,8 l 82 kW DX; KT 4 Zyl.**
Air flow sensor, gasoline injection	01.86-07.92		**F 026 TX2 051**
			F 026 TX2 051
1.8 16V [53]			**1,8 l 95 kW PL 4 Zyl.**
Air flow sensor, gasoline injection	02.86-07.92		**0 438 121 046**
Knock sensor	02.86-07.92	KZG	**0 261 231 038**
Sharan			
1.8 T [7M8]			**1,8 l 110 kW AJH 4 Zyl.**
Air mass meter, gasoline injection	11.97-02.00		**0 280 217 117**
			0 986 280 201
Phase sensor	11.97-02.00		**0 232 101 024**
Speed sensor, ignition/injection	11.97-02.00		**0 261 210 147**
Temperature sensor, intake air, injection system	11.97-02.00		**0 280 130 085**
1.8 T [7M9, 7M6]			**1,8 l 110 kW AWC 4 Zyl.**
Throttle valve assembly	05.00→		**0 280 750 065**
Air mass meter, gasoline injection	05.00→		**0 280 218 060**
			0 986 280 216
Phase sensor	05.00→		**0 232 101 024**
Knock sensor	05.00→		**0 261 231 146**
Boost pressure sensor, gasoline			
Fg.no. →7M..2..014 000	05.00-06.01		**0 281 002 177**
Fg.no. 7M..2..014 001→	07.01→		**0 281 002 399**
Temperature sensor, intake air, injection system	05.00→		**0 280 130 085**
1.9 TDI [7M8]			**1,9 l 66 kW AHU 4 Zyl.**
Air mass meter, diesel			
Fg.no. 7M..W..020 001→	08.97-02.00		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Pedal position sensor, diesel			
Fg.no. →7M..W..020 000	07.96-08.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
1.9 TDI [7M8]			**1,9 l 66 kW ANU 4 Zyl.**
Air mass meter, diesel	03.99-02.00		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel	03.99-02.00		**0 281 002 177**

V

Product			
◀ Sharan			
1.9 TDI [7M8]			**1,9 l 66 kW 1Z 4 Zyl.**
Pedal position sensor, diesel	09.95-07.96	AG	**0 205 001 031**
		GS	**0 205 001 032**
1.9 TDI [7M8]			**1,9 l 81 kW AFN 4 Zyl.**
Air mass meter, diesel			
Fg.no. 7M..W..020 001→	08.97-02.00		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Pedal position sensor, diesel			
Fg.no. →7M..W..020 000	09.96-08.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
1.9 TDI [7M8]			**1,9 l 81 kW AVG 4 Zyl.**
Air mass meter, diesel	08.99-02.00		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
1.9 TDI [7M9, 7M6]			**1,9 l 66/85 kW ANU; AUY 4 Zyl.**
Air mass meter, diesel	04.00→		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel			
Fg.no. →7M..2..014 000	04.00-06.01		**0 281 002 177**
Fg.no. 7M..2..014 001→	07.01→		**0 281 002 399**
1.9 TDI [7M9, 7M6]			**1,9 l 85 kW BVK 4 Zyl.**
Air mass meter, diesel	11.05→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	11.05→		**0 281 002 399**
1.9 TDI [7M9, 7M6]			**1,9 l 96/110 kW ASZ; BTB 4 Zyl.**
Air mass meter, diesel	11.02→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	11.02→		**0 281 002 401**
1.9 TDI 4 Motion [7M9, 7M6]			**1,9 l 85 kW AUY 4 Zyl.**
Air mass meter, diesel	05.00→		**0 281 002 757**
		WW	**0 280 217 121**
			0 986 280 202
Boost pressure sensor, Diesel			
Fg.no. →7M..2..014 000	05.00-06.01		**0 281 002 177**
Fg.no. 7M..2..014 001→	07.01→		**0 281 002 399**
2.0 [7M8]			**2,0 l 85 kW ADY 4 Zyl.**
Knock sensor	09.95-02.00		**0 261 231 077**
Temperature sensor, intake air, injection system	09.95-02.00		**0 280 130 073**
2.0 [7M9, 7M6]			**2,0 l 85 kW ATM 4 Zyl.**
Throttle valve assembly	05.00→		**0 280 750 057**
Air mass meter, gasoline injection	05.00→		**0 280 218 060**
			0 986 280 216
Phase sensor	05.00→		**0 232 101 031**
Knock sensor	05.00→		**0 261 231 146**
2.0 TDI [7M9, 7M6]			**2,0 l 100/103 kW BRT; BVH 4 Zyl.**
Air mass meter, diesel	11.05→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	11.05→		**0 281 002 401**
2.8 [7M8]			**2,8 l 128 kW AAA 6 Zyl.**
Air mass meter, gasoline injection	09.95-02.00		**0 280 217 512**
			0 986 280 203
Phase sensor			
Mot.no. AAA 263 000→	12.97-02.00		**0 232 103 019**
Speed sensor, ignition/injection	09.95-02.00		**0 261 210 107**
Knock sensor	09.95-02.00	KZA	**0 261 231 077**
		KZW	**0 261 231 047**
Temperature sensor, intake air, injection system	09.95-02.00		**0 280 130 039**
2.8 [7M8]			**2,8 l 128 kW AMY 6 Zyl.**
Air mass meter, gasoline injection	04.98-02.00		**0 280 217 512**
			0 986 280 203
Phase sensor	04.98-02.00		**0 232 103 019**

Product			
Speed sensor, ignition/injection	04.98-02.00		**0 261 210 107**
Knock sensor	04.98-02.00	KZA	**0 261 231 077**
		KZW	**0 261 231 047**
Temperature sensor, intake air, injection system	04.98-02.00		**0 280 130 039**
2.8 [7M9, 7M6]			**2,8 l 150 kW AYL 6 Zyl.**
Throttle valve assembly	05.00→		**0 280 750 086**
Air mass meter, gasoline injection	05.00→		**0 280 218 017**
			0 986 280 208
Phase sensor	05.00→		**0 232 103 019**
Knock sensor	05.00→	OHL	**0 261 231 146**
2.8 syncro [7M8]			**2,8 l 128 kW AAA 6 Zyl.**
Air mass meter, gasoline injection	07.96-02.00		**0 280 217 512**
			0 986 280 203
Phase sensor			
Mot.no. AAA 263 000→	12.97-02.00		**0 232 103 019**
Speed sensor, ignition/injection	07.96-02.00		**0 261 210 107**
Knock sensor	07.96-02.00	KZA	**0 261 231 077**
		KZW	**0 261 231 047**
Temperature sensor, intake air, injection system	07.96-02.00		**0 280 130 039**
2.8 syncro [7M8]			**2,8 l 128 kW AMY 6 Zyl.**
Air mass meter, gasoline injection	04.98-02.00		**0 280 217 512**
			0 986 280 203
Phase sensor	04.98-02.00		**0 232 103 019**
Speed sensor, ignition/injection	04.98-02.00		**0 261 210 107**
Knock sensor	04.98-02.00	KZA	**0 261 231 077**
		KZW	**0 261 231 047**
Temperature sensor, intake air, injection system	04.98-02.00		**0 280 130 039**
2.8 4 Motion [7M9, 7M6]			**2,8 l 150 kW AYL 6 Zyl.**
Throttle valve assembly	05.00→		**0 280 750 086**
Air mass meter, gasoline injection	05.00→		**0 280 218 017**
			0 986 280 208
Phase sensor	05.00→		**0 232 103 019**
Knock sensor	05.00→	OHL	**0 261 231 146**
Tiguan			
1.4 TSI [5N1]			**1,4 l 110 kW BWK 4 Zyl.**
Knock sensor	11.07→		**0 261 231 146**
Boost pressure sensor, gasoline	11.07→		**0 281 002 401**
2.0 TDI [5N1]			**2,0 l 100/103 kW CBAA; CBAB 4 Zyl.**
Boost pressure sensor, Diesel	11.07→		**0 281 002 401**
Touareg			
2.5 TDI [7LA]			**2,5 l 120 kW BLK 5 Zyl.**
Air mass meter, diesel	07.03-11.06		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	07.03-11.06		**0 281 002 401**
2.5 TDI [7LA]			**2,5 l 120 kW BPD 5 Zyl.**
Boost pressure sensor, Diesel	01.06-11.06		**0 281 002 401**
2.5 TDI [7LA]			**2,5 l 128 kW BAC 5 Zyl.**
Air mass meter, diesel	01.03-11.06		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	01.03-11.06		**0 281 002 401**
2.5 TDI [7LA]			**2,5 l 128 kW BPE 5 Zyl.**
Boost pressure sensor, Diesel	01.06-11.06		**0 281 002 401**
2.5 TDI [7L6]			**2,5 l 120/128 kW BPD; BPE 5 Zyl.**
Boost pressure sensor, Diesel	12.06→		**0 281 002 401**
3.0 TDI [7LA]			**3,0 l 155 kW BUN 6 Zyl.**
Boost pressure sensor, Diesel	04.06-11.06		**0 281 002 401**
3.0 TDI [7LA]			**3,0 l 165 kW BKS 6 Zyl.**
Speed sensor, diesel	11.04-11.06	AG	**0 261 210 261**
Boost pressure sensor, Diesel	11.04-11.06		**0 281 002 401**

Product			
3.0 TDI [7L6]			**3,0 l 155/165 kW BKS; BUN 6 Zyl.**
Speed sensor, diesel	12.06→	AG	**0 261 210 261**
3.2 [7LA]			**3,2 l 162 kW AZZ; BAA; BKJ; BMV; BRJ 6 Zyl.**
Air mass meter, gasoline injection	11.02-11.06		**0 280 218 073**
			0 986 280 222
Phase sensor	11.02-11.06		**0 232 103 019**
Knock sensor	11.02-11.06	OHL	**0 261 231 146**
3.6 FSI [7LA]			**3,6 l 206 kW BHK 6 Zyl.**
Air mass meter, gasoline injection	08.05-11.06		**0 280 218 175**
Knock sensor	08.05-11.06	OHL	**0 261 231 146**
3.6 FSI [7LA]			**3,6 l 206 kW BHL 6 Zyl.**
Knock sensor	10.05-11.06	OHL	**0 261 231 146**
3.6 FSI [7L6]			**3,6 l 206 kW BHK 6 Zyl.**
Air mass meter, gasoline injection	12.06→		**0 280 218 175**
Knock sensor	12.06→	OHL	**0 261 231 146**
4.2 [7LA]			**4,2 l 228 kW AXQ 8 Zyl.**
Throttle valve assembly	12.02-11.06		**0 280 750 047**
Air mass meter, gasoline injection	12.02-11.06		**0 280 218 060**
			0 986 280 216
Phase sensor	12.02-11.06		**0 232 101 024**
Speed sensor, ignition/injection	12.02-05.05		**0 261 210 192**
	06.05-11.06		**0 261 210 261**
Knock sensor	12.02-11.06		**0 261 231 038**
4.2 [7LA]			**4,2 l 228 kW BHX 8 Zyl.**
Throttle valve assembly	04.03-11.06		**0 280 750 047**
Air mass meter, gasoline injection	04.03-11.06		**0 280 218 060**
			0 986 280 216
4.2 FSI [7LA]			**4,2 l 257 kW BAR 8 Zyl.**
Throttle valve assembly	06.06-11.06		**0 280 750 047**
Air mass meter, gasoline injection	06.06-11.06		**0 280 218 060**
			0 986 280 216
4.2 FSI [7L6]			**4,2 l 257 kW BAR 8 Zyl.**
Throttle valve assembly	12.06→		**0 280 750 047**
Air mass meter, gasoline injection	12.06→		**0 280 218 060**
			0 986 280 216
Speed sensor, ignition/injection	12.06→		**0 261 210 192**
5.0 TDI [7LA]			**5,0 l 230 kW AYH; BLE 10 Zyl.**
Air mass meter, diesel	11.02-11.06		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	11.02-11.06		**0 281 002 401**
5.0 TDI [7L6]			**5,0 l 230 kW BLE 10 Zyl.**
Air mass meter, diesel	12.06→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	12.06→		**0 281 002 401**
6.0 [7LA]			**6,0 l 331 kW BJN 12 Zyl.**
Air mass meter, gasoline injection	08.04-11.06		**0 280 218 073**
			0 986 280 222
Phase sensor	08.04-11.06		**0 232 103 019**
6.0 [7L6]			**6,0 l 331 kW BJN 12 Zyl.**
Air mass meter, gasoline injection	12.06→		**0 280 218 073**
			0 986 280 222
Phase sensor	12.06→		**0 232 103 019**

Touran

Product			
1.4 TSI [1T1]			**1,4 l 103 kW BMY 4 Zyl.**
Speed sensor, ignition/injection	02.06-11.06		**0 261 210 250**
Boost pressure sensor, gasoline	02.06-11.06		**0 281 002 401**
1.4 TSI [1T2]			**1,4 l 103 kW BMY 4 Zyl.**
Speed sensor, ignition/injection	11.06→		**0 261 210 250**
Boost pressure sensor, gasoline	11.06→		**0 281 002 401**
1.6 [1T1]			**1,6 l 75 kW BGU; BSE; BSF 4 Zyl.**
Speed sensor, ignition/injection	07.03-11.06		**0 261 210 199**
Knock sensor	07.03-11.06		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	07.03-11.06		**0 261 230 031**
1.6 [1T2]			**1,6 l 75 kW BSE; BSF 4 Zyl.**
Speed sensor, ignition/injection	11.06→		**0 261 210 199**
Knock sensor	11.06→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	11.06→		**0 261 230 031**
1.6 FSI [1T1]			**1,6 l 85 kW BAG 4 Zyl.**
Speed sensor, ignition/injection	02.03-05.04	AG	**0 261 210 250**
Knock sensor	02.03-05.04		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	02.03-05.04		**0 261 230 095**
1.6 FSI [1T1]			**1,6 l 85 kW BLF 4 Zyl.**
Speed sensor, ignition/injection	02.05-11.06	AG	**0 261 210 250**
Knock sensor	02.05-11.06		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	02.05-11.06		**0 261 230 095**
1.6 FSI [1T1]			**1,6 l 85 kW BLP 4 Zyl.**
Speed sensor, ignition/injection	05.04-05.05	AG	**0 261 210 250**
Pressure sensor, intake manifold, gasoline	05.04-05.05		**0 261 230 095**
1.6 FSI [1T2]			**1,6 l 85 kW BLF 4 Zyl.**
Speed sensor, ignition/injection	11.06→	AG	**0 261 210 250**
Knock sensor	11.06→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	11.06→		**0 261 230 095**
1.9 TDI [1T1]			**1,9 l 66 kW BRU; BXF 4 Zyl.**
Air mass meter, diesel	06.05-11.06		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	06.05-11.06		**0 281 002 399**
1.9 TDI [1T1]			**1,9 l 66 kW BXJ 4 Zyl.**
Air mass meter, diesel	07.06-11.06		**0 281 002 531**
			0 986 284 009
1.9 TDI [1T1]			**1,9 l 74/77 kW AVQ; BKC; BLS; BXE 4 Zyl.**
Air mass meter, diesel	02.03-11.06		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	02.03-11.06		**0 281 002 399**
1.9 TDI [1T2]			**1,9 l 66 kW BXF 4 Zyl.**
Air mass meter, diesel	11.06→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	11.06→		**0 281 002 399**
1.9 TDI [1T2]			**1,9 l 66 kW BXJ 4 Zyl.**
Air mass meter, diesel	11.06→		**0 281 002 461**
			0 986 284 007
1.9 TDI [1T2]			**1,9 l 77 kW BLS; BXE 4 Zyl.**
Air mass meter, diesel	11.06→		**0 281 002 531**
			0 986 284 009
Boost pressure sensor, Diesel	11.06→		**0 281 002 399**
2.0 Eco Fuel [1T1]			**2,0 l 80 kW BSX 4 Zyl.**
Phase sensor	02.06-11.06		**0 232 101 031**
Speed sensor, ignition/injection	02.06-11.06		**0 261 210 199**
Knock sensor	02.06-11.06		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	02.06-11.06		**0 261 230 095**
2.0 Eco Fuel [1T2]			**2,0 l 80 kW BSX 4 Zyl.**
Phase sensor	11.06→		**0 232 101 031**
Speed sensor, ignition/injection	11.06→		**0 261 210 199**
Knock sensor	11.06→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	11.06→		**0 261 230 095**
2.0 FSI [1T1]			**2,0 l 110 kW AXW; BLR; BLX; BLY; BVY 4 Zyl.**
Knock sensor	10.03-11.06	OHL	**0 261 231 146**
Pressure sensor, intake manifold, gasoline	10.03-11.06		**0 261 230 031**
2.0 FSI [1T1]			**2,0 l 110 kW BVZ 4 Zyl.**
Knock sensor	11.05-11.06	OHL	**0 261 231 146**
Pressure sensor, intake manifold, gasoline	11.05-11.06		**0 261 230 031**

V

Product			
◀ Touran			
2.0 FSI [1T2]			**2,0 l 110 kW BVY; BVZ 4 Zyl.**
Knock sensor	11.06→	OHL	**0 261 231 146**
Pressure sensor, intake manifold, gasoline	11.06→		**0 261 230 031**
2.0 i			**2,0 l 85 kW BJZ 4 Zyl.**
Phase sensor	11.04→		**0 232 101 094**
Speed sensor, ignition/injection	11.04→		**0 261 210 254**
Knock sensor	11.04→		**0 261 231 146**
Pressure sensor, intake manifold, gasoline	11.04→		**0 261 230 095**
2.0 TDI [1T1]			**2,0 l 100/103/125 kW AZV; BKD; BMM; BMN 4 Zyl.**
Air mass meter, diesel	02.03-11.06		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	02.03-11.06		**0 281 002 401**
2.0 TDI [1T2]			**2,0 l 100/103/125 kW AZV; BKD; BMM; BMN 4 Zyl.**
Air mass meter, diesel	11.06→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	11.06→		**0 281 002 401**

Transporter

2.1 Syncro [24, 25]			**2,1 l 64 kW SR 4 Zyl.**
Wheel speed sensor, front	10.86-07.92	LAB	**0 265 001 196**
		RAB	**0 265 001 198**
Wheel speed sensor, rear	10.86-07.92		**0 265 001 149**
2.1 Syncro [24, 25]			**2,1 l 70/82 kW DJ; MV 4 Zyl.**
Air flow sensor, gasoline injection	08.85-07.92		**0 280 202 079**
			0 986 280 011
Wheel speed sensor, front	08.85-07.92	LAB	**0 265 001 196**
		RAB	**0 265 001 198**
Wheel speed sensor, rear	08.85-07.92		**0 265 001 149**

Transporter T3

1.6 D [24, 25]			**1,6 l 37 kW CS 4 Zyl.**
Wheel speed sensor, front	08.85-07.87		**0 265 001 149**
Wheel speed sensor, rear	08.85-07.87		**0 265 001 151**
1.6 D Turbo [24, 25]			**1,6 l 51 kW JX 4 Zyl.**
Wheel speed sensor, front	08.85-07.92		**0 265 001 149**
Wheel speed sensor, rear	08.85-07.92		**0 265 001 151**
1.6 D Turbo Syncro [24, 25]			**1,6 l 51 kW JX 4 Zyl.**
Wheel speed sensor, front	03.86-07.92	LAB	**0 265 001 196**
		RAB	**0 265 001 198**
Wheel speed sensor, rear	03.86-07.92		**0 265 001 149**
1.7 D [24, 25]			**1,7 l 42 kW KY 4 Zyl.**
Wheel speed sensor, front	10.86-07.92		**0 265 001 149**
Wheel speed sensor, rear	10.86-07.92		**0 265 001 151**
1.9 [24, 25]			**1,9 l 40 kW EY 4 Zyl.**
Wheel speed sensor, rear	08.85-05.88		**0 265 001 151**
1.9 [24, 25]			**1,9 l 44 kW DF 4 Zyl.**
Wheel speed sensor, front	08.85-07.92		**0 265 001 149**
Wheel speed sensor, rear	08.85-07.92		**0 265 001 151**
1.9 [24, 25]			**1,9 l 54 kW SP 4 Zyl.**
Wheel speed sensor, rear	08.86-10.88		**0 265 001 151**
1.9 [24, 25]			**1,9 l 57 kW DG 4 Zyl.**
Wheel speed sensor, front	08.85-07.92		**0 265 001 149**
Wheel speed sensor, rear	08.85-07.92		**0 265 001 151**
1.9 Syncro [24, 25]			**1,9 l 54/57 kW DG; SP 4 Zyl.**
Wheel speed sensor, front	08.85-07.92	LAB	**0 265 001 196**
		RAB	**0 265 001 198**
Wheel speed sensor, rear	08.85-07.92		**0 265 001 149**
2.1 [24, 25]			**2,1 l 64/68/70 kW MV; SR; SS 4 Zyl.**
Air flow sensor, gasoline injection	08.85-07.92		**0 280 202 079**
			0 986 280 011
Wheel speed sensor, rear	08.85-07.92		**0 265 001 151**

Product			
2.1 [24, 25]			**2,1 l 82 kW DJ 4 Zyl.**
Air flow sensor, gasoline injection	07.85-07.92		**0 280 202 079**
			0 986 280 011
Wheel speed sensor, front	08.85-07.92		**0 265 001 149**
Wheel speed sensor, rear	08.85-07.92		**0 265 001 151**

Transporter T4

1.8 [70]			**1,8 l 49 kW PD 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	12.90-07.92		**0 265 005 214**
Wheel speed sensor, front	12.90-07.92		**0 265 006 407**
Wheel speed sensor, rear	12.90-07.92	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
1.9 D [70]			**1,9 l 45 kW 1X 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.90-04.97		**0 265 005 214**
Wheel speed sensor, front	09.90-04.97		**0 265 006 407**
Wheel speed sensor, rear	09.90-04.97	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-04.97	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
1.9 D Turbo [70]			**1,9 l 50 kW ABL 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	10.92-06.03		**0 265 005 214**
Wheel speed sensor, front	10.92-06.03		**0 265 006 407**
Wheel speed sensor, rear	10.92-06.03	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-06.03	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.0 [70]			**2,0 l 62 kW AAC 4 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.90-06.03		**0 265 005 214**
Wheel speed sensor, front	09.90-06.03		**0 265 006 407**
Wheel speed sensor, rear	09.90-06.03	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-06.03	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.4 D [70]			**2,4 l 55 kW AJA 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	05.97-06.03		**0 265 005 214**
Wheel speed sensor, front	05.97-06.03		**0 265 006 407**
Wheel speed sensor, rear	05.97-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.4 D [70]			**2,4 l 57 kW AAB 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.90-05.98		**0 265 005 214**
Wheel speed sensor, front	09.90-05.98		**0 265 006 407**
Wheel speed sensor, rear	09.90-05.98	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-05.98	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.4 D Syncro [7D]			**2,4 l 57 kW AAB 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	11.92-09.98		**0 265 005 214**
Wheel speed sensor, front	11.92-09.98		**0 265 006 407**
Wheel speed sensor, rear	11.92-09.98	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-09.98	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**

Product			
2.5 [70]			**2,5 l 81 kW AAF 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	11.90-12.93		**0 265 005 214**
Wheel speed sensor, front	11.90-12.93		**0 265 006 407**
Wheel speed sensor, rear	11.90-12.93	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
2.5 [70]			**2,5 l 81 kW ACU 5 Zyl.**
Knock sensor	01.94-10.96	L30	**0 261 231 066**
		L34	**0 261 231 077**
Duo sensor, acceleration and yaw rate, brake system	01.94-10.96		**0 265 005 214**
Wheel speed sensor, front	01.94-10.96		**0 265 006 407**
Wheel speed sensor, rear	01.94-10.96	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-10.96	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.5 [70]			**2,5 l 81 kW AEN 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	09.95-12.95		**0 265 005 214**
Wheel speed sensor, front	09.95-12.95		**0 265 006 407**
Wheel speed sensor, rear	09.95-12.95	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
2.5 [70]			**2,5 l 81 kW AEU 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	08.96-06.03		**0 265 005 214**
Wheel speed sensor, front	08.96-06.03		**0 265 006 407**
Wheel speed sensor, rear	08.96-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 [70]			**2,5 l 85 kW AET; APL; AVT 5 Zyl.**
Knock sensor	08.96-06.03	L30	**0 261 231 066**
		L34	**0 261 231 077**
Duo sensor, acceleration and yaw rate, brake system	08.96-06.03		**0 265 005 214**
Wheel speed sensor, front	08.96-06.03		**0 265 006 407**
Wheel speed sensor, rear	08.96-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 Syncro [7D]			**2,5 l 81 kW AAF 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	11.92-12.93		**0 265 005 214**
Wheel speed sensor, front	11.92-12.93		**0 265 006 407**
Wheel speed sensor, rear	11.92-12.93	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
2.5 Syncro [7D]			**2,5 l 81 kW ACU 5 Zyl.**
Knock sensor	01.94-10.96	L30	**0 261 231 066**
		L34	**0 261 231 077**
Duo sensor, acceleration and yaw rate, brake system	01.94-10.96		**0 265 005 214**
Wheel speed sensor, front	01.94-10.96		**0 265 006 407**
Wheel speed sensor, rear	01.94-10.96	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-10.96	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**
2.5 Syncro [7D]			**2,5 l 81 kW AEU 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	06.97-11.01		**0 265 005 214**
Wheel speed sensor, front	06.97-11.01		**0 265 006 407**
Wheel speed sensor, rear	06.97-11.01	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 Syncro [7D]			**2,5 l 85 kW AET; APL; AVT 5 Zyl.**
Knock sensor	05.96-06.03	L30	**0 261 231 066**
		L34	**0 261 231 077**
Duo sensor, acceleration and yaw rate, brake system	05.96-06.03		**0 265 005 214**
Wheel speed sensor, front	05.96-06.03		**0 265 006 407**
Wheel speed sensor, rear	05.96-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 65 kW AJT 5 Zyl.**
Air mass meter, diesel			
Fg.no. →70..1H048 284,→70..1X047 893	05.98-08.00		**0 281 002 216**
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	05.98-04.01		**0 281 002 177**
Fg.no. 70..1..200 001→	05.01-06.03		**0 281 002 399**
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	05.98-05.99	GS	**0 205 001 020**
Duo sensor, acceleration and yaw rate, brake system	05.98-06.03		**0 265 005 214**
Wheel speed sensor, front	05.98-06.03		**0 265 006 407**
Wheel speed sensor, rear	05.98-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 65 kW AYY 5 Zyl.**
Air mass meter, diesel	10.01-06.03		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel	10.01-06.03		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	10.01-06.03		**0 265 005 214**
Wheel speed sensor, front	10.01-06.03		**0 265 006 407**
Wheel speed sensor, rear	10.01-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 75 kW ACV 5 Zyl.**
Air mass meter, diesel			
Fg.no. →70..1H048 284,→70..1X047 893	05.98-08.00		**0 281 002 216**
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	01.95-04.01		**0 281 002 177**
Fg.no. 70..1..200 001→	05.01-06.03		**0 281 002 399**
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	01.95-05.99	GS	**0 205 001 020**
Duo sensor, acceleration and yaw rate, brake system	01.95-06.03		**0 265 005 214**
Wheel speed sensor, front	01.95-06.03		**0 265 006 407**
Wheel speed sensor, rear	01.95-06.03	LAB,MVB	**0 265 006 508**
		MVB,RAB	**0 265 006 510**
Fg.no. 70..T..200 001→	01.96-06.03	LAB,OBB	**0 265 006 408**
		OBB,RAB	**0 265 006 409**

V

Product

◀ Transporter T4

2.5 TDI [70]			**2,5 l 75 kW AUF 5 Zyl.**
Air mass meter, diesel			
Fg.no. →70..1H048 284,→70..1X047 893	05.99-08.00		**0 281 002 216**
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	05.99-04.01		**0 281 002 177**
Fg.no. 70..1..200 001→	05.01-06.03		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	05.99-06.03		**0 265 005 214**
Wheel speed sensor, front	05.99-06.03		**0 265 006 407**
Wheel speed sensor, rear	05.99-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 75 kW AXL 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	04.01-06.03		**0 265 005 214**
Wheel speed sensor, front	04.01-06.03		**0 265 006 407**
Wheel speed sensor, rear	04.01-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 75 kW AYC 5 Zyl.**
Air mass meter, diesel	04.01-06.03		**0 281 002 463**
			0 986 284 008
Duo sensor, acceleration and yaw rate, brake system	04.01-06.03		**0 265 005 214**
Wheel speed sensor, front	04.01-06.03		**0 265 006 407**
Wheel speed sensor, rear	04.01-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 111 kW AHY 5 Zyl.**
Air mass meter, diesel			
Fg.no. →70..1..001 319	05.98-05.00		**0 280 217 529**
			0 986 280 204
Fg.no. 70..1..001 320→	06.00-09.00		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	05.98-09.00		**0 281 002 177**
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	05.98-05.99	GS	**0 205 001 020**
Duo sensor, acceleration and yaw rate, brake system	05.98-09.00		**0 265 005 214**
Wheel speed sensor, front	05.98-09.00		**0 265 006 407**
Wheel speed sensor, rear	05.98-09.00	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI [70]			**2,5 l 111 kW AXG 5 Zyl.**
Air mass meter, diesel	09.00-06.03		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	09.00-04.01		**0 281 002 177**
Fg.no. 70..1..200 001→	05.01-06.03		**0 281 002 399**
Duo sensor, acceleration and yaw rate, brake system	09.00-06.03		**0 265 005 214**
Wheel speed sensor, front	09.00-06.03		**0 265 006 407**
Wheel speed sensor, rear	09.00-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**

Product

2.5 TDI Syncro [7D]			**2,5 l 75 kW ACV 5 Zyl.**
Air mass meter, diesel			
Fg.no. →70..1H048 284,→70..1X047 893	05.98-08.00		**0 281 002 216**
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		**0 281 002 463**
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	03.98-04.01		**0 281 002 177**
Fg.no. 70..1..200 001→	05.01-06.03		**0 281 002 399**
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	03.98-05.99	GS	**0 205 001 020**
Duo sensor, acceleration and yaw rate, brake system	03.98-06.03		**0 265 005 214**
Wheel speed sensor, front	03.98-06.03		**0 265 006 407**
Wheel speed sensor, rear	03.98-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.5 TDI Syncro [7D]			**2,5 l 75 kW AXL 5 Zyl.**
Duo sensor, acceleration and yaw rate, brake system	04.01-06.03		**0 265 005 214**
Wheel speed sensor, front	04.01-06.03		**0 265 006 407**
Wheel speed sensor, rear	04.01-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.8 [70]			**2,8 l 103 kW AES 6 Zyl.**
Air mass meter, gasoline injection	01.96-05.00		**0 280 217 512**
			0 986 280 203
Phase sensor			
Mot.no. AES 010 241→	12.97-05.00		**0 232 103 019**
Speed sensor, ignition/injection	01.96-05.00		**0 261 210 107**
Temperature sensor, intake air, injection system	01.96-05.00		**0 280 130 039**
Duo sensor, acceleration and yaw rate, brake system	01.96-05.00		**0 265 005 214**
Wheel speed sensor, front	01.96-05.00		**0 265 006 407**
Wheel speed sensor, rear	01.96-05.00	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**
2.8 [70]			**2,8 l 150 kW AMV 6 Zyl.**
Throttle valve assembly	05.00-06.03		**0 280 750 086**
Air mass meter, gasoline injection	05.00-06.03		**0 280 218 017**
			0 986 280 208
Phase sensor	05.00-06.03		**0 232 103 019**
Duo sensor, acceleration and yaw rate, brake system	05.00-06.03		**0 265 005 214**
Wheel speed sensor, front	05.00-06.03		**0 265 006 407**
Wheel speed sensor, rear	05.00-06.03	LAB,MVB	**0 265 006 508**
		LAB,OBB	**0 265 006 408**
		MVB,RAB	**0 265 006 510**
		OBB,RAB	**0 265 006 409**

Transporter T5

1.9 TDI [7H]	**1,9 l 62/63/75/77 kW AXB; AXC; BRR; BRS 4 Zyl.**	
Air mass meter, diesel	04.03→	**0 281 002 531**
		0 986 284 009
Boost pressure sensor, Diesel	04.03→	**0 281 002 399**
1.9 TDI [7J]	**1,9 l 62/63/75/77 kW AXB; AXC; BRR; BRS 4 Zyl.**	
Air mass meter, diesel	04.03→	**0 281 002 531**
		0 986 284 009
Boost pressure sensor, Diesel	04.03→	**0 281 002 399**

Product			
2.0 [7H]			**2,0 l 85 kW AXA 4 Zyl.**
Throttle valve assembly	06.03→		**0 280 750 167**
Air mass meter, gasoline injection	06.03→		**0 280 218 060**
			0 986 280 216
Phase sensor	06.03→		**0 232 101 031**
Knock sensor	06.03→	OHL	**0 261 231 146**
2.0 [7J]			**2,0 l 85 kW AXA 4 Zyl.**
Throttle valve assembly	06.03→		**0 280 750 167**
Air mass meter, gasoline injection	06.03→		**0 280 218 060**
			0 986 280 216
Phase sensor	06.03→		**0 232 101 031**
Knock sensor	06.03→	OHL	**0 261 231 146**
2.5 TDI [7H]			**2,5 l 96/120/128 kW AXD; AXE; BLJ 5 Zyl.**
Air mass meter, diesel	02.03→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	02.03→		**0 281 002 401**
2.5 TDI [7J]			**2,5 l 96 kW AXD 5 Zyl.**
Air mass meter, diesel	04.03→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	04.03→		**0 281 002 401**
2.5 TDI [7J]			**2,5 l 96 kW BNZ 5 Zyl.**
Boost pressure sensor, Diesel	06.06→		**0 281 002 401**
2.5 TDI [7J]			**2,5 l 128 kW AXE 5 Zyl.**
Air mass meter, diesel	01.04→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	01.04→		**0 281 002 401**
2.5 TDI [7J]			**2,5 l 128 kW BPC 5 Zyl.**
Boost pressure sensor, Diesel	06.06→		**0 281 002 401**
2.5 TDI 4 Motion [7H]			**2,5 l 96/128 kW AXD; AXE 5 Zyl.**
Air mass meter, diesel	07.04→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	07.04→		**0 281 002 401**
2.5 TDI 4 Motion [7J]			**2,5 l 96 kW AXD 5 Zyl.**
Air mass meter, diesel	07.04→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	07.04→		**0 281 002 401**
2.5 TDI 4 Motion [7J]			**2,5 l 96 kW BNZ 5 Zyl.**
Boost pressure sensor, Diesel	06.06→		**0 281 002 401**
2.5 TDI 4 Motion [7J]			**2,5 l 128 kW AXE 5 Zyl.**
Air mass meter, diesel	07.04→		**0 281 002 461**
			0 986 284 007
Boost pressure sensor, Diesel	07.04→		**0 281 002 401**
2.5 TDI 4 Motion [7J]			**2,5 l 128 kW BPC 5 Zyl.**
Boost pressure sensor, Diesel	06.06→		**0 281 002 401**
3.2 [7H]			**3,2 l 170/173 kW BDL; BKK 6 Zyl.**
Throttle valve assembly	02.03→		**0 280 750 086**
Air mass meter, gasoline injection	02.03→		**0 280 218 073**
			0 986 280 222
Phase sensor	02.03→		**0 232 103 019**
Knock sensor	02.03→	OHL	**0 261 231 146**
3.2 [7J]			**3,2 l 170 kW BDL 6 Zyl.**
Throttle valve assembly	02.04→		**0 280 750 086**
Air mass meter, gasoline injection	02.04→		**0 280 218 073**
			0 986 280 222
Phase sensor	02.04→		**0 232 103 019**
Knock sensor	02.04→	OHL	**0 261 231 146**
3.2 4 Motion [7H]			**3,2 l 173 kW BKK 6 Zyl.**
Throttle valve assembly	07.04→		**0 280 750 086**
Air mass meter, gasoline injection	07.04→		**0 280 218 073**
			0 986 280 222

Product			
Phase sensor	07.04→		**0 232 103 019**
Knock sensor	07.04→	OHL	**0 261 231 146**
3.2 4 Motion [7J]			**3,2 l 170 kW BDL 6 Zyl.**
Throttle valve assembly	07.04→		**0 280 750 086**
Air mass meter, gasoline injection	07.04→		**0 280 218 073**
			0 986 280 222
Phase sensor	07.04→		**0 232 103 019**
Knock sensor	07.04→	OHL	**0 261 231 146**

Vanagon

2.1 , Syncro [24-27]			**2,1 l 70 kW MV 4 Zyl.**
Air flow sensor, gasoline injection	08.85-07.92		**0 280 202 079**
			0 986 280 011

Vento

1.4 [1H2]			**1,4 l 44 kW AEX 4 Zyl.**
Knock sensor	07.95-12.97	KZA	**0 261 231 045**
Pressure sensor, intake manifold, gasoline	07.95-12.97		**0 261 230 011**
1.6 [1H2]			**1,6 l 55 kW AEA; AEE 4 Zyl.**
Knock sensor	10.94-12.97	KZA	**0 261 231 045**
1.6 [1H2]			**1,6 l 74 kW AEK 4 Zyl.**
Air mass meter, gasoline injection	10.94-12.95		**0 280 217 103**
Knock sensor	10.94-12.95		**0 261 231 036**
Temperature sensor, intake air, injection system	10.94-12.95		**0 280 130 039**
1.6 [1H2]			**1,6 l 74 kW AFT; AKS 4 Zyl.**
Knock sensor	12.95-12.97		**0 261 231 036**
Temperature sensor, intake air, injection system	12.95-12.97		**0 280 130 039**
1.8 [1H2]			**1,8 l 55/66 kW AAM; ABS 4 Zyl.**
Temperature sensor, coolant, injection system	11.91-12.97		**0 280 130 040**
1.9 SDI [1H2]			**1,9 l 47 kW AEY 4 Zyl.**
Pedal position sensor, diesel	01.95-12.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
1.9 TDI [1H2]			**1,9 l 66 kW AHU; ALE 4 Zyl.**
Pedal position sensor, diesel	08.96-12.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
1.9 TDI [1H2]			**1,9 l 66 kW 1Z 4 Zyl.**
Pressure sensor, intake manifold, diesel			
Fg.no. →1H..SP078 090,→1H..SK009 001	09.93-07.94		**0 261 230 037**
Pedal position sensor, diesel	07.95-07.96	AG	**0 205 001 031**
		GS	**0 205 001 032**
	09.93-06.95	LLE	**0 205 001 024**
		RLE	**0 205 001 023**
1.9 TDI [1H2]			**1,9 l 81 kW AFN 4 Zyl.**
Pedal position sensor, diesel	02.96-12.97	AG	**0 205 001 031**
		GS	**0 205 001 032**
2.0 [1H2]			**2,0 l 79/85 kW ADY; AEP; AGG; AKR 4 Zyl.**
Knock sensor	10.94-12.97	KZA	**0 261 231 077**
2.0 [1H2]			**2,0 l 85 kW 2E 4 Zyl.**
Pulse generator, ignition/Jetronic	11.91-09.94		**0 356 914 213**
Knock sensor	11.91-09.94	KZA	**0 261 231 077**
2.8 [1H2]			**2,8 l 120 kW AAA 6 Zyl.**
Air mass meter, gasoline injection	07.94-04.96		**0 280 217 504**
	05.96-12.97		**0 280 217 512**
			0 986 280 203
Speed sensor, ignition/injection	07.94-06.95		**0 261 210 080**
	07.95-12.97		**0 261 210 107**
Knock sensor	07.94-12.97	KZA	**0 261 231 077**
		KZW	**0 261 231 047**
Temperature sensor, intake air, injection system	07.94-12.97		**0 280 130 039**

V

Product				
◀ Vento				
2.8 [1H2]			**2,8 l 128 kW AAA 6 Zyl.**	
Air mass meter, gasoline injection	01.92-06.94		**0 280 213 021**	
			0 986 280 122	
	07.94-04.96		**0 280 217 504**	
	05.96-12.97		**0 280 217 512**	
			0 986 280 203	

Product			
Speed sensor, ignition/injection	01.92-06.95		**0 261 210 080**
	07.95-12.97		**0 261 210 107**
Knock sensor	01.92-12.97	KZA	**0 261 231 077**
		KZW	**0 261 231 047**
Temperature sensor, intake air, injection system	01.92-12.97		**0 280 130 039**

V

de

Gegenüberstellung

Benutzerhinweise

Im nachfolgenden Katalogteil sind Bestellnummern von Herstellern anderer Marken, für die es einbaugleiche Bosch-Erzeugnisse oder -Teile gibt, aufgeführt. Da die verschiedenartigsten Bezeichnungssysteme angewendet werden, konnten die fremden Bestellnummern nur in einer einheitlichen, alphanumerischen Sortierfolge geordnet werden. Sie weicht bei einigen Herstellern von der dort üblichen Sortierfolge ab. Eine Rückumschlüsselung von Bosch- zu Fremdnummern ist nicht zulässig.

Hinweis

Aus wettbewerbsrechtlichen Gründen dürfen gegenüber Endkunden zur Kennzeichnung von Bosch-Teilen nur die Bosch-Teilenummern verwendet werden.

en

Cross-reference

Notes for users

The following catalog section lists part numbers of non-Bosch equipment for which there are interchangeable Bosch products or components available. Since a wide range of different designation systems are used, we were forced to arrange the non-Bosch part numbers in a uniform alphanumerical order. This differs from the customary order employed by some manufacturers. Reconversion of Bosch numbers back to the numbers of other manufacturers is not permitted.

Note

The laws governing competition stipulate that only Bosch type numbers may be used vis-à-vis the final customer for the identification of Bosch parts.

fr

Table de correspondance

A l'attention de l'utilisateur

Cette section du catalogue reprend les références des fabricants d'autres marques pour lesquelles il existe des produits ou des composants Bosch de montage identique. De multiples systèmes de codage étant utilisés, les références des produits d'autres marques ne peuvent être reprises que suivant un classement alphanumérique uniforme. Pour certains fabricants, ce classement peut différer de celui qu'ils utilisent habituellement. La reconversion de références Bosch en références d'autres marques n'est pas autorisée.

Remarque

En raison des dispositions légales concernant la concurrence seules les références Bosch peuvent être utilisées vis-à-vis des clients finaux pour l'identification des pièces Bosch.

it

Comparazione

Avvertenze per la consultazione

Nella seguente parte del catalogo vengono riportati i numeri di ordinazione di costruttori di prodotti d'altra marca, per i quali sono disponibili prodotti o parti di prodotti Bosch di corrispondente applicazione. Dato che vengono utilizzati i più diversi sistemi di denominazione, si è potuto ordinare i numeri di ordinazione di altra marca solo in una sequenza di classificazione unitaria ed alfanumerica. Per alcune case costruttrici si differenzia perciò dalla sequenza di classificazione normalmente usata. In questo confronto le sigle Bosch vanno considerate come dati indicativi. Non è ammessa una ricodificazione da numeri di ordinazione Bosch a numeri di altra marca.

Avvertenza

Per motivi legati ai diritti che regolano la concorrenza, per l'identificazione dei componenti Bosch destinati all'utente finale, possono essere impiegati solo i codici Bosch.

es

Equivalencias

Indicaciones para el usuario

A continuación se han relacionado números de pedido de fabricantes de otras marcas para los que existen productos o piezas Bosch de iguales características. Dado que se utilizan los más diversos sistemas de designación, los números de pedido ajenos han podido relacionarse tan sólo en un orden unificado, alfanumérico. En el caso de algunos fabricantes, el orden de esta clasificación difiere del que utilizan habitualmente. No es admisible la recodificación de los números de Bosch en números ajenos.

Nota

Por aspectos legales relativos a la competencia, de cara a los clientes finales únicamente deben utilizarse los números de piezas tipo Bosch para identificar piezas Bosch.

ALFA ROMEO

112 68 5	**0 232 103 052**
113 05 05 015 00	**0 335 530 031**
113 10 11 021 00	**0 280 101 001**
113 56 05 018 00	**0 261 211 003**
115 44 05 013 00	**0 261 210 001**
115 44 05 013 00	**0 261 210 002**
115 44 05 013 00/00	**0 261 210 001**
115 44 05 014 00	**0 261 230 001**
116 00 65 135 24	**0 332 204 101**
116 08 01 633 00	**0 335 541 002**
116 10 65 135 07	**0 332 014 151**
116 10 65 135 14	**0 332 204 101**
116 46 11 013 00	**0 280 202 013**
116 46 11 013 00/00	**0 280 202 013**
116 46 11 022 00	**0 280 120 302**
116 85 11 013 00	**0 280 202 027**
116 85 11 013 00	**0 986 280 078**
116 85 11 022 00	**0 280 120 304**
116 85 11 043 00	**0 280 230 001**
116 96 51 350 00	**0 332 014 151**
119 11 11 010 00	**0 280 130 023**
119 11 11 013 00	**0 280 202 010**
119 11 11 043 00	**0 332 514 105**
119 11 11 043 01	**0 332 514 127**
119 11 11 043 01/00	**0 332 514 121**
130 74 33 080	**0 204 154 020**
131 53 52 080	**0 204 154 044**
131 53 52 080	**0 204 154 045**
132 03 27 080	**0 265 006 427**
132 03 28 080	**0 265 006 406**
164 00 45 136 00	**0 265 001 156**
164 00 45 137 00	**0 265 001 074**
164 00 45 138 00	**0 265 001 073**
164 20 45 136 01	**0 265 001 156**
164 20 45 136 02	**0 265 001 156**
164 76 11 135 00	**0 280 230 006**
195 00 11 013 00	**0 280 202 045**
195 00 11 022 00	**0 280 120 300**
195 05 05 017 00	**0 261 231 001**
195 05 05 017 01	**0 261 231 006**
195 05 05 018 00	**0 261 211 004**
195 05 11 010 00	**0 280 130 032**
195 05 11 013 00	**0 280 202 058**
195 05 11 043 00	**0 280 230 009**
195 26 11 013 00	**0 280 202 078**
195 32 11 010 00	**0 280 130 026**
195 32 11 013 01	**0 280 202 201**
195 32 11 013 01	**0 986 280 069**
195 32 11 019 00	**0 261 210 036**
195 36 11 013 02	**0 280 202 202**
195 36 11 022 00	**0 280 120 311**
195 46 11 013 00	**0 280 202 105**
195 50 11 013 00	**0 280 202 108**
195 50 11 013 00	**0 986 280 067**
195 63 11 013 00	**0 280 202 113**
195 64 11 013 00	**0 280 203 034**
195 70 11 013 00	**0 280 202 060**
195 70 11 013 00	**0 986 280 046**
233 59 11	**0 265 007 079**
464 07 008	**0 280 217 111**
464 11 675	**0 281 002 144**
464 16 748	**0 280 217 514**
464 21 112	**0 265 006 238**
464 32 103	**0 281 002 213**
464 33 053	**0 281 002 137**
464 34 529	**0 265 006 164**
464 34 53	**0 265 006 163**
464 37 264	**0 281 002 214**
464 42 040	**0 204 120 946**
464 44 280	**0 280 752 005**
464 44 287	**0 280 217 531**
464 46 873	**0 281 002 214**
464 47 503	**0 280 218 019**
464 47 503	**0 986 280 236**
464 50 545	**0 265 006 325**
464 51 1118	**0 265 006 212**
464 56 661	**0 265 006 163**
464 56 796	**0 205 001 010**
464 57 537	**0 265 006 164**
464 60 544	**0 265 006 364**
464 60 545	**0 265 006 365**
464 63 384	**0 204 120 987**
464 64 9280	**0 280 217 102**
464 66 175	**0 205 003 052**
464 68 682	**0 281 002 137**
464 68 682	**0 281 002 215**
464 69 867	**0 261 231 131**
464 69 917	**0 280 218 001**
464 69 917	**0 986 280 234**
46472687	**0 261 210 163**
46473033	**0 265 006 540**
46473049	**0 265 006 539**
46474583	**0 261 210 161**
46474585	**0 261 230 035**
46475007	**0 280 750 013**
46477973	**0 261 210 167**
46478160	**0 280 752 004**
46481638	**0 281 002 210**
46481639	**0 281 002 214**
46481640	**0 281 002 213**
46512475	**0 204 127 122**
46512475	**0 281 002 203**
46519886	**0 265 007 039**
46519916	**0 265 007 036**
46519917	**0 265 007 037**
46520005	**0 265 007 038**
46522739	**0 232 101 037**
46522957	**0 204 127 379**
46522958	**0 204 127 353**
46525288	**0 261 231 144**
46530202	**0 265 007 043**
46530204	**0 265 007 045**
46531418	**0 265 007 072**
46531419	**0 265 007 070**
46532105	**0 204 127 412**
46533308	**0 280 218 004**
46533308	**0 986 280 235**
46533518	**0 261 230 030**
46539830	**0 265 007 034**
46539831	**0 265 007 035**
46539832	**0 265 007 032**
46539833	**0 265 007 033**
46540022	**0 265 007 050**
46540023	**0 265 007 049**
46540024	**0 265 007 055**
46540025	**0 265 007 054**
46541253	**0 280 218 019**
46541253	**0 986 280 236**
46542976	**0 281 002 260**
46542976	**0 281 002 405**
46544765	**0 265 007 075**
46544766	**0 265 007 076**
46545467	**0 265 007 051**
46545468	**0 265 007 053**
46545469	**0 265 007 052**
46546935	**0 265 007 044**
46547231	**0 265 007 024**
46547232	**0 265 007 025**
46547233	**0 265 007 026**
46547234	**0 265 007 027**
46550482	**0 204 127 413**
46550582	**0 204 127 413**
46553045	**0 261 230 030**
46559804	**0 281 002 309**
46559804	**0 986 284 113**
46736164	**0 281 002 380**
46736962	**0 204 127 463**
46737767	**0 265 007 063**
46737768	**0 265 007 064**
46737769	**0 265 007 065**
46737770	**0 265 007 066**
46750234	**0 204 127 480**
46752064	**0 265 007 072**
46761337	**0 265 007 098**
46761338	**0 265 007 099**
46770138	**0 265 007 093**
46770139	**0 265 007 091**
467831830	**0 265 007 102**
467831840	**0 265 007 103**
46806128	**0 280 002 474**
46808221	**0 281 002 533**
46808221	**0 986 284 114**
46823093	**0 265 007 486**
46823094	**0 265 007 487**
46823095	**0 265 007 488**
46838209	**0 265 007 126**
50011475	**0 265 006 164**
50011475	**0 265 006 537**
50011476	**0 265 006 163**
50011476	**0 265 006 538**
51493180	**0 265 006 325**
533 702	**0 332 014 151**
533 71 10 000 00/00	**0 335 530 012**
542 645	**0 335 530 029**
542 64 50 000 00/00	**0 335 530 012**
549 182	**0 280 202 206**
549 182	**0 986 280 065**
55187973	**0 232 103 052**
59469230	**0 280 230 006**
59680800	**0 280 202 059**
59680800	**0 986 280 044**
59680820	**0 280 202 060**
59680820	**0 986 280 046**
60500571	**0 280 202 211**
60500571	**0 986 280 091**
6050 05 710	**0 280 202 204**
6050 05 710	**0 986 280 055**
605082500	**0 265 001 074**
605082510	**0 265 001 073**
605117510	**0 265 001 156**
60512672	**0 280 120 300**
60512698	**0 261 231 006**
6051 320 060	**0 986 280 069**
6051 32 060	**0 280 202 201**
6051 32 080	**0 261 210 036**
6051 33 360	**0 280 202 202**
6051 33 370	**0 280 120 315**
6051 81 350	**0 280 101 001**
6051 86 940	**0 261 210 002**
6051 86 950	**0 261 230 001**
6052 28 730	**0 280 202 027**
6052 28 730	**0 986 280 078**
6052 28 750	**0 280 120 304**
6052 28 760	**0 280 230 001**
6052 33 830	**0 280 130 023**
6052 33 860	**0 280 202 010**
6052 33 900	**0 332 514 127**
60534263	**0 261 231 006**
60534264	**0 261 211 004**
6053 43 130	**0 280 202 058**
60534316	**0 280 230 009**
6053 47 060	**0 280 202 078**
6053 48 380	**0 280 202 105**
6053 49 590	**0 280 202 108**
6053 49 590	**0 986 280 067**
6053 78 350	**0 280 202 206**
6053 78 350	**0 986 280 065**
60545800	**0 265 001 251**

A

605458490	**0 265 001 250**
6054 71 130	**0 280 202 205**
6054 87 430	**0 261 231 007**
6055 00 420	**0 280 203 035**
60555613	**0 261 220 001**
60555613	**0 261 220 002**
605573630	**0 265 003 061**
605574090	**0 265 003 062**
605580150	**0 265 001 268**
605592690	**0 265 003 066**
605594060	**0 265 001 267**
605596600	**0 265 003 074**
605596600	**0 265 006 212**
60559661	**0 265 006 197**
6055 96 610	**0 265 003 063**
6056 07 150	**0 261 210 047**
60565464	**0 265 003 101**
60565479	**0 265 003 102**
60565479	**0 265 006 118**
6056 58 370	**0 280 203 034**
60569060	**0 261 210 096**
60569704	**0 280 202 213**
60569704	**0 986 280 024**
60573739	**0 261 210 090**
6057940	**0 280 202 212**
6057940	**0 986 280 081**
60579846	**0 280 203 034**
60589472	**0 280 217 503**
60591616	**0 281 002 085**
60591909	**0 280 130 073**
60592752	**0 261 231 095**
60595754	**0 261 210 113**
60601097	**0 265 006 118**
60601099	**0 265 006 120**
60603965	**0 205 001 016**
60615270	**0 265 006 162**
60615953	**0 265 006 260**
60615954	**0 265 006 261**
60622632	**0 265 006 325**
60622633	**0 265 006 326**
60628356	**0 281 002 202**
60630438	**0 204 127 273**
60630466	**0 204 127 127**
60652012	**0 265 007 016**
60652013	**0 265 007 017**
60652016	**0 265 007 018**
60652439	**0 280 750 012**
60652776	**0 265 007 021**
60652777	**0 265 007 022**
60652874	**0 265 007 020**
60654314	**0 280 750 012**
60654900	**0 204 127 376**
60656290	**0 265 007 040**
60656291	**0 265 007 041**
60656301	**0 265 007 042**
60659263	**0 265 007 046**
60659264	**0 265 007 047**
60659265	**0 265 007 018**
60659265	**0 265 007 048**
60659531	**0 204 127 456**
60660054	**0 280 750 053**
60662165	**0 204 127 377**
60663029	**0 280 218 036**
60663029	**0 986 280 237**
60806252	**0 265 006 212**
60806254	**0 265 006 197**
60807529	**0 265 005 031**
60808397	**0 265 003 075**
60808904	**0 261 210 096**
60808986	**0 261 210 090**
6080915	**0 280 202 212**
6080915	**0 986 280 081**
60809658	**0 280 202 211**
60809658	**0 986 280 091**
60810692	**0 261 210 113**
60810791	**0 261 231 095**
60810813	**0 280 217 111**
60811021	**0 281 002 085**
60811201	**0 232 101 026**
6081145	**0 280 217 514**
6081220	**0 280 130 055**
6081224	**0 280 130 055**
60812394	**0 265 006 212**
60812395	**0 265 006 162**
60813773	**0 265 006 238**
60814769	**0 281 002 214**
60814852	**0 280 218 019**
60814852	**0 986 280 236**
60815340	**0 205 003 052**
60815463	**0 204 127 122**
71713685	**F 00C 1G6 969**
71715149	**3 437 010 452**
71788020	**0 986 280 234**
7630317	**0 265 001 215**
7651951	**0 265 007 082**
7668164	**0 280 202 211**
7668164	**0 986 280 091**
7706580	**0 280 120 300**
77065804	**0 280 120 300**
7721274	**0 281 002 093**
7724097	**0 205 001 010**
7738223	**0 280 130 055**
7763719	**0 280 130 073**
7770239	**0 280 130 107**
77773440	**0 232 101 026**
77872560	**0 261 210 124**
824012520	**0 265 001 073**
824076790	**0 265 001 074**
82434700	**0 265 005 030**
824347000	**0 265 005 017**
824356600	**0 265 001 248**
824356610	**0 265 001 249**
824356620	**0 265 001 246**
824356630	**0 265 001 247**
824427230	**0 265 001 209**
824484640	**0 265 001 304**
82450141	**0 265 005 031**
824501410	**0 265 005 014**
824501410	**0 265 005 031**
82458587	**0 265 006 212**
824585870	**0 265 003 074**
824585870	**0 265 006 212**
82472243	**0 265 006 197**

ASTON MARTIN

0265001323	**0 265 001 323**
0265001324	**0 265 001 324**
0265006216	**0 265 006 216**

AUDI → VW

AVTOVAZ

21083-1130010-01	**0 280 218 004**
21083-1130010-01	**0 986 280 235**
21083-1130010-10	**0 280 218 037**
21083-1130010-20	**0 280 218 116**

BENTLEY

PB100609PC	**0 261 231 165**
PF100607PB	**0 261 210 253**
PF107942PA	**0 280 752 037**
UT 14052 PA	**0 265 006 349**
UT 14505 PB	**0 265 006 350**
3W0 955 559	**1 397 212 078**
3W5 955 559 B	**1 397 212 120**
3W5 955 559 C	**1 397 212 121**
3W5 955 559 D	**1 397 212 122**
3W5 955 559 E	**1 397 212 123**

BMW

XX XX 1 274 134	**0 438 120 155**
XX XX 1 287 768	**0 132 010 453**
XX XX 1 340 549	**0 280 130 087**
XX XX 1 401 318	**0 280 217 801**
XX XX 1 435 501	**0 261 231 129**
XX XX 1 435 502	**0 261 231 132**
XX XX 1 459 049	**0 232 101 003**
XX XX 1 713 906	**0 132 010 454**
XX XX 1 720 096	**0 261 230 092**
XX XX 1 720 096	**0 261 230 109**
XX XX 1 730 908	**0 132 010 453**
XX XX 1 731 966	**0 132 010 454**
XX XX 1 733 024	**0 132 010 454**
XX XX 1 734 314	**0 280 200 203**
XX XX 1 738 501	**0 132 010 453**
XX XX 3 618 311	**0 263 003 481**
XX XX 3 618 311	**0 263 003 497**
XX XX 3 618 550	**0 263 003 481**
XX XX 4 031 076	**0 265 007 623**
XX XX 4 263 502	**0 261 211 004**
XX XX 4 624 717	**0 265 007 421**
XX XX 4 624 945	**0 261 210 001**
XX XX 4 709 397	**0 281 002 621**
XX XX 6 767 578	**0 265 007 655**
XX XX 6 935 590	**0 263 003 295**
XX XX 6 935 599	**0 263 003 295**
XX XX 6 935 600	**0 263 003 291**
XX XX 6 940 623	**0 263 003 376**
XX XX 6 983 853	**0 263 003 481**
XX XX 6 983 853	**0 263 003 483**
XX XX 6 988 965	**0 263 003 497**
XX XX 7 509 326	**0 261 230 070**
XX XX 7 527 518	**0 280 213 011**
XX XX 7 527 525	**0 280 212 025**
XX XX 7 692 905	**0 265 007 858**
XX XX 7 778 743	**0 281 002 567**
XX XX 7 786 391	**0 261 231 018**
XX XX 8 031 309	**0 263 003 380**
XX XX 8 031 310	**0 263 003 381**
XX XX 8 031 311	**0 263 003 382**
XX XX 8 031 312	**0 263 003 383**
XX XX 8 031 998	**0 263 003 384**
XX XX 8 031 999	**0 263 003 385**
XX XX 8 046 454	**0 263 003 629**
XX XX 9 111 163	**0 263 003 498**
XX XX 9 111 164	**0 263 003 499**
XX XX 9 111 165	**0 263 003 500**
XX XX 9 111 166	**0 263 003 501**
XX XX 9 111 167	**0 263 003 502**
XX XX 9 114 342	**0 263 003 498**
XX XX 9 114 344	**0 263 003 499**
XX XX 9 124 584	**0 263 003 623**
XX XX 9 124 586	**0 263 003 625**
11 11 7 664 361	**0 261 231 172**
11 64 1 252 408	**0 333 400 007**
11 64 1 257 241	**0 335 530 005**
11 64 1 257 656	**0 335 530 006**
11 74 1 260 083	**0 335 530 008**

◀ BMW

12 11 1 274 666	**0 335 541 016**
12 11 1 276 100	**0 335 541 017**
12 11 1 276 212	**0 335 541 018**
12 11 1 277 125	**0 335 541 019**
12 11 1 279 527	**0 335 530 025**
12 11 1 285 090	**0 335 530 030**
12 11 1 341 030	**0 232 101 034**
12 11 1 341 030	**0 232 101 093**
12 11 1 361 879	**0 335 541 002**
12 11 1 364 299	**0 335 541 010**
12 11 1 364 301	**0 335 541 010**
12 11 1 459 028	**0 232 101 002**
12 11 1 459 033	**0 232 101 002**
12 11 1 465 063	**0 232 101 033**
12 11 1 465 077	**0 232 101 033**
12 11 7 673 277	**0 232 101 093**
12 12 1 274 644	**0 261 210 002**
12 12 1 286 148	**0 356 914 209**
12 12 1 286 149	**0 356 914 212**
12 12 1 747 630	**0 132 009 319**
12 12 1 748 081	**0 132 009 318**
12 14 1 247 993	**0 261 231 112**
12 14 1 269 286	**0 261 210 001**
12 14 1 274 644	**0 261 210 002**
12 14 1 279 734	**0 261 231 001**
12 14 1 401 187	**0 261 231 094**
12 14 1 401 237	**0 261 231 093**
12 14 1 401 238	**0 261 231 092**
12 14 1 435 502	**0 261 231 113**
12 14 1 702 163	**0 261 231 096**
12 14 1 709 316	**0 261 231 135**
12 14 1 709 317	**0 261 231 136**
12 14 1 709 317	**0 261 231 200**
12 14 1 710 519	**0 261 210 035**
12 14 1 710 699	**0 261 210 028**
12 14 1 713 007	**0 261 210 060**
12 14 1 713 583	**0 261 210 044**
12 14 1 713 584	**0 261 210 045**
12 14 1 714 763	**0 261 210 061**
12 14 1 715 028	**0 261 210 035**
12 14 1 715 030	**0 261 210 062**
12 14 1 715 711	**0 261 210 044**
12 14 1 720 096	**0 261 210 092**
12 14 1 720 105	**0 261 210 091**
12 14 1 720 517	**0 261 231 008**
12 14 1 721 504	**0 261 210 057**
12 14 1 721 705	**0 261 210 058**
12 14 1 721 861	**0 261 210 058**
12 14 1 721 968	**0 261 210 047**
12 14 1 721 968	**0 261 210 057**
12 14 1 726 063	**0 261 210 054**
12 14 1 726 519	**0 261 210 053**
12 14 1 726 590	**0 261 210 053**
12 14 1 727 511	**0 261 210 082**
12 14 1 729 599	**0 261 210 063**
12 14 1 734 580	**0 261 231 072**
12 14 1 734 581	**0 261 231 073**
12 14 1 734 817	**0 261 210 097**
12 14 1 736 303	**0 261 231 074**
12 14 1 738 667	**0 261 231 090**
12 14 1 738 667	**0 261 231 195**
12 14 1 739 368	**0 261 231 097**
12 14 1 740 959	**0 232 103 003**
12 14 1 741 131	**0 261 231 107**
12 14 1 741 648	**0 261 231 113**
12 14 1 748 082	**0 132 010 453**
12 14 1 748 400	**0 232 103 003**
12 14 2 241 236	**0 261 210 032**
12 14 7 519 647	**0 261 231 171**
12 14 7 519 648	**0 261 231 170**
12 52 1 279 695	**0 261 210 028**
12 62 1 288 158	**0 280 130 037**
12 62 1 288 158	**0 280 130 056**
12 62 1 288 158	**0 280 130 089**
12 63 1 267 456	**0 335 530 019**
12 63 1 269 668	**0 335 530 021**
12 63 1 270 914	**0 335 530 020**
12 63 1 285 090	**0 335 530 020**
12 72 1 705 724	**0 132 009 301**
12 72 1 712 009	**0 281 002 291**
12 72 1 720 418	**0 132 009 319**
12 72 1 722 013	**0 132 009 318**
12 72 1 722 520	**0 132 009 318**
12 72 1 730 478	**0 132 009 318**
12 72 1 730 907	**0 132 009 318**
12 72 1 731 965	**0 132 009 319**
12 72 1 733 022	**0 132 009 319**
12 72 1 747 630	**0 132 009 319**
12 72 1 748 081	**0 132 009 318**
13 26 1 273 239	**0 280 202 039**
13 26 1 273 239	**0 986 280 001**
13 51 1 265 317	**0 438 120 018**
13 51 1 266 341	**0 438 120 030**
13 51 1 266 342	**0 438 120 039**
13 51 1 268 548	**F 026 TX2 062**
13 51 1 268 548	**0 438 120 086**
13 51 1 270 647	**0 438 120 111**
13 51 1 271 776	**0 438 120 110**
13 51 1 274 134	**0 438 120 148**
13 51 1 274 943	**0 438 120 140**
13 51 1 278 735	**0 438 120 158**
13 51 1 460 447	**0 280 200 040**
13 51 1 460 447	**0 986 280 083**
13 53 2 247 581	**0 281 002 260**
13 53 7 500 221	**0 261 545 005**
13 53 7 781 486	**0 281 002 405**
13 53 7 781 486	**0 281 002 475**
13 53 7 787 167	**0 281 002 497**
13 53 7 788 164	**0 281 002 475**
13 53 7 794 758	**0 281 002 672**
13 53 7 798 079	**0 281 002 868**
13 53 7 800 602	**0 281 002 948**
13 53 7 801 987	**0 281 002 869**
13 53 7 94 758	**0 281 002 671**
13 54 1 710 560	**0 280 120 404**
13 54 1 717 603	**0 280 120 316**
13 54 1 725 815	**0 205 003 001**
13 54 1 733 023	**0 205 003 001**
13 54 1 736 856	**0 205 003 001**
13 61 7 788 788	**0 281 002 567**
13 62 1 268 105	**0 280 203 007**
13 62 1 268 105	**0 280 203 011**
13 62 1 268 105	**0 986 280 034**
13 62 1 269 264	**0 280 203 008**
13 62 1 269 304	**0 280 203 010**
13 62 1 271 704	**0 280 203 011**
13 62 1 271 704	**0 986 280 034**
13 62 1 272 101	**0 280 202 025**
13 62 1 272 101	**0 986 280 018**
13 62 1 273 117	**0 280 203 012**
13 62 1 273 238	**0 280 202 029**
13 62 1 273 238	**0 986 280 032**
13 62 1 273 277	**0 280 120 301**
13 62 1 274 673	**0 280 203 022**
13 62 1 274 673	**0 986 280 082**
13 62 1 274 697	**0 280 203 013**
13 62 1 276 113	**0 280 203 014**
13 62 1 276 202	**0 280 202 040**
13 62 1 277 564	**0 280 203 016**
13 62 1 277 564	**0 986 280 015**
13 62 1 279 519	**0 280 203 017**
13 62 1 279 664	**0 280 202 039**
13 62 1 279 664	**0 986 280 001**
13 62 1 279 704	**0 280 203 018**
13 62 1 279 704	**0 986 280 072**
13 62 1 284 397	**0 280 130 026**
13 62 1 284 407	**0 280 202 031**
13 62 1 284 407	**0 986 280 035**
13 62 1 285 052	**0 280 202 050**
13 62 1 285 052	**0 986 280 005**
13 62 1 286 064	**0 280 203 027**
13 62 1 286 064	**0 986 280 002**
13 62 1 286 615	**0 280 202 082**
13 62 1 286 615	**0 986 280 003**
13 62 1 286 679	**0 280 101 001**
13 62 1 287 731	**0 261 211 001**
13 62 1 307 019	**0 280 203 025**
13 62 1 307 019	**0 986 280 043**
13 62 1 307 486	**0 280 203 028**
13 62 1 307 486	**0 986 280 049**
13 62 1 311 950	**0 280 214 001**
13 62 1 311 950	**0 986 280 124**
13 62 1 315 541	**0 280 214 006**
13 62 1 316 166	**0 280 212 026**
13 62 1 316 167	**0 280 212 026**
13 62 1 341 500	**0 280 130 076**
13 62 1 341 550	**0 280 130 076**
13 62 1 353 329	**0 280 130 014**
13 62 1 353 331	**0 280 130 006**
13 62 1 357 414	**0 280 130 023**
13 62 1 358 915	**0 280 203 001**
13 62 1 359 641	**0 280 203 002**
13 62 1 359 641	**0 986 280 066**
13 62 1 362 296	**0 280 203 003**
13 62 1 362 648	**0 280 203 004**
13 62 1 362 648	**0 986 280 036**
13 62 1 403 123	**0 280 217 806**
13 62 1 407 446	**0 280 752 023**
13 62 1 432 244	**0 280 217 812**
13 62 1 433 565	**0 280 217 124**
13 62 1 433 566	**0 280 217 533**
13 62 1 433 567	**0 280 217 814**
13 62 1 438 687	**0 280 218 075**
13 62 1 465 108	**0 280 130 101**
13 62 1 702 078	**0 280 217 800**
13 62 1 705 721	**0 280 202 066**
13 62 1 705 721	**0 986 280 016**
13 62 1 707 366	**0 280 130 056**
13 62 1 709 937	**0 280 101 006**
13 62 1 709 966	**0 280 130 026**
13 62 1 710 539	**0 280 202 083**
13 62 1 710 539	**0 986 280 009**
13 62 1 710 543	**0 280 202 092**
13 62 1 710 544	**0 280 202 091**
13 62 1 710 544	**0 986 280 006**
13 62 1 710 545	**0 280 202 093**
13 62 1 710 546	**0 280 202 090**
13 62 1 710 546	**0 986 280 068**
13 62 1 711 338	**0 280 101 005**
13 62 1 711 371	**0 280 130 039**
13 62 1 714 502	**0 280 202 204**
13 62 1 714 502	**0 986 280 055**
13 62 1 714 503	**0 280 202 203**
13 62 1 714 503	**0 280 202 209**
13 62 1 715 888	**0 280 214 001**
13 62 1 715 888	**0 986 280 124**
13 62 1 716 013	**0 132 009 307**
13 62 1 718 521	**0 280 212 010**
13 62 1 718 521	**0 986 280 130**
13 62 1 718 736	**0 280 130 060**
13 62 1 718 749	**0 132 009 313**
13 62 1 722 489	**0 280 213 011**
13 62 1 722 489	**0 986 280 116**
13 62 1 730 074	**0 280 213 011**
13 62 1 730 074	**0 986 280 116**
13 62 1 733 258	**0 280 217 502**
13 62 1 733 262	**0 280 217 800**
13 62 1 733 678	**0 280 212 025**
13 62 1 733 678	**0 986 280 111**
13 62 1 734 314	**0 280 202 203**

B

13 62 1 734 316	**0 280 202 209**
13 62 1 734 651	**0 280 200 204**
13 62 1 734 651	**0 986 280 029**
13 62 1 734 653	**0 280 200 205**
13 62 1 734 653	**0 986 280 040**
13 62 1 734 655	**0 280 202 134**
13 62 1 734 655	**0 986 280 007**
13 62 1 734 655	**0 986 280 092**
13 62 1 734 657	**0 280 202 135**
13 62 1 734 657	**0 986 280 033**
13 62 1 736 224	**0 280 217 110**
13 62 1 738 908	**0 280 217 502**
13 62 1 747 155	**0 280 217 502**
13 62 1 747 156	**0 280 217 800**
13 62 2 228 011	**0 280 752 001**
13 62 2 240 756	**0 132 009 310**
13 62 2 241 599	**0 281 002 018**
13 62 2 242 184	**0 280 130 055**
13 62 2 242 250	**0 132 009 315**
13 62 2 242 290	**0 132 009 310**
13 62 2 242 330	**0 132 009 316**
13 62 2 243 864	**0 281 002 063**
13 62 2 244 132	**0 205 001 006**
13 62 2 245 690	**0 205 001 040**
13 62 2 247 074	**0 928 400 314**
13 62 2 247 074	**0 928 400 519**
13 62 2 247 074	**0 928 400 527**
13 62 2 306 215	**0 280 130 076**
13 62 7 501 554	**0 280 218 077**
13 62 7 502 055	**0 280 218 076**
13 62 7 524 136	**0 280 218 135**
13 62 7 527 518	**0 986 280 116**
13 62 7 527 525	**0 986 280 111**
13 62 7 531 702	**0 280 218 159**
13 62 7 533 853	**0 280 218 165**
13 62 7 535 069	**0 261 230 134**
13 62 7 537 488	**0 280 218 169**
13 62 7 539 811	**0 261 230 136**
13 62 7 540 508	**0 261 230 135**
13 62 7 542 418	**0 280 218 205**
13 62 7 542 418	**0 280 218 206**
13 62 7 547 975	**0 280 200 204**
13 62 7 547 975	**0 986 280 029**
13 62 7 547 976	**0 280 202 050**
13 62 7 547 976	**0 986 280 005**
13 62 7 547 977	**0 280 202 082**
13 62 7 547 977	**0 986 280 003**
13 62 7 547 978	**0 280 202 083**
13 62 7 547 978	**0 986 280 009**
13 62 7 547 979	**0 986 280 007**
13 62 7 547 979	**0 986 280 092**
13 62 7 547 980	**0 280 202 135**
13 62 7 547 980	**0 986 280 033**
13 62 7 547 981	**0 280 203 027**
13 62 7 547 981	**0 986 280 002**

13 62 7 547 982	**0 280 203 028**
13 62 7 547 982	**0 986 280 049**
13 62 7 548 103	**0 280 218 189**
13 62 7 548 103	**0 280 218 197**
13 62 7 552 114	**0 261 230 198**
13 62 7 552 114	**0 261 231 198**
13 62 7 558 785	**0 986 280 092**
13 62 7 566 052	**0 232 103 064**
13 62 7 566 986	**0 280 218 075**
13 62 7 566 987	**0 280 218 076**
13 62 7 566 988	**0 280 218 135**
13 62 7 566 989	**0 280 218 159**
13 62 7 566 990	**0 280 218 169**
13 62 7 568 421	**0 261 231 136**
13 62 7 568 421	**0 261 231 200**
13 62 7 570 191	**0 232 103 064**
13 62 7 787 076	**0 928 400 468**
13 62 7 787 076	**0 928 400 527**
13 62 7 788 743	**0 281 002 567**
13 62 7 788 744	**0 928 400 504**
13 62 7 788 744	**0 928 400 529**
13 62 7 790 657	**0 281 002 621**
13 62 7 791 347	**0 281 002 621**
13 62 7 793 633	**0 281 002 713**
13 62 7 801 951	**0 281 002 849**
13 62 7 805 415	**0 281 002 936**
13 62 7 830 359	**0 280 218 062**
13 62 7 833 561	**0 261 230 115**
13 62 7 839 014	**0 280 218 062**
13 63 1 272 131	**0 332 514 121**
13 63 1 273 139	**0 332 514 120**
13 63 1 273 265	**0 280 120 320**
13 63 1 273 277	**0 280 120 301**
13 63 1 274 662	**0 335 530 022**
13 63 1 276 264	**0 280 230 001**
13 63 1 352 716	**0 280 120 014**
13 63 1 358 436	**0 280 120 035**
13 63 1 358 473	**0 280 120 206**
13 63 1 360 678	**0 280 100 030**
13 63 1 460 455	**0 280 120 302**
13 63 1 461 852	**0 280 122 201**
13 63 1 707 320	**0 280 120 402**
13 63 1 708 605	**0 280 120 406**
13 63 1 710 559	**0 280 120 310**
13 63 1 714 196	**0 280 230 011**
13 63 1 720 503	**0 280 120 416**
13 63 1 720 505	**0 280 120 414**
13 71 2 247 002	**0 928 400 314**
13 71 2 247 002	**0 928 400 519**
13 71 2 247 002	**0 928 400 527**
13 71 2 247 592	**0 928 400 357**
13 71 2 247 592	**0 928 400 520**
1 705 724	**0 132 009 308**
1 734 314	**0 280 200 201**
2 241 235	**0 261 210 032**

32 43 6 762 235	**0 265 005 285**
32 43 6 774 040	**0 265 005 285**
34 17 6 990	**0 265 005 680**
34 50 3 417 699	**0 265 005 644**
34 51 1 156 396	**0 265 005 003**
34 51 1 164 213	**0 265 005 302**
34 51 1 164 245	**0 265 005 203**
34 51 1 165 467	**0 265 005 303**
34 52 1 154 043	**0 265 001 023**
34 52 1 154 044	**0 265 001 029**
34 52 1 154 045	**0 265 001 027**
34 52 1 154 046	**0 265 001 025**
34 52 1 154 064	**0 265 001 038**
34 52 1 155 037	**0 265 001 058**
34 52 1 155 037	**0 265 001 191**
34 52 1 155 038	**0 265 001 057**
34 52 1 155 041	**0 265 001 059**
34 52 1 155 505	**0 265 001 137**
34 52 1 155 506	**0 265 001 136**
34 52 1 155 645	**0 265 001 135**
34 52 1 155 645	**0 265 001 339**
34 52 1 155 709	**0 265 001 168**
34 52 1 155 710	**0 265 001 167**
34 52 1 164 018	**0 265 005 202**
34 52 1 165 292	**0 265 005 215**
34 52 1 165 292	**0 265 005 248**
34 52 1 178 788	**0 265 001 113**
34 52 1 178 981	**0 265 001 058**
34 52 1 178 982	**0 265 001 057**
34 52 1 179 762	**0 265 001 199**
34 52 1 179 830	**0 265 001 205**
34 52 1 179 981	**0 265 001 038**
34 52 1 180 228	**0 265 001 135**
34 52 1 180 228	**0 265 001 339**
34 52 1 180 649	**0 265 001 301**
34 52 1 180 651	**0 265 001 303**
34 52 1 180 652	**0 265 001 302**
34 52 1 181 490	**0 265 001 205**
34 52 1 181 491	**0 265 001 339**
34 52 1 181 808	**0 265 001 340**
34 52 1 181 839	**0 265 001 339**
34 52 1 182 333	**0 265 001 205**
34 52 1 182 335	**0 265 001 340**
34 52 2 294 362	**0 265 001 244**
34 52 2 345 844	**0 265 007 077**
34 52 2 345 845	**0 265 007 078**
34 52 3 405 906	**0 265 007 621**
34 52 3 405 907	**0 265 007 622**
34 52 3 420 330	**0 265 007 854**
34 52 3 420 331	**0 265 007 855**
34 52 6 753 694	**0 265 005 248**
34 52 6 757 406	**0 265 005 249**
34 52 6 757 406	**0 265 005 285**
34 52 6 758 289	**0 265 007 461**
34 52 6 758 290	**0 265 007 462**

34 52 6 758 290	**0 265 007 845**
34 52 6 758 750	**0 265 005 266**
34 52 6 759 886	**0 265 007 615**
34 52 6 759 887	**0 265 007 616**
34 52 6 760 045	**0 265 007 471**
34 52 6 760 046	**0 265 007 472**
34 52 6 760 047	**0 265 007 623**
34 52 6 760 533	**0 265 007 619**
34 52 6 760 534	**0 265 007 620**
34 52 6 760 534	**0 265 007 853**
34 52 6 761 650	**0 265 007 592**
34 52 6 761 651	**0 265 007 593**
34 52 6 761 651	**0 265 007 845**
34 52 6 761 800	**0 265 007 592**
34 52 6 761 801	**0 265 007 593**
34 52 6 761 801	**0 265 007 845**
34 52 6 762 733	**0 265 007 617**
34 52 6 764 858	**0 265 007 669**
34 52 6 764 859	**0 265 007 670**
34 52 6 767 578	**0 265 007 655**
34 52 6 767 578	**0 265 007 850**
34 52 6 768 578	**0 265 005 610**
34 52 6 768 680	**0 265 005 615**
34 52 6 769 535	**0 265 005 622**
34 52 6 770 137	**0 265 005 622**
34 52 6 770 137	**0 265 005 679**
34 52 6 771 700	**0 265 007 850**
34 52 6 771 701	**0 265 007 851**
34 52 6 771 702	**0 265 007 848**
34 52 6 771 703	**0 265 007 849**
34 52 6 771 704	**0 265 007 852**
34 52 6 771 705	**0 265 007 853**
34 52 6 771 708	**0 265 007 844**
34 52 6 771 709	**0 265 007 845**
34 52 6 771 710	**0 265 007 846**
34 52 6 771 711	**0 265 007 847**
34 52 6 771 712	**0 265 007 856**
34 52 6 771 713	**0 265 007 857**
34 52 6 773 019	**0 265 007 807**
34 52 6 773 020	**0 265 007 808**
34 52 6 774 039	**0 265 005 266**
34 52 6 774 435	**0 265 005 285**
34 52 6 774 602	**0 265 005 678**
34 52 6 774 602	**0 265 005 681**
34 52 677 509	**0 265 007 960**
34 52 677 510	**0 265 007 961**
34 52 6 777 435	**0 265 005 285**
34 52 6 779 913	**0 265 005 721**
34 52 6 779 913	**0 265 005 761**
34 52 7 651 951	**0 265 007 082**
34 52 7 651 951	**0 265 007 421**
34 52 7 657 454	**0 265 007 420**
34 52 7 657 454	**0 265 007 440**
34 52 7 657 455	**0 265 007 421**
34 52 7 665 742	**0 265 007 418**

◀ BMW

34 52 7 665 743	**0 265 007 419**
34 52 7 687 528	**0 265 007 684**
61 12 1 365 275	**0 265 001 005**
61 12 1 365 276	**0 265 002 003**
61 31 1 267 455	**0 335 530 018**
61 31 1 352 156	**0 332 003 014**
61 31 1 353 361	**0 332 003 021**
61 31 1 358 269	**0 332 514 103**
61 31 1 361 488	**0 335 530 013**
61 31 1 363 515	**0 335 530 015**
61 31 1 364 480	**0 332 514 105**
61 31 1 459 197	**0 280 130 032**
61 35 7 834 411	**0 261 230 127**
66 20 6 922 779	**0 263 003 244**
66 20 6 922 998	**0 263 003 244**
66 20 6 934 308	**0 263 003 244**

BUICK

2 534 4432	**0 261 231 163**
9 050 6101	**0 232 103 015**
9 209 9889	**0 261 230 087**
9 209 9890	**0 280 130 121**
9 209 9892	**0 261 231 163**
9 324 3251	**0 261 210 150**
9 339 0192	**0 261 230 116**

CHEVROLET

03 439 088	**0 280 130 107**
100 558 77	**0 280 213 009**
100 558 77	**0 986 280 105**
141 048 21 C	**0 265 001 228**
141 048 22 C	**0 265 001 227**
93 211 367	**9 280 082 000**
93 232 333	**9 280 082 001**
93 268 054	**F 000 DV0 100**
93 294 647	**0 265 006 488**
93 342 146	**0 281 002 214**
93 342 219	**0 281 002 209**
93 342 430	**0 281 002 514**
93 347 211	**0 281 002 667**
93 358 883	**0 280 130 107**
93 363 378	**F 000 DV0 103**
93 366 231	**F 000 DV0 104**
93 395 682	**F 000 DV1 057**

CHRYSLER

05033 109 AA	**0 281 002 503**
05033 109 AB	**0 281 002 503**
05033 109 AB	**0 281 002 571**
05033 109 AB	**0 281 002 572**
05149 001 AA	**0 281 002 847**
05149 001 AA	**0 281 002 848**
05293 155 AA	**0 281 002 367**
05293 155 AA	**0 281 002 368**
05293 155 AB	**0 281 002 451**
4 363 738	**0 265 001 159**
4 383 800	**0 265 001 161**
4 383 801	**0 265 001 162**
4 612 698	**0 281 002 132**
4 861 076	**0 281 002 132**
4 861 076	**0 281 002 189**
4 861 082	**0 281 002 189**
5 226 504	**0 280 130 046**
5 226 504	**0 280 130 057**
5 226 504	**0 280 130 058**
5 226 504	**0 280 130 063**
53 013 009	**0 281 002 279**
53 013 009 AA	**0 281 002 501**
53 013 109 AA	**0 281 002 433**
53 030 758	**0 281 002 156**
56 044 587 AA	**0 281 002 810**
56 044 587 AA	**0 281 002 811**

CITROEN

A 040 296	**0 261 211 003**
DX 144 119 A	**0 280 100 023**
DX 144 224 A	**0 280 120 011**
DX 144 228 A	**0 280 130 009**
DX 144 228 A	**0 280 130 014**
DX 144 263 A	**0 280 100 011**
DX 144 263 B	**0 280 100 023**
DX 524 101 A	**0 332 003 021**
V7 535 069	**0 261 230 134**
V7 540 508	**0 261 230 135**
V7 552 114	**0 261 231 197**
V7 552 114	**0 261 231 198**
0242 46	**0 280 130 026**
0242 62	**0 280 130 032**
1066 63	**0 280 755 046**
1192 W5	**0 281 002 184**
1430 80	**0 280 130 039**
1452 05	**0 280 230 006**
1452 10	**0 280 230 010**
14 808 450	**0 265 006 426**
14 808 460 80	**0 265 006 388**
14 888 410	**0 265 007 083**
14 916 610	**0 265 006 730**
14 916 620	**0 265 006 731**
14 938 820	**0 265 007 083**
1601 G4	**0 280 755 019**
1601 G5	**0 280 755 039**
1601 K7	**0 280 752 235**
1601 K7	**0 280 752 251**
1601 K8	**0 280 752 236**
1601 K9	**0 280 752 237**
1601 L1	**0 280 752 240**
1601 L4	**0 280 752 243**
1601 N4	**0 280 752 247**
1601 N5	**0 280 752 241**
1601 N6	**0 280 752 242**
1601 N7	**0 280 752 260**
1601 N7	**0 280 755 029**
1601 N8	**0 280 755 030**
1601 N9	**0 280 752 258**
1601 P3	**0 280 755 000**
1601 P3	**0 280 755 001**
1601 P4	**0 280 752 279**
1601 P5	**0 280 755 015**
1601 P6	**0 280 752 283**
1601 P7	**0 280 755 016**
1601 P8	**0 280 755 007**
1601 Q0	**0 280 755 005**
1601 Q1	**0 280 755 010**
1601 Q1	**0 280 755 011**
1601 Q2	**0 280 755 026**
1601 Q3	**0 280 755 027**
1601 Q3	**0 280 755 044**
1601 Q4	**0 280 755 012**
1601 Q5	**0 280 755 013**
1601 Q6	**0 280 755 018**
1601 Q8	**0 280 755 040**
1601 R2	**0 280 755 046**
1601 S0	**0 280 755 031**
1601 S1	**0 280 755 032**
1601 S2	**0 280 755 033**
1601 S3	**0 280 755 044**
1601 S4	**0 280 755 045**
1601 T1	**0 280 755 074**
1601 T2	**0 280 755 075**
1601 T3	**0 280 755 076**
1601 T4	**0 280 755 077**
1601 T6	**0 280 755 041**
1601 T7	**0 280 755 081**
1601 T8	**0 280 755 035**
1601 T9	**0 280 755 037**
1601 V0	**0 280 755 036**
1601 V1	**0 280 755 038**
1601 X6	**0 280 755 078**
1601 X7	**0 280 755 079**
1601 X7	**0 280 755 080**
1601 X8	**0 280 755 095**
1601 X9	**0 280 755 097**
1621 28	**0 261 211 003**
1622 C9	**0 205 001 015**
1625 90	**0 280 230 101**
1628 A3	**0 280 120 310**
1628 C5	**0 281 002 029**
1628 C6	**0 281 002 018**
1628 G4	**0 280 120 327**
1628 K9	**0 280 120 323**
1628 L1	**0 280 122 001**
1628 1E	**0 280 122 003**
1628 1F	**0 280 122 005**
1628 27	**0 280 120 305**
1628 50	**0 280 120 301**
1628 54	**0 281 002 008**
1628 8V	**0 280 122 009**
1635 P3	**0 280 750 041**
1635 Q9	**0 280 750 085**
1635 Z8	**0 280 750 164**
1636 37	**0 280 750 164**
18 593 070	**0 263 003 246**
1920 AC	**0 261 230 041**
1920 AC	**0 261 230 058**
1920 AJ	**0 261 230 043**
1920 AN	**0 261 230 057**
1920 C5	**0 280 130 039**
1920 C6	**0 280 202 118**
1920 C6	**0 986 280 057**
1920 FK	**0 281 002 492**
1920 FR	**0 261 231 168**
1920 FR	**0 261 231 169**
1920 H9	**9 465 160 006**
1920 KZ	**0 261 230 135**
1920 K8	**0 261 230 004**
1920 K8	**0 261 230 037**
1920 LA	**0 261 230 131**
1920 LA	**0 261 230 132**
1920 LS	**0 232 103 064**
1920 LT	**0 261 231 197**
1920 LT	**0 261 231 198**
1920 LW	**0 261 230 136**
1920 PY	**0 261 230 156**
1920 T7	**0 281 002 063**
1920 T7	**0 281 002 063**
1920 Z1	**0 281 002 128**
1920 0E	**0 261 230 012**
1920 0G	**0 280 122 011**
1920 1K	**0 261 230 034**
1920 1K	**0 261 230 057**
1920 27	**0 438 120 065**
1920 29	**0 280 202 044**
1920 3L	**0 281 002 122**
1920 34	**0 280 202 051**
1920 34	**0 986 280 051**
1920 46	**0 280 202 056**
1920 46	**0 986 280 028**
1920 49	**0 280 202 057**
1920 50	**0 280 101 001**
1920 55	**0 438 120 200**
1920 66	**0 280 202 070**
1920 68	**0 280 202 098**

1920 7R	**0 281 002 283**
1920 7R	**0 281 002 592**
1920 70	**0 280 202 097**
1920 70	**0 986 280 070**
1920 76	**0 280 213 006**
1920 76	**0 986 280 115**
1920 80	**0 280 202 109**
1920 80	**0 986 280 013**
1920 9H	**0 261 230 012**
1920 91	**0 280 202 602**
1920 91	**0 986 280 019**
1920 93	**0 280 202 202**
1920 93	**0 280 202 210**
1920 93	**0 986 280 063**
1921 01	**0 438 120 120**
1921 10	**0 438 120 099**
1921 24	**0 438 120 119**
1921 33	**0 438 120 153**
1921 42	**0 438 120 161**
1921 96	**0 438 120 068**
1922 R6	**0 261 230 134**
1929 03	**0 132 009 305**
1929 03	**0 281 002 031**
20 100 255	**0 263 003 267**
20 100 257	**0 263 003 266**
20 100 258	**0 263 003 268**
20 100 259	**0 263 003 274**
20 100 260	**0 263 003 271**
20 100 261	**0 263 003 272**
20 100 263	**0 263 003 273**
20 100 264	**0 263 003 263**
20 100 265	**0 263 003 264**
20 100 266	**0 263 003 265**
20 100 267	**0 263 003 269**
20 100 758	**0 263 003 246**
35 429 03	**0 263 003 246**
4472 80	**0 280 750 085**
4545 A4	**0 265 006 732**
4545 A8	**0 265 006 793**
4545 C2	**0 265 007 664**
4545 C3	**0 265 007 663**
4545 C3	**0 265 007 780**
4545 C4	**0 265 007 645**
4545 C4	**0 265 007 779**
4545 C7	**0 265 007 665**
4545 C8	**0 265 007 666**
4545 C9	**0 265 007 668**
4545 E0	**0 265 007 667**
4545 E1	**0 265 007 687**
4545 E2	**0 265 007 688**
4545 E3	**0 265 005 486**
4545 E5	**0 265 007 707**
4545 E6	**0 265 007 883**
4545 E7	**0 265 007 788**
4545 E8	**0 265 007 789**

4545 E9	**0 265 007 790**
4545 F0	**0 265 007 791**
4545 F6	**0 265 008 017**
4545 F7	**0 265 008 018**
4545 F8	**0 265 008 018**
4545 F9	**0 265 005 486**
4545 G9	**0 265 007 130**
4545 H0	**0 265 007 131**
4545 H7	**0 265 008 018**
4545 H8	**0 265 005 517**
4545 04	**0 204 154 008**
4545 04	**0 204 154 008**
4545 05	**0 204 154 003**
4545 05	**0 204 154 003**
4545 06	**0 204 154 002**
4545 06	**0 204 154 002**
4545 09	**0 204 154 028**
4545 09	**0 204 154 028**
4545 10	**0 204 154 011**
4545 10	**0 204 154 011**
4545 11	**0 265 003 064**
4545 12	**0 265 003 065**
4545 13	**0 204 154 018**
4545 13	**0 204 154 018**
4545 14	**0 204 154 014**
4545 14	**0 204 154 014**
4545 15	**0 204 154 007**
4545 15	**0 204 154 007**
4545 16	**0 204 154 009**
4545 16	**0 204 154 009**
4545 17	**0 204 154 015**
4545 17	**0 204 154 015**
4545 19	**0 204 154 013**
4545 19	**0 204 154 013**
4545 21	**0 265 003 072**
4545 21	**0 265 003 126**
4545 21	**0 265 003 126**
4545 21	**0 265 006 207**
4545 22	**0 265 003 073**
4545 22	**0 265 003 127**
4545 22	**0 265 006 208**
4545 23	**0 265 003 080**
4545 23	**0 265 003 123**
4545 23	**0 265 006 314**
4545 24	**0 265 003 081**
4545 24	**0 265 003 125**
4545 25	**0 265 005 105**
4545 25	**0 265 005 111**
4545 26	**0 204 154 016**
4545 26	**0 204 154 016**
4545 27	**0 204 150 083**
4545 27	**0 204 150 083**
4545 27	**0 204 154 040**
4545 27	**0 204 154 040**
4545 28	**0 265 003 100**

4545 28	**0 265 003 124**
4545 28	**0 265 003 124**
4545 28	**0 265 006 315**
4545 29	**0 204 154 017**
4545 29	**0 204 154 017**
4545 30	**0 204 154 029**
4545 30	**0 204 154 029**
4545 31	**0 265 003 099**
4545 31	**0 265 003 131**
4545 31	**0 265 006 201**
4545 32	**0 265 003 130**
4545 32	**0 265 006 200**
4545 33	**0 265 003 079**
4545 33	**0 265 003 129**
4545 33	**0 265 006 202**
4545 34	**0 265 003 106**
4545 34	**0 265 003 106**
4545 34	**0 265 006 204**
4545 35	**0 265 003 128**
4545 35	**0 265 006 199**
4545 36	**0 265 003 129**
4545 36	**0 265 006 202**
4545 37	**0 265 003 123**
4545 37	**0 265 006 314**
4545 38	**0 204 154 024**
4545 38	**0 204 154 024**
4545 39	**0 204 154 025**
4545 39	**0 204 154 025**
4545 40	**0 204 154 020**
4545 41	**0 204 154 027**
4545 41	**0 204 154 027**
4545 42	**0 204 154 026**
4545 44	**0 265 006 201**
4545 44	**0 265 006 201**
4545 45	**0 265 006 200**
4545 46	**0 265 006 202**
4545 47	**0 265 006 199**
4545 48	**0 265 006 205**
4545 49	**0 265 006 206**
4545 50	**0 265 006 203**
4545 51	**0 265 006 204**
4545 55	**0 265 006 207**
4545 56	**0 265 006 202**
4545 56	**0 265 006 208**
4545 60	**0 265 006 314**
4545 60	**0 265 006 314**
4545 61	**0 265 006 315**
4545 61	**0 265 006 315**
4545 62	**0 265 006 209**
4545 63	**0 204 154 038**
4545 63	**0 204 154 038**
4545 66	**0 265 006 389**
4545 67	**0 265 006 388**
4545 67	**0 265 006 388**
4545 68	**0 265 006 426**

4545 68	**0 265 006 426**
4545 69	**0 265 006 441**
4545 69	**0 265 006 441**
4545 70	**0 265 006 427**
4545 70	**0 265 006 427**
4545 71	**0 265 006 405**
4545 72	**0 265 006 406**
4545 75	**0 265 006 504**
4545 78	**0 265 006 389**
4545 82	**0 265 006 544**
4545 83	**0 265 006 545**
4545 84	**0 265 005 404**
4545 85	**0 265 006 659**
4545 88	**0 265 007 423**
4545 89	**0 265 007 424**
4545 92	**0 265 006 730**
4545 93	**0 265 006 731**
4545 94	**0 265 007 083**
4545 95	**0 265 007 084**
4549 05	**0 265 005 211**
4549 05	**0 265 005 290**
4549 07	**0 265 005 253**
4549 07	**0 265 005 290**
4549 16	**0 265 005 290**
4549 17	**0 265 005 606**
4549 21	**0 265 005 715**
4549 26	**0 265 005 291**
4549 26	**0 265 005 714**
4549 27	**0 265 005 292**
4549 28	**0 265 005 629**
4549 33	**0 265 005 629**
4549 39	**0 265 005 714**
4549 41	**0 265 005 703**
4549 43	**0 265 005 724**
4574 03	**0 261 230 058**
4649 28	**0 265 005 629**
4676 80	**0 261 230 043**
4679 80	**0 261 231 169**
5007 99	**0 280 122 003**
5 412 358	**0 280 130 014**
5 412 360	**0 280 130 006**
5 412 361	**0 280 120 011**
5 412 361	**0 280 120 018**
5 413 479	**0 280 100 036**
5 422 133	**0 332 003 021**
5 429 448	**0 280 100 048**
5 472 928	**0 332 514 103**
5 489 066	**0 280 202 005**
5 500 350	**0 280 120 200**
5 502 644	**0 280 130 023**
5918 73	**0 281 002 030**
5918 79	**0 261 210 029**
5918 80	**0 261 210 043**
5918 84	**0 261 210 029**
5946 03	**0 261 231 006**

◀ CITROEN

5946 05	**0 261 231 007**	91 514 547 80	**0 280 202 044**	95 638 095	**0 265 001 158**	96 161 385	**0 204 154 010**
5946 15	**0 261 231 071**	91 514 878 80	**0 261 231 001**	95 640 366	**0 281 002 037**	96 165 516	**0 265 003 105**
5946 17	**0 261 231 071**	91 514 880	**0 261 231 006**	96 000 118	**0 204 154 010**	96 165 516	**0 265 003 130**
5946 18	**0 261 231 070**	91 516 985	**0 280 202 056**	96 013 294	**0 280 230 014**	96 165 516	**0 265 003 130**
5946 21	**0 261 231 045**	91 516 985	**0 986 280 028**	96 015 940	**0 280 120 327**	96 165 516	**0 265 006 200**
5946 22	**0 261 231 109**	91 517 923 80	**0 280 230 010**	96 035 417	**0 280 202 118**	96 168 084	**0 261 231 045**
5946 25	**0 261 231 125**	91 517 932	**0 280 230 010**	96 035 417	**0 986 280 057**	96 180 488	**0 265 003 128**
5946 28	**0 261 231 128**	91 517 932 80	**0 280 230 010**	96 037 065	**0 261 231 034**	96 180 488	**0 265 006 199**
5946 30	**0 261 231 130**	91 518 192	**0 280 101 001**	96 037 068	**0 261 231 033**	96 181 977	**0 265 003 130**
6401 L3	**1 397 212 039**	91 518 192 80	**0 280 101 001**	96 038 938	**0 280 122 001**	96 181 977	**0 265 003 131**
6405 C0	**1 397 212 000**	91 518 194 80	**0 280 202 057**	96 039 179	**0 280 202 118**	96 181 977	**0 265 006 200**
6405 E8	**1 397 212 002**	91 519 925	**0 280 120 310**	96 039 179	**0 986 280 057**	96 181 977	**0 265 006 201**
6405 G0	**1 397 212 001**	91 519 925 80	**0 280 120 310**	96 046 811	**0 204 154 012**	96 181 978	**0 265 003 130**
6405 G5	**1 397 212 006**	91 520 606 80	**0 280 202 075**	96 056 021	**0 280 120 323**	96 181 978	**0 265 006 200**
6405 HK	**1 397 212 132**	91 527 047	**0 281 002 018**	96 067 683	**0 204 154 010**	96 181 979	**0 265 003 130**
6405 L3	**1 397 212 039**	91 536 076	**0 280 202 602**	96 067 694	**0 204 154 012**	96 181 979	**0 265 003 131**
6405 Q2	**1 397 212 064**	91 536 076	**0 986 280 019**	96 071 329	**0 265 003 065**	96 181 979	**0 265 006 200**
6405 Q3	**1 397 212 060**	91 537 218 80	**0 280 202 070**	96 075 741	**0 204 154 010**	96 181 979	**0 265 006 201**
6405 Q7	**1 397 212 074**	91 537 485	**0 132 009 305**	96 081 740	**0 280 120 327**	96 182 000	**0 265 003 125**
6405 R9	**1 397 212 083**	91 537 485 80	**0 132 009 305**	96 086 319	**0 265 005 111**	96 182 615	**0 261 230 012**
6405 W9	**1 397 212 109**	91 537 516	**0 281 002 029**	9608 631 980	**0 265 005 105**	96 183 217	**0 265 006 205**
6405 Y4	**1 397 212 112**	9153 751 680	**0 281 002 029**	96 087 509	**0 265 003 078**	96 183 261	**0 265 006 206**
6405 Y5	**1 397 212 086**	91 538 877	**0 280 202 097**	96 087 509	**0 265 003 128**	96 191 116	**0 281 002 063**
6505 Q5	**1 397 212 076**	91 538 877	**0 986 280 070**	96 087 509	**0 265 006 199**	96 195 593	**0 281 002 119**
6505 Q6	**1 397 212 076**	91 539 005 80	**0 280 202 098**	96 089 629	**0 265 003 079**	96 195 593	**0 281 002 122**
6555 20	**0 280 230 112**	91 540 545 80	**0 280 202 109**	96 089 629	**0 265 003 129**	96 210 452	**0 265 005 111**
6555 22	**0 280 230 009**	91 540 545 80	**0 986 280 013**	96 089 629	**0 265 006 202**	96 210 838	**1 397 212 000**
6555 47	**0 280 230 014**	91 541 027	**0 261 210 043**	96 099 080	**0 204 154 016**	96 211 621	**0 281 002 128**
6590 A5	**0 263 003 246**	91 541 738	**0 280 202 202**	96 105 849	**0 265 003 072**	96 213 344	**0 261 231 109**
72 408 124	**0 280 122 001**	91 548 738	**0 261 210 043**	96 105 849	**0 265 003 126**	96 217 750	**0 265 006 201**
72 408 254	**0 280 120 400**	92 526 538	**0 332 014 151**	96 105 849	**0 265 006 207**	96 217 752	**0 265 006 200**
72 408 654	**0 280 122 011**	92 526 538 80	**0 332 014 151**	96 105 850	**0 265 003 073**	96 217 753	**0 265 006 202**
72 408 744	**0 280 122 009**	93 011 154	**0 281 002 008**	96 105 850	**0 265 006 208**	96 217 755	**0 265 006 204**
72 408 754	**0 280 122 010**	93 327 326	**0 265 006 389**	96 105 926	**9 456 160 006**	96 217 756	**0 265 006 203**
74 013 460 30	**0 280 130 032**	95 496 103	**0 280 202 047**	96 105 926	**9 465 160 006**	96 217 759	**0 265 006 199**
74 013 676 43	**0 261 231 007**	95 496 375	**0 280 202 021**	96 106 029	**0 265 003 081**	96 217 763	**0 265 006 207**
74 013 676 45	**0 261 210 029**	95 496 621	**0 280 230 009**	96 106 029	**0 265 003 125**	96 217 765	**0 265 006 208**
7700 267 269	**0 280 230 112**	95 567 200	**0 280 120 301**	96 106 095	**0 265 003 080**	96 218 046	**0 265 006 209**
8334 57	**0 281 002 804**	95 567 200 80	**0 280 120 310**	96 106 095	**0 265 003 123**	96 227 489	**0 265 006 203**
8334 57A	**0 281 002 919**	95 572 330	**0 332 514 130**	96 106 095	**0 265 006 314**	96 231 343	**0 261 231 109**
91 000 407 80	**0 280 202 051**	95 572 333	**0 332 514 130**	96 107 893	**0 261 230 004**	96 252 846	**0 265 006 205**
91 000 407 80	**0 986 280 051**	95 598 944	**0 280 202 073**	96 109 509	**0 281 002 063**	96 255 387	**0 265 006 315**
91 000 409	**0 280 230 006**	95 605 079	**0 280 202 061**	96 127 657	**0 261 231 071**	96 255 404	**0 265 006 314**
91 000 409 80	**0 280 230 006**	95 605 079	**0 280 202 064**	96 127 657	**0 261 231 106**	96 272 628	**0 265 006 205**
91 040 296 80	**0 261 211 003**	95 605 079	**0 986 280 041**	96 127 658	**0 261 231 070**	96 275 932	**0 261 231 128**
91 040 370	**0 280 130 026**	95 605 084	**0 280 120 313**	96 127 658	**0 261 231 105**	96 280 713	**0 265 006 389**
91 040 398	**0 281 002 030**	95 610 350	**0 265 001 098**	96 128 155	**0 265 003 064**	96 286 482	**0 261 231 130**
91 166 609	**1 397 212 039**	95 635 036	**0 280 202 099**	96 128 156	**0 265 003 080**	96 286 483	**0 261 231 127**
91 207 837	**0 281 002 018**	95 635 037	**0 280 120 312**	96 128 156	**0 265 003 123**	96 286 484	**0 261 231 125**
91 414 549	**0 280 130 026**	95 635 037	**0 280 120 317**	96 128 156	**0 265 006 314**	96 286 689	**1 397 212 001**
91 508 771 80	**0 280 230 101**	95 635 040	**0 280 202 100**	96 131 470	**0 280 130 084**	96 295 910	**0 280 750 041**
91 508 772 80	**0 280 230 100**	95 635 043	**0 280 202 101**	96 140 648	**0 265 003 099**	96 297 255	**0 265 006 441**
91 512 716	**0 280 230 101**	95 635 045	**0 280 120 318**	96 140 648	**0 265 003 131**	96 300 147	**0 265 005 404**
91 512 716 80	**0 280 230 101**	95 637 307	**0 265 001 157**	96 140 648	**0 265 006 201**	96 303 414	**0 265 005 211**
91 513 886 80	**0 280 230 104**	95 637 307	**0 265 001 245**	96 149 640	**0 205 001 015**	96 303 414	**0 265 005 290**

96 305 913	**1 397 212 002**
96 317 068	**0 265 006 544**
96 317 069	**0 265 006 545**
96 318 136	**0 261 230 057**
96 337 132	**1 397 212 004**
96 343 935	**1 397 212 002**
96 343 935	**1 397 212 006**
96 353 847	**0 265 007 423**
96 353 848	**0 265 007 424**
96 354 934	**0 261 230 058**
96 358 840	**0 280 750 085**
96 365 830	**0 261 230 043**
96 382 908	**0 265 006 659**
96 384 235	**0 261 231 128**
96 386 487	**0 265 007 423**
96 393 814	**0 261 230 043**
96 394 188	**0 261 230 057**
96 394 189	**0 261 230 058**
96 394 190	**0 261 230 057**
96 394 191	**0 261 230 058**
96 411 890	**1 397 212 004**
96 411 890	**1 397 212 039**
96 411 890	**1 397 212 060**
96 415 250	**0 265 005 253**
96 415 250	**0 265 005 290**
96 430 590	**0 280 752 235**
96 430 591	**0 280 752 247**
96 430 592	**0 280 752 236**
96 430 732	**0 280 752 238**
96 430 847	**0 280 752 237**
96 430 848	**0 280 752 248**
96 430 934	**0 280 752 240**
96 431 704	**0 265 006 732**
96 434 731	**0 280 752 243**
96 436 596	**0 265 007 423**
96 436 605	**0 265 007 424**
96 436 880	**0 265 007 424**
96 436 977	**0 265 007 423**
96 440 934	**0 280 752 240**
96 442 063	**0 261 230 085**
96 442 066	**0 261 230 085**
96 449 305	**0 280 752 242**
96 449 396	**0 280 752 241**
96 449 667	**0 265 007 423**
96 449 668	**0 265 007 424**
96 453 114	**0 261 231 169**
96 454 477	**0 265 005 253**
96 454 477	**0 265 005 290**
96 458 515	**0 280 752 235**
96 458 522	**0 280 752 237**
96 461 258	**0 265 007 645**
96 461 258	**0 265 007 779**
96 464 045	**0 280 755 016**
96 466 196	**1 397 212 050**
96 467 021	**0 280 752 251**
96 467 555	**1 397 212 039**
96 468 373	**1 397 212 050**
96 469 709	**0 265 007 668**
96 469 711	**0 265 007 667**
96 469 712	**0 265 007 665**
96 469 725	**0 265 007 666**
96 471 352	**0 280 752 279**
96 475 755	**0 280 752 258**
96 476 944	**1 397 212 060**
96 477 813	**0 280 752 259**
96 477 813	**0 280 752 260**
96 477 813	**0 280 755 029**
96 477 814	**0 280 752 262**
96 477 967	**0 280 752 264**
96 477 967	**0 280 755 028**
96 480 873	**0 265 006 793**
96 488 392	**0 280 755 029**
96 489 571	**0 280 755 006**
96 489 571	**0 280 755 007**
96 494 001	**0 265 005 291**
96 494 001	**0 265 005 714**
96 495 100	**0 280 750 164**
96 49 614 177	**0 263 003 476**
96 497 761	**0 265 005 606**
96 498 334	**1 397 212 064**
96 499 043	**0 265 005 292**
96 502 357	**0 265 005 290**
96 502 361	**0 265 005 486**
96 503 417	**0 280 755 012**
96 503 418	**0 280 755 013**
96 504 521	**0 265 005 290**
96 508 818	**0 280 755 000**
96 508 818	**0 280 755 001**
96 508 891	**0 280 755 001**
96 508 892	**0 280 755 018**
96 509 352	**0 263 003 263**
96 511 983	**0 280 755 019**
96 511 984	**0 280 755 039**
96 512 701	**0 280 755 041**
96 515 042	**0 280 755 010**
96 515 107	**0 280 755 004**
96 515 107	**0 280 755 005**
96 515 372	**0 280 755 017**
96 517 022	**1 397 212 073**
96 517 023	**1 397 212 074**
96 518 352	**1 397 212 083**
96 519 693	**0 265 007 707**
96 524 902	**1 397 212 050**
96 524 903	**1 397 212 076**
96 526 967	**0 265 007 664**
96 526 969	**0 265 007 663**
96 526 969	**0 265 007 780**
96 527 700	**0 280 755 015**
96 528 436	**0 280 752 282**
96 528 436	**0 280 752 283**
96 529 212	**0 280 755 030**
96 531 052	**0 280 755 036**
96 531 058	**0 280 755 038**
96 531 059	**0 280 755 032**
96 535 678	**0 280 755 083**
96 536 631	**0 265 007 789**
96 544 055	**0 280 755 040**
96 544 061	**0 280 755 042**
96 544 063	**0 280 755 082**
96 546 648	**1 397 212 050**
96 547 253	**0 280 755 044**
96 547 453	**0 280 755 045**
96 547 545 80	**0 280 755 039**
96 548 774	**0 280 755 026**
96 548 775	**0 280 755 027**
96 552 700	**0 265 007 788**
96 554 671	**0 280 755 035**
96 554 673	**0 280 755 037**
96 555 024	**0 280 755 031**
96 555 025	**0 280 755 033**
96 570 548	**1 397 212 083**
96 571 232	**0 265 005 629**
96 573 958	**0 280 755 046**
96 573 958 VV	**0 280 755 046**
96 573 958 77	**0 280 755 046**
96 575 584	**1 397 212 109**
96 578 716	**1 397 212 108**
96 578 717	**1 397 212 106**
96 578 723	**1 397 212 107**
96 583 737	**1 397 212 105**
96 583 825	**1 397 212 113**
96 584 207	**0 265 007 645**
96 584 207	**0 265 007 779**
96 585 998	**0 265 007 883**
96 586 439	**0 280 755 075**
96 586 529	**0 280 755 079**
96 588 691	**1 397 212 112**
96 588 692	**1 397 212 086**
96 594 498	**0 280 755 074**
96 594 499	**0 280 755 078**
96 594 854	**1 397 212 116**
96 594 857	**1 397 212 117**
96 600 591	**1 397 212 118**
96 600 591	**1 397 212 124**
96 600 592	**1 397 212 119**
96 600 652	**1 397 212 118**
96 605 913	**1 397 212 002**
96 803 275	**1 397 212 124**
96 803 276	**1 397 212 125**
96 807 568	**0 280 755 084**
9999 163 554	**0 280 230 006**

DACIA

60 00 581 611	**0 280 130 107**
60 00 581 616	**0 261 210 152**
60 01 538 842	**0 280 130 107**
82 00 195 825	**0 265 007 596**
82 00 254 687	**0 265 007 583**
82 00 254 688	**0 265 007 582**

DAEWOO

949530 /065559	**0 261 210 153**
96205922	**0 265 006 414**
96205924	**0 265 006 415**
96253827	**0 265 006 404**
96283017	**0 265 006 593**
96283018	**0 265 006 594**
96283019	**0 265 006 595**
96283020	**0 265 006 596**
96549712	**0 265 006 752**
96549713	**0 265 006 751**

DAF

1261071	**0 281 002 256**
1292636	**0 280 122 001**
1315657	**0 281 002 258**
1315659	**0 280 130 039**
1326649	**0 281 002 257**
1339008	**0 281 002 301**
1339009	**0 281 002 302**
1365737	**0 281 002 409**
1365738	**0 281 002 408**
1398467	**0 281 002 511**
1398468	**0 281 002 316**
1408346	**0 281 002 472**
1426321	**0 281 002 412**
1607435	**0 281 002 675**
1607436	**0 281 002 676**
1697325	**0 281 002 655**
1698686	**0 281 002 316**
233066	**0 331 101 001**
269783	**0 335 530 011**
291696	**0 335 530 017**
292959	**0 335 530 016**
532114	**0 331 101 002**
693056	**0 331 100 023**

DAIHATSU

89420 97209 000	**0 261 230 044**
89420 97209 000	**0 261 230 088**
89420 97209 000	**0 261 230 089**

FERRARI

000237886	**0 280 218 224**
110355	**0 332 204 101**
114291	**0 335 322 003**
118789	**0 280 230 007**
121517	**0 280 120 310**
121720	**0 280 130 032**
121738	**0 280 101 001**
124717	**0 280 230 006**
125769	**0 280 130 026**
126058	**0 265 001 092**
126059	**0 265 001 093**
126112	**0 265 001 090**
126113	**0 265 001 091**
128019	**0 280 120 314**
130395	**0 280 120 302**
130974	**0 280 120 311**
130975	**0 261 210 029**
131403	**0 280 120 312**
134808	**0 280 101 003**
136374	**0 280 212 018**
137266	**0 232 101 006**
137823	**0 280 120 315**
138403	**0 280 213 023**
142434	**0 280 122 001**
146 233	**0 232 101 016**
146312	**0 232 101 006**
150866	**0 232 103 006**
152262	**0 261 210 106**
154916	**0 280 213 012**
154916	**0 986 280 110**
158170	**0 280 122 004**
159266	**0 265 006 116**
159267	**0 265 006 117**
162397	**0 280 217 800**
162419	**0 280 130 039**
162530	**0 280 217 521**
162916	**0 261 210 126**
163145	**0 265 006 252**
163146	**0 265 006 253**
164082	**0 261 210 152**
164 937	**0 261 210 182**
170038	**0 280 752 028**
170592	**0 265 006 429**
170593	**0 265 006 430**
171707	**0 280 218 012**
171716	**0 280 750 038**
172750	**0 280 122 005**
172750	**0 280 130 026**
172771	**0 261 231 145**
177672	**0 261 231 145**
177673	**0 232 103 026**
179137	**0 261 230 015**
180045	**0 280 218 084**
180137	**0 281 002 170**
181120	**0 280 218 085**
181809	**0 261 231 158**
182194	**0 261 210 198**
182266	**0 261 231 159**
187739	**0 261 231 166**
187740	**0 261 231 167**
188171	**0 265 005 241**
188171	**0 265 005 248**
188171	**0 265 005 428**
188172	**0 265 005 241**
188172	**0 265 005 428**
189394	**0 265 005 418**
189540	**0 261 210 237**
190276	**0 261 230 015**
190405	**0 265 005 411**
196819	**0 280 752 285**
196899	**0 280 752 284**
205297	**0 280 752 284**
206070	**0 265 005 616**
217446	**0 261 231 211**
217453	**0 261 231 212**
363802105	**0 265 006 213**
383700102	**0 280 752 005**
40 13 01 06	**0 332 204 101**
60 68 49 44	**1 397 212 011**
61 76 63 00	**0 280 230 012**
62 37 06 00	**0 280 230 009**
94002644	**0 265 005 411**
94002648	**0 265 005 241**

FIAT

100496101	**0 281 002 456**
112685	**0 232 103 052**
112685	**0 281 002 844**
1307433080	**0 204 154 020**
1307437080	**0 204 154 026**
1307438080	**0 204 154 027**
1315352080	**0 204 154 044**
1315353080	**0 204 154 045**
1320327080	**0 265 006 427**
1320328080	**0 265 006 406**
1320329080	**0 265 006 405**
13243690	**0 281 002 184**
1324369080	**0 281 002 184**
1324369080	**0 986 284 112**
133732208	**0 281 002 565**
1349820080	**0 280 755 049**
1350038080	**0 280 755 050**
1471884080	**0 204 154 024**
1472087080	**0 204 154 025**
1480845080	**0 265 006 426**
1480846080	**0 265 006 388**
1482480080	**0 265 006 504**
1493882080	**0 265 007 083**
1493883080	**0 265 007 084**
2335911	**0 265 007 079**
3547833	**0 280 217 005**
42357800	**0 280 202 018**
4339372	**0 332 014 151**
4383066	**0 332 015 011**
4393598	**0 280 120 215**
4393601	**0 280 130 023**
4420994	**0 332 514 105**
4421251	**0 280 202 017**
4429201	**0 280 202 019**
4429207	**0 280 200 024**
4429207	**0 280 200 034**
4429207	**0 986 280 075**
4430292	**0 280 202 012**
4430294	**0 280 120 300**
4430298	**0 332 514 121**
4430298	**0 332 514 127**
46125769	**0 280 130 026**
46130395	**0 280 120 302**
46132195	**0 438 121 066**
46137823	**0 280 120 315**
46401855	**0 265 005 030**
46401856	**0 265 005 030**
46401856	**0 265 005 031**
46404401	**0 265 006 210**
46404402	**0 265 006 211**
46406454	**0 261 210 117**
46407008	**0 280 217 111**
46411135	**0 261 210 129**
46411427	**0 261 210 127**
46411675	**0 281 002 144**
46416748	**0 280 217 514**
46419399	**0 261 210 130**
464211118	**0 265 006 212**
46421112	**0 265 006 238**
46421118	**0 265 003 074**
46421118	**0 265 006 212**
46421122	**0 265 006 138**
46422412	**0 265 006 197**
46426391	**0 265 006 346**
46427958	**0 265 006 262**
46432103	**0 281 002 213**
46433052	**0 280 130 039**
46433053	**0 281 002 122**
46433053	**0 281 002 137**
46433054	**0 261 230 009**
46434529	**0 265 006 164**
4643453	**0 265 006 163**
46434532	**0 265 006 166**
46437264	**0 281 002 214**
46441787	**0 281 002 160**
46442040	**0 204 120 946**
46444280	**0 280 752 004**
46444280	**0 280 752 005**
46444287	**0 280 217 531**
46444287	**0 986 280 233**
464457881	**0 265 006 347**
46446873	**0 281 002 159**
46446873	**0 281 002 214**
46447503	**0 280 218 019**
46447503	**0 986 280 236**
46447508	**0 281 002 199**
46450545	**0 265 006 325**
46456661	**0 265 006 163**
46456796	**0 205 001 010**
46457537	**0 265 006 164**
46457881	**0 265 006 347**
46460544	**0 265 006 364**
46460545	**0 265 006 365**
46463384	**0 204 120 987**
46464928	**0 280 217 102**
46466175	**0 205 003 052**
46467348	**0 265 006 124**
46468682	**0 281 002 137**
46468682	**0 281 002 215**
46469784	**0 265 006 249**
46469866	**0 261 210 160**
46469867	**0 261 231 131**
46469867	**0 261 231 148**
46469917	**0 280 218 001**
46469917	**0 986 280 234**
46470477	**0 261 210 160**
46472179	**0 281 002 209**
46472180	**0 281 002 203**
46472182	**0 281 002 199**
46472687	**0 261 210 160**
46472687	**0 261 210 163**
46473033	**0 265 006 539**
46473033	**0 265 006 540**
46473049	**0 265 006 539**
46473049	**0 265 006 540**
46474583	**0 261 210 161**
46474585	**0 261 230 035**
46475007	**0 280 750 013**
46475007	**3 437 010 459**
46477973	**0 261 210 167**
46478160	**0 280 752 004**
46481638	**0 281 002 210**
46481639	**0 281 002 214**
46481640	**0 281 002 213**
46512475	**0 204 127 122**
46512475	**0 281 002 203**
46519886	**0 265 007 039**
46519916	**0 265 007 036**
46519917	**0 265 007 037**
46520005	**0 265 007 038**
46522739	**0 232 101 037**
46522957	**0 204 127 379**
46522958	**0 204 127 353**

F

46525288	**0 261 231 144**
46530202	**0 265 007 043**
46530204	**0 265 007 045**
46531417	**0 265 007 071**
46531418	**0 265 007 072**
46531419	**0 265 007 070**
46531420	**0 265 007 069**
46532105	**0 204 127 412**
46533308	**0 280 218 004**
46533308	**0 986 280 235**
46533515	**0 280 750 042**
46533518	**0 261 230 030**
46539830	**0 265 007 034**
46539831	**0 265 007 035**
46539832	**0 265 007 032**
46539833	**0 265 007 033**
46540022	**0 265 007 050**
46540023	**0 265 007 049**
46540024	**0 265 007 055**
46540025	**0 265 007 054**
46541253	**0 280 218 019**
46541253	**0 986 280 236**
46542976	**0 281 002 260**
46542976	**0 281 002 405**
46544765	**0 265 007 075**
46544766	**0 265 007 076**
46545467	**0 265 007 051**
46545468	**0 265 007 053**
46545469	**0 265 007 052**
46546238	**0 281 002 386**
46546935	**0 265 007 044**
46547231	**0 265 007 024**
46547232	**0 265 007 025**
46547233	**0 265 007 026**
46547234	**0 265 007 027**
46550482	**0 204 127 413**
46550582	**0 204 127 413**
46552950	**0 232 103 035**
465529510	**0 261 231 148**
46553045	**0 261 230 030**
46557523	**0 265 005 225**
46557523	**0 265 005 241**
46557523	**0 265 005 277**
46557534	**0 265 007 086**
46557535	**0 265 007 085**
46557536	**0 265 007 089**
46557537	**0 265 007 089**
46559804	**0 281 002 309**
46559804	**0 986 284 113**
4655982	**0 281 002 308**
4655982	**0 986 284 117**
46559828	**0 986 284 117**
46736164	**0 281 002 380**
46736962	**0 204 127 463**
46737767	**0 265 007 063**

46737768	**0 265 007 064**
46737769	**0 265 007 065**
46737770	**0 265 007 066**
46739156	**0 265 007 059**
46739157	**0 265 007 061**
46743211	**0 261 545 010**
46745961	**0 281 002 320**
46749246	**0 280 218 054**
46749246	**0 986 280 238**
46750234	**0 204 127 480**
46750422	**F 009 D00 252**
46752063	**0 265 007 071**
46752064	**0 265 007 072**
46753680	**0 265 005 418**
467545380	**0 261 210 219**
467545390	**0 261 210 219**
46755863	**0 281 002 380**
46761337	**0 265 007 098**
46761338	**0 265 007 099**
46763852	**0 265 007 073**
46763853	**0 265 007 074**
46766873	**0 281 002 379**
46769978	**0 261 230 042**
46769979	**0 261 230 052**
46770138	**0 265 007 093**
46770139	**0 265 007 091**
46772456	**0 265 007 101**
46772459	**0 265 007 100**
46772460	**0 265 007 101**
46776188	**0 265 006 673**
46778586	**0 281 002 415**
46778965	**0 265 005 428**
46779078	**0 280 752 227**
46779352	**0 261 210 220**
46779638	**0 281 002 405**
467831830	**0 265 007 102**
467831840	**0 265 007 103**
46784470	**0 265 007 400**
46784471	**0 265 007 401**
46784582	**0 281 002 613**
46784582	**0 986 284 116**
467860490	**0 232 103 039**
46788928	**0 265 007 059**
46796114	**0 265 007 061**
46798352	**0 281 002 603**
46798363	**0 261 210 227**
46798367	**0 232 103 046**
46798368	**0 232 103 048**
46798369	**0 232 103 046**
46798480	**0 281 002 386**
46800065	**F 009 D00 255**
46803379	**0 265 005 241**
46803400	**0 280 752 231**
46804400	**0 280 752 231**
46806128	**0 280 002 474**

468061280	**0 281 002 474**
46808221	**0 281 002 533**
46808221	**0 986 284 114**
46808734	**0 261 210 203**
46809773	**0 265 006 689**
46809774	**0 265 006 688**
46809930	**0 280 752 277**
46810176	**F 009 D00 258**
46810176	**0 204 127 462**
46811121	**0 232 103 043**
46811121	**0 232 103 048**
46811122	**0 280 218 120**
46811122	**0 986 280 240**
46811123	**0 232 103 024**
46811235	**0 281 002 160**
46811235	**0 281 002 510**
46811312	**0 280 218 113**
46811312	**0 986 280 239**
46812910	**0 281 002 534**
4681516	**0 261 210 238**
46816928	**0 265 007 401**
46816929	**0 265 007 400**
46823093	**0 265 007 486**
46823093	**0 265 007 487**
46823094	**0 265 007 486**
46823094	**0 265 007 487**
46823095	**0 265 007 488**
46824377	**0 281 002 598**
46824377	**0 986 284 115**
46825442	**0 281 002 506**
46826211	**0 265 007 113**
46826474	**0 265 007 111**
46826474	**0 265 007 112**
46826475	**0 265 007 111**
46826475	**0 265 007 112**
468278580	**1 397 212 047**
46828247	**0 265 007 640**
46828247	**0 265 008 006**
46831064	**0 265 005 277**
46837685	**0 265 007 518**
46837686	**0 265 007 610**
46837687	**0 265 007 519**
46837688	**0 265 007 520**
46837689	**0 265 007 611**
46837690	**0 265 007 521**
46838209	**0 265 007 126**
46838609	**0 265 007 543**
46838609	**0 265 007 551**
46838609	**0 265 007 563**
46838610	**0 265 007 550**
46839673	**0 265 007 544**
46839673	**0 265 008 007**
46840338	**0 265 001 195**
46842227	**0 265 007 542**
46842228	**0 265 007 543**

46844825	**0 265 007 564**
46844826	**0 265 007 565**
46844827	**0 265 007 566**
46844828	**0 265 007 567**
46845597	**0 265 007 485**
46846931	**0 265 007 510**
46846932	**0 265 007 511**
46846933	**0 265 007 512**
46846934	**0 265 007 513**
47752064	**0 265 007 072**
4897501	**0 281 002 398**
50010522	**0 265 006 402**
50010523	**0 265 006 403**
50011475	**0 265 006 164**
50011475	**0 265 006 537**
50011476	**0 265 006 163**
50011476	**0 265 006 538**
500372234	**0 281 002 405**
500374763	**0 281 002 513**
50093165	**0 265 001 336**
504048261	**0 281 002 667**
504081877	**0 281 002 733**
504245257	**0 281 002 845**
504247741	**0 281 002 903**
50504914	**0 280 755 051**
50504914	**0 280 755 053**
50505939	**0 280 752 228**
50510340	**0 265 008 218**
506812	**0 265 005 411**
51493180	**0 265 006 325**
51702279	**0 265 007 503**
51702279	**0 265 008 049**
51702646	**0 265 007 636**
51705195	**0 265 007 561**
51705196	**0 265 007 560**
51705197	**0 265 007 563**
51705198	**0 265 007 562**
51706546	**0 265 007 126**
51713211	**0 265 007 449**
51713211	**0 265 008 005**
51715557	**0 280 752 250**
51718056	**0 265 007 448**
51725099	**0 265 007 685**
51725100	**0 265 007 686**
51727705	**0 265 007 129**
51732518	**0 265 007 629**
51737851	**0 265 007 611**
51737851	**0 265 007 831**
51737852	**0 265 007 521**
51739391	**0 265 007 774**
51739392	**0 265 007 773**
51742256	**0 265 007 678**
51743697	**0 265 007 771**
51743697	**0 265 007 772**
51743698	**0 265 007 771**

F

◀ FIAT

517436980	**0 265 007 772**
51745715	**0 265 007 639**
51746232	**0 265 005 616**
51748608	**0 265 007 691**
51753528	**0 265 007 711**
51759243	**0 265 007 678**
51759244	**0 265 007 629**
51759509	**0 265 007 830**
51761978	**0 265 007 795**
51761985	**0 265 007 796**
51764254	**0 265 007 833**
51768620	**0 265 007 678**
51770449	**0 265 007 969**
51774023	**0 281 002 369**
51774531	**0 281 002 613**
51774531	**0 986 284 116**
51775574	**0 281 002 325**
51775576	**0 281 002 369**
51780555	**0 280 755 053**
51782033	**0 281 002 861**
51782034	**0 281 002 980**
51782035	**0 281 002 860**
51782787	**0 265 007 833**
51783168	**0 280 752 295**
51785640	**0 280 755 052**
51785683	**0 280 752 232**
51785804	**0 281 002 506**
51787268	**0 265 008 035**
51787753	**0 265 007 686**
51787753	**0 265 007 980**
51791153	**0 265 008 005**
51791154	**0 265 008 006**
51791156	**0 265 007 544**
51791156	**0 265 008 007**
51792165	**0 265 008 002**
51792166	**0 265 008 003**
51792707	**0 281 002 963**
51796983	**0 265 007 134**
51796984	**0 265 007 132**
51797783	**0 261 230 173**
51797945	**0 265 008 049**
51799347	**0 265 008 055**
51799348	**0 265 008 056**
51801310	**0 265 007 833**
51808334	**0 265 008 288**
51812551	**0 265 008 188**
51989980	**0 265 007 135**
55183650	**0 281 002 792**
55183650	**0 281 002 793**
55183651	**0 281 002 618**
55184544	**0 281 002 777**
55184549	**0 281 002 617**
55186669	**0 261 231 176**
55187316	**0 280 750 137**
55187332	**0 261 210 266**
55187718	**0 281 002 549**
55187722	**0 280 218 164**
55187722	**0 986 280 241**
55187820	**0 261 231 173**
55187973	**0 232 103 052**
55189517	**0 261 210 114**
55190587	**0 281 002 763**
551905870	**0 281 002 764**
55190763	**0 281 002 568**
55192238	**0 261 545 011**
55193048	**0 281 002 309**
55193048	**0 986 284 113**
55193049	**0 280 218 054**
55193049	**0 986 280 238**
55194195	**0 280 120 015**
55194788	**0 281 002 784**
551947880	**0 281 002 716**
55195077	**0 281 002 568**
55195077	**0 281 002 734**
55195078	**0 281 002 706**
551963850	**0 280 218 182**
55198717	**0 281 002 770**
55198717	**0 281 002 771**
55200301	**0 281 002 783**
55200301	**0 281 002 784**
55206757	**0 281 002 980**
552067590	**0 281 002 917**
55206796	**0 281 002 844**
55206797	**0 281 002 845**
55216291	**0 281 006 004**
553500480	**0 281 002 618**
55700425	**0 265 007 671**
55700426	**0 265 007 769**
55701387	**0 265 007 768**
557019510	**0 265 005 607**
55703974	**0 265 007 896**
55775576	**0 281 002 369**
5893108	**0 280 202 602**
5893108	**0 986 280 019**
5893599	**0 280 200 602**
5894034	**0 280 202 601**
5894034	**0 986 280 076**
5920385	**0 280 202 023**
5920385	**0 986 280 017**
5920388	**0 280 200 024**
5920388	**0 986 280 075**
5929385	**0 280 202 023**
5929385	**0 986 280 017**
5945040	**0 280 202 038**
5946923	**0 280 230 006**
5968080	**0 280 202 059**
5968080	**0 986 280 044**
59680802	**0 280 202 059**
59680802	**0 986 280 044**
5968082	**0 280 202 060**
5968082	**0 986 280 046**
5972332	**0 280 130 026**
5991955	**0 280 120 311**
5991956	**0 280 120 312**
5997041	**0 280 101 001**
5999235	**0 280 230 114**
60472180	**0 281 002 320**
60500571	**0 280 202 204**
60500571	**0 280 202 211**
60500571	**0 986 280 055**
60500571	**0 986 280 091**
60507061	**0 332 204 101**
6050825	**0 265 001 074**
60508251	**0 265 001 073**
60511751	**0 265 001 156**
60512672	**0 280 120 300**
60512698	**0 261 231 006**
60513205	**0 280 130 026**
60513206	**0 280 202 201**
60513206	**0 986 280 069**
60513208	**0 261 210 036**
60513336	**0 280 202 202**
60513336	**0 280 202 210**
60513336	**0 986 280 063**
60513337	**0 280 120 315**
60513747	**0 280 120 435**
60513882	**0 280 203 026**
60513882	**0 986 280 042**
605138820	**0 280 203 026**
605138820	**0 986 280 042**
60518135	**0 280 101 001**
60518377	**0 261 211 003**
60518694	**0 261 210 001**
60518695	**0 261 230 001**
60522010	**0 280 202 013**
60522875	**0 280 120 304**
60522876	**0 280 230 001**
60523383	**0 280 130 023**
60523386	**0 280 202 010**
60523390	**0 332 514 127**
60534263	**0 261 231 006**
60534264	**0 261 211 004**
60534312	**0 280 130 032**
60534313	**0 280 202 058**
60534316	**0 280 230 009**
60534706	**0 280 202 078**
60534838	**0 280 202 105**
60534959	**0 280 202 108**
60534959	**0 986 280 067**
60535033	**0 280 202 113**
60537835	**0 280 202 206**
60537835	**0 986 280 065**
60545849	**0 265 001 250**
6054585	**0 265 001 251**
60547113	**0 280 202 205**
60548743	**0 261 231 007**
60549359	**0 280 122 001**
60550042	**0 280 203 035**
60555613	**0 261 220 001**
60555613	**0 261 220 002**
60557363	**0 265 003 061**
60557409	**0 265 003 062**
60558015	**0 265 001 268**
60559269	**0 265 003 066**
60559406	**0 265 001 267**
60560715	**0 261 210 047**
60565464	**0 265 003 101**
60565464	**0 265 006 119**
60565479	**0 265 003 102**
60565479	**0 265 006 118**
60565836	**0 356 914 213**
60565836	**0 356 914 224**
60565837	**0 280 203 034**
60569060	**0 261 210 096**
60569704	**0 280 202 208**
60569704	**0 280 202 213**
60569704	**0 986 280 024**
60569704	**0 986 280 025**
60572382	**0 280 202 207**
60573739	**0 261 210 090**
60574615	**0 280 130 039**
60576483	**0 265 005 109**
60577321	**0 265 003 096**
60577321	**0 265 006 162**
6057940	**0 280 202 207**
6057940	**0 280 202 212**
6057940	**0 986 280 081**
60579846	**0 280 203 034**
60586655	**0 232 103 009**
60588375	**0 265 001 355**
60588419	**0 280 217 106**
60589472	**0 280 217 503**
60591616	**0 281 002 085**
60591909	**0 280 130 073**
60592752	**0 261 231 007**
60592752	**0 261 231 095**
60593506	**0 205 001 009**
6059481	**0 205 001 009**
60595754	**0 261 210 113**
60599278	**0 265 005 110**
60601097	**0 265 006 118**
60601098	**0 265 006 119**
60601099	**0 265 006 120**
6060217	**0 280 203 026**
6060217	**0 986 280 042**
60602177	**0 280 203 026**
60602177	**0 986 280 042**
60605410	**0 232 103 010**
60615270	**0 265 006 162**
60615953	**0 265 006 260**

F

60615954	**0 265 006 261**
60622632	**0 265 006 325**
60622633	**0 265 006 326**
60628356	**0 281 002 202**
60629558	**0 204 127 126**
60630438	**0 204 127 273**
60630466	**0 204 127 127**
60652012	**0 265 007 016**
60652013	**0 265 007 017**
60652016	**0 265 007 018**
60652439	**0 280 750 012**
60652439	**0 280 750 023**
60652443	**0 280 750 011**
60652776	**0 265 007 021**
60652777	**0 265 007 022**
60652874	**0 265 007 020**
60654043	**0 280 750 053**
60654043	**0 280 750 073**
60654314	**0 280 750 012**
60654900	**0 204 127 376**
60654900	**0 281 002 203**
60654946	**0 280 750 073**
60656290	**0 265 007 040**
60656291	**0 265 007 041**
60656301	**0 265 007 042**
60657874	**0 280 750 023**
60659263	**0 265 007 046**
60659264	**0 265 007 047**
60659265	**0 265 007 018**
60659265	**0 265 007 048**
60659531	**0 204 127 456**
60660039	**1 397 212 011**
60660054	**0 280 750 053**
60661479	**0 204 127 462**
60662165	**0 204 127 377**
60662823	**0 261 231 152**
60662824	**0 261 231 153**
60662825	**0 232 103 024**
60662826	**0 261 210 203**
60663029	**0 280 218 036**
60663029	**0 986 280 237**
60665711	**0 280 752 224**
60671190	**0 280 750 121**
60675805	**F 009 D00 257**
60679537	**0 280 752 249**
60684944	**1 397 212 011**
60699853	**0 265 005 499**
60700045	**0 280 202 045**
60722873	**0 280 202 027**
60722873	**0 986 280 078**
60755045	**0 280 200 601**
60755045	**0 986 280 061**
60755046	**0 280 200 001**
60755046	**0 280 200 002**
60800132	**0 280 230 006**
60800163	**0 280 202 060**
60800163	**0 986 280 046**
60800167	**0 280 130 026**
60800522	**0 280 130 032**
60802028	**0 280 218 113**
60802028	**0 986 280 239**
60802037	**0 986 284 115**
60805107	**0 280 202 060**
60805107	**0 986 280 046**
60805373	**0 280 101 001**
60806252	**0 265 003 074**
60806252	**0 265 006 212**
60806254	**0 265 003 063**
60806254	**0 265 006 197**
60807526	**0 265 001 301**
60808142	**0 280 130 026**
60808397	**0 265 003 075**
60808904	**0 261 210 096**
60808986	**0 261 210 090**
6080915	**0 280 202 212**
6080915	**0 986 280 081**
60809658	**0 280 202 211**
60809658	**0 986 280 091**
60810394	**0 265 005 030**
60810394	**0 265 005 031**
60810692	**0 261 210 113**
60810695	**0 232 103 009**
60810774	**0 265 003 096**
60810774	**0 265 006 162**
60810791	**0 261 231 095**
60810813	**0 280 217 111**
60811021	**0 281 002 085**
60811201	**0 232 101 026**
6081145	**0 280 217 514**
6081220	**0 280 130 055**
6081224	**0 280 130 055**
60812394	**0 265 006 212**
60812395	**0 265 006 162**
60812644	**0 265 006 197**
60813773	**0 265 006 238**
60814589	**0 261 210 160**
60814715	**0 281 002 209**
60814769	**0 281 002 214**
60814770	**0 281 002 213**
60814852	**0 280 218 019**
60814852	**0 986 280 236**
60815022	**0 281 002 202**
60815340	**0 205 003 052**
60815463	**0 204 127 122**
60815616	**0 280 217 531**
60815616	**0 986 280 233**
60815816	**0 204 127 462**
60816027	**0 265 007 073**
60816028	**0 265 007 074**
60816137	**0 281 002 309**
60816137	**0 986 284 113**
60816293	**0 280 217 531**
60816293	**0 986 280 233**
6081644	**0 281 002 308**
6081644	**0 986 284 117**
60816448	**0 986 284 117**
60816463	**0 204 127 480**
60816553	**0 281 002 474**
60816693	**0 280 218 054**
60816693	**0 986 280 238**
60816746	**0 261 210 203**
7084986	**0 261 230 030**
71713685	**F 00C 1G6 969**
71715149	**3 437 010 452**
71719014	**0 265 006 197**
71728869	**0 265 005 428**
71730275	**0 265 005 303**
717359980	**0 281 002 184**
71738374	**3 437 010 459**
71738437	**3 437 010 460**
71749476	**0 281 006 004**
71787951	**0 986 280 239**
71787955	**0 986 284 117**
71787959	**0 986 280 238**
71787967	**0 986 284 113**
71787996	**0 986 284 115**
71788000	**0 986 280 233**
71788004	**0 986 280 236**
71788020	**0 986 280 234**
71788023	**0 986 280 235**
71788026	**0 986 280 237**
71788032	**0 986 284 112**
71788038	**0 986 284 114**
71788047	**0 986 280 240**
71788050	**0 986 284 116**
71788743	**0 986 280 241**
71788746	**0 986 284 113**
71789488	**0 986 284 116**
73502778	**0 281 002 617**
73503657	**0 281 002 437**
735036570	**0 281 002 437**
7354478650	**0 263 003 645**
7354478660	**0 263 003 646**
7354478670	**0 263 003 647**
7354478680	**0 263 003 648**
7354478690	**0 263 003 649**
7354478700	**0 263 003 650**
7354478710	**0 263 003 651**
7354478720	**0 263 003 652**
7354478730	**0 263 003 653**
7354478740	**0 263 003 654**
7354478750	**0 263 003 655**
7354478760	**0 263 003 656**
7354478770	**0 263 003 657**
7354481400	**0 263 003 677**
740134603	**0 280 130 032**
75204203	**0 331 101 004**
7529274	**0 261 230 004**
7540622	**0 280 120 314**
7546795	**0 280 200 046**
7553412	**0 280 202 081**
7555126	**0 280 202 102**
7555126	**0 986 280 054**
7555127	**0 280 202 103**
7555128	**0 280 200 051**
7576067	**0 280 230 009**
7597692	**0 280 120 323**
7612317	**0 280 202 114**
7612317	**0 986 280 080**
7612319	**0 280 202 115**
7612320	**0 280 213 006**
7612320	**0 986 280 115**
7616269	**0 261 210 029**
7628059	**0 280 230 009**
7629856	**0 280 101 003**
7630317	**0 265 001 215**
7630318	**0 265 001 216**
7630319	**0 265 001 217**
7636642	**0 280 120 328**
7637025	**0 280 122 001**
7640095	**0 280 120 307**
7644804	**0 280 120 307**
7647004	**0 280 130 032**
7647004	**0 280 130 069**
7648065	**0 280 213 025**
7648065	**0 986 280 114**
7648113	**0 280 120 313**
7651951	**0 265 007 082**
7651951	**0 265 007 421**
7668164	**0 280 202 204**
7668164	**0 280 202 211**
7668164	**0 986 280 055**
7668164	**0 986 280 091**
76691230	**0 261 231 007**
7669143	**0 280 130 066**
7686033	**0 280 202 060**
7686033	**0 986 280 046**
7686599	**0 280 130 060**
7690200	**0 280 200 055**
7693640	**0 280 202 013**
7693640	**0 280 202 103**
7694623	**0 280 120 331**
7706073	**0 280 202 128**
7706577	**0 280 120 328**
7706578	**0 280 120 314**
7706579	**0 280 120 307**
7706580	**0 280 120 300**
77065804	**0 280 120 300**
7706581	**0 280 120 331**
7706582	**0 280 120 323**

F

◀ FIAT

77065830	**0 280 120 313**
7706584	**0 280 120 312**
7706585	**0 280 120 311**
7709815	**0 232 102 004**
77118780	**0 280 212 024**
77118780	**0 986 280 123**
7712078	**0 265 001 338**
7717686	**0 280 230 005**
7718934	**0 265 001 337**
7718935	**0 265 001 336**
7721274	**0 281 002 089**
7721274	**0 281 002 093**
7724096	**0 281 002 088**
7724097	**0 205 001 010**
7731633	**0 261 210 098**
77362294	**0 281 002 412**
77363439	**1 287 213 612**
77364543	**F 01C 600 085**
7738223	**0 280 130 055**
7739430	**0 261 210 093**
7739431	**0 232 101 018**
7746949	**0 261 210 100**
7750753	**0 280 230 014**
7750754	**0 280 230 018**
7756924	**0 261 210 103**
7756925	**0 261 210 102**
7757923	**0 281 002 087**
77579230	**0 281 002 087**
7763718	**0 280 217 106**
7763719	**0 280 130 073**
7764102	**0 265 003 109**
7764102	**0 265 006 402**
7765599	**0 261 231 102**
7766248	**0 265 006 140**
7766249	**0 265 006 139**
77662510	**0 281 002 102**
7766252	**0 261 210 104**
7767750	**0 281 002 185**
7770239	**0 280 130 107**
77773440	**0 232 101 026**
7779229	**0 280 122 005**
77825160	**0 265 001 387**
7787256	**0 261 210 124**
77872560	**0 261 210 124**
7788905	**0 281 002 108**
7790917	**0 261 210 119**
77942200	**0 265 006 161**
7798691	**0 261 210 114**
7799032	**0 261 210 118**
7799033	**0 261 210 115**
8133931	**0 265 008 037**
82277331	**0 280 100 024**
82277332	**0 280 121 001**
82277333	**0 280 130 006**
82277334	**0 280 130 014**
82277344	**0 332 003 023**
82281564	**0 280 120 031**
82308690	**0 280 120 213**
82348191	**0 280 202 014**
82357799	**0 280 202 015**
82357800	**0 280 202 018**
82365378	**0 332 514 121**
82369630	**0 335 530 023**
82390387	**0 280 202 015**
82401252	**0 265 001 073**
82406063	**0 265 001 072**
82407679	**0 265 001 074**
82434700	**0 265 005 017**
82434700	**0 265 005 030**
8243566	**0 265 001 248**
82435661	**0 265 001 249**
82435662	**0 265 001 246**
82435663	**0 265 001 247**
82442723	**0 265 001 209**
824451370	**0 265 001 210**
82448464	**0 265 001 304**
82450141	**0 265 005 014**
82450141	**0 265 005 031**
82455274	**0 265 001 261**
82458587	**0 265 003 074**
82458587	**0 265 006 212**
82458588	**0 265 003 063**
82458954	**0 265 003 071**
82458954	**0 265 006 262**
82458956	**0 265 003 075**
8246063	**0 265 001 072**
82467204	**0 265 003 075**
82472241	**0 265 001 216**
82472242	**0 265 001 217**
82472243	**0 265 003 063**
82472243	**0 265 006 197**
82485111	**0 265 003 121**
82485111	**0 265 006 238**
82485174	**0 265 006 160**
82485175	**0 265 006 300**
9009423	**0 331 101 001**
92308690	**0 280 120 213**
960389388	**0 280 122 001**
9610592680	**9 456 160 006**
9617220680	**0 280 122 003**
9618261580	**0 261 230 012**
9621334480	**0 261 231 109**
9628648280	**0 261 231 130**
9631813680	**0 261 230 057**
9633310080	**0 281 002 283**
9639418880	**0 261 230 057**
9645447780	**0 265 005 211**
9645447780	**0 265 005 290**
9650452180	**0 265 005 290**
9923794	**0 331 101 003**
9927593	**0 331 101 004**
9934319	**0 331 101 008**
9944334	**0 332 014 411**
99455420	**0 281 002 170**
9946862	**0 280 122 001**

FORD

AUC 2C190 A	**0 265 006 543**
AU2 2C204 A	**0 265 006 627**
AU2 2C205 A	**0 265 006 626**
A95GX 13K236 MA	**0 263 003 004**
A95VWX 13K236 EA	**0 263 009 016**
A95VWX 13K236 FA	**0 263 009 017**
BAT 6S701 A	**0 261 230 029**
BA 12A699 A	**0 261 231 045**
BA 9F479 A	**0 261 230 098**
BG5X 10884 AA	**0 281 002 471**
BG5X 6C315 AA	**0 281 002 411**
BG5X 6C315 BA	**0 281 002 410**
BG5X 9D290 AA	**0 281 002 316**
BG5X 9F479 AA	**0 281 002 398**
BG6X 9F479 CA	**0 281 002 851**
EA 12A648 A	**0 280 130 049**
ED E5EF 12B529 BA	**0 280 202 121**
ED E5EF 12B529 BA	**0 986 280 039**
EL 2C204 A	**0 265 006 230**
ERR 7354	**0 261 210 158**
ER 2C190 A	**0 265 006 484**
ER 2C190 A	**0 265 006 485**
ER 2C190 C	**0 265 006 485**
ER 2C204 A	**0 265 006 482**
ER 2C205 A	**0 265 006 481**
ER 6B288 1	**0 261 210 168**
E3GF 12B529 B1	**0 280 200 037**
E3SF 12B529 AA	**0 280 202 042**
E3SF 12B529 BA	**0 280 202 055**
E42X 12B529 AA	**0 280 203 024**
E5EF 12B529 BA	**0 280 202 072**
E5ZF 121B529 AA	**0 280 202 071**
E7SF 12B529 AA	**0 280 203 030**
E7SF 12B529 AA	**0 280 203 031**
E9EF 12B529 AA	**0 280 202 122**
E9EF 12B529 AA	**0 986 280 039**
F3XY 2C204 BA	**0 265 006 560**
F4ZZ 2C190 BB	**0 265 006 431**
F4ZZ 2C190 CB	**0 265 006 432**
F5RZ 2C190 A	**0 204 154 021**
F5RZ 2C190 A	**0 204 154 032**
F6DZ 2C190 B	**0 265 006 150**
F6RZ 2C182 AA	**0 204 154 030**
F6RZ 2C182 BA	**0 204 154 021**
F6RZ 2C182 BA	**0 204 154 032**
F7DZ 2C190 AA	**0 265 006 149**
F7DZ 2C190 CB	**0 265 006 159**
F7DZ 2C216 BB	**0 265 006 158**
F7RZ 2C190 BA	**0 204 154 036**
F7RZ 2C204 AA	**0 204 154 035**
F7ZZ 2C204 AB	**0 265 006 287**
F7ZZ 2C205 AB	**0 265 006 286**
F77F 12A669 BB	**0 261 231 119**
F77F 12A699 AB	**0 261 231 114**
F77F 12A699 BA	**0 261 231 114**
F77F 12A699 BA	**0 261 231 119**
F77F 12A699 BC	**0 261 231 119**
F8DZ 2C204 AA	**0 265 006 147**
H81AG 9P843 AA	**0 438 120 174**
M9100391	**0 261 230 146**
M9100473	**0 261 230 132**
M9100487	**0 261 230 172**
NSC 500 600	**0 261 231 185**
NSC 500600	**0 261 231 186**
SR0 500140	**0 265 005 654**
VP1S7W 2B372 AD	**0 265 007 879**
VP6CZU 12B579 AA	**0 280 218 144**
V1C15 2B372 AA	**0 265 007 125**
V1C15 2B372 AB	**0 265 007 125**
V83AB 12B532 AA	**0 280 230 103**
V83AB 9P841 AA	**0 438 120 199**
V83AB 9P916 AA	**0 438 120 174**
V85AB 9P704 AA	**0 280 230 006**
V85SF 12A648 AA	**0 280 130 037**
V85SF 12B527 AA	**0 280 120 302**
V86AB 12A648 AA	**0 280 130 049**
V90SF 12A697 AA	**0 280 130 067**
V97GB 12B579 AA	**0 281 002 164**
V97GB 9F479 AB	**0 281 002 122**
WR2A 2C190 AA	**0 265 006 484**
WR2A 2C190 AC	**0 265 006 484**
WR2A 2C190 CB	**0 265 006 485**
WR2A 2C204 AD	**0 265 006 482**
WR2A 2C204/5 AA	**0 265 006 481**
WR2A 2C205 AD	**0 265 006 481**
WR2A 2C2190 A	**0 265 006 483**
WR2A 2C2190 AA	**0 265 006 483**
WR2A 6B288 AA	**0 261 210 168**
WR2A 9H535 AA	**F 005 T00 001**
WR2A 9H535 AA	**F 005 T00 002**
XBZF 9F479 AA	**0 261 230 060**
XB2F 9F479 AA	**0 261 230 059**
XE 12A646 A	**0 280 230 006**
XF1Z 2C204 BB	**0 265 006 148**
XF 12B529 A	**0 280 202 077**
XF3F 12A699 AA	**0 261 231 139**
XF5Z 2C190 AB	**0 265 006 454**
XF5Z 2C204 AC	**0 265 006 456**
XF5Z 2C204 AD	**0 265 006 457**
XF5Z 2C216 AB	**0 265 006 455**
XL3F 12A699 AA	**0 261 231 137**
XL3F 12A699 BA	**0 261 231 138**
XL 3F 12A699 CA	**0 261 231 143**

F

XR33 2C218 AA	**0 265 006 433**
XS6F 9F479 AA	**0 261 230 027**
XS6F 9F479 AA	**0 261 230 028**
XS6F 9F479 AB	**0 261 230 027**
XS6F 9F479 AB	**0 261 230 028**
XW4H 17D547 AB	**1 397 212 003**
XW4H 17D547 AC	**1 397 212 003**
XW4T 17D547 AC	**1 397 212 003**
XW4T 17D547 A1	**1 397 212 003**
X230 00004 XX	**0 265 005 236**
YC15 2B352 BA	**0 265 006 460**
YC15 2B372 AB	**0 265 006 458**
YC15 2B372 AC	**0 265 006 458**
YC15 2B372 AD	**0 265 006 458**
YC15 2B372 AE	**0 265 006 458**
YC15 2B372 AF	**0 265 006 458**
YC15 2B372 BA	**0 265 004 460**
YC15 2B372 BA	**0 265 006 460**
YC15 2B372 BB	**0 265 006 460**
YC15 2B372 BC	**0 265 006 811**
YC15 2B372 CA	**0 265 006 461**
YC15 2B372 CB	**0 265 006 812**
YC15 2B372 DA	**0 265 006 464**
YC15 2B372 DB	**0 265 006 464**
YC15 2B372 DC	**0 265 006 813**
YC15 2B372 EA	**0 265 006 465**
YC15 2B372 EB	**0 265 006 465**
YC15 2B372 EC	**0 265 006 814**
YC15 2B372 FA	**0 265 006 725**
YF1Z 2C190 AB	**0 265 006 505**
YF1Z 2C190 BB	**0 265 006 506**
YM21 12B529 AB	**0 280 218 061**
YM21 12B529 BA	**0 280 218 018**
YR23 2C190 AA	**0 265 006 543**
YR23 2C190 AC	**0 265 006 543**
YS6G 12A366 AA	**0 261 210 031**
YS6G 12A699 AA	**0 261 231 151**
YS6G 12B579 AA	**0 280 218 050**
YS6G 12K073 AA	**0 232 103 021**
YS6G 12K073 AA	**0 232 103 031**
YS6G 2C444 AB	**0 261 230 055**
YS6G 2C444 AB	**0 261 230 056**
YS6G 6C315 AA	**0 261 210 097**
YS6G 9E296 AA	**0 280 750 072**
YS6G 9E926 AA	**0 280 750 071**
YS6G 9E926 AA	**0 280 750 072**
YS6G 9F472 BA	**0 261 545 002**
YS6G 9F832 BB	**0 280 752 030**
YS6G 9F832 BC	**0 280 752 030**
YW4T 17D547 AA	**1 397 212 003**
053 906301 1	**0 280 202 126**
053 906301 4	**0 280 202 136**
091 003 AA00	**0 265 006 798**
091 004 AA00	**0 265 006 801**
091 005 AA00	**0 265 006 799**
094 003 AA00	**0 265 006 697**
1C15 2B372 AA	**0 265 006 541**
1C15 2B372 AB	**0 265 006 541**
1C15 2B372 AC	**0 265 006 815**
1C15 2B372 BA	**0 265 006 542**
1C15 2B372 BB	**0 265 006 816**
1C15 2B372 CA	**0 265 006 687**
1C15 2B372 CB	**0 265 006 687**
1C15 2B372 CC	**0 265 006 817**
1C15 2B372 CD	**0 265 006 817**
1C15 2B372 DA	**0 265 006 686**
1C15 2B372 DB	**0 265 006 818**
1C15 2B372 DC	**0 265 006 818**
1F1Z 2C190 AB	**0 265 006 649**
1F1Z 2C190 BB	**0 265 006 651**
1F1Z 2C190 CB	**0 265 006 648**
1F1Z 2C190 DB	**0 265 006 650**
1F1Z 2C204 AB	**0 265 006 646**
1F1Z 2C204 BB	**0 265 006 647**
1L2A 12A699 AA	**0 261 231 154**
1R1E 9E926 AA	**0 280 750 156**
1R23 2C204 AA	**0 265 006 627**
1R23 2C205 AA	**0 265 006 626**
1S7A 9F479 AB	**0 261 230 044**
1S7A 9F479 AB	**0 261 230 045**
1S7A 9F479 AC	**0 261 230 044**
1S7A 9F479 AC	**0 261 230 045**
1S7T 14B296 AB	**0 265 005 236**
1S7T 14B296 AC	**0 265 005 236**
1S7T 14B296 AC	**0 265 005 414**
1S7T 14B296 AD	**0 265 005 236**
1S7T 2B372 AB	**0 265 007 087**
1S7T 2B372 AB	**0 265 007 417**
1S7T 2B372 AC	**0 265 007 087**
1S7T 2B372 AC	**0 265 007 879**
1S7T 2B372 AD	**0 265 007 879**
1S7T 2M118 AA	**0 265 005 303**
1S7T 3F818 AA	**0 265 005 414**
1S7T 3F818 AC	**0 265 005 414**
1S7T 3F818 AD	**0 265 005 414**
1S71 14B286 AC	**0 265 005 236**
1U1L 9E979 BA	**0 280 750 138**
1U1L 9E979 CA	**0 280 750 140**
1W1Z 2C190 AB	**0 265 006 600**
1X43 2B372 AB	**0 265 007 404**
1X43 2B372 AB	**0 265 007 417**
1X43 2B372 AC	**0 265 007 404**
1X43 2B372 AD	**0 265 007 404**
1X43 2B372 AE	**0 265 007 404**
1X43 2B372 AF	**0 265 007 404**
1X43 2B372 AG	**0 265 007 404**
1X43 2B372 BB	**0 265 007 417**
1X43 2B372 BC	**0 265 007 417**
1X43 2B372 BD	**0 265 007 417**
1X43 2B372 BF	**0 265 007 417**
1X43 2B372 BG	**0 265 007 417**
1 003 759	**0 280 217 512**
1 012 021	**0 204 154 030**
1 012 022	**0 204 154 021**
1 012 022	**0 204 154 032**
1 017 547	**0 204 154 022**
1 023 255	**0 263 009 016**
1 025 012	**0 204 154 035**
1 025 014	**0 204 154 036**
1 028 457	**0 204 154 031**
1 036 449	**0 204 154 039**
1 041 355	**0 281 002 122**
1 041 359	**0 281 002 164**
1 051 396	**0 280 217 121**
1 051 396	**0 281 002 757**
1 051 396	**0 986 280 202**
1 054 014	**0 261 231 124**
1 087 424	**0 261 230 027**
1 087 424	**0 261 230 028**
1 115 018	**0 265 007 087**
1 115 528	**0 265 005 236**
1 117 731	**0 265 005 414**
1 118 425	**0 265 005 414**
1 119 026	**0 265 005 303**
1 119 939	**0 261 230 044**
1 119 939	**0 261 230 045**
1 128 924	**0 265 005 236**
1 144 400	**0 261 231 162**
1 144 924	**0 265 007 125**
1 146 400	**0 265 007 087**
1 209 109	**0 281 002 461**
1 209 109	**0 281 002 462**
1 222 569	**0 261 210 221**
1 222 569	**0 261 210 222**
1 222 677	**0 232 103 040**
1 222 677	**0 232 103 041**
1 223 521	**0 280 218 104**
1 223 521	**0 280 218 105**
1 223 690	**0 261 230 068**
1 223 690	**0 261 230 069**
1 223 701	**0 280 750 110**
1 223 701	**0 280 750 111**
1 225 306	**0 261 545 006**
1 319 158	**0 232 103 052**
1 319 158	**0 232 103 053**
1 319 285	**0 261 230 122**
1 319 285	**0 261 230 180**
1 320 734	**0 261 231 160**
1 320 734	**0 261 231 161**
1 321 042	**0 280 750 110**
1 338 678	**0 261 230 119**
1 338 678	**0 261 230 120**
1 346 641	**0 265 005 617**
1 346 641	**0 265 005 639**
1 367 813	**0 261 230 090**
1 367 827	**0 280 218 134**
1 372 511	**0 261 230 131**
1 372 511	**0 261 230 132**
1 379 704	**0 261 230 105**
1 379 704	**0 261 230 106**
1 384 275	**0 280 217 121**
1 384 275	**0 281 002 757**
1 384 275	**0 986 280 202**
1 385 800	**0 265 007 817**
1 386 268	**0 265 007 879**
1 428 448	**0 280 217 121**
1 428 448	**0 281 002 757**
1 428 448	**0 986 280 202**
1 439 251	**0 261 230 122**
1 439 251	**0 261 230 123**
1 439 251	**0 261 230 180**
1 439 900	**0 261 230 044**
1 439 900	**0 261 230 045**
1 440 437	**0 261 230 171**
1 440 437	**0 261 230 172**
1 446 702	**0 261 230 180**
1 446 702	**0 261 230 181**
1 478 729	**0 261 230 068**
1 478 729	**0 261 230 069**
1 478 730	**0 261 545 006**
1 485 435	**0 265 005 722**
1 503 280	**0 261 230 225**
1 604 628	**0 335 530 024**
1 613 116	**0 438 120 174**
1 626 473	**0 280 130 037**
1 626 474	**0 280 120 302**
1 639 020	**0 280 130 049**
2C46 12A697 AA	**0 281 002 576**
2C46 6C315 AA	**0 281 002 660**
2C46 9T305 AA	**0 281 002 704**
2M5T 17D547 A	**1 397 212 020**
2M5T 17D547 AA	**1 397 212 020**
2S61 12A699 AA	**0 262 231 162**
2S61 12A699 AB	**0 261 231 161**
2S61 12A699 AB	**0 261 231 162**
2S7A 12B579 CA	**0 280 218 104**
2S7A 12B579 CA	**0 280 218 105**
2S7A 2C444 AA	**0 261 230 083**
2S7A 2C444 AA	**0 261 230 084**
2S7G 12A699 AB	**0 261 231 161**
2S7G 12A699 AC	**0 261 231 161**
2S7G 12A699 AD	**0 261 231 160**
2S7G 12A699 AD	**0 261 231 161**
2S7G 12K073 AA	**0 232 103 040**
2S7G 12K073 AA	**0 232 103 041**
2S7G 6C315 AC	**0 261 210 221**
2S7G 6C315 AC	**0 261 210 222**
2S7G 9E926 AB	**0 280 750 110**
2S7G 9E926 AB	**0 280 750 111**
2S7G 9E926 AC	**0 280 750 110**

F

◀ FORD

2S7G 9E926 AC	**0 280 750 111**
2S7G 9F479 AA	**0 261 230 068**
2S7G 9F479 AA	**0 261 230 069**
2S7G 9F479 AB	**0 261 230 068**
2S7G 9F479 AB	**0 261 230 069**
2S7G 9F972 AC	**0 261 545 006**
2S7G 9F972 AC	**0 261 545 007**
2S7G 9F972 AD	**0 261 545 006**
2S7G 9F972 AD	**0 261 545 007**
2U1L 9F479 AA	**0 261 230 099**
2U1L 9F479 AA	**0 261 230 100**
27 906301	**0 280 202 140**
3C11 2B372 AA	**0 265 006 784**
3C11 2B372 AB	**0 265 006 784**
3C11 2B372 AC	**0 265 006 784**
3F2E 9G756 AA	**0 261 230 093**
3F2E 9G756 AA	**0 261 230 094**
3F2E 9G756 AD	**0 261 230 093**
3F2E 9G756 AD	**0 261 230 094**
3F2E 9G756 AD	**0 261 230 097**
3F2E 9G756 DA	**0 261 230 094**
3M21 12B529 AA	**0 281 002 461**
3M21 12B529 AA	**0 281 002 462**
3R23 12A699 AB	**0 261 231 045**
3R23 2C204 AB	**0 265 006 821**
3R23 2C205 AB	**0 265 006 822**
3R23 9F479 AA	**0 261 230 097**
3R23 9F479 AA	**0 261 230 098**
3R23 9U434 AA	**0 261 230 029**
3R3Z 2C190 BA	**0 265 006 534**
3R3Z 2C190 CA	**0 265 006 535**
3S7T 17D547 AA	**1 397 212 021**
3S7T 17D547 AB	**1 397 212 021**
3W1T 17D547 AC	**1 397 212 033**
3W1Z 2C190 AB	**0 265 006 660**
3W4T 17D547 AA	**1 397 212 054**
3 027 144	**0 261 231 143**
305 906 059 1	**0 280 230 016**
325 927807 3	**0 265 006 220**
325 927807 4	**0 265 006 219**
34 906161	**0 280 130 053**
377 927807	**0 265 006 218**
3 943 759	**0 261 231 119**
3 991 033	**0 261 231 138**
4F13 2C190 AA	**0 265 007 589**
4F13 2C190 BA	**0 265 007 591**
4F13 2C216 BA	**0 265 007 590**
4L3A 12A699 AA	**0 261 231 183**
4M5G 12K073 AA	**0 232 103 052**
4M5G 12K073 AA	**0 232 103 053**
4M51 9F479 AA	**0 261 230 119**
4M51 9F479 AA	**0 261 230 120**
4N11 12B579 AA	**0 280 218 137**
4N11 12B579 AA	**0 280 218 138**
4S4G 9F472 AA	**0 261 230 122**
4S4G 9F472 AA	**0 261 230 123**
4S4G 9F472 AA	**0 261 230 180**
4S4G 9F479 AA	**0 261 230 122**
4S4G 9F479 AA	**0 261 230 123**
4S4G 9F479 AA	**0 261 230 180**
4S4G 9F479 AB	**0 261 230 122**
4S4G 9F479 AB	**0 261 230 123**
4S4G 9F479 AB	**0 261 230 180**
4S4G 9F479 AC	**0 261 230 180**
4S4G 9F479 AC	**0 261 230 181**
4S7T 14B296 AA	**0 265 005 617**
4S7T 14B296 AA	**0 265 005 639**
4 041 998	**0 265 006 541**
4 041 999	**0 265 006 542**
4 042 001	**0 265 006 458**
4 042 002	**0 265 004 460**
4042004	**0 265 006 461**
4 053 304	**0 265 006 464**
4 053 305	**0 265 006 465**
4 095 197	**0 265 006 686**
4 099 156	**0 265 006 458**
4 099 157	**0 265 006 460**
4 109 876	**0 265 006 687**
4 131 399	**0 265 006 541**
4 131 400	**0 265 006 687**
4 446 245	**0 265 006 458**
4 476 762	**0 261 231 183**
4 490 313	**0 261 230 093**
4 522 490	**0 265 006 811**
4 522 491	**0 265 006 812**
4 533 632	**0 265 006 814**
4 533 633	**0 265 006 813**
4 537 234	**0 265 006 815**
4 537 235	**0 265 006 816**
4 537 236	**0 265 006 817**
4 537 237	**0 265 006 818**
4 537 240	**0 265 006 784**
4 540 494	**0 265 006 458**
4 577 323	**0 265 006 817**
4 583 026	**0 265 006 818**
5M5T 17D547 JRA	**1 397 212 110**
5M5T 17D547 JRB	**1 397 212 110**
5 167 503	**0 281 002 104**
6C11 2B372 AA	**0 265 007 816**
6C11 2B372 AB	**0 265 007 816**
6C11 2B372 BB	**0 265 007 818**
6C11 2B372 BC	**0 265 007 818**
6C11 2B372 BD	**0 265 007 818**
6C11 2B372 CB	**0 265 007 817**
6C11 2B372 CC	**0 265 007 817**
6C11 2B372 CD	**0 265 007 817**
6C11 3C190 AA	**0 265 005 626**
6C11 3C190 AB	**0 265 005 626**
6C11 3C190 AB	**0 265 005 690**
6C11 9F479 AA	**0 261 230 131**
6C11 9F479 AA	**0 261 230 132**
6C11 9F479 AB	**0 261 230 225**
6G9N 12B676 AA	**0 261 230 105**
6G9N 12B676 AA	**0 261 230 106**
6G9N 17D547 AA	**1 397 212 104**
6G9N 17D547 AB	**1 397 212 104**
6G9N 17D547 AC	**1 397 212 103**
6G9N 17D547 AC	**1 397 212 104**
6G9N 17D547 AD	**1 397 212 103**
6G9N 9G760 AA	**0 280 218 134**
6M5Y 9F479 AA	**0 261 230 090**
6M5Y 9F479 AA	**0 261 230 091**
6X43 14B296 AA	**0 265 005 653**
6X71 9F479 AA	**0 261 230 171**
6X71 9F479 AA	**0 261 230 172**
6 118 548	**0 438 120 069**
6 127 294	**0 280 200 044**
6 127 295	**0 280 202 063**
6 127 295	**0 986 280 031**
6 136 431	**0 261 220 001**
6 140 070	**0 280 230 113**
6 140 071	**0 280 230 109**
6 140 460	**0 438 120 199**
6 142 551	**0 280 200 047**
6 142 551	**0 986 280 056**
6 142 552	**0 986 280 056**
6 152 883	**0 261 231 001**
6 152 883	**0 261 231 006**
6 153 146	**0 280 130 050**
6 156 847	**F 026 TX2 066**
6 156 847	**0 438 121 055**
6 158 434	**0 335 530 033**
6 160 234	**0 280 202 094**
6 169 571	**0 261 231 006**
6 173 066	**0 280 230 116**
6 177 822	**0 280 230 117**
618 2129	**0 280 230 118**
7 045 374	**0 204 154 021**
7 045 374	**0 204 154 032**
7 045 375	**0 204 154 023**
7 701 966	**0 265 006 482**
78GG 13K082 CA	**0 335 530 024**
8A0 143 71Y	**0 204 154 035**
8A0 243 71Y	**0 204 154 036**
8A6T 17D547 AA	**1 397 212 142**
8C11 3C190 AA	**0 265 005 722**
8X23 14B296 AB	**0 265 005 704**
80TF 9C968 CA	**0 438 120 069**
80TF 9P916 AA	**0 438 120 069**
81AB 9L463 BA	**0 335 530 024**
81DB 15K235 RA	**0 332 204 101**
82AB 9L463 BA	**0 335 530 027**
83AB 12B528 AB	**0 280 230 113**
83BB 12B528 AB	**0 280 230 109**
83DA 12B529 AA	**0 280 202 048**
83SF 9P916 AA	**0 438 120 199**
84DA 9H535 AA	**0 280 202 077**
84DA 9H535 AA	**0 986 280 023**
85BB 9L463 AA	**0 335 530 033**
85GB 12B529 AA	**0 280 200 044**
85GB 12B529 BA	**0 280 202 063**
85GB 12B529 BA	**0 986 280 031**
86AB 12A648 AA	**0 280 130 050**
86AB 12A697 AA	**0 261 220 001**
86AB 12B528 AA	**0 280 230 116**
86GB 12B529 AA	**0 280 200 047**
86GB 12B529 AA	**0 986 280 056**
86SF 12A648 AA	**0 280 130 050**
86SF 12A699 AA	**0 261 231 001**
86SF 12A699 AB	**0 261 231 006**
86SF 9P916 AA	**F 026 TX2 066**
86SF 9P916 AA	**0 438 121 055**
87BB 12B528 AA	**0 280 230 117**
87GB 12B529 AA	**0 280 202 094**
88BB 12B528 BA	**0 280 230 118**
88GB 12B529 AA	**0 281 002 029**
88GB 6C315 AA	**0 281 002 030**
88GB 9B989 AA	**0 132 009 305**
88GB 9F479 AA	**0 281 002 018**
90SF 12A697 AA	**0 280 130 060**
92SX 12B528 AA	**0 280 230 119**
92TF 12K073 AB	**0 232 102 005**
93BB 2B372 AH	**0 204 154 019**
93BB 2B372 AH	**0 204 154 030**
93BB 2B372 BF	**0 204 154 021**
93BB 2B372 BF	**0 204 154 032**
93BB 2B372 CF	**0 204 154 022**
93BB 2B372 DF	**0 204 154 023**
94DA 19E642 AA	**9 141 064 423**
95VW 12A697 CA	**0 280 130 073**
95VW 12A697 CA	**0 280 130 078**
95VW 12B529 BB	**0 280 217 121**
95VW 12B529 BB	**0 280 217 122**
95VW 12B529 BB	**0 281 002 757**
95VW 12B529 BB	**0 986 280 202**
95VW 12B529 BC	**0 280 217 121**
95VW 12B529 BC	**0 281 002 757**
95VW 12B529 BC	**0 281 002 758**
95VW 12B529 BC	**0 986 280 202**
95VW 12B529 DA	**0 280 217 504**
95VW 12B529 DA	**0 280 217 505**
95VW 12B529 DB	**0 280 217 512**
95VW 12B573 AA	**0 261 230 007**
95VW 12B573 AA	**0 261 230 008**
95VW 12B573 AA	**0 261 230 037**
95VW 9B949 DA	**0 205 001 024**
95VW 9B949 DB	**0 205 001 032**
95VW 9B949 EA	**0 205 001 032**
95VW 9B949 EA	**0 205 001 041**
95VW 9B949 EB	**0 205 001 044**

F

95VW 9P986 BA	**0 232 103 019**
96BG 2B372 AA	**0 204 154 019**
96BG 2B372 AA	**0 204 154 030**
96BG 2B372 BA	**0 204 154 021**
96BG 2B372 BA	**0 204 154 032**
96BG 2B372 CA	**0 204 154 022**
96DA 2C204 AA	**0 265 006 230**
97BB 2C285 AB	**0 204 154 038**
97BG 2B372 AA	**0 204 154 030**
97BG 2B372 AA	**0 204 154 035**
97BG 2B372 BA	**0 204 154 036**
97BG 2B372 CA	**0 204 154 031**
97BG 2B372 EA	**0 204 154 039**
97BX 13K236 BA	**0 263 003 015**
97JF 9F593 BA	**0 280 122 005**
97VW 9B949 BA	**0 205 001 031**
97VW 9B949 BB	**0 281 002 226**
98VW 12B529 BA	**0 280 217 117**
98VW 12B529 BA	**0 280 217 118**
98VW 9P791 AA	**0 280 101 001**
98VW 9P791 AA	**0 280 101 002**
98VW 9P971 AA	**0 280 101 001**
98VW 9P971 AA	**0 280 101 002**
988F 12A699 BB	**0 261 231 124**
988F 12A699 BC	**0 261 231 124**

GMC (GENERAL MOTORS CORP.)

1 017 8691	**0 265 003 090**
1 017 8692	**0 265 003 089**
1 020 4740	**0 265 001 379**
1 033 5962	**0 263 003 275**
1 033 5963	**0 263 003 260**
1 041 5656	**0 265 005 410**
1 041 5656	**0 265 005 411**
1 043 7635	**0 265 005 223**
1 256 6778	**0 280 130 122**
1 256 6845	**0 261 231 174**
1 256 6846	**0 280 218 114**
1 256 6846	**0 280 218 115**
1 256 8929	**0 261 230 030**
1 256 8929	**0 261 230 075**
1 257 1081	**0 280 750 136**
1 257 4130	**0 280 750 163**
1 257 5467	**0 261 230 101**
1 258 9447	**0 261 545 019**
1 259 0194	**0 261 231 182**
1 259 0991	**0 261 210 274**
1 259 0991	**0 261 210 290**
1 261 3030	**0 261 210 290**
1 261 4935	**0 261 545 031**
1 350 2779	**0 261 230 162**
1 519 7080	**0 265 005 624**
2 199 450	**0 280 218 177**
2 442 0587	**0 261 230 101**
2 574 2495	**0 263 003 279**
2 574 2893	**0 263 003 277**
2 574 5708	**0 263 003 278**
2 574 7658	**0 263 003 261**
2 576 0243	**0 263 003 276**
5 433 329	**0 261 210 263**
5 520 0301	**0 281 002 784**
9 015 435	**0 261 231 209**
9 018 3892	**0 280 130 032**
9 041 0792	**0 280 130 068**
9 041 0792	**0 280 130 107**
9 041 1538	**0 280 130 073**
9 044 8771	**0 261 231 079**
9 049 9610	**0 261 230 009**
9 050 6101	**0 232 103 015**
9 054 0188	**0 281 002 138**
9 058 9767	**0 281 002 285**
9 118 150	**0 281 002 285**
9 204 3128	**0 265 001 325**
9 209 9888	**0 261 210 230**
9 209 9892	**0 261 231 163**
9 317 7371	**0 281 002 510**
9 317 9850	**0 281 002 662**
9 318 0268	**0 281 002 617**
9 318 1944	**0 281 002 716**
9 318 9955	**0 281 002 830**
9 320 3180	**0 261 231 004**
9 321 1367	**9 280 082 000**
9 321 6076	**0 280 217 506**
9 321 6076	**0 280 217 507**
9 321 6076	**0 280 217 525**
9 321 6076	**0 280 217 526**
9 321 6079	**0 261 210 083**
9 321 6451	**0 232 103 006**
9 323 2333	**9 280 082 001**
9 323 2413	**0 261 210 128**
9 323 2415	**0 261 230 013**
9 323 6338	**0 261 210 138**
9 324 3251	**0 261 210 150**
9 325 9413	**0 261 230 022**
9 326 1954	**0 261 231 046**
9 326 2063	**F 000 DV0 101**
9 326 8054	**F 000 DV0 100**
9 331 0500	**0 232 103 067**
9 336 3456	**F 000 DV0 105**
9 336 8719	**F 000 DV0 101**
9 336 8720	**F 000 DV0 102**

HOLDEN

VS 194 59	**0 280 212 015**
VS 194 62	**0 280 120 326**
12 566 845	**0 261 231 174**
12 566 846	**0 280 218 115**
12 566 847	**0 232 103 047**
12 566 848	**0 261 210 247**
12 582 232	**0 261 230 112**
12 582 652	**0 261 210 247**
12 598 948	**0 261 545 011**
21 994 504	**0 280 218 177**
90 287 309	**0 265 001 206**
90 346 045	**0 265 001 233**
90 346 046	**0 265 001 232**
90 399 364	**0 280 202 213**
90 410 792	**0 280 130 107**
90 423 088	**0 280 130 039**
90 451 441	**0 261 210 030**
90 490 185	**0 280 130 093**
90 510 152	**0 280 213 024**
90 510 154	**0 280 217 106**
90 510 156	**0 280 217 503**
90 510 281	**0 261 231 006**
90 510 884	**0 265 003 070**
90 530 439	**0 280 122 014**
90 541 502	**0 280 122 014**
90 541 520	**0 280 130 093**
90 541 591	**0 280 217 519**
92 017 805	**0 280 130 026**
92 017 809	**0 280 202 052**
92 017 810	**0 280 120 307**
92 023 996	**0 280 202 074**
92 024 661	**0 280 212 008**
92 024 661	**0 986 280 104**
92 043 129	**0 265 001 331**
92 045 770	**0 265 001 356**
92 045 771	**0 265 001 344**
92 050 125	**0 265 006 227**
92 050 126	**0 265 006 228**
92 050 127	**0 265 006 229**
92 061 896	**9 430 060 020**
92 062 198	**9 430 060 022**
92 062 490	**0 261 210 128**
92 605 959	**0 265 006 810**
92 606 805	**0 265 006 810**

HONDA

1640A PWE G000	**0 280 750 141**
1640A PWE G01	**0 280 750 141**
16400 PDD X00	**0 280 218 012**
16400 PLZ E01	**0 281 002 482**
16400 PLZ E011 M5	**0 281 002 482**
16400 PWE G00	**0 280 750 141**
16400 P5T G00	**0 281 002 120**
17815 S37G0	**0 281 002 370**
17815 S37 G00	**0 205 001 028**
30530 PWE G01	**0 261 231 120**
37500 RBD E010	**0 281 002 659**
37500 RBD E010 M5	**0 281 002 659**
37830 PDD X00	**0 281 002 389**
37830PDFE01	**0 261 230 020**
37830PWEG01	**0 261 230 099**
37830 RBD E011 M4	**0 281 002 680**
37830 RBD E012 M4	**0 281 002 680**
37830 RBD E013 M4	**0 281 002 680**
37840 PDF E01	**0 232 103 022**
37840 PDF E010	**0 232 103 023**
37840 RBDA E010	**0 281 002 659**
37841 RBD E010	**0 281 002 406**
37841 RBD E010 M4	**0 281 002 406**
37841 RSR E010 M4	**0 281 002 906**
37841 RSRZ E010 M4	**0 281 002 906**
37870 PDF E00	**0 280 130 107**
37870 PDF E01	**0 280 130 107**
37870 P5T G00	**0 280 130 026**
37870 RBDA E010	**0 281 002 659**
37870 RBD E011	**0 281 002 209**
37870 RBD E011 M4	**0 281 002 209**
37880 PDF E00	**0 280 130 073**
37880 PDF E01	**0 280 130 073**
37880 PDF E11	**0 280 130 092**
37880 P5T G00	**0 280 130 039**
37970 PFT E01	**0 281 002 370**
37970 PLZ E00	**0 281 002 577**
37970 PLZ G00	**0 281 002 578**
37971 PLZ E000	**0 281 002 484**
37971 PLZ E01	**0 281 002 484**
37971 PLZ E010	**0 281 002 484**
37971 PLZ E011	**0 281 002 484**
37971 PLZ E012	**0 281 002 484**
37971 PLZ E012 M6	**0 281 002 484**
37980 RBDA E000	**0 281 002 658**
39960 SMG 0031	**0 265 005 649**
39960 STK A010 M1	**0 265 005 683**
57450 S74 E00	**0 265 006 259**
57455 S74 E00	**0 265 006 258**
57470 S74 E00	**0 265 006 268**
57475 S74 E00	**0 265 006 267**
78420 P5T G00	**0 281 002 121**

HYUNDAI

M28164 3A001	**0 281 002 798**
M28164 3A001	**0 281 002 799**
M39250-2B000	**0 261 231 190**
28100 35400	**0 280 218 029**
28100 35400	**0 280 218 030**
28100 39000	**0 280 218 029**
28100 39450	**0 280 218 090**
28100 39450	**0 280 218 091**

H

◀ HYUNDAI

28100 39500	**0 280 218 160**
28100 39500	**0 280 218 161**
28164 22051	**0 280 217 102**
28164 22060	**0 280 217 102**
28164 22110	**0 280 212 024**
28164 22110	**0 986 280 123**
28164 22610	**0 280 218 027**
28164 22610	**0 280 218 028**
28164 23010	**0 280 217 116**
28164 23200	**0 280 217 116**
28164 26700	**0 280 218 126**
28164 26700	**0 280 218 127**
28164 27050	**0 281 002 669**
28164 27050	**0 281 002 670**
28164 27500	**0 281 002 528**
28164 27500	**0 281 002 529**
28164 38080	**0 280 218 020**
28164 38080	**0 280 218 021**
28164 38200	**0 280 218 111**
28164 38200	**0 280 218 112**
28164 38210	**0 280 218 111**
28164 4A000	**0 281 002 554**
28164 4A000	**0 281 002 555**
31402 27010	**0 281 002 732**
32705 17050	**0 281 002 543**
32705 17050	**0 281 002 544**
32705 17950	**0 281 002 547**
32705 17950	**0 281 002 548**
32705 26000	**0 281 002 446**
32705 26010	**0 281 002 556**
32705 26010	**0 281 002 557**
32710 25810	**0 281 002 545**
32710 25810	**0 281 002 546**
32710 25830	**0 281 002 546**
35170 22001	**0 280 122 001**
35170 22010	**0 280 122 001**
35170 22600	**0 280 122 014**
35190 27000	**0 281 002 470**
39180 22001	**0 261 210 083**
39180 22030	**0 261 210 099**
39180 22040	**0 261 210 099**
39220 21310	**0 280 130 062**
39220 22000	**0 280 130 026**
39250 22003	**0 261 231 091**
39330 26300	**0 261 230 013**
39350 22031	**0 232 103 004**
95640 M3200	**0 265 005 142**

ISUZU

8 9434 3307 0	**9 461 614 499**
8 9440 3289 0	**9 461 611 810**
8 9440 3289 1	**9 461 611 810**
8 9712 3879 0	**9 411 612 924**
8 97164 324 0	**0 265 005 048**
8 97226 992 0	**0 281 002 486**
8 97227 219 0	**0 281 002 209**
8 97240 057 0	**0 281 002 516**
8 97241 083 0	**0 280 218 079**
8 97306 560 1	**0 281 002 406**
8 97361 397 0	**0 280 218 146**
8 97376 977 0	**0 281 002 717**
8 97378 846 0	**0 281 002 486**

IVECO

1056458	**0 206 001 001**
1304579	**0 331 100 023**
1367644	**0 261 231 046**
2831362	**0 281 002 472**
3230182500	**0 281 002 472**
41200631	**0 205 001 203**
42056458	**0 206 001 001**
42056583	**0 206 001 002**
42056583	**0 206 001 014**
42056585	**0 206 001 001**
42100525	**0 265 050 010**
42100525	**0 265 050 108**
42105225	**0 265 050 010**
42534892	**0 206 001 013**
42541069	**2 427 233 004**
4383066	**0 332 015 011**
4393598	**0 280 120 215**
4393601	**0 280 130 023**
4430298	**0 332 514 121**
4843498	**0 263 300 908**
4890189	**0 281 002 410**
4890190	**0 281 002 411**
4893924	**0 281 002 316**
4897224	**0 281 002 471**
4897242	**0 281 002 629**
4897501	**0 281 002 398**
500306772	**0 261 210 126**
500306957	**0 281 002 232**
500334956	**0 281 002 453**
500342090	**0 265 004 025**
500343018	**0 281 002 332**
500343090	**0 486 000 079**
500344802	**0 281 002 359**
500344803	**0 281 002 360**
500351377	**0 281 002 514**
500354371	**0 281 002 491**
500360579	**0 281 002 257**
500371540	**0 281 002 512**
500372234	**0 281 002 405**
500374763	**0 281 002 513**
500382599	**0 281 002 209**
500388702	**0 205 001 204**
5010207164	**0 206 001 019**
5010512742	**0 205 001 204**
501073323	**0 281 002 576**
504005575	**0 281 002 509**
504007426	**0 265 004 025**
504014314	**0 281 002 515**
504026069	**0 281 002 565**
504036803	**0 281 002 602**
504048261	**0 281 002 667**
504049164	**0 281 002 630**
504051082	**0 281 002 184**
504052598	**0 281 002 634**
50405298	**0 281 002 631**
504053982	**0 281 002 472**
504061734	**0 281 002 632**
504061734	**0 281 002 692**
504061735	**0 281 002 633**
504064370	**0 261 230 042**
504073323	**0 281 002 576**
504074171	**0 280 218 084**
504088431	**0 281 002 437**
504088732	**0 281 002 534**
504096645	**0 281 002 315**
504107853	**0 265 005 489**
504107856	**0 265 005 241**
504116724	**0 281 002 825**
504123163	**0 281 002 755**
504129943	**0 281 002 778**
504136035	**0 281 002 764**
504152959	**0 281 002 706**
504229208	**0 281 002 788**
504245257	**0 281 002 845**
504247741	**0 281 002 903**
5162472	**0 261 210 036**
5163536	**0 281 002 104**
5893108	**0 280 202 602**
5893108	**0 986 280 019**
5893599	**0 280 200 602**
5894034	**0 280 202 601**
5894034	**0 986 280 076**
5920385	**0 280 202 023**
5920385	**0 986 280 017**
5920388	**0 280 200 024**
5920388	**0 986 280 075**
5946923	**0 280 230 006**
5968080	**0 280 202 059**
5968080	**0 986 280 044**
5968082	**0 280 202 060**
5968082	**0 986 280 046**
5972332	**0 280 130 026**
5991955	**0 280 120 311**
5991956	**0 280 120 312**
5997041	**0 280 101 001**
60191922	**0 205 001 204**
69191922	**0 205 001 204**
7168821	**0 265 050 002**
73503657	**0 281 002 437**
7540622	**0 280 120 314**
7546795	**0 280 200 045**
7555126	**0 280 202 102**
7555126	**0 986 280 054**
7555128	**0 280 200 051**
7597692	**0 280 120 323**
7612317	**0 280 202 114**
7612317	**0 986 280 080**
7612319	**0 280 202 115**
7612320	**0 280 213 006**
7612320	**0 986 280 115**
7616269	**0 261 210 029**
7628059	**0 280 230 009**
7629856	**0 280 101 003**
7630317	**0 265 001 215**
7647004	**0 280 130 032**
7648065	**0 280 213 025**
7648065	**0 986 280 114**
76691230	**0 261 231 007**
7669143	**0 280 130 066**
7686033	**0 280 202 060**
7686033	**0 986 280 046**
7686599	**0 280 130 060**
7693640	**0 280 202 103**
7706073	**0 280 202 128**
7706577	**0 280 120 328**
7706578	**0 280 120 314**
7706579	**0 280 120 307**
7706580	**0 280 120 300**
7706581	**0 280 120 331**
7706582	**0 280 120 323**
7706584	**0 280 120 312**
7706585	**0 280 120 311**
7709815	**0 232 102 004**
7712078	**0 265 001 338**
7718934	**0 265 001 337**
7718935	**0 265 001 336**
7724097	**0 205 001 010**
7731633	**0 261 210 098**
7738223	**0 280 130 055**
7739430	**0 261 210 093**
7739431	**0 232 101 018**
7750754	**0 280 230 018**
7756924	**0 261 210 103**
7756925	**0 261 210 102**
7765599	**0 261 231 102**
7766248	**0 265 006 140**
7766249	**0 265 006 139**
7766251	**0 281 002 102**
7766252	**0 261 210 104**
77773440	**0 232 101 026**
7779229	**0 280 122 005**
7788905	**0 281 002 108**
7790917	**0 261 210 119**

H

7798691	**0 261 210 114**
77990320	**0 261 210 118**
7799033	**0 261 210 115**
8010000554	**0 206 001 016**
8024221	**0 280 217 503**
8024223	**0 261 210 113**
8024224	**0 232 103 009**
8024226	**0 280 130 073**
8025562	**0 280 217 813**
8025562	**0 280 217 817**
8029510	**0 280 122 001**
8038558	**0 280 217 817**
80891268	**0 281 002 667**
82434700	**0 265 005 017**
82434700	**0 265 005 030**
93159374	**0 281 002 471**
93190723	**0 281 002 056**
98412656	**0 281 002 046**
98412657	**0 281 002 011**
98420607	**0 281 002 023**
98420742	**0 205 001 200**
98424639	**0 281 002 087**
98424793	**0 280 130 026**
9842482	**0 281 002 089**
98432254	**0 265 050 026**
98432255	**0 265 050 012**
98432255	**0 265 050 025**
98432255	**0 265 050 030**
98432255	**0 265 050 129**
98439687	**0 205 001 201**
98439687	**0 280 217 503**
98480585	**0 205 001 202**
98496568	**0 281 002 227**
99450797	**0 281 002 165**
99451024	**0 281 002 166**
99455420	**0 281 002 170**
99455421	**0 281 002 205**
99455422	**0 261 210 113**
99460474	**0 281 002 260**
99465103	**0 265 050 108**
99465103	**0 265 050 147**
99465104	**0 265 050 129**
99476427	**0 265 050 152**
99645104	**0 265 050 129**

JAGUAR

C2S 17482	**0 265 007 087**
C2S 17482	**0 265 007 879**
C2S 17728	**0 265 007 404**
C2S 17729	**0 265 007 417**
C2S 20882	**0 265 007 404**
C2S 20883	**0 265 007 417**
C2S 2340	**0 265 007 087**
C2S 2341	**0 265 007 404**
C2S 2342	**0 265 007 417**
C2S 43216	**0 265 007 879**
C2S 4696	**0 265 005 414**
C2S 4701	**0 265 005 236**
C 43031	**0 280 120 046**
DAC 4737	**0 280 130 055**
DAC 7253	**0 265 001 270**
DAC 7254	**0 265 001 269**
DAC 7255	**0 265 001 272**
DAC 7277	**0 265 001 271**
DAC 8519	**0 261 210 001**
DBC 1546	**0 265 001 094**
DBC 1547	**0 265 001 096**
DBC 1557	**0 265 001 095**
DBC 2144	**0 261 210 003**
DBC 3647	**0 265 001 096**
DBC 5981	**0 265 005 014**
DBC 5981	**0 265 005 031**
EAC 1849	**0 280 203 006**
EAC 1849	**0 986 280 022**
EAC 5606	**0 280 213 001**
EAC 5713	**0 280 130 032**
EAC 9811	**0 280 130 061**
RKC 3634	**0 280 202 016**
TKC 5083	**0 332 514 121**
UKC 2525	**0 280 130 023**
ULC 1763	**0 280 120 211**
ULC 3117	**0 280 120 301**
XW4H 17D547 AC	**1 397 212 003**
XW4T 17D547 AC	**1 397 212 003**
YW4T 17D547 AA	**1 397 212 003**
1S7T 14B296 AC	**0 265 005 236**
1S7T 14B296 AD	**0 265 005 236**
1S7T 2B372 AB	**0 265 007 087**
1S7T 3F818 AC	**0 265 005 414**
1S7T 3F818 AD	**0 265 005 414**
1X43 2B372 AB	**0 265 007 404**
1X43 2B372 AE	**0 265 007 404**
1X43 2B372 BB	**0 265 007 417**
1X43 2B372 BE	**0 265 007 417**
6X43 14B296 AA	**0 265 005 653**
73171 A	**0 280 203 005**
73171 A	**0 986 280 047**
8X23 14B296 AB	**0 265 005 704**
8X23 14B296 AB	**0 265 005 707**

KARMANN

300648	**0 261 210 145**
300648	**0 261 210 146**
303146	**0 265 005 618**
303146	**0 265 007 618**
303147	**0 265 005 620**
303147	**0 265 007 620**
303147	**0 265 007 853**
304084	**0 265 006 825**
304085	**0 265 006 827**
304086	**0 265 006 823**
313754	**0 261 210 147**
313760	**0 261 210 178**
318349	**0 261 210 190**
410091	**0 261 210 065**
410200	**0 261 210 154**
415678	**0 281 002 727**
415678	**0 281 002 762**
417217	**0 280 218 174**
434670	**0 280 218 191**
437003	**0 280 218 181**
437818	**0 280 218 174**
442218	**0 281 002 823**
525428	**0 280 217 114**

KIA

KK387 43 70X	**0 265 006 297**
KK387 43 71Y	**0 265 006 299**
KK387 43 72Y	**0 265 006 298**
KK387 43 73X	**0 265 006 296**
K2A1 18 891	**0 261 210 154**
OK 53C 416 00	**0 281 002 540**
OK 53C 416 00	**0 281 002 541**
OK0AA 132 10	**0 280 218 092**
OK0AA 13 210	**0 280 218 093**
OK01A 18 211	**0 261 230 004**
OK01C 18 211	**0 261 230 015**
OK01C 18 921	**0 261 210 065**
OK01C 18 921	**0 261 231 046**
OK011 13 210B	**0 280 217 105**
OK011 18 911	**0 280 122 001**
OK04G 18 891	**0 261 210 154**
OK2A5 18 891	**0 261 210 162**
OK2B2 18 891	**0 261 210 185**
OK2B4 18 891	**0 261 210 186**
OK2NC 13 210	**0 280 218 086**
OK737 18 840	**0 280 130 026**
OK9A0 18 891	**0 261 210 104**
OK9A2 13 210	**0 280 217 116**
OK9A2-18-911	**0 280 122 012**
OK9A4-18-911	**0 280 122 013**
OK934-18-131	**0 356 914 224**
OK934-18-891	**0 261 210 065**
OK937-13-210	**0 280 202 125**
OK937-18-911	**0 280 120 316**
OK95A 43 701	**0 265 006 352**
OK95A 43 701A	**0 265 006 352**
OK95A 43 711A	**0 265 006 353**
OK95A 43 731	**0 265 006 351**
OK95A 43 731A	**0 265 006 351**
OK99D 43 430	**0 265 005 012**
28100 39450	**0 280 218 090**
28164 38 080	**0 280 218 106**
28164 38 080	**0 280 218 107**
28164 38210	**0 280 218 111**
28164 4A000	**0 281 002 554**
39350 2B010	**0 232 103 074**
39350 2B010	**0 232 103 075**
96000 4D 000	**1 397 212 079**
96000 4D 100	**1 397 212 079**
96000 4D 100	**1 397 212 087**

KIA MOTORS SLOVAKIA

28164 2A401	**0 281 002 724**
28164 27800	**0 281 002 721**
28164 27900	**0 281 002 601**
39300 2A400	**0 281 002 901**
39300 2A400	**0 281 002 902**
39300 27400	**0 281 002 902**
39300 27400	**0 281 002 904**
39300 27400	**0 281 002 905**

LANCIA

1307433080	**0 204 154 020**
1307438080	**0 204 154 027**
1315352080	**0 204 154 044**
1315353080	**0 204 154 045**
1320327080	**0 265 006 427**
1320328080	**0 265 006 406**
1320329080	**0 265 006 405**
2335911	**0 265 007 079**
3547833	**0 280 217 005**
42357800	**0 280 202 018**
4339372	**0 332 014 151**
4383066	**0 332 015 011**
4393598	**0 280 120 215**
4393601	**0 280 130 023**
4420994	**0 332 514 105**
4421251	**0 280 202 017**
4429201	**0 280 202 019**
4429207	**0 280 200 024**
4429207	**0 280 200 034**
4429207	**0 986 280 075**
4430292	**0 280 202 012**
4430294	**0 280 120 300**
4430298	**0 332 514 121**
4430298	**0 332 514 127**
46125769	**0 280 130 026**
46130395	**0 280 120 302**
46132195	**0 438 121 066**
46137823	**0 280 120 315**

L

◀ LANCIA

46401855	**0 265 005 030**
46401856	**0 265 005 030**
46401856	**0 265 005 031**
46404401	**0 265 006 210**
46404402	**0 265 006 211**
46406454	**0 261 210 117**
46407008	**0 280 217 111**
46411135	**0 261 210 129**
46411427	**0 261 210 127**
46411675	**0 281 002 144**
46416748	**0 280 217 514**
46419399	**0 261 210 130**
464211118	**0 265 006 212**
46421112	**0 265 006 238**
46421118	**0 265 003 074**
46421118	**0 265 006 212**
46421122	**0 265 006 138**
46422412	**0 265 006 197**
46427958	**0 265 006 262**
46432103	**0 281 002 213**
46433052	**0 280 130 039**
46433053	**0 281 002 122**
46433053	**0 281 002 137**
46433054	**0 261 230 009**
46434529	**0 265 006 164**
4643453	**0 265 006 163**
46434532	**0 265 006 166**
46437264	**0 281 002 214**
46441787	**0 281 002 160**
46442040	**0 204 120 946**
46444280	**0 280 752 005**
46444287	**0 280 217 531**
464457881	**0 265 006 347**
46446873	**0 281 002 159**
46446873	**0 281 002 214**
46447503	**0 280 218 019**
46447503	**0 986 280 236**
46450545	**0 265 006 325**
46456661	**0 265 006 163**
46456796	**0 205 001 010**
46457537	**0 265 006 164**
46457881	**0 265 006 347**
46460544	**0 265 006 364**
46460545	**0 265 006 365**
46463384	**0 204 120 987**
464649280	**0 280 217 102**
46466175	**0 205 003 052**
46467348	**0 265 006 124**
46468682	**0 281 002 137**
46468682	**0 281 002 215**
46469784	**0 265 006 249**
46469867	**0 261 231 131**
46469917	**0 280 218 001**
46469917	**0 986 280 234**
46472180	**0 281 002 203**
46472687	**0 261 210 163**
46473033	**0 265 006 540**
46473049	**0 265 006 539**
46474583	**0 261 210 161**
46474585	**0 261 230 035**
46475007	**0 280 750 013**
46477973	**0 261 210 167**
46478160	**0 280 752 004**
46481638	**0 281 002 210**
46481639	**0 281 002 214**
46481640	**0 281 002 213**
46512475	**0 204 127 122**
46512475	**0 281 002 203**
46519886	**0 265 007 039**
46519916	**0 265 007 036**
46519917	**0 265 007 037**
46520005	**0 265 007 038**
46522739	**0 232 101 037**
46522957	**0 204 127 379**
46522958	**0 204 127 353**
46525288	**0 261 231 144**
46530202	**0 265 007 043**
46530204	**0 265 007 045**
46531418	**0 265 007 072**
46531419	**0 265 007 070**
46532105	**0 204 127 412**
46533308	**0 280 218 004**
46533308	**0 986 280 235**
46533518	**0 261 230 030**
46539830	**0 265 007 034**
46539831	**0 265 007 035**
46539832	**0 265 007 032**
46539833	**0 265 007 033**
46540022	**0 265 007 050**
46540023	**0 265 007 049**
46540024	**0 265 007 055**
46540025	**0 265 007 054**
46541253	**0 280 218 019**
46541253	**0 986 280 236**
46542976	**0 281 002 260**
46542976	**0 281 002 405**
46544765	**0 265 007 075**
46544766	**0 265 007 076**
46545467	**0 265 007 051**
46545468	**0 265 007 053**
46545469	**0 265 007 052**
46546935	**0 265 007 044**
46547231	**0 265 007 024**
46547232	**0 265 007 025**
46547233	**0 265 007 026**
46547234	**0 265 007 027**
46550482	**0 204 127 413**
46550582	**0 204 127 413**
46553045	**0 261 230 030**
46559804	**0 281 002 309**
46559804	**0 986 284 113**
46736164	**0 281 002 380**
46736962	**0 204 127 463**
46737767	**0 265 007 063**
46737768	**0 265 007 064**
46737769	**0 265 007 065**
46737770	**0 265 007 066**
46750234	**0 204 127 480**
46752064	**0 265 007 072**
46761337	**0 265 007 098**
46761338	**0 265 007 099**
46770138	**0 265 007 093**
46770139	**0 265 007 091**
467831830	**0 265 007 102**
467831840	**0 265 007 103**
46798368	**0 232 103 048**
46806128	**0 280 002 474**
46823093	**0 265 007 486**
46823094	**0 265 007 487**
46823095	**0 265 007 488**
46838209	**0 265 007 126**
50011475	**0 265 006 164**
50011475	**0 265 006 537**
50011476	**0 265 006 163**
50011476	**0 265 006 538**
50093165	**0 265 001 336**
51493180	**0 265 006 325**
55189517	**0 261 210 114**
5893108	**0 280 202 602**
5893108	**0 986 280 019**
5893599	**0 280 200 602**
5894034	**0 280 202 601**
5894034	**0 986 280 076**
5920385	**0 280 202 023**
5920385	**0 986 280 017**
5920388	**0 280 200 024**
5920388	**0 986 280 075**
5929385	**0 280 202 023**
5929385	**0 986 280 017**
5945040	**0 280 202 038**
5946923	**0 280 230 006**
5968080	**0 280 202 059**
5968080	**0 986 280 044**
59680802	**0 280 202 059**
59680802	**0 986 280 044**
5968082	**0 280 202 060**
5968082	**0 986 280 046**
5972332	**0 280 130 026**
5991955	**0 280 120 311**
5991956	**0 280 120 312**
5997041	**0 280 101 001**
5999235	**0 280 230 114**
60500571	**0 280 202 204**
60500571	**0 280 202 211**
60500571	**0 986 280 055**
60500571	**0 986 280 091**
60507061	**0 332 204 101**
6050825	**0 265 001 074**
60508251	**0 265 001 073**
60511751	**0 265 001 156**
60512672	**0 280 120 300**
60512698	**0 261 231 006**
60513205	**0 280 130 026**
60513206	**0 280 202 201**
60513206	**0 986 280 069**
60513208	**0 261 210 036**
60513336	**0 280 202 202**
60513336	**0 280 202 210**
60513336	**0 986 280 063**
60513337	**0 280 120 315**
60513747	**0 280 120 435**
60513882	**0 280 203 026**
60513882	**0 986 280 042**
605138820	**0 280 203 026**
605138820	**0 986 280 042**
60518135	**0 280 101 001**
60518377	**0 261 211 003**
60518694	**0 261 210 001**
60518695	**0 261 230 001**
60522010	**0 280 202 013**
60522875	**0 280 120 304**
60522876	**0 280 230 001**
60523383	**0 280 130 023**
60523386	**0 280 202 010**
60523390	**0 332 514 127**
60534263	**0 261 231 006**
60534264	**0 261 211 004**
60534312	**0 280 130 032**
60534313	**0 280 202 058**
60534316	**0 280 230 009**
60534706	**0 280 202 078**
60534838	**0 280 202 105**
60534959	**0 280 202 108**
60534959	**0 986 280 067**
60535033	**0 280 202 113**
60537835	**0 280 202 206**
60537835	**0 986 280 065**
60545849	**0 265 001 250**
6054585	**0 265 001 251**
60547113	**0 280 202 205**
60548743	**0 261 231 007**
60550042	**0 280 203 035**
60555613	**0 261 220 001**
60555613	**0 261 220 002**
60557363	**0 265 003 061**
60557409	**0 265 003 062**
60558015	**0 265 001 268**
60559269	**0 265 003 066**
60559406	**0 265 001 267**
60560715	**0 261 210 047**

L

60565464	**0 265 003 101**
60565479	**0 265 003 102**
60565479	**0 265 006 118**
60565836	**0 356 914 224**
60565837	**0 280 203 034**
60569060	**0 261 210 096**
60569704	**0 280 202 208**
60569704	**0 280 202 213**
60569704	**0 986 280 024**
60569704	**0 986 280 025**
60572382	**0 280 202 207**
60573739	**0 261 210 090**
60574615	**0 280 130 039**
60576483	**0 265 005 109**
60577321	**0 265 003 096**
60577321	**0 265 006 162**
6057940	**0 280 202 207**
6057940	**0 280 202 212**
6057940	**0 986 280 081**
60579846	**0 280 203 034**
60588375	**0 265 001 355**
60588419	**0 280 217 106**
60589472	**0 280 217 503**
60591616	**0 281 002 085**
60591909	**0 280 130 073**
60592752	**0 261 231 095**
60593506	**0 205 001 009**
6059481	**0 205 001 009**
60595754	**0 261 210 113**
60599278	**0 265 005 110**
60601097	**0 265 006 118**
60601098	**0 265 006 119**
60601099	**0 265 006 120**
6060217	**0 280 203 026**
6060217	**0 986 280 042**
60602177	**0 280 203 026**
60602177	**0 986 280 042**
60605410	**0 232 103 010**
60615270	**0 265 006 162**
60615953	**0 265 006 260**
60615954	**0 265 006 261**
60622632	**0 265 006 325**
60622633	**0 265 006 326**
60628356	**0 281 002 202**
60629558	**0 204 127 126**
60630438	**0 204 127 273**
60630466	**0 204 127 127**
60652012	**0 265 007 016**
60652013	**0 265 007 017**
60652016	**0 265 007 018**
60652439	**0 280 750 012**
60652443	**0 280 750 011**
60652776	**0 265 007 021**
60652777	**0 265 007 022**
60652874	**0 265 007 020**
60654314	**0 280 750 012**
60654900	**0 204 127 376**
60656290	**0 265 007 040**
60656291	**0 265 007 041**
60656301	**0 265 007 042**
60659263	**0 265 007 046**
60659264	**0 265 007 047**
60659265	**0 265 007 018**
60659265	**0 265 007 048**
60659531	**0 204 127 456**
60660039	**1 397 212 011**
60660054	**0 280 750 053**
60662165	**0 204 127 377**
60662823	**0 261 231 152**
60663029	**0 280 218 036**
60663029	**0 986 280 237**
60684944	**1 397 212 011**
60700045	**0 280 202 045**
60722873	**0 280 202 027**
60722873	**0 986 280 078**
60755045	**0 280 200 601**
60755045	**0 986 280 061**
60755046	**0 280 200 002**
60800132	**0 280 230 006**
60800163	**0 280 202 060**
60800163	**0 986 280 046**
60800167	**0 280 130 026**
60800522	**0 280 130 032**
60805107	**0 280 202 060**
60805107	**0 986 280 046**
60805373	**0 280 101 001**
60806252	**0 265 003 074**
60806252	**0 265 006 212**
60806254	**0 265 003 063**
60806254	**0 265 006 197**
60807526	**0 265 001 301**
60808142	**0 280 130 026**
60808397	**0 265 003 075**
60808904	**0 261 210 096**
60808986	**0 261 210 090**
6080915	**0 280 202 212**
6080915	**0 986 280 081**
60809658	**0 280 202 211**
60809658	**0 986 280 091**
60810394	**0 265 005 030**
60810394	**0 265 005 031**
60810692	**0 261 210 113**
60810774	**0 265 003 096**
60810774	**0 265 006 162**
60810791	**0 261 231 095**
60810813	**0 280 217 111**
60811021	**0 281 002 085**
60811201	**0 232 101 026**
6081145	**0 280 217 514**
6081220	**0 280 130 055**
6081224	**0 280 130 055**
60812394	**0 265 006 212**
60812395	**0 265 006 162**
60812644	**0 265 006 197**
60813773	**0 265 006 238**
60814769	**0 281 002 214**
60814852	**0 280 218 019**
60814852	**0 986 280 236**
60815022	**0 281 002 202**
60815340	**0 205 003 052**
60815463	**0 204 127 122**
71713685	**F 00C 1G6 969**
71715149	**3 437 010 452**
71788020	**0 986 280 234**
740134603	**0 280 130 032**
75204203	**0 331 101 004**
7540622	**0 280 120 314**
7546795	**0 280 200 046**
7553412	**0 280 202 081**
7555126	**0 280 202 102**
7555126	**0 986 280 054**
7555127	**0 280 202 103**
7555128	**0 280 200 051**
7576067	**0 280 230 009**
7597692	**0 280 120 323**
7612317	**0 280 202 114**
7612317	**0 986 280 080**
7612319	**0 280 202 115**
7612320	**0 280 213 006**
7612320	**0 986 280 115**
7616269	**0 261 210 029**
7628059	**0 280 230 009**
7629856	**0 280 101 003**
7630317	**0 265 001 215**
7630318	**0 265 001 216**
7630319	**0 265 001 217**
7636642	**0 280 120 328**
7640095	**0 280 120 307**
7644804	**0 280 120 307**
7647004	**0 280 130 032**
7647004	**0 280 130 069**
7648065	**0 280 213 025**
7648065	**0 986 280 114**
7648113	**0 280 120 313**
7651951	**0 265 007 082**
7668164	**0 280 202 204**
7668164	**0 280 202 211**
7668164	**0 986 280 055**
7668164	**0 986 280 091**
76691230	**0 261 231 007**
7669143	**0 280 130 066**
7686033	**0 280 202 060**
7686033	**0 986 280 046**
7686599	**0 280 130 060**
7690200	**0 280 200 055**
7693640	**0 280 202 013**
7693640	**0 280 202 103**
7694623	**0 280 120 331**
7706073	**0 280 202 128**
7706577	**0 280 120 328**
7706578	**0 280 120 314**
7706579	**0 280 120 307**
7706580	**0 280 120 300**
77065804	**0 280 120 300**
7706581	**0 280 120 331**
7706582	**0 280 120 323**
77065830	**0 280 120 313**
7706584	**0 280 120 312**
7706585	**0 280 120 311**
7709815	**0 232 102 004**
77118780	**0 280 212 024**
77118780	**0 986 280 123**
7712078	**0 265 001 338**
7717686	**0 280 230 005**
7718934	**0 265 001 337**
7718935	**0 265 001 336**
7721274	**0 281 002 089**
7721274	**0 281 002 093**
7724096	**0 281 002 088**
7724097	**0 205 001 010**
7731633	**0 261 210 098**
7738223	**0 280 130 055**
7739430	**0 261 210 093**
7739431	**0 232 101 018**
7746949	**0 261 210 100**
7750753	**0 280 230 014**
7750754	**0 280 230 018**
7756924	**0 261 210 103**
7756925	**0 261 210 102**
77579230	**0 281 002 087**
7763718	**0 280 217 106**
7763719	**0 280 130 073**
7764102	**0 265 003 109**
7765599	**0 261 231 102**
7766248	**0 265 006 140**
7766249	**0 265 006 139**
7766251	**0 281 002 102**
7766252	**0 261 210 104**
7767750	**0 281 002 185**
7770239	**0 280 130 107**
77773440	**0 232 101 026**
7779229	**0 280 122 005**
77825160	**0 265 001 387**
77872560	**0 261 210 124**
7788905	**0 281 002 108**
7790917	**0 261 210 119**
77942200	**0 265 006 161**
7798691	**0 261 210 114**
77990320	**0 261 210 118**
7799033	**0 261 210 115**

L

◀ LANCIA

82277331	**0 280 100 024**
82277332	**0 280 121 001**
82277333	**0 280 130 006**
82277334	**0 280 130 014**
82277344	**0 332 003 023**
82281564	**0 280 120 031**
82308690	**0 280 120 213**
82348191	**0 280 202 014**
82357799	**0 280 202 015**
82357800	**0 280 202 018**
82365378	**0 332 514 121**
82369630	**0 335 530 023**
82390387	**0 280 202 015**
82401252	**0 265 001 073**
82406063	**0 265 001 072**
82407679	**0 265 001 074**
82434700	**0 265 005 017**
82434700	**0 265 005 030**
8243566	**0 265 001 248**
82435661	**0 265 001 249**
82435662	**0 265 001 246**
82435663	**0 265 001 247**
82442723	**0 265 001 209**
824451370	**0 265 001 210**
82448464	**0 265 001 304**
82450141	**0 265 005 014**
82450141	**0 265 005 031**
82455274	**0 265 001 261**
82458587	**0 265 003 074**
82458587	**0 265 006 212**
82458588	**0 265 003 063**
82458954	**0 265 003 071**
82458954	**0 265 006 262**
82458956	**0 265 003 075**
8246063	**0 265 001 072**
82467204	**0 265 003 075**
82472241	**0 265 001 216**
82472242	**0 265 001 217**
82472243	**0 265 003 063**
82472243	**0 265 006 197**
82485111	**0 265 003 121**
82485174	**0 265 006 160**
82485175	**0 265 006 300**
9009423	**0 331 101 001**
92308690	**0 280 120 213**
9617220680	**0 280 122 003**
9618261580	**0 261 230 012**
9633310080	**0 281 002 283**
9923794	**0 331 101 003**
9927593	**0 331 101 004**
9934319	**0 331 101 008**
9944334	**0 332 014 411**

LEYLAND-DAF

545190001	**0 265 006 832**
545190003	**0 265 006 833**

LOTUS

A116E6059F	**0 280 218 051**
A116E6059F	**0 986 280 231**
A116E6063F	**0 261 230 042**
A116E6066F	**0 261 230 009**

MAGIRUS-DEUTZ

4206 1635	**0 265 050 002**
9841 2656	**0 281 002 046**
9841 2657	**0 281 002 011**
9842 0607	**0 281 002 023**
9842 0742	**0 205 001 200**

MAHINDRA

0315CC0031N	**0 281 002 756**

MAN

N1 01101 8687	**0 206 001 013**
11 99013 0478	**0 261 231 019**
39 15270 909	**0 281 002 217**
51 09413 7001	**0 281 002 421**
51 09413 7002	**0 281 002 421**
51 13105 6003	**0 280 750 094**
51 13105 6005	**0 280 750 129**
51 27120 0005	**0 281 002 105**
51 27120 0006	**0 281 002 106**
51 27120 0008	**0 281 002 270**
51 27120 0009	**0 281 002 271**
51 27120 0013	**0 232 103 006**
51 27120 0014	**0 281 002 426**
51 27120 0015	**0 281 002 427**
51 27120 0017	**0 281 002 599**
51 27120 7037	**0 281 002 315**
51 27120 7038	**0 281 002 662**
51 27421 0077	**0 281 002 046**
51 27421 0078	**0 281 002 011**
51 27421 0079	**0 281 002 023**
51 27421 0102	**0 281 002 109**
51 27421 0113	**0 281 002 232**
51 27421 0128	**0 281 002 233**
51 27421 0142	**0 281 002 418**
51 27421 0178	**0 281 002 534**
51 27421 0182	**0 281 002 631**
51 27421 0198	**0 281 002 655**
51 27421 0213	**0 281 002 011**
51 27421 0216	**0 281 002 655**
51 27421 0229	**0 281 002 706**
51 27421 0230	**0 281 002 706**
51 27421 0236	**0 281 002 706**
51 57421 0229	**0 281 002 706**
81 25920 6067	**0 206 001 020**
81 25920 6068	**0 206 001 015**
81 25920 6069	**0 206 001 011**
81 25920 6072	**0 205 001 206**
81 25920 6076	**0 206 001 017**
81 25970 6012	**0 132 009 309**
81 25970 6017	**0 132 009 312**
81 25970 6017	**0 132 009 321**
81 25970 6021	**0 206 001 005**
81 25970 6022	**0 206 001 003**
81 25970 6034	**0 206 001 008**
81 25970 6040	**0 132 009 321**
81 25970 6067	**0 206 001 020**
81 25970 6072	**0 205 001 206**
81 25970 6076	**0 206 001 017**
81 25970 6079	**0 281 002 350**
81 25970 6095	**0 281 002 587**
81 26212 0002	**0 331 101 002**
81 26212 0003	**0 331 101 001**
81 26212 0008	**0 331 101 004**
81 27120 0018	**0 265 050 002**
81 27120 0025	**0 265 050 012**
81 27120 0027	**0 265 050 010**
81 27120 0028	**0 265 050 015**
81 27120 0031	**0 265 050 034**
81 27120 0035	**0 265 050 108**
81 27120 0036	**0 265 050 129**
81 27120 0037	**0 265 050 140**
81 27120 6060	**0 486 001 003**
81 27120 6061	**0 486 001 004**
81 27120 6067	**0 486 000 052**
81 27120 6068	**0 486 000 053**
81 27120 6070	**0 486 000 047**
81 27120 6071	**0 486 000 045**
81 27120 6072	**0 486 000 046**
81 27120 6073	**0 486 000 044**
81 27120 6075	**0 486 000 048**
81 27120 6076	**0 486 000 050**
81 27120 6077	**0 486 000 049**
81 27120 6078	**0 486 000 051**
81 27421 0202	**0 484 205 006**
90 81616 0366	**0 331 101 002**
90 81616 0367	**0 331 101 001**

MASERATI

112135	**0 261 231 167**
170592	**0 265 006 429**
180045	**0 280 218 084**
180137	**0 281 002 170**
182194	**0 261 210 198**
187739	**0 261 231 166**
187740	**0 261 231 167**
188172	**0 265 005 241**
196819	**0 280 752 285**
206070	**0 265 005 616**
208444	**0 280 218 217**
363802105	**0 265 006 213**

MAZDA

F153 43 7Y1	**0 265 005 254**
GD7E 43 701	**0 265 006 316**
GD7E 43 711	**0 265 006 318**
GD7E 43 721	**0 265 006 319**
GD7E 43 73XD	**0 265 006 317**
GD7E 43 731	**0 265 006 317**
L3K9-18-211	**0 261 230 128**
L3K9-18-211	**0 261 230 129**
L3K9-18-211A	**0 261 230 128**
L3K9-18-211A	**0 261 230 129**
L301-18-211	**0 261 230 122**
L301 18 211	**0 261 230 123**
L301 18 211	**0 261 230 180**
L807-18-211	**0 261 545 006**
L807-18-921	**0 261 231 160**
PN46-13-TS0	**9 461 614 120**
WE01-18-211	**0 281 002 680**
WE01-18-221	**0 281 002 729**
WLBD 18 221	**0 281 002 820**
WLE7-1-3TS0	**9 443 611 749**
0265006313	**0 265 006 313**
4S4G 9F479 AC	**0 261 230 180**
4S4G 9F479 AC	**0 261 230 181**

MERCEDES-BENZ

B6 782 38 02	**0 263 003 013**
Q00031 21V003	**0 261 230 049**
Q00094 93V000	**0 265 005 698**
000 074 00 14	**0 438 120 014**
000 074 01 14	**0 438 120 026**
000 074 02 14	**0 438 120 081**
000 074 03 14	**0 438 120 062**
000 074 03 14	**0 438 120 083**
000 074 04 14	**0 438 120 114**
000 074 05 14	**0 438 120 075**
000 074 06 14	**0 438 120 074**
000 074 07 14	**0 438 120 115**
000 074 08 14	**0 438 120 116**

000 074 09 14	**0 438 120 135**
000 074 10 14	**0 438 120 154**
000 074 11 14	**0 438 120 170**
000 074 12 14	**F 026 TX2 060**
000 074 12 14	**0 438 121 001**
000 074 12 14	**0 986 439 301**
000 074 13 14	**F 026 TX2 052**
000 074 13 14	**0 438 121 009**
000 074 13 14	**0 438 121 010**
000 074 15 14	**0 438 121 022**
000 074 16 14	**0 438 121 019**
000 074 18 14	**0 438 121 020**
000 074 20 14	**0 438 121 033**
000 074 20 14	**0 986 439 333**
000 074 20 14 0080	**0 986 439 333**
000 074 21 14	**0 438 121 043**
000 074 21 14	**0 986 439 343**
000 074 21 14 0080	**0 986 439 343**
000 074 23 14	**F 026 TX2 053**
000 074 23 14	**0 438 121 044**
000 074 24 14	**0 438 121 037**
000 074 24 14	**0 986 439 337**
000 074 25 14	**0 438 121 036**
000 074 27 14	**0 438 121 075**
000 074 28 14	**0 438 121 082**
000 074 28 14	**0 986 439 382**
000 074 28 14 0080	**0 986 439 382**
000 074 29 14	**F 026 TX2 055**
000 074 29 14	**0 438 121 072**
000 074 30 14	**F 026 TX2 057**
000 074 30 14	**0 438 121 080**
000 094 00 48	**0 280 217 100**
000 094 00 48	**0 280 217 101**
000 094 01 48	**0 280 214 004**
000 094 01 48	**0 280 214 005**
000 094 01 48	**0 986 280 121**
000 094 01 48	**0 986 280 134**
000 094 01 48 0080	**0 986 280 121**
000 094 01 48 0080	**0 986 280 134**
000 094 02 48	**0 280 213 015**
000 094 02 48	**0 280 213 016**
000 094 02 48	**0 986 280 126**
000 094 02 48	**0 986 280 129**
000 094 02 48 0080	**0 986 280 126**
000 094 02 48 0080	**0 986 280 129**
000 094 04 48	**0 280 213 018**
000 094 04 48	**0 280 213 019**
000 094 04 48	**0 986 280 125**
000 094 04 48	**0 986 280 136**
000 094 05 48	**0 280 217 500**
000 094 05 48	**0 280 217 501**
000 094 06 48	**0 280 213 018**
000 094 06 48	**0 280 213 019**
000 094 06 48	**0 986 280 125**
000 094 06 48	**0 986 280 136**

000 094 06 48 0080	**0 986 280 125**
000 094 06 48 0080	**0 986 280 136**
000 094 07 48	**0 280 217 807**
000 094 07 48	**0 280 217 808**
000 094 08 48	**0 280 217 509**
000 094 08 48	**0 280 217 510**
000 094 09 48	**0 280 217 114**
000 094 09 48	**0 280 217 115**
000 094 10 48	**0 280 217 517**
000 094 10 48	**0 280 217 518**
000 094 12 48	**0 281 002 152**
000 094 12 48	**0 281 002 153**
000 094 13 48	**0 280 217 523**
000 094 13 48	**0 280 217 524**
000 094 14 48	**0 281 002 384**
000 094 14 48	**0 281 002 385**
000 094 18 48	**0 280 218 080**
000 094 19 48	**0 280 218 081**
000 094 20 48	**0 281 002 585**
000 094 20 48	**0 281 002 586**
000 094 22 48	**0 281 002 656**
000 094 22 48	**0 281 002 657**
000 094 32 48	**0 281 002 896**
000 094 32 48	**0 281 002 897**
000 141 25 25	**0 205 003 007**
000 141 26 25	**0 205 003 009**
000 141 38 25	**0 205 003 006**
000 141 39 25	**0 205 003 008**
000 141 39 25	**0 205 003 019**
000 141 39 25	**0 205 003 020**
000 141 45 25	**0 205 003 012**
000 141 46 25	**0 205 003 014**
000 141 55 25	**0 205 003 012**
000 141 55 25	**0 205 003 021**
000 141 55 25	**0 205 003 022**
000 141 56 25	**0 205 003 014**
000 141 56 25	**0 205 003 023**
000 141 56 25	**0 205 003 024**
000 141 72 25	**0 205 003 006**
000 141 72 25	**0 205 003 017**
000 141 72 25	**0 205 003 018**
000 141 87 25	**0 205 003 017**
000 141 87 25	**0 205 003 018**
000 141 87 25	**0 205 003 027**
000 141 87 25	**0 205 003 028**
000 141 87 25	**0 205 003 034**
000 141 88 25	**0 205 003 019**
000 141 88 25	**0 205 003 020**
000 141 88 25	**0 205 003 029**
000 141 88 25	**0 205 003 030**
000 141 88 25	**0 205 003 036**
000 152 08 10	**0 331 101 001**
000 152 09 10	**0 331 101 002**
000 152 39 10	**0 331 101 004**
000 152 44 10	**0 331 101 003**

000 152 48 10	**0 331 100 023**
000 153 84 28	**0 335 541 001**
000 153 88 20	**0 261 210 022**
000 158 07 19	**0 261 210 156**
000 158 07 19	**0 261 210 157**
000 540 04 17	**0 265 001 203**
000 540 04 17	**0 265 001 240**
000 540 05 17	**0 265 001 201**
000 540 10 17	**0 265 001 239**
000 540 11 17	**0 265 001 240**
000 542 65 18	**0 265 005 200**
000 542 65 18	**0 265 005 201**
000 542 69 18	**0 486 000 016**
000 542 87 19	**0 332 008 002**
000 542 92 14	**0 281 002 024**
000 542 92 14	**0 281 002 028**
000 542 93 14	**0 281 002 034**
000 542 93 14	**0 281 002 035**
000 542 96 14	**0 281 002 077**
000 542 96 14	**0 281 002 078**
000 800 71 75	**0 928 400 068**
000 800 75 75	**0 928 400 086**
000 800 80 75	**0 928 400 095**
000 821 01 63	**0 332 204 101**
000 994 07 01	**0 204 220 153**
000 998 47 01	**0 204 220 153**
001 094 35 03	**0 281 002 273**
001 153 09 28	**0 335 541 002**
001 408 7V 00 1	**0 265 005 303**
001 540 44 17	**0 265 005 219**
001 540 44 17	**0 265 005 220**
001 540 44 17	**0 265 005 246**
001 540 44 17	**0 265 005 258**
001 540 45 17	**0 265 005 230**
001 540 45 17	**0 265 005 231**
001 540 45 17	**0 265 005 246**
001 540 45 17	**0 265 005 258**
001 542 04 18	**0 486 000 001**
001 542 05 18	**0 486 000 002**
001 542 07 18	**0 486 001 001**
001 542 08 18	**0 486 001 002**
001 542 24 17	**0 281 002 011**
001 542 25 18	**0 486 001 001**
001 542 32 19	**0 332 014 151**
001 542 34 18	**0 486 000 001**
001 542 35 18	**0 486 001 001**
001 542 42 18	**0 265 004 011**
001 542 43 18	**0 265 004 012**
001 542 45 18	**0 265 004 013**
001 542 45 18	**0 265 004 015**
001 542 46 18	**0 265 004 014**
001 542 47 19	**0 332 014 453**
001 542 59 18	**0 263 003 013**
001 542 76 18	**0 486 000 034**
001 542 77 18	**0 486 001 013**

001 542 82 18	**0 486 000 035**
001 542 84 18	**0 486 001 014**
001 542 85 18	**0 486 001 015**
001 542 87 17	**0 280 130 009**
001 542 88 17	**0 280 130 006**
001 542 90 18	**0 265 005 219**
001 542 90 18	**0 265 005 220**
001 542 90 18	**0 265 005 246**
001 542 90 18	**0 265 005 258**
001 542 91 17	**0 280 100 006**
001 545 46 18	**0 265 004 016**
001 545 91 32	**0 265 001 008**
002 153 17 28	**0 261 210 009**
002 153 17 28	**0 261 210 010**
002 153 26 28	**0 261 210 007**
002 153 26 28	**0 261 210 008**
002 153 33 28	**0 261 210 014**
002 153 33 28	**0 261 210 015**
002 153 34 28	**0 261 210 020**
002 153 34 28	**0 261 210 021**
002 153 35 28	**0 261 210 022**
002 153 35 28	**0 261 210 023**
002 153 40 28	**0 261 210 025**
002 153 41 28	**0 261 210 026**
002 153 41 28	**0 261 210 027**
002 153 43 28	**0 261 210 016**
002 153 43 28	**0 261 210 017**
002 153 45 28	**0 261 210 018**
002 153 45 28	**0 261 210 019**
002 153 55 28	**0 261 210 033**
002 153 55 28	**0 261 210 034**
002 153 59 28	**0 261 210 037**
002 153 59 28	**0 261 210 038**
002 153 60 28	**0 261 210 039**
002 153 60 28	**0 261 210 040**
002 153 62 28	**0 261 231 009**
002 153 62 28	**0 261 231 010**
002 153 74 28	**0 261 231 024**
002 153 74 28	**0 261 231 025**
002 153 83 28	**0 261 231 028**
002 153 83 28	**0 261 231 029**
002 153 84 28	**0 261 231 026**
002 153 84 28	**0 261 231 027**
002 153 91 28	**0 261 210 049**
002 153 91 28	**0 261 210 050**
002 153 92 28	**0 261 210 051**
002 153 92 28	**0 261 210 052**
002 540 09 17	**0 265 005 303**
002 540 09 17	**0 265 005 307**
002 542 04 18	**0 486 000 043**
002 542 16 17	**0 280 100 012**
002 542 21 17	**0 280 130 014**
002 542 22 17	**0 280 100 025**
002 542 22 18	**0 486 000 084**
002 542 23 18	**0 486 000 020**

M

◀ MERCEDES-BENZ

002 542 24 18	**0 486 001 022**
002 542 28 17	**0 280 100 100**
002 542 29 18	**0 265 004 015**
002 542 30 18	**0 265 004 016**
002 542 32 17	**0 280 100 112**
002 542 33 17	**0 280 100 111**
002 542 37 18	**0 486 001 024**
002 542 66 18	**0 265 005 246**
002 542 66 18	**0 265 005 258**
002 545 02 45	**0 332 204 001**
002 545 19 05	**0 332 015 011**
002 545 80 24	**0 280 120 004**
002 820 55 10	**0 928 400 070**
003 153 01 28	**0 261 210 018**
003 153 01 28	**0 261 210 055**
003 153 01 28	**0 261 210 056**
003 153 08 28	**0 261 210 066**
003 153 08 28	**0 261 210 067**
003 153 13 28	**0 261 210 072**
003 153 13 28	**0 261 210 073**
003 153 14 28	**0 261 210 074**
003 153 14 28	**0 261 210 075**
003 153 15 28	**0 261 210 068**
003 153 15 28	**0 261 210 069**
003 153 16 28	**0 261 210 070**
003 153 16 28	**0 261 210 071**
003 153 23 28	**0 261 210 076**
003 153 23 28	**0 261 210 077**
003 153 24 28	**0 261 210 078**
003 153 24 28	**0 261 210 079**
003 153 27 28	**0 261 210 170**
003 153 27 28	**0 261 210 171**
003 153 33 28	**0 261 231 050**
003 153 33 28	**0 261 231 051**
003 153 34 28	**0 261 231 052**
003 153 34 28	**0 261 231 053**
003 153 35 28	**0 261 231 058**
003 153 35 28	**0 261 231 059**
003 153 36 28	**0 261 231 060**
003 153 36 28	**0 261 231 061**
003 153 46 28	**0 261 231 054**
003 153 46 28	**0 261 231 055**
003 153 47 28	**0 261 231 062**
003 153 47 28	**0 261 231 063**
003 153 48 28	**0 261 231 056**
003 153 48 28	**0 261 231 057**
003 153 50 28	**0 261 210 085**
003 153 50 28	**0 261 210 086**
003 153 55 28	**0 261 210 087**
003 153 55 28	**0 261 210 088**
003 153 60 28	**0 261 231 080**
003 153 60 28	**0 261 231 081**
003 153 61 28	**0 261 231 082**
003 153 61 28	**0 261 231 083**
003 153 66 28	**0 261 231 084**
003 153 66 28	**0 261 231 085**
003 153 67 28	**0 261 231 086**
003 153 67 28	**0 261 231 087**
003 153 74 28	**0 281 002 123**
003 153 74 28	**0 281 002 124**
003 153 75 28	**0 261 210 122**
003 153 75 28	**0 261 210 123**
003 153 78 28	**0 261 231 100**
003 153 78 28	**0 261 231 101**
003 153 80 28	**0 261 231 098**
003 153 80 28	**0 261 231 099**
003 153 81 28	**0 281 002 100**
003 153 83 28	**0 232 103 012**
003 153 83 28	**0 232 103 013**
003 153 83 28	**0 232 103 037**
003 153 86 28	**0 261 231 110**
003 153 86 28	**0 261 231 111**
003 153 95 28	**0 261 210 141**
003 153 95 28	**0 261 210 142**
003 542 03 18	**0 265 005 267**
003 542 03 18	**0 265 005 298**
003 542 05 18	**0 265 005 303**
003 542 78 17	**0 280 100 122**
003 545 11 24	**0 280 120 018**
003 545 49 24	**0 280 120 035**
003 545 61 24	**0 280 120 015**
003 545 66 24	**0 280 120 029**
004 094 34 48	**0 281 002 978**
004 094 34 48	**0 281 002 979**
004 153 06 28	**0 281 002 281**
004 153 06 28	**0 281 002 282**
004 153 07 28	**0 232 103 022**
004 153 07 28	**0 232 103 023**
004 153 07 28	**0 232 103 027**
004 153 07 28	**0 232 103 028**
004 153 07 28	**0 232 103 037**
004 153 09 28	**0 261 231 133**
004 153 09 28	**0 261 231 134**
004 153 15 28	**0 281 002 238**
004 153 15 28	**0 281 002 239**
004 153 18 28	**0 281 002 244**
004 153 18 28	**0 281 002 245**
004 153 22 28	**0 261 220 001**
004 153 22 28	**0 261 220 002**
0041533128	**0 281 002 498**
004 153 62 28	**0 261 231 128**
004 153 67 28	**0 281 002 504**
004 153 67 28	**0 281 002 505**
004 153 69 28	**0 232 103 037**
004 153 69 28	**0 232 103 038**
004 153 70 28	**0 261 002 469**
004 153 70 28	**0 281 002 468**
004 153 70 28	**0 281 002 469**
004 153 73 28	**0 281 002 489**
004 153 73 28	**0 281 002 490**
004 153 75 28	**0 281 002 499**
004 153 82 28	**0 281 002 456**
004 153 90 28	**0 261 231 188**
004 153 90 28	**0 261 231 189**
004 153 95 28	**0 261 230 104**
004 153 96 28	**0 232 103 050**
004 153 96 28	**0 232 103 051**
004 153 97 28	**0 232 103 051**
004 545 43 24	**0 280 120 044**
004 545 44 24	**0 280 120 045**
005 153 56 28	**0 261 230 154**
005 153 56 28	**0 261 545 012**
005 153 56 28	**0 261 545 013**
005 153 58 28	**0 281 002 700**
005 153 58 28	**0 281 002 703**
005 153 61 28	**0 261 230 118**
005 153 74 28	**0 281 002 726**
005 153 74 28	**0 281 002 727**
005 153 77 28	**0 281 002 761**
005 153 77 28	**0 281 002 762**
005 542 21 18	**0 265 005 752**
005 542 26 18	**0 265 005 735**
005 542 26 18	**0 265 007 735**
005 542 27 18	**0 265 005 752**
005 542 27 18	**0 265 005 753**
006 153 07 28	**0 232 103 085**
006 153 13 28	**0 261 230 139**
006 153 13 28	**0 261 230 140**
006 153 14 28	**0 261 230 141**
006 153 14 28	**0 261 230 142**
006 153 15 28	**0 261 230 143**
006 153 15 28	**0 261 230 144**
006 153 16 28	**0 261 230 153**
006 153 16 28	**0 261 230 154**
006 153 17 28	**0 232 103 070**
006 153 17 28	**0 232 103 071**
006 153 18 28	**0 232 103 072**
006 153 18 28	**0 232 103 073**
006 153 24 28	**0 232 103 066**
006 153 33 28	**0 281 002 672**
006 153 42 28	**0 281 002 892**
006 153 42 28	**0 281 002 893**
006 153 47 28	**0 261 230 118**
006 153 49 28	**0 281 002 822**
006 153 49 28	**0 281 002 823**
006 153 53 28	**0 281 002 884**
006 153 53 28	**0 281 002 885**
006 153 54 28	**0 281 002 888**
006 153 54 28	**0 281 002 889**
006 153 55 28	**0 281 002 890**
006 153 55 28	**0 281 002 891**
006 153 56 28	**0 281 002 886**
006 153 56 28	**0 281 002 887**
006 153 61 28	**0 232 103 077**
006 153 61 28	**0 232 103 078**
006 153 61 28	**0 232 103 086**
006 153 65 28	**0 281 002 842**
006 153 65 28	**0 281 002 843**
006 153 71 28	**0 232 103 086**
006 153 71 28	**0 232 103 087**
006 153 72 28	**0 281 002 882**
006 153 72 28	**0 281 002 883**
006 153 77 28	**0 232 103 081**
006 153 77 28	**0 232 103 082**
006 153 78 28	**0 281 002 926**
006 153 78 28	**0 281 002 927**
006 153 95 28	**0 281 002 925**
006 542 02 17	**0 280 130 030**
006 542 34 17	**0 280 130 035**
006 542 34 17	**0 280 130 036**
006 542 50 17	**0 280 101 003**
006 542 50 17	**0 280 101 004**
006 542 56 17	**0 280 130 042**
006 542 56 17	**0 280 130 043**
006 542 77 17	**0 280 130 044**
006 542 77 17	**0 280 130 045**
007 153 05 28	**0 261 230 227**
007 153 06 28	**0 281 002 967**
007 153 06 28	**0 281 002 968**
007 153 07 28	**0 232 103 085**
007 153 31 28	**0 261 230 229**
007 542 02 17	**0 281 002 025**
007 542 16 17	**0 132 009 304**
007 542 21 17	**0 280 130 047**
007 542 21 17	**0 280 130 048**
007 542 24 17	**0 281 002 011**
007 542 27 17	**0 281 002 023**
008 152 00 10	**0 331 101 003**
009 542 31 17	**0 281 002 058**
009 542 31 17	**0 281 002 059**
009 542 62 17	**0 265 002 039**
009 542 62 17	**0 265 002 040**
009 542 62 17	**0 265 002 075**
009 542 62 17	**0 265 002 076**
009 542 62 17	**0 265 002 229**
009 542 62 17	**0 265 002 230**
009 542 62 17	**0 265 005 016**
009 542 62 17	**0 265 005 039**
009 542 62 17	**0 265 005 040**
009 542 88 17	**0 205 001 008**
010 542 49 17	**0 265 005 018**
010 542 51 17	**0 265 005 102**
010 542 51 17	**0 265 005 106**
010 542 51 17	**0 265 005 107**
010 542 51 17	**0 265 005 150**
011 542 46 17	**0 265 005 106**
011 542 46 17	**0 265 005 107**
011 542 46 17	**0 265 005 150**
011 542 71 17	**0 265 005 044**
011 542 86 17	**0 205 001 029**

011 542 86 17	**0 205 001 030**
011 542 87 17	**0 205 001 302**
011 542 87 17	**0 205 001 303**
012 542 04 17	**0 265 005 113**
012 542 04 17	**0 265 005 114**
012 542 04 17	**0 265 005 151**
012 542 43 17	**0 265 005 040**
013 542 14 17	**0 265 006 515**
013 542 31 17	**0 206 001 018**
013 542 55 17	**0 265 006 619**
026 520 21 09	**0 265 005 300**
050 331 09 AA	**0 281 002 502**
050 331 09 AA	**0 281 002 503**
050 333 20 AA	**0 281 002 779**
050 333 20 AA	**0 281 002 780**
102 074 03 14	**0 438 121 009**
102 074 03 14	**0 438 121 010**
104 141 00 25	**0 205 003 042**
104 141 00 25	**0 205 003 043**
107 540 00 17	**0 265 001 012**
107 540 00 17	**0 265 001 013**
107 540 02 17	**0 265 001 128**
107 540 02 17	**0 265 001 129**
107 540 03 17	**0 265 001 126**
107 540 03 17	**0 265 001 127**
107 540 04 17	**0 265 002 019**
107 540 04 17	**0 265 002 255**
107 540 04 17	**0 265 002 256**
111 098 01 09	**0 280 750 045**
111 141 00 25	**0 205 003 044**
111 141 00 25	**0 205 003 045**
111 141 01 25	**0 280 750 021**
111 141 02 25	**0 280 750 067**
111 141 02 25	**0 280 750 068**
111 141 03 25	**0 280 750 074**
111 141 03 25	**0 280 750 075**
112 094 00 48	**0 280 217 515**
112 094 00 48	**0 280 217 516**
112 094 01 48	**0 280 218 082**
112 141 00 25	**0 205 003 046**
112 141 00 25	**0 205 003 047**
113 094 00 48	**0 280 217 810**
113 094 00 48	**0 280 217 811**
113 094 01 48	**0 280 218 083**
113 141 00 25	**0 205 003 048**
113 141 00 25	**0 205 003 049**
116 540 06 17	**0 265 002 001**
116 540 06 17	**0 265 002 002**
116 540 08 17	**0 265 001 001**
116 540 08 17	**0 265 001 002**
116 540 09 17	**0 265 001 003**
116 540 09 17	**0 265 001 004**
119 141 00 25	**0 205 003 037**
119 141 00 25	**0 205 003 038**
120 141 00 25	**0 205 003 039**
120 141 00 25	**0 205 003 040**
124 540 00 17	**0 265 002 010**
124 540 01 17	**0 265 001 111**
124 540 01 17	**0 265 001 112**
124 540 02 17	**0 265 001 109**
124 540 02 17	**0 265 001 110**
124 540 02 17	**0 265 001 281**
124 540 02 17	**0 265 001 282**
124 540 04 17	**0 265 002 021**
124 540 04 17	**0 265 002 207**
124 540 04 17	**0 265 002 208**
124 540 06 17	**0 265 001 154**
124 540 06 17	**0 265 001 155**
124 540 07 17	**0 265 001 152**
124 540 07 17	**0 265 001 153**
124 540 10 17	**0 265 002 045**
124 540 11 17	**0 265 002 047**
124 540 12 17	**0 265 002 049**
124 540 14 17	**0 265 001 299**
124 540 14 17	**0 265 001 300**
124 540 15 17	**0 265 001 297**
124 540 15 17	**0 265 001 298**
124 540 16 17	**0 265 001 283**
124 540 16 17	**0 265 001 284**
124 540 17 17	**0 265 001 281**
124 540 17 17	**0 265 001 282**
124 540 19 17	**0 265 002 079**
124 540 19 17	**0 265 002 080**
124 540 19 17	**0 265 002 207**
124 540 19 17	**0 265 002 208**
124 540 20 17	**0 265 002 081**
124 540 20 17	**0 265 002 082**
124 540 20 17	**0 265 002 209**
124 540 20 17	**0 265 002 210**
124 540 21 17	**0 265 002 085**
124 540 21 17	**0 265 002 086**
124 540 21 17	**0 265 002 205**
124 540 21 17	**0 265 002 206**
124 540 22 17	**0 265 002 083**
124 540 22 17	**0 265 002 084**
124 540 22 17	**0 265 002 203**
124 540 22 17	**0 265 002 204**
124 540 23 17	**0 265 002 109**
124 540 23 17	**0 265 002 110**
124 540 23 17	**0 265 002 237**
124 540 23 17	**0 265 002 238**
124 540 24 17	**0 265 002 107**
124 540 24 17	**0 265 002 108**
124 540 24 17	**0 265 002 235**
124 540 24 17	**0 265 002 236**
124 540 25 17	**0 265 002 115**
124 540 25 17	**0 265 002 116**
124 540 25 17	**0 265 002 243**
124 540 25 17	**0 265 002 244**
124 540 27 17	**0 265 002 117**
124 540 27 17	**0 265 002 118**
124 540 27 17	**0 265 002 245**
124 540 27 17	**0 265 002 246**
124 540 29 17	**0 265 006 127**
124 540 29 17	**0 265 006 128**
124 540 30 17	**0 265 006 125**
124 540 30 17	**0 265 006 126**
124 540 31 17	**0 265 006 110**
124 540 31 17	**0 265 006 111**
124 540 32 17	**0 265 006 108**
124 540 32 17	**0 265 006 109**
124 540 34 17	**0 265 002 131**
124 540 34 17	**0 265 002 132**
124 540 34 17	**0 265 002 253**
124 540 34 17	**0 265 002 254**
124 540 36 17	**0 265 001 399**
124 540 36 17	**0 265 001 400**
124 540 37 17	**0 265 001 397**
124 540 37 17	**0 265 001 398**
124 800 36 75	**0 928 400 237**
124 800 37 75	**0 928 400 238**
126 540 00 17	**0 265 002 004**
126 540 00 17	**0 265 002 005**
126 540 01 17	**0 265 001 032**
126 540 01 17	**0 265 001 033**
126 540 02 17	**0 265 001 020**
126 540 02 17	**0 265 001 030**
126 540 02 17	**0 265 001 031**
126 540 04 09	**0 265 001 009**
126 540 04 17	**0 265 001 016**
126 540 04 17	**0 265 001 017**
126 540 05 09	**0 265 001 011**
126 540 05 17	**0 265 001 018**
126 540 05 17	**0 265 001 019**
126 540 13 17	**0 265 002 012**
126 540 15 17	**0 265 002 014**
126 540 15 17	**0 265 002 015**
126 540 16 17	**0 265 001 015**
126 540 16 17	**0 265 001 021**
126 540 17 17	**0 265 001 014**
126 540 17 17	**0 265 001 020**
126 540 18 17	**0 265 002 030**
126 540 19 17	**0 265 002 028**
126 540 25 17	**0 265 001 279**
126 540 25 17	**0 265 001 280**
126 540 26 17	**0 265 001 277**
126 540 26 17	**0 265 001 278**
126 540 30 17	**0 265 002 089**
126 540 30 17	**0 265 002 090**
126 540 30 17	**0 265 002 259**
126 540 30 17	**0 265 002 260**
126 540 32 17	**0 265 002 087**
126 540 32 17	**0 265 002 088**
126 540 32 17	**0 265 002 257**
126 540 32 17	**0 265 002 258**
129 540 04 17	**0 265 002 035**
129 540 05 17	**0 265 002 033**
129 540 06 17	**0 265 002 037**
129 540 07 17	**0 265 002 032**
129 540 08 17	**0 265 001 223**
129 540 09 17	**0 265 001 221**
129 540 13 17	**0 265 002 069**
129 540 13 17	**0 265 002 223**
129 540 13 17	**0 265 002 224**
129 540 14 17	**0 265 002 067**
129 540 14 17	**0 265 002 221**
129 540 14 17	**0 265 002 222**
129 540 15 17	**0 265 002 051**
129 540 15 17	**0 265 002 052**
129 540 15 17	**0 265 002 201**
129 540 15 17	**0 265 002 202**
129 540 16 17	**0 265 002 053**
129 540 16 17	**0 265 002 054**
129 540 16 17	**0 265 002 213**
129 540 16 17	**0 265 002 214**
129 540 20 17	**0 265 002 113**
129 540 20 17	**0 265 002 114**
129 540 20 17	**0 265 002 241**
129 540 20 17	**0 265 002 242**
129 540 21 17	**0 265 002 111**
129 540 21 17	**0 265 002 112**
129 540 21 17	**0 265 002 239**
129 540 21 17	**0 265 002 240**
129 540 26 17	**0 265 006 131**
129 540 26 17	**0 265 006 132**
129 540 27 17	**0 265 006 129**
129 540 27 17	**0 265 006 130**
129 540 29 17	**0 265 006 185**
129 540 29 17	**0 265 006 186**
129 540 30 17	**0 265 006 183**
129 540 30 17	**0 265 006 184**
129 540 35 17	**0 265 006 279**
129 540 35 17	**0 265 006 280**
129 540 36 17	**0 265 006 291**
129 540 36 17	**0 265 006 292**
129 830 00 72	**1 147 212 064**
130 030 08	**0 265 007 717**
130 030 09	**0 265 007 716**
130 030 19	**0 265 007 715**
130 037 94	**0 265 008 044**
130 037 95	**0 265 008 043**
131 098 00 09	**0 280 750 039**
131 098 00 09	**0 280 750 040**
131 141 00 25	**0 280 750 001**
131 141 00 25	**0 280 750 002**
140 440 07 10	**0 265 001 351**
140 440 07 32	**0 265 001 405**
140 440 07 32	**0 265 001 406**
140 440 08 32	**0 265 001 403**
140 440 08 32	**0 265 001 404**

M

◀ MERCEDES-BENZ

140 440 09 32	**0 265 001 401**
140 440 09 32	**0 265 001 402**
140 540 02 17	**0 265 002 065**
140 540 02 17	**0 265 002 219**
140 540 02 17	**0 265 002 220**
140 540 03 17	**0 265 002 119**
140 540 03 17	**0 265 002 120**
140 540 03 17	**0 265 002 247**
140 540 03 17	**0 265 002 248**
140 540 04 17	**0 265 002 097**
140 540 07 17	**0 265 002 093**
140 540 07 17	**0 265 002 233**
140 540 07 17	**0 265 002 234**
140 540 08 17	**0 265 002 061**
140 540 08 17	**0 265 002 215**
140 540 08 17	**0 265 002 216**
140 540 09 17	**0 265 002 101**
140 540 11 17	**0 265 002 063**
140 540 11 17	**0 265 002 217**
140 540 11 17	**0 265 002 218**
140 540 12 09	**0 265 001 295**
140 540 12 09	**0 265 001 296**
140 540 13 09	**0 265 001 293**
140 540 13 09	**0 265 001 294**
140 540 14 09	**0 265 001 307**
140 540 15 09	**0 265 001 347**
140 540 15 09	**0 265 001 348**
140 540 16 09	**0 265 001 345**
140 540 16 09	**0 265 001 349**
140 540 16 09	**0 265 001 350**
140 540 17 09	**0 265 001 349**
140 540 17 09	**0 265 001 350**
140 540 20 17	**0 265 006 181**
140 540 20 17	**0 265 006 182**
140 540 21 17	**0 265 006 179**
140 540 21 17	**0 265 006 180**
140 540 28 17	**0 265 001 409**
140 540 28 17	**0 265 001 410**
140 540 29 17	**0 265 001 407**
140 540 29 17	**0 265 001 408**
140 540 34 17	**0 265 006 275**
140 540 34 17	**0 265 006 276**
140 540 35 17	**0 265 006 273**
140 540 35 17	**0 265 006 274**
156 153 00 28	**0 261 230 137**
156 153 00 28	**0 261 230 138**
157 153 00 28	**0 261 230 099**
157 153 01 28	**0 281 002 437**
168 540 00 17	**0 265 006 369**
168 540 00 17	**0 265 006 370**
168 540 01 17	**0 265 006 367**
168 540 01 17	**0 265 006 368**
168 540 03 17	**0 265 006 371**
168 540 03 17	**0 265 006 372**
169 540 04 17	**0 265 007 477**

169 540 04 17	**0 265 007 478**
169 540 08 17	**0 265 007 479**
169 540 08 17	**0 265 007 480**
169 540 11 17	**0 265 007 840**
169 540 12 17	**0 265 007 841**
169 540 14 17	**0 265 008 064**
169 540 15 17	**0 265 008 065**
201 540 00 17	**0 265 002 008**
201 540 00 17	**0 265 002 009**
201 540 01 17	**0 265 001 046**
201 540 01 17	**0 265 001 051**
201 540 01 17	**0 265 001 128**
201 540 02 17	**0 265 001 044**
201 540 02 17	**0 265 001 049**
201 540 02 17	**0 265 001 114**
201 540 07 17	**0 265 001 051**
201 540 07 17	**0 265 001 052**
201 540 07 17	**0 265 001 117**
201 540 07 17	**0 265 001 128**
201 540 08 17	**0 265 001 049**
201 540 08 17	**0 265 001 050**
201 540 08 17	**0 265 001 114**
201 540 08 17	**0 265 001 115**
201 540 09 17	**0 265 002 023**
201 540 10 17	**0 265 002 025**
201 540 13 17	**0 265 002 039**
201 540 13 17	**0 265 002 040**
201 540 13 17	**0 265 002 075**
201 540 13 17	**0 265 002 076**
201 540 13 17	**0 265 002 229**
201 540 13 17	**0 265 002 230**
201 540 14 17	**0 265 002 041**
201 540 14 17	**0 265 002 231**
201 540 15 17	**0 265 001 287**
201 540 15 17	**0 265 001 288**
201 540 16 17	**0 265 001 285**
201 540 16 17	**0 265 001 286**
201 540 19 17	**0 265 002 073**
201 540 19 17	**0 265 002 074**
201 540 19 17	**0 265 002 227**
201 540 19 17	**0 265 002 228**
201 540 20 17	**0 265 002 071**
201 540 20 17	**0 265 002 072**
201 540 20 17	**0 265 002 225**
201 540 20 17	**0 265 002 226**
201 540 22 17	**0 265 002 075**
201 540 22 17	**0 265 002 076**
201 540 22 17	**0 265 002 229**
201 540 22 17	**0 265 002 230**
201 540 23 17	**0 265 002 077**
201 540 23 17	**0 265 002 078**
201 540 23 17	**0 265 002 231**
201 540 23 17	**0 265 002 232**
202 540 01 17	**0 265 002 121**
202 540 01 17	**0 265 002 122**

202 540 01 17	**0 265 002 211**
202 540 01 17	**0 265 002 212**
202 540 02 17	**0 265 002 123**
202 540 02 17	**0 265 002 124**
202 540 03 17	**0 265 001 359**
202 540 03 17	**0 265 001 360**
202 540 04 17	**0 265 001 357**
202 540 04 17	**0 265 001 358**
202 540 05 17	**0 265 001 369**
202 540 05 17	**0 265 001 370**
202 540 06 17	**0 265 001 367**
202 540 06 17	**0 265 001 368**
202 540 09 17	**0 265 001 391**
202 540 10 17	**0 265 001 389**
202 540 12 17	**0 265 006 191**
202 540 12 17	**0 265 006 192**
202 540 13 17	**0 265 006 171**
202 540 13 17	**0 265 006 172**
202 540 15 17	**0 265 006 243**
202 540 15 17	**0 265 006 244**
202 540 16 17	**0 265 006 241**
202 540 16 17	**0 265 006 242**
202 540 17 17	**0 265 006 247**
202 540 17 17	**0 265 006 248**
202 540 18 17	**0 265 006 245**
202 540 18 17	**0 265 006 246**
202 540 20 17	**0 265 006 265**
202 540 20 17	**0 265 006 266**
202 540 21 17	**0 265 006 263**
202 540 21 17	**0 265 006 264**
202 540 34 17	**0 265 006 684**
202 540 34 17	**0 265 006 685**
202 540 71 10	**0 265 006 173**
202 540 71 10	**0 265 006 174**
202 540 78 08	**0 265 002 125**
202 540 78 08	**0 265 002 126**
202 540 78 08	**0 265 002 251**
202 540 78 08	**0 265 002 252**
202 540 79 08	**0 265 002 123**
202 540 79 08	**0 265 002 249**
202 540 79 08	**0 265 002 250**
202 830 04 72	**1 147 212 072**
207 540 00 17	**0 265 008 137**
207 540 03 17	**0 265 008 139**
210 540 06 17	**0 265 006 177**
210 540 06 17	**0 265 006 178**
210 540 07 17	**0 265 006 193**
210 540 07 17	**0 265 006 194**
210 540 10 17	**0 265 006 239**
210 540 10 17	**0 265 006 240**
210 540 48 10	**0 265 006 357**
210 540 48 10	**0 265 006 358**
210 540 49 10	**0 265 006 355**
210 540 49 10	**0 265 006 356**
210 540 90 08	**0 265 006 189**

210 540 90 08	**0 265 006 190**
210 540 91 08	**0 265 006 187**
210 540 91 08	**0 265 006 188**
210 540 92 08	**0 265 006 175**
210 540 92 08	**0 265 006 176**
211 540 00 17	**0 265 007 429**
211 540 00 17	**0 265 007 433**
211 540 04 17	**0 265 007 430**
211 540 04 17	**0 265 007 434**
211 540 12 17	**0 265 007 496**
211 540 12 17	**0 265 007 500**
211 540 13 17	**0 265 007 495**
211 540 13 17	**0 265 007 499**
211 540 18 17	**0 265 007 697**
211 540 18 17	**0 265 007 698**
211 540 18 17	**0 265 007 720**
211 540 19 17	**0 265 007 699**
211 540 19 17	**0 265 007 700**
211 540 19 17	**0 265 007 721**
211 540 23 17	**0 265 007 720**
211 540 23 17	**0 265 007 745**
211 540 24 17	**0 265 007 721**
211 540 24 17	**0 265 007 746**
211 540 29 17	**0 265 008 061**
211 540 29 17	**0 265 008 097**
211 540 30 17	**0 265 008 062**
211 540 30 17	**0 265 008 098**
211 540 31 17	**0 265 008 063**
211 821 19 58	**0 265 004 011**
212 540 01 17	**0 265 008 046**
212 540 02 17	**0 265 008 045**
212 540 03 17	**0 265 008 047**
212 540 05 17	**0 265 008 048**
212 540 21 17	**0 265 008 047**
216 542 00 18	**0 265 005 623**
216 542 00 18	**0 265 005 642**
216 542 01 18	**0 265 005 640**
220 540 01 17	**0 265 007 001**
220 540 01 17	**0 265 007 002**
220 540 02 17	**0 265 007 001**
220 540 02 17	**0 265 007 002**
220 540 04 17	**0 265 007 007**
220 540 04 17	**0 265 007 008**
220 540 05 17	**0 265 007 005**
220 540 05 17	**0 265 007 006**
220 540 09 17	**0 265 007 105**
220 540 10 17	**0 265 007 104**
220 540 14 17	**0 265 007 107**
220 540 14 17	**0 265 007 108**
220 540 17 17	**0 265 007 120**
220 540 17 17	**0 265 007 121**
220 540 18 17	**0 265 007 122**
220 540 18 17	**0 265 007 123**
220 540 20 17	**0 265 007 127**
220 540 20 17	**0 265 007 128**

M

230 540 01 17	**0 265 007 081**
230 540 01 17	**0 265 007 584**
230 540 04 17	**0 265 007 080**
230 540 04 17	**0 265 007 497**
230 540 04 17	**0 265 007 501**
230 540 07 17	**0 265 007 497**
230 540 07 17	**0 265 007 501**
230 540 08 17	**0 265 007 498**
230 540 08 17	**0 265 007 502**
230 540 08 17	**0 265 007 584**
230 540 08 17	**0 265 007 585**
230 540 10 17	**0 265 007 584**
230 540 10 17	**0 265 007 585**
230 540 11 17	**0 265 007 634**
230 540 11 17	**0 265 007 635**
230 540 12 17	**0 265 007 693**
230 540 12 17	**0 265 007 694**
230 540 12 17	**0 265 007 695**
230 540 12 17	**0 265 007 719**
230 540 13 17	**0 265 007 693**
230 540 13 17	**0 265 007 695**
230 540 13 17	**0 265 007 696**
230 540 13 17	**0 265 007 718**
230 540 15 17	**0 265 007 718**
230 540 15 17	**0 265 007 743**
230 540 16 17	**0 265 007 719**
230 540 16 17	**0 265 007 744**
230 540 19 17	**0 265 008 057**
230 540 20 17	**0 265 008 058**
240 540 03 17	**0 265 007 435**
240 540 05 17	**0 265 007 437**
240 540 05 17	**0 265 007 467**
240 540 08 17	**0 265 007 701**
240 540 09 17	**0 265 007 703**
240 540 10 17	**0 265 008 059**
240 540 11 17	**0 265 008 060**
266 141 05 25	**0 280 750 175**
266 141 05 25	**0 280 750 176**
271 141 00 25	**0 280 750 076**
271 141 00 25	**0 280 750 077**
273 094 02 48	**0 280 218 140**
273 094 03 48	**0 280 218 139**
273 094 03 48	**0 280 218 140**
273 094 05 48	**0 280 218 147**
273 094 05 48	**0 280 218 148**
273 094 05 48	**0 280 218 190**
273 094 06 48	**0 280 218 173**
273 094 06 48	**0 280 218 174**
273 094 06 48	**0 280 218 190**
273 094 07 48	**0 280 218 174**
273 094 07 48	**0 280 218 180**
273 094 07 48	**0 280 218 181**
273 094 07 48	**0 280 218 191**
273 094 08 48	**0 280 218 180**
273 094 08 48	**0 280 218 181**

273 094 08 48	**0 280 218 191**
273 094 09 48	**0 280 218 190**
273 094 09 48	**0 280 218 191**
275 141 02 25	**0 280 750 126**
275 141 05 25	**0 280 750 125**
275 141 06 25	**0 280 750 125**
275 141 06 25	**0 280 750 126**
334 039 51	**0 265 007 717**
334 039 52	**0 265 007 716**
334 039 63	**0 265 007 715**
357 540 13 17	**0 265 050 120**
357 540 14 17	**0 265 050 121**
408 540 00 17	**0 265 002 129**
408 540 00 17	**0 265 002 275**
418 540 00 17	**0 265 002 127**
418 540 00 17	**0 265 002 273**
418 540 01 17	**0 265 002 128**
418 540 01 17	**0 265 002 274**
427 540 00 17	**0 265 002 103**
427 540 00 17	**0 265 002 269**
427 540 01 17	**0 265 002 271**
437 540 00 17	**0 265 002 104**
437 540 00 17	**0 265 002 270**
437 540 01 17	**0 265 002 272**
451 540 00 17	**0 265 007 814**
451 540 01 17	**0 265 007 815**
451 540 02 17	**0 265 007 812**
451 542 00 18	**0 265 005 646**
451 542 00 18	**0 265 005 688**
451 542 01 18	**0 265 005 625**
451 542 01 18	**0 265 005 687**
451 542 07 18	**0 265 005 789**
454 540 02 17	**0 265 005 485**
454 542 03 18	**0 265 007 638**
454 542 04 18	**0 265 005 289**
454 542 04 18	**0 265 005 600**
454 542 05 18	**0 265 007 637**
454 542 06 18	**0 265 007 683**
463 540 01 17	**0 265 001 291**
463 540 02 17	**0 265 001 289**
463 540 02 17	**0 265 001 290**
463 540 03 17	**0 265 002 043**
463 540 03 17	**0 265 002 261**
463 540 19 17	**0 265 008 015**
463 540 20 17	**0 265 007 984**
463 540 21 17	**0 265 007 985**
530 130 09 AA	**0 281 002 501**
602 090 04 66	**0 928 400 285**
638 540 00 17	**0 265 007 422**
638 540 01 17	**0 265 007 455**
638 540 02 17	**0 265 007 456**
638 542 01 17	**0 265 006 196**
638 542 02 17	**0 265 006 214**
638 542 03 17	**0 265 006 195**
638 542 04 17	**0 265 006 215**

638 542 07 17	**0 265 006 515**
639 300 03 04	**0 281 002 560**
639 300 03 04	**0 281 002 561**
639 300 04 04	**0 281 002 562**
639 300 04 04	**0 281 002 563**
639 300 06 04	**0 281 002 561**
639 300 07 04	**0 281 002 563**
639 540 00 17	**0 265 007 422**
639 540 01 17	**0 265 007 455**
639 540 02 17	**0 265 007 456**
639 540 04 17	**0 265 007 422**
639 540 08 17	**0 265 007 643**
639 540 09 17	**0 265 007 644**
639 540 10 17	**0 265 007 715**
639 540 12 17	**0 265 007 717**
639 540 13 17	**0 265 007 716**
639 540 22 17	**0 265 008 044**
639 540 23 17	**0 265 008 043**
639 542 00 18	**0 265 005 429**
642 094 00 48	**0 281 002 653**
642 094 00 48	**0 281 002 654**
642 094 01 48	**0 281 002 695**
642 094 01 48	**0 281 002 696**
643 540 20 17	**0 265 007 984**
645 540 05 17	**0 265 050 101**
646 094 00 48	**0 281 002 535**
646 094 00 48	**0 281 002 536**
650 540 01 17	**0 265 050 102**
650 540 02 17	**0 265 050 103**
650 540 03 17	**0 265 050 122**
650 540 04 17	**0 265 050 123**
650 540 06 17	**0 486 000 003**
650 540 07 17	**0 486 000 004**
664 542 77 17	**0 206 001 012**
677 540 10 17	**0 265 050 115**
677 540 11 17	**0 265 050 116**
677 540 12 17	**0 265 050 117**
677 540 13 17	**0 265 050 118**
677 540 14 17	**0 265 050 119**
7 787 023 000	**0 206 001 010**
7 787 023 000	**0 206 001 011**
7 787 072 000 0	**0 205 001 206**
7 787 076 000	**0 206 001 012**
901 300 04 04	**0 281 002 334**
901 300 04 04	**0 281 002 335**
901 300 05 04	**0 281 002 336**
901 300 05 04	**0 281 002 337**
901 542 05 18	**0 265 004 019**
901 542 05 18	**0 265 004 022**
901 542 08 17	**0 265 004 008**
901 542 08 17	**0 265 004 009**
901 542 10 17	**0 265 004 007**
901 542 11 17	**0 265 004 010**
901 542 13 18	**0 265 004 028**
901 542 14 18	**0 265 004 029**

901 542 15 18	**0 265 005 453**
901 542 17 17	**0 265 004 009**
906 300 03 04	**0 280 755 025**
906 300 04 04	**0 280 755 022**
906 300 04 04	**0 280 755 023**
906 540 01 17	**0 265 007 659**
906 540 02 17	**0 265 007 660**
906 540 03 17	**0 265 007 657**
906 540 04 17	**0 265 007 979**
906 540 11 17	**0 265 007 661**
906 540 12 17	**0 265 007 662**
906 540 19 17	**0 265 007 880**
906 540 20 17	**0 265 007 881**
906 542 05 18	**0 265 005 628**

MITSUBISHI

AW311467	**0 280 130 026**
CW720411	**0 265 006 421**
CW720412	**0 265 006 422**
CW720413	**0 265 006 423**
CW721199	**0 265 006 447**
CW721200	**0 265 006 448**
CW722401	**0 265 006 445**
CW722402	**0 265 006 446**
CW 725334	**0 265 006 520**
CW 725335	**0 265 006 521**
CW 725336	**0 265 006 522**
CW 725337	**0 265 006 523**
CW 726419	**0 265 006 604**
CW 726420	**0 265 006 603**
CW743157	**F 01G 09F 000**
CW743160	**F 01G 09F 001**
MA 826089	**0 265 006 514**
MB 928934 V	**0 265 006 390**
MB 950343	**0 265 006 224**
MB 950344	**0 265 006 223**
MB 950345	**0 265 006 328**
MB 950346	**0 265 006 225**
ME 016373	**9 411 610 560**
ME 222926	**0 281 002 692**
ME 225366	**0 281 002 807**
ME 226971	**0 281 002 928**
MN 101778	**0 280 755 021**
MN 102857	**0 265 007 637**
MN 116462	**0 265 007 683**
MN 116637	**0 265 007 674**
MN 116638	**0 265 007 675**
MN 116639	**0 265 007 676**
MN 116640	**0 265 007 677**
MN 163706	**0 261 231 187**
MN 180306	**0 261 230 125**
MN 180306	**0 261 230 126**
MN 180307	**0 232 103 060**
MN 180307	**0 232 103 061**

◀ MITSUBISHI

MN 180314	**0 261 231 191**
MN 180314	**0 261 231 192**
MN 180316	**0 281 002 704**
MN 195775	**0 261 230 118**
MR 205395	**0 265 006 327**
MR 205396	**0 265 006 294**
MR 205397	**0 265 006 329**
MR 205398	**0 265 006 360**
MR 249983	**0 265 006 513**
MR 370932	**0 265 006 511**
MR 370933	**0 265 006 512**
MR407654	**0 265 006 552**
MR407655	**0 265 006 553**
MR 47523	**0 265 006 617**
MR 475233 V	**0 265 006 617**
MR 475234 V	**0 265 006 618**
MR 47524	**0 265 006 618**
MR569093	**0 265 006 720**
MR569094	**0 265 006 721**
MR 587456	**0 265 005 485**
MR 955037	**0 265 007 638**
MR 955352	**0 265 005 289**
MR 955352	**0 265 005 600**
MR 977019	**F 005 X00 000**
MR 985032	**0 261 230 118**
1525A005	**0 280 218 162**
1525A005	**0 280 218 163**
4670 A228	**0 265 005 625**
530621300	**0 265 006 698**
8651 A026	**0 265 005 504**

NISSAN

16119 1F700	**0 280 750 051**
16119 1F700	**0 280 750 052**
16119 1F710	**0 280 750 117**
16119 1F710	**0 280 750 118**
16119 25750 2	**0 280 750 051**
16119 25750 2	**0 280 750 052**
18002 JK60C	**0 280 755 093**
18002 1BA0A	**0 280 755 109**
18002 2X800	**0 281 002 590**
18002 2X800	**0 281 002 591**
18919 2J620	**0 281 002 250**
18919 5M300	**0 281 002 425**
18919 7F400	**0 206 001 022**
18919 7F401	**0 206 001 022**
22365 BN701	**0 281 002 552**
22365 9X700	**0 281 002 456**
22620 1F700	**0 280 122 014**
22630 V9400	**0 280 130 057**
22630 V9400	**0 280 130 063**
22630 0M200	**0 280 130 081**
22630 0M200	**0 280 130 082**
22630 37950	**0 280 130 064**
22630 37950	**0 280 130 065**
22630 70J00	**0 280 130 064**
22630 70J00	**0 280 130 065**
22630 99B00	**0 280 130 072**
22630 99B10	**0 280 130 071**
22630 99B10	**0 280 130 072**
22680 AU300	**0 280 218 117**
22680 AU300	**0 280 218 118**
22680 F425	**0 281 002 208**
22680 J5002	**0 280 212 012**
22680 J7000	**0 280 212 012**
22680 J7000	**0 986 280 128**
22680 J7100	**0 280 202 111**
22680 V5002	**0 280 212 012**
22680 V5002	**0 986 280 128**
22680 07F00	**0 280 202 111**
22680 36550	**0 280 218 005**
22680 36550	**0 280 218 006**
22680 36550	**0 986 280 232**
22680 40F00	**0 280 212 012**
22680 5M000	**0 280 218 152**
22680 5M020	**0 280 218 171**
22680 5U400	**0 280 218 094**
22680 5U400	**0 280 218 095**
22680 6N210	**0 280 218 096**
22680 6N210	**0 280 218 097**
22680 69T60	**0 281 002 466**
22680 69T60	**0 281 002 467**
22680 69T61	**0 281 002 663**
22680 69T61	**0 281 002 664**
22680 7F400	**0 281 002 176**
22680 7F400	**0 281 002 207**
22680 7F400	**0 281 002 208**
22680 7F400	**0 986 284 012**
22680 7F405	**0 281 002 595**
22680 7F406	**0 281 002 596**
22680 7F406	**0 281 002 597**
22680 7F411	**0 281 002 440**
22680 7F411	**0 281 002 441**
22680 7F425	**0 281 002 207**
22680 7F425	**0 281 002 208**
226807J500	**0 280 218 025**
22680 7J500	**0 280 218 026**
22680 7J500	**0 280 218 096**
22680 7J500	**0 280 218 097**
22680 7J600	**0 280 218 005**
22680 7J600	**0 280 218 006**
22680 7J600	**0 986 280 232**
22680 8J000	**0 280 218 154**
22680 8J020	**0 280 218 172**
22680 8U301	**0 280 218 150**
22680 8U320	**0 280 218 170**
22731 1F710	**0 232 103 033**
22731 1F710	**0 232 103 034**
22771 JG70A	**0 281 002 772**
23731 1F700	**0 261 210 201**
23731 1F700	**0 261 210 202**
23731 1F710	**0 232 103 033**
23731 1F710	**0 232 103 044**
23731 1F710	**0 232 103 045**
23731 9X800	**0 281 002 138**
25068 89TA0	**9 461 614 499**
25977 7F405	**0 281 002 191**
28556 9F207	**0 265 001 194**
47600 1U200	**0 265 214 206**
47660 1U600	**0 265 025 043**
47900 AV700	**0 265 007 466**
47900 AV710	**0 265 007 633**
47900 AX600	**0 265 007 539**
47900 BM500	**0 265 006 794**
47900 BN800	**0 265 007 554**
47900 BN805	**0 265 007 554**
47900 BU800	**0 265 007 558**
47900 BU805	**0 265 007 558**
47900 JD000	**0 265 007 908**
47900 JD600	**0 265 007 909**
47900 NB805	**0 265 007 554**
47900-0B101	**0 265 001 318**
47900 0X800	**0 265 006 778**
47900 0X900	**0 265 006 779**
47900-1E400	**0 265 003 087**
47900 1U200	**0 265 006 256**
47900 2F000	**0 265 006 378**
47900 2F001	**0 265 006 378**
47900 3F001	**0 265 006 378**
47900 3J310	**0 265 006 236**
47900 5F600	**0 265 006 256**
47900 5F605	**0 265 006 489**
47900 6F005	**0 265 006 382**
47900 6F605	**0 265 001 382**
47900 6F605	**0 265 006 382**
47900 7F000	**0 265 006 281**
47900 7F200	**0 265 006 285**
47900 7Z310	**0 265 006 607**
47900 70J00	**0 265 001 275**
47900-71J00	**0 265 001 314**
47900 8B700	**0 265 006 450**
47900 9F500	**0 265 006 709**
47900 9X200	**0 265 006 718**
47900 9X201	**0 265 006 719**
47900 9X400	**0 265 006 716**
47900 9X401	**0 265 006 717**
47900 9X500	**0 265 006 819**
47900 9X501	**0 265 006 820**
47901 AV700	**0 265 007 465**
47901 AV710	**0 265 007 632**
47901 AX600	**0 265 007 538**
47901 AX610	**0 265 007 538**
47901 BM500	**0 265 006 795**
47901 BN800	**0 265 007 555**
47901 BN805	**0 265 007 555**
47901 BU800	**0 265 007 559**
47901 BU805	**0 265 007 559**
47901-0B101	**0 265 001 319**
47901-1E400	**0 265 003 088**
47901 2F000	**0 265 006 379**
47901 2F001	**0 265 006 379**
47901 3J310	**0 265 006 237**
47901 70J00	**0 265 001 276**
47901-71J00	**0 265 001 315**
47901 9F500	**0 265 006 708**
47910 AV700	**0 265 007 464**
47910 AX600	**0 265 007 537**
47910 AX610	**0 265 007 537**
47910 BM400	**0 265 006 703**
47910 BN800	**0 265 007 522**
47910 BN800	**0 265 007 552**
47910 BU800	**0 265 007 556**
47910 JD000	**0 265 007 905**
47910-0B700	**0 265 001 393**
47910-0B000	**0 265 001 316**
47910 0X800	**0 265 006 755**
47910 1B000	**0 265 001 415**
47910-1E400	**0 265 003 085**
47910 1F510	**0 265 006 715**
47910 1U200	**0 265 006 254**
47910 3J300	**0 265 006 232**
47910 3J301	**0 265 006 232**
47910 4U100	**0 265 006 633**
47910 5F600	**0 265 006 254**
47910 5M300	**0 265 006 606**
47910 7B700	**0 265 006 608**
47910 7F000	**0 265 001 413**
47910 7F000	**0 265 006 671**
47910 7F001	**0 265 006 671**
47910 70J00	**0 265 001 273**
47910 71J00	**0 265 001 312**
47911 AV700	**0 265 007 463**
47911 BM400	**0 265 006 702**
47911 BN800	**0 265 007 553**
47911 BU000	**0 265 006 704**
47911 BU800	**0 265 007 557**
47911-0B000	**0 265 001 317**
47911 0L732	**0 265 006 524**
47911 0M032	**0 265 006 449**
47911 0X800	**0 265 006 756**
47911-1E400	**0 265 003 086**
47911 1F500	**0 265 006 658**
47911 1F510	**0 265 006 714**
47911 1U200	**0 265 006 255**
47911 3J300	**0 265 006 233**
47911 3J301	**0 265 006 233**
47911 4U100	**0 265 006 632**
47911 5F600	**0 265 006 255**
47911 5M300	**0 265 006 605**
47911 7B710	**0 265 006 536**

M

47911 7F000	**0 265 001 414**
47911 7F000	**0 265 006 670**
47911 7F001	**0 265 006 670**
47911 70J00	**0 265 001 274**
47911-71J00	**0 265 001 313**
47911 8B700	**0 265 006 453**
47930 AV400	**0 265 005 265**
47930 AX700	**0 265 005 259**
47930 AX700	**0 265 005 263**
47930 JD000	**0 265 005 156**
47930 7F000	**0 265 005 037**
47930 7F001	**0 265 005 037**
47930 70J00	**0 265 005 019**
47931 BC40A	**0 265 005 265**
47931 JD00A	**0 265 005 665**
47941 7P100	**0 265 005 209**
47941 78100	**0 265 005 210**
47945AS500-C106	**F 005 B00 400**
47945 JD000	**0 265 005 514**
47945 7P100	**0 265 005 403**
82004 17006	**1 397 212 084**
82005 83498	**0 265 008 077**
82007 24127	**0 265 008 078**
92017805	**0 280 130 026**

OPEL

X0 501 817	**0 280 750 006**
08 36 566	**0 986 280 140**
08 36 574	**0 986 280 140**
08 36 623	**0 986 280 113**
08 36 642	**0 986 280 113**
08 36 643	**0 986 280 140**
08 958 416	**0 280 202 009**
08 983 631	**0 280 130 023**
08 983 636	**0 280 120 200**
09 118 368	**0 261 210 151**
09 129 036	**0 261 230 026**
09 199 636	**0 265 005 435**
09 281 886	**0 280 120 039**
10 415 656	**0 265 005 410**
10 415 656	**0 265 005 411**
10 456 098	**0 261 210 084**
12 36 310	**0 265 005 425**
12 36 310	**0 265 005 434**
12 38 246	**0 265 005 430**
12 38 246	**0 265 005 435**
12 38 247	**0 265 005 255**
12 38 247	**0 265 005 262**
12 38 345	**0 261 231 006**
12 38 358	**0 261 210 030**
12 38 364	**0 261 210 031**
12 38 399	**0 265 008 089**
12 38 410	**0 265 003 050**
12 38 410	**0 265 006 488**
12 38 411	**0 265 001 236**
12 38 412	**0 265 001 235**
12 38 413	**0 265 001 238**
12 38 414	**0 265 001 237**
12 38 557	**0 332 514 124**
12 38 574	**0 332 015 012**
12 38 609	**0 332 003 023**
12 38 627	**0 332 514 103**
12 38 631	**0 332 014 453**
12 38 643	**0 332 514 109**
12 38 782	**0 261 210 048**
12 38 784	**0 265 003 070**
12 38 985	**0 265 003 094**
12 38 986	**0 265 003 093**
12 38 987	**0 265 003 092**
12 38 987	**0 265 006 487**
12 38 988	**0 265 003 091**
12 38 988	**0 265 006 486**
12 38 998	**0 265 006 488**
12 566 845	**0 261 231 174**
12 580 977	**0 280 218 136**
12 591 290	**0 261 230 146**
12 592 525	**0 261 230 185**
12 789 959	**0 261 210 229**
12 81 218	**0 332 014 453**
12 81 797	**0 332 514 123**
13 103 434	**0 265 005 269**
13 107 414	**0 265 005 448**
13 107 803	**1 397 212 058**
13 107 803	**1 697 212 058**
13 107 804	**1 397 212 056**
13 153 362	**1 397 212 072**
13 153 363	**1 397 212 071**
13 221 030	**0 265 005 608**
13 221 030	**0 265 005 656**
13 241 771	**0 280 218 209**
13 241 771	**0 280 218 210**
13 260 662	**0 265 008 089**
13 261 544	**0 280 218 227**
13 262 124	**0 280 218 208**
13 38 440	**0 280 130 007**
13 38 441	**0 280 130 014**
13 38 442	**0 280 130 014**
13 38 443	**0 280 130 023**
13 38 444	**0 280 130 026**
13 38 446	**0 280 130 032**
13 38 451	**0 280 130 107**
13 38 452	**0 280 130 032**
14 094 712	**0 280 213 004**
14 094 712	**0 986 280 103**
15 875 837	**0 280 218 219**
17 76 155	**0 332 014 151**
21 994 504	**0 280 218 177**
24 402 747	**1 397 212 007**
24 402 747	**1 397 212 009**
24 402 747	**1 397 212 019**
24 402 747	**1 397 212 040**
24 402 748	**1 397 212 007**
24 402 748	**1 397 212 043**
24 402 749	**1 397 212 045**
24 402 752	**1 397 212 007**
24 402 861	**0 280 218 052**
24 413 377	**0 265 005 255**
24 414 665	**0 281 002 428**
24 420 400	**0 261 210 206**
24 420 536	**0 280 750 133**
24 420 614	**0 280 218 119**
24 420 696	**0 261 231 173**
24 420 761	**0 281 002 438**
24 428 295	**0 265 005 415**
24 428 295	**0 265 005 433**
24 430 462	**0 265 005 425**
24 430 462	**0 265 005 434**
24 435 990	**0 281 002 476**
24 437 502	**0 281 002 478**
24 437 503	**0 281 002 479**
24 437 651	**0 280 218 087**
24 439 252	**0 281 002 549**
24 441 567	**0 265 005 430**
24 446 586	**0 280 750 119**
24 456 424	**1 397 212 042**
24 456 425	**1 397 212 044**
24 456 426	**1 397 212 025**
24 456 427	**1 397 212 026**
24 456 428	**1 397 212 046**
24 456 764	**0 281 002 605**
24 459 853	**0 281 002 437**
24 462 266	**0 281 002 564**
30 561 772	**0 261 210 133**
35 25 994	**0 265 001 241**
40 08 022	**0 280 202 020**
40 12 053	**0 332 014 151**
43 63 738	**0 265 001 159**
5 30 400	**0 265 001 056**
5 30 401	**0 265 001 055**
5 30 402	**0 265 001 097**
5 30 403	**0 265 001 143**
5 30 404	**0 265 001 144**
5 30 405	**0 265 001 147**
5 30 406	**0 265 001 145**
5 30 408	**0 265 001 220**
5 30 433	**0 265 001 134**
5 30 436	**0 265 001 206**
5 30 437	**0 265 001 226**
5 30 438	**0 265 001 213**
5 30 439	**0 265 001 207**
5 30 440	**0 265 001 208**
5 30 442	**0 265 001 232**
5 30 491	**0 265 001 233**
55 182 636	**0 261 231 174**
55 182 640	**0 261 231 174**
55 184 549	**0 281 002 617**
55 190 587	**0 281 002 764**
55 194 788	**0 281 002 716**
55 198 717	**0 281 002 771**
55 200 301	**0 281 002 784**
55 30 107	**0 265 005 303**
55 350 045	**0 281 002 619**
55 350 047	**0 281 002 620**
55 350 048	**0 281 002 618**
55 350 048	**0 281 002 683**
55 350 433	**0 280 218 121**
55 351 974	**0 280 218 142**
55 353 127	**0 280 218 121**
55 354 601	**0 281 002 662**
55 557 064	**0 281 002 773**
55 557 619	**0 280 218 164**
55 557 619	**0 986 280 241**
55 558 417	**0 281 002 789**
55 558 417	**0 281 002 802**
55 559 313	**0 280 218 142**
55 559 358	**0 261 230 145**
55 561 301	**0 281 002 832**
55 561 301	**0 281 002 833**
55 561 304	**0 281 002 830**
55 561 304	**0 281 002 831**
55 561 912	**0 280 218 208**
55 561 912	**0 281 002 940**
55 561 912	**0 281 002 941**
55 562 389	**0 280 218 211**
55 562 426	**0 281 002 912**
55 562 426	**0 281 002 913**
55 700 425	**0 265 007 671**
55 700 426	**0 265 007 669**
55 700 426	**0 265 007 769**
55 701 387	**0 265 007 768**
55 702 812	**0 265 005 609**
55 702 812	**0 265 005 657**
62 35 620	**0 265 005 269**
62 35 620	**0 265 005 270**
62 35 722	**0 265 005 608**
62 35 722	**0 265 005 656**
62 357 23	**0 265 005 609**
62 35 723	**0 265 005 657**
62 38 162	**0 265 005 229**
62 38 162	**0 265 005 255**
62 38 162	**0 265 005 261**
62 38 162	**0 265 005 262**
62 38 163	**0 265 005 415**
62 38 163	**0 265 005 433**
62 38 255	**0 265 005 448**
62 38 255	**0 265 005 449**
62 38 393	**0 261 210 048**
73 174 462	**0 986 280 063**
8 12 071	**0 280 120 200**

◀ OPEL

8 15 615	**0 280 202 084**
8 15 651	**0 280 202 084**
8 15 700	**0 280 101 001**
8 25 463	**0 280 122 004**
8 26 280	**0 280 120 003**
8 26 281	**0 280 120 039**
8 26 282	**0 280 120 019**
8 26 283	**0 280 120 039**
8 26 284	**0 280 120 200**
8 26 285	**0 280 120 301**
8 26 285	**0 280 120 319**
8 26 287	**0 280 120 405**
8 26 288	**0 280 120 316**
8 26 289	**0 280 120 412**
8 26 290	**0 280 120 326**
8 26 291	**0 280 120 436**
8 26 924	**0 280 122 001**
8 34 360	**0 280 130 006**
8 36 401	**0 280 130 073**
8 36 561	**0 280 202 207**
8 36 562	**0 280 202 208**
8 36 562	**0 280 202 213**
8 36 562	**0 986 280 024**
8 36 562	**0 986 280 025**
8 36 565	**0 280 217 003**
8 36 566	**0 280 213 024**
8 36 567	**0 280 217 106**
836 574	**0 280 213 024**
836584	**0 280 218 031**
8 36 588	**0 280 218 051**
836588	**0 986 280 231**
8 36 592	**0 281 002 180**
8 36 601	**0 280 200 003**
8 36 602	**0 280 200 003**
8 36 603	**0 280 202 006**
8 36 604	**0 280 202 007**
8 36 605	**0 280 202 009**
8 36 606	**0 280 202 024**
8 36 607	**0 280 202 030**
8 36 608	**0 280 202 033**
8 36 609	**0 280 202 037**
8 36 610	**0 280 202 054**
8 36 610	**0 280 202 074**
8 36 611	**0 280 202 068**
8 36 612	**0 280 202 076**
8 36 613	**0 280 202 053**
8 36 614	**0 280 202 086**
8 36 615	**0 280 202 089**
8 36 616	**0 280 202 084**
8 36 617	**0 280 202 201**
8 36 617	**0 986 280 069**
8 36 618	**0 280 202 202**
8 36 620	**0 280 202 602**
8 36 620	**0 986 280 019**
8 36 621	**0 280 203 032**

8 36 621	**0 986 280 074**
8 36 622	**0 280 200 603**
8 36 623	**0 280 212 015**
8 36 624	**0 280 202 204**
8 36 624	**0 986 280 055**
8 50 075	**0 280 100 005**
8 50 077	**0 280 100 013**
8 50 078	**0 280 100 105**
8 50 080	**0 280 100 124**
8 52 185	**0 280 130 032**
88 960 665	**F 00H W00 002**
88 960 666	**F 00H W00 001**
88 960 667	**F 00H W00 000**
90 003 095	**0 332 003 023**
90 003 448	**0 280 130 014**
90 006 052	**0 280 202 054**
90 008 806	**0 280 202 076**
90 016 570	**0 280 202 007**
90 018 835	**0 280 130 026**
90 019 927	**0 280 202 006**
90 020 809	**0 280 200 003**
90 042 050	**0 265 003 050**
90 042 050	**0 265 006 488**
90 061 276	**0 265 001 097**
90 061 297	**0 265 001 097**
90 062 407	**0 265 001 055**
90 062 408	**0 265 001 056**
90 080 939	**0 280 130 026**
90 094 357	**0 280 202 053**
90 140 378	**0 280 202 024**
90 141 745	**0 280 120 301**
90 187 326	**0 280 130 032**
90 187 501	**0 332 015 012**
90 194 931	**0 280 202 068**
90 210 450	**0 265 001 144**
90 210 495	**0 265 001 147**
90 213 477	**0 265 001 143**
90 213 515	**0 261 210 030**
90 220 944	**0 280 202 202**
90 220 944	**0 280 202 210**
90 220 944	**0 986 280 063**
90 220 968	**0 280 202 202**
90232732	**0 261 210 031**
90 264 609	**0 280 202 089**
90 264 759	**0 280 202 211**
90 264 759	**0 986 280 091**
90 271 067	**0 280 202 084**
90 272 153	**0 280 202 210**
90 272 153	**0 986 280 063**
90 272 154	**0 280 202 201**
90 272 154	**0 986 280 069**
90 273 089	**0 280 120 405**
90 281 021	**0 280 101 007**
90281818	**0 280 202 602**
90 281 818	**0 986 280 019**

90 287 309	**0 265 001 206**
90 287 310	**0 265 001 208**
90 287 311	**0 265 001 207**
90 296 182	**0 332 014 151**
90 296 998	**0 280 200 603**
90 298 201	**0 261 231 006**
90 299 240	**0 280 120 326**
90 307 088	**0 265 001 226**
90 307 089	**0 265 001 213**
90 323 510	**0 280 120 412**
90 323 839	**0 280 122 001**
90 337 650	**0 261 210 048**
90 341 204	**0 265 001 235**
90 341 206	**0 265 001 237**
90 346 045	**0 265 001 233**
90 346 046	**0 265 001 232**
90 347 697	**0 265 003 070**
90 350 520	**0 280 202 204**
90 350 520	**0 280 202 211**
90 350 520	**0 986 280 055**
90 350 520	**0 986 280 091**
90 357 231	**0 265 003 094**
90 357 232	**0 265 003 093**
90 357 232	**0 265 003 094**
90 357 233	**0 265 003 092**
90 357 233	**0 265 006 487**
90 357 480	**0 232 103 001**
90 360 342	**0 265 003 095**
90 399 364	**0 280 202 208**
90 399 364	**0 280 202 213**
90 399 364	**0 986 280 024**
90 399 364	**0 986 280 025**
90 399 392	**0 280 202 207**
90 399 392	**0 280 202 212**
90 399 392	**0 986 280 081**
90 401 965	**0 232 103 008**
90 409 524	**0 280 202 208**
90 409 524	**0 280 202 213**
90 409 524	**0 986 280 024**
90 409 524	**0 986 280 025**
90 409 525	**0 280 202 211**
90 409 525	**0 986 280 091**
90 409 526	**0 280 202 207**
90 409 526	**0 280 202 212**
90 409 526	**0 986 280 081**
90 410 792	**0 280 130 107**
90 410 793	**0 280 130 032**
90 410 793	**0 280 130 069**
90 411 537	**0 280 217 503**
90 423 088	**0 280 130 039**
90 423 637	**0 261 230 042**
90 423 761	**0 280 218 051**
90 423 761	**0 280 218 061**
90 423 761	**0 986 280 231**
90 423 807	**0 280 750 084**

90 442 182	**0 280 130 073**
90 443 390	**0 265 001 236**
90 443 391	**0 265 003 050**
90 443 391	**0 265 006 488**
90 448 661	**0 205 001 019**
90 448 964	**0 280 217 106**
90 449 573	**0 232 103 002**
90 449 573	**0 232 103 016**
90 451 441	**0 261 210 030**
90 459 666	**0 265 001 220**
90 464 741	**0 281 002 138**
90483739	**0 261 210 048**
90 486 133	**0 280 122 004**
90 487 306	**0 280 212 015**
90 487 306	**0 986 280 113**
90 490 042	**0 261 231 115**
90 490 043	**0 261 210 132**
90 490 166	**0 232 103 016**
90 490 185	**0 280 130 093**
90 490 496	**0 261 210 169**
90 491 965	**0 232 103 008**
90 494 182	**0 261 210 131**
90 499 610	**0 261 230 009**
90 501 816	**0 205 001 039**
90 502 544	**0 205 001 042**
90 502 696	**0 261 230 015**
90 505 794	**0 232 103 007**
90 505 794	**0 232 103 021**
90 505 795	**0 232 103 011**
90 506 101	**0 232 103 015**
90 509 164	**0 205 001 019**
90 510 127	**0 232 103 002**
90 510 127	**0 232 103 016**
90 510 151	**0 280 203 032**
90 510 151	**0 986 280 074**
90 510 152	**0 280 213 024**
90 510 152	**0 986 280 140**
90 510 153	**0 280 217 003**
90 510 154	**0 280 217 106**
90 510 156	**0 280 217 503**
90 510 182	**0 280 130 032**
90 510 182	**0 280 130 069**
90 510 183	**0 280 130 068**
90 510 183	**0 280 130 107**
90 510 188	**0 265 003 094**
90 510 188	**0 265 006 466**
90 510 189	**0 265 003 092**
90 510 189	**0 265 006 487**
90 510 190	**0 265 001 134**
90 510 208	**0 265 001 220**
90 510 275	**0 265 003 091**
90 510 275	**0 265 006 486**
90 510 281	**0 261 231 006**
90 510 656	**0 232 103 011**
90 510 657	**0 232 103 007**

90 510 667	**0 232 103 008**
90 510 884	**0 265 003 070**
90 511 177	**0 261 231 079**
90 512 567	**0 205 001 039**
90 528 254	**0 281 002 139**
90 528 435	**0 281 002 184**
90 529 471	**0 205 003 050**
90 529 673	**0 280 217 123**
90 530 434	**0 261 231 116**
90 530 439	**0 280 122 014**
90 530 442	**0 280 217 519**
90 530 767	**0 281 002 180**
90 530 838	**0 281 002 236**
90 530 839	**0 281 002 237**
90 532 619	**0 261 210 151**
90 540 188	**0 281 002 138**
90 540 695	**0 205 001 042**
90 540 743	**0 261 210 131**
90 540 744	**0 232 103 017**
90 540 931	**0 281 002 139**
90 541 290	**0 265 003 093**
90 541 298	**0 261 231 115**
90 541 409	**0 281 002 137**
90 541 502	**0 280 122 014**
90 541 520	**0 280 130 093**
90 541 521	**0 261 231 116**
90 541 577	**0 280 130 039**
90 541 590	**0 280 130 092**
90 541 591	**0 280 217 519**
90 541 609	**0 261 230 015**
90 542 063	**0 281 002 170**
90 543 282	**0 280 217 123**
90 543 463	**0 281 002 180**
90 543 510	**0 261 231 120**
90 560 111	**0 232 103 021**
90 563 161	**0 232 103 017**
90 570 185	**0 281 002 170**
90 571 550	**0 280 752 007**
90 572 503	**0 261 231 120**
90 573 217	**0 281 002 259**
90 581 208	**0 281 002 298**
90 581 208 AQ	**0 281 002 298**
90 581 216	**0 281 002 299**
91 153 350	**0 205 001 055**
91 153 352	**0 205 001 054**
91 153 783	**0 281 002 144**
91 153 947	**0 232 103 016**
91 17 449	**0 281 002 259**
91 17 763	**0 261 230 009**
91 17 961	**0 281 002 278**
91 17 962	**0 281 002 236**
91 17 963	**0 281 002 277**
91 17 964	**0 281 002 237**
91 18 140	**0 232 103 025**
91 18 150	**0 281 002 285**

91 18 160	**0 281 002 298**
91 18 161	**0 281 002 299**
91 18 368	**0 261 210 151**
91 18 374	**0 232 103 021**
91 18 549	**0 265 006 488**
91 18 849	**0 280 750 006**
91 19 062	**0 281 002 296**
91 19 063	**0 281 002 297**
91 19 075	**0 280 752 006**
91 28 412	**0 280 750 006**
91 28 434	**0 280 752 006**
91 28 851	**0 281 002 278**
91 28 852	**0 281 002 277**
91 29 106	**0 281 002 297**
91 29 107	**0 281 002 296**
91 34 756	**0 261 210 183**
91 46 032	**0 232 103 025**
91 57 512	**0 280 750 044**
91 58 595	**0 281 002 437**
91 81 239	**0 265 005 229**
91 81 239	**0 265 005 255**
91 81 239	**0 265 005 261**
91 81 239	**0 265 005 262**
91 81 240	**0 265 005 415**
91 81 240	**0 265 005 433**
91 93 119	**0 265 005 415**
91 93 119	**0 265 005 433**
91 93 149	**0 280 218 031**
91 93 149	**0 986 280 230**
91 93 276	**0 280 752 027**
91 93 277	**0 281 002 604**
91 93 533	**0 281 002 184**
91 95 066	**0 280 130 094**
91 95 630	**0 265 005 229**
91 95 630	**0 265 005 255**
91 95 630	**0 265 005 261**
91 95 630	**0 265 005 262**
91 95 631	**0 265 005 415**
91 95 631	**0 265 005 433**
91 95 729	**0 281 002 428**
91 95 883	**0 261 210 183**
91 95 885	**0 261 210 169**
91 96 400	**0 265 005 303**
91 96 671	**0 281 002 437**
91 96 724	**0 281 002 476**
91 98 639	**0 261 210 206**
91 99 636	**0 265 005 430**
91 99 636	**0 265 005 435**
91 99 886	**1 397 212 007**
92 00 584	**0 265 005 425**
92 00 584	**0 265 005 434**
92 01 175	**0 280 750 084**
92 01 425	**0 280 218 051**
92 01 425	**0 986 280 231**
92 017 809	**0 280 202 052**

92 02 252	**0 280 752 027**
92 02 253	**0 281 002 604**
92 04 425	**0 280 218 051**
92 04 425	**0 986 280 231**
92 061 913	**0 261 231 007**
92 27 760	**0 280 218 031**
92 27 760	**0 986 280 230**
92 28 959	**1 397 212 009**
92 92 698	**0 280 120 021**
92 92 698	**0 280 120 022**
93 170 202	**1 397 212 040**
93 170 245	**1 397 212 043**
93 170 246	**1 397 212 044**
93 170 309	**0 261 230 042**
93 170 362	**0 265 005 255**
93 170 362	**0 265 005 262**
93 171 176	**0 281 002 437**
93 171 184	**1 397 212 042**
93 171 185	**1 397 212 025**
93 171 355	**0 281 002 428**
93 171 356	**0 281 002 180**
93 171 527	**0 281 002 478**
93 171 627	**0 281 002 478**
93 171 748	**1 397 212 009**
93 171 749	**1 397 212 026**
93 171 760	**0 281 002 184**
93 172 012	**0 263 003 208**
93 172 747	**0 280 218 087**
93 172 949	**0 265 005 448**
93 172 949	**0 265 005 449**
93 173 727	**0 281 002 479**
93 174 460	**0 986 280 091**
93 174 461	**0 986 280 024**
93 174 462	**0 986 280 064**
93 174 464	**0 986 280 024**
93 174 465	**0 986 280 063**
93 174 628	**0 281 002 564**
93 176 039	**0 232 103 015**
93 176 086	**0 281 002 605**
93 177 171	**0 261 231 173**
93 177 196	**0 265 005 269**
93 177 196	**0 265 005 270**
93 177 365	**0 281 002 534**
93 177 414	**0 281 002 510**
93 177 718	**0 281 002 549**
93 178 050	**0 281 002 620**
93 178 243	**0 281 002 618**
93 178 244	**0 281 002 619**
93 178 598	**0 986 280 113**
93 178 599	**0 986 280 113**
93 178 600	**0 986 280 140**
93 178 601	**0 986 280 140**
93 178 788	**1 397 212 056**
93 179 433	**0 281 002 603**
93 179 513	**0 281 002 213**

93 179 850	**0 281 002 662**
93 179 927	**0 280 218 119**
93 180 105	**0 261 231 181**
93 180 268	**0 261 002 617**
93 180 268	**0 281 002 617**
93 180 405	**0 261 231 181**
93 180 922	**0 280 218 142**
93 180 992	**0 280 218 142**
93 181 025	**0 280 750 133**
93 181 894	**0 280 218 211**
93 181 944	**0 281 002 716**
93 183 528	**0 232 103 052**
93 183 599	**1 397 212 072**
93 183 600	**1 397 212 071**
93 185 444	**0 281 002 773**
93 185 455	**0 280 218 136**
93 185 556	**0 281 002 784**
93 185 626	**0 281 002 706**
93 186 084	**0 280 218 164**
93 186 084	**0 986 280 241**
93 186 483	**0 281 002 789**
93 186 840	**0 232 103 067**
93 187 126	**0 265 005 608**
93 187 126	**0 265 005 656**
93 187 247	**0 281 002 771**
93 188 239	**0 265 005 609**
93 188 239	**0 265 005 656**
93 188 239	**0 265 005 657**
93 188 724	**0 281 002 833**
93 189 202	**0 261 231 174**
93 189 275	**0 265 007 671**
93 189 276	**0 265 007 768**
93 189 276	**0 265 007 896**
93 189 277	**0 265 007 769**
93 189 506	**0 263 003 472**
93 189 955	**0 281 002 831**
93 190 052	**0 281 002 844**
93 191 478	**0 265 008 089**
93 192 107	**0 261 230 146**
93 192 439	**0 265 008 077**
93193710	**0 261 231 201**
93194121	**0 281 002 770**
93194121	**0 281 002 771**
93194419	**0 261 230 197**
93 194 900	**0 265 008 078**
93 232 413	**0 261 210 128**
93 243 251	**0 261 210 150**
93 245 824	**0 280 217 525**
93 245 824	**0 280 217 526**
93 294 467	**0 265 006 488**
93 310 500	**0 232 103 067**
93 328 218	**0 281 002 579**
93 388 248	**0 280 750 153**
93 399 801	**0 261 230 099**
93 399 899	**0 261 231 176**

◀ OPEL

93 857 508	**1 397 212 084**
93 857 938	**0 281 002 566**
93 858 411	**0 265 008 077**
93 860 619	**0 265 008 078**

PEUGEOT

A 040 296	**0 261 211 003**
DX 144 119 A	**0 280 100 023**
DX 144 224 A	**0 280 120 011**
DX 144 228 A	**0 280 130 009**
DX 144 228 A	**0 280 130 014**
DX 144 263 A	**0 280 100 011**
DX 144 263 B	**0 280 100 023**
DX 524 101 A	**0 332 003 021**
V7 535 069	**0 261 230 134**
V7 540 508	**0 261 230 135**
V7 552 114	**0 261 231 197**
V7 552 114	**0 261 231 198**
0242 46	**0 280 130 026**
0242 62	**0 280 130 032**
1066 63	**0 280 755 046**
1192 W5	**0 281 002 184**
1452 05	**0 280 230 006**
1452 10	**0 280 230 010**
14 808 450	**0 265 006 426**
14 808 460 80	**0 265 006 388**
14 888 410	**0 265 007 083**
14 916 610	**0 265 006 730**
14 916 620	**0 265 006 731**
14 938 820	**0 265 007 083**
1601 G4	**0 280 755 019**
1601 G5	**0 280 755 039**
1601 K7	**0 280 752 235**
1601 K7	**0 280 752 251**
1601 K8	**0 280 752 236**
1601 K9	**0 280 752 237**
1601 L1	**0 280 752 240**
1601 L4	**0 280 752 243**
1601 N4	**0 280 752 247**
1601 N5	**0 280 752 241**
1601 N6	**0 280 752 242**
1601 N7	**0 280 752 260**
1601 N7	**0 280 755 029**
1601 N8	**0 280 755 030**
1601 N9	**0 280 752 258**
1601 P3	**0 280 755 000**
1601 P3	**0 280 755 001**
1601 P4	**0 280 752 279**
1601 P5	**0 280 755 015**
1601 P6	**0 280 752 283**
1601 P7	**0 280 755 016**
1601 P8	**0 280 755 007**
1601 Q0	**0 280 755 005**
1601 Q1	**0 280 755 010**

1601 Q1	**0 280 755 011**
1601 Q2	**0 280 755 026**
1601 Q3	**0 280 755 027**
1601 Q3	**0 280 755 044**
1601 Q4	**0 280 755 012**
1601 Q5	**0 280 755 013**
1601 Q6	**0 280 755 018**
1601 Q8	**0 280 755 040**
1601 R2	**0 280 755 046**
1601 S0	**0 280 755 031**
1601 S1	**0 280 755 032**
1601 S2	**0 280 755 033**
1601 S3	**0 280 755 044**
1601 S4	**0 280 755 045**
1601 T1	**0 280 755 074**
1601 T2	**0 280 755 075**
1601 T3	**0 280 755 076**
1601 T4	**0 280 755 077**
1601 T6	**0 280 755 041**
1601 T7	**0 280 755 081**
1601 T8	**0 280 755 035**
1601 T9	**0 280 755 037**
1601 V0	**0 280 755 036**
1601 V1	**0 280 755 038**
1601 X6	**0 280 755 078**
1601 X7	**0 280 755 079**
1601 X7	**0 280 755 080**
1601 X8	**0 280 755 095**
1601 X9	**0 280 755 097**
1621 28	**0 261 211 003**
1622 C9	**0 205 001 015**
1625 90	**0 280 230 101**
1628 A3	**0 280 120 310**
1628 C5	**0 281 002 029**
1628 C6	**0 281 002 018**
1628 G4	**0 280 120 327**
1628 K9	**0 280 120 323**
1628 L1	**0 280 122 001**
1628 1E	**0 280 122 003**
1628 1F	**0 280 122 005**
1628 27	**0 280 120 305**
1628 50	**0 280 120 301**
1628 54	**0 281 002 008**
1628 8V	**0 280 122 009**
1635 P3	**0 280 750 041**
1635 Q9	**0 280 750 085**
1635 Z8	**0 280 750 164**
1636 37	**0 280 750 164**
18 593 070	**0 263 003 246**
1920 AC	**0 261 230 041**
1920 AC	**0 261 230 058**
1920 AJ	**0 261 230 043**
1920 AN	**0 261 230 057**
1920 C6	**0 280 202 118**
1920 C6	**0 986 280 057**

1920 FK	**0 281 002 492**
1920 FR	**0 261 231 168**
1920 FR	**0 261 231 169**
1920 H9	**9 465 160 006**
1920 KZ	**0 261 230 135**
1920 K8	**0 261 230 004**
1920 K8	**0 261 230 037**
1920 LA	**0 261 230 131**
1920 LA	**0 261 230 132**
1920 LS	**0 232 103 064**
1920 LT	**0 261 231 197**
1920 LT	**0 261 231 198**
1920 LW	**0 261 230 136**
1920 PY	**0 261 230 156**
1920 T7	**0 281 002 063**
1920 T7	**0 281 002 063**
1920 Z1	**0 281 002 128**
1920 0E	**0 261 230 012**
1920 0G	**0 280 122 011**
1920 1K	**0 261 230 034**
1920 1K	**0 261 230 057**
1920 27	**0 438 120 065**
1920 29	**0 280 202 044**
1920 3L	**0 281 002 122**
1920 34	**0 280 202 051**
1920 34	**0 986 280 051**
1920 46	**0 280 202 056**
1920 46	**0 986 280 028**
1920 49	**0 280 202 057**
1920 50	**0 280 101 001**
1920 55	**0 438 120 200**
1920 66	**0 280 202 070**
1920 68	**0 280 202 098**
1920 7R	**0 281 002 283**
1920 7R	**0 281 002 592**
1920 70	**0 280 202 097**
1920 70	**0 986 280 070**
1920 76	**0 280 213 006**
1920 76	**0 986 280 115**
1920 80	**0 280 202 109**
1920 80	**0 986 280 013**
1920 9H	**0 261 230 012**
1920 91	**0 280 202 602**
1920 91	**0 986 280 019**
1920 93	**0 280 202 202**
1920 93	**0 280 202 210**
1920 93	**0 986 280 063**
1921 01	**0 438 120 120**
1921 10	**0 438 120 099**
1921 24	**0 438 120 119**
1921 33	**0 438 120 153**
1921 42	**0 438 120 161**
1921 96	**0 438 120 068**
1922 R6	**0 261 230 134**
1929 03	**0 132 009 305**

1929 03	**0 281 002 031**
20 100 255	**0 263 003 267**
20 100 257	**0 263 003 266**
20 100 258	**0 263 003 268**
20 100 259	**0 263 003 274**
20 100 260	**0 263 003 271**
20 100 261	**0 263 003 272**
20 100 263	**0 263 003 273**
20 100 264	**0 263 003 263**
20 100 265	**0 263 003 264**
20 100 266	**0 263 003 265**
20 100 267	**0 263 003 269**
20 100 758	**0 263 003 246**
20 100 975	**0 263 003 334**
35 429 03	**0 263 003 246**
4472 80	**0 280 750 085**
4545 A4	**0 265 006 732**
4545 A8	**0 265 006 793**
4545 C2	**0 265 007 664**
4545 C3	**0 265 007 663**
4545 C3	**0 265 007 780**
4545 C4	**0 265 007 645**
4545 C4	**0 265 007 779**
4545 C7	**0 265 007 665**
4545 C8	**0 265 007 666**
4545 C9	**0 265 007 668**
4545 E0	**0 265 007 667**
4545 E1	**0 265 007 687**
4545 E2	**0 265 007 688**
4545 E3	**0 265 005 486**
4545 E5	**0 265 007 707**
4545 E6	**0 265 007 883**
4545 E7	**0 265 007 788**
4545 E8	**0 265 007 789**
4545 E9	**0 265 007 790**
4545 F0	**0 265 007 791**
4545 F6	**0 265 008 017**
4545 F7	**0 265 008 018**
4545 F8	**0 265 008 018**
4545 F9	**0 265 005 486**
4545 G9	**0 265 007 130**
4545 H0	**0 265 007 131**
4545 H7	**0 265 008 018**
4545 H8	**0 265 005 517**
4545 04	**0 204 154 008**
4545 04	**0 204 154 008**
4545 05	**0 204 154 003**
4545 05	**0 204 154 003**
4545 06	**0 204 154 002**
4545 06	**0 204 154 002**
4545 09	**0 204 154 028**
4545 09	**0 204 154 028**
4545 10	**0 204 154 011**
4545 10	**0 204 154 011**
4545 11	**0 265 003 064**

4545 12	**0 265 003 065**
4545 13	**0 204 154 018**
4545 13	**0 204 154 018**
4545 14	**0 204 154 014**
4545 14	**0 204 154 014**
4545 15	**0 204 154 007**
4545 15	**0 204 154 007**
4545 16	**0 204 154 009**
4545 16	**0 204 154 009**
4545 17	**0 204 154 015**
4545 17	**0 204 154 015**
4545 19	**0 204 154 013**
4545 19	**0 204 154 013**
4545 21	**0 265 003 072**
4545 21	**0 265 003 126**
4545 21	**0 265 003 126**
4545 21	**0 265 006 207**
4545 22	**0 265 003 073**
4545 22	**0 265 003 127**
4545 22	**0 265 006 208**
4545 23	**0 265 003 080**
4545 23	**0 265 003 123**
4545 23	**0 265 006 314**
4545 24	**0 265 003 081**
4545 24	**0 265 003 125**
4545 25	**0 265 005 105**
4545 25	**0 265 005 111**
4545 26	**0 204 154 016**
4545 26	**0 204 154 016**
4545 27	**0 204 150 083**
4545 27	**0 204 150 083**
4545 27	**0 204 154 040**
4545 27	**0 204 154 040**
4545 28	**0 265 003 100**
4545 28	**0 265 003 124**
4545 28	**0 265 003 124**
4545 28	**0 265 006 315**
4545 29	**0 204 154 017**
4545 29	**0 204 154 017**
4545 30	**0 204 154 029**
4545 30	**0 204 154 029**
4545 31	**0 265 003 099**
4545 31	**0 265 003 131**
4545 31	**0 265 006 201**
4545 32	**0 265 003 130**
4545 32	**0 265 006 200**
4545 33	**0 265 003 079**
4545 33	**0 265 003 129**
4545 33	**0 265 006 202**
4545 34	**0 265 003 106**
4545 34	**0 265 003 106**
4545 34	**0 265 006 204**
4545 35	**0 265 003 128**
4545 35	**0 265 006 199**
4545 36	**0 265 003 129**

4545 36	**0 265 006 202**
4545 37	**0 265 003 123**
4545 37	**0 265 006 314**
4545 38	**0 204 154 024**
4545 38	**0 204 154 024**
4545 39	**0 204 154 025**
4545 39	**0 204 154 025**
4545 40	**0 204 154 020**
4545 41	**0 204 154 027**
4545 41	**0 204 154 027**
4545 42	**0 204 154 026**
4545 44	**0 265 006 201**
4545 44	**0 265 006 201**
4545 45	**0 265 006 200**
4545 46	**0 265 006 202**
4545 47	**0 265 006 199**
4545 48	**0 265 006 205**
4545 49	**0 265 006 206**
4545 50	**0 265 006 203**
4545 51	**0 265 006 204**
4545 55	**0 265 006 207**
4545 56	**0 265 006 202**
4545 56	**0 265 006 208**
4545 60	**0 265 006 314**
4545 60	**0 265 006 314**
4545 61	**0 265 006 315**
4545 61	**0 265 006 315**
4545 62	**0 265 006 209**
4545 63	**0 204 154 038**
4545 63	**0 204 154 038**
4545 66	**0 265 006 389**
4545 67	**0 265 006 388**
4545 67	**0 265 006 388**
4545 68	**0 265 006 426**
4545 68	**0 265 006 426**
4545 69	**0 265 006 441**
4545 69	**0 265 006 441**
4545 70	**0 265 006 427**
4545 70	**0 265 006 427**
4545 71	**0 265 006 405**
4545 72	**0 265 006 406**
4545 75	**0 265 006 504**
4545 78	**0 265 006 389**
4545 82	**0 265 006 544**
4545 83	**0 265 006 545**
4545 84	**0 265 005 404**
4545 85	**0 265 006 659**
4545 88	**0 265 007 423**
4545 89	**0 265 007 424**
4545 89	**0 265 007 424**
4545 92	**0 265 006 730**
4545 93	**0 265 006 731**
4545 94	**0 265 007 083**
4545 95	**0 265 007 084**
4549 05	**0 265 005 211**

4549 05	**0 265 005 290**
4549 07	**0 265 005 253**
4549 07	**0 265 005 290**
4549 16	**0 265 005 290**
4549 17	**0 265 005 606**
4549 21	**0 265 005 715**
4549 26	**0 265 005 291**
4549 26	**0 265 005 714**
4549 27	**0 265 005 292**
4549 28	**0 265 005 629**
4549 33	**0 265 005 629**
4549 39	**0 265 005 714**
4549 41	**0 265 005 703**
4549 43	**0 265 005 724**
4574 03	**0 261 230 058**
4649 28	**0 265 005 629**
5007 99	**0 280 122 003**
5 412 358	**0 280 130 014**
5 412 360	**0 280 130 006**
5 412 361	**0 280 120 011**
5 412 361	**0 280 120 018**
5 413 479	**0 280 100 036**
5 422 133	**0 332 003 021**
5 429 448	**0 280 100 048**
5 472 928	**0 332 514 103**
5 489 066	**0 280 202 005**
5 500 350	**0 280 120 200**
5 502 644	**0 280 130 023**
5918 73	**0 281 002 030**
5918 79	**0 261 210 029**
5918 80	**0 261 210 043**
5918 84	**0 261 210 029**
5946 03	**0 261 231 006**
5946 05	**0 261 231 007**
5946 15	**0 261 231 071**
5946 17	**0 261 231 071**
5946 18	**0 261 231 070**
5946 21	**0 261 231 045**
5946 22	**0 261 231 109**
5946 25	**0 261 231 125**
5946 28	**0 261 231 128**
5946 30	**0 261 231 130**
6401 L3	**1 397 212 039**
6405 C0	**1 397 212 000**
6405 C0	**1 397 212 000**
6405 E8	**1 397 212 002**
6405 G0	**1 397 212 001**
6405 G5	**1 397 212 006**
6405 HK	**1 397 212 132**
6405 L3	**1 397 212 039**
6405 Q2	**1 397 212 064**
6405 Q3	**1 397 212 060**
6405 Q7	**1 397 212 074**
6405 R9	**1 397 212 083**
6405 W9	**1 397 212 109**

6405 Y4	**1 397 212 112**
6405 Y5	**1 397 212 086**
6505 Q5	**1 397 212 076**
6505 Q6	**1 397 212 076**
6555 20	**0 280 230 112**
6555 22	**0 280 230 009**
6555 47	**0 280 230 014**
6590 A5	**0 263 003 246**
72 408 124	**0 280 122 001**
72 408 254	**0 280 120 400**
72 408 654	**0 280 122 011**
72 408 744	**0 280 122 009**
72 408 754	**0 280 122 010**
74 013 460 30	**0 280 130 032**
74 013 676 43	**0 261 231 007**
74 013 676 45	**0 261 210 029**
77 002 672 69	**0 280 230 112**
77 007 723 10	**0 265 001 068**
82 001 893 85	**0 280 750 155**
8334 57	**0 281 002 804**
8334 57	**0 281 002 919**
91 000 407 80	**0 280 202 051**
91 000 407 80	**0 986 280 051**
91 000 409	**0 280 230 006**
91 000 409 80	**0 280 230 006**
91 040 296 80	**0 261 211 003**
91 040 370	**0 280 130 026**
91 040 398	**0 281 002 030**
91 166 609	**1 397 212 039**
91 207 837	**0 281 002 018**
91 414 549	**0 280 130 026**
91 508 771 80	**0 280 230 101**
91 508 772 80	**0 280 230 100**
91 512 716	**0 280 230 101**
91 512 716 80	**0 280 230 101**
91 513 886 80	**0 280 230 104**
91 514 547 80	**0 280 202 044**
91 514 878 80	**0 261 231 001**
91 514 880	**0 261 231 006**
91 516 985	**0 280 202 056**
91 516 985	**0 986 280 028**
91 517 923 80	**0 280 230 010**
91 517 932	**0 280 230 010**
91 517 932 80	**0 280 230 010**
91 518 192	**0 280 101 001**
91 518 192 80	**0 280 101 001**
91 518 194 80	**0 280 202 057**
91 519 925	**0 280 120 310**
91 519 925 80	**0 280 120 310**
91 520 606 80	**0 280 202 075**
91 527 047	**0 281 002 018**
91 536 076	**0 280 202 602**
91 536 076	**0 986 280 019**
91 537 218 80	**0 280 202 070**
91 537 485	**0 132 009 305**

P

◀ PEUGEOT

91 537 485 80	**0 132 009 305**
91 537 516	**0 281 002 029**
91 537 516 80	**0 281 002 029**
91 538 877	**0 280 202 097**
91 538 877	**0 986 280 070**
91 539 005 80	**0 280 202 098**
91 540 545 80	**0 280 202 109**
91 540 545 80	**0 986 280 013**
91 541 027	**0 261 210 043**
91 541 738	**0 280 202 202**
91 548 738	**0 261 210 043**
92 526 538	**0 332 014 151**
92 526 538 80	**0 332 014 151**
93 011 154	**0 281 002 008**
93 327 326	**0 265 006 389**
95 496 103	**0 280 202 047**
95 496 375	**0 280 202 021**
95 496 621	**0 280 230 009**
95 567 200	**0 280 120 301**
95 567 200 80	**0 280 120 310**
95 572 330	**0 332 514 130**
95 572 333	**0 332 514 130**
95 598 944	**0 280 202 073**
95 605 079	**0 280 202 061**
95 605 079	**0 280 202 064**
95 605 079	**0 986 280 041**
95 605 084	**0 280 120 313**
95 610 350	**0 265 001 098**
95 635 036	**0 280 202 099**
95 635 037	**0 280 120 312**
95 635 037	**0 280 120 317**
95 635 040	**0 280 202 100**
95 635 043	**0 280 202 101**
95 635 045	**0 280 120 318**
95 637 307	**0 265 001 157**
95 637 307	**0 265 001 245**
95 638 095	**0 265 001 158**
95 640 366	**0 281 002 037**
96 000 118	**0 204 154 010**
96 013 294	**0 280 230 014**
96 015 940	**0 280 120 327**
96 035 417	**0 280 202 118**
96 035 417	**0 986 280 057**
96 037 065	**0 261 231 034**
96 037 068	**0 261 231 033**
96 038 938	**0 280 122 001**
96 039 179	**0 280 202 118**
96 039 179	**0 986 280 057**
96 046 811	**0 204 154 012**
96 056 021	**0 280 120 323**
96 067 683	**0 204 154 010**
96 067 694	**0 204 154 012**
96 071 329	**0 265 003 065**
96 075 741	**0 204 154 010**
96 081 740	**0 280 120 327**

96 086 319	**0 265 005 111**
96 086 319 80	**0 265 005 105**
96 087 509	**0 265 003 078**
96 087 509	**0 265 003 128**
96 087 509	**0 265 006 199**
96 089 629	**0 265 003 079**
96 089 629	**0 265 003 129**
96 089 629	**0 265 006 202**
96 099 080	**0 204 154 016**
96 105 849	**0 265 003 072**
96 105 849	**0 265 003 126**
96 105 849	**0 265 006 207**
96 105 850	**0 265 003 073**
96 105 850	**0 265 003 127**
96 105 850	**0 265 006 208**
96 105 926	**9 456 160 006**
96 105 926	**9 465 160 006**
96 106 029	**0 265 003 081**
96 106 029	**0 265 003 125**
96 106 095	**0 265 003 080**
96 106 095	**0 265 003 123**
96 106 095	**0 265 006 314**
96 107 893	**0 261 230 004**
96 109 509	**0 281 002 063**
96 127 657	**0 261 231 071**
96 127 657	**0 261 231 106**
96 127 658	**0 261 231 070**
96 127 658	**0 261 231 105**
96 128 155	**0 265 003 064**
96 128 156	**0 265 003 080**
96 128 156	**0 265 003 123**
96 128 156	**0 265 006 314**
96 131 470	**0 280 130 084**
96 140 648	**0 265 003 099**
96 140 648	**0 265 003 131**
96 140 648	**0 265 006 201**
96 149 640	**0 205 001 015**
96 161 385	**0 204 154 010**
96 165 516	**0 265 003 105**
96 165 516	**0 265 003 130**
96 165 516	**0 265 003 130**
96 165 516	**0 265 006 200**
96 168 084	**0 261 231 045**
96 180 488	**0 265 003 128**
96 180 488	**0 265 006 199**
96 181 977	**0 265 003 130**
96 181 977	**0 265 003 131**
96 181 977	**0 265 006 200**
96 181 977	**0 265 006 201**
96 181 978	**0 265 003 130**
96 181 978	**0 265 006 200**
96 181 979	**0 265 003 130**
96 181 979	**0 265 003 131**
96 181 979	**0 265 006 200**
96 181 979	**0 265 006 201**

96 182 000	**0 265 003 125**
96 182 615	**0 261 230 012**
96 183 217	**0 265 006 205**
96 183 261	**0 265 006 206**
96 191 116	**0 281 002 063**
96 195 593	**0 281 002 119**
96 195 593	**0 281 002 122**
96 210 452	**0 265 005 111**
96 210 838	**1 397 212 000**
96 211 621	**0 281 002 128**
96 217 750	**0 265 006 201**
96 217 752	**0 265 006 200**
96 217 753	**0 265 006 202**
96 217 755	**0 265 006 204**
96 217 756	**0 265 006 203**
96 217 759	**0 265 006 199**
96 217 763	**0 265 006 207**
96 217 765	**0 265 006 208**
96 218 046	**0 265 006 209**
96 227 489	**0 265 006 203**
96 252 846	**0 265 006 205**
96 255 387	**0 265 006 315**
96 255 404	**0 265 006 314**
96 272 628	**0 265 006 205**
96 275 932	**0 261 231 128**
96 280 713	**0 265 006 389**
96 286 482	**0 261 231 130**
96 286 483	**0 261 231 127**
96 286 484	**0 261 231 125**
96 286 689	**1 397 212 001**
96 295 910	**0 280 750 041**
96 297 255	**0 265 006 441**
96 300 147	**0 265 005 404**
96 303 414	**0 265 005 211**
96 303 414	**0 265 005 290**
96 305 913	**1 397 212 002**
96 317 068	**0 265 006 544**
96 317 069	**0 265 006 545**
96 318 136	**0 261 230 057**
96 337 132	**1 397 212 004**
96 343 935	**1 397 212 002**
96 343 935	**1 397 212 006**
96 353 847	**0 265 007 423**
96 353 848	**0 265 007 424**
96 354 934	**0 261 230 058**
96 358 840	**0 280 750 085**
96 365 830	**0 261 230 043**
96 382 908	**0 265 006 659**
96 384 235	**0 261 231 128**
96 386 487	**0 265 007 423**
96 393 814	**0 261 230 043**
96 394 188	**0 261 230 057**
96 394 189	**0 261 230 058**
96 394 190	**0 261 230 057**
96 394 191	**0 261 230 058**

96 411 890	**1 397 212 004**
96 411 890	**1 397 212 039**
96 411 890	**1 397 212 060**
96 415 250	**0 265 005 253**
96 415 250	**0 265 005 290**
96 430 590	**0 280 752 235**
96 430 591	**0 280 752 247**
96 430 592	**0 280 752 236**
96 430 732	**0 280 752 238**
96 430 847	**0 280 752 237**
96 430 848	**0 280 752 248**
96 430 934	**0 280 752 240**
96 431 704	**0 265 006 732**
96 434 731	**0 280 752 243**
96 436 596	**0 265 007 423**
96 436 605	**0 265 007 424**
96 436 880	**0 265 007 424**
96 436 977	**0 265 007 423**
96 440 934	**0 280 752 240**
96 442 063	**0 261 230 085**
96 442 066	**0 261 230 085**
96 449 305	**0 280 752 242**
96 449 396	**0 280 752 241**
96 449 667	**0 265 007 423**
96 449 668	**0 265 007 424**
96 453 114	**0 261 231 169**
96 454 477	**0 265 005 253**
96 454 477	**0 265 005 290**
96 458 515	**0 280 752 235**
96 458 522	**0 280 752 237**
96 461 258	**0 265 007 645**
96 461 258	**0 265 007 779**
96 464 045	**0 280 755 016**
96 466 196	**1 397 212 050**
96 467 021	**0 280 752 251**
96 467 555	**1 397 212 039**
96 468 373	**1 397 212 050**
96 469 709	**0 265 007 668**
96 469 711	**0 265 007 667**
96 469 712	**0 265 007 665**
96 469 725	**0 265 007 666**
96 471 352	**0 280 752 279**
96 475 755	**0 280 752 258**
96 476 944	**1 397 212 060**
96 477 813	**0 280 752 259**
96 477 813	**0 280 752 260**
96 477 813	**0 280 755 029**
96 477 814	**0 280 752 262**
96 477 967	**0 280 752 264**
96 477 967	**0 280 755 028**
96 480 873	**0 265 006 793**
96 488 392	**0 280 755 029**
96 489 571	**0 280 755 006**
96 489 571	**0 280 755 007**
96 494 001	**0 265 005 291**

96 494 001	**0 265 005 714**
96 495 100	**0 280 750 164**
96 496 14 1 77	**0 263 003 476**
96 497 761	**0 265 005 606**
96 498 334	**1 397 212 064**
96 499 043	**0 265 005 292**
96 502 357	**0 265 005 290**
96 502 361	**0 265 005 486**
96 503 417	**0 280 755 012**
96 503 418	**0 280 755 013**
96 504 521	**0 265 005 290**
96 508 818	**0 280 755 000**
96 508 818	**0 280 755 001**
96 508 891	**0 280 755 000**
96 508 891	**0 280 755 001**
96 508 892	**0 280 755 018**
96 509 352	**0 263 003 263**
96 511 983	**0 280 755 019**
96 511 984	**0 280 755 039**
96 512 701	**0 280 755 041**
96 515 042	**0 280 755 010**
96 515 107	**0 280 755 004**
96 515 107	**0 280 755 005**
96 515 372	**0 280 755 017**
96 515 428	**0 280 755 011**
96 517 022	**1 397 212 073**
96 517 023	**1 397 212 074**
96 518 352	**1 397 212 083**
96 519 693	**0 265 007 707**
96 524 902	**1 397 212 050**
96 524 903	**1 397 212 076**
96 526 967	**0 265 007 664**
96 526 969	**0 265 007 663**
96 526 969	**0 265 007 780**
96 527 700	**0 280 755 015**
96 528 436	**0 280 752 282**
96 528 436	**0 280 752 283**
96 529 212	**0 280 755 030**
96 531 052	**0 280 755 036**
96 531 058	**0 280 755 038**
96 531 059	**0 280 755 032**
96 535 678	**0 280 755 083**
96 536 631	**0 265 007 789**
96 544 055	**0 280 755 040**
96 544 061	**0 280 755 042**
96 544 063	**0 280 755 082**
96 546 648	**1 397 212 050**
96 547 253	**0 280 755 044**
96 547 453	**0 280 755 045**
96 547 545 80	**0 280 755 039**
96 548 774	**0 280 755 026**
96 548 775	**0 280 755 027**
96 552 700	**0 265 007 788**
96 554 671	**0 280 755 035**
96 554 673	**0 280 755 037**
96 555 024	**0 280 755 031**
96 555 025	**0 280 755 033**
96 570 548	**1 397 212 083**
96 571 232	**0 265 005 629**
96 573 958	**0 280 755 046**
96 573 958 VV	**0 280 755 046**
96 573 958 77	**0 280 755 046**
96 575 584	**1 397 212 109**
96 578 716	**1 397 212 108**
96 578 717	**1 397 212 106**
96 578 723	**1 397 212 107**
96 583 737	**1 397 212 105**
96 583 825	**1 397 212 113**
96 584 207	**0 265 007 645**
96 584 207	**0 265 007 779**
96 585 998	**0 265 007 883**
96 586 439	**0 280 755 075**
96 586 529	**0 280 755 079**
96 588 691	**1 397 212 112**
96 588 692	**1 397 212 086**
96 594 498	**0 280 755 074**
96 594 499	**0 280 755 078**
96 594 854	**1 397 212 116**
96 594 857	**1 397 212 117**
96 598 794 77	**0 280 755 076**
96 598 795 77	**0 280 755 080**
96 600 591	**1 397 212 118**
96 600 591	**1 397 212 124**
96 600 592	**1 397 212 119**
96 600 652	**1 397 212 118**
96 605 913	**1 397 212 002**
96 803 275	**1 397 212 124**
96 803 276	**1 397 212 125**
96 805 660	**0 280 755 081**
96 807 568	**0 280 755 084**
9999 163 554	**0 280 230 006**

PIAGGIO

638562	**0 261 230 101**
639366	**0 261 210 151**
640134	**0 281 002 825**
640600	**0 281 002 511**
8133932	**0 265 007 684**
832029	**0 261 210 240**

PININFARINA

M28MN 116462	**0 265 007 683**
M28MR955037	**0 265 007 638**
M28MR955352	**0 265 005 289**
M28M01102857	**0 265 007 637**
M288651A026	**0 265 005 504**
084036	**1 397 212 021**
102857	**0 265 005 637**
116462	**0 265 007 683**
284670A228	**0 265 005 625**
465598040	**0 281 002 309**
551905870	**0 281 002 764**
551987170	**0 281 002 771**
552003010	**0 281 002 784**
8133931	**0 265 008 037**
93946739156	**0 265 007 059**
93951759244	**0 265 007 629**
93951768620	**0 265 007 678**
93951797783	**0 261 230 173**
93951799347	**0 265 008 055**
93951799348	**0 265 008 056**
93955187722	**0 280 218 164**
93955187722	**0 986 280 241**
93955190587	**0 281 002 764**
93955196385	**0 280 218 182**
93955198717	**0 281 002 771**
93955200301	**0 281 002 784**
93960684944	**1 397 212 011**

PORSCHE

022 906 301	**0 280 200 001**
039 906 051	**0 280 100 043**
039 906 111 A	**0 280 120 032**
124 540 231 7	**0 265 002 109**
3B0 955 559	**1 397 212 028**
473 906 301	**0 280 201 002**
7L0 955 559	**1 397 212 031**
7L0 955 559 A	**1 397 212 028**
7L0 955 559 B	**1 397 212 030**
7L0 955 559 C	**1 397 212 027**
7L0 955 559 C	**1 397 212 028**
7L5 905 381	**0 261 210 239**
7L5 905 381 A	**0 261 210 292**
7L5 906 461 A	**0 280 218 141**
7L5 919 275	**0 263 003 685**
7L5 919 275 M2Z	**0 263 003 683**
7L5 919 275 M3E	**0 263 003 684**
7L5 919 275 R7M	**0 263 003 725**
9A1 606 112 00	**0 261 210 300**
901 615 113 00	**0 336 611 006**
902 615 113 00	**0 336 611 004**
911 110 360 00	**0 438 120 004**
911 110 938 00	**0 438 120 004**
911 110 949 00	**0 438 120 004**
911 110 951 00	**0 438 120 002**
911 110 965 00	**0 438 120 070**
911 110 973 00	**0 438 120 118**
911 110 975 00	**0 438 120 143**
911 110 979 00	**0 438 120 149**
911 606 141 00	**0 261 231 008**
911 606 151 00	**0 280 101 001**
911 606 151 00	**0 280 101 002**
911 606 215 00	**0 261 210 002**
911 606 215 01	**0 261 210 005**
911 606 217 00	**0 261 210 125**
911 606 217 01	**0 261 210 046**
911 606 217 02	**0 261 210 046**
911 606 217 03	**0 261 210 059**
923 606 111 00	**0 280 201 006**
923 606 111 00	**0 986 280 060**
923 615 101 00	**0 332 514 103**
928 110 905 00	**0 438 120 049**
928 110 905 01	**0 438 120 107**
928 110 905 02	**0 438 120 142**
928 606 121 BX	**0 986 280 064**
928 606 121 01	**0 280 203 009**
928 606 121 01	**0 280 203 015**
928 606 121 01	**0 986 280 064**
928 606 121 02	**0 280 203 015**
928 606 121 02	**0 986 280 064**
928 606 125 01	**0 280 130 023**
928 606 126 00	**0 280 130 032**
928 606 141	**0 986 280 124**
928 606 141 X	**0 280 214 001**
928 606 141 00	**0 280 214 001**
928 606 141 00	**0 986 280 124**
928 606 143 00	**0 280 130 039**
928 606 144 00	**0 261 231 036**
928 606 153 00	**0 265 005 100**
928 606 157 00	**0 280 120 322**
928 606 157 01	**0 280 120 437**
928 606 402 00	**0 265 001 053**
928 606 402 01	**0 265 001 118**
928 606 404 0	**0 265 001 054**
928 606 404 00	**0 265 001 053**
928 606 404 01	**0 265 001 119**
928 606 404 01	**0 265 006 141**
928 606 404 02	**0 265 006 141**
930 110 803 00	**0 438 120 024**
930 110 803 00	**0 438 120 024**
930 110 805 00	**0 438 120 017**
930 110 907 00	**0 438 120 085**
930 110 924 00	**0 438 120 205**
930 606 013 00	**0 280 130 034**
930 606 013 01	**0 280 130 059**
930 606 013 02	**0 280 130 059**
930 606 119 00	**0 280 120 214**
930 606 119 01	**0 280 120 216**
930 606 119 02	**0 280 120 309**
930 606 123 X	**0 280 203 023**
930 606 123 X	**0 986 280 026**
930 606 123 00	**0 280 203 023**
930 606 123 00	**0 986 280 026**

P

◀ PORSCHE

930 606 915 00	**0 280 130 070**
931 110 906 00	**0 438 120 091**
931 110 906 01	**0 438 120 092**
931 110 906 02	**0 438 120 141**
931 110 906 03	**0 438 120 152**
931 606 119 00	**0 280 120 301**
931 606 119 01	**0 280 120 107**
944 606 113 01	**0 280 120 308**
944 606 115 00	**0 261 210 003**
944 606 116 00	**0 280 122 001**
944 606 116 01	**0 280 122 004**
944 606 121 AX	**0 280 202 064**
944 606 121 AX	**0 986 280 041**
944 606 121 X	**0 280 202 028**
944 606 121 X	**0 986 280 037**
944 606 121 00	**0 280 202 028**
944 606 121 00	**0 986 280 037**
944 606 121 01	**0 280 202 064**
944 606 121 01	**0 986 280 041**
944 606 124 X	**0 280 203 029**
944 606 124 X	**0 986 280 048**
944 606 124 00	**0 280 203 029**
944 606 124 00	**0 986 280 048**
944 606 125 00	**0 280 130 026**
944 606 129 00	**0 261 220 001**
944 606 145 00	**0 261 231 006**
944 606 170 00	**0 232 101 005**
944 606 170 01	**0 232 101 005**
944 606 170 02	**0 232 101 013**
944 606 401 00	**0 265 001 146**
944 606 401 02	**0 265 006 142**
944 609 121 00	**0 280 202 028**
944 609 121 00	**0 986 280 037**
948 605 115 02	**0 280 750 114**
948 605 115 03	**0 280 750 114**
951 093 110 07	**0 261 231 001**
951 606 113 00	**0 280 120 400**
951 606 121 AX	**0 280 203 026**
951 606 121 AX	**0 986 280 042**
951 606 121 01	**0 280 203 026**
951 606 121 01	**0 986 280 042**
951 606 125 01	**0 280 213 017**
951 606 125 01	**0 986 280 139**
951 606 125 02	**0 280 213 017**
951 606 125 02	**0 986 280 139**
951 606 141 00	**0 261 231 001**
955 605 062 00	**0 280 750 008**
955.606.106.00	**0 232 103 019**
955.606.106.00	**0 232 103 020**
955 606 123 00	**0 280 218 071**
955 606 123 00	**0 280 218 072**
955 606 123 00	**0 986 280 221**
955 606 123 31	**0 281 002 435**
955 606 123 35	**0 280 218 141**
955 606 123 40	**0 280 218 198**
955 606 180 00	**0 261 230 042**
955 606 275 00	**0 263 003 187**
955 606 371 00	**0 261 210 192**
955 606 371 00	**0 261 210 193**
955 606 381 00	**0 261 210 239**
955 606 381 10	**0 261 210 292**
955 618 506 00	**1 397 212 028**
955 618 506 00	**1 397 212 095**
955 618 506 01	**1 397 212 095**
955 618 506 10	**1 397 212 031**
955 618 506 11	**1 397 212 097**
955 618 507 00	**1 397 212 027**
955 618 507 01	**1 397 212 094**
955 618 507 10	**1 397 212 030**
955 618 507 11	**1 397 212 096**
955 618 516 00	**1 397 212 089**
955 618 517 00	**1 397 212 090**
955 618 518 00	**1 397 212 082**
955 618 518 01	**1 397 212 115**
955.618.518.02	**1 397 212 129**
956 606 125 00	**0 280 218 055**
959 606 173 00	**0 265 005 004**
964 110 910 00	**0 438 120 221**
964 606 115 00	**0 280 120 416**
964 606 115 00	**0 280 120 417**
964 606 141 00	**0 261 231 018**
964 606 141 00	**0 261 231 030**
964 606 402 01	**0 265 001 230**
964 606 402 02	**0 265 006 146**
964 606 403 02	**0 265 006 145**
964 606 404 01	**0 265 001 229**
964 606 404 02	**0 265 006 144**
965 606 116 00	**0 261 220 001**
965 606 116 00	**0 261 220 002**
986 606 112 00	**0 261 210 149**
986 606 112 00	**0 261 210 204**
986 606 112 01	**0 261 210 149**
986 606 112 01	**0 261 210 204**
986 606 112 02	**0 261 210 204**
986 606 112 03	**0 261 210 248**
986 606 125 01	**0 280 218 055**
987 606 125 00	**0 280 218 145**
987 606 165 00	**0 280 218 218**
993 606 013 00	**0 280 130 097**
993 606 113 00	**0 280 130 073**
993 606 114 00	**0 280 130 085**
993 606 123 00	**0 280 217 803**
993 606 123 01	**0 280 217 803**
993 606 124 00	**0 280 217 809**
993 606 124 01	**0 280 217 809**
993 606 141 00	**0 261 231 118**
993 606 153 00	**0 265 005 108**
993 606 217 00	**0 261 210 125**
993 606 217 01	**0 261 210 136**
993 606 402 00	**0 265 006 101**
993 606 404 00	**0 265 006 107**
993 606 405 00	**0 265 006 107**
996 605 115 00	**0 280 750 008**
996 605 115 00	**0 280 750 009**
996 605 115 00	**0 280 750 010**
996 605 115 01	**0 280 750 008**
996 606 105 00	**0 261 210 205**
996 606 105 01	**0 261 210 249**
996 606 106 01	**0 232 103 012**
996 606 106 01	**0 232 103 037**
996 606 106 02	**0 232 103 022**
996 606 106 03	**0 232 103 040**
996 606 108 00	**0 265 005 122**
996 606 109 00	**0 265 005 450**
996 606 109 01	**0 265 005 450**
996 606 109 02	**0 265 005 450**
996 606 110 00	**0 265 005 212**
996 606 110 01	**0 265 005 212**
996 606 112 00	**0 261 210 149**
996 606 112 00	**0 261 210 204**
996 606 112 01	**0 261 210 149**
996 606 112 01	**0 261 210 204**
996 606 113 00	**0 280 130 092**
996 606 113 01	**0 280 130 123**
996 606 115 00	**0 280 752 010**
996 606 115 01	**0 280 752 010**
996 606 116 00	**0 280 122 016**
996 606 117 00	**0 265 005 224**
996 606 119 00	**0 265 005 450**
996 606 121 00	**0 261 231 120**
996 606 123 00	**0 280 217 007**
996 606 124 00	**0 280 218 009**
996 606 125 00	**0 261 231 148**
996 606 145 00	**0 265 005 250**
996 606 147 00	**0 265 005 247**
996 606 147 00	**0 265 005 250**
996 606 180 00	**0 261 230 042**
996 606 205 00	**0 261 230 015**
996 606 223 9A	**0 280 130 026**
996 606 230 9C	**0 261 230 004**
996 606 406 00	**0 265 006 344**
996 606 407 02	**0 265 007 439**
997 605 115 00	**0 280 750 008**
997 606 106 00	**0 232 103 057**
997 606 106 01	**0 232 103 057**
997 606 121 00	**0 261 231 173**
997 606 125 00	**0 280 218 192**
997 606 145 00	**0 265 005 645**
997 606 145 01	**0 265 005 645**
997 606 145 02	**0 265 005 645**
997 606 145 05	**0 265 005 746**
997 606 203 00	**0 261 230 147**
997 606 203 01	**0 261 230 147**
997 606 407 00	**0 265 007 624**
997 606 407 01	**0 265 007 624**

PSA (PEUGEOT S.A.)

E8163	**0 280 217 112**
V7 535 06980	**0 261 230 134**
V7 539 81180	**0 261 230 136**
V7 540 50880	**0 261 230 135**
V7 550 79880	**0 232 103 064**
V7 552 11480	**0 261 231 198**
V7 566 05280	**0 232 103 064**
V7 570 19180	**0 232 103 064**
14 008 99580	**0 265 007 791**
14 009 68980	**0 265 007 130**
14 009 69180	**0 265 007 131**
14 009 71980	**0 265 007 791**
14 010 40880	**0 265 007 791**
14 916 61080	**0 265 006 730**
14 938 83080	**0 265 007 084**
14 999 36080	**0 265 007 790**
14 999 38080	**0 265 007 791**
1601 Y8	**0 280 755 124**
1601 Y9	**0 280 755 126**
1601 Z0	**0 280 755 125**
1601 Z1	**0 280 755 127**
91 5410 2780	**0 261 210 043**
96 286 48280	**0 261 231 130**
96 354 93480	**0 261 230 041**
96 358 84080	**0 280 750 085**
96 393 81480	**0 261 230 043**
96 394 18880	**0 261 230 057**
96 394 18980	**0 261 230 058**
96 430 93280	**0 280 752 241**
96 449 39680	**0 280 752 241**
96 453 11480	**0 261 231 169**
96 467 02180	**0 280 752 251**
96 494 00180	**0 265 005 291**
96 494 00180	**0 265 005 714**
96 495 10080	**0 280 750 164**
96 497 76180	**0 265 005 606**
96 499 04380	**0 265 005 292**
96 503 41880	**0 280 755 013**
96 503 41880	**0 280 755 018**
96 504 52180	**0 265 005 290**
96 511 98380	**0 280 755 019**
96 512 70180	**0 280 755 041**
96 512 70280	**0 280 755 043**
96 515 04280	**0 280 755 011**
96 519 69380	**0 265 007 707**
96 526 96780	**0 265 007 664**
96 527 70080	**0 280 755 015**
96 531 05280	**0 280 755 036**
96 531 05880	**0 280 755 038**
96 531 05980	**0 280 755 032**
96 535 67880	**0 280 755 083**
96 536 63180	**0 265 007 789**
96 544 05580	**0 280 755 040**

P

96 544 05980	**0 280 755 099**
96 544 06180	**0 280 755 042**
96 544 06380	**0 280 755 082**
96 544 38180	**0 280 755 019**
96 547 25380	**0 280 755 044**
96 547 45380	**0 280 755 045**
96 548 77480	**0 280 755 026**
96 552 70080	**0 265 007 788**
96 554 67180	**0 280 755 035**
96 554 67380	**0 280 755 037**
96 555 02480	**0 280 755 031**
96 555 02580	**0 280 755 033**
96 571 23280	**0 265 005 629**
96 583 73780	**1 397 212 105**
96 584 20780	**0 265 007 779**
96 585 99880	**0 265 007 883**
96 586 43980	**0 280 755 075**
96 586 52980	**0 280 755 079**
96 586 84180	**0 265 005 517**
96 588 69180	**1 397 212 112**
96 588 69280	**1 397 212 086**
96 590 59580	**0 261 230 156**
96 594 49880	**0 280 755 074**
96 594 49980	**0 280 755 078**
96 594 85480	**1 397 212 116**
96 594 85780	**1 397 212 117**
96 598 78780	**0 280 755 077**
96 598 79480	**0 280 755 076**
96 598 79580	**0 280 755 080**
96 600 59180	**1 397 212 118**
96 600 59280	**1 397 212 119**
96 606 03480	**0 261 230 131**
96 606 03480	**0 261 230 132**
96 615 03980	**0 280 755 095**
96 615 04180	**0 280 755 097**
96 618 09080	**0 280 750 164**
96 619 74980	**0 265 008 017**
96 619 75080	**0 265 008 018**
96 622 89780	**0 265 005 629**
96 629 37380	**0 265 005 486**
96 631 38180	**0 265 005 715**
96 631 87680	**0 265 005 714**
96 634 67180	**1 397 212 132**
96 639 32180	**0 265 005 724**
96 803 27580	**1 397 212 124**
96 803 27680	**1 397 212 125**
96 805 05280	**1 397 212 126**
96 805 65880	**0 280 755 041**
96 805 66080	**0 280 755 081**
96 807 56880	**0 280 755 084**
96 808 21780	**1 397 212 127**
96 808 21980	**1 397 212 128**
96 811 24880	**0 280 755 100**
96 814 34380	**0 280 755 102**
96 819 90080	**0 280 755 103**

96 821 96080	**1 397 212 136**
96 821 96180	**1 397 212 137**
96 826 22980	**0 280 755 094**
96 826 48580	**0 280 755 096**
96 830 01580	**0 280 755 122**
96 830 01780	**0 280 755 123**
96 832 02380	**1 397 212 134**
96 839 72880	**1 397 212 143**
96 843 78880	**0 280 755 120**
96 843 79280	**0 280 755 121**
96 848 34480	**0 280 755 117**
96 848 34580	**0 280 755 118**

RENAULT

00 03 586 006	**0 331 101 014**
00 11 068 986	**0 261 210 055**
08 70 399 600	**0 331 101 002**
18 00 500 01R	**0 280 755 085**
18 00 500 02R	**0 280 755 088**
18 00 500 03R	**0 280 755 087**
18 00 500 04R	**0 280 755 089**
50 00 409 318	**0 332 204 101**
50 00 790 462	**0 204 154 001**
50 01 824 508	**0 331 101 016**
50 01 853 014	**0 281 002 405**
50 01 853 015	**0 281 002 311**
50 01 867 660	**0 281 002 534**
50 10 143 029	**0 265 050 109**
50 10 143 030	**0 265 050 110**
50 10 143 031	**0 265 050 141**
50 10 143 032	**0 265 050 142**
50 10 143 084	**0 484 205 004**
50 10 143 519	**0 205 001 205**
50 10 151 547	**0 265 050 011**
50 10 190 356	**0 206 001 007**
50 10 207 164	**0 206 001 019**
50 10 236 261	**0 281 002 087**
50 10 236 265	**0 281 002 089**
50 10 236 266	**0 205 001 201**
50 10 412 448	**0 281 002 316**
50 10 412 449	**0 261 210 151**
50 10 412 449	**0 281 002 315**
50 10 412 450	**0 281 002 209**
50 10 437 074	**0 281 002 206**
50 10 437 653	**0 281 002 576**
50 10 437 746	**0 281 002 614**
50 10 450 894	**0 281 002 576**
50 10 512 742	**0 205 001 204**
51 00 101 976	**0 331 101 004**
58 21 051 500	**1 397 212 077**
60 00 581 611	**0 280 130 107**
60 00 581 616	**0 261 210 152**

60 01 020 677	**0 265 001 170**
60 01 020 678	**0 265 001 169**
60 01 020 679	**0 265 001 171**
60 01 020 680	**0 265 001 172**
60 01 021 402	**0 265 005 004**
60 01 021 402	**0 265 005 041**
60 01 024 812	**0 265 001 311**
60 01 024 813	**0 265 001 310**
60 01 024 814	**0 265 001 309**
60 01 052 003	**0 332 014 411**
60 25 303 224	**0 265 006 284**
60 25 304 654	**0 265 006 282**
60 25 304 655	**0 265 006 283**
60 25 402 447	**0 265 005 416**
60 40 000 691	**0 265 006 711**
60 40 002 862	**0 265 006 744**
60 40 002 893	**0 265 006 745**
60 40 002 895	**0 265 006 746**
60 40 002 896	**0 265 006 747**
60 40 004 524	**0 265 007 529**
60 40 004 527	**0 265 007 528**
60 40 004 542	**0 265 007 583**
60 40 004 543	**0 265 007 582**
60 40 004 808	**0 265 007 534**
60 40 004 809	**0 265 007 533**
60 40 004 810	**0 265 007 532**
60 40 004 811	**0 265 007 531**
60 40 005 449	**0 265 007 606**
60 40 005 450	**0 265 007 607**
60 40 005 494	**0 265 007 597**
67 00 001 748	**0 265 005 529**
74 00 269 548	**0 335 541 006**
74 01 306 024	**0 280 130 028**
74 01 367 645	**0 261 210 029**
74 03 507 697	**0 280 217 107**
74 20 452 258	**0 281 002 575**
74 39 146 108	**0 232 101 030**
77 00 100 572	**0 280 217 107**
77 00 100 572	**0 281 002 195**
77 00 100 650	**0 281 002 175**
77 00 104 747	**0 281 002 221**
77 00 107 123	**0 281 002 255**
77 00 110 571	**0 281 002 349**
77 00 267 269	**0 280 230 112**
77 00 267 388	**0 280 130 026**
77 00 271 090	**0 261 231 006**
77 00 272 242	**0 265 003 118**
77 00 272 242	**0 265 006 735**
77 00 272 243	**0 265 003 120**
77 00 272 243	**0 265 006 737**
77 00 272 244	**0 265 003 119**
77 00 272 244	**0 265 006 736**
77 00 301 311	**0 265 006 400**
77 00 301 312	**0 265 006 401**
77 00 301 315	**0 265 006 386**

77 00 301 316	**0 265 006 387**
77 00 305 115	**0 265 006 157**
77 00 305 116	**0 265 006 156**
77 00 305 117	**0 265 006 155**
77 00 305 118	**0 265 006 154**
77 00 306 256	**0 281 002 093**
77 00 308 256	**0 205 001 208**
77 00 313 681	**0 265 006 528**
77 00 377 184	**0 261 210 113**
77 00 411 745	**0 265 006 384**
77 00 411 746	**0 265 006 385**
77 00 411 747	**0 265 006 383**
77 00 413 230	**0 206 001 021**
77 00 415 681	**0 265 006 383**
77 00 415 682	**0 265 006 384**
77 00 415 683	**0 265 006 385**
77 00 417 967	**0 265 006 363**
77 00 417 968	**0 265 006 361**
77 00 417 969	**0 265 006 362**
77 00 419 589	**0 281 002 274**
77 00 421 068	**0 265 006 442**
77 00 421 069	**0 265 006 443**
77 00 421 070	**0 265 006 444**
77 00 434 097	**0 265 005 417**
77 00 545 776	**0 280 100 031**
77 00 545 777	**0 280 120 011**
77 00 545 778	**0 280 130 006**
77 00 545 779	**0 280 130 014**
77 00 545 853	**0 332 003 027**
77 00 569 162	**0 280 120 018**
77 00 582 688	**0 280 130 023**
77 00 582 696	**0 280 201 001**
77 00 582 697	**0 280 120 203**
77 00 586 529	**0 332 514 101**
77 00 586 529	**0 332 514 103**
77 00 679 443	**0 280 200 027**
77 00 680 341	**0 280 120 301**
77 00 682 115	**0 332 514 121**
77 00 683 389	**0 332 015 012**
77 00 708 958	**0 280 200 036**
77 00 708 960	**0 280 230 001**
77 00 708 960	**0 280 230 005**
77 00 709 620	**0 280 200 035**
77 00 715 635	**0 280 202 049**
77 00 715 635	**0 986 280 053**
77 00 715 675	**0 280 230 005**
77 00 717 549	**0 265 001 071**
77 00 717 550	**0 265 001 069**
77 00 720 786	**0 280 101 001**
77 00 721 268	**0 280 230 006**
77 00 723 330	**0 280 200 043**
77 00 730 103	**0 280 230 115**
77 00 739 427	**0 280 130 032**
77 00 749 185	**0 265 001 242**
77 00 749 187	**0 265 001 243**

R

◀ RENAULT

77 00 749 188	**0 265 005 012**
77 00 749 188	**0 265 005 038**
77 00 755 370	**0 265 001 070**
77 00 755 371	**0 265 001 068**
77 00 772 309	**0 265 001 069**
77 00 772 310	**0 265 001 068**
77 00 794 541	**0 204 154 005**
77 00 794 542	**0 204 154 006**
77 00 796 159	**0 204 154 004**
77 00 806 172	**0 265 003 067**
77 00 806 172	**0 265 006 442**
77 00 806 173	**0 265 003 069**
77 00 806 173	**0 265 006 443**
77 00 806 174	**0 265 003 068**
77 00 806 174	**0 265 006 444**
77 00 807 607	**0 265 003 067**
77 00 807 608	**0 265 003 068**
77 00 807 609	**0 265 003 069**
77 00 810 688	**0 265 003 082**
77 00 810 688	**0 265 006 361**
77 00 810 689	**0 265 003 083**
77 00 810 689	**0 265 006 362**
77 00 810 690	**0 265 003 084**
77 00 810 690	**0 265 006 363**
77 00 815 767	**0 265 005 104**
77 00 815 767	**0 265 005 111**
77 00 859 31	**0 261 210 137**
77 00 871 678	**0 261 231 046**
77 01 024 622	**0 438 120 120**
77 01 026 739	**0 438 120 133**
77 01 030 600	**0 438 121 021**
77 01 032 558	**0 438 121 048**
77 01 047 921	**0 280 122 001**
77 01 048 994	**0 281 002 405**
77 01 055 704	**0 281 002 534**
77 01 056 064	**0 281 002 568**
77 01 056 064	**0 281 002 865**
77 01 062 395	**0 281 002 740**
77 01 068 374	**0 281 002 865**
77 01 068 387	**0 281 002 522**
77 01 069 617	**0 281 002 867**
77 02 218 698	**0 280 130 068**
77 02 218 698	**0 280 130 107**
77 02 218 699	**0 261 210 137**
77 11 120 019	**0 280 750 154**
82 00 001 914	**1 397 212 001**
82 00 001 914	**1 397 212 004**
82 00 001 914	**1 397 212 015**
82 00 014 888	**1 397 212 018**
82 00 026 737	**0 265 005 417**
82 00 026 739	**0 265 005 232**
82 00 026 739	**0 265 005 259**
82 00 026 739	**0 265 005 263**
82 00 026 739	**0 265 005 264**
82 00 043 135	**0 265 007 467**
82 00 043 136	**0 265 007 468**
82 00 058 186	**0 265 006 710**
82 00 058 187	**0 265 006 711**
82 00 063 060	**1 397 212 018**
82 00 071 210	**1 397 212 018**
82 00 071 210	**1 397 212 035**
82 00 071 290	**1 397 212 035**
82 00 074 266	**0 265 005 259**
82 00 074 266	**0 265 005 263**
82 00 120 636	**0 265 005 441**
82 00 124 508	**0 280 218 079**
82 00 146 271	**0 281 002 573**
82 00 155 613	**0 281 002 552**
82 00 168 253	**0 281 002 566**
82 00 173 959	**0 265 006 746**
82 00 173 960	**0 265 006 747**
82 00 173 963	**0 265 006 744**
82 00 173 966	**0 265 006 745**
82 00 186 294	**0 265 007 527**
82 00 186 298	**0 265 007 535**
82 00 186 299	**0 265 007 536**
82 00 189 385	**0 280 750 154**
82 00 189 385	**0 280 750 155**
82 00 189 766	**0 281 002 588**
82 00 194 432	**0 281 002 573**
82 00 195 825	**0 265 007 596**
82 00 195 828	**0 265 007 606**
82 00 195 830	**0 265 007 607**
82 00 195 832	**0 265 007 527**
82 00 195 832	**0 265 007 597**
82 00 206 489	**0 281 002 589**
82 00 212 693	**0 265 007 534**
82 00 212 695	**0 265 007 532**
82 00 212 696	**0 265 007 533**
82 00 212 698	**0 265 007 531**
82 00 225 971	**0 281 002 593**
82 00 233 831	**0 281 002 616**
82 00 254 681	**0 265 007 529**
82 00 254 685	**0 265 007 528**
82 00 254 687	**0 265 007 583**
82 00 254 688	**0 265 007 582**
82 00 254 688	**0 266 007 582**
82 00 292 433	**0 281 002 740**
82 00 310 109	**0 281 002 589**
82 00 346 992	**0 265 007 467**
82 00 356 172	**0 281 002 945**
82 00 375 080	**0 281 002 709**
82 00 391 398	**0 281 002 796**
82 00 391 398	**0 281 002 921**
82 00 415 812	**0 265 007 792**
82 00 415 812	**0 265 007 890**
82 00 417 006	**1 397 212 084**
82 00 417 006	**1 397 212 140**
82 00 418 270	**0 281 002 920**
82 00 418 820	**0 281 002 834**
82 00 419 177	**0 265 007 742**
82 00 440 544	**0 265 007 809**
82 00 440 551	**0 265 007 810**
82 00 440 561	**0 265 007 811**
82 00 441 401	**0 265 007 936**
82 00 441 403	**0 265 007 937**
82 00 441 404	**0 265 007 938**
82 00 441 620	**0 265 007 939**
82 00 441 622	**0 265 007 940**
82 00 457 357	**0 265 007 793**
82 00 457 357	**0 265 007 891**
82 00 457 358	**0 265 007 794**
82 00 457 358	**0 265 007 892**
82 00 469 905	**0 281 002 772**
82 00 485 061	**0 265 005 701**
82 00 576 683	**0 281 002 836**
82 00 600 208	**0 281 002 867**
82 00 703 127	**0 281 002 915**
82 00 703 127	**0 281 002 916**
82 00 703 127	**0 281 002 944**
82 00 750 883	**0 281 002 573**
82 00 781 987	**0 265 005 529**
82 00 804 554	**0 265 005 416**
96 12 765 880	**0 261 231 070**
96 28 648 480	**0 261 231 125**
96 31 813 680	**0 261 230 034**
96 35 493 480	**0 261 230 041**

ROLLS-ROYCE

PB 100609 PC	**0 261 231 165**
PB 107265 PA	**0 280 130 093**
PB 115625 PA	**0 280 130 086**
PF 100607 PA	**0 261 210 147**
PF 100607 PA	**0 261 210 148**
PF 100607 PB	**0 261 210 252**
PF 100607 PB	**0 261 210 253**
PF 100607 PB	**0 261 210 254**
PF 100607 PB	**0 261 210 256**
PF 100608 PA	**0 232 103 026**
PF 100636 PB	**0 281 002 400**
PF 100765 PA	**0 280 750 127**
PF 100765 PA	**0 280 750 128**
PF 101317 PA	**0 280 218 074**
PF 101318 PA	**0 280 752 037**
PF 107942	**0 280 752 037**
PF 107942 PA	**0 280 752 037**
UD 22452	**0 332 204 101**
UE 45749	**0 280 120 300**
UE 70074	**0 281 002 018**
UE 71609	**0 261 210 029**
UE 71610	**0 280 130 026**
UE 72296	**0 261 210 047**
UE 73585	**0 280 120 407**
UE 74159	**0 280 217 801**
UE 74490	**0 280 130 039**
UE 74654	**0 280 122 007**
UE 75265	**0 261 230 004**
UR 27227	**0 265 001 140**
UR 27227	**0 265 006 350**
UR 27419	**0 265 001 139**
UR 27419	**0 265 006 348**
UR 27420	**0 265 001 138**
UR 27420	**0 265 006 349**
UT 12022	**0 280 130 060**
UT 14052 PA	**0 265 006 349**
UT 14053	**0 265 006 348**
UT 14053 PA	**0 265 006 348**
UT 14054	**0 265 006 350**
UT 14505 PB	**0 265 006 350**
036 906 051 C	**0 261 230 054**
038 906 051 B	**0 281 002 400**
06A 905 161 A	**0 232 103 020**
07C 133 062 A	**0 280 750 157**
07C 133 062 A	**0 280 750 158**
07C 906 018 H	**0 261 210 047**
077 133 062 C	**0 280 750 128**
1U0 919 275	**0 263 003 187**
3B0 955 559 A	**1 397 212 012**
3D0 919 275 B	**0 263 003 224**
3D0 919 275 B	**0 263 003 244**
3W0 955 559	**1 397 212 078**
3W0 955 559 A	**1 397 212 078**
3W5 955 559 B	**1 397 212 012**
3W5 955 559 B	**1 397 212 120**
3W5 955 559 C	**1 397 212 121**
3W7 920 840 D	**0 265 001 138**
3Z0 963 535	**0 280 130 093**
8E0 907 637 A	**0 265 005 245**
8E0 907 637 B	**0 265 005 618**

ROVER

AMR 5707	**0 281 002 182**
ERR 2079	**0 261 210 028**
ERR 2079	**0 281 002 104**
ERR 2080	**0 205 001 011**
ERR 2080	**0 205 001 021**
ERR 2081	**0 280 130 026**
ERR 2082	**0 280 130 039**
ERR 2082A	**0 280 130 039**
ERR 2083	**0 281 002 063**
ERR 2708	**0 205 001 006**
ERR 4645	**0 281 002 107**
ERR 7107	**0 205 001 040**
ERR 7171	**0 280 217 532**

ERR 7322	**0 280 122 016**
ERR 7352	**0 261 210 155**
ERR 7354	**0 261 210 158**
LR 000467	**1 397 212 103**
LR 000467	**1 397 212 104**
LR 000524	**0 261 230 108**
LR 000634	**0 232 103 052**
LR 000634	**0 232 103 053**
LR 005490	**0 261 230 108**
LR 005493	**0 261 230 108**
MHK 000230	**0 280 217 814**
MHK 100360	**0 281 002 120**
MHK 100410	**0 281 002 119**
MHK 100410	**0 281 002 389**
MHK 100410 L	**0 281 002 389**
MHK 100640	**0 281 002 205**
MHK 100800	**0 280 218 010**
MHK 100850	**0 281 002 182**
MHK 101070	**0 280 218 012**
MHK 101130	**0 928 400 357**
MHK 101130	**0 928 400 520**
MHK 101190	**0 281 002 389**
MHK 101190 A	**0 281 002 389**
MJC 100031	**0 281 002 329**
MSJ 100070	**0 281 002 370**
MVK 000010	**0 281 002 291**
NSC 100110	**0 281 002 121**
NSC 100430	**0 281 002 145**
NSC 100650	**0 261 231 140**
NSC 500600	**0 261 231 186**
SLC 100180	**0 281 002 310**
SRB 000010	**0 265 005 248**
SRO 000010	**0 265 005 248**
SRO 000020	**0 265 005 283**
SRO 000020	**0 265 005 639**
SRO 500140	**0 265 005 654**
SRO 500140	**0 265 005 655**
SSB 000140	**0 265 005 303**
SSB 10002	**0 265 003 057**
SSB 10002	**0 265 006 473**
SSB 10003	**0 265 003 058**
SSB 10003	**0 265 006 474**
SSB 10006	**0 265 003 059**
SSB 10006	**0 265 006 475**
SSB 10007	**0 265 003 060**
SSB 10007	**0 265 006 473**
SSB 10007	**0 265 006 476**
SSB 10008	**0 265 001 320**
SSB 10022	**0 265 006 103**
SSB 10023	**0 265 006 104**
SSB 10024	**0 265 006 105**
SSB 10025	**0 265 006 106**
SSB 100640	**0 265 006 307**
SSB 10066	**0 265 006 167**
SSB 10067	**0 265 006 170**
SSB 100670	**0 265 006 168**
SSB 100680	**0 265 006 169**
SSB 10069	**0 265 006 168**
SSB 100690	**0 265 006 170**
SSB 100700	**0 265 006 259**
SSB 100710	**0 265 006 258**
SSB 100720	**0 265 006 268**
SSB 100730	**0 265 006 267**
SSB 10075	**0 265 006 305**
SSB 100780	**0 265 006 167**
SSB 100790	**0 265 006 269**
SSB 100881	**0 265 006 270**
SSB 100891	**0 265 006 271**
SSB 10092	**0 265 006 306**
SSB 100920	**0 265 006 305**
SSB 100930	**0 265 006 306**
SSB 500090	**0 265 007 650**
SSB 500091	**0 265 007 738**
SSB 500092	**0 265 007 923**
SSB 500100	**0 265 007 651**
SSB 500100	**0 265 007 922**
SSB 500102	**0 265 007 922**
SSB 500132	**0 265 007 778**
SSB 500133	**0 265 007 924**
STC 4768	**0 281 002 909**
WKW 000070	**0 261 230 046**
2 A M 73243 A	**0 280 202 046**
2 A M 73243 A	**0 986 280 027**
3991033	**0 261 231 138**

RVI (RENAULT VEHICULES IND.)

00 08 670 113	**0 280 218 109**
26 505 010 9031	**0 265 050 109**
50 10 412 449	**0 261 210 151**
50 10 412 449	**0 281 002 315**
50 10 437 653	**0 281 002 576**
74 20 374 282	**0 281 002 459**
74 20 374 299	**0 281 002 450**
74 20 513 340	**0 281 002 744**
74 20 513 343	**0 281 002 742**
74 20 524 936	**0 281 002 743**
74 207 745	**0 280 218 089**
74 20 774 533	**0 280 218 089**
74 20 993 000	**0 261 230 150**

SAAB (SAAB AUTOMOBILE AB)

750 161	**0 280 120 300**
75 01 612	**0 280 120 300**
75 38 655	**0 280 212 013**
75 38 655	**0 986 280 109**
75 38 663	**0 280 212 011**
75 38 663	**0 986 280 131**
756 356	**0 280 130 055**
75 63 562	**0 280 130 055**
75 68 655	**0 280 212 013**
75 68 655	**0 986 280 109**
75 68 800	**0 261 231 006**
75 68 801	**0 261 231 006**
75 91 183	**0 280 212 014**
75 91 183	**0 986 280 108**
78 72 385	**0 280 212 022**
78 72 385	**0 986 280 133**
78 72 393	**0 280 212 018**
83 22 497	**0 438 120 009**
83 33 288	**0 438 120 046**
83 37 701	**0 438 120 050**
835 069	**0 280 120 030**
83 50 696	**0 280 120 030**
83 50 712	**0 280 100 115**
83 54 938	**0 280 100 118**
83 76 022	**0 280 100 009**
83 76 030	**0 280 120 010**
83 76 030	**0 280 120 036**
83 76 105	**0 332 003 021**
837 611	**0 280 130 006**
83 76 113	**0 280 130 006**
837 612	**0 280 130 009**
837 612	**0 280 130 014**
83 76 121	**0 280 130 014**
83 80 701	**0 280 100 018**
83 88 076	**0 438 120 003**
83 88 076	**0 438 120 013**
87 88 200	**0 280 130 032**
88 17 967	**0 280 212 017**
88 17 967	**0 986 280 119**
88 17 975	**0 280 212 011**
88 17 975	**0 986 280 131**
88 18 296	**0 280 212 005**
88 18 296	**0 986 280 112**
88 18 304	**0 280 212 009**
88 18 304	**0 986 280 135**
88 23 221	**0 280 212 013**
88 23 221	**0 986 280 109**
88 23 239	**0 280 212 014**
88 23 239	**0 986 280 108**
88 26 778	**0 280 212 019**
88 26 778	**0 986 280 117**
88 27 429	**0 280 213 012**
88 27 429	**0 986 280 110**
88 27 453	**0 280 212 018**
88 27 461	**0 280 212 022**
88 27 461	**0 986 280 133**
88 27 479	**0 280 213 012**
88 27 479	**0 986 280 110**
88 57 195	**0 280 122 001**
89 78 280	**0 280 212 017**
89 78 280	**0 986 280 119**
89 81 573	**0 438 120 219**
90 202 252	**0 281 002 539**
90 202 252	**0 281 002 605**
90 423 637	**0 261 230 042**
90 490 496	**0 261 210 169**
90 494 182	**0 261 210 131**
90 543 282	**0 280 217 123**
91 13 838	**0 280 212 019**
91 13 838	**0 986 280 117**
91 13 846	**0 280 213 012**
91 13 846	**0 986 280 110**
91 153 782	**0 261 210 132**
91 18 368	**0 261 210 151**
91 28 304	**0 281 002 277**
91 28 919	**0 280 217 105**
913 780	**0 280 130 065**
91 37 803	**0 280 130 075**
914 241	**0 261 231 046**
91 42 415	**0 261 231 046**
91 77 213	**0 280 130 094**
91 77 221	**0 261 210 133**
91 77 221	**0 261 210 269**
91 81 538	**0 280 122 014**
91 85 232	**0 261 210 169**
93 02 944	**0 438 120 071**
93 15 276	**0 438 120 073**
93171176	**0 281 002 437**
93171356	**0 281 002 180**
93 17 272	**0 438 120 087**
93180268	**0 281 002 617**
93187247	**0 281 002 771**
93189275	**0 265 007 671**
93189276	**0 265 007 896**
93189277	**0 265 007 769**
93189955	**0 281 002 831**
93192107	**0 261 230 146**
93 42 122	**0 438 120 139**
93 45 786	**0 438 120 159**
935 702	**0 280 130 026**
93 57 021	**0 280 130 026**
935 803	**0 261 230 001**
935 803	**0 261 231 001**
93 58 037	**0 261 231 001**
93 75 643	**0 280 212 005**
93 75 643	**0 986 280 112**
93 857 938	**0 281 002 566**
93 90 428	**0 280 212 002**
93 90 428	**0 280 212 009**
93 90 428	**0 986 280 135**
93 93 463	**0 280 120 300**
95 43 901	**0 281 002 437**

◀ SAAB

95 44 560	**0 281 002 138**
99 83 636	**0 335 541 002**

SCANIA

12580977	**0 280 218 136**
12608424	**0 232 103 079**
12785535	**1 397 212 017**
12787793	**0 263 003 208**
12789959	**0 261 210 229**
12803629	**1 397 212 017**
13107803	**1 397 212 058**
1326136	**0 265 050 025**
1326141	**0 265 050 027**
1350462	**0 265 050 112**
1355368	**0 281 002 129**
1356604	**0 265 050 112**
1356605	**0 265 050 113**
1358967	**0 281 002 130**
1362168	**0 484 205 003**
1365526	**0 265 050 143**
1365527	**0 265 050 144**
1365529	**0 265 050 145**
1365530	**0 265 050 146**
1377926	**0 281 002 129**
1381247	**0 281 002 190**
1383578	**0 281 002 174**
1386289	**0 486 001 007**
1386290	**0 486 001 006**
1393992	**0 486 000 025**
1393993	**0 486 000 026**
1393994	**0 486 000 027**
1400674	**0 486 000 023**
1411764	**0 486 000 069**
1761044	**F 00B H60 025**
1789353	**0 281 002 421**
1789354	**0 280 750 129**
1789360	**0 261 231 173**
1789364	**0 281 002 655**
220260	**0 331 101 014**
238924	**0 331 101 009**
24437503	**0 281 002 479**
24456764	**0 281 002 605**
30539175	**0 280 213 012**
30561772	**0 261 210 133**
30561772	**0 261 210 269**
30589495	**0 261 230 086**
332533	**0 265 050 035**
3325340	**0 265 050 002**
3325340	**0 265 050 006**
367265	**0 281 002 046**
367266	**0 281 002 011**
4227203	**0 261 210 030**
4239034	**0 280 217 503**
4239067	**0 280 130 073**
4243408	**0 265 003 070**
4300562	**0 280 217 506**
4300562	**0 280 217 508**
4300562	**0 280 217 525**
4300562	**0 280 217 526**
4300729	**0 261 231 115**
4300737	**0 261 210 132**
4400404	**0 265 006 295**
4444758	**0 261 230 014**
4621363	**0 232 103 007**
4660122	**0 281 002 211**
4660452	**0 232 103 016**
4660593	**0 280 130 092**
4660809	**0 280 217 119**
4660817	**0 280 217 520**
4661062	**0 280 122 004**
4661062	**0 280 122 008**
4661070	**0 280 217 521**
4662888	**0 281 002 212**
4686648	**0 265 006 337**
4727186	**0 261 230 015**
4772232	**0 281 002 138**
4773800	**0 281 002 137**
4779161	**0 265 006 295**
4779161	**0 265 006 359**
4780177	**0 280 217 519**
4780185	**0 280 217 120**
4780193	**0 280 217 522**
483423	**0 486 000 028**
483424	**0 486 000 029**
483548	**0 486 000 105**
483549	**0 486 000 106**
4909966	**0 265 006 337**
5057468	**0 265 006 331**
5060702	**0 265 005 424**
5060710	**0 265 005 251**
5149869	**1 397 212 013**
5166293	**0 281 002 444**
5166434	**0 261 230 030**
5166541	**0 281 002 443**
5167879	**0 281 002 443**
5167895	**0 261 230 020**
5196365	**0 261 230 086**
5196365	**0 261 260 317**
5233283	**0 265 005 303**
5340005	**0 281 002 538**
5340112	**0 281 002 539**
5342951	**0 281 002 605**
5390752	**0 265 006 743**
55184549	**0 281 002 716**
55190587	**0 281 002 764**
55194788	**0 281 002 716**
55200301	**0 281 002 784**
55557326	**0 261 210 133**
55557326	**0 261 210 269**
5584883	**1 397 212 013**
58807A	**0 263 003 208**
58807B	**0 263 003 208**

SEAT

038 906 461 D	**0 281 002 768**
038 906 461 D	**0 281 002 769**
270 600 001	**0 261 230 020**
278 001 016	**0 280 130 100**
6K0 906 301	**0 280 202 142**
6K0 906 301	**0 280 202 143**
6K2 721 727 B	**0 281 002 338**

SISU

8370 70189	**0 281 002 808**

SMART (MCC)

R00 7749 V006	**0 280 752 274**
R01 2590 V001	**0 280 752 272**
000 1459 V002	**0 281 002 238**
000 1459 V002	**0 281 002 239**
000 1459 V002	**0 281 002 499**
000 2173 V003	**0 265 006 373**
000 2173 V003	**0 265 006 478**
000 2202 V001	**0 265 006 375**
000 2202 V001	**0 265 006 557**
000 2202 V002	**0 265 006 375**
000 2202 V002	**0 265 006 557**
000 2245 T012	**0 280 752 205**
000 2245 V010	**0 280 752 204**
000 2245 V010	**0 280 752 205**
000 2245 V011	**0 280 752 205**
000 2245 V012	**0 280 752 205**
000 2245 V014	**0 280 752 205**
000 2245 V015	**0 280 752 222**
000 2245 V016	**0 280 752 225**
000 2245 V016	**0 280 752 226**
000 2245 V017	**0 280 752 225**
000 2245 V017	**0 280 752 226**
000 2245 V018	**0 280 752 230**
000 2245 V019	**0 280 752 253**
000 2245 V019	**0 280 752 254**
000 2245 V020	**0 280 752 269**
000 2245 V020	**0 280 752 270**
000 2245 V021	**0 280 752 270**
000 2247 V001	**0 265 006 374**
000 2247 V001	**0 265 006 556**
000 2247 V002	**0 265 006 374**
000 2247 V002	**0 265 006 556**
000 2472 V003	**0 265 006 373**
000 2473 V003	**0 265 006 478**
000 3094 V004	**0 205 003 055**
000 3094 V004	**0 205 003 056**
000 3094 V006	**0 205 003 055**
000 3094 V006	**0 205 003 056**
000 3094 V007	**0 205 003 055**
000 3094 V007	**0 205 003 056**
000 3117 V002	**0 261 210 141**
000 3117 V002	**0 261 210 142**
000 3120 V002	**0 261 231 133**
000 3120 V002	**0 261 231 134**
000 3121 V002	**0 281 002 137**
000 3121 V003	**0 261 230 049**
000 4419 V004	**0 280 752 246**
000 4740 T003	**0 265 006 556**
000 4740 V004	**0 265 006 556**
000 4742 T003	**0 265 006 557**
000 4742 V003	**0 265 006 557**
000 4742 V004	**0 265 006 557**
000 7749 V004	**0 280 752 245**
000 7749 V004	**0 280 752 246**
000 7749 V005	**0 280 752 246**
000 7749 V006	**0 280 752 273**
000 7749 V006	**0 280 752 274**
000 9493 V001	**0 265 005 279**
000 9493 V002	**0 265 005 279**
000 9493 V003	**0 265 005 671**
000 9493 V003	**0 265 005 698**
000 9493 V004	**0 265 005 698**
001 0743 V001	**0 265 006 753**
001 0743 V002	**0 265 006 753**
001 2227 V001	**0 265 006 748**
001 2227 V003	**0 265 006 788**
001 2589 V001	**0 280 752 267**
001 2589 V001	**0 280 752 268**
001 2590 V001	**0 280 752 271**
001 2590 V001	**0 280 752 272**
001 2590 V002	**0 280 755 002**
001 2590 V002	**0 280 755 003**
001 3784 V001	**0 280 752 280**
001 3784 V001	**0 280 752 281**
001 3784 V002	**0 280 752 281**
001 4087 V001	**0 265 005 303**
001 6146 V001	**0 261 230 141**
001 6146 V001	**0 261 230 142**

SSANGYONG

A6650943048	**0 280 218 131**
000 094 00 48	**0 280 217 100**
000 094 05 48	**0 280 217 517**
000 094 05 48	**0 280 217 518**
216144	**0 265 005 125**
48920 05000	**0 265 006 134**
48920 05000X	**0 265 006 134**
48920 11000	**0 265 006 397**

S

48930 05000	**0 265 006 135**
48930 05001	**0 265 006 135**
48930 06000	**0 265 006 343**
48930 06001	**0 265 006 343**
48940 11000	**0 265 006 398**
48950 11000	**0 265 006 399**
48970 11000	**0 265 006 396**
66154 03217	**0 265 006 341**
66154 03317	**0 265 006 338**
66154 03417	**0 265 006 339**
86750 05000	**0 265 005 038**
86750-05000	**0 265 005 045**
86750-06000	**0 265 005 115**

STEYR FAHRZEUGTECHNIK

001 540 45 17	**0 265 005 230**
002 542 66 18	**0 265 005 246**
002 545 19 05	**0 332 015 011**
003 542 03 18	**0 265 005 267**
006 153 49 28	**0 281 002 823**
113 094 00 48	**0 280 217 810**
113 094 00 48	**0 280 217 811**
125 809 77	**0 280 218 136**
13107803	**1 397 212 058**
210 540 48 10	**0 265 006 357**
210 540 49 10	**0 265 006 355**
210 540 91 08	**0 265 006 187**
211 540 10 17	**0 265 007 469**
211 540 12 17	**0 265 007 496**
211 540 13 17	**0 265 007 495**
211 540 20 17	**0 265 007 705**
211 540 24 17	**0 265 007 721**
216 542 00 18	**0 265 005 623**
220 540 11 17	**0 265 007 107**
273 094 05 48	**0 280 218 148**
273 094 07 48	**0 280 218 174**
273 094 07 48	**0 280 218 186**
273 094 08 48	**0 280 218 181**
273 094 09 48	**0 280 218 181**
273 094 09 48	**0 280 218 191**
3417699	**0 265 005 644**
463 540 19 17	**0 265 008 015**
463 540 20 17	**0 265 007 984**
463 540 21 17	**0 265 007 985**
55190587	**0 281 002 764**
55198717	**0 281 002 771**
55200301	**0 281 002 784**
55350048	**0 281 002 618**
6762235	**0 265 005 285**
6774040	**0 265 005 285**
6777435	**0 265 005 285**
7531702	**0 280 218 159**
7 533 853	**0 280 218 165**
7566989	**0 280 218 159**
7801951	**0 281 002 849**
906 542 05 18	**0 265 005 628**

SUBARU

27542 AE000	**0 265 005 216**

SUZUKI

127603	**0 281 002 619**
13800 T79J5 000	**0 281 002 770**
13800 T7950 001	**0 281 002 618**
13800 79J50	**0 281 002 618**
13800 84E50	**0 281 002 619**
13800 86J00	**0 281 002 862**
15736 67G00	**0 281 002 592**
15760-66K70	**0 261 545 042**
18590 T79J5 000	**0 281 002 770**
18590 73KA0	**0 261 230 197**
18590-79G61-000	**0 281 002 845**
18590 79J50	**0 281 002 771**
18590 82K00	**0 261 230 198**
18590 82K50	**0 261 230 200**
18590 84E50	**0 281 002 510**
18640 73KA0	**0 261 231 201**
33945 T79J0	**0 265 005 636**
37520 10B3	**0 261 231 036**
37620 30B3	**0 280 130 037**
56200 T79J00	**0 265 007 954**
56210 T79J00	**0 265 007 955**
56220 T79J00	**0 265 007 954**
56310 T79J00	**0 265 007 957**
56320 T79J00	**0 265 007 956**

TALBOT

A 040 296	**0 261 211 003**
A 514 296	**0 261 211 003**
A 514 548 80	**0 280 120 305**
A 514 549 80	**0 280 130 026**
A 514 880 80	**0 261 231 001**
91 040 398 80	**0 281 002 030**
91 207 837 80	**0 281 002 018**
91 414 549 80	**0 280 130 026**
91 514 548 80	**0 280 120 305**
91 514 549 80	**0 280 130 026**
91 514 880 80	**0 261 231 006**
91 516 985 80	**0 280 202 056**
91 516 985 80	**0 986 280 028**
91 537 485 80	**0 132 009 305**
91 537 516 80	**0 281 002 029**
91 538 877 80	**0 280 202 097**
91 538 877 80	**0 986 280 070**
91 540 545 80	**0 280 202 109**
91 540 545 80	**0 986 280 013**
91 541 027 80	**0 261 210 043**
91 541 738 80	**0 280 202 202**
95 640 366 80	**0 281 002 037**
96 087 509 80	**0 265 003 078**
96 089 629 80	**0 265 003 079**
96 107 893 80	**0 261 230 004**
96 140 648 80	**0 265 003 099**
96 165 516 80	**0 265 003 130**
96 165 516 80	**0 265 006 200**
96 180 488 80	**0 265 003 128**
96 181 977 80	**0 265 003 131**
96 181 977 80	**0 265 006 201**
96 181 978 80	**0 265 003 130**
96 181 978 80	**0 265 006 200**

TATA (TELCO)

269915409948	**0 261 230 133**
269954219944	**0 265 005 146**
279715209903	**0 280 218 183**

TOYOTA

47900 6F605	**0 265 001 417**
67000 01062	**0 265 005 432**
78010 YV010	**0 280 755 019**
78010 YV020	**0 280 755 039**
84307 02080	**0 265 005 519**
84307 02090	**0 265 005 520**
89183 0H010	**0 265 005 703**
89183 0W010	**0 265 005 208**
89183 02010	**0 265 005 260**
89183 02020	**0 265 005 297**
89183 05010	**0 265 005 239**
89183 05010	**0 265 005 273**
89183 05010	**0 265 005 297**
89183 05020	**0 265 005 273**
89183 05020	**0 265 005 297**
89183 06010	**0 265 005 633**
89183 06010	**0 265 005 650**
89183 07010	**0 265 005 226**
89183 07020	**0 265 005 274**
89183 08010	**0 265 005 239**
89183 08010	**0 265 005 243**
89183 08010	**0 265 005 273**
89183 08010	**0 265 005 297**
89245 0W010	**0 265 005 402**
89245 02010	**0 265 005 432**
89245 02020	**0 265 005 487**
89245 02040	**0 265 005 518**
89245 05010	**0 265 005 426**
89245 07010	**0 265 005 412**
89422-0W010	**0 280 130 105**
89422 05010	**0 280 130 077**
89422 05010	**0 280 130 104**
89422 05020	**0 280 130 104**
89441 0W010	**0 265 005 119**
89452 05010	**0 280 122 008**
89458 0D010	**0 281 002 628**
89458 02011	**0 281 002 871**
89458 52010	**0 281 002 521**
89465 0H020	**0 280 755 019**
89542 0D010	**0 265 006 675**
89542 0H010	**0 265 007 687**
89542 02020	**0 265 006 516**
89542 02040	**0 265 006 677**
89542 02060	**0 265 007 805**
89542 02110	**0 265 007 803**
89542 05010	**0 265 001 381**
89542 05010	**0 265 001 416**
89542 05020	**0 265 001 416**
89542 05030	**0 265 006 333**
89542 05030	**0 265 006 666**
89542 05040	**0 265 006 666**
89542 340NM	**0 265 006 677**
89542 990DL	**0 265 001 381**
89542 990DL	**0 265 001 416**
89543 0D010	**0 265 006 674**
89543 0D011	**0 265 006 674**
89543 02020	**0 265 006 517**
89543 02040	**0 265 006 676**
89543 02060	**0 265 007 806**
89543 02110	**0 265 007 804**
89543 05010	**0 265 001 382**
89543 05010	**0 265 001 417**
89543 05020	**0 265 001 417**
89543 05030	**0 265 006 334**
89543 05030	**0 265 006 665**
89543 05040	**0 265 006 665**
89543 340NM	**0 265 006 676**
89544 0H010	**0 265 007 688**
89544 02040	**0 265 007 802**
89545 02010	**0 265 006 518**
89545 05010	**0 265 001 383**
89545 05010	**0 265 001 418**
89545 05020	**0 265 001 418**
89545 05030	**0 265 006 335**
89545 05030	**0 265 006 336**
89545 05030	**0 265 006 668**
89545 05040	**0 265 006 668**
89546 02010	**0 265 006 519**
89546 05010	**0 265 001 384**
89546 05010	**0 265 001 419**
89546 05020	**0 265 001 419**
89546 05030	**0 265 006 335**
89546 05030	**0 265 006 336**

T

◀ TOYOTA

89546 05030	**0 265 006 667**
89546 05040	**0 265 006 667**
89615 0H010	**0 261 231 193**
89615 02010	**0 261 231 149**
89615 05010	**0 261 231 045**
89615 05010	**0 261 231 103**
89637 07010	**0 265 005 303**
90080 19018	**0 232 103 029**
90080 19020	**0 232 103 036**
90080 19026	**0 281 002 406**
90919 W5001	**0 232 103 069**
90919 W5003	**0 232 103 069**
96430 73280	**0 280 752 238**

VOLVO

1011926	**0 261 230 108**
1079477	**0 281 002 251**
11987137	**0 332 204 101**
1219678	**0 335 541 004**
1219680	**0 335 541 005**
1235013	**0 332 015 012**
1235020	**0 332 015 009**
1259925	**0 332 014 151**
1259926	**0 332 204 101**
1266408	**0 438 120 025**
1266426	**0 438 120 043**
1266545	**0 438 120 043**
1266808	**0 438 120 076**
1266810	**0 438 120 077**
1269028	**0 438 120 027**
1269029	**0 438 120 031**
1269144	**0 438 120 080**
1269146	**0 438 120 056**
1269148	**0 438 120 079**
1269332	**0 438 120 065**
1269794	**0 438 120 132**
1270259	**0 280 218 008**
1270492	**0 261 231 121**
1270501	**0 261 230 019**
1271004	**0 280 120 300**
1271861	**0 280 213 025**
1271861	**0 986 280 114**
1271862	**0 280 213 026**
1275173	**0 205 001 047**
1275245	**0 281 002 075**
1275245	**0 281 002 155**
1275245	**0 986 280 089**
1275245	**0 986 280 090**
1275342	**0 261 230 018**
1275749	**0 280 217 107**
1276509	**0 438 120 100**
1306024	**0 280 130 028**
1306937	**0 280 130 023**
1306938	**0 280 120 301**
1306938	**0 280 130 006**
1306939	**0 280 212 001**
1306964	**0 280 202 034**
1306964	**0 986 280 059**
1306967	**0 280 202 035**
1306967	**0 986 280 045**
1317030	**0 261 210 001**
1317030	**0 261 210 003**
1317273	**0 261 220 001**
1317273	**0 261 220 002**
1317546	**0 438 120 138**
1317551	**0 438 120 134**
1317867	**0 438 120 125**
1324080	**0 265 001 064**
1324081	**0 265 001 065**
1326065	**0 280 212 002**
1326065	**0 986 280 106**
1326658	**0 261 231 001**
1326730	**0 280 230 005**
1332396	**0 280 130 026**
1336354	**0 280 213 006**
1336354	**0 986 280 115**
1336385	**0 280 122 001**
1336534	**0 280 213 006**
1336534	**0 986 280 115**
1346645	**0 280 212 007**
1346645	**0 986 280 102**
1346698	**0 280 202 067**
1357451	**0 438 120 202**
1357666	**0 438 120 203**
1363557	**0 265 001 186**
1363558	**0 265 001 185**
1363559	**0 265 001 184**
1366220	**0 280 217 002**
1367643	**0 261 231 007**
1367644	**0 261 231 006**
1367644	**0 261 231 046**
1367645	**0 261 210 029**
1367970	**0 280 202 096**
1398781	**0 265 001 064**
1398781	**0 265 001 065**
1501832	**0 332 014 151**
1504952	**0 332 204 101**
1620170	**0 132 009 320**
1620170	**0 281 002 396**
1650865	**0 281 002 023**
20153340	**0 281 002 744**
20374282	**0 281 002 458**
20374282	**0 281 002 459**
20374299	**0 281 002 449**
20374299	**0 281 002 450**
20452258	**0 281 002 574**
20452258	**0 281 002 575**
20513340	**0 281 002 744**
20513343	**0 261 210 151**
20513343	**0 281 002 742**
20524936	**0 281 002 576**
20524936	**0 281 002 743**
20774533	**0 280 218 089**
20792328	**0 281 002 706**
20885267	**0 281 002 946**
20993000	**0 261 230 150**
241722	**0 280 120 012**
241725	**0 280 100 010**
241726	**0 280 130 014**
241810	**0 280 130 006**
241812	**0 332 003 021**
243028	**0 332 003 025**
243181	**0 331 100 023**
243183	**0 280 100 015**
243316	**0 280 100 035**
243366	**0 280 120 026**
243715	**0 331 101 008**
243847	**0 331 101 004**
243896	**0 438 120 005**
243897	**0 438 120 006**
244228	**0 438 120 016**
269548	**0 335 541 006**
285227	**0 280 230 005**
30621300	**0 265 006 698**
30622083	**0 261 230 105**
30622083	**0 261 230 106**
30637412	**0 281 002 612**
30649885	**1 397 212 067**
30649886	**1 397 212 034**
30650013	**0 280 750 103**
30650013	**0 280 750 104**
30650014	**0 261 230 092**
30650014	**0 261 230 109**
30650015	**0 261 230 108**
30650015	**0 261 230 110**
30650561	**0 280 750 132**
3065338	**1 397 212 104**
3065388	**1 397 212 104**
30655308	**1 397 212 104**
30655338	**1 397 212 103**
30655338	**1 397 212 104**
30658184	**0 261 230 044**
30677251	**0 281 002 730**
30677251	**0 281 002 731**
30677300	**0 281 002 706**
30677300	**0 281 002 707**
30677999	**0 281 002 731**
30711552	**0 280 750 146**
30711552	**0 280 750 147**
30711553	**0 280 750 103**
30711553	**0 280 750 104**
30711554	**0 280 750 131**
30711554	**0 280 750 132**
30756097	**0 261 230 108**
30756098	**0 261 230 092**
30756098	**0 261 230 109**
30814716	**0 265 006 226**
30814716	**0 265 006 366**
30850024	**0 265 006 366**
30854299	**0 265 006 425**
30862697	**0 206 001 021**
30870894	**0 265 006 224**
30870895	**0 265 006 223**
3090470	**0 331 101 016**
3093845	**2 427 233 004**
31214359	**1 397 212 103**
31251446	**0 261 230 237**
31251447	**0 261 230 239**
3172774	**0 281 002 382**
3172774	**0 281 002 383**
3173630	**0 484 205 007**
3198232	**0 281 002 450**
3198232	**0 281 002 455**
3285227	**0 280 230 005**
3292959	**0 335 530 016**
3343029	**0 280 120 319**
3411906	**0 280 212 007**
3411906	**0 986 280 102**
3433347	**0 261 231 006**
3433477	**0 280 130 032**
3450030	**0 280 122 001**
3454442	**0 280 212 021**
3454442	**0 986 280 107**
346030	**0 280 130 032**
3501987	**0 280 213 010**
3501987	**0 986 280 138**
3507697	**0 280 217 107**
3515092	**0 265 001 231**
3515093	**0 265 001 187**
3517020	**0 280 212 016**
3517020	**0 986 280 101**
3517068	**0 280 120 325**
3517569	**0 280 213 012**
3517569	**0 986 280 110**
3517763	**0 280 213 020**
3517763	**0 986 280 132**
3517772	**0 280 120 400**
3517881	**0 280 217 001**
3534814	**0 280 213 026**
3540601	**0 265 001 332**
3547266	**0 280 212 021**
3547266	**0 986 280 107**
3843012	**0 261 230 147**
3843100	**0 281 002 706**
3843100	**0 281 002 864**
3944124	**0 281 002 248**
3944124	**0 281 002 249**
39649886	**1 397 212 068**

T

3985596	**0 281 002 263**
3985596	**0 281 002 264**
3987882	**0 281 002 292**
3987882	**0 281 002 293**
43065338	**1 397 212 103**
43065338	**1 397 212 104**
460835	**0 280 100 053**
460866	**0 280 100 054**
461560	**0 280 120 039**
461583	**0 280 100 059**
461666	**0 280 100 066**
462567	**0 280 100 056**
462793	**0 438 120 003**
48648049	**1 397 212 052**
58807B	**0 263 003 208**
6603575	**0 331 101 001**
6777707	**0 204 154 022**
6793386	**0 204 154 021**
6793386	**0 204 154 032**
6842536	**0 261 230 006**
6900118	**0 204 154 023**
6950953	**0 204 154 019**
6950953	**0 204 154 030**
6950954	**0 204 154 022**
77756	**0 331 101 002**
811959	**0 261 230 021**
8119598	**0 261 230 021**
8141475	**0 281 002 086**
8251496	**0 986 280 102**
8251497	**0 986 280 101**
8251498	**0 986 280 110**
8251499	**0 986 280 114**
8251500	**0 986 280 115**
8251501	**0 986 280 107**
8251502	**0 986 280 138**
8251503	**0 986 280 090**
8251504	**0 986 280 106**
831725	**0 332 204 101**
8360979	**0 335 530 032**
839367	**0 332 014 151**
850024	**0 265 006 366**
8602391	**0 280 218 045**
8602791	**0 280 212 007**
8602791	**0 986 280 102**
8602792	**0 280 212 016**
8602792	**0 986 280 101**
8602793	**0 280 213 012**
8602793	**0 986 280 110**
8602794	**0 280 213 025**
8602794	**0 986 280 114**
8602795	**0 280 213 006**
8602795	**0 986 280 115**
8602796	**0 280 212 021**
8602796	**0 986 280 107**
8602797	**0 280 213 010**
8602797	**0 986 280 138**
8602798	**0 281 002 155**
8602798	**0 986 280 090**
8602803	**0 280 212 002**
8602803	**0 986 280 106**
8627279	**0 261 230 067**
8627296	**0 280 218 088**
8627297	**0 280 218 089**
8631533	**0 232 103 042**
8631588	**0 281 002 398**
8631588	**0 281 002 527**
8648049	**1 397 212 052**
8653171	**0 261 231 178**
8658497	**0 280 750 146**
8658497	**0 280 750 147**
8658536	**0 261 230 092**
8658536	**0 261 230 109**
8658726	**0 232 103 063**
8662738	**1 397 212 034**
86627386	**1 397 212 034**
8670112	**0 280 218 045**
8670112	**0 280 218 108**
8670113	**0 280 218 046**
8670113	**0 280 218 109**
8670114	**0 280 218 089**
8670115	**0 280 218 088**
8670115	**0 280 218 089**
8670263	**0 280 218 108**
8670398	**0 280 218 088**
8677288	**0 261 230 090**
8677288	**0 261 230 091**
8677657	**0 280 750 103**
8677657	**0 280 750 104**
8677658	**0 280 750 131**
8677658	**0 280 750 132**
8677866	**0 280 750 103**
8677866	**0 280 750 104**
8677867	**0 280 750 131**
8677867	**0 280 750 132**
8687927	**0 280 750 146**
8687927	**0 280 750 147**
8692624	**0 280 218 134**
8699448	**0 261 230 092**
8699448	**0 261 230 109**
8699449	**0 261 230 108**
874241	**0 281 002 576**
874556	**0 281 002 534**
9125462	**0 261 230 029**
9125569	**0 261 230 021**
9127410	**0 265 001 380**
9143648	**0 232 101 029**
9146108	**0 232 101 030**
9146483	**0 280 217 511**
9432570	**0 261 231 142**
9434287	**0 205 001 049**
9438757	**0 280 218 045**
9445148	**0 280 218 007**
9447055	**0 205 001 046**
9470640	**0 280 218 045**
9470776	**0 280 218 046**
9474059	**0 205 001 048**
9483937	**1 397 212 008**
9488047	**0 280 750 103**
9488047	**0 280 750 104**
9545148	**0 280 218 007**

VOLVO CAR

MB 950344	**0 265 006 223**
MN 902991	**0 281 002 762**
MN 903266	**0 281 002 823**
RA8 651A026	**0 265 005 504**
SMN 102857	**0 265 007 637**
SMN 116462	**0 265 007 683**
SMN 116562	**0 265 007 683**
SMN 163706	**0 261 231 187**
SMN 195775	**0 261 230 118**
SMR 587456	**0 265 005 485**
SMR 955037	**0 265 007 638**
SMR 955352	**0 265 005 289**
SMR 985032	**0 261 230 118**
S46 70A228	**0 265 005 625**
S86 51A026	**0 265 005 504**
467 0A228	**0 265 005 625**
865 1A026	**0 265 005 504**

VW (VOLKSWAGEN)

X03 952 633	**0 280 200 045**
X03 952 640	**0 280 130 026**
X03 952 671	**0 280 230 009**
X03 961 006	**0 280 200 050**
X03 972 830	**0 280 200 052**
X03 972 830	**0 986 280 058**
X03 976 245	**0 280 200 053**
0B8 927 321	**0 232 103 037**
0B8 927 321	**0 232 103 038**
000 VT5 077	**0 281 002 461**
000 VT5 077	**0 281 002 462**
000 395 2633	**0 280 200 045**
000 395 2640	**0 280 130 026**
000 395 2671	**0 280 230 009**
000 397 2830	**0 280 200 052**
000 397 2830	**0 986 280 058**
004 153 82 28	**0 281 002 456**
004 165 008	**0 261 210 064**
013 001 224	**0 263 003 475**
021 133 062	**0 205 003 053**
021 133 062	**0 205 003 054**
021 905 377	**0 261 231 044**
021 905 377	**0 261 231 047**
021 905 377	**0 261 231 048**
021 905 377 A	**0 261 231 064**
021 905 377 A	**0 261 231 065**
021 906 433	**0 261 210 080**
021 906 433	**0 261 210 081**
021 906 433 A	**0 261 210 080**
021 906 433 A	**0 261 210 081**
021 906 433 C	**0 261 210 107**
021 906 433 C	**0 261 210 108**
021 906 433 D	**0 261 210 156**
021 906 433 D	**0 261 210 157**
021 906 445	**0 261 210 044**
021 906 461	**0 280 213 021**
021 906 461	**0 280 213 022**
021 906 461	**0 986 280 122**
021 906 461	**0 986 280 127**
021 906 462	**0 280 217 504**
021 906 462	**0 280 217 505**
021 906 462 A	**0 280 217 512**
021 906 462 A	**0 280 217 513**
021 906 462 A	**0 986 280 203**
021 906 462 A	**0 986 280 303**
021 906 462 AX	**0 986 280 203**
021 906 462 AX	**0 986 280 303**
021 907 317 A	**0 261 210 120**
021 907 317 A	**0 261 210 121**
021 907 319	**0 261 210 094**
021 907 319	**0 261 210 095**
021 907 319 A	**0 261 210 120**
021 907 319 A	**0 261 210 121**
021 907 475 D	**0 280 752 016**
021 907 475 D	**0 280 752 017**
021 907 475 E	**0 280 752 018**
021 907 475 E	**0 280 752 019**
022 133 062 AB	**0 280 750 086**
022 133 062 AB	**0 280 750 087**
022 133 062 AC	**0 280 750 097**
022 133 062 AC	**0 280 750 098**
022 133 062 AF	**0 280 750 008**
022 133 062 T	**0 280 750 086**
022 133 062 T	**0 280 750 087**
022 906 041	**0 280 130 012**
022 906 041	**0 280 130 013**
022 906 041 A	**0 280 130 017**
022 906 041 A	**0 280 130 018**
022 906 051	**0 280 100 003**
022 906 051 A	**0 280 100 019**
022 906 051 B	**0 280 100 027**
022 906 051 C	**0 280 100 037**
022 906 051 E	**0 280 100 049**
022 906 059	**0 332 514 101**
022 906 059	**0 332 514 103**
022 906 111 A	**0 280 120 042**
022 906 111 A	**0 280 120 043**
022 906 111 B	**0 280 120 021**

V

◀ VW

022 906 111 B	**0 280 120 022**
022 906 111 D	**0 280 120 201**
022 906 111 E	**0 280 120 103**
022 906 111 E	**0 280 120 104**
022 906 111 G	**0 280 120 207**
022 906 301	**0 280 200 001**
022 906 301	**0 280 200 002**
022 906 301 A	**0 280 200 012**
022 906 301 A	**0 280 200 013**
022 906 301 A	**0 986 280 071**
022 906 301 B	**0 280 200 018**
022 906 301 B	**0 280 200 019**
022 906 301 B	**0 986 280 050**
022 906 301 D	**0 280 200 020**
022 906 301 D	**0 280 200 021**
022 906 301 D	**0 986 280 038**
025 906 041	**0 280 130 026**
025 906 041	**0 280 130 033**
025 906 301	**0 280 200 038**
025 906 301	**0 280 200 039**
025 906 301	**0 986 280 012**
025 906 301 A	**0 280 200 041**
025 906 301 A	**0 280 200 042**
025 906 301 C	**0 280 202 079**
025 906 301 C	**0 280 202 080**
025 906 301 C	**0 986 280 011**
025 906 301 C	**0 986 280 085**
026 133 353	**0 438 121 011**
026 133 353	**0 438 121 012**
026 133 353 C	**0 438 121 057**
026 133 353 C	**0 438 121 058**
026 133 471	**F 026 TX2 063**
026 133 471	**0 438 121 011**
026 133 471	**0 438 121 012**
026 133 471 A	**0 438 121 047**
026 133 471 B	**F 026 TX2 051**
026 133 471 B	**0 438 120 208**
026 133 471 B	**0 438 120 209**
026 133 471 C	**0 438 121 057**
026 133 471 C	**0 438 121 058**
026 133 471 D	**0 438 121 070**
026 133 471 D	**0 438 121 071**
026 133 471 D	**0 986 439 370**
026 133 593	**0 261 230 016**
026 133 593	**0 261 230 017**
026 133 593	**0 261 230 116**
026 133 593	**0 261 230 117**
026 905 359 2	**1 237 031 296**
026 905 377	**0 261 231 002**
026 905 377	**0 261 231 003**
026 906 161	**0 280 130 026**
026 906 161	**0 280 130 040**
026 906 161	**0 280 130 041**
026 906 161 A	**0 280 130 127**
026 906 161 A	**0 280 130 128**
027 133 471	**F 026 TX2 050**
027 133 471	**0 438 120 195**
027 133 471	**0 438 120 196**
027 998 041 1	**0 261 230 095**
028 130 301	**0 281 002 073**
028 130 301	**0 986 280 088**
028 906 301	**0 281 002 072**
028 906 301	**0 281 002 073**
028 906 301	**0 986 280 088**
028 906 461	**0 281 002 216**
028 906 461	**0 281 002 217**
028 906 461	**0 986 284 001**
028 906 461 X	**0 986 284 001**
028 907 475	**0 205 001 023**
028 907 475 A	**0 205 001 024**
028 907 475 AA	**0 281 002 253**
028 907 475 AB	**0 281 002 254**
028 907 475 AC	**0 280 752 002**
028 907 475 AC	**0 280 752 003**
028 907 475 AJ	**0 281 002 286**
028 907 475 AL	**0 281 002 289**
028 907 475 AM	**0 280 752 020**
028 907 475 AP	**0 281 002 339**
028 907 475 B	**0 205 001 018**
028 907 475 B	**0 205 001 032**
028 907 475 BC	**0 281 002 331**
028 907 475 BD	**0 280 752 022**
028 907 475 C	**0 205 001 031**
028 907 475 P	**0 281 002 275**
028 907 475 S	**0 281 002 229**
028 907 475 T	**0 280 752 002**
028 907 475 T	**0 280 752 003**
028 907 568	**0 205 001 023**
028 907 568 A	**0 205 001 024**
03C 906 051	**0 261 230 095**
03C 906 051	**0 261 230 096**
03C 906 051 F	**0 261 230 148**
03C 906 051 F	**0 261 230 149**
03C 906 433	**0 261 210 250**
03C 906 433	**0 261 210 251**
03C 957 147	**0 261 210 250**
03C 957 147	**0 261 210 251**
03G 906 051 F	**0 281 002 837**
03G 906 051 F	**0 281 002 838**
03G 906 461 C	**0 281 002 735**
03G 906 461 C	**0 281 002 736**
03H 906 461	**0 280 218 175**
03H 906 461	**0 280 218 176**
030 133 062	**0 280 750 049**
030 133 062	**0 280 750 050**
030 133 062 A	**0 280 750 049**
030 133 062 A	**0 280 750 050**
030 133 062 B	**0 280 750 095**
030 133 062 B	**0 280 750 096**
030 133 062 C	**0 280 750 095**
030 133 062 C	**0 280 750 096**
030 905 065	**1 237 031 296**
030 905 377	**0 261 231 066**
030 905 377	**0 261 231 067**
030 905 377 A	**0 261 231 045**
030 905 377 A	**0 261 231 108**
030 905 377 C	**0 261 231 146**
030 905 377 C	**0 261 231 147**
030 905 377.1	**0 261 231 122**
030 905 377 1	**0 261 231 126**
030 906 051	**0 261 230 010**
030 906 051	**0 261 230 011**
030 906 051 A	**0 261 230 010**
030 906 051 A	**0 261 230 011**
030 906 301	**0 280 200 048**
030 906 301	**0 280 200 049**
030 906 301	**0 986 280 030**
030 906 301	**0 986 280 084**
030 906 433 D	**0 261 210 172**
030 906 433 D	**0 261 210 173**
030 906 433 E	**0 261 210 174**
030 906 433 E	**0 261 210 175**
030 906 433 K	**0 261 210 207**
030 906 433 K	**0 261 210 208**
030 957 147 C	**0 261 210 174**
030 957 147 C	**0 261 210 175**
030 957 147 D	**0 261 210 172**
030 957 147 D	**0 261 210 173**
030 957 147 E	**0 261 210 174**
030 957 147 E	**0 261 210 175**
030 957 147 F	**0 261 210 194**
030 957 147 F	**0 261 210 195**
030 957 147 F	**0 261 210 215**
030 957 147 F	**0 261 210 216**
030 957 147 G	**0 261 210 188**
030 957 147 G	**0 261 210 189**
030 957 147 K	**0 261 210 215**
030 957 147 K	**0 261 210 216**
030 957 147 L	**0 261 210 213**
030 957 147 L	**0 261 210 214**
030 957 147 R	**0 261 210 223**
030 957 147 R	**0 261 210 224**
030 957 147 R	**0 261 210 225**
030 957 147 R	**0 261 210 226**
030 957 147 S	**0 261 210 257**
030 957 147 S	**0 261 210 258**
031 906 041	**0 280 130 014**
031 906 081	**0 280 130 006**
034 133 154 C	**0 280 120 410**
034 133 154 C	**0 280 120 411**
034 133 154 E	**0 280 120 420**
034 133 154 E	**0 280 120 421**
034 133 353 J	**0 438 121 059**
034 133 353 J	**0 438 121 060**
034 133 353 M	**0 438 121 067**
034 133 353 M	**0 438 121 068**
034 133 353 P	**0 438 120 218**
034 133 353 R	**0 438 121 083**
034 133 353 R	**0 438 121 084**
034 133 471	**F 026 TX2 064**
034 133 471	**0 438 121 013**
034 133 471	**0 438 121 014**
034 133 471 B	**0 438 121 041**
034 133 471 C	**0 438 121 053**
034 133 471 C	**0 438 121 054**
034 133 471 D	**0 280 213 005**
034 133 471 D	**0 280 213 007**
034 133 471 D	**0 280 213 008**
034 133 471 D	**0 986 280 120**
034 133 471 D	**0 986 280 137**
034 133 471 E	**0 438 120 210**
034 133 471 E	**0 438 120 211**
034 133 471 F	**0 438 121 059**
034 133 471 F	**0 438 121 060**
034 133 471 G	**F 026 TX2 054**
034 133 471 G	**0 438 121 049**
034 133 471 G	**0 438 121 050**
034 133 471 H	**0 438 121 073**
034 133 471 H	**0 438 121 074**
034 133 471 J	**0 438 121 068**
034 133 471 K	**0 280 213 008**
034 133 471 K	**0 986 280 120**
034 133 471 K	**0 986 280 137**
034 133 471 L	**0 438 121 064**
034 133 471 L	**0 438 121 065**
034 133 471 M	**0 438 121 083**
034 133 471 N	**0 280 213 017**
034 133 471 N	**0 986 280 139**
034 905 161	**0 232 101 020**
034 905 161	**0 232 101 021**
034 905 215	**0 232 101 014**
034 905 215	**0 232 101 015**
034 905 215 B	**0 232 101 015**
034 905 215 B	**0 232 102 002**
034 905 215 B	**0 232 102 003**
034 905 377 A	**0 261 231 004**
034 905 377 A	**0 261 231 005**
034 905 377 C	**0 261 231 016**
034 905 377 C	**0 261 231 017**
034 905 377 D	**0 261 231 014**
034 905 377 D	**0 261 231 015**
034 905 377 H	**0 261 231 031**
034 905 377 H	**0 261 231 032**
034 906 161	**0 280 130 053**
034 906 161	**0 280 130 054**
035 133 353 AA	**0 438 120 183**
035 133 353 AC	**0 438 121 003**
035 133 353 AC	**0 438 121 004**
035 133 353 AD	**0 438 120 194**
035 133 353 AE	**0 438 121 023**

V

035 133 353 AE	**0 438 121 024**
035 133 353 AG	**0 438 121 017**
035 133 353 AG	**0 438 121 018**
035 133 353 AS	**0 438 121 061**
035 133 353 AS	**0 438 121 062**
035 133 353 T	**0 438 120 179**
035 133 471	**0 438 120 040**
035 133 471	**0 438 120 041**
035 133 471 A	**0 438 120 112**
035 133 471 A	**0 438 120 113**
035 133 471 AA	**0 438 121 007**
035 133 471 AA	**0 438 121 008**
035 133 471 AB	**0 438 121 018**
035 133 471 AC	**0 280 214 001**
035 133 471 AC	**0 986 280 124**
035 133 471 AD	**0 438 121 030**
035 133 471 AE	**0 438 121 023**
035 133 471 AF	**0 438 121 052**
035 133 471 B	**0 438 120 121**
035 133 471 B	**0 438 120 122**
035 133 471 C	**0 438 120 052**
035 133 471 C	**0 438 120 053**
035 133 471 D	**0 438 120 044**
035 133 471 D	**0 438 120 045**
035 133 471 E	**0 438 120 136**
035 133 471 E	**0 438 120 137**
035 133 471 F	**0 438 120 146**
035 133 471 F	**0 438 120 147**
035 133 471 G	**0 438 120 144**
035 133 471 H	**0 438 120 169**
035 133 471 K	**0 438 120 177**
035 133 471 L	**0 438 120 185**
035 133 471 L	**0 438 120 186**
035 133 471 N	**0 438 120 181**
035 133 471 N	**0 438 120 182**
035 133 471 P	**0 438 120 193**
035 133 471 Q	**0 438 120 178**
035 133 471 Q	**0 438 120 197**
035 133 471 Q	**0 438 120 198**
035 133 471 R	**0 438 120 180**
035 133 471 S	**0 438 121 004**
035 133 471 T	**0 438 121 005**
035 133 471 T	**0 438 121 006**
035 906 111	**0 280 120 300**
035 919 369 M	**0 280 130 037**
035 919 369 M	**0 280 130 038**
036 133 062 B	**0 280 750 057**
036 133 062 B	**0 280 750 058**
036 133 062 C	**0 280 750 059**
036 133 062 C	**0 280 750 063**
036 133 062 C	**0 280 750 064**
036 133 062 D	**0 280 750 059**
036 133 062 D	**0 280 750 060**
036 133 062 J	**0 280 750 112**
036 133 062 J	**0 280 750 113**

036 906 051 C	**0 261 230 053**
036 906 051 C	**0 261 230 054**
036 906 051 E	**0 261 230 071**
036 906 051 E	**0 261 230 072**
036 906 051 F	**0 261 230 079**
036 906 051 F	**0 261 230 080**
036 906 051 G	**0 261 230 081**
036 906 051 G	**0 261 230 082**
036 906 433	**0 261 210 110**
036 906 433 B	**0 261 210 233**
036 906 433 B	**0 261 210 234**
036 906 461	**0 280 217 108**
036 906 461	**0 280 217 109**
036 906 461 A	**0 280 218 056**
036 906 461 A	**0 280 218 057**
036 906 461 A	**0 986 280 214**
036 906 461 A	**0 986 280 314**
036 906 461 AX	**0 986 280 214**
036 906 461 AX	**0 986 280 314**
037 905 377	**0 261 231 075**
037 905 377	**0 261 231 076**
037 905 377 A	**0 261 231 077**
037 905 377 A	**0 261 231 078**
037 906 301	**0 280 202 106**
037 906 301	**0 280 202 107**
037 906 301	**0 986 280 008**
037 906 301	**0 986 280 086**
037 906 301 B	**0 280 202 130**
037 906 301 B	**0 280 202 131**
037 906 301 B	**0 280 202 138**
037 906 301 B	**0 280 202 139**
037 906 301 B	**0 986 280 010**
037 906 301 B	**0 986 280 077**
037 906 301 B	**0 986 280 087**
037 906 301 C	**0 280 202 130**
037 906 301 C	**0 280 202 131**
037 906 301 C	**0 986 280 010**
037 906 301 C	**0 986 280 087**
037 906 461	**0 280 217 103**
037 906 461	**0 280 217 104**
037 906 461 A	**0 280 217 103**
037 906 461 A	**0 280 217 104**
037 906 461 C	**0 280 217 117**
037 906 461 C	**0 280 217 118**
037 906 461 C	**0 986 280 201**
037 906 461 C	**0 986 280 301**
037 906 461 CX	**0 986 280 201**
037 906 461 CX	**0 986 280 301**
037 906 462	**0 280 217 505**
038 906 051	**0 281 002 177**
038 906 051	**0 281 002 178**
038 906 051 A	**0 281 002 394**
038 906 051 A	**0 281 002 395**
038 906 051 B	**0 281 002 399**
038 906 051 B	**0 281 002 400**

038 906 051 C	**0 281 002 401**
038 906 051 C	**0 281 002 402**
038 906 051 D	**0 261 230 073**
038 906 051 D	**0 261 230 074**
038 906 051 E	**0 261 230 209**
038 906 051 F	**0 261 230 202**
038 906 051 G	**0 261 230 207**
038 906 051 H	**0 261 230 215**
038 906 051 J	**0 261 230 215**
038 906 461	**0 281 002 463**
038 906 461	**0 281 002 464**
038 906 461	**0 986 284 008**
038 906 461 B	**0 281 002 531**
038 906 461 B	**0 281 002 532**
038 906 461 B	**0 986 284 009**
038 906 461 BX	**0 986 284 009**
038 906 461 C	**0 280 217 121**
038 906 461 C	**0 281 002 757**
038 906 461 C	**0 281 002 758**
038 906 461 C	**0 986 280 202**
038 906 461 D	**0 281 002 768**
038 906 461 D	**0 281 002 769**
038 906 461 D	**0 986 284 011**
038 906 461 DX	**0 986 284 011**
038 906 461 X	**0 986 284 008**
039 906 051	**0 280 100 043**
039 906 051	**0 280 100 044**
039 906 059	**0 332 514 108**
039 906 111 A	**0 280 120 032**
039 906 111 A	**0 280 120 033**
039 906 301	**0 280 200 022**
039 906 301	**0 280 200 023**
040 906 161 4	**0 280 130 039**
043 906 111	**0 280 120 105**
043 906 111	**0 280 120 106**
043 906 301	**0 280 200 006**
043 906 301	**0 280 200 007**
043 906 301	**0 986 280 014**
045 906 461	**0 281 002 318**
045 906 461	**0 281 002 319**
045 906 461	**0 986 284 002**
045 906 461 X	**0 986 284 002**
046 130 385	**0 281 002 018**
046 905 379	**0 280 130 039**
046 905 379	**0 280 130 078**
046 905 379 A	**0 280 130 078**
046 907 475	**0 132 009 316**
046 907 475 A	**0 205 001 001**
046 907 475 B	**0 205 001 001**
046 907 475 D	**0 205 001 007**
046 907 475 E	**0 205 001 013**
046 907 475 F	**0 205 001 017**
046 907 475 G	**0 205 001 018**
047 133 471	**0 438 120 022**
047 133 471 A	**0 438 120 060**

047 133 471 B	**0 438 120 066**
047 133 471 B	**0 438 120 067**
047 133 471 C	**0 438 120 108**
048 133 154	**0 280 120 334**
048 133 154	**0 280 120 335**
048 133 154	**0 280 120 426**
048 133 154	**0 280 120 427**
048 133 471	**0 438 121 087**
048 133 471	**0 438 121 088**
048 133 471	**0 986 439 387**
048 905 161	**0 232 102 006**
048 905 161	**0 232 102 007**
049 133 353 AB	**0 438 121 027**
049 133 353 AB	**0 438 121 028**
049 133 471	**0 438 120 008**
049 133 471 A	**0 438 120 020**
049 133 471 B	**0 438 120 028**
049 133 471 B	**0 438 120 029**
049 133 471 D	**0 438 120 090**
049 133 471 F	**0 438 120 054**
049 133 471 F	**0 438 120 055**
049 133 471 G	**0 438 120 105**
049 133 471 G	**0 438 120 106**
049 133 471 H	**0 438 120 128**
049 133 471 H	**0 438 120 129**
049 133 471 J	**0 438 120 155**
049 133 471 J	**0 438 120 156**
049 133 471 K	**0 438 120 130**
049 133 471 K	**0 438 120 131**
049 133 471 L	**0 438 120 162**
049 133 471 L	**0 438 120 163**
049 133 471 M	**0 438 120 189**
049 133 471 M	**0 438 120 190**
049 133 471 N	**0 438 121 027**
049 133 471 N	**0 438 121 028**
050 906 433 B	**0 261 210 134**
050 906 433 B	**0 261 210 135**
051 133 154 A	**0 280 120 422**
051 133 154 A	**0 280 120 423**
051 133 471	**0 438 121 076**
051 133 471	**0 438 121 077**
051 133 471	**0 986 439 376**
051 133 471 A	**F 026 TX2 059**
051 133 471 A	**0 438 121 089**
051 133 471 A	**0 438 121 090**
051 133 471 A	**0 986 439 389**
051 905 377	**0 261 231 021**
051 905 377 B	**0 261 231 022**
051 905 381	**0 356 914 213**
051 905 381	**0 356 914 214**
053 905 377	**0 261 231 013**
053 905 381	**0 356 914 222**
053 905 381	**0 356 914 223**
053 906 301 1	**0 280 202 126**
053 906 301 4	**0 280 202 136**

V

◀ VW

054 133 154 F	**0 280 120 433**
054 133 154 F	**0 280 120 434**
054 133 471 B	**F 026 TX2 058**
054 133 471 B	**0 438 121 085**
054 133 471 B	**0 438 121 086**
054 133 471 B	**0 986 439 386**
054 133 471 BX	**F 026 TX2 058**
054 905 377	**0 261 231 036**
054 905 377	**0 261 231 037**
054 905 377 A	**0 261 231 038**
054 905 377 A	**0 261 231 039**
054 905 377 G	**0 261 231 036**
054 905 377 G	**0 261 231 037**
054 905 377 H	**0 261 231 037**
054 905 377 H	**0 261 231 038**
054 905 377 H	**0 261 231 039**
057 130 758	**0 281 002 238**
057 130 758	**0 281 002 354**
057 130 758 B	**0 281 002 606**
057 130 758 B	**0 281 002 607**
057 130 767	**0 281 002 406**
057 130 767	**0 281 002 407**
057 906 461	**0 281 002 355**
057 906 461	**0 281 002 356**
057 906 461	**0 986 284 003**
057 906 461 B	**0 281 002 436**
057 906 461 C	**0 281 002 435**
057 906 461 C	**0 281 002 436**
057 906 461 C	**0 986 284 006**
057 906 461 CX	**0 986 284 006**
057 906 461 X	**0 986 284 003**
058 133 063 P	**0 280 750 009**
058 133 063 P	**0 280 750 010**
058 133 471 A	**0 280 217 112**
058 133 471 A	**0 280 217 113**
058 905 161 A	**0 232 101 004**
058 905 161 B	**0 232 101 024**
058 905 161 B	**0 232 101 025**
058 905 161 C	**0 232 101 091**
058 905 279	**0 280 130 086**
058 905 379	**0 280 130 085**
058 905 379	**0 280 130 086**
059 130 758	**0 281 002 504**
059 130 758	**0 281 002 691**
059 906 051	**0 281 002 326**
059 906 051	**0 281 002 327**
059 906 461 A	**0 281 002 224**
059 906 461 A	**0 281 002 225**
059 906 461 B	**0 281 002 403**
059 906 461 B	**0 281 002 404**
059 906 461 B	**0 986 284 004**
059 906 461 BX	**0 986 284 004**
059 906 461 E	**0 281 002 429**
059 906 461 E	**0 281 002 430**
059 906 461 E	**0 986 284 005**

059 906 461 EX	**0 986 284 005**
06A 133 062 AA	**0 280 750 167**
06A 133 062 AA	**0 280 750 168**
06A 133 062 B	**0 280 750 057**
06A 133 062 B	**0 280 750 058**
06A 133 062 D	**0 280 750 061**
06A 133 062 D	**0 280 750 062**
06A 133 062 E	**0 280 750 065**
06A 133 062 E	**0 280 750 066**
06A 133 062 G	**0 280 750 115**
06A 133 062 G	**0 280 750 116**
06A 133 062 J	**0 280 750 099**
06A 133 062 P	**0 280 750 057**
06A 133 062 P	**0 280 750 058**
06A 133 062 Q	**0 280 750 061**
06A 133 062 Q	**0 280 750 062**
06A 133 062 R	**0 280 750 159**
06A 133 062 R	**0 280 750 160**
06A 133 471 X	**0 986 280 206**
06A 905 161	**0 232 101 032**
06A 905 161 A	**0 232 103 019**
06A 905 161 A	**0 232 103 020**
06A 905 161 B	**0 232 101 031**
06A 905 161 B	**0 232 101 032**
06A 905 161 C	**0 232 101 038**
06A 905 161 C	**0 232 101 039**
06A 905 161 D	**0 232 101 094**
06A 905 161 D	**0 232 101 095**
06A 906 433 A	**0 261 210 145**
06A 906 433 A	**0 261 210 146**
06A 906 433 B	**0 261 210 254**
06A 906 433 C	**0 261 210 147**
06A 906 433 C	**0 261 210 148**
06A 906 433 E	**0 261 210 145**
06A 906 433 E	**0 261 210 146**
06A 906 433 F	**0 261 210 165**
06A 906 433 F	**0 261 210 166**
06A 906 433 L	**0 261 210 199**
06A 906 433 L	**0 261 210 200**
06A 906 433 M	**0 261 210 275**
06A 906 433 M	**0 261 210 276**
06A 906 433 N	**0 261 210 254**
06A 906 433 N	**0 261 210 255**
06A 906 461	**0 280 217 121**
06A 906 461	**0 280 217 122**
06A 906 461	**0 281 002 757**
06A 906 461	**0 986 280 202**
06A 906 461	**0 986 280 302**
06A 906 461 A	**0 280 218 002**
06A 906 461 A	**0 280 218 003**
06A 906 461 A	**0 986 280 205**
06A 906 461 A	**0 986 280 305**
06A 906 461 AC	**0 280 218 212**
06A 906 461 AC	**0 280 218 213**
06A 906 461 AX	**0 986 280 205**

06A 906 461 AX	**0 986 280 305**
06A 906 461 C	**0 280 218 023**
06A 906 461 C	**0 280 218 024**
06A 906 461 C	**0 986 280 209**
06A 906 461 C	**0 986 280 309**
06A 906 461 CX	**0 986 280 209**
06A 906 461 CX	**0 986 280 309**
06A 906 461 D	**0 280 218 032**
06A 906 461 D	**0 280 218 033**
06A 906 461 D	**0 986 280 210**
06A 906 461 D	**0 986 280 310**
06A 906 461 DX	**0 986 280 210**
06A 906 461 DX	**0 986 280 310**
06A 906 461 E	**0 280 218 034**
06A 906 461 E	**0 280 218 035**
06A 906 461 E	**0 986 280 211**
06A 906 461 E	**0 986 280 311**
06A 906 461 EX	**0 986 280 211**
06A 906 461 EX	**0 986 280 311**
06A 906 461 G	**0 280 218 060**
06A 906 461 G	**0 280 218 061**
06A 906 461 G	**0 986 280 216**
06A 906 461 G	**0 986 280 316**
06A 906 461 GX	**0 986 280 216**
06A 906 461 GX	**0 986 280 316**
06A 906 461 L	**0 280 218 063**
06A 906 461 L	**0 280 218 064**
06A 906 461 L	**0 986 280 217**
06A 906 461 L	**0 986 280 317**
06A 906 461 LX	**0 986 280 217**
06A 906 461 LX	**0 986 280 317**
06A 906 461 M	**0 280 218 065**
06A 906 461 M	**0 280 218 066**
06A 906 461 M	**0 986 280 218**
06A 906 461 M	**0 986 280 318**
06A 906 461 MX	**0 986 280 218**
06A 906 461 MX	**0 986 280 318**
06A 906 461 N	**0 280 218 100**
06A 906 461 N	**0 280 218 101**
06A 906 461 N	**0 986 280 223**
06A 906 461 N	**0 986 280 323**
06A 906 461 NX	**0 986 280 223**
06A 906 461 NX	**0 986 280 323**
06A 906 461 R	**0 280 218 102**
06A 906 461 R	**0 280 218 103**
06A 906 461 T	**0 280 218 124**
06A 906 461 T	**0 280 218 125**
06A 906 461 X	**0 986 280 202**
06A 906 461 X	**0 986 280 302**
06A 906 473	**0 280 218 193**
06A 906 473	**0 280 218 194**
06A 906 473 A	**0 280 218 195**
06A 906 473 A	**0 280 218 196**
06B 133 062 B	**0 280 750 009**
06B 133 062 B	**0 280 750 010**

06B 133 062 E	**0 280 750 080**
06B 133 062 E	**0 280 750 081**
06B 133 062 H	**0 280 750 088**
06B 133 062 H	**0 280 750 089**
06B 133 062 M	**0 280 750 009**
06B 133 062 M	**0 280 750 010**
06B 133 471	**0 280 218 013**
06B 133 471	**0 280 218 014**
06B 133 471	**0 986 280 206**
06B 133 471	**0 986 280 306**
06B 133 471 A	**0 280 218 058**
06B 133 471 A	**0 280 218 059**
06B 133 471 A	**0 986 280 215**
06B 133 471 A	**0 986 280 315**
06B 133 471 AX	**0 986 280 215**
06B 133 471 AX	**0 986 280 315**
06B 133 471X	**0 986 280 306**
06B 905 377 B	**0 261 231 202**
06B 905 377 B	**0 261 231 203**
06B 905 379	**0 280 130 116**
06B 905 379	**0 280 130 117**
06B 906 051	**0 261 230 031**
06B 906 051	**0 261 230 032**
06B 906 461	**0 280 218 132**
06B 906 461	**0 280 218 133**
06D 133 062	**0 280 750 134**
06D 133 062	**0 280 750 135**
06D 906 051	**0 261 545 008**
06D 906 051	**0 261 545 009**
06D 906 051	**0 261 545 036**
06D 906 051	**0 261 545 037**
06D 906 051 A	**0 261 545 009**
06D 906 051 A	**0 261 545 036**
06D 906 051 A	**0 261 545 037**
06D 906 051 C	**0 261 545 017**
06D 906 051 C	**0 261 545 018**
06H 906 051	**0 261 545 024**
06H 906 051	**0 261 545 025**
06H 906 051 A	**0 261 545 036**
06H 906 051 A	**0 261 545 037**
06J 906 051	**0 261 545 015**
06J 906 051	**0 261 545 016**
06J 906 051 A	**0 261 545 022**
06J 906 051 A	**0 261 545 023**
06J 906 051 B	**0 261 545 035**
063 133 471	**0 438 120 007**
07C 133 062	**0 280 750 107**
07C 133 062	**0 280 750 108**
07C 133 062 A	**0 280 750 157**
07C 133 062 A	**0 280 750 158**
07C 133 062 C	**0 280 750 158**
07C 906 018 H	**0 261 210 047**
07C 906 051	**0 261 230 167**
07C 906 051	**0 261 230 168**
07C 906 461	**0 280 218 071**

V

07C 906 461	**0 280 218 072**
07C 906 461	**0 986 280 221**
07C 906 461	**0 986 280 321**
07C 906 461 A	**0 280 218 143**
07C 906 461 A	**0 280 218 144**
07C 906 461 X	**0 986 280 221**
07C 906 461 X	**0 986 280 321**
07D 906 461	**0 280 218 073**
07D 906 461	**0 280 218 074**
07D 906 461	**0 986 280 222**
07D 906 461	**0 986 280 322**
07D 906 461 X	**0 986 280 222**
07D 906 461 X	**0 986 280 322**
07E 133 062	**0 280 750 177**
07E 133 062	**0 280 750 178**
07Z 906 051	**0 281 002 558**
07Z 906 051	**0 281 002 559**
07Z 906 051 A	**0 281 002 710**
07Z 906 051 A	**0 281 002 711**
07Z 906 051 B	**0 281 002 759**
07Z 906 051 B	**0 281 002 760**
071 906 059	**0 332 514 129**
071 906 059 A	**0 332 514 125**
071 906 301	**0 280 200 025**
071 906 301 A	**0 280 200 028**
071 906 301 A	**0 280 200 029**
071 906 301 B	**0 280 200 030**
071 906 301 B	**0 280 200 031**
071 906 301 C	**0 280 200 032**
071 906 301 C	**0 280 200 033**
071 906 461	**0 280 217 523**
071 906 461	**0 280 217 524**
071 906 461 A	**0 280 217 529**
071 906 461 A	**0 280 217 530**
071 906 461 A	**0 986 280 204**
071 906 461 A	**0 986 280 304**
071 906 461 AX	**0 986 280 204**
071 906 461 AX	**0 986 280 304**
071 906 461 B	**0 280 218 017**
071 906 461 B	**0 280 218 018**
071 906 461 B	**0 986 280 208**
071 906 461 B	**0 986 280 308**
071 906 461 BX	**0 986 280 208**
071 906 461 BX	**0 986 280 308**
071 957 147	**0 261 210 177**
074 906 461 B	**0 281 002 461**
074 906 461 B	**0 281 002 462**
074 906 461 B	**0 986 284 007**
074 906 461 BX	**0 986 284 007**
074 906 461 C	**0 281 002 805**
074 906 461 C	**0 281 002 806**
074 907 475	**0 205 001 030**
077 133 062 C	**0 280 750 127**
077 133 062 C	**0 280 750 128**
077 133 154 A	**0 280 120 408**
077 133 154 B	**0 280 120 424**
077 133 154 B	**0 280 120 425**
077 133 154 D	**0 280 120 428**
077 133 154 D	**0 280 120 429**
077 133 471 C	**0 280 216 001**
077 133 471 C	**0 280 216 002**
077 133 471 D	**0 280 217 804**
077 133 471 D	**0 280 217 805**
077 133 471 E	**0 280 217 813**
077 133 471 E	**0 280 217 817**
077 133 471 G	**0 280 218 015**
077 133 471 G	**0 280 218 016**
077 133 471 G	**0 986 280 207**
077 133 471 G	**0 986 280 307**
077 133 471 GX	**0 986 280 207**
077 133 471 GX	**0 986 280 307**
077 133 471 H	**0 280 218 047**
077 133 471 H	**0 280 218 048**
077 133 471 H	**0 986 280 213**
077 133 471 H	**0 986 280 313**
077 133 471 HX	**0 986 280 213**
077 133 471 HX	**0 986 280 313**
077 133 471 J	**0 280 218 069**
077 133 471 J	**0 280 218 070**
077 133 471 J	**0 986 280 220**
077 133 471 J	**0 986 280 320**
077 133 471 JX	**0 986 280 220**
077 133 471 JX	**0 986 280 320**
077 133 471 K	**0 280 218 067**
077 133 471 K	**0 280 218 068**
077 133 471 K	**0 986 280 219**
077 133 471 K	**0 986 280 319**
077 133 471 KX	**0 986 280 219**
077 133 471 KX	**0 986 280 319**
077 133 471 M	**0 280 218 187**
077 133 471 M	**0 280 218 188**
077 905 375	**0 261 210 271**
077 905 375	**0 261 210 272**
077 905 377	**0 261 231 019**
077 905 377	**0 261 231 020**
077 905 377 A	**0 261 231 005**
077 905 377 A	**0 261 231 040**
077 905 377 A	**0 261 231 041**
077 905 381 C	**0 261 210 143**
077 905 381 D	**0 261 210 111**
077 905 381 D	**0 261 210 112**
077 905 381 E	**0 261 210 143**
077 905 381 E	**0 261 210 144**
077 905 381 F	**0 261 210 190**
077 905 381 F	**0 261 210 191**
077 905 381 G	**0 261 210 192**
077 905 381 G	**0 261 210 193**
077 905 381 H	**0 261 210 243**
077 905 381 H	**0 261 210 244**
077 905 381 J	**0 261 210 245**
077 905 381 J	**0 261 210 246**
077 905 381 K	**0 261 210 261**
077 905 381 K	**0 261 210 262**
077 905 381 L	**0 261 210 264**
077 905 381 L	**0 261 210 265**
077 905 381 N	**0 261 210 299**
077 906 461	**0 280 218 067**
077 906 461	**0 280 218 068**
077 906 461	**0 986 280 319**
077 919 501 B	**0 280 130 095**
077 919 501 B	**0 280 130 096**
077 919 501 C	**0 280 130 098**
077 919 501 C	**0 280 130 099**
078 133 062	**0 280 750 003**
078 133 062	**0 280 750 004**
078 133 062 C	**0 280 750 003**
078 133 062 C	**0 280 750 004**
078 133 154	**0 280 120 431**
078 133 154	**0 280 120 432**
078 905 155	**0 232 101 010**
078 905 155	**0 232 101 011**
078 905 155	**0 232 101 027**
078 905 155	**0 232 101 028**
078 905 161 A	**0 232 101 010**
078 905 161 A	**0 232 101 011**
078 905 161 A	**0 232 101 027**
078 905 161 A	**0 232 101 028**
078 905 161 C	**0 232 101 027**
078 905 161 C	**0 232 101 028**
078 905 379 A	**0 280 130 102**
078 905 379 A	**0 280 130 103**
078 906 051	**0 261 230 023**
078 906 161	**0 280 130 060**
078 906 161	**0 280 130 083**
078 906 433	**0 261 210 139**
078 906 433	**0 261 210 140**
078 906 433 A	**0 281 002 222**
078 906 433 A	**0 281 002 223**
078 906 433 B	**0 261 210 178**
078 906 433 B	**0 261 210 179**
078 906 433 F	**0 261 210 217**
078 906 433 F	**0 261 210 218**
078 906 433 J	**0 261 210 277**
078 906 433 J	**0 261 210 278**
078 906 461	**0 280 217 815**
078 906 461	**0 280 217 816**
078 906 461 B	**0 280 218 038**
078 906 461 B	**0 280 218 039**
078 906 461 B	**0 986 280 212**
078 906 461 B	**0 986 280 312**
078 906 461 BX	**0 986 280 212**
078 906 461 BX	**0 986 280 312**
078 906 461 K	**0 280 218 068**
078 906 461 K	**0 986 280 319**
079 133 471	**0 280 218 214**
079 133 471	**0 280 218 215**
079 905 381	**0 261 210 235**
079 905 381	**0 261 210 236**
1H1 721 568	**0 205 001 014**
1H1 721 568 A	**0 205 001 014**
1H1 721 568 B	**0 205 001 034**
1H1 721 568 N	**0 205 001 014**
1H1 723 568	**0 205 001 022**
1H1 723 568 A	**0 205 001 022**
1H1 723 568 A	**0 205 001 033**
1H2 721 727	**0 205 001 025**
1H2 721 727 A	**0 205 001 035**
1H2 723 727	**0 205 001 026**
1H2 723 727 A	**0 205 001 036**
1JD 906 433	**0 261 210 241**
1JD 906 433	**0 261 210 242**
1JD 906 433 A	**0 261 210 288**
1JD 906 433 A	**0 261 210 289**
1JD 906 461	**0 280 218 060**
1JD 906 461	**0 280 218 061**
1JD 906 461	**0 986 280 216**
1JD 906 461	**0 986 280 316**
1J0 919 275	**0 263 003 169**
1J0 919 275 A	**0 263 003 189**
1J0 919 275 B	**0 263 003 218**
1J1 721 503 AB	**0 281 002 342**
1J1 721 503 AC	**0 280 752 201**
1J1 721 503 B	**0 281 002 342**
1J1 721 503 H	**0 281 002 342**
1J1 721 503 K	**0 281 002 342**
1J1 721 503 L	**0 280 752 201**
1J1 721 503 M	**0 281 002 341**
1J1 721 503 M	**0 281 002 342**
1J1 721 503 N	**0 280 752 201**
1J1 721 503 Q	**0 280 752 203**
1J1 721 727	**0 205 001 043**
1J1 721 727 A	**0 281 002 219**
1J1 721 727 B	**0 281 002 269**
1J1 721 727 D	**0 281 002 269**
1J1 723 503 AA	**0 280 752 203**
1J1 723 503 AF	**0 281 002 344**
1J1 723 503 AG	**0 280 752 203**
1J1 723 503 AK	**0 281 002 344**
1J1 723 503 AL	**0 280 752 203**
1J1 723 503 M	**0 281 002 343**
1J1 723 503 M	**0 281 002 344**
1J1 723 503 N	**0 280 752 203**
1J1 723 503 Q	**0 280 752 203**
1J1 723 503 R	**0 281 002 344**
1J1 723 503 T	**0 281 002 344**
1J1 723 727	**0 205 001 045**
1J1 723 727 A	**0 205 001 045**
1J1 723 727 A	**0 281 002 220**
1J1 723 727 B	**0 281 002 266**
1J1 907 469	**0 281 002 193**

V

◀ VW

1J1 907 469 A	**0 281 002 194**
1J2 721 503	**0 281 002 345**
1J2 721 503	**0 281 002 346**
1J2 721 503 A	**0 280 752 210**
1J2 721 503 A	**0 280 752 211**
1J2 721 503 B	**0 281 002 346**
1J2 721 503 C	**0 280 752 210**
1J2 721 503 C	**0 280 752 211**
1J2 721 503 H	**0 281 002 346**
1J2 721 503 J	**0 280 752 210**
1J2 721 503 J	**0 280 752 211**
1J2 721 503K	**0 280 752 275**
1J2 721 503K	**0 280 752 276**
1J2 721 503 L	**0 280 752 266**
1J2 721 503 M	**0 281 002 622**
1J2 721 568 B	**0 205 001 051**
1J2 721 568 C	**0 205 001 050**
1J2 721 568 D	**0 205 001 051**
1J2 721 568 D	**0 281 002 230**
1J2 721 568 E	**0 281 002 267**
1J2 721 568 F	**0 280 752 012**
1J2 721 568 F	**0 280 752 013**
1J2 721 568 G	**0 281 002 267**
1J2 723 503	**0 281 002 347**
1J2 723 503	**0 281 002 348**
1J2 723 503 A	**0 280 752 213**
1J2 723 503 B	**0 281 002 348**
1J2 723 503 C	**0 280 752 213**
1J2 723 503 D	**0 281 002 348**
1J2 723 503 E	**0 280 752 213**
1J2 723 503 H	**0 281 002 348**
1J2 723 503 J	**0 280 752 213**
1J2 723 503 K	**0 281 002 348**
1J2 723 503 L	**0 280 752 213**
1J2 723 568 B	**0 205 001 050**
1J2 723 568 C	**0 205 001 051**
1J2 723 568 D	**0 205 001 050**
1J2 723 568 D	**0 281 002 231**
1J2 723 568 E	**0 281 002 268**
1J2 723 568 F	**0 280 752 014**
1J2 723 568 F	**0 280 752 015**
1J2 723 568 G	**0 281 002 268**
1K0 906 207 A	**0 261 230 169**
1K0 906 207 A	**0 261 230 170**
1K0 955 549 R	**1 397 212 082**
1K0 955 559	**1 397 212 059**
1K0 955 559 AA	**1 397 212 114**
1K0 955 559 AB	**1 397 212 129**
1K0 955 559 AD	**1 397 212 114**
1K0 955 559 AE	**1 397 212 114**
1K0 955 559 AE	**1 397 212 129**
1K0 955 559 H	**1 397 212 080**
1K0 955 559 K	**1 397 212 059**
1K0 955 559 L	**1 397 212 081**
1K0 955 559 M	**1 397 212 089**
1K0 955 559 N	**1 397 212 090**
1K0 955 559 O	**1 397 212 100**
1K0 955 559 P	**1 397 212 099**
1K0 955 559 Q	**1 397 212 100**
1K0 955 559 R	**1 397 212 082**
1K0 955 559 S	**1 397 212 102**
1K0 955 559 T	**1 397 212 115**
1U0 919 275	**0 263 003 187**
2D0 907 469	**0 205 001 030**
2D0 927 807	**0 265 004 009**
2D0 927 807 A	**0 265 004 010**
2D0 927 808	**0 265 004 008**
2D0 927 808 A	**0 265 004 010**
2D0 963 141	**0 332 015 011**
2E0 721 507 B	**0 280 755 025**
2E0 721 507 C	**0 280 755 023**
2E0 906 461	**0 281 002 586**
2E0 906 461 C	**0 281 002 897**
2E0 907 637	**0 265 005 628**
2E0 927 748 B	**0 265 007 661**
2E0 927 748 C	**0 265 007 662**
2E0 927 748 F	**0 265 007 880**
2E0 927 748 G	**0 265 007 881**
2E0 927 801	**0 265 007 659**
2E0 927 801 A	**0 265 007 660**
2E0 927 801 B	**0 265 007 657**
2E0 927 801 B	**0 265 007 661**
2K0 906 052	**0 261 545 020**
2K0 906 052	**0 261 545 021**
2P0 133 491	**0 281 002 667**
2P0 906 051	**0 281 002 514**
2R0 906 051 C	**0 281 002 437**
2R0 906 433	**0 281 002 410**
2R0 906 433 C	**0 281 002 411**
2R0 906 433 D	**0 281 002 214**
2R0 919 081 D	**0 281 002 472**
2R0 919 501	**0 281 002 316**
2R0 919 501 A	**0 281 002 471**
2R0 919 501 B	**0 281 002 209**
2S0 906 051	**0 281 002 576**
2T2 906 051 B	**0 281 002 851**
2T2 919 333	**0 281 002 534**
20103332	**0 263 003 683**
20103758	**0 263 003 685**
20103759	**0 263 003 725**
237 906 311 1	**0 261 230 004**
237 906 311 1	**0 261 230 008**
251 907 388	**0 265 005 009**
251 927 807	**0 265 001 148**
251 927 807	**0 265 001 149**
251 927 807 A	**0 265 001 150**
251 927 807 B	**0 265 001 195**
251 927 807 B	**0 265 001 196**
251 927 807 D	**0 265 001 195**
251 927 808	**0 265 001 197**
251 927 808	**0 265 001 198**
261 230 138	**0 261 230 138**
270 600 001	**0 261 230 020**
281 927 807	**0 265 003 097**
281 927 807 A	**0 265 001 330**
281 927 807 B	**0 265 003 141**
291 927 807	**0 265 003 098**
3A0 906 051	**0 261 230 007**
3A0 906 051	**0 261 230 008**
3A0 906 051	**0 261 230 037**
3A1 721 568 B	**0 205 001 037**
3A1 723 568	**0 205 001 027**
3A1 723 568 A	**0 205 001 038**
3B0 927 807 G	**0 265 006 572**
3B0 927 807 G	**0 265 006 573**
3B0 927 807 H	**0 265 006 574**
3B0 927 807 H	**0 265 006 575**
3B0 955 559	**1 397 212 014**
3B0 955 559	**1 397 212 028**
3B0 955 559	**1 397 212 029**
3B0 955 559	**1 397 212 038**
3B0 955 559 A	**1 397 212 012**
3B0 955 559 B	**1 397 212 091**
3B0 955 559 C	**1 397 212 098**
3D0 919 275 B	**0 263 003 224**
3D0 919 275 B	**0 263 003 244**
3D0 919 275 B	**0 263 003 552**
3D0 919 275 C	**0 263 003 526**
3D0 919 275 D	**0 263 003 525**
3D0 927 804	**0 265 007 409**
3D0 927 807	**0 265 007 409**
3D0 955 559	**1 397 212 032**
3D0 955 559 A	**1 397 212 038**
3D0 955 559 B	**1 397 212 093**
3D0 955 559 C	**1 397 212 092**
3W0 955 559	**1 397 212 078**
3W0 955 559 A	**1 397 212 078**
3W0 955 559 A	**1 397 212 085**
3W0 955 559 B	**1 397 212 120**
3W5 955 559 C	**1 397 212 121**
3W5 955 559 D	**1 397 212 122**
3W5 955 559 E	**1 397 212 123**
3W5 955 559 F	**1 397 212 130**
3W5 955 559 G	**1 397 212 131**
305 906 059 1	**0 280 230 016**
311 906 041 A	**0 280 130 003**
311 906 041 A	**0 280 130 004**
311 906 051 B	**0 280 100 001**
311 906 051 C	**0 280 100 007**
311 906 051 D	**0 280 100 101**
311 906 051 E	**0 280 100 106**
311 906 051 E	**0 280 100 116**
311 906 061	**0 332 003 021**
311 906 061	**0 332 003 022**
311 906 081	**0 280 130 001**
311 906 081 B	**0 280 130 015**
311 906 111 B	**0 280 120 001**
311 906 111 B	**0 280 120 002**
311 906 111 C	**0 280 120 040**
311 906 111 C	**0 280 120 041**
311 906 111 D	**0 280 120 019**
311 906 111 D	**0 280 120 020**
311 906 111 E	**0 280 120 024**
311 906 111 E	**0 280 120 025**
325 927 807 3	**0 265 006 220**
325 927 807 4	**0 265 006 219**
33D 906 461	**0 280 218 204**
331 927 807	**0 265 001 107**
331 927 807 A	**0 265 001 105**
347 927 803 A	**0 265 001 007**
357 721 568	**0 205 001 012**
357 721 568 A	**0 205 001 012**
376 927 807	**0 265 006 642**
376 927 807	**0 265 006 643**
376 927 807 A	**0 265 006 644**
376 927 807 A	**0 265 006 645**
377 906 051	**0 261 230 037**
377 906 051	**0 261 230 038**
377 906 461	**0 280 218 053**
377 927 807	**0 265 006 218**
377 927 807 B	**0 265 006 222**
377 927 807 C	**0 265 006 221**
377 927 807 D	**0 265 006 410**
377 927 807 F	**0 265 006 411**
4A0 133 471	**0 281 002 074**
4A0 133 471	**0 281 002 075**
4A0 133 471	**0 986 280 089**
4B0 907 637	**0 265 005 214**
4B0 907 637 A	**0 265 005 213**
4B0 907 637 A	**0 265 005 214**
4B0 927 803 B	**0 265 006 577**
4B0 927 803 B	**0 265 006 578**
4B0 927 803 E	**0 265 006 764**
4B0 927 803 E	**0 265 006 765**
4B0 927 803 F	**0 265 006 654**
4B0 927 803 F	**0 265 006 655**
4B0 927 807 E	**0 265 006 564**
4B0 927 807 E	**0 265 006 565**
4B0 927 807 F	**0 265 006 566**
4B0 927 807 F	**0 265 006 567**
4B0 927 807 J	**0 265 006 564**
4B0 927 807 J	**0 265 006 565**
4B0 927 807 J	**0 265 006 583**
4B0 927 807 J	**0 265 006 584**
4B0 927 807 K	**0 265 006 566**
4B0 927 807 K	**0 265 006 567**
4B0 927 807 K	**0 265 006 585**
4B0 927 807 K	**0 265 006 586**
4B0 927 807 M	**0 265 006 663**
4B0 927 807 M	**0 265 006 664**

V

4B0 927 807 N	**0 265 006 764**
4B0 927 807 N	**0 265 006 766**
4B0 927 807 N	**0 265 006 767**
4B0 927 807 P	**0 265 006 768**
4B0 927 807 P	**0 265 006 769**
4B0 927 807 Q	**0 265 006 760**
4B0 927 807 Q	**0 265 006 761**
4B0 927 807 R	**0 265 006 762**
4B0 927 807 R	**0 265 006 763**
4B0 927 807 S	**0 265 006 770**
4B0 927 807 S	**0 265 006 771**
4D0 907 571	**0 265 005 401**
4D0 907 657	**0 265 005 206**
4D0 907 657	**0 265 005 207**
4D0 927 803 B	**0 265 006 579**
4D0 927 803 B	**0 265 006 580**
4D0 927 803 C	**0 265 006 579**
4D0 927 803 C	**0 265 006 580**
4D0 927 803 D	**0 265 006 579**
4D0 927 803 D	**0 265 006 580**
4D0 927 803 E	**0 265 006 661**
4D0 927 803 E	**0 265 006 662**
4D0 927 807 B	**0 265 006 587**
4D0 927 807 B	**0 265 006 588**
4E0 927 803	**0 265 007 407**
4E0 927 803	**0 265 007 408**
4E0 927 803	**0 265 007 727**
4E0 927 803	**0 265 007 728**
4E0 927 803 A	**0 265 007 407**
4E0 927 803 A	**0 265 007 727**
4E0 927 803 A	**0 265 007 728**
4E0 927 803 D	**0 265 007 929**
4E0 927 803 D	**0 265 007 930**
4E0 927 804	**0 265 007 405**
4E0 927 804	**0 265 007 406**
4E0 927 804 A	**0 265 007 405**
4E0 927 804 A	**0 265 007 725**
4E0 927 804 A	**0 265 007 726**
4E0 927 804 D	**0 265 007 927**
4E0 927 804 D	**0 265 007 928**
4E5 927 807	**0 265 007 729**
4F0 907 637	**0 265 005 278**
4F0 907 637	**0 265 005 601**
4Z0 927 803 B	**0 265 006 772**
4Z0 927 803 B	**0 265 006 773**
4Z7 927 803 A	**0 265 006 652**
4Z7 927 803 B	**0 265 006 772**
4Z7 927 807 C	**0 265 006 654**
4Z7 927 807 C	**0 265 006 655**
4Z7 927 807 E	**0 265 006 656**
4Z7 927 807 E	**0 265 006 657**
4Z7 927 807 F	**0 265 006 780**
4Z7 927 807 F	**0 265 006 781**
4Z7 927 807 G	**0 265 006 782**
4Z7 927 807 G	**0 265 006 783**

411 906 271	**0 335 530 004**
437 927 803 B	**0 265 001 047**
437 927 803 B	**0 265 001 048**
437 927 803 H	**0 265 001 007**
443 907 388	**0 265 005 007**
443 927 803	**0 265 001 042**
443 927 803 A	**0 265 001 039**
443 927 803 A	**0 265 001 040**
443 927 803 B	**0 265 004 001**
443 927 807	**0 265 001 041**
443 927 807	**0 265 001 042**
443 927 807 A	**0 265 001 060**
443 927 807 A	**0 265 001 061**
443 927 807 B	**0 265 001 088**
443 927 807 B	**0 265 001 089**
443 927 807 C	**0 265 001 120**
473 906 301	**0 280 201 002**
539 063 015	**0 280 202 137**
539 906 301 5	**0 280 202 137**
6K2 721 727 A	**0 280 752 025**
6K2 721 727 B	**0 281 002 338**
6N1 721 503 B	**0 281 002 321**
6N1 721 503 B	**0 281 002 322**
6N1 721 503 D	**0 281 002 322**
6N1 721 503 F	**0 261 002 322**
6N1 721 503 F	**0 280 752 206**
6N1 721 503 F	**0 280 752 207**
6N1 721 503 F B41	**0 281 002 322**
6N1 721 503 G	**0 280 752 206**
6N1 721 503 G	**0 280 752 207**
6N1 723 503	**0 281 002 324**
6N1 723 503 B	**0 281 002 323**
6N1 723 503 B	**0 281 002 324**
6N1 723 503 F	**0 281 002 324**
6N1 723 503 G	**0 280 752 209**
6N1 723 503 H	**0 281 002 324**
6N1 723 503 J	**0 280 752 209**
6N1 723 503 K	**0 281 002 324**
6N1 723 503 L	**0 280 752 209**
6N1 723 503 M	**0 281 002 324**
6N1 723 503 N	**0 280 752 209**
6Q0 907 637 A	**0 265 005 691**
6Q0 907 637 A	**0 265 005 692**
6Q1 721 503	**0 281 002 377**
6Q1 721 503	**0 281 002 378**
6Q1 721 503 A	**0 280 752 214**
6Q1 721 503 A	**0 280 752 215**
6Q1 721 503 D	**0 281 002 378**
6Q1 721 503 E	**0 280 752 214**
6Q1 721 503 E	**0 280 752 215**
6Q1 721 503 F	**0 280 755 063**
6Q1 721 503 H	**0 280 755 055**
6Q1 723 503	**0 281 002 371**
6Q1 723 503	**0 281 002 372**
6Q1 723 503 B	**0 281 002 372**

6Q1 723 503 C	**0 280 752 217**
6Q1 723 503 E	**0 280 752 214**
6Q1 723 503 F	**0 281 002 372**
6Q1 723 503 G	**0 280 752 217**
6Q1 723 503 H	**0 281 002 372**
6Q1 723 503 J	**0 280 752 217**
6Q1 723 503 K	**0 280 755 064**
6Q1 723 503 K	**0 280 755 065**
6Q1 723 503 L	**0 280 755 057**
6Q2 721 503	**0 281 002 374**
6Q2 721 503 B	**0 281 002 374**
6Q2 721 503 C	**0 280 752 219**
6Q2 721 503 E	**0 280 755 066**
6Q2 721 503 E	**0 280 755 067**
6Q2 721 503 F	**0 281 002 374**
6Q2 721 503 G	**0 280 752 219**
6Q2 721 503 H	**0 280 755 058**
6Q2 721 503 H	**0 280 755 059**
6Q2 723 503	**0 281 002 375**
6Q2 723 503	**0 281 002 376**
6Q2 723 503 B	**0 281 002 376**
6Q2 723 503 C	**0 280 752 221**
6Q2 723 503 D	**0 281 002 376**
6Q2 723 503 E	**0 280 752 221**
6Q2 723 503 F	**0 281 002 376**
6Q2 723 503 G	**0 280 752 220**
6Q2 723 503 G	**0 280 752 221**
6Q2 723 503 H	**0 280 755 068**
6Q2 723 503 H	**0 280 755 069**
6Q2 723 503 J	**0 280 755 061**
6U0 919 501	**0 280 130 026**
6W0 906 081	**0 280 130 073**
672 046	**1 237 031 296**
7D0 721 727	**0 205 001 020**
7D0 723 727	**0 205 001 052**
7D0 927 807	**0 265 006 507**
7D0 927 807	**0 265 006 508**
7D0 927 808	**0 265 006 509**
7D0 927 808	**0 265 006 510**
7L0 955 559	**1 397 212 031**
7L0 955 559 A	**1 397 212 028**
7L0 955 559 B	**1 397 212 030**
7L0 955 559 B	**1 397 212 032**
7L0 955 559 C	**1 397 212 027**
7L0 955 559 C	**1 397 212 028**
7L0 955 559 C	**1 397 212 029**
7L0 955 559 D	**1 397 212 097**
7L0 955 559 E	**1 397 212 095**
7L0 955 559 F	**1 397 212 096**
7L0 955 559 G	**1 397 212 094**
7L5 905 381	**0 261 210 239**
7L5 905 381 A	**0 261 210 292**
7L5 906 461 A	**0 280 218 141**
7L5 906 461 B	**0 280 218 198**
7L5 919 041	**0 263 003 487**

7L5 919 275	**0 263 003 487**
7L5 919 275	**0 263 003 492**
7L5 919 275	**0 263 003 685**
7L5 919 275	**0 263 003 725**
7L5 919 275 A7W	**0 263 003 490**
7L5 919 275 C9Z	**0 263 003 491**
7L5 919 275 D5Q	**0 263 003 488**
7L5 919 275 M1W	**0 263 003 495**
7L5 919 275 M3W	**0 263 003 494**
7L5 919 275 M6U	**0 263 003 496**
7L5 919 275 M6X	**0 263 003 493**
7L5 919 275 R9A	**0 263 003 489**
7L6 919 275	**0 263 003 577**
7M0 907 469	**0 205 001 041**
701 721 727	**0 205 001 020**
701 721 727 A	**0 205 001 020**
701 723 727 A	**0 205 001 052**
701 927 807	**0 265 003 077**
701 927 807	**0 265 003 107**
701 927 807 A	**0 265 003 076**
701 927 807 A	**0 265 006 301**
701 927 807 A	**0 265 006 407**
701 927 807 C	**0 265 003 107**
701 927 807 D	**0 265 006 303**
701 927 807 D	**0 265 006 409**
701 927 807 E	**0 265 006 304**
701 927 807 E	**0 265 006 408**
701 927 807 F	**0 265 006 301**
701 927 807 F	**0 265 006 407**
8A0 143 71Y	**0 204 154 035**
8A0 243 71Y	**0 204 154 036**
8D0 927 807 F	**0 265 006 568**
8D0 927 807 F	**0 265 006 569**
8D0 927 807 G	**0 265 006 570**
8D0 927 807 G	**0 265 006 571**
8D0 927 807 H	**0 265 006 692**
8D0 927 807 H	**0 265 006 693**
8D0 927 807 J	**0 265 006 694**
8D0 927 807 J	**0 265 006 695**
8E0 907 597	**0 265 005 303**
8E0 907 637 A	**0 265 005 245**
8E0 907 637 A	**0 265 005 252**
8E0 907 637 B	**0 265 005 618**
8E0 907 637 B	**0 265 005 619**
8E0 907 637 B	**0 265 007 618**
8E0 907 637 C	**0 265 005 620**
8E0 907 637 C	**0 265 005 621**
8E0 907 637 C	**0 265 007 620**
8E0 907 637 C	**0 265 007 853**
8E0 927 803	**0 265 006 682**
8E0 927 803 A	**0 265 006 682**
8E0 927 803 A	**0 265 006 683**
8E0 927 803 B	**0 265 006 808**
8E0 927 803 B	**0 265 006 809**
8E0 927 807 B	**0 265 006 680**

V

◀ VW

8E0 927 807 B	**0 265 006 681**
8E0 927 807 C	**0 265 006 706**
8E0 927 807 C	**0 265 006 707**
8E0 927 807 E	**0 265 006 825**
8E0 927 807 E	**0 265 006 826**
8E0 927 807 F	**0 265 006 827**
8E0 927 807 F	**0 265 006 828**
8E0 927 807 G	**0 265 006 823**
8E0 927 807 G	**0 265 006 824**
8K0 907 637 A	**0 265 005 667**
8K0 907 637 A	**0 265 005 668**
8K0 907 637 B	**0 265 005 669**
8K0 907 637 B	**0 265 005 670**
8K0 907 637 C	**0 265 005 738**
8N2 721 503	**0 280 752 233**
8N2 721 503	**0 280 752 234**
8N2 721 503 A	**0 280 752 233**
8N2 721 503 A	**0 280 752 234**
8N2 721 503 C	**0 280 752 233**
8N2 721 503 C	**0 280 752 234**
8N2 721 503 D	**0 280 752 233**
8N2 721 503 D	**0 280 752 234**
8N2 723 503 A	**0 280 752 233**
8N2 723 503 A	**0 280 752 234**
8N2 723 503 B	**0 280 752 255**
8N2 723 503 B	**0 280 752 256**
8Z0 906 461	**0 281 002 610**
8Z0 906 461	**0 281 002 611**
8Z0 959 643	**0 285 002 071**
800 000 140	**0 281 002 477**
811 927 807	**0 265 001 099**
811 927 807	**0 265 001 100**
853 919 562	**0 280 101 001**
853 919 562	**0 280 101 002**
853 919 562 A	**0 280 101 010**
853 919 562 A	**0 280 101 011**
857 927 807 A	**0 265 001 062**
857 927 807 A	**0 265 001 063**
859 907 388	**0 265 005 001**
859 907 388	**0 265 005 002**
859 927 807	**0 265 001 083**
859 927 808	**0 265 001 082**
893 927 807	**0 265 001 182**
893 927 807	**0 265 001 183**
893 927 807 B	**0 265 001 180**
893 927 807 B	**0 265 001 181**

ZASTAVA (YUGO)

466 427 71	**0 261 230 025**

Notizen – notes